

AIM: Manage simulated engine failures and circuit abnormalities with correct decisions and procedures.

DP RTO: 3-step – throttle, brakes + elevator, directional control; **max 2 RTOs then 15 min brake cooldown** ☐

DP EFATO: Nose down, throttle closed, land ahead; **no turn-back**; student patters landing area selection ☐

DP EFIC downwind: Glide attitude; one-third aim point; turn towards final immediately; student practices ☐

DP Sideslip on final: Demo entry, hold, exit; student practices on normal final at safe height ☐

P EFIC from base: Student assesses glide; configures; sideslip or field ☐

P Flapless circuit: Vapp +5 kt; attitude higher; shallower angle; longer rollout; instructor patters while student performs on first attempt ☐

P Low level circuit: 500 ft AGL – deteriorating weather scenario ☐

P Partial power failure: Instructor reduces without announcement; student takes appropriate action ☐

P Occupied runway: Go-around immediately without prompting ☐

P Normal circuits with landings: Interspersed throughout ☐

COMMON ERRORS

- **Large turn after EFATO** -> Land ahead – **non-negotiable**
- **Not lowering nose** -> Attitude first – nose down, throttle closed
- **Delayed EFIC** -> Plan must exist before the emergency
- **Sideslip too low** -> Never below 100 ft without runway assured

STANDARDS FOR PROGRESSION

P S **Two separate flights at S standard required before solo authorisation**
Solo (S): EFATO – nose down, land ahead within 3 s; EFIC correct at every position; flapless ± 200 m; sideslip correct; occupied runway go-around without prompting; RTO within 2 s

C NC

⚠ SAFETY All sims briefed; student confirms. **Never simulate EFATO in a way that endangers aircraft**. Low-level EFATO (below 300 ft): only permitted if initiated from a go-around before landing threshold - prohibited RWY 36. Sideslip: never below 100 ft without runway assured. student's hand on throttle at all times