



AIM: Execute the ABCDEF sequence and FLWOP circuit from memory. Conduct a precautionary search.

P **Departure/transit:** Student as PIC; *scan for landing fields throughout every transit from this lesson onward* ☐

D **ABCDEF demo:** Instructor calls “engine failure”; works through full sequence aloud – A, B, C, D, E, F; FLWOP circuit to high-key then low-key; sideslip if high; go-around at 500 ft ☐

P **ABCDEF – first 1-2 attempts:** Instructor assists recall if needed; student works through sequence ☐

P **ABCDEF – subsequent attempts:** From memory; go-around at 500 ft – *never below* ☐

P **Precautionary search:** Student selects field; two inspection passes (1000 ft, 500 ft AGL); states landing/reject decision aloud with reasoning ☐

P **Return:** Student as PIC; join; land independently ☐

ABCDEF QUICK REFERENCE

- **A – Attitude:** Best glide; trim – **first and most time-critical**
- **B – Best Field:** 6-S; aim point at **one-third**; high-key; low-key
- **C – Checks (FAST):** Fuel; Air; Switches; Throttle – after A and B only
- **D – Declare:** MAYDAY – callsign, position, problem, plan, POB; Centre preferred
- **E – Explain:** Pax brief; seatbelt tight; brace; reassure
- **F – Final:** All switches off; **flap before master if electric flaps**

COMMON ERRORS

- **Delayed attitude** -> A is first; every second costs height
- **Checks before A and B** -> FAST only after field chosen and glide established
- **MAYDAY on CTAF** -> Centre first; CTAF if Centre not established
- **Too high on glide** -> Correct early

STANDARDS FOR PROGRESSION

P **S** **Two separate flights at S required before area solo.**

Solo (S): A within 5 s; ABCDEF from memory; MAYDAY correct; low-key 1000 ft; field made with margin; PSL heights correct

C **NC**

⚠ SAFETY Training go-around height **minimum 500 ft AGL** – specified before flight; **never breach**. **Do not operate such that a real engine failure would endanger the aircraft**. PSL 300 ft pass: aerodrome only