3 Introductory projects

New instructions used in this chapter:

- MOVLW
- MOVWF
- DECFSZ

Let's have a look at a few variations of flashing the LEDs on and off to develop our programming skills.

LED Flasher2

Suppose we want to switch the LED on for 2 seconds and off for 1 second. Figure 2.1 shows the circuit diagram for this application. The code for this would be:

:Program starts now.

, 6			
BEGIN	BSF	PORTB,0	;Turn on B0
	CALL	DELAY1	;Wait 1 second
	CALL	DELAY1	;Wait 1 second
	BCF	PORTB,0	;Turn off B0
	CALL	DELAY1	;Wait 1 second
	GOTO	BEGIN	;Repeat

END

NB. This code would be added to HEADER84.ASM into the section called, "Program starts now".

To do this open MPLAB, then FILE - OPEN - HEADER84.ASM

Add the code and saveas LED FLASHER2.ASM

The text would then be assembled by the MPLAB software and then blown into the Microcontroller as explained in Chapter 2.

How does it work?

The comments alongside the code explain what the lines are doing. Because we do not have a 2 second delay we wait for 1 second twice. You can of course write a 2 second delay routine but we will be looking at this later.

SOS

For our next example let us switch B0 on and off just as we have been doing but this time we will use delays of ½ second and ½ second. This is not much different than we have done previously, but instead of turning an LED on and off we will replace it by a buzzer. The program is not just going to turn a buzzer on and off, but do it in a way that generates the signal, SOS. Which is DOT, DOT, DOT DASH, DASH, DASH DOT, DOT. Where the DOT is the buzzer on for 1/4 second and the DASH is the buzzer on for $\frac{1}{2}$ second with $\frac{1}{4}$ second between the beeps.

The circuit diagram for the SOS circuit is shown in Figure 3.1.




Figure 3.1 SOS circuit diagram

Code for SOS circuit

The complete code for the SOS circuit is shown below because an extra subroutine, DELAYP25, has been added.

;SOS.ASM for 16F84. This sets PORTA as an INPUT (NB 1means input) and PORTB as an OUTPUT (NB 0 means output).

;The OPTION Register is set to /256 to give timing pulses of 1/32 of a second. ;1second, 0.5 second and 0.25 second delays are included in the subroutine :section.

;EQUATES SECTION TMR₀ **EOU** 1 means TMR0 is file 1. **EQU** 3 **STATUS** :means STATUS is file 3. **EOU** 5 means PORTA is file 5. **PORTA EOU** 6 :means PORTB is file 6. **PORTB** :TRISA (the PORTA I/O selection) is file 85H **TRISA** EQU 85H TRISB EQU 86H ;TRISB (the PORTB I/O selection) is file 86H OPTION R EOU 81H ;the OPTION register is file 81H **ZEROBIT EOU** :means ZEROBIT is bit 2. :COUNT is file 0C, a register to count events. COUNT **EQU** 0CH ************** LIST P = 16F84;we are using the 16F84. ;the start address in memory is 0 ORG **GOTO START** :goto start! ;Configuration Bits ;selects LP oscillator, WDT off, PUT on, CONFIG H'3FF0' :Code Protection disabled. ********** SUBROUTINE SECTION ;1 second delay. DELAY1 **CLRF** TMR0 :START TMR0. **LOOPA** MOVF TMR₀,W :READ TMR0 INTO W. **SUBLW** .32 :TIME - 32 STATUS, **BTFSS** :Check TIME-W = 0ZEROBIT **GOTO LOOPA** :Time is not = 32. RETLW 0 ;Time is 32, return. ;0.5 second delay. **DELAYP5 CLRF** TMR0 :START TMR0. LOOPB MOVF TMR0,W ;READ TMR0 INTO W. **SUBLW** .16 ;TIME - 16 **BTFSS** STATUS, **ZEROBIT** ;Check TIME-W = 0**GOTO LOOPB** :Time is not = 16.

RETLW

0

:Time is 16, return.

CALL

BSF

CALL

.0.25	L dalar.		
;0.25 second	•	TMDO	CTART TMR
DELAYP25		TMR0	;START TMR0.
LOOPC	MOVF	TMR0,W	;READ TMR0 INTO W.
	SUBLW	.8	;TIME - 8
	BTFSS	STATUS,	Clarate TIME W
	СОТО	ZEROBIT	;Check TIME-W = 0
	GOTO	LOOPC	; Time is not $= 8$.
	RETLW	0	;Time is 8, return.
·**********	******	******	*******
;CONFIGU	RATION SEC	TION	
START	BSF	STATUS,5	;Turns to Bank1.
	MOVLW	B'00011111'	;5bits of PORTA are I/P
	MOVWF	TRISA	
	MOVLW	B'00000000'	
	MOVWF	TRISB	;PORTB is OUTPUT
	MOVLW	B'00000111'	;Prescaler is /256
	MOVWF	OPTION R	;TIMER is 1/32 secs.
		_	,
	BCF	STATUS,5	;Return to Bank0.
	CLRF	PORTA	;Clears PortA.
	CLRF	PORTB	;Clears PortB.
.******** '	******	******	*******
;Program st	arts now.		
BEGIN	BSF	PORTB,0	;Turn ON B0, DOT
	CALL	DELAYP25	;Wait 0.25 seconds
	BCF	PORTB,0	Turn OFF B0.
	CALL	DELAYP25	;Wait 0.25 seconds
	BSF	PORTB,0	Turn ON B0, DOT
	CALL	DELAYP25	;Wait 0.25 seconds
	BCF	PORTB,0	Turn OFF B0.
	CALL	DELAYP25	;Wait 0.25 seconds
	BSF	PORTB,0	;Turn ON B0, DOT
	CALL	DELAYP25	;Wait 0.25 seconds
	BCF	PORTB,0	;Turn OFF B0.
	CATT	DELAMBS	**** 1: 0.5

DELAYP5

PORTB,0

DELAYP5

;Wait 0.5 seconds

;Turn ON B0, DASH ;Wait 0.5 seconds

BCF	PORTB,0	;Turn OFF B0.
CALL	DELAYP25	;Wait 0.25 seconds
BSF	PORTB,0	;Turn ON B0, DASH
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,0	;Turn OFF B0.
CALL	DELAYP25	;Wait 0.25 seconds
BSF		
_ ~ -	PORTB,0	;Turn ON B0, DASH
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,0	;Turn OFF B0.
CALL	DELAYP5	;Wait 0.5 seconds
BSF	PORTB,0	;Turn ON B0, DOT
CALL	DELAYP25	;Wait 0.25 seconds
BCF	PORTB,0	;Turn OFF B0.
CALL	DELAYP25	;Wait 0.25 seconds
BSF	PORTB,0	;Turn ON B0, DOT
CALL	DELAYP25	;Wait 0.25 seconds
BCF	PORTB,0	;Turn OFF B0.
CALL	DELAYP25	;Wait 0.25 seconds
BSF	PORTB,0	;Turn ON B0, DOT
CALL	DELAYP25	;Wait 0.25 seconds
BCF	PORTB,0	;Turn OFF B0.
CALL	DELAYP5	:Wait 0.5 seconds
CITEE	BEERTITO	, water our records
CALL	DELAY1	
CALL	DELAY1	;Wait 2 seconds before returning.
GOTO	BEGIN	;Repeat
3310	DEGII	;YOU MUST END!!
		, TOO MOST END:

How does it work?

END

I think the explanation of the code is clear from the comments. At the end of the SOS the program has a delay of 2 seconds before repeating. This should be a useful addition to any alarm project.

We will now move onto switching a number of outputs on and off. Consider flashing all 8 outputs on PORTB on and off at ½ second intervals.

Flashing 8 LEDs

The circuit for this is shown in Figure 3.2.

This code is to be added to HEADER84.ASM as in LED_FLASHER2.ASM




Figure 3.2 Flashing 8 LEDs

BEGIN	BSF	PORTB,0	;Turn ON B0
	BSF	PORTB,1	;Turn ON B1
	BSF	PORTB,2	;Turn ON B2
	BSF	PORTB,3	;Turn ON B3
	BSF	PORTB,4	;Turn ON B4
	BSF	PORTB,5	;Turn ON B5
	BSF	PORTB,6	;Turn ON B6
	BSF	PORTB,7	;Turn ON B7
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,0	;Turn OFF B0
	BCF	PORTB,1	;Turn OFF B1
	BCF	PORTB,2	;Turn OFF B2
	BCF	PORTB,3	;Turn OFF B3

BCF	PORTB,4	;Turn OFF B4
BCF	PORTB,5	;Turn OFF B5
BCF	PORTB,6	;Turn OFF B6
BCF	PORTB,7	;Turn OFF B7
CALL	DELAYP5	;Wait 0.5 seconds
GOTO	BEGIN	

Save the program as FLASH8.ASM, assemble and program the 16F84 as indicated in Chapter 2.

There is an easier way than this of switching all outputs on a port, which we look at later in this chapter with a set of disco lights.

Chasing 8 LEDs

Let's now consider the code to chase the 8 LEDs. The circuit of Figure 3.2 is required for this. The code will switch B0 on and off, then B1, then B2 etc.

BEGIN	BSF	PORTB,0	;Turn ON B0
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,0	;Turn OFF B0
	BSF	PORTB,1	;Turn ON B1
	CALL	DELAYP5	;Wait 0.5 seconds
	D.C.E.	DODED 1	T 055 P1
	BCF	PORTB,1	;Turn OFF B1
	BSF	PORTB,2	;Turn ON B2
	CALL	DELAYP5	;Wait 0.5 seconds
	DCE	DODTD 2	Tum OFF D2
	BCF	PORTB,2	;Turn OFF B2
	BSF	PORTB,3	;Turn ON B3
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,3	;Turn OFF B3
	BSF	PORTB,4	;Turn ON B4
	CALL	DELAYP5	;Wait 0.5 seconds
			,
	BCF	PORTB,4	;Turn OFF B4
	BSF	PORTB,5	;Turn ON B5
	CALL	DELAYP5	;Wait 0.5 seconds

BCF BSF CALL	PORTB,5 PORTB,6 DELAYP5	;Turn OFF B5 ;Turn ON B6 ;Wait 0.5 seconds
BCF	PORTB,6	;Turn OFF B6
BSF	PORTB,7	;Turn ON B7
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,7	;Turn OFF B7
CALL	DELAYP5	;Wait 0.5 seconds
GOTO	BEGIN	

This code once again is added to the bottom of HEADER84.ASM and is saved as

CHASE8A.ASM

Now that we have chased the LEDs one way let's run them back the other way and call the program CHASE8B.ASM. I think you know the routine add the code to the bottom of HEADER84.ASM etc. So I will not mention it again.

;CHASE8B.ASM ;Program starts now.

BEGIN	BSF	PORTB,0	;Turn ON B0
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,0	;Turn OFF B0
	BSF	PORTB,1	;Turn ON B1
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,1	;Turn OFF B1
	BSF	PORTB,2	;Turn ON B2
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,2	;Turn OFF B2
	BSF	PORTB,3	;Turn ON B3
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,3	;Turn OFF B3
	BSF	PORTB,4	;Turn ON B4
	CALL	DELAYP5	;Wait 0.5 seconds

BCF	PORTB,4	;Turn OFF B4
BSF	PORTB,5	;Turn ON B5
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,5	;Turn OFF B5
BSF	PORTB,6	;Turn ON B6
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,6	;Turn OFF B6
BSF	PORTB,7	;Turn ON B7
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,7	;Turn OFF B7
BSF	PORTB,6	;Turn ON B6
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,6	;Turn OFF B6
BSF	PORTB,5	;Turn ON B5
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,5	;Turn OFF B5
BSF	PORTB,4	;Turn ON B4
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,4	;Turn OFF B4
BSF	PORTB,3	;Turn ON B3
CALL	DELAYP5	;Wait 0.5 seconds
BCF	PORTB,3	;Turn OFF B3
BSF	PORTB,2	;Turn ON B2
CALL	DELAYP5	;Wait 0.5 seconds
BCF BSF CALL BCF GOTO	PORTB,2 PORTB,1 DELAYP5 PORTB,1 BEGIN	;Turn OFF B2 ;Turn ON B1 ;Wait 0.5 seconds ;Turn OFF B1

Just one last flasher program. Let us switch each output on in turn leaving them on as we go and then switch them off in turn. Try this for yourselves before looking at the solution!

The program is saved as UPANDDOWN.ASM

BEGIN	BSF	PORTB,0	;Turn ON B0
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,1	;Turn ON B1
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,2	;Turn ON B2
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,3	;Turn ON B3
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,4	;Turn ON B4
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,5	;Turn ON B5
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,6	;Turn ON B6
	CALL	DELAYP5	;Wait 0.5 seconds
	BSF	PORTB,7	;Turn ON B7
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,7	;Turn OFF B6
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,6	;Turn OFF B6
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,5	;Turn OFF B5
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,4	;Turn OFF B4
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,3	;Turn OFF B3
	CALL	DELAYP5	;Wait 0.5 seconds
	BCF	PORTB,2	;Turn OFF B2
	CALL BCF	DELAYP5 PORTB,1	;Wait 0.5 seconds ;Turn OFF B1
	CALL	DELAYP5	;Wait 0.5 seconds

BCF	PORTB,0	;Turn OFF B0
CALL	DELAYP5	;Wait 0.5 seconds
GOTO	BEGIN	

There are lots of other combinations for you to practice on. I'll leave you to experiment further.

Consider another example of the delay routine:

Traffic lights

If you have ever tried to design a 'simple' set of traffic lights then you will appreciate how much circuitry is required. An oscillator circuit, counters and logic decode circuitry.

The microcontroller circuit is a much better solution even for this 'simple' arrangement. The circuit is shown in Figure 3.3.




Figure 3.3 Traffic lights circuit

A truth table of the operation of the lights is probably a better aid to a solution rather than a flowchart.

Traffic light truth table

Time	B7	В6	B5	B4	В3	B2	B1	В0
			R1	A1	G1	R2	A2	G2
2sec	0	0	1	0	0	1	0	0
2sec	0	0	1	1	0	1	0	0
5sec	0	0	0	0	1	1	0	0
2sec	0	0	0	1	0	1	0	0
2sec	0	0	1	0	0	1	0	0
2sec	0	0	1	0	0	1	1	0
5sec	0	0	1	0	0	0	0	1
2sec	0	0	1	0	0	0	1	0
	REPEAT							

Program listing for the traffic lights

;TRAFFIC.ASM

BEGIN	MOVLW	B'00100100'	;R1, R2 on.
	MOVWF CALL	PORTB DELAY2	;Wait 2 Seconds.
	MOVLW	B'00110100'	;R1, A1, R2 on.
	MOVWF CALL	PORTB DELAY2	;Wait 2 Seconds.
	MOVLW	B'00001100'	;G1, R2 on.
	MOVWF CALL	PORTB DELAY5	:Wait 5 Seconds.
	MOVLW	B'00010100'	;A1, R2 on.
	MOVWF	PORTB	, ,
	CALL	DELAY2	;Wait 2 Seconds.
	MOVLW MOVWF	B'00100100' PORTB	;R1, R2 on.

CALL	DELAY2	;Wait 2 Seconds.
MOVLW MOVWF	B'00100110' PORTB	;R1, R2, A2 on.
CALL	DELAY2	;Wait 2 Seconds.
MOVLW MOVWF	B'00100001' PORTB	;R1, G2 on.
CALL	DELAY5	;Wait 5 Seconds.
MOVLW MOVWF	B'00100010' PORTB	;R1, A2 on.
CALL	DELAY2	;Wait 2 Seconds.
GOTO	BEGIN	

How does it work

In a previous examples we turned LEDs on and off with the two commands BSF and BCF, but a much better way has been used with the TRAFFIC.ASM program.

The basic difference is the introduction of two more commands:

- MOVLW MOVe the Literal (a number) into the Working register.
- MOVWF MOVe the Working register to the File.

The data, in this example, binary numbers, are moved to W and then to the file which is the output PORTB to switch the LEDs on and off. Unfortunately the data cannot be placed in PORTB with only one instruction it has to go via the W register.

So:

MOVLW	B'00100100'	clears B7,B6, sets B5, clears B4,B3, sets B2
		and clears B1, B0 in the W register
MOVWF	PORTB	moves the data from the W register to PORTB
		to turn the relevant LEDs on and off.

All 8 outputs are turned on/off with these 2 instructions.

CALL DELAY2 and CALL DELAY5 waits 2 seconds and 5 seconds before continuing with the next operation. DELAY2 and DELAY5 need adding to the subroutine section as:

; 5 second delay.

DELAY5 CLRF :START TMR0. TMR0

LOOPC	MOVF SUBLW BTFSS GOTO RETLW	TMR0,W .160 STATUS,ZEROBIT LOOPC 0	;READ TMR0 INTO W. ;TIME - 160 ;Check TIME - W = 0 ;Time is not = 160. ;Time is 160, return.
; 2 second	delay.		
DELAY2	CLRF	TMR0	;START TMR0.
LOOPD	MOVF	TMR0,W	;READ TMR0 INTO W.
	SUBLW	.64	;TIME - 64
	BTFSS	STATUS, ZEROBIT	;Check TIME - $W = 0$
	GOTO	LOOPD	; Time is not $= 64$.
	RETLW	0	:Time is 64, return.

The W register

The W or working register is the most important register in the micro. It is in the W register were all the calculations and logical manipulations such as addition, subtraction, and-ing, or-ing etc., are done.

The W register shunts data around like a telephone exchange re-routes telephone calls. In order to move data from locationA to locationB, the data has to be moved from location A to W and then from W to location B

NB. If the three lines in the TRAFFIC.ASM program are repeated then any pattern and any delay can be used to sequence the lights – you can make your own disco lights!

Repetition (e.g. disco lights)

Instead of just repeating one sequence over and over, suppose we wish to repeat several sequences before returning to the start as with a set of disco lights.

Consider the circuit shown in Figure 3.4. The 8 'Disco Lights' B0-B7 are to be run as two sequences.

```
Sequence 1
            Turn all lights on.
            Wait.
            Turn all lights off
            Wait
Sequence 2
            Turn B7-B4 ON, B3-B0 OFF
            Turn B7-B4 OFF, B3-B0 ON
            Wait
```




Figure 3.4 Disco lights

Suppose we wish Sequence 1 to run 5 times before going onto Sequence 2 to run 10 times and then repeat. A section of program is repeated a number of times with 4 lines of code shown below:

```
MOVLW .5 ;Move 5 into W
MOVWF COUNT ;Move W into user file COUNT
.
SEQ1
.
DECFSZ COUNT ;decrement file COUNT skip if zero.
GOTO SEQ1 ;COUNT not yet zero, repeat sequence
```

- The first two lines set up a file COUNT with 5. (Count is the first user file and is found in memory location 0CH.) 5 is first of all moved into W then from there to file COUNT.
- SEQ1 is executed.
- The DECFSZ COUNT instruction, DECrement File and Skip if Zero, decrements, takes 1 off, the file COUNT and skips GOTO SEQ1 if the count is zero, if not zero then do SEQ1 again.

This way SEQ1 is executed 5 times and COUNT goes from 5 to 4 to 3 to 2 to 1 to 0 when we skip and follow onto SEQ2. SEQ2 is then done 10 times, say, and the code would be:

MOVLW .10 ;Move 10 into W
MOVWF COUNT ;Move W into user file COUNT
.
SEQ2
.
DECFSZ COUNT ;decrement file COUNT skip if zero.
GOTO SEQ2 ;COUNT not yet zero, repeat sequence

Program code for the disco lights

;DISCO.ASM

BEGIN	MOVLW MOVWF	.5 COUNT	;Set COUNT = 5
SEQ1	MOVLW MOVWF CALL MOVLW MOVWF CALL DECFSZ GOTO	B'11111111' PORTB DELAYP5 B'00000000' PORTB DELAYP5 COUNT SEQ1	;Turn B7-B0 ON ;Wait 0.5 seconds ;Turn B7-B0 OFF ;Wait 0.5 seconds ;COUNT-1, skip if 0.
SEQ2	MOVLW MOVLW MOVWF CALL MOVLW MOVWF	.10 COUNT B'11110000' PORTB DELAYP5 B'00001111' PORTB	;Set COUNT = 10 ;B7-B4 on, B3-B0 off ;Wait 0.5 seconds ;B7-B4 off, B3-B0 on
END	CALL DECFSZ GOTO GOTO	DELAYP5 COUNT SEQ2 BEGIN	;Wait 0.5 seconds ;COUNT-1, skip if 0.

Using the idea of repeating sequences like this any number of combinations can be repeated. The times of course do not need to be of 0.5 seconds duration. The flash rate can be speeded up or slowed down depending on the combination.

Try programming a set of your own Disco Lights. This should keep you quiet for hours (days!).

More than 8 outputs

Suppose we wish to have a set of disco lights in a 3×3 matrix as shown in Figure 3.5. This configuration of course requires 9 outputs. We have 8 outputs on PORTB so we need to make one of the PORTA bits an output also, say PORTA bit0.




Figure 3.5 9 Disco light set

To change PORTA bit0 from an input to an output change the lines in the Configuration section from:

MOVLW B'00011111' MOVWF TRISA

to

MOVLW B'00011110' MOVWF TRISA

NB a 1 signifies an input a 0 signifies an output.

So to set a '+' pattern in the lights we turn on B7, B4, B1, B3 and B5, keeping the others off. The code for this would be:

MOVLW B'00000000'

MOVWF PORTA ;A0 is clear

MOVLW B'10111010'

MOVWF PORTB :B7, B5, B4, B3 and B1 are on

So to set an 'X' pattern in the lights we turn on B6, B4, B2, A0 and B0, keeping the others off. The code for this would be:

MOVLW B'00000001'

MOVWF PORTA :A0 is on

MOVLW B'01010101'

MOVWF PORTB ;B6, B4, B2 and B0 are on

There are endless combinations you can make with 9 lights. In fact there are 512. That is 2^9 . This should give you something to go at!