
O-RAN Work Group 10 (OAM for O-RAN)

O-RAN O1 Performance Measurements Specification

Copyright © 2026 by the O-RAN ALLIANCE e.V.

The copying or incorporation into any other work of part or all of the material available in this specification in any form without the prior written permission of O-RAN ALLIANCE e.V. is prohibited, save that you may print or download extracts of the material of this specification for your personal use, or copy the material of this specification for the purpose of sending to individual third parties for their information provided that you acknowledge O-RAN ALLIANCE as the source of the material and that you inform the third party that these conditions apply to them and that they must comply with them.

O-RAN ALLIANCE e.V., Buschkauler Weg 27, 53347 Alfter, Germany

Register of Associations, Bonn VR 11238, VAT ID DE321720189

Contents

Foreword	4
Modal verbs terminology	4
1 Scope	5
2 References	5
2.1 Normative references	5
2.2 Informative references	5
3 Definition of terms, symbols and abbreviations	6
3.1 Terms	6
3.2 Symbols	6
3.3 Abbreviations	6
3.4 Measurement Family	7
4 Requirements	8
4.1 General Requirements	8
5 Performance Measurement definition	8
5.1 5G Performance Measurements	8
Annex A (informative): O-RAN O1 defined Performance Measurements	10
A.1 Overview	10
A.2 O-CU-CP Performance measurements	10
A.2.1 NR X2-C Interface performance measurements (O-CU)	10
A.2.2 NR Xn-C Interface performance measurements (O-CU)	11
A.2.3 NR F1-C Interface performance measurements (O-CU-CP)	12
A.2.4 Number of UE Contexts for EN-DC	13
A.2.5 Number of UE Contexts for SA	19
A.2.6 Monitoring of procedure for EN-DC	31
A.2.7 Monitoring of RRC Connection for EN-DC	36
A.2.8 Monitoring of RRC Connection for SA	39
A.2.9 Monitoring of Establishment calls for SA	47
A.2.10 Monitoring of PDU session connection for SA	61
A.2.11 Monitoring of mobility for SA	68
A.2.12 Monitoring of RRC re-establishment for SA	73
A.2.13 Monitoring of connection status for SA	78
A.2.14 Monitoring of procedure for NR-DC	81
A.2.15 Monitoring of CA for SA	87
A.3 O-CU-UP Performance measurements	90
A.3.1 NR PDCP performance measurements	90
A.3.2 Void	103
A.3.3 NR S1-U Interface Performance Measurements	103
A.3.4 NR NG-U Interface Performance Measurements	105
A.3.5 NR X2-U Interface performance measurements (O-CU)	106
A.3.6 NR Xn-U Interface performance measurements (O-CU)	107
A.4 O-DU Performance measurements	108
A.4.1 NR F1 Interface performance measurements	108
A.4.2 NR RLC performance measurements	116
A.4.3 NR MAC performance measurements	132
A.4.4 NR UL HARQ performance measurements	133
A.4.5 NR DL HARQ performance measurements	137
A.4.6 NR UL Signal Quality Level performance measurements	141
A.4.7 NR DL Signal Quality Level performance measurements	151
A.4.8 NR Beamforming performance measurements	158
A.4.9 NR RACH Usage performance measurements	160
A.4.10 NR Timing Advance performance measurements	164
A.4.11 NR Cell Utilization performance measurements	164

A.4.12	Void	191
A.4.13	O-RU Performance measurements measured at O-DU	191
A.4.14	O-RU Performance measurements measured at O-RU	201
A.4.15	D2 Interface performance measurements	201
Annex B (informative): 3GPP TS 32.404 template usage for O-RAN O1 defined Performance Measurements		207
Annex (informative): Change History		209

Foreword

This Technical Specification (TS) has been produced by WG10 of the O-RAN ALLIANCE.

The content of the present document is subject to continuing work within O-RAN and may change following formal O-RAN approval. Should the O-RAN ALLIANCE modify the contents of the present document, it will be re-released by O-RAN with an identifying change of version date and an increase in version number as follows:

version xx.yy.zz

where:

- xx: the first digit-group is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc. (the initial approved document will have xx=01). Always 2 digits with leading zero if needed.
- yy: the second digit-group is incremented when editorial only changes have been incorporated in the document. Always 2 digits with leading zero if needed.
- zz: the third digit-group included only in working versions of the document indicating incremental changes during the editing process. External versions never include the third digit-group. Always 2 digits with leading zero if needed.

Modal verbs terminology

In the present document "**shall**", "**shall not**", "**should**", "**should not**", "**may**", "**need not**", "**will**", "**will not**", "**can**" and "**cannot**" are to be interpreted as described in clause 3.2 of the O-RAN Drafting Rules (Verbal forms for the expression of provisions).

"**must**" and "**must not**" are **NOT** allowed in O-RAN deliverables except when used in direct citation.

1 Scope

The present document specifies the O-RAN Performance Measurements (PMeas) for 5G networks that may be supported on the O1 Interface [3].

2 References

2.1 Normative references

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the referenced document (including any amendments) applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document in 3GPP Release 18.

NOTE: While any hyperlinks included in this clause were valid at the time of publication, O-RAN cannot guarantee their long-term validity.

The following referenced documents are necessary for the application of the present document.

- [1] 3GPP TS 32.404: "Telecommunication management; Performance Management (PM); Performance Measurements; Definition and template".
- [2] 3GPP TS 28.552: "Management and orchestration; 5G performance measurements".
- [3] O-RAN.WG10.TS.O1-Interface: "O-RAN O1 Interface Specification".
- [4] ORAN-WG4.TS.MP.0: "Management Plane Specification".
- [5] 3GPP TS 38.401: "NG-RAN; Architecture description".
- [6] 3GPP TS 38.323: "NR; Packet Data Convergence Protocol (PDCP) specification".
- [7] O-RAN.WG5.O-DU-O1: "O1 Interface specification for O-DU".
- [8] O-RAN.WG5.O-CU-O1: "O1 Interface specification for O-CU-UP and O-CU-CP".
- [9] O-RAN.WG10.TS.NRM: "O-RAN O1 Network Resource Model Specification".
- [10] O-RAN.WG5.TS.D2GAP: "D2 Interface: General Aspects and Principles".
- [11] O-RAN.WG5.TS.D2AP: "D2 Interface: D2 Application Protocol (D2AP)".
- [12] O-RAN.WG1.TS.OAD: "O-RAN Architecture Description".

2.2 Informative references

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the referenced document (including any amendments) applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document in 3GPP Release 18.

NOTE: While any hyperlinks included in this clause were valid at the time of publication, O-RAN cannot guarantee their long-term validity.

The following referenced documents are not necessary for the application of the present document, but they assist the user with regard to a particular subject area.

- [i.1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
- [i.2] O-RAN.WG4.TS.CUS: "O-RAN Control, User and Synchronization Plane".
- [i.3] 3GPP TS 36.413: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN); S1 Application Protocol (S1AP)".
- [i.4] 3GPP TS 36.423: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN); X2 Application Protocol (X2AP)".
- [i.5] 3GPP TS 38.413: "NG-RAN; NG Application Protocol (NGAP)".
- [i.6] 3GPP TS 38.473: "NG-RAN; F1 Application Protocol (F1AP)".
- [i.7] O-RAN.WG5.TS.C.1-R004-v14.00: "O-RAN WG5 NR C-Plane Profile".

3 Definition of terms, symbols and abbreviations

3.1 Terms

For the purposes of the present document, the terms given in 3GPP TR 21.905 [i.1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in 3GPP TR 21.905 [i.1].

carrier aggregation: Aggregation of two or more NR or E-UTRA component carriers in order to support wider transmission bandwidths.

D2 interface: The inter O-DU interface to enable multi-vendor carrier aggregation in NR is named as D2 according to WG1 ATG definitions (refer to O-RAN.WG1.TS.OAD [12]).

PCell O-DU: O-DU, where the PCell is configured for a UE to support inter O-DU carrier aggregation (refer to O-RAN.WG5.TS.D2GAP [10]).

SCell O-DU: O-DU, where only SCell(s) are configured for a UE to support inter O-DU carrier aggregation (refer to O-RAN.WG5.TS.D2GAP [10]).

3.2 Symbols

For the purposes of the present document, the symbols given in 3GPP TR 21.905 [i.1] and the following apply. A symbol defined in the present document takes precedence over the definition of the same symbol, if any, in 3GPP TR 21.905 [i.1].

3.3 Abbreviations

For the purposes of the present document, the abbreviations given in 3GPP TR 21.905 [i.1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in 3GPP TR 21.905 [i.1].

3GPP	3rd Generation Partnership Project
CC	Cumulative counter
D2-c	D2 Control plane interface
D2-u	D2 User Plane interface

DL	Down Link
MAC	Medium Access Control
PCell	Primary Cell
PDU	Protocol Data Unit
PMeas	Performance Measurements
SCell	Secondary Cell
SI	Status Inspection
TB	Transport Block

3.4 Measurement Family

The measurement names defined in the present document are all beginning with a prefix 'OR.<measurement-family-name>'. This family name identifies all measurements which relate to a given functionality, and it may be used for measurement administration.

For the purposes of the present document, the measurement families given in 3GPP TS 28.552 [2] and the following apply,

- L3M (measurements related to Layer 3 Measurement)
- D2M (measurements related to D2 Interface)
- ORU (measurements related to O-RAN Radio Unit)

NOTE: The family names that have been marked 'deprecated' are not captured in the above list.

4 Requirements

4.1 General Requirements

The general requirements in Table 4.1-1 apply to the definition of O-RAN performance measurements (including the template to be used):

Table 4.1-1 – General Requirements for O-RAN performance measurement definition

Requirement label	Description	Motivation
REQ-PMeas-MC-1	O-RAN O1 performance measurements shall be defined using the template specified in 3GPP TS 32.404 [1].	Identify the template to be used for the definition of O1 performance measurements
REQ-PMeas-MC-2	The Measurement Name of an O-RAN defined measurement shall begin with “OR” prefix to indicate that O-RAN is the source of the measurement definition.	
REQ-PMeas-MC-3	The short form of the Measurement Name in the Measurement Type for an O-RAN defined measurement shall begin with "OR." to indicate that O-RAN is the source of the measurement definition.	
REQ-PMeas-MC-4	In case O-RAN extends the definition of an existing 3GPP measurement, a new O-RAN measurement shall be defined. 3GPP Measurement Name should be part of the newly defined O-RAN Measurement Name. 3GPP measurement definition shall be referred in the newly defined O-RAN measurement definition, when possible.	
REQ-PMeas-MC-5	When an O-RAN measurement is defined in 3GPP, the O-RAN measurement shall be deprecated. Reference to the new 3GPP measurement shall be added. NOTE: “Deprecated” means the measurement definition is valid, it can be used, but its use is discouraged. Deprecated measurement definition includes the replacement measurement definition specified as default.	
REQ-PMeas-MC-6	When defining an O-RAN performance measurement with filtering, the 3GPP filtering mechanism defined in 3GPP TS 28.552 [2], clause 4.2 shall be used.	

5 Performance Measurement definition

5.1 5G Performance Measurements

The 3GPP defined 5G performance measurements for gNB are in 3GPP TS 28.552 [2] clause 5.1.

The O-RAN defined measurements are defined in Annex A of the present document. An annex subclause is available per O-RAN NF as follows:

- Annex A.2 per O-CU-CP
- Annex A.3 per O-CU-UP
- Annex A.4 per O-DU

NOTE: The following area of improvements have been identified in the context of O-RAN O1 performance measurements that needs to be further analysed:

- 1) *PmGroup* definition and harmonization with 3GPP sub-counters. 3GPP TS 28.552 [2] has already defined sub-counters per specific criteria (e.g., QoS, SNSSAI). If *PmGroup* is required, an harmonization of the performance groups between O-DU, O-CU-CP, and O-CU-UP NFs should be also considered. *PmGroup* stage 2, stage 3 and value ranges (e.g value 0 and valid subrange per id types) have to be specified and properly referenced from this document.

NOTE: point 8 below has to be considered also in the context of the PmGroup definition and harmonization.

- 2) Void
- 3) O-RAN O1 performance counters definitions where both overall counter and optional sub-counters per specific targets are defined should be aligned with similar 3GPP performance measurement definitions (see 3GPP TS 28.552 [2], clause 5.1.3.4.2).
- 4) O-RAN O1 Measurement result review to ensure valid values are used according to 3GPP TS 32.404 [1] and should be reviewed (e.g., kilobyte instead of an integer value representing the number of measured bits/bytes).
- 5) Void
- 6) Validate O-RAN defined sub-counter name for existing 3GPP counter, in line with existing O1 Performance measurement requirements of this document.
- 7) Improve "Description" subclause with information about "PmGroup" & "CuCountGroup" based on information in "Condition" subclause.
- 8) Review the naming rule of performance measurements in case of subcounters. When a performance measurement has multiple subcounters, currently it is hard to distinguish the subcounters. It is proposed that O-RAN O1 performance measurements reuse filter naming rules improvements introduced in 3GPP TS 28.552 [2], clause 4.2.2.

Annex A (informative): O-RAN O1 defined Performance Measurements

A.1 Overview

The following clauses define the O-RAN O1 defined performance measurements per O-RAN NF.

ANNEX A.2 O-CU-CP

ANNEX A.3 O-CU-UP

ANNEX A.4 O-DU

NOTE 1: The usage of CuCountGroup and PMCountGroup in following clauses is based on WG5 models as specified in [7], [8]. This may be subject to change following completion of O1 consolidation activities and new WG10 models as specified in O1 NRM [9].

NOTE 2: How the MnS Consumer configures the Neighbour eNB Index/Neighbour gNB Index is not defined in this specification.

A.2 O-CU-CP Performance measurements

A.2.1 NR X2-C Interface performance measurements (O-CU)

A.2.1.1 Transmitted X2-C messages

- a) This counter provides the number of the transmitted X2-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- b) CC
- c) Measurement subcounter is incremented by 1 whenever X2 C-plane message is transmitted when the signal type of the X2 C-plane message is group of *Signaltype*.
- d) Each measurement is an integer value representing the number of the transmitted X2-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- e) OR.L3M.TxX2CMesg.*Signaltype* (default), OR.X2.TxX2CMesg.*Signaltype* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *Signaltype* is signal type:
 - 0: non UE-associated
 - 1: UE associated
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.1.2 Received X2-C messages

- a) This counter provides the number of the received X2-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].

- b) CC
- c) Measurement subcounter is incremented by 1 whenever X2 C-plane message is received when the signal type of the X2 C-plane message is group of *Signaltype*.
- d) Each measurement is an integer value representing the number of the received X2-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- e) OR.L3M.RxX2CMesg.*Signaltype* (default), OR.X2.RxX2CMesg.*Signaltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Signaltype* is signal type:
 - 0: non UE-associated
 - 1: UE associated
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.2 NR Xn-C Interface performance measurements (O-CU)

A.2.2.1 Transmitted Xn-C messages

- a) This counter provides the number of the transmitted Xn-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- b) CC
- c) Measurement subcounter is incremented by 1 whenever Xn C-plane message is transmitted when the signal type of Xn C-plane message is group of *Signaltype*.
- d) Each measurement is an integer value representing the number of the transmitted Xn-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- e) OR.L3M.TxXnCMesg.*Signaltype* (default), OR.Xn.TxXnCMesg.*Signaltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Signaltype* is signal type:
 - 0: non UE-associated
 - 1: UE associated
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.2.2 Received Xn-C messages

- a) This counter provides the number of the received Xn-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- b) CC

- c) Measurement subcounter is incremented by 1 whenever Xn C-plane message is received when the signal type of the Xn C-plane message is group of *Signaltype*.
- d) Each measurement is an integer value representing the number of the received Xn-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- e) OR.L3M.RxXnCMesg.*Signaltype* (default), OR.Xn.RxXnCMesg.*Signaltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Signaltype* is signal type:
 - 0: non UE-associated
 - 1: UE associated
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.3 NR F1-C Interface performance measurements (O-CU-CP)

A.2.3.1 Transmitted F1-C messages

- a) This counter provides the number of the transmitted F1-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- b) CC
- c) Measurement subcounter is incremented by 1 whenever F1 C-plane message is transmitted when the signal type of the F1 C-plane message is group of *Signaltype*.
- d) Each measurement is an integer value representing the number of the transmitted F1-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- e) OR.L3M.TxF1CMesg.*Signaltype* (default), OR.F1.TxF1CMesg.*Signaltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Signaltype* is signal type:
 - 0: non UE-associated
 - 1: UE associated
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.3.2 Received F1-C messages

- a) This counter provides the number of the received F1-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- b) CC
- c) Measurement subcounter is incremented by 1 whenever F1 C-plane message is received when the signal type of the F1 C-plane message is group of *Signaltype*.

- d) Each measurement is an integer value representing the number of the received F1-C messages per signal type that is non UE-associated or UE-associated signaling 3GPP TS 38.401 [5].
- e) OR.L3M.RxF1CMesg.*Signaltype* (default), OR.F1.RxF1CMesg.*Signaltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Signaltype* is signal type:
 - 0: non UE-associated
 - 1: UE associated
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4 Number of UE Contexts for EN-DC

A.2.4.1 Max SN terminated split bearer UE Contexts

- a) This counter provides the maximum number of UE Contexts that are configured SN terminated split bearer.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of UE context that are configured SN terminated split bearer during the granularity period.

These subcounters only cover Scell-users with P(S)Cell in the same gNB. The inter-gNB CA is not covered.

- the triggers of addition of number of UE Contexts for PSCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated split bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for target cell))
 - received RRC: RRC Reconfiguration Complete (Intra/Inter DU PSCell change using SRB3 (for target cell))
- the triggers of subtraction of number of UE Contexts for PSCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated MCG bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for source cell))
 - received F1-AP: UE Context Release Complete (Intra/Inter DU PSCell change using SRB3 (for source cell))
 - received X2-AP: UE Context Release
- the triggers of addition for SCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated split bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for target cell), SCell Addition using SRB1)
 - received RRC: RRC Reconfiguration Complete (Intra/Inter DU PSCell change using SRB3 (for target cell), SCell Addition using SRB3)
- the triggers of subtraction for SCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated MCG bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for source cell), SCell deletion using SRB1)
 - received F1-AP: UE Context Release Complete (Intra/Inter DU PSCell change using SRB3 (for source cell), SCell deletion using SRB3)
 - received X2-AP: UE Context Release

- d) Each measurement is an integer value representing the maximum number of UE Contexts that are configured SN terminated split bearer.
- e) OR.UECNTX.MaxSnSplitBearer.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UEENDC.MaxSnSplitBearer.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
 - 0: PSCell
 - 1: SCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.2 Max SN terminated MCG bearer UE Contexts

- a) This counter provides the maximum number of UE Contexts that are configured SN terminated MCG bearer.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of UE Contexts that are configured SN terminated MCG bearer during the granularity period.
 - the triggers of addition of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated MCG bearer)
 - received X2-AP: SgNB Reconfiguration Confirm (to SN terminated MCG bearer)
 - the triggers of subtraction of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated split bearer)
 - received X2-AP: UE Context Release
- d) Each measurement is an integer value representing the maximum number of UE Contexts that are configured SN terminated MCG bearer.
- e) OR.UECNTX.MaxSnMcgBearer (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UEENDC.MaxSnMcgBearer (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.3 Average SN terminated split bearer UE Contexts

- a) This counter provides the average number of UE Contexts that are configured SN terminated split bearer.
- b) SI
- c) The measurement is obtained by reporting the average observed value of UE Contexts that are configured SN terminated split bearer during the granularity period.

These subcounters only cover SCell-users with P(S)Cell in the same gNB. The inter-gNB CA is not covered.

- the triggers of addition of number of UE Contexts for PSCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated split bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for target cell))
 - received RRC: RRC Reconfiguration Complete (Intra/Inter DU PSCell change using SRB3 (for target cell))
 - the triggers of subtraction of number of UE Contexts for PSCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated MCG bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for source cell))
 - received F1-AP: UE Context Release Complete (Intra/Inter DU PSCell change using SRB3 (for source cell))
 - received X2-AP: UE Context Release
 - the triggers of addition for SCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated split bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for target cell), SCell Addition using SRB1)
 - received RRC: RRC Reconfiguration Complete (Intra/Inter DU PSCell change using SRB3 (for target cell), SCell Addition using SRB3)
 - the triggers of subtraction for SCell
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated MCG bearer)
 - received X2-AP: SgNB Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for source cell), SCell deletion using SRB1)
 - received F1-AP: UE Context Release Complete (Intra/Inter DU PSCell change using SRB3 (for source cell), SCell deletion using SRB3)
 - received X2-AP: UE Context Release
- d) Each measurement is an integer value representing the average number of UE Contexts that are configured SN terminated split bearer.
- e) OR.UECNTX.AveSnSplitBearer.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UEENDC.AveSnSplitBearer.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PSCell
1: SCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.4 Average SN terminated MCG bearer UE Contexts

- a) This counter provides the average number of UE Contexts that are configured SN terminated MCG bearer that are already setup.
- b) SI
- c) The measurement is obtained by reporting the average observed value of UE Contexts that are configured SN terminated MCG bearer that are already setup during the granularity period.

- the triggers of addition of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated MCG bearer)
 - received X2-AP: SgNB Reconfiguration Confirm (to SN terminated MCG bearer)
- the triggers of subtraction of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (to SN terminated split bearer)
 - received X2-AP: UE Context Release
- d) Each measurement is an integer value representing the average number of UE Contexts that are configured SN terminated MCG bearer that are already setup.
- e) OR.UECNTX.AveSnMcgBearer (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.UEENDC.AveSnMcgBearer (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.5 Total DL CA UE Contexts PSCell

- a) This counter provides the total number of UE Contexts that are set of DL CA as PSCell in units of NR Cell.
- b) CC
- c) This measurement provides the total number of UE Contexts using this cell as PSCell during each granularity period. This measurement is split into subcounters per number of CC configured for DL CA in unit of NR Cell group.

The measurement is obtained by reporting the total observed value of UE Contexts that are set of DL CA as PSCell in units of NR Cell during the granularity period per CC.
 - the triggers of addition of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell addition)
 - received RRC: RRC Reconfiguration Complete (SCell addition/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell addition/change)
 - the triggers of subtraction of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell release)
 - received RRC: RRC Reconfiguration Complete (SCell release/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell release/change)
 - received X2-AP: UE Context Release
- d) Each measurement is an integer value representing the total number of UE Contexts that are set of DL CA as PSCell in units of NR Cell.
- e) OR.UECNTX.TotalDlCaUePscell.Ccnum (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.UEENDC.TotalDlCaUePscell.Ccnum (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Ccnum* is the number of CC:
 - 0: #0CC (number of SCell excluding PSCell in the cell group)
 - 1: #1CC (number of SCell excluding PSCell in the cell group)
 - ...
 - 7: #7CC (number of SCell excluding PSCell in the cell group)
- f) NRCellCU
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.6 Void

A.2.4.7 Total DL CA UE Contexts SCell

- a) This counter provides the total number of UE Contexts that are set of DL CA as SCell in units of NR Cell.
- b) CC
- c) The measurement is obtained by reporting the total observed value of UE Contexts that are set of DL CA as SCell in units of NR Cell during the granularity period per CC.
 - the triggers of addition of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell addition)
 - received RRC: RRC Reconfiguration Complete (SCell addition/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell addition/change)
 - the triggers of subtraction of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell release)
 - received F1-AP: UE Context Release Complete (SCell release/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell release/change)
 - received X2-AP: UE Context Release
- d) Each measurement is an integer value representing the total number of UE Contexts that are set of DL CA as SCell in units of NR Cell.
- e) OR.UECNTX.TotalDlCaUeScell.*Ccnum* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UEENDC.TotalDlCaUeScell.*Ccnum* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *Ccnum* is the number of CC:
 - 0: #1CC (number of SCell excluding PSCell in the cell group)
 - 1: #2CC (number of SCell excluding PSCell in the cell group)
 - ...
 - 6: #7CC (number of SCell excluding PSCell in the cell group)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.8 Void

A.2.4.9 Max DL CA UE Contexts PSCell

- a) This counter provides the maximum number of UE Contexts that are set of DL CA as PSCell in units of NR Cell.
- b) SI

- c) The measurement is obtained by reporting the maximum observed value UE Contexts that are set of DL CA as PSCell in units of NR Cell during the granularity period per CC.
 - the triggers of addition of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell downlink addition)
 - received RRC: RRC Reconfiguration Complete (SCell downlink addition/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell downlink addition/change)
 - the triggers of subtraction of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell downlink release)
 - received F1-AP: UE Context Release Complete (SCell downlink release/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell downlink release/change)
 - received X2-AP: UE downlink Context Release
- d) Each measurement is an integer value representing the maximum number of UE Contexts that are set of DL CA as PSCell in units of NR Cell.
- e) OR.UECNTX.MaxDlCaUePscell.Ccnum (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UEENDC.MaxDlCaUePscell.Ccnum (deprecated, refer to NOTE in REQ-PMeas-MC-5) where Ccnum is the number of CC:
 - 0: #0CC (number of SCell excluding PSCell in the cell group)
 - 1: #1CC (number of SCell excluding PSCell in the cell group)
 - ...
 - 7: #7CC (number of SCell excluding PSCell in the cell group)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.10 Void

A.2.4.11 Max DL CA UE Contexts SCell

- a) This counter provides the maximum number of UE Contexts that are set of DL CA as SCell in units of NR Cell.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of UE Contexts that are set of DL CA as SCell in units of NR Cell during the granularity period per CC.
 - the triggers of addition of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell downlink addition)
 - received RRC: RRC Reconfiguration Complete (SCell downlink addition/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell downlink addition/change)
 - the triggers of subtraction of number of UE Contexts
 - received X2-AP: SgNB Reconfiguration Complete (SCell downlink release)
 - received F1-AP: UE Context Release Complete (SCell downlink release/change using SRB3)
 - received X2-AP: SgNB Modification Confirm (SCell downlink release/change)
 - received X2-AP: UE downlink Context Release

- d) Each measurement is an integer value representing the maximum number of UE Contexts that are set of DL CA as SCell in units of NR Cell.
- e) OR.UECNTX.MaxDlCaUeScell.Ccnum (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.UENDC.MaxDlCaUeScell.Ccnum (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Ccnum* is the number of CC:
 - 0: #1CC (number of SCell excluding PSCell in the cell group)
 - 1: #2CC (number of SCell excluding PSCell in the cell group)
 - ...
 - 7: #6CC (number of SCell excluding PSCell in the cell group)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.4.12 Void

A.2.5 Number of UE Contexts for SA

A.2.5.1 Total RRC Connected UE Contexts

- a) This counter provides the total number of the RRC connected UE Contexts in PCell.
- b) CC
- c) This measurement provides the total number of RRC connected UE Contexts during each granularity period.

The measurement is obtained by reporting the total observed value of RRC connected UE Contexts in PCell during the granularity period.

- the triggers of addition of RRC connected UE Contexts
 - received RRC: RRC Setup Complete
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
- the triggers of subtraction of RRC connected UE Contexts
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, UE Context Release including EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-CU Inter gNB-DU HO, Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - send RRC: RRC Release (RRC Connected to RRC inactive)
- d) Each measurement is an integer value representing the total number of UE Contexts that are set of DL CA as SCell in units of NR Cell.
- e) OR.UECNTX.TotalRrcConnectedUes (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.UESA.TotalRrcConnectedUes (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.2 Total UE Contexts Per QoS

- a) This counter provides the total number of the UE Contexts for PCell and SCell. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) The measurement is obtained by reporting the total observed value of UE Contexts for PCell and SCell during the granularity period.

NOTE: multiple 5QIs can be set per UE Context, each 5QI is counted per QoS flow.

- the triggers of addition for PCell
 - received NG-AP: Initial Context Setup Response
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - send NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
 - send NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
- the triggers of subtraction for PCell
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
 - send NG-AP: PDU Session Resource Release Response (PDU Session Release)
 - send NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
- the triggers of addition for SCell
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
- the triggers of subtraction for SCell
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the total number of the UE Contexts for PCell and SCell. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- e) The measurement name has the form OR.UECNTX.TotalUes.*Celltype* or OR.UECNTX.TotalUes.*Celltype_Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.TotalUes.*Celltype* or OR.UESA.TotalUes.*Celltype_Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level and where *Celltype* is the cell type:

0: PCell

1: SCell

- f) NRCelLCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.3 Total SCell Configuration UE Contexts

- a) This counter provides the total number of each SCell configuration UE Contexts.
- b) CC
- c) The measurement is obtained by reporting the total observed value of SCell configuration UE Contexts during the granularity period.
 - the triggers of addition
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
 - the triggers of subtraction
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the total number of each SCell configuration UE Contexts.
- e) OR.UECNTX.TotalScellConfigUes.SCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.TotalScellConfigUes.SCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCelLCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.4 Total Measurement Gap UE Contexts

- a) This counter provides the total number of UE Contexts which is configured with measurement gap.
- b) CC
- c) The measurement is obtained by reporting the total observed value of UE Contexts which is configured with measurement gap during the granularity period.
 - the triggers of addition
 - received RRC: RRC Reconfiguration Complete (setup measurement gap)
 - the triggers of subtraction
 - received RRC: RRC Reconfiguration Complete (release measurement gap)
- d) Each measurement is an integer value representing the total number of UE Contexts which is configured with measurement gap.
- e) OR.UECNTX.TotalMeasGapUes (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.TotalMeasGapUes (deprecated, refer to NOTE in REQ-PMeas-MC-5)

- f) NRCelICU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.5 Max RRC Connected UE Contexts

- a) This counter provides the maximum number of the RRC connected UE Contexts in PCell.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of RRC connected UE Contexts in PCell during the granularity period.
 - the triggers of addition of the RRC connected UE Contexts
 - received RRC: RRC Setup Complete
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - the triggers of subtraction of the RRC connected UE Contexts
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, UE Context Release including EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-CU Inter gNB-DU HO, Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - send RRC: RRC Release (RRC Connected to RRC inactive)
- d) Each measurement is an integer value representing the maximum number of the RRC connected UE Contexts in PCell.
- e) OR.UECNTX.MaxRrcConnectedUes (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.MaxRrcConnectedUes (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCelICU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.6 Max UE Contexts Per QoS

- a) This counter provides the maximum number of the UE Contexts for PCell and SCell. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of UE Contexts for PCell and SCell during the granularity period.

NOTE: multiple 5QIs can be set per UE Context, each 5QI is counted per QoS flow.

- the triggers of addition for PCell
 - received NG-AP: Initial Context Setup Response

- received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - send NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
 - send NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
- the triggers of subtraction for PCell
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
 - send NG-AP: PDU Session Resource Release Response (PDU Session Release)
 - send NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
 - the triggers of addition for SCell
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
 - the triggers of subtraction for SCell
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the maximum number of the UE Contexts for PCell and SCell. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- e) The measurement name has the form *OR.UECNTX.MaxUes.CellType* or *OR.UECNTX.MaxUes.CellType_Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), *OR.UESA.MaxUes.CellType* or *OR.UESA.MaxUes.CellType_Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level and where *CellType* is the cell type:
- 0: PCell
1: SCell
- f) NRCelLCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.7 Max SCell Configuration UE Contexts

- a) This counter provides the maximum number of each SCell configuration UE Contexts.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of each SCell configuration UE Contexts during the granularity period.
- the triggers of addition
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)

- received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
- the triggers of subtraction
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the maximum number of each SCell configuration UE Contexts.
- e) OR.UECNTX.MaxScellConfigUes.SCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.MaxScellConfigUes.SCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.8 Max Measurement Gap UE Contexts

- a) This counter provides the maximum number of UE Contexts which is configured with measurement gap.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of UE Contexts which is configured with measurement gap during the granularity period.
 - the triggers of addition
 - received RRC: RRC Reconfiguration Complete (setup measurement gap)
 - the triggers of subtraction
 - received RRC: RRC Reconfiguration Complete (release measurement gap)
- d) Each measurement is an integer value representing the maximum number of UE Contexts which is configured with measurement gap.
- e) OR.UECNTX.MaxMeasGapUes (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.MaxMeasGapUes (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.9 Total emergency UE Contexts

- a) This counter provides the total number of the emergency UE Contexts in a Cell.
- b) CC
- c) The measurement is obtained by reporting the total observed value of emergency UE Contexts in a Cell during the granularity period per Cell Type.

emergency UE Contexts: UE Contexts corresponding to ARP number assigned for emergency call or Establishment cause (or Resume cause): emergency is assigned.

- the triggers of addition for PCell
 - send NG-AP: Initial Context Setup Response
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - the triggers of subtraction for PCell
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
 - the triggers of addition for SCell
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
 - the triggers of subtraction for SCell
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the total number of the emergency UE Contexts in a Cell.
- e) OR.UECNTX.TotalEmergencyUes.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.TotalEmergencyUes.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PCell
1: SCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.10 Total high priority access UE Contexts

- a) This counter provides the total number of the high priority access UE Contexts in a Cell.
- b) CC
- c) The measurement is obtained by reporting the total observed value of high priority access UE Contexts in a Cell during the granularity period per Cell Type.

high priority access UE Contexts: UE Contexts corresponding to ARP number assigned for high priority access call or Establishment cause (or Resume cause): highPriorityAccess is assigned.

- the triggers of addition for PCell
 - send NG-AP: Initial Context Setup Response
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - the triggers of subtraction for PCell
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
 - the triggers of addition for SCell
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
 - the triggers of subtraction for SCell
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the total number of the high priority access UE Contexts in a Cell.
- e) OR.UECNTX.TotalHighPriAccessUes.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.TotalHighPriAccessUes.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PCell
1: SCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.11 Max emergency UE Contexts

- a) This counter provides the maximum number of the Emergency UE Contexts in a Cell.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of the Emergency UE Contexts in a Cell during the granularity period per Cell Type.

Emergency UE Contexts: UEs corresponding to ARP number assigned for emergency call or Establishment cause (or Resume cause): emergency is assigned.

- the triggers of addition for PCell
 - send NG-AP: Initial Context Setup Response

- received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - the triggers of subtraction for PCell
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
 - the triggers of addition for SCell
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
 - the triggers of subtraction for SCell
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the maximum number of the Emergency UE Contexts in a Cell.
- e) OR.UECNTX.MaxEmergencyUes.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.MaxEmergencyUes.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PCell
1: SCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.12 Max high priority access UE Contexts

- a) This counter provides the maximum number of the high priority access UE Contexts in a Cell.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of the high priority access UE Contexts in a Cell during the granularity period per Cell Type.

high priority access UE Contexts: UE Contexts corresponding to ARP number assigned for high priority access call or Establishment cause (or Resume cause): highPriorityAccess is assigned.

- the triggers of addition for PCell
 - send NG-AP: Initial Context Setup Response
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))

- received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - the triggers of subtraction for PCell
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
 - the triggers of addition for SCell
 - received RRC: RRC Reconfiguration Complete (SCell addition/change)
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected with SCell addition)
 - the triggers of subtraction for SCell
 - received RRC: RRC Reconfiguration Complete (SCell release/change)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn)
 - received NG-AP: UE Context Release Command
- d) Each measurement is an integer value representing the maximum number of the high priority access UE Contexts in a Cell.
- e) OR.UECNTX.MaxHighPriAccessUes.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.MaxHighPriAccessUes.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PCell
1: SCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.13 Total SN terminated split bearer UE Contexts in NR-DC

- a) This counter provides the total number of UE Contexts configured as SN terminated split bearer in the NR-DC.
- b) CC
- c) The measurement is obtained by reporting the total observed value of the UE Contexts configured as SN terminated split bearer in the NR-DC during the granularity period.

These subcounters only cover SCell-users with P(S)Cell in the same gNB. The inter-gNB CA is not covered.

- the triggers of addition for PCell
 - send Xn-AP: SN Reconfiguration Complete (SN Addition, Inter-Master HO w/o SN change, Inter-Master HO w/ SN change, PCell change (Intra-MN) (for target cell))
- the triggers of subtraction for PCell
 - send Xn-AP: SN Reconfiguration Complete (PCell change (Intra-MN) (for source cell))
 - send Xn-AP: UE Context Release (SN Release without keeping UE, SN Release with keeping UE, RRC Connection Re-establishment (Intra gNB-CU), NG HO)

- received Xn-AP: UE Context Release (MN to gNB Change, Inter-Master HO w/o SN change, Inter-Master HO w/ SN change, RRC Connection Re-establishment (Inter gNB-CU))
 - the triggers of addition for PSCell
 - received Xn-AP: SN Reconfiguration Complete (to SN terminated split bearer)
 - received Xn-AP: S-Node Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for target cell))
 - received RRC: RRC Reconfiguration Complete (Intra DU PSCell change using SRB3 (for target cell))
 - the triggers of subtraction for PSCell
 - received Xn-AP: S-Node Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for source cell))
 - received RRC: RRC Reconfiguration Complete (Intra DU PSCell change using SRB3 (for source cell))
 - received Xn-AP: UE Context Release
- d) Each measurement is an integer value representing the total number of UE Contexts configured as SN terminated split bearer in the NR-DC.
- e) OR.UECNTX.TotalSnSplitbearUes.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UENRDC.TotalSnSplitbearUes.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PCell
1: PSCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.14 Max SN terminated split bearer UE Contexts in NR-DC

- a) This counter provides the maximum number of UE Contexts configured as SN terminated split bearer in the NR-DC.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of the UE Contexts configured as SN terminated split bearer in the NR-DC during the granularity period.

These subcounters only cover Scell-users with P(S)Cell in the same gNB. The inter-gNB CA is not covered.

- the triggers of addition for PCell
 - send Xn-AP: SN Reconfiguration Complete (SN Addition, Inter-Master HO w/o SN change, Inter-Master HO w/ SN change, PCell change (Intra-MN) (for target cell))
- the triggers of subtraction for PCell
 - send Xn-AP: SN Reconfiguration Complete (PCell change (Intra-MN) (for source cell))
 - send Xn-AP: UE Context Release (SN Release without keeping UE, SN Release with keeping UE, RRC Connection Re-establishment (Intra gNB-CU), NG HO)
 - received Xn-AP: UE Context Release (MN to gNB Change, Inter-Master HO w/o SN change, Inter-Master HO w/ SN change, RRC Connection Re-establishment (Inter gNB-CU))
- the triggers of addition for PSCell
 - received Xn-AP: SN Reconfiguration Complete (to SN terminated split bearer)
 - received Xn-AP: S-Node Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for target cell))
 - received RRC: RRC Reconfiguration Complete (Intra DU PSCell change using SRB3 (for target cell))
- the triggers of subtraction for PSCell
 - received Xn-AP: S-Node Modification Confirm (Intra/Inter DU PSCell change using SRB1 (for source cell))

- received RRC: RRC Reconfiguration Complete (Intra DU PSCell change using SRB3 (for source cell))
 - received Xn-AP: UE Context Release
- d) Each measurement is an integer value representing the maximum number of UE Contexts configured as SN terminated split bearer in the NR-DC.
- e) OR.UECNTX.MaxSnSplitbearUes.*Celltype* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UENRDC.MaxSnSplitbearUes.*Celltype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *Celltype* is the cell type:
- 0: PCell
1: PSCell
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.5.15 Total UE Contexts during voice call

- a) This counter provides the total number of the UE Contexts during voice call.
- b) CC
- c) The measurement is obtained by reporting the total observed value of the UE Contexts during voice call during the granularity period.
- the triggers of addition
 - send NG-AP: Initial Context Setup Response
 - received RRC: RRC Reconfiguration Complete (Inter RAT HO to NR, Inter gNB-CU HO, Intra gNB-CU Inter gNB-DU HO, Intra-DU Inter Cell HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU), RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received RRC: RRC Resume Complete (RRC inactive to RRC Connected)
 - the triggers of subtraction
 - send RRC: RRC Release (UE Context Release, RRC Connected to RRC inactive, SN Release without keeping UE)
 - received Xn-AP: UE Context Release (Inter gNB-CU HO, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter-RAT HO to LTE, Intra gNB-CU Inter gNB-DU HO, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-Cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter Cell))
 - received F1-AP: UE Context Release Command (RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
- d) Each measurement is an integer value representing the total number of the UE Contexts during voice call.
- e) OR.UECNTX.TotalUesVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.UESA.TotalUesVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6 Monitoring of procedure for EN-DC

A.2.6.1 Number of SgNB Addition procedure attempted for each Cell

- a) This counter provides the number of the transmitted X2-AP:SGNB ADDITION REQUEST ACKNOWLEDGE messages.
- b) CC
- c) Measurement counter is incremented by 1 whenever X2-AP:SGNB ADDITION REQUEST ACKNOWLEDGE message is transmitted as PSCell.
- d) Each measurement is an integer value representing the number of the transmitted X2-AP:SGNB ADDITION REQUEST ACKNOWLEDGE messages.
- e) OR.UCNTX.SgnbAddAttemptCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbAddAttemptCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.2 Number of SgNB Addition procedure successfully for each Cell

- a) This counter provides the number of the completed SgNB addition Procedure.
- b) CC
- c) Measurement counter is incremented by 1 whenever SgNB addition procedure is completed as PSCell (i.e. X2-AP:SGNB RECONFIGURATION COMPLETE message (SgNB addition complete) is received and RACH processing with UE is completed).
- d) Each measurement is an integer value representing the number of the completed SgNB addition Procedure.
- e) OR.UCNTX.SgnbAddSuccessCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbAddSuccessCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.3 Number of SgNB Addition procedure attempted for each neighbour eNB

- a) This counter provides the number of the transmitted X2-AP:SGNB ADDITION REQUEST ACKNOWLEDGE messages.

This counter is split into subcounters per neighbour eNB.

- b) CC

- c) Measurement subcounter is incremented by 1 whenever X2-AP:SGNB ADDITION REQUEST ACKNOWLEDGE message is transmitted when the eNB configured by the message is group of subcounter.*neighboureNB*.
- d) Each measurement is an integer value representing the number of the transmitted X2-AP:SGNB ADDITION REQUEST ACKNOWLEDGE messages.
- e) OR.UECNTX.SgnbAddAttemptNeiEnb.*neighboureNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbAddAttemptNeiEnb.*neighboureNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighboureNB* is neighbour eNB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.4 Number of SgNB Addition procedure successfully for each neighbour eNB

- a) This counter provides the number of the completed SgNB addition Procedure.
This counter is split into subcounters per neighbour eNB.
- b) CC
- c) Measurement counter is incremented by 1 whenever SgNB addition procedure is completed (i.e. X2-AP:SGNB RECONFIGURATION COMPLETE message (SgNB addition complete) is received and RACH processing with UE is completed) when the eNB configured by the message is group of subcounter.*neighboureNB*.
- d) Each measurement is an integer value representing the number of the completed SgNB addition Procedure.
- e) OR.UECNTX.SgnbAddSuccessNeiEnb.*neighboureNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbAddSuccessNeiEnb.*neighboureNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighboureNB* is neighbour eNB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.5 Number of SgNB modification procedure attempted for each neighbour eNB

- a) This counter provides the number of the received X2-AP:SGNB MODIFICATION REQUEST messages or transmitted X2-AP:SGNB MODIFICATION REQUIRED messages.

This counter is split into subcounters per neighbour eNB.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever X2-AP:SGNB MODIFICATION REQUEST message is received or X2-AP:SGNB MODIFICATION REQUIRED message is transmitted , when the eNB configured by the message is group of subcounter.*neighboureNB*.

Double counting is not performed if the procedure is changed to the MN initiated SN Modification procedure after transmitted X2-AP:SGNB MODIFICATION REQUIRED message (e.g. Measurement gap Coordination(SN initiated)).

This subcounter will not be incremented if received X2-AP:SGNB MODIFICATION REQUEST message which True is set for SCG Configuration Query IE.
- d) Each measurement is an integer value representing the number of the received X2-AP:SGNB MODIFICATION REQUEST messages or transmitted X2-AP:SGNB MODIFICATION REQUIRED messages.
- e) OR.UECNTX.SgnbModAttemptNeiEnb.*neighboureNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbModAttemptNeiEnb.*neighboureNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighboureNB* is neighbour eNB index:

0: #0
1: #1
...
63: #63
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.6 Number of SgNB modification procedure successfully for each neighbour eNB

- a) This counter provides the number of the completed SgNB modification Procedure.

This counter is split into subcounters per neighbour eNB.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever SgNB Modification procedure is completed (i.e. X2-AP:SGNB RECONFIGURATION COMPLETE message(SgNB modification complete) is received or X2-AP:SGNB MODIFICATION CONFIRM is received and RACH processing with UE is completed) when the eNB configured by the message is group of subcounter.*neighboureNB*.
- d) Each measurement is an integer value representing the number of the completed SgNB modification Procedure.
- e) OR.UECNTX.SgnbModSuccessNeiEnb.*neighboureNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbModSuccessNeiEnb.*neighboureNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighboureNB* is neighbour eNB index:

0: #0
1: #1
...
63: #63
- f) GNBCUCPFunction
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.7 Number of Inter gNB-DU PSCell change using SRB1 for RRC Reconfiguration attempted

- a) This counter provides the number of transmitted X2AP- SgNB Modification Required messages when the following procedure.
 - PSCell Change using SRB1 for RRC Reconfiguration – full configuration option, clause 5.6.15 [i.7]
 - PSCell Change using SRB1 for RRC Reconfiguration – delta configuration option, clause 5.6.16 [i.7]
- b) CC
- c) Measurement is incremented by 1 whenever X2AP- SgNB Modification Required message is transmitted when the following procedure.
 - PSCell Change using SRB1 for RRC Reconfiguration – full configuration option, clause 5.6.15 [i.7]
 - PSCell Change using SRB1 for RRC Reconfiguration – delta configuration option, clause 5.6.16 [i.7]
- d) Each measurement is an integer value representing number of transmitted X2AP- SgNB Modification Required messages.
- e) OR.UECNTX.InterGnbDuPscellchSrb1Attempt (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.InterGnbDuPscellchSrb1Attempt (deprecated, refer to NOTE in REQ-PMcas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.8 Number of Inter gNB-DU PSCell change using SRB1 for RRC Reconfiguration successful

- a) This counter provides the number of the received X2AP- SgNB Modification Confirm message when the following procedure.
 - PSCell Change using SRB1 for RRC Reconfiguration – full configuration option, clause 5.6.15 [i.7]
 - PSCell Change using SRB1 for RRC Reconfiguration – delta configuration option, clause 5.6.16 [i.7]
- b) CC
- c) Measurement is incremented by 1 whenever X2AP- SgNB Modification Confirm message is received when the following procedure.
 - PSCell Change using SRB1 for RRC Reconfiguration – full configuration option, clause 5.6.15 [i.7]
 - PSCell Change using SRB1 for RRC Reconfiguration – delta configuration option, clause 5.6.16 [i.7]
- d) Each measurement is an integer value representing number of received X2AP- SgNB Modification Confirm messages.

- e) OR.UECNTX.InterGnbDuPscellchSrb1Success (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.InterGnbDuPscellchSrb1Success (deprecated, refer to NOTE in REQ-PMcas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.9 Number of Intra gNB-DU PSCell Change via SRB1 attempted

- a) This counter provides the number of transmitted X2AP- SgNB Modification Required messages when the following procedure.
 - Intra gNB-DU PSCell Change using SRB1 for RRC Reconfiguration, clause 5.6.17 [i.7]
- b) CC
- c) Measurement is incremented by 1 whenever X2AP- SgNB Modification required message is transmitted when the following procedure.
 - Intra gNB-DU PSCell Change using SRB1 for RRC Reconfiguration, clause 5.6.17 [i.7]
- d) Each measurement is an integer value representing number of transmitted X2AP- SgNB Modification Required messages.
- e) OR.UECNTX.IntraGnbDuPscellchSrb1Attempt (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.IntraGnbDuPscellchSrb1Attempt (deprecated, refer to NOTE in REQ-PMcas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.10 Number of Intra gNB-DU PSCell Change via SRB1 successfully

- a) This counter provides the number of received X2AP- SgNB Modification Confirm message when the following procedure.
 - Intra gNB-DU PSCell Change using SRB1 for RRC Reconfiguration, clause 5.6.17 [i.7]
- b) CC
- c) Measurement is incremented by 1 whenever X2AP- SgNB Modification Confirm message is received when the following procedure.
 - Intra gNB-DU PSCell Change using SRB1 for RRC Reconfiguration, clause 5.6.17 [i.7]
- d) Each measurement is an integer value representing number of received X2AP- SgNB Modification Confirm messages.
- e) OR.UECNTX.IntraGnbDuPscellchSrb1Success (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.IntraGnbDuPscellchSrb1Success (deprecated, refer to NOTE in REQ-PMcas-MC-5)
- f) NRCellCU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.6.11 Number of SgNB addition procedure requested for each neighbour eNB

- a) This counter provides the number of SgNB addition request messages received at SgNB.
This counter splits into subcounters per neighbour eNB.
- b) CC
- c) Measurement subcounter is incremented by 1 for each neighbour eNB whenever an X2-AP:SGNB ADDITION REQUEST message is received at SgNB.
- d) Each measurement is an integer value representing the number of received X2-AP:SGNB ADDITION REQUEST messages at SgNB.
- e) OR.UECNTX.SgnbAddReqNeiEnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ENDCPROCEDURE.SgnbAddReqNeiEnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighbourNB* is neighbour eNB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) GNBCUCPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.7 Monitoring of RRC Connection for EN-DC

A.2.7.1 Number of Measurement Gap Coordination for per FR2 gap via SRB3 attempted

- a) This counter provides the number of the transmitted RRC:RRC Reconfiguration messages via SRB3 when the following procedure.
 - Measurement Gap Coordination for per FR2 gap (without MN involvement) Procedure (SN initiated).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRCReconfiguration message is transmitted via SRB3 when the following procedure.
 - Measurement Gap Coordination for per FR2 gap (without MN involvement) Procedure (SN initiated).
- d) Each measurement is an integer value representing the number of the transmitted RRC:RRC Reconfiguration messages via SRB3.
- e) OR.RRC.ReconfSrb3AttemptGap (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.ReconfSrb3AttemptGap (deprecated, refer to NOTE in REQ-PMeas-MC-5)

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.7.2 Number of Measurement Gap Coordination for per FR2 gap via SRB3 successfully

- a) This counter provides the number of the received RRC:RRC Reconfiguration Complete messages via SRB3 when the following procedure.
 - Measurement Gap Coordination for per FR2 gap (without MN involvement) Procedure (SN initiated).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRCReconfiguration Complete message is received via SRB3 when the following procedure.
 - Measurement Gap Coordination for per FR2 gap (without MN involvement) Procedure (SN initiated).
- d) Each measurement is an integer value representing the number of the received RRC:RRC Reconfiguration Complete messages via SRB3.
- e) OR.RRC.ReconfSrb3SuccessGap (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.RRCCONENDC.ReconfSrb3SuccessGap (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.7.3 Number of Inter gNB-DU PSCell Change via SRB3 attempted

- a) This counter provides the number of the transmitted RRC:RRC Reconfiguration messages via SRB3 when the following procedure.
 - Inter gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRCReconfiguration message is transmitted via SRB3 when the following procedure.
 - Inter gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- d) Each measurement is an integer value representing the number of the transmitted RRC:RRC Reconfiguration messages via SRB3.
- e) OR.RRC.ReconfSrb3AttemptInterDuPscellch (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.RRCCONENDC.ReconfSrb3AttemptInterDuPscellch (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.7.4 Number of Inter gNB-DU PSCell Change via SRB3 successfully

- a) This counter provides the number of the received RRC:RRC Reconfiguration Complete messages via SRB3 when the following procedure.
 - Inter gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRCReconfiguration Complete message is received via SRB3 when the following procedure.
 - Inter gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- d) Each measurement is an integer value representing the number of the transmitted RRC:RRC Reconfiguration messages via SRB3.
- e) OR.RRC.ReconfSrb3SuccessInterDuPscellch (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.ReconfSrb3SuccessInterDuPscellch (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.7.5 Number of Intra gNB-DU PSCell Change via SRB3 attempted

- a) This counter provides the number of the transmitted RRC:RRC Reconfiguration messages via SRB3 when the following procedure.
 - Intra gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRCReconfiguration message is transmitted via SRB3 when the following procedure.
 - Intra gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- d) Each measurement is an integer value representing the number of the transmitted RRC:RRC Reconfiguration messages via SRB3.
- e) OR.RRC.ReconfSrb3AttemptIntraDuPscellch (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.ReconfSrb3AttemptIntraDuPscellch (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.7.6 Number of Intra gNB-DU PSCell Change via SRB3 successfully

- a) This counter provides the number of the received RRC:RRC Reconfiguration Complete messages via SRB3 when the following procedure.
 - Intra gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRCReconfiguration Complete message is received via SRB3 when the following procedure.
 - Intra gNB-DU PSCell Change using SRB3 for RRC Reconfiguration
- d) Each measurement is an integer value representing the number of the received RRC:RRC Reconfiguration Complete messages via SRB3.
- e) OR.RRC.ReconfSrb3SuccessIntraDuPscellch (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONENDC.ReconfSrb3SuccessIntraDuPscellch (deprecated, refer to NOTE in REQ-PM meas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8 Monitoring of RRC Connection for SA

A.2.8.1 Number of initial RRC Connection requests

- a) This counter provides the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is in the first time for each ue-Identity.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Request (or RRC: RRC Resume Request) message is received via F1-C, if RRC: RRC Setup Request (or RRC: RRC Resume Request) message of the same ue-Identity is not received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is in the first time for each ue-Identity.
- e) OR.RRC.IniConReq (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONSA.IniConReq (deprecated, refer to NOTE in REQ-PM meas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.2 Number of RRC connection completions for initial RRC Connection requests

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the initial RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Response) message which corresponds to the initial RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure is received via F1-C.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the initial RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.
- e) OR.RRC.IniConComp (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.RRCCONSA.IniConComp (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.3 Number of retransmission RRC Connections requests

- a) This counter provides the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is retransmission for each ue-Identity.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Request (or RRC: RRC Resume Request) message is received via F1-C, if RRC: RRC Setup Request (or RRC: RRC Resume Request) message of the same ue-Identity is received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is retransmission for each ue-Identity.
- e) OR.RRC.RetConReq (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.RRCCONSA.RetConReq (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.4 Number of RRC Connections completions for retransmission RRC Connections requests

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the retransmission RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.

- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Response) message which corresponds to the retransmission RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure is received via F1-C.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the retransmission RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.
- e) OR.RRC.RetransConComp (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONSA.RetransConComp (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.5 Number of incomplete RRC Connection by failed resource allocations

- a) This counter provides the number of the RRC Connection configuration interrupted by failed resource allocations.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC Connection configuration is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to RRC: RRC Setup Complete (or RRC: RRC Resume Complete) by failed resource allocations.
- d) Each measurement is an integer value representing the number of the RRC Connection configuration interrupted by failed resource allocations.
- e) OR.RRC.IncompConResourAllo (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONSA.IncompConResourAllo (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.6 Number of incomplete RRC Connection by O-CU internal error

- a) This counter provides the number of the RRC Connection configuration interrupted by O-CU internal error (e.g. L3 message sending NG).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC Connection configuration is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to RRC: RRC Setup Complete (or RRC: RRC Resume Complete) by O-CU internal error.
- d) Each measurement is an integer value representing the number of the RRC Connection configuration interrupted by O-CU internal error (e.g. L3 message sending NG).

- e) OR.RRC.IncompConOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONSA.IncompConOcuInterErr (deprecated, refer to NOTE in REQ-PMMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.7 Number of initial RRC Connection requests each Establishment Cause

- a) This counter provides the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is in the first time for each ue-Identity.

This counter is split into subcounters per EstablishmentCause.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC: RRC Setup Request (or RRC: RRC Resume Request) message is received via F1-C, if RRC: RRC Setup Request (or RRC: RRC Resume Response) message of the same ue-Identity is not received for a certain period of time from the reception timing when the cell configured by the message is group of subcounter.*EstablishmentCause*.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is in the first time for each ue-Identity.
- e) OR.RRC.IniConReqEstaCause.*EstablishmentCause* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCCONSA.IniConReqEstaCause.*EstablishmentCause* (deprecated, refer to NOTE in REQ-PMMeas-MC-5), where *EstablishmentCause* is EstablishmentCause:

0: EstablishmentCause = emergency

1: EstablishmentCause = highPriorityAccess

2: EstablishmentCause = mt-Access

3: EstablishmentCause = mo-Signalling

4: EstablishmentCause = mo-Data

5: EstablishmentCause = mo-VoiceCall

6: EstablishmentCause = mo-VideoCall

7: EstablishmentCause = mo-SMS

8: EstablishmentCause = mps-PriorityAccess

9: EstablishmentCause = mcs-PriorityAccess

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.8 Number of RRC connection completions for initial RRC Connection requests each Establishment Cause

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the initial RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.

This counter is split into subcounters per EstablishmentCause.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC:RRC Setup Complete (or RRC: RRC Resume Response) message which corresponds to the initial RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure is received via F1-C when the cell configured by the message is group of subcounter.*EstablishmentCause*.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the initial RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.
- e) OR.RRC.IniConCompEstaCause.*EstablishmentCause* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCONSA.IniConCompEstaCause.*EstablishmentCause* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *EstablishmentCause* is EstablishmentCause:

0: EstablishmentCause = emergency

1: EstablishmentCause = highPriorityAccess

2: EstablishmentCause = mt-Access

3: EstablishmentCause = mo-Signalling

4: EstablishmentCause = mo-Data

5: EstablishmentCause = mo-VoiceCall

6: EstablishmentCause = mo-VideoCall

7: EstablishmentCause = mo-SMS

8: EstablishmentCause = mps-PriorityAccess

9: EstablishmentCause = mcs-PriorityAccess

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.9 Number of retransmission RRC Connections requests each Establishment Cause

- a) This counter provides the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is retransmission for each ue-Identity.

This counter is split into subcounters per EstablishmentCause.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC: RRC Setup Request (or RRC: RRC Resume Request) message is received via F1-C, if RRC: RRC Setup Request (or RRC: RRC Resume Request) message of the same ue-

Identity is received for a certain period of time from the reception timing when the cell configured by the message is group of subcounter.*EstablishmentCause*.

- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Request (or RRC: RRC Resume Request) messages via F1-C which is retransmission for each ue-Identity.
- e) OR.RRC.RetransConReqEstaCause.*EstablishmentCause* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCONSA.RetransConReqEstaCause.*EstablishmentCause* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *EstablishmentCause* is EstablishmentCause:
 - 0: EstablishmentCause = emergency
 - 1: EstablishmentCause = highPriorityAccess
 - 2: EstablishmentCause = mt-Access
 - 3: EstablishmentCause = mo-Signalling
 - 4: EstablishmentCause = mo-Data
 - 5: EstablishmentCause = mo-VoiceCall
 - 6: EstablishmentCause = mo-VideoCall
 - 7: EstablishmentCause = mo-SMS
 - 8: EstablishmentCause = mps-PriorityAccess
 - 9: EstablishmentCause = mcs-PriorityAccess
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.10 Number of RRC Connections completions for retransmission RRC Connections requests each Establishment Cause

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the retransmission RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.
This counter is split into subcounters per EstablishmentCause.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Response) message which corresponds to the retransmission RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure is received via F1-C when the cell configured by the message is group of subcounter.*EstablishmentCause*.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Response) messages via F1-C which corresponds to the retransmission RRC: RRC Setup Request (or RRC: RRC Resume Request) except fall-back procedure.
- e) OR.RRC.RetransConCompEstaCause.*EstablishmentCause* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCONSA.RetransConCompEstaCause.*EstablishmentCause* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *EstablishmentCause* is EstablishmentCause:

- 0: EstablishmentCause = emergency
- 1: EstablishmentCause = highPriorityAccess
- 2: EstablishmentCause = mt-Access
- 3: EstablishmentCause = mo-Signalling
- 4: EstablishmentCause = mo-Data
- 5: EstablishmentCause = mo-VoiceCall
- 6: EstablishmentCause = mo-VideoCall
- 7: EstablishmentCause = mo-SMS
- 8: EstablishmentCause = mps-PriorityAccess
- 9: EstablishmentCause = mcs-PriorityAccess

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.11 Number of incomplete RRC Connection by failed resource allocations each Establishment Cause

- a) This counter provides the number of the RRC Connection configuration interrupted by failed resource allocations.
This counter is split into subcounters per EstablishmentCause.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC Connection configuration is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to RRC: RRC Setup Complete (or RRC: RRC Resume Complete) by failed resource allocations when the cell configured by the message is group of subcounter.*EstablishmentCause*.
- d) Each measurement is an integer value representing the number of the RRC Connection configuration interrupted by failed resource allocations.
- e) OR.RRC.IncompConResourAlloEstaCause.*EstablishmentCause* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCONSA.IncompConResourAlloEstaCause.*EstablishmentCause* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *EstablishmentCause* is EstablishmentCause:
 - 0: EstablishmentCause = emergency
 - 1: EstablishmentCause = highPriorityAccess
 - 2: EstablishmentCause = mt-Access
 - 3: EstablishmentCause = mo-Signalling
 - 4: EstablishmentCause = mo-Data
 - 5: EstablishmentCause = mo-VoiceCall
 - 6: EstablishmentCause = mo-VideoCall
 - 7: EstablishmentCause = mo-SMS

8: EstablishmentCause = mps-PriorityAccess

9: EstablishmentCause = mcs-PriorityAccess

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.8.12 Number of incomplete RRC Connection by O-CU internal error each Establishment Cause

- a) This counter provides the number of the RRC Connection configuration interrupted by O-CU internal error (e.g. L3 message sending NG).

This counter is split into subcounters per EstablishmentCause.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC Connection configuration is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to RRC: RRC Setup Complete (or RRC: RRC Resume Complete) by O-CU internal error when the cell configured by the message is group of subcounter. *EstablishmentCause*.
- d) Each measurement is an integer value representing the number of the RRC Connection configuration interrupted by O-CU internal error (e.g. L3 message sending NG).
- e) OR.RRC.IncompConOcuInterErrEstaCause.*EstablishmentCause* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RRCONSA.IncompConOcuInterErrEstaCause.*EstablishmentCause* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *EstablishmentCause* is EstablishmentCause:

0: EstablishmentCause = emergency

1: EstablishmentCause = highPriorityAccess

2: EstablishmentCause = mt-Access

3: EstablishmentCause = mo-Signalling

4: EstablishmentCause = mo-Data

5: EstablishmentCause = mo-VoiceCall

6: EstablishmentCause = mo-VideoCall

7: EstablishmentCause = mo-SMS

8: EstablishmentCause = mps-PriorityAccess

9: EstablishmentCause = mcs-PriorityAccess

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9 Monitoring of Establishment calls for SA

A.2.9.1 Number of attempted establishment calls for mo-Data

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (Resume Cause):mo-Data).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Complete) message is received via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-Data).
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (Resume Cause):mo-Data).
- e) OR.RRC.AttemptModata (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.AttemptModata (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.2 Number of successful establishment calls for mo-Data

- a) This counter provides the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mt-Data):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- b) CC
- c) Measurement counter is incremented by 1 whenever the following event occurs after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-Data):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
 Measurement counter is incremented by 1 whenever NG-AP:Initial Context Setup Response message is transmitted after received RRC: RRC Setup Request (Establishment Cause: mo-Data).
- d) Each measurement is an integer value representing the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mt-Data):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- e) OR.RRC.SuccessModata (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.SuccessModata (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.3 Number of incomplete establishment calls for mo-Data by protocol error

- a) This counter provides the number of the Call establishment for mo-Data interrupted by protocol error.
- b) CC
- c) Measurement counter is incremented by 1 whenever Call establishment for mo-Data is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by protocol error.
- d) Each measurement is an integer value representing the number of the Call establishment for mo-Data interrupted by protocol error.
- e) OR.RRC.IncompModataProtocolErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompModataProtocolErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.4 Number of incomplete establishment calls for mo-Data by O-CU internal error

- a) This counter provides the number of the call establishment for mo-Data interrupted by O-CU internal error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mo-Data is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-CU internal error.
- d) Each measurement is an integer value representing the number of the call establishment for mo-Data interrupted by O-CU internal error.
- e) OR.RRC.IncompModataOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompModataOcuInterErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.5 Number of incomplete establishment calls for mo-Data by O-DU error detection

- a) This counter provides the number of the call establishment for mo-Data interrupted by O-DU Error Detection.

- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mo-Data is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-DU Error Detection.
- d) Each measurement is an integer value representing the number of the call establishment for mo-Data interrupted by O-DU Error Detection.
- e) OR.RRC.IncompModataOduErrDetect (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompModataOduErrDetect (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.6 Number of attempted establishment calls for mt-Access

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mt-Access).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Complete) message is received via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mt-Access).
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mt-Access).
- e) OR.RRC.AttemptMtaccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.AttemptMtaccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.7 Number of successful establishment calls for mt-Access

- a) This counter provides the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause):mt-Access):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- b) CC

- c) Measurement counter is incremented by 1 whenever the following event occurs after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause):mt-Access):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- d) Each measurement is an integer value representing the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause):mt-Access):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- e) OR.RRC.SuccessMtaccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.SuccessMtaccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.8 Number of incomplete establishment calls for mt-Access by protocol error

- a) This counter provides the number of the call establishment for mt-Access interrupted by protocol error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mt-Access is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by protocol error.
- d) Each measurement is an integer value representing the number of the call establishment for mt-Access interrupted by protocol error.
- e) OR.RRC.IncompMtaccessProtocolErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.IncompMtaccessProtocolErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.9 Number of incomplete establishment calls for mt-Access by O-CU internal error

- a) This counter provides the number of the call establishment for mt-Access interrupted by O-CU internal error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mt-Access is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-CU internal error.

- d) Each measurement is an integer value representing the number of the call establishment for mt-Access interrupted by O-CU internal error.
- e) OR.RRC.IncompMtaccessOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMtaccessOcuInterErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.10 Number of incomplete establishment calls for mt-Access by O-DU error detection

- a) This counter provides the number of the call establishment for mt-Access is interrupted by O-DU Error Detection.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mt-Access is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by DU Error Detection.
- d) Each measurement is an integer value representing the number of the call establishment for mt-Access is interrupted by O-DU Error Detection.
- e) OR.RRC.IncompMtaccessOduErrDetect (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMtaccessOduErrDetect (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.11 Number of attempted establishment calls for mo-Signalling

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause):mo-Signalling).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Complete) message is received via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause):mo-Signalling).
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause):mo-Signalling).
- e) OR.RRC.AcceptMosignal (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.AcceptMosignal (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.12 Number of successful establishment calls for mo-Signalling

- a) This counter provides the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-Signalling):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- b) CC
- c) Measurement counter is incremented by 1 whenever the following event occurs after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-Signalling):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- d) Each measurement is an integer value representing the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-Signalling):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- e) OR.RRC.SuccessMosignal (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.SuccessMosignal (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.13 Number of incomplete establishment calls for mo-Signalling by protocol error

- a) This counter provides the number of the call establishment for mo-Signalling interrupted by protocol error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mo-Signalling is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by protocol error.
- d) Each measurement is an integer value representing the number of the call establishment for mo-Signalling interrupted by protocol error.
- e) OR.RRC.IncompMosignalProtocolErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.IncompMosignalProtocolErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.14 Number of incomplete establishment calls for mo-Signalling by O-CU internal error

- a) This counter provides the number of the call establishment for mo-Signalling interrupted by O-CU internal error.
- b) CC
- c) Measurement counter is incremented by 1 whenever mo-Signalling configuration is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-CU internal error.
- d) Each measurement is an integer value representing the number of the call establishment for mo-Signalling interrupted by O-CU internal error.
- e) OR.RRC.IncompMosignalOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMosignalOcuInterErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.15 Number of incomplete establishment calls for mo-Signalling by O-DU error detection

- a) This counter provides the number of the call establishment for mo-Signalling interrupted by O-DU error detection.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mo-Signalling is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-DU error detection.
- d) Each measurement is an integer value representing the number of the call establishment for mo-Signalling interrupted by O-DU error detection.
- e) OR.RRC.IncompMosignalDuErrDetect (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMosignalDuErrDetect (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.16 Number of attempted establishment calls for mo-SMS

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-SMS).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Complete) message is received via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-SMS).
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-SMS).
- e) OR.RRC.AttemptMossmms (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.AttemptMossmms (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.17 Number of successful establishment calls for mo-SMS

- a) This counter provides the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-SMS):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- b) CC
- c) Measurement counter is incremented by 1 whenever the following event occurs after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-SMS):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- d) Each measurement is an integer value representing the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): mo-SMS):
 - send NG-AP: Initial Context Setup Response
 - received NG-AP: UE Context Release Command (for deregistration) before sending NG-AP: Initial Context Setup Response
- e) OR.RRC.SuccessMossmms (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.SuccessMossmms (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.2.9.18 Number of incomplete establishment calls for mo-SMS by protocol error

- a) This counter provides the number of the call establishment for mo-SMS interrupted by protocol error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mo-SMS is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by protocol error.
- d) Each measurement is an integer value representing the number of the call establishment for mo-SMS interrupted by protocol error.
- e) OR.RRC.IncompMossmProtocolErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMossmProtocolErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.19 Number of incomplete establishment calls for mo-SMS by O-CU internal error

- a) This counter provides the number of the call establishment for mo-SMS interrupted by O-CU internal error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for mo-SMS is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-CU internal error.
- d) Each measurement is an integer value representing the number of the call establishment for mo-SMS interrupted by O-CU internal error.
- e) OR.RRC.IncompMossmOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMossmOcuInterErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.20 Number of incomplete establishment calls for mo-SMS by O-DU error detection

- a) This counter provides the number of the call establishment for mo-SMS interrupted by O-DU error detection.
- b) CC

- c) Measurement counter is incremented by 1 whenever call establishment for mo-SMS is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-DU error detection.
- d) Each measurement is an integer value representing the number of the call establishment for mo-SMS interrupted by O-DU error detection.
- e) OR.RRC.IncompMossmOduErrDetect (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompMossmOduErrDetect (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.21 Number of attempted establishment calls for high priority access

- a) This counter provides the number of the received RRC: RRC Setup Complete messages (or RRC: RRC Resume Complete) via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): highPriorityAccess).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Complete) message is received via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): highPriorityAccess).
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete messages (or RRC: RRC Resume Complete) via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): highPriorityAccess).
- e) OR.RRC.AttemptHighPriAccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.AttemptHighPriAccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.22 Number of successful establishment calls for high priority access

- a) This counter provides the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): highPriorityAccess):
 - NG-AP: Initial Context Setup Response is transmitted.
 - NG-AP: UE Context Release Command (for detach) is received before NG-AP: Initial Context Setup Response is transmitted.
- b) CC
- c) Measurement counter is incremented by 1 whenever the following event occurs after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): highPriorityAccess):

- send NG-AP: Initial Context Setup Response
 - NG-AP: UE Context Release Command (for detach) is received before NG-AP: Initial Context Setup Response is transmitted.
- d) Each measurement is an integer value representing the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): highPriorityAccess):
- NG-AP: Initial Context Setup Response is transmitted.
 - NG-AP: UE Context Release Command (for detach) is received before NG-AP: Initial Context Setup Response is transmitted.
- e) OR.RRC.SuccessHighPriAccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.SuccessHighPriAccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.23 Number of incomplete establishment calls for high priority access by protocol error

- a) This counter provides the number of the call establishment for high priority access interrupted by protocol error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for high priority access is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by protocol error (Call acceptance condition of CU/DU is not met).
- d) Each measurement is an integer value representing the number of the call establishment for high priority access interrupted by protocol error.
- e) OR.RRC.IncompHighPriAccessProtocolErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.IncompHighPriAccessProtocolErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.24 Number of incomplete establishment calls for high priority access by O-CU internal error

- a) This counter provides the number of the call establishment for high priority access interrupted by O-CU internal error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for high priority access is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-CU internal error (Call acceptance condition of CU/DU is not met).
- d) Each measurement is an integer value representing the number of the call establishment for high priority access interrupted by O-CU internal error.

- e) OR.RRC.IncompHighPriAccessOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompHighPriAccessOcuInterErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.25 Number of incomplete establishment calls for high priority access by O-DU error detection

- a) This counter provides the number of the call establishment for high priority access interrupted by O-DU error detection.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for high priority access is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-DU error detection (Call acceptance condition of CU/DU is not met).
- d) Each measurement is an integer value representing the number of the call establishment for high priority access interrupted by O-DU error detection.
- e) OR.RRC.IncompHighPriAccessOduErrDetect (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompHighPriAccessOduErrDetect (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.26 Number of attempted establishment calls for emergency

- a) This counter provides the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): emergency).
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete (or RRC: RRC Resume Complete) message is received via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): emergency).
- d) Each measurement is an integer value representing the number of the received RRC: RRC Setup Complete (or RRC: RRC Resume Complete) messages via F1-C after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): emergency).
- e) OR.RRC.AttemptEmergency (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.AttemptEmergency (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.27 Number of successful establishment calls for emergency

- a) This counter provides the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): emergency):
 - send NG-AP: Initial Context Setup Response
 - NG-AP: UE Context Release Command (for detach) is received before NG-AP: Initial Context Setup Response is transmitted.
- b) CC
- c) Measurement counter is incremented by 1 whenever the following event occurs after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): emergency):
 - NG-AP: Initial Context Setup Response is transmitted.
 - NG-AP: UE Context Release Command (for detach) is received before NG-AP: Initial Context Setup Response is transmitted.
- d) Each measurement is an integer value representing the number of the following message after received RRC: RRC Setup Request (or RRC: RRC Resume Request) (Establishment Cause (or Resume Cause): emergency):
 - send NG-AP: Initial Context Setup Response
 - NG-AP: UE Context Release Command (for detach) is received before NG-AP: Initial Context Setup Response is transmitted.
- e) OR.RRC.SuccessEmergency (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.SuccessEmergency (deprecated, refer to NOTE in REQ-PMMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.28 Number of incomplete establishment calls for emergency by protocol error

- a) This counter provides the number of the call establishment for emergency interrupted by protocol error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for emergency is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by protocol error (Call acceptance condition of CU/DU is not met).
- d) Each measurement is an integer value representing the number of the call establishment for emergency interrupted by protocol error.
- e) OR.RRC.IncompEmergencyProtocolErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ESTACALL.IncompEmergencyProtocolErr (deprecated, refer to NOTE in REQ-PMMeas-MC-5)
- f) NRCellCU
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.29 Number of incomplete establishment calls for emergency by O-CU internal error

- a) This counter provides the number of the call establishment for emergency interrupted by O-CU internal error.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for emergency is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-CU internal error (Call acceptance condition of CU/DU is not met).
- d) Each measurement is an integer value representing the number of the call establishment for emergency interrupted by O-CU internal error.
- e) OR.RRC.IncompEmergencyOcuInterErr (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompEmergencyOcuInterErr (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.30 Number of incomplete establishment calls for emergency by O-DU error detection

- a) This counter provides the number of the call establishment for emergency interrupted by O-DU error detection.
- b) CC
- c) Measurement counter is incremented by 1 whenever call establishment for emergency is interrupted between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete) by O-DU error detection (Call acceptance condition of CU/DU is not met).
- d) Each measurement is an integer value representing the number of the call establishment for emergency interrupted by O-DU error detection.
- e) OR.RRC.IncompEmergencyOduErrDetect (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ESTACALL.IncompEmergencyOduErrDetect (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.9.31 Void

A.2.9.32 Discarded paging records

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

O-RAN addition:

The counter is optionally split into subcounter per Paging Priority.

The counter is optionally split into subcounter per Paging Origin.

It is an optional counter for O-CU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

O-RAN addition:

The subcounter per Paging Priority level is incremented by 1 for each Paging Priority whenever a paging record is including Paging Priority is discarded at the gNB-CU.

NOTE 1: Paging Priority is defined in 3GPP TS 38.413 [i.5], clause 9.3.1.78.

The subcounter per Paging Origin level is incremented by 1 for each paging origin whenever a paging record including paging origin is discarded at the gNB-CU.

NOTE 2: Paging Origin is defined in 3GPP TS 38.413 [i.5], clause 9.3.3.22.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

O-RAN addition:

Subcounter OR.PAG.DiscardedNbrCnInitiated.*PagingPriority* where *PagingPriority* is Paging Priority number:

0: PrioLevel1

1: PrioLevel2

...

7: PrioLevel8

Subcounter OR.PAG.DiscardedNbrCnInitiated.*PagingOrigin* where *PagingOrigin* identifies the Paging Origin IE.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.4

- i) Network Operator's Traffic Engineering Community

A.2.10 Monitoring of PDU session connection for SA

A.2.10.1 Accepted PDU Session Resource Configuration

- a) This counter provides the number of the accepted PDU session resource configuration. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever gNB received the following message, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- "NG-AP: Initial Context Setup Request" is received
 - "NG-AP: PDU Session Resource Setup Request"
 - "NG-AP: PDU Session Resource Modify Request"
- d) Each measurement is an integer value representing the number of the accepted PDU session resource configuration. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- e) The measurement name has the form OR.SM.AcceptConfig or OR.SM.AcceptConfig_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.AcceptConfig or OR.PDUSESSION.AcceptConfig_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCelICU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.2 Completed PDU Session Resource Configuration

- a) This counter provides the number of the completed PDU session resource configuration. The measurement is optionally calculated per QoS (5QI or QCI).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever gNB transmitted the following message, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- "NG-AP: Initial Context Setup Response"
 - "NG-AP: PDU Session Resource Setup Response"
 - "NG-AP: PDU Session Resource Modify Response"
- d) Each measurement is an integer value representing the number of the completed PDU session resource configuration. The measurement is optionally calculated per QoS (5QI or QCI).
- e) The measurement name has the form OR.SM.CompConfig or OR.SM.CompConfig_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.CompConfig or OR.PDUSESSION.CompConfig_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCelICU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.3 Interrupted PDU Session Resource configuration by Protocol Error

- a) This counter provides the number of the PDU session resource configuration interrupted by protocol error. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC

- c) Measurement subcounter is incremented by 1 whenever the PDU session resource configuration interrupted in the following interval by protocol error, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete)
 - between Xn-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w Xn)
 - between NG-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w/o Xn)
 - between NG-AP: Handover Request to NG-AP: Handover Notify (Inter RAT HO to NR)
 - between NG-AP: PDU Session Resource Setup Request to NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
 - between NG-AP: PDU Session Resource Modify Request to NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
 - between NG-AP: PDU Session Resource Release Request to NG-AP: PDU Session Resource Release Response (PDU Session Release)
- d) Each measurement is an integer value representing the number of the PDU session resource configuration interrupted by protocol error. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- e) The measurement name has the form OR.SM.InterruptConfigProcolErr or OR.SM.InterruptConfigProcolErr_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.InterruptConfigProcolErr or OR.PDUSESSION.InterruptConfigProcolErr_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.4 Interrupted PDU Session Resource configuration by O-DU Error Detection

- a) This counter provides the number of the PDU session resource configuration interrupted by O-DU error detection. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the PDU session resource configuration interrupted in the following interval by O-DU error detection, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete)
- between Xn-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w Xn)
- between NG-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w/o Xn)
- between NG-AP: Handover Request to NG-AP: Handover Notify (Inter RAT HO to NR)
- between NG-AP: PDU Session Resource Setup Request to NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
- between NG-AP: PDU Session Resource Modify Request to NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
- between NG-AP: PDU Session Resource Release Request to NG-AP: PDU Session Resource Release Response (PDU Session Release)

- d) Each measurement is an integer value representing the number of the PDU session resource configuration interrupted by O-DU error detection.
- e) The measurement name has the form OR.SM.InterruptConfigOduErrDetect or OR.SM.InterruptConfigOduErrDetect_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.InterruptConfigOduErrDetect or OR.PDUSESSION.InterruptConfigOduErrDetect_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCellicu
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.5 Interrupted PDU Session Resource configuration by O-CU internal error

- a) This counter provides the number of the PDU session resource configuration interrupted by O-CU internal error. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the PDU session resource configuration interrupted in the following interval by O-CU internal error, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete)
 - between Xn-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w Xn)
 - between NG-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w/o Xn)
 - between NG-AP: Handover Request to NG-AP: Handover Notify (Inter RAT HO to NR)
 - between NG-AP: PDU Session Resource Setup Request to NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
 - between NG-AP: PDU Session Resource Modify Request to NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
 - between NG-AP: PDU Session Resource Release Request to NG-AP: PDU Session Resource Release Response (PDU Session Release)
- d) Each measurement is an integer value representing the number of the PDU session resource configuration interrupted by O-CU internal error.
 - e) The measurement name has the form OR.SM.InterruptConfigOcuInterErr or OR.SM.InterruptConfigOcuInterErr_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.InterruptConfigOcuInterErr or OR.PDUSESSION.InterruptConfigOcuInterErr_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
 - f) NRCellicu
 - g) Packet Switched
 - h) 5GS
 - i) Network Operator's Traffic Engineering Community

A.2.10.6 Accepted PDU Session Resource Configuration for emergency and high priority access

- a) This counter provides the number of the accepted PDU session resource configuration for emergency and high priority access. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever gNB received the following message after received RRC: RRC Setup Request (Establishment Cause: emergency or high priority access), optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- received NG-AP: Initial Context Setup Request
- received NG-AP: PDU Session Resource Setup Request
- received NG-AP: PDU Session Resource Modify Request
- d) Each measurement is an integer value representing the number of the accepted PDU session resource configuration for emergency and high priority access.
- e) The measurement name has the form OR.SM.AcceptConfigEmergencyHighPriAccess or OR.SM.AcceptConfigEmergencyHighPriAccess_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.AcceptConfigEmergencyHighPriAccess or OR.PDUSESSION.AcceptConfigEmergencyHighPriAccess_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.7 Completed PDU Session Resource Configuration for emergency and high priority access

- a) This counter provides the number of the completed PDU session resource configuration for emergency and high priority access. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever gNB transmitted the following message after received RRC: RRC Setup Request (Establishment Cause: emergency or high priority access), optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- send NG-AP: Initial Context Setup Response
- send NG-AP: PDU Session Resource Setup Response
- send NG-AP: PDU Session Resource Modify Response
- d) Each measurement is an integer value representing the number of the completed PDU session resource configuration for emergency and high priority access.
- e) The measurement name has the form OR.SM.CompConfigEmergencyHighPriAccess or OR.SM.CompConfigEmergencyHighPriAccess_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.CompConfigEmergencyHighPriAccess or OR.PDUSESSION.CompConfigEmergencyHighPriAccess_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCellCU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.8 Interrupted PDU Session Resource configuration for emergency and high priority access by Protocol Error

- a) This counter provides the number of the PDU session resource configuration for emergency and high priority access interrupted by protocol error. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the PDU session resource configuration for emergency and high priority access interrupted in the following interval by protocol error, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete)
- between Xn-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w Xn)
- between NG-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w/o Xn)
- between NG-AP: Handover Request to NG-AP: Handover Notify (Inter RAT HO to NR)
- between NG-AP: PDU Session Resource Setup Request to NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
- between NG-AP: PDU Session Resource Modify Request to NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
- between NG-AP: PDU Session Resource Release Request to NG-AP: PDU Session Resource Release Response (PDU Session Release)
- d) Each measurement is an integer value representing the number of the PDU session resource configuration for emergency and high priority access interrupted by protocol error.
- e) The measurement name has the form OR.SM.InterruptConfigProcolErrEmergencyHighPriAccess or OR.SM.InterruptConfigProcolErrEmergencyHighPriAccess_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.InterruptConfigProcolErrEmergencyHighPriAccess or OR.PDUSESSION.InterruptConfigProcolErrEmergencyHighPriAccess_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.9 Interrupted PDU Session Resource configuration for emergency and high priority access by O-DU Error Detection

- a) This counter provides the number of the PDU session resource configuration for emergency and high priority access interrupted by O-DU error detection. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC

- c) Measurement subcounter is incremented by 1 whenever the PDU session resource configuration for emergency and high priority access interrupted in the following interval by O-DU error detection, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete)
 - between Xn-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w Xn)
 - between NG-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w/o Xn)
 - between NG-AP: Handover Request to NG-AP: Handover Notify (Inter RAT HO to NR)
 - between NG-AP: PDU Session Resource Setup Request to NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
 - between NG-AP: PDU Session Resource Modify Request to NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
 - between NG-AP: PDU Session Resource Release Request to NG-AP: PDU Session Resource Release Response (PDU Session Release)
- d) Each measurement is an integer value representing the number of the PDU session resource configuration for emergency and high priority access interrupted by O-DU error detection.
- e) The measurement name has the form OR.SM.InterruptConfigOduErrDetectEmergencyHighPriAccess or OR.SM.InterruptConfigOduErrDetectEmergencyHighPriAccess_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.InterruptConfigOduErrDetectEmergencyHighPriAccess or OR.PDUSESSION.InterruptConfigOduErrDetectEmergencyHighPriAccess_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.10.10 Interrupted PDU Session Resource configuration for emergency and high priority access by O-CU internal Error

- a) This counter provides the number of the PDU session resource configuration for emergency and high priority access interrupted by O-CU internal error. The measurement is optionally calculated per QoS (mapped 5QI or QCI in EN-DC).
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the PDU session resource configuration for emergency and high priority access interrupted in the following interval by O-CU internal error, optionally calculated per QoS.

NOTE: multiple 5QIs can be set per PDU session, each 5QI is counted per QoS flow.

- between RRC: RRC Setup Request (or RRC: RRC Resume Request) to NG-AP: Initial Context Setup Response (or RRC: RRC Resume Complete)
- between Xn-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w Xn)
- between NG-AP: Handover Request to NG-AP: Path Switch Acknowledge (Inter gNB-CU HO w/o Xn)
- between NG-AP: Handover Request to NG-AP: Handover Notify (Inter RAT HO to NR)
- between NG-AP: PDU Session Resource Setup Request to NG-AP: PDU Session Resource Setup Response (PDU Session Establishment)
- between NG-AP: PDU Session Resource Modify Request to NG-AP: PDU Session Resource Modify Response (PDU Session Modification)
- between NG-AP: PDU Session Resource Release Request to NG-AP: PDU Session Resource Release Response (PDU Session Release)

- d) Each measurement is an integer value representing the number of the PDU session resource configuration for emergency and high priority access interrupted by O-CU internal error.
- e) The measurement name has the form OR.SM.InterruptConfigOcuInterErrEmergencyHighPriAccess or OR.SM.InterruptConfigOcuInterErrEmergencyHighPriAccess_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDUSESSION.InterruptConfigOcuInterErrEmergencyHighPriAccess or OR.PDUSESSION.InterruptConfigOcuInterErrEmergencyHighPriAccess_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is QoS and represents the mapped 5QI or QCI level.
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11 Monitoring of mobility for SA

A.2.11.1 Accepted Handover

- a) This counter provides the number of the accepted Intra RAT handover.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB decides to perform Intra RAT HO procedure by the received (transmitted) following messages:
 - Intra-Cell HO: transmitted "RRC: RRC Reconfiguration"
 - HO procedure other than those above: received "RRC: Measurement report"
- d) Each measurement is an integer value representing the number of the accepted Intra RAT handover.
- e) OR.MM.AcceptHo (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.MOBILITY.AcceptHo (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.2 Completed Handover

- a) This counter provides the number of the completed Intra RAT handover.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB detects successful Intra RAT handover procedure triggered by source gNB by the received following messages:
 - Intra-gNB HO: received "RRC: RRC Reconfiguration Complete"
 - HO procedure other than those above: received "XnAP:UE CONTEXT RELEASE" from the target gNB at Xn HO or "NGAP: UE CONTEXT RELEASE COMMAND" from AMF at NG HO
- d) Each measurement is an integer value representing the number of the completed Intra RAT handover.

- e) OR.MM.CompHo (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.MOBILITY.CompHo (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.3 Accepted Inter RAT Handover to LTE

- a) This counter provides the number of the accepted Inter RAT Handover to LTE.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB decides to perform Inter RAT HO to LTE procedure by the received following messages:
 - received RRC: Measurement report (Inter RAT HO to LTE)
- d) Each measurement is an integer value representing the number of the accepted Inter RAT Handover to LTE.
- e) OR.MM.AcceptHotoLte (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.MOBILITY.AcceptHotoLte (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.4 Completed Inter RAT Handover to LTE

- a) This counter provides the number of the completed Inter RAT Handover to LTE.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB detects successful handover procedure triggered by source gNB by the received following messages:
 - received NG-AP: UE Context Release Command (Inter RAT HO to LTE)
- d) Each measurement is an integer value representing the number of the completed Inter RAT Handover to LTE.
- e) OR.MM.CompHotoLte (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.MOBILITY.CompHotoLte (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.5 Accepted EPS Fallback

- a) This counter provides the number of the accepted EPS Fallback.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell decides to perform EPS Fallback procedure by the received following messages:
 - received NG-AP: PDU Session Resource Modify Request (EPS Fallback)
- d) Each measurement is an integer value representing the number of the accepted EPS Fallback.
- e) OR.MM.AcceptEpsFallback (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.MOBILITY.AcceptEpsFallback (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.6 Completed EPS Fallback

- a) This counter provides the number of the completed EPS Fallback.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell detects successful EPS Fallback procedure triggered by the received following messages:
 - received NG-AP: UE Context Release Command (EPS Fallback)
- d) Each measurement is an integer value representing the number of the completed EPS Fallback.
- e) OR.MM.CompEpsFallback (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.MOBILITY.CompEpsFallback (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.7 Normal interrupted EPS Fallback

- a) This counter provides the number of the completed EPS Fallback.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell detects interrupted EPS Fallback procedure triggered by the received following messages:
 - received NG-AP: UE Context Release Command (Cause:Deregister) during EPS Fallback procedure
- d) Each measurement is an integer value representing the number of the completed EPS Fallback.

- e) OR.MM.NormalInterruptedEpsFallback (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MOBILITY.NormalInterruptedEpsFallback (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.8 Accepted Handover during Voice call

- a) This counter provides the number of the accepted Intra RAT handover during voice call.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB decides to perform Intra RAT HO procedure by the received (transmitted) following messages during voice call:
 - transmitted RRC: RRC Reconfiguration (Intra-cell HO)
 - HO procedure other than those above: received RRC: Measurement report
- d) Each measurement is an integer value representing the number of the accepted Intra RAT handover during voice call.
- e) OR.MM.AcceptHoVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MOBILITY.AcceptHoVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.9 Completed Handover during Voice call

- a) This counter provides the number of the completed Intra RAT handover during voice call.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB detects successful Intra RAT handover procedure triggered by source gNB by the received following messages during voice call:
 - received RRC: RRC Reconfiguration Complete (Intra gNB-CU Inter gNB-DU HO, Intra gNB-DU Inter-cell HO)
 - HO procedure other than those above: received Xn-AP: UE CONTEXT RELEASE (Inter gNB-CU HO w/ Xn),
NG-AP: UE CONTEXT RELEASE COMMAND (Inter gNB-CU HO w/o Xn)
- d) Each measurement is an integer value representing the number of the completed Intra RAT handover during voice call.
- e) OR.MM.CompHoVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MOBILITY.CompHoVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.2.11.10 Accepted Inter RAT Handover to LTE during Voice call

- a) This counter provides the number of the accepted Inter RAT handover to LTE during voice call.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB decides to perform Inter RAT HO to LTE procedure by the received following messages during voice call:
 - received RRC: Measurement report that triggers Inter RAT HO to LTE
- d) Each measurement is an integer value representing the number of the accepted Inter RAT handover to LTE during voice call.
- e) OR.MM.AcceptHotoLteVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MOBILITY.AcceptHotoLteVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.11.11 Completed Inter RAT Handover to LTE during Voice call

- a) This counter provides the number of the completed Inter RAT handover during voice call.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever source gNB detects successful Inter RAT handover procedure triggered by source gNB by the received following messages during voice call:
 - received NG-AP: UE CONTEXT RELEASE COMMAND from the AMF at Inter RAT HO to LTE
- d) Each measurement is an integer value representing the number of the completed Inter RAT handover during voice call.
- e) OR.MM.CompHotoLteVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MOBILITY.CompHotoLteVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12 Monitoring of RRC re-establishment for SA

A.2.12.1 Number of initial RRC re-establishment requests when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reestablishment Request messages via F1-C which is in the first time for each ReestabUE-Identity when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reestablishment Request message is received via F1-C when UE context can be retrieved, if RRC: RRC Reestablishment Request of the same ReestabUE-Identity is not received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reestablishment Request messages via F1-C which is in the first time for each ReestabUE-Identity when UE context can be retrieved.
- e) OR.RRC.IniReqUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.IniReqUecontext (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.2 Number of RRC re-establishment request completions for initial RRC re-establishment requests when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the initial RRC: RRC Reestablishment Request when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reconfiguration Complete message which corresponds to the initial RRC: RRC Reestablishment Request is received via F1-C when UE context can be retrieved.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the initial RRC: RRC Reestablishment Request when UE context can be retrieved.
- e) OR.RRC.IniReqCompUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.IniReqCompUecontext (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.3 Number of retransmission RRC re-establishment requests when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reestablishment Request messages via F1-C which is the retransmission for each ReestabUE-Identity when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reestablishment Request message is received via F1-C when UE context can be retrieved, if RRC: RRC Reestablishment Request message of the same ReestabUE-Identity is received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reestablishment Request messages via F1-C which is the retransmission for each ReestabUE-Identity when UE context can be retrieved.
- e) OR.RRC.RetaransReqUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.REEST.RetaransReqUecontext (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.4 Number of RRC re-establishment request completions for retransmission RRC re-establishment request when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the retransmission RRC: RRC Reestablishment Request when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reconfiguration Complete message which corresponds to the retransmission RRC: RRC Reestablishment Request is received via F1-C when UE context can be retrieved.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the retransmission RRC: RRC Reestablishment Request when UE context can be retrieved.
- e) OR.RRC.RetaransReqCompUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.REEST.RetaransReqCompUecontext (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.5 Number of initial RRC re-establishment requests when UE context cannot be retrieved

- a) This counter provides the number of the received RRC: RRC Reestablishment Request messages via F1-C which is in the first time for each ReestabUE-Identity when UE context cannot be retrieved.

- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reestablishment Request message is received via F1-C when UE context cannot be retrieved, if RRC: RRC Reestablishment Request of the same ReestabUE-Identity is not received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reestablishment Request messages via F1-C which is in the first time for each ReestabUE-Identity when UE context cannot be retrieved.
- e) OR.RRC.IniReqNotUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.IniReqNotUecontext (deprecated, refer to NOTE in REQ-PMes-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.6 Number of RRC re-establishment request completions for initial RRC re-establishment requests when UE context cannot be retrieved

- a) This counter provides the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the initial RRC: RRC Reestablishment Request when UE context cannot be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Setup Complete message which corresponds to the initial RRC: RRC Reestablishment Request is received via F1-C when UE context cannot be retrieved.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the initial RRC: RRC Reestablishment Request when UE context cannot be retrieved.
- e) OR.RRC.IniReqCompNotUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.IniReqCompNotUecontext (deprecated, refer to NOTE in REQ-PMes-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.7 Number of retransmission RRC re-establishment requests when UE context cannot be retrieved

- a) This counter provides the number of the received RRC: RRC Reestablishment Request messages via F1-C which is the retransmission for each ReestabUE-Identity when UE context cannot be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reestablishment Request message is received via F1-C when UE context cannot be retrieved, if RRC: RRC Reestablishment Request message of the same ReestabUE-Identity is received for a certain period of time from the reception timing.

- d) Each measurement is an integer value representing the number of the received RRC: RRC Reestablishment Request messages via F1-C which is the retransmission for each ReestabUE-Identity when UE context cannot be retrieved.
- e) OR.RRC.RetransReqNotUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.RetransReqNotUecontext (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.8 Number of RRC re-establishment request completions for retransmission RRC re-establishment requests when UE context cannot be retrieved

- a) This counter provides the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the retransmission RRC: RRC Reestablishment Request when UE context cannot be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reconfiguration Complete message which corresponds to the retransmission RRC: RRC Reestablishment Request is received via F1-C when UE context cannot be retrieved.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the retransmission RRC: RRC Reestablishment Request when UE context cannot be retrieved.
- e) OR.RRC.RetransReqCompNotUecontext (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.RetransReqCompNotUecontext (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.9 Number of initial RRC re-establishment requests during Voice call when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reestablishment Request messages via F1-C which is in the first time for each ReestabUE-Identity during voice call when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reestablishment Request message is received via F1-C during voice call when UE context can be retrieved, if RRC: RRC Reestablishment Request of the same ReestabUE-Identity is not received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reestablishment Request messages via F1-C which is in the first time for each ReestabUE-Identity during voice call when UE context can be retrieved.
- e) OR.RRC.IniReqUecontextVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.REEST.IniReqUecontextVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.10 Number of RRC re-establishment request completions for initial RRC re-establishment requests during Voice call when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the initial RRC: RRC Reestablishment Request during voice call when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reconfiguration Complete message which corresponds to the initial RRC: RRC Reestablishment Request is received via F1-C during voice call when UE context can be retrieved.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the initial RRC: RRC Reestablishment Request during voice call when UE context can be retrieved.
- e) OR.RRC.IniReqCompUecontextVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.REEST.IniReqCompUecontextVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.11 Number of retransmission RRC re-establishment requests during Voice call when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reestablishment Request messages via F1-C which is the retransmission for each ReestabUE-Identity during voice call when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reestablishment Request message is received via F1-C during voice call when UE context can be retrieved, if RRC: RRC Reestablishment Request message of the same ReestabUE-Identity is received for a certain period of time from the reception timing.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reestablishment Request messages via F1-C which is the retransmission for each ReestabUE-Identity during voice call when UE context can be retrieved.
- e) OR.RRC.RetaransReqUecontextVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.REEST.RetaransReqUecontextVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.12.12 Number of RRC re-establishment request completions for retransmission RRC re-establishment request during Voice call when UE context can be retrieved

- a) This counter provides the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the retransmission RRC: RRC Reestablishment Request during voice call when UE context can be retrieved.
- b) CC
- c) Measurement counter is incremented by 1 whenever RRC: RRC Reconfiguration Complete message which corresponds to the retransmission RRC: RRC Reestablishment Request is received via F1-C during voice call when UE context can be retrieved.
- d) Each measurement is an integer value representing the number of the received RRC: RRC Reconfiguration Complete messages via F1-C which corresponds to the retransmission RRC: RRC Reestablishment Request during voice call when UE context can be retrieved.
- e) OR.RRC.RetaransReqCompUecontextVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.REEST.RetaransReqCompUecontextVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.13 Monitoring of connection status for SA

A.2.13.1 Normally Released Calls

- a) This counter provides the number of the normally released calls.
- b) CC
- c) Measurement subcounter is incremented by the number of the normally released calls. Normal released calls is as follows:
 - received NG-AP: UE Context Release Command (Cause: Normal release or Deregister)
 - the expiry of a UE inactivity timer, the gNB release the RRC connection
- d) Each measurement is an integer value representing the number of the normally released calls.
- e) OR.UECNTX.NormalRelCalls (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CONNECTSTATUS.NormalRelCalls (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.13.2 Abnormally Released Calls

- a) This counter provides the number of the abnormally released calls.
- b) CC
- c) Measurement subcounter is incremented by the number of the abnormally released calls.
 - Trigger timing: when gNB release the UE Context except for the Normally Released calls (A.2.13.1) and Another Cell HO UE Contexts (A.2.13.3).
- d) Each measurement is an integer value representing the number of the abnormally released calls.
- e) OR.UECNTX.AbnormalRelCalls (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CONNECTSTATUS.AbnormalRelCalls (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.13.3 Another Cell HO UE Contexts

- a) This counter provides the number of the UE Contexts which has transferred to another cell.
- b) CC
- c) Measurement subcounter is incremented by the number of the UE Contexts which has transferred to another cell. Another Cell released call is as follows:
 - received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter gNB-CU HO w/o Xn, Inter-RAT HO to LTE, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter-cell))
 - received F1-AP: UE Context Release Command (Intra gNB-CU Inter gNB-DU HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
- d) Each measurement is an integer value representing the number of the UE Contexts which has transferred to another cell.
- e) OR.UECNTX.AnotherCellHoUes (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CONNECTSTATUS.AnotherCellHoUes (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.13.4 Normally Released Calls during voice call

- a) This counter provides the number of the normally released calls during voice call.
- b) CC
- c) Measurement subcounter is incremented by the number of the normally released calls during voice call. Normal released calls are as follows:
 - received NG-AP: UE Context Release Command (Cause: Normal release or Deregister)
 - the expiry of a UE inactivity timer, the gNB release the RRC connection
- d) Each measurement is an integer value representing the number of the normally released calls during voice call.
- e) OR.UECNTX.NormalRelCallsVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CONNECTSTATUS.NormalRelCallsVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.13.5 Abnormally Released Calls during voice call

- a) This counter provides the number of the abnormally released calls during voice call.
- b) CC
- c) Measurement subcounter is incremented by the number of the abnormally released calls during voice call.
 - Trigger timing: when gNB release the UE Context except for the Normally Released calls (A.2.13.4) and Another Cell HO UE contexts (A.2.13.6) during voice call.
- d) Each measurement is an integer value representing the number of the abnormally released calls during voice call.
- e) OR.UECNTX.AbnormalRelCallsVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CONNECTSTATUS.AbnormalRelCallsVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.13.6 Another Cell HO UE Contexts during voice call

- a) This counter provides the number of the UE Contexts which has transferred to another cell during voice call.
- b) CC
- c) Measurement subcounter is incremented by the number of the UE Contexts which has transferred to another cell during voice call. Another Cell released calls are as follows:

- received Xn-AP: UE Context Release (Inter gNB-CU HO w/ Xn, RRC Connection Re-establishment (Inter gNB-CU))
 - received NG-AP: UE Context Release Command (Inter gNB-CU HO w/o Xn, Inter-RAT HO to LTE, EPS fallback)
 - received RRC: RRC Reconfiguration Complete (Intra gNB-DU Inter-cell HO, RRC Connection Re-establishment (Intra gNB-DU Inter-cell))
 - received F1-AP: UE Context Release Command (Intra gNB-CU Inter gNB-DU HO, RRC Connection Re-establishment (Intra gNB-CU Inter gNB-DU))
- d) Each measurement is an integer value representing the number of the UE Contexts which has transferred to another cell during voice call.
- e) OR.UECNTX.AnotherCellHoUesVoice (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CONNECTSTATUS.AnotherCellHoUesVoice (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14 Monitoring of procedure for NR-DC

A.2.14.1 Number of S-NG-RAN Node Addition procedure attempted for each Cell

- a) This counter provides the number of the transmitted Xn-AP: S-NODE ADDITION REQUEST ACKNOWLEDGE message.
- b) CC
- c) Measurement counter is incremented by 1 whenever Xn-AP: S-NODE ADDITION REQUEST ACKNOWLEDGE message is transmitted as PSCell.
- d) Each measurement is an integer value representing the number of the transmitted Xn-AP: S-NODE ADDITION REQUEST ACKNOWLEDGE message.
- e) OR.UECNTX.SnAddAttemptCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnAddAttemptCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.2 Number of S-NG-RAN Node Addition procedure successfully for each Cell

- a) This counter provides the number of the completed S-NG-RAN Node addition Procedure.
- b) CC
- c) Measurement counter is incremented by 1 whenever S-NG-RAN Node addition procedure is completed as PSCell (i.e. Xn-AP: S-NODE RECONFIGURATION COMPLETE message (SN addition complete) is received and RACH processing with UE Context is completed).

- d) Each measurement is an integer value representing the number of the completed S-NG-RAN Node addition Procedure.
- e) OR.UECNTX.SnAddSuccessCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.NRDCPROCEDURE.SnAddSuccessCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.3 Number of S-NG-RAN Node Addition procedure attempted for each neighbour gNB

- a) This counter provides the number of the transmitted Xn-AP: S-NODE ADDITION REQUEST ACKNOWLEDGE messages.

This counter is split into subcounters per neighbour gNB.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever Xn-AP: S-NODE ADDITION REQUEST ACKNOWLEDGE message is transmitted when the gNB configured by the message is group of subcounter *neighbourNB*.
- d) Each measurement is an integer value representing the number of the transmitted Xn-AP: S-NODE ADDITION REQUEST ACKNOWLEDGE messages.
- e) OR.UECNTX.SnAddAttemptNeiGnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnAddAttemptNeiGnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighbourNB* is neighbour gNB index:

0: #0
1: #1
...
63: #63
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.4 Number of S-NG-RAN Node Addition procedure successfully for each neighbour gNB

- a) This counter provides the number of the completed S-NG-RAN Node addition Procedure.

This counter is split into subcounters per neighbour gNB.
- b) CC
- c) Measurement counter is incremented by 1 whenever S-NG-RAN Node addition procedure is completed (i.e. Xn-AP: S-NODE RECONFIGURATION COMPLETE message (SN addition complete) is received and RACH processing with UE Context is completed) when the gNB configured by the message is group of subcounter *neighbourNB*.
- d) Each measurement is an integer value representing the number of the completed S-NG-RAN Node addition Procedure.

- e) OR.UECNTX.SnAddSuccessNeiGnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnAddSuccessNeiGnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighbourNB* is neighbour gNB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.5 Number of S-NG-RAN Node modification procedure attempted for each Cell

- a) This counter provides the number of the received Xn-AP: S-NODE MODIFICATION REQUEST messages or transmitted Xn-AP: S-NODE MODIFICATION REQUIRED messages.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever Xn-AP: S-NODE MODIFICATION REQUEST message is received or Xn-AP: S-NODE MODIFICATION REQUIRED message is transmitted as PSCell.

Double counting is not performed if the procedure is changed to the MN initiated SN Modification procedure after transmitted Xn-AP: S-NODE MODIFICATION REQUIRED message (e.g. Measurement gap Coordination (SN initiated)).

This subcounter will not be incremented if received Xn-AP: S-NODE MODIFICATION REQUEST message which True is set for SCG Configuration Query IE.

- d) Each measurement is an integer value representing the number of the received Xn-AP: S-NODE MODIFICATION REQUEST messages or transmitted Xn-AP: S-NODE MODIFICATION REQUIRED messages.
- e) OR.UECNTX.SnModAttemptCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnModAttemptCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.6 Number of S-NG-RAN Node modification procedure successfully for each Cell

- a) This counter provides the number of the completed S-NG-RAN Node modification Procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever SN Modification procedure is completed as PSCell (i.e. Xn-AP: S-NODE RECONFIGURATION COMPLETE message (SN modification complete) is received or Xn-AP: S-NODE MODIFICATION CONFIRM is received and RACH processing with UE Context is completed)

- d) Each measurement is an integer value representing the number of the completed S-NG-RAN Node modification Procedure.
- e) OR.UECNTX.SnModSuccessCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnModSuccessCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.7 Number of S-NG-RAN Node modification procedure attempted for each neighbour gNB

- a) This counter provides the number of the received Xn-AP: S-NODE MODIFICATION REQUEST messages or transmitted Xn-AP: S-NODE MODIFICATION REQUIRED messages.

This counter is split into subcounters per neighbour gNB.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever Xn-AP: S-NODE MODIFICATION REQUEST message is received or Xn-AP: S-NODE MODIFICATION REQUIRED message is transmitted, when the gNB configured by the message is group of subcounter *neighbourNB*.

Double counting is not performed if the procedure is changed to the MN initiated SN Modification procedure after transmitted Xn-AP: S-NODE MODIFICATION REQUIRED message (e.g. Measurement gap Coordination (SN initiated)).

This subcounter will not be incremented if received Xn-AP: S-NODE MODIFICATION REQUEST message which True is set for SCG Configuration Query IE.

- d) Each measurement is an integer value representing the number of the received Xn-AP: S-NODE MODIFICATION REQUEST messages or transmitted Xn-AP: S-NODE MODIFICATION REQUIRED messages.
- e) OR.UECNTX.SnModAttemptNeiGnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnModAttemptNeiGnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighbourNB* is neighbour gNB index:

0: #0
1: #1
...
63: #63

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.8 Number of S-NG-RAN Node modification procedure successfully for each neighbour gNB

- a) This counter provides the number of the completed S-NG-RAN Node modification Procedure.
This counter is split into subcounters per neighbour gNB.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever SN Modification procedure is completed (i.e. Xn-AP: S-NODE RECONFIGURATION COMPLETE message (SN modification complete) is received or Xn-AP: S-NODE MODIFICATION CONFIRM is received and RACH processing with UE Context is completed) when the gNB configured by the message is group of subcounter.*neighbourNB*.
- d) Each measurement is an integer value representing the number of the completed S-NG-RAN Node modification Procedure.
- e) OR.UECNTX.SnModSuccessNeiGnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnModSuccessNeiGnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighbourNB* is neighbour gNB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.9 Number of S-NG-RAN Node Release procedure attempted for each Cell

- a) This counter provides the number of the received Xn-AP: S-NODE RELEASE REQUIRED messages or transmitted Xn-AP: S-NODE RELEASE REQUEST messages.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever Xn-AP: S-NODE RELEASE REQUIRED message is received or Xn-AP: S-NODE RELEASE REQUEST message is transmitted as PSCell.
- d) Each measurement is an integer value representing the number of the received Xn-AP: S-NODE RELEASE REQUIRED messages or transmitted Xn-AP: S-NODE RELEASE REQUEST messages.
- e) OR.UECNTX.SnRelAttemptCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnRelAttemptCell (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.10 Number of S-NG-RAN Node Release procedure successfully for each Cell

- a) This counter provides the number of the completed S-NG-RAN Node Release Procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever SN Release procedure is completed as PSCell (i.e. Xn-AP: UE CONTEXT RELEASE message is transmitted
- d) Each measurement is an integer value representing the number of the completed S-NG-RAN Node Release Procedure.
- e) OR.UECNTX.SnRelSuccessCell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnRelSuccessCell (deprecated, refer to NOTE in REQ-PMcas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.11 Number of S-NG-RAN Node Release procedure attempted for each neighbour gNB

- a) This counter provides the number of the received Xn-AP: S-NODE RELEASE REQUIRED messages or transmitted Xn-AP: S-NODE RELEASE REQUEST messages.

This counter is split into subcounters per neighbour gNB.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever Xn-AP: S-NODE RELEASE REQUIRED message is received or Xn-AP: S-NODE RELEASE REQUEST message is transmitted, when the gNB configured by the message is group of subcounter.*neighbourNB*.
- d) Each measurement is an integer value representing the number of the received Xn-AP: S-NODE RELEASE REQUIRED messages or transmitted Xn-AP: S-NODE RELEASE REQUEST messages.
- e) OR.UECNTX.SnRelAttemptNeiGnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDCPROCEDURE.SnRelAttemptNeiGnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMcas-MC-5) where *neighbourNB* is neighbour gNB index:

0: #0
1: #1
...
63: #63
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.12 Number of S-NG-RAN Node Release procedure successfully for each neighbour gNB

- a) This counter provides the number of the completed S-NG-RAN Node Release Procedure.
This counter is split into subcounters per neighbour gNB.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever SN Release procedure is completed (i.e. Xn-AP: UE CONTEXT RELEASE message is transmitted)
- d) Each measurement is an integer value representing the number of the completed S-NG-RAN Node Release Procedure.
- e) OR.UECNTX.SnRelSuccessNeiGnb.*neighbourNB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDPROCEDURE.SnRelSuccessNeiGnb.*neighbourNB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *neighbourNB* is neighbour gNB index:

0: #0
1: #1
...
63: #63
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.14.13 Number of SCGFailureInformation received

- a) This counter provides the number of SCGFailureInformation received.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RRC: SCG Failure Information message is received.
- d) Each measurement is an integer value representing the number of SCGFailureInformation received.
- e) OR.RRC.NumFailInfoRec (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NRDPROCEDURE.NumFailInfoRec (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.15 Monitoring of CA for SA

A.2.15.1 Number of SCell Addition procedure attempted

- a) This counter provides the number of the attempted SCell addition procedure.
- b) CC

- c) Measurement subcounter is incremented by 1 whenever PCell decides to perform SCell addition procedure by the following trigger.
 - received RRC: Measurement report for SCell addition.
 - SCell addition triggered internal the gNB other than above trigger.
- d) Each measurement is an integer value representing the number of the attempted SCell addition procedure.
- e) OR.RRC.ScCellAddAttempt (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.SACAPROCEDURE.ScCellAddAttempt (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.15.2 Number of SCell Addition procedure successfully

- a) This counter provides the number of the completed SCell addition procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell detects successful SCell addition procedure by the received following messages.
 - received RRC: RRC Reconfiguration Complete for SCell addition.
- d) Each measurement is an integer value representing the number of the completed SCell addition procedure.
- e) OR.RRC.ScCellAddSuccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.SACAPROCEDURE.ScCellAddSuccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.15.3 Number of SCell Change procedure attempted

- a) This counter provides the number of the attempted SCell change procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell decides to perform SCell change procedure by the following trigger.
 - received RRC: Measurement report for SCell change.
 - SCell change triggered internal the gNB other than above trigger.
- d) Each measurement is an integer value representing the number of the attempted SCell change procedure.
- e) OR.RRC.ScCellChangeAttempt (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.SACAPROCEDURE.ScCellChangeAttempt (deprecated, refer to NOTE in REQ-PMeas-MC-5)

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.15.4 Number of SCell Change procedure successfully

- a) This counter provides the number of the completed SCell change procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell detects successful SCell change procedure by the received following messages.
 - received RRC: RRC Reconfiguration Complete for SCell change.
- d) Each measurement is an integer value representing the number of the completed SCell change procedure.
- e) OR.RRC.ScellChangeSuccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.SACAPROCEDURE.ScellChangeSuccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.15.5 Number of SCell Deletion procedure attempted

- a) This counter provides the number of the attempted SCell deletion procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell decides to perform SCell deletion procedure by the following trigger.
 - received RRC: Measurement report for SCell deletion.
 - SCell deletion triggered internal the gNB other than above trigger.
- d) Each measurement is an integer value representing the number of the attempted SCell deletion procedure.
- e) OR.RRC.ScellDeletionAttempt (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.SACAPROCEDURE.ScellDeletionAttempt (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.2.15.6 Number of SCell Deletion procedure successfully

- a) This counter provides the number of the completed SCell deletion procedure.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PCell detects successful SCell deletion procedure by the received following messages.
 - received RRC: RRC Reconfiguration Complete for SCell deletion.
- d) Each measurement is an integer value representing the number of the completed SCell deletion procedure.
- e) OR.RRC.ScellDeletionSuccess (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.SACAPROCEDURE.ScellDeletionSuccess (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3 O-CU-UP Performance measurements

A.3.1 NR PDCP performance measurements

A.3.1.1 Distribution of UE per UL received data volume

- a) This counter provides the distribution of the UE per received uplink data volume. When more than one RLCs are configured, the data volume refers to all volume regardless through which RLC the data is transferred. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) If O-CU connects 5GC, the measurement is the number of the QoS flow of which x is mapped to bin of subcounter *binX*. If O-CU connects EPC, the measurement is the number of the bearer of which x is mapped to the bin of subcounter *binX*. The number, x is acquired and calculated at the end of granularity period.

 x is incremented by the volume of the UL PDCP PDU volume whenever the UL PDCP PDU is received from lower layer, and optionally when the UL PDCP PDU is mapped to the filter.
- d) Each measurement is an integer value representing the distribution of the UE per received uplink data volume.
- e) The measurement name has the form OR.DRB.DistUeUlRxData.*binX* or OR.DRB.DistUeUlRxData.*binX_Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DistUeUlRxData.*binX* or OR.PDCP.DistUeUlRxData.*binX_Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI, and where *binX* is the bin of the throughput, x :

 bin 1: $0 \text{ Byte} < x < 1 \text{ kByte}$
 bin 2: $1 \text{ kByte} \leq x < 2 \text{ kByte}$
 bin 3: $2 \text{ kByte} \leq x < 5 \text{ kByte}$
 bin 4: $5 \text{ kByte} \leq x < 10 \text{ kByte}$
 bin 5: $10 \text{ kByte} \leq x < 20 \text{ kByte}$
 bin 6: $20 \text{ kByte} \leq x < 50 \text{ kByte}$

- bin 7: $50 \text{ kByte} \leq x < 100 \text{ kByte}$
- bin 8: $100 \text{ kByte} \leq x < 200 \text{ kByte}$
- bin 9: $200 \text{ kByte} \leq x < 500 \text{ kByte}$
- bin 10: $500 \text{ kByte} \leq x < 1 \text{ MByte}$
- bin 11: $1 \text{ MByte} \leq x < 1.5 \text{ MByte}$
- bin 12: $1.5 \text{ MByte} \leq x < 2 \text{ MByte}$
- bin 13: $2 \text{ MByte} \leq x < 2.5 \text{ MByte}$
- bin 14: $2.5 \text{ MByte} \leq x < 3 \text{ MByte}$
- bin 15: $3 \text{ MByte} \leq x < 3.5 \text{ MByte}$
- bin 16: $3.5 \text{ MByte} \leq x < 4 \text{ MByte}$
- bin 17: $4 \text{ MByte} \leq x < 4.5 \text{ MByte}$
- bin 18: $4.5 \text{ MByte} \leq x < 5 \text{ MByte}$
- bin 19: $5 \text{ MByte} \leq x < 10 \text{ MByte}$
- bin 20: $10 \text{ MByte} \leq x$

- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.2 Distribution of DL UE throughput in O-CU

- a) This counter provides the distribution of the UE throughput in downlink. When more than one RLCs are configured, the data volume refers to the all volume regardless through which RLC the data is transferred.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) If O-CU connects 5GC, the measurement is the number of the QoS flow of which throughput, x/y is mapped to bin of subcounter.*binX*.

If O-CU connects EPC, the measurement is the number of the bearer of which throughput, x/y is mapped to bin of subcounter.*binX*.

The number, x/y is acquired and calculated at the end of granularity period.

x is incremented by the volume of the DL PDCP PDU volume which is acknowledged by the DDDS whenever DDDS is received, and optionally when PDCP PDU is mapped to the filter.

y is the smaller value in the followings:

- $y = \Sigma(y1 - y2)$:
where y1 is the point in time after y2 when data up until the second last piece of data in the transmitted data burst which emptied the PDCP SDU available for transmission for the filterable group was successfully transmitted, as acknowledged by the UE, and where y2 is the point in time when the first transmission begins after a PDCP SDU becomes available for transmission, where previously no PDCP SDUs were available for transmission for the particular filter.
- The measurement reporting period could be pre-defined (e.g: 60000 ms).

- d) Each measurement is an integer value representing the distribution of the UE throughput in downlink.
- e) The measurement name has the form OR.DRB.DistDIUeThroughput.*binX* or OR.DRB.DistDIUeThroughput.*binX_Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DistDIUeThroughput.*binX* or OR.PDCP.DistDIUeThroughput.*binX_Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a

combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI, and where $binX$ is the bin of the throughput, x/y :

- bin 1: $0 \text{ Mbps} \leq x/y < 1 \text{ Mbps}$
- bin 2: $1 \text{ Mbps} \leq x/y < 2 \text{ Mbps}$
- bin 3: $2 \text{ Mbps} \leq x/y < 5 \text{ Mbps}$
- bin 4: $5 \text{ Mbps} \leq x/y < 10 \text{ Mbps}$
- bin 5: $10 \text{ Mbps} \leq x/y < 20 \text{ Mbps}$
- bin 6: $20 \text{ Mbps} \leq x/y < 50 \text{ Mbps}$
- bin 7: $50 \text{ Mbps} \leq x/y < 100 \text{ Mbps}$
- bin 8: $100 \text{ Mbps} \leq x/y < 200 \text{ Mbps}$
- bin 9: $200 \text{ Mbps} \leq x/y < 500 \text{ Mbps}$
- bin 10: $500 \text{ Mbps} \leq x/y < 1 \text{ Gbps}$
- bin 11: $1 \text{ Gbps} \leq x/y < 1.5 \text{ Gbps}$
- bin 12: $1.5 \text{ Gbps} \leq x/y < 2 \text{ Gbps}$
- bin 13: $2 \text{ Gbps} \leq x/y < 2.5 \text{ Gbps}$
- bin 14: $2.5 \text{ Gbps} \leq x/y < 3 \text{ Gbps}$
- bin 15: $3 \text{ Gbps} \leq x/y < 3.5 \text{ Gbps}$
- bin 16: $3.5 \text{ Gbps} \leq x/y < 4 \text{ Gbps}$
- bin 17: $4 \text{ Gbps} \leq x/y < 4.5 \text{ Gbps}$
- bin 18: $4.5 \text{ Gbps} \leq x/y < 5 \text{ Gbps}$
- bin 19: $5 \text{ Gbps} \leq x/y < 10 \text{ Gbps}$
- bin 20: $10 \text{ Gbps} \leq x/y$

- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.3 Total discarded UL PDCP SDU volume

- a) This counter provides the UL PDCP SDU volume discarded at PDCP due to any cause. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement counter is incremented by the volume of the UL PDCP SDU whenever the UL PDCP SDU is discarded, and optionally when the UL PDCP SDU is mapped to the filter.
- d) Each measurement is an integer value representing the UL PDCP SDU volume discarded at PDCP due to any cause in kilobits.
- e) The measurement name has the form OR.DRB.TotalDiscardedUIPdcPsdVol or OR.DRB.TotalDiscardedUIPdcPsdVol_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.TotalDiscardedUIPdcPsdVol or OR.PDCP.TotalDiscardedUIPdcPsdVol_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level and SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.4 UL PDCP SDU volume discarded due to bearer release

- a) This counter provides the UL PDCP SDU volume discarded at PDCP due to bearer release.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement counter is incremented by the volume of the UL PDCP SDU whenever the UL PDCP SDU is discarded due to bearer release, and optionally when the UL PDCP SDU is mapped to the filter.
- d) Each measurement is an integer value representing the UL PDCP SDU volume discarded at PDCP due to bearer release in kilobits.
- e) The measurement name has the form OR.DRB.UIPdcpsduVolDiscardBearerRel or OR.DRB.UIPdcpsduVolDiscardBearerRel_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.UIPdcpsduVolDiscardBearerRel or OR.PDCP.UIPdcpsduVolDiscardBearerRel_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.5 Total discarded DL PDCP SDU volume

- a) This counter provides the DL PDCP SDU volume discarded at PDCP due to any causes.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement counter is incremented by the volume of the DL PDCP SDU whenever the DL PDCP SDU is discarded, and optionally when the DL PDCP SDU is mapped to the filter.
- d) Each measurement is an integer value representing the DL PDCP SDU volume discarded at PDCP due to any causes in kilobits.
- e) The measurement name has the form OR.DRB.TotalDiscardedDIPdcpsduVol or OR.DRB.TotalDiscardedDIPdcpsduVol_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.TotalDiscardedDIPdcpsduVol or OR.PDCP.TotalDiscardedDIPdcpsduVol_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level, SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.6 DL PDCP SDU volume discarded due to bearer release

- a) This counter provides the DL PDCP SDU volume discarded at PDCP due to bearer release.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement counter is incremented by the volume of the DL PDCP SDU whenever the DL PDCP SDU is discarded due to bearer release, and optionally when the DL PDCP SDU is mapped to the filter.
- d) Each measurement is an integer value representing the DL PDCP SDU volume discarded at PDCP due to bearer release in kilobits.
- e) The measurement name has the form OR.DRB.DIPdcpSduVolDiscardLessBearerRel or OR.DRB.DIPdcpSduVolDiscardLessBearerRel_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DIPdcpSduVolDiscardLessBearerRel or OR.PDCP.DIPdcpSduVolDiscardLessBearerRel_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.7 DL PDCP SDU volume discarded due to out of memory

- a) This counter provides the DL PDCP SDU volume discarded at PDCP due to out of memory.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement counter is incremented by the volume of the DL PDCP SDU whenever the DL PDCP SDU is discarded due to out of memory, and optionally when the DL PDCP SDU is mapped to the filter.
- d) Each measurement is an integer value representing the DL PDCP SDU volume discarded at PDCP due to out of memory in kilobits.
- e) The measurement name has the form OR.DRB.DIPdcpSduVolDiscardOutOfMemory or optionally OR.DRB.DIPdcpSduVolDiscardOutOfMemory_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DIPdcpSduVolDiscardOutOfMemory or optionally OR.PDCP.DIPdcpSduVolDiscardOutOfMemory_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.8 PDCP transmission stop

- a) This counter provides the number of the detection of PDCP transmission stop.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement counter is incremented by 1 whenever PDCP transmission stop is occurred, and optionally when the PDCP SDU is mapped to the filter. It is incremented by 1 at most in each filter for one radio bearer until the transmission stop is resolved.
- d) Each measurement is an integer value representing the number of the detection of PDCP transmission stop.
- e) The measurement name has the form OR.DRB.TxStop or optionally OR.DRB.TxStop_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.TxStop or optionally OR.PDCP.TxStop_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.9 UL F1-U packet loss rate

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
O-RAN addition:
The split into subcounters per S-NSSAI is recommended when the Slicing feature is supported.
The split into subcounters per QoS is recommended where QoS identifies the target quality of service class.
- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
O-RAN addition:
The numbers are accumulated in the granularity period T.
- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.2

A.3.1.10 UL PDCP SDU Loss Rate

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1
- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1

- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1

O-RAN addition:

The numbers are accumulated in the granularity period T.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1
- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.1

A.3.1.11 DL PDCP SDU Loss Rate

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1

O-RAN addition:

The numbers are accumulated in the granularity period T.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.1

A.3.1.12 DL F1-U packet loss rate

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3

O-RAN addition:

The numbers are accumulated in the granularity period T.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3

- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3

A.3.1.13 UL PDCP SDU Data Volume

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2
- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2

O-RAN addition:

NOTE: excludes UL PDCP SDU received as data forwarding.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2 (default)

or

O-RAN addition:

OR.PDCP.UIPdcPsdDataVol or optionally OR.PDCP.UIPdcPsdDataVol_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.2

A.3.1.14 UL PDCP SDU Data Volume on X2 Interface

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

O-RAN addition:

The measurement is for X2 interface.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

O-RAN addition:

The measurement is for X2 interface.

NOTE: excludes UL PDCP SDU received as data forwarding.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

O-RAN addition:

The measurement name has the form OR.DRB.UIPdcPsdDataVolX2 or optionally OR.DRB.UIPdcPsdDataVolX2_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.UIPdcPsdDataVolX2 or optionally OR.PDCP.UIPdcPsdDataVolX2_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

A.3.1.15 UL PDCP SDU Data Volume on Xn Interface

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

O-RAN addition:

The measurement is for Xn interface.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

O-RAN addition:

The measurement is for Xn interface.

NOTE: excludes UL PDCP SDU received as data forwarding.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

O-RAN addition:

The measurement name has the form OR.DRB.UIPdcPsdDataVolXn or optionally OR.DRB.UIPdcPsdDataVolXn_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.UIPdcPsdDataVolXn or optionally OR.PDCP.UIPdcPsdDataVolXn_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.4

A.3.1.16 DL PDCP SDU Data Volume

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1
- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1

O-RAN addition:

NOTE: excludes DL PDCP SDU transmitted as data forwarding.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1 (default)

or

O-RAN addition:

OR.PDCP.DIPdcpSduDataVol or optionally OR.PDCP.DIPdcpSduDataVol *Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.1

A.3.1.17 DL PDCP SDU Data Volume on X2 Interface

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

O-RAN addition:

The measurement is for X2 interface.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

O-RAN addition:

The measurement is for X2 interface.

NOTE: excludes DL PDCP SDU transmitted as data forwarding.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

O-RAN addition:

The measurement name has the form OR.DRB.DIPdcpSduDataVolX2 or optionally OR.DRB.DIPdcpSduDataVolX2 *Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DIPdcpSduDataVolX2 or optionally OR.PDCP.DIPdcpSduDataVolX2 *Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

A.3.1.18 DL PDCP SDU Data Volume on Xn Interface

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

O-RAN addition:

The measurement is for Xn interface.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

O-RAN addition:

The measurement is for Xn interface.

NOTE: excludes DL PDCP SDU transmitted as data forwarding.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

O-RAN addition:

The measurement name has the form OR.DRB.DIPdcpSduDataVolXn or optionally OR.DRB.DIPdcpSduDataVolXn_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DIPdcpSduDataVolXn or optionally OR.PDCP.DIPdcpSduDataVolXn_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.6.2.3

A.3.1.19 UL PDCP SDU Data Volume per cell

- a) This counter provides the UL PDCP SDU volume received via X2, Xn or F1.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP PDU is received via X2-U, Xn-U or F1-U UL GTP-u tunnel, and optionally when the UL PDCP SDU is mapped to the filter.

NOTE: excludes UL PDCP SDU received as data forwarding.

- d) Each measurement is an integer value representing the UL PDCP SDU volume received via X2, Xn or F1 in Mbit.
- e) The measurement name has the form OR.DRB.UIPdcpsduDataVolCell or optionally OR.DRB.UIPdcpsduDataVolCell_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.UIPdcpsduDataVolCell or optionally OR.PDCP.UIPdcpsduDataVolCell_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.20 UL PDCP SDU Data Volume on X2 Interface per cell

- a) This counter provides the UL PDCP SDU volume received via X2.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP PDU is received via X2-U UL GTP-u tunnel, and optionally when the UL PDCP SDU is mapped to the filter.

NOTE: excludes UL PDCP SDU received as data forwarding.

- d) Each measurement is an integer value representing the UL PDCP SDU volume received via X2 in Mbit.
- e) The measurement name has the form OR.DRB.UIPdcPsdDataVolX2Cell or optionally OR.DRB.UIPdcPsdDataVolX2Cell_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.UIPdcPsdDataVolX2Cell or optionally OR.PDCP.UIPdcPsdDataVolX2Cell_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.21 UL PDCP SDU Data Volume on Xn Interface per cell

- a) This counter provides the UL PDCP SDU volume received via Xn.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP PDU is received via Xn-U UL GTP-u tunnel, and optionally when the UL PDCP SDU is mapped to the filter.

NOTE: excludes UL PDCP SDU received as data forwarding.

- d) Each measurement is an integer value representing the UL PDCP SDU volume received via Xn in Mbit.
- e) The measurement name has the form OR.DRB.UIPdcPsdDataVolXnCell or optionally OR.DRB.UIPdcPsdDataVolXnCell_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.UIPdcPsdDataVolXnCell or optionally OR.PDCP.UIPdcPsdDataVolXnCell_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.22 DL PDCP SDU Data Volume per cell

- a) This counter provides the DL PDCP SDU volume transmitted via X2, Xn or F1.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP PDU is transmitted via X2-U, Xn-U or F1-U DL GTP-u tunnel, and optionally when the DL PDCP SDU is mapped to the filter.

NOTE: excludes DL PDCP SDU transmitted as data forwarding.

- d) Each measurement is an integer value representing the DL PDCP SDU volume transmitted via X2, Xn or F1 in Mbit.

- e) The measurement name has the form OR.DRB.DlPdcPsdUDataVolCell or optionally OR.DRB.DlPdcPsdUDataVolCell_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DlPdcPsdUDataVolCell or optionally OR.PDCP.DlPdcPsdUDataVolCell_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCelICU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.23 DL PDCP SDU Data Volume on X2 Interface per cell

- a) This counter provides the DL PDCP SDU volume transmitted via X2.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP PDU is transmitted via X2-U DL GTP-u tunnel, and optionally when the DL PDCP SDU is mapped to the filter.

NOTE: excludes DL PDCP SDU transmitted as data forwarding.
- d) Each measurement is an integer value representing the DL PDCP SDU volume transmitted via X2 in Mbit.
- e) The measurement name has the form OR.DRB.DlPdcPsdUDataVolX2Cell or optionally OR.DRB.DlPdcPsdUDataVolX2Cell_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DlPdcPsdUDataVolX2Cell or optionally OR.PDCP.DlPdcPsdUDataVolX2Cell_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCelICU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.1.24 DL PDCP SDU Data Volume on Xn Interface per cell

- a) This counter provides the DL PDCP SDU volume transmitted via Xn.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP PDU is transmitted via Xn-U DL GTP-u tunnel, and optionally when the DL PDCP SDU is mapped to the filter.

NOTE: excludes DL PDCP SDU transmitted as data forwarding.
- d) Each measurement is an integer value representing the DL PDCP SDU volume transmitted via Xn in Mbit.
- e) The measurement name has the form OR.DRB.DlPdcPsdUDataVolXnCell or optionally OR.DRB.DlPdcPsdUDataVolXnCell_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.PDCP.DlPdcPsdUDataVolXnCell or optionally OR.PDCP.DlPdcPsdUDataVolXnCell_Filter (deprecated, refer to

NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) NRCellCU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.2 Void

A.3.3 NR S1-U Interface Performance Measurements

A.3.3.1 UL PDCP SDU volume transmitted via S1-U UL GTP-U tunnel

- a) This counter provides the UL PDCP SDU volume transmitted via S1-U UL GTP-U tunnel
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP SDU is transmitted via S1-U UL GTP-u tunnel, and optionally when the UL PDCP SDU is mapped to the filter. S1 interface is defined in 3GPP TS 36.413 [i.3], clause 8.
- d) Each measurement is an integer value representing the UL PDCP SDU volume transmitted via S1-U UL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.UIPdcPsdUVolTxS1UUl or optionally OR.GTP.UIPdcPsdUVolTxS1UUl_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.S1.UIPdcPsdUVolTxS1UUl or optionally OR.S1.UIPdcPsdUVolTxS1UUl_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.3.2 DL PDCP SDU volume received via S1-U DL GTP-U tunnel

- a) This counter provides the DL PDCP SDU volume received via S1-U DL GTP-U tunnel.
The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP SDU is received via S1-U DL GTP-u tunnel, and optionally when the DL PDCP SDU is mapped to the filter. S1 interface is defined in 3GPP TS 36.413 [i.3], clause 8.
- d) Each measurement is an integer value representing the DL PDCP SDU volume received via S1-U DL GTP-U tunnel in kilobits.

- e) The measurement name has the form OR.GTP.DlPdcPduVolRxS1UDl or optionally OR.GTP.DlPdcPduVolRxS1UDl_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.S1.DlPdcPduVolRxS1UDl or optionally OR.S1.DlPdcPduVolRxS1UDl_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.3.3 UL PDCP SDUs transmitted via S1-U UL GTP-U tunnel

- a) This counter provides the number of the UL PDCP SDUs transmitted via S1-U UL GTP-U tunnel. The counter is split into subcounters per GTP Path. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by 1 whenever the UL PDCP SDU is transmitted via S1 U UL GTP-u tunnel.
Optionally, the GTP Path filter is calculated, where the number of measurements is accumulated per the number of supported GTP Path, and additionally per filter.
- d) Each measurement is an integer value representing the number of the UL PDCP SDUs transmitted via S1-U UL GTP-U tunnel.
- e) The measurement name has the form OR.GTP.UlPdcPduTxS1UUL.*GTPPath* or OR.GTP.UlPdcPduTxS1UUL.*GTPPath_Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.S1.UlPdcPduTxS1UUL.*GTPPath* or OR.S1.UlPdcPduTxS1UUL.*GTPPath_Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *GTPPath* is GTP Path and where *Filter* is a combination of QoS level and S-NSSAI. Where QoS represents the mapped 5QI or QCI level and SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.3.4 DL PDCP SDUs transmitted via S1-U DL GTP-U tunnel

- a) This counter provides the number of the DL PDCP SDUs transmitted via S1-U DL GTP-U tunnel. The counter is split into subcounters per GTP Path. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by 1 whenever the DL PDCP SDU is transmitted via S1 U DL GTP-u tunnel.
Optionally the GTP Path filter is calculated, where the number of measurements is accumulated per the number of supported GTP Path per filter.

- d) Each measurement is an integer value representing the number of the DL PDCP SDUs transmitted via S1-U DL GTP-U tunnel.
- e) The measurement name has the form OR.GTP.DlPdcPduTxS1UDl.*GTPPath* or OR.GTP.DlPdcPduTxS1UDl.*GTPPath_Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.S1.DlPdcPduTxS1UDl.*GTPPath* or OR.S1.DlPdcPduTxS1UDl.*GTPPath_Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *GTPPath* is GTP Path and where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level and SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.4 NR NG-U Interface Performance Measurements

A.3.4.1 UL PDCP SDU volume transmitted via NG-U UL GTP-U tunnel

- a) This counter provides the UL PDCP SDU volume transmitted via NG-U UL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP SDU is transmitted via NG-U UL GTP-u tunnel, and optionally when the UL PDCP SDU is mapped to the filter. NG-U interface is defined in 3GPP TS 38.413 [i.5], clause 8.
- d) Each measurement is an integer value representing the UL PDCP SDU volume transmitted via NG-U UL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.UlPdcPduVolTxNGUUI or optionally OR.GTP.UlPdcPduVolTxNGUUI_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NG.UlPdcPduVolTxNGUUI or optionally OR.NG.UlPdcPduVolTxNGUUI_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.4.2 DL PDCP SDU volume received via NG-U DL GTP-U tunnel

- a) This counter provides the DL PDCP SDU volume received via NG-U DL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP SDU is received via NG-U DL GTP-u tunnel, and optionally when the DL PDCP SDU is mapped to the filter. NG-U interface is defined in 3GPP TS 38.413 [i.5], clause 8.

- d) Each measurement is an integer value representing the DL PDCP SDU volume received via NG-U DL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.DIPdcpSduVolRxNGUDI or optionally OR.GTP.DIPdcpSduVolRxNGUDI_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.NG.DIPdcpSduVolRxNGUDI or optionally OR.NG.DIPdcpSduVolRxNGUDI_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.5 NR X2-U Interface performance measurements (O-CU)

A.3.5.1 UL PDCP SDU volume received via X2-U UL GTP-U tunnel (X2-U UL data forwarding)

- a) This counter provides the UL PDCP SDU volume received via X2-U UL GTP-U tunnel for data forwarding. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP PDU is received via X2-U UL GTP-u tunnel for data forwarding, and optionally when the UL PDCP SDU is mapped to the filter. X2 interface is defined in 3GPP TS 36.423 [i.4], clause 8.
- d) Each measurement is an integer value representing the UL PDCP SDU volume received via X2-U UL GTP-U tunnel for data forwarding in kilobits.
- e) The measurement name has the form OR.GTP.UIPdcpSduVolRxX2UUIDataForward or optionally OR.GTP.UIPdcpSduVolRxX2UUIDataForward_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.X2.UIPdcpSduVolRxX2UUIDataForward or optionally OR.X2.UIPdcpSduVolRxX2UUIDataForward_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and S-NSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.5.2 DL PDCP SDU volume received via X2-U DL GTP-U tunnel (X2-U DL data forwarding)

- a) This counter provides the DL PDCP SDU volume received via X2-U DL GTP-U tunnel for data forwarding. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC

- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP PDU is transmitted via X2-U DL GTP-u tunnel for data forwarding, and optionally when the DL PDCP SDU is mapped to the filter. X2 interface is defined in 3GPP TS 36.423 [i.4], clause 8.
- d) Each measurement is an integer value representing the DL PDCP SDU volume received via X2-U DL GTP-U tunnel for data forwarding in kilobits.
- e) The measurement name has the form OR.GTP.DlPdcPsdUVolRxX2UDlDataForward or optionally OR.GTP.DlPdcPsdUVolRxX2UDlDataForward_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.X2.DlPdcPsdUVolRxX2UDlDataForward or optionally OR.X2.DlPdcPsdUVolRxX2UDlDataForward_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level and SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.6 NR Xn-U Interface performance measurements (O-CU)

A.3.6.1 UL PDCP SDU volume received via Xn-U UL GTP-U tunnel (Xn-U UL data forwarding)

- a) This counter provides the UL PDCP SDU volume received via Xn-U UL GTP-U tunnel for data forwarding. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of UL PDCP SDU whenever the UL PDCP PDU is received via Xn-U UL GTP-u tunnel for data forwarding, and optionally when the UL PDCP SDU is mapped to the filter. Xn interface is defined in 3GPP TS 36.423 [i.4], clause 8.
- d) Each measurement is an integer value representing the UL PDCP SDU volume received via Xn-U UL GTP-U tunnel for data forwarding in kilobits.
- e) The measurement name has the form OR.GTP.UlPdcPsdUVolRxXnUUIDataForward or optionally OR.GTP.UlPdcPsdUVolRxXnUUIDataForward_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.Xn.UlPdcPsdUVolRxXnUUIDataForward or optionally OR.Xn.UlPdcPsdUVolRxXnUUIDataForward_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level and SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.3.6.2 DL PDCP SDU volume received via Xn-U DL GTP-U tunnel (Xn-U DL data forwarding)

- a) This counter provides the DL PDCP SDU volume received via Xn-U DL GTP-U tunnel for data forwarding. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.
- b) CC
- c) The measurement is incremented by the volume of DL PDCP SDU whenever the DL PDCP PDU is transmitted via Xn-U DL GTP-u tunnel for data forwarding, and optionally when the DL PDCP SDU is mapped to the filter. Xn interface is defined in 3GPP TS 36.423 [i.4], clause 8.
- d) Each measurement is an integer value representing the DL PDCP SDU volume received via Xn-U DL GTP-U tunnel for data forwarding in kilobits.
- e) The measurement name has the form OR.GTP.DlPdcPsdUVolTxXnUDlDataForward or optionally OR.GTP.DlPdcPsdUVolTxXnUDlDataForward_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.Xn.DlPdcPsdUVolTxXnUDlDataForward or optionally OR.Xn.DlPdcPsdUVolTxXnUDlDataForward_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) GNBCUUPFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4 O-DU Performance measurements

A.4.1 NR F1 Interface performance measurements

A.4.1.1 UL PDCP PDUs transmitted via F1-U UL GTP-U tunnel

- a) This counter provides the number of the UL PDCP PDUs transmitted via F1-U UL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the UL PDCP PDU is transmitted via F1 U UL GTP-u tunnel, and optionally when the QCI or the 5QI of the UL PDCP PDU is the filter.
- d) Each measurement is an integer value representing the number of the UL PDCP PDUs transmitted via F1-U UL GTP-U tunnel.
- e) The measurement name has the form OR.GTP.UlPdcPpduTxF1UUl or OR.GTP.UlPdcPpduTxF1UUl_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.UlPdcPpduTxF1UUl or OR.F1.UlPdcPpduTxF1UUl_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.2 UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel

- a) This counter provides the UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

NOTE: Measurement Object Class, gNBDFunction, is different to A.4.1.14.

It is optional counter for O-DU.

- b) CC
- c) The measurement is accumulated by the volume of UL PDCP PDU whenever the UL PDCP PDU is transmitted via F1 U UL GTP-u tunnel, and optionally when the QCI or the 5QI of the UL PDCP PDU is the filter. F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.UIPdcPduVolTxF1UUl or OR.GTP.UIPdcPduVolTxF1UUl_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.UIPdcPduVolTxF1UUl or OR.F1.UIPdcPduVolTxF1UUl_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.3 Maximum UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel

- a) This counter provides the maximum UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.

- b) SI
- c) The measurement is obtained by reporting the maximum observed value of the UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel during the granularity period.
F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the maximum UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.MaxUIPdcPduVolTxF1UUl or OR.GTP.MaxUIPdcPduVolTxF1UUl_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.MaxUIPdcPduVolTxF1UUl or OR.F1.MaxUIPdcPduVolTxF1UUl_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.4 Minimum UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel

- a) This counter provides the minimum UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) SI
- c) The measurement is obtained by reporting the minimum observed value of the UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel during the granularity period
F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the minimum UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.MinUIPdcPduVolTxF1U or OR.GTP.MinUIPdcPduVolTxF1U_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.MinUIPdcPduVolTxF1U or OR.F1.MinUIPdcPduVolTxF1U_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.5 DL PDCP PDUs received via F1-U DL GTP-U tunnel

- a) This counter provides the number of the DL PDCP PDUs received via F1-U DL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the DL PDCP PDU is received via F1 U DL GTP-u tunnel, optionally when the QCI or the 5QI of the DL PDCP PDU is the filter.
- d) Each measurement is an integer value representing the number of the DL PDCP PDUs received via F1-U DL GTP-U tunnel.
- e) The measurement name has the form OR.GTP.DIPdcPduRxF1UDl or OR.GTP.DIPdcPduRxF1UDl_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.DIPdcPduRxF1UDl or OR.F1.DIPdcPduRxF1UDl_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.6 DL PDCP PDU volume received via F1-U DL GTP-U tunnel

- a) This counter provides the DL PDCP PDU volume received via F1-U DL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

NOTE: Measurement Object Class, gNBDFunction, is different to A.4.1.15.

It is optional counter for O-DU.

- b) CC
- c) The measurement is accumulated by the volume of DL PDCP PDU whenever the DL PDCP PDU is received via F1 U DL GTP-u tunnel, optionally when the QCI or the 5QI of the DL PDCP PDU is the filter. F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the DL PDCP PDU volume received via F1-U DL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.DlPdcPduVolRxF1UDl or OR.GTP.DlPdcPduVolRxF1UDl_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.DlPdcPduVolRxF1UDl or OR.F1.DlPdcPduVolRxF1UDl_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.7 Maximum DL PDCP PDU volume received via F1-U DL GTP-U tunnel

- a) This counter provides the maximum DL PDCP PDU volume received via F1-U DL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.

- b) SI
- c) The measurement is obtained by reporting the maximum observed value of the DL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel during the granularity period.
F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the maximum DL PDCP PDU volume received via F1-U DL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.MaxDlPdcPduVolRxF1UDl or OR.GTP.MaxDlPdcPduVolRxF1UDl_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.MaxDlPdcPduVolRxF1UDl or OR.F1.MaxDlPdcPduVolRxF1UDl_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.8 Minimum DL PDCCP PDU volume received via F1-U DL GTP-U tunnel

- a) This counter provides the minimum DL PDCCP PDU volume received via F1-U DL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) SI
- c) The measurement is obtained by reporting the minimum observed value of the DL PDCCP PDU volume received via F1-U DL GTP-U tunnel during the granularity period.
F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the minimum DL PDCCP PDU volume received via F1-U DL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.MinDIPdcpPduVolRxF1UDl or OR.GTP.MinDIPdcpPduVolRxF1UDl_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.MinDIPdcpPduVolRxF1UDl or OR.F1.MinDIPdcpPduVolRxF1UDl_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.9 Transmitted F1-C messages

- a) This counter provides the number of the transmitted F1-C messages per signal type that is non UE-associated or UE-associated signaling.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the F1 C-plane message is transmitted per the signal type of the F1 C-plane message: non UE-associated or UE-associated as subcounter.*Sigtype*.
- d) Each measurement is an integer value representing the number of the transmitted F1-C messages per signal type that is non UE-associated or UE-associated signaling.
- e) OR.L3M.TxF1CMes.*Sigtype* (default), OR.F1.TxF1CMes.*Sigtype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where
Sigtype is the signal type:
0: non UE-associated
1: UE-associated
- f) gNBDFunction

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.10 Received F1-C messages

- a) This counter provides the number of the received F1-C SCTP messages per signal type that is non UE-associated or UE-associated signaling.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the F1 C-plane message is received per the signal type of the F1 C-plane message: non UE-associated or UE-associated as subcounter.*Sigtype*.
- d) Each measurement is an integer value representing the number of the received F1-C SCTP messages per signal type that is non UE-associated or UE-associated signaling.
- e) OR.L3M.RxF1CMes.*Sigtype* (default), OR.F1.RxF1CMes.*Sigtype* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where
Sigtype is the signal type:
0: non UE-associated
1: UE-associated
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.11 DL F1-U packets discarded due to NR U-Plane protocol error

- a) This counter provides the number of the DL F1-U packets discarded due to NR U-Plane protocol error.
It is recommended to support for O-DU.
- b) CC
- c) The measurement counter is incremented by 1 whenever the DL F1-U plane packet is discarded due to NR U-plane protocol error.
- d) Each measurement is an integer value representing the number of the DL F1-U packets discarded due to NR U-Plane protocol error.
- e) OR.DRB.DIF1UDiscardNRUProtocolError (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.DIF1UDiscardNRUProtocolError (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.12 DL F1-U packet loss rate

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3

O-RAN addition:

It is optional counter for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3

O-RAN addition:

The measurement name has the form OR.DRB.F1UPacketLossRateDL or OR.DRB.F1UPacketLossRateDL_*Filter*. Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) O-RAN Measurement Object Class:

gNBDFunction

- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3
i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.1.3

A.4.1.13 DL Packet Drop Rate in gNB-DU

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2

O-RAN addition:

It is optional counter for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2
c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2
d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2
e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2

O-RAN addition:

The measurement name has the form OR.DRB.RlcPacketDropRateDL or OR.DRB.RlcPacketDropRateDL_*Filter*. Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.

- f) gNBDFunction

- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2
h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2
i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.2.2

A.4.1.14 UL PDCP PDU volume transmitted via F1-U UL GTP-U tunnel

- a) This counter provides the UL PDCP PDU volume of the cell transmitted via F1-U UL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.

NOTE: Measurement Object Class, NRCellDU, is different to A.4.1.2.

It is optional counter for O-DU.

- b) CC
- c) The measurement counter is accumulated by the volume of UL PDCP PDU whenever the UL PDCP PDU is transmitted from the Cell via F1 U UL GTP-u tunnel. F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the UL PDCP PDU volume of the cell transmitted via F1-U UL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.UIPdcPduCellVOITxF1UUI or OR.GTP.UIPdcPduCellVOITxF1UUI_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.UIPdcPduCellVOITxF1UUI or OR.F1.UIPdcPduCellVOITxF1UUI_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.1.15 DL PDCP PDU volume received via F1-U DL GTP-U tunnel

- a) This counter provides the DL PDCP PDU volume of the cell received via F1-U DL GTP-U tunnel. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI.

NOTE: Measurement Object Class, NRCellDU, is different to A.4.1.6.

It is optional counter for O-DU.

- b) CC
- c) The measurement counter is accumulated by the volume of DL PDCP PDU whenever the DL PDCP PDU is received to the Cell via F1 U DL GTP-u tunnel. F1 interface is defined in 3GPP TS 38.473 [i.6], clause 8.
- d) Each measurement is an integer value representing the DL PDCP PDU volume of the cell received via F1-U DL GTP-U tunnel in kilobits.
- e) The measurement name has the form OR.GTP.DIPdcPduCellVolTxF1UDI or OR.GTP.DIPdcPduCellVolTxF1UDI_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.F1.DIPdcPduCellVolTxF1UDI or OR.F1.DIPdcPduCellVolTxF1UDI_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, SNSSAI represents S-NSSAI.
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2 NR RLC performance measurements

A.4.2.1 Received UL RLC PDUs

- a) This counter provides the number of the received UL RLC PDUs. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the UL RLC PDU is received, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the received UL RLC PDUs.
- e) The measurement name has the form OR.DRB.RxUIRlcPdu or OR.DRB.RxUIRlcPdu_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.RxUIRlcPdu or OR.RLC.RxUIRlcPdu_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.2 Received UL RLC PDU volume

- a) This counter provides the received UL RLC PDU volume. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is recommended to support for O-DU.
- b) SI
- c) The measurement is incremented by the volume of the UL RLC PDU whenever the UL RLC PDU is received, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the received UL RLC PDU volume in kilobits.
- e) The measurement name has the form OR.DRB.RxUIRlcPduVol or OR.DRB.RxUIRlcPduVol_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.RxUIRlcPduVol or OR.RLC.RxUIRlcPduVol_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.3 Request for UL RLC PDUs retransmission

- a) This counter provides the number of the requests sent for UL RLC PDUs retransmission. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.

- b) CC
- c) The measurement is incremented by 1 whenever the UL RLC PDU retransmission request is sent, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the requests sent for UL RLC PDUs retransmission.
- e) The measurement name has the form OR.DRB.ReqUIRlcPduRetrans or OR.DRB.ReqUIRlcPduRetrans_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.ReqUIRlcPduRetrans or OR.RLC.ReqUIRlcPduRetrans_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.4 Transmitted DL RLC PDUs

- a) This counter provides the number of the transmitted DL RLC PDUs. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.

- b) CC
- c) The measurement subcounter is incremented by 1 whenever the DL RLC PDU is transmitted, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the transmitted DL RLC PDUs.
- e) The measurement name has the form OR.DRB.TxDIRlcPdu or OR.DRB.TxDIRlcPdu_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.TxDIRlcPdu or OR.RLC.TxDIRlcPdu_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.5 Transmitted DL RLC PDU volume

- a) This counter provides the transmitted DL RLC PDU volume. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is recommended to support for O-DU.

- b) SI
- c) The measurement is incremented by the volume of the DL RLC PDU whenever the DL RLC PDU is transmitted, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the transmitted DL RLC PDU volume in kilobits.
- e) The measurement name has the form OR.DRB.TxDIRlcPduVol or OR.DRB.TxDIRlcPduVol_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.TxDIRlcPduVol or OR.RLC.TxDIRlcPduVol_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.6 Retransmitted DL RLC PDUs

- a) This counter provides the number of the DL RLC PDUs retransmitted in RLC layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the DL RLC PDU is retransmitted in RLC layer, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the DL RLC PDUs retransmitted in RLC layer.
- e) The measurement name has the form OR.DRB.RetransDIRlcPdu or OR.DRB.RetransDIRlcPdu_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.RetransDIRlcPdu or OR.RLC.RetransDIRlcPdu_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.7 Retransmitted DL RLC PDU volume

- a) This counter provides the DL RLC PDU volume retransmitted in RLC layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is recommended to support for O-DU.
- b) SI
- c) The measurement is incremented by the volume of the DL RLC PDU whenever the DL RLC PDU is retransmitted in RLC layer, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.

- d) Each measurement is an integer value representing the DL RLC PDU volume retransmitted in RLC layer in kilobits.
- e) The measurement name has the form OR.DRB.RetransDIRlcPduVol or OR.DRB.RetransDIRlcPduVol_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.RetransDIRlcPduVol or OR.RLC.RetransDIRlcPduVol_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.8 UL RLC PDUs discarded due to bearer release

- a) This counter provides the number of the UL RLC PDUs discarded due to bearer release. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the UL RLC PDU is discarded due to bearer release, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the UL RLC PDUs discarded due to bearer release.
- e) The measurement name has the form OR.DRB.UIRlcPduDiscardBearerRel or OR.DRB.UIRlcPduDiscardBearerRel_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.UIRlcPduDiscardBearerRel or OR.RLC.UIRlcPduDiscardBearerRel_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.9 UL RLC PDU volume discarded due to bearer release

- a) This counter provides the UL RLC PDU volume discarded due to bearer release. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is recommended to support for O-DU.
- b) SI
- c) The measurement is incremented by the volume of the UL RLC PDU whenever the UL RLC PDU is discarded due to bearer release, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the UL RLC PDU volume discarded due to bearer release in kilobits.
- e) The measurement name has the form OR.DRB.UIRlcPduVolDiscardBearerRel or OR.DRB.UIRlcPduVolDiscardBearerRel_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),

OR.RLC.UIRlcPduVolDiscardBearerRel or OR.RLC.UIRlcPduVolDiscardBearerRel_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.

- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.10 UL RLC PDUs discarded due to RLC re-establishment

- a) This counter provides the number of the UL RLC PDUs discarded due to RLC re-establishment. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.

- b) CC
- c) The measurement is incremented by 1 whenever the UL RLC PDU is discarded due to RLC re-establishment, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the UL RLC PDUs discarded due to RLC re-establishment.
- e) The measurement name has the form OR.DRB.UIRlcPduDiscardRlcReest or OR.DRB.UIRlcPduDiscardRlcReest_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.UIRlcPduDiscardRlcReest or OR.RLC.UIRlcPduDiscardRlcReest_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.11 UL RLC PDU volume discarded due to RLC re-establishment

- a) This counter provides the UL RLC PDU volume discarded due to RLC re-establishment. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is recommended to support for O-DU.

- b) SI
- c) The measurement is incremented by the volume of the UL RLC PDU whenever the UL RLC PDU is discarded due to RLC re-establishment, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the UL RLC PDU volume discarded due to RLC re-establishment in kilobits.
- e) The measurement name has the form OR.DRB.UIRlcPduVolDiscardRlcReest or OR.DRB.UIRlcPduVolDiscardRlcReest_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.UIRlcPduVolDiscardRlcReest or OR.RLC.UIRlcPduVolDiscardRlcReest_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.

- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.12 UL RLC PDUs discarded due to other causes

- a) This counter provides the number of the UL RLC PDUs discarded due to other causes. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the UL RLC PDU is discarded for reason other than bearer release and RLC re-establishment, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the UL RLC PDUs discarded due to other causes.
- e) The measurement name has the form OR.DRB.RlcPduDiscardOther or OR.DRB.RlcPduDiscardOther_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.RlcPduDiscardOther or OR.RLC.RlcPduDiscardOther_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.13 UL RLC PDU volume discarded due to other causes

- a) This counter provides the UL RLC PDU volume discarded due to other causes. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is recommended to support for O-DU.
- b) CC
- c) The measurement is incremented by the volume of the UL RLC PDU whenever the UL RLC PDU is discarded for reason other than bearer release and RLC re-establishment, optionally when the QCI or the 5QI of the UL RLC PDU is the filter.
- d) Each measurement is an integer value representing the UL RLC PDU volume discarded due to other causes in kilobits.
- e) The measurement name has the form OR.DRB.UIRlcPduVolDiscardOther or OR.DRB.UIRlcPduVolDiscardOther_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.UIRlcPduVolDiscardOther or OR.RLC.UIRlcPduVolDiscardOther_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.2.14 DL RLC PDUs discarded due to bearer release

- a) This counter provides the number of DL RLC PDUs discarded due to bearer release. This counter includes DL RLC PDUs which has transmitted or not lower layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.

- b) CC
- c) The measurement is incremented by 1 whenever the DL RLC PDU is discarded due to bearer release, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of DL RLC PDUs discarded due to bearer release.
- e) The measurement name has the form OR.DRB.DIRlcPduDiscardBearerRel or OR.DRB.DIRlcPduDiscardBearerRel_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcPduDiscardBearerRel or OR.RLC.DIRlcPduDiscardBearerRel_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.15 DL RLC PDU volume discarded due to bearer release

- a) This counter provides the DL RLC PDU volume discarded due to bearer release. This counter includes DL RLC PDUs which has transmitted or not lower layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is recommended to support for O-DU.

- b) SI
- c) The measurement is incremented by the volume of the DL RLC PDU whenever the DL RLC PDU is discarded due to bearer release, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the DL RLC PDU volume discarded due to bearer release in kilobits.
- e) The measurement name has the form OR.DRB.DIRlcPduVolDiscardBearerRel or OR.DRB.DIRlcPduVolDiscardBearerRel_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcPduVolDiscardBearerRel or OR.RLC.DIRlcPduVolDiscardBearerRel_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.16 DL RLC PDUs discarded due to RLC re-establishment

- a) This counter provides the number of the DL RLC PDUs discarded due to RLC re-establishment. This counter includes DL RLC PDUs which has transmitted or not lower layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the DL RLC PDU is discarded due to RLC re-establishment, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the DL RLC PDUs discarded due to RLC re-establishment.
- e) The measurement name has the form OR.DRB.DIRlcPduDiscardRlcReest or OR.DRB.DIRlcPduDiscardRlcReest_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcPduDiscardRlcReest or OR.RLC.DIRlcPduDiscardRlcReest_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.17 DL RLC PDU volume discarded due to RLC re-establishment

- a) This counter provides the DL RLC PDU volume discarded due to RLC re-establishment. This counter includes DL RLC PDUs which has transmitted or not lower layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).
It is recommended to support for O-DU.
- b) SI
- c) The measurement is incremented by the volume of the DL RLC PDU whenever the DL RLC PDU is discarded due to RLC re-establishment, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the DL RLC PDU volume discarded due to RLC re-establishment in kilobits.
- e) The measurement name has the form OR.DRB.DIRlcPduVolDiscardRlcReest or OR.DRB.DIRlcPduVolDiscardRlcReest_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcPduVolDiscardRlcReest or OR.RLC.DIRlcPduVolDiscardRlcReest_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level representing the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.18 DL RLC PDUs discarded due to full buffer

- a) This counter provides the number of the DL RLC PDUs discarded due to full RLC transmission buffer. This counter includes DL RLC PDUs which has not been transmitted to lower layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is optional counter for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever the DL RLC PDU is discarded due to full RLC transmission buffer, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of the DL RLC PDUs discarded due to full RLC transmission buffer.
- e) The measurement name has the form OR.DRB.DIRlcPduDiscardTxFullBuffer or OR.DRB.DIRlcPduDiscardTxFullBuffer_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcPduDiscardTxFullBuffer or OR.RLC.DIRlcPduDiscardTxFullBuffer_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.19 DL RLC PDU volume discarded due to full buffer

- a) This counter provides the DL RLC PDU volume discarded due to full RLC transmission buffer. This counter includes DL RLC PDUs which has not been transmitted to lower layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is recommended to support for O-DU.
- b) SI
- c) The measurement is incremented by the volume of the DL RLC PDU whenever the DL RLC PDU is discarded due to full RLC transmission buffer, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the DL RLC PDU volume discarded due to full RLC transmission buffer in kilobits.
- e) The measurement name has the form OR.DRB.DIRlcPduVolDiscardTxFullBuffer or OR.DRB.DIRlcPduVolDiscardTxFullBuffer_Filter (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcPduVolDiscardTxFullBuffer or OR.RLC.DIRlcPduVolDiscardTxFullBuffer_Filter (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level representing the mapped 5QI or QCI level.
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.20 The number of exceeding maximum RLC retransmissions

- a) This counter provides the number of received NACK for the final retransmission in RLC layer. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is recommended to support for O-DU.
- b) CC
- c) The measurement is incremented by 1 whenever RLC status report including NACK for the final retransmission is received, optionally when the QCI or the 5QI of the DL RLC PDU is the filter.
- d) Each measurement is an integer value representing the number of received NACK for the final retransmission in RLC layer.
- e) The measurement name has the form OR.DRB.NumExceedMaxRlcRetrans or OR.DRB.NumExceedMaxRlcRetrans_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.NumExceedMaxRlcRetrans or OR.RLC.NumExceedMaxRlcRetrans_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level and represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.21 Average delay DL in gNB-DU

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3

O-RAN addition:

It is optional counter for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3
- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3

O-RAN addition:

The measurement name has the form OR.DRB.RlcSduDelayDL or OR.DRB.RlcSduDelayDL_*Filter*. Where *Filter* is a combination of PLMN, QoS level and SNSSAI. Where PLMN represents the PLMN ID, QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.

- f) O-RAN Measurement Object Class: gNBDUFunction
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.3.3

A.4.2.22 IP Latency DL in gNB-DU

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2

O-RAN addition:

It is optional counter for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2
- d) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2

O-RAN addition:

The measurement name has the form OR.DRB.RlcSduLatencyDl or OR.DRB.RlcSduLatencyDl_*Filter*. Where *Filter* is a combination of PLMN, QoS level and SNSSAI. Where PLMN represents the PLMN ID, QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.

- f) O-RAN Measurement Object Class: gNBDUFunction
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.3.4.2

A.4.2.23 Void

A.4.2.24 Void

A.4.2.25 DL RLC SDU discarded due to discard timer expiry indication

- a) This counter provides the number of the DL RLC SDUs discarded due to the discard timer expiry indication from the higher layers. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is an optional counter for O-DU.

- b) CC
- c) The measurement increases by 1 whenever the DL RLC SDU is discarded due to the expiration of the *discartimer* indicated by the higher layers, optionally where the QCI or the 5QI of the DL RLC SDU is the filter.
NOTE: The *discartimer* is configured for only DRBs, as per 3GPP TS 38.323 [6], clause 7.3.
- d) Each measurement is an integer value representing the number of the DL RLC SDUs discarded due to the discard timer expiry indication from the higher layers.
- e) The measurement name has the form OR.DRB.RlcSduDiscardTimerExpiry OR.DRB.RlcSduDiscardTimerExpiry_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.RlcSduDiscardTimerExpiry OR.RLC.RlcSduDiscardTimerExpiry_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.26 DL RLC SDU Volume discarded due to discard timer expiry indication

- a) This counter provides the DL RLC SDU volume discarded due to the discard timer expiry indication from the higher layers. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

It is recommended to support O-DU.

- b) SI
- c) The measurement increases by the RLC SDU volume in kilobits whenever the DL RLC SDU is discarded due to the expiration of the *discardtimer* indicated by the higher layers, optionally where the QCI or the 5QI of the DL RLC SDU is the filter.

NOTE: The *discardtimer* is configured for only DRBs, as per 3GPP TS 38.323 [6], clause 7.3.

- d) Each measurement is an integer value representing the DL RLC SDU volume discarded due to the discard timer expiry indication from the higher layers in kilobits.
- e) The measurement name has the form OR.DRB.DIRlcSduVolDiscardTimerExpiry or OR.DRB.DIRlcSduVolDiscardTimerExpiry_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.DIRlcSduVolDiscardTimerExpiry or OR.RLC.DIRlcSduVolDiscardTimerExpiry_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.2.27 Received paging records

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3

O-RAN addition:

The counter is optionally split into subcounter per Paging Identity.

The counter is optionally split into subcounter per Paging Priority.

The counter is optionally split into subcounter per Paging Origin.

It is an optional counter for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3

O-RAN addition:

The subcounter per Paging Identity level is incremented by 1 for each Paging Identity whenever a paging record is received by gNB-DU.

NOTE 1: Paging Identity is defined in 3GPP TS 38.473 [i.6], clauses 9.3.1.43 and 9.3.1.44.

The subcounter per Paging Priority level is incremented by 1 for each Paging Priority whenever a paging record including Paging Priority is received by gNB-DU.

NOTE 2: Paging Priority is defined in 3GPP TS 38.473 [i.6], clause 9.3.1.41.

The subcounter per Paging Origin level is incremented by 1 for each paging origin whenever a paging record including paging origin is received by gNB-DU.

NOTE 3: Paging Origin is defined in 3GPP TS 38.473 [i.6], clause 9.3.1.79.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3

O-RAN addition:

Subcounter OR.PAG.ReceivedNbr.*PagingIdentity* where *PagingIdentity* is Paging Identity number:

- 0: RAN UE Paging identity
- 1: CN UE Paging identity

Subcounter OR.PAG.ReceivedNbr.*PagingPriority* where *PagingPriority* is Paging Priority number:

- 0: PrioLevel1
- 1: PrioLevel2
- ...
- 7: PrioLevel8

Subcounter OR.PAG.ReceivedNbr.*PagingOrigin* where *PagingOrigin* identifies the Paging Origin IE.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.3
- i) Network Operator's Traffic Engineering Community

A.4.2.28 Discarded paging records

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6

O-RAN addition:

The counter is optionally split into subcounter per Paging Identity.

The counter is optionally split into subcounter per Paging Priority.

The counter is optionally split into subcounter per Paging Origin.

It is an optional counter for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6

O-RAN addition:

The subcounter per Paging Identity level is incremented by 1 for each Paging Identity whenever a paging record is discarded at the gNB-DU.

NOTE 1: Paging Identity is defined in 3GPP TS 38.473 [i.6], clauses 9.3.1.43 and 9.3.1.44.

The subcounter per Paging Priority level is incremented by 1 for each Paging Priority whenever a paging record including Paging Priority is discarded at the gNB-DU.

NOTE 2: Paging Priority is defined in 3GPP TS 38.473 [i.6], clause 9.3.1.41.

The subcounter per Paging Origin level is incremented by 1 for each paging origin whenever a paging record including paging origin is discarded at the gNB-DU.

NOTE 3: Paging Origin is defined in 3GPP TS 38.473 [i.6], clause 9.3.1.79.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6

O-RAN addition:

Subcounter OR.PAG.DiscardedNbr.*PagingIdentity* where *PagingIdentity* is Paging Identity number:

- 0: RAN UE Paging identity
- 1: CN UE Paging identity

Subcounter OR.PAG.DiscardedNbr.*PagingPriority* where *PagingPriority* is Paging Priority number:

- 0: PrioLevel1
- 1: PrioLevel2
- ...
- 7: PrioLevel8

Subcounter OR.PAG.DiscardedNbr.*PagingOrigin* where *PagingOrigin* identifies the Paging Origin IE.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.27.6
- i) Network Operator's Traffic Engineering Community

A.4.2.29 Non-Linear Scale Distribution of restricted UL data throughput in RLC

- a) This measurement provides the distribution of restricted Uplink data throughput experienced by UE in RLC layer. This measurement is intended for data bursts that are large enough to require transmissions to be split across multiple slots.

It is an optional counter for O-DU.

The bins corresponding to the UL throughput experienced by UE in RLC layer is defined as follows.

- bin1: 0 Kbps = Throughput
- bin2: 0 Kbps < Throughput < 100 Kbps
- bin3: 100 Kbps <= Throughput < 200 Kbps
- bin4: 200 Kbps <= Throughput < 500 Kbps
- bin5: 500 Kbps <= Throughput < 1 Mbps
- bin6: 1 Mbps <= Throughput < 2 Mbps
- bin7: 2 Mbps <= Throughput < 5 Mbps
- bin8: 5 Mbps <= Throughput < 10 Mbps
- bin9: 10 Mbps <= Throughput < 20 Mbps
- bin10: 20 Mbps <= Throughput < 40 Mbps
- bin11: 40 Mbps <= Throughput < 60 Mbps
- bin12: 60 Mbps <= Throughput < 80 Mbps
- bin13: 80 Mbps <= Throughput < 100 Mbps
- bin14: 100 Mbps <= Throughput < 200 Mbps
- bin15: 200 Mbps <= Throughput < 400 Mbps
- bin16: 400 Mbps <= Throughput < 600 Mbps
- bin17: 600 Mbps <= Throughput < 800 Mbps
- bin18: 800 Mbps <= Throughput < 1 Gbps
- bin19: 1 Gbps <= Throughput < 2 Gbps
- bin20: 2 Gbps <= Throughput < 5 Gbps

bin21: 5 Gbps <= Throughput

- b) DER (n=1)
- c) Considering there are n samples during measurement time T and each sample has the same time period t_n , the measurement of one sample is obtained by the following formula for a measurement period t_n ,

If $\text{ThpTimeUL} > 0$, $\frac{\sum \text{ThpVolUL}}{\sum \text{ThpTimeUL}} \times 1000 [\text{kbits/s}]$

If $\text{ThpTimeUL} = 0$, $0 [\text{kbit/s}]$

,where $\text{ThpTimeUL} = T_1 - T_2 [\text{ms}]$.

ThpVolUL	The total RLC level volume of data (in kbits) successfully transmitted from RLC layer to the upper layer (PDCP).
ThpTimeUL	The measurement duration in which data is successfully transmitted from RLC layer to the upper layer.
T1	The point in time after T2 when the last RLC data is transmitted from RLC layer to the upper layer.
T2	The point in time when the first RLC data is transmitted from RLC layer to the upper layer.

For each measurement sample, the bin corresponding to the UL throughput experienced by the UE is incremented by one. Separate counters are maintained for each mapped 5QI (or QCI for option 3) and for each supported SNSSAI.

- d) A set of integers, each representing the (integer) number of samples with a UL throughput in the range represented by that bin. If the optional QoS level subcounter and S-NSSAI subcounter measurements are performed, the number of measurements is equal to the number of mapped 5QIs or QCIs and number of supported S-NSSAI.
- e) The measurement name has the form OR.DRB.UERlcThpUILogDist.Bin or OR.DRB.UERlcThpUILogDist.Bin_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.UERlcThpUILogDist.Bin or OR.RLC.UERlcThpUILogDist.Bin_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level, S-NSSAI. Where QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.
- f) gNBDFunction
- g) Valid for packet switched traffic.
- h) 5GS
- i) One usage of this measurement is for performance assurance within integrity area (user plane connection quality).

A.4.2.30 Non-Linear Scale Distribution of restricted DL data throughput in RLC

- a) This measurement provides the distribution of restricted Downlink data throughput experienced by UE in RLC layer. This measurement is intended for data bursts that are large enough to require transmissions to be split across multiple slots.

It is an optional counter for O-DU.

The bins corresponding to the DL throughput experienced by UE in RLC layer is defined as follows.

bin1: 0 Kbps = Throughput

bin2: 0 Kbps < Throughput < 100 Kbps

bin3: 100 Kbps <= Throughput < 200 Kbps

bin4: 200 Kbps <= Throughput < 500 Kbps

bin5: 500 Kbps <= Throughput < 1 Mbps

bin6: 1 Mbps <= Throughput < 2 Mbps

bin7: 2 Mbps ≤ Throughput < 5 Mbps
bin8: 5 Mbps ≤ Throughput < 10 Mbps
bin9: 10 Mbps ≤ Throughput < 20 Mbps
bin10: 20 Mbps ≤ Throughput < 40 Mbps
bin11: 40 Mbps ≤ Throughput < 60 Mbps
bin12: 60 Mbps ≤ Throughput < 80 Mbps
bin13: 80 Mbps ≤ Throughput < 100 Mbps
bin14: 100 Mbps ≤ Throughput < 200 Mbps
bin15: 200 Mbps ≤ Throughput < 400 Mbps
bin16: 400 Mbps ≤ Throughput < 600 Mbps
bin17: 600 Mbps ≤ Throughput < 800 Mbps
bin18: 800 Mbps ≤ Throughput < 1 Gbps
bin19: 1 Gbps ≤ Throughput < 2 Gbps
bin20: 2 Gbps ≤ Throughput < 5 Gbps
bin21: 5 Gbps ≤ Throughput

- b) DER (n=1)
- c) Considering there are n samples during measurement time T and each sample has the same time period t_n , the measurement of one sample is obtained by the following formula for a measurement period t_n ,

$$\text{If } \text{ThpTimeDl} > 0, \frac{\sum \text{ThpVolDl}}{\sum \text{ThpTimeDl}} \times 1000 [\text{kbits/s}]$$

$$\text{If } \text{ThpTimeDl} = 0, 0 [\text{kbit/s}]$$

,where $\text{ThpTimeDl} = T1 - T2$ [ms].

ThpVolDl	The total RLC level volume of data (in kbits) successfully transmitted in DL. NOTE: In case of RLC UM, ThpVolDl is calculated based on the total data transmitted. In case of RLC AM, ThpVolDl is calculated only for data for which RLC ACK was confirmed within the measurement period.
ThpTimeDl	The measurement duration in which data is transmitted from RLC layer to lower layer.
T1	The point in time after T2 when the last RLC data is transmitted from RLC layer to the lower layer.
T2	The point in time when the first RLC data is transmitted from RLC layer to the lower layer.

For each measurement sample, the bin corresponding to the DL throughput experienced by the UE is incremented by one. Separate counters are maintained for each mapped 5QI (or QCI for option 3) and for each supported SNSSAI.

- d) A set of integers, each representing the (integer) number of samples with a DL throughput in the range represented by that bin. If the optional QoS level subcounter and S-NSSAI subcounter measurements are performed, the number of measurements is equal to the number of mapped 5QIs or QCIs and number of supported S-NSSAI.
- e) The measurement name has the form OR.DRB.UERlcThpDlLogDist.Bin or OR.DRB.UERlcThpDlLogDist.Bin_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.RLC.UERlcThpDlLogDist.Bin or OR.RLC.UERlcThpDlLogDist.Bin_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a combination of QoS level, S-NSSAI. Where QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.
- f) gNBDUFunction
- g) Valid for packet switched traffic.
- h) 5GS
- i) One usage of this measurement is for performance assurance within integrity area (user plane connection quality).

A.4.3 NR MAC performance measurements

A.4.3.1 Received UL MAC PDU volume

- a) This counter provides the UL MAC PDU volume received as initial transmission or retransmission in MAC layer.
It is recommended to support for O-DU
- b) CC
- c) Measurement subcounter is incremented by the volume of the UL MAC PDU whenever the UL MAC PDU is received as initial transmission or retransmission when the SSB for PUSCH is the group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the UL MAC PDU volume received as initial transmission or retransmission in MAC layer in kilobits.
- e) OR.DRB.RxUIMacPduVol.*SSB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MAC.RxUIMacPduVol.*SSB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:
0: #0
1: #1
...
63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.3.2 Transmitted DL MAC PDU volume

- a) This counter provides the DL MAC PDU volume transmitted as initial transmission or retransmission in MAC layer.
It is recommended to support for O-DU.
- b) CC
- c) Measurement subcounter is incremented by the volume of the DL MAC PDU whenever the DL MAC PDU is transmitted as initial transmission or retransmission when the SSB for PDSCH is the group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the DL MAC PDU volume transmitted as initial transmission or retransmission in MAC layer in kilobits.
- e) OR.DRB.TxDIMacPduVol.*SSB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.MAC.TxDIMacPduVol.*SSB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:
0: #0
1: #1
...
63: #63
- f) NRCellDU
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.3.3 Void

A.4.4 NR UL HARQ performance measurements

A.4.4.1 Distribution of PUSCH per MCS (initial transmission)

- a) This counter provides the distributions of PUSCH at the initial transmission per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is received for initial transmission when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of PUSCH at the initial transmission per MCS.
- e) OR.TB.DistPuschMcsInitial.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULHARQ.DistPuschMcsInitial.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *MCSInitial* is the MCS index for initial transmission:

0: $I_{MCS} = 0$

1: $I_{MCS} = 1$

...

28: $I_{MCS} = 28$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding

1: MCS index table 2 for PDSCH/PUSCH without transform precoding

2: MCS index table 3 for PDSCH/PUSCH without transform precoding

3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)

4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)

5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)

6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.4.2 Distribution of PUSCH per MCS (initial transmission/CRC OK)

- a) This counter provides the distributions of the number of CRC succeeded for PUSCH at initial transmission per MCS.
It is optional counter for O-DU.
- b) CC

- c) Measurement subcounter is incremented by 1 whenever PUSCH of which CRC is OK is received for initial transmission when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of the number of CRC succeeded for PUSCH at initial transmission per MCS.
- e) OR.TB.DistPuschMcsInitialTxCRC.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULHARQ.DistPuschMcsInitialTxCRC.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSInitial* is the MCS index for initial transmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$
 - ...
 - 28: $I_{MCS} = 28$

MCSTable is the MCS table:

 - 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 - 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 - 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
 - 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
 - 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
 - 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
 - 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.4.3 Distribution of PUSCH per MCS (any/CRC OK)

- a) This counter provides the distributions of PUSCH at initial transmission or retransmission per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH of which CRC is OK is received for initial transmission or retransmission when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of PUSCH at initial transmission or retransmission per MCS.
- e) OR.TB.DistPuschMcsAny.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULHARQ.DistPuschMcsAny.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for initial transmission or retransmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$
 - ...
 - 31: $I_{MCS} = 31$

MCSTable is the MCS table:

- 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
- 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
- 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
- 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
- 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
- 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
- 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.4.4 Distribution of PUSCH per MCS (exceeding HARQ retransmission)

- a) This counter provides the distributions of the number of CRC failure for PUSCH at final retransmission per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH of which CRC is NG is received for final retransmission when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of the number of CRC failure for PUSCH at final retransmission per MCS.
- e) OR.TB.DistPuschMcsExceedHarqRetrans.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULHARQ.DistPuschMcsExceedHarqRetrans.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for final retransmission:

- 0: $I_{MCS} = 0$
- 1: $I_{MCS} = 1$
- ...
- 31: $I_{MCS} = 31$

MCSTable is the MCS table:

- 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
- 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
- 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
- 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
- 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
- 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
- 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.4.5 Distribution of PUSCH per MCS (MU-MIMO/initial transmission)

- a) This counter provides the distributions of PUSCH at initial transmission in MU-MIMO usage per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is transmitted (including MU-MIMO usage) for initial transmission when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of PUSCH at initial transmission in MU-MIMO usage per MCS.
- e) OR.TB.DistPuschMcsMuMimoInitialTx.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULHARQ.DistPuschMcsMuMimoInitialTx.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSInitial* is the MCS index for initial transmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$
 - ...
 - 28: $I_{MCS} = 28$

MCSTable is the MCS table:

 - 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 - 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 - 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
 - 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
 - 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
 - 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
 - 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.4.6 Distribution of PUSCH per MCS (MU-MIMO/initial transmission/ACK)

- a) This counter provides the distributions of the number of HARQ-ACK for PUSCH at initial transmission in MU-MIMO usage per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is which of CRC is OK is transmitted (including MU-MIMO usage) for initial transmission when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of the number of HARQ-ACK for PUSCH at initial transmission in MU-MIMO usage per MCS.

- e) OR.TB.DistPuschMcsMuMimoInitialTxAck.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULHARQ.DistPuschMcsMuMimoInitialTxAck.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *MCSInitial* is the MCS index for initial transmission:

0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$
 ...
 28: $I_{MCS} = 28$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
 3: MCS index table for PUSCH with transform precoding and 64QAM ($q=1$)
 4: MCS index table for PUSCH with transform precoding and 64QAM ($q=2$)
 5: MCS index table 2 for PUSCH with transform precoding and 64QAM($q=1$)
 6: MCS index table 2 for PUSCH with transform precoding and 64QAM ($q=2$)

- f) NRCellDU
 g) Packet Switched
 h) 5GS
 i) Network Operator's Traffic Engineering Community

A.4.5 NR DL HARQ performance measurements

A.4.5.1 Distribution of PDSCH per MCS (initial transmission)

- a) This counter provides the distributions of PDSCH at initial transmission. This counter excludes MU-MIMO usage.
 It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted (except for MU-MIMO usage) for initial transmission when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of PDSCH at initial transmission.
- e) OR.TB.DistPdschMcsInitial.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLHARQ.DistPdschMcsInitial.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *MCSInitial* is the MCS index for initial transmission:

0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$
 ...
 28: $I_{MCS} = 28$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 2: MCS index table 3 for PDSCH/PUSCH without transform precoding

- f) NRCellDU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.5.2 Distribution of PDSCH per MCS (initial transmission/ACK)

- a) This counter provides the distributions of the number of HARQ-ACK for PDSCH at initial transmission per MCS. This counter excludes MU-MIMO usage.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the HARQ-ACK feedback is received for the corresponding PDSCH (except for MU-MIMO usage) transmitted for initial transmission when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of the number of HARQ-ACK for PDSCH at initial transmission per MCS.
- e) OR.TB.DistPdschMcsInitialTxAck.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLHARQ.DistPdschMcsInitialTxAck.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMc-MC-5) where *MCSInitial* is the MCS index for initial transmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$
 - ...
 - 28: $I_{MCS} = 28$*MCSTable* is the MCS table:
 - 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 - 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 - 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.5.3 Distribution of PDSCH per MCS (any/ACK)

- a) This counter provides the distributions of the number of HARQ-ACK for PDSCH at initial transmission or retransmission per MCS. This counter excludes MU-MIMO usage.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the HARQ-ACK feedback is received for the corresponding PDSCH (except for MU-MIMO usage) transmitted for initial transmission or retransmission when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of the number of HARQ-ACK for PDSCH at initial transmission or retransmission per MCS.

- e) OR.TB.DistPdschMcsAny.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLHARQ.DistPdschMcsAny.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for initial transmission or retransmission:

0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$
 ...
 31: $I_{MCS} = 31$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 2: MCS index table 3 for PDSCH/PUSCH without transform precoding

- f) NRCellDU
 g) Packet Switched
 h) 5GS
 i) Network Operator's Traffic Engineering Community

A.4.5.4 Distribution of PDSCH per MCS (exceeding HARQ retransmission)

- a) This counter provides the distributions of the number of HARQ-NACK for PDSCH at final retransmission per MCS. This counter excludes MU-MIMO usage.
 It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the HARQ-NACK feedback or no feedback related with HARQ is received for the corresponding PDSCH (except for MU-MIMO usage) transmitted for final retransmission when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of the number of HARQ-NACK for PDSCH at final retransmission per MCS.
- e) OR.TB.DistPdschMcsExceedHarqRetrans.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLHARQ.DistPdschMcsExceedHarqRetrans.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for final retransmission:

0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$
 ...
 31: $I_{MCS} = 31$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 2: MCS index table 3 for PDSCH/PUSCH without transform precoding

- f) NRCellDU
 g) Packet Switched
 h) 5GS
 i) Network Operator's Traffic Engineering Community

A.4.5.5 Distribution of PDSCH per MCS (MU-MIMO/initial transmission)

- a) This counter provides the distributions of PDSCH at initial transmission in MU-MIMO usage per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted (including MU-MIMO usage) for initial transmission when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of PDSCH at initial transmission in MU-MIMO usage per MCS.
- e) OR.TB.DistPdschMcsMuMimoInitialTx.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLHARQ.DistPdschMcsMuMimoInitialTx.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSInitial* is the MCS index for initial transmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$
 - ...
 - 28: $I_{MCS} = 28$

MCSTable is the MCS table:

 - 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 - 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 - 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.5.6 Distribution of PDSCH per MCS (MU-MIMO/initial transmission/ACK)

- a) This counter provides the distributions of the number of HARQ-ACK for PDSCH at initial transmission in MU-MIMO usage per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the HARQ-ACK feedback is received for the corresponding PDSCH (including MU-MIMO usage) transmitted for initial transmission when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSInitial*.
- d) Each measurement is an integer value representing the distributions of the number of HARQ-ACK for PDSCH at initial transmission in MU-MIMO usage per MCS.
- e) OR.TB.DistPdschMcsMuMimoInitialTxAck.*MCSInitial.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLHARQ.DistPdschMcsMuMimoInitialTxAck.*MCSInitial.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSInitial* is the MCS index for initial transmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$

...

28: $I_{MCS} = 28$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding

1: MCS index table 2 for PDSCH/PUSCH without transform precoding

2: MCS index table 3 for PDSCH/PUSCH without transform precoding

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6 NR UL Signal Quality Level performance measurements

A.4.6.1 Distribution of PUSCH per MCS (Rank1)

- a) This counter provides the distributions of PUSCH transmitted with rank 1 per MCS.

It is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is received with Rank 1 when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of PUSCH transmitted with rank 1 per MCS.
- e) OR.L1M.DistPuschMcsRank1.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.DistPuschMcsRank1.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for initial transmission:

0: $I_{MCS} = 0$

1: $I_{MCS} = 1$

...

31: $I_{MCS} = 31$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding

1: MCS index table 2 for PDSCH/PUSCH without transform precoding

2: MCS index table 3 for PDSCH/PUSCH without transform precoding

3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)

4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)

5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)

6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.2 Distribution of PUSCH per MCS (Rank2)

- a) This counter provides the distributions of PUSCH transmitted with rank 2 per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is received with Rank 2 when the MCS table of the PUSCH is group of subcounter.*MCSTable* and when the MCS index of the PUSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of PUSCH transmitted with rank 2 per MCS.
- e) OR.L1M.DistPuschMcsRank2.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.DistPuschMcsRank2.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for initial transmission:

0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$
 ...
 31: $I_{MCS} = 31$

MCSTable is the MCS table:

0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.3 Distribution of PUSCH per SSB (Rank1)

- a) This counter provides the distributions of PUSCH transmitted with rank 1 per SSB.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is received with Rank 1 when the SSB used for the PUSCH is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the distributions of PUSCH transmitted with rank 1 per SSB.
- e) OR.L1M.DistPuschSsbBeamRank1.*SSB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.DistPuschSsbBeamRank1.*SSB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:

0: #0
 1: #1
 ...
 63: #63

- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.4 Distribution of PUSCH per SSB (Rank2)

- a) This counter provides the distributions of PUSCH transmitted with rank 2 per SSB.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PUSCH is received with Rank 2 when the SSB used for the PUSCH is group of subcounter.SSB.
- d) Each measurement is an integer value representing the distributions of PUSCH transmitted with rank 2 per SSB.
- e) OR.L1M.DistPuschSsbBeamRank2.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.DistPuschSsbBeamRank2.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
0: #0
1: #1
...
63: #63
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.5 PUSCH received power

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of received power of FL DMRS of PUSCH. This counter obtains the power for every slot or mini slot in which PUSCH reception is expected. The power is normalized by PRB and antenna port. If Rx beam is created by some antenna ports, this counter is calculated with the power of only the antenna ports used to create Rx beam.
It is recommended to support for O-DU.
- b) SI
- c) Measurement subcounter of subcounter.statistic(avg.) is calculated by $\text{round}(x/y, 2) * 10^2$, where:
 x is incremented by the volume of power of front loaded DMRS of PUSCH whenever PUSCH reception is expected when SSB used for PUSCH is group of subcounter.SSB. The power is normalized by PRB and antenna port. If Rx beam is created by some antenna ports, this counter is calculated with the power of only the antenna ports used to create Rx beam.
 y is incremented by 1 whenever PUSCH reception is expected when SSB used for PUSCH is group of subcounter.SSB.

Measurement subcounter of subcounter.statistic(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of power of front loaded DMRS of PUSCH whenever PUSCH reception is expected when SSB used for PUSCH is group of subcounter.SSB. The power is normalized by PRB and antenna port. If Rx beam is created by some antenna ports, this counter is calculated with the power of only the antenna ports used to create Rx beam.

- d) Each measurement is an integer value representing the PUSCH received power in dBm/ 10^2 .
- e) OR.L1M.PuschRxPower.SSB.statistic (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.PuschRxPower.SSB.statistic (deprecated, refer to NOTE in REQ-PMes-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
 statistic is
 - 0: average
 - 1: maximum
 - 2: minimum
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.6 PUSCH RSSI

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistic of the power of the REs in which PUSCH DMRS reception is expected.

It is recommended to support for O-DU.

- b) SI
- c) Measurement subcounter of subcounter.statistic(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

x is incremented by the volume of power of the RE which PUSCH DMRS reception is expected whenever PUSCH reception is expected when SSB used for PUSCH is group of subcounter.SSB.

y is incremented by 1 whenever PUSCH reception is expected when SSB used for PUSCH is group of subcounter.SSB.

Measurement subcounter of subcounter.statistic(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of power of the RE which PUSCH DMRS reception is expected whenever PUSCH reception is expected when SSB used for PUSCH is group of subcounter.SSB.

- d) Each measurement is an integer value representing the PUSCH RSSI in dBm/ 10^2 .
- e) OR.L1M.PuschRssi.SSB.statistic (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.PuschRssi.SSB.statistic (deprecated, refer to NOTE in REQ-PMes-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1

...

63: #63

statistic is

0: average

1: maximum

2: minimum

- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.7 PUSCH SINR

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of PUSCH with 2 dB bin of SINR of UE specific PUSCH.

It is optional counter for O-DU.

- b) SI

- c) Measurement subcounter of subcounter.*statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

x is incremented by the volume of SINR of the UE specific PUSCH when SSB used for PUSCH is group of subcounter.*SSB* and when MIMO layer of the PUSCH is group of subcounter.*MIMO*.

y is incremented by 1 whenever PUSCH which power detection check is OK is received when SSB used for PUSCH is group of subcounter.*SSB* and when MIMO layer of the PUSCH is group of subcounter.*MIMO*.

Measurement subcounter of subcounter.*statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of SINR of the UE specific PUSCH when SSB used for PUSCH is group of subcounter.*SSB* and when MIMO layer of the PUSCH is group of subcounter.*MIMO*.

- d) Each measurement is an integer value representing the PUSCH SINR in dB/10².
- e) OR.L1M.PuschSinr.SSB.MIMO.statistic (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.PuschSinr.SSB.MIMO.statistic (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:

0: #0

1: #1

...

63: #63

MIMO is the number of MIMO layer:

0: 1 layer

1: 2 layer

...

7: 8 layer

statistic is

- 0: average
- 1: maximum
- 2: minimum

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.8 PUCCH RSSI

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of the power of the REs in which PUCCH DMRS reception is expected.

It is recommended to support for O-DU.

- b) SI
- c) Measurement subcounter of subcounter.*statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

x is incremented by the volume of power of the RE which PUCCH DMRS reception is expected whenever PUCCH reception is expected when SSB used for PUCCH is group of subcounter.*SSB*.

y is incremented by 1 whenever PUCCH reception is expected when SSB used for PUCCH is group of subcounter.*SSB*.

Measurement subcounter of subcounter.*statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of power of the RE which PUCCH DMRS reception is expected whenever PUCCH reception is expected when SSB used for PUCCH is group of subcounter.*SSB*.

- d) Each measurement is an integer value representing the PUCCH RSSI in dBm/10².
- e) OR.L1M.PucchRssi.*SSB.statistic* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.PucchRssi.*SSB.statistic* (deprecated, refer to NOTE in REQ-PMMeas-MC-5) where *SSB* is the SSB index:

- 0: #0
- 1: #1
- ...
- 63: #63

statistic is

- 0: average
- 1: maximum
- 2: minimum

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.9 PUCCH SINR

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of SINR of UE specific PUCCH.
It is optional counter for O-DU.
- b) SI
- c) Measurement subcounter of subcounter.*statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:
 x is incremented by the volume of SINR of the UE specific PUCCH when SSB used for PUCCH is group of subcounter.*SSB*.
 y is incremented by 1 whenever PUCCH which power detection check is OK is received when SSB used for PUCCH is group of subcounter.*SSB*.
Measurement subcounter of subcounter.*statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:
 z is the volume of SINR of the UE specific PUCCH when SSB used for PUCCH is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the PUCCH SINR in dB/10².
- e) OR.L1M.PucchSinr.*SSB.statistic* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.PucchSinr.*SSB.statistic* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *SSB* is the SSB index:
0: #0
1: #1
...
63: #63

statistic is
0: average
1: maximum
2: minimum
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.10 PRACH preamble correlation value

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of the correlation value among preambles of the PRB where PRACH preamble is detected. This counter is normalized by PRB.
It is recommended to support for O-DU.
- b) SI
- c) Measurement of subcounter.*SSB.statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:
 x is incremented by the correlation volume among preambles of the PRB whenever PRACH preamble is detected when SSB used for PRACH is subcounter.*SSB*.
 y is incremented by 1 whenever PRACH preamble is detected when SSB used for PRACH is subcounter.*SSB*.

The correlation value is calculated by summing the received power of the PRACH and the preamble repetition gain within one PRACH reception per SSB index.

Measurement of subcounter.*SSB.statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the correlation volume among preambles of the PRB whenever PRACH preamble is detected when SSB used for PRACH is subcounter.*SSB*.

- d) Each measurement is an integer value representing the PRACH preamble correlation value in dBm/10².
- e) OR.RACH.PrachPreambleCorrelationValue.*SSB.statistic* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.PrachPreambleCorrelationValue.*SSB.statistic* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- statistic* is
 - 0: average
 - 1: maximum
 - 2: minimum
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.11 RSSI of PRACH transmission occasion

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of the RACH occasion RSSI. This counter is normalized by PRB.

It is optional counter for O-DU.
- b) SI
- c) Measurement subcounter of subcounter.*statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

x is incremented by the volume of RSSI at every PRACH occasion when SSB used for PRACH is group of subcounter.*SSB*.

y is incremented by 1 at every PRACH occasion when SSB used for PRACH is group of subcounter.*SSB*.

Measurement subcounter of subcounter.*statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of RSSI at every PRACH occasion when SSB used for PRACH is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the RSSI of PRACH transmission occasion in dBm/10².
- e) OR.RACH.RssiPrachTxOccasion.*SSB.statistic* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.RssiPrachTxOccasion.*SSB.statistic* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:

0: #0
1: #1
...
63: #63

statistic is
0: average
1: maximum
2: minimum

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.12 Distribution of path loss for FR1

- a) This counter provides the distributions of PUSCH including PHR with a certain bin of the pathloss. This counter is for FR1.

It is optional counter for O-DU.

- b) CC
- c) This subcounter is measured only when the cell uses FR1.

Measurement subcounter is incremented by 1 whenever PHR is received when the SSB used for the PUSCH is group of subcounter.*SSB* and when the pathloss calculated with the PHR is group of subcounter.*binX*.

- d) Each measurement is an integer value representing the distributions of PUSCH including PHR with a certain bin of the pathloss.
- e) OR.L1M.DistPathlossFr1.*SSB.binX* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.DistPathlossFr1.*SSB.binX* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:

0: #0
1: #1
...
63: #63

binX is the bin of the pathloss, *x*.
Bin1: $0 \text{ dB} \leq x < 40 \text{ dB}$
Bin2: $40 \text{ dB} \leq x < 45 \text{ dB}$
Bin3: $45 \text{ dB} \leq x < 50 \text{ dB}$
...
Bin25: $155 \text{ dB} \leq x$

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.6.13 Path loss for FR2

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of the pathloss. This counter is for FR2.

It is optional counter for O-DU.

- b) SI

- c) This subcounter is measured only when the cell uses FR2.

Measurement subcounter of subcounter.*statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

x is incremented by the volume of the pathloss calculated with PHR whenever PHR is received when the SSB used for the PUSCH is group of subcounter.*SSB*.

y is incremented by 1 whenever PHR is received when the SSB used for the PUSCH is group of subcounter.*SSB*

Measurement subcounter of subcounter.*statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of the pathloss calculated with PHR whenever PHR is received when the SSB used for the PUSCH is group of subcounter.*SSB*.

- d) Each measurement is an integer value representing the path loss for FR2 in dB/10².
- e) OR.L1M.PathlossFr2.*SSB.statistic* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.ULSQL.PathlossFr2.*SSB.statistic* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *SSB* is the SSB index:

0: #0

1: #1

...

63: #63

statistic is

0: average

1: maximum

2: minimum

- f) NRCellDU

- g) Packet Switched

- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.6.14 Detection of UL out-of-sync

- a) This counter provides the number of the detection of UL out-of-sync for bearer type change from SN terminated split bearer to SN terminated MCG bearer or SgNB release or RRC release.

It is recommended to support for O-DU.

- b) CC

- c) Measurement subcounter is incremented by 1 whenever the UL out-of-sync is detected per SSB index of the UE: #0, #1, ..., #63 as subcounter.*SSB*.

- d) Each measurement is an integer value representing the number of the detection of UL out-of-sync for bearer type change from SN terminated split bearer to SN terminated MCG bearer or SgNB release or RRC release.
- e) OR.L1M.DetectUlOutSync.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.ULSQL.DetectUlOutSync.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7 NR DL Signal Quality Level performance measurements

A.4.7.1 Distribution of PDSCH per MCS (Rank1)

- a) This counter provides the distributions of PDSCH transmitted with rank 1 per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 1 when the MCS table of the PDSCH is group of subcounter.MCSTable and when the MCS index of the PDSCH is group of subcounter.MCSRetx.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 1 per MCS.
- e) OR.L1M.DistPdschMcsRank1.MCSRetx.MCSTable (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschMcsRank1.MCSRetx.MCSTable (deprecated, refer to NOTE in REQ-PMeas-MC-5) where MCSRetx is the MCS index for initial transmission:
 - 0: $I_{MCS} = 0$
 - 1: $I_{MCS} = 1$
 - ...
 - 31: $I_{MCS} = 31$

MCSTable is the MCS table:

 - 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 - 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 - 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
 - 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
 - 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
 - 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
 - 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.2 Distribution of PDSCH per MCS (Rank2)

- a) This counter provides the distributions of PDSCH transmitted with rank 2 per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 2 when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 2 per MCS.
- e) OR.L1M.DistPdschMcsRank2.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschMcsRank2.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for initial transmission:

 0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$
 ...
 31: $I_{MCS} = 31$

MCSTable is the MCS table:
 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
 3: MCS index table for PUSCH with transform precoding and 64QAM (q=1)
 4: MCS index table for PUSCH with transform precoding and 64QAM (q=2)
 5: MCS index table 2 for PUSCH with transform precoding and 64QAM(q=1)
 6: MCS index table 2 for PUSCH with transform precoding and 64QAM (q=2)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.3 Distribution of PDSCH per MCS (Rank3)

- a) This counter provides the distributions of PDSCH transmitted with rank 3 per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 3 when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 3 per MCS.
- e) OR.L1M.DistPdschMcsRank3.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschMcsRank3.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *MCSRetx* is the MCS index for initial transmission:

 0: $I_{MCS} = 0$
 1: $I_{MCS} = 1$

...
31: $I_{MCS} = 31$

MCSTable is the MCS table:

- 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
- 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
- 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
- 3: MCS index table for PUSCH with transform precoding

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.4 Distribution of PDSCH per MCS (Rank4)

- a) This counter provides the distributions of PDSCH transmitted with rank 4 per MCS.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 4 when the MCS table of the PDSCH is group of subcounter.*MCSTable* and when the MCS index of the PDSCH is group of subcounter.*MCSRetx*.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 4 per MCS.
- e) OR.L1M.DistPdschMcsRank4.*MCSRetx.MCSTable* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschMcsRank4.*MCSRetx.MCSTable* (deprecated, refer to NOTE in REQ-PMes-MC-5) where *MCSRetx* is the MCS index for initial transmission:

0: $I_{MCS} = 0$
1: $I_{MCS} = 1$
...
31: $I_{MCS} = 31$

MCSTable is the MCS table:

- 0: MCS index table 1 for PDSCH/PUSCH without transform precoding
- 1: MCS index table 2 for PDSCH/PUSCH without transform precoding
- 2: MCS index table 3 for PDSCH/PUSCH without transform precoding
- 3: MCS index table for PUSCH with transform precoding

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.5 Distribution of PDSCH per SSB (Rank1)

- a) This counter provides the distributions of PDSCH transmitted with rank 1 per SSB.
It is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 1 when the SSB used for the PDSCH is group of subcounter.SSB.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 1 per SSB.
- e) OR.L1M.DistPdschSsbBeamRank1.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschSsbBeamRank1.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.6 Distribution of PDSCH per SSB (Rank2)

- a) This counter provides the distributions of PDSCH transmitted with rank 2 per SSB.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 2 when the SSB used for the PDSCH is group of subcounter.SSB.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 2 per SSB.
- e) OR.L1M.DistPdschSsbBeamRank2.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschSsbBeamRank2.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.7 Distribution of PDSCH per SSB (Rank3)

- a) This counter provides the distributions of PDSCH transmitted with rank 3 per SSB.
It is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 3 when the SSB used for the PDSCH is group of subcounter.SSB.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 3 per SSB.
- e) OR.L1M.DistPdschSsbBeamRank3.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschSsbBeamRank3.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.8 Distribution of PDSCH per SSB (Rank4)

- a) This counter provides the distributions of PDSCH transmitted with rank 4 per SSB.
It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted with Rank 4 when the SSB used for the PDSCH is group of subcounter.SSB.
- d) Each measurement is an integer value representing the distributions of PDSCH transmitted with rank 4 per SSB.
- e) OR.L1M.DistPdschSsbBeamRank4.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistPdschSsbBeamRank4.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.9 Distribution of Wideband CQI for FR1

- a) This counter provides the distributions of the wideband CQI reports.
It is optional counter for O-DU.

- b) CC
- c) This subcounter is measured only when the cell uses FR1.

Measurement subcounter is incremented by 1 whenever CQI report is received when the SSB index used for the CQI report is group of subcounter.*SSB*, when the CQI table of the CQI report is group of subcounter.*CQITable* and when the CQI is group of subcounter.*CQI*.
- d) Each measurement is an integer value representing the distributions of the wideband CQI reports.
- e) OR.L1M.DistWidebandCqiFR1.*SSB.CQITable.CQI* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.DistWidebandCqiFR1.*SSB.CQITable.CQI* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:

0: #0
1: #1
...
63: #63

CQITable is the CQI table:
0: table 1
1: table 2

CQI is the CQI index:
0: CQI index 0
1: CQI index 1
...
15: CQI index 15
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.10 Wideband CQI for FR2

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of linear value of the wideband CQI reports.

It is optional counter for O-DU.
- b) SI
- c) This subcounter is measured only when the cell uses FR2.

Measurement subcounter of subcounter.*statistic*(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

 x is incremented by the volume of CQI whenever CQI report is received when the SSB index used for the CQI report is group of subcounter.*SSB* and when the CQI table of the CQI report is group of subcounter.*CQITable*.

 y is incremented by 1 whenever CQI report is received when the SSB index used for the CQI report is group of subcounter.*SSB* and when the CQI table of the CQI report is group of subcounter.*CQITable*.

Measurement subcounter of subcounter.*statistic*(max/min) is maximum/minimum number of $\text{round}(z, 2) \cdot 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) \cdot 10^2$, if $\text{round}(z, 2) \cdot 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of CQI whenever CQI report is received when the SSB index used for the CQI report is group of subcounter.SSB and when the CQI table of the CQI report is group of subcounter.CQITable.

- d) Each measurement is an integer value representing the wideband CQI for FR2 in $CQI/10^2$.
- e) OR.L1M.WidebandCqiFR2.SSB.CQITable.statistic (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.WidebandCqiFR2.SSB.CQITable.statistic (deprecated, refer to NOTE in REQ-PMes-MC-5) where SSB is the SSB index:

0: #0
1: #1
...
63: #63

CQITable is the CQI table:

0: table 1
1: table 2

statistic is

0: average
1: maximum
2: minimum

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.7.11 PDCCH transmission power

- a) This counter measures the following x and provides $\text{round}(x, 2) \cdot 10^2$. x is the statistics of transmission power determined by outer-loop TPC of UE specific PDCCH. If one or more PDCCHs associated with same SSB are transmitted within some OFDM symbols in one slot, this counter counts 1 sample and calculates power as linear average within OFDM symbols. If one or more PDCCHs associated with different SSBs are transmitted in each OFDM symbols in the one slot, this counter counts the PDCCHs for each SSB, and doesn't calculate power as average within OFDM symbols.

It is optional counter for O-DU.

- b) SI
- c) Measurement of subcounter.SSB.DCI.statistic(avg.) is calculated by $\text{round}(x/y, 2) \cdot 10^2$, where:

x is incremented by the volume of transmission power of PDCCH whenever PDCCH is transmitted when SSB used for PDCCH is subcounter.SSB and when the DCI format of transmitted DCI is subcounter.SSB.DCI. If one or more PDCCHs associated with same SSB are transmitted within plural OFDM symbols in one slot, the volume is linear average within the OFDM symbols. If one or more PDCCHs associated with different SSBs are transmitted in each OFDM symbols in the one slot, x is incremented for each PDCCH per SSB.

y is incremented by 1 whenever PDCCH is transmitted when SSB used for PDCCH is subcounter.SSB and when the DCI format of transmitted DCI is subcounter.SSB.DCI. If one or more PDCCHs associated with same SSB are transmitted within plural OFDM symbols in one slot, y is only incremented once per slot. If one or more PDCCHs associated with different SSBs are transmitted in each OFDM symbols in the one slot, y is incremented once per OFDM symbol.

Measurement of subcounter.*statistic.SSB.DCI*(max/min) is maximum/minimum number of $\text{round}(z, 2) * 10^2$. It is assigned whenever z is updated by the volume $\text{round}(z, 2) * 10^2$, if $\text{round}(z, 2) * 10^2$ is bigger/smaller than previously counted volume, where:

z is the volume of transmission power of PDCCH whenever PDCCH is transmitted when SSB used for PDCCH is subcounter.*SSB* and when the DCI format of transmitted DCI is subcounter.*SSB.DCI*. If one or more PDCCHs associated with same SSB are transmitted within plural OFDM symbols in one slot, the volume is linear average within OFDM symbols. If one or more PDCCHs associated with different SSBs are transmitted in each OFDM symbols in the one slot, z is once per OFDM symbol.

- d) Each measurement is an integer value representing the PDCCH transmission power in dBm/10².
- e) OR.L1M.PdcchTxPower.*SSB.DCI.statistic* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.DLSQL.PdcchTxPower.*SSB.DCI.statistic* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:

0: #0
1: #1
...
63: #63

DCI is the DCI format:

0: 0_0
1: 0_1
2: 1_0
3: 1_1

statistic is

0: average
1: maximum
2: minimum

- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.8 NR Beamforming performance measurements

A.4.8.1 Distribution of UEs per beam index

- a) This counter provides distribution of the UEs with beam index. This counter obtains the number of the UEs per beam index.

This is recommended to support for O-DU.

- b) CC
- c) Measurement subcounter is incremented by the number of the UEs per SSB index of the UE: #0, #1, ..., #63 as subcounter.*SSB*.

The measurement is obtained by calculating the observed distribution of UEs per beam index per granularity period.

- d) Each measurement is an integer value representing the distribution of the UEs with beam index.

- e) OR.L1M.DistUeBeamIndex.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.BF.DistUeBeamIndex.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where

SSB is the SSB index:

0: #0
1: #1
..
63: #63

- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.8.2 Best and Second Best Beam distribution

- a) This counter provides the distribution of Best and Second best beams. This counter is only updated when number of SSB is 8 or less.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by the number of the UEs per the best and second best SSB index of the UE: best beam #0 and second beam #0, best beam #1 and second beam #0, ..., best beam#7 and second beam#7 as subcounter.*binX*.

The value for a given bin shall be incremented when either best or second best beam is changed for any reason.

- d) Each measurement is an integer value representing the distribution of Best and Second best beams.
- e) OR.L1M.BestSecondBestBeamDist.*binX* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.BF.BestSecondBestBeamDist.*binX* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where

Bin1 is best beam #0 and second beam #0.
Bin2 is best beam #1 and second beam #0.
:
BinX is best beam #a and second beam #b. : $X = a + 8b + 1$
:
Bin64 is best beam#7 and second beam#7.

- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.8.3 UE reported differential L1-RSRP of second best beam

- a) This counter provides the distribution of the UE reported differential L1-RSRP of second best beam from the L1-RSRP of the best beam.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever L1-RSRP report is received when the differential L1-RSRP of second best beam from the L1-RSRP of the best beam is group of subcounter.bin.
- d) Each measurement is an integer value representing the distribution of the UE reported differential L1-RSRP of second best beam from the L1-RSRP of the best beam.
- e) OR.L1M.UeReportedDisffL1RsrpSecondBestBeam.bin X (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.BF.UeReportedDisffL1RsrpSecondBestBeam.bin X (deprecated, refer to NOTE in REQ-PMes-MC-5) where bin X corresponds to the UE reported differential L1-RSRP, x , of second best beam from the L1-RSRP of the best beam.
 Bin1: $0 \geq x > -2$ dB
 Bin2: $-2 \text{ dB} \geq x > -4$ dB
 ...
 Bin16: $-30 \text{ dB} \geq x$
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9 NR RACH Usage performance measurements

A.4.9.1 Received preambles in group A

- a) This counter provides the number of the received random preambles of group A.
 This is recommended to support for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever random preamble of group A is received when the SSB which is used for preamble transmission is group of subcounter.SSB.
- d) Each measurement is an integer value representing the number of the received random preambles of group A.
- e) OR.RACH.RxPreamblesGroupA.SSB where SSB is the SSB index:
 0: #0
 1: #1
 ...
 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9.2 The number of received dedicated preamble

- a) This counter provides the number of the received dedicated preambles.
This is recommended to support for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever dedicated preamble is received when the SSB which is used for preamble transmission is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the number of the received dedicated preambles.
- e) *OR.RACH.NumRxDedictedPreamble.SSB* where *SSB* is the SSB index:
0: #0
1: #1
...
63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9.3 Transmitted RARs for preamble in group A

- a) This counter provides the number of the transmitted RAR for preambles of group A.
This is recommended to support for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RAR for preamble of group A is transmitted when the SSB which is used for RAR transmission is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the number of the transmitted RAR for preambles of group A.
- e) *OR.RACH.TxRarPreambleGroupA.SSB* where *SSB* is the SSB index:
0: #0
1: #1
...
63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9.4 Transmitted RARs for dedicated preamble

- a) This counter provides the number of the transmitted RAR for dedicated preambles.

This is recommended to support for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever RAR for dedicated preamble is transmitted when the SSB which is used for RAR transmission is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the number of the transmitted RAR for dedicated preambles.
- e) OR.RACH.TxRarDedicatedPreamble.*SSB* where *SSB* is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9.5 Failures at assignment of dedicated preamble

- a) This counter provides the number indicating use of random preamble due to NG of dedicated preamble delivery.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RA procedure using random preamble is triggered due to NG of dedicated preamble assignment when the SSB which is used for random preamble transmission is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the number indicating use of random preamble due to NG of dedicated preamble delivery.
- e) OR.RACH.FailAssignmentDedicatedPreamble.*SSB* where *SSB* is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9.6 Occasions for dedicated preamble reception

- a) This counter provides the number of the occasions for dedicated preamble. If multiple dedicated preambles are assigned, this counter calculated as the number of assigned preambles.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by the number of assigned preambles whenever dedicated preamble(s) are expected to be received when the SSB which is used for random preamble transmission is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the number of the occasions for dedicated preamble.
- e) OR.RACH.OccasionDedicatedPreambleRx.*SSB* where *SSB* is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.9.7 Failures at assignment of a dedicated preamble for PDCCH order RA (UL out-of-sync)

- a) This counter provides the number of failures at assignment of a dedicated preamble when the gNB detects UL out-of-sync and tries CFRA operation (PDCCH order) to recover UL link connection.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 whenever a failure at assignment of a dedicated preamble is occurred due to UL out-of-sync when the SSB used for assignment of a dedicated preamble is group of subcounter.*SSB*.
- d) Each measurement is an integer value representing the number of failures at assignment of a dedicated preamble when the gNB detects UL out-of-sync and tries CFRA operation (PDCCH order) to recover UL link connection.
- e) OR.RACH.FailAssignmentDedicatedPreamblePdcchOrderRaUlOutSync.*SSB* where *SSB* is the SSB index:
 - 0: #0
 - 1: #1
 - ...
 - 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.10 NR Timing Advance performance measurements

A.4.10.1 Distribution of N_{TA} value of RAR message

- a) This counter provides the distributions of RARs with the bin of N_{TA} value described the following. The bin type is selected corresponding to CellSize.

This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever RAR is transmitted when the SSB index used for the RAR is group of subcounter.*SSB* and when the N_{TA} is group of subcounter.*binX*.
- d) Each measurement is an integer value representing the distributions of RARs with the bin of N_{TA} value.
- e) OR.L1M.DistNtaRarMessage.*SSB.binX* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.TA.DistNtaRarMessage.*SSB.binX* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where

SSB is the SSB index:

0: #0

1: #1

..

63: #63

binX depends on cellSize below:

CellSize = *large*:

bin1: $0 \leq N_{TA} < 72765$

bin2: $72765 \leq N_{TA} < 145530$

...

bin10: $654885 \leq N_{TA}$

CellSize = *middle*:

bin1: $0 \leq N_{TA} < 29106$

bin2: $29106 \leq N_{TA} < 58212$

...

bin10: $261954 \leq N_{TA}$

CellSize = *small*:

bin1: $0 \leq N_{TA} < 728$

bin2: $728 \leq N_{TA} < 1456$

...

bin10: $6552 \leq N_{TA}$

CellSize = *Very small*:

Reserved

- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11 NR Cell Utilization performance measurements

A.4.11.1 Slots at which PDCCH resource shortage occurred

- a) This counter provides the number of the slots when PDCCH shortage occurred.

This is recommended to support for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 at every slot in which CCE resource shortage restricts the multiplexing number of PDCCH at least once.
- d) Each measurement is an integer value representing the number of the slots when PDCCH shortage occurred.
- e) OR.RRU.SlotPdcchResourceShortageOccurred (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.SlotPdcchResourceShortageOccurred (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.2 Cancelled DCI due to PDCCH resource shortage

- a) This counter provides the number of the cancels of DCI transmission due to PDCCH resource shortage.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by the number of DCI which is canceled due to CCE resource shortage whenever CCE resource shortage restricts the multiplexing number of PDCCH.
- d) Each measurement is an integer value representing the number of the cancels of DCI transmission due to PDCCH resource shortage.
- e) OR.RRU.CancelDciPdcchResourceShortage (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.CancelDciPdcchResourceShortage (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.3 Maximum UEs buffering UL and DL data

- a) This counter obtains the number of UEs buffering both UL and DL data. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

This is optional counter for O-DU.

- b) CC
- c) The measurement is obtained by reporting the maximum observed value of the UEs buffering both UL and DL data during the granularity period.

NOTE: multiple 5QIs can be set per UE, each 5QI is counted per QoS flow.

- d) Each measurement is an integer value representing the maximum UEs buffering UL and DL data.

- e) The measurement name has the form OR.DRB.MaxUeBufferUIDIData or OR.DRB.MaxUeBufferUIDIData_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MaxUeBufferUIDIData or OR.CellU.MaxUeBufferUIDIData_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.4 Maximum UEs buffering UL data

- a) This counter obtains the maximum number of UEs buffering UL data. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

This is optional counter for O-DU.

- b) CC
- c) The measurement is obtained by reporting the maximum observed value of the UEs buffering UL data during the granularity period.

NOTE: multiple 5QIs can be set per UE, each 5QI is counted per QoS flow.

- d) Each measurement is an integer value representing the maximum UEs buffering UL data.
- e) The measurement name has the form OR.DRB.MaxUeBufferUIData or OR.DRB.MaxUeBufferUIData_*Filter*. (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MaxUeBufferUIData or OR.CellU.MaxUeBufferUIData_*Filter*. (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.5 Maximum UEs buffering DL data

- a) This counter obtains the maximum number of UEs buffering DL data. The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC).

This is optional counter for O-DU.

- b) CC
- c) The measurement is obtained by reporting the maximum observed value of the UEs buffering DL data during the granularity period.

NOTE: multiple 5QIs can be set per UE, each 5QI is counted per QoS flow.

- d) Each measurement is an integer value representing the maximum UEs buffering DL data.

- e) The measurement name has the form OR.DRB.MaxUeBufferDIData or OR.DRB.MaxUeBufferDIData_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MaxUeBufferDIData or OR.CellU.MaxUeBufferDIData_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is a QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.6 Multiplexed receptions of PUSCH

- a) This counter provides the accumulated number of the multiplication number of PUSCH.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 at every slot in which PUSCH is received when the multiplexed number in frequency domain is group of subcounter.*mux*.
- d) Each measurement is an integer value representing the accumulated number of the multiplication number of PUSCH.
- e) OR.CARR.MultiplexRxPusch.*mux* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MultiplexRxPusch.*mux* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *mux* is the number of multiplex:
 - 0: 1 multiplex
 - 1: 2 multiplex to 5 multiplex
 - 2: 6 multiplex to 12 multiplex
 - 3: more than 12 multiplex
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.7 Multiplexed transmissions of PDSCH

- a) This counter provides the accumulated number of the multiplication number of PDSCH.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 when PDSCH is transmitted when the multiplexed number in frequency domain is group of subcounter.*mux*.
- d) Each measurement is an integer value representing the accumulated number of the multiplication number of PDSCH.
- e) OR.CARR.MultiplexTxPdsch.*mux* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MultiplexTxPdsch.*mux* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *mux* is the number of multiplex:

- 0: 1 multiplex
- 1: 2 multiplex to 5 multiplex
- 2: 6 multiplex to 12 multiplex
- 3: more than 12 multiplex

- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.8 Maximum DRX inactive UEs

- a) This counter obtains the maximum number of UEs configured as DRX inactive.
This is optional counter for O-DU.
- b) CC
- c) This measurement represents the number of UEs of which *drx-InactivityTimer* is assumed to be running. The measurement is obtained by reporting the maximum observed value of the UEs configured as DRX inactive during the granularity period.
- d) Each measurement is an integer value representing the maximum DRX inactive UEs.
- e) OR.UECNTX.MaxDrxInactiveUe (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.MaxDrxInactiveUe (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.9 Maximum DRX active UEs

- a) This counter obtains the maximum number of UEs configured as DRX active.
This is optional counter for O-DU.
- b) CC
- c) This measurement represents the number of UEs which is configured *drx-config* and of which *drx-InactivityTimer* is assumed not to be running. The measurement is obtained by reporting the maximum observed value of the UEs configured as DRX active during the granularity period.
- d) Each measurement is an integer value representing the maximum DRX active UEs.
- e) OR.UECNTX.MaxDrxActiveUe (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.MaxDrxActiveUe (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCelIDU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.11.10 Distribution of trafficInactivityTimer

- a) This counter provides the distribution of the UEs whose trafficInactivityTimer is running with 1 s bin of the trafficInactivityTimer. trafficInactivityTimer measures the consecutive time when no UL/DL data for the UE is available. This counter obtains the number of UEs every granularity period.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by the number of UEs whose trafficInactivityTimer is in the value of the subcounter.*binX*.

The number is acquired as an instantaneous value after each granularity period.

- d) Each measurement is an integer value representing the distribution of the UEs whose trafficInactivityTimer is running with 1 s bin of the trafficInactivityTimer.
- e) OR.UECNTX.DistTrafficInactiveTimer.*binX* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.DistTrafficInactiveTimer.*binX* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where

bin 1: $0 \text{ s} \leq \text{trafficInactivityTimer} < 1 \text{ s}$
bin 2: $1 \text{ s} \leq \text{trafficInactivityTimer} < 2 \text{ s}$
bin 3: $2 \text{ s} \leq \text{trafficInactivityTimer} < 4 \text{ s}$
bin 4: $4 \text{ s} \leq \text{trafficInactivityTimer} < 8 \text{ s}$
bin 5: $8 \text{ s} \leq \text{trafficInactivityTimer} < 16 \text{ s}$
bin 6: $16 \text{ s} \leq \text{trafficInactivityTimer} < 32 \text{ s}$
bin 7: $32 \text{ s} \leq \text{trafficInactivityTimer} < 64 \text{ s}$
bin 8: $64 \text{ s} \leq \text{trafficInactivityTimer} < 128 \text{ s}$
bin 9: $128 \text{ s} \leq \text{trafficInactivityTimer}$

- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.11 Slots in which scheduler assigned as mini slot

- a) This counter provides the number of slots with mini slot scheduling. This counter is for FR2.

This is optional counter for O-DU.

- b) CC
- c) Measurement subcounter is incremented by 1 at every slot in which PDSCH which is multiplexed in time domain in a slot is assigned.
- d) Each measurement is an integer value representing the number of slots with mini slot scheduling. This counter is for FR2.
- e) OR.RRU.SlotSchedulerAssignMiniSlot (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.SlotSchedulerAssignMiniSlot (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.12 Mini slots in which PUSCH was received

- a) This counter provides the number of mini slots when PUSCH is received.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 when PUSCH which is multiplexed in time domain in a slot is assigned.
- d) Each measurement is an integer value representing the number of mini slots when PUSCH is received.
- e) OR.RRU.MiniSlotsPuschRx (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.MiniSlotsPuschRx (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.13 UEs in the cell using this cell as PSCell or having activated SCell in DL

- a) This counter provides the accumulated number of the UEs in the cell using this cell as PSCell or having activated SCell in DL.
This is optional counter for O-DU.
- b) CC
- c) The measurement is obtained by reporting the accumulated observed value of the UEs in the cell using this cell as PSCell or having activated SCell in DL during the granularity period.
- d) Each measurement is an integer value representing the accumulated number of the UEs in the cell using this cell as PSCell or having activated SCell in DL.
- e) OR.UECNTX.UeCellPscellActiveScellDI (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.UeCellPscellActiveScellDI (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.14 UEs in the cell using this cell as PSCell or having activated SCell in UL

- a) This counter provides the accumulated number of the UEs in the cell using this cell as PSCell or having activated SCell in UL.
This is optional counter for O-DU.
- b) CC
- c) The measurement is obtained by reporting the accumulated observed value of the UEs in the cell using this cell as PSCell or having activated SCell in UL during the granularity period.
- d) Each measurement is an integer value representing the accumulated number of the UEs in the cell using this cell as PSCell or having activated SCell in UL.
- e) OR.UECNTX.UeCellPscellActiveScellUl (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.UeCellPscellActiveScellUl (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.15 Distribution of PSCell UEs with X activated SCells in UL

- a) This counter provides the distribution of the PSCell UE with the number of activated SCell in UL.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by the number of the UE configured this cell as PSCell per the number of activated SCell in UL: 1 active SCell, 2 active SCell, ..., 31 active SCell as subcounter. *SCell*.
The measurement is obtained by calculating the observed distribution of PSCell UEs with X activated SCells in UL per granularity period.
- d) Each measurement is an integer value representing the distribution of the PSCell UE with the number of activated SCell in UL.
- e) OR.UECNTX.DistPscellUeXactiveScellUl.NumScell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.DistPscellUeXactiveScellUl.NumScell (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *NumScell* is the number of active SCell:
 - 0: 1 active SCell
 - 1: 2 active SCell
 - ...
 - 30: 31 active SCell
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.16 Distribution of PSCell UEs with X activated SCells in DL

- a) This counter provides the distribution of the PSCell UEs with the number of activated SCell in DL.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by the number of the UE configured this cell as PSCell per the number of activated SCell in DL: 1 active SCell, 2 active SCell, ..., 31 active SCell as subcounter. *SCell*.
The measurement is obtained by calculating the observed distribution of PSCell UEs with X activated SCells in DL per granularity period.
- d) Each measurement is an integer value representing the distribution of the PSCell UEs with the number of activated SCell in DL.
- e) OR.UECNTX.DistPscellUeXactiveScellDL.*NumScell* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.DistPscellUeXactiveScellDL.*NumScell* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *NumScell* is the number of active SCell:
 - 0: 1 active SCell
 - 1: 2 active SCell
 - ...
 - 30: 31 active SCell
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.17 Maximum amount of PSCell UEs (UL)

- a) This counter obtains the maximum number of the PSCell UEs for UL.
This is optional counter for O-DU.
- b) CC
- c) The measurement is obtained by reporting the maximum observed value PSCell UEs for UL during the granularity period.
- d) Each measurement is an integer value representing the maximum amount of PSCell UEs (UL).
- e) OR.UECNTX.MaxPscellUeUl.*NumScell* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MaxPscellUeUl.*NumScell* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *NumScell* is the number of active SCell:
 - 0: 1 active SCell
 - 1: 2 active SCell
 - ...
 - 30: 31 active SCell
- f) NRCellDU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.11.18 Minimum amount of PSCell UEs (UL)

- a) This counter obtains the minimum number of the PSCell UEs for UL.
This is optional counter for O-DU.
- b) CC
- c) The measurement is obtained by reporting the minimum observed value PSCell UEs for UL during the granularity period.
- d) Each measurement is an integer value representing the minimum amount of PSCell UEs (UL).
- e) OR.UECNTX.MinPscellUeUl.NumScell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MinPscellUeUl.NumScell (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *NumScell* is the number of active SCell:
 - 0: 1 active SCell
 - 1: 2 active SCell
 - ...
 - 30: 31 active SCell
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.19 Maximum amount of PSCell UEs (DL)

- a) This counter obtains the maximum number of the PSCell UEs for DL.
This is optional counter for O-DU.
- b) CC
- c) The measurement is obtained by reporting the maximum observed value PSCell UEs for DL during the granularity period.
- d) Each measurement is an integer value representing the maximum amount of PSCell UEs (DL).
- e) OR.UECNTX.MaxPscellUeDl.NumScell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.MaxPscellUeDl.NumScell (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *NumScell* is the number of active SCell:
 - 0: 1 active SCell
 - 1: 2 active SCell
 - ...
 - 30: 31 active SCell
- f) NRCellDU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.11.20 Minimum amount of PSCell UEs (DL)

- a) This counter obtains the minimum number of the PSCell UEs for DL.
This is optional counter for O-DU.
- b) CC
- c) The measurement is obtained by reporting the minimum observed value PSCell UEs for DL during the granularity period.
- d) Each measurement is an integer value representing the minimum amount of PSCell UEs (DL).
- e) OR.UECNTX.MinPscellUeDl.NumScell (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.MinPscellUeDl.NumScell (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *NumScell* is the number of active SCell:
 - 0: 1 active SCell
 - 1: 2 active SCell
 - ...
 - 30: 31 active SCell
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.21 Activation/Deactivation MAC CE (SCell Active)

- a) This counter provides the number of the Activation/Deactivation MAC Ces transmitted for Scell activation.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is the incremented by 1 whenever Activation/Deactivation MAC Ces is transmitted for Scell activation.
- d) Each measurement is an integer value representing the number of the Activation/Deactivation MAC Ces transmitted for Scell activation.
- e) OR.CARR.ActDeactMacCeScellAct (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.ActDeactMacCeScellAct (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.22 Activation/Deactivation MAC CE (SCell Deactive)

- a) This counter provides the number of the Activation/Deactivation MAC CEs transmitted for SCell deactivation. If Activation/Deactivation MAC CE isn't transmitted when sCellDeactivationTimer expires, this counter includes the number of sCellDeactivationTimer expiry.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is the incremented by 1 whenever Activation/Deactivation MAC CEs is transmitted for SCell deactivation or whenever sCellDeactivationTimer managed at O-DU expires.
- d) Each measurement is an integer value representing the number of the Activation/Deactivation MAC CEs transmitted for SCell deactivation.
- e) OR.CARR.ActDeactMacCeScellDeact (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.ActDeactMacCeScellDeact (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.23 Distribution of DL Total PRB Usage

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

O-RAN addition:

Averaging is done over a time period t_n (e.g: 1s).

- bin 1: $0 \% \leq \text{PRB usage} < 5 \%$
- bin 2: $5 \% \leq \text{PRB usage} < 10 \%$
- bin 3: $10 \% \leq \text{PRB usage} < 15 \%$
- bin 4: $15 \% \leq \text{PRB usage} < 20 \%$
- bin 5: $20 \% \leq \text{PRB usage} < 25 \%$
- bin 6: $25 \% \leq \text{PRB usage} < 30 \%$
- bin 7: $30 \% \leq \text{PRB usage} < 35 \%$
- bin 8: $35 \% \leq \text{PRB usage} < 40 \%$
- bin 9: $40 \% \leq \text{PRB usage} < 45 \%$
- bin 10: $45 \% \leq \text{PRB usage} < 50 \%$
- bin 11: $50 \% \leq \text{PRB usage} < 55 \%$
- bin 12: $55 \% \leq \text{PRB usage} < 60 \%$
- bin 13: $60 \% \leq \text{PRB usage} < 65 \%$
- bin 14: $65 \% \leq \text{PRB usage} < 70 \%$
- bin 15: $70 \% \leq \text{PRB usage} < 75 \%$
- bin 16: $75 \% \leq \text{PRB usage} < 80 \%$
- bin 17: $80 \% \leq \text{PRB usage} < 85 \%$
- bin 18: $85 \% \leq \text{PRB usage} < 90 \%$
- bin 19: $90 \% \leq \text{PRB usage} < 95 \%$
- bin 20: $95 \% \leq \text{PRB usage} < 100 \%$

This is recommended to support for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

O-RAN addition:

Averaging is done over a time period t_n (e.g: 1s) and the bin defined in description should be used.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

O-RAN addition:

OR.RRU.PrbTotDIDist.Bin or OR.RRU.PrbTotDIDist.Bin_*Filter*, where *Filter* is a combination of *PLMN* and *QOS* and *SNSSAI*, where *PLMN* represents the PLMN ID, *QOS* represents the mapped 5QI or QCI value, and *SNSSAI* represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

- i) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.3

A.4.11.24 Distribution of UL Total PRB Usage

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4

O-RAN addition:

Averaging is done over a time period t_n (e.g: 1s).

bin 1: $0 \% \leq \text{PRB usage} < 5 \%$
 bin 2: $5 \% \leq \text{PRB usage} < 10 \%$
 bin 3: $10 \% \leq \text{PRB usage} < 15 \%$
 bin 4: $15 \% \leq \text{PRB usage} < 20 \%$
 bin 5: $20 \% \leq \text{PRB usage} < 25 \%$
 bin 6: $25 \% \leq \text{PRB usage} < 30 \%$
 bin 7: $30 \% \leq \text{PRB usage} < 35 \%$
 bin 8: $35 \% \leq \text{PRB usage} < 40 \%$
 bin 9: $40 \% \leq \text{PRB usage} < 45 \%$
 bin 10: $45 \% \leq \text{PRB usage} < 50 \%$
 bin 11: $50 \% \leq \text{PRB usage} < 55 \%$
 bin 12: $55 \% \leq \text{PRB usage} < 60 \%$
 bin 13: $60 \% \leq \text{PRB usage} < 65 \%$
 bin 14: $65 \% \leq \text{PRB usage} < 70 \%$
 bin 15: $70 \% \leq \text{PRB usage} < 75 \%$
 bin 16: $75 \% \leq \text{PRB usage} < 80 \%$
 bin 17: $80 \% \leq \text{PRB usage} < 85 \%$
 bin 18: $85 \% \leq \text{PRB usage} < 90 \%$
 bin 19: $90 \% \leq \text{PRB usage} < 95 \%$
 bin 20: $95 \% \leq \text{PRB usage} < 100 \%$

This is recommended to support for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4

- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4

O-RAN addition:

Averaging is done over a time period t_n (e.g: 1s) and the bin defined in description should be used.

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4

O-RAN addition:

OR.RRU.PrbTotUIDist.Bin_*Filter*, where *Filter* is a combination of PLMN and QOS and SNSSAI, where *PLMN* represents the PLMN ID, *QOS* represents the mapped 5QI or QCI value, and *SNSSAI* represents S-NSSAI.

- f) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.1.2.4

A.4.11.25 Average DL Cell throughput

- a) This counter provides the Average DL Cell throughput of MAC. This counter is obtained by accumulating the MAC level volume of a data, and then dividing by the scheduled time per cell. The measurement is performed at the MAC level. This measurement can be split into subcounters per supported S-NSSAI.

This is optional counter for O-DU.

The counter is split into subcounters per S-NSSAI. The counter is recommended when related slice feature is supported.

- b) SI
- c) Measurement subcounter is calculated by x/y .
 x is incremented by the volume of DL MAC PDU whenever the successfully delivery of DL MAC PDU is confirmed.
 y is incremented by the transmission period (e.g. 0.5ms or 0.125ms) for the PDU whenever DL MAC PDU is transmitted (i.e. including HARQ retransmission) .
 If S-NSSAI subcounter is maintained, the number of measurements is accumulated per the number of supported S-NSSAI.
- d) Each measurement is an integer value representing the Average DL Cell throughput of MAC in kbps.
- e) OR.DRB.AveDLCellThroughput or OR.DRB.AveDLCellThroughput.*SNSSAI* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.AveDLCellThroughput or OR.CellU.AveDLCellThroughput.*SNSSAI* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where SNSSAI identifies the S-NSSAI.
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.26 Average UL Cell throughput

- a) This counter provides the Average UL Cell throughput of MAC. This counter is obtained by accumulating the MAC level volume of a data, and then dividing by the scheduled time per cell. The measurement is performed at the MAC level. This measurement can be split into subcounters per S-NSSAI.

This is optional counter for O-DU.

The counter is split into subcounters per S-NSSAI. The counter is recommended when related slice feature is supported.

- b) SI
- c) Measurement subcounter is calculated by x/y .
 x is incremented by the volume of UL MAC PDU whenever UL MAC PDU is successfully received.
 y is incremented by the transmission period whenever the UL MAC PDU is received (i.e. including HARQ retransmission) .
 If S-NSSAI subcounter is maintained, the number of measurements is accumulated per the number of supported S-NSSAI.
- d) Each measurement is an integer value representing the Average UL Cell throughput of MAC in kbps.
- e) OR.DRB.AveULCellThroughput or OR.DRB.AveULCellThroughput.*SNSSAI* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.AveULCellThroughput or OR.CellU.AveULCellThroughput.*SNSSAI* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *SNSSAI* identifies the S-NSSAI.
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.27 Average DL Beam throughput

- a) This counter provides the Average DL Beam throughput of MAC. This counter is obtained by accumulating the MAC level volume of a data, and then dividing by the scheduled time per SSB index. The measurement is performed at the MAC level.
 This is optional counter for O-DU.
- b) SI
- c) Measurement subcounter is calculated by x/y .
 x is incremented by the volume of DL MAC PDU whenever DL MAC PDU is confirmed the successfully delivery when the SSB used for PDSCH is the group of subcounter.*SSB*.
 y is incremented by the transmission period whenever the DL MAC PDU is transmitted (i.e. including HARQ retransmission) when the SSB used for PDSCH is the group of subcounter.*SSB*..
- d) Each measurement is an integer value representing the Average DL Beam throughput of MAC in kbps.
- e) OR.DRB.AveDLBeamThroughput.*SSB* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.AveDLBeamThroughput.*SSB* (deprecated, refer to NOTE in REQ-PMeas-MC-5) where *SSB* is the SSB index:
 0: #0
 1: #1
 ...
 63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.11.28 Average UL Beam throughput

- a) This counter provides the Average UL Beam throughput of MAC. This counter is obtained by accumulating the MAC level volume of a data, and then dividing by the scheduled time per SSB index. The measurement is performed at the MAC level.

This is optional counter for O-DU.

- b) SI
- c) Measurement subcounter is calculated by x/y .
 x is incremented by the volume of UL MAC PDU whenever UL MAC PDU is successfully received when the SSB used for PUSCH is the group of subcounter.SSB.
 y is incremented by the transmission period whenever the UL MAC PDU is received (i.e. including HARQ retransmission) when the SSB used for PUSCH is the group of subcounter.SSB.
- d) Each measurement is an integer value representing the Average UL Beam throughput of MAC in kbps.
- e) OR.DRB.AveULBeamThroughput.SSB (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.AveULBeamThroughput.SSB (deprecated, refer to NOTE in REQ-PMeas-MC-5) where SSB is the SSB index:
0: #0
1: #1
...
63: #63
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.29 Average DL active DRB

- a) This counter provides the average number of DL active DRB. This counter is obtained by averaging the number of the active DRB which has data in MAC/RLC buffer during measurement time per cell.
This is optional counter for O-DU.
- b) SI
- c) The measurement is obtained by reporting the average observed value of DL active DRB during the granularity period.
- d) Each measurement is an integer value representing the average number of DL active DRB.
- e) OR.DRB.AveDLActDrb (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.AveDLActDrb (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.11.30 Maximum DL active DRB

- a) This counter provides the maximum number of DL active DRB. This counter is obtained by providing the maximum number of the active DRB which has data in MAC/RLC buffer during measurement time per cell.
This is optional counter for O-DU.
- b) SI
- c) The measurement is obtained by reporting the maximum observed value of DL active DRB during the granularity period.
- d) Each measurement is an integer value representing the maximum number of DL active DRB.
- e) OR.DRB.MaxDLActDrb (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.MaxDLActDrb (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.31 Void

A.4.11.32 Void

A.4.11.33 Distribution of UL UE throughput in gNB

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

O-RAN addition:

The reference measurement time T for calculating the throughput of each UE is 1000ms.

The bins corresponding to the UL throughput experienced by the UE is defined as follow.

bin 1: $0 \leq \text{UL UE throughput} < 0.05 \times \text{Throughput}$

bin 2: $0.05 \times \text{Throughput} \leq \text{UL UE throughput} < 0.1 \times \text{Throughput}$

bin 3: $0.1 \times \text{Throughput} \leq \text{UL UE throughput} < 0.15 \times \text{Throughput}$

bin 4: $0.15 \times \text{Throughput} \leq \text{UL UE throughput} < 0.2 \times \text{Throughput}$

bin 5: $0.2 \times \text{Throughput} \leq \text{UL UE throughput} < 0.25 \times \text{Throughput}$

bin 6: $0.25 \times \text{Throughput} \leq \text{UL UE throughput} < 0.3 \times \text{Throughput}$

bin 7: $0.3 \times \text{Throughput} \leq \text{UL UE throughput} < 0.35 \times \text{Throughput}$

bin 8: $0.35 \times \text{Throughput} \leq \text{UL UE throughput} < 0.4 \times \text{Throughput}$

bin 9: $0.4 \times \text{Throughput} \leq \text{UL UE throughput} < 0.45 \times \text{Throughput}$

bin 10: $0.45 \times \text{Throughput} \leq \text{UL UE throughput} < 0.5 \times \text{Throughput}$

bin 11: $0.5 \times \text{Throughput} \leq \text{UL UE throughput} < 0.55 \times \text{Throughput}$

- bin 12: $0.55 \times \text{Throughput} \leq \text{UL UE throughput} < 0.6 \times \text{Throughput}$
- bin 13: $0.6 \times \text{Throughput} \leq \text{UL UE throughput} < 0.65 \times \text{Throughput}$
- bin 14: $0.65 \times \text{Throughput} \leq \text{UL UE throughput} < 0.7 \times \text{Throughput}$
- bin 15: $0.7 \times \text{Throughput} \leq \text{UL UE throughput} < 0.75 \times \text{Throughput}$
- bin 16: $0.75 \times \text{Throughput} \leq \text{UL UE throughput} < 0.8 \times \text{Throughput}$
- bin 17: $0.8 \times \text{Throughput} \leq \text{UL UE throughput} < 0.85 \times \text{Throughput}$
- bin 18: $0.85 \times \text{Throughput} \leq \text{UL UE throughput} < 0.9 \times \text{Throughput}$
- bin 19: $0.9 \times \text{Throughput} \leq \text{UL UE throughput} < 0.95 \times \text{Throughput}$
- bin 20: $0.95 \times \text{Throughput} \leq \text{UL UE throughput} < \text{Throughput}$

*Throughput is a predefined value in the implementation

The measurement is optionally calculated per S-NSSAI, per QoS level (mapped 5QI or QCI in EN-DC) and PLMN ID, according to 3GPP TS 28.552 [2] clause 5.1.1.3.4.

This is recommended to support for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

O-RAN addition:

The per UE throughput is calculated by the following formula. And the bin defined in description should be used.

If $\Sigma \text{ThpTimeUL} > 0$, $\frac{\Sigma \text{ThpVolUL}}{\Sigma \text{ThpTimeUL}} \times 1000 [\text{kbits/s}]$
 If $\Sigma \text{ThpTimeUL} = 0$, $0 [\text{kbit/s}]$

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

O-RAN addition:

The measurement name has the form OR.DRB.UEThpUIDist.Bin or OR.DRB.UEThpUIDist.Bin_*Filter*. Where *Filter* is a combination of PLMN, QoS level and SNSSAI. Where PLMN represents the PLMN ID, QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.

- f) gNBDFunction
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

A.4.11.34 Distribution of DL UE throughput in gNB

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

O-RAN addition:

The reference measurement time T for calculating the throughput of each UE is 1000ms.
 The bins corresponding to the DL throughput experienced by the UE is defined as follow.

- bin 1: $0 \leq \text{DL UE throughput} < 0.05 \times \text{Throughput}$
- bin 2: $0.05 \times \text{Throughput} \leq \text{DL UE throughput} < 0.1 \times \text{Throughput}$
- bin 3: $0.1 \times \text{Throughput} \leq \text{DL UE throughput} < 0.15 \times \text{Throughput}$

bin 4: $0.15 \times \text{Throughput} \leq \text{DL UE throughput} < 0.2 \times \text{Throughput}$
bin 5: $0.2 \times \text{Throughput} \leq \text{DL UE throughput} < 0.25 \times \text{Throughput}$
bin 6: $0.25 \times \text{Throughput} \leq \text{DL UE throughput} < 0.3 \times \text{Throughput}$
bin 7: $0.3 \times \text{Throughput} \leq \text{DL UE throughput} < 0.35 \times \text{Throughput}$
bin 8: $0.35 \times \text{Throughput} \leq \text{DL UE throughput} < 0.4 \times \text{Throughput}$
bin 9: $0.4 \times \text{Throughput} \leq \text{DL UE throughput} < 0.45 \times \text{Throughput}$
bin 10: $0.45 \times \text{Throughput} \leq \text{DL UE throughput} < 0.5 \times \text{Throughput}$
bin 11: $0.5 \times \text{Throughput} \leq \text{DL UE throughput} < 0.55 \times \text{Throughput}$
bin 12: $0.55 \times \text{Throughput} \leq \text{DL UE throughput} < 0.6 \times \text{Throughput}$
bin 13: $0.6 \times \text{Throughput} \leq \text{DL UE throughput} < 0.65 \times \text{Throughput}$
bin 14: $0.65 \times \text{Throughput} \leq \text{DL UE throughput} < 0.7 \times \text{Throughput}$
bin 15: $0.7 \times \text{Throughput} \leq \text{DL UE throughput} < 0.75 \times \text{Throughput}$
bin 16: $0.75 \times \text{Throughput} \leq \text{DL UE throughput} < 0.8 \times \text{Throughput}$
bin 17: $0.8 \times \text{Throughput} \leq \text{DL UE throughput} < 0.85 \times \text{Throughput}$
bin 18: $0.85 \times \text{Throughput} \leq \text{DL UE throughput} < 0.9 \times \text{Throughput}$
bin 19: $0.9 \times \text{Throughput} \leq \text{DL UE throughput} < 0.95 \times \text{Throughput}$
bin 20: $0.95 \times \text{Throughput} \leq \text{DL UE throughput} < \text{Throughput}$

*Throughput is a predefined value in the implementation

The measurement is optionally calculated per S-NSSAI, per QoS level (mapped 5QI or QCI in EN-DC) and PLMN ID, according to 3GPP TS 28.552 [2] clause 5.1.1.3.2.

This is recommended to support for O-DU.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

O-RAN addition:

The per UE throughput is calculated by the following formula. And the bin defined in description should be used.

If $\Sigma \text{ThpTimeDl} > 0, \frac{\Sigma \text{ThpVolDl}}{\Sigma \text{ThpTimeDl}} \times 1000 [\text{kbits/s}]$
If $\Sigma \text{ThpTimeDl} = 0, 0 [\text{kbit/s}]$

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

O-RAN addition:

The measurement name has the form OR.DRB.UEThpDlDist.Bin or OR.DRB.UEThpDlDist.Bin_*Filter*. Where *Filter* is a combination of PLMN, QoS level and SNSSAI. Where PLMN represents the PLMN ID, QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.

- f) gNBDFunction
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

A.4.11.35 Distribution of DL packet drop rate

- a) This measurement provides distribution of UE's fraction of RLC SDU packets which are dropped on the downlink, due to high traffic load, traffic management etc, in the gNB-DU. Only user-plane traffic (DTCH) is considered. A dropped packet is one who context is removed from the gNB-DU without any part of it having been transmitted on the air interface.

The measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC) and per S-NSSAI. The filter is recommended when related slice feature is supported.

The reference measurement time T for calculating the packet drop rate of each UE is 1000ms.

The bins corresponding to the DL packet drop rate experienced by the UE is defined as follow.

- bin 1: $0 \leq \text{DL Packet drop rate} < 5$
- bin 2: $5 \leq \text{DL Packet drop rate} < 10$
- bin 3: $10 \leq \text{DL Packet drop rate} < 15$
- bin 4: $15 \leq \text{DL Packet drop rate} < 20$
- bin 5: $20 \leq \text{DL Packet drop rate} < 25$
- bin 6: $25 \leq \text{DL Packet drop rate} < 30$
- bin 7: $30 \leq \text{DL Packet drop rate} < 35$
- bin 8: $35 \leq \text{DL Packet drop rate} < 40$
- bin 9: $40 \leq \text{DL Packet drop rate} < 45$
- bin 10: $45 \leq \text{DL Packet drop rate} < 50$
- bin 11: $50 \leq \text{DL Packet drop rate} < 55$
- bin 12: $55 \leq \text{DL Packet drop rate} < 60$
- bin 13: $60 \leq \text{DL Packet drop rate} < 65$
- bin 14: $65 \leq \text{DL Packet drop rate} < 70$
- bin 15: $70 \leq \text{DL Packet drop rate} < 75$
- bin 16: $75 \leq \text{DL Packet drop rate} < 80$
- bin 17: $80 \leq \text{DL Packet drop rate} < 85$
- bin 18: $85 \leq \text{DL Packet drop rate} < 90$
- bin 19: $90 \leq \text{DL Packet drop rate} < 95$
- bin 20: $95 \leq \text{DL Packet drop rate}$

- b) SI
- c) This measurement is obtained as: $1000000 \times \text{Number of DL packets, for which no part has been transmitted over the air, of the data radio bearers for each UE, that are discarded in the gNB-DU divided by Number of DL packets for data radio bearers for each UE that were received from gNB-CU-UP. Then map packet drop rate to the bins according to their value and the thresholds of the bins and then provide an integer value of the number of samples in Bin}$

Optionally QoS and S-NSSAI filtering is obtained by the number of measurements is accumulated per the number of supported QoS and S-NSSAI.

- d) Each measurement is an integer value representing the distribution of UE's fraction of RLC SDU packets which are dropped on the downlink, due to high traffic load, traffic management etc, in the gNB-DU.
- e) The measurement name has the form OR.DRB.RlcPacketDropRateDlDist.Bin or OR.DRB.RlcPacketDropRateDlDist.Bin_Filter. Where *Filter* is a combination of QoS level and SNSSAI. Where QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.
- f) gNBFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.36 PDCCH for BWP switching

- a) This measurement provides the total number of PDCCH for BWP switching. This measurement optionally is split into subcounters per BWP ID.
- b) CC
- c) The measurement is incremented by 1 whenever PDCCH for BWP switching is triggered. This measurement shall not count retransmission.

If the optional BWP ID level subcounter measurements are performed, the number of measurements is equal to the number of BWP IDs to which the target BWP is to be switched.

- d) Each measurement is an integer value representing the total number of PDCCH for BWP switching.
- e) OR.RRU.PdcchBwpSwitch or optionally OR.RRU.PdcchBwpSwitch.*BWP* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.Cell.PdcchBwpSwitch or optionally OR.Cell.PdcchBwpSwitch.*BWP* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *BWP* is BWP ID.
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.37 Distribution of Activated BWP ID

- a) This measurement provides distribution of UEs for activated BWP. The measurement is split into subcounters per active BWP ID. This counter obtains the number of the UEs.
- b) CC
- c) Measurement subcounter is incremented by the number of the UEs per active BWP ID. This measurement shall count UEs configured multiple BWPs and triggered BWP switching by PDCCH. (ex. Energy saving). The number of UEs is acquired as an instantaneous value.

The measurement is obtained by calculating the observed distribution of UEs for activated BWP ID per granularity period

- d) Each measurement is an integer value representing the distribution of UEs for activated BWP.
- e) OR.RRU.DistActBwpId.*BWP* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.Cell.DistActBwpId.*BWP* (deprecated, refer to NOTE in REQ-PMeas-MC-5), where *BWP* is BWP ID.
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.38 Non-linear Scale Distribution of UL UE throughput in gNB

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

O-RAN addition:

The reference measurement time T for calculating the throughput of each UE is 1000ms.
The bins corresponding to the UL throughput experienced by the UE is defined as follows.

bin1: 0 kbps <= UL UE Throughput < 100 Kbps
bin2: 100 Kbps <= UL UE Throughput < 200 Kbps
bin3: 200 Kbps <= UL UE Throughput < 500 Kbps
bin4: 500 Kbps <= UL UE Throughput < 1 Mbps
bin5: 1 Mbps <= UL UE Throughput < 2 Mbps
bin6: 2 Mbps <= UL UE Throughput < 5 Mbps
bin7: 5 Mbps <= UL UE Throughput < 10 Mbps
bin8: 10 Mbps <= UL UE Throughput < 20 Mbps
bin9: 20 Mbps <= UL UE Throughput < 40 Mbps
bin10: 40 Mbps <= UL UE Throughput < 60 Mbps
bin11: 60 Mbps <= UL UE Throughput < 80 Mbps
bin12: 80 Mbps <= UL UE Throughput < 100 Mbps
bin13: 100 Mbps <= UL UE Throughput < 200 Mbps
bin14: 200 Mbps <= UL UE Throughput < 400 Mbps
bin15: 400 Mbps <= UL UE Throughput < 600 Mbps
bin16: 600 Mbps <= UL UE Throughput < 800 Mbps
bin17: 800 Mbps <= UL UE Throughput < 1 Gbps
bin18: 1 Gbps <= UL UE Throughput < 2 Gbps
bin19: 2 Gbps <= UL UE Throughput < 5 Gbps
bin20: 5 Gbps <= UL UE Throughput

The measurement is optionally calculated per S-NSSAI, per QoS level (mapped 5QI or QCI in EN-DC) and PLMN ID, according to 3GPP TS 28.552 [2] clause 5.1.1.3.4.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

O-RAN addition:

The per UE throughput is calculated by the following formula. And the bin defined in description should be used.

If $\Sigma \text{ThpTimeUL} > 0$, $\frac{\Sigma \text{ThpVolUL}}{\Sigma \text{ThpTimeUL}} \times 1000 [\text{kbits/s}]$
If $\Sigma \text{ThpTimeUL} = 0$, 0 [kbit/s]

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

O-RAN addition:

The measurement name has the form OR.DRB.UETHpUILogDist.Bin or OR.DRB.UETHpUILogDist.Bin_*Filter*. Where *Filter* is a combination of PLMN, QoS level and SNSSAI. Where PLMN represents the PLMN ID, QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.

- f) gNBDUFunction
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.4

A.4.11.39 Non-linear Scale Distribution of DL UE throughput in gNB

- a) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

O-RAN addition:

The reference measurement time T for calculating the throughput of each UE is 1000ms.
The bins corresponding to the DL throughput experienced by the UE is defined as follows.

bin1: 0 kbps $\leq$ DL UE Throughput < 500 Kbps
bin2: 500 Kbps $\leq$ DL UE Throughput < 1 Mbps
bin3: 1 Mbps $\leq$ DL UE Throughput < 5 Mbps
bin4: 5 Mbps $\leq$ DL UE Throughput < 10 Mbps
bin5: 10 Mbps $\leq$ DL UE Throughput < 20 Mbps
bin6: 20 Mbps $\leq$ DL UE Throughput < 40 Mbps
bin7: 40 Mbps $\leq$ DL UE Throughput < 60 Mbps
bin8: 60 Mbps $\leq$ DL UE Throughput < 80 Mbps
bin9: 80 Mbps $\leq$ DL UE Throughput < 100 Mbps
bin10: 100 Mbps $\leq$ DL UE Throughput < 120 Mbps
bin11: 120 Mbps $\leq$ DL UE Throughput < 160 Mbps
bin12: 160 Mbps $\leq$ DL UE Throughput < 200 Mbps
bin13: 200 Mbps $\leq$ DL UE Throughput < 400 Mbps
bin14: 400 Mbps $\leq$ DL UE Throughput < 800 Mbps
bin15: 800 Mbps $\leq$ DL UE Throughput < 1.6 Gbps
bin16: 1.6 Gbps $\leq$ DL UE Throughput < 2 Gbps
bin17: 2 Gbps $\leq$ DL UE Throughput < 4 Gbps
bin18: 4 Gbps $\leq$ DL UE Throughput < 8 Gbps
bin19: 8 Gbps $\leq$ DL UE Throughput < 16 Gbps
bin20: 16 Gbps $\leq$ DL UE Throughput

The measurement is optionally calculated per S-NSSAI, per QoS level (mapped 5QI or QCI in EN-DC) and PLMN ID, according to 3GPP TS 28.552 [2] clause 5.1.1.3.2.

- b) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- c) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

O-RAN addition:

The per UE throughput is calculated by the following formula. And the bin defined in description should be used.

If $\Sigma \text{ThpTimeDl} > 0$, $\frac{\Sigma \text{ThpVoldl}}{\Sigma \text{ThpTimeDl}} \times 1000 [\text{kbits/s}]$
If $\Sigma \text{ThpTimeDl} = 0$, $0 [\text{kbit/s}]$

- d) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- e) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

O-RAN addition:

The measurement name has the form OR.DRB.UEThpDlLogDist.Bin or OR.DRB.UEThpDlLogDist.Bin_*Filter*. Where *Filter* is a combination of PLMN, QoS level and SNSSAI. Where PLMN represents the PLMN ID, QoS represents the mapped 5QI or QCI level, and SNSSAI represents S-NSSAI.

- f) gNBDFunction
- g) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- h) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2
- i) Refer to 3GPP TS 28.552 [2] clause 5.1.1.3.2

A.4.11.40 PUSCH slots

- a) This counter provides the number of the slots when PUSCH was received.
This is recommended to support for O-DU.
- b) CC

- c) Measurement subcounter is incremented by 1 whenever PUSCH is received.
- d) Each measurement is an integer value representing the number of the slots when PUSCH was received.
- e) OR.RRU.PuschSlot (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.PuschSlot (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.41 PDSCH slots

- a) This counter provides the number of the slots when PDSCH was transmitted.
This is recommended to support for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDSCH is transmitted.
- d) Each measurement is an integer value representing the number of the slots when PDSCH was transmitted.
- e) OR.RRU.PdschSlot (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.PdschSlot (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.42 PDCCH slots

- a) This counter provides the number of the slots when PDCCH was transmitted.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever PDCCH is transmitted.
- d) Each measurement is an integer value representing the number of the slots when PDCCH was transmitted.
- e) OR.RRU.PdcchSlot (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.PdcchSlot (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.43 CCE utilization rate

- a) This counter measures the following x in the report period and provides $\text{round}(x, 2) \cdot 10^2$. x is the usage rate of CCE.

This is recommended to support for O-DU.

- b) SI
- c) Measurement subcounter is $\text{round}(x/y, 2) \cdot 10^2$.
 x is incremented by the number of CCEs which are used to transmit DCI whenever PDCCH is transmitted.
 y is incremented by the number of CCEs which can be used whenever PDCCH is transmitted.
- d) Each measurement is an integer value representing the CCE utilization rate in percentage/ 10^2 .
- e) OR.RRU.CceUtilizationRate (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.CceUtilizationRate (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.44 UEs buffering UL and DL data

- a) This counter provides the accumulated number of the UEs buffering both UL and DL data.
This is recommended to support for O-DU.
- b) CC
- c) The measurement is incremented by the number of the UEs which have both UL and DL data and optionally with filter.
The measurement is obtained by reporting the accumulated observed value of the UEs buffering both UL and DL data during the granularity period.
NOTE: multiple 5QIs can be set per UE, each 5QI is counted per QoS flow.
- d) Each measurement is an integer value representing the accumulated number of the UEs buffering both UL and DL data.
- e) The measurement name has the form OR.DRB.UeBufferingUplinkData or OR.DRB.UeBufferingUplinkData_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.UeBufferingUplinkData or OR.CellU.UeBufferingUplinkData_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.45 UEs buffering UL data

- a) This counter provides the accumulated number of the UEs buffering UL data.

This is recommended to support for O-DU.

- b) CC

- c) The measurement is incremented by the number of the Ues, optionally when UL data is the filter.

The measurement is obtained by reporting the accumulated observed value of the UEs buffering UL data during the granularity period.

NOTE: multiple 5QIs can be set per UE, each 5QI is counted per QoS flow.

- d) Each measurement is an integer value representing the accumulated number of the UEs buffering UL data.
- e) The measurement name has the form OR.DRB.UeBufferingULData or OR.DRB.UeBufferingULData_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.UeBufferingULData or OR.CellU.UeBufferingULData_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.46 UEs buffering DL data

- a) This counter provides the accumulated number of the UEs buffering DL data.

This is recommended to support for O-DU.

- b) CC

- c) This measurement provides the accumulated number of UEs buffering DL data. This measurement is optionally calculated per QoS level (mapped 5QI or QCI in EN-DC). The measurement is incremented by the number of the Ues, optionally when DL data is the filter.

The measurement is obtained by reporting the accumulated observed value of the UEs buffering DL data during the granularity period.

NOTE: multiple 5QIs can be set per UE, each 5QI is counted per QoS flow.

- d) Each measurement is an integer value representing the accumulated number of the UEs buffering DL data.
- e) The measurement name has the form OR.DRB.UeBufferingDLData or OR.DRB.UeBufferingDLData_*Filter* (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.UeBufferingDLData or OR.CellU.UeBufferingDLData_*Filter* (deprecated, refer to NOTE in REQ-PMeas-MC-5). Where *Filter* is the QoS level. Where QoS represents the mapped 5QI or QCI level.
- f) NRCelIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.47 DRX inactive UEs

- a) This counter provides the accumulated number of the UEs configured as DRX inactive.
This is optional counter for O-DU.
- b) CC
- c) Measurement is incremented by the number of UEs of which *drx-InactivityTimer* is assumed to be running.
The measurement is obtained by reporting the accumulated observed value of the UEs configured as DRX inactive during the granularity period.
- d) Each measurement is an integer value representing the accumulated number of the UEs configured as DRX inactive.
- e) OR.UECNTX.DrxInactUe (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.DrxInactUe (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.48 DRX active UEs

- a) This counter provides the accumulated number of the UEs configured as DRX active.
This is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by the number of UEs which is configured *drx-config* and of which *drx-InactivityTimer* is assumed not to be running.
The measurement is obtained by reporting the accumulated observed value of the UEs configured as DRX active during the granularity period.
- d) Each measurement is an integer value representing the accumulated number of the UEs configured as DRX active.
- e) OR.UECNTX.DrxActUe (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family), OR.CellU.DrxActUe (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.11.49 PDSCH slot for paging

- a) This counter provides the number of PDSCH slot in which paging message is actually transmitted.
- b) CC

- c) This counter is incremented by 1 even when the same paging message is transmitted for different beam.
- d) Each measurement is an integer value representing the number of PDSCH slot in which paging message is actually transmitted.
- e) OR.RRU.PdschSlotForPaging (default, refer to 3GPP TS 28.552 [2] clause 3.3 Measurement Family),
OR.CellU.PdschSlotForPaging (deprecated, refer to NOTE in REQ-PMeas-MC-5)
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.12 Void

A.4.13 O-RU Performance measurements measured at O-DU

A.4.13.1 Uplink data and control frames received in total

- a) The total number of control/user plane messages received.
It is recommended to support for O-DU.
- b) CC
- c) The total number of control/user plane eCPRI or 1914.3 messages received. This counter is the sum of all valid and errored messages received.
- d) Each measurement is an integer value representing the total number of control/user plane messages received.
- e) OR.ORU.RX.Total
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.2 Uplink data frames received on Time

- a) The number of inbound user plane messages that arrived within the specified time window.
It is recommended to support for O-DU.
- b) CC
- c) The number of inbound user plane (ecpri type 0) messages that arrived within the specified time window. Some "on time" messages may have sequence number errors or corruption errors but as long as they arrived within specified window time, this counter should include them. If the received message has been transport-fragmented, the full message shall be reassembled before checking its arrival window.
- d) Each measurement is an integer value representing the number of inbound user plane messages that arrived within the specified time window.

- e) OR.ORU.RXData.OnTime
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.3 Uplink data frames received too early

- a) The number of inbound user plane messages which were detected to have arrived before the start of their designated receive window time.

It is recommended to support for O-DU.
- b) CC
- c) The number of inbound user plane messages which were detected to have arrived before the start of their designated receive window time.
- d) Each measurement is an integer value representing the number of inbound user plane messages which were detected to have arrived before the start of their designated receive window time.
- e) OR.ORU.RXData.TooEarly
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.4 Uplink data frames received too late

- a) The number of inbound user plane messages which were detected to have arrived after the end of their designated receive window time.

It is recommended to support for O-DU.
- b) CC
- c) The number of inbound user plane messages which were detected to have arrived after the end of their designated receive window time.
- d) Each measurement is an integer value representing the number of inbound user plane messages which were detected to have arrived after the end of their designated receive window time.
- e) OR.ORU.RXData.TooLate
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.5 Uplink control frames received on Time

- a) The number of inbound control plane messages that are completely arrived within the reception time window for uplink C-Plane messages (C-Plane UL). Refer to WG4 CUS-Plane specification [i.2], clause 4.4.3 and clause 9.1 for details.

It is recommended to support for O-DU.

- b) CC
- c) The number of valid inbound control plane (ecpri type 2) messages that arrived within the specified time window. Some “on time” messages may have sequence number errors or corruption errors but as long as they arrived within specified window time, this counter should count them.
- d) Each measurement is an integer value representing the number of inbound control plane messages that are completely arrived within the reception time window for uplink C-Plane messages (C-Plane UL).
- e) OR.ORU.RXControl.OnTime
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator’s Traffic Engineering Community

A.4.13.6 Uplink control frames received too early

- a) The number of inbound control plane messages which were detected to be arrived before the start of their designated reception time window for uplink C-Plane messages (C-Plane UL). Refer to WG4 CUS-Plane specification [i.2], clause 4.4.3 and clause 9.1 for details.

It is recommended to support for O-DU.

- b) CC
- c) The number of inbound control plane messages which were detected to be arrived before the start of their designated reception window time.

This counter increments whether the message is subsequently processed or dropped.
- d) Each measurement is an integer value representing the number of inbound control plane messages which were detected to be arrived before the start of their designated reception time window for uplink C-Plane messages (C-Plane UL).
- e) OR.ORU.RXControl.TooEarly
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator’s Traffic Engineering Community

A.4.13.7 Uplink control frames received too late

- a) The number of inbound control plane messages which were detected to be arrived after the end of their designated reception time window for C-Plane messages (C-Plane UL). Refer to WG4 CUS-Plane specification [i.2], clause 4.4.3 and clause 9.1 for details.

It is recommended to support for O-DU.

- b) CC
- c) The number of inbound control plane messages which were detected to be arrived after the end of their designated reception window time.
This counter increments whether the message is subsequently processed or dropped.
- d) Each measurement is an integer value representing the number of inbound control plane messages which were detected to be arrived after the end of their designated reception time window for C-Plane messages (C-Plane UL).
- e) OR.ORU.RXControl.TooLate
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.8 Uplink data frames with detecting sequence identifier error

- a) The number of inbound on time user plane messages in which a sequence identifier number error is detected.

It is optional counter for O-DU.

- b) CC
- c) The number of inbound on time user plane messages in which a sequence identifier number error is detected.
This error occurs when the ecpriSeqId field does not increment. Both the Sequence ID, and Subsequence ID fields must be checked if transport fragmentation is supported otherwise only the Sequence ID field may be checked.
In addition to identifying a sending equipment sequencing error, this counter can increment when packets are dropped prior to reception by the RU, or when packets reordered by the network exceed the receiving device's capabilities.
- d) Each measurement is an integer value representing the number of inbound on time user plane messages in which a sequence identifier number error is detected.
- e) OR.ORU.RXData.SeqidErr
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.9 Uplink control frames with detecting sequence identifier error

- a) The number of inbound on time control messages in which a sequence identifier number error is detected.

It is optional counter for O-DU.

- b) CC
- c) The number of inbound on time control messages in which a sequence identifier number error is detected.
This counter increments under the same conditions as the rx_seqid_num_err except for control plane messages.
- d) Each measurement is an integer value representing the number of inbound on time control messages in which a sequence identifier number error is detected.
- e) OR.ORU.RXControl.SeqidErr
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.10 Uplink frames with corrupt contents

- a) The number of inbound on time messages with a correct ecpriSeqId (no sequence number error) which are dropped by the terminating entity due to the message containing one or more eCPRI/1914.3 or ORAN protocol errors.

It is optional counter for O-DU.

- b) CC
- c) The number of inbound on time messages with a correct ecpriSeqId (no sequence number error) which are dropped by the terminating entity due to the message containing one or more eCPRI/1914.3 or ORAN protocol errors.

Protocol errors are defined as when eCPRI/1914.3/ORAN defined fields contain invalid values or indicate unsupported capabilities. Some examples of this are:
 1. PcId or section Id number which has not been configured.
 2. Unexpected use of C bit,
 3. Unconfigured or Unsupported udCompHdr setting.
 4. Unsupported section extension.
 5. Wrong ecpriVersion and/or payloadVersion information
 6. ecpriMessage field does not contain 0, 2, or 5.
- d) Each measurement is an integer value representing the number of inbound on time messages with a correct ecpriSeqId (no sequence number error) which are dropped by the terminating entity due to the message containing one or more eCPRI/1914.3 or ORAN protocol errors.
- e) OR.ORU.RX.Corrupt
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.11 Uplink frames dropped and discarded

- a) The total number of inbound messages which are discarded by the receiving O-RAN entity for any reason.

It is optional counter for O-DU.

- b) CC
- c) The total number of inbound messages which are discarded by the receiving O-RAN entity for any reason.
- d) Each measurement is an integer value representing the total number of inbound messages which are discarded by the receiving O-RAN entity for any reason.
- e) OR.ORU.RX.ErrDrop
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.12 Downlink control and data frames transmitted

- a) The number of valid outbound control/user plane messages.

It is recommended to support for O-DU.

- b) CC
- c) The number of valid outbound control/user plane messages.
- d) Each measurement is an integer value representing the number of valid outbound control/user plane messages.
- e) OR.ORU.TX.Total
- f) aggregation (O-RU)
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.13 Downlink control frames transmitted to O-RU in total at O-DU

- a) The number of valid outbound control plane messages. This counter is required only if O-RU supports LAA/LBT capabilities.

It is recommended to support for O-DU.

- b) CC
- c) The number of valid outbound control plane messages. This counter is required only if O-RU supports LAA/LBT capabilities.
- d) Each measurement is an integer value representing the number of valid outbound control plane messages.
- e) OR.ORU.TXControl.Total
- f) aggregation (O-RU)
- g) Packet Switched

- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.14 TRx Control activation

- a) This counter is divided into sub-counters, each of which provides the cumulative number of times the O-DU has attempted to activate the specific TRx Control configuration to the O-RU using C-Plane command within a specified reporting period.

The O-DU increments this sub-counter when it sends a C-Plane command to activate a specific TRx Control configuration in the O-RU.

The counter name follows the format OR.ORU.TrxCtrl.ActReq_Filter,

where the filter represents the configuration ID (NOTE: This ID should correspond to the "mask-name" in the list **supported-trx-control-masks** provided by O-RU in o-ran-module-cap.yang module and can be referenced in clause 20.3.1.2 of [4]).

For example, if the configuration is indexed by the mask-name "32TRx", then the sub-counter name would be OR.ORU.TrxCtrl.ActReq.32TRx.

This is optional counter for O-DU.

- b) CC
- c) O-RU supports Energy Saving by employing TRx Control.
- d) Each measurement is an integer value representing the cumulative number of times the O-DU has attempted to activate the specific TRx Control configuration to the O-RU using C-Plane command within a specified reporting period.
- e) OR.ORU.TrxCtrl.ActReq_Filter
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.15 TRx Control activation failure

- a) This counter accumulates the total number of failures that occurred when O-DU attempts to activate the specific TRx Control configuration in O-RU using C-Plane command within a designated reporting period.

This counter is divided into sub-counters, each of which counts the unsuccessful attempts by the O-DU to activate a specific TRx Control configuration in the O-RU.

The O-DU increments the counter when it experiences a failure while attempting to activate a specific TRx Control configuration in the O-RU using a C-Plane command. Failures are counted based on:

- The reception of a NACK message
- The absence of expected ACK message

The counter name follows the format OR.ORU.TrxCtrl.Fail_Filter,

where the filter represents the configuration ID (NOTE: This ID should correspond to the "mask-name" in the list **supported-trx-control-masks** provided by O-RU in o-ran-module-cap.yang module and can be referenced in clause 20.3.1.2 of [4]).

For example, if the configuration is indexed by the mask-name "32TRx", then the sub-counter name would be OR.ORU.TrxCtrl.Fail.32TRx.

This is optional counter for O-DU.

- b) CC
- c) O-RU supports Energy Saving by employing TRx Control.
- d) Each measurement is an integer value representing the total number of failures that occurred when O-DU attempts to activate the specific TRx Control configuration in O-RU using C-Plane command within a designated reporting period.
- e) OR.ORU.TrxCtrl.Fail_Filter
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.16 TRx Control Cumulative Activity time

- a) This counter provides the cumulative time that the O-RU utilizes in energy-saving mode using the TRx Control configuration within each reporting period.

This counter is divided into sub-counters, each recording the cumulative duration that the O-RU spends in a specific TRx Control configuration from the moment it is activated by the O-DU using C-Plane command.

Time is measured in milliseconds and should be rounded up in the event of a fractional result. The O-DU starts the timer immediately upon receiving confirmation of the activation of a specific TRx Control configuration in the O-RU. This counter becomes pertinent only when the O-DU receives an ACK/NACK message from the O-RU for the C-Plane based TRx Control implementation.

The counter name follows the format OR.ORU.TrxCtrl.UtiTime_Filter,

where the filter represents the configuration ID (NOTE: This ID should correspond to the "mask-name" in the list **supported-trx-control-masks** provided by O-RU in o-ran-module-cap.yang module and can be referenced in clause 20.3.1.2 of [4]).

For example, if the configuration is indexed by the mask-name "32TRx", then the sub-counter name would be OR.ORU.TrxCtrl.UtiTime.32TRx.

This is optional counter for O-DU.

- b) CC
- c) The O-RU supports Energy Saving by employing TRx Control. At least one TRx Control configuration is activated to conserve energy within the O-RU.
- d) Each measurement is an integer value representing the cumulative time that the O-RU utilizes in energy-saving mode using the TRx Control configuration within each reporting period in unit of time.
- e) OR.ORU.TrxCtrl.UtiTime_Filter
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.17 Advanced Sleep Mode activation

- a) This counter is divided into sub-counters, each of which provides the cumulative number of times the O-DU has attempted to activate the specific Sleep Mode to the O-RU using C-Plane command within a specified reporting period.

The O-DU increments this sub-counter when it sends a C-Plane command to activate a specific Sleep Mode in the O-RU. The counter name follows the format OR.ORU.Asm.ActReq_Filter,

where the filter represents the configuration ID (NOTE: This ID should correspond to the "sleep-mode-type" provided by O-RU in the o-ran-module-cap.yang module and can be referenced in clause 20.4.1 of [4]).

As sub-counters are in relation to specific Sleep Modes by values of sleep-mode-type node, expected names for sub-counters are as follows:

name of sub-counter for SLEEP_MODE_0 should be OR.ORU.Asm.ActReq.SM0,
name of sub-counter for SLEEP_MODE_1 should be OR.ORU.Asm.ActReq.SM1,
name of sub-counter for SLEEP_MODE_2 should be OR.ORU.Asm.ActReq.SM2,
name of sub-counter for SLEEP_MODE_3 should be OR.ORU.Asm.ActReq.SM3.

This is optional counter for O-DU.

- b) CC
- c) O-RU supports Energy Saving by employing Advanced Sleep Mode.
- d) Each measurement is an integer value representing the cumulative number of times the O-DU has attempted to activate the specific Sleep Mode to the O-RU using C-Plane command within a specified reporting period.
- e) OR.ORU.Asm.ActReq_Filter
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.18 Advanced Sleep Mode activation failure

- a) This counter accumulates the total number of failures that occurred when O-DU attempts to activate the specific Sleep Mode in O-RU using C-Plane command within a designated reporting period.

This counter is divided into sub-counters, each of which counts the unsuccessful attempts by the O-DU to activate a specific Sleep Mode in the O-RU.

The O-DU increments the counter when it experiences a failure while attempting to activate a specific Sleep Mode in the O-RU using a C-Plane command. Failures are counted based on:

- The reception of a NACK message
- The absence of expected ACK message

The counter name follows the format OR.ORU.Asm.Fail_Filter,

where the filter represents the configuration ID (NOTE: This ID should correspond to the "sleep-mode-type" provided by O-RU in the o-ran-module-cap.yang module and can be referenced in clause 20.4.1 of [4]).

As sub-counters are in relation to specific Sleep Modes by values of sleep-mode-type node, expected names for sub-counters are as follows:

name of sub-counter for SLEEP_MODE_0 should be OR.ORU.Asm.Fail.SM0,
name of sub-counter for SLEEP_MODE_1 should be OR.ORU.Asm.Fail.SM1,
name of sub-counter for SLEEP_MODE_2 should be OR.ORU.Asm.Fail.SM2,
name of sub-counter for SLEEP_MODE_3 should be OR.ORU.Asm.Fail.SM3.

This is optional counter for O-DU.

- b) CC
- c) O-RU supports Energy Saving by employing Advanced Sleep Mode.
- d) Each measurement is an integer value representing the total number of failures that occurred when O-DU attempts to activate the specific Sleep Mode in O-RU using C-Plane command within a designated reporting period.
- e) OR.ORU.Asm.Fail_Filter
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.13.19 Advanced Sleep Mode Cumulative Activity time

- a) This counter provides the cumulative time that the O-RU utilizes in energy-saving mode using the Sleep Mode within each reporting period.

This counter is divided into sub-counters, each recording the cumulative duration that the O-RU spends in a specific Sleep Mode from the moment it is activated by the O-DU using C-Plane command.

Time is measured in milliseconds and should be rounded up in the event of a fractional result. The O-DU starts the timer immediately upon receiving confirmation of the activation of a specific Sleep Mode in the O-RU. This counter becomes pertinent only when the O-DU receives an ACK/NACK message from the O-RU for the C-Plane based Advanced Sleep Mode implementation.

The counter name follows the format OR.ORU.Asm.UtiTime_Filter,

where the filter represents the configuration ID (NOTE: This ID should correspond to the "sleep-mode-type" provided by O-RU in the o-ran-module-cap.yang module and can be referenced in clause 20.4.1 of [4]).

As sub-counters are in relation to specific Sleep Modes by values of sleep-mode-type node, expected names for sub-counters are as follows:

name of sub-counter for SLEEP_MODE_0 should be OR.ORU.Asm.UtiTime.SM0,
name of sub-counter for SLEEP_MODE_1 should be OR.ORU.Asm.UtiTime.SM1,
name of sub-counter for SLEEP_MODE_2 should be OR.ORU.Asm.UtiTime.SM2,
name of sub-counter for SLEEP_MODE_3 should be OR.ORU.Asm.UtiTime.SM3.

This is optional counter for O-DU.

- b) CC
- c) The O-RU supports Energy Saving by employing Advanced Sleep Mode. At least one Sleep Mode is activated to conserve energy within the O-RU.
- d) Each measurement is an integer value representing the cumulative time that the O-RU utilizes in energy-saving mode using the Sleep Mode within each reporting period in unit of time.
- e) OR.ORU.Asm.UtiTime_Filter
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.14 O-RU Performance measurements measured at O-RU

Please see [4].

A.4.15 D2 Interface performance measurements

A.4.15.1 Transmitted D2-c messages per cell

- a) This counter provides the number of the transmitted D2-c messages per cell.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever D2-c message is transmitted per cell per signal type that is non UE-associated or UE-associated signaling.
- d) Each measurement is an integer value representing the number of transmitted D2-c messages.
- e) $OR.D2M.TxD2CMsgCell.Sigtype$ where
Sigtype is the signal type:
0: non UE-associated
1: UE-associated
- f) $NRCelIDU$
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.2 Transmitted D2-c messages per O-DU

- a) This counter provides the number of the transmitted D2-c messages per O-DU per signal type that is non UE-associated or UE-associated signaling.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever D2-c message is transmitted per O-DU per signal type that is non UE-associated or UE-associated signaling.
- d) Each measurement is an integer value representing the number of the transmitted D2-c messages.
- e) $OR.D2M.TxD2CMsgDU.Sigtype$ where
Sigtype is the signal type:
0: non UE-associated
1: UE-associated
- f) $gNBDFunction$
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.3 Received D2-c messages per cell

- a) This counter provides the number of the received D2-c messages per cell per signal type that is non UE-associated or UE-associated signaling.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever D2-c message is received per cell as per the signal type of the D2 C-plane message: non UE-associated or UE-associated as subcounter.*Sigtype*.
- d) Each measurement is an integer value representing the number of the received D2-c messages per signal type that is non UE-associated or UE-associated signaling.
- e) OR.D2M.RxD2CMsgCell.*Sigtype* where
Sigtype is the signal type:
0: non UE-associated
1: UE-associated
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.4 Received D2-c messages per O-DU

- a) This counter provides the number of the received D2-c messages per O-DU per signal type that is non UE-associated or UE-associated signaling.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever D2-c message is received per O-DU per signal type that is non UE-associated or UE-associated signaling.
- d) Each measurement is an integer value representing the number of the received D2-c messages per signal type that is non UE-associated or UE-associated signaling.
- e) OR.D2M.RxD2CMsgDU.*Sigtype* where
Sigtype is the signal type:
0: non UE-associated
1: UE-associated
- f) gNBFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.5 Inter O-DU SCell addition attempted

- a) This counter provides the number of SCell additions triggered by the PCell O-DU.

- b) CC
- c) Measurement counter is incremented by 1 by the PCell O-DU for every SCell addition for each UE listed in the UE ADDITION REQUEST message (refer to O-RAN.WG5.TS.D2AP [11], clause 5.3.2.1).
- d) Each measurement is an integer value representing the number of SCell attempted additions triggered by the PCell O-DU.
- e) OR.D2M.InterODUSCellAdd
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.6 Inter O-DU SCell addition failure

- a) This counter provides the number of SCell addition failures in a PCell O-DU.
- b) CC
- c) Measurement counter is incremented by 1 by the PCell O-DU for every SCell addition failure for each UE listed in the UE ADDITION RESPONSE message (refer to O-RAN.WG5.TS.D2AP [11], clause 5.3.2.1).
- d) Each measurement is an integer value representing the number of SCell addition failure in a PCell O-DU.
- e) OR.D2M.InterODUSCellAddFail
- f) gNBDFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.7 Transmitted D2 DL User Data transfer messages

- a) This counter provides the transmitted total number of DL DATA TRANSFER message containing DL User data for new transmission over the D2 interface. This counter will be incremented at the PCell O-DU.
- b) CC
- c) Measurement counter is incremented by 1 whenever transmitted DL DATA TRANSFER message contains DL User data for new transmission over the D2 interface (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.3).
- d) Each measurement is an integer value representing the transmitted total number of DL DATA TRANSFER message containing DL User data for new transmission over the D2 interface.
- e) OR.D2M.TxDLUserDataMsg
- f) NRCellDU
- g) Packet Switched
- h) 5GS

- i) Network Operator's Traffic Engineering Community

A.4.15.8 Received D2 DL User Data transfer messages

- a) This counter provides the received total number DL DATA TRANSFER message containing DL User data for new transmission over the D2 interface. This counter will be incremented at the SCell O-DU.
- b) CC
- c) Measurement counter is incremented by 1 whenever received DL DATA TRANSFER message contains DL User data for new transmission over the D2 interface (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.3).
- d) Each measurement is an integer value representing the received total number of DL DATA TRANSFER message containing DL User data for new transmission over the D2 interface.
- e) OR.D2M.RxDLUserDataMsg
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.9 Transferred DL User Data Volume

- a) This counter provides the DL User Data volume (Only new transmission) that are transmitted by PCell O-DU over D2 interface.
- b) CC
- c) Measurement counter is incremented by the volume of DL user data whenever DL user data is transmitted by PCell O-DU over D2 interface using 'DL DATA TRANSFER' message (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.3).
- d) Each measurement is an integer value representing the DL user data volume that is transmitted by PCell O-DU over D2 interface and measured in Mbits.
- e) OR.D2M.TxDLUserDataVolume
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.10 Received DL User Data Volume

- a) This counter provides the DL User Data volume (Only new transmission) that are received by SCell O-DU over D2 interface.
- b) CC
- c) Measurement counter is incremented by the volume of DL user data whenever DL user data is received by SCell O-DU over D2 interface using 'DL DATA TRANSFER' message (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.3).

- d) Each measurement is an integer value representing the DL user data volume that is received by SCell O-DU over D2 interface and measured in Mbits.
- e) OR.D2M.RxDLUserDataVolume
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.11 Number of requests for retransmission of DL User Data PDUs

- a) This counter provides the total count of DL SCHEDULING REQUEST messages that are transmitted by PCell O-DU over D2 interface for requesting the retransmission of DL data by SCell O-DU.
- b) CC
- c) Measurement counter is incremented by 1 by PCell O-DU for each retransmission requested in DL SCHEDULING REQUEST over D2 interface (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.1).
- d) Each measurement is an integer value representing the total number of DL SCHEDULING REQUEST message for requesting the retransmission of DL data.
- e) OR.D2M.RetransmissionRequests
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.12 Number of successful retransmissions of DL User Data PDUs

- a) This counter provides the total number of DL SCHEDULING REQUEST messages received by SCell O-DU which successfully triggered the retransmissions for the UE.
- b) CC
- c) Measurement counter is incremented by 1 by SCell O-DU for each successful retransmission that was requested in DL SCHEDULING REQUEST by PCell O-DU (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.1).
- d) Each measurement is an integer value representing total number of DL SCHEDULING REQUEST messages that successfully triggered retransmission of DL user data PDUs for the UE.
- e) OR.D2M.SuccessfulRetransmissions
- f) NRCellIDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.13 Retransmitted DL User Data Volume

- a) This counter provides the DL user data volume of successful retransmissions by the SCell O-DU.
- b) CC
- c) Measurement counter is incremented by the volume of DL user data whenever DL user data is successfully retransmitted to the UE by the SCell O-DU (refer to O-RAN.WG5.TS.D2AP [11], clause 6.3.1.1).
- d) Each measurement is an integer value representing the DL user data volume that is successfully retransmitted to the UE by the SCell O-DU and measured in Mbits.
- e) OR.D2M.RetransmittedDLUserDataVolume
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.14 DL messages discarded due to delayed reception at PCell

- a) This counter provides the total count of D2 messages that did not satisfy the criteria of T2 timer, resulting in their discard.
- b) CC
- c) Measurement counter is incremented by 1 whenever a D2 message that did not satisfy the criteria of T2 timer is discarded.
- d) Each measurement is an integer value representing total count of all the D2 messages that did not satisfy the criteria of T2 timer and hence discarded.
- e) OR.D2M.DiscardedDLMsgDelayedPCell
- f) NRCellDU
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

A.4.15.15 DL messages discarded due to delayed reception at SCell

- a) This counter provides the total count of D2 messages that did not satisfy the criteria of T1 or T3 timers, resulting in their discard.
- b) CC
- c) Measurement counter is incremented by 1 whenever a D2 message that did not satisfy the criteria of T1 or T3 timer is discarded.
- d) Each measurement is an integer value representing total count of all the D2 messages that did not satisfy the criteria of T1 or T3 timer and hence discarded.
- e) OR.D2M.DiscardedDLMsgDelayedSCell
- f) NRCellDU

- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

Annex B (informative): 3GPP TS 32.404 template usage for O-RAN O1 defined Performance Measurements

An example of the usage of the 3GPP TS 32.404 [1] Performance Measurement template to define the O1 performance measurements contained in this document is shown. The fields to be specified, according to the 3GPP performance measurement template, are labelled from a) to i) as follows:

Clause Header (indicating the name of the Performance Measurement)

- a) Description
- b) Collection Method
- c) Condition
- d) Measurement Result
- e) Measurement Type
- f) Measurement Object Class
- g) Switching Technology
- h) Generation
- i) Purpose

For more information about the meaning of each field refer to 3GPP TS 32.404 [1], clause 3.3

O1 Performance Measurement Example

Received UL RLC PDUs

- a) This counter provides the number of the received UL RLC PDUs. It is optional counter for O-DU.
- b) CC
- c) Measurement subcounter is incremented by 1 whenever the UL RLC PDU is received when the QCI or the 5QI of the UL RLC PDU is group of subcounter.Pmgroup.
- d) Each measurement is an integer value representing the number of the received UL RLC PDUs. It is optional counter for O-DU.
- e) OR.RLC.RxULRLcPdu.Pmgroup where Pmgroup is PmCountGroup number:

0: #0

1: #1

...

19: #19

- f) gNBDUFunction
- g) Packet Switched
- h) 5GS
- i) Network Operator's Traffic Engineering Community

Annex (informative): Change History

Date	Revision	Description
2024.07.29	01.00	First Release Inclusion of CRs: • Addition of O1 PMeas Scope • Addition of O1 PMeas Requirements • Change of short name from O1 PM to O1 PMeas • Addition of contents regarding further clarifications to clause 5.1 • Import of PMeas definitions from WG5 specs to Annex A • Application of new PMeas template in Annex A • Corrections and clarifications in Annex A • Addition of note regarding WG5 models to clause A.1 • Addition of new PMeas to clauses A.4.2.25 and A.4.2.26 • Addition of PMeas template usage to Annex B
2024.12.09	02.00	Summary of changes since the previous version: • Adoption of 3GPP filter mechanism • Addition of a new general requirement • Update to 3GPP Release 18 references • Alignment with 3GPP for measurement values • Addition of counting triggers • Corrections and clarifications for measurement definitions • Voiding A.2.9.31, A.4.2.23, A.4.2.24, A.4.3.3, A.4.11.31, and A.4.11.32 • Voiding NOTE 2) and 5) in clause 5.1
2025.03.27	03.00	Summary of changes since the previous version: • Correction of UE reported differential L1-RSRP of second best beam • Correction of Request for UL RLC PDUs retransmission • Modification of condition in UEs buffering performance measurements • Removal of Type A-Type B measurements differentiation • Addition of PSCell sub-counters • Correction of Multiplexed receptions of PUSCH and Multiplexed transmissions of PDSCH
2025.07.23	04.00	Summary of changes since the previous version: • Alignment to new TS Template • Clarification of measurement time period • Addition of paging-related measurements • Correction of bin ranges in A.4.11.35 • Correction of the bitwidth in the measurement result • Addition of simplified UE RLC throughput measurements for UL and DL • Alignment with 3GPP for PLMN use • Addition of performance measurements for PSCell change using SRB1
2025.12.08	05.00	Summary of changes since the previous version: • Addition of a new measurement for the number of SgNB addition requests • Correction of volume-related measurements • Alignment with 3GPP on PM family names • Editorial adjustments
2026.03.23	06.00	Summary of changes since the previous version: • Addition of new O-DU measurements for D2 interface • Addition of a new clause regarding Measurement Family • Removal of O-RAN additions for multiple measurements • Correction of typo in A.2.5.1 Total RRC Connected UE Contexts