

# **QCOM** User Guide

Rev. QCOM\_User\_Guide\_V1.1

Date: 2015-03-30



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

## **Quectel Wireless Solutions Co., Ltd.**

Office 501, Building 13, No.99, Tianzhou Road, Shanghai, China, 200233

Tel: +86 21 5108 6236 Mail: <u>info@quectel.com</u>

## Or our local office, for more information, please visit:

http://www.quectel.com/support/salesupport.aspx

## For technical support, to report documentation errors, please visit:

http://www.quectel.com/support/techsupport.aspx

Or Email: Support@quectel.com

#### **GENERAL NOTES**

QUECTEL OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

### **COPYRIGHT**

THIS INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTABLE, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THIS CONTENTS ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2015. All rights reserved.

QCOM\_User\_Guide Confidential / Released 1 / 11



# **About the Document**

# History

Revision	Date	Author	Description
1.0	2010-12-21	Walter LI	Initial
1.1	2015-03-30	Harvey HE	Updated QCOM version to 1.6

QCOM\_User\_Guide Confidential / Released 2 / 11



# Contents

About the Document				
Figure Index				
1 Introduction				
2	2 How to Use the Tool			
	2.1. De	escription of the Tool	6	
	2.1.1.	COM Port Configuration	7	
	2.1.2.	Open and Close COMP Port	8	
	2.1.3.	Send Data	8	
	214	Send Data Continuously	10	



# Figure Index

FIGURE 1: THE FUNCTION OF THE TOOL	. 6
FIGURE 2: UI OF COM PORT	. 7
FIGURE 3: UI OF BAUD RATE	. 7
FIGURE 4: OTHER PARAMETERS CONFIGURATION	. 7
FIGURE 5: OPEN PORT BUTTON	. 8
FIGURE 6: CLOSE PORT BUTTON	. 8
FIGURE 7: SEND DATA	. 8
FIGURE 8: SEND DATA CONTINUOUSLY	10



# 1 Introduction

This document describes how to use "QCOM" tool which is provided by Quectel. The tool can run without installation. And it supports the following OS:

- Windows 95
- Windows 98
- Windows 2000
- Windows ME
- Windows XP

This document is applicable to all GSM, UMTS and LTE modules.

QCOM\_User\_Guide Confidential / Released 5 / 11



# 2 How to Use the Tool

The tool is used to send and receive data with serial port.

# 2.1. Description of the Tool

The figure 1 describes the functions of the tool.




Figure 1: The Function of the Tool

- Red area displays the received data.
- Blue area displays status information.
- Purple area is used to send data or files.
- Green area is used to send data continuously.

QCOM\_User\_Guide Confidential / Released 6 / 11



# 2.1.1. COM Port Configuration

#### 1. Port

According to the connection between PC and terminal, select the right serial port as Figure 2.



Figure 2: UI of COM Port

#### 2. Baud rate

Choose an appropriate baud rate. Please refer to Figure 3.




Figure 3: UI of Baud Rate

### 3. Other parameters configuration of COM port

Choose appropriate Stop Bits, Parity, Byte Size, and Flow Control, shown as Figure 4.



**Figure 4: Other Parameters Configuration** 



# 2.1.2. Open and Close COMP Port

#### 1. Open COM Port

Click "Open Port" to open the selected COM port. Please refer to Figure 5.




Figure 5: Open Port Button

#### 2. Close COM Port

Click "Close Port" to close the selected COM port. Please refer to Figure 6.



Figure 6: Close Port Button

### 2.1.3. Send Data




Figure 7: Send Data



- A) Red area is used to input data which would be sent.
- B) Green area is used to choose file needed and send a whole file.
- C) Blue area is used to save received data as a file.
- D) DTR: Enable the DTR pin of COM port.
- E) RTS: Enable the RTS pin of COM port.
- F) View File: Show the data of the file which has been sent.
- G) Show Time: Show the time of each received data.
- H) HEX String: The input string is HEX string.
- 1) Show in HEX: The received data is shown in HEX.
- J) Send with Enter: Send data with "Enter".
- K) Clear Information: Clear all received data and status information.
- L) Send Command: Start to send the data which you input.
- M) Select File: Select the file which would be sent.
- N) Send File: Start to send the file that you have selected.
- O) Save Log: Select the file of which the Log data was saved.



# 2.1.4. Send Data Continuously




Figure 8: Send Data Continuously

- A) Red area is used to enable the data to be sent.
- B) Blue area is used to input data which would be sent.
- C) Green area is used to start data sending.
- D) Choose All Commands: Enable all available commands which would be sent.
- E) HEX: The input string is HEX string.
- F) Enter: Send data with "Enter".
- G) Delay: Delay time for each data.
- H) Delay Time: Default delay time.

QCOM\_User\_Guide Confidential / Released 10 / 11



- I) Run Times: The times of sending all selected data continuously.
- J) Run: Start to send all selected data continuously.
- K) Stop: Stop sending all selected data continuously.
- L) Save As Script: Save all data and configure as ini file.
- M) Load Test Script: Load data and configure from an ini file.

