



Tactile Switch(es)




These are tactile buttons.

ESP32-WROOM




ESP32 has built in regulators, no need of external ones.

Waveshare Display




Waveshare Display


PCM5102A




TP4056 Module



SPST Rocker Switch




MT3608 Booster




Set MT3608 to 5V.

3.3V MicroSD Module




MicroSD Module

3.5mm TRS Jack



AudioJack3

LiPo 3.7V Battery



LiPo 3.7V 1000mAh Battery

Sheet: /
File: breadplayerrr.kicad_sch

Title:

Size: A4
KiCad E.D.A. 10.0.3

Date:

Rev:
Id: 1/1