



CSE 332: Computer Architecture & Organization

Assignment#1 Spring 2025

Submitted by,

Name: Muhtadina Serniabat Tasin

Student ID: 223 2160 642

Section: 5

Serial: 24

Submitted to,

Dr. Mohammad Abdul Qayum [MAQm]

Submission Date – Sunday, 18 February, 2025

Due Date – Sunday, 18 February, 2025

Contents

1. BJT, MOSFET	8
Definition:.....	8
Elaboration:	8
Suitable Method:	8
2. Diode and LED (Light Emitting Diode)	8
Definition:.....	8
Elaboration:	8
Suitable Method:	8
Figures and Flowcharts:	9
3. pMOS, nMOS, CMOS	9
Definition:.....	9
Elaboration:	9
Figures and Flowcharts:	9
4. Universal Logic Gates	9
Definition:.....	9
Elaboration:	9
Figures and Flowcharts:	9
5. CMOS 3-input NAND Logic	10
Definition:.....	10
Figures and Flowcharts:	10
6. Process Node Technology	10
Definition:.....	10
Figures and Flowcharts:	10
7. Edge-Triggered D Flip-Flop	10
Definition:.....	10
Figures and Flowcharts:	10
8. Clock Edge	10
Definition:.....	10
Figures and Flowcharts:	10
9. Combinational Logic	11
Definition:.....	11
Elaboration:	11

Figures and Flowcharts:	11
10. Sequential Logic	11
Definition:.....	11
Elaboration:	11
Figures and Flowcharts:	11
11. Moore State Machine	11
Definition:.....	11
Figures and Flowcharts:	11
12. Register Transfer Level (RTL)	12
Definition:.....	12
Figures and Flowcharts:	12
13. Timing Diagram	12
Definition:.....	12
Figures and Flowcharts:	12
14. Karnaugh Map	12
Definition:.....	12
Figures and Flowcharts:	12
15. Multiplexer (MUX)	12
Definition:.....	12
Figures and Flowcharts:	12
16. Demultiplexer (DEMUX)	13
Definition:.....	13
Figures and Flowcharts:	13
17. Decoder	13
Definition:.....	13
Figures and Flowcharts:	13
18. Encoder	13
Definition:.....	13
Figures and Flowcharts:	13
19. Full Bit Adder	13
Definition:.....	13
Figures and Flowcharts:	13
20. Ripple Carry Adder	13

Definition:.....	13
Figures and Flowcharts:	14
21. Comparator	14
Definition:.....	14
Figures and Flowcharts:	14
22. Counter	14
Definition:.....	14
Figures and Flowcharts:	14
23. Shift Register	14
Definition:.....	14
Figures and Flowcharts:	14
24. Ring Oscillator	14
Definition:.....	14
Figures and Flowcharts:	14
25. Clock Divider	15
Definition:.....	15
Figures and Flowcharts:	15
26. Asynchronous Design	15
Definition:.....	15
Figures and Flowcharts:	15
27. Setup Time	15
Definition:.....	15
Figures and Flowcharts:	15
28. Hold Time	15
Definition:.....	15
Figures and Flowcharts:	15
29. Propagation Delay	15
Definition:.....	15
Figures and Flowcharts:	16
30. Fan-out	16
Definition:.....	16
Figures and Flowcharts:	16
31. Photolithography in chip fabrication	16

Definition:.....	16
Elaboration:	16
Figures and Flowcharts:	16
32. RTL Synthesis	16
Definition:.....	16
Elaboration:	17
Figures and Flowcharts:	17
33. HDL (Hardware Description Language)	17
Definition:.....	17
Elaboration:	17
Figures and Flowcharts:	17
34. EDA (Electronic Design Automation) Example	17
Definition:.....	17
Elaboration:	17
Figures and Flowcharts:	18
35. VHDL, Verilog	18
Definition:.....	18
Elaboration:	18
Figures and Flowcharts:	18
36. FPGA (Field-Programmable Gate Array)	18
Definition:.....	18
Elaboration:	18
Figures and Flowcharts:	19
37. CPLD (Complex Programmable Logic Device)	19
Definition:.....	19
Elaboration:	19
Figures and Flowcharts:	19
38. ASIC (Application-Specific Integrated Circuit)	19
Definition:.....	19
Elaboration:	19
Figures and Flowcharts:	19
39. Gate-Level Design	19
Definition:.....	19

Elaboration:	20
Figures and Flowcharts:	20
40. Testbench	20
Definition:.....	20
Elaboration:	20
Figures and Flowcharts:	20
41. DFT (Design for Testability)	20
Definition:.....	20
Elaboration:	20
Figures and Flowcharts:	20
42. Logic Synthesis	21
Definition:.....	21
Elaboration:	21
Figures and Flowcharts:	21
43. Power Optimization	21
Definition:.....	21
Elaboration:	21
Figures and Flowcharts:	21
44. Heterogeneous Multicore Processor	21
Definition:.....	21
Elaboration:	22
Figures and Flowcharts:	22
45. Cache	22
Definition:.....	22
Elaboration:	22
Figures and Flowcharts:	22
46. Main Memory	22
Definition:.....	22
Elaboration:	22
Figures and Flowcharts:	22
47. Five Steps from Sand to Chip	23
Figures and Flowcharts:	23
48. Five Stages from HDL to Chip Layout	23

Figures and Flowcharts:	23
49. RISC, CISC	23
Definition:.....	23
Elaboration:	23
Figures and Flowcharts:	24
50. Wafer, Die, Chip Packaging.....	24
Definition:.....	24
Elaboration:	24
Figures and Flowcharts:	24

1. BJT, MOSFET

Definition:

- BJT(Bipolar Junction Transistor) is a current-controlled device that consists of three layers: Emitter, Base, and Collector. It operates in active, cutoff, or saturation regions.
- MOSFET(Metal-Oxide-Semiconductor Field-Effect Transistor) is a voltage-controlled device that comes in two types: n-channel and p-channel. It is widely used in digital circuits due to its high efficiency and switching speed.

Elaboration:

- BJT works based on the movement of charge carriers (electrons and holes) between its three terminals.
- MOSFETs operate by controlling a channel between the source and drain using a gate voltage.

Suitable Method:

- BJTs are preferred in analog circuits, whereas MOSFETs are widely used in digital circuits due to their lower power consumption.

2. Diode and LED (Light Emitting Diode)

Definition:

- A Diode is a two-terminal semiconductor device that allows current to flow in only one direction.
- A Light Emitting Diode (LED) is a diode that emits light when forward-biased.

Elaboration:

- The diode functions based on the PN junction principle and is used in rectifiers, clamping circuits, etc.
- LEDs are used in indicators, displays, and lighting due to their efficiency.

Suitable Method:

- Rectifiers use diodes to convert AC to DC.

Figures and Flowcharts:

- **Diode and LED Structure**

3. pMOS, nMOS, CMOS

Definition:

- pMOS (Positive-channel MOSFET): Uses holes as charge carriers.
- nMOS (Negative-channel MOSFET): Uses electrons as charge carriers.
- CMOS (Complementary MOS): Uses both pMOS and nMOS transistors to create energy-efficient logic circuits.

Elaboration:

- CMOS technology is widely used in modern VLSI circuits due to low power dissipation.

Figures and Flowcharts:

- **CMOS Inverter Diagram**

4. Universal Logic Gates

Definition:

- Universal logic gates are NAND and NOR gates that can be used to implement any Boolean function.

Elaboration:

- NAND and NOR gates are fundamental for digital circuit design as they allow for complete logical operations.

Figures and Flowcharts:

- **Universal Gate Diagrams**

5. CMOS 3-input NAND Logic

Definition:

- A CMOS NAND gate with 3 inputs uses both pMOS and nMOS transistors to implement logic functions.

Figures and Flowcharts:

- **CMOS NAND Gate Implementation**

6. Process Node Technology

Definition:

- The process node represents the manufacturing technology used in semiconductor fabrication, denoted in nanometers (e.g., 7nm, 5nm).

Figures and Flowcharts:

- **Semiconductor Process Node Evolution**

7. Edge-Triggered D Flip-Flop

Definition:

- A D Flip-Flop is a sequential circuit that captures the input value at a specific clock edge (rising or falling).

Figures and Flowcharts:

- **D Flip-Flop Timing Diagram**

8. Clock Edge

Definition:

- The transition of a clock signal (rising or falling) that triggers sequential logic operations.

Figures and Flowcharts:

- **Clock Edge Timing**

9. Combinational Logic

Definition:

- Combinational logic is a type of digital logic where the output is determined solely by the current inputs without any memory elements.

Elaboration:

- It is used in arithmetic operations, multiplexers, decoders, and other logic circuits.

Figures and Flowcharts:

- **Combinational Logic Diagram**

10. Sequential Logic

Definition:

- Sequential logic is a type of digital logic where the output depends on both current inputs and past inputs (memory).

Elaboration:

- It includes flip-flops, counters, and shift registers, used in clocked circuits.

Figures and Flowcharts:

- **Sequential Logic Diagram**

11. Moore State Machine

Definition:

- A Moore State Machine is a finite-state machine where the outputs depend only on the current state.

Figures and Flowcharts:

- **Moore FSM Diagram**

12. Register Transfer Level (RTL)

Definition:

- RTL is a design abstraction that describes how data is transferred between registers using combinational logic.

Figures and Flowcharts:

- **RTL Design Flow**

13. Timing Diagram

Definition:

- A graphical representation of signals in a digital circuit over time.

Figures and Flowcharts:

- **Timing Diagram Example**

14. Karnaugh Map

Definition:

- A visual method for simplifying Boolean expressions.

Figures and Flowcharts:

- **K-Map Examples**

15. Multiplexer (MUX)

Definition:

- A circuit that selects one of many inputs and forwards it to the output based on select lines.

Figures and Flowcharts:

- **MUX Circuit Diagram**

16. Demultiplexer (DEMUX)

Definition:

- A circuit that distributes a single input to multiple outputs based on select lines.

Figures and Flowcharts:

- **DEMUX Circuit Diagram**

17. Decoder

Definition:

- A circuit that converts an n -bit input into a unique 2^n -bit output.

Figures and Flowcharts:

- **Decoder Circuit**

18. Encoder

Definition:

- A circuit that converts 2^n inputs into an n -bit output.

Figures and Flowcharts:

- **Encoder Circuit**

19. Full Bit Adder

Definition:

- A digital circuit that adds three input bits and outputs a sum and carry.

Figures and Flowcharts:

- **Full Adder Circuit**

20. Ripple Carry Adder

Definition:

- A type of binary adder that chains multiple full adders in sequence.

Figures and Flowcharts:

- **Ripple Carry Adder Diagram**

21. Comparator

Definition:

- A digital circuit that compares two binary numbers and outputs the comparison result (equal, greater, or lesser).

Figures and Flowcharts:

- **Comparator Circuit**

22. Counter

Definition:

- A sequential circuit that counts pulses and stores the count value.

Figures and Flowcharts:

- **Counter Circuit**

23. Shift Register

Definition:

- A sequential circuit that shifts binary data in a serial or parallel manner.

Figures and Flowcharts:

- **Shift Register Diagram**

24. Ring Oscillator

Definition:

- A simple oscillator circuit made of an odd number of inverters.

Figures and Flowcharts:

- **Ring Oscillator Diagram**

25. Clock Divider

Definition:

- A circuit that reduces the frequency of a clock signal by an integer factor.

Figures and Flowcharts:

- **Clock Divider Circuit**

26. Asynchronous Design

Definition:

- A circuit design methodology that does not rely on a global clock signal.

Figures and Flowcharts:

- **Asynchronous Logic**

27. Setup Time

Definition:

- The minimum time before a clock edge when the input must remain stable.

Figures and Flowcharts:

- **Setup Time Diagram**

28. Hold Time

Definition:

- The minimum time after a clock edge when the input must remain stable.

Figures and Flowcharts:

- **Hold Time Diagram**

29. Propagation Delay

Definition:

- The time taken for a signal to travel from input to output.

Figures and Flowcharts:

- **Propagation Delay Analysis**

30. Fan-out

Definition:

- The maximum number of logic inputs a gate can drive without degradation.

Figures and Flowcharts:

- **Fan-out Concept**

31. Photolithography in chip fabrication

Definition:

- **Photolithography** is a process used in semiconductor manufacturing to transfer intricate circuit patterns onto silicon wafers using light.

Elaboration:

- A **photoresist** is applied to the wafer and exposed to ultraviolet (UV) light through a mask containing the circuit design.
- The exposed regions of the photoresist are either hardened (**positive resist**) or dissolved (**negative resist**), allowing selective etching of the underlying material.
- Photolithography enables the fabrication of nanoscale transistor structures and is crucial for advanced process nodes like **5nm and below**.

Figures and Flowcharts:

- [Photolithography Process](#)
- [Semiconductor Lithography Overview](#)

32. RTL Synthesis

Definition:

- **RTL (Register Transfer Level) Synthesis** is the process of converting high-level hardware descriptions (written in HDL) into an optimized gate-level representation that can be implemented in hardware.

Elaboration:

- RTL synthesis takes an **HDL design** (e.g., Verilog or VHDL) and translates it into logic gates and flip-flops using **Boolean optimization techniques**.
- The synthesized netlist is then mapped to a specific **FPGA or ASIC** technology for fabrication.
- Key steps include **logic synthesis, technology mapping, and gate-level optimization** to ensure area, power, and speed efficiency.

Figures and Flowcharts:

- [RTL Synthesis Flow](#)
- [Synthesis Process Overview](#)

33. HDL (Hardware Description Language)

Definition:

- **HDL (Hardware Description Language)** is a specialized programming language used to describe and model the behavior and structure of digital circuits.

Elaboration:

- Common HDLs include **VHDL and Verilog**, which allow designers to specify circuit behavior at a high level before synthesis into logic gates.
- HDLs support **concurrent execution** and are used for both simulation and hardware implementation in **ASICs and FPGAs**.
- They enable hardware prototyping, verification, and **automated logic synthesis**.

Figures and Flowcharts:

- [HDL Workflow](#)
- [Verilog vs VHDL Comparison](#)

34. EDA (Electronic Design Automation) Example

Definition:

- **Electronic Design Automation (EDA)** refers to software tools used to design, simulate, and verify integrated circuits (ICs) and electronic systems.

Elaboration:

- EDA tools assist in **circuit design, logic synthesis, timing analysis, and physical layout**.

- Examples include:
 - **Synopsys Design Compiler** – for logic synthesis.
 - **Cadence Virtuoso** – for IC layout and simulation.
 - **Xilinx Vivado** – for FPGA design and implementation.
- These tools optimize power, area, and timing constraints for **ASICs and FPGAs**.

Figures and Flowcharts:

- [EDA Tool Workflow](#)
- [VLSI Design Flow Using EDA](#)

Let me know if you need further elaboration!

35. VHDL, Verilog

Definition:

- VHDL (VHSIC Hardware Description Language) and Verilog are two popular Hardware Description Languages (HDLs) used to model digital circuits.
- VHDL is strongly typed and more verbose, whereas Verilog is more concise and similar to C.

Elaboration:

- VHDL is widely used in defense and aerospace industries due to its strong typing.
- Verilog is preferred in commercial ASIC and FPGA design due to its simplicity.

Figures and Flowcharts:

- **VHDL vs. Verilog Comparison**

36. FPGA (Field-Programmable Gate Array)

Definition:

- An FPGA is a reconfigurable digital circuit consisting of an array of programmable logic blocks connected via configurable interconnects.

Elaboration:

- Unlike ASICs, FPGAs can be reprogrammed after manufacturing, making them ideal for prototyping and low-volume applications.

Figures and Flowcharts:

- **FPGA Architecture**

37. CPLD (Complex Programmable Logic Device)

Definition:

- CPLDs are programmable logic devices that contain multiple macrocells and offer non-volatile storage for configuration.

Elaboration:

- They provide faster and more predictable timing than FPGAs but are less flexible in terms of logic resources.

Figures and Flowcharts:

- **CPLD vs. FPGA**

38. ASIC (Application-Specific Integrated Circuit)

Definition:

- ASIC is a custom-designed integrated circuit optimized for a specific application, offering high performance and low power consumption.

Elaboration:

- ASICs are commonly used in mobile processors, GPUs, and networking hardware.
- Unlike FPGAs, ASICs cannot be reprogrammed once manufactured.

Figures and Flowcharts:

- **ASIC Design Process**

39. Gate-Level Design

Definition:

- A gate-level design represents digital circuits in terms of basic logic gates and their interconnections.

Elaboration:

- It is the lowest level of abstraction before hardware implementation, generated after RTL synthesis.

Figures and Flowcharts:

- **Gate-Level Schematic**

40. Testbench

Definition:

- A testbench is a simulation environment used to verify the correctness of an HDL-based circuit by applying test vectors.

Elaboration:

- Testbenches include stimulus generation, response checking, and timing analysis.

Figures and Flowcharts:

- **Testbench Simulation**

41. DFT (Design for Testability)

Definition:

- **Design for Testability (DFT)** refers to design techniques that improve the ability to test an integrated circuit (IC) for defects after fabrication.

Elaboration:

- DFT incorporates structures like **scan chains**, **Built-In Self-Test (BIST)**, and **boundary scan (JTAG)** to enhance fault detection.
- It ensures that testing procedures, such as **Automatic Test Pattern Generation (ATPG)**, can efficiently diagnose faults in digital circuits.

Figures and Flowcharts:

- [DFT Implementation Flow](#)
- [Scan Chain Example](#)

42. Logic Synthesis

Definition:

- **Logic Synthesis** is the process of converting an abstract hardware description (HDL) into an optimized gate-level netlist.

Elaboration:

- It involves **Boolean optimization, technology mapping, and gate-level transformation** to minimize area, power, and timing constraints.
- The synthesized netlist is used for **placement and routing** in the physical design phase.

Figures and Flowcharts:

- [Logic Synthesis Flow](#)
- [Optimization Example](#)

43. Power Optimization

Definition:

- **Power optimization** refers to design techniques used to reduce power consumption in digital circuits.

Elaboration:

- Methods include **clock gating, power gating, dynamic voltage and frequency scaling (DVFS), and multi-Vt optimization**.
- Essential in **battery-powered and high-performance computing systems** to enhance energy efficiency.

Figures and Flowcharts:

- [Power Optimization Techniques](#)
- [Clock Gating Implementation](#)

44. Heterogeneous Multicore Processor

Definition:

- A **Heterogeneous Multicore Processor** consists of multiple cores with different architectures optimized for various tasks.

Elaboration:

- Examples include **ARM big.LITTLE** architecture, where high-performance cores handle intensive tasks, and power-efficient cores handle background processes.
- Used in **smartphones, embedded systems, and AI accelerators**.

Figures and Flowcharts:

- [Heterogeneous Multicore Architecture](#)
- [Big.LITTLE Concept](#)

45. Cache

Definition:

- **Cache** is a small, high-speed memory located between the processor and main memory to store frequently accessed data.

Elaboration:

- Cache is categorized into **L1, L2, and L3** levels, where L1 is the fastest and smallest.
- Uses techniques like **associativity, replacement policies, and prefetching** to enhance CPU performance.

Figures and Flowcharts:

- [Cache Memory Hierarchy](#)
- [Cache Replacement Policies](#)

46. Main Memory

Definition:

- **Main memory (RAM)** is the primary storage medium that holds data and programs for immediate access by the CPU.

Elaboration:

- Types include **SRAM (Static RAM)** and **DRAM (Dynamic RAM)**.
- Main memory acts as a bridge between **slow storage (HDD/SSD)** and **fast CPU cache**.

Figures and Flowcharts:

- [Memory Hierarchy](#)

- [RAM Architecture](#)

47. Five Steps from Sand to Chip

1. **Purification** – Silicon is extracted from sand and purified.
2. **Crystal Growth** – A pure silicon ingot is grown using the Czochralski process.
3. **Wafer Formation** – The ingot is sliced into thin wafers.
4. **Photolithography & Etching** – Circuits are patterned onto the wafer.
5. **Doping & Metallization** – Transistors and interconnects are formed.

Figures and Flowcharts:

- [Silicon Chip Manufacturing](#)

48. Five Stages from HDL to Chip Layout

1. **RTL Design** – Write hardware description in **Verilog/VHDL**.
2. **Logic Synthesis** – Convert RTL to gate-level representation.
3. **Placement & Routing** – Physically arrange the gates on a chip.
4. **Timing Analysis & Optimization** – Ensure timing constraints are met.
5. **Fabrication & Packaging** – Manufacture and package the chip.

Figures and Flowcharts:

- [VLSI Design Flow](#)

49. RISC, CISC

Definition:

- **RISC (Reduced Instruction Set Computing)** uses simple instructions executed in a single cycle.
- **CISC (Complex Instruction Set Computing)** uses complex instructions that may take multiple cycles.

Elaboration:

- RISC is **used in ARM processors** for power efficiency.
- CISC is **used in x86 processors** for compatibility and performance.

Figures and Flowcharts:

- [RISC vs. CISC Comparison](#)

50. Wafer, Die, Chip Packaging

Definition:

- **Wafer** – A thin slice of silicon that contains multiple dies.
- **Die** – A single functional unit cut from the wafer.
- **Chip Packaging** – The final step where the die is enclosed in a protective casing.

Elaboration:

- Wafers undergo **photolithography, doping, and etching** before being diced into individual dies.
- Each die is tested, packaged, and integrated into **PCBs or embedded systems**.

Figures and Flowcharts:

- [Wafer-to-Chip Process](#)
- [Chip Packaging Techniques](#)