FOREWORD

This wiring diagram has been prepared to provide information on the electrical system of the 1990 LEXUS LS400.

Applicable models: UCF 10 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
 1990 LEXUS LS400 Repair Manual Volume 1 Volume 2 	RM144U1 RM144U2
 1990 LEXUS LS400 New Car Features 	NCF054U

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE -

This vehicle has an SRS AIRBAG (referred to as the airbag in the remainder of this manual).

When handling airbag components (removal, installation or inspection, ect.), always follow the direction given in the repair manuals listed above to prevent the occurence of accidents and airbag malfunction.