CELLULAR MOBILE TELEPHONE

SERVICE HINTS

T17 (A) TELEPHONE TRANSCEIVER AND SPEAKER RELAY

(A) 9-GROUND: ALWAYS APPROX. 12 VOLTS

(A) 10-GROUND : APPROX. 12 VOLTS WITH IGNITION SW AT ACC OR ON POSITION

(A) 11-GROUND : ALWAYS CONTINUITY

: PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C15	26	R 4 A	27	T18 B	29
M 2	29	R16	29	·	
R 2 B	27	T17 A	29		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1G	18	COWL WIRE AND J/B NO.1 (LEFT SIDE OF STEERING COLUMN TUBE)
2B	20	COWL WIRE AND J/B NO.2 (ENGINE COMPARTMENT LEFT)
4D	23	COWL WIRE AND J/B NO.4 (BEHIND THE COMBINATION METER)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)			
EA3	32	COWL WIRE AND ENGINE ROOM MAIN WIRE (INSIDE OF J/B NO.2)			
II2	34	INSTRUMENT PANEL WIRE AND FLOOR NO.1 WIRE (UNDER THE INSTRUMENT PANEL BRACE RH)			
BQ2	38	COWL WIRE AND FLOOR NO.2 WIRE (LEFT KICK PANEL)			
BQ3	36	OUVL WIRE AND FLOOR NO.2 WIRE (LEFT RICK PAINEL)			
BU1	38	REAR DOOR LH WIRE AND FLOOR NO.2 WIRE (LEFT CENTER PILLAR)			
BW2	38	FLOOR NO.1 WIRE AND FLOOR NO.2 WIRE (UNDER THE LEFT SIDE OF REAR SEAT CUSHION)			
BW3	30	TEOOR NO. I WINE AND I LOOK NO. 2 WINE (ONDER THE LET I SIDE OF REAR SEAT COSTILON)			

: GROUND POINTS

•		
CODE	SEE PAGE	GROUND POINTS LOCATION
EB	32	FRONT SIDE OF LEFT FENDER

: SPLICE POINTS

CODE	E SEE PAGE WIRE HARNESS WITH SPLICE POINTS		CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 91	36	COWL WIRE	B 47	38	FLOOR NO.2 WIRE

















