gPROMS System Programmer Guide

Process Systems Enterprise Ltd.

6th Floor East 26-28 Hammersmith Grove London W6 7HA United Kingdom

Tel: +44 20 8563 0888 Fax: +44 20 8563 0999

Release 2.3.4 — October 2004

© 1997–2008 Process Systems Enterprise Limited.

ModelEnterprise and gPROMS are trademarks of Process Systems Enterprise Limited. All other registered and pending trademarks mentioned in this material are considered the sole property of their respective owners. All rights reserved.

No part of this material may be copied, distributed, published, retransmitted or modified in any way without the prior written consent of Process Systems Enterprise Limited. This document is the property of Process Systems Enterprise Ltd., and must not be reproduced in any manner without prior written permission.

Disclaimer

gPROMS provides an environment for modelling the behaviour of complex systems. While gPROMS provides valuable insights into the behaviour of the system being modelled, this is not a substitute for understanding the real system and any dangers that it may present. Except as otherwise provided, all warranties, representations, terms and conditions express and implied (including implied warranties of satisfactory quality and fitness for a particular purpose) are expressly excluded to the fullest extent permitted by law. gPROMS provides a framework for applications which may be used for supervising a process control system and initiating operations automatically. gPROMS is not intended for environments which require fail-safe characteristics from the supervisor system. Process Systems Enterprise Limited ("PSE") specifically disclaims any express or implied warranty of fitness for environments requiring a fail-safe supervisor. Nothing in this disclaimer shall limit PSE's liability for death or personal injury caused by its negligence.

The license management portion of this product is based on: SentinelLM ©1996–1997 Rainbow Technologies, Inc. All rights reserved.

FLEXIm ©2001 GLOBEtrotter Software, Inc. A Macrovision Company. All rights reserved.

SentinelLM is a trademark of Rainbow Technologies, Inc.

FLEXIm is a trademark of GLOBEtrotter Software, Inc.

Code from LAPACK and BLAS is used in gPROMS.

We would like to thank the authors

E. Anderson, Z. Bai, C. Bischof, S. Blackford, J. Demmel,
J. Dongarra, J. Du Croz, A. Greenbaum, S. Hammarling,
A. McKenney, and D. Sorensen
for making the code publicly available.

The gPROMS Model Builder interface uses the following packages: ANTLR (http://www.antlr.org).

Xerces and Xalan (http://xml.apache.org/) from the Apache XML Project.

Components from NetBeans (http://www.netbeans.org).

To support the multiple shooting implementation for dynamic optimisation, gPROMS makes use of HQP, a solver for non-linearly constrained, large-scale optimization problems.

HQP is free software. The programs and libraries in HQP are distributed under the GNU Lesser General Public License (LGPL) as published by the Free Software Foundation. The source code for HQP is available at http://www.sourceforge.net/projects/hqp.

We would like to thank HQP's author, Ruediger Franke of ABB, for his help in developing the interface from gPROMS to HQP. To support the Distributed Computing facility, gPROMS makes use of omniORB2, an Object Request Broker (ORB) which implements specification 2.3 of the Common Object Request Broker Architecture (CORBA).

omniORB2 is copyright AT&T Laboratories, Cambridge. It is free software. The programs in omniORB2 are distributed under the GNU General Public Licence as published by the Free Software Foundation. The libraries in omniORB2 are distributed under the GNU Library General Public Licence.

Contents

1	Intr	roducti	ion	12
	1.1	Overv	iew	12
	1.2	Prerec	quisites	13
2	Dev	elopin	g New Foreign Objects	14
	2.1	Introd	luction	15
	2.2	The g	PROMS Foreign Object Interface	15
		2.2.1	The Foreign Object initialisation procedure	16
		2.2.2	The Foreign Object verification procedures	17
		2.2.3	The Foreign Object calculation procedures	20
		2.2.4	The Foreign Object termination procedure	22
	2.3	Imple	mentation of Foreign Objects	29
		2.3.1	Writing Foreign Objects	29
		2.3.2	Writing Foreign Objects in FORTRAN and C	30
		2.3.3	Writing Foreign Objects in C++	31
		2.3.4	Compiling Foreign Objects	33
		2.3.5	Installing Foreign Objects	33
		2.3.6	Documenting Foreign Object classes	34
	2.4	Imple	menting Foreign Objects using COM	34
		2.4.1	The Foreign Object COM interfaces	34
		2.4.2	Registering a Foreign Object COM server	35
		2.4.3	Using COM-based Foreign Objects within gPROMS	36

3	Inte	erfacin	g Physical Property Packages to gPROMS	42
	3.1	Const	ructing Foreign Objects for physical property packages	43
	3.2	Direct	Foreign Object services	46
		3.2.1	The gF0I Foreign Object initialisation service	47
		3.2.2	The gFOCM Foreign Object verification service	48
		3.2.3	The gFOCMI Foreign Object verification service	49
		3.2.4	The gFOT Foreign Object termination service	50
	3.3	The p	hysical property calculation procedures	50
	3.4	Prepa	ring the Physical Property Interface Foreign Object	51
	3.5	An ex	ample	52
4	Dev	elopin/	g New Foreign Processes	58
	4.1	Introd	luction	59
	4.2	The F	PI communication protocol	60
		4.2.1	The gFPI procedure	62
		4.2.2	The gFPPAUSE procedure	63
		4.2.3	The gFPGET procedure	64
		4.2.4	The gFPSEND procedure	66
		4.2.5	The gFPSENDM procedure	68
		4.2.6	The gFPLINEARISE procedure	70
		4.2.7	The gFPT procedure	73
	4.3	FPI in	mplementation for real-time applications	74
	4.4	Imple	mentation of Foreign Processes	76
		4.4.1	Writing Foreign Processes in FORTRAN and C	76
		4.4.2	Writing Foreign Processes in C++	76
		4.4.3	Compiling Foreign Processes	78
		4.4.4	Installing Foreign Processes	79
5	The	e gPR0	OMS Output Channel Interface	80
	5.1	Introd	luction	81

	5.2	Using Output Channels in gPROMS		
	5.3	The gl	PROMS Output Channel Interface	84
		5.3.1	The initialisation procedure	85
		5.3.2	The register distribution domain procedure	86
		5.3.3	The register variable procedure	89
		5.3.4	The finish initialisation procedure	90
		5.3.5	The time reporting procedure	91
		5.3.6	The variable values reporting procedure	92
		5.3.7	The reset results procedure	93
		5.3.8	The termination procedure	94
	5.4	Imple	mentation of Output Channels	95
		5.4.1	Writing Output Channels in FORTRAN and C \ldots	95
		5.4.2	Compiling Output Channels	95
		5.4.3	Installing Output Channels	96
6	Tho	, aDD(OMS Equation Set Object	97
U		grice	MD Equation Set Object	31
	6.1	Introd	uction	98
	6.1		uction	98 99
	6.1	Descri	ption of discontinuous equations in ESOs	99
		Descri	ption of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions	99 99
		Descri 6.2.1 6.2.2	ption of discontinuous equations in ESOs	99 99 100
		Descri 6.2.1 6.2.2 6.2.3	ption of discontinuous equations in ESOs	99 99 100 100
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4	ption of discontinuous equations in ESOs	99 99 100 100 104
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfa	ption of discontinuous equations in ESOs	99 99 100 100 104 106
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfa	ption of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions Mathematical descriptions of physical discontinuities State-Transition Networks The representation of logical conditions in STNs ace definition gESO	99 99 100 100 104 106 106
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfat IGPAL	origins of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions Mathematical descriptions of physical discontinuities State-Transition Networks The representation of logical conditions in STNs ace definition gESO Methods relating to the ESO structure	99 99 100 100 104 106 106
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfat IGPAL 6.4.1	Origins of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions Mathematical descriptions of physical discontinuities State-Transition Networks The representation of logical conditions in STNs ace definition gESO Methods relating to the ESO structure Methods relating to the ESO variables	99 99 100 100 104 106 106 108
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfat IGPAL 6.4.1 6.4.2 6.4.3	Origins of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions Mathematical descriptions of physical discontinuities State-Transition Networks The representation of logical conditions in STNs ace definition gESO Methods relating to the ESO structure Methods relating to the ESO variables Methods for storage of sensitivities	99 99 100 100 104 106 106 108 111
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfat IGPAL 6.4.1 6.4.2 6.4.3 6.4.4	Origins of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions Mathematical descriptions of physical discontinuities State-Transition Networks The representation of logical conditions in STNs ace definition gESO Methods relating to the ESO structure Methods for storage of sensitivities Methods relating to the ESO equations	99 99 100 100 104 106 108 111 119
	6.2	Descri 6.2.1 6.2.2 6.2.3 6.2.4 Interfat IGPAL 6.4.1 6.4.2 6.4.3	Origins of discontinuous equations in ESOs Origins of discontinuous equations in physical descriptions Mathematical descriptions of physical discontinuities State-Transition Networks The representation of logical conditions in STNs ace definition gESO Methods relating to the ESO structure Methods relating to the ESO variables Methods for storage of sensitivities	99 99 100 100 104 106 106 108 111

		6.4.7	General ESO methods	130
	6.5	IGPDi	ffAlgESO	130
		6.5.1	Methods relating to the ESO structure	131
		6.5.2	Methods relating to the ESO variables	133
		6.5.3	Methods relating to the ESO derivatives	134
	6.6	ICape	NumericSTN	139
7	The	gPRO	OMS Dynamic Optimisation Object	144
	7.1	The d	ynamic optimisation problem in gPROMS	146
	7.2	The gl	PROMS Dynamic Optimisation Object	148
	7.3	Functi	onal specification of the gDOO	149
		7.3.1	The Equation Set Object	149
		7.3.2	The initial conditions	150
		7.3.3	The time horizon and its partitioning	150
		7.3.4	Partitioning of the ESO variables	151
		7.3.5	The objective function	152
		7.3.6	Interior point constraints	152
		7.3.7	End-point constraints	152
		7.3.8	The gDOO status	153
	7.4	Auxilia	ary interfaces	154
		7.4.1	The IBoundedQuantity interface	154
		7.4.2	The IBoundedQuantityArray interface	159
		7.4.3	The IIndexedBoundedQuantity interface	161
	7.5	The I	gDOO interface	163
		7.5.1	Methods relating to the ESO	163
		7.5.2	Methods relating to the initial conditions	165
		7.5.3	Methods relating to the time horizon and its partitioning \dots	166
		7.5.4	Methods relating to the control variables	168
		7.5.5	Methods relating to the time-invariant parameters	173
		7.5.6	Methods relating to the fixed variables	175

		7.5.7	Methods relating to the objective function	175
		7.5.8	Methods relating to the interior point constraints	177
		7.5.9	Methods relating to the end-point constraints	179
		7.5.10	Methods relating to the gDOO status $\ \ldots \ \ldots \ \ldots \ \ldots$	181
		7.5.11	Methods relating to the optimisation type	182
		7.5.12	Methods relating to the availability of lagrange multipliers	183
	7.6	CORE	A Interface Definitions	184
		7.6.1	gDOO.idl	184
		7.6.2	$Bounded Quantity. idl \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	187
		7.6.3	ControlVariable.idl	190
		7.6.4	$Interior Point Constraint. idl \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$	191
		7.6.5	$Endpoint Constraint.idl\dots$	193
		7.6.6	general.idl	194
8				196
	The	~DD(II/IS Numerical Solvers Intentages	
0		_	OMS Numerical Solvers Interfaces	
0	The 8.1	Introd	uction	198
0		Introd 8.1.1	uction	198 198
0	8.1	Introd 8.1.1 8.1.2	Systems System Factories System Factories	198 198 198
•		Introd 8.1.1 8.1.2	uction	198 198
•	8.1	Introd 8.1.1 8.1.2	Systems System Factories System Factories	198 198 198
•	8.1	Introd 8.1.1 8.1.2 Interfa 8.2.1	Systems System Factories System Factorie	198 198 198 199
•	8.1	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types	Systems System Factories Ce overview Configurability of numerical solvers	198 198 198 199 200
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics	198 198 198 199 200 201
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics NumericSolverComponent	198 198 198 199 200 201 201
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel ICapel	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics NumericSolverComponent NumericAttribute	198 198 198 199 200 201 201 204
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel ICapel 8.5.1	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics NumericSolverComponent NumericAttribute ICapeNumericStringAttribute	198 198 199 200 201 201 204 206
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel ICapel 8.5.1 8.5.2	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics NumericSolverComponent NumericAttribute ICapeNumericStringAttribute ICapeNumericIntegerAttribute	198 198 199 200 201 201 204 206 206
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel 8.5.1 8.5.2 8.5.3	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics NumericSolverComponent NumericAttribute ICapeNumericIntegerAttribute ICapeNumericIntegerAttribute ICapeNumericRealAttribute	198 198 199 200 201 201 204 206 206 207
0	8.1 8.2 8.3 8.4	Introd 8.1.1 8.1.2 Interfa 8.2.1 Types ICapel 8.5.1 8.5.2 8.5.3 8.5.4	Systems System Factories Ce overview Configurability of numerical solvers and values of algorithmic parameters and statistics NumericSolverComponent NumericAttribute ICapeNumericStringAttribute ICapeNumericIntegerAttribute ICapeNumericRealAttribute ICapeNumericBooleanAttribute	198 198 199 200 201 201 204 206 206 207

	8.6.1	ICapeNumericStringParameter	209
	8.6.2	$ICape Numeric Integer Parameter \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	210
	8.6.3	ICapeNumericRealParameter	211
	8.6.4	ICapeNumericBooleanParameter	213
	8.6.5	$ICape Numeric Enumerated Parameter \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	213
	8.6.6	$ICape Numeric Interface Parameter \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	214
8.7	Linear-	-Algebra components	214
	8.7.1	ICapeNumericLAComponent	215
	8.7.2	ICapeNumericLASystemFactory	215
	8.7.3	ICapeNumericLASystem	216
8.8	Non-lin	near algebra components	219
	8.8.1	ICapeNumericNLAComponent	219
	8.8.2	ICapeNumericNLASystemFactory	222
	8.8.3	ICapeNumericNLASystem	223
8.9	Differe	ntial algebraic equation components	224
	8.9.1	ICapeNumericDAEComponent	224
	8.9.2	ICapeNumericDAESystemFactory	227
	8.9.3	ICapeNumericDAESystem	228
8.10	CORB	A interface definitions	232
	8.10.1	$ICape Utility Component. idl \\ \ldots \\ \ldots \\ \ldots$	233
	8.10.2	$ICape Numeric Solver Component. idl \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	234
	8.10.3	ICapeNumericAttribute.idl	235
	8.10.4	$ICape Numeric Parameter. idl \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	237
	8.10.5	ICapeNumericStatistic.idl	239
	8.10.6	$ICape Numeric LAC omponent. idl \\ \ldots \\ \ldots \\ \ldots$	241
	8.10.7	$ICape Numeric LA System. idl \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $	242
	8.10.8	$ICape Numeric NLA Component. idl \\ \ldots \\ \ldots \\ \ldots$	243
	8.10.9	ICapeNumericNLASystem.idl	244
	8.10.10	ICapeNumericDAEComponent.idl	245

		8.10.11	ICapeNumericDAESystem.idl	246
9	The	gPRO	MS Dynamic Optimisation Solver Interfaces	247
	9.1	Genera	al principles	248
		9.1.1	Solver managers and systems	248
		9.1.2	Numeric-solver parameters	248
	9.2	The Ig	DONumericSolverComponent Interface	248
	9.3	The Ig	gDOSolverManager interface	249
	9.4	The Ig	DOSystem interface	249
	9.5	CORB	A interface definitions	250
		9.5.1	gNumericSolver.idl	250
\mathbf{A}	Cre	ating S	Shared Object Libraries Under UNIX	252
	A.1	Shared	object libraries for DIGITAL UNIX v4.0 and later	254
		A.1.1	Foreign Object code written in FORTRAN 77	254
		A.1.2	Foreign Object code written in C	254
		A.1.3	Foreign Object code written in C++	254
	A.2	Shared	object libraries for IBM AIX v4.2 and later	255
		A.2.1	Foreign Object code written in FORTRAN 77	255
		A.2.2	Foreign Object code written in C	255
		A.2.3	Foreign Object code written in C++	255
	A.3	Shared	object libraries for Linux	256
		A.3.1	Foreign Object code written in FORTRAN 77	256
		A.3.2	Foreign Object code written in C	256
		A.3.3	Foreign Object code written in C++	256
	A.4	Shared	object libraries for SGI IRIX64 v6.2 and later	257
		A.4.1	Foreign Object code written in FORTRAN 77	257
		A.4.2	Foreign Object code written in C	257
		A.4.3	Foreign Object code written in C++	257
	A.5	Shared	Object libraries for SUN Solaris v2.5 and later	258

		A.5.1	Foreign Object code written in FORTRAN 77	258
		A.5.2	Foreign Object code written in C	258
		A.5.3	Foreign Object code written in C++	258
В	Cre	ating I	Dynamic Link Libraries under Windows	259
	B.1	Dynan	nic link libraries with DIGITAL FORTRAN 5.0	260
	D o	D	nic link libraries with Microsoft Visual C++ 5.0	000

Chapter 1

Introduction

1.1 Overview

This manual describes several advanced features of the gPROMS package. These include:

- The gPROMS Foreign Object Interface (see chapter 2).
 - Foreign Objects are external software components that provide certain computational services to gPROMS MODELs. These include physical property packages, external unit operation modules, or even complete computational fluid dynamics (CFD) software packages. This chapter explains how to make use of foreign objects that are already interfaced to gPROMS; and also how to develop and interface your own foreign objects.
- The gPROMS Physical Property Interface (see chapter 3).
 - Physical property packages form a special type of foreign objects (see above) that are encountered very frequently in practice. The gPROMS Physical Property Interface (PPI) defines a standard set of physical property facilities that should be supported by all physical property packages interfaced to gPROMS. Some widely used physical property packages are already interfaced to gPROMS; details on how to use them are also provided in this chapter. Finally, the PPI provides a particularly convenient way of interfacing new physical property packages to gPROMS.
- The gPROMS Foreign Process Interface (see chapter 4).
 - The Foreign Process Interface (FPI) allows gPROMS simulations to interact with external software such as distributed control systems and operator training packages in order to exchange data and other information. The interaction takes the form of a special set of elementary actions within the gPROMS TASK language. FPI is particularly useful for embedding gPROMS simulations within larger software systems.

• The gPROMS Output Channel Interface (see chapter 5).

The Output Channel Interface (OCI) allows gPROMS to communicate its simulation results to external software components. This open interface means that users can develop their own software which will have access to the large quantity of results information generated by gPROMS.

1.2 Prerequisites

A good understanding of gPROMS at an advanced level is essential for making the most of the facilities described in this manual. The "gPROMS Advanced User Guide" and/or the gPROMS Advanced Training Course provide the necessary background.

With the exception of chapter 3, the chapters in this manual can be read independently of each other. Some understanding of the concepts presented in chapter 2 is a necessary prerequisite for chapter 3.

Chapter 2

Developing New Foreign Objects

Contents

2.1	Intr	oduction	15
2.2	The	gPROMS Foreign Object Interface	15
	2.2.1	The Foreign Object initialisation procedure	16
	2.2.2	The Foreign Object verification procedures	17
	2.2.3	The Foreign Object calculation procedures	20
	2.2.4	The Foreign Object termination procedure	22
2.3	Imp	lementation of Foreign Objects	29
	2.3.1	Writing Foreign Objects	29
	2.3.2	Writing Foreign Objects in FORTRAN and C	30
	2.3.3	Writing Foreign Objects in C++	3
	2.3.4	Compiling Foreign Objects	33
	2.3.5	Installing Foreign Objects	33
	2.3.6	Documenting Foreign Object classes	34
2.4	Imp	lementing Foreign Objects using COM	34
	2.4.1	The Foreign Object COM interfaces	34
	2.4.2	Registering a Foreign Object COM server	35
	2.4.3	Using COM-based Foreign Objects within gPROMS	36

2.1 Introduction

In this chapter, we describe how external software can be linked to gPROMS via the Foreign Object Interface. The information presented here will typically be of interest to gPROMS system programmers concerned with using the Foreign Object mechanism to interface external software to gPROMS. The reader should already be familiar with the use of Foreign Objects as described in chapter 4 of the "gPROMS Advanced User Guide".

2.2 The gPROMS Foreign Object Interface

This section describes the Foreign Object Interface (FOI), *i.e.* the protocol used for communication between gPROMS and any external software component that provides services via one or more callable routines.

A Foreign Object provides one or more methods, each of which takes inputs from gPROMS and returns an output. The inputs and output can be scalar or vector quantities. In addition to the value of the output, a Foreign Object method may also be able to provide values for the partial derivatives of its output with respect to one or more of its inputs.

Each Foreign Object class is implemented as a distinct piece of software. To achieve the required functionality, gPROMS makes use of six services provided by this software:

• a Foreign Object instance initialisation procedure:

gFOI

• two Foreign Object verification procedures:

gFOCM, gFOCMI

• two Foreign Object calculation procedures:

gFOM, gFOMD

• a Foreign Object termination procedure:

gFOT

Below, we examine the precise nature of each of these procedures.

2.2.1 The Foreign Object initialisation procedure

At the start of executing a PROCESS entity, gPROMS will construct a list of all distinct Foreign Object classes and their instances that are used by it. It then attempts to create each instance by calling the gFOI procedure of the corresponding class.

The gFOI procedure has the following form:

• gFOI (ForeignObjectID, ForeignObjectHandle, Status)

where the arguments are as described in table 2.1.

The ForeignObjectID is a string identifying the instance of the Foreign Object class that is to be created. The class name is prepended to the instance name separated from it by a double colon "::". For example, in the case of the example shown in figures 2.1 and 2.2, gPROMS would set ForeignObjectID to:

"ThermoPack::MygPROMSDir/Aromatics.tpk"

in the call to gFOI.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
ForeignObjectID	Character*256	Full name of Foreign Object (terminated with a null).	YES	NO
ForeignObjectHandle	Integer	Handle for identifying Foreign Object in subsequent calls (see text).	NO	YES
Status	Integer	Status of this initialisation. Status = 1 implies successful initialisation. All other values signify failure.	NO	YES

Table 2.1: Arguments of the procedure gFOI.

gPROMS is not concerned with the way in which the external software will actually interpret the ForeignObjectID passed to it. However, the success or failure of the attempted instance creation must be reported to it via the Status argument. If the instantiation fails (Status different from 1), execution of the PROCESS cannot proceed further and is terminated immediately.

During a typical run, gPROMS may need to issue a large number of requests to the services provided by a given Foreign Object software. In order to minimise the overhead associated with these requests, the gFOI routine may also return to gPROMS a "handle",

```
1
     MODEL Flash
2
       PARAMETER
 3
         PPP AS FOREIGN_OBJECT "ThermoPack"
 4
         NoComp AS INTEGER
5
       VARIABLE
6
         F, L, V AS MolarRate
7
         Hf AS MolarEnergy
8
         Q AS EnergyRate
9
         T AS Temperature
10
         P AS Pressure
         x, y, z AS ARRAY(NoComp) OF MoleFraction
11
       SET
12
13
         NoComp := PPP.NumberOfComponents ;
       EQUATION
14
15
         F*z = L*x + V*y ;
         F*Hf = L*PPP.LiquidEnthalpy(T,P,x) + V*PPP.VapourEnthalpy(T,P,y) + Q ;
16
17
         x*PPP.LiquidFugacityCoeff(T,P,x) = y*PPP.VapourFugacityCoeff(T,P,y);
         SIGMA(x) = SIGMA(y) = 1;
18
         IF PPP.StableLiquid(T,P,x) THEN
19
20
21
         ELSE
22
23
         END
     END # Model Flash
24
```

Figure 2.1: An example of a gPROMS MODEL using a Foreign Object.

ForeignObjectHandle. This is usually an address allowing the corresponding Foreign Object instance to be located quickly. gPROMS will *not* attempt any interpretation or make any direct use of this handle. However, it will pass it to all subsequent calls requesting services relating to this particular Foreign Object instance (see sections 2.2.2–2.2.4).

2.2.2 The Foreign Object verification procedures

In general, gPROMS does not know a priori what methods a Foreign Object can provide nor does it know what inputs each method needs or what output it calculates. However, it can deduce this information from the gPROMS input file. Once the various Foreign Object instances are created successfully (see section 2.2.1), gPROMS will try to verify

```
1 PROCESS PlantSimulation
2 UNIT
3    Plant AS TwoTankSystem
4    SET
5    Plant.LPPP := "MygPROMSDir/LPThermo.tpk";
6    ...
```

Figure 2.2: SETting of a Foreign Object value within a PROCESS entity.

the correctness of this information by issuing requests to the Foreign Object verification procedures (cf. section 10.2.3 of the "gPROMS Introductory User Guide").

2.2.2.1 Verification of method existence and structure

The first verification procedure, gFOCM, is used by gPROMS to ascertain the existence of a given method, to determine the number of inputs that the method expects, and to obtain detailed information on the method's output. It has the form:

The arguments of gFOCM are described in detail in table 2.2. The first two, ForeignObjectID and ForeignObjectHandle, are used by gPROMS to identify the Foreign Object instance to which the request relates (cf. section 2.2.1). The third argument, MethodName¹, identifies the method. gFOCM should then return the number of inputs that this method expects as well as detailed information on the method's (unique) output. By setting Status to a value of 1, gFOCM signals that, indeed, such a method is supported by the Foreign Object.

The specification of the physical dimensions of the method output is done in terms of the integers p_i and q_i that define a quantity's dimensions as:

$$\prod_{i=1}^{10} [Fundamental Dimension]_i^{p_i/q_i}$$

¹The MethodName is always provided by gPROMS in capitals in all calls to Foreign Object services.

where the 10 fundamental dimensions, i=1,...,10, are listed in table 2.3. In the argument list of gFOCM, p_i corresponds to OutputDimensionsNum and q_i to OutputDimensionsDenom. Although, in most cases, the index p_i/q_i will take integer values (i.e. q_i will be 1 for all i), using both p_i and q_i allows rational indices also to be specified whenever necessary. For example, if the method output is a velocity, the dimensions returned should be:

$${\tt OutputDimensionsNum} = [\ 1,\ 0,\ \hbox{-}1,\ 0,\ 0,\ 0,\ 0,\ 0,\ 0,\ 0]$$

and:

$$\mathtt{OutputDimensionsDenom} = [1, 1, 1, 1, 1, 1, 1, 1, 1, 1]$$

The Foreign Object also has to specify the units of measurement of the output by setting the arguments OutputOffset and OutputMultiplier. These are such that:

$$\left(\begin{array}{c} \text{Value of} \\ \text{Output in} \\ \text{SI Units} \end{array} \right) = \text{OutputOffset} + \text{OutputMultiplier} \times \left(\begin{array}{c} \text{Value of} \\ \text{Output Computed by} \\ \text{Foreign Object} \end{array} \right)$$

For instance, for a velocity measured in km/hr, the OutputOffset should be 0 while the OutputMultiplier should have a value of 1000/3600. On the other hand, for a temperature measured in degrees Fahrenheit, the corresponding values should be 255.37 (= 273.15 - 5/9*32) and 5/9 respectively.

2.2.2.2 Verification of method inputs

Once the existence of a Foreign Object method is ascertained and the number of its inputs is determined, the next step for gPROMS is to obtain detailed information on these inputs. This is achieved via a call to the routine gFOCMI, the form of which is as follows:

 gFOCMI (ForeignObjectID, ForeignObjectHandle, MethodName, NoInputs, InputNames, InputLengths, InputTypes, InputDerivsAvailable, InputDimensionsNum, InputDimensionsDenom, InputOffsets, InputMultipliers, Status)

where the arguments are as described in table 2.4.

The first four arguments of gFOCMI are identical to those for gFOCM. Also, the arguments InputLengths, InputTypes, InputDimensionsNum, InputDimensionsDenom, InputOffsets and InputMultipliers are similar to the corresponding arguments of gFOCM. Of course, in this case, they are all arrays of length NoInputs as the necessary information must be supplied for all inputs of the method.

The argument InputNames allows the Foreign Object to associate a name with each one of its inputs. These names can be used by gPROMS for generating diagnostic messages and also for identifying individual inputs in subsequent requests for information issued to the Foreign Object. Finally, the argument InputDerivsAvailable allows the Foreign Object to inform gPROMS whether the method will be able to provide the partial derivatives of its output with respect to a particular input.

2.2.3 The Foreign Object calculation procedures

If the Foreign Object initialisation and verification are completed successfully, gPROMS proceeds with the execution of the PROCESS under consideration. This requires the evaluation of the outputs of the various Foreign Object methods used in the problem for given values of their inputs. It also usually involves the evaluation of partial derivatives of the outputs with respect to the inputs.

In order to obtain the above numerical information, gPROMS will call the following procedures during the run:

- gFOM (ForeignObjectID, ForeignObjectHandle, MethodName, OutputLength, NoInputs, InputLengths, TotalInpLength, MethodInputs, MethodOutput, Status)
- gFOMD (ForeignObjectID, ForeignObjectHandle, MethodName, OutputLength, NoInputs, InputLengths, TotalInpLength, MethodInputs, DInputName, DInputLength, DerivOutputs, Status)

Their arguments are described in table 2.5 and table 2.6 respectively; most of these arguments have already been encountered. Before calling either of the two procedures, gPROMS copies the current values of the method arguments into a single array MethodInputs in the order in which they were declared. The total length of this array is computed by gPROMS and passed to the procedures in argument TotalInpLength. This is done only for convenience: TotalInpLength is simply the sum of the NoInputs entries in array InputLengths.

In case of gFOM, the method output is returned to gPROMS in argument MethodOutput of length OutputLength. The values for outputs of type INTEGER should be converted by gFOM to the equivalent real quantities; similarly, for LOGICAL results, the values returned should be 1.0 for TRUE and 0.0 for FALSE.

In case of gFOMD, the arguments DInputName and DInputLength are used by gPROMS to pass the name and the length of the input with respect to which the partial derivatives of the output are requested. The values of these derivatives are returned by gFOMD in array DerivOutputs. Note that gFOMD must only return the partial derivatives with

respect to the *one* input specified in the DInputName argument. This will be discussed in more detail later.

gPROMS will never call gFOMD for an input that is not of type REAL, or one for which partial derivatives are not available as notified to gPROMS by a call to gFOCMI.

2.2.3.1 Specifying partial derivative outputs

As stated before, gFOMD must only return the partial derivatives of the method with respect to the *one* input specified by gPROMS in the DInputName. This is because gPROMS calls for the partial derivatives with respect to each input separately: returning *all* of the partial derivatives with respect to *all* of the inputs at the same time in the DerivOutputs argument will cause errors.

So the values that you must specify in the DerivOutputs argument depend on the dimensionality of the method and of the requested input.

- Scalar method (f) and scalar input (x)This is the simplest case, in which the output is also a scalar equal to the derivative of the method with respect to the input: $\partial f/\partial x$.
- Scalar method (f) and vector input $(\underline{x} \in \mathbb{R}^N)$ In this case, the output will be a vector of length equal to the length of the input. Each element i of the output vector must be the value of the partial derivative of the method with respect to the ith element of the input vector. So DerivOutputs must be equal to $[\partial f/\partial x_1 \ \partial f/\partial x_2 \ \dots \ \partial f/\partial x_N]^T$.
- Vector method $(\underline{f} \in \mathbb{R}^M)$ and scalar input (x)In this case, the output must be a vector of length M. Each element i of the output vector must be the partial derivative of the ith element of the method with respect to the input. The DerivOutputs argument must therefore contain $[\partial f_1/\partial x \ \partial f_2/\partial x \ \dots \ \partial f_M/\partial x]^T$.
- Vector method $(\underline{f} \in \mathbb{R}^M)$ and vector input $(\underline{x} \in \mathbb{R}^N)$ This is the final possibility. In this case, the output is also a vector and its length must be $M \times N$. The first N elements must be the partial derivatives of the first element of the method (f_1) with respect to the N elements of the input \underline{x} , as in the second case above. The next N elements are then the partial derivatives of the second element of the method (f_2) with respect to the N elements of the input. So the overall form of the DerivOutputs argument must be $[\partial f_1/\partial \underline{x} \ \partial f_2/\partial \underline{x} \ \dots \ \partial f_M/\partial \underline{x}]^{\mathrm{T}}$. Fully expanded, this is: $[\partial f_1/\partial x_1 \ \partial f_1/\partial x_2 \ \dots \ \partial f_1/\partial x_N \ \partial f_2/\partial x_1 \ \dots \ \partial f_2/\partial x_N \ \dots \ \partial f_M/\partial x_{N-1} \ \partial f_M/\partial x_N]^{\mathrm{T}}$.

The example files tank_c.c, tank_cpp.cxx and tank_f.f provided with gPROMS contain an example of a gFOMD implementation (in C, C++ and FORTRAN, respectively).

These files can be found in the scr/examples/foi subdirectory of the gPROMS installation directory.

2.2.4 The Foreign Object termination procedure

The Foreign Object termination procedure is of the form:

• gFOT (ForeignObjectID, ForeignObjectHandle, Status).

The arguments are as listed in table 2.1, but with the argument ForeignObjectHandle specified on entry and unchanged on exit.

At the end of the PROCESS execution, gPROMS will call this procedure in turn for each Foreign Object instance that has been successfully created via an earlier successful call to gFOI. This is intended to provide the external package with an opportunity to do any necessary housekeeping (e.g. closing of databank files etc.).

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
ForeignObjectID	Character*256	Full name of Foreign Object (terminated with a null).	YES	NO
ForeignObjectHandle	Integer	Handle for identifying Foreign Object.	YES	NO
MethodName	Character*256	Name of method (terminated with a null).	YES	NO
NoInputs	Integer	Number of inputs for this method.	NO	YES
OutputLength OutputType	Integer Integer	Length of method output. The type of the method output. This will be: 1 for REAL, 2 for	NO NO	YES YES
OutputDimensionsNum	Integer	INTEGER, and 3 for LOGICAL. The numerator of the fundamental dimensions of the output of the method. An array of length	NO	YES
OutputDimensionsDenom	Integer	The denominator of the fundamental dimensions of the output of the method. An array of	NO	YES
OutputOffset	Double Precision	length 10. Offset constant for conversion of units of measurement of method output to SI units. A scalar	NO	YES
OutputMultiplier	Double Precision	quantity. Multiplier constant for conversion of units of measurement of method output to SI units. A scalar quantity.	NO	YES
Status	Integer	Status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 2.2: Arguments of the procedure gFOCM.

Fundamental Dimension	Description	SI Units
1 2 3 4 5 6 7 8 9	Length Mass Time Electric Current Temperature Amount of Substance Luminous Intensity Plane Angle Solid Angle Money	metre kilogram second Ampere Kelvin mole candela radian steradian US dollar

Table 2.3: Physical dimensions for the inputs and output of a method.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
ForeignObjectID	Character*256	Full name of Foreign Object (terminated with a null).	YES	NO
ForeignObjectHandle	Integer	Handle for identifying Foreign Object.	YES	NO
MethodName	Character*256	Name of method (terminated with a null).	YES	NO
NoInputs	Integer	Number of inputs for this method.	YES	YES
InputNames	Character*256	The names of the method inputs. An array of length NoInputs.	NO	YES
InputLengths	Integer	The length of the method inputs. For example, a scalar input will have a length of 1. An array of length NoInputs.	NO	YES
InputTypes	Integer	The types of the method inputs. This will be 1 for REAL, 2 for INTEGER, and 3 for LOGICAL. An array of length NoInputs.	NO	YES
InputDerivsAvailable	Integer	Flags that indicate whether the method can compute partial derivatives of its output with respect to its inputs. A value of 0 indicates that the corresponding partial derivative is not available. Any other value signifies that the derivative can be computed on request. An array of length NoInputs.	NO	YES

Table continued on next page \dots

continued from previous page				
InputDimensionsNum	Integer	The numerators of the fundamental dimensions of the method inputs. A one-dimensional array of total length NoInputs*10, where	NO	YES
InputDimensionsDenom	Integer	the values are ordered by input. The denominators of the fundamental dimensions of the method inputs. A one-dimensional array of total length NoInputs*10, where the values are ordered by	NO	YES
InputOffsets	Double Precision	input. Offset constants for conversion of units of measurement of inputs to SI units. An array of length NoInputs.	NO	YES
InputMultipliers	Double Precision	Multiplier constants for conversion of units of measurement of inputs to SI units. An array of length NoInputs.	NO	YES
Status	Integer	Status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 2.4: Arguments of the procedure gFOCMI.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
ForeignObjectID	Character*256	Full name of Foreign Object (terminated with a null).	YES	NO
ForeignObjectHandle	Integer	Handle for identifying Foreign Object.	YES	NO
MethodName	Character*256	Name of the method (terminated with a null).	YES	NO
OutputLength	Integer	Length of method output.	YES	NO
NoInputs	Integer	Number of method inputs.	YES	NO
InputLengths	Integer	Lengths of method inputs. An array of length NoInputs.	YES	NO
TotalInpLength	Integer	Total length of array MethodInputs.	YES	NO
MethodInputs	Double Precision	Numerical values of all the inputs for this method.	YES	NO
MethodOutput	Double Precision	The numerical value(s) of the method output to be re- turned. An array of length OutputLength.	NO	YES
Status	Integer	Status of requested computation. A value of 1 indicates a successful computation. A value of 0 indicates that the Foreign Object does not support the requested calculation. All other values signify failure.	NO	YES

Table 2.5: Arguments of the procedure gFOM.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
ForeignObjectID	Character*256	Full name of Foreign Object (terminated with a null).	YES	NO
ForeignObjectHandle	Integer	Handle for identifying Foreign Object.	YES	NO
MethodName	Character*256	Name of the method (terminated with a null).	YES	NO
OutputLength	Integer	Length of method output.	YES	NO
NoInputs	Integer	Number of method inputs.	YES	NO
InputLengths	Integer	Lengths of method inputs. An array of length NoInputs.	YES	NO
TotalInpLength	Integer	Total length of array MethodInputs.	YES	NO
MethodInputs	Double Precision	Numerical values of all the inputs for this method.	YES	NO
DInputName	Character*256	Name of the input with respect to which the partial derivatives are to be calculated.	YES	NO
DInputLength	Integer	Length of the input with respect to which the partial derivatives are to be calculated.	YES	NO
DerivOutputs	Double Precision	Numerical values of the requested partial derivatives. These will be packed in a one-dimensional array of total length OutputLength*DInputLength. The values must be ordered by output.	NO	YES
Status	Integer	Status of requested computation. A value of 1 indicates a successful computation. A value of 0 indicates that the Foreign Object does not support the requested calculation. All other values signify failure.	NO	YES

Table 2.6: Arguments of the procedure gFOMD.

2.3 Implementation of Foreign Objects

This section deals with some of the details of the implementation of Foreign Object software and the precise ways in which this can be compiled and linked to gPROMS.

2.3.1 Writing Foreign Objects

In principle, Foreign Object software can be written in any procedural language such as FORTRAN, C and C++. Although the first two are perfectly adequate, at least for simple applications, special care must be taken if the problem under consideration makes use of multiple instances of the same Foreign Object class. In such cases, it is important that each instance has a separate area of private storage. This is not a trivial task if the private storage is allocated statically (as is the case with FORTRAN) because essentially there is just a *single* area of storage that is declared by the code describing the Foreign Object class.

There are several ways of overcoming the above difficulty with different degrees of elegance, efficiency and ease of implementation:

1. Create multiple copies of the same class.

This is rather inefficient since it involves keeping multiple copies of the same code under different names. Realistically, it is an option only with very small Foreign Object codes.

2. Allocate large static workspace in Foreign Object class code and manage its allocation and use among all instances of the class.

Perhaps the easiest way of achieving this is by using the ForeignObjectHandle (cf. section 2.2.1) as a means of indexing the instances of the class that are active at any given time. In particular, the gFOI procedure can maintain a count of the number of instances that have been created thus far; initially this is zero. Each invocation of gFOI increases this count by 1 and returns its current value as the ForeignObjectHandle.

Consider, now, a Foreign Object class, each instance of which requires a real workspace of length 1000. Suppose, furthermore, that it is expected that any gPROMS problem might involve up to 10 such instances. In a FORTRAN implementation, we can then declare a workspace array in a COMMON block of the form:

COMMON /WWW/ W(10,1000)

and insert this in all 6 service procedures (*cf.* section 2.2). Then each of the latter can use the value of the ForeignObjectHandle passed to it by gPROMS to reference the correct part of the workspace.

3. Allocate workspace for each Foreign Object instance dynamically.

This option differs from 2 above in that there is no need to allocate a static array that is large enough to hold the data for all instances that might be created during a run. Instead, each call to gFOI allocates the required workspace dynamically. The ForeignObjectHandle returned by gFOI could be a pointer to the workspace allocated for the corresponding instance.

Obviously, this option is available only with languages that allow such dynamic storage operation (e.g. C).

Of course, the use of truly object-oriented languages such as C++ does provide a real advantage in making it easier to handle multiple instances of a Foreign Object class being used in the same problem. By defining a C++ class whose methods are those of the Foreign Object and whose private data include everything which is specific to a given instance, the gF0I routine can consist simply of creating an instance of this C++ class. The private data of this instance can be established e.g. in the constructor of this class or in special initialization methods.

WARNING!

In writing code for Foreign Objects, always use the default declaration for INTEGER type arguments to the six service procedures.

Do *not* make use of any explicit declarations of integer variable lengths (e.g. INTEGER*4). Doing so may render your code incompatible with gPROMS on some platforms (e.g. those using 64-bit integers).

2.3.2 Writing Foreign Objects in FORTRAN and C

As mentioned in section 2.2, any Foreign Object implementation has to provide six service procedures. For convenience, skeleton files are provided for both FORTRAN and C. The skeletons contain only the calling frame for the service procedures. The names of these files are foi.c and foi.f². The C version also relies on the header files gF0Interface.h and gTypes.h which:

- provide prototype definitions for the six Foreign Object interface routines,
- define a macro which ensures that the function prototypes are exported when compiling for MS Windows and
- define own versions of the basic types for ease of portability.

²All the provided example code can be found in the src/examples/foi subdirectory of the gPROMS installation directory.

Please note: It is strongly recommended that you do not change the prototypes and type definitions because they ensure that the function calls follow the conventions gPROMS uses internally.

In addition to the above files, an example implementation of a simple Foreign Object (tank_c.c and tank_f.f) is provided together with a gPROMS input file (tank_fo.gPROMS³) that makes use of this Foreign Object. This example shows how to evaluate the arguments from the service procedures and how to trigger the methods of the Foreign Objects you wish to implement; here the calculation of the liquid level and the flow out of a tank are implemented.

2.3.3 Writing Foreign Objects in C++

As mentioned above, C++ offers a straightforward way to implement a Foreign Object and to manage multiple instances of the same class. How to do this is demonstrated in detail by the provided example code⁴.

The basic idea is to divide the responsibilities into:

- the interface to gPROMS,
- managing the Foreign Objects, comprising the task of creating, destroying and accessing them, and finally
- the Foreign Objects.

The provided classes and interfaces provided are designed so that the user can use them as a library without having to bother with the low-level interface to gPROMS and the management of the Foreign Objects.

In the above list, the second group of responsibilities is dealt with by a single object, a so-called Factory. On request, this Factory will create and destroy Foreign Objects. Internally it keeps track of all the Foreign Objects. Actually, the Factory is designed to be the only interface through which Foreign Objects can be created and accessed; the key for retrieving them is the ForeignObjectHandle which was assigned to the Foreign Object upon creation.

Since the Factory manages all the Foreign Objects, there should exist only one instance of the Factory class. This is ensured by a Singleton function, get_F0Factory(). This function (and only this function) provides access to the Factory, which is ensured by keeping constructors and destructors of the Factory class private.

³tank_fo.gPROMS is located in the examples/gPROMS subdirectory of the gPROMS installation directory.

⁴In order to understand these examples, at least a basic understanding of C++ and object oriented terminology is necessary.

The interface functions are necessary because gPROMS expects the service procedures to be provided as functions. From the interface functions, then, member functions of the class implementation are called. For example, if you have implemented a class MyForeignObject, a gPROMS call to gFOM() will actually be translated in a call to MyForeignObject::Evalmethod(). However, before this call actually takes place, the interface function first asks the Factory to retrieve the Foreign Object identified by the handle passed to gFOM() by gPROMS.

The interface functions can be found in the file gFOInterface.cxx and need not be changed if it is not intended to change the underlying structure of the C++ interface.

Two additional classes are provided: gFOClass and gFOFactory. Both of them are purely abstract classes, which means you cannot instantiate them directly. Instead, their purpose is to provide the basic functionality (or interface) which has to be implemented in the Foreign Object. When defining and implementing a Foreign Object, you should derive your own classes from these two classes and define the virtual functions of the abstract base classes. In this context, gFOClass is the base class for the Foreign Object, whereas gFOFactory is the base class for a user-provided factory which is responsible for generating and accessing a single or multiple Foreign Objects. This simple inheritance structure is shown in figure 2.3 for the tank example.




Figure 2.3: Inheritance for the tank example

When deriving from gFOClass, the only member functions which have to be provided by the user are the equivalents for the service procedures shown in table 2.7.

Service procedure	C++ equivalent
gFOCM()	Checkmethod()
gFOCMI()	Checkmethodinputs()
gFOM()	Evalmethod()
gFOMD()	Evalmethodderiv()

Table 2.7: Service procedure and their C++ equivalent

Note that the argument lists of the member functions in table 2.7 are identical to their corresponding functions in gFOInterface.h except that they are missing the first two arguments of the latter: the ForeignObjectID and ForeignObjectHandle are unnecessary since these functions operate on the specific object with which they are associated.

Example implementations for these member functions can be found in tank_cpp.h and tank_cpp.cxx. gFOI() and gFOT() do not have to be defined because they call member functions which are already implemented in gFOFactory and which are responsible for creating and destroying Foreign Objects.

When deriving a Factory from the gFOFactory provided, the only member function which has to be provided by the user is CreateObject() plus a global function which will provide access to the factory, get_FOfactory(), cf. the files tank_factory.h and tank_factory.cxx.

If the proposed structure is adopted, none of the interface files has to be changed, only classes with the member functions, as in the tank example, have to be provided by the user.

2.3.4 Compiling Foreign Objects

gPROMS employs a *dynamic loading* mechanism that allows it to load Foreign Object code and make use of its services without the need for a separate linking step. Standardised dynamic loading facilities are nowadays available under both the UNIX and MS Windows operating systems. These provide direct control over the process of loading the Foriegn Object code into memory during program execution.

In view of the above, each Foreign Object class is physically implemented as a UNIX shared object library (e.g. ThermoPack.so) or a Windows dynamic link library (e.g. ThermoPack.dll). Appendix A details how these libraries can be created for the currently supported UNIX platforms, while appendix B provides the equivalent explanation for Windows.

2.3.5 Installing Foreign Objects

Once the code describing the Foreign Object class is written and compiled as explained in section 2.3.1 and section 2.3.4 above, the resulting dynamic library has to be installed in a place where gPROMS can find it during runtime. There are two main options for this:

- In a sub-directory called fo of the user's current gPROMS working directory.
 This sub-directory is at the same level as the input, output and save sub-directories.
- In a sub-directory called **fo** of the gPROMS installation directory.

Clearly, the first option is appropriate only for Foreign Objects that are used by a small number of users, otherwise it may lead to unnecessary waste of disk space; it may also make the maintenance of the Foreign Object code very difficult to manage. The second

option makes the Foreign Object accessible to all gPROMS users but will usually require system administrator priviledges.

On UNIX platforms, a third option is for individual users to place a symbolic link to the actual Foreign Object library inside their private fo sub-directory. The actual code may, thus, reside anywhere in the system where it is accessible to the group of users who need it. This has the advantage of saving disk space without requiring system administrator privileges.

2.3.6 Documenting Foreign Object classes

The information that users of Foreign Objects need to know in order to use them correctly within gPROMS is listed in chapter 4 of the "gPROMS Advanced User Guide". We recommend that, as a Foreign Object developer, you base the documentation of your software on this list.

2.4 Implementing Foreign Objects using COM

Section 2.3 of this chapter has described the implementation of Foreign Objects in FORTRAN and C/C++ and their linking to gPROMS as dynamic libraries or shared objects. This section presents some of the details of implementing Foreign Objects alternatively as COM objects and, hence, the material in this section is only applicable to the Windows operating system. COM objects can be written in any suitable computer language like Visual Basic and C++, and, because they need to be registered with the Windows registry, can be placed in any location in the computer.

In the following sections, the full process of writing and using COM objects as Foreign Objects in gPROMS is described. This will cover the description of the required gPROMS files, the COM interfaces and full IDLs, registration details, and how to refer to the COM objects in gPROMS input files.

2.4.1 The Foreign Object COM interfaces

There are two COM interfaces which need to be implemented by any Foreign Object COM server: the first provides an identification of the interface while the second provides all the methods of the gPROMS FOI. The full details are presented next. All the data types are defined in table 2.16.

2.4.1.1 The IFOICOMServerIdentification interface

The purpose of this interface is to provide an identification of the FOI COM server. This is in the form of the name and a short description of what it does. The information

provided is used by gPROMS when it provides a list of all the available FOI COM servers in the MS Windows registry (cf. section 2.4.3). The interface implements two methods: GetServerName and GetServerDescription, and their IDLs are given in tables 2.8 and 2.9. The interface inherits from the IDispatch interface.

Interface Name	IF0IC0MServerIdentification	
Method Name	GetServerName	
Method Returns	FOIError	
Method Description	This method returns the FOI COM server name	
Method Arguments		
Name	Type	Description
[out,retval] *name	FOIString	Name of the FOI COM server

Table 2.8: IFOICOMServerIdentification::GetServerName

2.4.1.2 The IgPROMSF0I interface

This interface implements all the gPROMS FOI methods described in detail in section 2.2. There are six methods in the interface: Initialise, CheckMethod, CheckMethodInputs, EvalMethod, EvalMethodDeriv, Terminate. The IDLs of all the methods are given in tables 2.10 to 2.15. The interface inherits from the IDispatch interface. gPROMS will call the Initialise method after the COM object has been successfully created but before any other method of the interface is called.

2.4.2 Registering a Foreign Object COM server

All gPROMS Foreign Object COM servers need to be registered in a specific location (category) in the Windows registry. The necessary CATID together with the IIDs of the two interfaces are given next.

- IFOICOMServerIdentification_IID C92162CD-4F79-11d5-9082-00C04F7D052E
- IgPROMSF0I_IID C92162CE-4F79-11d5-9082-00C04F7D052E
- FOICOMComponent_CATID D75D9500-5118-11d5-9082-00C04F7D052E

Interface Name	IF0IC0MServerIdentification		
Method Name	GetServerD	GetServerDescription	
Method Returns	FOIError		
Method Description	This method returns the description of the FOI COM server		
Method Arguments			
Name	Type	Description	
[out,retval] *desc	FOIString	Description of the FOI COM server	

 $Table\ 2.9:\ {\tt IFOICOMServerIdentification} :: {\tt GetServerDescription}$

The first two are the IIDs of the two interfaces described in section 2.4.1, while the third is the category identifier (CATID) where all FOI COM servers should be placed.

2.4.3 Using COM-based Foreign Objects within gPROMS

Before any COM object written to provide the Foreign Object Interface (FOI) services is used in gPROMS, the file FOICOM.dll must be placed in the gPROMS fo sub-directory. This file acts as a bridge between the standard gPROMS FOI and the COM server, and should have been installed as part of the standard gPROMS installation process. The tasks performed by the dll include searching the Windows registry for FOI COM components, creation of such components, and the handling of all the FOI calls between gPROMS and the COM server.

Once a Foreign Object COM server has been properly installed in the Windows registry (see section 2.4.2), it can be used within gPROMS using the latter's standard Foreign Object mechanism (which is fully described in chapter 4 of the "gPROMS Advanced User Guide").

In the PROCESS entity, the class of the Foreign Object needs to be declared as COMForeignObject. The value of the particular instance of the Foreign Object should be set to the ProgID under which the FOI COM server has been installed in the MS Windows registry (cf. section 2.4.2). For example, the following specification:

- 1. PROCESS TEST
- 2. UNIT

Interface Name	IgPROMSFOI		
Method Name	Initialise		
Method Returns	FOIError		
Method Description	This method initialises the FOI COM server		
Method Arguments			
Name	Type	Description	
[in] fo_id	FOIString	The full FO Id from gPROMS	

Table 2.10: IgPROMSFOI::Initialise

specifies that the Foreign Object Hydraulics appearing in instance F of MODEL BufferTank is a COM-based Foreign Object server that has been installed in the MS Windows registry under the ProgID "TankCo.Mixer.1".

It is often necessary to specify options for a Foreign Object. This may be the location of a particular file that the FOI COM server needs or the variants of a particular method of the Foreign Object. Any option for the FOI COM server should be put within angled brackets "<" and ">". For example, the specification above may be modified to:

which may be used to indicate that a turbulent regime should be assumed for the calculations of hydraulics in this mixer unit. gPROMS will always pass the full string value of the Foreign Object (i.e., "COMForeignObject::TankCo.Mixer.1<Turbulent>") to the Foreign Object COM server using the IgPROMSFOI::Initialise method. It is the

Interface Name	IgPROMSF0I		
Method Name	CheckMethod		
Method Returns	FOIError		
Method Description	Checks the existence of a given Foreign Object method		
Method Arguments			
Name	Type	Description	
[in] method_name [out] *num_inputs [out] *output_length [out] *output_type [out] *out_dimen_num [out] *out_dimen_den [out] *out_offset [out] *out_multipl	FOIString FOILong FOILong FOILong FOIArrayLong FOIArrayLong FOIDouble FOIDouble	The name of the method The number of inputs The length of the output The type of the output The dimensions of the numerator of the output The dimensions of the denominator of the output The offset value for the output The multiplier value for the output	

Table 2.11: IgPROMSF0I::CheckMethod

responsibility of the Foreign Object to parse this string and to modify its behaviour accordingly.

If, for whatever reason, the ProgID of a COM-based Foreign Object is not known, then attempting the execution of the above PROCESS entity without specifying a ProgID, that is:

will produce a list of the ProgIDs of all the FOI COM servers that are currently installed in the registry.

Interface Name	IgPROMSFOI				
Method Name	CheckMethodInpu	CheckMethodInputs			
Method Returns	FOIError				
Method Description	Checks the inputs of a given Foreign Object method				
	Method .	Arguments			
Name	Type	Description			
[in] method_name [out] *input_names [out] *input_lengths [out] *input_types [out] *input_deriv_avail [out] *input_dimens_num [out] *input_dimens_den [out] *input_offsets [out] *input_multipl	FOIString FOIArrayString FOIArrayLong FOIArrayLong FOIArrayLong FOIArrayLong FOIArrayLong FOIArrayLong FOIArrayDouble FOIArrayDouble	The name of the method The names of the inputs The lengths of the inputs The types of the inputs The availability of the derivatives with respect to the inputs The dimensions of the numerator of the inputs The dimensions of the denominator of the inputs The offset values for the inputs The multiplier values for the inputs			

 $Table\ 2.12:\ {\tt IgPROMSFOI::CheckMethodInputs}$

Interface Name	IgPROMSF0I			
Method Name	EvalMethod	EvalMethod		
Method Returns	FOIError			
Method Description	Evaluates a Foreign Object method for a given set of inputs			
Method Arguments				
Name	Type	Description		
[in] method_name [in] input_values [out] *output_values	FOIString FOIArrayDouble FOIArrayDouble	The name of the method The values of the inputs The values of the output		

Table 2.13: IgPROMSFOI::EvalMethod

Interface Name	IgPROMSF0I			
Method Name	EvalMethodDeriv			
Method Returns	FOIError			
Method Description	Evaluates the partial derivatives of a Foreign Object method for a given set of inputs			
Method Arguments				
Name	Type	Description		
[in] method_name [in] deriv_input_name	FOIString FOIString	The name of the method The name of the input with respect to which the drivatives are required		
[in] input_values [out] *output_values	FOIArrayDouble FOIArrayDouble	The values of all the inputs The values of the output		

 $Table\ 2.14:\ {\tt IgPROMSFOI::EvalMethodDeriv}$

Interface Name	IgPROMSF0I		
Method Name	Termi	Terminate	
Method Returns	FOIEr	FOIError	
Method Description	This method terminates the FOI COM server		
Method Arguments			
Name	Name Type Description		
no arguments			

Table 2.15: IgPROMSF0I::Terminate()

FOICOM Data Type	COM Data Type
FOIChar FOILong FOIDouble FOIBoolean FOIString FOIVariant FOIInterface FOIDate FOIError FOIArrayLong FOIArrayDouble FOIArrayBoolean	char long int double VARIANT_BOOL BSTR VARIANT LPDISPATCH DATE HRESULT VARIANT VARIANT VARIANT
FOIArrayString	VARIANT

Table 2.16: FOICOM Data Types

Chapter 3

Interfacing Physical Property Packages to gPROMS

Contents

3.2	Dire	ct Foreign Object services	46
	3.2.1	The gF0I Foreign Object initialisation service	47
	3.2.2	The gFOCM Foreign Object verification service	48
	3.2.3	The gFOCMI Foreign Object verification service	49
	3.2.4	The gFOT Foreign Object termination service	50
3.3	The	physical property calculation procedures	50
3.4	Prep	paring the Physical Property Interface Foreign Object.	5 1
3.5	An e	example	52

This chapter explains how you can interface a new physical property package to gPROMS. It assumes a good understanding of the gPROMS Foreign Object concept and interface as described in chapter 2 of this manual.

3.1 Constructing Foreign Objects for physical property packages

There are essentially two different ways of interfacing a physical property package to gPROMS. These are illustrated schematically in figure 3.1. The first, shown in the left part of the diagram makes direct use of the Foreign Object Interface (FOI). To do this, you need to construct your own implementation of a FOI between gPROMS and the external package following the instructions given in section 2.2 and section 2.3.




Figure 3.1: Interfacing external physical property packages to gPROMS

The above option certainly provides you with the maximum degree of flexibility. However, most physical property packages are fundamentally similar to each other and you will probably find that, in trying to implement your own FOI for one of these, you are reproducing work that has already been done by other people (including the gPROMS development team) on several occasions in the past! It may, therefore, be more efficient to use one of these ready-made FOIs as the basis of your interface. This approach, illustrated schematically in the right part of figure 3.1, is described below.

gPROMS already includes a special Foreign Object interface to packages that provide the physical properties listed in table 3.1. This is shown as PP-FOI in figure 3.1. The basic ideas are as follows:

gPROMS Property Name	Inputs	Description	Type
NormalBoilingPoint		Normal boiling point	Vector
CriticalTemperature		Critical temperature	Vector
CriticalPressure		Critical pressure	Vector
CriticalVolume		Critical volume	Vector
NormalFreezingPoint		Melting point	Vector
MolecularWeight		Molecular weight	Vector
IdealGasEnthalpyOfFormationAt25C		Enthalpy of formation	Vector
NumberOfComponents		Number of components	Scalar
VapourPressure	T	Pure component vapour pressures	Vector
LiquidCpCv	T, P, n	Ratio of C_P to C_V in the liquid phase	Scalar
VapourCpCv	T, P, n	Ratio of C_P to C_V in the vapour phase	Scalar
LiquidCompressibilityFactor	T, P, n	Compressibility factor for the liquid phase	Scalar
VapourCompressibilityFactor	T, P, n	Compressibility factor for the vapour phase	Scalar
LiquidEnthalpy	T, P, n	Total enthalpy of the liquid phase	Scalar
VapourEnthalpy	T, P, n	Total enthalpy of the vapour phase	Scalar
LiquidExcessEnthalpy	T, P, n	Excess enthalpy of the mixture	Scalar
LiquidEntropy	T, P, n	Total entropy of the liquid phase	Scalar
VapourEntropy	T, P, n	Total entropy of the vapour phase	Scalar
LiquidFugacityCoefficient	T, P, n	Liquid fugacity coefficients	Vector
VapourFugacityCoefficient	T, P, n	Vapour fugacity coefficients	Vector
LiquidActivityCoefficient	T, P, n	Liquid fugacity coefficients	Vector

Table continued on next page ...

continued from previous pag	e		
LiquidGibbsFreeEnergy	T, P, n	Total Gibbs energy of the liquid phase	Scalar
VapourGibbsFreeEnergy	T, P, n	Total Gibbs energy of the vapour phase	Scalar
LiquidExcessGibbsFreeEnergy	T, P, n	Excess Gibbs energy of the mixture	Scalar
LiquidHeatCapacity	T, P, n	Liquid heat capacity at constant pressure	Scalar
VapourHeatCapacity	T, P, n	Vapour heat capacity at constant pressure	Scalar
LiquidEnergy	T, P, n	Total internal energy of the liquid phase	Scalar
VapourEnergy	T, P, n	Total internal energy of the vapour phase	Scalar
LiquidVolume	T, P, n	Total liquid volume	Scalar
VapourVolume	T, P, n	Total vapour volume	Scalar
LiquidDensity	T, P, n	Density of the liquid phase	Scalar
VapourDensity	T, P, n	Density of the vapour phase	Scalar
LiquidThermalConductivity	T, P, n	Thermal conductivity of the liquid phase	Scalar
VapourThermalConductivity	T, P, n	Thermal conductivity of the vapour phase	Scalar
LiquidViscosity	T, P, n	Viscosity of the liquid phase	Scalar
VapourViscosity	T, P, n	Viscosity of the vapour phase	Scalar
SurfaceTension	T, P, n_L, n_V	Surface tension of the mixture	Scalar

Table 3.1: Physical property functions and their arguments

- 1. On the outside, PP-FOI provides *some* of the services required of Foreign Objects in gPROMS; more specifically, it includes the code implementation of the gFOM and gFOMD services that are used by gPROMS to evaluate the methods and their partial derivatives with respect to their inputs.
- 2. On the inside, PP-FOI fulfils these services by issuing calls to routines that you provide within your Physical Property Interface (PPI).
- 3. Your PPI also includes the code implementation of the four services that are not already provided by PP-FOI. These are:
 - the gFOI Foreign Object initialisation service,
 - the gFOCM service for checking the methods of the Foreign Object,
 - the gFOCMI service for checking the inputs of the methods of the Foreign Object, and
 - the gFOT termination service.

gPROMS will issue direct calls to these services.

4. The combination of the code for the standard PP-FOI with that for your own PPI now provides all six services required by any Foreign Object. Thus, you have now created a new Foreign Object (shown as a dotted box in figure 3.1) corresponding to the physical property package that you want to interface to gPROMS. You may now compile this Foreign Object according to the instructions given in section 2.3.

The main advantage of using the approach outlined above is that steps 1 and 2 take away from you much of the effort involved in providing the gFOM and gFOMD services — and experience indicates that this is usually the most difficult part of constructing a Foreign Object.

The rest of this section discusses in detail the functionality that your PPI needs to provide to gPROMS.

3.2 Direct Foreign Object services

As explained in section 3.1, your PPI must directly provide four of the six services required of all gPROMS Foreign Objects. Sample FORTRAN 77 code implementing these services is provided in file PP-FODirect.f in sub-directory src/examples/foi of the standard gPROMS installation directory on your computer system. We recommend that you study this code in conjunction with the information provided in this section, and, if possible, use it as the basis of developing your own code: in most cases, you may have to make only a few relatively minor changes to the sample code provided!

We now consider each of these four services in more detail.

3.2.1 The gF0I Foreign Object initialisation service

The purpose of this service is to allow gPROMS to create an instance of the class of Foreign Objects corresponding to the physical property package that you are interfacing to gPROMS. The complete specification of gFOI can be found in section 2.2.1.

At the start of the execution of an activity, gPROMS will pass to gF0I a string of characters identifying the particular instance of the physical property package that needs to be created. This string will have been specified in the user's input file and will typically be the name of a file that contains information on the components being used, the methods and options to be used for computing various thermophysical properties and so on.

Your implementation of gF0I will have to execute all actions necessary for initialising the physical property package and making it ready for responding to requests for computing properties (and, in some cases, their partial derivatives) as well as other information (see section 3.3). These initialisation actions may include:

- locating, opening and reading the data file named in the string passed by gPROMS;
- validating the contents of this file;
- retrieving physical property parameters from one or more databanks and storing them in appropriate data structures in memory.

In many cases, the physical property package will provide a "loader" routine that may be called to carry out most or all of the above operations.

In any case, your gF0I must eventually return to gPROMS a status flag indicating whether the initialisation operation has been successful, and, optionally, a "handle" that may be used to identify this particular Foreign Object instance in future references.

WARNING!

The use of the Foreign Object Interface generally allows a gPROMS activity to interact with multiple instances of the same physical property package (e.g. corresponding to different component sets and/or calculation options).

If your physical property package cannot accommodate this feature, or if you do not wish to support it in your interface, it is important to ensure that any user attempt to create multiple instances is intercepted and handled appropriately. An easy way of achieving this is to maintain a counter of the number of instances that are currently active and to make this accessible to both the gFOI and the gFOT services, each call to which will respectively increase and decrease the counter by 1. Any attempt to increase the counter above 1 by repeated calls to gFOI should be rejected by setting its Status flag to 0.

3.2.2 The gFOCM Foreign Object verification service

The purpose of this service is to allow gPROMS to check the existence and structure of the physical property methods that are supposed to be provided by the physical property Foreign Object. The complete specification of gFOCM can be found in section 2.2.2.1.

At the start of an activity and having called gFOI, gPROMS will call gFOCM once for each type of physical property that has been referenced in conjunction with this particular Foreign Object in the user's input file. These properties will normally be a subset of those listed in table 3.1. For instance, suppose that the user has created an instance of the physical property package and has then used it to calculate vapour enthalpies and densities in his MODELs. Then, gPROMS will issue two calls to gFOCM regarding methods VapourEnthalpy and VapourDensity respectively.

If you examine the code for gFOCM provided in the file PP-FODirect.f, you will see that there is a part of the code that refers to each and every physical property in table 3.1. By far the easiest way of creating your own gFOCM is to edit this code. The changes that you can legitimately make are the following:

- If your physical property package does *not* provide a certain physical property, then change the value of the Status flag from 1 to 0.
- If the units of measurement of the physical property are *not* strictly SI, then change the values of OutputOffset and OutputMultiplier from the values of O and 1 that they respectively have in the sample code.

WARNING!

The rest of the information returned by gFOCM relates to fundamental characteristics of the physical properties listed in table 3.1 — for example, the number of the inputs expected by the property. Changes to any part of this information will therefore alter the nature of the physical property itself, which may be both confusing and dangerous to users making use of your physical property interface.

If a property in table 3.1 does not have the precise form of what you want to achieve, do not change it. Instead, mark it as unavailable (by returning Status=0) and extend the interface by defining another property (with a different name) having the desired structure.

3.2.3 The gFOCMI Foreign Object verification service

The purpose of this service is to allow gPROMS to verify the nature of each and every input of each physical property method provided by the physical property Foreign Object. The complete specification of gFOCMI can be found in section 2.2.2.2.

At the start of an activity and having verified via gFOCM that a particular method referred to by the user's input file exists and has the correct structure, gPROMS will immediately call gFOCMI for the same method.

If you examine the code for gFOCMI provided in the file PP-FODirect.f, you will see that there is a part of the code that refers to each and every input of each and every physical property in table 3.1. By far the easiest way of creating your own gFOCMI is to edit this code. The changes that you can legitimately make are the following:

- If your physical property package does *not* provide the partial derivatives of a certain physical property with respect to a certain input, then change the value of the corresponding InputDerivsAvailable flag from 1 to 0.
- If the units of measurement of a certain input are *not* strictly SI, then change the corresponding values of InputOffsets and InputMultipliers from the values of 0 and 1 that they respectively have in the sample code.

WARNING!

The rest of the information returned by gFOCMI relates to fundamental characteristics of the physical properties listed in table 3.1 — for example, the type and ordering of the inputs. Changes to any part of this information will therefore alter the nature of the physical property itself, which may be both confusing and dangerous to users making use of your physical property interface.

If the inputs of a property in table 3.1 do not have the form that you desire, mark the property as unavailable (by returning Status=0 in gFOCM) and extend the interface by defining another property (with a different name) having the desired structure.

3.2.4 The gFOT Foreign Object termination service

The purpose of this service is to allow gPROMS to destroy an instance of a physical property Foreign Object created earlier by a call to gFOI. The complete specification of gFOT can be found in section 2.2.4.

At the end of the activity, gPROMS will call gF0T identifying to it the Foreign Object instance that has to be destroyed. This is intended to provide the physical property package with an opportunity to do any necessary housekeeping such as:

- deletion of any temporary files that may have been created for the purposes of this run;
- releasing of any dynamically allocated memory;
- closing of databank files.

3.3 The physical property calculation procedures

Section 3.2 has described four of the six services that a Foreign Object must provide to gPROMS. The remaining two services, gFOM and gFOMD, are concerned with the computation of the values of the physical properties and the partial derivatives of the latter with respect to their inputs. FORTRAN 77 code for these services is provided in file PP-FOI.f in sub-directory src/foi of the standard gPROMS installation directory on your computer system.

You do *not* normally need to change the code in PP-FOI.f. However, if you examine it, you will see that it obtains the information requested by gPROMS by calling certain

other routines. It is your responsibility to provide the latter in your Physical Property Interface.

A list¹ of procedures that you need to provide is presented in table 3.2 and the description of their arguments in table 3.3. Some of the things that you need to know are:

- The same procedure (e.g. Enthalpy) is used for the calculation of the total, vapour and liquid phase properties, thus corresponding to three different properties listed in table 3.1 (i.e. Enthalpy, VapourEnthalpy and LiquidEnthalpy).
- If your physical property package does not support the calculation of a particular physical property, the corresponding interface routine does not need to be provided, assuming, of course, that you have informed gPROMS of this via gFOCM.
- The value of the physical property must be returned on *every* call to the corresponding procedure. On the other hand, the partial derivatives with respect to temperature, pressure, volume, internal energy, enthalpy and mole numbers need only be computed if the corresponding logical flags NeedDt, NeedDp, NeedDv, NeedDu, NeedDn are set to TRUE. It should be noted that, while the procedure must always compute *at least* the partial derivatives requested by a certain call to it, no error will occur if any *additional* derivatives are returned.
- gPROMS will never request the evaluation of any partial derivatives that have been notified to it as unavailable by the initial call to gFOCMI.
- All procedures have the arguments ForeignObjectInstanceName and ForeignObjectHandle. These are two different ways used by gPROMS to identify the particular instance of the physical property package to which this request for information refers. They are important only if it is envisaged that gPROMS activities will interact with multiple instances of the same property package; if this is not the case, they can be ignored.
- The value of the maximum number of components (maxncs) used in local arrays in gFOM and gFOMD has been present to 40. This can be changed directly in both procedures.

3.4 Preparing the Physical Property Interface Foreign Object

You can now proceed to construct the Foreign Object that will implement the Physical Property Interface. This will comprise three pieces of code:

¹Tables 3.2 and 3.3 do not contain equilibrium flash methods. A full description of the equilibrium flash methods is given in chapter 6 of the "gPROMS Advanced User Guide". The routines presented in this chapter can easily be extended to include the flash methods.

- the code implementing the direct Foreign Object services, as described in section 3.2;
- the physical property calculation routines detailed in section 3.3;
- a copy of the file PP-FOI.f provided with gPROMS (see top of section 3.3).

The first two of these correspond to the box marked as "Your PPI" in figure 3.1, while the third one implements the box marked "gPROMS PP-FOI".

Once you create a FORTRAN 77 file containing the above code, you can compile it into a Foreign Object according to the detailed instructions given in section 2.3.4 and appendix A. Give an appropriate name to the generated shared object library (under UNIX) or dynamic link library (under MS Windows) and install it as detailed in section 2.3.5.

Note that it will not normally be necessary to incorporate the actual physical property package source code physically together with the three code segments mentioned above. Instead, you can compile it separately using the appropriate compiler options (see appendix A) and then include the object file(s) thus generated in the shared object or dynamic link library by listing their names in the link statement.

3.5 An example

To illustrate the ideas discussed in section 3.2 and section 3.3 and to see how they all fit together, let's consider a more concrete example. Suppose we wish to create an interface to a physical property package called *SuperPro*, the code to which is held in two FORTRAN 77 files, called SUP1.f and SUP2.f respectively. The interface is to run on a DEC UNIX workstation under the OSF/1 operating system.

We would then need to go through the following steps:

- 1. Make a copy of the file PhysProps/PP-FODirect.f distributed with gPROMS into a new file SUP-direct.f.
- 2. Edit the four procedures gFOI, gFOCM, gFOCMI and gFOT contained in file SUP-direct.f as described in section 3.2.
- 3. Create a new file called SUP-PPI.f containing the physical property calculation procedures listed in table 3.2. Use the file PP-FOI.f provided with the gPROMS installation directory as a starting point. These will typically call other procedures contained in files SUP1.f and/or SUP2.f.
- 4. For convenience, combine files SUP-direct.f and SUP-PPI.f as well as the file PhysProps/PP-F0I.f distributed with gPROMS into a file called SUP-PPIAll.f.

5. Compile the file SUP-PPIAll.f on the DEC OSF/1 system using the command (cf. appendix A):

6. Compile the physical property source files SUP1.f and SUP2.f using the command:

7. Now, link the three object files created by the compilations at steps 5 and 6 above into a single shared object library called SuperPro.so (cf. appendix A):

Once SuperPro.so is created, you have two choices regarding its installation (cf. section 2.3.5). If it is mainly going to be employed for your own private use, you can place it in a sub-directory called fo of your gPROMS working directory. If, on the other hand, it is to be made generally (and automatically) available to all users on your computer network, you may wish to install it in sub-directory fo of the gPROMS installation directory making it publicly accessible; you will probably need some system administrator privileges to be able to do this.

Interface Procedure	Inputs
NormalBoilingPoint	ForeignObjectName, ForeignObjectHandle, PropertyValueVector, Status
CriticalTemperature	ForeignObjectName, ForeignObjectHandle, PropertyValueVector, Status
CriticalPressure	ForeignObjectName, ForeignObjectHandle, PropertyValueVector, Status
CriticalVolume	ForeignObjectName, ForeignObjectHandle, PropertyValueVector, Status
NormalFreezingPoint	ForeignObjectName, ForeignObjectHandle, PropertyValueVector, Status
MolecularWeight	ForeignObjectName, ForeignObjectHandle, PropertyValueVector, Status
NumberOfComponents	ForeignObjectName, ForeignObjectHandle, PropertyValueScalar, Status
VapourPressure	ForeignObjectName, ForeignObjectHandle, T, PropertyValueVector, NeedDt, dvectordt, Status
BubbleTemperature	ForeignObjectName, ForeignObjectHandle, P, n, PropertyValueScalar, NeedDp, NeedDn, dscalardp, dscalardn, Status
BubblePressure	ForeignObjectName, ForeignObjectHandle, T, n, PropertyValueScalar, NeedDt, NeedDn, dscalardt, dscalardn, Status
DewTemperature	ForeignObjectName, ForeignObjectHandle, P, n, PropertyValueScalar, NeedDp, NeedDn, dscalardp, dscalardn, Status
DewPressure	ForeignObjectName, ForeignObjectHandle, T, n, PropertyValueScalar, NeedDt, NeedDn, dscalardt, dscalardn, Status
CpCv	ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,
CompressibilityFactor	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueVector, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp, dscalardn, Status
Enthalpy	ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueVector, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,
ExcessEnthalpy	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp, dscalardn, Status
Entropy	ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp, dscalardn, Status
FugacityCoefficient	ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueVector, NeedDt, NeedDp, NeedDn, dvectordt, dvectordp, dvectordn, Status
	Table continued on next page

continued from previous page				
ActivityCoefficient	ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueVector, NeedDt, NeedDp, NeedDn, dvectordt, dvectordp,			
GibbsFreeEnergy	dvectordn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
ExcessGibbsFreeEnergy	dscalardn, Status ForeignObjectName, ForeignObjectHandle, T, P, n, Property-ValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
HeatCapacity	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
Energy	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
Volume	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
Density	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
ThermalConductivity	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
Viscosity	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, PropertyValueScalar, NeedDt, NeedDp, NeedDn, dscalardt, dscalardp,			
SurfaceTension	dscalardn, Status ForeignObjectName, ForeignObjectHandle, phase, T, P, n, n2, PropertyValueScalar, NeedDt, NeedDp, NeedDn, NeedDn2,			
TPFlash	dscalardt, dscalardp, dscalardn, Status ForeignObjectName, ForeignObjectHandle, T, P, n, PropertyValueVector, NeedDt, NeedDp, NeedDn, dflashdscalar, dflashdscalar,			
TVFlash	dflashdn, Status ForeignObjectName, ForeignObjectHandle, T, V, n, PropertyValueVector, NeedDt, NeedDv, NeedDn, dflashdscalar, dflashdscalar,			
PHFlash	dflashdn, Status ForeignObjectName, ForeignObjectHandle, P, H, n, PropertyValueVector, NeedDp, NeedDh, NeedDn, dflashdscalar, dflashdscalar,			
UVFlash	dflashdn, Status ForeignObjectName, ForeignObjectHandle, U, V, n, PropertyValueVector, NeedDu, NeedDv, NeedDn, dflashdscalar, dflashdn, Status			

Table 3.2: Physical property calculation procedures

		.	a .a.s	a .a -
Name of Argument	Type	Description	Specified	Specified
			on Entry	on Exit
ForeignObjectName	Character*256	Full name of the Foreign Object.	YES	NO
ForeignObjectHandle	Integer	Handle for identifying Foreign	YES	NO
		Object.		
phase	Character*256	Type of phase present: "liquid", "vapour"/"vapor" or "total".	YES	NO
Т	Double Precision	Temperature.	YES	NO
P	Double Precision	Pressure.	YES	NO
V	Double Precision	Volume.	YES	NO
U	Double Precision	Internal energy.	YES	NO
Н	Double Precision	Enthalpy.	YES	NO
n,n2	Double Precision	Mole numbers of components.	YES	NO
		An array of size NoComp.		
PropertyValueScalar	Double Precision	The numerical value of the prop-	NO	YES
		erty to be returned (scalar prop-		
		erty).		
PropertyValueVector	Double Precision	The numerical value of the prop-	NO	YES
		erty to be returned (vector prop-		
		erty). An array of size NoComp.	*****	37.0
NeedDt, NeedDp, NeedDv,	Logical	Logical flags. On entry, these	YES	NO
NeedDu, NeedDh, NeedDn		will specify whether the partial		
		derivatives with respect to T, P,		
		V, U, H and n respectively are needed.		
dscalardt, dscalardp	Double Precision	These return the numerical val-	NO	YES
dscarardt, dscarardp	Double I recision	ues of the derivatives with respect	110	1120
		to T and P respectively for scalar		
		properties.		
dvectordt, dvectordp	Double Precision	These return the numerical val-	NO	YES
,		ues of the derivatives with respect	-	
		to T and P respectively for vec-		
		tor properties. An array of size		
		NoComp.		
	•	-	=	-

Table continued on next page \dots

continued from previous page				
dflashdscalar	Double Precision	These return the numerical values of the derivatives with respect to T, P, V, U and H for results of flash calculations. An <i>array</i> whos size depends on the size of the flash results.	NO	YES
dscalardn	Double Precision	These return the numerical values of the derivatives with respect to n, for scalar properties. An array of size NoComp.	NO	YES
dvectordn	Double Precision	These return the numerical values of the derivatives with respect to n, for vector properties. A one-dimensional array of size (NoComp*NoComp). The array is ordered by property vector element, i.e. all derivatives of the first property element appear before all derivaties of the second property element. For example, if NoComp=4, $\partial \phi_2/\partial n_3$ will be stored in position 7.	NO	YES
dflashdn	Double Precision	These return the numerical values of the derivatives with respect to n, for results of flash calculations. An array whos size depends on the size of the flash results.	NO	YES
Status	Integer	Status of requested computation. A value of 1 indicates a successful computation. All other values indicate failure.	NO	YES

Table 3.3: Arguments of the physical property calculation procedures

Chapter 4

Developing New Foreign Processes

Contents

4.1	Intr	oduction	5
4.2	The	FPI communication protocol	6
	4.2.1	The gFPI procedure	6
	4.2.2	The gFPPAUSE procedure	6
	4.2.3	The gFPGET procedure	6
	4.2.4	The gFPSEND procedure	6
	4.2.5	The gFPSENDM procedure	6
	4.2.6	The gFPLINEARISE procedure	7
	4.2.7	The gFPT procedure	7
4.3	FPI	implementation for real-time applications	7
4.4	Imp	lementation of Foreign Processes	7
	4.4.1	Writing Foreign Processes in FORTRAN and C	7
	4.4.2	Writing Foreign Processes in C++	7
	4.4.3	Compiling Foreign Processes	7
	4.4.4	Installing Foreign Processes	7

4.1 Introduction

The Foreign Process Interface (FPI) provides a general mechanism for the exchange of information between executing gPROMS simulations and external software.

This communication takes place at discrete time points throughout the duration of the simulation. The user is entirely free to determine the frequency and content of the exchanges which may include:

- time-synchronisation signals;
- values of variables and flags;
- information on the mathematical model used for the simulation and its current state.

The FPI comprises two main components:

• A set of elementary communication tasks.

By inserting instances of these tasks in TASK and PROCESS SCHEDULEs, the user determines the timing and content of any communication that will occur when the SCHEDULE is executed.

• A communication protocol between gPROMS and the external software.

The execution of an elementary communication task in a SCHEDULE automatically causes gPROMS to invoke one of a set of procedures provided by the user.

The FPI communication protocol specifies

- what procedures must be provided;
- their names;
- the precise form of their argument lists.

The FPI communication protocol does *not* specify the *content or detailed behaviour* of these procedures. They can be as complex or as simple as desired—in fact, some of them may be completely empty!

The rest of this chapter is organised as follows:

- Section 4.2 presents the protocol used by gPROMS for its communication with the PFI procedures.
- Section 4.4.3 discusses the compilation and linking of FPI implementations.
- Finally, section 4.3 covers some important issues concerning FPI implementations.

4.2 The FPI communication protocol

By placing the FPI elementary communication tasks (see section 5.2 of the "gPROMS Advanced User Guide") within simulation SCHEDULES, the user can specify the timing and nature of the information exchanges that are to take place between the executing gPROMS PROCESS and the foreign process.

The actual communication takes place by gPROMS issuing calls to a set of procedures (or "subroutines"). The FPI communication protocol is concerned with defining the form of the interaction of these procedures, through their argument lists, with the program that invokes them. The precise content of the procedures is *not* specified—it will vary from implementation to implementation, being determined by the requirements of each particular application.

Any implementation of the FPI must provide five procedures, gFPPAUSE, gFPGET, gFPSEND, gFPSENDM and gFPLINEARISE corresponding to the five elementary communication tasks PAUSE, GET, SEND, SENDMATHINFO and LINEARISE respectively. In addition to these, it must also provide two other procedures, gFPI and gFPT, used by the gPROMS PROCESS respectively to initiate and terminate its interaction with the foreign process.

The rest of this section provides a detailed specification of these seven procedures. This is done using FORTRAN subroutine terminology; however, the equivalent C code could also be used.

In describing the type of the arguments of the various procedures, we will use the notation I, R and C for integer, real and character. Where necessary, the number of bytes allocated to each type will also be specified; for instance, C*256 will denote a character variable of 256 byte length. Note that some of the arguments will be arrays. This will be apparent from the procedure declaration.

A complete example of an FPI implementation is provided as source code in the gPROMS installation directory, see section 4.4 below. This corresponds to the standard FPI provided within the gPROMS executable (see section 5.3.1 in the "gPROMS Advanced User Guide").

NOTE

Wherever an argument is described as "Unchanged" in the "On Exit" column, it is the responsibility of the FPI implementation developer to ensure that the FPI does not alter this argument in any way.

gPROMS does *not* check for any changes in arguments of this type on return from the FPI procedures.

gPROMS is built to use the long integer type available on a particular system. To make sure that your FPI implementation works with gPROMS, do not make use of any explicit declarations of integer variable length (e.g. INTEGER*4) in your FORTRAN code. It is recommended that you always use the default declaration for INTEGER type arguments to the FPI services and use compiler options to make the default integer equivalent to the long type.

If the FPI procedures are implemented in FORTRAN, then they should be compiled with appropriate compiler options so that the resulting symbols for them are in lowercase and have an underscore appended to them (e.q. gfplinearise_).

4.2.1 The gFPI procedure

Purpose: To initialise the communication link between the gPROMS PROCESS and the

foreign process.

Invoked: Automatically, at the start of the execution of any gPROMS PROCESS.

PROCEDURE DECLARATION

SUBROUTINE gFPI (FPID, FPHANDLE, PRNAME, STATUS)

CHARACTER * 256 FPID, PRNAME

INTEGER FPHANDLE INTEGER STATUS

Argument	Type	On Entry	On Exit
FPID	C*256	Full name of Foreign Process	Unchanged
		(terminated with a null)	
FPHANDLE	Ι	0	A unique integer assigned by
			the foreign process to identify
			its interactions with this par-
			ticular execution of this spe-
			cific gPROMS PROCESS
PRNAME	C*256	Name of executing gPROMS	Unchanged
		PROCESS which has initiated	
		this call	
STATUS	Ι	1	1 if interaction has been initi-
			ated successfully; 0 otherwise
NIOTED			

NOTES

• The gPROMS PROCESS will use *both* its own name (PRNAME) *and* the FPHANDLE assigned to it by the foreign process in all its subsequent communications with it (see sections 4.2.2–4.2.5).

The FPHANDLE identifier may be particularly useful for advanced applications involving interactions of multiple gPROMS PROCESSes with the same foreign process, when the latter may need to know which of the former it is talking to at any given time.

If such sophistication is not required, FPHANDLE may be left unchanged by the gFPI procedure.

• Setting the STATUS variable to 0 within gFPI will indicate to gPROMS the existence of a problem in its communication with the foreign process, and will cause the execution of the gPROMS PROCESS to be terminated immediately.

4.2.2 The gFPPAUSE procedure

Purpose:	To carr	ry out any PAUSE tasks in the s	imulation SCHEDULE, as detailed in		
	section 5.2.1 of the "gPROMS Advanced User Guide".				
Invoked:	Whene	Whenever a PAUSE elementary communication task is executed in a			
	SCHEDU	LE.			
		PROCEDURE DECLA	RATION		
	SUBROU	TINE gFPPAUSE (FPID, FPHANDI	LE, PRNAME,		
	+	SIGNAL, TIME,	STATUS)		
	CHARACT	ΓER * 256 FPID, PRNAME, SIGN	JAL		
	INTEGE	R FPHANDLE			
	DOUBLE	PRECISION TIME			
	INTEGE	R STATUS			
Argument	Type	On Entry	On Exit		
FPID	C*256	Full name of Foreign Process	Unchanged		
FPHANDLE	I	Identifier assigned to this	Unchanged		
		gPROMS PROCESS by foreign			
		process following call to gFPI			
		(see section 4.2.1)			
PRNAME	C*256	Name of executing gPROMS	Unchanged		
	PROCESS which has initiated				
		this call			
SIGNAL	C*256	SigName string specified for	Unchanged		
		current instance of PAUSE task			
		in SCHEDULE			
TIME	R*8	Current simulation time	Unchanged		
STATUS	I	1	1 if the task has been per-		
			formed successfully; 0 other-		
			wise		
		NOTES			
•	The decisi, if diff, that will be talled if the Differ tallable is set to U				
within this procedure will be determined by the user through the gPROMS					

gPROMS does not, by itself, initiate any action on such occasions.

4.2.3 The gFPGET procedure

Purpose: To carry out any GET tasks in the simulation SCHEDULE, as detailed in sec-

tion 5.2.2 of the "gPROMS Advanced User Guide".

Invoked: Whenever a GET elementary communication task is executed in a SCHEDULE.

PROCEDURE DECLARATION

O-- E--:4

SUBROUTINE gFPGET (FPID, FPHANDLE, PRNAME, SIGNAL,

+ TIME, N, NAME, ITYPE, X,

+ STATUS)

CHARACTER * 256 FPID, PRNAME, SIGNAL, NAME(N)

INTEGER FPHANDLE, N, ITYPE(N)
DOUBLE PRECISION TIME, X(N)

INTEGER STATUS

Argument	Type	On Entry	On Exit
FPID	C*256	Full name of Foreign Process	Unchanged
FPHANDLE	Ι	Identifier assigned to this	Unchanged
		gPROMS PROCESS by foreign	
		process following call to gFPI	
		(see section $4.2.1$)	
PRNAME	C*256	Name of executing gPROMS	Unchanged
		PROCESS which has initiated	
		this call	
SIGNAL	C*256	SigName string specified for	Unchanged
		current instance of GET task in	
		SCHEDULE	
TIME	R*8	Current simulation time	Unchanged
N	Ι	Number of variable values to	Unchanged
		be obtained from the foreign	
		process	
NAME	C*256	Names of variables to be ob-	Unchanged
		tained from the foreign process	
		as specified by their Foreign-	
		ProcessID in the GET task	
ITYPE	Ι	Type of variables to be ob-	Unchanged
		tained from the foreign pro-	
		cess: 1 for real; 2 for integer; 3	
		for logical	

Argument	Type	On Entry	On Exit		
X	R*8	Values of variables to be ob-	New values of these variables		
		tained from the foreign process			
		just before the execution of the			
		GET task			
STATUS	Ι	1	1 if the task has been per-		
			formed successfully; 0 other-		
			wise		
		NOTES			
•	_		by gPROMS to the equivalent real		
		_	real array X. Similarly, logical-valued		
			E and 0.0 for FALSE. gPROMS auto-		
	matically compensates for any rounding errors that may be introduced by				
	this convention.				
	The same convention should be followed by gFPGET for returning the new				
	values of these variables.				
•	• If the GET task is applied to entire gPROMS arrays or distributions or slices thereof, then N counts each element of the array etc. as a separate entry. The				
			2 2		
	name, type and value arrays NAME, ITYPE and X respectively, are dimensioned				
	and initialised accordingly, with all elements of the same array or distribution				
_	occupying consecutive positions in them.				
•	The action, if any, that will be taken if the STATUS variable is set to 0				
	within this procedure will be determined by the user through the gPROMS SCHEDULE.				
		MS does <i>not</i> , by itself, initiate ar	ny action on such occasions.		

4.2.4 The gFPSEND procedure

Purpose: To carry out any SEND tasks in the simulation SCHEDULE, as detailed in

section 5.2.3 of the "gPROMS Advanced User Guide".

Invoked: Whenever a SEND elementary communication task is executed in a SCHEDULE.

PROCEDURE DECLARATION

SUBROUTINE gFPSEND (FPID, FPHANDLE, PRNAME, SIGNAL,

+ TIME, N, NAME, ITYPE, X, STATUS)

CHARACTER * 256 FPID, PRNAME, SIGNAL, NAME(N)

INTEGER FPHANDLE, N, ITYPE(N)
DOUBLE PRECISION TIME, X(N)

INTEGER STATUS

Argument	Type	On Entry	On Exit
FPID	C*256	Full name of Foreign Process	Unchanged
FPHANDLE	Ι	Identifier assigned to this	Unchanged
		gPROMS PROCESS by foreign	
		process following call to gFPI	
		(see section 4.2.1)	
PRNAME	C*256	Name of executing gPROMS	Unchanged
		PROCESS which had initiated	
		this call	
SIGNAL	C*256	SigName string specified for	Unchanged
		current instance of SEND task	
	D.VO	in SCHEDULE	
TIME	R*8	Current simulation time	Unchanged
N	I	Number of variable values to	Unchanged
NI A MED	C*050	be sent to the foreign process	TT 1 . 1
NAME	C*256	Names of variables being	Unchanged
		transmitted to the foreign process as specified by their	
		ForeignProcessID in the SEND	
		task	
ITYPE	I	Type of variables being trans-	Unchanged
11112	1	mitted to the foreign process:	ononangoa
		1 for real; 2 for integer; 3 for	
		logical	
X	R*8	Current values of variables be-	Unchanged
		ing transmitted to the foreign	
		process	
STATUS	I	1	1 if the task has been per-
			formed successfully; 0 other-
			wise

NOTES

- Integer-valued local TASK variables are converted by gPROMS to the equivalent real for communication to gFPSEND via the real array X. Similarly, logical-valued variables are encoded as +1.0 for TRUE and 0.0 for FALSE.
- If the SEND task is applied to entire gPROMS arrays or distributions or slices thereof (see section 11.2.3 of the "gPROMS Introductory User Guide"), then N counts each element of the array etc. as a separate entry. The name, type and value arrays NAME, ITYPE and X respectively, are dimensioned and initialised accordingly, with all elements of the same array or distribution occupying consecutive positions in them.
- The action, if any, that will be taken if the STATUS variable is set to 0 within this procedure will be determined by the user through the gPROMS SCHEDULE.
 - gPROMS does not, by itself, initiate any action on such occasions.

4.2.5 The gFPSENDM procedure

Purpose:	To carr	v out any SENDMATHINFO tasks in t	the simulation SCHEDULE, as detailed	
1 di pose.		in section 5.2.4 of the "gPROMS Introductory User Guide".		
Invoked:	Whenever a SENDMATHINFO elementary communication task is executed in a			
	SCHEDULE.			
	DOILEDO	PROCEDURE DECLA	RATION	
	SUBBOU	TINE gFPSENDM (FPID, FPHANDI		
	+	NV, NE, ND, N		
	+	X, XDOT, ITYF		
	+	IROW, ICOL, J		
	+	STATUS)		
	CHARACT	ΓER * 256 FPID, PRNAME, SIGN	IAI. NAME(N)	
		R FPHANDLE, NV, NE, ND, NZ,	·	
	+	IROW(NZ), ICOL(NZ)		
		PRECISION TIME, X(NV), XDOT	C(NV), JACELM(NZ)	
		R STATUS		
Argument	Type	On Entry	On Exit	
FPID	C*256	Full name of Foreign Process	Unchanged	
FPHANDLE	Ι	Identifier assigned to this	Unchanged	
		gPROMS PROCESS by foreign		
		process following call to gFPI		
		(see section $4.2.1$).		
PRNAME	C*256	Name of executing gPROMS	Unchanged	
		PROCESS which has initiated		
		this call		
SIGNAL	C*256	SigName string speci-	Unchanged	
		fied for current instance		
		of SENDMATHINFO task in		
		SCHEDULE		
TIME	R*8	Current simulation time	Unchanged	
NV	Ι	Total number of variables in	Unchanged	
		the mathematical model		
NE	Ι	Total number of equations in	Unchanged	
		the mathematical model		
ND	Ι	Number of differential vari-	Unchanged	
		ables in the mathematical		
		model		
NZ	Ι	Number of nonzero Jacobian	Unchanged	
		elements in the mathematical		
		model		

Argument	Type	On Entry	On Exit		
X	R*8	Current values of all variables	Unchanged		
		in the mathematical model			
XDOT	R*8	Current values of time deriva-	Unchanged		
		tives of variables in the math-			
		ematical model			
ITYPE	Ι	Current type of variables in	Unchanged		
		the mathematical model: 0 for			
		input; 1 for algebraic; 2 for dif-			
		ferential variable			
NAME	C*256	Complete gPROMS path-	Unchanged		
		names for variables in the			
		mathematical model			
IROW	Ι	Row numbers of elements in	Unchanged		
		current Jacobian matrix			
ICOL	Ι	Column numbers of elements	Unchanged		
		in current Jacobian matrix			
JACELM	R*8	Current numerical values of	Unchanged		
		elements in current Jacobian			
	_	matrix			
STATUS	Ι	1	1 if the task has been per-		
			formed successfully; 0 other-		
		NOTES	wise		
	The arr		on for <i>all</i> the variables in the model		
			input, algebraic or differential vari-		
	ables.	regard to their classification as	input, argeorate of differential vari-		
		ormation necessary for making t	his classification is contained solely		
	in ITYP				
•			ly the entries corresponding to dif-		
		l variables contain meaningful va			
•			aformation on the partial derivatives		
	_	equations with respect to all of the	_		
	An entr	ry $ICOL(k) = +j$, where j is a	positive integer, indicates a partial		
	derivative with respect to variable $X(j)$.				
	An entr	ry $ICOL(k) = -j$, where j is a j	positive integer, indicates a partial		
	derivati	ve with respect to variable XDOT	(j).		
•	The ac	tion, if any, that will be taken	if the STATUS variable is set to 0		
	within	this procedure will be determined	d by the user through the gPROMS		
	SCHEDULE.				
gPROMS does <i>not</i> , by itself, initiate any action on such occasions.					

4.2.6 The gFPLINEARISE procedure

Purpose:	To carr	ry out any LINEARISE task in t	the simulation, as detailed in sec-
	tion 5.2	.5 of the "Advanced User Guide"	,
Invoked:	Whenev	ver a LINEARISE elementary cor	nmunication task is executed in a
	SCHEDU		
		PROCEDURE DECLA	RATION
	SUBROUT	INE gFPLINEARISE (FPID, FPHA	NDLE, PRNAME, SIGNAL, TIME
	+	NU, UINDICES,	UNAMES,
	+	NY, YINDICES,	YNAMES
	+	NX, XINDICES,	XNAMES,
	+	A, B, C, D,	
	+	STATUS)	
		ER * 256 FPID, PRNAME	
		ER * 256 UNAMES(NU), YNAMES(-
		FPHANDLE, NU, NY, NX, STATU	
		UINDICES(NU), YINDICES(NY),	XINDICES(NX)
		PRECISION TIME	
			NU), C(NY * NX), D(NY * NU)
Argument	Type C*256	On Entry	On Exit
FPID	C*256	Full name of Foreign Process	Unchanged
EDIIANDI E	т	(terminated with a null)	II
FPHANDLE	I	Identifier assigned to this	Unchanged
		gPROMS PROCESS by foreign process following call to gFPI	
		(see section 4.2.1)	
PRNAME	C*256	Name of executing gPROMS	Unchanged
TIMANE	250	PROCESS which has initiated	Chenanged
		this call	
SIGNAL	C*256	SigalName string speci-	Unchanged
2 2 311111	200	fied for current instance of	
		the LINEARISE task in the	
		SCHEDULE	
TIME	R*8	Current simulation time	Unchanged

Argument	Type	On Entry	On Exit
NU	Ι	Number of input variables	Unchanged
		specified in the LINEARISE	
		task. Any input variables that	
		are not independent (cf. Case	
		6) will be removed, so in this	
		case, this argument will give	
		the number of independent in-	
		put variables.	
UINDICES	I	Indices of input variables in	Unchanged
		the global variable array. Any	
		input variables that are not	
		independent (cf. Case 6) will	
		be removed, so in this case,	
		this argument will give the	
		indices of independent input	
		variables.	
UNAMES	C*256	Names (tag names) of input	Unchanged
		variables. Any input variables	
		that are not independent (cf.	
		Case 6) will be removed, so in	
		this case, this argument will	
		give the names of independent	
	_	input variables.	
NY	Ι	Number of output variables	Unchanged
		specified in the LINEARISE	
	_	task.	** 1
YINDICES	I	Indices of output variables in	Unchanged
	C to to	the global variable array.	TT 1 1
YNAMES	C*256	Names (tag names) of output	Unchanged
	т	variables.	TT 1 1
NX	Ι	Number of the minimal subset	Unchanged
VINDIADA	т	of state variables.	
XINDICES	I	Indices of state variables in the	Unchanged
VIIAMEG	C*orc	global variable array.	TT1
XNAMES	C*256	Names of state variables.	Unchanged

Argument	Type	On Entry	On Exit
A	R*8	Matrix A in equation $(5.7)^1$	Unchanged
		$(NX \times NX \text{ elements, sorted by})$	
		rows).	
В	R*8	Matrix B in equation (5.7)	Unchanged
		$(NX \times NU \text{ elements, sorted by})$	
		rows).	
C	R*8	Matrix C in equation (5.7)	Unchanged
		$(NY \times NX \text{ elements, sorted by})$	
		rows).	
D	R*8	Matrix D in equation (5.7)	Unchanged
		$(NY \times NU \text{ elements, sorted by})$	
		rows).	
STATUS	I	Flag indicating success/failure	1: successful execution;
		of the LINEARISE task	
			0: non-existent Jacobian ele-
			ment;
			-1: structurally singular DAE
			system;
			-2: failure of linear system
			solver.
		NOTES	

- The action, if any, that will be taken if the STATUS variable is not equal to 1 within this procedure will be determined by the user through the gPROMS SCHEDULE.
 - gPROMS does not, by itself, initiate any action on such occasions.

4.2.7 The gFPT procedure

Purpose: To terminate the communication link between the gPROMS PROCESS and

the foreign process.

Invoked: Automatically, at the end of the execution of any gPROMS PROCESS.

PROCED	\mathbf{URE}	DECLA	$\mathbf{AR}A$	TI	ON	ſ
--------	----------------	-------	----------------	----	----	---

SUBROUTINE gFPT (FPID, FPHANDLE, PRNAME, STATUS)

CHARACTER * 256 FPID, PRNAME

INTEGER FPHANDLE INTEGER STATUS

Argument	Type	On Entry	On Exit
FPID	C*256	Full name of Foreign Process	Unchanged
		(terminated with a null)	
FPHANDLE	Ι	Identifier assigned to this	Unchanged
		gPROMS PROCESS by foreign	
		process following call to gFPI	
		(see section $4.2.1$)	
PRNAME	C*256	Name of executing gPROMS	Unchanged
		PROCESS which has initiated	
		this call	
STATUS	Ι	1	1 if interaction has been termi-
			nated successfully; 0 otherwise

NOTES

- This procedure may be used for tidying up (closing files etc.) and terminating the interaction in an orderly fashion.
- Setting the STATUS variable to 0 within gFPT has no effect on the execution of the gPROMS PROCESS since the latter is terminating at this point anyway.

4.3 FPI implementation for real-time applications

In many FPI applications (e.g. model-based control), it is essential for the gPROMS simulation to keep up with real time. We have already considered the factors that may slow down the simulation. If this takes place to the extent that the simulation is slower than the real plant, clearly we need to address the performance issues (see section 5.4 of the "gPROMS Advanced User Guide").

On the other hand, the simulation will usually be faster than the real plant. In this case, we must continually compare the current simulation time with the real time, and make the simulation wait for an appropriate period if necessary.

The synchronisation can be done by a gPROMS TASK that is being executed in parallel to the main simulation SCHEDULE. This can be of the form:

```
TASK Synchronise
  PARAMETER
    SynchronisationInterval
                                   REAL
  VARIABLE
    StatVar
                                   LOGICAL
  SCHEDULE
    SEQUENCE
      StatVar := TRUE ;
      WHILE StatVar DO
        SEQUENCE
          CONTINUE FOR SynchronisationInterval
          PAUSE SIGNALID "SynchronisationSignal"
                STATUS StatVar
        END
      END
    END
END
```

The invocation of this TASK from the main SCHEDULE of the simulation specifies a synchronisation interval and a given termination condition. The main WHILE loop in this TASK consists of two steps: first, we allow the simulation to proceed for the SynchronisationInterval. We then issue a PAUSE request to the FPI, identifying this as a SynchronisationSignal. The gFPPAUSE procedure will have to intercept this, calculate the necessary waiting time, and act accordingly²:

²Here we are assuming the availability of two routines: TIMER returning the elapsed real time since the start of the simulation, and SLEEP that causes the calling program to wait for a specified period.

```
SUBROUTINE gFPPAUSE (FPID, FPHANDLE, PRNAME,
                           SIGNAL, TIME, STATUS)
      CHARACTER * 256 FPID, PRNAME, SIGNAL
                       FPHANDLE
      INTEGER
      DOUBLE PRECISION TIME
      INTEGER
                       STATUS
C
C.....Check if this is a synchronisation request
      IF (INDEX (SIGNAL, 'SynchronisationSignal') .GT. 0) THEN
C
C......Get real (elapsed) time since start of simulation
        CALL TIMER (RTIME)
C
C......Get time lag between simulation and real time
        TIMELG = TIME - RTIME
C......If necessary, make this procedure wait
         IF (TIMELG .GT. 0.0) THEN
            CALL SLEEP ( TIMELG )
         ELSE IF (TIMELG .LT. 0.0) THEN
            PRINT *,' Simulation falling behind real time...'
            STATUS = 0
        ENDIF
C
      ELSE
C
C.....Other types of PAUSE request...
      ENDIF
C
      RETURN
      END
```

In some applications (e.g. operator training), we may actually wish to run the simulation at a constant factor (greater or smaller than 1) of real time. In such cases, we introduce a real quantity FACTOR and modify the line:

```
TIMELG = TIME - RTIME
```

in the gFPPAUSE procedure to:

```
TIMELG = TIME/FACTOR - RTIME
```

For instance, if FACTOR = 2.0, the above will make the simulation run twice as fast

as real time—assuming, of course, that this is achievable with the given model and hardware.

4.4 Implementation of Foreign Processes

This section deals with some of the details of the implementation of Foreign Processes and the precise ways in which this can be compiled and linked to gPROMS.

4.4.1 Writing Foreign Processes in FORTRAN and C

As mentioned in section 4.2, any Foreign Process implementation has to provide five communication procedures and two procedures for initialisation and termination of Foreign Processes.

In order to demonstrate the implementation of these procedures, examples are provided for both FORTRAN and C, cf. fpi_demo_c.c and fpi_demo_f.f³. The various routines simply print out messages to the screen. gFPGET and gFPPAUSE also expect to read some input from the terminal. The example code is accompanied by a gPROMS input file, fpi.gPROMS⁴.

The C version also relies on the header files gFPInterface.h and gTypes.h which:

- provide prototype definitions for the six Foreign Process Interface routines,
- define a macro which ensures that the function prototypes are exported when compiling for Windows and
- define their own versions of the basic types for ease of portability.

It is strongly recommended that you do not change the prototypes and type definitions because they ensure that the function calls follow the conventions gPROMS uses internally.

4.4.2 Writing Foreign Processes in C++

Although using C or FORTRAN as the implementation language should be sufficient for many applications, C++ may be more appropriate in more advanced cases, e.g. if you wish to connect multiple gPROMS PROCESSes to one Foreign Process. In this case, the reasons outlined in section 2.3.1 for choosing C++ apply here as well.

³All the provided example code can be found in the src/examples/fpi subdirectory of the gPROMS installation directory.

⁴fpi.gPROMS is located in the examples/gPROMS subdirectory of the gPROMS installation directory.

The ideas outlined in this section are structurally similar to the section concerning Foreign Objects, cf. section 2.3.3.

The basic idea for handling multiple gPROMS PROCESSes connecting to one FPI is to define one class whose instances will be parameterised according to the gPROMS PROCESS they represent or to define different classes and instantiate accordingly. The responsibilities then are divided into:

- the interface to gPROMS,
- managing the multiple instances, comprising the task of creating, destroying and accessing them, and finally
- the objects representing the different gPROMS processes.

Furthermore, the provided classes and interfaces are designed such that the user can use them as a library without having to bother with the low-level interface to gPROMS and the list of gPROMSprocesses.

In the above list, the second group of responsibilities is dealt with by a single object, a so-called Factory. On request, this Factory will create and destroy Foreign Processes⁵. Internally it keeps track of all the Foreign Processes. Actually, the Factory is designed to be the only interface through which Foreign Processes can be created and accessed; the key for retrieving them is the ForeignProcessHandle which was given to the Foreign Process upon creation.

Since the Factory manages all the Foreign Processes, there should exist only one instance of the Factory class. This is ensured by a Singleton function, get_FPFactory(). This function (and only this function) provides access to the Factory, which is ensured by keeping constructors and destructors of the Factory class private.

The interface functions are necessary because gPROMS expects the service procedures to be provided as functions. From the interface functions, then, member functions of the class implementation are called. For example, if you have implemented a class MyForeignProcess, a gPROMS call to gFOM() will actually be translated in a call to MyForeignObject::Evalmethod(). However, before this call actually takes place, the interface function first asks the Factory to retrieve the Foreign Process which is identified by the handle.

The interface functions can be found in the file gFPInterface.cxx and need not be changed if it is not intended to change the underlying structure of the C++ interface.

Two additional classes are provided, gFPClass and gFPFactory, both of which are purely abstract classes, which means you cannot instantiate them directly. Instead, their purpose is to provide the basic functionality (or interface) which has to be implemented

⁵For brevity, the plural is used at this place. Remember, however, that gPROMS currently allows only one FPI, in contrast to multiple FO's. Nevertheless, it is possible to use multiple objects with different responsibilities within one FPI.

in the Foreign Process. When defining and implementing a Foreign Process, the user should derive his own classes from these two classes and define the virtual functions of the abstract base classes. In this context, gFPClass is the base class for the Foreign Process, whereas gFPFactory is the base class for a user-provided Factory.

When deriving from gFPClass, the only member functions which have to be provided by the user are the equivalents for the service procedures shown in table 4.1.

Communication procedure	C++ equivalent
gFPPAUSE()	Pause()
gFPGET()	Get()
gFPSEND()	Send()
gFSENDM()	SendM()
gFPLINEARISE()	Linearise()

Table 4.1: Service procedure and their C++ equivalent

Note that the argument lists of the member functions in table 4.1 are identical to their corresponding routines in gFPInterface.h except that they are missing the first arguments of the latter identifying the calling gPROMS process and thus the specific instance since these routines operate on the specific object with which they are associated.

Example implementations for these member functions can be found in gFPClass_demo.h resp. gFPClass_demo.cxx. gFPI() and gFPT() do not have to be defined because they call member functions which are already implemented in gFPFactory and which are responsible for creating and destroying Foreign Processes.

When deriving a Factory from the provided gFPFactory, the only member function which has to be provided by the user is CreateObject() plus a global function which will provide access to the factory, get_FPfactory(), cf. the files gFPFactory_demo.h and gFPFactory_demo.cxx.

If the proposed structure is adopted, none of the interface files has to be changed, only classes with the member functions as in the tank example have to be provided by the user.

4.4.3 Compiling Foreign Processes

gPROMS employs a dynamic loading mechanism that allows it to load users' FPI code into the gPROMS address space at run-time. To make dynamic loading possible, users' FPI implementations must be implemented as dynamic shared object libraries on UNIX systems, or as dynamic link libraries on MS Windows systems. Appendix A details how these libraries can be created for the currently supported UNIX platforms, while appendix B provides the equivalent information for Windows.

At the start of a simulation, if there is any communication task in the process schedule,

gPROMS will try to open the specified FPI shared object library and attach the library to the running gPROMS address space. If the specified file cannot be opened as a shared object library or the FPI function symbols gfpi_, gfppause_, gfpget_, gfpsend_, gfpsendm_, gfplinearise_and gfpt_cannot be found in the shared library, appropriate error messages will be given and the simulation will be terminated.

The shared library will be detached from the gPROMS process at the end of a simulation.

4.4.4 Installing Foreign Processes

Once the Foreign Process code has been written and compiled as explained in sections 4.4.1 to section 4.4.3, the resulting dynamic library has to be installed in a place where gPROMS can find it during runtime. There are two main options for this:

- In a sub-directory called fpi of the user's current gPROMS working directory.
 This sub-directory is at the same level as the input, output and save sub-directories.
- In a sub-directory called fpi of the gPROMS system installation directory.

Clearly, the first option is appropriate only for Foreign Processes that are used by a small number of users, otherwise it may lead to unnecessary waste of disk space; it may also make the maintenance of the Foreign Process code very difficult to manage. The second optino make the Foreign Processes accessible to all gPROMS users but will usually require system administrator priviledges.

On UNIX platforms, a third option is for individual users to place a symbolic link to the actual Foreign Process library inside their private fp sub-directory. The actual code may, thus, reside anywhere in the system where it is accessible to the group of users who need it. This has the advantage of saving disk space without requiring system administrator privileges.

Chapter 5

The gPROMS Output Channel Interface

Contents

5.1	Intro	oduction	81
5.2	Usin	g Output Channels in gPROMS	81
5.3	The	gPROMS Output Channel Interface	84
	5.3.1	The initialisation procedure	85
	5.3.2	The register distribution domain procedure	86
	5.3.3	The register variable procedure	89
	5.3.4	The finish initialisation procedure	90
	5.3.5	The time reporting procedure	91
	5.3.6	The variable values reporting procedure	92
	5.3.7	The reset results procedure	93
	5.3.8	The termination procedure	94
5.4	Imp	lementation of Output Channels	95
	5.4.1	Writing Output Channels in FORTRAN and C \hdots	95
	5.4.2	Compiling Output Channels	95
	5.4.3	Installing Output Channels	96

5.1 Introduction

A gPROMS Output Channel is an external software component used by gPROMS to manipulate results generated by the execution of gPROMS simulations.

The Output Channel Interface (OCI) is a published protocol that gPROMS uses for communicating its simulation results to other software. With this open interface, it is possible for gPROMS users to develop their own Output Channel component software which will have access to a rich amount of information on the simulation results generated by gPROMS.

5.2 Using Output Channels in gPROMS

Three standard Output Channel components are distributed with gPROMS. These are dynamic shared libraries implementing the Output Channel Interface. The first is gRMS, which is a general result management system that allows the user to display simulation results quickly in the form of 2D and 3D graphs. gRMS is described in detail in appendix B of the "gPROMS Introductory User Guide". The second is gPLOT, which outputs simulation results to a text file. gPLOT is described in appendix D of the "gPROMS Introductory User Guide". The third standard Output Channel, called gExcelOutput, is based on the Microsoft Excel 97, making use of the facilities it provides for the storage and display of results. Currently the gExcelOutput Output Channel is only available on Microsoft Windows operating systems. The gExcelOutput is described in detail in appendix C of the "gPROMS Introductory User Guide".

In addition to the three standard Output Channels, it is also possible for users to provide and use their own results handling option. This can be done by developing a dynamic shared library that implements the OCI.

A gPROMS PROCESS may use the four results handling options either separately or in any combination. The desired option may be switched on by specifying the appropriate parameters in the SOLUTIONPARAMETERS section. An example of the syntax used for this purpose is shown below:

```
SOLUTIONPARAMETERS

gRMS := ON

cPLOT := OFF
```

gPLOT := OFF ;
gExcelOutput := ON ;
gUserOutput := ON ;

Each option may be activated or deactivated by specifying the ON and OFF switches respectively. By default the gRMS Output Channel is switched ON on and all other channels are switched OFF.

If an Output Channel is switched ON, then the set of results generated by the execution of a PROCESS will, by default, be identified by the name of that PROCESS. On the other hand, the user also has the option of specifying a different name by which the results of the PROCESS simulation will be identified. An example of such a specification is shown below:

```
# process entity "Simulate1"
...
SOLUTIONPARAMETERS
  gRMS := "StartUpSimulation";
  gPLOT := ON ;
SCHEDULE
```

Here the results will be stored in a gRMS archive called StartUpSimulation.gRMS and a gPLOT ASCII file called TEST.gPLOT. In all cases, specifying a results name against an Output Channel in SOLUTIONPARAMETERS automatically switches this channel ON.

The specified Output Channel components will be searched by gPROMS at the start of PROCESS execution in the following order:

- in a sub-directory called oc of the user's current gPROMS working directory. This sub-directory is at the same level as the input, output and save sub-directories.
- in a sub-directory called oc of the gPROMS system installation directory (specified by the GPROMSHOME environment variable).

The three pre-built Output Channel components have fixed class names corresponding to the channel options. The dynamic shared libraries for the three standard channels (gRMS.so and gPLOT.so for Unix systems, gExcelOutput.DLL and gPLOT.DLL for Windows NT) are normally installed in the oc sub-directory of the gPROMS system installation directory. The user-developed component is usually placed in the user's own gPROMS oc sub-directory. Installing it in the gPROMS system directory will usually require system administrator's privileges.

The default class name for the user-provided Output Channel component is <code>gUserOutput.Thus gPROMS</code> will search for a dynamic shared library called <code>gUserOutput.so</code> (for Unix systems) or <code>gUserOutput.DLL</code> (for Windows NT). However, the default class name can be overridden by specifying it before the results identification name, with the two being separated by two consecutive colons. Thus, the specification:

```
SOLUTIONPARAMETERS
    gUserOutput := "WonderPlotter::StartUpSimulation";
```

will cause gPROMS to search for an Output Channel component in a dynamic shared library called WonderPlotter.so (for Unix systems), or WonderPlotter.DLL (for Windows NT) and, assuming it loads it successfully, to communicate with it a set of results to be identified as StartUpSimulation.

5.3 The gPROMS Output Channel Interface

This section describes the Output Channel Interface (OCI), *i.e.* the protocol used for communication between gPROMS and any Output Channel component that provides results manipulation via one or more callable procedures. The information presented here will typically be of interest to gPROMS system programmers concerned with writing an Output Channel component to provide special results manipulation to a group of gPROMS users.

An Output Channel component is implemented as a dynamic shared library which exposes its implementations of the following eight procedures: gOCI, gOCRDD, gOCRV, gOCFIN, gOCTIME, gOCVALUE, gOCRESET and gOCT.

The rest of this section provides a detailed specification of these eight procedures. The programming interface is illustrated using FORTRAN subroutine terminology; however, the Output Channel component can be implemented in any other programming language.

NOTE

Wherever an argument is described as "NO" in the "Specified On Exit" column, it is the responsibility of the Output Channel developer to ensure that the OCI does not alter this argument in any way.

gPROMS does *not* check for any changes in arguments of this type on return from the OCI procedures.

gPROMS is built to use the long integer type available on a particular system. To make sure that your OCI implementation works with gPROMS, do not make use of any explicit declarations of integer variable length (e.g. INTEGER*4) in your FORTRAN code. It is recommended that you always use the default declaration for INTEGER type arguments to the OCI services and use compiler options to make the default integer equivalent to the long type.

The OCI FORTRAN procedures should be compiled with appropriate compiler options so the resulting symbols for them are in lowercase and have an underscore appended to them (e.g. goci_).

5.3.1 The initialisation procedure

At the start of the execution of a PROCESS entity, gPROMS will try to create instances for all the Output Channels which are switched ON in the SOLUTIONPARAMETERS section of the process. Upon successful loading of the dynamic shared library corresponding to the Output Channel, gPROMS will request a proper initialisation for the channel by calling the gOCI procedure defined in the dynamic shared library.

The goci procedure has the following form:

gOCI(OutputChannelID, OutputChannelHandle, Status)

where the arguments are as described in table 5.1.

Type	Description	Specified on Entry	Specified on Exit
Character*256	Full name of Output Channel (terminated with a null).	YES	NO
Integer	Handle for identifying Output	NO	YES
Integer	Status of this initialisation. Status = 1 implies successful initialisation. All other values	NO	YES
	Character*256 Integer	Character*256 Full name of Output Channel (terminated with a null). Integer Handle for identifying Output Channel in subsequent calls. Integer Status of this initialisation. Status = 1 implies successful	Character*256 Full name of Output Channel (terminated with a null). Integer Handle for identifying Output (Channel in subsequent calls. Integer Status of this initialisation. Status = 1 implies successful initialisation. All other values

Table 5.1: Arguments of the procedure gOCI.

OutputChannelID is a string identifying the instance of the Output Channel class. The class name is separated from the instance by two consecutive colons.

OutputChannelHandle is an integer handle returned to gPROMS by the Output Channel for future references. gPROMS will *not* attempt any interpretation or make any direct use of this handle. However, it will pass it to all subsequent calls for services relating to this particular Output Channel instance.

The Status argument must be set by the Output Channel to indicate success or failure of its initialisation. If the initialisation fails (Status different from 1), the execution of the gPROMS PROCESS will be terminated immediately. In this case, the Output Channel is responsible for the freeing of resources it has already utilised up to the point of failure.

5.3.2 The register distribution domain procedure

If the initialisation of the Output Channel is successful, gPROMS will then attempt to register with the Output Channel all the distribution domains over which monitored variables are distributed, and integer parameters and constants which are used to declare arrays of variables by making calls to the gOCRDD procedure.

gPROMS variables may be dependent on a number of domains. These are:

- time,
- spatial domains,
- discrete domains.

All variables are considered to be dependent on the time domain, even for steady-state models. Spatial domains are continuous domains and are used when models contain partial differential equations. Discrete domains are created when variables are declared as arrays. For example, to decribe the behavour of a fluid as it flows through a pipe, the variables would be distributed over a continuous domain (the axial position in the pipe). If the fluid contains more than one chemical species, then these would be distributed over a discrete domain and some of the variables describing the fluid properties would be distributed over both the axial continuous domain and the discrete domain of the chemical component. ARRAYs and DISTRIBUTION_DOMAINs are described in detail in chapters 3 and 5 respectively of the "gPROMS Introductory User Guide".

The gocrdD procedure has the following form:

gOCRDD(OutputChannelID, OutputChannelHandle,
DistributionDomainName, DistributionDomainIndex, NoPoints,
PointList, DiscretisationMethod, DiscretisationMethodOrder,
DiscretisationNoElements, DiscretisationElementLength, Status)

where the arguments are described in table 5.2.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output Channel in subsequent calls.	YES	NO
DistributionDomainName	Character*256	Fully qualified name of the distribution domain (termi-	YES	NO
DistributionDomainIndex	Integer	nated with a null). Integer that will be used to identify this distribution domain in calls to gocrv (see	YES	NO
NoPoints	Integer	section 5.3.3). The number of discretisation points in the distribution domain.	YES	NO
PointList	Double Precision	Array of length NoPoints containing the position of each discretisation point.	YES	NO

Table continued on next page ...

continued from previous page				
DiscretisationMethod	Character*10	An identifier specifying the method used by gPROMS for discretising this distribution domain [currently valid values: BFDM, CFDM, FFDM, OCFEM, GaussQ, DISCRETE] (terminated with a null).	YES	NO
DiscretisationMethodOrder	Integer	The order of the discretisation method used by gPROMS for discretising this distribution domain.	YES	NO
DiscretisationNoElements	Integer	The number of elements used by gPROMS for discretising this distribution domain.	YES	NO
DiscretisationElementLength	Double Precision	Array of length DiscretisationNoElements containing the length of the elements used by gPROMS for discretising this distribution domain.	YES	NO
Status	Integer	Completion status of this service request. Status = 1 implies successful distribution domain registration. All other values signify failure.	NO	YES

Table 5.2: Arguments of the procedure gOCRDD.

Note that ARRAYs of variables are also treated as being distributed with the discretisation method set to <code>DISCRETE</code>. gPROMS automatically generates a unique name for each such <code>DISCRETE</code> domain.

5.3.3 The register variable procedure

After all the relevant distribution domains and parameters have been successfully registered with the Output Channel, gPROMS will then register all monitored variables with the Output Channel by making calls to the gOCRV procedure.

The gocrav procedure has the following form:

where the arguments are described in table 5.3.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output Channel in subsequent calls.	YES	NO
VariableName	Character*256	Fully qualified name of the variable (terminated with a null).	YES	NO
VariableIndex	Integer	Integer that will be used to identify this variable in calls to gOCVALUE (see section 5.3.6).	YES	NO
NoDomains	Integer	The number of domains over which the variable is distributed	YES	NO
DomainList	Integer	Array of length NoDomains identifying which domains the variable is distributed over.	YES	NO
Status	Integer	Completion status of this service request. Status = 1 implies successful variable registration. All other values signify failure.	NO	YES

Table 5.3: Arguments of the procedure gOCRV.

5.3.4 The finish initialisation procedure

After the successful initialisation and registration of all relevant distribution domains and monitored variables, gPROMS notifies the Output Channel of the completion of this initial process. This is achieved by calling the gOCFIN procedure. At this point, the Output Channel can adjust the resources used for storing all the information received, and use the information about distribution domains and variables for displaying or printing the variable names.

The gocfin procedure has the following form:

gOCFIN(OutputChannelID, OutputChannelHandle, Status)

where the arguments are described in table 5.4.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output Channel in subsequent calls.	YES	NO
Status	Integer	Completion status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 5.4: Arguments of the procedure gOCFIN.

5.3.5 The time reporting procedure

At every reporting interval during the simulation, the integration time is sent to the Output Channel by calling the gOCTIME procedure.

The goctime procedure has the following form:

gOCTIME(OutputChannelID, OutputChannelHandle, Time, Status)

where the arguments are described in table 5.5.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output Channel in subsequent calls.	YES	NO
Time	Double Precision	The current reporting time interval.	YES	NO
Status	Integer	Completion status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 5.5: Arguments of the procedure gOCTIME.

5.3.6 The variable values reporting procedure

After the reporting time is sent, gPROMS will send the current values of every monitored variable by making calls to the gOCVALUE procedure.

The gocvalue procedure has the following form:

where the arguments are described in table 5.6.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output Channel in subsequent calls.	YES	NO
VariableIndex	Integer	Integer identifying the variable that these values are for.	YES	NO
NoValues	Integer	The number of values for the variable at this time. This should always be the product of the numbers of points in each domain over which the variable is distributed (excluding time).	YES	NO
ValueList	Double Precision	Array of length NoValues containing the values for the variable at this time. The array is stored in an order that makes the rightmost index vary fastest (i.e. a[0][0][0],	YES	NO
Status	Integer	a[0][0][1], a[0][1][0],). Completion status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 5.6: Arguments of the procedure gOCVALUE.

5.3.7 The reset results procedure

To support the RESETRESULTS elementary task (see section 7.3.3 of the "gPROMS Introductory User Guide"), the Output Channel should define the gOCRESET procedure to do whatever is appropriate. The Output Channel implementations provided as standard within gPROMS use this procedure to remove all the times and variable values stored for those times but maintain the registered distribution domains and variables.

The gocreset procedure has the following form:

gOCRESET(OutputChannelID, OutputChannelHandle, Status)

where the arguments are described in table 5.7.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output Channel in subsequent calls.	YES	NO
Status	Integer	Completion status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 5.7: Arguments of the procedure gocreset.

5.3.8 The termination procedure

At the end of PROCESS execution, gPROMS will close all Output Channels that are currently active by calling their gOCT procedures. This is intended to provide the Output Channels with an opportunity to do any necessary housekeeping.

The goot procedure has the following form:

gOCT(OutputChannelID, OutputChannelHandle, Status)

where the arguments are described in table 5.8.

Name of Argument	Type	Description	Specified on Entry	Specified on Exit
OutputChannelID	Character*256	Full name of Output Channel (terminated with a null).	YES	NO
OutputChannelHandle	Integer	Handle for identifying Output	YES	NO
Status	Integer	Channel in subsequent calls. Completion status of this service request. Status = 1 implies successful completion of this service. All other values signify failure.	NO	YES

Table 5.8: Arguments of the procedure gOCT.

5.4 Implementation of Output Channels

This section deals with some of the details of the implementation of Output Channels and the precise ways in which this can be compiled and linked to gPROMS.

5.4.1 Writing Output Channels in FORTRAN and C

As described in section 5.3, any Output Channel implementation has to provide six communication procedures and two procedures for initialisation and termination respecively. For convenience, skeleton files are provided for both FORTRAN and C. The skeletons only contain the calling frame for the procedures. The name of these files are oci.c and oci.f. The C version also relies on the header files goCInterface.h and gTypes.h which

- provide prototype definitions for the eight Output Channel Interface routines,
- define a macro which ensures that the function prototypes are exported when compiling for Windows, and
- define own versions of the basic types for ease of portability.

Please note: It is strongly recommended that you do not change the prototypes and type definitions because they ensure that the function calls follow the conventions gPROMS uses internally.

5.4.2 Compiling Output Channels

gPROMS employs a *dynamic loading* mechanism that allows it to load users' OCI code into the gPROMS address space at run-time. To make dynamic loading possible, users' OCI implementations must be implemented as dynamic shared object libraries on UNIX systems, or as dynamic link libraries on Windows systems. Appendix A details how these libraries can be created for the currently supported UNIX platforms, while appendix B provides the equivalent information for Windows.

At the start of a simulation, if there is any communication task in the process schedule, gPROMS will try to open the specified OCI shared object library and attach the library to the running gPROMS address space. If the specified file cannot be opened as a shared object library or the eight OCI function symbols goci_, gocrdd_, gocrv_, gocfin_, goctime_, gocvalue_, gocreset_ and goct_ cannot be found in the shared library, appropriate error messages will be given and the simulation will be terminated.

The shared library will be detached from the gPROMS process at the end of a simulation.

5.4.3 Installing Output Channels

Once the code describing the Output Channel has been written and compiled as explained in section 5.4.1 and section 5.4.2, the resulting dynamic library has to be installed in a place where gPROMS can find it during runtime. There are two main options for this:

- In a sub-directory called oc of the user's current gPROMS working directory.
 This sub-directory is at the same level as the input, output and save sub-directories.
- In a sub-directory called **oc** of the gPROMS installation directory.

Clearly, the first option is appropriate only for Output Channels that are used by a small number of users, otherwise it may lead to unnecessary waste of disk space; it may also make the maintenance of the Foreign Process code very difficult to manage. The second option makes the Output Channels accessible to all gPROMS users but will usually reauire system administrator priviledges.

On UNIX platforms, a third option is for individual users to place a symbolic link to the actual Output Channel library inside their private oc sub-directory. The actual code may, thus, reside anywhere in the system where it is accessible to the group of users who need it. This has the advantage of saving disk space without requiring system administrator privileges.

Chapter 6

The gPROMS Equation Set Object

Contents

6.1		oduction
6.2	Desc	cription of discontinuous equations in ESOs 9
	6.2.1	Origins of discontinuous equations in physical descriptions $\mathfrak Q$
	6.2.2	Mathematical descriptions of physical discontinuities 10
	6.2.3	State-Transition Networks
	6.2.4	The representation of logical conditions in STNs
6.3	Inte	rface definition
6.4	IGP	AlgESO
	6.4.1	Methods relating to the ESO structure
	6.4.2	Methods relating to the ESO variables
	6.4.3	Methods for storage of sensitivities
	6.4.4	Methods relating to the ESO equations
	6.4.5	Methods relating to the ESO STNs
	6.4.6	Methods relating to rectangular ESOs
	6.4.7	General ESO methods
6.5	IGP	DiffAlgESO
	6.5.1	Methods relating to the ESO structure
	6.5.2	Methods relating to the ESO variables
	6.5.3	Methods relating to the ESO derivatives
6.6	ICa	peNumericSTN

6.1 Introduction

In order to carry out mathematical solution procedures such as simulation, optimisation etc, gPROMS internally combines the equations and variables present in all its models into a single large system of equations. A published interface, the *Equation Set Object* (ESO) is provided to access this system once constructed. This interface is used internally by gPROMS in the application of its own numerical solvers.

You will need a good understanding of the ESO interface if you are interested in either

• interfacing your own solver(s) to gPROMS

or

• extracting the mathematical information embedded in gPROMS models for your own purposes (e.g. implementing your own model-based applications).

The gSERVER document (XREF) describes how to obtain initial object handles to the ESO representing a gPROMS process. The purpose of this chapter is explain the detailed semantics of this interface.

The interface to is intended to serve the needs of the various solver objects by allowing them to obtain information about the size and structure of the system, to adjust the values of variables occurring in it, and to compute the resulting equation residuals and, potentially, other related information (e.q. partial derivatives).

More specifically, an ESO will support a number of operations including the following:

- Obtain the current values of a specified subset of the variables.
- Alter the values of any specified subset of the variables.
- Get the structure¹ of the sparse matrix representing the partial derivatives of a specified subset of the equations with respect to a specified subset of the variables.
- Compute the residuals of any specified subset of the equations at the current variable values.
- Get a sparse matrix containing the values of the partial derivatives of a specified subset of the equations with respect to a specified subset of the variables (at the object's current variable values).

A more complete definition will be given later.

The information associated with an ESO differs depending on whether the set of equations being described is purely algebraic (as is the case with the NLASystem class

 $^{^{1}}i.e.$ a list of the partial derivatives which will not be identically zero for all values of the variables.

mentioned above) or mixed differential and algebraic (as in the case of DAESystem). For this reason, we introduce a hierarchy of ESOs. At present, this hierarchy comprises two classes²:

- 1. Class Algebraic SO defines a purely algebraic set of equations.
- 2. Class *DifferentialAlgebraicESO* inherits from class AlgebraicESO and refines it to define a mixed set of differential and algebraic equations.

It is very common for gPROMS models to involve conditions dictating which one of alternate sets of equations is to be applied at any point in the simulation. This leads to a hierarchical approach to storage of equations in the ESO via the State Transition Network concept, as explained in the next section.

After this discussion, the majority of this chapter is devoted to detailed description of the semantics of all the methods of both classes of ESO, and also the State Transition Network. Finally, the CORBA Interface Definition Language (IDL) files describing these interfaces are presented.

6.2 Description of discontinuous equations in ESOs

Our best understanding of a number of common process phenomena is based on discontinuous descriptions. Since the ESO concept gives a mathematical description of general processes, it must take account of the potentially discontinuous nature of this description.

6.2.1 Origins of discontinuous equations in physical descriptions

There are many example of process phenomena that are commonly described in a discontinuous manner. These include:

- appearance and disappearance of thermodynamic phases;
- transitions of flow regimes from laminar to turbulent, and vice-versa;
- changes in the direction of flow, and their consequences;
- changes in flow due to discontinuities in equipment geometry (e.g. position of overflow pipes);
- equipment breakdown.

 $^{^{2}}$ In future we may well introduce further levels in this hierarchy (e.g. IntegroPartialDifferentialAlgebraicESO).

Additional discontinuities may arise as a result of discrete control actions and disturbances imposed on the process by external agents. However, here we are primarily concerned with discontinuities in the physical behaviour since it is precisely this behaviour that ESOs describe mathematically.

6.2.2 Mathematical descriptions of physical discontinuities

The mathematical descriptions of physical discontinuities is itself discontinuous. Early modelling tools described such discontinuities via the use of conditional equations typically defined using IF/THEN/ELSE constructs. Each such conditional equation has one of two different forms depending on the value (TRUE or FALSE) of a logical condition. The latter is itself expressed in terms of the values of the system variables. As an example, consider the friction factor for flow in a pipe. This is a different function of the Reynolds number depending on whether the flow is laminar or turbulent. Mathematically, this effect is described by the following conditional equation:

IF
$$Re < 2100$$
 THEN
$$f = \frac{16}{Re}$$
 ELSE
$$\frac{1}{\sqrt{f}} = -4\log_{10}\left(\frac{1.26}{Re\sqrt{f}} + \frac{\epsilon/D}{3.7}\right)$$

Albeit by far the simplest mechanism for specifying discontinuous equations, IF/THEN/ELSE equations are not sufficiently general for the description of the range of phenomena occurring in chemical processes. For instance, they are unable to describe:

- Asymmetric discontinuities such as the hysteresis phenomena that occur in the opening and closing of safety relief valves; such valves tend to open at a higher pressure than the one at which they actually close.
- Irreversible discontinuities such as those occurring when equipment breaks down when certain operating limits (e.g. pressure) are reached; in most cases, the breakdown, once it occurs, cannot be reversed even if the operating conditions revert to their normal ranges.

For this reason, the description of discontinuities in ESOs is based on a more general formalism, called *State-Transition Networks*.

6.2.3 State-Transition Networks

For the purposes of this chapter, a State-Transition Network (STN) is simply a description of a discontinuous equation or set of equations. An example of an STN is shown




Figure 6.1: Example of a State-Transition Network.

in Figure 6.1. Each STN comprises two types of information, a set of states³ and a set of transitions from one state to another.

A state in an STN corresponds to one of the operating regimes of a discontinuous phenomenon. So, for instance, the STN describing the flow regime in a pipe would typically have two states corresponding to the laminar and turbulent regimes respectively.

In fact, IF/THEN/ELSE conditional equations (see section 6.2.2) are special cases of STNs in which, for any pair of states s and s', both transitions $s \to s'$ and $s' \to s$ occur and the logical conditions associated with the former transition are the negation of those associated with the latter. Thus, the STN describing the friction factor equation discussed in section 6.2.2 is shown in Figure 6.2.

More formally, each state s in an STN is characterised by:

- A set of equations
- A (possibly empty) set of transitions to other states.

At any particular point in time, exactly one state in a STN is designated as being active. In physical terms, this implies that the process behaviour satisfies the equations in that state.

Each transition (s, s') in an STN is characterised by:

• A start state, s

³The states in a STN are also sometimes called "modes" in order to avoid confusion with the term "states" used in control theory.




Figure 6.2: STN for the Reynolds-number example.

- An end state, s'
- A logical condition.

If, at a certain point in time, a state s of the STN is active and the logical condition associated with a transition (s, s') becomes TRUE, then the transition (s, s') takes place, i.e. state s stops being active and state s' becomes active.

In the interests of simplicity, all STNs used for the purposes of CAPE-OPEN must satisfy the following assumption:

• All equations and logical conditions are expressed in terms of (subsets of) the *same* set of variables.

6.2.3.1 State-Transition Networks in gPROMS

The gPROMS modelling language enables the user to describe STNs using two mechanisms. These are the IF/THEN/ELSE statements and the CASE construct. These mechanisms are described fully in chapter 4 of the "gPROMS Introductory User Guide". The example shown above can be modelled in gPROMS using either of the methods shown below.

• Using IF/THEN/ELSE

```
IF ReynoldsNumber < 2100 THEN
  FrictionFactor = 16 / ReynoldsNumber ;
ELSE
  1 / SQRT(FrictionFactor) = - 4 * LOG10(
    1.26/( ReynoldsNumber*SQRT(FrictionFactor) )</pre>
```

```
+ EddyDiffusivity/(3.7*Diameter)
                                             );
    END

    Using CASE

    SELECTOR.
     FlowRegime AS (Laminar, Turbulent)
    EQUATION
     CASE FlowRegime OF
        WHEN Laminar:
          FrictionFactor = 16 / ReynoldsNumber ;
          SWITCH TO Turbulent IF ReynoldsNumber >= 2100;
        WHEN Turbulent:
          1 / SQRT(FrictionFactor) = - 4 * LOG10(
            1.26/( ReynoldsNumber*SQRT(FrictionFactor) )
            + EddyDiffusivity/(3.7*Diameter)
          SWITCH TO Laminar IF ReynoldsNumber < 2100;
     END
```

The two examples above illustrate that IF structures can only be used to model symmetric transitions, whereas CASE structures can easily handle asymmetric and unidirectional (simply by omitting the SWITCH TO statement for the appropriate state) transitions.

6.2.3.2 State-Transition Networks in ESOs

An ESO can contain one or more STNs. Thus, the complete set of equations describing the ESO at any particular point in time comprises:

- the ESO's own equations (i.e. excluding those in the STNs it contains);
- the equations in the active state of its constituent STNs.

Conversely, the equations associated with each state in an STN are themselves described by an ESO. The relation between STNs and ESOs is, therefore, recursive. This allows for the nesting of discontinuous equations to an arbitrary number of levels.

An underlying assumption is that an ESO and all the ESOs describing the states of all STNs contained within it share the *same* set of variables. Albeit not necessary, this assumption obviates the need for complex mapping mechanisms between different variable sets; it also happens to be satisfied by most typical cases where descriptions of discontinuous phenomena occur within process models.

6.2.4 The representation of logical conditions in STNs

A key issue in the representation of STNs is the representation of the logical conditions that are associated with the transitions. In particular, it is important to identify the amount and type of information that an STN object must provide to its clients regarding these logical conditions. Clearly, such decisions depend crucially on the type of usage that is envisaged for these STNs by, for instance, numerical solvers⁴.

It is important to understand that the above logical conditions may be quite complex. For instance, a certain transition could be triggered by a logical condition of the form:

$$\left[[x_1^2 + x_2^2 \ge x_3^2] \lor \neg [x_1^2 \le x_2] \right] \land [x_2 \ge x_3]$$

where, x_1, x_2 and x_3 are real-valued variables, and the symbols \vee , \wedge and \neg denote the OR, AND and NOT logical operators.

Most of the older numerical codes for the simulation and optimisation of processes involving discontinuities required only the evaluation of complex logical expressions such as the above for given values of the variables occurring in them. Consequently, a simple interface that would return the value (TRUE or FALSE) of a specified logical condition at the current values of the ESO's variables would be sufficient in this case.

However, more modern solution methods derive their improved reliability and efficiency from the availability of more information on each logical condition. For example, if the above logical condition were to change value (from TRUE to FALSE, or vice-versa) at a particular point in time, these methods would need to know *exactly which* of the three logical subexpressions:

$$x_1^2 + x_2^2 \ge x_3^2$$
, $x_1^2 \le x_2$, $x_2 \ge x_3$

was the one that changed value, thereby causing the change in the value of the overall logical expression. The solution method would also need to know other information on this particular sub-expression, such as the set of variables that appear in it, and its partial derivatives with respect to these variables.

The aim of Cape Open was to accommodate the requirements of the modern solution methods without resulting in an excessively complex interface. This is particularly important as simpler methods are still being used by many of the currently available tools. As a compromise, the interface supports arbitrarily complex logical conditions involving any combination of the \vee , \wedge and \neg operators while imposing the following restriction:

⁴Already similar decisions have been made implicitly in the design of the basic ESO. In that case, it was deemed appropriate that the ESO should provide numerical values for the residuals of its equations and their partial derivatives, as well as information on the structure of these equations. On the other hand, it was not thought necessary to provide information on the symbolic form of these equations.

• All lowest level logical sub-expressions in a logical expression are of the form:

$$x_i > 0$$

where x_i is any one of the variables occurring in the ESO.

This assumption is not actually as restrictive as it might first appear. For instance, the logical condition shown above could be expressed as:

$$[[x_4 \ge 0] \lor \neg [x_5 \ge 0]] \land [x_6 \ge 0]$$

where we have introduced three new variables x_4 , x_5 and x_6 defined via the three additional equations:

$$x_4 \equiv x_1^2 + x_2^2 - x_3^2, \ x_5 \equiv -x_1^2 + x_2, \ x_6 \equiv x_2 - x_3$$

The main advantage of introducing the above restriction is that it permits the representation of any logical condition as a sequence of integer values. Such sequences have the following semantics:

- Each positive integer value represents the lowest-level condition.
- Each negative integer value represents one of the three Boolean operators:
- -1 denotes AND (\land) .
- -2 denotes OR (\vee) .
- -3 denotes NOT (\neg) .
- Prefix notation is used, allowing simple recursive evaluation.

Thus, consider the following examples:

- A sequence consisting of the single value (3) denotes the condition $x_3 \ge 0$.
- The sequence (-2, 1, -3, 2) denotes the condition $(x_1 \ge 0) \lor \neg (x_2 \ge 0)$ (i.e. " x_1 non-negative or x_2 negative").
- The condition $[[x_4 \ge 0] \lor \neg [x_5 \ge 0]] \land [x_6 \ge 0]$ (see example above) becomes (-1, -2, 4, -3, 5, 6).

The simple pseudo-code in Figure 6.3 illustrates how these sequences can be evaluated by a simple recursive routine. The precondition is that the sequence of integers is stored in a global array seq, and a global index at is initially set to the lower bound of seq. Also, we assume that the current variable values are held in the global vector x.

```
Boolean function eval()
  integer val; // a local variable.
  val:=seq[at];
  at:=at+1;
  If val>0 THEN
     Return (x[val]>=0);
  Else
     Case val:
        -1: Return eval() AND eval();
        -2: Return eval() OR eval();
        -3: Return NOT eval();
     End
  End
End
```

Figure 6.3: Pseudo-code for the evaluation of logical conditions.

6.3 Interface definition

We now proceed to describe the interfaces to the Equation Set Objects in detail.

WARNING!

The interfaces described in this document are PSE's internal development originating from the proposed CAPEOPEN standard. To avoid confusion, the names IGPAlgESO and IGPDiffAlgESO are used.

The major extensions are the introduction of the IVariableSet interface to isolate methods related only to variables, and the "index set" technique introduced for efficiency.

The description here omits some deprecated methods currently present in the interfaces.

6.4 IGPAlgESO

Inherits from: ICapeUtilityComponent

This is the interface of the Algebraic Equation Set Object which represents a set of non-linear algebraic equations of the form:

$$f(x) = 0.$$

In general, a set described by an ESO can be rectangular, *i.e.* the number of variables does not have to be the same as the number of equations.

The variables in an ESO are characterised by their current values (that can be changed via the provided interface), and also lower and upper bounds. Usually, these bounds relate to the domain of definition of the equations⁵ and/or physical reality⁶. For this reason, any attempt to set one or more variables to values outside these bounds is considered to be illegal and will, therefore, be rejected.

The equations in an ESO are assumed to be sparse, *i.e.* any given equation will involve only a subset of the variables in the ESO. Consequently, only a (usually small) subset of the partial derivatives $\partial f/\partial x$ will not be zero for any set of values of the variables x. The sparsity pattern of the ESO refers to the number of such non-zero elements, and the row, i (*i.e.* equation f_i), and column, j (*i.e.* variable x_j), to which each such non-zero corresponds. The way in which information on this structure is defined is entirely analogous to that for linear systems (cf section 8.7).

The interface defined in this section provides mechanisms for obtaining information on the current values and bounds of the variables x, as well as the sparsity pattern of the ESO. It also allows modification of the variable values, and the computation of the values ("residuals") of the equations f(x) for the current values of x and of the non-zero elements of the matrix $\partial f/\partial x$ (the so-called "Jacobian" matrix).

Additionally, the concept of variable "properties" is introduced. These can be used freely by client software to record string information associated with sets of variables. The following pre-defined properties may also be used:

- **ASSIGN** Variables present in the gPROMS ASSIGN section (which thus should not be treated as unknowns by a solver) are marked with this property.
- **PARAM** Variables marked with this property are identified as *parameters* for optimisation: sensitivities with respect to these variables are then available from the ESO after integrations.
- **2ND_ORDER_PARAM** Variables marked with this property are identified as *second* order parameters for optimisation: second order sensitivities with respect to these variables are then available from the ESO after integrations.

See the discussion of the ISensitivityStorage interface for details of the last two items above.

As we have seen in section 6.2, an ESO may contain one or more state-transition networks (STNs). The equations in each state and the logical conditions associated with each transition in these STNs are all expressed in terms of the ESO's own set of variables (see section 6.2.3.2).

Several of the methods provided by the ICapeNumericAlgebraicESO interface allow access to information on an ESO's equations (e.g. their number, residuals, Jacobian

⁵For instance, an equation involving a term $\sqrt{1-x}$ is undefined for any value of variable x exceeding unity; thus, x is subject to an upper bound of 1.

⁶For instance, variables representing molar fractions must stay between a lower bound of 0 and an upper bound of 1.

structure and values). It must be emphasised that, in all these cases, the information provided pertains *only* to the equations that are contained *directly* within the ESO and not those within any STNs that this ESO may contain.

Detailed information on the STNs within an ESO must, instead, be obtained via a different set of methods provided by interface ICapeNumericSTN (see section 6.6). For this purpose, the ICapeNumericAlgebraicESO interface includes methods for determining the number of STNs present in an ESO as well as the ICapeNumericSTN interface to each such STN.

Finally, we note that CAPE-OPEN does *not* define any standard mechanisms or interfaces for the *construction* of ESOs. These are left at the discretion of each implementor.

6.4.1 Methods relating to the ESO structure

IGPAlgESO:	:Get V	/ariab	leSet
TOT TINDEO	. ~ ~ ~ *	ar ran	

Description Gets the separate interface for information on variables in the ESO. **Arguments**

In/Out	Name	Type	Description
[return]		IVariableSet	The interface.

IGPAlgESO::GetNumEqns

Description

Gets the number of equations in the ESO. Note that this does not include any equations associated with the states in the state transition networks (if present).

Arguments

In/Out	Name	Type	Description
[out]	NumEqns	CapeLong	The number of equations in the ESO (not including any equations in any STNs con-
[return]		CapeError	tained in the ESO).

IGPAlgESO:: GetNumNonZeroes

Description

Gets the number of structurally non-zero entries in the ESO's Jacobian matrix $(\partial f/\partial x)$. Note that this does not include entries arising from any equations associated with the states in the state transition networks (if present).

In/Out	Name	Type	Description
[out] [return]	NumNonZeroes	CapeLong CapeError	The number of non-zeroes

IGPAlgESO:: GetJacobianStruct

Description

Retrieves the sparsity pattern of the equation system contained in an ESO. Note that this does *not* include entries arising from any equations associated with the states in the state transition networks (if present).

Note: the argument CanBeComputed(k) is used by the ESO to indicate whether or not it is able to compute particular entries of the Jacobian. A strictly positive value indicates that the ESO is able to compute this particular derivative (see the GetJacobianValue method).

Arguments

In/Out	Name	Type	Description
[out]	NonZeroes	CapeLong	The number of (structural) non-zeroes in the matrix.
[out]	RowNums	CapeArrayLong	The list of row numbers for each non-zero.
[out]	ColNums	CapeArrayLong	The list of column numbers for each non-zero.
[out]	CanBe- Computed	CapeArrayLong ^a	See Note above.
[return]	•	CapeError	

^aAlthough a Boolean would suffice for this argument, a Long is used here to allow for possible future refinement of the information conveyed.

IGPAlgESO::**GetNumSTNs**

Description Arguments

Returns the number of state transition networks in the ESO.

In/Out	Name	Type	Description
[out] [return]	NoSTNs	CapeLong CapeError	The number of STNs.

${\tt IGPAlgESO::} \textbf{GetListOfSTNsWithSwitches}$

Description Returns the indices of all STNs of the current ESO with active transition conditions (if any)

Arguments

In/Out	Name	Type	Description
[out]	STNList	CapeArrayLong CapeError	Indices of the STNs. Note: an STN will appear in this list if either its GetActiveTransitions method will return a non-empty list or the GetListOfSTNsWithSwitches method of the ESO of its current state would return a non-empty list. This recursive definition ensures that the presence of any active transition can be detected with a single call to the top level ESO.

6.4.2 Methods relating to the ESO variables

IVariable Set:: GetNumVars

 $\begin{tabular}{ll} \textbf{Description} & \textbf{Gets the number of variables in the ESO}. \end{tabular}$

In/Out	Name	Type	Description
[out] [return]	NumVars	CapeLong CapeError	The number of variables in the ESO.

IVariableSet::GetVarNames

Description Gets the names of (a subset of) the variables in the ESO. **Arguments**

In/Out	Name	Type	Description
[in]	VarNums	CapeArrayLong	The indices of the variables whose names are required. Note: a zero-length list indicates <i>all</i> of the variables in the ESO.
[out] [return]	VarNames	CapeArrayString CapeError	The names of the required variables.

IVariableSet::GetVarNums

Description Gets the indices of (a subset of) the variables in the ESO. **Arguments**

In/Out	Name	Type	Description
[in]	VarNames	CapeArrayString	The names of the variables whose indices are required.
[out]	VarNums	CapeArrayLong	The indices of the required variables. For incorrect names, zero is returned.
[return]		CapeError	,

IVariableSet::GetBounds

Description Gets the values of the lower and upper bounds of (a subset of) an ESO's variables.

Arguments

In/Out	Name	Type	Description
[in]	VarNums	CapeArrayLong	The indices of the variables whose bounds are required. Note: a zero length list indicates <i>all</i> the variables in the ESO.
[out] [out] [return]	LowerBounds UpperBounds	CapeArrayDouble CapeArrayDouble CapeError	The values of the lower bounds. The values of the upper bounds.

IVariableSet::GetBoundsIS

Description

Gets the values of the lower and upper bounds of a registered subset of an ESO's variables.

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the set of variables whose bounds are required (see IVariable-Set::RegisterIndexSet).
[out] [out] [return]	LowerBounds UpperBounds	CapeArrayDouble CapeArrayDouble CapeError	The values of the lower bounds. The values of the upper bounds.

IVariableSet::SetVariables

Description Sets the values of (a subset of) an ESO's variables. **Arguments**

In/Out	Name	Type	Description
[in]	VarNums	CapeArrayLong	The indices of the variables whose values are to be set.
[in] [return]	Vals	CapeArrayDouble CapeError	The values of the variables.

IVariableSet::SetVariablesIS

Description Arguments

Sets the values of a registered subset of an ESO's variables.

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the set of variables whose values are to be set (see IVariable-
[in] [return]	Vals	CapeArrayDouble CapeError	Set::RegisterIndexSet). The values of the variables.

IVariableSet::GetVariables

 $\begin{array}{ll} \textbf{Description} & \text{Gets the values of (a subset of) an ESO's variables.} \\ \textbf{Arguments} & \end{array}$

In/Out	Name	Type	Description
[in]	VarNums	CapeArrayLong	The indices of the variables whose values are required. Note: a zero length list in-
io [return]	Vals	CapeArrayDouble CapeError	dicates all the variables in the ESO. The values of the variables.

IVariableSet::GetVariablesIS

Description Gets the values of a registered subset of an ESO's variables. **Arguments**

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the set of variables whose values are required (see IVariable-
[out] [return]	Vals	CapeArrayDouble CapeError	Set::RegisterIndexSet). The values of the variables.

IVariableSet::RegisterIndexSet

Description

Records a set of variable indices in order to permit use of SetVariables IS, GetVariables IS, and GetBounds IS

Arguments

In/Out	Name	Type	Description
[in] [return]	EltNums	CapeLong CapeLong	The indices of the variables which we will require access to. The "handle" to be used on subsequent calls to GetVariablesIS etc.

$IV a riable Set:: {\bf Unregister Index Set}$

Description

Informs the VariableSet that a registered set of variable indices will no longer be required

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the registered set.

IVariableSet::GetSensitivityStorage

Description

Gets the separate interface for information on the sensitivities of variables in the variable set.

Arguments

In/Out	Name	Type	Description
[return]		ISensitivityStorage	The interface.

IVariable Set:: SetVarProperty

Description

Marks all variables in a list as having a given property.

Arguments

In/Out	Name	Type	Description
[in]	VarInds	CapeArrayLong	The indices. The property.
[in]	PropName	CapeString	

$IVariable Set:: {\bf Clear Var Property}$

Description Arguments

Ensures that the listed variables do not have the given property.

In/Out	Name	Type	Description
[in]	VarInds PropName	CapeArrayLong CapeString	The indices. The property.

IVariableSet::GetVarsWithProperty

Description Gets a list of all variables marked as having a given property. **Arguments**

In/Out	Name	Type	Description
[in]	PropName	CapeString	The property. The indices.
[out]	VarInds	CapeArrayLong	

IVariable Set:: GetNumVarsWithProperty

Description Gets the number of variables marked as having a given property. **Arguments**

In/Out	Name	Type	Description
[in] [return]	PropName	CapeString CapeLong	The property. The number.

IVariable Set:: GetPropertiesOfVars

Description Gets a list of all the properties of each variable listed. **Arguments**

In/Out	Name	Type	Description
[in]	VarInds	CapeArrayLong	The indices. Tring Array of lists of properties (one per variable index).
[out]	PropLists	CapeArrayArraySt	

6.4.3 Methods for storage of sensitivities

IS ensitivity Storage :: SetVarSensitivities

Description Saves an array of **Arguments**

Saves an array of sensitivity values

In/Out	Name	Type	Description
[in]	VarSen	CapeArrayDouble	The sensitivity values $\frac{\partial x}{\partial p}$, beginning with every variable's sensitivity to the first parameter, etc. Total length of the array must be (length of x)×(number of parameters).
[return]		CapeError	

IS ensitivity Storage :: GetVarSensitivities

 $\begin{array}{c} \textbf{Description} \\ \textbf{Arguments} \end{array}$

Gets the array of sensitivity values from the ${\rm ESO}$

In/Out	Name	Type	Description
[out]	VarSen	CapeArrayDouble	The sensitivity values, beginning with every variable's sensitivity to the first parameter, etc. Total length of the array will be (length of x)×(number of parameters). Effect undefined if no prior call to SetVarSensitivities.
[return]		CapeError	

IS ensitivity Storage :: SetVar2ndOrderSensitivities

Description Saves an array of second order sensitivity values **Arguments**

In/Out	Name	Type	Description
[in]	VarSen	CapeArrayDouble CapeError	The second order sensitivity values, i.e. the sensitivity of $\frac{\partial x}{\partial p}$ to the second order parameters q , in the order $\frac{\partial^2 x_1}{\partial p_1 \partial q_1} \cdots \frac{\partial^2 x_N}{\partial p_1 \partial q_1}, \frac{\partial^2 x_1}{\partial p_2 \partial q_1} \cdots \frac{\partial^2 x_N}{\partial p_n \partial q_1}, \cdots \frac{\partial^2 x_1}{\partial p_1 \partial q_2}$ Total length of the array must be (length of x)× (number of parameters)×(number of 2nd order parameters).

IS ensitivity Storage :: GetVar2ndOrderSensitivities

Description Gets the array of second order sensitivity values from the ESO **Arguments**

In/Out	Name	Type	Description
[out]	VarSen	CapeArrayDouble	The sensitivity values, as above. Effect undefined if no prior call to
[return]		CapeError	SetVar2ndOrderSensitivities.

IS ensitivity Storage :: SetVar2ndOrderParamSensitivities

Description Saves an array of sensitivities to the second order parameters **Arguments**

In/Out	Name	Type	Description
[in]	VarSen	CapeArrayDouble	The sensitivity values, i.e. the sensitivity of x to the second order parameters q , in the order $\frac{\partial x_1}{\partial q_1} \dots \frac{\partial x_N}{\partial q_1}, \frac{\partial x_1}{\partial q_2} \dots$ Total length of the array must be (length of x)× (number of 2nd order parameters).
[return]		CapeError	

IS ensitivity Storage :: GetVar2ndOrderParamSensitivities

Description Gets an array of sensitivities to the second order parameters **Arguments**

In/Out	Name	Type	Description
[out]	VarSen		The sensitivity values, i.e. the sensitivity of x to the second order parameters q , the order $\frac{\partial x_1}{\partial q_1} \dots \frac{\partial x_N}{\partial q_1}, \frac{\partial x_1}{\partial q_2} \dots$ Total length of the array will be (length of x)× (number of 2nd order parameters). Effect undefined if no prior call to SetVar2nd0rderParamSensitivities
[return]		CapeError	

IS ensitivity Storage :: SetDerivativesSensitivities

Description Saves an array of sensitivity values **Arguments**

In/Out	Name	Type	Description
[in]	VarSen	CapeArrayDouble	The sensitivity values, beginning with each time derivative's sensitivity to the first parameter, etc. Total length of the array must be (length of x)×(number of parameters).
[return]		CapeError	r

IS ensitivity Storage :: GetDerivativesSensitivities

Description Gets the array of sensitivity values from the ESO **Arguments**

In/Out	Name	Type	Description
[out]	VarSen	CapeArrayDouble	The sensitivity values, beginning with each time derivative's sensitivity to the first parameter, etc. Total length of the array will be (length of x)×(number of parameters). Effect undefined if no prior call to SetDerivativesSensitivities.
[return]		CapeError	

6.4.4 Methods relating to the ESO equations

IGPAlgESO:: GetEqnNames

Description Gets the Arguments

Gets the names of (a subset of) the equations in the ESO.

In/Out	Name	Type	Description
[in]	EqnNums	CapeArrayLong	The indices of the equations whose names are required. Note: a zero-length list in-
[out] [return]	EqnNames	CapeArrayString CapeError	dicates <i>all</i> of the variables in the ESO. The names of the required equations.

${\tt IGPAlgESO::} \textbf{GetAllResiduals}$

Description

Obtain the current values of the residuals of an ESO's equations. Note that this does not include any equations associated with the states in the state transition networks (if present).

In/Out	Name	Type	Description
[out]	Residuals	CapeArrayDouble	The residuals, $i.e.$ the value of for each included in EqnIndices, at the current set
[return]		CapeError	of values of the variables x .

IGPAlgESO:: **GetResiduals**

Description

Obtain the current values of the residuals of a subset of an ESO's equations. Note that this does not include any equations associated with the states in the state transition networks (if present).

Arguments

In/Out	Name	Type	Description
[in]	EqnIndices	CapeArrayLong	The numbers of the equations whose residuals are required.
[out]	Residuals	CapeArrayDouble	The residuals, <i>i.e.</i> the value of for each included in EqnIndices, at the current set of values of the variables x .
[return]		CapeError	

IGPAlgESO:: GetResidualsIS

Description

Obtain the current values of the residuals of a registered subset of an ESO's equations. Note that this does not include any equations associated with the states in the state transition networks (if present).

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the set of equation numbers whose residuals are required, as re-
[out]	Residuals	CapeArrayDouble	turned by RegisterEquationIndexSet The residuals, <i>i.e.</i> the value of for each included in EqnIndices, at the current set
[return]		CapeError	of values of the variables x .

IGPAlgESO:: RegisterEquationIndexSet

Description Records a set of equation numbers in order to permit use of GetResidualsIS

Arguments

In/Out	Name	Type	Description
[in] [return]	EqnNums	CapeLong CapeLong	The indices of the residuals which we will require. The "handle" to be used on subsequent calls to GetResidualsIS.

$IGPAlgESO:: {\bf Unregister Equation Index Set}$

Description Informs the ESO that a registered set of equation numbers will no longer be required

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the registered set.

6.4.5 Methods relating to the ESO STNs

IGPAlgESO:: GetSTNNames

Description Returns the names of the state transition networks in the ESO. **Arguments**

In/Out	Name	Type	Description
[out] [return]	Names	CapeArrayString CapeError	The names of all STNs in the ESO.

IGPAlgESO:: GetAllSTNs

Description Returns a sequence of interfaces corresponding to all the STNs in the ESO.

In/Out	Name	Type Description
[out]	STNs	CapeArrayInterface Interfaces to each requested STN. (ICapeNumeric-
[return]		STN) CapeError

IGPAlgESO::GetSTNs

Description	Returns a sequence of interfaces corresponding to requested STNs in
A marros anta	the ESO.

Arguments

In/Out	Name	Type	Description
[in]	STNIndices	CapeArrayLong	The indices of the STNs whose interfaces are required.
[out]	STNs	CapeArrayInterface (ICapeNumeric- STN)	e Interfaces to each requested STN.
[return]		CapeError	

6.4.6 Methods relating to rectangular ESOs

IGPAlgESO:: GetAllJacobianValues

Description

Gets the values of the structurally non-zero values of an ESO's Jacobian. Note that this does not include entries arising from any additional equations associated with the states in the state transition networks (if present).

Note: for entries which were indicated by the GetJacobianStruct method as "unavailable", no error should arise, but the value returned will be undefined.

In/Out	Name	Type	Description
[out]	Vals	CapeArrayDouble	The non-zero values of the requested submatrix of the Jacobian.
[return]		CapeError	interial of the succession.

IGPAlgESO:: GetJacobianValues

Description

Gets the values of a subset of the structurally non-zero values of an ESO's Jacobian. Note that this does not include entries arising from any additional equations associated with the states in the state transition networks (if present).

Note: for entries which were indicated by the GetJacobianStruct method as "unavailable", no error should arise, but the value returned will be undefined.

In/Out	Name	Type	Description
[in]	EltIndices	CapeArrayLong	The indices of the elements of the complete structure which we require.
[out]	Vals	CapeArrayDouble	The non-zero values of the requested submatrix of the Jacobian.
[return]		CapeError	

IGPAlgESO:: GetJacobian Values IS

Description

Gets the values of a registered subset of the structurally non-zero values of an ESO's Jacobian. Note that this does not include entries arising from any additional equations associated with the states in the state transition networks (if present).

Note: for entries which were indicated by the GetJacobianStruct method as "unavailable", no error should arise, but the value returned will be undefined.

Arguments

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the subset of elements requires (as returned by RegisterJaco-
[out]	Vals	CapeArrayDouble	bianIndexSet). The non-zero values of the requested submatrix of the Jacobian.
[return]		CapeError	matrix of the gaeostan.

IGPAlgESO:: RegisterJacobianIndexSet

es			

Records a set of Jacobian element indices in order to permit use of GetJacobianValuesIS

In/Out	Name	Type	Description
[in]	EltNums	CapeLong	The indices of the elements of the complete structure which we will require.
[return]		CapeLong	The "handle" to be used on subsequent calls to GetJacobianValuesIS.

IGPAlgESO::UnregisterJacobianIndexSet

Description

Informs the ESO that a registered set of Jacobian indices will no

longer be required

Arguments

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the registered set.

6.4.7 General ESO methods

IGPAlgESO::Delete

Description Deletes the ESO.

6.5 IGPDiffAlgESO

Inherits from: IGPAlgESO

This is the interface of the Differential-Algebraic Equation Set Object which represents a (generally rectangular) set of differential-algebraic equations of the form:

$$f(x, \dot{x}, t),$$

where t is the independent variable and x(t) is a vector of dependent variables. Also \dot{x} denotes the derivatives $\mathrm{d}f/\mathrm{d}t$. We note that, in general, the quantities will appear in the system for only a subset of the dependent variables x. This subset of x are often referred to as the "differential variables" while the rest are the "algebraic variables". Of course, all these variables are functions of the independent variable t.

It is worth clarifying the semantic interpretation of the methods that are inherited by this interface from IGPAlgESO:

- GetNumVars must return the length of the vector x.
- \bullet GetBounds, SetVariables and GetVariables relate only to the vector x.

- All the methods associated with the Jacobian (GetNumNonZeroes, GetJacobianStruct and GetJacobianValues) relate to $\partial f/\partial x$.
- The equation residuals and Jacobian are evaluated at the current values of x, \dot{x} and t.
- GetVariableSet returns an IVariableSet interface which can be narrowed to an ID-ifferentialVariableSet in order to access the additional methods for time derivatives (see below).

The methods defined in this section introduce equivalent functionality for accessing and altering information pertaining to \dot{x} (via the IDifferentialVariableSet interface). They also provide mechanisms for accessing and altering the value of the independent variable t.

6.5.1 Methods relating to the ESO structure

IGPDiffAlgESO:: **GetNumDiffVars**

Description Gets the number of differential variables in the ESO. **Arguments**

In/Out	Name	Type	Description
[out] [return]	NumDiffVar	CapeLong CapeError	The number of differential variables.

IGPDiffAlgESO:: GetNumDiffNonZeroes

Description

Gets the number of non-zero entries in the Jacobian of the ESO with respect to \dot{x} . Note that this does *not* include entries arising from any equations associated with any state transition network within this ESO.

Arguments

I	n/Out	Name	Type	Description
[c	out]	NumNonZeroes	CapeLong	The number of non-zero elements of the Jacobian.
[r	return]		CapeError	Jacobian.

IGPDiffAlgESO:: GetDiffJacobianStruct

Description

Retrieves the sparsity pattern of the Jacobian. Note that this does not include entries arising from any equations associated with any state-transition network within this ESO.

Note: CanBeComputed(k) is used to indicate whether or not the ESO is able to compute particular entries of the Jacobian. A strictly positive value indicates that the ESO is able to compute this particular entry (see the GetDiffJacobianValue method).

In/Out	Name	Type	Description
[out]	NonZeroes	CapeLong	The number of (structural) non-zeroes in the matrix.
[out]	RowNums	CapeArrayLong	The list of row numbers for each non-zero.
[out]	ColNums	CapeArrayLong	The list of column numbers for each non-zero.
[out]	CanBe- Computed	CapeArrayLong	See note above.
[return]		CapeError	

6.5.2 Methods relating to the ESO variables

${\tt IGPDiffAlgESO::} \textbf{GetDiffVarIndices}$

Description Gets the indices of the differential variables in the ESO. **Arguments**

In/Out	Name	Type	Description
[out] [return]	DiffVarIndices	CapeArrayLong CapeError	The indices of the differential variables.

IGPDiffAlgESO:: GetIndependentVariable

Description Gets the current value of the independent variable t in an ESO. **Arguments**

In/Out	Name	Type	Description
[out]	IndVarVal	CapeDouble	The current value of the independent variable.
[return]		CapeError	able.

IGPDiffAlgESO:: SetIndependentVariable

Description Sets the current value of the independent variable t in an ESO. **Arguments**

In/Out	Name	Type	Description
[in]	IndVarVal	CapeDouble	The current value of the independent variable.
[return]		CapeError	abic.

6.5.3 Methods relating to the ESO derivatives

IDifferentialVariableSet::SetDerivatives

Description Sets the numerical values of (a subset of) an ESO's \dot{x} terms.

Note: the ESO stores time derivatives for all variables, regardless

of whether these occur in the equations explicitly.

In/Out	Name	Type	Description
[in]	VarNums	CapeArrayLong	The indices of the variables whose derivatives are to be set.
[in] [return]	Vals	CapeArrayDouble CapeError	The values of the derivatives.

ID ifferential Variable Set:: Set Derivatives IS

Description

Sets the numerical values of a registered subset of an ESO's \dot{x} terms. Note: the ESO stores time derivatives for all variables, regardless of whether these occur in the equations explicitly.

Arguments

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" to the set of variables whose derivatives are to be set (see IVariable-
[in] [return]	Vals	CapeArrayDouble CapeError	Set::RegisterIndexSet) The values of the derivatives.

IDifferentialVariableSet::GetDerivatives

Description

Gets the numerical values of (a subset of) an ESO's \dot{x} terms. Note however that passing index i to this method and SetDerivatives refers to the derivative of x_i w.r.t. the independent variable, and **not** to "the ith element of x which has an \dot{x} term appearing in the equations". This in fact places a requirement on the ESO to store a time derivative for all elements of x.

In/Out	Name	Type	Description
[in]	VarNums	CapeArrayLong	The indices of the variables whose derivatives are required. Note: a zero-length list indicates that values should be returned for all entries.
[out] [return]	Vals	CapeArrayDouble CapeError	The values of the derivatives.

ID ifferential Variable Set:: GetDerivativesIS

Description Gets the derivatives of a registered subset of an ESO's variables. **Arguments**

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the set of variables whose derivatives are required (see IVariable-Set::RegisterIndexSet).
[out] [return]	Vals	CapeArrayDouble CapeError	,

IGPDiffAlgESO:: GetAllDiffJacobianValues

Description

Gets the values of the (structurally) non-zero elements of an ESO's Jacobian with respect to \dot{x} . Note that this does not include entries arising from any equations associated with any state transition network within this ESO.

Note: For entries which were indicated by the GetDiffJacobianStruct method as "unavailable", no error should arise, but the value returned will be undefined.

In/Out	Name	Type	Description
[out]	Vals	CapeArrayDouble	The non-zero values of the requested submatrix of the Jacobian.
[return]		CapeError	

${\tt IGPDiffAlgESO::} \textbf{GetDiffJacobianValues}$

Description

Gets the values of a subset of the (structurally) non-zero elements of an ESO's Jacobian with respect to \dot{x} . Note that this does not include entries arising from any equations associated with any state transition network within this ESO.

Note: For entries which were indicated by the GetDiffJacobianStruct method as "unavailable", no error should arise, but the value returned will be undefined.

In/Out	Name	Type	Description
[in]	EltNums	CapeArrayLong	The indices of the elements of the complete structure that is required.
[out]	Vals	CapeArrayDouble	The non-zero values of the requested submatrix of the Jacobian.
[return]		CapeError	

${\tt IGPDiffAlgESO::} \textbf{GetDiffJacobianValuesIS}$

Description

Gets the values of a registered subset of the structurally non-zero values of an ESO's Jacobian wrt \dot{x} . Note that this does not include entries arising from any additional equations associated with the states in the state transition networks (if present).

Note: for entries which were indicated by the GetDiffJacobianStruct method as "unavailable", no error should arise, but the value returned will be undefined.

Arguments

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the subset of elements requires (as returned by RegisterDiffJaco-
[out]	Vals	CapeArrayDouble	bianIndexSet). The non-zero values of the requested submatrix of the Jacobian.
[return]		CapeError	

IGPAlgESO:: RegisterDiffJacobianIndexSet

esc			

Records a set of Jacobian element indices in order to permit use of GetDiffJacobianValuesIS

In/Out	Name	Type	Description
[in]	EltNums	CapeLong	The indices of the elements of the complete structure which we will require.
[return]		CapeLong	The "handle" to be used on subsequent calls to GetDiffJacobianValuesIS.

${\tt IGPAlgESO::} \textbf{UnregisterDiffJacobianIndexSet}$

Description	Informs the ESO that a registered set of differential Jacobian indices
Arguments	will no longer be required

Arguments

In/Out	Name	Type	Description
[in]	indSet	CapeLong	The "handle" of the registered set.

6.6 ICapeNumericSTN

The concept of a State-Transition Network (STN) as a means of representing discontinuous process behaviour was introduced in section 6.2.3. The ICapeNumericSTN interface described in this section allows access to the information defining the structure of a certain STN, including:

- The names of all states in the STN.
- The transitions that are possible from each state.
- The logical conditions that trigger each transition.
- The subESO corresponding to a specific state.
- Indication of which transitions are active.

It also allows access to an ESO that contains the equations that are associated with each state. This access is provided by an appropriate ESO interface (see sections 6.4 and 6.5).

ICapeNumericSTN::GetStateList

Description Returns the names of all the distinct states in the network. **Arguments**

In/Out	Name	Type	Description
[out] [return]	StateList	CapeArrayString CapeError	The state names.

ICapeNumericSTN::GetCurrentState

Description Gets the active stated in the STN **Arguments**

In/Out	Name	Type	Description
[out] [return]	StateName	CapeString CapeError	The name of the active state.

ICapeNumericSTN::SetCurrentState

Description Sets the active stated in the STN **Arguments**

In/Out	Name	Type	Description
[in] [return]	StateName	CapeString CapeError	The name of the state to become active.

ICapeNumericSTN::GetPossibleTransitions

Description

Returns the names of the states which can be reached from a specified state of the network, together with the logical conditions which control each transition.

The conditions are represented by sequences of CapeLong values: see Section 6.2 for an explanation of this representation.

In/Out	Name	Type	Description
[in] [out]	FromState ToStates	CapeString CapeArrayString	The state name. The states that can be reached from From-State.
[out]	Condition- Structs	CapeArrayLong	For the <i>i</i> th entry in ToStates, Condition-Structs will contain a sequence of Long values defining the condition for transition to that state from FromState.
[return]		CapeError	

ICapeNumericSTN::GetActiveTransitions

Description

Returns the names of the states which can be reached from the current state and for which with the current variable values, the condition for transition to that state is true. For each such state, it also returns an integer indication of the "strength" of the condition, and the logical condition itself.

The conditions are represented by sequences of CapeLong values: see Section 6.2 for an explanation of this representation.

In/Out	Name	Type	Description
[out]	ToStates	CapeArrayString	The states for which the transition conditions are active.
FromState	e.		
[out]	Strengths	CapeArrayLong	If the condition for transition to the <i>i</i> th entry in ToStates is $x_k \ge 0$, the <i>i</i> th entry of Strengths will be 1 if $x_k = 0$ (to machine precision), 2 if $0 < x_k < 10^{-6}$ or 4 if $x_k > 10^{-6}$. For more complex conditions, the strength of the weakest element is given.
[out]	Condition- Structs	CapeArrayLong	For the <i>i</i> th entry in ToStates, Condition- Structs will contain a sequence of Long values defining the condition for transition to that state from the current state.
[return]		CapeError	

ICapeNumericSTN::GetStateESO

Description Returns the ESO representing the equations which apply if a specified state is active.

In/Out	Name	Type	Description
[in] [out] [return]	State ESO	CapeString CapeInterface (IGPAlgESO) ^a CapeError	The name of the state of interest. The set of equations corresponding to this state.

^aThe "expected type" is given here as AlgebraicESO, because the client software (most likely a solver) can be confident that the ESO will support this interface. It should check whether the returned ESO includes differential variables by:

 $[\]bullet$ COM—calling query interface(IGPDiffAlgESO) on ESO.

[•] CORBA—calling IGPDiffAlgESO::_narrow on ESO.

Chapter 7

The gPROMS Dynamic Optimisation Object

Contents

7.1 7.2		The dynamic optimisation problem in gPROMS 146 The gPROMS Dynamic Optimisation Object 148				
7.3		ctional specification of the gDOO				
1.0	7.3.1	The Equation Set Object				
	7.3.2	The initial conditions				
	7.3.3	The time horizon and its partitioning				
	7.3.4	Partitioning of the ESO variables				
	7.3.5	The objective function				
	7.3.6	Interior point constraints				
	7.3.7	End-point constraints				
	7.3.8	The gDOO status				
7.4	Aux	iliary interfaces				
	7.4.1	The IBoundedQuantity interface				
	7.4.2	The IBoundedQuantityArray interface				
	7.4.3	The IIndexedBoundedQuantity interface				
7.5	The	IgD00 interface				
	7.5.1	Methods relating to the ESO				
	7.5.2	Methods relating to the initial conditions				
	7.5.3	Methods relating to the time horizon and its partitioning 166				
	7.5.4	Methods relating to the control variables				
	7.5.5	Methods relating to the time-invariant parameters 173				
	7.5.6	Methods relating to the fixed variables				
	7.5.7	Methods relating to the objective function				
	7.5.8	Methods relating to the interior point constraints 177				

7.5.9	Methods relating to the end-point constraints 179
7.5.10	Methods relating to the gDOO status
7.5.11	Methods relating to the optimisation type
7.5.12	Methods relating to the availability of lagrange multipliers 183
7.6 COF	RBA Interface Definitions
7.6.1	gDOO.idl
7.6.2	BoundedQuantity.idl
7.6.3	ControlVariable.idl
7.6.4	InteriorPointConstraint.idl
7.6.5	EndpointConstraint.idl
7.6.6	general.idl

7.1 The dynamic optimisation problem in gPROMS

Dynamic optimisation in gPROMS considers transient systems operating over a finite non-zero time horizon [0,T]. The latter is partitioned into K non-zero intervals $[t^k,t^{k+1}], k=0,..,K-1$ such that $t^0\equiv 0$ and $t^K\equiv T^1$.

The mathematical problem being solved by gPROMS is of the form:

$$\min_{T,v,\{\tau^k,\alpha^k,k=0,\dots,K-1\}} z_{i^*}(T) \tag{7.1}$$

subject to:

$$F(t, x(t), \dot{x}(t), y(t), u(t), v) = 0, \quad \forall t \in [0, T]$$
 (7.2)

$$z_i(0) = z_i^0, \quad \forall i \in \mathcal{I} \tag{7.3}$$

$$z_i^{k,\min} \le z_i(t^k) \le z_i^{k,\max}, \quad \forall i \in \mathcal{C}, k = 0, ..., K - 1$$

$$(7.4)$$

$$z_i^{K,\min} \le z_i(T) \le z_i^{K,\max}, \quad \forall i \in \mathcal{E}$$
 (7.5)

$$u(t) = \mathcal{U}(t, \alpha^k), \quad \forall t \in [t^k, t^{k+1}), k = 0, ..., K - 1$$
 (7.6)

$$u^{k,\min} \le u(t) \le u^{k,\max}, \quad \forall t \in [t^k, t^{k+1}), k = 0, ..., K - 1$$
 (7.7)

$$v^{\min} \le v \le v^{\max} \tag{7.8}$$

$$\tau^{k,\min} \le \tau^k \le \tau^{k,\max}, \quad \forall t \in [t^k, t^{k+1}), k = 0, ..., K - 1$$
 (7.9)

$$T^{\min} \le T \le T^{\max} \tag{7.10}$$

where:

$$\tau^k \equiv t^{k+1} - t^k, \quad \forall k = 0, .., K - 1$$
 (7.11)

¹In this section, subscripts generally denote elements of a vector while superscripts are used to denote symbols associated with a point in the time domain partition grid.

and therefore:

$$T = \sum_{k=0}^{K-1} \tau^k \tag{7.12}$$

The dynamic behaviour of the system is described by a system of differential and algebraic equations (DAEs) (cf. equation 7.2). These involve the independent variable t, differential variables $x(t) \in \Omega_x \subseteq \mathbb{R}^{n_x}$, the algebraic variables $y(t) \in \Omega_y \subseteq \mathbb{R}^{n_y}$, the control variables $u(t) \in \Omega_u \subseteq \mathbb{R}^{n_u}$, the time-invariant parameters $v \in \Omega_v \subseteq \mathbb{R}^{n_v}$, as well as the derivatives of x with respect to time, \dot{x} . The functions F are a vector of length $n_x + n_y$, i.e. $F: [0,T] \times \Omega_x \times \mathbb{R}^{n_x} \times \Omega_y \times \Omega_u \times \Omega_v \to \mathbb{R}^{n_x+n_y}$.

The vector z simply denotes the combination of x and y, *i.e.*:

$$\{z\} \equiv \{x\} \cup \{y\} \tag{7.13}$$

The indices of the differential variables x and algebraic variables y within the vector z are given by the index sets \mathcal{D} and \mathcal{A} respectively, *i.e.*:

$$\mathcal{D} \cup \mathcal{A} = \{1, ..., n_x + n_y\}; \qquad \mathcal{D} \cap \mathcal{A} = \emptyset$$
 (7.14)

The objective function to be minimised (or maximised) is the value of the i^* th element of z (cf. equation 7.1) at the final time T.

The initial condition of the system is specified in terms of given values z_i^0 of a subset of the variables z defined by the index set $\mathcal{I} \subseteq \{1,..,n_x+n_y\}$. It is assumed that the DAE system 7.2 is of index 1 and such that the matrix:

$$\left(\frac{\partial F}{\partial \dot{x}} \frac{\partial F}{\partial y}\right) \tag{7.15}$$

is non-singular. Therefore, the number of initial condition specifications is equal to the number of differential variables, i.e.:

$$|\mathcal{I}| = n_x \tag{7.16}$$

The optimisation may be subject to various interior point and end-point constraints (cf. equations 7.4 and 7.5 respectively). These two classes are expressed as lower and upper bounds imposed on subsets \mathcal{C} and \mathcal{E} of the variables z. Again, $\mathcal{C}, \mathcal{E} \subseteq \{1, ..., n_x + n_y\}$

The control variables u(t) in each interval k are restricted to parameterised functions \mathcal{U} of time t and a finite vector of parameters α^k (cf. equation 7.6). Different types of

parameterisation may be used for different control variables². The latter are restricted to lie between specified lower and upper bounds (cf. equation 7.7).

Lower and upper bounds are also imposed on the time-invariant parameters v, the lengths of the intervals τ^k and the overall time horizon T (cf. equations 7.8, 7.9 and 7.10).

7.2 The gPROMS Dynamic Optimisation Object

A gPROMS Dynamic Optimisation Object (gDOO) contains information on:

- the specification of a nonlinear dynamic optimisation problem of the form described in section 7.1;
- the solution of the optimisation problem.

Thus a gDOO is the primary means of communication between gPROMS and dynamic optimisation solvers—both native and external. More specifically, a "typical" sequence of operations will be as follows:

- 1. User selects a PROCESS in the gPROMS ModelBuilder, and selects Optimise... from the Activities menu.
- 2. gPROMS constructs a new gDOO.
- 3. gPROMS places in the gDOO all the relevant information defining the optimisation problem.
- 4. gPROMS passes the gDOO to a dynamic optimisation solver.
- 5. The dynamic optimisation solver solves the problem described in the gDOO.
- 6. The dynamic optimisation solver places the problem solution in the gDOO.
- 7. gPROMS retrieves the solution from the gDOO and transmits the results to an appropriate Output Channel.

Steps 4–6 above involve the dynamic optimisation solver. The interface that allows gPROMS to communicate with this type of software is described in detail in chapter 9. In this section, we present an interface to the gDOO aimed at supporting the operations described above as well as other related ones.

²At present, gPROMS supports only piecewise constant and piecewise linear parameterisations.

7.3 Functional specification of the gDOO

The gDOO comprises a set of data and operations that define the dynamic optimisation problem and allow various types of information about it to be obtained. These are described below.

7.3.1 The Equation Set Object

A key component of the gDOO is the set of variables and equations that describe the transient behaviour of the system to be optimised. This is described in terms of a differential-algebraic Equation Set Object (ESO) (see chapter 6 for details).

The ESO used in the gDOO describes a DAE system of the form:

$$F(\zeta, \dot{\zeta}, t) = 0, \tag{7.17}$$

where $\zeta(t)$ is the set of all variables in the gPROMS PROCESS under consideration:

$$\{\zeta\} \equiv \{x\} \cup \{y\} \cup \{u\} \cup \{v\} \cup \{w\}$$
 (7.18)

The set of variables w(t) comprises those that are *not* to be manipulated by the optimisation. Instead, they are given values of time (or constant). In gPROMS terms, these include the variables that are ASSIGNed but are neither control variables nor time-invariant parameters³ The ESO internally contains values of the independent variable t and all dependent variables $\zeta(t)$ as well as their time derivatives $\zeta(t)^4$. It also provides methods for accessing and changing these values, and for computing the corresponding values of the functions F and the partial derivatives $\partial F/\partial \zeta$ and $\partial F/\partial \dot{\zeta}$. Other information available include:

- the system size in terms of the numbers of variables ζ and equations F(.);
- the lower and upper bounds for the variables as specified in the gPROMS DECLARE and PRESET sections;
- the sparsity structures of the $\partial F/\partial \zeta$ and $\partial F/\partial \dot{\zeta}$ matrices.

The ESO is a *fundamental* part of the gDOO. This means that the ESO to be used in a certain gDOO is specified at the time that the gDOO is created and cannot be replaced by another ESO at a later stage. This restriction is introduced because most

³In some cases, w may also include control variables, the time variation of which is completely fixed in the optimisation entity by specifying identical lower and upper bounds on their parameterisations in each and every control interval.

⁴Note that ESOs created by gPROMS never involve directly the independent variable t.

other information in a gDOO refers to the ESO and is defined in relation to it⁵; consequently, permitting the replacement of the ESO in a gDOO by another ESO may create inconsistencies in existing data.

7.3.2 The initial conditions

The gDOO contains a number of initial condition specifications, each of which is generally characterised by:

- the index of the corresponding variable in the vector ζ (cf. equation 7.18);
- its value of the corresponding variable at the start of the optimisation;
- its value of the corresponding variable at the end of the optimisation;
- its lower and upper bounds on the corresponding variable;
- the Lagrange multipliers associated with the lower and upper bound constraints at the end of the optimisation.

Clearly, some of the above information is not relevant if the initial condition involves fixing a particular element of vector ζ at a specified value.

7.3.3 The time horizon and its partitioning

The gDOO is characterised by the number of control intervals, K. In addition, it contains the following information concerning the time horizon, T, and each of the control interval lengths τ^k , $k = 0.., K - 1^6$:

- the value at the start of the optimisation;
- the value at the end of the optimisation⁷;
- the lower and upper bounds;
- the Lagrange multipliers associated with the lower and upper bound constraints at the end of the optimisation.

⁵For example, all variables and constraints known to the optimisation, as well as the objective function itself, are defined in terms of their indices in the ESO variable vector.

⁶Obviously, information pertaining to the solution of an optimisation problem (e.g. the final values of variables, or the Lagrange multipliers associated with various constraints) will not be available before an optimisation calculation is actually attempted using the gDOO under consideration.

⁷A gDOO may be used for a sequence of optimisation calculations. In this chapter, the term "start (or end) of the optimisation" will always refer to the *last* optimisation calculation applied to the gDOO.

7.3.4 Partitioning of the ESO variables

The information described in section 7.3.1 is already made available by the ESO interface. Additionally, the gDOO contains information on the partitioning of the variable set ζ into x, y, u, v and w. It also contains other relevant information on the variables in each of these categories and also supports appropriate operations pertaining to these variables:

7.3.4.1 The control variables, u

For each control variable u, the gDOO contains the following information:

- the index of the corresponding variable in the vector ζ (cf. equation 7.18);
- the type of parameterisation applied to this control variable;
- for the control parameters α^k corresponding to this control variable in each control interval k = 0, ..., K 1:
 - their values at the start of the optimisation;
 - their values at the end of the optimisation;
 - their lower and upper bounds (cf. equation 7.7)
 - the Lagrange multipliers associated with the lower and upper bound constraints at the end of the optimisation.

The gDOO can also compute and provide the value of each control variable u at the current value of the independent variable t using the parameterisation given by equation (7.6), as well as the values of the partial derivatives $\partial \mathcal{U}/\partial \alpha$ and $\partial \mathcal{U}/\partial t$.

7.3.4.2 The time-invariant parameters, v

For each time-invariant parameter v, the gDOO contains the following information:

- the index of the corresponding variable in the vector ζ (cf. equation 7.18);
- its value at the start of the optimisation;
- its value at the end of the optimisation;
- its lower and upper bounds (cf. equation 7.8);
- the Lagrange multipliers associated with the lower and upper bound constraints at the end of the optimisation.

7.3.4.3 The fixed variables, w

The gDOO allows an external program to request that the values of the fixed variables w within the ESO are made consistent with the current value of the independent variable t.

7.3.5 The objective function

The objective function is associated with the following information:

- the index of the corresponding variable in the vector ζ (cf. equation 7.18);
- the value of the objective function at the start of the optimisation;
- the value of the objective function at the end of the optimisation.

7.3.6 Interior point constraints

For each interior point constraint (cf. equation 7.4), the gDOO contains the following information:

- the index of the corresponding variable in the vector ζ (cf. equation 7.18);
- the following information on the corresponding variable at each point k = 0, ..., K 1,
 - its value at the start of the optimisation;
 - its value at the end of the optimisation;
 - its lower and upper bounds;
 - the Lagrange multipliers associated with the lower and upper bound constraints at the end of the optimisation.

7.3.7 End-point constraints

For each end-point constraint (cf. equation 7.5), the gDOO contains the following information:

- the index of the corresponding variable in the vector ζ (cf. equation 7.18);
- its value of the corresponding variable at the start of the optimisation;
- its value of the corresponding variable at the end of the optimisation;

- its lower and upper bounds on the corresponding variable;
- the Lagrange multipliers associated with the lower and upper bound constraints at the end of the optimisation.

7.3.8 The gDOO status

Most applications will employ the gDOO in a straightforward "linear" manner of the type described in the introduction to section 7.2. However, in some cases, it may be necessary to support a more complex pattern of usage whereby a gDOO is formed, then used to solve a problem, then modified in a certain way before being used to solve another problem, and so on.

In order to facilitate such applications, the gDOO is always aware of its current status. It also allows external software access to this status. Valid values of a gDOO's status include:

- EmptygDOO: a newly created gDOO with no information other than the ESO used to create it (cf. section 7.3.1).
- IncompletegDOO: a gDOO that contains some information (beyond its ESO) but it is not yet complete (see below).
- CompletegDOO: a gDOO that contains sufficient information to define a complete dynamic optimisation problem, solution of which, however, has not yet been attempted. In practice, this information must, at a minimum, involve *all* of the following:
 - the objective function;
 - the time horizon information;
 - variable partitioning information such that:

$$\dim(x) + \dim(y) = \dim(F) \tag{7.19}$$

- at least one time-invariant parameter or control variable;
- SolvedgD00 This is a complete gDOO that has been solved successfully by a dynamic optimisation solver.
- FailedgD00 This is a complete gDOO, the attempted solution of which by a dynamic optimisation solver has failed.

Any modification of the information in a gDOO in whatever state changes its status to either IncompletegDOO or CompletegDOO.

7.4 Auxiliary interfaces

Much of the information contained within a gDOO shares common characteristics. For example, many quantities are restricted to lie between given lower and upper bounds; several other quantities are indexed over the number of intervals, k = 0, ..., K - 1. The auxiliary interfaces defined in this section aim at facilitating the handling of such information in a uniform manner.

7.4.1 The IBoundedQuantity interface

As seen in section 7.3, a common type of information in gDOO is a quantity, typically corresponding either to an optimisation decision variable or a constraint, that is bounded between given lower and upper bounds. In addition to the values of these bounds, gDOO also generally contains the values of the quantity itself at the start and at the end of an optimisation calculation, as well as appropriate Lagrange multiplier information.

The IBoundedQuantity interface specifically aims at managing this frequently occurring type of information, providing a set of methods for both accessing and modifying it.

IBoundedQuantity::SetBounds				
Description	Sets the values of the lower and upper bounds of the bounded quantity or modifies their existing values.			
Arguments	or modifies their existing varies.			

In/Out	Name	Type	Description
[in]	lowerBound upperBound	double double	The new value of the lower bound. The new value of the upper bound.

IBounded Quantity:: SetValueAtStart

Description

Sets the value of the bounded quantity at the start of the optimisation calculation.

Arguments

In/Out	Name	Type	Description
[in]	startingValue	double	The new starting value.

IBounded Quantity :: SetValueAtEnd

Description

Sets the value of the bounded quantity at the end of the last optimisation calculation.

Arguments

In/Out Name Type Description

[in] endValue double The new end value.

IBounded Quantity:: SetLagrangeMultipliers

Description

Sets the values of the Lagrange multipliers corresponding to the lower and upper bounds at the end of the last optimisation calculation.

Arguments

In/Out	Name	Type	Description
[in]	LBLagrange	double	The new value of the Lagrange multiplier associated with the lower bound imposed
[in]	UBLagrange	double	on the bounded quantity. The new value of the Lagrange multiplier associated with the upper bound imposed on the bounded quantity.

IBounded Quantity:: GetBounds

Description

Obtains the current values of the lower and upper bounds of the bounded quantity.

In/Out	Name	Type	Description
[out] [out]	lowerBound upperBound	double double	The current value of the lower bound. The current value of the upper bound.

IBounded Quantity:: GetValueAtStart

Description

Gets the value of the bounded quantity at the start of the optimisation calculation.

Arguments

In/Out	Name	Type	Description
[return]	startingValue	double	The current starting value.

IBounded Quantity:: GetValueAtEnd

Description

Gets the value of the bounded quantity at the end of the last opti-

misation calculation.

In/Out	Name	Type	Description
[return]	endValue	double	The current end value.

IBounded Quantity:: GetLagrangeMultipliers

Description

Gets the values of the Lagrange multipliers corresponding to the lower and upper bounds at the end of the last optimisation calculation.

Arguments

In/Out	Name	Type	Description
[out]	LBLagrange	double	The current value of the Lagrange multi- plier associated with the lower bound im-
[out]	UBLagrange	double	posed on the bounded quantity. The current value of the Lagrange multiplier associated with the upper bound imposed on the bounded quantity.

IBoundedQuantity::IsFullySpecified

Description

Returns TRUE if both the lower and upper bounds of the bounded quantity, as well as its value at the start of the optimisation have been specified; otherwise it returns FALSE.

IBoundedQuantity::IsFixed

Description

Returns TRUE if the lower and upper bounds of the bounded quantity have both been specified and currently have the same value; otherwise it returns FALSE.

IBoundedQuantity::Destroy

Description Destroys the IBoundedQuantity interface.

7.4.2 The IBoundedQuantityArray interface

Some information occurring in the gDOO involves ordered arrays of either single bounded quantities (*cf.* section 7.4.1) or vectors of bounded quantities. Such information includes the control interval lengths, the interior point constraints and the parameters that describe individual control variables.

The IBoundedQuantityArray interface aims at facilitating the handling of such information in a uniform manner. The array is empty on creation. Elements can then be created within it at specified positions; in general, each element can be a *vector* of bounded quantities. The length of this vector must be specified on creation. Specifying a length of 1 effectively results in the element of the list being a scalar.

IBoundedQuantityArray::GetNumberOfElements

Description

Gets the number of bounded quantities in the bounded quantity array.

Arguments

In/Out	Name	Type	Description
[return]	numberOf- Elements	long	The number of elements in the bounded quantity array.

IBoundedQuantityArray::IsFullySpecified

Description

Returns TRUE if both the lower and upper bounds of each and every element of the bounded quantity array, as well as their values at the start of the optimisation have been specified; otherwise it returns FALSE.

The following methods allow access to, and the manipulation of, individual elements of a bounded quantity array. Elements are specified by their position in the array, a number ranging from 0 to numberOfElements - 1.

IBoundedQuantityArray::GetElement

Description

Gets the bounded quantity at a specified position in the bounded quantity array.

Arguments

In/Out	Name	Type	Description
[in]	pos	long	The position of the desired bounded quantity.
[return]	BQList	IBounded- QuantityList	The list of bounded quantities at the specified position.

IBounded Quantity Array:: CreateElement

Description

Creates a new list of bounded quantities of specified length at a specified position in the bounded quantity array and returns an interface to it. If an element already exists at this position, an exception is thrown.

In/Out	Name	Type	Description
[in]	pos	long	The position where the new bounded quantity should be inserted.
[in] [return]	size BQList	long IBounded- QuantityList	The size of the list. An interface to the newly created list of bounded quantities.

IBounded Quantity Array:: CreateElementAtEnd

Description

Creates a new list of bounded quantities of specified length at the end the bounded quantity array and returns an interface to it.

Arguments

In/Out	Name	Type	Description
[in] [return]	size BQList	long IBounded- QuantityList	The size of the list. An interface to the newly created list of bounded quantities.

IBounded Quantity Array:: DeleteElement

Description

Deletes the element at a specified position in the bounded quantity array. Any elements to the right of this element are shifted one position to the left. The number of elements in the array is decreased by 1.

Arguments

In/Out	Name	Type	Description
[in]	pos	long	The position of the element to be deleted.

IBoundedQuantityArray::Destroy

Description Destroys the IBoundedQuantityArray interface.

7.4.3 The IIndexedBoundedQuantity interface

Some information occurring in the gDOO can be described in terms of a single bounded quantity (cf. section 7.4.1) plus an index denoting a position in the global variable vector ζ (cf. equation (7.18)). Information of this type includes the time-invariant parameters

and the end-point constraints, as well as the initial conditions.

The IIndexedBoundedQuantity interface aims at facilitating the handling of such information in a uniform manner. It inherits from interface IBoundedQuantity and extends it with methods allowing access to its index and its kind; the latter is of the enumerated type:

 $\label{eq:ibqk_undefined} \mbox{IBQK_TIME_INVARIANT, IBQK_ENDPOINT,} \\ \mbox{IBQK_INTERIORPOINT, IBQK_INITIAL_CONDITION}$

Both the index and the kind of an indexed bounded quantity are fundamental characteristics that are specified at the time of its creation and cannot be changed subsequently.

IIndexed Bounded Quantity:: GetIndex

Description

Gets the index of the indexed bounded quantity within the global variable vector ζ .

Arguments

In/Out	Name	Type	Description
[return]	Index	long	The indexed bounded quantity index.

IIndexed Bounded Quantity:: GetKind

Description

Gets the kind of the indexed bounded quantity.

]	In/Out	Name	Type	Description
[[return]	Kind	IBQKind	The indexed bounded quantity kind.

7.5 The IgD00 interface

To implement the functionality described in section 7.3, gDOO supports a number of methods. These are described in this section.

IgDOO::GetProcessName

Description Returns the name of the process being optimised. **Arguments**

In/Out	Name	Type	Description
[return]	name	string	The name of the process being optimised.

IgDOO::Destroy

Description Deletes the gDOO.

7.5.1 Methods relating to the ESO

IgDOO::GetDynamicESO

Description Gets the ESO used for the construction of the gDOO. **Arguments**

In/Out	Name	Type	Description
[return]	ESO	ICapeNumeric- Differential- AlgebraicESO	The ESO used for the construction of the gDOO.

${\tt IgDOO::} \textbf{GetInitialConditionESO}$

Description Arguments

Gets the ESO which represents the initial conditions.

In/Out Name Type Description [return] ESO ICapeNumeric-Differential-tions. The ESO representing the initial conditions. AlgebraicESO

${\tt IgDOO::SynchroniseTimeInvariantsWithESO}$

Description

Set the variables in the dynamic ESO which correspond to time invariant parameters to the current values of those parameters as held by the $\tt gDOO$.

${\tt IgDOO::SynchroniseControlsWithESO}$

Description

Get the current independent variable value from the dynamic ESO, and then set the variables in the dynamic ESO which correspond to controls to the current values of those controls as computed by the gD00.

7.5.2 Methods relating to the initial conditions

${\rm IgDOO}.: {\bf CreateInitialCondition}$

Description

Creates a new initial condition specification imposed on the variable with a specified index within the global variable vector ζ .

Arguments

In/Out	Name	Type	Description
[in]	index	long	The index of the new time-invariant parameter.
[return]	IC	IIndexed- BoundedQuantity	An interface to the new initial condition.

${\rm IgDOO} :: \textbf{DeleteInitialCondition}$

Description Arguments

Remove a specified initial condition from the list of initial conditions.

In/Out	Name	Type	Description
[in]	index	long	The index of the initial condition to be deleted.

${\rm IgDOO} :: {\bf GetInitial Conditions}$

Description

Gets the list of the initial conditions within the gDOO. In a newly created gDOO, this list is of zero length.

Arguments

In/Out	Name	Type	Description
[return]	ICs	IIndexed- Bounded- QuantityList	List of interfaces to the current initial conditions.

7.5.3 Methods relating to the time horizon and its partitioning

IgDOO::**GetTimeHorizon**

tion time horizon.

Description

Gets an interface to a bounded quantity representing the optimisa-

In/Out	Name	Type	Description
[return]	TimeHorizon	IBounded- Quantity	Interface to time horizon.

${\bf IgDOO} {::} {\bf GetControlIntervals}$

Description

Gets an interface to a bounded quantity vector representing the control intervals. In a newly created gDOO, this vector is of zero length.

Arguments

In/Out	Name	Type	Description
[return]	Control- Intervals	ITimeIntervalList	Interface to vector of control intervals.

IgDOO:: SetCurrentControlInterval

Description

Set which interval is the current one (first is 0).

Arguments

In/Out	Name	Type	Description
[in]	interval	long	The interval number.

IgDOO:: GetCurrentControlInterval

Description Arguments Return which interval is the current one (first is 0).

 In/Out
 Name
 Type
 Description

 [return]
 interval
 long
 The interval number.

7.5.4 Methods relating to the control variables

7.5.4.1 The IControlVariable interface

A control variable is a complex object that is characterised by several diverse items of information. Consequently, a separate interface, IControlVariable is introduced for a single control variable. We describe this interface here while the methods that the gDOO provides for the manipulation of the set of control variables with it are described in section 7.5.4.2.

Each control variable corresponds to a different variable in the global variable vector ζ , as described by its index. The variation of the control variable over the time horizon is assumed to be piecewise polynomial where the "pieces" correspond to the control intervals into which the time horizon has been partitioned. The polynomials in each piece are assumed to be of a given degree (a non-negative integer) and may exhibit a certain continuity at the interval boundaries; the continuity is an integer of value -1 or higher and which cannot exceed the degree of the polynomial.

The index, degree and continuity of a control variable are fundamental characteristics that are specified at the time of its creation and cannot be changed subsequently.

IControlVariable::GetIndex			
Description	Gets the index of the control variable within the global variable vector ζ .		

In/Out	Name	Type	Description
[return]	index	long	The control variable index.

IControlVariable::GetDegree

Description

Gets the polynomial degree of the control variable within each inter-

Arguments

In/Out	Name	Type	Description
[return]	degree	long	The control variable degree.

IControlVariable::GetContinuity

Description

Gets the order of continuity of the control variable at the control

interval boundaries.

Arguments

In/Out	Name	Type	Description
[return]	continuity	long	The control variable continuity.

Within each control interval, a control variable is described by a vector of parameters. The number of parameters in each interval depends on both the degree and the continuity of the variable, and is given by:

• Within the first interval, k = 1:

Number of Parameters = Degree + 1

• Within subsequent intervals, k = 2, ..., K:

Number of Parameters = Degree - Continuity

Each parameter describing a control variable over each control interval generally corresponds to a separate Bounded Quantity (cf. section 7.4.1). As there are generally several parameters associated with each control interval, the complete set of parameters for a certain control variable form a bounded quantity array (cf. section 7.4.2). This array

is constructed upon the creation of the control variable and is empty. The following method allows access to it.

IControlVariable::GetParameters

Description Gets the parameters that are associated with the control variable. **Arguments**

In/Out	Name	Type	Description
[return]	CVParameters	IBounded- QuantityArray	The control variable parameters.

IControl Variable:: GetControl Value

Description

Gets the value of the control variable computed at the current values of the parameters and time.

In/Out	Name	Type	Description
[return]	CVValue	double	The control variable value.

IControlVariable::GetControlDerivatives

Description

Gets the partial derivatives of the control variable with respect to all its parameters, computed at the current values of the parameters and time.

Arguments

In/Out	Name	Type	Description
[return]	CVDeriva- tives	DoubleList	The partial derivatives of the control variable with respect to the parameters, in the order in which the parameters appear in the corresponding IBoundedQuantityArray.

IControl Variable:: GetIntervalLengthDerivative

Description

Gets the partial derivative of the control variable with respect to the length of the interval, (on the assumption that the parameters remain fixed while the interval length is changed).

Arguments

In/Out	Name	Type	Description
[return]	derivative	double	The partial derivatives of the control variable with respect to the interval length.

IControlVariable::Destroy

Description Deletes the IControlVariable interface.

7.5.4.2 Methods for Manipulating the Control Variable List

${\rm IgDOO}.: {\bf CreateControlVariable}$

Description

Creates a new control variable corresponding to a variable with a specified index within the global variable vector ζ .

Arguments

In/Out	Name	Type	Description
[in] [in]	index degree	long long	The index of the new control variable The polynomial degree of the new control variable
[in]	continuity	long	The degree of continuity of the control variable
[return]	CV	IControlVariable	An interface to the new control variable.

${\rm IgDOO} :: \textbf{DeleteControlVariable}$

Description Arguments

Removes a specified variable from the list of control variables.

In/Out	Name	Type	Description
[in]	index	long	The index of the control variable to be deleted.

${\rm IgDOO}.: {\bf GetControlVariables}$

Description Gets the list of the control variables within the gDOO. In a newly created gDOO, this list is of zero length.

Arguments

In/Out	Name	Type	Description
[return]	CVs	IControlVariable- List	List of interfaces to the current control variables.

7.5.5 Methods relating to the time-invariant parameters

${\rm IgDOO} :: \textbf{CreateTimeInvariantParameter}$

Description	Creates a new time-invariant parameter corresponding to a variable
	with a specified index within the global variable vector ζ .

In/Out	Name	Type	Description
[in]	index	long	The index of the new time-invariant parameter.
[return]	TIP	IIndexed- BoundedQuantity	An interface to the new time-invariant parameter.

${\tt IgDOO::} \textbf{DeleteTimeInvariantParameter}$

Description Remove a specified variable from the list of time-invariant parameters.

Arguments

In/Out	Name	Type	Description
[in]	index	long	The index of the time-invariant parameter to be deleted.

${\tt IgDOO::} \textbf{GetTimeInvariantParameters}$

Description Gets the list of the time-invariant parameters within the gDOO. In a newly created gDOO, this list is of zero length.

In/Out	Name	Type	Description
[return]	TIPs	IIndexed- Bounded- QuantityList	List of interfaces to the current time-invariant parameters.

7.5.6 Methods relating to the fixed variables

${\tt IgDOO::} \textbf{CreateFixedVariable}$

Description Creates a new fixed variable corresponding to a variable with a spec-

ified index within the global variable vector ζ , and fixes its value at

a specified value.

Arguments

In/Out	Name	Type	Description
[in]	index	long	The index of the new fixed variable. The value of the new fixed variable.
[in]	value	double	

7.5.7 Methods relating to the objective function

${\tt IgDOO::} \textbf{SetObjectiveFunctionIndex}$

Description Sets the index of the objective function variable within the global

variable vector ζ .

In/Out	Name	Type	Description
[in]	index	long	The objective function index.

${\tt IgDOO::} \textbf{SetObjectiveFunctionValueAtStart}$

Description

Sets the value of the objective function at the start of the last optimisation calculation.

Arguments

In/Out	Name	Type	Description
[in]	value	double	The start value of the objective function.

${\tt IgDOO::} \textbf{SetObjectiveFunctionValueAtEnd}$

Description

Sets the value of the objective function at the end of the last optimisation calculation.

Arguments

In/Out	Name	Type	Description
[return]	value	double	The end value of the objective function.

${\tt IgDOO::} \textbf{GetObjectiveFunctionIndex}$

Description

Gets the index of the objective function variable within the global variable vector ζ .

In/Out	Name	Type	Description
[return]	index	long	The objective function index.

${\tt IgDOO::} \textbf{GetObjectiveFunctionValueAtStart}$

Description

Gets the value of the objective function at the start of the last optimisation calculation.

Arguments

In/Out	Name	Type	Description
[return]	value	double	The start value of the objective function.

IgDOO:: GetObjectiveFunctionValueAtEnd

Description

Gets the value of the objective function at the end of the last optimisation calculation.

Arguments

In/Out	Name	Type	Description
[return]	value	double	The end value of the objective function.

7.5.8 Methods relating to the interior point constraints

7.5.8.1The IInteriorpointConstraint interface

Each interior-point constraint is described by its index in the global variable vector ζ and the node for which it is valid. Consequently, the IInteriorpointConstraint interface inherits from IIndexedBoundedQuantity, extending it by the information pertaining to the node.

The index and the node of an interior point constraint is a fundamental characteristic that is specified at the time of its creation and cannot be changed subsequently.

IInteriorpointConstraint:: GetNode

Description

Gets the node of the interior point constraint for which the constraint

Arguments

In/Out	Name	Type	Description
[return]	node	long	The interior point constraint node.

7.5.8.2 Methods for manipulating the interior point constraint list

${\tt IgDOO::} \textbf{CreateInteriorpointConstraint}$

Description

Creates a new interior point constraint corresponding to a variable with a specified index and an interval in the time horizon.

In/Out	Name	Type	Description
[in]	index	long	The index of the new interior-point constraint.
[in]	interval	long	The interval for which the constraint is valid.
[return]	IPC	IInteriorpoint- Constraint	An interface to the new interior point constraint.

${\rm IgDOO::} \textbf{DeleteInteriorpointConstraint}$

Description Remove a specified variable from the list of interior-point constraints. **Arguments**

In/Out	Name	Type	Description
[in]	index	long	The index of the interior-point constraint to be deleted.

${\tt IgDOO::} \textbf{GetInteriorPointConstraints}$

Description G

Gets the list of the interior point constraints within the gDOO. In a newly created gDOO, this list is of zero length.

Arguments

In/Out	Name	Type	Description
[in]	index IPCs	long IInteriorpoint- ConstraintList	Index of the variable for which the constraints are retrieved. List of interfaces to the current interior point constraints.

7.5.9 Methods relating to the end-point constraints

As with interior-point constraints, an interface is defined for end-point constraints. The ${\tt IEndpointConstraint}$ interface inherits from ${\tt IIndexedBoundedQuantity}$ but, unlike the ${\tt IInteriorpointConstraint}$ interface, adds no further methods (i.e. it is an alias). The ${\tt IEndpointConstraintList}$ interface is simply a sequence of ${\tt IEndpointConstraint}$ interfaces.

${\tt IgDOO::} \textbf{CreateEndPointConstraint}$

Description

Creates a new end-point constraint corresponding to a variable with a specified index within the global variable vector ζ .

Arguments

In/Out	Name	Type	Description
[in] [return]	index EPC	long IEndpoint- Constraint	The index of the new end-point constraint. An interface to the new end-point constraint.

${\tt IgDOO::} \textbf{DeleteEndPointConstraint}$

Description Arguments Remove a specified variable from the list of end-point constraints.

In/Out Name Type Description

[in] index long The index of the end-point constraint to be deleted.

IgDOO::GetEndPointConstraints

Description

Gets the list of the end-point constraints within the gDOO. In a newly created gDOO, this list is of zero length.

Arguments

In/Out	Name	Type	Description
[return]	EPCs	IEndpoint- ConstraintList	List of interfaces to the current end-point constraints.

7.5.10 Methods relating to the gDOO status

The methods described in this section allow the modification of, and access to the gDOO status (*cf.* section 7.3.8). They make use of the following enumerated type:

gDOOStatus = {S_EMPTY, S_INCOMPLETE, S_COMPLETE, S_SOLVED, S_FAILED}

In general, the status of the gDOO is determined internally by the gDOO itself and cannot be changed by external software. The only relaxation to this rule is that external software (typically, a dynamic optimisation solver) can change the value of status from S_COMPLETE to either S_SOLVED or S_FAILED.

IgDOO::SetStatus

Description Arguments

Sets the current value of the gDOO Status.

In/Out	Name	Type	Description
[in]	status	gDOOStatus	The new status of the gDOO.

IgDOO::GetStatus

Description Gets the current value of the gDOO Status. **Arguments**

In/Out	Name	Type	Description
[return]	status	gDOOStatus	Current status of the gDOO.

7.5.11 Methods relating to the optimisation type

Two methods allow the optimisation type to be set and retrieved. They make use of the following enumerated type:

gD000ptimisationType = {OT_NONE, OT_MINIMISATION, OT_MAXIMISATION }

IgDOO::SetOptimisationType

Description Sets the current type of optimisation. **Arguments**

In/Out	Name	Type	Description
[in]	type	gDOOOptim	isation Type new type of optimisation for the gDOO.

${\tt IgDOO::} \textbf{GetOptimisationType}$

Description Gets the current type of the optimisation. **Arguments**

In/Out	Name	Type	Description
[return]	type	gDOOOptimisation	n TCymperent type of optimisation.

7.5.12 Methods relating to the availability of lagrange multipliers

The following two methods set and retrieve a boolean attribute signifying the availability of Lagrange multipliers.

${\tt IgDOO::} \textbf{SetLagrangeMultiplierAvailability}$

Description Sets the availability of Lagrange multipliers. **Arguments**

In/Out	Name	Type	Description
[in]	available	boolean	The new value of the availability of Lagrange multipliers ($\in \{True, False\}$).

${\tt IgDOO::} \textbf{SetLagrangeMultiplierAvailability}$

Description Returns the current availability of Lagrange multipliers. **Arguments**

In/Out	Name	Type	Description
[return]	available	boolean	The current value of the availability of Lagrange multipliers ($\in \{True, False\}$).

7.6 CORBA Interface Definitions

This section records the CIDL implementations of the interfaces described in the previous sections.

7.6.1 gDOO.idl

Th	ie	io	the	ton	امتحا	inter	faco
$T\Pi$	us.	12	une	UOD	16 ver	HILLET	race.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

#ifndef I_GD00_IDL

```
#define I_GD00_IDL
#include "general.idl"
#include "ICapeNumericDiffAlgESO.idl"
#include "BoundedQuantity.idl"
#include "ControlVariable.idl"
#include "InteriorpointConstraint.idl"
#include "EndpointConstraint.idl"
module psenterprise
    module Optimisation
        interface IgD00
            enum gD00Status {
                S_EMPTY,
                S_INCOMPLETE,
                S_COMPLETE,
                S_SOLVED,
                S_FAILED
            };
            enum gD000ptimisationType {
                OT_NONE,
                OT_MINIMISATION,
                OT_MAXIMISATION
            };
            gD00Status
                                   GetStatus();
                                   SetStatus(in gD00Status status);
            void
            gD000ptimisationType
                                   GetOptimisationType();
                                   SetOptimisationType(in gD000ptimisationType type);
            ICapeNumericDifferentialAlgebraicESO GetDynamicESO();
            ICapeNumericDifferentialAlgebraicESO GetInitialConditionESO();
            IIndexedBoundedQuantity
                                          CreateInitialCondition(in long index);
            void
                                          DeleteIntialCondition(in long index);
            IIndexedBoundedQuantityList GetInitialConditions();
            IBoundedQuantity
                                          GetTimeHorizon();
            ITimeIntervalList
                                          GetControlIntervals();
            void
                                          SetCurrentControlInterval(in long interval);
            long
                                          GetCurrentControlInterval();
            void
                                          SynchroniseControlsWithESO();
                                          SynchroniseTimeInvariantsWithESO();
            void
            IInteriorpointConstraint
                                          CreateInteriorpointConstraint(in long index,
```

```
in long interval);
            void
                                         DeleteInteriorpointConstraint(in long index);
            IInteriorpointConstraintList GetInteriorpointConstraints(in long index);
                                         CreateControlVariable(in long index,
            IControlVariable
                                                                in long degree,
                                                                in long continuitiy);
                                         CreateEndpointConstraint(in long index);
            IEndpointConstraint
            void
                                         DeleteEndpointConstraint(in long index);
            IEndpointConstraintList
                                         GetEndpointConstraints();
                                         DeleteControlVariable(in long index);
            void
            IControlVariableList
                                         GetControlVariables();
                                         CreateTimeInvariantParameter(in long index);
            IIndexedBoundedQuantity
                                         DeleteTimeInvariantParameter(in long index);
                                         GetTimeInvariantParameters();
            IIndexedBoundedQuantityList
            IIndexedBoundedQuantity
                                         CreateFixedVariable(in long index,
                                                              in double value);
            void
                        SetObjectiveFunctionIndex(in long index);
            void
                        SetObjectiveFunctionValueAtStart(in double value);
            void
                        SetObjectiveFunctionValueAtEnd(in double value);
            long
                        GetObjectiveFunctionIndex();
            double
                        GetObjectiveFunctionValueAtStart();
            double
                        GetObjectiveFunctionValueAtEnd();
            string
                        GetProcessName();
            boolean
                        LagrangeMultipliersAvailable();
            void
                        SetLagrangeMultiplierAvailability(in boolean available);
            void
                        Destroy();
        };
        interface IgDOOFactory
            IgD00 CreategD00(in ICapeNumericDifferentialAlgebraicESO theESO);
        };
    }; // module gD00
}; // module psenterprise
#endif // I_GD00_IDL
```

7.6.2 BoundedQuantity.idl

This file defines the BoundedQuantity, BoundedQuantityArray, TimeInterval and IndexBoundedQuantity interfaces used in the definition of the gDOO.

Copyright (c) 2001 Process Systems Enterprise Ltd.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef I_BOUNDED_QUANTITY_IDL
#define I_BOUNDED_QUANTITY_IDL
#include "general.idl"
module psenterprise
   module Optimisation
        interface IBoundedQuantity
            void GetBounds(out double lowerBound, out double upperBound);
            void SetBounds(in double lowerDouble, in double upperBound);
            double GetValueAtStart();
            void SetValueAtStart(in double startingValue);
            double GetValueAtEnd();
            void SetValueAtEnd(in double endValue);
            void GetLagrangeMultipliers(out double LBLagrange, out double UBLagrange);
            void SetLagrangeMultipliers(in double LBLagrange, in double UBLagrange);
            boolean IsFullySpecified();
            boolean IsFixed();
            void Destroy();
        }; // BoundedQuantity
```

```
interface ITimeInterval : IBoundedQuantity
            double GetStartTimeAtStart();
            void SetStartTimeAtStart(in double STime);
            double GetStartTimeAtEnd();
            void SetStartTimeAtEnd(in double STime);
        }; // TimeInterval
        typedef sequence<ITimeInterval> ITimeIntervalList;
        interface IBoundedQuantityArray
            long GetNumberOfElements();
            boolean IsFullySpecified();
            IBoundedQuantityList CreateElement(in long pos, in long size);
            IBoundedQuantityList CreateElementAtEnd(in long size);
            IBoundedQuantityList GetElement(in long pos);
            void DeleteElement(in long pos);
            void Destroy();
        }; // BoundedQuantityArray
        interface IIndexedBoundedQuantity : IBoundedQuantity
            enum IBQKind
            {
                IBQK_UNDEFINED,
                IBQK_TIME_INVARIANT,
                IBQK_ENDPOINT,
                IBQK_INTERIORPOINT,
                IBQK_INITIAL_CONDITION
            };
            long GetIndex();
            IBQKind GetKind();
        };
        typedef sequence<IIndexedBoundedQuantity> IIndexedBoundedQuantityList;
    }; // module gD00
}; // module
#endif // _I_BOUNDED_QUANTITY_IDL
```

typedef sequence<IBoundedQuantity> IBoundedQuantityList;

gPROMS	${\rm System}$	${\bf Programmer}$	Guide

7.6.3 ControlVariable.idl

Detailed information on a control variable (across the whole time horizon).

Copyright (c) 2001 Process Systems Enterprise Ltd.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef I_CONTROL_VARIABLE_IDL
#define I_CONTROL_VARIABLE_IDL
#include "general.idl"
#include "BoundedQuantity.idl"
module psenterprise {
    module Optimisation {
        interface IControlVariable {
            long GetIndex();
            long GetDegree();
            long GetContinuity();
            IBoundedQuantityArray GetParameters();
            double GetControlValue();
            DoubleList GetControlDerivatives();
            double GetTimeDerivative();
            void Destroy();
        };
        typedef sequence<IControlVariable> IControlVariableList;
```

```
interface IPiecewiseConstant : IControlVariable {
      };
      interface IPiecewiseLinear : IControlVariable {
      };
   }; // module gDOO
}; // module psenterprise
#endif // I_CONTROL_VARIABLE_IDL
7.6.4 InteriorPointConstraint.idl
An IPC is an indexed bounded quantity related to a particular node.
______
           Copyright (c) 2001 Process Systems Enterprise Ltd.
                          LEGAL NOTICE
   These coded instructions, statements, and computer programs contain
   proprietary information belonging to Process Systems Enterprise Ltd.,
   and are protected by International copyright law. They may not be
   disclosed to third parties without the prior written consent of
   Process Systems Enterprise Ltd.
#ifndef I_INTERIORPOINT_CONSTRAINT_IDL
#define I_INTERIORPOINT_CONSTRAINT_IDL
#include "general.idl"
#include "BoundedQuantity.idl"
module psenterprise
```

module Optimisation

{

```
interface IInteriorpointConstraint : IIndexedBoundedQuantity {
        long GetNode(); // time zero is node zero!
    };

    typedef sequence<IInteriorpointConstraint> IInteriorpointConstraintList;
    }; // module gDOO
}; // module
#endif // I_INTERIORPOINT_CONSTRAINT_IDL
```

7.6.5 EndpointConstraint.idl

Another specialisation on IndexedBoundedQuantity, although in this case nothing is added.

Copyright (c) 2001 Process Systems Enterprise Ltd.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd.,

and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef I_ENDIORPOINT_CONSTRAINT_IDL
#define I_ENDPOINT_CONSTRAINT_IDL

#include "general.idl"

#include "BoundedQuantity.idl"

module psenterprise
{
    module Optimisation
    {
        interface IEndpointConstraint : IIndexedBoundedQuantity {
        };
        typedef sequence<IEndpointConstraint> IEndpointConstraintList;
    }; // module gDOO
}; // module
#endif // I_ENDPOINT_CONSTRAINT_IDL
```

7.6.6 general.idl

All the above files make use of "general" definitions provided in this file.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef GENERAL_IDL
#define GENERAL_IDL
module psenterprise
{
      // Some general types
      typedef sequence<long>
                           LongSeq;
      typedef sequence<double> DoubleSeq;
      typedef sequence<boolean> BooleanSeq;
      typedef sequence<string> StringSeq;
      typedef sequence<long>
                           LongList;
      typedef sequence<double> DoubleList;
      typedef sequence<boolean> BooleanList;
      typedef sequence<string> StringList;
      //
      // Common user exceptions
      //-----
      // An object with a given name already exist in the scope
      exception ObjectAlreadyExistException {
      };
```

```
// An object with a given name not found in the scope
exception ObjectNotFoundException {
        string m_Reason;
};

// The given name is invalid
exception InvalidObjectNameException {
};

// The given kind is not acceptable
exception InvalidKindException {
};

#endif // GENERAL_IDL
```

Chapter 8

The gPROMS Numerical Solvers Interfaces

Contents

8.1	Intro	oduction
	8.1.1	Systems
	8.1.2	System Factories
8.2	Inte	rface overview
	8.2.1	Configurability of numerical solvers
8.3	Typ	es and values of algorithmic parameters and statistics . 201
8.4	ICap	peNumericSolverComponent
8.5	ICap	peNumericAttribute
	8.5.1	ICapeNumericStringAttribute
	8.5.2	ICapeNumericIntegerAttribute
	8.5.3	ICapeNumericRealAttribute
	8.5.4	ICapeNumericBooleanAttribute
	8.5.5	ICapeNumericEnumeratedAttribute
	8.5.6	ICapeNumericInterfaceAttribute
8.6	The	solver parameter interfaces
	8.6.1	ICapeNumericStringParameter
	8.6.2	ICapeNumericIntegerParameter
	8.6.3	ICapeNumericRealParameter
	8.6.4	ICapeNumericBooleanParameter
	8.6.5	ICapeNumericEnumeratedParameter
	8.6.6	ICapeNumericInterfaceParameter
8.7	Line	ear-Algebra components
	8.7.1	ICapeNumericLAComponent
	8.7.2	ICapeNumericLASystemFactory
	8.7.3	ICapeNumericLASystem

8.8	Non-	-linear algebra components
	8.8.1	ICapeNumericNLAComponent
	8.8.2	ICapeNumericNLASystemFactory
	8.8.3	ICapeNumericNLASystem
8.9	Diffe	erential algebraic equation components
	8.9.1	ICapeNumericDAEComponent
	8.9.2	ICapeNumericDAESystemFactory
	8.9.3	ICapeNumericDAESystem
8.10	COF	tBA interface definitions
	8.10.1	ICapeUtilityComponent.idl
	8.10.2	$ICape Numeric Solver Component. idl. \dots \dots$
	8.10.3	$ICape Numeric Attribute. idl \\ \ldots \\ \ldots \\ 235$
	8.10.4	$ICape Numeric Parameter. idl \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $
	8.10.5	$ICape Numeric Statistic.idl \dots \dots$
	8.10.6	ICape Numeric LA Component. idl
	8.10.7	$ICape Numeric LA System. idl \ . \ . \ . \ . \ . \ . \ . \ . \ . \ $
	8.10.8	ICapeNumericNLAComponent.idl
	8.10.9	ICapeNumericNLASystem.idl
	8.10.10	OICapeNumericDAEComponent.idl
	8.10.11	ICapeNumericDAESystem.idl

8.1 Introduction

gPROMS provides capabilities and open interfaces for the solution of five different types of mathematical problem:

- 1. The solution of square systems of linear algebraic equations.
- 2. The solution of square systems of non-linear algebraic equations.
- 3. The solution of square systems of mixed ordinary differential and algebraic equations (DAEs) over time or another independent variable.
- 4. The solution of dynamic optimisation problems.
- 5. The solution of parameter estimation problems.

8.1.1 Systems

The above is achieved by introducing five different classes of object, each corresponding to one of the problems listed above. In the rest of this document, these objects are generally referred to as "Systems":

- 1. The Linear Algebraic System (*LASystem*) object.
- 2. The Non-Linear Algebraic System (*NLSystem*) object.
- 3. The Differential-Algebraic Equation System (DASystem) object.
- 4. The Dynamic Optimisation System (DOSystem) object.
- 5. The Parameter Estimation System (*PESystem*) object.

Each of these contains both the data that characterise the corresponding mathematical problem and the numerical algorithms that solve this problem.

8.1.2 System Factories

In addition to the five types of System defined above, five Factory classes are introduced. These are used to create instances of the corresponding Systems using information that defines the structure of each such instance.

- 1. The Linear Algebraic System Factory (*LASystemFactory*).
- 2. The Non-Linear Algebraic System Factory (*NLSystemFactory*).
- 3. The Differential-Algebraic Equation System Factory (DASystemFactory).

- 4. The Dynamic Optimisation System Factory (DOSystemFactory).
- 5. The Parameter Estimation System Factory (*PESystemFactory*).

WARNING!

As the CAPE-OPEN standard is still in development, the current interface definition may change in line with any updates in the CAPE-OPEN standard.

8.2 Interface overview

We note the following key points:

- 1. All components must support¹ the basic *ICapeUtilityComponent* interface. This provides some basic functionality regarding the identification of components, their versioning and so on.
- 2. Two interfaces are inherited directly from ICapeUtilityComponent:
 - (a) ICapeNumericSolverComponent is the basic interface for all Systems and System Factories. Its main function is to provide a general and uniform way for configuring these via the setting of various algorithmic parameters (e.g. convergence tolerances etc.) to appropriate values.
 - (b) ICapeNumericAlgebraicESO is the basic interface to all Equation Set Objects. In particular, it provides the full functionality required to describe a set of non-linear algebraic equations.
- 3. Five different interfaces are inherited from ICapeNumericSolverComponent, namely:
 - (a) ICapeNumericLAComponent
 - (b) ICapeNumericNLAComponent
 - (c) ICapeNumericDAEComponent
 - (d) IqDOSolverComponent
 - (e) IPESolverComponent

Each of these corresponds to one of the five types of mathematical problem described in section 8.1. Their basic function is to provide ways in which algorithmic parameters that are associated with numerical codes of the corresponding type can be altered. These parameters will generally differ from one type of solver to another. For instance, non-linear equation solvers are characterised by

¹Via direct or indirect inheritance, in the case of CORBA.

- a convergence tolerance while DAE integrators require absolute and relative error tolerances. However, it is assumed that any parameters defined at this level will be recognised by all solvers of a certain type.
- 4. Inherited methods are documented only under the parent interface which defines them.
- 5. All methods should return a CapeError value. One role of this value is to report a successful execution: the error conditions applicable to each method will have to be defined as part of the refinement of this interface definition.

8.2.1 Configurability of numerical solvers

It will be clear from the discussion in section 8.2 that algorithmic parameters are a major consideration as far as gPROMS is concerned. It is, therefore, important to understand the precise role of these parameters in the various classes that have been described:

- The values of the parameters in an instance of a certain class of System (e.g. NLASystem) configure the behaviour of this particular instance. For example, a parameter called MaxIterations could determine the maximum number of iterations that a given NLASystem would take towards its solution.
- The values of the parameters in an instance of a certain class of
- SystemFactory (e.q. NLASystemFactory) could serve two quite different roles:
 - A parameter could configure the behaviour of any System that is subsequently created by this SystemFactory. For example, a parameter called MaxIterations in an NLASystemFactory could determine the (initial) value of the parameter MaxIterations in any NLASystem created by it².
 - A parameter could configure the behaviour of this particular SystemFactory instance itself. Such parameters could determine some aspect of the structure of the Systems generated by this factory that cannot be changed after these Systems are created. An example could be a SystemFactory that has access to two different versions of a particular linear solver; in this case, one of its parameters could be used to determine which of the two solvers will be incorporated in any System created by this factory³.

 $^{^2}$ Of course, the value of MaxIterations in this System instance can later be changed by making use of the SetParameter method associated with this System.

³Of course, a different approach in this case would be to have two different classes of SystemFactory, each corresponding to a different version of the solver.

8.3 Types and values of algorithmic parameters and statistics

The algorithmic parameters and statistics handled by the various interfaces presented in this chapter may contain single values or arrays of any one of the following types:

- CapeString
- CapeLong
- CapeDouble
- CapeBoolean
- CapeInterface
- "enumerated".

For each type, a different derived class of ICapeNumericAttribute is provided.

It is particularly worth noting that some algorithmic parameters are of type CapeInter-face. Consider, for example, a non-linear algebraic equation solver based on a Newton or quasi-Newton iterative scheme. An important parameter in this case would be the linear algebra solver that is used to solve the set of linear equations arising at each iteration. In our interfaces, such a parameter would be an interface to a SystemFactory (e.g. ICapeNumericLASystemFactory in the example just mentioned). Once this interface is made available, the non-linear solver may use it to create one or more LASystems as and when required.

8.4 ICapeNumericSolverComponent

Inherits from: ICapeUtilityComponent

This interface exists to provide facilities for identifying the various algorithmic parameters (e.g. convergence accuracy, integration error tolerances etc.) and statistics (e.g. number of times used, CPU consumption) that are recognised by a numerical solver, and for altering the values of parameters if necessary.

The following enumeration is used:

```
enum CapeSolverType
{
    CAPE_LA_SOLVER, CAPE_NLA_SOLVER, CAPE_DAE_SOLVER,
    CAPE_PE_SOLVER, CAPE_DO_SOLVER
};
```

ICapeNumericSolverComponent::GetType

Description Arguments Gets the type of a solver component.

In/Out	Name	Type	Description
[return]		CapeSolverType	Type of the current solver — see above for possible values.

ICape Numeric Solver Component :: GetParameters

Description

Gets the list of parameters with which a Solver Component (i.e. a

System or a SystemFactory) can be configured.

Arguments

In/Out	Name	Type	Description
[return]		CapeArrayInterface (ICapeNumeric- Parameter)	Interfaces allowing access to the parameters and their associated information

ICape Numeric Solver Component :: GetParameterByName

Description Get the interface to a given known parameter with which a Solver-Component (*i.e.* a System or a SystemFactory) can be configured.

Arguments

In/Out	Name	Type	Description
[return]		CapeInterface (ICapeNumeric- Parameter)	Interface allowing access to the parameter and its associated information: null CORBA pointer if wrong name.

ICape Numeric Solver Component :: GetStatistics

Description Gets the list of statistics providing information on usage of a Solver-

Component (i.e. a System or a SystemFactory).

Arguments

In/Out	Name	Type	Description
[return]			Interfaces allowing access to the statistics and their associated information

ICapeNumeric	SolverComponent::	GetStatisticByName
---------------------	-------------------	--------------------

Get the interface of the named statistic of a SolverComponent (i.e. Description a System or a SystemFactory).

Arguments

In/Out	Name	Type	Description
[return]		CapeInterface (ICapeNumeric- Statistic)	Interface allowing access to the statistic and its associated information: null CORBA pointer if wrong name.

ICapeNumericAttribute 8.5

This interface exists to provide a base class for individual Parameter and Statistic interfaces.

The following enumeration is used:

enum CapeNumericAttributeType { STRING_ATTRIBUTE,

INTEGER_ATTRIBUTE, REAL_ATTRIBUTE, BOOLEAN_ATTRIBUTE,

ENUMERATED_STRING_ATTRIBUTE, SOLVER_INTERFACE_ATTRIBUTE };

ICape Numeric Attribute :: Get Name

Description Gets the name of the attribute.

_	CDCLIP	0101
A	rgume	$_{ m ents}$

In/Out	Name	Type	Description
[return]		CapeString	Name of the attribute.

ICapeNumericAttribute::GetDescription

Description

Gets a description of the attribute. Implementors should ensure that parameters are described adequately for online documentation.

Arguments

In/Out	Name	Type	Description
[return]		CapeString	Description of the attribute.

ICapeNumericAttribute::GetType

Description

Gets the type of the attribute.

Arguments

In/Out	Name	Type	Description
[return]		CapeNumeric- AttributeType	Type of the current attribute — see above for possible values.

ICapeNumericAttribute::GetDimensionality

Description

Gets the "size" of the attribute as a multi-dimensional array of values. E.g. a 2-by-3-by-4 array would be described by the sequence $\{2,3,4\}$. For scalar values a zero length sequence or $\{1\}$ should be returned.

Arguments

In/Out	Name	Type	Description
[return]		CapeArrayLong	The list of sizes.

8.5.1 ICapeNumericStringAttribute

Inherits from: ICapeNumericAttribute

This interface extends ICapeNumericAttribute with a GetValue method appropriate for strings.

ICapeNumericStringAttribute::GetValue

Description Gets the value of (an element of) the attribute. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar attributes)
[return]		CapeString	Value of the element.

$\bf 8.5.2 \quad ICape Numeric Integer Attribute$

Inherits from: ICapeNumericAttribute

This interface extends ICapeNumericAttribute with a GetValue method appropriate for integers.

ICape NumericInteger Attribute:: GetValue

Description Gets the value of (an element of) the attribute. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar attributes)
[return]		CapeLong	Value of the element.

8.5.3 ICapeNumericRealAttribute

Inherits from: ICapeNumericAttribute

This interface extends ICapeNumericAttribute with a GetValue method appropriate for reals.

ICape Numeric Real Attribute :: GetValue

Description Gets the value of (an element of) the attribute. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar attributes)
[return]		CapeDouble	Value of the element.

$\bf 8.5.4 \quad ICape Numeric Boolean Attribute$

Inherits from: ICapeNumericAttribute

This interface extends ICapeNumericAttribute with a GetValue method appropriate for booleans.

ICape Numeric Boolean Attribute :: GetValue

Description Gets the value of (an element of) the attribute. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar attributes)
[return]		CapeBoolean	Value of the element.

8.5.5 ICapeNumericEnumeratedAttribute

Inherits from: ICapeNumericAttribute

This interface extends ICapeNumericAttribute with methods appropriate for DIY enumerations, i.e. strings from a restricted set of values.

ICapeNumericEnumeratedAttribute::GetPossibleValues

Description

Returns the set of possible values this attribute may take. In the case of array attributes, this set of possible values applies to all elements.

Arguments

In/Out	Name	Type	Description
[return]		CapeArrayString	The values.

ICape Numeric Enumerated Attribute:: GetValue

Description Arguments

Gets the value of (an element of) the attribute.

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar attributes)
[return]		CapeString	Value of the element.

8.5.6 ICapeNumericInterfaceAttribute

Inherits from: ICapeNumericAttribute

This interface extends ICapeNumericAttribute with a GetValue method appropriate for CORBA interfaces, together with a utility method to determine the solver type to which the interface refers.

ICapeNumericInterfaceAttribute::GetSolverType

Description Returns the type of solver required for this attribute — see section

8.4 for possible values. In the case of array attributes, this set of

possible values applies to all elements.

Arguments

In/Out	Name	Type	Description
[return]		CapeSolverType	The type.

ICapeNumericInterfaceAttribute::GetValue

Description Gets the value of (an element of) the attribute.

Arguments

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar attributes)
[return]		CapeInterface	Value of the element.

8.6 The solver parameter interfaces

This set of six interfaces inherit from the corresponding numeric component attribute interfaces, as described below:

8.6.1 ICapeNumericStringParameter

Inherits from: ICapeNumericStringAttribute

This interface extends ICapeNumericStringAttribute with a SetValue method appropriate for strings.

ICape Numeric String Parameter:: SetValue

Description Sets the value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element to be set (ignored for scalar parameters)
[in]		CapeString	New value of the element.

8.6.2 ICapeNumericIntegerParameter

 $Inherits\ from:\ ICapeNumericIntegerAttribute$

This interface extends ICapeNumericIntegerAttribute with a SetValue method appropriate for integers, and with bounds checking methods.

ICape Numeric Integer Parameter:: SetValue

Description Sets the value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element to be set (ignored for scalar parameters)
[return]		CapeLong	Value of the element.

ICape Numeric Integer Parameter:: GetLowerBound

Description Gets the lowest permitted value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar parameters)
[return]		CapeLong	The lower bound.

ICape Numeric Integer Parameter:: GetUpperBound

Description Gets the highest permitted value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong CapeLong	Index of the element required (ignored for scalar parameters) The upper bound.
[recurii]		Capelong	The upper bound.

8.6.3 ICapeNumericRealParameter

Inherits from: ICapeNumericRealAttribute

This interface extends ICapeNumericRealAttribute with a SetValue method appropriate for reals, and with bounds checking methods.

ICapeNumericRealParameter::SetValue

 $\begin{array}{ll} \textbf{Description} & \text{Sets the value of (an element of) the parameter.} \\ \textbf{Arguments} & \end{array}$

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element to be set (ignored for scalar parameters)
[in]		CapeDouble	New value of the element.

ICape Numeric Real Parameter :: GetLowerBound

Description Gets the lowest permitted value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar parameters)
[return]		CapeDouble	The lower bound.

ICape Numeric Real Parameter :: Get Upper Bound

Description Gets the highest permitted value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element required (ignored for scalar parameters)
[return]		CapeDouble	The upper bound.

8.6.4 ICapeNumericBooleanParameter

Inherits from: ICapeNumericBooleanAttribute

This interface extends ICapeNumericBooleanAttribute with a SetValue method appropriate for booleans.

ICape Numeric Boolean Parameter:: SetValue

Description Sets the value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element to be set (ignored for scalar parameters)
[in]		CapeBoolean	New value of the element.

8.6.5 ICapeNumericEnumeratedParameter

 $Inherits\ from:\ ICapeNumericEnumeratedAttribute$

This interface extends ICapeNumericEnumeratedAttribute with a SetValue method appropriate for this type.

ICapeNumericEnumeratedParameter::SetValue

Description Sets the value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element to be set (ignored for scalar parameters)
[in]		CapeString	New value of the element.

8.6.6 ICapeNumericInterfaceParameter

Inherits from: ICapeNumericInterfaceAttribute

This interface extends ICapeNumericInterfaceAttribute with a SetValue method appropriate for CORBA interfaces.

 $ICape Numeric Interface Parameter:: {\bf SetValue}$

Description Sets the value of (an element of) the parameter. **Arguments**

In/Out	Name	Type	Description
[in]	element	CapeArrayLong	Index of the element to be set (ignored for scalar parameters)
[in]		CapeInterface	New value of the element.

8.7 Linear-Algebra components

This section describes the collection of interfaces used for linear algebra solvers. These are concerned with the definition and solution of square, linear systems of algebraic

equations of the form:

$$Ax = b$$
.

Here A and b are a (known) $n \times n$ real matrix and a (known) real vector of length n respectively, while x is an (unknown) real vector of length n to be computed as the solution of the linear system.

In the interests of efficiency in computation and memory utilisation, a sparse format is used for the matrix A. This stores only the NZ non-zero elements in this matrix⁴. The position of each of these elements is defined in terms of the indices of the row and column in which it occurs.

The size of the system, together with the number and position of the non-zero elements in the matrix A, define the *structure* of a linear system.

8.7.1 ICapeNumericLAComponent

Inherits from: ICapeNumericComponent

This interface defines methods for the identification and setting of parameters that will occur in all CAPE-OPEN compliant linear algebra components. Thus far, no such generic parameters have been identified.

8.7.2 ICapeNumericLASystemFactory

Inherits from: ICapeNumericLAComponent

This is the interface of the LASystemFactory which creates and configures LASystems given the matrix structure which defines them.

⁴Usually, but not always, the number of non-zero elements, NZ, will be much smaller than n^2 .

 $ICape Numeric LA System Factory:: {\bf Create LA System}$

Description Creates an LASystem with a given sparsity structure. **Arguments**

In/Out	Name	Type	Description
[in]	N	CapeLong	The number of rows and columns of the matrix.
[in]	NonZeroes	CapeLong	The number of non-zero elements in the matrix structure.
[in]	RowNums	CapeArrayLong	The row positions of the non-zero elements.
[in]	ColNums	CapeArrayLong	The column positions of the non-zero elements.
[out]	TheLASystem	CapeInterface (ICapeNumeric- LASystem) ^a	The LASystem created by the factory.
[return]		CapeError	

 $[^]a$ This notation is used throughout this document to indicate the expected type of interface for each method argument of type CapeInterface.

8.7.3 ICapeNumericLASystem

Inherits from: ICapeNumericLAComponent

This interface permits operations on LASystems created via the ICapeNumericLASystemFactory interface. In particular, it allows the specification of numerical values for the non-zero elements of the matrix A and the right hand side vector b, as well as obtaining the solution x of the linear system thus defined.

Note that it is *not* possible to alter the structure of an LASystem after its creation by an LASystemFactory.

ICape Numeric LA System:: SetMatrixVals

Description Sets the numerical values of the non-zero elements of an LASystem's matrix.

Arguments

In/Out	Name	Type	Description
[in]	MatrixVals	CapeArrayDouble	The values of the non-zero matrix elements.
[return]		CapeError	

ICape Numeric LA System:: GetMatrixVals

Description Gets the numerical values of the non-zero elements of an LASystem's matrix.

[out] MatrixVals CapeArrayDouble The values of the non-zero matrix ele-	In/Out	Name	Type	Description
[return] CapeError		MatrixVals		The values of the non-zero matrix elements.

ICapeNumericLASystem::SetRHS

Description Sets the numerical values of an LASystem's right hand side. **Arguments**

In/Out	Name	Type	Description
[in] [return]	RHSVals	CapeArrayDouble CapeError	The values of the right hand side vector.

ICapeNumericLASystem::GetRHS

Description Gets the numerical values of an LASystem's right hand side. **Arguments**

In/Out	Name	Type	Description
[out] [return]	RHSVals	CapeArrayDouble CapeError	The values of the right hand side vector.

ICapeNumericLASystem::GetSolution

Description Gets the solution of the current linear system. **Arguments**

In/Out	Name	Type	Description
[out] [return]	X	CapeArrayDouble CapeError	The solution of the current linear algebra problem.

8.8 Non-linear algebra components

In this section we define the interfaces related to the solution of sets of non-linear algebraic equations.

8.8.1 ICapeNumericNLAComponent

Inherits from: ICapeNumericSolverComponent

This interface defines methods for the identification and setting of parameters that will occur in *all* CAPE-OPEN compliant non-linear algebra components. A small number of such generic parameters have been identified; separate methods are defined for obtaining information on, and changing the value of each such parameter.

ICape Numeric NLA Component :: Set Convergence Tolerance

Description

Sets the convergence tolerance to be used in solving a non-linear system. The precise interpretation of this parameter will depend on individual implementations; the nature of the convergence criterion used by non-linear solvers is not defined by CAPE-OPEN.

In/Out	Name	Type	Description
[in] [return]	ConvTolValue	CapeDouble CapeError	The convergence tolerance value.

ICape Numeric NLA Component :: GetConvergenceTolerance

Description

Gets information on the convergence tolerance to be used in solving a non-linear system, as well as its current value. The precise interpretation of this parameter will depend on individual implementations; the nature of the convergence criterion used by non-linear solvers is not defined by CAPE-OPEN.

Arguments

In/Out	Name	Type	Description
[out]	ConvTol	ICapeNumeric- RealParameter CapeError	Information on the convergence tolerance parameter (see section 8.2.1).

ICapeNumericNLAComponent::SetMaxIterations

Description

Sets the maximum number of iterations to be used in solving a non-linear system. The precise interpretation of this parameter will depend on individual implementations; the nature of what constitutes an "iteration" used by non-linear solvers is not defined by CAPE-OPEN.

In/Out	Name	Type	Description
[in]	MaxItsValue	CapeLong	The maximum number of iterations to be performed.
[return]		CapeError	

ICape Numeric NLA Component :: GetMaxIterations

Description

Gets information on the maximum number of iterations to be used in solving a non-linear system, as well as its current value. The precise interpretation of this parameter will depend on individual implementations; the nature of what constitutes an "iteration" used by non-linear solvers is not defined by CAPE-OPEN.

Arguments

In/Out	Name	Type	Description
[out]	MaxIts	ICapeNumeric- IntegerParameter CapeError	Information on the maximum iterations parameter.

ICapeNumericNLAComponent::SetLASystemFactory

Description

Specifies an LASystemFactory that an NLAComponent may use to create one or more LASystems, the solution of which occurs as a sub-problem in the solution of the non-linear algebraic system.

In/Out	Name	Type	Description
[in]	LASystemF	CapeInterface (ICapeNumeri- cLASystemFac-	An LASystemFactory that the NLAComponent may use for creating any LASystems that it may need.
[return]		tory) CapeError	

ICape Numeric NLA Component :: GetLASystemFactory			
Description	Gets the LASystemFactory that an NLAComponent is using to create one or more LASystems, the solution of which occurs as a subproblem in the solution of the non-linear algebraic system.		
Arguments			

In/Out	Name	Type	Description
[out]	LASystemF	ICapeNumeric- Interface-	Information on the LASystemFactory which the NLAComponent is currently us-
[return]		Parameter CapeError	ing.

8.8.2 ICapeNumericNLASystemFactory

 $Inherits\ from :\ ICapeNumericNLAC omponent$

This is the interface of the Non-Linear Algebraic System Factory, which creates and configures Non-linear Algebraic Systems given the algebraic ESOs which define them.

ICapeNumericNLASystemFactory::CreateNLASystem		
Description Arguments	Creates an NLASystem with a given set of algebraic equations.	

In/Out	Name	Type	Description
[in]	TheESO	CapeInterface (ICapeNumeri-	The algebraic ESO which defines this system.
[out]	TheNLASystem	(ICapeNumericN-	The NLASystem instance created by the factory.
[return]		LASystem) CapeError	

8.8.3 ICapeNumericNLASystem

Inherits from: ICapeNumericNLAComponent

This is the interface of the Non-Linear Algebra Object, which solves systems of equations of the form:

$$f(x) = 0.$$

ICapeNumericNLASystem:: GetESO

Description Gets the ESO with which an NLASystem was constructed. **Arguments**

In/Out	Name	Type	Description
[out]	ESO	CapeInterface (ICapeNumeri-	The ESO with which the NLASystem was constructed.
[return]		cAlgebraicESO) CapeError	

ICape Numeric NLA System:: Solve

Description Attempt to solve the non-linear algebra problem. Note: the initial guesses for this solution will be the ESO's current variable values.

In/Out	Name	Type	Description
[return]		CapeError	

ICapeNumericNLASystem::DoOneIteration		
Description Arguments	Perform a single iteration on the non-linear algebra problem. Note: the nature of what constitutes an "iteration" used by non-linear solvers is not defined by CAPE-OPEN.	

In/Out	Name	Type	Description
[return]		CapeError	

8.9 Differential algebraic equation components

In this section, we describe the interfaces related to the solution of differential-algebraic equation systems.

8.9.1 ICapeNumericDAEComponent

Inherits from: ICapeNumericSolverComponent

This interface defines methods for the identification and setting of parameters that will occur in *all* CAPE-OPEN compliant differential-algebraic components. A small number of such generic parameters have been identified; separate methods are defined for obtaining information on, and changing the value of each such parameter.

ICape Numeric DAE Component :: SetAbsoluteTolerance

Description

Sets the absolute tolerance to be used in performing local error tests while solving the DAE system. The precise interpretation of this parameter will depend on individual implementations; the exact nature of the error measure used (e.g. local truncation error, local error etc.) and the way in which this is estimated are not defined by CAPE-OPEN.

Arguments

In/Out	Name	Type	Description
[in] [return]	ATolValue	CapeDouble CapeError	The absolute tolerance value.

ICape Numeric DAE Component :: GetAbsoluteTolerance

Description

Gets information on the absolute tolerance to be used in performing local error tests while solving a DAE system, as well as the current value of this parameter. The precise interpretation of this parameter will depend on individual implementations; the exact nature of the error measure used (e.g. local truncation error, local error etc.) and the way in which this is estimated are not defined by CAPE-OPEN.

In/Out	Name	Type	Description
[out] [return]	ATol	ICapeNumeric- RealParameter CapeError	Information on the absolute tolerance parameter (see section 8.2.1).

ICape Numeric DAE Component ::

Description Arguments

In/Out	Name	Type	Description
[return]		CapeError	

ICape Numeric DAE Component :: Set Relative Tolerance

Description

Sets the relaitive tolerance to be used in performing local error tests while solving the DAE system. The precise interpretation of this parameter will depend on individual implementations; the exact nature of the error measure used (e.g. local truncation error, local error etc.) and the way in which this is estimated are not defined by CAPE-OPEN.

In/Out	Name	Type	Description
[in] [return]	RTolValue	CapeDouble CapeError	The relative tolerance value.

ICape Numeric DAE Component :: GetRelative Tolerance

Description

Gets information on the relative tolerance to be used in performing local error tests while solving a DAE system, as well as the current value of this parameter. The precise interpretation of this parameter will depend on individual implementations; the exact nature of the error measure used (e.g. local truncation error, local error etc.) and the way in which this is estimated are not defined by CAPE-OPEN.

Arguments

In/Out	Name	Type	Description
[out]	RTol	ICapeNumeric- RealParameter CapeError	Information on the relative tolerance parameter (see section 8.2.1).

8.9.2 ICapeNumericDAESystemFactory

Inherits from: ICapeNumericDAEComponent

This is the interface of the Differential-Algebraic Equation System Factory which creates and configures DAE Systems given the Differential Algebraic ESO which defines them.

ICaı	peNumerio	${ m cDAES}$ vstem	Factory::Create	eDAESvstem
------	-----------	--------------------	-----------------	------------

Description Uses a given ESO to create a DAESystem. Note — this should be the

ESO of the dynamic model only: the initial conditions are provided

by alternative mechanisms, see below.

Arguments

In/Out	Name	Type	Description
[in]	TheESO	CapeInterface (ICapeNumericD- ifferentialAlge- braicESO)	The differential-algebraic ESO which defines this system.
[out]	DAESystem	CapeInterface (ICapeNumeric- DAESystem)	The DAESystem instance created by the factory.

8.9.3 ICapeNumericDAESystem

Inherits from: ICapeNumericDAEComponent

This is the interface of the Differential-Algebraic Equation System, which solves systems of equations of the form:

$$f(x, \dot{x}, u, t)$$

over some range of values of the independent variable t.

ICape Numeric DAE System:: GetDynamicESO

Description Gets the ESO with which a DAESystem was constructed. **Arguments**

In/Out	Name	Type	Description
[out]	TheESO	CapeInterface (ICapeNumericD- ifferentialAlge- braicESO)	The differential-algebraic ESO which defines this system.

 $ICape Numeric DAE System:: {\bf Initialise}$

Description

Combine the dynamic ESO with a set of initial conditions and solve for x and \dot{x} . The result is left in the defining ESO.

In/Out	Name	Type	Description
[in]	ICESO	CapeInterface (ICapeNumericD- ifferentialAlge- braicESO)	The initial condition ESO.

ICapeNumericDAESystem::SimpleInitialise

Description

Requiring specified elements of the dynamic ESO to remain fixed, solve for remaining x and \dot{x} entries. The result is left in the defining ESO.

Arguments

In/Out	Name	Type	Description
[in]	ISpec	CapeArrayLong	The indices of variables which are to remain fixed. Negative indicates that the \dot{x} value is fixed.

ICapeNumericDAESystem::AdvanceTime

Description

Move the solution forward to a specified time. The result is left in the defining ESO.

In/Out	Name	Type	Description
[in] [in]	t allowOvershoot	CapeDouble CapeBoolean	The target independent variable value. If true, the integrator may internally overshoot the requested time (in which case
[out]	flag	CapeLong	interpolation will be used to leave the correct results in the ESO). Zero for success, a number of other values for failure.

$ICape Numeric DAE System:: {\bf Simple Initialise}$

Description

Requiring the differential variables of the dynamic ESO (i.e. those members of x with \dot{x} terms occurring in the dynamic equations) to remain fixed, solve for remaining x entries and \dot{x} . The result is left in the defining ESO.

No arguments.

ICapeNumericDAESystem::SetSensitivityFlag

Description

Set a boolean flag to indicate that sensitivities should be computed on the next integration. A call to this routine which actually changes the flag value should be followed a call to either Initialise or SimpleInitialise. If an integration (i.e. a series of calls to AdvanceTime and SimpleReinitialise) is carried out with this flag true, accumulated sensitivity values will be present in the ESO at the end of the integration.

In/Out	Name	Type	Description
[in]	flag	CapeBoolean	New value for the flag.

8.10 CORBA interface definitions

This section records the CIDL implementations of the interfaces described in the previous sections. All files for the interface definitions can be found in the sub-directory src/examples/eso_idl of the gPROMS distribution.

The header file ICapeUtilityDefinitions.idl defines the standard CAPE-OPEN types in terms of the basic CORBA types, as follows:

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef __CAPETYPES__
#define __CAPETYPES__
typedef long CapeError;
typedef long CapeLong;
typedef double CapeDouble;
typedef boolean CapeBoolean;
typedef string CapeString;
typedef any CapeVariant;
typedef Object CapeInterface;
typedef sequence<CapeLong> CapeArrayLong;
typedef sequence<CapeArrayLong> CapeArrayArrayLong;
typedef sequence<CapeDouble> CapeArrayDouble;
typedef sequence<CapeString> CapeArrayString;
typedef sequence<CapeInterface> CapeArrayInterface;
#endif
```

8.10.1 ICapeUtilityComponent.idl

This interface defines basic identification methods.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef I_CAPE_UTILITY_COMPONENT_IDL
#define I_CAPE_UTILITY_COMPONENT_IDL

#include "ICapeUtilityDefinitions.idl"
interface ICapeUtilityComponent {
   CapeString GetVersionNumber();
   CapeString GetComponentName();
   CapeString GetComponentDescription();
};

#endif // I_CAPE_UTILITY_COMPONENT_IDL
```

8.10.2 ICapeNumericSolverComponent.idl

The base interface for all types of solvers.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeUtilityComponent.idl"
enum CapeSolverType
{
    CAPE_LA_SOLVER, CAPE_NLA_SOLVER, CAPE_DAE_SOLVER,
    CAPE_PE_SOLVER, CAPE_DO_SOLVER
};
interface ICapeNumericSolverComponent : ICapeUtilityComponent
{
    CapeSolverType GetType();
    void SelfDestruct();
    CapeArrayInterface GetParameters();
    CapeInterface GetParameterByName(in CapeString name);
    CapeArrayInterface GetStatistics();
    CapeInterface GetStatisticByName(in CapeString name);
};
```

8.10.3 ICapeNumericAttribute.idl

The base class for solver parameter and statistic specifications. Note: includes ICape-NumericSolverComponent.idl for the CapeSolverType enumeration.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericSolverComponent.idl"
enum CapeNumericAttributeType { STRING_ATTRIBUTE,
                                INTEGER_ATTRIBUTE,
                                REAL_ATTRIBUTE,
                                BOOLEAN_ATTRIBUTE,
                                ENUMERATED_STRING_ATTRIBUTE,
                                SOLVER_INTERFACE_ATTRIBUTE };
interface ICapeNumericAttribute
{
    CapeString GetName();
    CapeString GetDescription();
    CapeNumericAttributeType GetType();
    CapeArrayLong GetDimensionality();
};
interface ICapeNumericStringAttribute : ICapeNumericAttribute
    CapeString GetValue(in CapeArrayLong element);
};
```

```
interface ICapeNumericIntegerAttribute : ICapeNumericAttribute
{
     CapeLong GetValue(in CapeArrayLong element);
};
interface ICapeNumericRealAttribute : ICapeNumericAttribute
{
     CapeDouble GetValue(in CapeArrayLong element);
};
interface ICapeNumericBooleanAttribute : ICapeNumericAttribute
     CapeBoolean GetValue(in CapeArrayLong element);
};
interface ICapeNumericEnumeratedAttribute : ICapeNumericAttribute
{
     CapeArrayString GetPossibleValues();
     CapeString GetValue(in CapeArrayLong element);
};
interface ICapeNumericInterfaceAttribute : ICapeNumericAttribute
{
     CapeSolverType GetSolverType();
     CapeInterface GetValue(in CapeArrayLong element);
     CapeString GetDefaultName();
};
```

8.10.4 ICapeNumericParameter.idl

The interface for solution parameters, i.e. user-settable information items affecting aspects of the solution process.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericAttribute.idl"
interface ICapeNumericStringParameter: ICapeNumericStringAttribute
   void SetValue(in CapeArrayLong element, in CapeString value);
};
interface ICapeNumericIntegerParameter : ICapeNumericIntegerAttribute
{
   CapeLong GetLowerBound(in CapeArrayLong element);
   CapeLong GetUpperBound(in CapeArrayLong element);
   void SetValue(in CapeArrayLong element, in CapeLong value);
};
interface ICapeNumericRealParameter : ICapeNumericRealAttribute
   CapeDouble GetLowerBound(in CapeArrayLong element);
   CapeDouble GetUpperBound(in CapeArrayLong element);
   void SetValue(in CapeArrayLong element, in CapeDouble value);
};
```

interface ICapeNumericBooleanParameter : ICapeNumericBooleanAttribute

8.10. CORBA interface definitions.

```
{
    void SetValue(in CapeArrayLong element, in CapeBoolean value);
};

interface ICapeNumericEnumeratedParameter : ICapeNumericEnumeratedAttribute
{
    void SetValue(in CapeArrayLong element, in CapeString value);
};

interface ICapeNumericInterfaceParameter : ICapeNumericInterfaceAttribute
{
    void SetValue(in CapeArrayLong element, in CapeInterface value);
};
```

8.10.5 ICapeNumericStatistic.idl

The interface for solver statistics, i.e. read-only information on aspects of the solution process.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericAttribute.idl"
interface ICapeNumericStringStatistic : ICapeNumericStringAttribute
{
}:
interface ICapeNumericIntegerStatistic : ICapeNumericIntegerAttribute
{
};
interface ICapeNumericRealStatistic : ICapeNumericRealAttribute
{
};
interface ICapeNumericBooleanStatistic : ICapeNumericBooleanAttribute
{
};
interface ICapeNumericEnumeratedStatistic : ICapeNumericEnumeratedAttribute
};
```

```
interface ICapeNumericInterfaceStatistic : ICapeNumericInterfaceAttribute
{
};
```

8.10.6 ICapeNumericLAComponent.idl

};

8.10.7 ICapeNumericLASystem.idl

The following file contains the definitions of both LASystem and LASystemFactory.

Copyright (c) 2000 Process Systems Enterprise Ltd.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericLAComponent.idl"
interface ICapeNumericLASystem : ICapeNumericLAComponent {
 exception WrongLength{};
 exception NoMatrixValues{};
  CapeError SetMatrixVals(in CapeArrayDouble MatrixVals)
raises (WrongLength);
  exception NoRHSValues{};
 CapeError GetMatrixVals(out CapeArrayDouble MatrixVals)
raises (NoRHSValues);
 CapeError SetRHS(in CapeArrayDouble RHSVals) raises (WrongLength);
 CapeError GetRHS(out CapeArrayDouble RHSVals) raises (NoRHSValues);
 exception Singular{};
 CapeError GetSolution(out CapeArrayDouble X)
raises (Singular, NoMatrixValues, NoRHSValues);
};
interface ICapeNumericLASystemFactory : ICapeNumericLAComponent {
 CapeError CreateLASystem(in CapeLong N, in CapeLong NonZeroes,
in CapeArrayLong RowNums, in CapeArrayLong ColumnNums,
out CapeInterface TheLASystem);
};
```

8.10.8 ICapeNumericNLAComponent.idl

The base class for nonlinear algebra solver and system.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericSolverComponent.idl"
interface ICapeNumericNLAComponent : ICapeNumericSolverComponent {
   CapeError SetConvergenceTolerance(in CapeDouble ConvTolValue);
   CapeError GetConvergenceTolerance(out CapeDouble ConvTolValue);
   CapeError SetMaxIterations(in CapeLong MaxItsValue);
   CapeError GetMaxIterations(out CapeLong MaxItsValue);
   CapeError SetLASystemFactory(in CapeInterface LASystemF);
   CapeError GetLASystemFactory(out CapeInterface LASystemF);
};
```

8.10.9 ICapeNumericNLASystem.idl

Again, both the definitions of System and SystemFactory are included in this file.

/*****************************

Copyright (c) 2000 Process Systems Enterprise Ltd.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericNLAComponent.idl"
interface ICapeNumericNLASystem : ICapeNumericNLAComponent {
   CapeError GetESO(out CapeInterface ESO);
   CapeError Solve();
   CapeError DoOneIteration();

   CapeError SetTestESO(in CapeInterface theESO);
   CapeError SetPresetVarNums(in CapeArrayLong varNums);
};

interface ICapeNumericNLASystemFactory : ICapeNumericNLAComponent {
   CapeError CreateNLASystem(in CapeInterface TheESO,
   out CapeInterface TheNLASystem);
};
```

The base class for differential-algebraic solver and system.

8.10.10 ICapeNumericDAEComponent.idl

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#include "ICapeUtilityDefinitions.idl"
#include "ICapeNumericSolverComponent.idl"
interface ICapeNumericDAEComponent : ICapeNumericSolverComponent {
 CapeError SetAbsoluteTolerance(in CapeDouble absTolValue);
 CapeError GetAbsoluteTolerance(out CapeDouble absTolValue);
 CapeError SetRelativeTolerance(in CapeDouble relTolValue);
 CapeError GetRelativeTolerance(out CapeDouble relTolValue);
 CapeError SetEventTolerance(in CapeDouble eveTolValue);
 CapeError GetEventTolerance(out CapeDouble eveTolValue);
 CapeError SetLASystemFactory(in CapeInterface laSysFact);
 CapeError GetLASystemFactory(out CapeInterface laSysFact);
 CapeError SetInitialisationNLASystemFactory(in CapeInterface initNLASysFact);
 CapeError GetInitialisationNLASystemFactory(out CapeInterface initNLASysFact);
 CapeError SetReinitialisationNLASystemFactory(in CapeInterface reinitNLASysFact);
 CapeError GetReinitialisationNLASystemFactory(out CapeInterface reinitNLASysFact);
};
```

Again, both the definitions of System and SystemFactory are included in this interface.

8.10.11 ICapeNumericDAESystem.idl

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

Chapter 9

The gPROMS Dynamic Optimisation Solver Interfaces

Contents

	9.1.1 Solver managers and systems
	9.1.2 Numeric-solver parameters
9.2	The IgDONumericSolverComponent Interface
9.3	The IgDOSolverManager interface
9.4	The IgDOSystem interface
9.5	CORBA interface definitions

The solution of a dynamic optimisation problem described by a gPROMS Dynamic Optimisation Object (see chapter 7) requires an appropriate numerical solver that can extract the necessary information from the gDOO, formulate the necessary mathematical problem and solve it. Finally, it has to place the solution back into the gDOO from where it can be accessed by other clients (e.g. for output display purposes).

9.1 General principles

The gPROMS Dynamic Optimisation Solver (gDOS) concept provides a general mechanism that allows diverse solvers to perform the above functions in a manner transparent to gPROMS itself. Its basic design principles are described below¹:

9.1.1 Solver managers and systems

The implementation of each gDOS must provide a means of creating gPROMS Dynamic Optimisation Solver Manager (gDOSolverManager) objects.

The gDOSolverManager object has one major method that, given the description of a dynamic optimisation problem in the form of a gDOO, creates a gPROMS Dynamic Optimisation System (gDOSystem) object. The latter is a combination of the problem to be solved (*i.e.* the gDOO) and the numerical solver to be used for its solution.

Each gDOSystem provides a Solve method that, when invoked, effects the solution of the dynamic optimisation problem.

9.1.2 Numeric-solver parameters

The behaviour of the numerical solver can be configured by using the solver parameters according to the principals described in section 8.3.

9.2 The IgDONumericSolverComponent Interface

This interface describes a component (solver manager or system) associated with a dynamic optimisation solver. It inherits from the general ICapeNumericSolverComponent.

At present, IgDONumericSolverComponent does not provide any functionality beyond that already provided by ICapeNumericSolverComponent. In the future, it may provide a means of specifying certain minimal functionality that must be supported by *all* dynamic optimisation solvers in gPROMS.

 $^{^1\}mathrm{These}$ are generally consistent with the design of CAPE-OPEN numerical solvers as described in chapter 8.

9.3 The IgDOSolverManager interface

The main function of the IgDOSystemFactory interface is to provide a means of creating a gDOSystem from a given gDOO. It inherits from the IgDONumericSolverComponent interface and extends it with the following method:

IgDOSystemFactory::CreateDOSystem				
Description	Creates a gDOSystem from a given gDOO.			
Arguments				

In/Out	Name	Type	Description
[in]	gDOO	IgDOO	The gDOO that forms the basis of the new gDOSystem.
[return]	gDOSystem	IgDOSystem	The newly created gDOSystem.

9.4 The IgDOSystem interface

The main function of the IgDOSystem interface is to provide a means of solving the dynamic optimisation problem described by the gDOO that forms the basis of the corresponding gDOSystem object. It inherits from the IgDONumericSolverComponent interface and extends it with the following method:

IgDOSystem::Solve		
Description Arguments	Solves the gDOSystem and returns the system status.	

In/Out	Name	Type	Description
[return]	status	gDOSystemStatus	Returns one of the system-status constants as defined below.

9.5 CORBA interface definitions

This section records the CIDL implementations of the interfaces described in the previous sections. All files for the interface definitions can be found in the sub-directory src/examples/gdoo_idl of the gPROMS distribution.

9.5.1 gNumericSolver.idl

This file defines all the interfaces referred to above.

LEGAL NOTICE

These coded instructions, statements, and computer programs contain proprietary information belonging to Process Systems Enterprise Ltd., and are protected by International copyright law. They may not be disclosed to third parties without the prior written consent of Process Systems Enterprise Ltd.

```
#ifndef I_GNUMERIC_SOLVER_COMPONENT_IDL
#define I_GNUMERIC_SOLVER_COMPONENT_IDL

#include "general.idl"
#include "ICapeNumericSolverComponent.idl"
#include "gD00.idl"

module psenterprise {
    module Optimisation {
    interface IgDOSolverComponent : ICapeNumericSolverComponent {
```

```
};
interface IgDOSystem : IgDOSolverComponent {
    enum gDOSystemStatus {
GDOSS_OK,
GDOSS_NOT_COMPLETE,
GDOSS_ALREADY_SOLVED,
GDOSS_SOLUTION_FAILED
    };
    gDOSystemStatus Solve();
};
interface IgDOSolverManager : IgDOSolverComponent {
    IgDOSystem CreategDOSystem(in IgDOO gDOO);
};
    }; // module Optimisation
}; // module psenterprise
#endif // I_GNUMERIC_SOLVER_COMPONENT_IDL
```

Appendix A

Creating Shared Object Libraries Under UNIX

Contents

A.1 Shar	red object libraries for DIGITAL UNIX v4.0 and later 254
A.1.1	Foreign Object code written in FORTRAN 77
A.1.2	Foreign Object code written in C
A.1.3	Foreign Object code written in C++
A.2 Shar	red object libraries for IBM AIX v4.2 and later 255
A.2.1	Foreign Object code written in FORTRAN 77 255
A.2.2	Foreign Object code written in C
A.2.3	Foreign Object code written in C++
A.3 Shar	red object libraries for Linux
A.3.1	Foreign Object code written in FORTRAN 77 256
A.3.2	Foreign Object code written in C
A.3.3	Foreign Object code written in C++
A.4 Shar	red object libraries for SGI IRIX64 v6.2 and later 257
A.4.1	Foreign Object code written in FORTRAN 77 257
A.4.2	Foreign Object code written in C
A.4.3	Foreign Object code written in C++
A.5 Shar	red Object libraries for SUN Solaris v2.5 and later 258
A.5.1	Foreign Object code written in FORTRAN 77
A.5.2	Foreign Object code written in C
A.5.3	Foreign Object code written in C++

This appendix provides information on how you can construct shared object libraries for Foreign Objects and Foreign Processes Interfaces under the various UNIX platforms that are currently supported by gPROMS.

We assume that the starting point for the creation of shared object library is the Foreign Object or Foreign Process Interface code written in either FORTRAN 77, C or C++. By way of an example, we will refer to three code files, Thermo.f, Thermo.c and Thermo.cxx written in these three languages respectively. The objective in all three cases is to create a shared object library (called ThermoPack.so on most platforms).

A.1 Shared object libraries for DIGITAL UNIX v4.0 and later

A.1.1 Foreign Object code written in FORTRAN 77

```
f77 -c -O -i8 Thermo.f
ld -shared -all -o ThermoPack.so Thermo.o -lfor -lots -lm -lc
```

A.1.2 Foreign Object code written in C

```
cc -c -O Thermo.c
ld -shared -all -o ThermoPack.so Thermo.o -lm -lc
```

A.1.3 Foreign Object code written in C++

```
cxx -x -0 Thermo.c
```

ld -shared -all -o Thermopack.so Thermo.o -lcxxstd -lcxx -lm -lc

A.2 Shared object libraries for IBM AIX v4.2 and later

Using IBM C Set 3.6 and IBM XL Fortran 5.1.1.

A.2.1 Foreign Object code written in FORTRAN 77

```
xlf_r -c -02 -qextname Thermo.f
makeC++SharedLib_r -o Thermopack.so -lxlf90_r -p 100
```

A.2.2 Foreign Object code written in C

```
xlC_r -c -02 Thermo.c
makeC++SharedLib_r -o Thermopack.so -p 100
```

A.2.3 Foreign Object code written in C++

```
xlC_r -c -02 Thermo.cxx
makeC++SharedLib_r -o Thermopack.so -p 100
```

A.3 Shared object libraries for Linux

Shared objects for use with the Linux version of gPROMS must be linked with glibc (libc.so.6) rather than libc.so.5.

We recommend using egcs 1.1.2 or later for compiling shared objects on Linux.

A.3.1 Foreign Object code written in FORTRAN 77

We recommend that you do not use any code optimisation when using g77 as there appear to be some bugs in the compiler that lead to incorrect code being generated.

```
g77 -c -fPIC Thermo.f
g77 -shared -o ThermoPack.so Thermo.o -lg2c -lm
```

A.3.2 Foreign Object code written in C

```
gcc -c -O -fPIC Thermo.c
gcc -shared -o ThermoPack.so Thermo.o -lm -lc
```

A.3.3 Foreign Object code written in C++

```
g++ -c -0 -fPIC Thermo.cxx g++ -shared -o ThermoPack.so Thermo.o -lm -lc \,
```

A.4 Shared object libraries for SGI IRIX64 v6.2 and later

A.4.1 Foreign Object code written in FORTRAN 77

```
f77 -c -n32 -mips4 -02 -KPIC Thermo.f
ld -shared -n32 -mips4 -o ThermoPack.so Thermo.o -lftn -lm
```

A.4.2 Foreign Object code written in C

```
cc -c -n32 -mips4 -O2 -KPIC Thermo.c
ld -shared -n32 -mips4 -o ThermoPack.so Thermo.o -lm
```

A.4.3 Foreign Object code written in C++

```
CC -c -n32 -mips4 -02 -KPIC Thermo.cxx ld -shared -n32 -mips4 -o ThermoPack.so Thermo.o -lC -lm \,
```

A.5 Shared Object libraries for SUN Solaris v2.5 and later

Using the SUN workshop 4.2 FORTRAN, C and C++ compilers.

A.5.1 Foreign Object code written in FORTRAN 77

```
f77 -c -0 -KPIC Thermo.f
ld -dy -G -z text -o ThermoPack.so Thermo.o -1F77 -1M77 \
    -1sunmath -lm
```

A.5.2 Foreign Object code written in C

```
cc -c -O -KPIC Thermo.c
ld -dy -G -z text -o ThermoPack.so Thermo.o -lm -lc
```

A.5.3 Foreign Object code written in C++

```
CC -c -O -KPIC Thermo.cxx ld -dy -G -z text -o ThermoPack.so Thermo.o -lm -lc -lC
```

Appendix B

Creating Dynamic Link Libraries under Windows

Contents

B.1	Dynamic link	libraries	with	DIGITAL	FORTRAN	5.0	260
B.2	Dynamic link	libraries	with	Microsoft	Visual C++	5.0	263

This appendix explains how you can create dynamic link libraries ("DLLs") for use with the gPROMS Foreign Object and Foreign Process Interface protocols.

We assume that the starting point for the creation of these DLLs is the Foreign Object or FPI code written in either FORTRAN, C or C++, as described in sections 2.3 and 4.4 of this manual.

B.1 Dynamic link libraries with DIGITAL FORTRAN 5.0

To create gPROMS-compatible DLLs from source code written in FORTRAN, you need to use the DIGITAL FORTRAN 5.0 compiler. This integrates with the Microsoft Developers Studio.

The creation of the DLL involves the following steps:

1. Make your FORTRAN files suitable for communication between gPROMS and DIGITAL FORTRAN 5.0.

To do this, you need to use the ATTRIBUTES compiler directive¹ to specify additional properties for each of the subroutines in the DLL that will be called by gPROMS. These are:

- the gfoi, gfocm, gfocmi, gfom, gfomd and gfot subroutines for Foreign Objects;
- the gfpi, gfppause, gfpget, gfpsend, gfpsendm and gfpt subroutines for Foreign Processes;
- the goci, gocrdd, gocrv, gocfin, goctime, gocvalue, gocreset and gocct subroutines for Output Channels.

Do not do this with any other subroutine in your FORTRAN source!

An example is shown in figure B.1 for the gfocmi subroutine of Foreign Objects (see section 2.2). The compiler directives are the lines starting with the string:

!DEC\$ ATTRIBUTES

immediately following the initial subroutine statement.

Note that:

• All these lines start in the first column of the FORTRAN input file.

 $^{^{1}}$ The ATTRIBUTES compiler directive is explained in section 14.2.1.3 of the "DIGITAL FORTRAN 5.0 Language Reference".

```
subroutine gfocmi(foid, fohandle, methodname,
                       noinputs, inputnames, inputlengths,
                       inputtypes, inputderivsavailable,
                       inputdimsnum, inputdimsden,
                       inputoffsets, inputmultipliers,
                       status)
!DEC$ ATTRIBUTES C, ALIAS: 'gfocmi_', DLLEXPORT :: gfocmi
!DEC$ ATTRIBUTES REFERENCE :: foid, fohandle, methodname, noinputs
!DEC$ ATTRIBUTES REFERENCE :: inputnames, inputlengths, inputtypes
!DEC$ ATTRIBUTES REFERENCE :: inputderivsavailable, inputdimsnum
!DEC$ ATTRIBUTES REFERENCE :: inputdimsden, inputoffsets
!DEC$ ATTRIBUTES REFERENCE :: inputmultipliers, status
      character*256
                       foid, methodname, inputnames(noinputs)
                       fohandle, noinputs, inputlengths(noinputs),
      integer
                       inputtypes(noinputs),
                       inputderivsavailable(noinputs),
                       inputdimsnum(noinputs*10),
                       inputdimsden(noinputs*10),
                       status
     double precision inputoffsets(noinputs),
                       inputmultipliers(noinputs)
     *** Body of gfocmi goes here ***
      return
      end
```

Figure B.1: Example of the use of ATTRIBUTES compiler directives in DIGITAL FORTRAN 5.0.

- The first line is of the form:
 !DEC\$ ATTRIBUTES C, ALIAS: 'gfocmi_', DLLEXPORT :: gfocmi
 Note that the name of the subroutine (gfocmi, in this case) appears twice, and that, the first time, it is followed by an underscore symbol.
- The remaining lines involve the string:

!DEC\$ ATTRIBUTES REFERENCE ::

followed by a list of one or more arguments of the subroutine. For instance: !DEC\$ ATTRIBUTES REFERENCE:: foid, fohandle, methodname, noinputs It does not matter how many arguments are listed in each line provided that the line does not extend beyond column 72. However, you must ensure that each and every argument of the subroutine appears in one such line. Examples can be found in the sample files fo/source/fo_win32.f and fpi/source/fpi_win32.f provided with the gPROMS distribution. You may wish simply to copy the relevant lines from those files into your own FORTRAN source.

- 2. Start up the Microsoft Developer Studio.
- 3. From within the File menu, select New... Projects, and choose Win32 Dynamic Link Library from the list of available project types. In the same dialog, provide a suitable name for your DLL as the project name. We suggest that you place the project directory under your personal gPROMS fo (or fpi) directory.
- 4. Using the Project... Add to Project... Files menu item, insert the FOR-TRAN file(s) defining your Foreign Object or Foreign Process Interface into the project.
- 5. Using the Build... Build *filename*.dll menu item, build the project and copy the resulting DLL under your fo (or fpi or oc) directory.

B.2 Dynamic link libraries with Microsoft Visual C++ 5.0

To create gPROMS-compatible DLLs from source code written in C or C++, you need to use the Microsoft Visual C++ 5.0 compiler. This forms part of the Microsoft Developers Studio.

The creation of the DLL involves the following steps:

- 1. Start up the Microsoft Developer Studio.
- 2. From the File menu, select New... Projects, and choose Win32 Dynamic Link Library from the list of available project types. In the same dialog, provide a suitable name for your DLL as the project name. We suggest that you place the project directory under your personal gPROMS fo (or fpi) directory.
- 3. Using the File... Project... Add to Project menu item, insert the C/C++ file(s) defining your Foreign Object or Foreign Process Interface into the project.
- 4. We recommend that you #include the header files fo/source/gF0Interface.h (for Foreign Objects) or fpi/source/gFPInterface.h (for Foreign Process Interfaces) into your project. Both of these are included in the gPROMS distribution. If you do not wish to do this, then the definition of each of the procedures in the DLL that will be called by gPROMS must be "decorated" by introducing the string _declspec(dllexport) between the void designator and the name of the procedure. The procedures that need to be modified in this way are:
 - the gfoi, gfocm, gfocmi, gfom, gfomd and gfot procedures for Foreign Objects:
 - the gstart, gpause, gget, gsend, gsendm and gend procedures for Foreign Processes:
 - the goci, gocrdd, gocrv, gocfin, goctime, gocvalue, gocreset and gocct subroutines for Output Channels.

An example is shown in figure B.2

5. Using the Build... Build filename.dll menu item, build the project and copy the resulting DLL into your fo (or fpi or oc) directory.

Figure B.2: Example of the use of $_declspec(dllexport)$ "decoration" in Microsoft Visual C++5.0.