Garden Shed Submains - Installation Guide

This guide covers wiring a garden shed from a house switchboard.

The maximum cable run from the house switchboard to the shed is 40 metres.

Use 6 mm2 SDI cable for the submains.

The shed circuit must be protected by a 32 A RCBO at the house switchboard.

Commissioning and Testing
Before energising the shed circuit, measure the earth loop impedance.
The earth loop impedance must be below 1.5 ohms.
Record all results in the schedule of test results.
A certificate of compliance must be issued when the work is complete.