# Algorithms for Wireless Communications

## **Andreas Burg**

Institute for Integrated Signal Processing Systems, RWTH Aachen
Telecommunications Circuits Laboratory, EPFL

Lecture: Spatial Multiplexing in MIMO Channels






## **Spatial Multiplexing with MIMO Systems**

#### Multi-Antenna Techniques


#### **Spatial Diversity (e.g. Alamouti's scheme):**


- Requires uncorrelated antenna elements (>> λ/2 distance)
- "Unlikely that all antennas are in deep fades"
- Reduces fast fading amplitude variations
- Makes the transmission more robust



#### **Beamforming:**

- Requires correlated antenna elements (λ/2 distance)
- Focusing of power into a desired direction
- Increases signal power in this direction
- Decreases interference power in other directions






## Multi-Antenna Techniques


#### **Space-Division Multiple Access:**

- Users are separated by their spatial signature
- Multiple data streams, but only one per user
- Does not require multiple receive antennas
- Does not require complex receiver processing



#### **Spatial Multiplexing**

- Requires uncorrelated antenna elements
- Transmission of multiple code words along independent spatial modes
- Increases throughput for high link SNR
- Requires multiple receive antennas
- Requires complex receiver processing



#### Narrow Band MIMO Channel Model

- Consider a system with
  - n<sub>T</sub> transmit antennas and
  - n<sub>R</sub> receiveantennas and
- Collect the transmitted symbols, the noise- and the received- samples in vectors

$$\underline{\mathbf{x}} = \begin{pmatrix} x_1 \\ \vdots \\ x_{n_T} \end{pmatrix} \quad ; \quad \underline{\mathbf{w}} = \begin{pmatrix} w_1 \\ \vdots \\ w_{n_R} \end{pmatrix} \quad ; \quad \underline{\mathbf{y}} = \begin{pmatrix} y_1 \\ \vdots \\ Y_{n_R} \end{pmatrix}$$

and represent the channel as a n<sub>R</sub> x n<sub>T</sub> matrix

$$\mathbf{H} = egin{pmatrix} h_{1,1} & \cdots & \cdots & h_{1,n_T} \\ dots & & dots \\ h_{n_R,1} & \cdots & \cdots & h_{n_R,n_t} \end{pmatrix}$$

yields

$$\underline{\mathbf{Y}} = \underline{\mathbf{H}} \ \underline{\mathbf{x}} + \underline{\mathbf{w}}$$

■ For OFDM, we can consider each tone as an independent MIMO system. For the discussion, we consider a single subcarrier only (flat fading). Thus, we can drop the subcarrier index.

We further assume the channel is time invariant during a burst. Thus,
 we can drop the time indices in the channel matrix and the model is

$$y = Hx + w$$

where x is the  $n_T$ -dimensional complex vector of transmit signals, y is the  $n_R$ -dimensional complex vector of receive signals and w the  $n_R$ -dimensional complex Gaussian noise vector with  $w \sim CN(0, N_0 I_{n_p})$ .

There is a total power constraint P' on the signals from the transmit antennas.

(Note that the underlining has been dropped for simplicity)

Let the singular value decomposition of H be

$$H = U \Lambda V^H$$

■ Recall that the first  $n_{min}$ =min( $n_R$ , $n_T$ ) diagonal elements of  $\Lambda$  are the ordered positive square roots of the eigenvalues of the matrix HH<sup>H</sup>. We can rewrite the SVD as

$$\mathbf{H} = \sum_{i=1}^{n_{min}} \lambda_i \mathbf{u}_i \mathbf{v}_i^H$$

where the  $u_i$  are the eigenvectors of  $HH^H$  and the  $v_i$  are the eigenvectors of  $H^HH$ .

• The rank of H is precisely the number of non-zero singular values  $\lambda_i$ .

If we define


$$\widetilde{\mathbf{x}} := \mathbf{V}^{\mathsf{H}} \mathbf{x} \Leftrightarrow \mathbf{x} := \mathbf{V} \widetilde{\mathbf{x}} \quad , \quad \widetilde{\mathbf{y}} := \mathbf{U}^{\mathsf{H}} \mathbf{y} \quad , \quad \widetilde{\mathbf{w}} := \mathbf{U}^{\mathsf{H}} \mathbf{w}$$

then we can rewrite the transmission equation

$$\mathbf{U}^{\mathsf{H}}\mathbf{y} = \mathbf{U}^{\mathsf{H}}\mathbf{H}\mathbf{x} + \mathbf{U}^{\mathsf{H}}\mathbf{w} = \mathbf{U}^{\mathsf{H}}\mathbf{H}\mathbf{V}\widetilde{\mathbf{x}} + \mathbf{U}^{\mathsf{H}}\mathbf{w}$$

$$\Rightarrow$$
  $\widetilde{y} = \Lambda \widetilde{x} + \widetilde{w}$ 

- Since U is unitary,  $w \sim \tilde{CN}(0, N_0 I_{n_r})$  has the same distribution as w, and  $\bar{x}$  has the same power as x (i.e.  $||x||^2 = ||x||^2$ ).
- The SVD can be interpreted as two coordinate transformations (two base transformations).



$$\begin{split} \boldsymbol{x} := \boldsymbol{V} \widetilde{\boldsymbol{x}} & \boldsymbol{y} = \boldsymbol{H} \boldsymbol{x} + \boldsymbol{w} = \boldsymbol{U} \boldsymbol{\Lambda} \, \boldsymbol{V}^H \boldsymbol{x} + \boldsymbol{w} \\ &= \boldsymbol{U} \Big( \boldsymbol{\Lambda} \, \boldsymbol{V}^H \boldsymbol{x} + \widetilde{\boldsymbol{w}} \Big) \\ &= \boldsymbol{V} \left( \boldsymbol{\Lambda} \, \boldsymbol{V}^H \boldsymbol{x} + \widetilde{\boldsymbol{w}} \right) \\ &\widetilde{\boldsymbol{y}} = \boldsymbol{\Lambda} \widetilde{\boldsymbol{x}} + \widetilde{\boldsymbol{w}} \end{split}$$

#### Interpretation

 The Singular Value Decomposition (SVD) can be interpreted as two coordinate transformations (or base transformations).

If

- the input is expressed in terms of a coordinate system defined by the columns of V and
- the output is expressed in terms of a coordinate system defined by the columns of U,
- then the input/output relationship is very simple: we have n<sub>min</sub> independent parallel channels.

Eigenmode transmission

#### MIMO Capacity without transmit Channel Knowledge

■ The maximum rate of reliable communication (achievable rate) for k parallel Gaussian channels is

$$R = \sum_{n=0}^{k} \log_2 \left( 1 + \frac{P_n ' \lambda_n^2}{N_0} \right)$$
 bits/channel use

k equals the number of non-zero eigenvalues  $k \le n_{\min}$ 

If transmitter has no channel knowledge: distribute power equally across dimensions

$$P_n' = \frac{1}{k} P'$$
 ,  $n = 1, ..., k$ 

the capacity is the maximum achievable rate for any power allocation meeting this constraint

$$R = \sum_{n=0}^{k} \log_2 \left( 1 + \frac{1}{k} \frac{P'}{N_0} \lambda_n^2 \right)$$
 bits/channel use

## MIMO Capacity without transmit Channel Knowledge

Rewriting the capacity expression of the subchannels yields

$$R = \log_2 \prod_{n=0}^k \left( 1 + \frac{1}{k} \frac{P'}{N_0} \lambda_n^2 \right)$$
 bits/channel use

 We use the following relationship that relates the product of the Eigenvalues of a matrix to its determinant

$$\det(\mathbf{A}) = \prod_{n=0}^{rank} \left(\lambda_n^2\right)$$

- We further use that  $1 + \lambda_n^2$  are the Eigenvalues of 1 + Q if  $\lambda_n^2$  are the Eigenvalues of Q
- Therefore:

$$R = \log_2 \prod_{n=0}^k \left( 1 + \frac{1}{k} \frac{P'}{N_0} \lambda_n^2 \right) = \log_2 \left( \det \left( I + \frac{1}{k} \frac{P'}{N_0} \mathbf{H} \mathbf{H}^H \right) \right)$$
 bits/channel use

## Derivation: Optimum Power Allocation in MIMO System (Water Filling)

 The maximum rate of reliable communication (achievable rate) for k parallel Gaussian channels is

$$R = \sum_{n=0}^{k} \log_2 \left( 1 + \frac{P_n ' \lambda_n^2}{N_0} \right)$$
 bits/channel use

k equals the number of non-zero eigenvalues  $k \le n_{\min}$ 

Under a (common) power constraint

$$\sum_{n=1}^{k} P_n' = P' \qquad P_n' \ge 0 \quad , \quad n = 1, ..., k$$

the capacity is the maximum achievable rate for any power allocation meeting this constraint

$$C = \max_{P_1', \dots, P'_k} \sum_{n=1}^k \log_2 \left( 1 + \frac{P_n' |\lambda_n|^2}{N_0} \right) \quad with \quad \sum_{n=1}^k P_n' = P' \qquad P_n' \ge 0$$

## Waterfilling (5.3.3 ctd.)

 We can determine the optimal power allocation using the method of Lagrange multiplier

$$L(\lambda, P_1', ..., P_k') = \sum_{n=1}^k \log_2 \left( 1 + \frac{P_n' |\lambda_n|^2}{N_0} \right) - \lambda \left( \sum_{n=1}^k P_n' - P' \right) \log_2 e$$

Since the individual power allocations must be nonnegative, the optimality condition is

$$\frac{\partial L}{\partial P_n'} \begin{cases} = 0 & \text{if } P_n' > 0 \\ \le 0 & \text{if } P_n' = 0 \end{cases}$$

i.e. using the maximizing value for positive allocations (first rule) or using a zero allocation if larger allocations would reduce L (due to a negative derivative, second rule)

Defining x<sup>+</sup>=max(x,0), the resulting optimal power allocation is

$$P_n' = \left(\frac{1}{\lambda} - \frac{N_0}{\left|\lambda_n\right|^2}\right)^+ \quad \text{with } \lambda \text{ such that} \quad P' = \sum_{n=1}^k \left(\frac{1}{\lambda} - \frac{N_0}{\left|\lambda_n\right|^2}\right)^+$$

We have already seen examples of parallel Gaussian channels (e.g. OFDM in frequency dimension). Here the spatial dimension plays the same role as the frequency dimension in OFDM. The capacity\* is by now familiar:

$$C'_{n_{min}} = \sum_{i=1}^{n_{min}} log_2 \left( 1 + \frac{P_i' \lambda_i^2}{N_0} \right) \quad bits/s/Hz$$

where the P<sub>i</sub>' are the waterfilling power allocations:


$$P_i' = \left(\mu - \frac{N_0}{\lambda_i^2}\right)^+ \qquad P' = \sum_{i=1}^{n_{min}} \left(\mu - \frac{N_0}{\lambda_i^2}\right)^+$$

Each  $\lambda_i$  corresponds to an eigenmode of the channel (also called eigenchannel). Each non-zero eigenchannel can support a data stream: thus, the MIMO-channel can support the spatial multiplexing of up to  $n_{min}$  data streams.

<sup>\*</sup> Note that this again assumes that the channel is known at the transmitter

#### Waterfilling: Optimum Power Allocation


The optimal power allocation is



Source: David Tse, Pramod Viswanath, "Fundamentals of Wireless Communication", Cambridge Press 2005

Note: more power is allocated to the already "strong" channels

## **SVD Architecture for MIMO Communication**



- What are the key parameters that determine performance?
- At high SNR
  - "the water level is deep", or, formally,

for all **non-zero** singular values:  $\frac{N_0}{\lambda_i^2} << \mu$ 

Thus, the optimum power allocations for the non-zero SV approach

$$P_i' = \left(\mu - \frac{N_0}{\lambda_i^2}\right)^+ \approx \mu = \frac{P'}{k}$$

which represents equal power allocation, and is  $P'_{i}=0$  for the zero SV. ( $k \le n_{min}$  is the number of non-zero  $\lambda_{i}^{2}$  or the rank of **H**)

$$C' \approx \sum_{i=1}^{k} log_2 \left( 1 + \frac{P' \lambda_i^2}{k N_0} \right)$$

In this case we get for the capacity

• Since 
$$\frac{N_0}{\lambda_i^2} << \mu = \frac{P'}{k} \Leftrightarrow \frac{P' \lambda_i^2}{k N_0} >> 1$$

we can further approximate for the capacity (with SNR:=P'/N<sub>0</sub>)

$$C' \approx \sum_{i=1}^{k} log_{2} \left( 1 + \frac{P' \lambda_{i}^{2}}{k N_{0}} \right) \approx \sum_{i=1}^{k} log_{2} \left( SNR \cdot \frac{\lambda_{i}^{2}}{k} \right)$$

$$\approx k log_{2} SNR + \sum_{i=1}^{k} log_{2} \left( \frac{\lambda_{i}^{2}}{k} \right) bits/s/Hz$$

■ The parameter k is the number of spatial degrees of freedom per second per Hertz. It represents the dimension of the transmitted signal as modified by the MIMO channel, i.e., the dimension of the image under the mapping by H. This is equal to the rank of H (or, equivalently, the number of non-zero singular values). With full rank k=n<sub>min</sub> and the MIMO channel provides n<sub>min</sub> spatial degrees of freedom.

 A more refined picture is obtained by looking at the non-zero singular values themselves. By Jensen's inequality

$$C' \approx \sum_{i=1}^{k} log_2 \left( 1 + \frac{P' \lambda_i^2}{k N_0} \right)$$

$$= k \sum_{i=1}^{k} \frac{1}{k} log_2 \left( 1 + \frac{P' \lambda_i^2}{k N_0} \right) \le k log_2 \left( 1 + \frac{P'}{k N_0} \left( \frac{1}{k} \sum_{i=1}^{k} \lambda_i^2 \right) \right)$$

■ The sum of the eigenvalues of a matrix equals its trace (see, e.g. "Matrix Algebra"), thus, we have:

$$\sum_{i=1}^{k} \lambda_i^2 = \text{Tr} \left[ \mathbf{H} \mathbf{H}^{\mathsf{H}} \right] = \text{Tr} \left[ \mathbf{H}^{\mathsf{H}} \mathbf{H} \right] = \sum_{i=1}^{k} \left| \mathbf{h}_{i,j} \right|^2$$

This term can be interpreted as the total power gain of the matrix channel, if one spreads the energy equally between all transmit antennas.

For a real convex function  $\varphi$ , numbers  $x_i$  in its domain, and positive weights  $a_i$ , Jensen's inequality can be stated as:

$$\varphi\left(\frac{\sum a_i x_i}{\sum a_i}\right) \le \frac{\sum a_i \varphi(x_i)}{\sum a_i};$$

and the inequality is clearly reversed if  $\varphi$  is concave.

Source: Wikipedia

- The inequality upper-bounds the capacity
- Consider channel realizations with the same total power gain and, thus, with the same capacity upper bound
  - Since equality only holds for identical terms in the sum, the maximum capacity (under the above constraint!) is achieved if all singular values are identical
  - More generally, the less spread out the singular values, the larger the capacity in the high SNR regime
  - The ratio  $\max_i(\lambda_i)/\min_i(\lambda_i)$  is defined to be the condition number of the matrix **H**. The matrix is said to be well-conditioned if the condition number is close to 1

Well-conditioned channel matrices facilitate communication in the high SNR regime

At *low SNR* only the strongest eigenmodes will be filled up by the waterfilling, thus, an approximately optimal strategy is to allocate all power to the strongest eigenmode. The resulting capacity is\*

$$C' \approx log_2 \left( 1 + \frac{P' \max_{i} (\lambda_i^2)}{N_0} \right) \approx \frac{P'}{N_0} \max_{i} (\lambda_i^2) log_2 e \quad bits/s/Hz$$

■ The MIMO channel provides a power gain of  $\max_i(\lambda_i^2)$ . The rank and condition number of H are less relevant for low SNR. What matters is the maximum singular value  $\lambda_i$ .

\* where we have made use of: log2(1+x)=ln(1+x)·log2(e) and: ln(1+x)≈x for x<<1

#### Conclusions

- The derivations so far assumed that the channel is known and constant
- This is a hypothetical scenario, but it indicates what the limits are and which transmitter architectures allow achieving the limits for some real scenarios:
  - when the channel is fading slowly and
  - we have a burst transmission such that the channel does not change significantly during a burst and
  - we can estimate the channel before transmission starts.
- Burst transmission in systems with high data rates and low mobility often meets the first two requirements
- In TDD (Time Division Duplex) systems the same carrier frequency is used in uplink and downlink. Because of the reciprocity of the link, the channel can be estimated for the downlink transmission from the received uplink signal.
- If the channel is constant over some bursts, we may estimate the channel in the downlink receiver and feed the channel state back through the uplink channel to use it in subsequent transmissions.

#### Conclusions

- (Nearly)Error free transmission requires infinitely long code words. In practice, transmission with low error probability close to the capacity limit requires long codes. The derived limits are an average over all channel realizations and, thus, transmitting close to the capacity limit requires codes that span multiple time constants (coherence time) of the channel.
- There are practical limits for code word lengths and long code words cause long delays in decoding (which may not be acceptable).
- If the channel coherence time is much shorter than the code word length (in "Fundamentals of Wireless Communications" this is called fast fading) we may use the previously derived capacity limits as reference for a scenario where the transmitter at most has statistical information about the channel.
- If the channel coherence time is larger than the code word length ("slow fading") we will get a time varying behaviour of the transmission. In this case it is advisable to feed back information to the transmitter to adjust the transmission scheme. This may range from full CSI ("initially studied scenario") to simple quality information.
- Final remark: in the derivations we have assumed that that "CSI is known at the receiver". In reality, the receiver must estimate the channel, i.e. it must extract information about the channel from the received signal. This reduces the mutual information between received signal and transmitted signal and, thus, reduces the capacity (recall the slides on achievable rates using pilöts)