

«typedef»

mqttState

DISP_MQTT_CONNECTING_1,
DISP_MQTT_CONNECTING_2,
DISP_MQTT_CONNECTED,
DISP_MQTT_DISCONNECT,
DISP_MQTT_SENDING,
DISP_MQTT_ERROR,

mqttDisp(state : uint8_t) : void
 setMotDisp(motorId : uint8_t) : void
 setGnssAnt(gnssAntMode : uint8_t) : void

setModeDisp(modeName : char*) : void

cleanDisp(void) : void

~DispController()