PCB-A / Functional test

Work instruction, routing v1 - SAMPLE for Mini MES

1. Place the board on the fixture, close the lid.
2. Scan the serial; the tester L1-TEST-01 runs program PCB-A-FT-v1.
3. PASS: put the board on the green tray.
4. FAIL: choose the defect code on the kiosk, put the board on the red tray for Repair.