

Starting Platforms Non-skid

Non-Skid Change &/or Replace Material

Removal:

- 1. Heat (hair dryer) can be applied to help loosen material.
- 2. Pick edge of vinyl away until you can get a grip.
- 3. Pull back vinyl against itself to remove. This will help keep adhesive from being left behind.
- 4. If any glue/adhesive is left, remove with Acetone using a lint-free paper towel. Do not get on the decals or hand grips. Clean thoroughly, then wipe with alcohol, we use Isopropyl 70/30. DO NOT USE A METAL SCRAPER TO REMOVE ADHESIVE!

Installation:

- 1. Lay Vinyl on top, positioning to where it is to be installed.
- 2. Tape vinyl through center to the platform. Creating a "hinge" in center where the tape is located.
- 3. Lift up one side of the hinge, remove liner all the way back to tape and then cut liner off.
- 4. Lay vinyl back down, keeping tight to not create wrinkles. Using a decal squeegee work from middle out, all the way down with firm, steady, even pressure. If a small bubble appears use pin (like a needle) to blead out air.
- 5. Remove tape, repeat for second side of hinge.
- 6. Utilize an edge sealer such a Sealitpen http://www.sealitpen.com/ or 3M 3950 edge sealer to complete seal. This is not required but will prolong life.
- 7. Let material set for a day before any use.

If you have questions or need assistance, contact our Customer Service.