

tkts.local

A Minimal Article Printer

Contents

tkts.local	1
A Minimal Article Printer	1
A focused device for printing what matters.	1
Features	2
Getting Started	2
First-Time Setup	2
Access the Device	2
Optional: Connect to Local WiFi	2
Printing Methods	3
1. Direct Input	3
2. URL Printing	3
3. API Integration	3
4. HTTP POST	3

tkts.local

A Minimal Article Printer

A focused device for printing what matters.

tkts.local is a no-fuss, human-centered article printer designed for clarity and immediacy.

It does not require ink.

It does not require complicated setup.

It simply prints.

Whether you are producing lists, notes, tickets, or short-form writing, **tkts.local** delivers clean, readable output in a refined single-column format.

Features

- Prints **alphanumeric text**, lists, tickets, and receipts
 - Supports **bold**, *italics*, highlights, and **five text sizes**
 - Generates **QR codes** for links and quick sharing
 - Capable of printing **simple photographs**
 - Connects via:
 - WiFi
 - Bluetooth
 - USB
-

Getting Started

First-Time Setup

When powered on for the first time:

1. The device will **blink three times**
2. It will automatically print a **WiFi QR code**
3. Scan the QR code to connect to the device's network

The network will appear as:

tkts.local[number]

Access the Device

Once connected to the device network:

1. Open your web browser
2. Navigate to:

`http://tkts.local`

From here, you can begin printing immediately.

Optional: Connect to Local WiFi

To make the printer available to your home or office network:

1. Go to **Settings** → **Find WiFi Networks**
2. Select your network
3. Enter your **SSID** and **password**

Note: Only **2.4 GHz networks** are supported

Once connected: - The device will appear on your network as:

tkts

- Access it at:

<http://tkts.local>

Printing Methods

tkts.local supports multiple input methods:

1. Direct Input

Use the built-in text editor in the web interface to type and print immediately.

2. URL Printing

Submit a URL to print content from a webpage.

3. API Integration

Integrate with external systems or scripts for automated printing.

4. HTTP POST

Send text directly to the printer:

```
curl -X POST http://tkts.local/print \
  --data-binary "Hello **World**"
```

When connected to your WiFi network:

Any device on the same network can access the printer. No additional configuration is required

Simply visit:

<http://tkts.local> Design Philosophy

tkts.local is built around a single idea:

Printing should be immediate, intentional, and human-readable.

It embraces constraints:

A narrow column Focused typography Minimal configuration

The result is a device that encourages clarity over complexity.

Function	Address / Action
Device UI	http://tkts.local
Print endpoint	/print (HTTP POST)
Setup network	Settings → WiFi
Default name	tkts

Notes Optimized for short-form content Designed for continuous use No ink or toner required Quick Reference Function Address / Action Device UI http://tkts.local

Print endpoint /print (HTTP POST) Setup network Settings → WiFi Default name tkts