Report Generated by Test Manager

Title: DCFC_All_Test_Cases_SRD_O5
Author: Tridib Banik
Date: 09-Nov-2025 02:10:08

Test Environment

Platform: PCWIN64
MATLAB: (R2023b)

Summary

Name	Outcome	Duration (Seconds)
Results: 2025-Nov-09 02:06:24	13	46.879
DCFC_Test_Cases	13	46.821
New Test Suite 1	13	46.821
15.5.0.2.a		2.088
15.5.0.2.b		4.145
15.5.0.3.a		1.785
15.5.0.3.b		3.726
15.5.0.3.c		4.153
15.5.0.4.a		4.257
15.5.0.4.b		4.147
15.5.0.5		4.03
15.5.0.6		4.17
15.5.0.7		4.143
15.5.0.8		4.148
15.5.0.9.a		2.619
15.5.0.9.b		3.073

Results: 2025-Nov-09 02:06:24

Result Type:	Result Set
Parent:	None
Start Time:	09-Nov-2025 02:06:25
End Time:	09-Nov-2025 02:07:12
Outcome:	Total: 13, Passed: 13

Back to Report Summary

DCFC_Test_Cases

Test Result Information

Result Type:	Test File Result
Parent:	Results: 2025-Nov-09 02:06:24
Start Time:	09-Nov-2025 02:06:25
End Time:	09-Nov-2025 02:07:12
Outcome:	Total: 13, Passed: 13

Test Suite Information

Name:	DCFC_Test_Cases

Back to Report Summary

New Test Suite 1

Test Result Information

Result Type:	Test Suite Result
Parent:	DCFC_Test_Cases
Start Time:	09-Nov-2025 02:06:25
End Time:	09-Nov-2025 02:07:12
Outcome:	Total: 13, Passed: 13

Test Suite Information

Name:	New Test Suite 1

Back to Report Summary

15.5.0.2.a

Test Result Information

Result Type: Test Case Result
Parent: New Test Suite 1
Start Time: 09-Nov-2025 02:06:25
End Time: 09-Nov-2025 02:06:27
Outcome: Passed

Test Case Information

Name: 15.5.0.2.a
Type: Baseline Test

Test Case Requirements

Description: 15.5.0.2.a
Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link

Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.2.b

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:27
End Time:	09-Nov-2025 02:06:31
Outcome:	Passed

Test Case Information

Name:	15.5.0.2.b
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.2.b

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.3.a

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:31
End Time:	09-Nov-2025 02:06:33
Outcome:	Passed

Test Case Information

Name:	15.5.0.3.a
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.3.a

Document: ../../../../../Requirement_mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.3.b

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:33
End Time:	09-Nov-2025 02:06:37
Outcome:	Passed

Test Case Information

Name:	15.5.0.3.b
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.3.b

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.3.c

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:37
End Time:	09-Nov-2025 02:06:41
Outcome:	Passed

Test Case Information

Name:	15.5.0.3.c
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.3.c

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.4.a

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:41
End Time:	09-Nov-2025 02:06:45
Outcome:	Passed

Test Case Information

Name:	15.5.0.4.a
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.4.a

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.4.b

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:45
End Time:	09-Nov-2025 02:06:50
Outcome:	Passed

Test Case Information

Name:	15.5.0.4.b
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.4.b

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.5

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:50
End Time:	09-Nov-2025 02:06:54
Outcome:	Passed

Test Case Information

Name:	15.5.0.5
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.5

Document: ../../../../../Requirement_mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.6

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:54
End Time:	09-Nov-2025 02:06:58
Outcome:	Passed

Test Case Information

Name:	15.5.0.6
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.6

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.7

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:06:58
End Time:	09-Nov-2025 02:07:02
Outcome:	Passed

Test Case Information

Name:	15.5.0.7
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.7

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.8

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:07:02
End Time:	09-Nov-2025 02:07:06
Outcome:	Passed

Test Case Information

Name:	15.5.0.8
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.8

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.9.a

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:07:06
End Time:	09-Nov-2025 02:07:09
Outcome:	Passed

Test Case Information

Name:	15.5.0.9.a
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.9.a

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary

15.5.0.9.b

Test Result Information

Result Type:	Test Case Result
Parent:	New Test Suite 1
Start Time:	09-Nov-2025 02:07:09
End Time:	09-Nov-2025 02:07:12
Outcome:	Passed

Test Case Information

Name:	15.5.0.9.b
Type:	Baseline Test

Test Case Requirements

Description: 15.5.0.9.b

Document: ../../../Requirement_Mapping/BWC_SRD_Rev7.xlsx

Verify Result

Name	Link to Plot
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)	Link
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)	Link
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)	Link
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)	Link
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)	Link
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)	Link
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)	Link
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)	Link
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)	Link
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)	Link
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)	Link
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)	Link
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)	Link
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)	Link
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)	Link
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)	Link
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)	Link
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)	Link
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)	Link
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)	Link
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)	Link

Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)	Link
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)	Link
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)	Link
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)	Link
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)	Link
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)	Link
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)	Link
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)	Link

Name
Test Assessment/.../step_1_1:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_2:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_1_3:verify(uint64(HVBatChargeStat) == 0)
Test Assessment/.../step_1_4:verify(uint64(HVBatChargeStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_2_1:verify(uint64(HVBatChargeStat) == 1)
Test Assessment/.../step_3_1:verify(uint64(DC_Isolation_Sts) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_4_1:verify(uint64(DC_Isolation_Sts) == 1)
Test Assessment/.../step_3_1:verify(uint64(HVBat_DC_CntctrStat) == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_6_1:verify(uint64(HVBat_DC_CntctrStat) == 1)
Test Assessment/.../step_7_1:verify(uint64(HVBatChargeStat) == 2)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_8_1:verify((MaxChargeCurrentAllowed) == 2.50*34)
Test Assessment/.../step_9_1:verify((MaxChargeCurrentAllowed) == 2.17*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_10_1:verify((MaxChargeCurrentAllowed) == 1.50*34)
Test Assessment/.../step_11_1:verify((MaxChargeCurrentAllowed) == 1.33*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_12_1:verify((MaxChargeCurrentAllowed) == 1.00*34)
Test Assessment/.../step_13_1:verify((MaxChargeCurrentAllowed) == 0.85*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.70*34)
Test Assessment/.../step_14_1:verify((MaxChargeCurrentAllowed) == 0.15*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0.06*34)
Test Assessment/.../step_16_1:verify((MaxChargeCurrentAllowed) == 0*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_18_1:verify((MaxChargeCurrentAllowed) == 0*34)
Test Assessment/.../step_19_1:verify(HVBat_DC_CntctrOpn == 1)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_20_1:verify(HVBatChargeStat == 3)
Test Assessment/.../step_21_1:verify(HVBat_DC_CntctrStat == 2)



Back to Report SummaryBack to Signal Summary

Name
Test Assessment/.../step_22_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_23_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_24_1:verify(HVBat_DC_CntctrOpn == 0)
Test Assessment/.../step_25_1:verify(HVBat_DC_CntctrStat == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_26_1:verify(HVBatChargeStat == 0)
Test Assessment/.../step_27_1:verify(MaxChargeCurrentAllowed == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_28_1:verify(DC_Isolation_Sts == 0)
Test Assessment/.../step_29_1:verify(HVBatChargeStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_30_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_31_1:verify(HVBat_DC_CntctrStat == 1)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_32_1:verify(HVBatChargeStat == 2)
Test Assessment/.../step_33_1:verify(MaxChargeCurrentAllowed == 1.50*34)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_34_1:verify(HVBat_DC_CntctrStat == 0)
Test Assessment/.../step_35_1:verify(HVBatChargeStat == 6)



[Back to Report Summary](#)[Back to Signal Summary](#)

Name
Test Assessment/.../step_36_1:verify(MaxChargeCurrentAllowed == 0)
Test Assessment/.../step_37_1:verify(DC_Isolation_Sts == 0)



[Back to Report Summary](#)[Back to Signal Summary](#)

Simulation

System Under Test Information

Model:	Simulink_Program
Harness:	Simulink_Program_Harness1
Harness Owner:	Simulink_Program/Subsystem/Plug-In Charging/dcfc
Release:	Current

Simulation Mode:	normal
Override SIL or PIL Mode:	0
Configuration Set:	Configuration3
Start Time:	0
Stop Time:	100
Checksum:	474775615 1369570535 3048184467 3462105877

Simulation Logs:
'Time' is defined, but is never used in the Test Sequence block. Delete this object.

'ChargingSysSts' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatCell_Voltage_High_Thrsh' is defined, but is never used in the Test Sequence block. Delete this object.

'ActiveStep' is defined, but is never used in the Test Sequence block. Delete this object.

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_8_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_9_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **2.17*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_10_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.50*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_11_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.33*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_12_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **1.00*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_13_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.85*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.70*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_14_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.15*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0.06*34**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_16_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_18_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**(MaxChargeCurrentAllowed)** == **0*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_19_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **1**, 'Test 15.5.0.6')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_20_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **3**, 'Test 15.5.0.9.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_21_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **2**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_22_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_23_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.9.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_24_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrOpn** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_25_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_26_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_27_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_28_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.5')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_29_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **1**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_30_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.2.b')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_31_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **1**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_32_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **2**, 'Test 15.5.0.4.a')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_33_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **1.50*34**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_34_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBat_DC_CntctrStat** == **0**, 'Test 15.5.0.8')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_35_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**HVBatChargeStat** == **6**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_36_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**MaxChargeCurrentAllowed** == **0**, 'Test 15.5.0.7')

Using the '==' operator to compare expressions of type double in the 'verify' statement can produce unexpected results.

Step 'step_37_1' in Test Sequence 'Simulink_Program_Harness1/Test Assessment':

verify(**DC_Isolation_Sts** == **0**, 'Test 15.5.0.7')

'HVBat_DC_CntctrStat' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBatChargeStat' is defined, but is never used in the Test Sequence block. Delete this object.

'DC_Isolation_Sts' is defined, but is never used in the Test Sequence block. Delete this object.

'MaxChargeCurrentAllowed' is defined, but is never used in the Test Sequence block. Delete this object.

'HVBat_DC_CntctrOpn' is defined, but is never used in the Test Sequence block. Delete this object.

Back to Report Summary

Test Logs:
No baseline criteria evaluation performed as no baseline data is available for this test.

Back to Report Summary