

Circuit Diagrams Tiger 1200 GT, Tiger 1200 GT Pro, Tiger 1200 Rally Pro

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.


All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. 01/2022 Issue 1





TABLE OF CONTENTS


Circuit Diagrams	Page
1 - Power Distribution Circuit	4
2 - Starter Motor Circuit	5
3 - Keyless Control Circuit	6
4 - Ignition Circuit	7
5 - ABS Circuit	8
6 - Brake Circuit	9
7 - Chassis Control Circuit	10
8 - Suspension Control Circuit	11
9 - Engine Management Circuit - ECM Power and Ground	12
0 - Engine Management Circuit - Pressure Sensors	13
11 - Engine Management Circuit - Temperature Sensors	14
2 - Engine Management Circuit - Switches	15
3 - Engine Management Circuit - Position Sensors	16
4 - Engine Management Circuit - Level Sensor	17
5 - Engine Management Circuit - Fuel Injection Components	18
6 - Engine Management Circuit - Throttle Control	19
17 - Engine Management Circuit - Cooling Fan	20
8 - Engine Management Circuit - Fuel Pump	21
9 - Instrument Circuit	22
⁰ - Lighting Circuit - Front	23
21 - Lighting Circuit - Rear	24
2 - Lighting Circuit - Indicators	25
3 - Communication Network Circuit	26
¹ 4 - Horn Circuit	27
^{25 -} Diagnostic Connector Circuit	28
6 - Accessories Circuit	29
P7 Heated Accessories Circuit	30
8 - Alarm Circuit	31
9 - Rider Information Circuit	32
0 - Ground Circuit	33




02 STARTER MOTOR CIRCUIT













06 BRAKE CIRCUIT





















12 ENGINE MANAGEMENT CIRCUIT - SWITCHES







14 ENGINE MANAGEMENT CIRCUIT - LEVEL SENSORS







16 ENGINE MANAGEMENT CIRCUIT - THROTTLE CONTROL







18 ENGINE MANAGEMENT CIRCUIT - FUEL PUMP







20 LIGHTING CIRCUIT - FRONT













24 HORN CIRCUIT










28 ALARM CIRCUIT



29 RIDER INFORMATION CIRCUIT

