Cooling Fan Operation

This document contains revised information on the cooling fan operation. It must be kept with the Owner's Handbook.

A Caution

The cooling fan operates automatically when the engine is running, and may continue to operate after the engine has been switched off.

Always keep hands and clothing away from the fan.

Contact with the rotating fan could result in minor or moderate injury.

The operation of the cooling fan has changed. The cooling fan may continue to operate for up to two minutes after the engine has been switched off.