

Circuit Diagrams
Rocket 3 GT, Rocket 3 R, Rocket 3 TFC

This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. Issue 1






TABLE OF CONTENTS


lircuit Diagrams		Page
1 -	- Power Distribution Circuit	L
2 -	- Starter Motor Circuit	5
3 -	- Keyless Control Circuit	6
	- Ignition Circuit 1 OF 2	\overline{t}
5 -	- Ignition Circuit 2 OF 2	8
	- ABS Circuit	Ç
7 -	- Engine Management Circuit - ECM Power and Ground	10
	Engine Management Circuit - Pressure Sensors	1
	Engine Management Circuit - Temperature Sensors	12
	- Engine Management Circuit - Switches	13
11 -	- Engine Management Circuit - Position Sensors	14
2 -	- Engine Management Circuit - Level Sensor	15
	- Engine Management Circuit - Fuel Injection Components 1 OF 2	16
	- Engine Management Circuit - Fuel Injection Components 2 OF 2	17
5 -	- Engine Management Circuit - Throttle Control	18
6 -	- Engine Management Circuit - Cooling Fan	19
7 -	- Engine Management Circuit - Fuel Pump	20
8 -	- Instrument Circuit	2
9 -	- Lighting Circuit - Front	22
0 -	- Lighting Circuit - Rear	23
21 -	- Lighting Circuit - Indicators	24
2 -	- Communication Network Circuit	25
3 -	- Horn Circuit	26
4 -	Diagnostic Connector Circuit	27
5 -	- Alarm Circuit	28
6	Accessories Circuit	29
7 -	- Heated Accessories Circuit	30
	Rider Information Circuit	3
9 -	Ground Circuit - Front	32
0 -	Ground Circuit - Middle	33
31 -	Ground Circuit - Rear	34


01 POWER DISTRIBUTION CIRCUIT







03 KEYLESS CONTROL CIRCUIT






05 IGNITION CIRCUIT 2 OF 2







07 ENGINE MANAGEMENT CIRCUIT – ECM POWER AND GROUND




10/34




09 ENGINE MANAGEMENT CIRCUIT – TEMPERATURE SENSORS





12/34




11 ENGINE MANAGEMENT CIRCUIT - POSITION SENSORS









16/34





15 ENGINE MANAGEMENT CIRCUIT – THROTTLE CONTROL







17 ENGINE MANAGEMENT CIRCUIT – FUEL PUMP







19 LIGHTING CIRCUIT - FRONT










24/34




23 HORN CIRCUIT












27 HEATED ACCESSORIES CIRCUIT






29 GROUND CIRCUIT - FRONT



30 GROUND CIRCUIT - MIDDLE



31 GROUND CIRCUIT - REAR

