

**Circuit Diagrams Street Triple RS** 


This document is protected by copyright and may not, in whole or part be stored in a retrieval system, or transmitted in any form or by any means, copied, photocopied, translated or reduced to any machine-readable form without prior consent in writing from Triumph Motorcycles Limited.

No liability can be accepted for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible.

Triumph Motorcycles Limited reserves the right to make changes and alter specifications without prior notice and without incurring an obligation to make such changes to products manufactured previously. See your authorised Triumph dealer for the latest information on product improvements incorporated after this publication.

All information contained in this publication is based on the latest product information available at the time of publication. Illustrations in this publication are intended for reference use only and may not depict actual model component parts.

© Triumph Motorcycles Ltd. 09.2019 Issue 1




#### **TABLE OF CONTENTS**

Circuit Diagrams	Page
1 - Power Distribution Circuit	
2 - Starter Motor Circuit	<u>!</u>
3 - Ignition Circuit	$\epsilon$
4 - ABS Circuit	
5 - Brake Circuit	8
6 - Engine Management Circuit - ECM Power and Ground	
7 - Engine Management Circuit - Pressure Sensors	10
8 - Engine Management Circuit - Temperature Sensors	1
9 - Engine Management Circuit - Switches	17
10 - Engine Management Circuit - Position Sensors	13
11 - Engine Management Circuit - Level Sensors	14
12 - Engine Management Circuit - Fuel Injection Components	1!
13 - Engine Management Circuit - Throttle Control	16
14 - Engine Management Circuit - Cooling Fan Circuit	1
15 - Engine Management Circuit - Fuel Pump Circuit	18
16 - Instrument Circuit	19
17 - Lighting Circuit - Front	20
18 - Lighting Circuit - Rear	2
19 - Lighting Circuit - Indicators	27
20 - Communication Network Circuit	23
21 - Horn Circuit	24
22 - Immobiliser Circuit	2.5
23 - Diagnostic Connector Circuit	26
24 - Accessories Circuit	2
25 - Heated Accessories Circuit	28
26 - Alarm Circuit	29
27 - Rider Information Circuit	30
28 - Earth Circuit - Front	3
29 - Earth Circuit - Middle	37
30 - Farth Circuit - Rear	33


# 01 - POWER DISTRIBUTION CIRCUIT STARTER MOTOR STARTER SOLENOID REGULATOR RECTIFIER <u>ALTERNAT</u>OR M48B-1 BATTERY SUB-HARNESS M48B-2 BATTERY POSITIVE TERMINAL M48B-3 FRONT ACCESSORY SOCKET, LIVE M21-2 BATTERY INSTRUMENTS -F29-2B--M01-6-BATTERY HOT F29-3B INSTRUMENTS -M01-18 TURN INDICATORS SUPPLY F29-4B 10.0 LIGHTING A HORN RELAY B DIP BEAM RELAY -R0511-B3-A STARTER MOTOR RELAY B ENGINE MANAGEMENT SYSTEM RELAY -R0907-A3-A STARTER MOTOR RELAY B ENGINE MANAGEMENT SYSTEM RELAY F25 15.0 EMS F29-5B-**-**F29-5A-R0907-B3 DC POSITIVE **IGNITION SWITCH** -M13-1- BATTERY F26 10.0 IGNITION F29-6B-**M13-6** BATTERY #2 ABS MODULATOR **--**F29-7A---F29-7B--M59-18- BATTERY A COOLING FAN RELAY B FUEL PUMP RELAY -N-----F29-8A-A COOLING FAN RELAY B FUEL PUMP RELAY ENGINE GROUND 2 **-**M48A-1

#### 02 - STARTER MOTOR CIRCUIT




5/33

#### 03 - IGNITION CIRCUIT




#### 04 - ABS CIRCUIT




7/33

## 05 - BRAKE CIRCUIT



#### 06 - ENGINE MANAGEMENT CIRCUIT - ECM POWER AND GROUND




9/33


## 07 - ENGINE MANAGEMENT CIRCUIT - PRESSURE SENSORS




#### 08 - ENGINE MANAGEMENT CIRCUIT - TEMPERATURE SENSORS




## 09 - ENGINE MANAGEMENT CIRCUIT - SWITCHES




## 10 - ENGINE MANAGEMENT CIRCUIT - POSITION SENSORS




# 11 - ENGINE MANAGEMENT CIRCUIT - LEVEL SENSORS




#### 12 - ENGINE MANAGEMENT CIRCUIT - FUEL INJECTION COMPONENTS




#### 13 - ENGINE MANAGEMENT CIRCUIT - THROTTLE CONTROL




## 14 - ENGINE MANAGEMENT CIRCUIT - COOLING FAN




# 15 - ENGINE MANAGEMENT CIRCUIT - FUEL PUMP




#### 16 - INSTRUMENT CIRCUIT




## 17 - LIGHTING CIRCUIT - FRONT




#### 18 - LIGHTING CIRCUIT - REAR




#### 19 - LIGHTING CIRCUIT - INDICATORS




#### 20 - COMMUNICATIONS NETWORK CIRCUIT




# 21 - HORN CIRCUIT




# 22 - IMMOBILISER CIRCUIT




## 23 - DIAGNOSTIC SOCKET CIRCUIT




## 24 - ACCESSORIES CIRCUIT




## 25 - HEATED ACCESSORIES CIRCUIT




# 26 - ALARM CIRCUIT



#### 27 - RIDER INFORMATION CIRCUIT





#### 28 - EARTH CIRCUIT - FRONT





## 29 - EARTH CIRCUIT - MIDDLE





#### 30 - EARTH CIRCUIT - REAR

