To be located on all DC junction boxes and every 10' on DC conduit





**DC Junction Box** 



Soladeck

DC Conduit






Service Disconnect



NEC 690.56(C)(1)(A)







**Utility Meter** Socket

ELECTRICAL SHOCK HAZARD





**RAPID SHUTDOWN** SWITCH FOR SOLAR PV SYSTEM 690.56(C)(3)









Photovoltaic **AC Disconnect** 












NEC 690.54

**Load Center** (To Combine Inverters)





**PHOTOVOLTAIC** DC DISCONNECT NEC 690.4(B)







Inverter(s)

**PHOTOVOLTAIC** DC DISCONNECT

NEC 690.53



DC Disconnect





**Enphase Envoy Box**