





SERIES 100 UL ROOF MOUNT SYSTEM

SnapNrack Residential PV Mounting Systems Code Compliant Installation Manual

1) Locate the rafter



2) Drill the pilot hole



3) Prep the base



4) Attach base



5) Set the flashing



6) Attach L-Foot





Series 100 UL Flashed L-Foot

Step-by-Step Instructions1) Locate the rafter underneath

- 1) Locate the rafter underneath the decking of the roof by looking underneath the eaves or in the attic.
- 2) Drill a pilot hole through the roofing material into the rafter to ensure that the lag bolt will be located into a solid portion of the rafter. If the rafter is not found then seal the pilot hole immediately with roofing sealant.
- 3) Apply roofing sealant to the bottom of the base and directly onto the lag bolt to ensure a water tight seal.
- 4) Attach the L-foot base with a 5/16" lag bolt and a minimum embedment of 2 $\frac{1}{2}$ " lag shank into the rafter. Tighten Lag bolt to seat with a hand wrench.
- 5) Slide the flashing underneath the row of shingles, directly above the installed standard base, and then line up the hole in the flashing with the threads on the base. It may be necessary to pry up shingles with a breaker bar.
- 6) Attach the L-foot to the threaded portion of the base that is protruding from the flashing. Then tighten the flange bolt over the threads to 10 16 ft-lbs. The L-foot can be attached in any orientation.

Notes

- SnapNrack engineered systems should only be used with SnapNrack components and hardware. Any alternate application may void the warranty and structural calculations could become invalid.

Warning

- If a pilot hole is drilled and a rafter is not found, immediately seal pilot hole with roofing sealant to avoid water damage.
- Do not over tighten hardware.
- Always wear fall protection and safety gear.

Design Tools

- SnapNrack has a suite of design tools to help configure your PV installation to be an accurate and fast install. Please visit us at: www.SnapNrack.com