

## INFORMATION SHEET

# KUP-L-Tap, Insul-Eater Single Use Insulation Piercing Connectors

### 1) Specifications:

Conductors - Class B or C Aluminum and or Copper wires Temperature rating - 90°C

Item ID	Run	Тар	Torque (in-lbs)	Tools (Socket & Box wrenches)	Voltage
IPC-1/0-2	1/0 - 8 AWG	#2 - #8 AWG	192	1/2"	300 (480 grounded Y system)
IPC-4/0-6	4/0 - #4 AWG	#6 - #14 AWG	156	1/2"	600
IPC-4/0-2/0 * +	4/0 - #2 AWG	2/0 - #6 AWG	300	1/2"	600
IPC-250-4/0 * #	250 kcmil-#1 AWG	4/0 - #6 AWG	360	5/8"	600
IPC-350-4/0	350 kcmil-4/0	4/0 - #10 AWG	300	5/8"	300 (480 grounded Y system)
IPC-350-350	350 kcmil-4/0	350 kcmil-4/0	300	5/8"	300 (480 grounded Y system)
IPC-500-12	500-250 kcmil	#10-#12 AWG	300	5/8"	300 (480 grounded Y system)
IPC-500-250	500-250 kcmil	250 - #4 AWG	720	5/8" & 11/16"	600
IPC-500-500 *	500-300 kcmil	500-250 kcmil	900	7/8"	600
IPC-750-500 *	750-500kcmil	500-350kcmil	900	7/8"	600

<sup>\*</sup> Can be used on bare wire or bare & insulated wire combinations

- \* When used on bare conductor, break out the tabs and extend wire 1.5 2" beyond the connector body.
- + Tap side is limited to .528" OD including the insulation.
- # Max OD on the main is .730" inculding insulation

-IPC-250-4/0 & IPC-4/0-2/0- To insure the top and bottom are aligned -There are lines on the side of the connector to help.

- 2) Installation Instructions For Use as a Run and Tap:
  - a) Remove the tab blocking the Main conductor groove with screwdriver or pliers.
    - Tap must be broken cleanly to the bottom of the channel.
  - b) Cut insulated cable end **squarely** and apply a crisscrossed layer of UL listed electrical **tape over the exposed end of the wire.**Tape the exposed wire end with Two pieces of **tape** measuring approximately three inches long.
  - c) **Separate** the connector halves by loosening the bolt.
  - d) Slide the connector over the run conductor.
  - e) Insert the tap conductor until it butts up against the tab.

### BE SURE THE TAP CONDUCTOR IS ALL THE WAY THROUGH THE CONNECTOR.

- f) Center both conductors over the piercing teeth, and finger tighten the bolt.
  - (Refer to the diagram below for correct placement of conductors)
- g) Holding the connector firmly in your hand, tighten the bolt to the torque in the above table.

## 3) Additional Information

- a) Connector can be used on BUILDING CODE (Stranded CLASS B or C) wire either copper and/or aluminum conductors
- b) The Insul-Eater is **fully** insulated without an external cover or tape
- c) The Insul-Eater connector should not be installed when tap conductor is under load

