



POWER / BATERAI




MikroKontroller




A A B B C C D D


TB6612 DRIVER MOTOR



L298N



SERVO



HOLE

