



- * 5 : 不带车灯自动熄灭系统 * 8 :7ZR-FE * 9 :4ZR-FE







R R

E36(A) 主车身 ECU HEAD HF 8**(**A) 5**(**A) 29**(**A) 28**(**A) (*4) (*4) д (<u>*</u> œ B(*5) B(*5) 20 HF HU Α HF (HL) HU EL Т Α EL 变光器开关 闪烁 关闭 0-灯光控制开关 AUT0 (*1) 低 0-**~** -0 高 尾灯 0--0 大灯 EL E15 大灯变光器开关总成 15 * 1 : 带自动灯光控制 * 4 : 带车灯自动熄灭系统 E71 4 号接线连接器 * 5 : 不带车灯自动熄灭系统

E36(A) 主车身 ECU





90980-12A15

