

Windows 2000/XP Device Driver

Installation

- **DTU-205**
- **DTU-225**
- **DTU-234**

1. Introduction

Dtu2xx is the Windows-2000/XP device driver for DEKTEC's line of digital-video USB Devices. The driver is generic to all DEKTEC USB Devices that have a type number starting with "DTU-2". The Dtu2xx driver supports operation of multiple devices.

1.1. USB Devices Supported by the Dtu2xx Device Driver

The **Dtu2xx** device driver supports the following DEKTEC devices:

DTU-205	FantASI USB-2 ASI/SDI Output Adapter
DTU-225	FantASI USB-2 ASI/SDI Input Adapter
DTU-234	FantASI USB-2 VSB/QAM-B Input Adapter

1.2. Files

The **Dtu2xx.zip** archive contains the following files:

Dtu2xx Setup.exe	Setup program that installs the Dtu2xx device driver.
Dtu2xx Installation.pdf	This installation document.

The setup program copies two **Dtu2xx** device-driver files into a selectable directory, defaulting to **C:\Program Files\DEKTEC\Drivers**.

Dtu2xx.inf	V2.2.1.67	Device driver information file (".inf").
Dtu2xx.sys	V2.2.1.67	Device driver 'system' file (executable).

Thereafter, setup instructs the Windows 2000/XP Plug'n Play manager to install the device driver files. A log file is created, to aid debugging in case of an install failure.

DtDrvInstall.log	Log of installation events.
-------------------------	-----------------------------

2. Installing the Software

The **Dtu2xx** setup program is self-contained. Installing the device driver is as simple as running the setup executable and pressing "Next" a few times.

NOTE

- A Windows 2000/XP device driver can only be installed by a user account with the privilege to *load and unload device drivers*, e.g. administrator.
- Please make sure that no application is currently running that uses a DEKTEC device.

Please *disconnect* all DTU-2XX devices *before* running this installation. No DTU-2XX device should be connected to the system while running this installation.

After having installed the driver files the following should be performed to complete the installation:

1. Connect the **DTU-2xx** adapter to a USB port using the supplied USB cable.

Windows recognizes a new **DTU-2xx** (no firmware) device and the 'install new hardware wizard' will prompt you for the location of the **DTU-2xx** driver files.

2. If Windows XP with SP2 is used Windows will ask if: "Windows can connect to Windows Update to search for software". Select **No, not this time** and press **Next**.
3. Choose **install software automatically** and press **Next**.
4. The Wizard will now install the driver needed for configuring the **DTU-2xx** device.
5. Press **Finish** when completed.

At this point windows will recognize the configured **DTU-2xx** device and will prompt you again to install a driver for this device.

6. Repeat Steps 2 to 5 to complete the installation.

3. Troubleshooting

3.1. Device Status LED



At start-up the device led (the left led) will flash red, green and orange to indicate the power-up sequence. After the power-up sequence the device led gives an indication about the driver status. When the driver is correctly installed and all firmware is correctly downloaded the device led indicator should be constant **green**.

If the device led is **orange** the driver is probably not correctly installed. See 3.2 for verification of the device status.

When the device led keeps flashing **red** or not lit at all make sure the device is correctly connected to the USB port. If the device is correctly connected and the problem persists please contact DEKTEC for support at fantasi@dektec.com or support@dektec.com.

3.2. Checking Device Status in the Device Manager

The Windows-2000/XP device manager can be used to check whether the Dtu2xx driver runs properly. To check the device status of a DTU-2XX:

1. Open the Windows-2000/XP device manager: right-click **My Computer**, select **Manage**, and go to **Device Manager** under **System Tools**.
2. Locate the DEKTEC device in category **Professional audio/video interfaces**.
3. Right-click the device, select **Properties**, and check the **Device status** pane.

The status should be: **This device is working properly**. If not, don't try the Windows-2000/XP Troubleshooter (it does not know anything about DEKTEC cards), but inspect the event log (§3.3) and the install log (§3.4). If the problem persists, please contact DEKTEC at fantasi@dektec.com or support@dektec.com.

3.3. Checking the Event Log

The System Event Log can be consulted to check whether the **Dtu2xx** device driver has been loaded and started properly. To open the System Event Log:

1. Right-click **My Computer**, select **Manage**, and open **Event Viewer** under **System Tools**.
2. Select the **System** log.
3. Driver messages from DEKTEC USB-2 devices have **Dtu2xx** in the **Source** column.

If the driver loads successfully, the following event message is logged:

The Dtu2xx driver (Rev 2.2.1.67) has loaded successfully.

The device-driver version listed in this message should match the **Dtu2xx**-version number listed in the file overview in §1.2.

For each DEKTEC USB-2 device connected in the system, a start-up message listing USB Device Type and Firmware Version should be logged, e.g.:

The DTU-205 (Firmware Version 0) started successfully.

Obviously, if the Dtu2xx driver detects an error while trying to start the USB-2 Device, the message above will not occur. Instead, an error message is logged, which may be helpful to find the source of the problem.

3.4. Checking the Install Log

The install log is a text file ([DtDrivInstall.log](#)) written into [C:\Program Files\DEKTEC\Drivers](#) (or a redirected path). In case of installation troubles, please contact DEKTEC at fantasi@dektec.com or support@dektec.com, attaching the install log.

4. Dtu2xx WDM Device Driver Revision History

Version	Date	Change Description
V2.2.1.67	2005.07.13	• Improved performance for DTU-205 • Fixes memory leak in driver resulting in a system crash after several hours/days • Fixes system lock-up during PC reboot
V2.1.0.57	2005.02.10	• Fixed bug where DTU-225 FIFO load could exceed the actual FIFO size (i.e. > 8MB)
V2.0.2.50	2004.11.03	• Fixed bug where DTU-225 did not always provide packet alignment data when in ST188 or ST204 mode
V2.0.0.45	2004.09.01	• Includes support for the DTU-205 • Merged functionality of Dtu2xxLoad.sys and Dtu2xx.sys driver into one driver (dtu2xx.sys)
V1.0.2.18	2004.06.29	• Fixed problem in driver, which caused a blue-screen crash of windows
V1.0.0.6	2004.04.08	• Fix on status flags. • Service Start Type to 'on demand' to suppress error events at start-up
V1.0.0.0	2004.03.18	• USB-1 support