


Open Chiplet Atlas Harness (OCAH)

Technical Reference Manual

Version 0.5.33, 2026-09-11

Table of Contents

Documentation Overview . . . 1
List of Figures . . . 2
List of Tables . . . 6
1. OCAH Architecture & Design . . . 77
1.1. Platform Overview . . . 77
1.1.1. OCAH High-Level Features . . . 77
1.1.2. Top Block Diagram . . . 77
1.2. OCAH Memory Map . . . 78
1.2.1. Decode Response Codes . . . 79
1.3. Power Domains . . . 80
1.4. Clock Domains . . . 80
1.4.1. Reference Counter . . . 82
1.5. Reset . . . 82
1.5.1. IC_RESET TDR . . . 83
1.6. RTL Assertions . . . 83
2. OCAH Platform Components . . . 85
2.1. System Management Unit (SMU) . . . 85
2.1.1. Composition . . . 85
2.1.2. AXI Crossbar . . . 86
2.1.3. Clocks and Resets . . . 88
2.1.4. Lifecycle and Feature Control . . . 90
2.1.5. Security Processor (SEP) . . . 91
2.1.5.1. Overview . . . 91
2.1.5.1.1. Responsibilities . . . 93
2.1.5.1.2. Threat Model . . . 93
2.1.5.1.3. Attack Countermeasures . . . 93
2.1.5.1.4. Clocks and Resets . . . 93
2.1.5.1.5. CPU . . . 93
2.1.5.1.6. Boot ROM . . . 94
2.1.5.1.7. Interconnect . . . 94
2.1.5.1.8. Interrupts . . . 94
2.1.5.1.9. Peripherals . . . 94
2.1.5.1.10. Security and Lifecycle . . . 94
2.1.5.1.11. Cryptographic Subsystem . . . 94
2.1.5.1.12. Memory Map . . . 94
2.1.5.2. Threat Model . . . 94
2.1.5.2.1. Software Attacks . . . 94
2.1.5.2.2. Physical Attacks . . . 95
2.1.5.2.3. Supply-Chain Attacks . . . 95
2.1.5.2.4. Limits of Protection . . . 95
2.1.5.3. Attack Countermeasures . . . 95
2.1.5.3.1. Debug and DFT Security Considerations . . . 95

2.1.5.3.1.1. Debug and Scan Dump . . . 96
2.1.5.3.1.2. Class 2 Asset Manifest and Naming . . . 96
2.1.5.3.1.3. Secure Test Mode (SECURE_TM) . . . 97
2.1.5.4. Clocks and Resets . . . 98
2.1.5.4.1. Clock Distribution . . . 98
2.1.5.4.2. Reset Architecture . . . 99
2.1.5.4.3. SEP Reset Controller . . . 100
2.1.5.4.3.1. Software Reset Register . . . 102
2.1.5.4.3.2. Isolation and Reset Sequencing . . . 103
2.1.5.4.3.3. Resetting the Key Manager . . . 105
2.1.5.4.3.4. Resetting the TRNG . . . 105
2.1.5.4.3.5. Memory Map and Register Reference . . . 106
2.1.5.4.3.5.1. Memory Map . . . 106
2.1.5.4.3.5.2. Detailed Register Map . . . 106
2.1.5.4.3.5.2.1. SEP Reset Control Address Map . . . 106
2.1.5.4.3.5.2.1.1. SW_RESET_N . . . 106
2.1.5.5. CPU . . . 106
2.1.5.5.1. Processor Core . . . 108
2.1.5.5.2. Local Memory . . . 108
2.1.5.5.2.1. Dual Scratch Register Banks . . . 108
2.1.5.5.2.1.1. Scratch Register Reference . . . 109
2.1.5.5.2.1.1.1. SEP Scratch Address Map . . . 109
2.1.5.5.2.1.1.1.1. SCRATCH[8] . . . 109
2.1.5.5.3. Reset and Boot . . . 109
2.1.5.5.3.1. Configuration Straps . . . 109
2.1.5.5.3.2. Reset Vector . . . 109
2.1.5.5.4. System Interfaces . . . 110
2.1.5.5.4.1. DMA Interface . . . 110
2.1.5.5.5. Debug . . . 110
2.1.5.5.6. Alarm Aggregation Processor (AGP) . . . 110
2.1.5.5.7. Memory Map and Register Reference . . . 110
2.1.5.5.7.1. Memory Map . . . 110
2.1.5.5.7.2. Detailed Register Map . . . 110
2.1.5.5.7.2.1. SEP CPU Control Address Map . . . 110
2.1.5.5.7.2.1.1. CLOCK_GATE_CTRL . . . 112
2.1.5.5.7.2.1.2. REFERENCE_COUNTER . . . 112
2.1.5.5.7.2.1.3. TIMEOUT_INTERRUPT . . . 112
2.1.5.5.7.2.1.4. PKA_CTRL . . . 112
2.1.5.5.7.2.1.5. TIMEOUT_COUNT_DMA . . . 113
2.1.5.5.7.2.1.6. TIMEOUT_COUNT_SYS_IN . . . 113
2.1.5.5.7.2.1.7. TIMEOUT_COUNT_MAILBOX_INBOUND . . . 113
2.1.5.5.7.2.1.8. TIMEOUT_COUNT_MAILBOX_OUTBOUND . . . 113
2.1.5.5.7.2.1.9. TIMEOUT_COUNT_ENTROPY_WRITE . . . 113
2.1.5.5.7.2.1.10. TIMEOUT_COUNT_ENTROPY_READ . . . 113

2.1.5.5.7.2.1.11. TIMEOUT_COUNT_FILTER_OUT . . . 114
2.1.5.5.7.2.1.12. TIMEOUT_COUNT_ALIAS_REMAP . . . 114
2.1.5.5.7.2.1.13. TIMEOUT_ENABLE . . . 114
2.1.5.5.7.2.1.14. TIMEOUT_CLEAR . . . 114
2.1.5.5.7.2.1.15. TIMEOUT_MODE . . . 114
2.1.5.5.7.2.1.16. SEP_TEST_CTRL . . . 114
2.1.5.5.7.2.1.17. SEP_GLOBAL_BASE_ADDR . . . 115
2.1.5.5.7.2.1.18. SEP_LOCAL_BASE_ADDR . . . 115
2.1.5.5.7.2.1.19. SEP_REGION_SIZE . . . 115
2.1.5.5.7.2.1.20. SMU_GLOBAL_BASE_ADDR . . . 115
2.1.5.5.7.2.1.21. SMU_REGION_SIZE . . . 115
2.1.5.5.7.2.1.22. SMC_FUSE_SENSE_STATUS . . . 115
2.1.5.5.7.2.1.23. SEP_FUSE_SENSE_STATUS . . . 116
2.1.5.5.7.2.1.24. SEP_SW_DEBUG . . . 116
2.1.5.5.7.2.1.25. SEP_NMI_VEC . . . 116
2.1.5.5.7.2.1.26. SEP_NMI_VEC_LOCK . . . 116
2.1.5.5.7.2.1.27. EXT_TRNG_SRC_SEL . . . 116
2.1.5.5.7.2.1.28. EXT_TRNG_SRC_SEL_LOCK . . . 117
2.1.5.5.7.2.1.29. KM_WIPE_CTRL . . . 117
2.1.5.5.7.2.1.30. DMA_BUS_ERR_STATUS . . . 117
2.1.5.5.7.2.1.31. DMA_BUS_ERR_CLEAR . . . 117
2.1.5.5.7.2.1.32. PERIPH_BUS_ERR_STATUS . . . 117
2.1.5.5.7.2.1.33. PERIPH_BUS_ERR_CLEAR . . . 118
2.1.5.5.7.2.1.34. SEP_VERSION_ID . . . 118
2.1.5.6. Boot ROM . . . 118
2.1.5.6.1. ROM Architecture . . . 118
2.1.5.6.2. Hardware Configuration and Integrity . . . 118
2.1.5.6.3. Boot Flow . . . 119
2.1.5.6.3.1. BL0 Secure Boot and BL1 Execution Unlock . . . 119
2.1.5.6.4. Firmware Reference . . . 119
2.1.5.7. Interconnect . . . 119
2.1.5.7.1. Topology . . . 119
2.1.5.7.1.1. Top Level AXI4 . . . 119
2.1.5.7.1.2. Fabric Topology . . . 121
2.1.5.7.2. Interfaces . . . 124
2.1.5.7.3. Address Remapping . . . 125
2.1.5.7.4. Filtering and Protection . . . 125
2.1.5.7.5. Routing . . . 125
2.1.5.7.5.1. Transaction Routing . . . 126
2.1.5.7.6. Memory Map and Register Reference . . . 127
2.1.5.7.6.1. Memory Map . . . 127
2.1.5.7.6.2. Detailed Register Map . . . 127
2.1.5.8. Interrupts . . . 127
2.1.5.8.1. Controllers . . . 127

2.1.5.8.2. Sources and Routing . . . 127
2.1.5.8.2.1. SEP CPU Interrupt Vector Map . . . 127
2.1.5.8.2.2. Non-PIC Interrupt Paths . . . 129
2.1.5.8.2.2.1. NMI — Watchdog Timer Bark . . . 129
2.1.5.8.2.2.2. Timer and Software Interrupts . . . 129
2.1.5.8.2.2.3. Memory ECC Errors . . . 129
2.1.5.8.2.2.3.1. Correctable (single-bit) errors . . . 129
2.1.5.8.2.2.3.2. Uncorrectable (double-bit) errors . . . 130
2.1.5.8.2.2.3.3. Debug bus mirror . . . 130
2.1.5.8.3. Software Handling . . . 130
2.1.5.8.4. Memory Map and Register Reference . . . 131
2.1.5.8.4.1. Memory Map . . . 131
2.1.5.8.4.2. Detailed Register Map . . . 131
2.1.5.8.4.2.1. EL2_PIC . . . 131
2.1.5.8.4.2.1.1. meipl[256] . . . 132
2.1.5.8.4.2.1.2. meip[8] . . . 132
2.1.5.8.4.2.1.3. meie[256] . . . 132
2.1.5.8.4.2.1.4. mpiccfg . . . 132
2.1.5.8.4.2.1.5. meigwctrl[256] . . . 132
2.1.5.8.4.2.1.6. meigwclr[256] . . . 132
2.1.5.9. Peripherals . . . 133
2.1.5.9.1. Direct Memory Access (DMA) . . . 133
2.1.5.9.1.1. OCAH Modifications . . . 133
2.1.5.9.1.1.1. Completion Reporting . . . 134
2.1.5.9.1.2. Future Enhancements . . . 135
2.1.5.9.1.3. Memory Map and Register Reference . . . 135
2.1.5.9.1.3.1. Memory Map . . . 135
2.1.5.9.1.3.2. Detailed Register Map . . . 135
2.1.5.9.1.3.2.1. DMA Controller . . . 135
2.1.5.9.1.3.2.1.1. INTR_STATE . . . 136
2.1.5.9.1.3.2.1.2. INTR_ENABLE . . . 136
2.1.5.9.1.3.2.1.3. INTR_TEST . . . 136
2.1.5.9.1.3.2.1.4. ALERT_TEST . . . 137
2.1.5.9.1.3.2.1.5. SRC_ADDR_LO . . . 137
2.1.5.9.1.3.2.1.6. SRC_ADDR_HI . . . 137
2.1.5.9.1.3.2.1.7. DST_ADDR_LO . . . 137
2.1.5.9.1.3.2.1.8. DST_ADDR_HI . . . 137
2.1.5.9.1.3.2.1.9. ADDR_SPACE_ID . . . 137
2.1.5.9.1.3.2.1.10. ENABLED_MEMORY_RANGE_BASE . . . 138
2.1.5.9.1.3.2.1.11. ENABLED_MEMORY_RANGE_LIMIT . . . 138
2.1.5.9.1.3.2.1.12. RANGE_VALID . . . 138
2.1.5.9.1.3.2.1.13. RANGE_REGWEN . . . 138
2.1.5.9.1.3.2.1.14. CFG_REGWEN . . . 138
2.1.5.9.1.3.2.1.15. TOTAL_DATA_SIZE . . . 138

2.1.5.9.1.3.2.1.16. CHUNK_DATA_SIZE . . . 139
2.1.5.9.1.3.2.1.17. TRANSFER_WIDTH . . . 139
2.1.5.9.1.3.2.1.18. CONTROL . . . 139
2.1.5.9.1.3.2.1.19. SRC_CONFIG . . . 140
2.1.5.9.1.3.2.1.20. DST_CONFIG . . . 140
2.1.5.9.1.3.2.1.21. STATUS . . . 140
2.1.5.9.1.3.2.1.22. ERROR_CODE . . . 141
2.1.5.9.1.3.2.1.23. SHA2_DIGEST_0[16] . . . 141
2.1.5.9.1.3.2.1.24. HANDSHAKE_INTR_ENABLE . . . 141
2.1.5.9.1.3.2.1.25. CLEAR_INTR_SRC . . . 141
2.1.5.9.1.3.2.1.26. CLEAR_INTR_BUS . . . 142
2.1.5.9.1.3.2.1.27. INTR_SRC_ADDR_0[11] . . . 142
2.1.5.9.1.3.2.1.28. INTR_SRC_WR_VAL_0[11] . . . 142
2.1.5.9.2. Mailboxes . . . 142
2.1.5.9.3. Peripheral Subsystem . . . 144
2.1.5.9.4. Serial Peripheral Interface (SPI) . . . 145
2.1.5.9.4.1. Use Cases . . . 145
2.1.5.9.4.2. Features . . . 145
2.1.5.9.4.3. Integration and Register Access . . . 145
2.1.5.9.4.4. Interrupts . . . 146
2.1.5.9.4.5. DMA Trigger . . . 146
2.1.5.9.4.6. Core Reference . . . 146
2.1.5.9.4.7. Memory Map and Register Reference . . . 146
2.1.5.9.4.7.1. Memory Map . . . 146
2.1.5.9.4.7.2. Detailed Register Map . . . 146
2.1.5.9.4.7.2.1. SPI Host . . . 146
2.1.5.9.4.7.2.1.1. INTR_STATE . . . 147
2.1.5.9.4.7.2.1.2. INTR_ENABLE . . . 147
2.1.5.9.4.7.2.1.3. INTR_TEST . . . 147
2.1.5.9.4.7.2.1.4. ALERT_TEST . . . 147
2.1.5.9.4.7.2.1.5. CONTROL . . . 147
2.1.5.9.4.7.2.1.6. STATUS . . . 148
2.1.5.9.4.7.2.1.7. CONFIGOPTS . . . 149
2.1.5.9.4.7.2.1.8. CSID . . . 149
2.1.5.9.4.7.2.1.9. COMMAND . . . 149
2.1.5.9.4.7.2.1.10. ERROR_ENABLE . . . 150
2.1.5.9.4.7.2.1.11. ERROR_STATUS . . . 150
2.1.5.9.4.7.2.1.12. EVENT_ENABLE . . . 150
2.1.5.9.5. Watchdog Timer (WDT) . . . 151
2.1.5.9.5.1. Bus Interface . . . 151
2.1.5.9.5.2. Clock, Reset, and Debug Behavior . . . 151
2.1.5.9.5.3. Bark Interrupt and Bite Reset . . . 151
2.1.5.9.5.4. Programming Reference . . . 151
2.1.5.9.5.5. Memory Map and Register Reference . . . 152

2.1.5.9.5.5.1. Memory Map . . . 152
2.1.5.9.5.5.2. Detailed Register Map . . . 152
2.1.5.9.5.5.2.1. Always-On Timer . . . 152
2.1.5.9.5.5.2.1.1. ALERT_TEST . . . 152
2.1.5.9.5.5.2.1.2. WKUP_CTRL . . . 152
2.1.5.9.5.5.2.1.3. WKUP_THOLD_HI . . . 153
2.1.5.9.5.5.2.1.4. WKUP_THOLD_LO . . . 153
2.1.5.9.5.5.2.1.5. WKUP_COUNT_HI . . . 153
2.1.5.9.5.5.2.1.6. WKUP_COUNT_LO . . . 153
2.1.5.9.5.5.2.1.7. WDOG_REGWEN . . . 153
2.1.5.9.5.5.2.1.8. WDOG_CTRL . . . 153
2.1.5.9.5.5.2.1.9. WDOG_BARK_THOLD . . . 153
2.1.5.9.5.5.2.1.10. WDOG_BITE_THOLD . . . 154
2.1.5.9.5.5.2.1.11. WDOG_COUNT . . . 154
2.1.5.9.5.5.2.1.12. INTR_STATE . . . 154
2.1.5.9.5.5.2.1.13. INTR_TEST . . . 154
2.1.5.9.5.5.2.1.14. WKUP_CAUSE . . . 154
2.1.5.10. Security and Lifecycle . . . 154
2.1.5.10.1. OTP Fuse Controller . . . 154
2.1.5.10.1.1. Fuse Sensing and Boot Sequencing . . . 157
2.1.5.10.1.2. Shadow Register and JTAG Access Control . . . 158
2.1.5.10.1.3. Fuse Programming and RMA Authorization . . . 158
2.1.5.10.1.3.1. Programming Voltage . . . 158
2.1.5.10.1.4. Shadow Register Updates and Test-Mode Protection . . . 158
2.1.5.10.1.5. Fuse Fields . . . 159
2.1.5.10.1.6. Anti-Rollback Security-Version Flags . . . 162
2.1.5.10.1.7. RTL Integration . . . 162
2.1.5.10.1.8. Memory Map and Register Reference . . . 162
2.1.5.10.1.8.1. Memory Map . . . 162
2.1.5.10.1.8.2. Detailed Register Map . . . 163
2.1.5.10.1.8.2.1. SEP eFuse Map Address Map . . . 163
2.1.5.10.1.8.2.1.1. LOCKS . . . 164
2.1.5.10.1.8.2.1.2. LOCKS_SPARE . . . 166
2.1.5.10.1.8.2.1.3. LC_STATE . . . 167
2.1.5.10.1.8.2.1.4. SBOOT_DIS . . . 167
2.1.5.10.1.8.2.1.5. TRANSIENT_RMA_EN . . . 167
2.1.5.10.1.8.2.1.6. SIP_DIS . . . 167
2.1.5.10.1.8.2.1.7. SYS_DIS . . . 168
2.1.5.10.1.8.2.1.8. RMA_SIP_TOKEN_DIGEST . . . 169
2.1.5.10.1.8.2.1.9. RMA_CHIPLET_TOKEN_DIGEST . . . 169
2.1.5.10.1.8.2.1.10. CLASS_KEY . . . 169
2.1.5.10.1.8.2.1.11. CHIPLET_PUBK_REVOKE . . . 169
2.1.5.10.1.8.2.1.12. BL1_VERSION . . . 169
2.1.5.10.1.8.2.1.13. BL2_VERSION . . . 170

2.1.5.10.1.8.2.1.14. CHIPLET_UID . . . 170
2.1.5.10.1.8.2.1.15. SIP_PUBK_HASH0 . . . 170
2.1.5.10.1.8.2.1.16. SIP_UID . . . 170
2.1.5.10.1.8.2.1.17. SYS_PUBK_HASH . . . 170
2.1.5.10.1.8.2.1.18. SYS_UID . . . 170
2.1.5.10.1.8.2.1.19. STATUS_RPT . . . 170
2.1.5.10.1.8.2.1.20. ROM_CTL . . . 171
2.1.5.10.1.8.2.1.21. SYSCLK_FREQ_MHZ . . . 171
2.1.5.10.1.8.2.1.22. CHIPLET_PUBK_HASH0 . . . 171
2.1.5.10.1.8.2.1.23. CHIPLET_PUBK_HASH1 . . . 171
2.1.5.10.1.8.2.1.24. REQUIRED_SIGNERS . . . 171
2.1.5.10.1.8.2.1.25. REQUIRED_ALGS . . . 172
2.1.5.10.1.8.2.1.26. CHIPLET_PUBK_PQC_HASH0 . . . 172
2.1.5.10.1.8.2.1.27. CHIPLET_PUBK_PQC_HASH1 . . . 172
2.1.5.10.1.8.2.1.28. SIP_PUBK_PQC_HASH0 . . . 172
2.1.5.10.1.8.2.1.29. SYS_PUBK_PQC_HASH . . . 172
2.1.5.10.1.8.2.1.30. SIP_PUBK_HASH1 . . . 172
2.1.5.10.1.8.2.1.31. SIP_PUBK_PQC_HASH1 . . . 173
2.1.5.10.1.8.2.1.32. SEP_CHIPLET_ID . . . 173
2.1.5.10.1.8.2.1.33. SEP_SIP_ID . . . 173
2.1.5.10.1.8.2.1.34. SEP_SYS_ID . . . 173
2.1.5.10.1.8.2.1.35. spare0 . . . 173
2.1.5.10.1.8.2.1.36. spare1 . . . 173
2.1.5.10.1.8.2.1.37. spare2 . . . 173
2.1.5.10.1.8.2.1.38. spare3 . . . 174
2.1.5.10.1.8.2.1.39. spare4 . . . 174
2.1.5.10.1.8.2.1.40. spare5 . . . 174
2.1.5.10.1.8.2.1.41. spare6 . . . 174
2.1.5.10.1.8.2.1.42. spare7 . . . 174
2.1.5.10.1.8.2.1.43. spare8 . . . 174
2.1.5.10.2. Token Processing . . . 175
2.1.5.10.2.1. Token Generation, Storage and Provisioning . . . 175
2.1.5.10.2.2. Token Matching Mechanism and Attack Countermeasures . . . 175
2.1.5.10.2.3. Token Submission . . . 175
2.1.5.10.2.4. Matching Logic Countermeasures . . . 176
2.1.5.10.2.5. Post Token Matching Handling . . . 177
2.1.5.10.3. Security Disable (SEC_DIS) . . . 177
2.1.5.10.3.1. Token Activation . . . 178
2.1.5.10.3.2. Fuse Sensing and the Shadow Map . . . 178
2.1.5.10.3.3. Reset Persistence . . . 178
2.1.5.10.3.4. Silicon Revision Scope . . . 178
2.1.5.10.3.5. Implementation Requirements . . . 178
2.1.5.10.4. Life Cycle Controller (LCC) . . . 179
2.1.5.10.4.1. Lifecycle States . . . 180

2.1.5.10.4.2. Multiple Security Domains . . . 182
2.1.5.10.4.3. Debug and Functional Feature Control . . . 183
2.1.5.10.4.3.1. Disable Vector Format (SIP_DIS / SYS_DIS) . . . 183
2.1.5.10.4.3.2. DIS Vector Ownership: Predecessor-Programs-Disables . . . 184
2.1.5.10.4.3.3. Combining Rule: OR then Invert . . . 185
2.1.5.10.4.3.4. When Each DIS Vector Applies . . . 185
2.1.5.10.4.3.5. Overrides and Final Gates (SEC_DIS) . . . 185
2.1.5.10.4.3.6. Per-LC-state Feature Control Profile . . . 185
2.1.5.10.4.4. In-Field Debug Demotion . . . 186
2.1.5.10.4.4.1. Programming and Locking . . . 187
2.1.5.10.4.4.2. Reset Behavior . . . 187
2.1.5.10.4.5. Asset and Scan-Chain Protection . . . 187
2.1.5.10.4.5.1. Asset Classes . . . 187
2.1.5.10.4.5.2. `secure_tm` and the Secure Scan Chain . . . 188
2.1.5.10.4.5.3. Feature-Bit to Scan-Chain Mapping . . . 189
2.1.5.10.4.5.4. Debug and Test Port Path Gating . . . 189
2.1.5.10.4.6. Non-Primary Chiplets . . . 190
2.1.5.10.4.7. Adopter Extension . . . 191
2.1.5.10.4.8. Firmware Authorization . . . 191
2.1.5.10.4.9. Memory Map and Register Reference . . . 192
2.1.5.10.4.9.1. Memory Map . . . 192
2.1.5.10.4.9.2. Detailed Register Map . . . 192
2.1.5.10.4.9.2.1. SEP Lifecycle Control Address Map . . . 192
2.1.5.10.4.9.2.1.1. FEAT_CTRL . . . 192
2.1.5.10.4.9.2.1.2. DEMOTE_1 . . . 192
2.1.5.10.4.9.2.1.3. DEMOTE_2 . . . 192
2.1.5.10.5. Test Mode Entry . . . 192
2.1.5.10.5.1. Entry and Exit . . . 193
2.1.5.10.5.2. Protection While Active . . . 193
2.1.5.11. Cryptographic Subsystem . . . 193
2.1.5.11.1. OpenTitan Alert Termination . . . 196
2.1.5.11.2. Single-Beat Access Only . . . 196
2.1.5.11.3. Key Manager Key Delivery . . . 196
2.1.5.11.4. TRNG and DRBG . . . 197
2.1.5.11.4.1. Entropy Generation . . . 198
2.1.5.11.4.2. Distribution and Source Selection . . . 199
2.1.5.11.4.2.1. FIPS Provenance . . . 199
2.1.5.11.4.3. Reset and Recovery Boundaries . . . 199
2.1.5.11.4.3.1. Scan Protection Boundary . . . 200
2.1.5.11.4.4. DRBG Deterministic Random Bit Generator . . . 200
2.1.5.11.4.4.1. Parameters . . . 200
2.1.5.11.4.4.2. External Interfaces . . . 200
2.1.5.11.4.4.3. Seed Assembly . . . 201
2.1.5.11.4.4.4. OpenTitan CSRNG and EDN . . . 201

2.1.5.11.4.4.5. Bus Protocol Adaptation . . . 201
2.1.5.11.4.5. Memory Map and Register Reference . . . 202
2.1.5.11.4.5.1. Memory Map . . . 202
2.1.5.11.4.5.2. Detailed Register Map . . . 202
2.1.5.11.4.5.2.1. CSRNG Registers . . . 202
2.1.5.11.4.5.2.1.1. Cryptographically Secure Random Number Generator . . . 202
2.1.5.11.4.5.2.1.1.1. INTR_STATE . . . 203
2.1.5.11.4.5.2.1.1.2. INTR_ENABLE . . . 203
2.1.5.11.4.5.2.1.1.3. INTR_TEST . . . 203
2.1.5.11.4.5.2.1.1.4. ALERT_TEST . . . 203
2.1.5.11.4.5.2.1.1.5. REGWEN . . . 204
2.1.5.11.4.5.2.1.1.6. CTRL . . . 204
2.1.5.11.4.5.2.1.1.7. CMD_REQ . . . 204
2.1.5.11.4.5.2.1.1.8. RESEED_INTERVAL . . . 204
2.1.5.11.4.5.2.1.1.9. RESEED_COUNTER_0 . . . 204
2.1.5.11.4.5.2.1.1.10. RESEED_COUNTER_1 . . . 205
2.1.5.11.4.5.2.1.1.11. RESEED_COUNTER_2 . . . 205
2.1.5.11.4.5.2.1.1.12. SW_CMD_STS . . . 205
2.1.5.11.4.5.2.1.1.13. GENBITS_VLD . . . 205
2.1.5.11.4.5.2.1.1.14. GENBITS . . . 206
2.1.5.11.4.5.2.1.1.15. INT_STATE_READ_ENABLE . . . 206
2.1.5.11.4.5.2.1.1.16. INT_STATE_READ_ENABLE_REGWEN . . . 206
2.1.5.11.4.5.2.1.1.17. INT_STATE_NUM . . . 206
2.1.5.11.4.5.2.1.1.18. INT_STATE_VAL . . . 206
2.1.5.11.4.5.2.1.1.19. FIPS_FORCE . . . 207
2.1.5.11.4.5.2.1.1.20. HW_EXC_STS . . . 207
2.1.5.11.4.5.2.1.1.21. RECOV_ALERT_STS . . . 207
2.1.5.11.4.5.2.1.1.22. ERR_CODE . . . 208
2.1.5.11.4.5.2.1.1.23. ERR_CODE_TEST . . . 209
2.1.5.11.4.5.2.1.1.24. MAIN_SM_STATE . . . 209
2.1.5.11.4.5.2.2. EDN Registers . . . 209
2.1.5.11.4.5.2.2.1. Entropy Distribution Network . . . 209
2.1.5.11.4.5.2.2.1.1. INTR_STATE . . . 210
2.1.5.11.4.5.2.2.1.2. INTR_ENABLE . . . 210
2.1.5.11.4.5.2.2.1.3. INTR_TEST . . . 210
2.1.5.11.4.5.2.2.1.4. ALERT_TEST . . . 210
2.1.5.11.4.5.2.2.1.5. REGWEN . . . 211
2.1.5.11.4.5.2.2.1.6. CTRL . . . 211
2.1.5.11.4.5.2.2.1.7. BOOT_INS_CMD . . . 212
2.1.5.11.4.5.2.2.1.8. BOOT_GEN_CMD . . . 212
2.1.5.11.4.5.2.2.1.9. SW_CMD_REQ . . . 212
2.1.5.11.4.5.2.2.1.10. SW_CMD_STS . . . 212
2.1.5.11.4.5.2.2.1.11. HW_CMD_STS . . . 213
2.1.5.11.4.5.2.2.1.12. RESEED_CMD . . . 213

2.1.5.11.4.5.2.2.1.13. GENERATE_CMD . . . 214
2.1.5.11.4.5.2.2.1.14. MAX_NUM_REQS_BETWEEN_RESEEDS . . . 214
2.1.5.11.4.5.2.2.1.15. RECOV_ALERT_STS . . . 214
2.1.5.11.4.5.2.2.1.16. ERR_CODE . . . 215
2.1.5.11.4.5.2.2.1.17. ERR_CODE_TEST . . . 216
2.1.5.11.4.5.2.2.1.18. MAIN_SM_STATE . . . 216
2.1.5.11.5. Entropy Source . . . 216
2.1.5.11.5.1. Noise Generation . . . 217
2.1.5.11.5.2. Decorrelation and BIW Mixing . . . 219
2.1.5.11.5.3. Health Testing . . . 219
2.1.5.11.5.4. Health Test Watermark . . . 220
2.1.5.11.5.5. Persistent Failure and AlertHang . . . 220
2.1.5.11.5.6. SHA-256 Whitening . . . 220
2.1.5.11.5.7. Output FIFO . . . 220
2.1.5.11.5.8. Reset . . . 221
2.1.5.11.5.9. Debug Observation Pin . . . 221
2.1.5.11.5.10. Memory Map and Register Reference . . . 221
2.1.5.11.5.10.1. Memory Map . . . 221
2.1.5.11.5.10.2. Detailed Register Map . . . 221
2.1.5.11.5.10.2.1. Entropy Source Address Map . . . 221
2.1.5.11.5.10.2.1.1. COMPONENT_ID . . . 223
2.1.5.11.5.10.2.1.2. CTRL . . . 223
2.1.5.11.5.10.2.1.3. DEBUG_CTRL . . . 224
2.1.5.11.5.10.2.1.4. INTR_STATUS . . . 224
2.1.5.11.5.10.2.1.5. INTR_ENABLE . . . 225
2.1.5.11.5.10.2.1.6. INTR_TEST . . . 225
2.1.5.11.5.10.2.1.7. SHA256_STATUS . . . 226
2.1.5.11.5.10.2.1.8. FIFO_CTRL . . . 226
2.1.5.11.5.10.2.1.9. FIFO_STATUS . . . 226
2.1.5.11.5.10.2.1.10. FIFO_RDATA . . . 227
2.1.5.11.5.10.2.1.11. HEALTH_TEST_CTRL . . . 227
2.1.5.11.5.10.2.1.12. HEALTH_TEST_WINDOW_SIZE . . . 227
2.1.5.11.5.10.2.1.13. MARKOV_TEST_PROB_THRESHOLDS . . . 227
2.1.5.11.5.10.2.1.14. HEALTH_TEST_STATUS . . . 227
2.1.5.11.5.10.2.1.15. REPETITION_TEST_COUNT . . . 227
2.1.5.11.5.10.2.1.16. APT_PATTERN_COUNT_1BIT . . . 228
2.1.5.11.5.10.2.1.17. APT_PATTERN_COUNT_2BIT . . . 228
2.1.5.11.5.10.2.1.18. APT_PROPORTION_1BIT . . . 228
2.1.5.11.5.10.2.1.19. APT_PROPORTION_LO . . . 228
2.1.5.11.5.10.2.1.20. MARKOV_TEST_COUNTS_0 . . . 228
2.1.5.11.5.10.2.1.21. RING_OSC_ENABLE . . . 228
2.1.5.11.5.10.2.1.22. RING_OSC_TUNE . . . 229
2.1.5.11.5.10.2.1.23. RING_OSC_CTRL . . . 229
2.1.5.11.5.10.2.1.24. DECORRELATOR_CTRL . . . 229

2.1.5.11.5.10.2.1.25. DECORRELATOR_MASK . . . 229
2.1.5.11.5.10.2.1.26. MAIN_SM_STATUS . . . 229
2.1.5.11.5.10.2.1.27. GENERATOR_0_HEALTH_STATUS . . . 230
2.1.5.11.5.10.2.1.28. GENERATOR_1_HEALTH_STATUS . . . 230
2.1.5.11.5.10.2.1.29. GENERATOR_2_HEALTH_STATUS . . . 230
2.1.5.11.5.10.2.1.30. GENERATOR_3_HEALTH_STATUS . . . 230
2.1.5.11.5.10.2.1.31. GENERATOR_4_HEALTH_STATUS . . . 230
2.1.5.11.5.10.2.1.32. GENERATOR_5_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.33. GENERATOR_6_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.34. GENERATOR_7_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.35. GENERATOR_8_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.36. GENERATOR_9_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.37. GENERATOR_10_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.38. GENERATOR_11_HEALTH_STATUS . . . 231
2.1.5.11.5.10.2.1.39. GENERATOR_0_SAMPLE_CLK_CONFIG . . . 232
2.1.5.11.5.10.2.1.40. GENERATOR_1_SAMPLE_CLK_CONFIG . . . 232
2.1.5.11.5.10.2.1.41. GENERATOR_2_SAMPLE_CLK_CONFIG . . . 232
2.1.5.11.5.10.2.1.42. GENERATOR_3_SAMPLE_CLK_CONFIG . . . 232
2.1.5.11.5.10.2.1.43. GENERATOR_4_SAMPLE_CLK_CONFIG . . . 232
2.1.5.11.5.10.2.1.44. GENERATOR_5_SAMPLE_CLK_CONFIG . . . 232
2.1.5.11.5.10.2.1.45. GENERATOR_6_SAMPLE_CLK_CONFIG . . . 233
2.1.5.11.5.10.2.1.46. GENERATOR_7_SAMPLE_CLK_CONFIG . . . 233
2.1.5.11.5.10.2.1.47. GENERATOR_8_SAMPLE_CLK_CONFIG . . . 233
2.1.5.11.5.10.2.1.48. GENERATOR_9_SAMPLE_CLK_CONFIG . . . 233
2.1.5.11.5.10.2.1.49. GENERATOR_10_SAMPLE_CLK_CONFIG . . . 233
2.1.5.11.5.10.2.1.50. GENERATOR_11_SAMPLE_CLK_CONFIG . . . 234
2.1.5.11.5.10.2.1.51. HT_WATERMARK_NUM . . . 234
2.1.5.11.5.10.2.1.52. HT_WATERMARK . . . 234
2.1.5.11.5.10.2.1.53. REPCNT_TOTAL_FAILS . . . 234
2.1.5.11.5.10.2.1.54. APT_HI_TOTAL_FAILS . . . 234
2.1.5.11.5.10.2.1.55. APT_LO_TOTAL_FAILS . . . 234
2.1.5.11.5.10.2.1.56. MARKOV_HI_TOTAL_FAILS . . . 234
2.1.5.11.5.10.2.1.57. MARKOV_LO_TOTAL_FAILS . . . 235
2.1.5.11.5.10.2.1.58. ALERT_SUMMARY_FAIL_COUNTS . . . 235
2.1.5.11.5.10.2.1.59. ALERT_FAIL_COUNTS . . . 235
2.1.5.11.5.10.2.1.60. FIPS_LOCK . . . 235
2.1.5.11.5.10.2.1.61. ALERT_THRESHOLD . . . 235
2.1.5.11.5.10.2.1.62. MIN_ENTROPY_H . . . 235
2.1.5.11.5.10.2.1.63. RECOMMENDED_THRESHOLDS . . . 236
2.1.5.11.5.10.2.1.64. BIW_OBS_CTRL . . . 236
2.1.5.11.5.10.2.1.65. BIW_OBS_STATUS . . . 236
2.1.5.11.5.10.2.1.66. BIW_OBS_RDATA . . . 236
2.1.5.11.5.10.2.1.67. NOISE_OBS_CTRL . . . 236
2.1.5.11.5.10.2.1.68. NOISE_OBS_STATUS . . . 237

2.1.5.11.5.10.2.1.69. NOISE_OBS_RDATA . . . 237
2.1.5.11.6. Entropy Pool . . . 237
2.1.5.11.6.1. Access Policy . . . 237
2.1.5.11.6.2. Memory Map and Register Reference . . . 237
2.1.5.11.6.2.1. Memory Map . . . 237
2.1.5.11.6.2.2. Detailed Register Map . . . 238
2.1.5.11.6.2.2.1. SEP Entropy Pool . . . 238
2.1.5.11.6.2.2.1.1. STATUS . . . 238
2.1.5.11.6.2.2.1.2. IRQ_CAUSE . . . 238
2.1.5.11.6.2.2.1.3. DATA . . . 238
2.1.5.11.7. AES Cipher . . . 238
2.1.5.11.7.1. OCAH Modifications . . . 239
2.1.5.11.7.2. Memory Map and Register Reference . . . 239
2.1.5.11.7.2.1. Memory Map . . . 239
2.1.5.11.7.2.2. Detailed Register Map . . . 240
2.1.5.11.7.2.2.1. AES Accelerator . . . 240
2.1.5.11.7.2.2.1.1. ALERT_TEST . . . 240
2.1.5.11.7.2.2.1.2. KEY_SHARE0[8] . . . 240
2.1.5.11.7.2.2.1.3. KEY_SHARE1[8] . . . 241
2.1.5.11.7.2.2.1.4. IV[4] . . . 241
2.1.5.11.7.2.2.1.5. DATA_IN[4] . . . 241
2.1.5.11.7.2.2.1.6. DATA_OUT[4] . . . 241
2.1.5.11.7.2.2.1.7. CTRL_SHADOWED . . . 241
2.1.5.11.7.2.2.1.8. CTRL_AUX_SHADOWED . . . 242
2.1.5.11.7.2.2.1.9. CTRL_AUX_REGWEN . . . 242
2.1.5.11.7.2.2.1.10. TRIGGER . . . 242
2.1.5.11.7.2.2.1.11. STATUS . . . 243
2.1.5.11.7.2.2.1.12. CTRL_GCM_SHADOWED . . . 243
2.1.5.11.8. HMAC-SHA2 . . . 243
2.1.5.11.8.1. OCAH Modifications . . . 244
2.1.5.11.8.2. Memory Map and Register Reference . . . 244
2.1.5.11.8.2.1. Memory Map . . . 244
2.1.5.11.8.2.2. Detailed Register Map . . . 245
2.1.5.11.8.2.2.1. HMAC Accelerator . . . 245
2.1.5.11.8.2.2.1.1. INTR_STATE . . . 245
2.1.5.11.8.2.2.1.2. INTR_ENABLE . . . 246
2.1.5.11.8.2.2.1.3. INTR_TEST . . . 246
2.1.5.11.8.2.2.1.4. ALERT_TEST . . . 246
2.1.5.11.8.2.2.1.5. CFG . . . 246
2.1.5.11.8.2.2.1.6. CMD . . . 247
2.1.5.11.8.2.2.1.7. STATUS . . . 248
2.1.5.11.8.2.2.1.8. ERR_CODE . . . 248
2.1.5.11.8.2.2.1.9. WIPE_SECRET . . . 248
2.1.5.11.8.2.2.1.10. KEY[32] . . . 248

2.1.5.11.8.2.2.1.11. DIGEST[16] 248
2.1.5.11.8.2.2.1.12. MSG_LENGTH_LOWER 248
2.1.5.11.8.2.2.1.13. MSG_LENGTH_UPPER 249
2.1.5.11.9. KMAC-SHA3 249
2.1.5.11.9.1. OCAH Modifications 249
2.1.5.11.9.2. Memory Map and Register Reference 250
2.1.5.11.9.2.1. Memory Map 250
2.1.5.11.9.2.2. Detailed Register Map 250
2.1.5.11.9.2.2.1. KMAC Accelerator 250
2.1.5.11.9.2.2.1.1. INTR_STATE 251
2.1.5.11.9.2.2.1.2. INTR_ENABLE 251
2.1.5.11.9.2.2.1.3. INTR_TEST 251
2.1.5.11.9.2.2.1.4. ALERT_TEST 251
2.1.5.11.9.2.2.1.5. CFG_REGWEN 251
2.1.5.11.9.2.2.1.6. CFG_SHADOWED 252
2.1.5.11.9.2.2.1.7. CMD 253
2.1.5.11.9.2.2.1.8. STATUS 253
2.1.5.11.9.2.2.1.9. ENTROPY_PERIOD 254
2.1.5.11.9.2.2.1.10. ENTROPY_REFRESH_HASH_CNT 255
2.1.5.11.9.2.2.1.11. ENTROPY_REFRESH_THRESHOLD_SHADOWED 255
2.1.5.11.9.2.2.1.12. ENTROPY_SEED 255
2.1.5.11.9.2.2.1.13. KEY_SHARE0[16] 255
2.1.5.11.9.2.2.1.14. KEY_SHARE1[16] 255
2.1.5.11.9.2.2.1.15. KEY_LEN 255
2.1.5.11.9.2.2.1.16. PREFIX[11] 255
2.1.5.11.9.2.2.1.17. ERR_CODE 256
2.1.5.11.10. Adams Bridge (ABR) 256
2.1.5.11.10.1. OCAH Modifications 257
2.1.5.11.11. OTBN PKA Public Key Accelerator 259
2.1.5.11.11.1. OCAH Modifications 261
2.1.5.11.11.2. Memory Map and Register Reference 261
2.1.5.11.11.2.1. Memory Map 261
2.1.5.11.11.2.2. Detailed Register Map 261
2.1.5.11.11.2.2.1. OpenTitan Big Number Accelerator 261
2.1.5.11.11.2.2.1.1. INTR_STATE 262
2.1.5.11.11.2.2.1.2. INTR_ENABLE 262
2.1.5.11.11.2.2.1.3. INTR_TEST 262
2.1.5.11.11.2.2.1.4. ALERT_TEST 262
2.1.5.11.11.2.2.1.5. CMD 262
2.1.5.11.11.2.2.1.6. CTRL 263
2.1.5.11.11.2.2.1.7. STATUS 263
2.1.5.11.11.2.2.1.8. ERR_BITS 263
2.1.5.11.11.2.2.1.9. FATAL_ALERT_CAUSE 264
2.1.5.11.11.2.2.1.10. INSN_CNT 264

2.1.5.11.11.2.2.1.11. LOAD_CHECKSUM . . . 264
2.1.5.11.12. Key Manager (KM) . . . 264
2.1.5.11.12.1. Architecture . . . 265
2.1.5.11.12.1.1. Parameters . . . 267
2.1.5.11.12.1.2. Reset Conditioning . . . 267
2.1.5.11.12.1.3. Mailbox Transport . . . 268
2.1.5.11.12.1.4. Key Delivery . . . 270
2.1.5.11.12.1.5. Adams Bridge Key Sideload Interfaces . . . 271
2.1.5.11.12.1.6. Key Manager CPU Interrupt Processing . . . 272
2.1.5.11.12.1.7. Host Coordination . . . 272
2.1.5.11.12.1.8. Key and Policy Vault (KPV) . . . 274
2.1.5.11.12.1.9. KPV Scrambling . . . 275
2.1.5.11.12.1.10. Wipe State . . . 275
2.1.5.11.12.1.11. Scan and Scan-Dump Protection . . . 275
2.1.5.11.12.1.12. Key Manager Control and Status Registers (KMCSR) . . . 276
2.1.5.11.12.1.13. DRBG Sampler . . . 279
2.1.5.11.12.1.13.1. Reads, prefetch and register access . . . 279
2.1.5.11.12.1.13.2. Errors and reset . . . 280
2.1.5.11.12.1.14. OTP Inputs and Readout . . . 281
2.1.5.11.12.1.15. CRC Accelerator . . . 282
2.1.5.11.12.1.16. ROM and SRAM Error Detection . . . 283
2.1.5.11.12.1.17. Parity Error Protection . . . 283
2.1.5.11.12.1.18. SRAM Write Locking . . . 283
2.1.5.11.12.1.19. ROM Warm-Persistent SRAM Region . . . 284
2.1.5.11.12.1.20. Mutable Firmware Model . . . 284
2.1.5.11.12.1.21. SRAM Scrambling . . . 285
2.1.5.11.12.1.21.1. Parameters . . . 285
2.1.5.11.12.1.21.2. Port Interface . . . 285
2.1.5.11.12.1.21.3. Data Scrambling Algorithm . . . 285
2.1.5.11.12.1.21.4. Address Tweaking . . . 287
2.1.5.11.12.1.21.5. Address Scrambling . . . 287
2.1.5.11.12.1.21.6. Byte-Wise Scrambling Mode . . . 288
2.1.5.11.12.1.21.7. Instantiation Variants . . . 288
2.1.5.11.12.1.21.8. Integration in the Key Manager . . . 289
2.1.5.11.12.2. Firmware . . . 290
2.1.5.11.12.3. Memory Map and Register Reference . . . 290
2.1.5.11.12.3.1. Memory Map . . . 290
2.1.5.11.12.3.2. Detailed Register Map . . . 292
2.1.5.11.12.3.2.1. Address Summary Registers . . . 292
2.1.5.11.12.3.2.1.1. Key Manager Top-Level Address Map . . . 292
2.1.5.11.12.3.2.1.1.1. KM_WRITE_DATA . . . 304
2.1.5.11.12.3.2.1.1.2. KM_WRITE_SEPARATOR . . . 304
2.1.5.11.12.3.2.1.1.3. KM_READ_DATA . . . 305
2.1.5.11.12.3.2.1.1.4. KM_STATUS . . . 305

2.1.5.11.12.3.2.1.1.5. KM_IRQ_STATUS . . . 305
2.1.5.11.12.3.2.1.1.6. KM_IRQ_ENABLE . . . 306
2.1.5.11.12.3.2.1.1.7. KM_CTRL . . . 306
2.1.5.11.12.3.2.1.1.8. LOCKS . . . 306
2.1.5.11.12.3.2.1.1.9. LOCKS_SPARE . . . 309
2.1.5.11.12.3.2.1.1.10. LC_STATE . . . 309
2.1.5.11.12.3.2.1.1.11. SBOOT_DIS . . . 309
2.1.5.11.12.3.2.1.1.12. TRANSIENT_RMA_EN . . . 310
2.1.5.11.12.3.2.1.1.13. SIP_DIS . . . 310
2.1.5.11.12.3.2.1.1.14. SYS_DIS . . . 310
2.1.5.11.12.3.2.1.1.15. RMA_SIP_TOKEN_DIGEST . . . 311
2.1.5.11.12.3.2.1.1.16. RMA_CHIPLET_TOKEN_DIGEST . . . 311
2.1.5.11.12.3.2.1.1.17. CLASS_KEY . . . 311
2.1.5.11.12.3.2.1.1.18. CHIPLET_PUBK_REVOKE . . . 311
2.1.5.11.12.3.2.1.1.19. BL1_VERSION . . . 312
2.1.5.11.12.3.2.1.1.20. BL2_VERSION . . . 312
2.1.5.11.12.3.2.1.1.21. CHIPLET_UID . . . 312
2.1.5.11.12.3.2.1.1.22. SIP_PUBK_HASH0 . . . 312
2.1.5.11.12.3.2.1.1.23. SIP_UID . . . 312
2.1.5.11.12.3.2.1.1.24. SYS_PUBK_HASH . . . 313
2.1.5.11.12.3.2.1.1.25. SYS_UID . . . 313
2.1.5.11.12.3.2.1.1.26. STATUS_RPT . . . 313
2.1.5.11.12.3.2.1.1.27. ROM_CTL . . . 313
2.1.5.11.12.3.2.1.1.28. SYSCLK_FREQ_MHZ . . . 313
2.1.5.11.12.3.2.1.1.29. CHIPLET_PUBK_HASH0 . . . 313
2.1.5.11.12.3.2.1.1.30. CHIPLET_PUBK_HASH1 . . . 314
2.1.5.11.12.3.2.1.1.31. REQUIRED_SIGNERS . . . 314
2.1.5.11.12.3.2.1.1.32. REQUIRED_ALGS . . . 314
2.1.5.11.12.3.2.1.1.33. CHIPLET_PUBK_PQC_HASH0 . . . 314
2.1.5.11.12.3.2.1.1.34. CHIPLET_PUBK_PQC_HASH1 . . . 314
2.1.5.11.12.3.2.1.1.35. SIP_PUBK_PQC_HASH0 . . . 314
2.1.5.11.12.3.2.1.1.36. SYS_PUBK_PQC_HASH . . . 315
2.1.5.11.12.3.2.1.1.37. SIP_PUBK_HASH1 . . . 315
2.1.5.11.12.3.2.1.1.38. SIP_PUBK_PQC_HASH1 . . . 315
2.1.5.11.12.3.2.1.1.39. SEP_CHIPLET_ID . . . 315
2.1.5.11.12.3.2.1.1.40. SEP_SIP_ID . . . 315
2.1.5.11.12.3.2.1.1.41. SEP_SYS_ID . . . 315
2.1.5.11.12.3.2.1.1.42. spare0 . . . 316
2.1.5.11.12.3.2.1.1.43. spare1 . . . 316
2.1.5.11.12.3.2.1.1.44. spare2 . . . 316
2.1.5.11.12.3.2.1.1.45. spare3 . . . 316
2.1.5.11.12.3.2.1.1.46. spare4 . . . 316
2.1.5.11.12.3.2.1.1.47. spare5 . . . 316
2.1.5.11.12.3.2.1.1.48. spare6 . . . 316

2.1.5.11.12.3.2.1.1.49. spare7 . . . 317
2.1.5.11.12.3.2.1.1.50. spare8 . . . 317
2.1.5.11.12.3.2.1.1.51. EFUSE_INTERFACE_CTRL_STATUS . . . 317
2.1.5.11.12.3.2.1.1.52. EFUSE_PROGRAM_CTRL . . . 317
2.1.5.11.12.3.2.1.1.53. EFUSE_READ_CTRL . . . 318
2.1.5.11.12.3.2.1.1.54. EFUSE_PROGRAM_INTERFACE_READ_DATA . . . 318
2.1.5.11.12.3.2.1.1.55. EFUSE_READ_INTERFACE_READ_DATA . . . 318
2.1.5.11.12.3.2.1.1.56. EFUSE_READ_REQ_TIMEOUT . . . 318
2.1.5.11.12.3.2.1.1.57. EFUSE_PROGRAM_REQ_TIMEOUT . . . 319
2.1.5.11.12.3.2.1.1.58. RMA_SIP_TOKEN_I[8] . . . 319
2.1.5.11.12.3.2.1.1.59. RMA_CHIPLET_TOKEN_I[8] . . . 319
2.1.5.11.12.3.2.1.1.60. SEC_DISABLE_TOKEN_I[8] . . . 319
2.1.5.11.12.3.2.1.1.61. TOKEN_EOP . . . 319
2.1.5.11.12.3.2.1.1.62. RMA_SIP_TOKEN_MATCH . . . 319
2.1.5.11.12.3.2.1.1.63. RMA_CHIPLET_TOKEN_MATCH . . . 320
2.1.5.11.12.3.2.1.1.64. SEC_DISABLE_TOKEN_MATCH . . . 320
2.1.5.11.12.3.2.1.1.65. TOKEN_MATCH_FAULT . . . 320
2.1.5.11.12.3.2.1.1.66. KEY_ENTRY[64].WORD[16] . . . 320
2.1.5.11.12.3.2.1.1.67. CTRL[64] . . . 320
2.1.5.11.12.3.2.1.1.68. KPV_SCRAMBLER_KEY . . . 321
2.1.5.11.12.3.2.1.1.69. KPV_SCRAMBLER_CTRL . . . 321
2.1.5.11.12.3.2.1.1.70. VERSION . . . 321
2.1.5.11.12.3.2.1.1.71. CTRL . . . 321
2.1.5.11.12.3.2.1.1.72. SOFT_RST_CODE . . . 322
2.1.5.11.12.3.2.1.1.73. kmcsr.IRQ_STATUS . . . 322
2.1.5.11.12.3.2.1.1.74. kmcsr.IRQ_ENABLE . . . 322
2.1.5.11.12.3.2.1.1.75. SCRAMBLER_KEY . . . 323
2.1.5.11.12.3.2.1.1.76. SCRAMBLER_CTRL . . . 323
2.1.5.11.12.3.2.1.1.77. SRAM_LOCK . . . 323
2.1.5.11.12.3.2.1.1.78. IRQ_SET . . . 323
2.1.5.11.12.3.2.1.1.79. SRAM_WRITE_LOCK_VIOLATION . . . 324
2.1.5.11.12.3.2.1.1.80. RECOVERABLE_ERR . . . 324
2.1.5.11.12.3.2.1.1.81. BOOT_STATUS . . . 324
2.1.5.11.12.3.2.1.1.82. OTP_LIFE_CYCLE . . . 324
2.1.5.11.12.3.2.1.1.83. OTP_DEMOTION_STATE . . . 325
2.1.5.11.12.3.2.1.1.84. SRAM_EXEC_MODE . . . 325
2.1.5.11.12.3.2.1.1.85. IRQ_ENTRY_ADDR . . . 325
2.1.5.11.12.3.2.1.1.86. IRQ_ENTRY_LOCK . . . 325
2.1.5.11.12.3.2.1.1.87. VUART_TX . . . 325
2.1.5.11.12.3.2.1.1.88. VUART_RX . . . 325
2.1.5.11.12.3.2.1.1.89. VUART_STATUS . . . 326
2.1.5.11.12.3.2.1.1.90. TB_RESULT . . . 326
2.1.5.11.12.3.2.1.1.91. TB_SIGNATURE . . . 326
2.1.5.11.12.3.2.1.1.92. TB_ERRCODE . . . 326

2.1.5.11.12.3.2.1.1.93. TB_SUBTEST . . . 326
2.1.5.11.12.3.2.1.1.94. TB_CMD . . . 326
2.1.5.11.12.3.2.1.1.95. TB_CMD_ARG . . . 327
2.1.5.11.12.3.2.1.1.96. TB_CMD_STATUS . . . 327
2.1.5.11.12.3.2.1.1.97. TB_CMD_RESULT . . . 327
2.1.5.11.12.3.2.1.1.98. DEBUG . . . 327
2.1.5.11.12.3.2.1.1.99. OTP_CHIPLET_UID_VAL_0 . . . 327
2.1.5.11.12.3.2.1.1.100. OTP_CHIPLET_UID_VAL_1 . . . 327
2.1.5.11.12.3.2.1.1.101. OTP_CHIPLET_UID_VAL_2 . . . 327
2.1.5.11.12.3.2.1.1.102. OTP_CHIPLET_UID_VAL_3 . . . 327
2.1.5.11.12.3.2.1.1.103. OTP_CHIPLET_UID_VAL_4 . . . 328
2.1.5.11.12.3.2.1.1.104. OTP_CHIPLET_UID_VAL_5 . . . 328
2.1.5.11.12.3.2.1.1.105. OTP_CHIPLET_UID_VAL_6 . . . 328
2.1.5.11.12.3.2.1.1.106. OTP_CHIPLET_UID_VAL_7 . . . 328
2.1.5.11.12.3.2.1.1.107. OTP_CHIPLET_UID_CPL_0 . . . 328
2.1.5.11.12.3.2.1.1.108. OTP_CHIPLET_UID_CPL_1 . . . 328
2.1.5.11.12.3.2.1.1.109. OTP_CHIPLET_UID_CPL_2 . . . 328
2.1.5.11.12.3.2.1.1.110. OTP_CHIPLET_UID_CPL_3 . . . 329
2.1.5.11.12.3.2.1.1.111. OTP_CHIPLET_UID_CPL_4 . . . 329
2.1.5.11.12.3.2.1.1.112. OTP_CHIPLET_UID_CPL_5 . . . 329
2.1.5.11.12.3.2.1.1.113. OTP_CHIPLET_UID_CPL_6 . . . 329
2.1.5.11.12.3.2.1.1.114. OTP_CHIPLET_UID_CPL_7 . . . 329
2.1.5.11.12.3.2.1.1.115. OTP_SIP_UID_VAL_0 . . . 329
2.1.5.11.12.3.2.1.1.116. OTP_SIP_UID_VAL_1 . . . 329
2.1.5.11.12.3.2.1.1.117. OTP_SIP_UID_VAL_2 . . . 329
2.1.5.11.12.3.2.1.1.118. OTP_SIP_UID_VAL_3 . . . 330
2.1.5.11.12.3.2.1.1.119. OTP_SIP_UID_VAL_4 . . . 330
2.1.5.11.12.3.2.1.1.120. OTP_SIP_UID_VAL_5 . . . 330
2.1.5.11.12.3.2.1.1.121. OTP_SIP_UID_VAL_6 . . . 330
2.1.5.11.12.3.2.1.1.122. OTP_SIP_UID_VAL_7 . . . 330
2.1.5.11.12.3.2.1.1.123. OTP_SIP_UID_CPL_0 . . . 330
2.1.5.11.12.3.2.1.1.124. OTP_SIP_UID_CPL_1 . . . 330
2.1.5.11.12.3.2.1.1.125. OTP_SIP_UID_CPL_2 . . . 331
2.1.5.11.12.3.2.1.1.126. OTP_SIP_UID_CPL_3 . . . 331
2.1.5.11.12.3.2.1.1.127. OTP_SIP_UID_CPL_4 . . . 331
2.1.5.11.12.3.2.1.1.128. OTP_SIP_UID_CPL_5 . . . 331
2.1.5.11.12.3.2.1.1.129. OTP_SIP_UID_CPL_6 . . . 331
2.1.5.11.12.3.2.1.1.130. OTP_SIP_UID_CPL_7 . . . 331
2.1.5.11.12.3.2.1.1.131. OTP_SYS_UID_VAL_0 . . . 331
2.1.5.11.12.3.2.1.1.132. OTP_SYS_UID_VAL_1 . . . 331
2.1.5.11.12.3.2.1.1.133. OTP_SYS_UID_VAL_2 . . . 332
2.1.5.11.12.3.2.1.1.134. OTP_SYS_UID_VAL_3 . . . 332
2.1.5.11.12.3.2.1.1.135. OTP_SYS_UID_VAL_4 . . . 332
2.1.5.11.12.3.2.1.1.136. OTP_SYS_UID_VAL_5 . . . 332

2.1.5.11.12.3.2.1.1.137. OTP_SYS_UID_VAL_6 . . . 332
2.1.5.11.12.3.2.1.1.138. OTP_SYS_UID_VAL_7 . . . 332
2.1.5.11.12.3.2.1.1.139. OTP_SYS_UID_CPL_0 . . . 332
2.1.5.11.12.3.2.1.1.140. OTP_SYS_UID_CPL_1 . . . 333
2.1.5.11.12.3.2.1.1.141. OTP_SYS_UID_CPL_2 . . . 333
2.1.5.11.12.3.2.1.1.142. OTP_SYS_UID_CPL_3 . . . 333
2.1.5.11.12.3.2.1.1.143. OTP_SYS_UID_CPL_4 . . . 333
2.1.5.11.12.3.2.1.1.144. OTP_SYS_UID_CPL_5 . . . 333
2.1.5.11.12.3.2.1.1.145. OTP_SYS_UID_CPL_6 . . . 333
2.1.5.11.12.3.2.1.1.146. OTP_SYS_UID_CPL_7 . . . 333
2.1.5.11.12.3.2.1.1.147. OTP_CLASS_KEY_VAL_0 . . . 333
2.1.5.11.12.3.2.1.1.148. OTP_CLASS_KEY_VAL_1 . . . 334
2.1.5.11.12.3.2.1.1.149. OTP_CLASS_KEY_VAL_2 . . . 334
2.1.5.11.12.3.2.1.1.150. OTP_CLASS_KEY_VAL_3 . . . 334
2.1.5.11.12.3.2.1.1.151. OTP_CLASS_KEY_VAL_4 . . . 334
2.1.5.11.12.3.2.1.1.152. OTP_CLASS_KEY_VAL_5 . . . 334
2.1.5.11.12.3.2.1.1.153. OTP_CLASS_KEY_VAL_6 . . . 334
2.1.5.11.12.3.2.1.1.154. OTP_CLASS_KEY_VAL_7 . . . 334
2.1.5.11.12.3.2.1.1.155. OTP_CLASS_KEY_CPL_0 . . . 335
2.1.5.11.12.3.2.1.1.156. OTP_CLASS_KEY_CPL_1 . . . 335
2.1.5.11.12.3.2.1.1.157. OTP_CLASS_KEY_CPL_2 . . . 335
2.1.5.11.12.3.2.1.1.158. OTP_CLASS_KEY_CPL_3 . . . 335
2.1.5.11.12.3.2.1.1.159. OTP_CLASS_KEY_CPL_4 . . . 335
2.1.5.11.12.3.2.1.1.160. OTP_CLASS_KEY_CPL_5 . . . 335
2.1.5.11.12.3.2.1.1.161. OTP_CLASS_KEY_CPL_6 . . . 335
2.1.5.11.12.3.2.1.1.162. OTP_CLASS_KEY_CPL_7 . . . 335
2.1.5.11.12.3.2.1.1.163. OTP_READ_LOCK . . . 336
2.1.5.11.12.3.2.1.1.164. OTP_CHANGE_STATUS . . . 336
2.1.5.11.12.3.2.1.1.165. OTP_READ_LOCK_COLD . . . 336
2.1.5.11.12.3.2.1.1.166. OTP_SEP_CHIPLET_ID_VAL_0 . . . 337
2.1.5.11.12.3.2.1.1.167. OTP_SEP_CHIPLET_ID_VAL_1 . . . 337
2.1.5.11.12.3.2.1.1.168. OTP_SEP_CHIPLET_ID_VAL_2 . . . 337
2.1.5.11.12.3.2.1.1.169. OTP_SEP_CHIPLET_ID_VAL_3 . . . 337
2.1.5.11.12.3.2.1.1.170. OTP_SEP_CHIPLET_ID_VAL_4 . . . 337
2.1.5.11.12.3.2.1.1.171. OTP_SEP_CHIPLET_ID_VAL_5 . . . 338
2.1.5.11.12.3.2.1.1.172. OTP_SEP_CHIPLET_ID_VAL_6 . . . 338
2.1.5.11.12.3.2.1.1.173. OTP_SEP_CHIPLET_ID_VAL_7 . . . 338
2.1.5.11.12.3.2.1.1.174. OTP_SEP_CHIPLET_ID_CPL_0 . . . 338
2.1.5.11.12.3.2.1.1.175. OTP_SEP_CHIPLET_ID_CPL_1 . . . 338
2.1.5.11.12.3.2.1.1.176. OTP_SEP_CHIPLET_ID_CPL_2 . . . 338
2.1.5.11.12.3.2.1.1.177. OTP_SEP_CHIPLET_ID_CPL_3 . . . 338
2.1.5.11.12.3.2.1.1.178. OTP_SEP_CHIPLET_ID_CPL_4 . . . 338
2.1.5.11.12.3.2.1.1.179. OTP_SEP_CHIPLET_ID_CPL_5 . . . 339
2.1.5.11.12.3.2.1.1.180. OTP_SEP_CHIPLET_ID_CPL_6 . . . 339

2.1.5.11.12.3.2.1.1.181. OTP_SEP_CHIPLET_ID_CPL_7 . . . 339
2.1.5.11.12.3.2.1.1.182. OTP_SEP_SIP_ID_VAL_0 . . . 339
2.1.5.11.12.3.2.1.1.183. OTP_SEP_SIP_ID_VAL_1 . . . 339
2.1.5.11.12.3.2.1.1.184. OTP_SEP_SIP_ID_VAL_2 . . . 339
2.1.5.11.12.3.2.1.1.185. OTP_SEP_SIP_ID_VAL_3 . . . 339
2.1.5.11.12.3.2.1.1.186. OTP_SEP_SIP_ID_VAL_4 . . . 340
2.1.5.11.12.3.2.1.1.187. OTP_SEP_SIP_ID_VAL_5 . . . 340
2.1.5.11.12.3.2.1.1.188. OTP_SEP_SIP_ID_VAL_6 . . . 340
2.1.5.11.12.3.2.1.1.189. OTP_SEP_SIP_ID_VAL_7 . . . 340
2.1.5.11.12.3.2.1.1.190. OTP_SEP_SIP_ID_CPL_0 . . . 340
2.1.5.11.12.3.2.1.1.191. OTP_SEP_SIP_ID_CPL_1 . . . 340
2.1.5.11.12.3.2.1.1.192. OTP_SEP_SIP_ID_CPL_2 . . . 340
2.1.5.11.12.3.2.1.1.193. OTP_SEP_SIP_ID_CPL_3 . . . 340
2.1.5.11.12.3.2.1.1.194. OTP_SEP_SIP_ID_CPL_4 . . . 341
2.1.5.11.12.3.2.1.1.195. OTP_SEP_SIP_ID_CPL_5 . . . 341
2.1.5.11.12.3.2.1.1.196. OTP_SEP_SIP_ID_CPL_6 . . . 341
2.1.5.11.12.3.2.1.1.197. OTP_SEP_SIP_ID_CPL_7 . . . 341
2.1.5.11.12.3.2.1.1.198. OTP_SEP_SYS_ID_VAL_0 . . . 341
2.1.5.11.12.3.2.1.1.199. OTP_SEP_SYS_ID_VAL_1 . . . 341
2.1.5.11.12.3.2.1.1.200. OTP_SEP_SYS_ID_VAL_2 . . . 341
2.1.5.11.12.3.2.1.1.201. OTP_SEP_SYS_ID_VAL_3 . . . 342
2.1.5.11.12.3.2.1.1.202. OTP_SEP_SYS_ID_VAL_4 . . . 342
2.1.5.11.12.3.2.1.1.203. OTP_SEP_SYS_ID_VAL_5 . . . 342
2.1.5.11.12.3.2.1.1.204. OTP_SEP_SYS_ID_VAL_6 . . . 342
2.1.5.11.12.3.2.1.1.205. OTP_SEP_SYS_ID_VAL_7 . . . 342
2.1.5.11.12.3.2.1.1.206. OTP_SEP_SYS_ID_CPL_0 . . . 342
2.1.5.11.12.3.2.1.1.207. OTP_SEP_SYS_ID_CPL_1 . . . 342
2.1.5.11.12.3.2.1.1.208. OTP_SEP_SYS_ID_CPL_2 . . . 342
2.1.5.11.12.3.2.1.1.209. OTP_SEP_SYS_ID_CPL_3 . . . 343
2.1.5.11.12.3.2.1.1.210. OTP_SEP_SYS_ID_CPL_4 . . . 343
2.1.5.11.12.3.2.1.1.211. OTP_SEP_SYS_ID_CPL_5 . . . 343
2.1.5.11.12.3.2.1.1.212. OTP_SEP_SYS_ID_CPL_6 . . . 343
2.1.5.11.12.3.2.1.1.213. OTP_SEP_SYS_ID_CPL_7 . . . 343
2.1.5.11.12.3.2.1.1.214. DATA . . . 343
2.1.5.11.12.3.2.1.1.215. CFG . . . 343
2.1.5.11.12.3.2.1.1.216. STATUS . . . 344
2.1.5.11.12.3.2.1.1.217. PREFETCH_DATA . . . 344
2.1.5.11.12.3.2.1.1.218. KEY_SHARE0[12] . . . 344
2.1.5.11.12.3.2.1.1.219. KEY_SHARE1[12] . . . 344
2.1.5.11.12.3.2.1.1.220. otbn_wrapper_key.KEY_CTRL . . . 344
2.1.5.11.12.3.2.1.1.221. aes_wrapper_key.KEY_SHARE0[8] . . . 345
2.1.5.11.12.3.2.1.1.222. aes_wrapper_key.KEY_SHARE1[8] . . . 345
2.1.5.11.12.3.2.1.1.223. aes_wrapper_key.KEY_CTRL . . . 345
2.1.5.11.12.3.2.1.1.224. kmac_wrapper_key.KEY_SHARE0[8] . . . 345

2.1.5.11.12.3.2.1.1.225. kmac_wrapper_key.KEY_SHARE1[8] . . . 345
2.1.5.11.12.3.2.1.1.226. kmac_wrapper_key.KEY_CTRL . . . 345
2.1.5.11.12.3.2.1.1.227. hmac_wrapper_key.KEY_SHARE0[8] . . . 345
2.1.5.11.12.3.2.1.1.228. hmac_wrapper_key.KEY_SHARE1[8] . . . 346
2.1.5.11.12.3.2.1.1.229. hmac_wrapper_key.KEY_CTRL . . . 346
2.1.5.11.12.3.2.1.1.230. abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8] . . . 346
2.1.5.11.12.3.2.1.1.231. abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8] . . . 346
2.1.5.11.12.3.2.1.1.232. abr_wrapper_key.MLDSA_SEED.KEY_CTRL . . . 346
2.1.5.11.12.3.2.1.1.233. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8] . . . 346
2.1.5.11.12.3.2.1.1.234. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8] . . . 346
2.1.5.11.12.3.2.1.1.235. abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL . . . 347
2.1.5.11.12.3.2.1.1.236. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8] . . . 347
2.1.5.11.12.3.2.1.1.237. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8] . . . 347
2.1.5.11.12.3.2.1.1.238. abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL . . . 347
2.1.5.11.12.3.2.1.1.239. abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8] . . . 347
2.1.5.11.12.3.2.1.1.240. abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8] . . . 347
2.1.5.11.12.3.2.1.1.241. abr_wrapper_key.MLKEM_MSG.KEY_CTRL . . . 347
2.1.5.11.12.3.2.1.1.242. KEY[8] . . . 348
2.1.5.11.12.3.2.1.1.243. abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL . . . 348
2.1.5.11.12.3.2.1.1.244. abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_STATUS . . . 348
2.1.5.11.12.3.2.1.1.245. abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_ENABLE . . . 348
2.1.5.11.12.3.2.2. Control and Status Registers . . . 348
2.1.5.11.12.3.2.2.1. Key Manager Control and Status Registers . . . 348
2.1.5.11.12.3.2.2.1.1. VERSION . . . 356
2.1.5.11.12.3.2.2.1.2. CTRL . . . 356
2.1.5.11.12.3.2.2.1.3. SOFT_RST_CODE . . . 356
2.1.5.11.12.3.2.2.1.4. IRQ_STATUS . . . 356
2.1.5.11.12.3.2.2.1.5. IRQ_ENABLE . . . 357
2.1.5.11.12.3.2.2.1.6. SCRAMBLER_KEY . . . 357
2.1.5.11.12.3.2.2.1.7. SCRAMBLER_CTRL . . . 358
2.1.5.11.12.3.2.2.1.8. SRAM_LOCK . . . 358
2.1.5.11.12.3.2.2.1.9. IRQ_SET . . . 358
2.1.5.11.12.3.2.2.1.10. SRAM_WRITE_LOCK_VIOLATION . . . 359
2.1.5.11.12.3.2.2.1.11. RECOVERABLE_ERR . . . 359
2.1.5.11.12.3.2.2.1.12. BOOT_STATUS . . . 359
2.1.5.11.12.3.2.2.1.13. OTP_LIFE_CYCLE . . . 359
2.1.5.11.12.3.2.2.1.14. OTP_DEMOTION_STATE . . . 359
2.1.5.11.12.3.2.2.1.15. SRAM_EXEC_MODE . . . 359
2.1.5.11.12.3.2.2.1.16. IRQ_ENTRY_ADDR . . . 360
2.1.5.11.12.3.2.2.1.17. IRQ_ENTRY_LOCK . . . 360
2.1.5.11.12.3.2.2.1.18. VUART_TX . . . 360
2.1.5.11.12.3.2.2.1.19. VUART_RX . . . 360
2.1.5.11.12.3.2.2.1.20. VUART_STATUS . . . 360
2.1.5.11.12.3.2.2.1.21. TB_RESULT . . . 360

2.1.5.11.12.3.2.2.1.22. TB_SIGNATURE . . . 361
2.1.5.11.12.3.2.2.1.23. TB_ERRCODE . . . 361
2.1.5.11.12.3.2.2.1.24. TB_SUBTEST . . . 361
2.1.5.11.12.3.2.2.1.25. TB_CMD . . . 361
2.1.5.11.12.3.2.2.1.26. TB_CMD_ARG . . . 361
2.1.5.11.12.3.2.2.1.27. TB_CMD_STATUS . . . 361
2.1.5.11.12.3.2.2.1.28. TB_CMD_RESULT . . . 361
2.1.5.11.12.3.2.2.1.29. DEBUG . . . 361
2.1.5.11.12.3.2.2.1.30. OTP_CHIPLET_UID_VAL_0 . . . 362
2.1.5.11.12.3.2.2.1.31. OTP_CHIPLET_UID_VAL_1 . . . 362
2.1.5.11.12.3.2.2.1.32. OTP_CHIPLET_UID_VAL_2 . . . 362
2.1.5.11.12.3.2.2.1.33. OTP_CHIPLET_UID_VAL_3 . . . 362
2.1.5.11.12.3.2.2.1.34. OTP_CHIPLET_UID_VAL_4 . . . 362
2.1.5.11.12.3.2.2.1.35. OTP_CHIPLET_UID_VAL_5 . . . 362
2.1.5.11.12.3.2.2.1.36. OTP_CHIPLET_UID_VAL_6 . . . 362
2.1.5.11.12.3.2.2.1.37. OTP_CHIPLET_UID_VAL_7 . . . 363
2.1.5.11.12.3.2.2.1.38. OTP_CHIPLET_UID_CPL_0 . . . 363
2.1.5.11.12.3.2.2.1.39. OTP_CHIPLET_UID_CPL_1 . . . 363
2.1.5.11.12.3.2.2.1.40. OTP_CHIPLET_UID_CPL_2 . . . 363
2.1.5.11.12.3.2.2.1.41. OTP_CHIPLET_UID_CPL_3 . . . 363
2.1.5.11.12.3.2.2.1.42. OTP_CHIPLET_UID_CPL_4 . . . 363
2.1.5.11.12.3.2.2.1.43. OTP_CHIPLET_UID_CPL_5 . . . 363
2.1.5.11.12.3.2.2.1.44. OTP_CHIPLET_UID_CPL_6 . . . 363
2.1.5.11.12.3.2.2.1.45. OTP_CHIPLET_UID_CPL_7 . . . 364
2.1.5.11.12.3.2.2.1.46. OTP_SIP_UID_VAL_0 . . . 364
2.1.5.11.12.3.2.2.1.47. OTP_SIP_UID_VAL_1 . . . 364
2.1.5.11.12.3.2.2.1.48. OTP_SIP_UID_VAL_2 . . . 364
2.1.5.11.12.3.2.2.1.49. OTP_SIP_UID_VAL_3 . . . 364
2.1.5.11.12.3.2.2.1.50. OTP_SIP_UID_VAL_4 . . . 364
2.1.5.11.12.3.2.2.1.51. OTP_SIP_UID_VAL_5 . . . 364
2.1.5.11.12.3.2.2.1.52. OTP_SIP_UID_VAL_6 . . . 365
2.1.5.11.12.3.2.2.1.53. OTP_SIP_UID_VAL_7 . . . 365
2.1.5.11.12.3.2.2.1.54. OTP_SIP_UID_CPL_0 . . . 365
2.1.5.11.12.3.2.2.1.55. OTP_SIP_UID_CPL_1 . . . 365
2.1.5.11.12.3.2.2.1.56. OTP_SIP_UID_CPL_2 . . . 365
2.1.5.11.12.3.2.2.1.57. OTP_SIP_UID_CPL_3 . . . 365
2.1.5.11.12.3.2.2.1.58. OTP_SIP_UID_CPL_4 . . . 365
2.1.5.11.12.3.2.2.1.59. OTP_SIP_UID_CPL_5 . . . 365
2.1.5.11.12.3.2.2.1.60. OTP_SIP_UID_CPL_6 . . . 366
2.1.5.11.12.3.2.2.1.61. OTP_SIP_UID_CPL_7 . . . 366
2.1.5.11.12.3.2.2.1.62. OTP_SYS_UID_VAL_0 . . . 366
2.1.5.11.12.3.2.2.1.63. OTP_SYS_UID_VAL_1 . . . 366
2.1.5.11.12.3.2.2.1.64. OTP_SYS_UID_VAL_2 . . . 366
2.1.5.11.12.3.2.2.1.65. OTP_SYS_UID_VAL_3 . . . 366

2.1.5.11.12.3.2.2.1.66. OTP_SYS_UID_VAL_4 . . . 366
2.1.5.11.12.3.2.2.1.67. OTP_SYS_UID_VAL_5 . . . 367
2.1.5.11.12.3.2.2.1.68. OTP_SYS_UID_VAL_6 . . . 367
2.1.5.11.12.3.2.2.1.69. OTP_SYS_UID_VAL_7 . . . 367
2.1.5.11.12.3.2.2.1.70. OTP_SYS_UID_CPL_0 . . . 367
2.1.5.11.12.3.2.2.1.71. OTP_SYS_UID_CPL_1 . . . 367
2.1.5.11.12.3.2.2.1.72. OTP_SYS_UID_CPL_2 . . . 367
2.1.5.11.12.3.2.2.1.73. OTP_SYS_UID_CPL_3 . . . 367
2.1.5.11.12.3.2.2.1.74. OTP_SYS_UID_CPL_4 . . . 367
2.1.5.11.12.3.2.2.1.75. OTP_SYS_UID_CPL_5 . . . 368
2.1.5.11.12.3.2.2.1.76. OTP_SYS_UID_CPL_6 . . . 368
2.1.5.11.12.3.2.2.1.77. OTP_SYS_UID_CPL_7 . . . 368
2.1.5.11.12.3.2.2.1.78. OTP_CLASS_KEY_VAL_0 . . . 368
2.1.5.11.12.3.2.2.1.79. OTP_CLASS_KEY_VAL_1 . . . 368
2.1.5.11.12.3.2.2.1.80. OTP_CLASS_KEY_VAL_2 . . . 368
2.1.5.11.12.3.2.2.1.81. OTP_CLASS_KEY_VAL_3 . . . 368
2.1.5.11.12.3.2.2.1.82. OTP_CLASS_KEY_VAL_4 . . . 369
2.1.5.11.12.3.2.2.1.83. OTP_CLASS_KEY_VAL_5 . . . 369
2.1.5.11.12.3.2.2.1.84. OTP_CLASS_KEY_VAL_6 . . . 369
2.1.5.11.12.3.2.2.1.85. OTP_CLASS_KEY_VAL_7 . . . 369
2.1.5.11.12.3.2.2.1.86. OTP_CLASS_KEY_CPL_0 . . . 369
2.1.5.11.12.3.2.2.1.87. OTP_CLASS_KEY_CPL_1 . . . 369
2.1.5.11.12.3.2.2.1.88. OTP_CLASS_KEY_CPL_2 . . . 369
2.1.5.11.12.3.2.2.1.89. OTP_CLASS_KEY_CPL_3 . . . 369
2.1.5.11.12.3.2.2.1.90. OTP_CLASS_KEY_CPL_4 . . . 370
2.1.5.11.12.3.2.2.1.91. OTP_CLASS_KEY_CPL_5 . . . 370
2.1.5.11.12.3.2.2.1.92. OTP_CLASS_KEY_CPL_6 . . . 370
2.1.5.11.12.3.2.2.1.93. OTP_CLASS_KEY_CPL_7 . . . 370
2.1.5.11.12.3.2.2.1.94. OTP_READ_LOCK . . . 370
2.1.5.11.12.3.2.2.1.95. OTP_CHANGE_STATUS . . . 370
2.1.5.11.12.3.2.2.1.96. OTP_READ_LOCK_COLD . . . 371
2.1.5.11.12.3.2.2.1.97. OTP_SEP_CHIPLET_ID_VAL_0 . . . 371
2.1.5.11.12.3.2.2.1.98. OTP_SEP_CHIPLET_ID_VAL_1 . . . 371
2.1.5.11.12.3.2.2.1.99. OTP_SEP_CHIPLET_ID_VAL_2 . . . 372
2.1.5.11.12.3.2.2.1.100. OTP_SEP_CHIPLET_ID_VAL_3 . . . 372
2.1.5.11.12.3.2.2.1.101. OTP_SEP_CHIPLET_ID_VAL_4 . . . 372
2.1.5.11.12.3.2.2.1.102. OTP_SEP_CHIPLET_ID_VAL_5 . . . 372
2.1.5.11.12.3.2.2.1.103. OTP_SEP_CHIPLET_ID_VAL_6 . . . 372
2.1.5.11.12.3.2.2.1.104. OTP_SEP_CHIPLET_ID_VAL_7 . . . 372
2.1.5.11.12.3.2.2.1.105. OTP_SEP_CHIPLET_ID_CPL_0 . . . 372
2.1.5.11.12.3.2.2.1.106. OTP_SEP_CHIPLET_ID_CPL_1 . . . 373
2.1.5.11.12.3.2.2.1.107. OTP_SEP_CHIPLET_ID_CPL_2 . . . 373
2.1.5.11.12.3.2.2.1.108. OTP_SEP_CHIPLET_ID_CPL_3 . . . 373
2.1.5.11.12.3.2.2.1.109. OTP_SEP_CHIPLET_ID_CPL_4 . . . 373

2.1.5.11.12.3.2.2.1.110. OTP_SEP_CHIPLET_ID_CPL_5 . . . 373
2.1.5.11.12.3.2.2.1.111. OTP_SEP_CHIPLET_ID_CPL_6 . . . 373
2.1.5.11.12.3.2.2.1.112. OTP_SEP_CHIPLET_ID_CPL_7 . . . 373
2.1.5.11.12.3.2.2.1.113. OTP_SEP_SIP_ID_VAL_0 . . . 373
2.1.5.11.12.3.2.2.1.114. OTP_SEP_SIP_ID_VAL_1 . . . 374
2.1.5.11.12.3.2.2.1.115. OTP_SEP_SIP_ID_VAL_2 . . . 374
2.1.5.11.12.3.2.2.1.116. OTP_SEP_SIP_ID_VAL_3 . . . 374
2.1.5.11.12.3.2.2.1.117. OTP_SEP_SIP_ID_VAL_4 . . . 374
2.1.5.11.12.3.2.2.1.118. OTP_SEP_SIP_ID_VAL_5 . . . 374
2.1.5.11.12.3.2.2.1.119. OTP_SEP_SIP_ID_VAL_6 . . . 374
2.1.5.11.12.3.2.2.1.120. OTP_SEP_SIP_ID_VAL_7 . . . 374
2.1.5.11.12.3.2.2.1.121. OTP_SEP_SIP_ID_CPL_0 . . . 375
2.1.5.11.12.3.2.2.1.122. OTP_SEP_SIP_ID_CPL_1 . . . 375
2.1.5.11.12.3.2.2.1.123. OTP_SEP_SIP_ID_CPL_2 . . . 375
2.1.5.11.12.3.2.2.1.124. OTP_SEP_SIP_ID_CPL_3 . . . 375
2.1.5.11.12.3.2.2.1.125. OTP_SEP_SIP_ID_CPL_4 . . . 375
2.1.5.11.12.3.2.2.1.126. OTP_SEP_SIP_ID_CPL_5 . . . 375
2.1.5.11.12.3.2.2.1.127. OTP_SEP_SIP_ID_CPL_6 . . . 375
2.1.5.11.12.3.2.2.1.128. OTP_SEP_SIP_ID_CPL_7 . . . 375
2.1.5.11.12.3.2.2.1.129. OTP_SEP_SYS_ID_VAL_0 . . . 376
2.1.5.11.12.3.2.2.1.130. OTP_SEP_SYS_ID_VAL_1 . . . 376
2.1.5.11.12.3.2.2.1.131. OTP_SEP_SYS_ID_VAL_2 . . . 376
2.1.5.11.12.3.2.2.1.132. OTP_SEP_SYS_ID_VAL_3 . . . 376
2.1.5.11.12.3.2.2.1.133. OTP_SEP_SYS_ID_VAL_4 . . . 376
2.1.5.11.12.3.2.2.1.134. OTP_SEP_SYS_ID_VAL_5 . . . 376
2.1.5.11.12.3.2.2.1.135. OTP_SEP_SYS_ID_VAL_6 . . . 376
2.1.5.11.12.3.2.2.1.136. OTP_SEP_SYS_ID_VAL_7 . . . 377
2.1.5.11.12.3.2.2.1.137. OTP_SEP_SYS_ID_CPL_0 . . . 377
2.1.5.11.12.3.2.2.1.138. OTP_SEP_SYS_ID_CPL_1 . . . 377
2.1.5.11.12.3.2.2.1.139. OTP_SEP_SYS_ID_CPL_2 . . . 377
2.1.5.11.12.3.2.2.1.140. OTP_SEP_SYS_ID_CPL_3 . . . 377
2.1.5.11.12.3.2.2.1.141. OTP_SEP_SYS_ID_CPL_4 . . . 377
2.1.5.11.12.3.2.2.1.142. OTP_SEP_SYS_ID_CPL_5 . . . 377
2.1.5.11.12.3.2.2.1.143. OTP_SEP_SYS_ID_CPL_6 . . . 377
2.1.5.11.12.3.2.2.1.144. OTP_SEP_SYS_ID_CPL_7 . . . 378
2.1.5.11.12.3.2.3. Key and Policy Vault Registers . . . 378
2.1.5.11.12.3.2.3.1. Key and Policy Vault (KM Port) . . . 378
2.1.5.11.12.3.2.3.1.1. KEY_ENTRY[64].WORD[16] . . . 378
2.1.5.11.12.3.2.3.1.2. CTRL[64] . . . 378
2.1.5.11.12.3.2.3.1.3. KPV_SCRAMBLER_KEY . . . 379
2.1.5.11.12.3.2.3.1.4. KPV_SCRAMBLER_CTRL . . . 379
2.1.5.11.12.3.2.4. DRBG Sampler Registers . . . 379
2.1.5.11.12.3.2.4.1. DRBG Sampler . . . 379
2.1.5.11.12.3.2.4.1.1. DATA . . . 380

2.1.5.11.12.3.2.4.1.2. CFG . . . 380
2.1.5.11.12.3.2.4.1.3. STATUS . . . 380
2.1.5.11.12.3.2.4.1.4. PREFETCH_DATA . . . 380
2.1.5.11.12.3.2.5. KM Mailbox Registers . . . 380
2.1.5.11.12.3.2.5.1. Key Manager Mailbox KM Side . . . 380
2.1.5.11.12.3.2.5.1.1. KM_WRITE_DATA . . . 381
2.1.5.11.12.3.2.5.1.2. KM_WRITE_SEPARATOR . . . 381
2.1.5.11.12.3.2.5.1.3. KM_READ_DATA . . . 381
2.1.5.11.12.3.2.5.1.4. KM_STATUS . . . 381
2.1.5.11.12.3.2.5.1.5. KM_IRQ_STATUS . . . 382
2.1.5.11.12.3.2.5.1.6. KM_IRQ_ENABLE . . . 382
2.1.5.11.12.3.2.5.1.7. KM_CTRL . . . 382
2.1.5.11.12.3.2.6. SEP Mailbox Registers . . . 382
2.1.5.11.12.3.2.6.1. Key Manager Mailbox SEP Side . . . 383
2.1.5.11.12.3.2.6.1.1. SEP_WRITE_DATA . . . 383
2.1.5.11.12.3.2.6.1.2. SEP_WRITE_SEPARATOR . . . 383
2.1.5.11.12.3.2.6.1.3. SEP_READ_DATA . . . 383
2.1.5.11.12.3.2.6.1.4. SEP_STATUS . . . 383
2.1.5.11.12.3.2.6.1.5. SEP_IRQ_STATUS . . . 384
2.1.5.11.12.3.2.6.1.6. SEP_IRQ_ENABLE . . . 384
2.1.5.11.12.3.2.6.1.7. SEP_CTRL . . . 384
2.1.5.11.12.3.2.7. Adams Bridge Key Interface Registers . . . 385
2.1.5.11.12.3.2.7.1. Adams Bridge Key Sideload Registers . . . 385
2.1.5.11.12.3.2.7.1.1. MLDSA_SEED.KEY_SHARE0[8] . . . 386
2.1.5.11.12.3.2.7.1.2. MLDSA_SEED.KEY_SHARE1[8] . . . 386
2.1.5.11.12.3.2.7.1.3. MLDSA_SEED.KEY_CTRL . . . 386
2.1.5.11.12.3.2.7.1.4. MLKEM_SEED_D.KEY_SHARE0[8] . . . 386
2.1.5.11.12.3.2.7.1.5. MLKEM_SEED_D.KEY_SHARE1[8] . . . 386
2.1.5.11.12.3.2.7.1.6. MLKEM_SEED_D.KEY_CTRL . . . 387
2.1.5.11.12.3.2.7.1.7. MLKEM_SEED_Z.KEY_SHARE0[8] . . . 387
2.1.5.11.12.3.2.7.1.8. MLKEM_SEED_Z.KEY_SHARE1[8] . . . 387
2.1.5.11.12.3.2.7.1.9. MLKEM_SEED_Z.KEY_CTRL . . . 387
2.1.5.11.12.3.2.7.1.10. MLKEM_MSG.KEY_SHARE0[8] . . . 387
2.1.5.11.12.3.2.7.1.11. MLKEM_MSG.KEY_SHARE1[8] . . . 387
2.1.5.11.12.3.2.7.1.12. MLKEM_MSG.KEY_CTRL . . . 387
2.1.5.11.12.3.2.7.1.13. KEY[8] . . . 388
2.1.5.11.12.3.2.7.1.14. MLKEM_SHARED_KEY.KEY_CTRL . . . 388
2.1.5.11.12.3.2.7.1.15. IRQ_STATUS . . . 388
2.1.5.11.12.3.2.7.1.16. IRQ_ENABLE . . . 388
2.1.5.11.12.3.2.8. AES Key Interface Registers . . . 388
2.1.5.11.12.3.2.8.1. AES Wrapper Key Registers . . . 388
2.1.5.11.12.3.2.8.1.1. KEY_SHARE0[8] . . . 389
2.1.5.11.12.3.2.8.1.2. KEY_SHARE1[8] . . . 389
2.1.5.11.12.3.2.8.1.3. KEY_CTRL . . . 389

2.1.5.11.12.3.2.9. HMAC Key Interface Registers . . . 389
2.1.5.11.12.3.2.9.1. HMAC Wrapper Key Registers . . . 389
2.1.5.11.12.3.2.9.1.1. KEY_SHARE0[8] . . . 390
2.1.5.11.12.3.2.9.1.2. KEY_SHARE1[8] . . . 390
2.1.5.11.12.3.2.9.1.3. KEY_CTRL . . . 390
2.1.5.11.12.3.2.10. KMAC Key Interface Registers . . . 390
2.1.5.11.12.3.2.10.1. KMAC Wrapper Key Registers . . . 390
2.1.5.11.12.3.2.10.1.1. KEY_SHARE0[8] . . . 390
2.1.5.11.12.3.2.10.1.2. KEY_SHARE1[8] . . . 391
2.1.5.11.12.3.2.10.1.3. KEY_CTRL . . . 391
2.1.5.11.12.3.2.11. OTBN Key Interface Registers . . . 391
2.1.5.11.12.3.2.11.1. OTBN Wrapper Key Registers . . . 391
2.1.5.11.12.3.2.11.1.1. KEY_SHARE0[12] . . . 391
2.1.5.11.12.3.2.11.1.2. KEY_SHARE1[12] . . . 391
2.1.5.11.12.3.2.11.1.3. KEY_CTRL . . . 392
2.1.5.12. Memory Map and Register Reference . . . 392
2.1.5.12.1. Memory Map . . . 392
2.1.5.12.2. Single-Beat Register Access . . . 393
2.1.5.12.3. Units Unreachable from the Inbound Port . . . 393
2.1.5.12.4. Detailed Register Map . . . 398
2.1.5.12.4.1. External Window Reference Model . . . 398
2.1.5.12.4.1.1. SEP External . . . 398
2.1.5.12.4.1.1.1. EFUSE_BANK_INIT_TIME . . . 398
2.1.6. System Management Controller (SMC) . . . 398
2.1.6.1. Overview . . . 398
2.1.6.1.1. Clocks and Resets . . . 400
2.1.6.1.2. CPU . . . 400
2.1.6.1.3. Boot ROM . . . 400
2.1.6.1.4. Interconnect . . . 400
2.1.6.1.5. Interrupts . . . 400
2.1.6.1.6. Peripherals . . . 401
2.1.6.1.7. Design-for-Debug and CLA . . . 401
2.1.6.1.8. eFuse Scan Protection . . . 401
2.1.6.1.9. Memory Map . . . 401
2.1.6.2. Clocks and Resets . . . 401
2.1.6.2.1. Clock Architecture . . . 401
2.1.6.2.1.1. Timer and Debug Timebases . . . 404
2.1.6.2.1.2. Peripheral Timing Requirements . . . 405
2.1.6.2.2. Reset Architecture . . . 405
2.1.6.2.2.1. Power-Good and Cold Reset . . . 406
2.1.6.2.2.2. Primary and Warm Reset . . . 406
2.1.6.2.2.3. Reset Synchronization . . . 407
2.1.6.2.3. Function Level Reset and Isolation . . . 407
2.1.6.2.3.1. Isolation Controls . . . 407

2.1.6.2.3.2. Timing and Recovery . . . 408
2.1.6.2.3.3. Isolation Connections . . . 408
2.1.6.2.4. Subsystem Controls and Clock Gating . . . 412
2.1.6.2.5. Memory Map and Register Reference . . . 412
2.1.6.2.5.1. Memory Map . . . 413
2.1.6.2.5.2. Detailed Register Map . . . 413
2.1.6.2.5.2.1. Reset Unit Address Map . . . 413
2.1.6.2.5.2.1.1. SS_CONFIG . . . 413
2.1.6.2.5.2.1.2. SS_CONFIG_LOCK . . . 413
2.1.6.2.5.2.1.3. SS_COLD_RESET_N . . . 414
2.1.6.2.5.2.1.4. SS_WARM_RESET_N . . . 414
2.1.6.2.5.2.1.5. SS_CONFIG_HOLD . . . 414
2.1.6.2.5.2.1.6. SS_SRAM_HOLD . . . 414
2.1.6.2.5.2.1.7. SS_CRITICAL_HOLD . . . 414
2.1.6.2.5.2.1.8. SS_DEBUG_HOLD . . . 414
2.1.6.2.5.2.1.9. SS_RESET_COMPLETE . . . 415
2.1.6.2.5.2.1.10. SS_COLD_RESET_LOCK . . . 415
2.1.6.2.5.2.1.11. SS_FORCE_TO_REF_CLK . . . 415
2.1.6.2.5.2.1.12. SYNC_REG . . . 415
2.1.6.2.5.2.1.13. ISOLATE_REQ_REG . . . 415
2.1.6.2.5.2.1.14. ISOLATE_REQ_PINEN_REG . . . 415
2.1.6.2.5.2.1.15. ISOLATE_REQ_SMC_REG . . . 415
2.1.6.2.5.2.1.16. ISOLATE_REQ_SMCEN_REG . . . 416
2.1.6.2.5.2.1.17. ISOLATE_REQ_VIS . . . 416
2.1.6.2.5.2.1.18. ISOLATE_REQ_FLR_COUNTER_VALUE . . . 416
2.1.6.2.5.2.1.19. ISOLATE_REQ_FLR_RESET_COUNTER_VALUE . . . 416
2.1.6.3. CPU . . . 416
2.1.6.3.1. Processor Core . . . 418
2.1.6.3.2. Local Memory . . . 418
2.1.6.3.3. Reset and Boot . . . 418
2.1.6.3.4. Memory Repair . . . 419
2.1.6.3.5. System Interfaces . . . 419
2.1.6.3.6. CPU AXI Isolation . . . 420
2.1.6.3.6.1. Drain Handshake . . . 420
2.1.6.3.6.2. Timeout Recovery . . . 420
2.1.6.3.6.3. Reset-Domain Crossing . . . 421
2.1.6.3.7. Interrupt Integration . . . 421
2.1.6.3.8. Watchdog Interface . . . 421
2.1.6.3.9. Bus Error Reporting . . . 421
2.1.6.3.10. Debug . . . 422
2.1.6.3.10.1. Debug Module Configuration . . . 422
2.1.6.3.10.2. Abstract Command Writes While cmderr Is Set . . . 423
2.1.6.3.11. Memory Map and Register Reference . . . 424
2.1.6.3.11.1. Memory Map . . . 424

2.1.6.3.11.2. Detailed Register Map . . . 424
2.1.6.3.11.2.1. CPU Control Address Map . . . 424
2.1.6.3.11.2.1.1. RESET_VECTOR[4] . . . 425
2.1.6.3.11.2.1.2. RESET_CTRL . . . 425
2.1.6.3.11.2.1.3. CORE_RESET_PULSE_COUNT . . . 426
2.1.6.3.11.2.1.4. RESET_TIMEOUT . . . 426
2.1.6.3.11.2.1.5. REFERENCE_COUNTER . . . 426
2.1.6.3.11.2.1.6. WDT_TIMEOUT . . . 426
2.1.6.3.11.2.1.7. WDT_TIMEOUT_RESET . . . 427
2.1.6.3.11.2.1.8. TEST_CTRL . . . 427
2.1.6.3.11.2.1.9. SCRATCH[16] . . . 427
2.1.6.3.11.2.1.10. WB_PC_CORE0[8] . . . 427
2.1.6.3.11.2.1.11. WB_PC_CORE1[8] . . . 427
2.1.6.3.11.2.1.12. WB_PC_CORE2[8] . . . 427
2.1.6.3.11.2.1.13. WB_PC_CORE3[8] . . . 428
2.1.6.3.11.2.1.14. SMC_ATTRIBUTES . . . 428
2.1.6.3.11.2.1.15. MUTEX[4] . . . 428
2.1.6.3.11.2.1.16. SEMA[4] . . . 428
2.1.6.3.11.2.1.17. DUMMY_ROM_0 . . . 428
2.1.6.3.11.2.1.18. DUMMY_ROM_1 . . . 429
2.1.6.3.11.2.1.19. DUMMY_ROM_2 . . . 429
2.1.6.3.11.2.1.20. DUMMY_ROM_3 . . . 429
2.1.6.3.11.2.1.21. DUMMY_ROM_NULL[4] . . . 429
2.1.6.3.11.2.2. CLINT Address Map . . . 429
2.1.6.3.11.2.2.1. MSIP[4] . . . 429
2.1.6.3.11.2.2.2. MTIMECMP[4] . . . 430
2.1.6.3.11.2.2.3. MTIME . . . 430
2.1.6.3.11.2.3. Debug Module Hart Interface . . . 430
2.1.6.3.11.2.3.1. HALTED . . . 431
2.1.6.3.11.2.3.2. GOING . . . 431
2.1.6.3.11.2.3.3. RESUMING . . . 431
2.1.6.3.11.2.3.4. EXCEPTION . . . 431
2.1.6.3.11.2.3.5. WHERETO . . . 431
2.1.6.3.11.2.3.6. ABSTRACT[5] . . . 432
2.1.6.3.11.2.3.7. PROGBUF[16] . . . 432
2.1.6.3.11.2.3.8. IMPEBREAK . . . 432
2.1.6.3.11.2.3.9. DATA[4] . . . 432
2.1.6.3.11.2.3.10. FLAGS . . . 432
2.1.6.3.11.2.3.11. ROM[26] . . . 432
2.1.6.3.11.2.4. Bus Error Unit Address Map . . . 432
2.1.6.3.11.2.4.1. CAUSE . . . 433
2.1.6.3.11.2.4.2. PHYS_ADDR . . . 433
2.1.6.3.11.2.4.3. ENABLE . . . 433
2.1.6.3.11.2.4.4. PLIC_ENABLE . . . 434

2.1.6.3.11.2.4.5. ACCRUED_ENABLE . . . 434
2.1.6.3.11.2.4.6. LOCAL_ENABLE . . . 434
2.1.6.4. Boot ROM . . . 435
2.1.6.4.1. ROM Architecture . . . 435
2.1.6.4.2. Hardware Configuration and Integrity . . . 435
2.1.6.4.3. Boot Flow . . . 435
2.1.6.4.4. Firmware Reference . . . 435
2.1.6.5. Interconnect . . . 435
2.1.6.5.1. Topology . . . 435
2.1.6.5.1.1. Fabric Topology . . . 435
2.1.6.5.1.2. Configuration Parameters . . . 438
2.1.6.5.1.3. Dual-Network Architecture . . . 439
2.1.6.5.2. Interfaces . . . 439
2.1.6.5.2.1. AXI Interface Widths . . . 439
2.1.6.5.2.2. Traffic Managers and Subordinates . . . 440
2.1.6.5.2.2.1. Traffic Managers . . . 440
2.1.6.5.2.2.2. Traffic Subordinates . . . 440
2.1.6.5.3. Address Remapping . . . 441
2.1.6.5.3.1. Alias Remapping . . . 441
2.1.6.5.3.2. Privilege-Controlled Remapping . . . 441
2.1.6.5.4. Filtering and Protection . . . 442
2.1.6.5.4.1. Inbound Filtering . . . 442
2.1.6.5.4.2. Outbound Filtering . . . 443
2.1.6.5.4.3. Protection Requirements . . . 443
2.1.6.5.4.3.1. AXI Protection Bit Encoding . . . 443
2.1.6.5.4.3.2. Non-Secure Bit Filtering (AXI4 Filters) . . . 444
2.1.6.5.4.3.3. Full 3-Bit Protection Matching (AXI-Lite) . . . 444
2.1.6.5.4.3.4. Protection Bit Pass-Through . . . 445
2.1.6.5.4.3.5. Configuration Examples . . . 445
2.1.6.5.5. Routing . . . 445
2.1.6.5.5.1. Local and Remote Resource Access . . . 445
2.1.6.5.5.2. Outbound Traffic Flow . . . 445
2.1.6.5.6. Memory Map and Register Reference . . . 445
2.1.6.5.6.1. Memory Map . . . 446
2.1.6.5.6.2. Detailed Register Map . . . 446
2.1.6.5.6.2.1. Alias Remap Registers . . . 446
2.1.6.5.6.2.1.1. AXI Alias Remap Address Map . . . 446
2.1.6.5.6.2.1.1.1. region_start . . . 446
2.1.6.5.6.2.1.1.2. region_end . . . 446
2.1.6.5.6.2.1.1.3. region_attrs . . . 446
2.1.6.5.6.2.2. Output Remap Registers . . . 447
2.1.6.5.6.2.2.1. Output Remap Address Map . . . 447
2.1.6.5.6.2.2.1.1. region_attrs . . . 447
2.1.6.5.6.2.3. Inbound Traffic Filter Control Registers . . . 447

2.1.6.5.6.2.3.1. AXI Filter Control Address Map . . . 447
2.1.6.5.6.2.3.1.1. FILTER_CONFIG . . . 448
2.1.6.5.6.2.3.1.2. START_ADDR . . . 448
2.1.6.5.6.2.3.1.3. END_ADDR . . . 449
2.1.6.5.6.2.4. Outbound Traffic Filter Control Registers . . . 449
2.1.6.6. Interrupts . . . 449
2.1.6.6.1. Controllers . . . 449
2.1.6.6.1.1. Controller Addresses . . . 449
2.1.6.6.1.2. PLIC Sources and Contexts . . . 449
2.1.6.6.1.3. CLINT . . . 450
2.1.6.6.1.4. Bus Error Units . . . 450
2.1.6.6.2. Sources and Routing . . . 450
2.1.6.6.2.1. Raw Vector and PLIC Numbering . . . 450
2.1.6.6.2.2. SMC CPU Interrupt Vector Map . . . 450
2.1.6.6.2.2.1. Exact Indexed Map . . . 451
2.1.6.6.2.2.2. Routing Notes . . . 453
2.1.6.6.3. Software Handling . . . 453
2.1.6.6.4. Memory Map and Register Reference . . . 454
2.1.6.6.4.1. Memory Map . . . 454
2.1.6.6.4.2. Detailed Register Map . . . 454
2.1.6.6.4.2.1. PLIC Address Map . . . 454
2.1.6.6.4.2.1.1. PRIORITY[337] . . . 455
2.1.6.6.4.2.1.2. PENDING[11] . . . 455
2.1.6.6.4.2.1.3. CORE0_MEIP_ENABLE[11] . . . 455
2.1.6.6.4.2.1.4. CORE1_MEIP_ENABLE[11] . . . 455
2.1.6.6.4.2.1.5. CORE2_MEIP_ENABLE[11] . . . 456
2.1.6.6.4.2.1.6. CORE3_MEIP_ENABLE[11] . . . 456
2.1.6.6.4.2.1.7. CORE0_SEIP_ENABLE[11] . . . 456
2.1.6.6.4.2.1.8. CORE1_SEIP_ENABLE[11] . . . 456
2.1.6.6.4.2.1.9. CORE2_SEIP_ENABLE[11] . . . 456
2.1.6.6.4.2.1.10. CORE3_SEIP_ENABLE[11] . . . 456
2.1.6.6.4.2.1.11. CORE0_MEIP_THRESHOLD . . . 456
2.1.6.6.4.2.1.12. CORE0_MEIP_CLAIM_COMPLETE . . . 457
2.1.6.6.4.2.1.13. CORE1_MEIP_THRESHOLD . . . 457
2.1.6.6.4.2.1.14. CORE1_MEIP_CLAIM_COMPLETE . . . 457
2.1.6.6.4.2.1.15. CORE2_MEIP_THRESHOLD . . . 457
2.1.6.6.4.2.1.16. CORE2_MEIP_CLAIM_COMPLETE . . . 457
2.1.6.6.4.2.1.17. CORE3_MEIP_THRESHOLD . . . 457
2.1.6.6.4.2.1.18. CORE3_MEIP_CLAIM_COMPLETE . . . 458
2.1.6.6.4.2.1.19. CORE0_SEIP_THRESHOLD . . . 458
2.1.6.6.4.2.1.20. CORE0_SEIP_CLAIM_COMPLETE . . . 458
2.1.6.6.4.2.1.21. CORE1_SEIP_THRESHOLD . . . 458
2.1.6.6.4.2.1.22. CORE1_SEIP_CLAIM_COMPLETE . . . 458
2.1.6.6.4.2.1.23. CORE2_SEIP_THRESHOLD . . . 459

2.1.6.6.4.2.1.24. CORE2_SEIP_CLAIM_COMPLETE . . . 459
2.1.6.6.4.2.1.25. CORE3_SEIP_THRESHOLD . . . 459
2.1.6.6.4.2.1.26. CORE3_SEIP_CLAIM_COMPLETE . . . 459
2.1.6.7. Peripherals . . . 459
2.1.6.7.1. Direct Memory Access (DMA) Engine . . . 460
2.1.6.7.1.1. Architecture and Configuration . . . 460
2.1.6.7.1.2. Transfer Configuration . . . 462
2.1.6.7.1.2.1. Stream and Register Ownership . . . 462
2.1.6.7.1.2.2. Linear and Two-Dimensional Copies . . . 462
2.1.6.7.1.3. Submission and Completion . . . 463
2.1.6.7.1.4. Memory Map and Register Reference . . . 463
2.1.6.7.1.4.1. Memory Map . . . 463
2.1.6.7.1.4.2. Detailed Register Map . . . 463
2.1.6.7.1.4.2.1. iDMA Controller Address Map . . . 463
2.1.6.7.1.4.2.1.1. CONFIG . . . 465
2.1.6.7.1.4.2.1.2. STATUS_0 . . . 465
2.1.6.7.1.4.2.1.3. STATUS_1 . . . 466
2.1.6.7.1.4.2.1.4. STATUS_2 . . . 466
2.1.6.7.1.4.2.1.5. STATUS_3 . . . 466
2.1.6.7.1.4.2.1.6. STATUS_4 . . . 466
2.1.6.7.1.4.2.1.7. STATUS_5 . . . 466
2.1.6.7.1.4.2.1.8. STATUS_6 . . . 467
2.1.6.7.1.4.2.1.9. STATUS_7 . . . 467
2.1.6.7.1.4.2.1.10. STATUS_8 . . . 467
2.1.6.7.1.4.2.1.11. STATUS_9 . . . 467
2.1.6.7.1.4.2.1.12. STATUS_10 . . . 467
2.1.6.7.1.4.2.1.13. STATUS_11 . . . 468
2.1.6.7.1.4.2.1.14. STATUS_12 . . . 468
2.1.6.7.1.4.2.1.15. STATUS_13 . . . 468
2.1.6.7.1.4.2.1.16. STATUS_14 . . . 468
2.1.6.7.1.4.2.1.17. STATUS_15 . . . 468
2.1.6.7.1.4.2.1.18. NEXT_ID_0 . . . 469
2.1.6.7.1.4.2.1.19. NEXT_ID_1 . . . 469
2.1.6.7.1.4.2.1.20. NEXT_ID_2 . . . 469
2.1.6.7.1.4.2.1.21. NEXT_ID_3 . . . 469
2.1.6.7.1.4.2.1.22. NEXT_ID_4 . . . 469
2.1.6.7.1.4.2.1.23. NEXT_ID_5 . . . 469
2.1.6.7.1.4.2.1.24. NEXT_ID_6 . . . 470
2.1.6.7.1.4.2.1.25. NEXT_ID_7 . . . 470
2.1.6.7.1.4.2.1.26. NEXT_ID_8 . . . 470
2.1.6.7.1.4.2.1.27. NEXT_ID_9 . . . 470
2.1.6.7.1.4.2.1.28. NEXT_ID_10 . . . 470
2.1.6.7.1.4.2.1.29. NEXT_ID_11 . . . 470
2.1.6.7.1.4.2.1.30. NEXT_ID_12 . . . 471

2.1.6.7.1.4.2.1.31. NEXT_ID_13 . . . 471
2.1.6.7.1.4.2.1.32. NEXT_ID_14 . . . 471
2.1.6.7.1.4.2.1.33. NEXT_ID_15 . . . 471
2.1.6.7.1.4.2.1.34. DONE_0 . . . 471
2.1.6.7.1.4.2.1.35. DONE_1 . . . 471
2.1.6.7.1.4.2.1.36. DONE_2 . . . 472
2.1.6.7.1.4.2.1.37. DONE_3 . . . 472
2.1.6.7.1.4.2.1.38. DONE_4 . . . 472
2.1.6.7.1.4.2.1.39. DONE_5 . . . 472
2.1.6.7.1.4.2.1.40. DONE_6 . . . 472
2.1.6.7.1.4.2.1.41. DONE_7 . . . 472
2.1.6.7.1.4.2.1.42. DONE_8 . . . 473
2.1.6.7.1.4.2.1.43. DONE_9 . . . 473
2.1.6.7.1.4.2.1.44. DONE_10 . . . 473
2.1.6.7.1.4.2.1.45. DONE_11 . . . 473
2.1.6.7.1.4.2.1.46. DONE_12 . . . 473
2.1.6.7.1.4.2.1.47. DONE_13 . . . 473
2.1.6.7.1.4.2.1.48. DONE_14 . . . 473
2.1.6.7.1.4.2.1.49. DONE_15 . . . 474
2.1.6.7.1.4.2.1.50. DST_ADDRESS_LO . . . 474
2.1.6.7.1.4.2.1.51. DST_ADDRESS_HI . . . 474
2.1.6.7.1.4.2.1.52. SRC_ADDRESS_LO . . . 474
2.1.6.7.1.4.2.1.53. SRC_ADDRESS_HI . . . 474
2.1.6.7.1.4.2.1.54. LENGTH_LO . . . 474
2.1.6.7.1.4.2.1.55. LENGTH_HI . . . 474
2.1.6.7.1.4.2.1.56. DST_STRIDE_LO . . . 475
2.1.6.7.1.4.2.1.57. DST_STRIDE_HI . . . 475
2.1.6.7.1.4.2.1.58. SRC_STRIDE_LO . . . 475
2.1.6.7.1.4.2.1.59. SRC_STRIDE_HI . . . 475
2.1.6.7.1.4.2.1.60. NUM_REPETITIONS_LO . . . 475
2.1.6.7.1.4.2.1.61. NUM_REPETITIONS_HI . . . 475
2.1.6.7.2. Zeroer . . . 475
2.1.6.7.2.1. Use Cases . . . 476
2.1.6.7.2.2. Architecture . . . 476
2.1.6.7.2.2.1. State Machine . . . 476
2.1.6.7.2.2.2. Operation Flow . . . 477
2.1.6.7.2.2.3. AXI Master Interface . . . 477
2.1.6.7.2.2.4. Outstanding Transaction Management . . . 478
2.1.6.7.2.2.5. Dual Clock Domain Architecture . . . 478
2.1.6.7.2.2.6. Clock Domains . . . 478
2.1.6.7.2.2.7. Clock Gating . . . 478
2.1.6.7.2.2.8. Control and Status . . . 478
2.1.6.7.2.2.8.1. Operation Control . . . 479
2.1.6.7.2.2.8.2. Status Features . . . 479

2.1.6.7.2.3. Operation Details . . . 479
2.1.6.7.2.4. Memory Map and Register Reference . . . 479
2.1.6.7.2.4.1. Memory Map . . . 479
2.1.6.7.2.4.2. Detailed Register Map . . . 479
2.1.6.7.2.4.2.1. Zeroer Control Address Map . . . 479
2.1.6.7.2.4.2.1.1. DEST_ADDR . . . 480
2.1.6.7.2.4.2.1.2. SIZE . . . 480
2.1.6.7.2.4.2.1.3. CTRL_STATUS . . . 480
2.1.6.7.3. Watchdog Timers . . . 480
2.1.6.7.3.1. Operation . . . 480
2.1.6.7.3.1.1. Register Access . . . 481
2.1.6.7.3.2. Memory Map and Register Reference . . . 481
2.1.6.7.3.2.1. Memory Map . . . 481
2.1.6.7.3.2.2. Detailed Register Map . . . 481
2.1.6.7.3.2.2.1. Watchdog Timer Address Map . . . 481
2.1.6.7.3.2.2.1.1. CTRL . . . 481
2.1.6.7.3.2.2.1.2. COUNT . . . 482
2.1.6.7.3.2.2.1.3. COUNT_HI . . . 482
2.1.6.7.3.2.2.1.4. SCALED_COUNT . . . 482
2.1.6.7.3.2.2.1.5. FEED . . . 483
2.1.6.7.3.2.2.1.6. KEY . . . 483
2.1.6.7.3.2.2.1.7. CMP . . . 483
2.1.6.7.4. Mailbox Unit . . . 483
2.1.6.7.4.1. Overview . . . 483
2.1.6.7.4.2. Architecture . . . 484
2.1.6.7.4.2.1. Paired FIFOs . . . 484
2.1.6.7.4.2.2. Interrupts . . . 485
2.1.6.7.4.2.3. Clock and Reset . . . 485
2.1.6.7.4.3. Interface and Programming . . . 485
2.1.6.7.4.3.1. External Interface . . . 485
2.1.6.7.4.3.2. Access Results . . . 485
2.1.6.7.4.3.3. Sending and Receiving . . . 486
2.1.6.7.4.4. Memory Map and Register Reference . . . 486
2.1.6.7.4.4.1. Memory Map . . . 486
2.1.6.7.4.4.1.1. Per-Mailbox Register Map . . . 489
2.1.6.7.4.4.1.2. Address Examples . . . 489
2.1.6.7.4.4.2. Detailed Register Map . . . 490
2.1.6.7.4.4.2.1. AXI-Lite Mailbox Address Map . . . 490
2.1.6.7.4.4.2.1.1. WRITE_DATA . . . 490
2.1.6.7.4.4.2.1.2. READ_DATA . . . 490
2.1.6.7.4.4.2.1.3. STATUS . . . 490
2.1.6.7.4.4.2.1.4. ERROR_FLAGS . . . 491
2.1.6.7.4.4.2.1.5. WIRQT . . . 491
2.1.6.7.4.4.2.1.6. RIRQT . . . 491

2.1.6.7.4.4.2.1.7. IRQS . . . 491
2.1.6.7.4.4.2.1.8. IRQEN . . . 491
2.1.6.7.4.4.2.1.9. IRQP . . . 492
2.1.6.7.4.4.2.1.10. CTRL . . . 492
2.1.6.7.4.4.2.2. Subsystem Wrapper Maps . . . 492
2.1.6.7.4.4.2.2.1. SMC AXI-Lite Mailbox Wrapper Address Map . . . 492
2.1.6.7.4.4.2.2.1.1. outbound_mailbox_0.WRITE_DATA . . . 511
2.1.6.7.4.4.2.2.1.2. outbound_mailbox_0.READ_DATA . . . 511
2.1.6.7.4.4.2.2.1.3. outbound_mailbox_0.STATUS . . . 511
2.1.6.7.4.4.2.2.1.4. outbound_mailbox_0.ERROR_FLAGS . . . 511
2.1.6.7.4.4.2.2.1.5. outbound_mailbox_0.WIRQT . . . 511
2.1.6.7.4.4.2.2.1.6. outbound_mailbox_0.RIRQT . . . 512
2.1.6.7.4.4.2.2.1.7. outbound_mailbox_0.IRQS . . . 512
2.1.6.7.4.4.2.2.1.8. outbound_mailbox_0.IRQEN . . . 512
2.1.6.7.4.4.2.2.1.9. outbound_mailbox_0.IRQP . . . 512
2.1.6.7.4.4.2.2.1.10. outbound_mailbox_0.CTRL . . . 513
2.1.6.7.4.4.2.2.1.11. inbound_mailbox_0.WRITE_DATA . . . 513
2.1.6.7.4.4.2.2.1.12. inbound_mailbox_0.READ_DATA . . . 513
2.1.6.7.4.4.2.2.1.13. inbound_mailbox_0.STATUS . . . 513
2.1.6.7.4.4.2.2.1.14. inbound_mailbox_0.ERROR_FLAGS . . . 513
2.1.6.7.4.4.2.2.1.15. inbound_mailbox_0.WIRQT . . . 513
2.1.6.7.4.4.2.2.1.16. inbound_mailbox_0.RIRQT . . . 514
2.1.6.7.4.4.2.2.1.17. inbound_mailbox_0.IRQS . . . 514
2.1.6.7.4.4.2.2.1.18. inbound_mailbox_0.IRQEN . . . 514
2.1.6.7.4.4.2.2.1.19. inbound_mailbox_0.IRQP . . . 514
2.1.6.7.4.4.2.2.1.20. inbound_mailbox_0.CTRL . . . 515
2.1.6.7.4.4.2.2.1.21. outbound_mailbox_1.WRITE_DATA . . . 515
2.1.6.7.4.4.2.2.1.22. outbound_mailbox_1.READ_DATA . . . 515
2.1.6.7.4.4.2.2.1.23. outbound_mailbox_1.STATUS . . . 515
2.1.6.7.4.4.2.2.1.24. outbound_mailbox_1.ERROR_FLAGS . . . 515
2.1.6.7.4.4.2.2.1.25. outbound_mailbox_1.WIRQT . . . 515
2.1.6.7.4.4.2.2.1.26. outbound_mailbox_1.RIRQT . . . 516
2.1.6.7.4.4.2.2.1.27. outbound_mailbox_1.IRQS . . . 516
2.1.6.7.4.4.2.2.1.28. outbound_mailbox_1.IRQEN . . . 516
2.1.6.7.4.4.2.2.1.29. outbound_mailbox_1.IRQP . . . 516
2.1.6.7.4.4.2.2.1.30. outbound_mailbox_1.CTRL . . . 517
2.1.6.7.4.4.2.2.1.31. inbound_mailbox_1.WRITE_DATA . . . 517
2.1.6.7.4.4.2.2.1.32. inbound_mailbox_1.READ_DATA . . . 517
2.1.6.7.4.4.2.2.1.33. inbound_mailbox_1.STATUS . . . 517
2.1.6.7.4.4.2.2.1.34. inbound_mailbox_1.ERROR_FLAGS . . . 517
2.1.6.7.4.4.2.2.1.35. inbound_mailbox_1.WIRQT . . . 517
2.1.6.7.4.4.2.2.1.36. inbound_mailbox_1.RIRQT . . . 518
2.1.6.7.4.4.2.2.1.37. inbound_mailbox_1.IRQS . . . 518
2.1.6.7.4.4.2.2.1.38. inbound_mailbox_1.IRQEN . . . 518

2.1.6.7.4.4.2.2.1.39. inbound_mailbox_1.IRQP . . . 518
2.1.6.7.4.4.2.2.1.40. inbound_mailbox_1.CTRL . . . 519
2.1.6.7.4.4.2.2.1.41. outbound_mailbox_2.WRITE_DATA . . . 519
2.1.6.7.4.4.2.2.1.42. outbound_mailbox_2.READ_DATA . . . 519
2.1.6.7.4.4.2.2.1.43. outbound_mailbox_2.STATUS . . . 519
2.1.6.7.4.4.2.2.1.44. outbound_mailbox_2.ERROR_FLAGS . . . 519
2.1.6.7.4.4.2.2.1.45. outbound_mailbox_2.WIRQT . . . 519
2.1.6.7.4.4.2.2.1.46. outbound_mailbox_2.RIRQT . . . 520
2.1.6.7.4.4.2.2.1.47. outbound_mailbox_2.IRQS . . . 520
2.1.6.7.4.4.2.2.1.48. outbound_mailbox_2.IRQEN . . . 520
2.1.6.7.4.4.2.2.1.49. outbound_mailbox_2.IRQP . . . 520
2.1.6.7.4.4.2.2.1.50. outbound_mailbox_2.CTRL . . . 521
2.1.6.7.4.4.2.2.1.51. inbound_mailbox_2.WRITE_DATA . . . 521
2.1.6.7.4.4.2.2.1.52. inbound_mailbox_2.READ_DATA . . . 521
2.1.6.7.4.4.2.2.1.53. inbound_mailbox_2.STATUS . . . 521
2.1.6.7.4.4.2.2.1.54. inbound_mailbox_2.ERROR_FLAGS . . . 521
2.1.6.7.4.4.2.2.1.55. inbound_mailbox_2.WIRQT . . . 521
2.1.6.7.4.4.2.2.1.56. inbound_mailbox_2.RIRQT . . . 522
2.1.6.7.4.4.2.2.1.57. inbound_mailbox_2.IRQS . . . 522
2.1.6.7.4.4.2.2.1.58. inbound_mailbox_2.IRQEN . . . 522
2.1.6.7.4.4.2.2.1.59. inbound_mailbox_2.IRQP . . . 522
2.1.6.7.4.4.2.2.1.60. inbound_mailbox_2.CTRL . . . 523
2.1.6.7.4.4.2.2.1.61. outbound_mailbox_3.WRITE_DATA . . . 523
2.1.6.7.4.4.2.2.1.62. outbound_mailbox_3.READ_DATA . . . 523
2.1.6.7.4.4.2.2.1.63. outbound_mailbox_3.STATUS . . . 523
2.1.6.7.4.4.2.2.1.64. outbound_mailbox_3.ERROR_FLAGS . . . 523
2.1.6.7.4.4.2.2.1.65. outbound_mailbox_3.WIRQT . . . 523
2.1.6.7.4.4.2.2.1.66. outbound_mailbox_3.RIRQT . . . 524
2.1.6.7.4.4.2.2.1.67. outbound_mailbox_3.IRQS . . . 524
2.1.6.7.4.4.2.2.1.68. outbound_mailbox_3.IRQEN . . . 524
2.1.6.7.4.4.2.2.1.69. outbound_mailbox_3.IRQP . . . 524
2.1.6.7.4.4.2.2.1.70. outbound_mailbox_3.CTRL . . . 525
2.1.6.7.4.4.2.2.1.71. inbound_mailbox_3.WRITE_DATA . . . 525
2.1.6.7.4.4.2.2.1.72. inbound_mailbox_3.READ_DATA . . . 525
2.1.6.7.4.4.2.2.1.73. inbound_mailbox_3.STATUS . . . 525
2.1.6.7.4.4.2.2.1.74. inbound_mailbox_3.ERROR_FLAGS . . . 525
2.1.6.7.4.4.2.2.1.75. inbound_mailbox_3.WIRQT . . . 525
2.1.6.7.4.4.2.2.1.76. inbound_mailbox_3.RIRQT . . . 526
2.1.6.7.4.4.2.2.1.77. inbound_mailbox_3.IRQS . . . 526
2.1.6.7.4.4.2.2.1.78. inbound_mailbox_3.IRQEN . . . 526
2.1.6.7.4.4.2.2.1.79. inbound_mailbox_3.IRQP . . . 526
2.1.6.7.4.4.2.2.1.80. inbound_mailbox_3.CTRL . . . 527
2.1.6.7.4.4.2.2.1.81. outbound_mailbox_4.WRITE_DATA . . . 527
2.1.6.7.4.4.2.2.1.82. outbound_mailbox_4.READ_DATA . . . 527

2.1.6.7.4.4.2.2.1.83. outbound_mailbox_4.STATUS . . . 527
2.1.6.7.4.4.2.2.1.84. outbound_mailbox_4.ERROR_FLAGS . . . 527
2.1.6.7.4.4.2.2.1.85. outbound_mailbox_4.WIRQT . . . 527
2.1.6.7.4.4.2.2.1.86. outbound_mailbox_4.RIRQT . . . 528
2.1.6.7.4.4.2.2.1.87. outbound_mailbox_4.IRQS . . . 528
2.1.6.7.4.4.2.2.1.88. outbound_mailbox_4.IRQEN . . . 528
2.1.6.7.4.4.2.2.1.89. outbound_mailbox_4.IRQP . . . 528
2.1.6.7.4.4.2.2.1.90. outbound_mailbox_4.CTRL . . . 529
2.1.6.7.4.4.2.2.1.91. inbound_mailbox_4.WRITE_DATA . . . 529
2.1.6.7.4.4.2.2.1.92. inbound_mailbox_4.READ_DATA . . . 529
2.1.6.7.4.4.2.2.1.93. inbound_mailbox_4.STATUS . . . 529
2.1.6.7.4.4.2.2.1.94. inbound_mailbox_4.ERROR_FLAGS . . . 529
2.1.6.7.4.4.2.2.1.95. inbound_mailbox_4.WIRQT . . . 529
2.1.6.7.4.4.2.2.1.96. inbound_mailbox_4.RIRQT . . . 530
2.1.6.7.4.4.2.2.1.97. inbound_mailbox_4.IRQS . . . 530
2.1.6.7.4.4.2.2.1.98. inbound_mailbox_4.IRQEN . . . 530
2.1.6.7.4.4.2.2.1.99. inbound_mailbox_4.IRQP . . . 530
2.1.6.7.4.4.2.2.1.100. inbound_mailbox_4.CTRL . . . 531
2.1.6.7.4.4.2.2.1.101. outbound_mailbox_5.WRITE_DATA . . . 531
2.1.6.7.4.4.2.2.1.102. outbound_mailbox_5.READ_DATA . . . 531
2.1.6.7.4.4.2.2.1.103. outbound_mailbox_5.STATUS . . . 531
2.1.6.7.4.4.2.2.1.104. outbound_mailbox_5.ERROR_FLAGS . . . 531
2.1.6.7.4.4.2.2.1.105. outbound_mailbox_5.WIRQT . . . 531
2.1.6.7.4.4.2.2.1.106. outbound_mailbox_5.RIRQT . . . 532
2.1.6.7.4.4.2.2.1.107. outbound_mailbox_5.IRQS . . . 532
2.1.6.7.4.4.2.2.1.108. outbound_mailbox_5.IRQEN . . . 532
2.1.6.7.4.4.2.2.1.109. outbound_mailbox_5.IRQP . . . 532
2.1.6.7.4.4.2.2.1.110. outbound_mailbox_5.CTRL . . . 533
2.1.6.7.4.4.2.2.1.111. inbound_mailbox_5.WRITE_DATA . . . 533
2.1.6.7.4.4.2.2.1.112. inbound_mailbox_5.READ_DATA . . . 533
2.1.6.7.4.4.2.2.1.113. inbound_mailbox_5.STATUS . . . 533
2.1.6.7.4.4.2.2.1.114. inbound_mailbox_5.ERROR_FLAGS . . . 533
2.1.6.7.4.4.2.2.1.115. inbound_mailbox_5.WIRQT . . . 533
2.1.6.7.4.4.2.2.1.116. inbound_mailbox_5.RIRQT . . . 534
2.1.6.7.4.4.2.2.1.117. inbound_mailbox_5.IRQS . . . 534
2.1.6.7.4.4.2.2.1.118. inbound_mailbox_5.IRQEN . . . 534
2.1.6.7.4.4.2.2.1.119. inbound_mailbox_5.IRQP . . . 534
2.1.6.7.4.4.2.2.1.120. inbound_mailbox_5.CTRL . . . 535
2.1.6.7.4.4.2.2.1.121. outbound_mailbox_6.WRITE_DATA . . . 535
2.1.6.7.4.4.2.2.1.122. outbound_mailbox_6.READ_DATA . . . 535
2.1.6.7.4.4.2.2.1.123. outbound_mailbox_6.STATUS . . . 535
2.1.6.7.4.4.2.2.1.124. outbound_mailbox_6.ERROR_FLAGS . . . 535
2.1.6.7.4.4.2.2.1.125. outbound_mailbox_6.WIRQT . . . 535
2.1.6.7.4.4.2.2.1.126. outbound_mailbox_6.RIRQT . . . 536

2.1.6.7.4.4.2.2.1.127. outbound_mailbox_6.IRQS . . . 536
2.1.6.7.4.4.2.2.1.128. outbound_mailbox_6.IRQEN . . . 536
2.1.6.7.4.4.2.2.1.129. outbound_mailbox_6.IRQP . . . 536
2.1.6.7.4.4.2.2.1.130. outbound_mailbox_6.CTRL . . . 537
2.1.6.7.4.4.2.2.1.131. inbound_mailbox_6.WRITE_DATA . . . 537
2.1.6.7.4.4.2.2.1.132. inbound_mailbox_6.READ_DATA . . . 537
2.1.6.7.4.4.2.2.1.133. inbound_mailbox_6.STATUS . . . 537
2.1.6.7.4.4.2.2.1.134. inbound_mailbox_6.ERROR_FLAGS . . . 537
2.1.6.7.4.4.2.2.1.135. inbound_mailbox_6.WIRQT . . . 537
2.1.6.7.4.4.2.2.1.136. inbound_mailbox_6.RIRQT . . . 538
2.1.6.7.4.4.2.2.1.137. inbound_mailbox_6.IRQS . . . 538
2.1.6.7.4.4.2.2.1.138. inbound_mailbox_6.IRQEN . . . 538
2.1.6.7.4.4.2.2.1.139. inbound_mailbox_6.IRQP . . . 538
2.1.6.7.4.4.2.2.1.140. inbound_mailbox_6.CTRL . . . 539
2.1.6.7.4.4.2.2.1.141. outbound_mailbox_7.WRITE_DATA . . . 539
2.1.6.7.4.4.2.2.1.142. outbound_mailbox_7.READ_DATA . . . 539
2.1.6.7.4.4.2.2.1.143. outbound_mailbox_7.STATUS . . . 539
2.1.6.7.4.4.2.2.1.144. outbound_mailbox_7.ERROR_FLAGS . . . 539
2.1.6.7.4.4.2.2.1.145. outbound_mailbox_7.WIRQT . . . 539
2.1.6.7.4.4.2.2.1.146. outbound_mailbox_7.RIRQT . . . 540
2.1.6.7.4.4.2.2.1.147. outbound_mailbox_7.IRQS . . . 540
2.1.6.7.4.4.2.2.1.148. outbound_mailbox_7.IRQEN . . . 540
2.1.6.7.4.4.2.2.1.149. outbound_mailbox_7.IRQP . . . 540
2.1.6.7.4.4.2.2.1.150. outbound_mailbox_7.CTRL . . . 541
2.1.6.7.4.4.2.2.1.151. inbound_mailbox_7.WRITE_DATA . . . 541
2.1.6.7.4.4.2.2.1.152. inbound_mailbox_7.READ_DATA . . . 541
2.1.6.7.4.4.2.2.1.153. inbound_mailbox_7.STATUS . . . 541
2.1.6.7.4.4.2.2.1.154. inbound_mailbox_7.ERROR_FLAGS . . . 541
2.1.6.7.4.4.2.2.1.155. inbound_mailbox_7.WIRQT . . . 541
2.1.6.7.4.4.2.2.1.156. inbound_mailbox_7.RIRQT . . . 542
2.1.6.7.4.4.2.2.1.157. inbound_mailbox_7.IRQS . . . 542
2.1.6.7.4.4.2.2.1.158. inbound_mailbox_7.IRQEN . . . 542
2.1.6.7.4.4.2.2.1.159. inbound_mailbox_7.IRQP . . . 542
2.1.6.7.4.4.2.2.1.160. inbound_mailbox_7.CTRL . . . 543
2.1.6.7.4.4.2.2.1.161. outbound_mailbox_8.WRITE_DATA . . . 543
2.1.6.7.4.4.2.2.1.162. outbound_mailbox_8.READ_DATA . . . 543
2.1.6.7.4.4.2.2.1.163. outbound_mailbox_8.STATUS . . . 543
2.1.6.7.4.4.2.2.1.164. outbound_mailbox_8.ERROR_FLAGS . . . 543
2.1.6.7.4.4.2.2.1.165. outbound_mailbox_8.WIRQT . . . 543
2.1.6.7.4.4.2.2.1.166. outbound_mailbox_8.RIRQT . . . 544
2.1.6.7.4.4.2.2.1.167. outbound_mailbox_8.IRQS . . . 544
2.1.6.7.4.4.2.2.1.168. outbound_mailbox_8.IRQEN . . . 544
2.1.6.7.4.4.2.2.1.169. outbound_mailbox_8.IRQP . . . 544
2.1.6.7.4.4.2.2.1.170. outbound_mailbox_8.CTRL . . . 545

2.1.6.7.4.4.2.2.1.171. inbound_mailbox_8.WRITE_DATA . . . 545
2.1.6.7.4.4.2.2.1.172. inbound_mailbox_8.READ_DATA . . . 545
2.1.6.7.4.4.2.2.1.173. inbound_mailbox_8.STATUS . . . 545
2.1.6.7.4.4.2.2.1.174. inbound_mailbox_8.ERROR_FLAGS . . . 545
2.1.6.7.4.4.2.2.1.175. inbound_mailbox_8.WIRQT . . . 545
2.1.6.7.4.4.2.2.1.176. inbound_mailbox_8.RIRQT . . . 546
2.1.6.7.4.4.2.2.1.177. inbound_mailbox_8.IRQS . . . 546
2.1.6.7.4.4.2.2.1.178. inbound_mailbox_8.IRQEN . . . 546
2.1.6.7.4.4.2.2.1.179. inbound_mailbox_8.IRQP . . . 546
2.1.6.7.4.4.2.2.1.180. inbound_mailbox_8.CTRL . . . 547
2.1.6.7.4.4.2.2.1.181. outbound_mailbox_9.WRITE_DATA . . . 547
2.1.6.7.4.4.2.2.1.182. outbound_mailbox_9.READ_DATA . . . 547
2.1.6.7.4.4.2.2.1.183. outbound_mailbox_9.STATUS . . . 547
2.1.6.7.4.4.2.2.1.184. outbound_mailbox_9.ERROR_FLAGS . . . 547
2.1.6.7.4.4.2.2.1.185. outbound_mailbox_9.WIRQT . . . 547
2.1.6.7.4.4.2.2.1.186. outbound_mailbox_9.RIRQT . . . 548
2.1.6.7.4.4.2.2.1.187. outbound_mailbox_9.IRQS . . . 548
2.1.6.7.4.4.2.2.1.188. outbound_mailbox_9.IRQEN . . . 548
2.1.6.7.4.4.2.2.1.189. outbound_mailbox_9.IRQP . . . 548
2.1.6.7.4.4.2.2.1.190. outbound_mailbox_9.CTRL . . . 549
2.1.6.7.4.4.2.2.1.191. inbound_mailbox_9.WRITE_DATA . . . 549
2.1.6.7.4.4.2.2.1.192. inbound_mailbox_9.READ_DATA . . . 549
2.1.6.7.4.4.2.2.1.193. inbound_mailbox_9.STATUS . . . 549
2.1.6.7.4.4.2.2.1.194. inbound_mailbox_9.ERROR_FLAGS . . . 549
2.1.6.7.4.4.2.2.1.195. inbound_mailbox_9.WIRQT . . . 549
2.1.6.7.4.4.2.2.1.196. inbound_mailbox_9.RIRQT . . . 550
2.1.6.7.4.4.2.2.1.197. inbound_mailbox_9.IRQS . . . 550
2.1.6.7.4.4.2.2.1.198. inbound_mailbox_9.IRQEN . . . 550
2.1.6.7.4.4.2.2.1.199. inbound_mailbox_9.IRQP . . . 550
2.1.6.7.4.4.2.2.1.200. inbound_mailbox_9.CTRL . . . 551
2.1.6.7.4.4.2.2.1.201. outbound_mailbox_10.WRITE_DATA . . . 551
2.1.6.7.4.4.2.2.1.202. outbound_mailbox_10.READ_DATA . . . 551
2.1.6.7.4.4.2.2.1.203. outbound_mailbox_10.STATUS . . . 551
2.1.6.7.4.4.2.2.1.204. outbound_mailbox_10.ERROR_FLAGS . . . 551
2.1.6.7.4.4.2.2.1.205. outbound_mailbox_10.WIRQT . . . 551
2.1.6.7.4.4.2.2.1.206. outbound_mailbox_10.RIRQT . . . 552
2.1.6.7.4.4.2.2.1.207. outbound_mailbox_10.IRQS . . . 552
2.1.6.7.4.4.2.2.1.208. outbound_mailbox_10.IRQEN . . . 552
2.1.6.7.4.4.2.2.1.209. outbound_mailbox_10.IRQP . . . 552
2.1.6.7.4.4.2.2.1.210. outbound_mailbox_10.CTRL . . . 553
2.1.6.7.4.4.2.2.1.211. inbound_mailbox_10.WRITE_DATA . . . 553
2.1.6.7.4.4.2.2.1.212. inbound_mailbox_10.READ_DATA . . . 553
2.1.6.7.4.4.2.2.1.213. inbound_mailbox_10.STATUS . . . 553
2.1.6.7.4.4.2.2.1.214. inbound_mailbox_10.ERROR_FLAGS . . . 553

2.1.6.7.4.4.2.2.1.215. inbound_mailbox_10.WIRQT . . . 553
2.1.6.7.4.4.2.2.1.216. inbound_mailbox_10.RIRQT . . . 554
2.1.6.7.4.4.2.2.1.217. inbound_mailbox_10.IRQS . . . 554
2.1.6.7.4.4.2.2.1.218. inbound_mailbox_10.IRQEN . . . 554
2.1.6.7.4.4.2.2.1.219. inbound_mailbox_10.IRQP . . . 554
2.1.6.7.4.4.2.2.1.220. inbound_mailbox_10.CTRL . . . 555
2.1.6.7.4.4.2.2.1.221. outbound_mailbox_11.WRITE_DATA . . . 555
2.1.6.7.4.4.2.2.1.222. outbound_mailbox_11.READ_DATA . . . 555
2.1.6.7.4.4.2.2.1.223. outbound_mailbox_11.STATUS . . . 555
2.1.6.7.4.4.2.2.1.224. outbound_mailbox_11.ERROR_FLAGS . . . 555
2.1.6.7.4.4.2.2.1.225. outbound_mailbox_11.WIRQT . . . 555
2.1.6.7.4.4.2.2.1.226. outbound_mailbox_11.RIRQT . . . 556
2.1.6.7.4.4.2.2.1.227. outbound_mailbox_11.IRQS . . . 556
2.1.6.7.4.4.2.2.1.228. outbound_mailbox_11.IRQEN . . . 556
2.1.6.7.4.4.2.2.1.229. outbound_mailbox_11.IRQP . . . 556
2.1.6.7.4.4.2.2.1.230. outbound_mailbox_11.CTRL . . . 557
2.1.6.7.4.4.2.2.1.231. inbound_mailbox_11.WRITE_DATA . . . 557
2.1.6.7.4.4.2.2.1.232. inbound_mailbox_11.READ_DATA . . . 557
2.1.6.7.4.4.2.2.1.233. inbound_mailbox_11.STATUS . . . 557
2.1.6.7.4.4.2.2.1.234. inbound_mailbox_11.ERROR_FLAGS . . . 557
2.1.6.7.4.4.2.2.1.235. inbound_mailbox_11.WIRQT . . . 557
2.1.6.7.4.4.2.2.1.236. inbound_mailbox_11.RIRQT . . . 558
2.1.6.7.4.4.2.2.1.237. inbound_mailbox_11.IRQS . . . 558
2.1.6.7.4.4.2.2.1.238. inbound_mailbox_11.IRQEN . . . 558
2.1.6.7.4.4.2.2.1.239. inbound_mailbox_11.IRQP . . . 558
2.1.6.7.4.4.2.2.1.240. inbound_mailbox_11.CTRL . . . 559
2.1.6.7.4.4.2.2.1.241. outbound_mailbox_12.WRITE_DATA . . . 559
2.1.6.7.4.4.2.2.1.242. outbound_mailbox_12.READ_DATA . . . 559
2.1.6.7.4.4.2.2.1.243. outbound_mailbox_12.STATUS . . . 559
2.1.6.7.4.4.2.2.1.244. outbound_mailbox_12.ERROR_FLAGS . . . 559
2.1.6.7.4.4.2.2.1.245. outbound_mailbox_12.WIRQT . . . 559
2.1.6.7.4.4.2.2.1.246. outbound_mailbox_12.RIRQT . . . 560
2.1.6.7.4.4.2.2.1.247. outbound_mailbox_12.IRQS . . . 560
2.1.6.7.4.4.2.2.1.248. outbound_mailbox_12.IRQEN . . . 560
2.1.6.7.4.4.2.2.1.249. outbound_mailbox_12.IRQP . . . 560
2.1.6.7.4.4.2.2.1.250. outbound_mailbox_12.CTRL . . . 561
2.1.6.7.4.4.2.2.1.251. inbound_mailbox_12.WRITE_DATA . . . 561
2.1.6.7.4.4.2.2.1.252. inbound_mailbox_12.READ_DATA . . . 561
2.1.6.7.4.4.2.2.1.253. inbound_mailbox_12.STATUS . . . 561
2.1.6.7.4.4.2.2.1.254. inbound_mailbox_12.ERROR_FLAGS . . . 561
2.1.6.7.4.4.2.2.1.255. inbound_mailbox_12.WIRQT . . . 561
2.1.6.7.4.4.2.2.1.256. inbound_mailbox_12.RIRQT . . . 562
2.1.6.7.4.4.2.2.1.257. inbound_mailbox_12.IRQS . . . 562
2.1.6.7.4.4.2.2.1.258. inbound_mailbox_12.IRQEN . . . 562

2.1.6.7.4.4.2.2.1.259. inbound_mailbox_12.IRQP . . . 562
2.1.6.7.4.4.2.2.1.260. inbound_mailbox_12.CTRL . . . 563
2.1.6.7.4.4.2.2.1.261. outbound_mailbox_13.WRITE_DATA . . . 563
2.1.6.7.4.4.2.2.1.262. outbound_mailbox_13.READ_DATA . . . 563
2.1.6.7.4.4.2.2.1.263. outbound_mailbox_13.STATUS . . . 563
2.1.6.7.4.4.2.2.1.264. outbound_mailbox_13.ERROR_FLAGS . . . 563
2.1.6.7.4.4.2.2.1.265. outbound_mailbox_13.WIRQT . . . 563
2.1.6.7.4.4.2.2.1.266. outbound_mailbox_13.RIRQT . . . 564
2.1.6.7.4.4.2.2.1.267. outbound_mailbox_13.IRQS . . . 564
2.1.6.7.4.4.2.2.1.268. outbound_mailbox_13.IRQEN . . . 564
2.1.6.7.4.4.2.2.1.269. outbound_mailbox_13.IRQP . . . 564
2.1.6.7.4.4.2.2.1.270. outbound_mailbox_13.CTRL . . . 565
2.1.6.7.4.4.2.2.1.271. inbound_mailbox_13.WRITE_DATA . . . 565
2.1.6.7.4.4.2.2.1.272. inbound_mailbox_13.READ_DATA . . . 565
2.1.6.7.4.4.2.2.1.273. inbound_mailbox_13.STATUS . . . 565
2.1.6.7.4.4.2.2.1.274. inbound_mailbox_13.ERROR_FLAGS . . . 565
2.1.6.7.4.4.2.2.1.275. inbound_mailbox_13.WIRQT . . . 565
2.1.6.7.4.4.2.2.1.276. inbound_mailbox_13.RIRQT . . . 566
2.1.6.7.4.4.2.2.1.277. inbound_mailbox_13.IRQS . . . 566
2.1.6.7.4.4.2.2.1.278. inbound_mailbox_13.IRQEN . . . 566
2.1.6.7.4.4.2.2.1.279. inbound_mailbox_13.IRQP . . . 566
2.1.6.7.4.4.2.2.1.280. inbound_mailbox_13.CTRL . . . 567
2.1.6.7.4.4.2.2.1.281. outbound_mailbox_14.WRITE_DATA . . . 567
2.1.6.7.4.4.2.2.1.282. outbound_mailbox_14.READ_DATA . . . 567
2.1.6.7.4.4.2.2.1.283. outbound_mailbox_14.STATUS . . . 567
2.1.6.7.4.4.2.2.1.284. outbound_mailbox_14.ERROR_FLAGS . . . 567
2.1.6.7.4.4.2.2.1.285. outbound_mailbox_14.WIRQT . . . 567
2.1.6.7.4.4.2.2.1.286. outbound_mailbox_14.RIRQT . . . 568
2.1.6.7.4.4.2.2.1.287. outbound_mailbox_14.IRQS . . . 568
2.1.6.7.4.4.2.2.1.288. outbound_mailbox_14.IRQEN . . . 568
2.1.6.7.4.4.2.2.1.289. outbound_mailbox_14.IRQP . . . 568
2.1.6.7.4.4.2.2.1.290. outbound_mailbox_14.CTRL . . . 569
2.1.6.7.4.4.2.2.1.291. inbound_mailbox_14.WRITE_DATA . . . 569
2.1.6.7.4.4.2.2.1.292. inbound_mailbox_14.READ_DATA . . . 569
2.1.6.7.4.4.2.2.1.293. inbound_mailbox_14.STATUS . . . 569
2.1.6.7.4.4.2.2.1.294. inbound_mailbox_14.ERROR_FLAGS . . . 569
2.1.6.7.4.4.2.2.1.295. inbound_mailbox_14.WIRQT . . . 569
2.1.6.7.4.4.2.2.1.296. inbound_mailbox_14.RIRQT . . . 570
2.1.6.7.4.4.2.2.1.297. inbound_mailbox_14.IRQS . . . 570
2.1.6.7.4.4.2.2.1.298. inbound_mailbox_14.IRQEN . . . 570
2.1.6.7.4.4.2.2.1.299. inbound_mailbox_14.IRQP . . . 570
2.1.6.7.4.4.2.2.1.300. inbound_mailbox_14.CTRL . . . 571
2.1.6.7.4.4.2.2.1.301. outbound_mailbox_15.WRITE_DATA . . . 571
2.1.6.7.4.4.2.2.1.302. outbound_mailbox_15.READ_DATA . . . 571

2.1.6.7.4.4.2.2.1.303. outbound_mailbox_15.STATUS . . . 571
2.1.6.7.4.4.2.2.1.304. outbound_mailbox_15.ERROR_FLAGS . . . 571
2.1.6.7.4.4.2.2.1.305. outbound_mailbox_15.WIRQT . . . 571
2.1.6.7.4.4.2.2.1.306. outbound_mailbox_15.RIRQT . . . 572
2.1.6.7.4.4.2.2.1.307. outbound_mailbox_15.IRQS . . . 572
2.1.6.7.4.4.2.2.1.308. outbound_mailbox_15.IRQEN . . . 572
2.1.6.7.4.4.2.2.1.309. outbound_mailbox_15.IRQP . . . 572
2.1.6.7.4.4.2.2.1.310. outbound_mailbox_15.CTRL . . . 573
2.1.6.7.4.4.2.2.1.311. inbound_mailbox_15.WRITE_DATA . . . 573
2.1.6.7.4.4.2.2.1.312. inbound_mailbox_15.READ_DATA . . . 573
2.1.6.7.4.4.2.2.1.313. inbound_mailbox_15.STATUS . . . 573
2.1.6.7.4.4.2.2.1.314. inbound_mailbox_15.ERROR_FLAGS . . . 573
2.1.6.7.4.4.2.2.1.315. inbound_mailbox_15.WIRQT . . . 573
2.1.6.7.4.4.2.2.1.316. inbound_mailbox_15.RIRQT . . . 574
2.1.6.7.4.4.2.2.1.317. inbound_mailbox_15.IRQS . . . 574
2.1.6.7.4.4.2.2.1.318. inbound_mailbox_15.IRQEN . . . 574
2.1.6.7.4.4.2.2.1.319. inbound_mailbox_15.IRQP . . . 574
2.1.6.7.4.4.2.2.1.320. inbound_mailbox_15.CTRL . . . 575
2.1.6.7.4.4.2.2.1.321. outbound_mailbox_16.WRITE_DATA . . . 575
2.1.6.7.4.4.2.2.1.322. outbound_mailbox_16.READ_DATA . . . 575
2.1.6.7.4.4.2.2.1.323. outbound_mailbox_16.STATUS . . . 575
2.1.6.7.4.4.2.2.1.324. outbound_mailbox_16.ERROR_FLAGS . . . 575
2.1.6.7.4.4.2.2.1.325. outbound_mailbox_16.WIRQT . . . 575
2.1.6.7.4.4.2.2.1.326. outbound_mailbox_16.RIRQT . . . 576
2.1.6.7.4.4.2.2.1.327. outbound_mailbox_16.IRQS . . . 576
2.1.6.7.4.4.2.2.1.328. outbound_mailbox_16.IRQEN . . . 576
2.1.6.7.4.4.2.2.1.329. outbound_mailbox_16.IRQP . . . 576
2.1.6.7.4.4.2.2.1.330. outbound_mailbox_16.CTRL . . . 577
2.1.6.7.4.4.2.2.1.331. inbound_mailbox_16.WRITE_DATA . . . 577
2.1.6.7.4.4.2.2.1.332. inbound_mailbox_16.READ_DATA . . . 577
2.1.6.7.4.4.2.2.1.333. inbound_mailbox_16.STATUS . . . 577
2.1.6.7.4.4.2.2.1.334. inbound_mailbox_16.ERROR_FLAGS . . . 577
2.1.6.7.4.4.2.2.1.335. inbound_mailbox_16.WIRQT . . . 577
2.1.6.7.4.4.2.2.1.336. inbound_mailbox_16.RIRQT . . . 578
2.1.6.7.4.4.2.2.1.337. inbound_mailbox_16.IRQS . . . 578
2.1.6.7.4.4.2.2.1.338. inbound_mailbox_16.IRQEN . . . 578
2.1.6.7.4.4.2.2.1.339. inbound_mailbox_16.IRQP . . . 578
2.1.6.7.4.4.2.2.1.340. inbound_mailbox_16.CTRL . . . 579
2.1.6.7.4.4.2.2.1.341. outbound_mailbox_17.WRITE_DATA . . . 579
2.1.6.7.4.4.2.2.1.342. outbound_mailbox_17.READ_DATA . . . 579
2.1.6.7.4.4.2.2.1.343. outbound_mailbox_17.STATUS . . . 579
2.1.6.7.4.4.2.2.1.344. outbound_mailbox_17.ERROR_FLAGS . . . 579
2.1.6.7.4.4.2.2.1.345. outbound_mailbox_17.WIRQT . . . 579
2.1.6.7.4.4.2.2.1.346. outbound_mailbox_17.RIRQT . . . 580

2.1.6.7.4.4.2.2.1.347. outbound_mailbox_17.IRQS . . . 580
2.1.6.7.4.4.2.2.1.348. outbound_mailbox_17.IRQEN . . . 580
2.1.6.7.4.4.2.2.1.349. outbound_mailbox_17.IRQP . . . 580
2.1.6.7.4.4.2.2.1.350. outbound_mailbox_17.CTRL . . . 581
2.1.6.7.4.4.2.2.1.351. inbound_mailbox_17.WRITE_DATA . . . 581
2.1.6.7.4.4.2.2.1.352. inbound_mailbox_17.READ_DATA . . . 581
2.1.6.7.4.4.2.2.1.353. inbound_mailbox_17.STATUS . . . 581
2.1.6.7.4.4.2.2.1.354. inbound_mailbox_17.ERROR_FLAGS . . . 581
2.1.6.7.4.4.2.2.1.355. inbound_mailbox_17.WIRQT . . . 581
2.1.6.7.4.4.2.2.1.356. inbound_mailbox_17.RIRQT . . . 582
2.1.6.7.4.4.2.2.1.357. inbound_mailbox_17.IRQS . . . 582
2.1.6.7.4.4.2.2.1.358. inbound_mailbox_17.IRQEN . . . 582
2.1.6.7.4.4.2.2.1.359. inbound_mailbox_17.IRQP . . . 582
2.1.6.7.4.4.2.2.1.360. inbound_mailbox_17.CTRL . . . 583
2.1.6.7.4.4.2.2.1.361. outbound_mailbox_18.WRITE_DATA . . . 583
2.1.6.7.4.4.2.2.1.362. outbound_mailbox_18.READ_DATA . . . 583
2.1.6.7.4.4.2.2.1.363. outbound_mailbox_18.STATUS . . . 583
2.1.6.7.4.4.2.2.1.364. outbound_mailbox_18.ERROR_FLAGS . . . 583
2.1.6.7.4.4.2.2.1.365. outbound_mailbox_18.WIRQT . . . 583
2.1.6.7.4.4.2.2.1.366. outbound_mailbox_18.RIRQT . . . 584
2.1.6.7.4.4.2.2.1.367. outbound_mailbox_18.IRQS . . . 584
2.1.6.7.4.4.2.2.1.368. outbound_mailbox_18.IRQEN . . . 584
2.1.6.7.4.4.2.2.1.369. outbound_mailbox_18.IRQP . . . 584
2.1.6.7.4.4.2.2.1.370. outbound_mailbox_18.CTRL . . . 585
2.1.6.7.4.4.2.2.1.371. inbound_mailbox_18.WRITE_DATA . . . 585
2.1.6.7.4.4.2.2.1.372. inbound_mailbox_18.READ_DATA . . . 585
2.1.6.7.4.4.2.2.1.373. inbound_mailbox_18.STATUS . . . 585
2.1.6.7.4.4.2.2.1.374. inbound_mailbox_18.ERROR_FLAGS . . . 585
2.1.6.7.4.4.2.2.1.375. inbound_mailbox_18.WIRQT . . . 585
2.1.6.7.4.4.2.2.1.376. inbound_mailbox_18.RIRQT . . . 586
2.1.6.7.4.4.2.2.1.377. inbound_mailbox_18.IRQS . . . 586
2.1.6.7.4.4.2.2.1.378. inbound_mailbox_18.IRQEN . . . 586
2.1.6.7.4.4.2.2.1.379. inbound_mailbox_18.IRQP . . . 586
2.1.6.7.4.4.2.2.1.380. inbound_mailbox_18.CTRL . . . 587
2.1.6.7.4.4.2.2.1.381. outbound_mailbox_19.WRITE_DATA . . . 587
2.1.6.7.4.4.2.2.1.382. outbound_mailbox_19.READ_DATA . . . 587
2.1.6.7.4.4.2.2.1.383. outbound_mailbox_19.STATUS . . . 587
2.1.6.7.4.4.2.2.1.384. outbound_mailbox_19.ERROR_FLAGS . . . 587
2.1.6.7.4.4.2.2.1.385. outbound_mailbox_19.WIRQT . . . 587
2.1.6.7.4.4.2.2.1.386. outbound_mailbox_19.RIRQT . . . 588
2.1.6.7.4.4.2.2.1.387. outbound_mailbox_19.IRQS . . . 588
2.1.6.7.4.4.2.2.1.388. outbound_mailbox_19.IRQEN . . . 588
2.1.6.7.4.4.2.2.1.389. outbound_mailbox_19.IRQP . . . 588
2.1.6.7.4.4.2.2.1.390. outbound_mailbox_19.CTRL . . . 589

2.1.6.7.4.4.2.2.1.391. inbound_mailbox_19.WRITE_DATA . . . 589
2.1.6.7.4.4.2.2.1.392. inbound_mailbox_19.READ_DATA . . . 589
2.1.6.7.4.4.2.2.1.393. inbound_mailbox_19.STATUS . . . 589
2.1.6.7.4.4.2.2.1.394. inbound_mailbox_19.ERROR_FLAGS . . . 589
2.1.6.7.4.4.2.2.1.395. inbound_mailbox_19.WIRQT . . . 589
2.1.6.7.4.4.2.2.1.396. inbound_mailbox_19.RIRQT . . . 590
2.1.6.7.4.4.2.2.1.397. inbound_mailbox_19.IRQS . . . 590
2.1.6.7.4.4.2.2.1.398. inbound_mailbox_19.IRQEN . . . 590
2.1.6.7.4.4.2.2.1.399. inbound_mailbox_19.IRQP . . . 590
2.1.6.7.4.4.2.2.1.400. inbound_mailbox_19.CTRL . . . 591
2.1.6.7.4.4.2.2.1.401. outbound_mailbox_20.WRITE_DATA . . . 591
2.1.6.7.4.4.2.2.1.402. outbound_mailbox_20.READ_DATA . . . 591
2.1.6.7.4.4.2.2.1.403. outbound_mailbox_20.STATUS . . . 591
2.1.6.7.4.4.2.2.1.404. outbound_mailbox_20.ERROR_FLAGS . . . 591
2.1.6.7.4.4.2.2.1.405. outbound_mailbox_20.WIRQT . . . 591
2.1.6.7.4.4.2.2.1.406. outbound_mailbox_20.RIRQT . . . 592
2.1.6.7.4.4.2.2.1.407. outbound_mailbox_20.IRQS . . . 592
2.1.6.7.4.4.2.2.1.408. outbound_mailbox_20.IRQEN . . . 592
2.1.6.7.4.4.2.2.1.409. outbound_mailbox_20.IRQP . . . 592
2.1.6.7.4.4.2.2.1.410. outbound_mailbox_20.CTRL . . . 593
2.1.6.7.4.4.2.2.1.411. inbound_mailbox_20.WRITE_DATA . . . 593
2.1.6.7.4.4.2.2.1.412. inbound_mailbox_20.READ_DATA . . . 593
2.1.6.7.4.4.2.2.1.413. inbound_mailbox_20.STATUS . . . 593
2.1.6.7.4.4.2.2.1.414. inbound_mailbox_20.ERROR_FLAGS . . . 593
2.1.6.7.4.4.2.2.1.415. inbound_mailbox_20.WIRQT . . . 593
2.1.6.7.4.4.2.2.1.416. inbound_mailbox_20.RIRQT . . . 594
2.1.6.7.4.4.2.2.1.417. inbound_mailbox_20.IRQS . . . 594
2.1.6.7.4.4.2.2.1.418. inbound_mailbox_20.IRQEN . . . 594
2.1.6.7.4.4.2.2.1.419. inbound_mailbox_20.IRQP . . . 594
2.1.6.7.4.4.2.2.1.420. inbound_mailbox_20.CTRL . . . 595
2.1.6.7.4.4.2.2.1.421. outbound_mailbox_21.WRITE_DATA . . . 595
2.1.6.7.4.4.2.2.1.422. outbound_mailbox_21.READ_DATA . . . 595
2.1.6.7.4.4.2.2.1.423. outbound_mailbox_21.STATUS . . . 595
2.1.6.7.4.4.2.2.1.424. outbound_mailbox_21.ERROR_FLAGS . . . 595
2.1.6.7.4.4.2.2.1.425. outbound_mailbox_21.WIRQT . . . 595
2.1.6.7.4.4.2.2.1.426. outbound_mailbox_21.RIRQT . . . 596
2.1.6.7.4.4.2.2.1.427. outbound_mailbox_21.IRQS . . . 596
2.1.6.7.4.4.2.2.1.428. outbound_mailbox_21.IRQEN . . . 596
2.1.6.7.4.4.2.2.1.429. outbound_mailbox_21.IRQP . . . 596
2.1.6.7.4.4.2.2.1.430. outbound_mailbox_21.CTRL . . . 597
2.1.6.7.4.4.2.2.1.431. inbound_mailbox_21.WRITE_DATA . . . 597
2.1.6.7.4.4.2.2.1.432. inbound_mailbox_21.READ_DATA . . . 597
2.1.6.7.4.4.2.2.1.433. inbound_mailbox_21.STATUS . . . 597
2.1.6.7.4.4.2.2.1.434. inbound_mailbox_21.ERROR_FLAGS . . . 597

2.1.6.7.4.4.2.2.1.435. inbound_mailbox_21.WIRQT . . . 597
2.1.6.7.4.4.2.2.1.436. inbound_mailbox_21.RIRQT . . . 598
2.1.6.7.4.4.2.2.1.437. inbound_mailbox_21.IRQS . . . 598
2.1.6.7.4.4.2.2.1.438. inbound_mailbox_21.IRQEN . . . 598
2.1.6.7.4.4.2.2.1.439. inbound_mailbox_21.IRQP . . . 598
2.1.6.7.4.4.2.2.1.440. inbound_mailbox_21.CTRL . . . 599
2.1.6.7.4.4.2.2.1.441. outbound_mailbox_22.WRITE_DATA . . . 599
2.1.6.7.4.4.2.2.1.442. outbound_mailbox_22.READ_DATA . . . 599
2.1.6.7.4.4.2.2.1.443. outbound_mailbox_22.STATUS . . . 599
2.1.6.7.4.4.2.2.1.444. outbound_mailbox_22.ERROR_FLAGS . . . 599
2.1.6.7.4.4.2.2.1.445. outbound_mailbox_22.WIRQT . . . 599
2.1.6.7.4.4.2.2.1.446. outbound_mailbox_22.RIRQT . . . 600
2.1.6.7.4.4.2.2.1.447. outbound_mailbox_22.IRQS . . . 600
2.1.6.7.4.4.2.2.1.448. outbound_mailbox_22.IRQEN . . . 600
2.1.6.7.4.4.2.2.1.449. outbound_mailbox_22.IRQP . . . 600
2.1.6.7.4.4.2.2.1.450. outbound_mailbox_22.CTRL . . . 601
2.1.6.7.4.4.2.2.1.451. inbound_mailbox_22.WRITE_DATA . . . 601
2.1.6.7.4.4.2.2.1.452. inbound_mailbox_22.READ_DATA . . . 601
2.1.6.7.4.4.2.2.1.453. inbound_mailbox_22.STATUS . . . 601
2.1.6.7.4.4.2.2.1.454. inbound_mailbox_22.ERROR_FLAGS . . . 601
2.1.6.7.4.4.2.2.1.455. inbound_mailbox_22.WIRQT . . . 601
2.1.6.7.4.4.2.2.1.456. inbound_mailbox_22.RIRQT . . . 602
2.1.6.7.4.4.2.2.1.457. inbound_mailbox_22.IRQS . . . 602
2.1.6.7.4.4.2.2.1.458. inbound_mailbox_22.IRQEN . . . 602
2.1.6.7.4.4.2.2.1.459. inbound_mailbox_22.IRQP . . . 602
2.1.6.7.4.4.2.2.1.460. inbound_mailbox_22.CTRL . . . 603
2.1.6.7.4.4.2.2.1.461. outbound_mailbox_23.WRITE_DATA . . . 603
2.1.6.7.4.4.2.2.1.462. outbound_mailbox_23.READ_DATA . . . 603
2.1.6.7.4.4.2.2.1.463. outbound_mailbox_23.STATUS . . . 603
2.1.6.7.4.4.2.2.1.464. outbound_mailbox_23.ERROR_FLAGS . . . 603
2.1.6.7.4.4.2.2.1.465. outbound_mailbox_23.WIRQT . . . 603
2.1.6.7.4.4.2.2.1.466. outbound_mailbox_23.RIRQT . . . 604
2.1.6.7.4.4.2.2.1.467. outbound_mailbox_23.IRQS . . . 604
2.1.6.7.4.4.2.2.1.468. outbound_mailbox_23.IRQEN . . . 604
2.1.6.7.4.4.2.2.1.469. outbound_mailbox_23.IRQP . . . 604
2.1.6.7.4.4.2.2.1.470. outbound_mailbox_23.CTRL . . . 605
2.1.6.7.4.4.2.2.1.471. inbound_mailbox_23.WRITE_DATA . . . 605
2.1.6.7.4.4.2.2.1.472. inbound_mailbox_23.READ_DATA . . . 605
2.1.6.7.4.4.2.2.1.473. inbound_mailbox_23.STATUS . . . 605
2.1.6.7.4.4.2.2.1.474. inbound_mailbox_23.ERROR_FLAGS . . . 605
2.1.6.7.4.4.2.2.1.475. inbound_mailbox_23.WIRQT . . . 605
2.1.6.7.4.4.2.2.1.476. inbound_mailbox_23.RIRQT . . . 606
2.1.6.7.4.4.2.2.1.477. inbound_mailbox_23.IRQS . . . 606
2.1.6.7.4.4.2.2.1.478. inbound_mailbox_23.IRQEN . . . 606

2.1.6.7.4.4.2.2.1.479. inbound_mailbox_23.IRQP . . . 606
2.1.6.7.4.4.2.2.1.480. inbound_mailbox_23.CTRL . . . 607
2.1.6.7.4.4.2.2.1.481. outbound_mailbox_24.WRITE_DATA . . . 607
2.1.6.7.4.4.2.2.1.482. outbound_mailbox_24.READ_DATA . . . 607
2.1.6.7.4.4.2.2.1.483. outbound_mailbox_24.STATUS . . . 607
2.1.6.7.4.4.2.2.1.484. outbound_mailbox_24.ERROR_FLAGS . . . 607
2.1.6.7.4.4.2.2.1.485. outbound_mailbox_24.WIRQT . . . 607
2.1.6.7.4.4.2.2.1.486. outbound_mailbox_24.RIRQT . . . 608
2.1.6.7.4.4.2.2.1.487. outbound_mailbox_24.IRQS . . . 608
2.1.6.7.4.4.2.2.1.488. outbound_mailbox_24.IRQEN . . . 608
2.1.6.7.4.4.2.2.1.489. outbound_mailbox_24.IRQP . . . 608
2.1.6.7.4.4.2.2.1.490. outbound_mailbox_24.CTRL . . . 609
2.1.6.7.4.4.2.2.1.491. inbound_mailbox_24.WRITE_DATA . . . 609
2.1.6.7.4.4.2.2.1.492. inbound_mailbox_24.READ_DATA . . . 609
2.1.6.7.4.4.2.2.1.493. inbound_mailbox_24.STATUS . . . 609
2.1.6.7.4.4.2.2.1.494. inbound_mailbox_24.ERROR_FLAGS . . . 609
2.1.6.7.4.4.2.2.1.495. inbound_mailbox_24.WIRQT . . . 609
2.1.6.7.4.4.2.2.1.496. inbound_mailbox_24.RIRQT . . . 610
2.1.6.7.4.4.2.2.1.497. inbound_mailbox_24.IRQS . . . 610
2.1.6.7.4.4.2.2.1.498. inbound_mailbox_24.IRQEN . . . 610
2.1.6.7.4.4.2.2.1.499. inbound_mailbox_24.IRQP . . . 610
2.1.6.7.4.4.2.2.1.500. inbound_mailbox_24.CTRL . . . 611
2.1.6.7.4.4.2.2.1.501. outbound_mailbox_25.WRITE_DATA . . . 611
2.1.6.7.4.4.2.2.1.502. outbound_mailbox_25.READ_DATA . . . 611
2.1.6.7.4.4.2.2.1.503. outbound_mailbox_25.STATUS . . . 611
2.1.6.7.4.4.2.2.1.504. outbound_mailbox_25.ERROR_FLAGS . . . 611
2.1.6.7.4.4.2.2.1.505. outbound_mailbox_25.WIRQT . . . 611
2.1.6.7.4.4.2.2.1.506. outbound_mailbox_25.RIRQT . . . 612
2.1.6.7.4.4.2.2.1.507. outbound_mailbox_25.IRQS . . . 612
2.1.6.7.4.4.2.2.1.508. outbound_mailbox_25.IRQEN . . . 612
2.1.6.7.4.4.2.2.1.509. outbound_mailbox_25.IRQP . . . 612
2.1.6.7.4.4.2.2.1.510. outbound_mailbox_25.CTRL . . . 613
2.1.6.7.4.4.2.2.1.511. inbound_mailbox_25.WRITE_DATA . . . 613
2.1.6.7.4.4.2.2.1.512. inbound_mailbox_25.READ_DATA . . . 613
2.1.6.7.4.4.2.2.1.513. inbound_mailbox_25.STATUS . . . 613
2.1.6.7.4.4.2.2.1.514. inbound_mailbox_25.ERROR_FLAGS . . . 613
2.1.6.7.4.4.2.2.1.515. inbound_mailbox_25.WIRQT . . . 613
2.1.6.7.4.4.2.2.1.516. inbound_mailbox_25.RIRQT . . . 614
2.1.6.7.4.4.2.2.1.517. inbound_mailbox_25.IRQS . . . 614
2.1.6.7.4.4.2.2.1.518. inbound_mailbox_25.IRQEN . . . 614
2.1.6.7.4.4.2.2.1.519. inbound_mailbox_25.IRQP . . . 614
2.1.6.7.4.4.2.2.1.520. inbound_mailbox_25.CTRL . . . 615
2.1.6.7.4.4.2.2.1.521. outbound_mailbox_26.WRITE_DATA . . . 615
2.1.6.7.4.4.2.2.1.522. outbound_mailbox_26.READ_DATA . . . 615

2.1.6.7.4.4.2.2.1.523. outbound_mailbox_26.STATUS . . . 615
2.1.6.7.4.4.2.2.1.524. outbound_mailbox_26.ERROR_FLAGS . . . 615
2.1.6.7.4.4.2.2.1.525. outbound_mailbox_26.WIRQT . . . 615
2.1.6.7.4.4.2.2.1.526. outbound_mailbox_26.RIRQT . . . 616
2.1.6.7.4.4.2.2.1.527. outbound_mailbox_26.IRQS . . . 616
2.1.6.7.4.4.2.2.1.528. outbound_mailbox_26.IRQEN . . . 616
2.1.6.7.4.4.2.2.1.529. outbound_mailbox_26.IRQP . . . 616
2.1.6.7.4.4.2.2.1.530. outbound_mailbox_26.CTRL . . . 617
2.1.6.7.4.4.2.2.1.531. inbound_mailbox_26.WRITE_DATA . . . 617
2.1.6.7.4.4.2.2.1.532. inbound_mailbox_26.READ_DATA . . . 617
2.1.6.7.4.4.2.2.1.533. inbound_mailbox_26.STATUS . . . 617
2.1.6.7.4.4.2.2.1.534. inbound_mailbox_26.ERROR_FLAGS . . . 617
2.1.6.7.4.4.2.2.1.535. inbound_mailbox_26.WIRQT . . . 617
2.1.6.7.4.4.2.2.1.536. inbound_mailbox_26.RIRQT . . . 618
2.1.6.7.4.4.2.2.1.537. inbound_mailbox_26.IRQS . . . 618
2.1.6.7.4.4.2.2.1.538. inbound_mailbox_26.IRQEN . . . 618
2.1.6.7.4.4.2.2.1.539. inbound_mailbox_26.IRQP . . . 618
2.1.6.7.4.4.2.2.1.540. inbound_mailbox_26.CTRL . . . 619
2.1.6.7.4.4.2.2.1.541. outbound_mailbox_27.WRITE_DATA . . . 619
2.1.6.7.4.4.2.2.1.542. outbound_mailbox_27.READ_DATA . . . 619
2.1.6.7.4.4.2.2.1.543. outbound_mailbox_27.STATUS . . . 619
2.1.6.7.4.4.2.2.1.544. outbound_mailbox_27.ERROR_FLAGS . . . 619
2.1.6.7.4.4.2.2.1.545. outbound_mailbox_27.WIRQT . . . 619
2.1.6.7.4.4.2.2.1.546. outbound_mailbox_27.RIRQT . . . 620
2.1.6.7.4.4.2.2.1.547. outbound_mailbox_27.IRQS . . . 620
2.1.6.7.4.4.2.2.1.548. outbound_mailbox_27.IRQEN . . . 620
2.1.6.7.4.4.2.2.1.549. outbound_mailbox_27.IRQP . . . 620
2.1.6.7.4.4.2.2.1.550. outbound_mailbox_27.CTRL . . . 621
2.1.6.7.4.4.2.2.1.551. inbound_mailbox_27.WRITE_DATA . . . 621
2.1.6.7.4.4.2.2.1.552. inbound_mailbox_27.READ_DATA . . . 621
2.1.6.7.4.4.2.2.1.553. inbound_mailbox_27.STATUS . . . 621
2.1.6.7.4.4.2.2.1.554. inbound_mailbox_27.ERROR_FLAGS . . . 621
2.1.6.7.4.4.2.2.1.555. inbound_mailbox_27.WIRQT . . . 621
2.1.6.7.4.4.2.2.1.556. inbound_mailbox_27.RIRQT . . . 622
2.1.6.7.4.4.2.2.1.557. inbound_mailbox_27.IRQS . . . 622
2.1.6.7.4.4.2.2.1.558. inbound_mailbox_27.IRQEN . . . 622
2.1.6.7.4.4.2.2.1.559. inbound_mailbox_27.IRQP . . . 622
2.1.6.7.4.4.2.2.1.560. inbound_mailbox_27.CTRL . . . 623
2.1.6.7.4.4.2.2.1.561. outbound_mailbox_28.WRITE_DATA . . . 623
2.1.6.7.4.4.2.2.1.562. outbound_mailbox_28.READ_DATA . . . 623
2.1.6.7.4.4.2.2.1.563. outbound_mailbox_28.STATUS . . . 623
2.1.6.7.4.4.2.2.1.564. outbound_mailbox_28.ERROR_FLAGS . . . 623
2.1.6.7.4.4.2.2.1.565. outbound_mailbox_28.WIRQT . . . 623
2.1.6.7.4.4.2.2.1.566. outbound_mailbox_28.RIRQT . . . 624

2.1.6.7.4.4.2.2.1.567. outbound_mailbox_28.IRQS . . . 624
2.1.6.7.4.4.2.2.1.568. outbound_mailbox_28.IRQEN . . . 624
2.1.6.7.4.4.2.2.1.569. outbound_mailbox_28.IRQP . . . 624
2.1.6.7.4.4.2.2.1.570. outbound_mailbox_28.CTRL . . . 625
2.1.6.7.4.4.2.2.1.571. inbound_mailbox_28.WRITE_DATA . . . 625
2.1.6.7.4.4.2.2.1.572. inbound_mailbox_28.READ_DATA . . . 625
2.1.6.7.4.4.2.2.1.573. inbound_mailbox_28.STATUS . . . 625
2.1.6.7.4.4.2.2.1.574. inbound_mailbox_28.ERROR_FLAGS . . . 625
2.1.6.7.4.4.2.2.1.575. inbound_mailbox_28.WIRQT . . . 625
2.1.6.7.4.4.2.2.1.576. inbound_mailbox_28.RIRQT . . . 626
2.1.6.7.4.4.2.2.1.577. inbound_mailbox_28.IRQS . . . 626
2.1.6.7.4.4.2.2.1.578. inbound_mailbox_28.IRQEN . . . 626
2.1.6.7.4.4.2.2.1.579. inbound_mailbox_28.IRQP . . . 626
2.1.6.7.4.4.2.2.1.580. inbound_mailbox_28.CTRL . . . 627
2.1.6.7.4.4.2.2.1.581. outbound_mailbox_29.WRITE_DATA . . . 627
2.1.6.7.4.4.2.2.1.582. outbound_mailbox_29.READ_DATA . . . 627
2.1.6.7.4.4.2.2.1.583. outbound_mailbox_29.STATUS . . . 627
2.1.6.7.4.4.2.2.1.584. outbound_mailbox_29.ERROR_FLAGS . . . 627
2.1.6.7.4.4.2.2.1.585. outbound_mailbox_29.WIRQT . . . 627
2.1.6.7.4.4.2.2.1.586. outbound_mailbox_29.RIRQT . . . 628
2.1.6.7.4.4.2.2.1.587. outbound_mailbox_29.IRQS . . . 628
2.1.6.7.4.4.2.2.1.588. outbound_mailbox_29.IRQEN . . . 628
2.1.6.7.4.4.2.2.1.589. outbound_mailbox_29.IRQP . . . 628
2.1.6.7.4.4.2.2.1.590. outbound_mailbox_29.CTRL . . . 629
2.1.6.7.4.4.2.2.1.591. inbound_mailbox_29.WRITE_DATA . . . 629
2.1.6.7.4.4.2.2.1.592. inbound_mailbox_29.READ_DATA . . . 629
2.1.6.7.4.4.2.2.1.593. inbound_mailbox_29.STATUS . . . 629
2.1.6.7.4.4.2.2.1.594. inbound_mailbox_29.ERROR_FLAGS . . . 629
2.1.6.7.4.4.2.2.1.595. inbound_mailbox_29.WIRQT . . . 629
2.1.6.7.4.4.2.2.1.596. inbound_mailbox_29.RIRQT . . . 630
2.1.6.7.4.4.2.2.1.597. inbound_mailbox_29.IRQS . . . 630
2.1.6.7.4.4.2.2.1.598. inbound_mailbox_29.IRQEN . . . 630
2.1.6.7.4.4.2.2.1.599. inbound_mailbox_29.IRQP . . . 630
2.1.6.7.4.4.2.2.1.600. inbound_mailbox_29.CTRL . . . 631
2.1.6.7.4.4.2.2.1.601. outbound_mailbox_30.WRITE_DATA . . . 631
2.1.6.7.4.4.2.2.1.602. outbound_mailbox_30.READ_DATA . . . 631
2.1.6.7.4.4.2.2.1.603. outbound_mailbox_30.STATUS . . . 631
2.1.6.7.4.4.2.2.1.604. outbound_mailbox_30.ERROR_FLAGS . . . 631
2.1.6.7.4.4.2.2.1.605. outbound_mailbox_30.WIRQT . . . 631
2.1.6.7.4.4.2.2.1.606. outbound_mailbox_30.RIRQT . . . 632
2.1.6.7.4.4.2.2.1.607. outbound_mailbox_30.IRQS . . . 632
2.1.6.7.4.4.2.2.1.608. outbound_mailbox_30.IRQEN . . . 632
2.1.6.7.4.4.2.2.1.609. outbound_mailbox_30.IRQP . . . 632
2.1.6.7.4.4.2.2.1.610. outbound_mailbox_30.CTRL . . . 633

2.1.6.7.4.4.2.2.1.611. inbound_mailbox_30.WRITE_DATA . . . 633
2.1.6.7.4.4.2.2.1.612. inbound_mailbox_30.READ_DATA . . . 633
2.1.6.7.4.4.2.2.1.613. inbound_mailbox_30.STATUS . . . 633
2.1.6.7.4.4.2.2.1.614. inbound_mailbox_30.ERROR_FLAGS . . . 633
2.1.6.7.4.4.2.2.1.615. inbound_mailbox_30.WIRQT . . . 633
2.1.6.7.4.4.2.2.1.616. inbound_mailbox_30.RIRQT . . . 634
2.1.6.7.4.4.2.2.1.617. inbound_mailbox_30.IRQS . . . 634
2.1.6.7.4.4.2.2.1.618. inbound_mailbox_30.IRQEN . . . 634
2.1.6.7.4.4.2.2.1.619. inbound_mailbox_30.IRQP . . . 634
2.1.6.7.4.4.2.2.1.620. inbound_mailbox_30.CTRL . . . 635
2.1.6.7.4.4.2.2.1.621. outbound_mailbox_31.WRITE_DATA . . . 635
2.1.6.7.4.4.2.2.1.622. outbound_mailbox_31.READ_DATA . . . 635
2.1.6.7.4.4.2.2.1.623. outbound_mailbox_31.STATUS . . . 635
2.1.6.7.4.4.2.2.1.624. outbound_mailbox_31.ERROR_FLAGS . . . 635
2.1.6.7.4.4.2.2.1.625. outbound_mailbox_31.WIRQT . . . 635
2.1.6.7.4.4.2.2.1.626. outbound_mailbox_31.RIRQT . . . 636
2.1.6.7.4.4.2.2.1.627. outbound_mailbox_31.IRQS . . . 636
2.1.6.7.4.4.2.2.1.628. outbound_mailbox_31.IRQEN . . . 636
2.1.6.7.4.4.2.2.1.629. outbound_mailbox_31.IRQP . . . 636
2.1.6.7.4.4.2.2.1.630. outbound_mailbox_31.CTRL . . . 637
2.1.6.7.4.4.2.2.1.631. inbound_mailbox_31.WRITE_DATA . . . 637
2.1.6.7.4.4.2.2.1.632. inbound_mailbox_31.READ_DATA . . . 637
2.1.6.7.4.4.2.2.1.633. inbound_mailbox_31.STATUS . . . 637
2.1.6.7.4.4.2.2.1.634. inbound_mailbox_31.ERROR_FLAGS . . . 637
2.1.6.7.4.4.2.2.1.635. inbound_mailbox_31.WIRQT . . . 637
2.1.6.7.4.4.2.2.1.636. inbound_mailbox_31.RIRQT . . . 638
2.1.6.7.4.4.2.2.1.637. inbound_mailbox_31.IRQS . . . 638
2.1.6.7.4.4.2.2.1.638. inbound_mailbox_31.IRQEN . . . 638
2.1.6.7.4.4.2.2.1.639. inbound_mailbox_31.IRQP . . . 638
2.1.6.7.4.4.2.2.1.640. inbound_mailbox_31.CTRL . . . 639
2.1.6.7.4.4.2.2.2. SEP AXI-Lite Mailbox Wrapper Address Map . . . 639
2.1.6.7.4.4.2.2.2.1. outbound_mailbox_0.WRITE_DATA . . . 644
2.1.6.7.4.4.2.2.2.2. outbound_mailbox_0.READ_DATA . . . 644
2.1.6.7.4.4.2.2.2.3. outbound_mailbox_0.STATUS . . . 644
2.1.6.7.4.4.2.2.2.4. outbound_mailbox_0.ERROR_FLAGS . . . 644
2.1.6.7.4.4.2.2.2.5. outbound_mailbox_0.WIRQT . . . 644
2.1.6.7.4.4.2.2.2.6. outbound_mailbox_0.RIRQT . . . 644
2.1.6.7.4.4.2.2.2.7. outbound_mailbox_0.IRQS . . . 645
2.1.6.7.4.4.2.2.2.8. outbound_mailbox_0.IRQEN . . . 645
2.1.6.7.4.4.2.2.2.9. outbound_mailbox_0.IRQP . . . 645
2.1.6.7.4.4.2.2.2.10. outbound_mailbox_0.CTRL . . . 645
2.1.6.7.4.4.2.2.2.11. inbound_mailbox_0.WRITE_DATA . . . 646
2.1.6.7.4.4.2.2.2.12. inbound_mailbox_0.READ_DATA . . . 646
2.1.6.7.4.4.2.2.2.13. inbound_mailbox_0.STATUS . . . 646

2.1.6.7.4.4.2.2.2.14. inbound_mailbox_0.ERROR_FLAGS . . . 646
2.1.6.7.4.4.2.2.2.15. inbound_mailbox_0.WIRQT . . . 646
2.1.6.7.4.4.2.2.2.16. inbound_mailbox_0.RIRQT . . . 646
2.1.6.7.4.4.2.2.2.17. inbound_mailbox_0.IRQS . . . 647
2.1.6.7.4.4.2.2.2.18. inbound_mailbox_0.IRQEN . . . 647
2.1.6.7.4.4.2.2.2.19. inbound_mailbox_0.IRQP . . . 647
2.1.6.7.4.4.2.2.2.20. inbound_mailbox_0.CTRL . . . 647
2.1.6.7.4.4.2.2.2.21. outbound_mailbox_1.WRITE_DATA . . . 648
2.1.6.7.4.4.2.2.2.22. outbound_mailbox_1.READ_DATA . . . 648
2.1.6.7.4.4.2.2.2.23. outbound_mailbox_1.STATUS . . . 648
2.1.6.7.4.4.2.2.2.24. outbound_mailbox_1.ERROR_FLAGS . . . 648
2.1.6.7.4.4.2.2.2.25. outbound_mailbox_1.WIRQT . . . 648
2.1.6.7.4.4.2.2.2.26. outbound_mailbox_1.RIRQT . . . 648
2.1.6.7.4.4.2.2.2.27. outbound_mailbox_1.IRQS . . . 649
2.1.6.7.4.4.2.2.2.28. outbound_mailbox_1.IRQEN . . . 649
2.1.6.7.4.4.2.2.2.29. outbound_mailbox_1.IRQP . . . 649
2.1.6.7.4.4.2.2.2.30. outbound_mailbox_1.CTRL . . . 649
2.1.6.7.4.4.2.2.2.31. inbound_mailbox_1.WRITE_DATA . . . 650
2.1.6.7.4.4.2.2.2.32. inbound_mailbox_1.READ_DATA . . . 650
2.1.6.7.4.4.2.2.2.33. inbound_mailbox_1.STATUS . . . 650
2.1.6.7.4.4.2.2.2.34. inbound_mailbox_1.ERROR_FLAGS . . . 650
2.1.6.7.4.4.2.2.2.35. inbound_mailbox_1.WIRQT . . . 650
2.1.6.7.4.4.2.2.2.36. inbound_mailbox_1.RIRQT . . . 650
2.1.6.7.4.4.2.2.2.37. inbound_mailbox_1.IRQS . . . 651
2.1.6.7.4.4.2.2.2.38. inbound_mailbox_1.IRQEN . . . 651
2.1.6.7.4.4.2.2.2.39. inbound_mailbox_1.IRQP . . . 651
2.1.6.7.4.4.2.2.2.40. inbound_mailbox_1.CTRL . . . 651
2.1.6.7.4.4.2.2.2.41. outbound_mailbox_2.WRITE_DATA . . . 652
2.1.6.7.4.4.2.2.2.42. outbound_mailbox_2.READ_DATA . . . 652
2.1.6.7.4.4.2.2.2.43. outbound_mailbox_2.STATUS . . . 652
2.1.6.7.4.4.2.2.2.44. outbound_mailbox_2.ERROR_FLAGS . . . 652
2.1.6.7.4.4.2.2.2.45. outbound_mailbox_2.WIRQT . . . 652
2.1.6.7.4.4.2.2.2.46. outbound_mailbox_2.RIRQT . . . 652
2.1.6.7.4.4.2.2.2.47. outbound_mailbox_2.IRQS . . . 653
2.1.6.7.4.4.2.2.2.48. outbound_mailbox_2.IRQEN . . . 653
2.1.6.7.4.4.2.2.2.49. outbound_mailbox_2.IRQP . . . 653
2.1.6.7.4.4.2.2.2.50. outbound_mailbox_2.CTRL . . . 653
2.1.6.7.4.4.2.2.2.51. inbound_mailbox_2.WRITE_DATA . . . 654
2.1.6.7.4.4.2.2.2.52. inbound_mailbox_2.READ_DATA . . . 654
2.1.6.7.4.4.2.2.2.53. inbound_mailbox_2.STATUS . . . 654
2.1.6.7.4.4.2.2.2.54. inbound_mailbox_2.ERROR_FLAGS . . . 654
2.1.6.7.4.4.2.2.2.55. inbound_mailbox_2.WIRQT . . . 654
2.1.6.7.4.4.2.2.2.56. inbound_mailbox_2.RIRQT . . . 654
2.1.6.7.4.4.2.2.2.57. inbound_mailbox_2.IRQS . . . 655

2.1.6.7.4.4.2.2.2.58. inbound_mailbox_2.IRQEN . . . 655
2.1.6.7.4.4.2.2.2.59. inbound_mailbox_2.IRQP . . . 655
2.1.6.7.4.4.2.2.2.60. inbound_mailbox_2.CTRL . . . 655
2.1.6.7.4.4.2.2.2.61. outbound_mailbox_3.WRITE_DATA . . . 656
2.1.6.7.4.4.2.2.2.62. outbound_mailbox_3.READ_DATA . . . 656
2.1.6.7.4.4.2.2.2.63. outbound_mailbox_3.STATUS . . . 656
2.1.6.7.4.4.2.2.2.64. outbound_mailbox_3.ERROR_FLAGS . . . 656
2.1.6.7.4.4.2.2.2.65. outbound_mailbox_3.WIRQT . . . 656
2.1.6.7.4.4.2.2.2.66. outbound_mailbox_3.RIRQT . . . 656
2.1.6.7.4.4.2.2.2.67. outbound_mailbox_3.IRQS . . . 657
2.1.6.7.4.4.2.2.2.68. outbound_mailbox_3.IRQEN . . . 657
2.1.6.7.4.4.2.2.2.69. outbound_mailbox_3.IRQP . . . 657
2.1.6.7.4.4.2.2.2.70. outbound_mailbox_3.CTRL . . . 657
2.1.6.7.4.4.2.2.2.71. inbound_mailbox_3.WRITE_DATA . . . 658
2.1.6.7.4.4.2.2.2.72. inbound_mailbox_3.READ_DATA . . . 658
2.1.6.7.4.4.2.2.2.73. inbound_mailbox_3.STATUS . . . 658
2.1.6.7.4.4.2.2.2.74. inbound_mailbox_3.ERROR_FLAGS . . . 658
2.1.6.7.4.4.2.2.2.75. inbound_mailbox_3.WIRQT . . . 658
2.1.6.7.4.4.2.2.2.76. inbound_mailbox_3.RIRQT . . . 658
2.1.6.7.4.4.2.2.2.77. inbound_mailbox_3.IRQS . . . 659
2.1.6.7.4.4.2.2.2.78. inbound_mailbox_3.IRQEN . . . 659
2.1.6.7.4.4.2.2.2.79. inbound_mailbox_3.IRQP . . . 659
2.1.6.7.4.4.2.2.2.80. inbound_mailbox_3.CTRL . . . 659
2.1.6.7.4.4.2.2.2.81. outbound_mailbox_4.WRITE_DATA . . . 660
2.1.6.7.4.4.2.2.2.82. outbound_mailbox_4.READ_DATA . . . 660
2.1.6.7.4.4.2.2.2.83. outbound_mailbox_4.STATUS . . . 660
2.1.6.7.4.4.2.2.2.84. outbound_mailbox_4.ERROR_FLAGS . . . 660
2.1.6.7.4.4.2.2.2.85. outbound_mailbox_4.WIRQT . . . 660
2.1.6.7.4.4.2.2.2.86. outbound_mailbox_4.RIRQT . . . 660
2.1.6.7.4.4.2.2.2.87. outbound_mailbox_4.IRQS . . . 661
2.1.6.7.4.4.2.2.2.88. outbound_mailbox_4.IRQEN . . . 661
2.1.6.7.4.4.2.2.2.89. outbound_mailbox_4.IRQP . . . 661
2.1.6.7.4.4.2.2.2.90. outbound_mailbox_4.CTRL . . . 661
2.1.6.7.4.4.2.2.2.91. inbound_mailbox_4.WRITE_DATA . . . 662
2.1.6.7.4.4.2.2.2.92. inbound_mailbox_4.READ_DATA . . . 662
2.1.6.7.4.4.2.2.2.93. inbound_mailbox_4.STATUS . . . 662
2.1.6.7.4.4.2.2.2.94. inbound_mailbox_4.ERROR_FLAGS . . . 662
2.1.6.7.4.4.2.2.2.95. inbound_mailbox_4.WIRQT . . . 662
2.1.6.7.4.4.2.2.2.96. inbound_mailbox_4.RIRQT . . . 662
2.1.6.7.4.4.2.2.2.97. inbound_mailbox_4.IRQS . . . 663
2.1.6.7.4.4.2.2.2.98. inbound_mailbox_4.IRQEN . . . 663
2.1.6.7.4.4.2.2.2.99. inbound_mailbox_4.IRQP . . . 663
2.1.6.7.4.4.2.2.2.100. inbound_mailbox_4.CTRL . . . 663
2.1.6.7.4.4.2.2.2.101. outbound_mailbox_5.WRITE_DATA . . . 664

2.1.6.7.4.4.2.2.2.102. outbound_mailbox_5.READ_DATA . . . 664
2.1.6.7.4.4.2.2.2.103. outbound_mailbox_5.STATUS . . . 664
2.1.6.7.4.4.2.2.2.104. outbound_mailbox_5.ERROR_FLAGS . . . 664
2.1.6.7.4.4.2.2.2.105. outbound_mailbox_5.WIRQT . . . 664
2.1.6.7.4.4.2.2.2.106. outbound_mailbox_5.RIRQT . . . 664
2.1.6.7.4.4.2.2.2.107. outbound_mailbox_5.IRQS . . . 665
2.1.6.7.4.4.2.2.2.108. outbound_mailbox_5.IRQEN . . . 665
2.1.6.7.4.4.2.2.2.109. outbound_mailbox_5.IRQP . . . 665
2.1.6.7.4.4.2.2.2.110. outbound_mailbox_5.CTRL . . . 665
2.1.6.7.4.4.2.2.2.111. inbound_mailbox_5.WRITE_DATA . . . 666
2.1.6.7.4.4.2.2.2.112. inbound_mailbox_5.READ_DATA . . . 666
2.1.6.7.4.4.2.2.2.113. inbound_mailbox_5.STATUS . . . 666
2.1.6.7.4.4.2.2.2.114. inbound_mailbox_5.ERROR_FLAGS . . . 666
2.1.6.7.4.4.2.2.2.115. inbound_mailbox_5.WIRQT . . . 666
2.1.6.7.4.4.2.2.2.116. inbound_mailbox_5.RIRQT . . . 666
2.1.6.7.4.4.2.2.2.117. inbound_mailbox_5.IRQS . . . 667
2.1.6.7.4.4.2.2.2.118. inbound_mailbox_5.IRQEN . . . 667
2.1.6.7.4.4.2.2.2.119. inbound_mailbox_5.IRQP . . . 667
2.1.6.7.4.4.2.2.2.120. inbound_mailbox_5.CTRL . . . 667
2.1.6.7.4.4.2.2.2.121. outbound_mailbox_6.WRITE_DATA . . . 668
2.1.6.7.4.4.2.2.2.122. outbound_mailbox_6.READ_DATA . . . 668
2.1.6.7.4.4.2.2.2.123. outbound_mailbox_6.STATUS . . . 668
2.1.6.7.4.4.2.2.2.124. outbound_mailbox_6.ERROR_FLAGS . . . 668
2.1.6.7.4.4.2.2.2.125. outbound_mailbox_6.WIRQT . . . 668
2.1.6.7.4.4.2.2.2.126. outbound_mailbox_6.RIRQT . . . 668
2.1.6.7.4.4.2.2.2.127. outbound_mailbox_6.IRQS . . . 669
2.1.6.7.4.4.2.2.2.128. outbound_mailbox_6.IRQEN . . . 669
2.1.6.7.4.4.2.2.2.129. outbound_mailbox_6.IRQP . . . 669
2.1.6.7.4.4.2.2.2.130. outbound_mailbox_6.CTRL . . . 669
2.1.6.7.4.4.2.2.2.131. inbound_mailbox_6.WRITE_DATA . . . 670
2.1.6.7.4.4.2.2.2.132. inbound_mailbox_6.READ_DATA . . . 670
2.1.6.7.4.4.2.2.2.133. inbound_mailbox_6.STATUS . . . 670
2.1.6.7.4.4.2.2.2.134. inbound_mailbox_6.ERROR_FLAGS . . . 670
2.1.6.7.4.4.2.2.2.135. inbound_mailbox_6.WIRQT . . . 670
2.1.6.7.4.4.2.2.2.136. inbound_mailbox_6.RIRQT . . . 670
2.1.6.7.4.4.2.2.2.137. inbound_mailbox_6.IRQS . . . 671
2.1.6.7.4.4.2.2.2.138. inbound_mailbox_6.IRQEN . . . 671
2.1.6.7.4.4.2.2.2.139. inbound_mailbox_6.IRQP . . . 671
2.1.6.7.4.4.2.2.2.140. inbound_mailbox_6.CTRL . . . 671
2.1.6.7.4.4.2.2.2.141. outbound_mailbox_7.WRITE_DATA . . . 672
2.1.6.7.4.4.2.2.2.142. outbound_mailbox_7.READ_DATA . . . 672
2.1.6.7.4.4.2.2.2.143. outbound_mailbox_7.STATUS . . . 672
2.1.6.7.4.4.2.2.2.144. outbound_mailbox_7.ERROR_FLAGS . . . 672
2.1.6.7.4.4.2.2.2.145. outbound_mailbox_7.WIRQT . . . 672

2.1.6.7.4.4.2.2.2.146. outbound_mailbox_7.RIRQT . . . 672
2.1.6.7.4.4.2.2.2.147. outbound_mailbox_7.IRQS . . . 673
2.1.6.7.4.4.2.2.2.148. outbound_mailbox_7.IRQEN . . . 673
2.1.6.7.4.4.2.2.2.149. outbound_mailbox_7.IRQP . . . 673
2.1.6.7.4.4.2.2.2.150. outbound_mailbox_7.CTRL . . . 673
2.1.6.7.4.4.2.2.2.151. inbound_mailbox_7.WRITE_DATA . . . 674
2.1.6.7.4.4.2.2.2.152. inbound_mailbox_7.READ_DATA . . . 674
2.1.6.7.4.4.2.2.2.153. inbound_mailbox_7.STATUS . . . 674
2.1.6.7.4.4.2.2.2.154. inbound_mailbox_7.ERROR_FLAGS . . . 674
2.1.6.7.4.4.2.2.2.155. inbound_mailbox_7.WIRQT . . . 674
2.1.6.7.4.4.2.2.2.156. inbound_mailbox_7.RIRQT . . . 674
2.1.6.7.4.4.2.2.2.157. inbound_mailbox_7.IRQS . . . 675
2.1.6.7.4.4.2.2.2.158. inbound_mailbox_7.IRQEN . . . 675
2.1.6.7.4.4.2.2.2.159. inbound_mailbox_7.IRQP . . . 675
2.1.6.7.4.4.2.2.2.160. inbound_mailbox_7.CTRL . . . 675
2.1.6.7.5. System Timer OCTS . . . 676
2.1.6.7.5.1. Overview . . . 676
2.1.6.7.5.2. Operation . . . 676
2.1.6.7.5.2.1. Counting and Synchronization . . . 677
2.1.6.7.5.2.2. Pulse Generation and Clock Crossing . . . 678
2.1.6.7.5.2.3. Status and Credit Expiration . . . 678
2.1.6.7.5.2.4. Reset . . . 678
2.1.6.7.5.3. Interface . . . 678
2.1.6.7.5.3.1. Ports . . . 678
2.1.6.7.5.3.2. OCTS Synchronization Interface . . . 679
2.1.6.7.5.3.3. Timer Count . . . 679
2.1.6.7.5.3.4. Timing . . . 679
2.1.6.7.5.4. Memory Map and Register Reference . . . 679
2.1.6.7.5.4.1. Memory Map . . . 679
2.1.6.7.5.4.2. Detailed Register Map . . . 679
2.1.6.7.5.4.2.1. OCTS System Timer Address Map . . . 679
2.1.6.7.5.4.2.1.1. TIMER_START . . . 680
2.1.6.7.5.4.2.1.2. CTRL . . . 680
2.1.6.7.5.4.2.1.3. STATUS . . . 680
2.1.6.7.5.4.2.1.4. TIMER_PRESET_LO . . . 680
2.1.6.7.5.4.2.1.5. TIMER_PRESET_HI . . . 681
2.1.6.7.5.4.2.1.6. TIMER_COUNT_LO . . . 681
2.1.6.7.5.4.2.1.7. TIMER_COUNT_HI . . . 681
2.1.6.7.5.4.2.1.8. CREDIT_EXPIRED . . . 681
2.1.6.7.5.4.2.1.9. TIMER_GPIO_ENABLE . . . 681
2.1.6.7.6. eFuse . . . 681
2.1.6.7.6.1. Overview . . . 682
2.1.6.7.6.2. Description and Features . . . 682
2.1.6.7.6.3. Architecture . . . 682

2.1.6.7.6.3.1. Interface Controller . . . 682
2.1.6.7.6.3.2. Access Paths . . . 682
2.1.6.7.6.3.3. Command-path ownership . . . 682
2.1.6.7.6.3.4. Destination Endpoints . . . 682
2.1.6.7.6.3.5. Shadow Register Subsystem . . . 683
2.1.6.7.6.3.6. Features . . . 683
2.1.6.7.6.3.7. State Machine Architecture . . . 683
2.1.6.7.6.3.8. Parameterized Command Typedefs . . . 683
2.1.6.7.6.3.9. Foundry-Specific Signals . . . 684
2.1.6.7.6.3.10. Interface SHIM Layer . . . 684
2.1.6.7.6.3.11. eFuse Bank Model . . . 685
2.1.6.7.6.3.12. Access Permissions and Security . . . 685
2.1.6.7.6.3.13. Hardware vs. Software Locks . . . 685
2.1.6.7.6.3.14. Security Disable Bypass Mechanism . . . 686
2.1.6.7.6.3.15. Lifecycle State (LC_STATE) Effects . . . 686
2.1.6.7.6.3.16. Secure Test Mode (secure_tm_i) . . . 687
2.1.6.7.6.4. Interface . . . 688
2.1.6.7.6.4.1. Configuration Parameters . . . 688
2.1.6.7.6.4.2. Main AXI4-Lite Interfaces . . . 688
2.1.6.7.6.4.3. Fuse Bank Control Interface . . . 688
2.1.6.7.6.4.4. Fuse Command Interface . . . 688
2.1.6.7.6.4.5. Security and Control Signals . . . 688
2.1.6.7.6.4.6. Fuse Command Protocol . . . 688
2.1.6.7.6.5. Memory Map and Register Reference . . . 689
2.1.6.7.6.5.1. Memory Map . . . 689
2.1.6.7.6.5.2. Detailed Register Map . . . 690
2.1.6.7.6.5.2.1. Shadow Registers . . . 690
2.1.6.7.6.5.2.1.1. Efuse address map of physical efuse macro . . . 690
2.1.6.7.6.5.2.1.1.1. LOCKS . . . 690
2.1.6.7.6.5.2.1.1.2. JTAG_PUBLIC_IDENTITY . . . 692
2.1.6.7.6.5.2.1.1.3. I2C_I3C_ID[9] . . . 692
2.1.6.7.6.5.2.1.1.4. SMC_CONFIG . . . 692
2.1.6.7.6.5.2.1.1.5. OCCP_TRANSPORT_TIMEOUT . . . 693
2.1.6.7.6.5.2.1.1.6. SPARE[28] . . . 693
2.1.6.7.6.5.2.2. MMR Registers . . . 693
2.1.6.7.6.5.2.2.1. eFuse Token Registers Address Map . . . 693
2.1.6.7.6.5.2.2.1.1. RMA_SIP_TOKEN_I[8] . . . 694
2.1.6.7.6.5.2.2.1.2. RMA_CHIPLET_TOKEN_I[8] . . . 694
2.1.6.7.6.5.2.2.1.3. SEC_DISABLE_TOKEN_I[8] . . . 694
2.1.6.7.6.5.2.2.1.4. TOKEN_EOP . . . 694
2.1.6.7.6.5.2.2.1.5. RMA_SIP_TOKEN_MATCH . . . 695
2.1.6.7.6.5.2.2.1.6. RMA_CHIPLET_TOKEN_MATCH . . . 695
2.1.6.7.6.5.2.2.1.7. SEC_DISABLE_TOKEN_MATCH . . . 695
2.1.6.7.6.5.2.2.1.8. TOKEN_MATCH_FAULT . . . 695

2.1.6.7.6.5.2.3. eFuse Control Registers . . . 695
2.1.6.7.6.5.2.3.1. eFuse Interface Control Address Map . . . 696
2.1.6.7.6.5.2.3.1.1. EFUSE_INTERFACE_CTRL_STATUS . . . 696
2.1.6.7.6.5.2.3.1.2. EFUSE_PROGRAM_CTRL . . . 696
2.1.6.7.6.5.2.3.1.3. EFUSE_READ_CTRL . . . 697
2.1.6.7.6.5.2.3.1.4. EFUSE_PROGRAM_INTERFACE_READ_DATA . . . 697
2.1.6.7.6.5.2.3.1.5. EFUSE_READ_INTERFACE_READ_DATA . . . 697
2.1.6.7.6.5.2.3.1.6. EFUSE_READ_REQ_TIMEOUT . . . 698
2.1.6.7.6.5.2.3.1.7. EFUSE_PROGRAM_REQ_TIMEOUT . . . 698
2.1.6.7.6.5.2.4. SHIM Control Registers . . . 698
2.1.6.7.6.5.2.4.1. eFuse SHIM Control Model Address Map . . . 698
2.1.6.7.6.5.2.4.1.1. EFUSE_BANK_INIT_TIME . . . 698
2.1.6.7.7. UART 16550 . . . 698
2.1.6.7.7.1. Overview . . . 698
2.1.6.7.7.2. Architecture . . . 699
2.1.6.7.7.2.1. Transmit and Receive Paths . . . 700
2.1.6.7.7.2.2. Baud Timing and Register Views . . . 700
2.1.6.7.7.2.3. FIFO Protection and Line Errors . . . 700
2.1.6.7.7.2.4. Interrupt Priority and Service . . . 700
2.1.6.7.7.3. Interface . . . 701
2.1.6.7.7.3.1. Configuration Parameters . . . 701
2.1.6.7.7.3.2. Modem Control Interface . . . 701
2.1.6.7.7.3.3. DMA Interface . . . 701
2.1.6.7.7.3.4. Interface Timing Considerations . . . 701
2.1.6.7.7.3.5. Clock Domain . . . 701
2.1.6.7.7.3.6. Serial Interface Timing . . . 702
2.1.6.7.7.3.7. Protocol Support . . . 702
2.1.6.7.7.4. Memory Map and Register Reference . . . 702
2.1.6.7.7.4.1. Memory Map . . . 702
2.1.6.7.7.4.2. Detailed Register Map . . . 702
2.1.6.7.7.4.2.1. UART 16550 Main Address Map . . . 702
2.1.6.7.7.4.2.1.1. RBR . . . 703
2.1.6.7.7.4.2.1.2. IER . . . 703
2.1.6.7.7.4.2.1.3. IIR . . . 703
2.1.6.7.7.4.2.1.4. LCR . . . 703
2.1.6.7.7.4.2.1.5. MCR . . . 704
2.1.6.7.7.4.2.1.6. LSR . . . 704
2.1.6.7.7.4.2.1.7. MSR . . . 705
2.1.6.7.7.4.2.1.8. SCR . . . 705
2.1.6.7.7.4.2.1.9. ECR . . . 705
2.1.6.7.7.4.2.1.10. ITR . . . 706
2.1.6.7.7.4.2.2. UART 16550 Main Write-Only Address Map . . . 706
2.1.6.7.7.4.2.2.1. THR . . . 706
2.1.6.7.7.4.2.2.2. FCR . . . 706

2.1.6.7.7.4.2.3. UART 16550 Divisor Latch Address Map . . . 707
2.1.6.7.7.4.2.3.1. DLL . . . 707
2.1.6.7.7.4.2.3.2. DLM . . . 707
2.1.6.7.8. Log Engine . . . 707
2.1.6.7.8.1. Overview . . . 707
2.1.6.7.8.2. Operation . . . 709
2.1.6.7.8.2.1. Memory Slots and Lengths . . . 709
2.1.6.7.8.2.2. Arbitration and Data Transfer . . . 709
2.1.6.7.8.2.3. Errors and Interrupts . . . 709
2.1.6.7.8.2.4. Reset and Disable . . . 710
2.1.6.7.8.3. Interface . . . 710
2.1.6.7.8.4. Memory Map and Register Reference . . . 710
2.1.6.7.8.4.1. Memory Map . . . 710
2.1.6.7.8.4.2. Detailed Register Map . . . 711
2.1.6.7.8.4.2.1. Log Engine Address Map . . . 711
2.1.6.7.8.4.2.1.1. CTRL . . . 711
2.1.6.7.8.4.2.1.2. LOG_REGION_SIZE . . . 711
2.1.6.7.8.4.2.1.3. LOG_REGION_ADDR . . . 712
2.1.6.7.8.4.2.1.4. LOG_WRITE_ADDR . . . 712
2.1.6.7.8.4.2.1.5. INTR_STATUS . . . 712
2.1.6.7.8.4.2.1.6. INTR_ENABLE . . . 712
2.1.6.7.8.4.2.1.7. INTR_TEST . . . 712
2.1.6.7.8.4.2.1.8. LOG_CTRL[16] . . . 713
2.1.6.7.9. I2C Controller . . . 713
2.1.6.7.9.1. OCAH Modifications . . . 714
2.1.6.7.9.2. Memory Map and Register Reference . . . 716
2.1.6.7.9.2.1. Memory Map . . . 716
2.1.6.7.9.2.1.1. Address Alignment and Access Width . . . 716
2.1.6.7.9.2.2. Detailed Register Map . . . 716
2.1.6.7.9.2.2.1. I2C Address Map . . . 716
2.1.6.7.9.2.2.1.1. INTR_STATE . . . 717
2.1.6.7.9.2.2.1.2. INTR_ENABLE . . . 718
2.1.6.7.9.2.2.1.3. INTR_TEST . . . 719
2.1.6.7.9.2.2.1.4. SMBUS_CTRL . . . 719
2.1.6.7.9.2.2.1.5. CTRL . . . 719
2.1.6.7.9.2.2.1.6. STATUS . . . 721
2.1.6.7.9.2.2.1.7. RDATA . . . 721
2.1.6.7.9.2.2.1.8. FDATA . . . 721
2.1.6.7.9.2.2.1.9. FIFO_CTRL . . . 722
2.1.6.7.9.2.2.1.10. HOST_FIFO_CONFIG . . . 722
2.1.6.7.9.2.2.1.11. TARGET_FIFO_CONFIG . . . 722
2.1.6.7.9.2.2.1.12. HOST_FIFO_STATUS . . . 722
2.1.6.7.9.2.2.1.13. TARGET_FIFO_STATUS . . . 723
2.1.6.7.9.2.2.1.14. OVRD . . . 723

2.1.6.7.9.2.2.1.15. VAL . . . 723
2.1.6.7.9.2.2.1.16. TIMING0 . . . 723
2.1.6.7.9.2.2.1.17. TIMING1 . . . 724
2.1.6.7.9.2.2.1.18. TIMING2 . . . 724
2.1.6.7.9.2.2.1.19. TIMING3 . . . 724
2.1.6.7.9.2.2.1.20. TIMING4 . . . 724
2.1.6.7.9.2.2.1.21. TIMEOUT_CTRL . . . 725
2.1.6.7.9.2.2.1.22. TARGET_ID . . . 725
2.1.6.7.9.2.2.1.23. ACQDATA . . . 725
2.1.6.7.9.2.2.1.24. TXDATA . . . 726
2.1.6.7.9.2.2.1.25. HOST_TIMEOUT_CTRL . . . 726
2.1.6.7.9.2.2.1.26. TARGET_TIMEOUT_CTRL . . . 726
2.1.6.7.9.2.2.1.27. TARGET_NACK_COUNT . . . 727
2.1.6.7.9.2.2.1.28. TARGET_ACK_CTRL . . . 727
2.1.6.7.9.2.2.1.29. ACQ_FIFO_NEXT_DATA . . . 727
2.1.6.7.9.2.2.1.30. HOST_NACK_HANDLER_TIMEOUT . . . 727
2.1.6.7.9.2.2.1.31. CONTROLLER_EVENTS . . . 727
2.1.6.7.9.2.2.1.32. TARGET_EVENTS . . . 728
2.1.6.7.9.2.2.1.33. SMBUS_STATUS . . . 728
2.1.6.7.9.2.2.2. I2C Control Address Map . . . 728
2.1.6.7.9.2.2.2.1. I2C_CTRL[3] . . . 729
2.1.6.7.9.2.2.3. I2C Wrapper Address Map . . . 729
2.1.6.7.9.2.2.3.1. i2c[3].INTR_STATE . . . 731
2.1.6.7.9.2.2.3.2. i2c[3].INTR_ENABLE . . . 732
2.1.6.7.9.2.2.3.3. i2c[3].INTR_TEST . . . 733
2.1.6.7.9.2.2.3.4. i2c[3].SMBUS_CTRL . . . 734
2.1.6.7.9.2.2.3.5. i2c[3].CTRL . . . 734
2.1.6.7.9.2.2.3.6. i2c[3].STATUS . . . 735
2.1.6.7.9.2.2.3.7. i2c[3].RDATA . . . 736
2.1.6.7.9.2.2.3.8. i2c[3].FDATA . . . 736
2.1.6.7.9.2.2.3.9. i2c[3].FIFO_CTRL . . . 736
2.1.6.7.9.2.2.3.10. i2c[3].HOST_FIFO_CONFIG . . . 737
2.1.6.7.9.2.2.3.11. i2c[3].TARGET_FIFO_CONFIG . . . 737
2.1.6.7.9.2.2.3.12. i2c[3].HOST_FIFO_STATUS . . . 737
2.1.6.7.9.2.2.3.13. i2c[3].TARGET_FIFO_STATUS . . . 737
2.1.6.7.9.2.2.3.14. i2c[3].OVRD . . . 737
2.1.6.7.9.2.2.3.15. i2c[3].VAL . . . 738
2.1.6.7.9.2.2.3.16. i2c[3].TIMING0 . . . 738
2.1.6.7.9.2.2.3.17. i2c[3].TIMING1 . . . 738
2.1.6.7.9.2.2.3.18. i2c[3].TIMING2 . . . 739
2.1.6.7.9.2.2.3.19. i2c[3].TIMING3 . . . 739
2.1.6.7.9.2.2.3.20. i2c[3].TIMING4 . . . 739
2.1.6.7.9.2.2.3.21. i2c[3].TIMEOUT_CTRL . . . 739
2.1.6.7.9.2.2.3.22. i2c[3].TARGET_ID . . . 740

2.1.6.7.9.2.2.3.23. i2c[3].ACQDATA . . . 740
2.1.6.7.9.2.2.3.24. i2c[3].TXDATA . . . 740
2.1.6.7.9.2.2.3.25. i2c[3].HOST_TIMEOUT_CTRL . . . 741
2.1.6.7.9.2.2.3.26. i2c[3].TARGET_TIMEOUT_CTRL . . . 741
2.1.6.7.9.2.2.3.27. i2c[3].TARGET_NACK_COUNT . . . 741
2.1.6.7.9.2.2.3.28. i2c[3].TARGET_ACK_CTRL . . . 741
2.1.6.7.9.2.2.3.29. i2c[3].ACQ_FIFO_NEXT_DATA . . . 742
2.1.6.7.9.2.2.3.30. i2c[3].HOST_NACK_HANDLER_TIMEOUT . . . 742
2.1.6.7.9.2.2.3.31. i2c[3].CONTROLLER_EVENTS . . . 742
2.1.6.7.9.2.2.3.32. i2c[3].TARGET_EVENTS . . . 742
2.1.6.7.9.2.2.3.33. i2c[3].SMBUS_STATUS . . . 743
2.1.6.7.9.2.2.3.34. I2C_CTRL[3] . . . 743
2.1.6.7.10. I3C Controller . . . 743
2.1.6.7.10.1. OCAH Modifications . . . 744
2.1.6.7.10.2. Memory Map and Register Reference . . . 746
2.1.6.7.10.2.1. Memory Map . . . 746
2.1.6.7.10.2.1.1. Integration Limits . . . 746
2.1.6.7.10.2.2. Detailed Register Map . . . 746
2.1.6.7.10.2.2.1. OCA I3C Controller Wrapper Address Map . . . 746
2.1.6.7.10.2.2.1.1. i3c_csr[6].I3CBase.HCI_VERSION . . . 758
2.1.6.7.10.2.2.1.2. i3c_csr[6].I3CBase.HC_CONTROL . . . 758
2.1.6.7.10.2.2.1.3. i3c_csr[6].I3CBase.CONTROLLER_DEVICE_ADDR . . . 759
2.1.6.7.10.2.2.1.4. i3c_csr[6].I3CBase.HC_CAPABILITIES . . . 759
2.1.6.7.10.2.2.1.5. i3c_csr[6].I3CBase.RESET_CONTROL . . . 761
2.1.6.7.10.2.2.1.6. i3c_csr[6].I3CBase.PRESENT_STATE . . . 761
2.1.6.7.10.2.2.1.7. i3c_csr[6].I3CBase.INTR_STATUS . . . 761
2.1.6.7.10.2.2.1.8. i3c_csr[6].I3CBase.INTR_STATUS_ENABLE . . . 762
2.1.6.7.10.2.2.1.9. i3c_csr[6].I3CBase.INTR_SIGNAL_ENABLE . . . 762
2.1.6.7.10.2.2.1.10. i3c_csr[6].I3CBase.INTR_FORCE . . . 762
2.1.6.7.10.2.2.1.11. i3c_csr[6].I3CBase.DAT_SECTION_OFFSET . . . 763
2.1.6.7.10.2.2.1.12. i3c_csr[6].I3CBase.DCT_SECTION_OFFSET . . . 763
2.1.6.7.10.2.2.1.13. i3c_csr[6].I3CBase.RING_HEADERS_SECTION_OFFSET . . . 763
2.1.6.7.10.2.2.1.14. i3c_csr[6].I3CBase.PIO_SECTION_OFFSET . . . 763
2.1.6.7.10.2.2.1.15. i3c_csr[6].I3CBase.EXT_CAPS_SECTION_OFFSET . . . 763
2.1.6.7.10.2.2.1.16. i3c_csr[6].I3CBase.INT_CTRL_CMDS_EN . . . 764
2.1.6.7.10.2.2.1.17. i3c_csr[6].I3CBase.IBI_NOTIFY_CTRL . . . 764
2.1.6.7.10.2.2.1.18. i3c_csr[6].I3CBase.IBI_DATA_ABORT_CTRL . . . 764
2.1.6.7.10.2.2.1.19. i3c_csr[6].I3CBase.DEV_CTX_BASE_LO . . . 765
2.1.6.7.10.2.2.1.20. i3c_csr[6].I3CBase.DEV_CTX_BASE_HI . . . 765
2.1.6.7.10.2.2.1.21. i3c_csr[6].I3CBase.DEV_CTX_SG . . . 765
2.1.6.7.10.2.2.1.22. i3c_csr[6].PIOControl.COMMAND_PORT . . . 765
2.1.6.7.10.2.2.1.23. i3c_csr[6].PIOControl.RESPONSE_PORT . . . 765
2.1.6.7.10.2.2.1.24. i3c_csr[6].PIOControl.TX_DATA_PORT . . . 766
2.1.6.7.10.2.2.1.25. i3c_csr[6].PIOControl.RX_DATA_PORT . . . 766

2.1.6.7.10.2.2.1.26. i3c_csr[6].PIOControl.IBI_PORT . . . 766
2.1.6.7.10.2.2.1.27. i3c_csr[6].PIOControl.QUEUE_THLD_CTRL . . . 766
2.1.6.7.10.2.2.1.28. i3c_csr[6].PIOControl.DATA_BUFFER_THLD_CTRL . . . 766
2.1.6.7.10.2.2.1.29. i3c_csr[6].PIOControl.QUEUE_SIZE . . . 767
2.1.6.7.10.2.2.1.30. i3c_csr[6].PIOControl.ALT_QUEUE_SIZE . . . 767
2.1.6.7.10.2.2.1.31. i3c_csr[6].PIOControl.PIO_INTR_STATUS . . . 767
2.1.6.7.10.2.2.1.32. i3c_csr[6].PIOControl.PIO_INTR_STATUS_ENABLE . . . 767
2.1.6.7.10.2.2.1.33. i3c_csr[6].PIOControl.PIO_INTR_SIGNAL_ENABLE . . . 768
2.1.6.7.10.2.2.1.34. i3c_csr[6].PIOControl.PIO_INTR_FORCE . . . 768
2.1.6.7.10.2.2.1.35. i3c_csr[6].PIOControl.PIO_CONTROL . . . 768
2.1.6.7.10.2.2.1.36. i3c_csr[6].I3C_EC.SecFwRecoveryIf.EXTCAP_HEADER . . . 769
2.1.6.7.10.2.2.1.37. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_0 . . . 769
2.1.6.7.10.2.2.1.38. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_1 . . . 769
2.1.6.7.10.2.2.1.39. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_2 . . . 769
2.1.6.7.10.2.2.1.40. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_3 . . . 770
2.1.6.7.10.2.2.1.41. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_0 . . . 770
2.1.6.7.10.2.2.1.42. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_1 . . . 771
2.1.6.7.10.2.2.1.43. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_2 . . . 771
2.1.6.7.10.2.2.1.44. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_3 . . . 771
2.1.6.7.10.2.2.1.45. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_4 . . . 771
2.1.6.7.10.2.2.1.46. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_5 . . . 771
2.1.6.7.10.2.2.1.47. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_RESERVED . . . 771
2.1.6.7.10.2.2.1.48. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_0 . . . 772
2.1.6.7.10.2.2.1.49. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_1 . . . 773
2.1.6.7.10.2.2.1.50. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_RESET . . . 773
2.1.6.7.10.2.2.1.51. i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_CTRL . . . 774
2.1.6.7.10.2.2.1.52. i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_STATUS . . . 774
2.1.6.7.10.2.2.1.53. i3c_csr[6].I3C_EC.SecFwRecoveryIf.HW_STATUS . . . 774
2.1.6.7.10.2.2.1.54. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_0 . . . 775
2.1.6.7.10.2.2.1.55. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_1 . . . 775
2.1.6.7.10.2.2.1.56. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_0 . . . 775
2.1.6.7.10.2.2.1.57. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_1 . . . 776
2.1.6.7.10.2.2.1.58. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_2 . . . 776
2.1.6.7.10.2.2.1.59. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_3 . . . 776
2.1.6.7.10.2.2.1.60. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_4 . . . 776
2.1.6.7.10.2.2.1.61. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_RESERVED . . . 776
2.1.6.7.10.2.2.1.62. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_DATA . . . 777
2.1.6.7.10.2.2.1.63. i3c_csr[6].I3C_EC.StdbyCtrlMode.EXTCAP_HEADER . . . 777
2.1.6.7.10.2.2.1.64. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL . . . 777
2.1.6.7.10.2.2.1.65. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_ADDR . . . 778
2.1.6.7.10.2.2.1.66. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES . . . 778
2.1.6.7.10.2.2.1.67. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_CHAR . . . 779
2.1.6.7.10.2.2.1.68. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_STATUS . . . 780
2.1.6.7.10.2.2.1.69. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_CHAR . . . 780

2.1.6.7.10.2.2.1.70. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_PID_LO . . . 781
2.1.6.7.10.2.2.1.71. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_STATUS . . . 781
2.1.6.7.10.2.2.1.72. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_PID_LO . . . 781
2.1.6.7.10.2.2.1.73. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_SIGNAL_ENABLE . . . 782
2.1.6.7.10.2.2.1.74. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_FORCE . . . 782
2.1.6.7.10.2.2.1.75. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_GETCAPS . . . 782
2.1.6.7.10.2.2.1.76. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS . . . 783
2.1.6.7.10.2.2.1.77. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRT_DEVICE_ADDR . . . 783
2.1.6.7.10.2.2.1.78. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MWL . . . 783
2.1.6.7.10.2.2.1.79. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MRL . . . 784
2.1.6.7.10.2.2.1.80. i3c_csr[6].I3C_EC.TTI.EXTCAP_HEADER . . . 784
2.1.6.7.10.2.2.1.81. i3c_csr[6].I3C_EC.TTI.CONTROL . . . 784
2.1.6.7.10.2.2.1.82. i3c_csr[6].I3C_EC.TTI.STATUS . . . 785
2.1.6.7.10.2.2.1.83. i3c_csr[6].I3C_EC.TTI.RESET_CONTROL . . . 785
2.1.6.7.10.2.2.1.84. i3c_csr[6].I3C_EC.TTI.QUEUE_STATUS . . . 785
2.1.6.7.10.2.2.1.85. i3c_csr[6].I3C_EC.TTI.DESC_QUEUE_DEPTH . . . 786
2.1.6.7.10.2.2.1.86. i3c_csr[6].I3C_EC.TTI.DATA_QUEUE_DEPTH . . . 786
2.1.6.7.10.2.2.1.87. i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_DEPTH . . . 786
2.1.6.7.10.2.2.1.88. i3c_csr[6].I3C_EC.TTI.INTERRUPT_STATUS . . . 786
2.1.6.7.10.2.2.1.89. i3c_csr[6].I3C_EC.TTI.INTERRUPT_ENABLE . . . 788
2.1.6.7.10.2.2.1.90. i3c_csr[6].I3C_EC.TTI.INTERRUPT_FORCE . . . 788
2.1.6.7.10.2.2.1.91. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CTRL . . . 789
2.1.6.7.10.2.2.1.92. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_STATUS . . . 789
2.1.6.7.10.2.2.1.93. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_ENABLE . . . 790
2.1.6.7.10.2.2.1.94. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_FORCE . . . 790
2.1.6.7.10.2.2.1.95. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE0 . . . 791
2.1.6.7.10.2.2.1.96. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE1 . . . 791
2.1.6.7.10.2.2.1.97. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE2 . . . 791
2.1.6.7.10.2.2.1.98. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE3 . . . 791
2.1.6.7.10.2.2.1.99. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE4 . . . 791
2.1.6.7.10.2.2.1.100. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE5 . . . 791
2.1.6.7.10.2.2.1.101. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_FRAMING . . . 791
2.1.6.7.10.2.2.1.102. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_PEC . . . 792
2.1.6.7.10.2.2.1.103. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_LENGTH . . . 792
2.1.6.7.10.2.2.1.104. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_READONLY . . . 792
2.1.6.7.10.2.2.1.105. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_UNSUPPORTED . . . 792
2.1.6.7.10.2.2.1.106. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW . . . 792
2.1.6.7.10.2.2.1.107. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW . . . 792
2.1.6.7.10.2.2.1.108. i3c_csr[6].I3C_EC.TTI.RX_DESC_QUEUE_PORT . . . 793
2.1.6.7.10.2.2.1.109. i3c_csr[6].I3C_EC.TTI.RX_DATA_PORT . . . 793
2.1.6.7.10.2.2.1.110. i3c_csr[6].I3C_EC.TTI.TX_DESC_QUEUE_PORT . . . 793
2.1.6.7.10.2.2.1.111. i3c_csr[6].I3C_EC.TTI.TX_DATA_PORT . . . 793
2.1.6.7.10.2.2.1.112. i3c_csr[6].I3C_EC.TTI.IBI_PORT . . . 793
2.1.6.7.10.2.2.1.113. i3c_csr[6].I3C_EC.TTI.QUEUE_SIZE . . . 793

2.1.6.7.10.2.2.1.114. i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_SIZE . . . 793
2.1.6.7.10.2.2.1.115. i3c_csr[6].I3C_EC.TTI.QUEUE_THLD_CTRL . . . 794
2.1.6.7.10.2.2.1.116. i3c_csr[6].I3C_EC.TTI.DATA_BUFFER_THLD_CTRL . . . 794
2.1.6.7.10.2.2.1.117. i3c_csr[6].I3C_EC.SoCMgmtIf.EXTCAP_HEADER . . . 794
2.1.6.7.10.2.2.1.118. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_CONTROL . . . 794
2.1.6.7.10.2.2.1.119. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_STATUS . . . 795
2.1.6.7.10.2.2.1.120. i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_CFG . . . 795
2.1.6.7.10.2.2.1.121. i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_REG_W1C_ACCESS . . . 795
2.1.6.7.10.2.2.1.122. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_2 . . . 795
2.1.6.7.10.2.2.1.123. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_3 . . . 795
2.1.6.7.10.2.2.1.124. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_CONF . . . 795
2.1.6.7.10.2.2.1.125. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_ATTR . . . 796
2.1.6.7.10.2.2.1.126. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_2 . . . 797
2.1.6.7.10.2.2.1.127. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_3 . . . 797
2.1.6.7.10.2.2.1.128. i3c_csr[6].I3C_EC.SoCMgmtIf.T_R_REG . . . 797
2.1.6.7.10.2.2.1.129. i3c_csr[6].I3C_EC.SoCMgmtIf.T_F_REG . . . 797
2.1.6.7.10.2.2.1.130. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_REG . . . 797
2.1.6.7.10.2.2.1.131. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_I2C_REG . . . 798
2.1.6.7.10.2.2.1.132. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_DAT_REG . . . 798
2.1.6.7.10.2.2.1.133. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_REG . . . 798
2.1.6.7.10.2.2.1.134. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_OD_REG . . . 798
2.1.6.7.10.2.2.1.135. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_INIT_OD_REG . . . 798
2.1.6.7.10.2.2.1.136. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_I2C_REG . . . 798
2.1.6.7.10.2.2.1.137. i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_REG . . . 798
2.1.6.7.10.2.2.1.138. i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_OD_REG . . . 799
2.1.6.7.10.2.2.1.139. i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_I2C_REG . . . 799
2.1.6.7.10.2.2.1.140. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_REG . . . 799
2.1.6.7.10.2.2.1.141. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_I2C_REG . . . 799
2.1.6.7.10.2.2.1.142. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_RSTA_REG . . . 799
2.1.6.7.10.2.2.1.143. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_REG . . . 799
2.1.6.7.10.2.2.1.144. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_I2C_REG . . . 800
2.1.6.7.10.2.2.1.145. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_REG . . . 800
2.1.6.7.10.2.2.1.146. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_I2C_REG . . . 800
2.1.6.7.10.2.2.1.147. i3c_csr[6].I3C_EC.SoCMgmtIf.T_DS_OD_REG . . . 800
2.1.6.7.10.2.2.1.148. i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_REG . . . 800
2.1.6.7.10.2.2.1.149. i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_I2C_REG . . . 800
2.1.6.7.10.2.2.1.150. i3c_csr[6].I3C_EC.SoCMgmtIf.T_AVAL_REG . . . 800
2.1.6.7.10.2.2.1.151. i3c_csr[6].I3C_EC.SoCMgmtIf.T_IDLE_REG . . . 801
2.1.6.7.10.2.2.1.152. i3c_csr[6].I3C_EC.SoCMgmtIf.HDR_TIMEOUT_EN_REG . . . 801
2.1.6.7.10.2.2.1.153. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HDR_TIMEOUT_REG . . . 801
2.1.6.7.10.2.2.1.154. i3c_csr[6].I3C_EC.CtrlCfg.EXTCAP_HEADER . . . 801
2.1.6.7.10.2.2.1.155. i3c_csr[6].I3C_EC.CtrlCfg.CONTROLLER_CONFIG . . . 801
2.1.6.7.10.2.2.1.156. i3c_csr[6].I3C_EC.TERMINATION_EXTCAP_HEADER . . . 801
2.1.6.7.10.2.2.1.157. i3c_csr[6].DAT.DAT_MEMORY[128] . . . 802

2.1.6.7.10.2.2.1.158. i3c_csr[6].DCT.DCT_MEMORY[128] . . . 802
2.1.6.7.11. AVSBus Controller . . . 802
2.1.6.7.11.1. Overview . . . 802
2.1.6.7.11.2. Description and Features . . . 803
2.1.6.7.11.3. Architecture . . . 803
2.1.6.7.11.3.1. AVS Protocol Engine . . . 804
2.1.6.7.11.3.2. Clock Generation and Management . . . 805
2.1.6.7.11.3.3. CRC Verification Engine . . . 805
2.1.6.7.11.3.4. Command and Response FIFO System . . . 805
2.1.6.7.11.3.5. Reset and Initialization . . . 806
2.1.6.7.11.3.6. Data Flow and Control Path . . . 806
2.1.6.7.11.3.6.1. Command Path . . . 806
2.1.6.7.11.3.6.2. Response Inspection . . . 806
2.1.6.7.11.3.7. Clock Domain Architecture . . . 806
2.1.6.7.11.3.8. Protocol State Machine . . . 806
2.1.6.7.11.3.9. Error Handling and Diagnostics . . . 808
2.1.6.7.11.4. Interface . . . 809
2.1.6.7.11.4.1. AVSBus Frame Format . . . 809
2.1.6.7.11.4.2. Clock Architecture . . . 810
2.1.6.7.11.4.3. Reset Architecture . . . 811
2.1.6.7.11.4.4. Interrupt Interface . . . 811
2.1.6.7.11.4.5. Pad Enable Interface . . . 812
2.1.6.7.11.4.6. Timing . . . 812
2.1.6.7.11.4.7. Integration Example . . . 812
2.1.6.7.11.5. Memory Map and Register Reference . . . 813
2.1.6.7.11.5.1. Memory Map . . . 813
2.1.6.7.11.5.1.1. Address Alignment and Access Requirements . . . 813
2.1.6.7.11.5.2. Detailed Register Map . . . 814
2.1.6.7.11.5.2.1. AVSBus Controller Address Map . . . 814
2.1.6.7.11.5.2.1.1. AVS_CMD . . . 814
2.1.6.7.11.5.2.1.2. AVS_READBACK . . . 815
2.1.6.7.11.5.2.1.3. AVS_DEBUG_READBACK . . . 816
2.1.6.7.11.5.2.1.4. AVS_LATEST_SLAVE_SUBFRAME . . . 816
2.1.6.7.11.5.2.1.5. AVS_NORMAL_STATUS . . . 816
2.1.6.7.11.5.2.1.6. AVS_SLAVE_STATUS . . . 816
2.1.6.7.11.5.2.1.7. AVS_FIFOS_STATUS . . . 817
2.1.6.7.11.5.2.1.8. AVS_INTERRUPT . . . 817
2.1.6.7.11.5.2.1.9. AVS_INTERRUPT_MASK . . . 817
2.1.6.7.11.5.2.1.10. AVS_INTERRUPT_CLEAR . . . 818
2.1.6.7.11.5.2.1.11. AVS_CFG_0 . . . 818
2.1.6.7.11.5.2.1.12. AVS_CFG_1 . . . 818
2.1.6.7.11.5.2.1.13. AVS_CONFIG . . . 819
2.1.6.7.12. GPIO Peripheral . . . 819
2.1.6.7.12.1. Overview . . . 819

2.1.6.7.12.2. Operation . . . 820
2.1.6.7.12.2.1. Data and Direction Ownership . . . 821
2.1.6.7.12.2.2. Input Readback . . . 822
2.1.6.7.12.2.3. SMC Pad Ring . . . 822
2.1.6.7.12.2.4. Pad Settings and Secondary Function . . . 823
2.1.6.7.12.2.5. Interrupts . . . 824
2.1.6.7.12.2.6. Reset and Strap Capture . . . 824
2.1.6.7.12.2.7. Register Access Filtering . . . 824
2.1.6.7.12.3. Interface . . . 824
2.1.6.7.12.3.1. LSIO Interface . . . 825
2.1.6.7.12.3.2. LSIO Protocol Specifications . . . 825
2.1.6.7.12.3.3. GPIO Pad Interface . . . 825
2.1.6.7.12.3.4. Interrupt Interface . . . 825
2.1.6.7.12.3.5. Interrupt Specifications . . . 825
2.1.6.7.12.4. Memory Map and Register Reference . . . 825
2.1.6.7.12.4.1. Memory Map . . . 825
2.1.6.7.12.4.1.1. Reset Values . . . 825
2.1.6.7.12.4.2. Detailed Register Map . . . 826
2.1.6.7.12.4.2.1. GPIO Interface Address Map . . . 826
2.1.6.7.12.4.2.1.1. DATA_CTRL . . . 826
2.1.6.7.12.4.2.1.2. DATA_CTRL_ENABLE . . . 827
2.1.6.7.12.4.2.1.3. ACCESS_FILTER . . . 827
2.1.6.7.12.4.2.2. GPIO Control Address Map . . . 827
2.1.6.7.12.4.2.2.1. CONTROL . . . 827
2.1.6.7.12.4.2.3. GPIO Wrapper Address Map . . . 828
2.1.6.7.12.4.2.3.1. DATA_CTRL . . . 828
2.1.6.7.12.4.2.3.2. DATA_CTRL_ENABLE . . . 829
2.1.6.7.12.4.2.3.3. ACCESS_FILTER . . . 829
2.1.6.7.12.4.2.3.4. CONTROL . . . 830
2.1.6.7.13. Telemetry Receiver . . . 830
2.1.6.7.13.1. Overview . . . 830
2.1.6.7.13.1.1. Message Format . . . 830
2.1.6.7.13.2. Architecture . . . 831
2.1.6.7.13.2.1. Assembly and Decode . . . 831
2.1.6.7.13.2.2. Message Queue and Readout . . . 831
2.1.6.7.13.2.3. Interrupts . . . 831
2.1.6.7.13.2.4. Reset and Flush . . . 832
2.1.6.7.13.3. Interface . . . 832
2.1.6.7.13.3.1. Configuration Parameters . . . 832
2.1.6.7.13.3.2. Signal Interfaces . . . 832
2.1.6.7.13.3.3. Global Interface . . . 832
2.1.6.7.13.3.4. Clock and Reset . . . 832
2.1.6.7.13.3.5. ATB Telemetry Interface . . . 832
2.1.6.7.13.3.6. ATB Protocol Specifications . . . 833

2.1.6.7.13.3.7. Interrupt Interface . . . 833
2.1.6.7.13.3.8. Interrupt Specifications . . . 833
2.1.6.7.13.3.9. Subsystem Wrapper . . . 833
2.1.6.7.13.4. Memory Map and Register Reference . . . 833
2.1.6.7.13.4.1. Memory Map . . . 833
2.1.6.7.13.4.2. Detailed Register Map . . . 833
2.1.6.7.13.4.2.1. Telemetry Receiver Address Map . . . 833
2.1.6.7.13.4.2.1.1. CTRL . . . 834
2.1.6.7.13.4.2.1.2. STATUS . . . 834
2.1.6.7.13.4.2.1.3. INTR_STATUS . . . 835
2.1.6.7.13.4.2.1.4. INTR_ENABLE . . . 835
2.1.6.7.13.4.2.1.5. INTR_TEST . . . 835
2.1.6.7.13.4.2.1.6. TELEMETRY_PROBE_ID . . . 835
2.1.6.7.13.4.2.1.7. TELEMETRY_COUNTER_VLDS . . . 835
2.1.6.7.13.4.2.1.8. TELEMETRY_COUNTER[32] . . . 836
2.1.6.7.13.4.2.2. Telemetry Receiver Wrapper Address Map . . . 836
2.1.6.7.13.4.2.2.1. telemetry_receiver[3].CTRL . . . 836
2.1.6.7.13.4.2.2.2. telemetry_receiver[3].STATUS . . . 837
2.1.6.7.13.4.2.2.3. telemetry_receiver[3].INTR_STATUS . . . 837
2.1.6.7.13.4.2.2.4. telemetry_receiver[3].INTR_ENABLE . . . 837
2.1.6.7.13.4.2.2.5. telemetry_receiver[3].INTR_TEST . . . 838
2.1.6.7.13.4.2.2.6. telemetry_receiver[3].TELEMETRY_PROBE_ID . . . 838
2.1.6.7.13.4.2.2.7. telemetry_receiver[3].TELEMETRY_COUNTER_VLDS . . . 838
2.1.6.7.13.4.2.2.8. telemetry_receiver[3].TELEMETRY_COUNTER[32] . . . 838
2.1.6.7.14. UART and Log Engine Wrapper Registers . . . 838
2.1.6.7.14.1. UART Wrapper Address Map . . . 838
2.1.6.7.14.1.1. uart_log_engine_wrap[4].uart_log_engine_ctrl.CTRL . . . 840
2.1.6.7.14.1.2. uart_log_engine_wrap[4].uart.RBR . . . 840
2.1.6.7.14.1.3. uart_log_engine_wrap[4].uart.IER . . . 840
2.1.6.7.14.1.4. uart_log_engine_wrap[4].uart.IIR . . . 841
2.1.6.7.14.1.5. uart_log_engine_wrap[4].uart.LCR . . . 841
2.1.6.7.14.1.6. uart_log_engine_wrap[4].uart.MCR . . . 841
2.1.6.7.14.1.7. uart_log_engine_wrap[4].uart.LSR . . . 842
2.1.6.7.14.1.8. uart_log_engine_wrap[4].uart.MSR . . . 842
2.1.6.7.14.1.9. uart_log_engine_wrap[4].uart.SCR . . . 843
2.1.6.7.14.1.10. uart_log_engine_wrap[4].uart.ECR . . . 843
2.1.6.7.14.1.11. uart_log_engine_wrap[4].uart.ITR . . . 843
2.1.6.7.14.1.12. uart_log_engine_wrap[4].log_engine.CTRL . . . 843
2.1.6.7.14.1.13. uart_log_engine_wrap[4].log_engine.LOG_REGION_SIZE . . . 844
2.1.6.7.14.1.14. uart_log_engine_wrap[4].log_engine.LOG_REGION_ADDR . . . 844
2.1.6.7.14.1.15. uart_log_engine_wrap[4].log_engine.LOG_WRITE_ADDR . . . 844
2.1.6.7.14.1.16. uart_log_engine_wrap[4].log_engine.INTR_STATUS . . . 844
2.1.6.7.14.1.17. uart_log_engine_wrap[4].log_engine.INTR_ENABLE . . . 844
2.1.6.7.14.1.18. uart_log_engine_wrap[4].log_engine.INTR_TEST . . . 845

2.1.6.7.14.1.19. uart_log_engine_wrap[4].log_engine.LOG_CTRL[16] . . . 845
2.1.6.7.14.2. UART Log Engine Control Address Map . . . 845
2.1.6.7.14.2.1. CTRL . . . 845
2.1.6.7.14.3. UART Log Engine Wrapper Address Map . . . 845
2.1.6.7.14.3.1. uart_log_engine_ctrl.CTRL . . . 846
2.1.6.7.14.3.2. RBR . . . 846
2.1.6.7.14.3.3. IER . . . 846
2.1.6.7.14.3.4. IIR . . . 847
2.1.6.7.14.3.5. LCR . . . 847
2.1.6.7.14.3.6. MCR . . . 847
2.1.6.7.14.3.7. LSR . . . 848
2.1.6.7.14.3.8. MSR . . . 848
2.1.6.7.14.3.9. SCR . . . 849
2.1.6.7.14.3.10. ECR . . . 849
2.1.6.7.14.3.11. ITR . . . 849
2.1.6.7.14.3.12. log_engine.CTRL . . . 850
2.1.6.7.14.3.13. LOG_REGION_SIZE . . . 850
2.1.6.7.14.3.14. LOG_REGION_ADDR . . . 850
2.1.6.7.14.3.15. LOG_WRITE_ADDR . . . 850
2.1.6.7.14.3.16. INTR_STATUS . . . 850
2.1.6.7.14.3.17. INTR_ENABLE . . . 851
2.1.6.7.14.3.18. INTR_TEST . . . 851
2.1.6.7.14.3.19. LOG_CTRL[16] . . . 851
2.1.6.7.15. Peripheral Parameter Settings . . . 851
2.1.6.8. Design-for-Debug (DFD) and Core Logic Analyzer (CLA) . . . 852
2.1.6.8.1. Debug Bus . . . 853
2.1.6.8.2. Core Logic Analyzer . . . 853
2.1.6.8.3. Actions and Cross-Triggering . . . 854
2.1.6.8.4. Trace . . . 854
2.1.6.8.5. Interrupts . . . 854
2.1.6.8.6. Memory Map and Register Reference . . . 855
2.1.6.8.6.1. Memory Map . . . 855
2.1.6.8.6.2. Detailed Register Map . . . 855
2.1.6.8.6.2.1. SMC DFD MMR Aperture Address Map . . . 855
2.1.6.8.6.2.1.1. Trdstramcontrol . . . 860
2.1.6.8.6.2.1.2. Trdstramimpl . . . 861
2.1.6.8.6.2.1.3. Trdstramstartlow . . . 861
2.1.6.8.6.2.1.4. Trdstramstarthigh . . . 861
2.1.6.8.6.2.1.5. Trdstramlimitlow . . . 861
2.1.6.8.6.2.1.6. Trdstramlimithigh . . . 861
2.1.6.8.6.2.1.7. Trdstramwplow . . . 862
2.1.6.8.6.2.1.8. Trdstramwphigh . . . 862
2.1.6.8.6.2.1.9. Trdstramrplow . . . 862
2.1.6.8.6.2.1.10. Trdstramrphigh . . . 862

2.1.6.8.6.2.1.11. Trdstramdata . . . 862
2.1.6.8.6.2.1.12. dst_sink.ScratchLo . . . 862
2.1.6.8.6.2.1.13. dst_sink.ScratchHi . . . 862
2.1.6.8.6.2.1.14. Trfunnelcontrol . . . 863
2.1.6.8.6.2.1.15. Trfunnelimpl . . . 863
2.1.6.8.6.2.1.16. Trfunneldisinput . . . 863
2.1.6.8.6.2.1.17. funnel.ScratchLo . . . 863
2.1.6.8.6.2.1.18. funnel.ScratchHi . . . 863
2.1.6.8.6.2.1.19. CDbgClaCounter0Cfg . . . 863
2.1.6.8.6.2.1.20. CDbgClaCounter1Cfg . . . 864
2.1.6.8.6.2.1.21. CDbgClaCounter2Cfg . . . 864
2.1.6.8.6.2.1.22. CDbgClaCounter3Cfg . . . 864
2.1.6.8.6.2.1.23. CDbgNode0Eap0 . . . 865
2.1.6.8.6.2.1.24. CDbgNode0Eap1 . . . 865
2.1.6.8.6.2.1.25. CDbgNode1Eap0 . . . 866
2.1.6.8.6.2.1.26. CDbgNode1Eap1 . . . 866
2.1.6.8.6.2.1.27. CDbgNode2Eap0 . . . 867
2.1.6.8.6.2.1.28. CDbgNode2Eap1 . . . 867
2.1.6.8.6.2.1.29. CDbgNode3Eap0 . . . 868
2.1.6.8.6.2.1.30. CDbgNode3Eap1 . . . 868
2.1.6.8.6.2.1.31. CDbgSignalMask0Lo . . . 869
2.1.6.8.6.2.1.32. CDbgSignalMatch0Lo . . . 869
2.1.6.8.6.2.1.33. CDbgSignalMask1Lo . . . 869
2.1.6.8.6.2.1.34. CDbgSignalMatch1Lo . . . 869
2.1.6.8.6.2.1.35. CDbgSignalEdgeDetectCfg . . . 869
2.1.6.8.6.2.1.36. CDbgEapStatus . . . 869
2.1.6.8.6.2.1.37. CDbgClaCtrlStatus . . . 870
2.1.6.8.6.2.1.38. CDbgMuxSelLo . . . 871
2.1.6.8.6.2.1.39. CDbgRsvd1 . . . 872
2.1.6.8.6.2.1.40. CDbgRsvd2 . . . 872
2.1.6.8.6.2.1.41. CDbgTransitionMaskLo . . . 872
2.1.6.8.6.2.1.42. CDbgTransitionFromValueLo . . . 872
2.1.6.8.6.2.1.43. CDbgTransitionToValueLo . . . 872
2.1.6.8.6.2.1.44. CDbgOnesCountMaskLo . . . 872
2.1.6.8.6.2.1.45. CDbgOnesCountValue . . . 872
2.1.6.8.6.2.1.46. CDbgAnyChangeLo . . . 873
2.1.6.8.6.2.1.47. CDbgSignalSnapshotNode0Eap0Lo . . . 873
2.1.6.8.6.2.1.48. CDbgSignalSnapshotNode0Eap1Lo . . . 873
2.1.6.8.6.2.1.49. CDbgSignalSnapshotNode1Eap0Lo . . . 873
2.1.6.8.6.2.1.50. CDbgSignalSnapshotNode1Eap1Lo . . . 873
2.1.6.8.6.2.1.51. CDbgSignalSnapshotNode2Eap0Lo . . . 873
2.1.6.8.6.2.1.52. CDbgSignalSnapshotNode2Eap1Lo . . . 873
2.1.6.8.6.2.1.53. CDbgSignalSnapshotNode3Eap0Lo . . . 873
2.1.6.8.6.2.1.54. CDbgSignalSnapshotNode3Eap1Lo . . . 874

2.1.6.8.6.2.1.55. CDbgClaTimeMatch . . . 874
2.1.6.8.6.2.1.56. CDbgSignalMask2Lo . . . 874
2.1.6.8.6.2.1.57. CDbgSignalMatch2Lo . . . 874
2.1.6.8.6.2.1.58. CDbgSignalMask3Lo . . . 874
2.1.6.8.6.2.1.59. CDbgSignalMatch3Lo . . . 874
2.1.6.8.6.2.1.60. CDbgNode0Eap2 . . . 874
2.1.6.8.6.2.1.61. CDbgNode0Eap3 . . . 875
2.1.6.8.6.2.1.62. CDbgNode1Eap2 . . . 875
2.1.6.8.6.2.1.63. CDbgNode1Eap3 . . . 876
2.1.6.8.6.2.1.64. CDbgNode2Eap2 . . . 876
2.1.6.8.6.2.1.65. CDbgNode2Eap3 . . . 877
2.1.6.8.6.2.1.66. CDbgNode3Eap2 . . . 877
2.1.6.8.6.2.1.67. CDbgNode3Eap3 . . . 878
2.1.6.8.6.2.1.68. CDbgSignalSnapshotNode0Eap2Lo . . . 878
2.1.6.8.6.2.1.69. CDbgSignalSnapshotNode0Eap3Lo . . . 879
2.1.6.8.6.2.1.70. CDbgSignalSnapshotNode1Eap2Lo . . . 879
2.1.6.8.6.2.1.71. CDbgSignalSnapshotNode1Eap3Lo . . . 879
2.1.6.8.6.2.1.72. CDbgSignalSnapshotNode2Eap2Lo . . . 879
2.1.6.8.6.2.1.73. CDbgSignalSnapshotNode2Eap3Lo . . . 879
2.1.6.8.6.2.1.74. CDbgSignalSnapshotNode3Eap2Lo . . . 879
2.1.6.8.6.2.1.75. CDbgSignalSnapshotNode3Eap3Lo . . . 879
2.1.6.8.6.2.1.76. CDbgSignalDelayMuxSel . . . 880
2.1.6.8.6.2.1.77. CDbgClaXtriggerTimestretch . . . 880
2.1.6.8.6.2.1.78. CDbgClaTimestamp . . . 880
2.1.6.8.6.2.1.79. CDbgClaTimestampSync . . . 880
2.1.6.8.6.2.1.80. CDbgClaTimestampConfig . . . 881
2.1.6.8.6.2.1.81. CDbgClaTimestampOffset . . . 881
2.1.6.8.6.2.1.82. CDbgSignalMask0Hi . . . 881
2.1.6.8.6.2.1.83. CDbgSignalMatch0Hi . . . 881
2.1.6.8.6.2.1.84. CDbgSignalMask1Hi . . . 881
2.1.6.8.6.2.1.85. CDbgSignalMatch1Hi . . . 881
2.1.6.8.6.2.1.86. CDbgSignalMask2Hi . . . 881
2.1.6.8.6.2.1.87. CDbgSignalMatch2Hi . . . 882
2.1.6.8.6.2.1.88. CDbgSignalMask3Hi . . . 882
2.1.6.8.6.2.1.89. CDbgSignalMatch3Hi . . . 882
2.1.6.8.6.2.1.90. CDbgMuxSelHi . . . 882
2.1.6.8.6.2.1.91. CDbgTransitionMaskHi . . . 882
2.1.6.8.6.2.1.92. CDbgTransitionFromValueHi . . . 883
2.1.6.8.6.2.1.93. CDbgTransitionToValueHi . . . 883
2.1.6.8.6.2.1.94. CDbgOnesCountMaskHi . . . 883
2.1.6.8.6.2.1.95. CDbgAnyChangeHi . . . 883
2.1.6.8.6.2.1.96. CDbgSignalSnapshotNode0Eap0Hi . . . 883
2.1.6.8.6.2.1.97. CDbgSignalSnapshotNode0Eap1Hi . . . 883
2.1.6.8.6.2.1.98. CDbgSignalSnapshotNode1Eap0Hi . . . 883

2.1.6.8.6.2.1.99. CDbgSignalSnapshotNode1Eap1Hi . . . 883
2.1.6.8.6.2.1.100. CDbgSignalSnapshotNode2Eap0Hi . . . 884
2.1.6.8.6.2.1.101. CDbgSignalSnapshotNode2Eap1Hi . . . 884
2.1.6.8.6.2.1.102. CDbgSignalSnapshotNode3Eap0Hi . . . 884
2.1.6.8.6.2.1.103. CDbgSignalSnapshotNode3Eap1Hi . . . 884
2.1.6.8.6.2.1.104. CDbgSignalSnapshotNode0Eap2Hi . . . 884
2.1.6.8.6.2.1.105. CDbgSignalSnapshotNode0Eap3Hi . . . 884
2.1.6.8.6.2.1.106. CDbgSignalSnapshotNode1Eap2Hi . . . 884
2.1.6.8.6.2.1.107. CDbgSignalSnapshotNode1Eap3Hi . . . 885
2.1.6.8.6.2.1.108. CDbgSignalSnapshotNode2Eap2Hi . . . 885
2.1.6.8.6.2.1.109. CDbgSignalSnapshotNode2Eap3Hi . . . 885
2.1.6.8.6.2.1.110. CDbgSignalSnapshotNode3Eap2Hi . . . 885
2.1.6.8.6.2.1.111. CDbgSignalSnapshotNode3Eap3Hi . . . 885
2.1.6.8.6.2.1.112. CDbgLfsr . . . 885
2.1.6.8.6.2.1.113. CDbgLfsrMask . . . 885
2.1.6.8.6.2.1.114. CDbgTimestampCapture . . . 886
2.1.6.8.6.2.1.115. CDbgCompare0Lo . . . 886
2.1.6.8.6.2.1.116. CDbgCompare0MaskLo . . . 886
2.1.6.8.6.2.1.117. CDbgCompare1Lo . . . 886
2.1.6.8.6.2.1.118. CDbgCompare1MaskLo . . . 886
2.1.6.8.6.2.1.119. CDbgCompare2Lo . . . 886
2.1.6.8.6.2.1.120. CDbgCompare2MaskLo . . . 886
2.1.6.8.6.2.1.121. CDbgCompare3Lo . . . 886
2.1.6.8.6.2.1.122. CDbgCompare3MaskLo . . . 887
2.1.6.8.6.2.1.123. CDbgCompare0Hi . . . 887
2.1.6.8.6.2.1.124. CDbgCompare0MaskHi . . . 887
2.1.6.8.6.2.1.125. CDbgCompare1Hi . . . 887
2.1.6.8.6.2.1.126. CDbgCompare1MaskHi . . . 887
2.1.6.8.6.2.1.127. CDbgCompare2Hi . . . 887
2.1.6.8.6.2.1.128. CDbgCompare2MaskHi . . . 887
2.1.6.8.6.2.1.129. CDbgCompare3Hi . . . 888
2.1.6.8.6.2.1.130. CDbgCompare3MaskHi . . . 888
2.1.6.8.6.2.1.131. Scratch . . . 888
2.1.6.8.6.2.1.132. Trdstcontrol . . . 888
2.1.6.8.6.2.1.133. Trdstimpl . . . 889
2.1.6.8.6.2.1.134. Trdstinstfeatures . . . 889
2.1.6.8.6.2.1.135. CDbgDebugTraceCfg . . . 889
2.1.6.8.6.2.1.136. dst.ScratchLo . . . 890
2.1.6.8.6.2.1.137. dst.ScratchHi . . . 890
2.1.6.9. eFuse Shadow Register Scan Protection . . . 890
2.1.6.9.1. SMC eFuse Asset Classification . . . 890
2.1.6.9.2. Implementation . . . 891
2.1.6.9.3. Downstream Lock Path . . . 891
2.1.6.9.4. Notes for DFT . . . 891

2.1.6.9.5. Verification . . . 892
2.1.6.10. Memory Map and Register Reference . . . 892
2.1.6.10.1. Memory Map . . . 892
2.1.6.10.1.1. Address Space Organization . . . 892
2.1.6.10.1.2. AXI-Lite External Window . . . 897
2.1.6.10.1.3. Register Interface Standards . . . 898
2.1.6.10.1.4. Access Control and Security . . . 898
2.1.6.10.2. Detailed Register Map . . . 898
2.1.6.10.2.1. External Window Reference Maps . . . 898
2.1.6.10.2.1.1. PLL Wrapper Placeholder Address Map . . . 899
2.1.6.10.2.1.1.1. mem_array[954] . . . 899
2.1.6.10.2.1.2. PVT Wrapper Placeholder Address Map . . . 899
2.1.6.10.2.1.2.1. mem_array[594] . . . 899
2.1.6.10.2.1.3. Straps Address Map . . . 899
2.1.6.10.2.1.3.1. STRAPS_LO . . . 900
2.1.6.10.2.1.3.2. STRAPS_HI . . . 900
2.1.6.10.3. Spare SMC Register Blocks . . . 900
2.1.6.10.3.1. Chip Config, Scratch, NDM Reset, and Misc Wrap . . . 900
2.1.6.10.3.1.1. Chip Configuration Address Map . . . 900
2.1.6.10.3.1.1.1. VERSION_LO . . . 901
2.1.6.10.3.1.1.2. VERSION_HI . . . 901
2.1.6.10.3.1.1.3. CHIP_ID . . . 901
2.1.6.10.3.1.1.4. LC_STATE . . . 901
2.1.6.10.3.1.2. Scratch Address Map . . . 901
2.1.6.10.3.1.2.1. SCRATCH[8] . . . 901
2.1.6.10.3.1.3. NDM Reset Control Address Map . . . 901
2.1.6.10.3.1.3.1. NDMRESET_REQUEST . . . 902
2.1.6.10.3.1.3.2. NDMRESET_PROCESS . . . 902
2.1.6.10.3.1.3.3. NDMRESET_CLUSTER_COUNT . . . 902
2.1.6.10.3.1.4. SMC Miscellaneous Wrapper Address Map . . . 902
2.1.6.10.3.1.4.1. scratch_cold.SCRATCH[8] . . . 903
2.1.6.10.3.1.4.2. scratch_cold_warm.SCRATCH[8] . . . 903
2.1.6.10.3.1.4.3. VERSION_LO . . . 903
2.1.6.10.3.1.4.4. VERSION_HI . . . 903
2.1.6.10.3.1.4.5. CHIP_ID . . . 903
2.1.6.10.3.1.4.6. LC_STATE . . . 903
2.1.6.10.3.1.4.7. NDMRESET_REQUEST . . . 904
2.1.6.10.3.1.4.8. NDMRESET_PROCESS . . . 904
2.1.6.10.3.1.4.9. NDMRESET_CLUSTER_COUNT . . . 904
2.1.6.10.3.2. Base Config and DFX Status . . . 904
2.1.6.10.3.2.1. SMC Base Configuration Address Map . . . 904
2.1.6.10.3.2.1.1. GLOBAL_BASE . . . 905
2.1.6.10.3.2.1.2. LOCAL_BASE . . . 905
2.1.6.10.3.2.1.3. REGION_SIZE . . . 905

2.1.6.10.3.2.1.4. CLOCK_GATE_CONTROL . . . 905
2.1.6.10.3.2.1.5. HANG_DET_SYS_AXI_CTRL . . . 906
2.1.6.10.3.2.1.6. HANG_DET_SYS_AXI_TIMEOUT_THRESHOLD . . . 906
2.1.6.10.3.2.1.7. HANG_DET_SEP_AXI_CTRL . . . 906
2.1.6.10.3.2.1.8. HANG_DET_SEP_AXI_TIMEOUT_THRESHOLD . . . 907
2.1.6.10.3.2.1.9. HANG_DET_DATA_ACCEL_CTRL . . . 907
2.1.6.10.3.2.1.10. HANG_DET_DATA_ACCEL_TIMEOUT_THRESHOLD . . . 907
2.1.6.10.3.2.2. DFX Control and Status Address Map . . . 908
2.1.6.10.3.2.2.1. STATUS_SMU . . . 908
2.1.6.10.3.2.2.2. DEBUG_CTRL . . . 908
2.1.6.10.3.2.2.3. DEBUG_BUS_MUX . . . 909
2.1.6.10.3.3. Component Register References . . . 910
2.1.7. Debug & Test Ports (DTP) . . . 910
2.1.7.1. Capabilities . . . 910
2.1.7.2. Overview . . . 910
2.1.7.2.1. JTAG Interface Unit . . . 912
2.1.7.2.2. Cross Trigger Network . . . 912
2.1.7.2.3. Debug Access Paths . . . 912
2.1.7.3. Clocks and Resets . . . 913
2.1.7.3.1. Clock Domains . . . 913
2.1.7.3.2. Reset Architecture . . . 913
2.1.7.3.3. IC_RESET Overrides . . . 913
2.1.7.3.4. Clock Stop . . . 914
2.1.7.3.4.1. Halt Path Architecture . . . 914
2.1.7.3.4.2. Signal Flow . . . 916
2.1.7.3.5. Clock Distribution . . . 916
2.1.7.3.6. Reset Distribution . . . 917
2.1.7.4. JTAG Operation . . . 919
2.1.7.4.1. DTP JTAG Topology . . . 919
2.1.7.4.2. STAP Secondary Scan Path . . . 920
2.1.7.4.3. JTAG2AXI Bridges . . . 920
2.1.7.4.4. Debug Disable . . . 920
2.1.7.5. Cross-Trigger Operation . . . 921
2.1.7.5.1. Event Routing . . . 921
2.1.7.5.2. Clock Stop . . . 921
2.1.7.5.3. Programming Reference . . . 921
2.1.7.6. IP Reference . . . 922
2.1.7.6.1. JTAG . . . 922
2.1.7.6.1.1. JTAG Interface Unit . . . 922
2.1.7.6.1.1.1. Overview . . . 922
2.1.7.6.1.1.2. Configuration Parameters . . . 922
2.1.7.6.1.1.3. Architecture . . . 922
2.1.7.6.1.1.3.1. Scan Chain Topology . . . 923
2.1.7.6.1.1.3.1.1. STAP Chain Hierarchy . . . 923

2.1.7.6.1.1.3.1.2. Debug Disable Synchronization . . . 924
2.1.7.6.1.1.3.2. iJTAG Network . . . 924
2.1.7.6.1.1.3.2.1. DFT Secure Chain . . . 925
2.1.7.6.1.1.3.2.2. DFT Non-Secure Chain . . . 925
2.1.7.6.1.1.3.2.3. DFD Chain . . . 925
2.1.7.6.1.1.3.3. JTAG2AXI Interfaces . . . 925
2.1.7.6.1.1.4. Interface . . . 925
2.1.7.6.1.1.4.1. Instruction Encodings . . . 925
2.1.7.6.1.1.4.2. Signal Interface . . . 927
2.1.7.6.1.1.4.3. Dependencies . . . 927
2.1.7.6.1.2. JTAG PTAP . . . 927
2.1.7.6.1.2.1. Overview . . . 927
2.1.7.6.1.2.2. Configuration Parameters . . . 928
2.1.7.6.1.2.3. Architecture . . . 928
2.1.7.6.1.2.3.1. Module Hierarchy . . . 930
2.1.7.6.1.2.3.2. TAP Controller State Machine . . . 930
2.1.7.6.1.2.3.3. Reset Hierarchy . . . 931
2.1.7.6.1.2.3.4. TDR Multiplexer . . . 932
2.1.7.6.1.2.3.4.1. Zero-Length Bypass . . . 932
2.1.7.6.1.2.3.5. TDO Retiming . . . 932
2.1.7.6.1.2.3.6. ID Code . . . 932
2.1.7.6.1.2.3.7. Debug Control . . . 933
2.1.7.6.1.2.3.8. JTAG Capabilities . . . 933
2.1.7.6.1.2.3.9. Boundary Scan Support . . . 934
2.1.7.6.1.2.3.10. BIST Support . . . 934
2.1.7.6.1.2.3.11. Test Mode Persistence (TMP) Support . . . 934
2.1.7.6.1.2.3.12. 3DIC Support . . . 935
2.1.7.6.1.2.3.13. IC_RESET Support . . . 935
2.1.7.6.1.2.3.14. iJTAG Support . . . 936
2.1.7.6.1.2.3.15. JTAG2AXI Support . . . 936
2.1.7.6.1.2.3.15.1. *_JTAG2AXI_CAPS . . . 936
2.1.7.6.1.2.3.15.2. *_AXI_SINGLE_OP . . . 937
2.1.7.6.1.2.3.15.3. *_AXI_SERIES_CTRL . . . 938
2.1.7.6.1.2.3.15.4. *_AXI_SERIES_DATA_INCR . . . 939
2.1.7.6.1.2.3.15.5. *_AXI_SERIES_DATA_NO_INCR . . . 940
2.1.7.6.1.2.3.15.6. *_AXI_SERIES_DATA_WITH_ERROR_STATUS . . . 942
2.1.7.6.1.2.3.15.7. System Reset Recovery . . . 943
2.1.7.6.1.2.3.16. Debug Disable . . . 943
2.1.7.6.1.2.4. Interface . . . 943
2.1.7.6.1.2.4.1. Instruction Encodings . . . 943
2.1.7.6.1.2.4.2. Signal Interface . . . 945
2.1.7.6.1.2.4.3. Dependencies . . . 945
2.1.7.6.1.3. JTAG STAP . . . 945
2.1.7.6.1.3.1. Overview . . . 945

2.1.7.6.1.3.2. Configuration Parameters . . . 946
2.1.7.6.1.3.3. Architecture . . . 946
2.1.7.6.1.3.3.1. Module Hierarchy . . . 946
2.1.7.6.1.3.3.2. STAP Module . . . 946
2.1.7.6.1.3.3.3. 3DCR Register . . . 947
2.1.7.6.1.3.3.4. STAP Types . . . 948
2.1.7.6.1.3.3.5. Debug Disable . . . 948
2.1.7.6.1.3.3.6. Lockup Latches . . . 948
2.1.7.6.1.3.3.6.1. TDO Lockup Latch . . . 949
2.1.7.6.1.3.3.6.2. TDI Lockup Latch . . . 949
2.1.7.6.1.3.3.6.3. Scan Output Lockup Latch . . . 949
2.1.7.6.1.3.4. Interface . . . 949
2.1.7.6.1.3.4.1. Signal Interface . . . 949
2.1.7.6.1.3.4.2. Timing Requirements . . . 949
2.1.7.6.1.3.4.3. Dependencies . . . 949
2.1.7.6.2. Cross-Trigger . . . 949
2.1.7.6.2.1. Cross-Trigger Network . . . 949
2.1.7.6.2.1.1. Overview . . . 950
2.1.7.6.2.1.2. Configuration Parameters . . . 950
2.1.7.6.2.1.3. Architecture . . . 950
2.1.7.6.2.1.3.1. Cross Trigger Port (CTP) . . . 951
2.1.7.6.2.1.3.1.1. Wire-OR Mode . . . 951
2.1.7.6.2.1.3.1.2. Point-to-Point Mode . . . 952
2.1.7.6.2.1.3.2. Cross Trigger Matrix (CTM) . . . 952
2.1.7.6.2.1.3.3. Address Map . . . 953
2.1.7.6.2.1.3.4. Internal vs External CTP Architecture . . . 953
2.1.7.6.2.1.3.4.1. Internal CTP Signal Remapping . . . 953
2.1.7.6.2.1.3.5. Signal Flow . . . 954
2.1.7.6.2.1.3.6. Clock Stop Control . . . 954
2.1.7.6.2.1.3.7. Port Indexing . . . 955
2.1.7.6.2.1.4. Interface . . . 955
2.1.7.6.2.1.4.1. Cross Trigger Port (CTP) . . . 955
2.1.7.6.2.1.4.2. Cross Trigger Matrix (CTM) . . . 955
2.1.7.6.2.1.4.3. Cross Trigger Network Module Interface . . . 955
2.1.7.6.2.1.4.4. Dependencies . . . 956
2.1.7.6.2.1.5. Programming . . . 956
2.1.7.6.2.1.6. Memory Map . . . 956
2.1.7.6.2.1.6.1. Memory Map . . . 956
2.1.7.6.2.1.6.2. Detailed Register Map . . . 956
2.1.7.6.2.1.6.2.1. Cross Trigger Matrix Registers . . . 956
2.1.7.6.2.1.6.2.1.1. Cross Trigger Matrix Address Map . . . 956
2.1.7.6.2.1.6.2.1.1.1. CT_SRC[26].CONFIG_0 . . . 957
2.1.7.6.2.1.6.2.2. Cross Trigger Port Registers . . . 957
2.1.7.6.2.1.6.2.2.1. Cross Trigger Port Address Map . . . 957

2.1.7.6.2.1.6.2.2.1.1. CONFIG . . . 957
2.1.7.6.2.1.6.2.2.1.2. STATUS . . . 958
2.1.7.6.2.1.6.2.2.1.3. STRETCH_MULT . . . 958
2.1.7.6.2.1.6.2.3. Composite Network Registers . . . 958
2.1.7.6.2.1.6.2.3.1. Cross Trigger Network Address Map . . . 958
2.1.7.6.2.1.6.2.3.1.1. CT_SRC[26].CONFIG_0 . . . 959
2.1.7.6.2.1.6.2.3.1.2. ctp[16].CONFIG . . . 959
2.1.7.6.2.1.6.2.3.1.3. ctp[16].STATUS . . . 959
2.1.7.6.2.1.6.2.3.1.4. ctp[16].STRETCH_MULT . . . 960
2.1.7.6.2.2. Cross-Trigger Port . . . 960
2.1.7.6.2.2.1. Overview . . . 960
2.1.7.6.2.2.2. Configuration . . . 961
2.1.7.6.2.2.3. Architecture . . . 961
2.1.7.6.2.2.3.1. Submodule Hierarchy . . . 962
2.1.7.6.2.2.3.2. Wire-OR Mode . . . 963
2.1.7.6.2.2.3.2.1. Pulse Stretcher Operation . . . 963
2.1.7.6.2.2.3.3. Point-to-Point Mode . . . 964
2.1.7.6.2.2.3.3.1. Synchronization and CDC Handling . . . 966
2.1.7.6.2.2.3.3.2. Handshake State Machines . . . 967
2.1.7.6.2.2.4. Interface . . . 968
2.1.7.6.2.2.4.1. Signal Interface . . . 968
2.1.7.6.2.2.4.2. Dependencies . . . 968
2.1.7.6.2.3. Cross-Trigger Matrix . . . 968
2.1.7.6.2.3.1. Overview . . . 968
2.1.7.6.2.3.2. Architecture . . . 969
2.1.7.6.2.3.2.1. Routing Logic . . . 970
2.1.7.6.2.3.2.2. Port Indexing . . . 970
2.1.7.6.2.3.3. Interface . . . 970
2.1.7.6.2.3.3.1. Signal Interface . . . 970
2.1.7.6.2.3.3.2. Data Ports . . . 971
2.1.7.6.2.3.3.3. Dependencies . . . 971
2.1.7.7. Configuration and Reference . . . 971
2.1.7.7.1. Port Reference . . . 971
2.1.7.7.2. Configuration Parameters . . . 975
2.1.7.7.3. Address Map . . . 975
2.2. System Management Network (SMN) . . . 975
2.2.1. SMU Interface . . . 975
2.2.2. Addressing and Integration . . . 975
2.3. AXI-over-UCIe Bridge (AoU) . . . 976
2.3.1. Overview and Features . . . 976
2.3.1.1. Introduction . . . 976
2.3.1.1.1. Overview . . . 976
2.3.1.2. Features . . . 977
2.3.1.2.1. Basic features . . . 977

2.3.2. Architecture . . . 978
2.3.2.1. Block diagram . . . 978
2.3.2.2. TX_CORE . . . 979
2.3.2.2.1. TX_CORE QoS Scheme . . . 980
2.3.2.3. RX_CORE . . . 983
2.3.2.4. Message FIFO . . . 985
2.3.2.5. Data width converter . . . 986
2.3.2.5.1. Overview . . . 986
2.3.2.5.2. Width Adaptation Paths . . . 987
2.3.2.5.3. WLAST Regeneration . . . 988
2.3.2.6. AXI Transaction Splitter . . . 988
2.3.2.6.1. Overview . . . 988
2.3.2.6.2. Burst Splitting . . . 988
2.3.2.6.3. Response Reassembly . . . 989
2.3.2.6.4. SFR Configuration . . . 989
2.3.2.7. Write Early Response Controller . . . 990
2.3.2.7.1. Overview . . . 990
2.3.2.7.2. Transaction Flow -- Normal Case . . . 990
2.3.2.7.3. Transaction Flow -- Error Case . . . 991
2.3.2.7.4. ID Ordering . . . 991
2.3.2.7.5. Write-Outstanding Queue Backpressure . . . 992
2.3.2.7.6. Mixed Ordering -- Bufferable Before Non-Bufferable (Same ID) . . . 993
2.3.2.7.7. Mixed Ordering -- Non-Bufferable Before Bufferable (Same ID) . . . 995
2.3.2.7.8. Enable/Disable Procedure . . . 996
2.3.2.7.9. SFR Fields . . . 996
2.3.2.8. AXI Aggregator . . . 997
2.3.2.8.1. Overview . . . 997
2.3.2.8.2. Write Aggregation . . . 997
2.3.2.8.3. Read Aggregation . . . 998
2.3.2.8.4. SFR Fields . . . 998
2.3.2.9. Credit Controller . . . 999
2.3.2.10. RP Remapping . . . 1003
2.3.2.10.1. Configuration Rules . . . 1003
2.3.2.10.2. Header Encoding . . . 1004
2.3.2.10.3. Misconfiguration Behavior . . . 1004
2.3.2.11. UCIe Flit cancel mechanism . . . 1004
2.3.2.11.1. Cancel Cases . . . 1005
2.3.2.11.2. RX_FDI_IF Buffering . . . 1006
2.3.2.11.3. Timing . . . 1006
2.3.3. Interrupts and Errors . . . 1006
2.3.3.1. Interrupt . . . 1006
2.3.3.2. Error . . . 1008
2.3.4. PPA and Appendices . . . 1008
2.3.4.1. PPA . . . 1008

2.3.4.1.1. Performance . . . 1008
2.3.4.1.2. Power . . . 1011
2.3.4.1.3. Area . . . 1011
2.3.4.2. Appendix B. Referenced Documents . . . 1012
3. IP Reference . . . 1013
3.1. Management and I/O . . . 1013
3.2. Security . . . 1013
3.3. Debug and cross-trigger . . . 1013
3.4. Interconnect infrastructure . . . 1013
3.4.1. AXI Traffic Filter . . . 1013
3.4.1.1. Instances . . . 1014
3.4.1.2. Match, Then Permit . . . 1014
3.4.1.3. Address Range Granule . . . 1015
3.4.1.4. Blocked Transactions . . . 1015
3.4.1.5. Locking a Filter Entry . . . 1015
Appendix A: Register Field Access Notation . . . 1016
A.1. References . . . 1016
Appendix B: Referenced Documents . . . 1018
B.1. OCAH Documentation . . . 1018
B.2. OCA Specifications . . . 1018
B.3. Interface and Security Standards . . . 1018
B.4. External Design Documentation . . . 1019

Documentation Overview

The Open Chiplet Atlas Harness (OCAH) is a chiplet design IP where the non-application-specific functions are integrated to form a chiplet design framework. These non-application-specific functions include common chiplet subsystems within the System Management Unit (SMU): Security Processor (SEP), System Management Controller (SMC), and Debug & Test Ports (DTP). The System Management Network (SMN) and AXI-over-UCIe bridge (AoU) are separate platform components.

This manual is the architecture and register-level reference for those blocks. Motivation, use cases, and the OCA-layer feature overview are on the OCAH documentation home page.

List of Figures

Figure 1. OCAH Top-Level Block Diagram

Figure 2. OCAH Clock-Domain Zones

Figure 3. SMU composition with the optional SEP subsystem

Figure 4. SMU AXI crossbar connectivity

Figure 5. SMU aperture decode and routing

Figure 6. SMU clock distribution

Figure 7. SMU reset distribution

Figure 8. SEP lifecycle and feature-control propagation to SMC and DTP

Figure 9. SEP top-level microarchitecture

Figure 10. SEP clock tree and clock domains

Figure 11. SEP reset domains and reset sequencing

Figure 12. SEP Reset Controller reset logic

Figure 13. SEP crypto AXI isolation

Figure 14. SEP VeeR EL2 CPU subsystem and memory interfaces

Figure 15. SEP AXI4 connectivity. Filled circles indicate connections; dashes indicate no connection.

Figure 16. SEP input fabric

Figure 17. SEP local fabric

Figure 18. SEP output fabric

Figure 19. SEP system-peripheral traffic management

Figure 20. OpenTitan DMA core and inline hashing reference architecture

Figure 21. SEP secure DMA integration

Figure 22. SEP host mailbox architecture and interrupt routing

Figure 23. SEP peripheral extension port

Figure 24. SEP OTP fuse bank

Figure 25. eFuse controller and technology-specific interface shim

Figure 26. eFuse sensing state machine and shadow-register timing

Figure 27. SEP token processing

Figure 28. SEP lifecycle controller

Figure 29. SEP lifecycle state machine

Figure 30. SEP security domains

Figure 31. SEP cryptographic subsystem and external memory interfaces

Figure 32. SEP cryptographic subsystem resets

Figure 33. SEP TRNG and DRBG entropy distribution

Figure 34. Entropy source microarchitecture

Figure 35. Entropy source ring-oscillator complex
Figure 36. Entropy source decorrelator
Figure 37. OpenTitan AES core reference architecture
Figure 38. OpenTitan HMAC core reference architecture
Figure 39. OpenTitan KMAC core reference architecture
Figure 40. Adams Bridge ML-DSA reference architecture
Figure 41. Adams Bridge ML-KEM reference architecture
Figure 42. OpenTitan OTBN core reference architecture
Figure 43. Key Manager architecture
Figure 44. Key Manager cold and warm reset conditioning
Figure 45. Key Manager mailbox transport
Figure 46. Key Manager accelerator key path
Figure 47. SEP host and Key Manager key-load and key-transfer sequence
Figure 48. SRAM scrambler datapath
Figure 49. SMC top-level microarchitecture
Figure 50. SMC clock tree and clock domains in u_smc_base
Figure 51. SMC clock tree and clock domains in u_smc_cpu_wrapper and u_smc_peripherals
Figure 52. SMC reset unit architecture
Figure 53. SMC FLR isolation connections between chiplets
Figure 54. SMC-driven FLR isolation
Figure 55. Tile-request-driven FLR isolation
Figure 56. GPIO-driven FLR isolation
Figure 57. SMC CPU cluster and TileLink-to-AXI integration
Figure 58. SMC input fabric topology and routing
Figure 59. SMC local fabric and peripheral islands
Figure 60. SMC output fabric and remapping paths
Figure 61. SMC inbound and outbound traffic-filter mechanism
Figure 62. SMC DMA frontend, backend and shared fabric path
Figure 63. SMC memory zeroer state machine and AXI write flow
Figure 64. SMC mailbox wrapper and interrupt routing
Figure 65. System Timer OCTS primary/secondary synchronization and credit CDC
Figure 66. SMC UART wrapper
Figure 67. SMC log-engine wrapper and data paths
Figure 68. OpenTitan I2C core reference architecture
Figure 69. OCAH I2C wrapper and generated register interface
Figure 70. CHIPS Alliance i3c-core reference architecture

Figure 71. OCAH I3C wrapper

Figure 72. AVSBus controller block diagram

Figure 73. AVSBus protocol state machine

Figure 74. AVSBus clock selection

Figure 75. GPIO controller, interface shim, LSIO mux and strap-capture path

Figure 76. SMC pad ring GPIO interfaces and adopter pad shims

Figure 77. SMC DFD block diagram

Figure 78. DTP internal structure

Figure 79. DTP JTAG and CLA clock-stop aggregation

Figure 80. DTP system-clock and JTAG-clock distribution

Figure 81. DTP system and JTAG reset distribution

Figure 82. DTP JTAG scan chain

Figure 83. JTAG Interface Unit scan chain

Figure 84. PTAP module architecture

Figure 85. JTAG2AXI single-operation layout

Figure 86. JTAG2AXI series-control layout

Figure 87. JTAG2AXI incrementing data layout for effective size 0

Figure 88. JTAG2AXI incrementing data layout for effective size 1

Figure 89. JTAG2AXI incrementing data layout for effective size 2

Figure 90. JTAG2AXI incrementing data layout for effective size 3

Figure 91. JTAG2AXI non-incrementing data layout for effective size 0

Figure 92. JTAG2AXI non-incrementing data layout for effective size 1

Figure 93. JTAG2AXI non-incrementing data layout for effective size 2

Figure 94. JTAG2AXI non-incrementing data layout for effective size 3

Figure 95. JTAG2AXI error-status data layout for effective size 0

Figure 96. JTAG2AXI error-status data layout for effective size 1

Figure 97. JTAG2AXI error-status data layout for effective size 2

Figure 98. JTAG2AXI error-status data layout for effective size 3

Figure 99. STAP scan and control paths

Figure 100. SiP cross-trigger topology

Figure 101. CTP module structure

Figure 102. CTP wire-OR behavior

Figure 103. CTP wire-OR chiplet connections

Figure 104. CTP point-to-point behavior

Figure 105. CTP point-to-point chiplet connections

Figure 106. CTP request-acknowledge timing

Figure 107. CTM routing structure
Figure 108. Block Diagram of AOU_CORE and function description
Figure 109. Architecture of AOU_CORE
Figure 110. Block Diagram of Single RP AOU_TX_CORE
Figure 111. TX_CORE QoS Scheme
Figure 112. Round-Robin arbitration example
Figure 113. Port QoS arbitration example
Figure 114. AXI QoS arbitration example
Figure 115. Block Diagram of AOU_RX_CORE
Figure 116. Architecture of Chunk Decoder
Figure 117. Data FIFO
Figure 118. Req / Resp FIFO
Figure 119. AXI4MUX_3X1_TOP
Figure 120. AoU successful early write response
Figure 121. AoU error after an early write response
Figure 122. AoU write-outstanding backpressure
Figure 123. AoU bufferable then non-bufferable writes
Figure 124. AoU non-bufferable then bufferable writes
Figure 125. Write Aggregation -- Narrow-to-Wide Beat Merging
Figure 126. Block Diagram of AOU_CRD_CTRL
Figure 127. Example of WDATA and WSTRB FIFO Operation
Figure 128. Example of RDATA FIFO Operation
Figure 129. Resource Plane Remapping
Figure 130. UCIe Flit Cancel - Retransmit case
Figure 131. UCIe Flit Cancel - Flit Partially Valid case
Figure 132. UCIe Flit Cancel - Full Flit Cancel case
Figure 133. Example of selecting valid chunks for RX_CORE
Figure 134. Initial Latency of AOU_CORE with UCIe (Cycle)
Figure 135. AoU Bandwidth Efficiency with Respect to UCIe FDI Latency
Figure 136. Area of 1 RP AOU

List of Tables

Table 1. OCAH address-map configuration layers

Table 2. Decode response codes

Table 3. OCAH Clock Domains

Table 4. RTL assertion macro families

Table 5. SMU AXI crossbar ports

Table 6. SMU AXI crossbar routing by initiator and decoded aperture

Table 7. SEP lifecycle and feature-control effects

Table 8. SEP clock inputs

Table 9. SEP reset boundaries

Table 10. SEP SW_RESET_N fields

Table 11. Paths isolated before each software reset

Table 12. SEP Reset Control Address Map register list

Table 13. sep_reset_ctrl.SW_RESET_N fields

Table 14. AxPROT driven by the SEP bus masters

Table 15. SEP processor configuration

Table 16. SEP closely coupled memories

Table 17. Scratch-bank reset behavior

Table 18. SEP Scratch Address Map register list

Table 19. sep_scratch.SCRATCH[8] fields

Table 20. SEP CPU Control Address Map register list

Table 21. sep_cpu_ctrl.CLOCK_GATE_CTRL fields

Table 22. sep_cpu_ctrl.REFERENCE_COUNTER fields

Table 23. sep_cpu_ctrl.TIMEOUT_INTERRUPT fields

Table 24. sep_cpu_ctrl.PKA_CTRL fields

Table 25. sep_cpu_ctrl.TIMEOUT_COUNT_DMA fields

Table 26. sep_cpu_ctrl.TIMEOUT_COUNT_SYS_IN fields

Table 27. sep_cpu_ctrl.TIMEOUT_COUNT_MAILBOX_INBOUND fields

Table 28. sep_cpu_ctrl.TIMEOUT_COUNT_MAILBOX_OUTBOUND fields

Table 29. sep_cpu_ctrl.TIMEOUT_COUNT_ENTROPY_WRITE fields

Table 30. sep_cpu_ctrl.TIMEOUT_COUNT_ENTROPY_READ fields

Table 31. sep_cpu_ctrl.TIMEOUT_COUNT_FILTER_OUT fields

Table 32. sep_cpu_ctrl.TIMEOUT_COUNT_ALIAS_REMAP fields

Table 33. sep_cpu_ctrl.TIMEOUT_ENABLE fields

Table 34. sep_cpu_ctrl.TIMEOUT_CLEAR fields

Table 35. sep_cpu_ctrl.TIMEOUT_MODE fields
Table 36. sep_cpu_ctrl.SEP_TEST_CTRL fields
Table 37. sep_cpu_ctrl.SEP_GLOBAL_BASE_ADDR fields
Table 38. sep_cpu_ctrl.SEP_LOCAL_BASE_ADDR fields
Table 39. sep_cpu_ctrl.SEP_REGION_SIZE fields
Table 40. sep_cpu_ctrl.SMU_GLOBAL_BASE_ADDR fields
Table 41. sep_cpu_ctrl.SMU_REGION_SIZE fields
Table 42. sep_cpu_ctrl.SMC_FUSE_SENSE_STATUS fields
Table 43. sep_cpu_ctrl.SEP_FUSE_SENSE_STATUS fields
Table 44. sep_cpu_ctrl.SEP_SW_DEBUG fields
Table 45. sep_cpu_ctrl.SEP_NMI_VEC fields
Table 46. sep_cpu_ctrl.SEP_NMI_VEC_LOCK fields
Table 47. sep_cpu_ctrl.EXT_TRNG_SRC_SEL fields
Table 48. sep_cpu_ctrl.EXT_TRNG_SRC_SEL_LOCK fields
Table 49. sep_cpu_ctrl.KM_WIPE_CTRL fields
Table 50. sep_cpu_ctrl.DMA_BUS_ERR_STATUS fields
Table 51. sep_cpu_ctrl.DMA_BUS_ERR_CLEAR fields
Table 52. sep_cpu_ctrl.PERIPH_BUS_ERR_STATUS fields
Table 53. sep_cpu_ctrl.PERIPH_BUS_ERR_CLEAR fields
Table 54. sep_cpu_ctrl.SEP_VERSION_ID fields
Table 55. SEP AXI4 connectivity terms
Table 56. SEP PIC source assignments
Table 57. SEP correctable-error counters
Table 58. SEP uncorrectable-error traps
Table 59. EL2_PIC register list
Table 60. el2_pic.meipl[256] fields
Table 61. el2_pic.meip[8] fields
Table 62. el2_pic.meie[256] fields
Table 63. el2_pic.mpiccfg fields
Table 64. el2_pic.meigwctrl[256] fields
Table 65. el2_pic.meigwclr[256] fields
Table 66. DMA Controller register list
Table 67. secure_dma.INTR_STATE fields
Table 68. secure_dma.INTR_ENABLE fields
Table 69. secure_dma.INTR_TEST fields
Table 70. secure_dma.ALERT_TEST fields

Table 71. secure_dma.SRC_ADDR_LO fields
Table 72. secure_dma.SRC_ADDR_HI fields
Table 73. secure_dma.DST_ADDR_LO fields
Table 74. secure_dma.DST_ADDR_HI fields
Table 75. secure_dma.ADDR_SPACE_ID fields
Table 76. secure_dma.ENABLED_MEMORY_RANGE_BASE fields
Table 77. secure_dma.ENABLED_MEMORY_RANGE_LIMIT fields
Table 78. secure_dma.RANGE_VALID fields
Table 79. secure_dma.RANGE_REGWEN fields
Table 80. secure_dma.CFG_REGWEN fields
Table 81. secure_dma.TOTAL_DATA_SIZE fields
Table 82. secure_dma.CHUNK_DATA_SIZE fields
Table 83. secure_dma.TRANSFER_WIDTH fields
Table 84. secure_dma.CONTROL fields
Table 85. secure_dma.SRC_CONFIG fields
Table 86. secure_dma.DST_CONFIG fields
Table 87. secure_dma.STATUS fields
Table 88. secure_dma.ERROR_CODE fields
Table 89. secure_dma.SHA2_DIGEST_0[16] fields
Table 90. secure_dma.HANDSHAKE_INTR_ENABLE fields
Table 91. secure_dma.CLEAR_INTR_SRC fields
Table 92. secure_dma.CLEAR_INTR_BUS fields
Table 93. secure_dma.INTR_SRC_ADDR_0[11] fields
Table 94. secure_dma.INTR_SRC_WR_VAL_0[11] fields
Table 95. SEP mailbox qualification
Table 96. Features
Table 97. Interrupts
Table 98. SPI Host register list
Table 99. spi_controller.INTR_STATE fields
Table 100. spi_controller.INTR_ENABLE fields
Table 101. spi_controller.INTR_TEST fields
Table 102. spi_controller.ALERT_TEST fields
Table 103. spi_controller.CONTROL fields
Table 104. spi_controller.STATUS fields
Table 105. spi_controller.CONFIGOPTS fields
Table 106. spi_controller.CSID fields

Table 107. spi_controller.COMMAND fields
Table 108. spi_controller.ERROR_ENABLE fields
Table 109. spi_controller.ERROR_STATUS fields
Table 110. spi_controller.EVENT_ENABLE fields
Table 111. Always-On Timer register list
Table 112. aon_timer.ALERT_TEST fields
Table 113. aon_timer.WKUP_CTRL fields
Table 114. aon_timer.WKUP_THOLD_HI fields
Table 115. aon_timer.WKUP_THOLD_LO fields
Table 116. aon_timer.WKUP_COUNT_HI fields
Table 117. aon_timer.WKUP_COUNT_LO fields
Table 118. aon_timer.WDOG_REGWEN fields
Table 119. aon_timer.WDOG_CTRL fields
Table 120. aon_timer.WDOG_BARK_THOLD fields
Table 121. aon_timer.WDOG_BITE_THOLD fields
Table 122. aon_timer.WDOG_COUNT fields
Table 123. aon_timer.INTR_STATE fields
Table 124. aon_timer.INTR_TEST fields
Table 125. aon_timer.WKUP_CAUSE fields
Table 126. SEP fuse fields
Table 127. SEP eFuse Map Address Map register list
Table 128. sep_efuse_map.LOCKS fields
Table 129. sep_efuse_map.LOCKS_SPARE fields
Table 130. sep_efuse_map.LC_STATE fields
Table 131. sep_efuse_map.SBOOT_DIS fields
Table 132. sep_efuse_map.TRANSIENT_RMA_EN fields
Table 133. sep_efuse_map.SIP_DIS fields
Table 134. sep_efuse_map.SYS_DIS fields
Table 135. sep_efuse_map.RMA_SIP_TOKEN_DIGEST fields
Table 136. sep_efuse_map.RMA_CHIPLET_TOKEN_DIGEST fields
Table 137. sep_efuse_map.CLASS_KEY fields
Table 138. sep_efuse_map.CHIPLET_PUBK_REVOKE fields
Table 139. sep_efuse_map.BL1_VERSION fields
Table 140. sep_efuse_map.BL2_VERSION fields
Table 141. sep_efuse_map.CHIPLET_UID fields
Table 142. sep_efuse_map.SIP_PUBK_HASH0 fields

Table 143. sep_efuse_map.SIP_UID fields

Table 144. sep_efuse_map.SYS_PUBK_HASH fields

Table 145. sep_efuse_map.SYS_UID fields

Table 146. sep_efuse_map.STATUS_RPT fields

Table 147. sep_efuse_map.ROM_CTL fields

Table 148. sep_efuse_map.SYSCLK_FREQ_MHZ fields

Table 149. sep_efuse_map.CHIPLET_PUBK_HASH0 fields

Table 150. sep_efuse_map.CHIPLET_PUBK_HASH1 fields

Table 151. sep_efuse_map.REQUIRED_SIGNERS fields

Table 152. sep_efuse_map.REQUIRED_ALGS fields

Table 153. sep_efuse_map.CHIPLET_PUBK_PQC_HASH0 fields

Table 154. sep_efuse_map.CHIPLET_PUBK_PQC_HASH1 fields

Table 155. sep_efuse_map.SIP_PUBK_PQC_HASH0 fields

Table 156. sep_efuse_map.SYS_PUBK_PQC_HASH fields

Table 157. sep_efuse_map.SIP_PUBK_HASH1 fields

Table 158. sep_efuse_map.SIP_PUBK_PQC_HASH1 fields

Table 159. sep_efuse_map.SEP_CHIPLET_ID fields

Table 160. sep_efuse_map.SEP_SIP_ID fields

Table 161. sep_efuse_map.SEP_SYS_ID fields

Table 162. sep_efuse_map.spare0 fields

Table 163. sep_efuse_map.spare1 fields

Table 164. sep_efuse_map.spare2 fields

Table 165. sep_efuse_map.spare3 fields

Table 166. sep_efuse_map.spare4 fields

Table 167. sep_efuse_map.spare5 fields

Table 168. sep_efuse_map.spare6 fields

Table 169. sep_efuse_map.spare7 fields

Table 170. sep_efuse_map.spare8 fields

Table 171. Token roles and expected digests

Table 172. Token submission registers

Table 173. Token result encodings

Table 174. SEP lifecycle state encodings

Table 175. SEP feature-disable vector

Table 176. SEP disable-vector applicability

Table 177. Per-LC-state feature control profile

Table 178. SEP demotion controls

Table 179. SEP security asset classes
Table 180. SEP scan-chain gates
Table 181. DTP access cases
Table 182. DTP path feature gates
Table 183. SEP Lifecycle Control Address Map register list
Table 184. sep_lifecycle_ctrl.FEAT_CTRL fields
Table 185. sep_lifecycle_ctrl.DEMOTE_1 fields
Table 186. sep_lifecycle_ctrl.DEMOTE_2 fields
Table 187. Secure test-mode sampling in the SEP wrapper
Table 188. Required secure-test protections
Table 189. SEP crypto alert and fault routing
Table 190. Key Manager key delivery per accelerator
Table 191. SEP entropy sink paths
Table 192. SEP random-data stream contract
Table 193. TRNG reset effects outside the internal domain
Table 194. DRBG external interfaces
Table 195. Cryptographically Secure Random Number Generator register list
Table 196. csrng.INTR_STATE fields
Table 197. csrng.INTR_ENABLE fields
Table 198. csrng.INTR_TEST fields
Table 199. csrng.ALERT_TEST fields
Table 200. csrng.REGWEN fields
Table 201. csrng.CTRL fields
Table 202. csrng.CMD_REQ fields
Table 203. csrng.RESEED_INTERVAL fields
Table 204. csrng.RESEED_COUNTER_0 fields
Table 205. csrng.RESEED_COUNTER_1 fields
Table 206. csrng.RESEED_COUNTER_2 fields
Table 207. csrng.SW_CMD_STS fields
Table 208. csrng.GENBITS_VLD fields
Table 209. csrng.GENBITS fields
Table 210. csrng.INT_STATE_READ_ENABLE fields
Table 211. csrng.INT_STATE_READ_ENABLE_REGWEN fields
Table 212. csrng.INT_STATE_NUM fields
Table 213. csrng.INT_STATE_VAL fields
Table 214. csrng.FIPS_FORCE fields

Table 215. csrng.HW_EXC_STS fields
Table 216. csrng.RECOV_ALERT_STS fields
Table 217. csrng.ERR_CODE fields
Table 218. csrng.ERR_CODE_TEST fields
Table 219. csrng.MAIN_SM_STATE fields
Table 220. Entropy Distribution Network register list
Table 221. edn.INTR_STATE fields
Table 222. edn.INTR_ENABLE fields
Table 223. edn.INTR_TEST fields
Table 224. edn.ALERT_TEST fields
Table 225. edn.REGWEN fields
Table 226. edn.CTRL fields
Table 227. edn.BOOT_INS_CMD fields
Table 228. edn.BOOT_GEN_CMD fields
Table 229. edn.SW_CMD_REQ fields
Table 230. edn.SW_CMD_STS fields
Table 231. edn.HW_CMD_STS fields
Table 232. edn.RESEED_CMD fields
Table 233. edn.GENERATE_CMD fields
Table 234. edn.MAX_NUM_REQS_BETWEEN_RESEEDS fields
Table 235. edn.RECOV_ALERT_STS fields
Table 236. edn.ERR_CODE fields
Table 237. edn.ERR_CODE_TEST fields
Table 238. edn.MAIN_SM_STATE fields
Table 239. Noise ring-oscillator lengths per lane
Table 240. Entropy Source Address Map register list
Table 241. entropy_source.COMPONENT_ID fields
Table 242. entropy_source.CTRL fields
Table 243. entropy_source.DEBUG_CTRL fields
Table 244. entropy_source.INTR_STATUS fields
Table 245. entropy_source.INTR_ENABLE fields
Table 246. entropy_source.INTR_TEST fields
Table 247. entropy_source.SHA256_STATUS fields
Table 248. entropy_source.FIFO_CTRL fields
Table 249. entropy_source.FIFO_STATUS fields
Table 250. entropy_source.FIFO_RDATA fields

Table 251. entropy_source.HEALTH_TEST_CTRL fields
Table 252. entropy_source.HEALTH_TEST_WINDOW_SIZE fields
Table 253. entropy_source.MARKOV_TEST_PROB_THRESHOLDS fields
Table 254. entropy_source.HEALTH_TEST_STATUS fields
Table 255. entropy_source.REPETITION_TEST_COUNT fields
Table 256. entropy_source.APT_PATTERN_COUNT_1BIT fields
Table 257. entropy_source.APT_PATTERN_COUNT_2BIT fields
Table 258. entropy_source.APT_PROPORTION_1BIT fields
Table 259. entropy_source.APT_PROPORTION_LO fields
Table 260. entropy_source.MARKOV_TEST_COUNTS_0 fields
Table 261. entropy_source.RING_OSC_ENABLE fields
Table 262. entropy_source.RING_OSC_TUNE fields
Table 263. entropy_source.RING_OSC_CTRL fields
Table 264. entropy_source.DECORRELATOR_CTRL fields
Table 265. entropy_source.DECORRELATOR_MASK fields
Table 266. entropy_source.MAIN_SM_STATUS fields
Table 267. entropy_source.GENERATOR_0_HEALTH_STATUS fields
Table 268. entropy_source.GENERATOR_1_HEALTH_STATUS fields
Table 269. entropy_source.GENERATOR_2_HEALTH_STATUS fields
Table 270. entropy_source.GENERATOR_3_HEALTH_STATUS fields
Table 271. entropy_source.GENERATOR_4_HEALTH_STATUS fields
Table 272. entropy_source.GENERATOR_5_HEALTH_STATUS fields
Table 273. entropy_source.GENERATOR_6_HEALTH_STATUS fields
Table 274. entropy_source.GENERATOR_7_HEALTH_STATUS fields
Table 275. entropy_source.GENERATOR_8_HEALTH_STATUS fields
Table 276. entropy_source.GENERATOR_9_HEALTH_STATUS fields
Table 277. entropy_source.GENERATOR_10_HEALTH_STATUS fields
Table 278. entropy_source.GENERATOR_11_HEALTH_STATUS fields
Table 279. entropy_source.GENERATOR_0_SAMPLE_CLK_CONFIG fields
Table 280. entropy_source.GENERATOR_1_SAMPLE_CLK_CONFIG fields
Table 281. entropy_source.GENERATOR_2_SAMPLE_CLK_CONFIG fields
Table 282. entropy_source.GENERATOR_3_SAMPLE_CLK_CONFIG fields
Table 283. entropy_source.GENERATOR_4_SAMPLE_CLK_CONFIG fields
Table 284. entropy_source.GENERATOR_5_SAMPLE_CLK_CONFIG fields
Table 285. entropy_source.GENERATOR_6_SAMPLE_CLK_CONFIG fields
Table 286. entropy_source.GENERATOR_7_SAMPLE_CLK_CONFIG fields

Table 287. entropy_source.GENERATOR_8_SAMPLE_CLK_CONFIG fields
Table 288. entropy_source.GENERATOR_9_SAMPLE_CLK_CONFIG fields
Table 289. entropy_source.GENERATOR_10_SAMPLE_CLK_CONFIG fields
Table 290. entropy_source.GENERATOR_11_SAMPLE_CLK_CONFIG fields
Table 291. entropy_source.HT_WATERMARK_NUM fields
Table 292. entropy_source.HT_WATERMARK fields
Table 293. entropy_source.REPCNT_TOTAL_FAILS fields
Table 294. entropy_source.APT_HI_TOTAL_FAILS fields
Table 295. entropy_source.APT_LO_TOTAL_FAILS fields
Table 296. entropy_source.MARKOV_HI_TOTAL_FAILS fields
Table 297. entropy_source.MARKOV_LO_TOTAL_FAILS fields
Table 298. entropy_source.ALERT_SUMMARY_FAIL_COUNTS fields
Table 299. entropy_source.ALERT_FAIL_COUNTS fields
Table 300. entropy_source.FIPS_LOCK fields
Table 301. entropy_source.ALERT_THRESHOLD fields
Table 302. entropy_source.MIN_ENTROPY_H fields
Table 303. entropy_source.RECOMMENDED_THRESHOLDS fields
Table 304. entropy_source.BIW_OBS_CTRL fields
Table 305. entropy_source.BIW_OBS_STATUS fields
Table 306. entropy_source.BIW_OBS_RDATA fields
Table 307. entropy_source.NOISE_OBS_CTRL fields
Table 308. entropy_source.NOISE_OBS_STATUS fields
Table 309. entropy_source.NOISE_OBS_RDATA fields
Table 310. SEP Entropy Pool register list
Table 311. sep_entropy_pool.STATUS fields
Table 312. sep_entropy_pool.IRQ_CAUSE fields
Table 313. sep_entropy_pool.DATA fields
Table 314. AES Accelerator register list
Table 315. aes.ALERT_TEST fields
Table 316. aes.KEY_SHARE0[8] fields
Table 317. aes.KEY_SHARE1[8] fields
Table 318. aes.IV[4] fields
Table 319. aes.DATA_IN[4] fields
Table 320. aes.DATA_OUT[4] fields
Table 321. aes.CTRL_SHADOWED fields
Table 322. aes.CTRL_AUX_SHADOWED fields

Table 323. aes.CTRL_AUX_REGWEN fields
Table 324. aes.TRIGGER fields
Table 325. aes.STATUS fields
Table 326. aes.CTRL_GCM_SHADOWED fields
Table 327. HMAC Accelerator register list
Table 328. hmac.INTR_STATE fields
Table 329. hmac.INTR_ENABLE fields
Table 330. hmac.INTR_TEST fields
Table 331. hmac.ALERT_TEST fields
Table 332. hmac.CFG fields
Table 333. hmac.CMD fields
Table 334. hmac.STATUS fields
Table 335. hmac.ERR_CODE fields
Table 336. hmac.WIPE_SECRET fields
Table 337. hmac.KEY[32] fields
Table 338. hmac.DIGEST[16] fields
Table 339. hmac.MSG_LENGTH_LOWER fields
Table 340. hmac.MSG_LENGTH_UPPER fields
Table 341. KMAC Accelerator register list
Table 342. kmac.INTR_STATE fields
Table 343. kmac.INTR_ENABLE fields
Table 344. kmac.INTR_TEST fields
Table 345. kmac.ALERT_TEST fields
Table 346. kmac.CFG_REGWEN fields
Table 347. kmac.CFG_SHADOWED fields
Table 348. kmac.CMD fields
Table 349. kmac.STATUS fields
Table 350. kmac.ENTROPY_PERIOD fields
Table 351. kmac.ENTROPY_REFRESH_HASH_CNT fields
Table 352. kmac.ENTROPY_REFRESH_THRESHOLD_SHADOWED fields
Table 353. kmac.ENTROPY_SEED fields
Table 354. kmac.KEY_SHARE0[16] fields
Table 355. kmac.KEY_SHARE1[16] fields
Table 356. kmac.KEY_LEN fields
Table 357. kmac.PREFIX[11] fields
Table 358. kmac.ERR_CODE fields

Table 359. OpenTitan Big Number Accelerator register list
Table 360. otbn.INTR_STATE fields
Table 361. otbn.INTR_ENABLE fields
Table 362. otbn.INTR_TEST fields
Table 363. otbn.ALERT_TEST fields
Table 364. otbn.CMD fields
Table 365. otbn.CTRL fields
Table 366. otbn.STATUS fields
Table 367. otbn.ERR_BITS fields
Table 368. otbn.FATAL_ALERT_CAUSE fields
Table 369. otbn.INSN_CNT fields
Table 370. otbn.LOAD_CHECKSUM fields
Table 371. Key Manager reset inputs
Table 372. Key Manager reset-domain assignment
Table 373. Key Manager message with payload
Table 374. Key Manager header-only message
Table 375. Adams Bridge seed sideload inputs
Table 376. KM CPU interrupt routing
Table 377. KPV per-slot controls
Table 378. Key Manager VERSION fields
Table 379. Key Manager interrupt sources
Table 380. Key Manager executable regions
Table 381. DRBG sampler register behavior
Table 382. Key Manager DRBG sampler states
Table 383. Key Manager OTP readout registers
Table 384. CRC Accelerator Instructions
Table 385. Key Manager warm-persistent SRAM contents
Table 386. SRAM scrambler S-box
Table 387. SRAM scrambler permutation for bits 31 to 16
Table 388. SRAM scrambler permutation for bits 15 to 0
Table 389. SRAM scrambler address expansion
Table 390. SRAM scrambler address lanes
Table 391. SRAM scrambler module variants
Table 392. Key Manager CPU Memory Map
Table 393. Key Manager Top-Level Address Map register list
Table 394. key_manager.KM_WRITE_DATA fields

Table 395. key_manager.KM_WRITE_SEPARATOR fields
Table 396. key_manager.KM_READ_DATA fields
Table 397. key_manager.KM_STATUS fields
Table 398. key_manager.KM_IRQ_STATUS fields
Table 399. key_manager.KM_IRQ_ENABLE fields
Table 400. key_manager.KM_CTRL fields
Table 401. key_manager.LOCKS fields
Table 402. key_manager.LOCKS_SPARE fields
Table 403. key_manager.LC_STATE fields
Table 404. key_manager.SBOOT_DIS fields
Table 405. key_manager.TRANSIENT_RMA_EN fields
Table 406. key_manager.SIP_DIS fields
Table 407. key_manager.SYS_DIS fields
Table 408. key_manager.RMA_SIP_TOKEN_DIGEST fields
Table 409. key_manager.RMA_CHIPLET_TOKEN_DIGEST fields
Table 410. key_manager.CLASS_KEY fields
Table 411. key_manager.CHIPLET_PUBK_REVOKE fields
Table 412. key_manager.BL1_VERSION fields
Table 413. key_manager.BL2_VERSION fields
Table 414. key_manager.CHIPLET_UID fields
Table 415. key_manager.SIP_PUBK_HASH0 fields
Table 416. key_manager.SIP_UID fields
Table 417. key_manager.SYS_PUBK_HASH fields
Table 418. key_manager.SYS_UID fields
Table 419. key_manager.STATUS_RPT fields
Table 420. key_manager.ROM_CTL fields
Table 421. key_manager.SYSCLK_FREQ_MHZ fields
Table 422. key_manager.CHIPLET_PUBK_HASH0 fields
Table 423. key_manager.CHIPLET_PUBK_HASH1 fields
Table 424. key_manager.REQUIRED_SIGNERS fields
Table 425. key_manager.REQUIRED_ALGS fields
Table 426. key_manager.CHIPLET_PUBK_PQC_HASH0 fields
Table 427. key_manager.CHIPLET_PUBK_PQC_HASH1 fields
Table 428. key_manager.SIP_PUBK_PQC_HASH0 fields
Table 429. key_manager.SYS_PUBK_PQC_HASH fields
Table 430. key_manager.SIP_PUBK_HASH1 fields

Table 431. key_manager.SIP_PUBK_PQC_HASH1 fields

Table 432. key_manager.SEP_CHIPLET_ID fields

Table 433. key_manager.SEP_SIP_ID fields

Table 434. key_manager.SEP_SYS_ID fields

Table 435. key_manager.spare0 fields

Table 436. key_manager.spare1 fields

Table 437. key_manager.spare2 fields

Table 438. key_manager.spare3 fields

Table 439. key_manager.spare4 fields

Table 440. key_manager.spare5 fields

Table 441. key_manager.spare6 fields

Table 442. key_manager.spare7 fields

Table 443. key_manager.spare8 fields

Table 444. key_manager.EFUSE_INTERFACE_CTRL_STATUS fields

Table 445. key_manager.EFUSE_PROGRAM_CTRL fields

Table 446. key_manager.EFUSE_READ_CTRL fields

Table 447. key_manager.EFUSE_PROGRAM_INTERFACE_READ_DATA fields

Table 448. key_manager.EFUSE_READ_INTERFACE_READ_DATA fields

Table 449. key_manager.EFUSE_READ_REQ_TIMEOUT fields

Table 450. key_manager.EFUSE_PROGRAM_REQ_TIMEOUT fields

Table 451. key_manager.RMA_SIP_TOKEN_I[8] fields

Table 452. key_manager.RMA_CHIPLET_TOKEN_I[8] fields

Table 453. key_manager.SEC_DISABLE_TOKEN_I[8] fields

Table 454. key_manager.TOKEN_EOP fields

Table 455. key_manager.RMA_SIP_TOKEN_MATCH fields

Table 456. key_manager.RMA_CHIPLET_TOKEN_MATCH fields

Table 457. key_manager.SEC_DISABLE_TOKEN_MATCH fields

Table 458. key_manager.TOKEN_MATCH_FAULT fields

Table 459. key_manager.KEY_ENTRY[64].WORD[16] fields

Table 460. key_manager.CTRL[64] fields

Table 461. key_manager.KPV_SCRAMBLER_KEY fields

Table 462. key_manager.KPV_SCRAMBLER_CTRL fields

Table 463. key_manager.VERSION fields

Table 464. key_manager.CTRL fields

Table 465. key_manager.SOFT_RST_CODE fields

Table 466. key_manager.kmcsr.IRQ_STATUS fields

Table 467. key_manager.kmcsr.IRQ_ENABLE fields
Table 468. key_manager.SCRAMBLER_KEY fields
Table 469. key_manager.SCRAMBLER_CTRL fields
Table 470. key_manager.SRAM_LOCK fields
Table 471. key_manager.IRQ_SET fields
Table 472. key_manager.SRAM_WRITE_LOCK_VIOLATION fields
Table 473. key_manager.RECOVERABLE_ERR fields
Table 474. key_manager.BOOT_STATUS fields
Table 475. key_manager.OTP_LIFE_CYCLE fields
Table 476. key_manager.OTP_DEMOTION_STATE fields
Table 477. key_manager.SRAM_EXEC_MODE fields
Table 478. key_manager.IRQ_ENTRY_ADDR fields
Table 479. key_manager.IRQ_ENTRY_LOCK fields
Table 480. key_manager.VUART_TX fields
Table 481. key_manager.VUART_RX fields
Table 482. key_manager.VUART_STATUS fields
Table 483. key_manager.TB_RESULT fields
Table 484. key_manager.TB_SIGNATURE fields
Table 485. key_manager.TB_ERRCODE fields
Table 486. key_manager.TB_SUBTEST fields
Table 487. key_manager.TB_CMD fields
Table 488. key_manager.TB_CMD_ARG fields
Table 489. key_manager.TB_CMD_STATUS fields
Table 490. key_manager.TB_CMD_RESULT fields
Table 491. key_manager.DEBUG fields
Table 492. key_manager.OTP_CHIPLET_UID_VAL_0 fields
Table 493. key_manager.OTP_CHIPLET_UID_VAL_1 fields
Table 494. key_manager.OTP_CHIPLET_UID_VAL_2 fields
Table 495. key_manager.OTP_CHIPLET_UID_VAL_3 fields
Table 496. key_manager.OTP_CHIPLET_UID_VAL_4 fields
Table 497. key_manager.OTP_CHIPLET_UID_VAL_5 fields
Table 498. key_manager.OTP_CHIPLET_UID_VAL_6 fields
Table 499. key_manager.OTP_CHIPLET_UID_VAL_7 fields
Table 500. key_manager.OTP_CHIPLET_UID_CPL_0 fields
Table 501. key_manager.OTP_CHIPLET_UID_CPL_1 fields
Table 502. key_manager.OTP_CHIPLET_UID_CPL_2 fields

Table 503. key_manager.OTP_CHIPLET_UID_CPL_3 fields
Table 504. key_manager.OTP_CHIPLET_UID_CPL_4 fields
Table 505. key_manager.OTP_CHIPLET_UID_CPL_5 fields
Table 506. key_manager.OTP_CHIPLET_UID_CPL_6 fields
Table 507. key_manager.OTP_CHIPLET_UID_CPL_7 fields
Table 508. key_manager.OTP_SIP_UID_VAL_0 fields
Table 509. key_manager.OTP_SIP_UID_VAL_1 fields
Table 510. key_manager.OTP_SIP_UID_VAL_2 fields
Table 511. key_manager.OTP_SIP_UID_VAL_3 fields
Table 512. key_manager.OTP_SIP_UID_VAL_4 fields
Table 513. key_manager.OTP_SIP_UID_VAL_5 fields
Table 514. key_manager.OTP_SIP_UID_VAL_6 fields
Table 515. key_manager.OTP_SIP_UID_VAL_7 fields
Table 516. key_manager.OTP_SIP_UID_CPL_0 fields
Table 517. key_manager.OTP_SIP_UID_CPL_1 fields
Table 518. key_manager.OTP_SIP_UID_CPL_2 fields
Table 519. key_manager.OTP_SIP_UID_CPL_3 fields
Table 520. key_manager.OTP_SIP_UID_CPL_4 fields
Table 521. key_manager.OTP_SIP_UID_CPL_5 fields
Table 522. key_manager.OTP_SIP_UID_CPL_6 fields
Table 523. key_manager.OTP_SIP_UID_CPL_7 fields
Table 524. key_manager.OTP_SYS_UID_VAL_0 fields
Table 525. key_manager.OTP_SYS_UID_VAL_1 fields
Table 526. key_manager.OTP_SYS_UID_VAL_2 fields
Table 527. key_manager.OTP_SYS_UID_VAL_3 fields
Table 528. key_manager.OTP_SYS_UID_VAL_4 fields
Table 529. key_manager.OTP_SYS_UID_VAL_5 fields
Table 530. key_manager.OTP_SYS_UID_VAL_6 fields
Table 531. key_manager.OTP_SYS_UID_VAL_7 fields
Table 532. key_manager.OTP_SYS_UID_CPL_0 fields
Table 533. key_manager.OTP_SYS_UID_CPL_1 fields
Table 534. key_manager.OTP_SYS_UID_CPL_2 fields
Table 535. key_manager.OTP_SYS_UID_CPL_3 fields
Table 536. key_manager.OTP_SYS_UID_CPL_4 fields
Table 537. key_manager.OTP_SYS_UID_CPL_5 fields
Table 538. key_manager.OTP_SYS_UID_CPL_6 fields

Table 539. key_manager.OTP_SYS_UID_CPL_7 fields
Table 540. key_manager.OTP_CLASS_KEY_VAL_0 fields
Table 541. key_manager.OTP_CLASS_KEY_VAL_1 fields
Table 542. key_manager.OTP_CLASS_KEY_VAL_2 fields
Table 543. key_manager.OTP_CLASS_KEY_VAL_3 fields
Table 544. key_manager.OTP_CLASS_KEY_VAL_4 fields
Table 545. key_manager.OTP_CLASS_KEY_VAL_5 fields
Table 546. key_manager.OTP_CLASS_KEY_VAL_6 fields
Table 547. key_manager.OTP_CLASS_KEY_VAL_7 fields
Table 548. key_manager.OTP_CLASS_KEY_CPL_0 fields
Table 549. key_manager.OTP_CLASS_KEY_CPL_1 fields
Table 550. key_manager.OTP_CLASS_KEY_CPL_2 fields
Table 551. key_manager.OTP_CLASS_KEY_CPL_3 fields
Table 552. key_manager.OTP_CLASS_KEY_CPL_4 fields
Table 553. key_manager.OTP_CLASS_KEY_CPL_5 fields
Table 554. key_manager.OTP_CLASS_KEY_CPL_6 fields
Table 555. key_manager.OTP_CLASS_KEY_CPL_7 fields
Table 556. key_manager.OTP_READ_LOCK fields
Table 557. key_manager.OTP_CHANGE_STATUS fields
Table 558. key_manager.OTP_READ_LOCK_COLD fields
Table 559. key_manager.OTP_SEP_CHIPLET_ID_VAL_0 fields
Table 560. key_manager.OTP_SEP_CHIPLET_ID_VAL_1 fields
Table 561. key_manager.OTP_SEP_CHIPLET_ID_VAL_2 fields
Table 562. key_manager.OTP_SEP_CHIPLET_ID_VAL_3 fields
Table 563. key_manager.OTP_SEP_CHIPLET_ID_VAL_4 fields
Table 564. key_manager.OTP_SEP_CHIPLET_ID_VAL_5 fields
Table 565. key_manager.OTP_SEP_CHIPLET_ID_VAL_6 fields
Table 566. key_manager.OTP_SEP_CHIPLET_ID_VAL_7 fields
Table 567. key_manager.OTP_SEP_CHIPLET_ID_CPL_0 fields
Table 568. key_manager.OTP_SEP_CHIPLET_ID_CPL_1 fields
Table 569. key_manager.OTP_SEP_CHIPLET_ID_CPL_2 fields
Table 570. key_manager.OTP_SEP_CHIPLET_ID_CPL_3 fields
Table 571. key_manager.OTP_SEP_CHIPLET_ID_CPL_4 fields
Table 572. key_manager.OTP_SEP_CHIPLET_ID_CPL_5 fields
Table 573. key_manager.OTP_SEP_CHIPLET_ID_CPL_6 fields
Table 574. key_manager.OTP_SEP_CHIPLET_ID_CPL_7 fields

Table 575. key_manager.OTP_SEP_SIP_ID_VAL_0 fields
Table 576. key_manager.OTP_SEP_SIP_ID_VAL_1 fields
Table 577. key_manager.OTP_SEP_SIP_ID_VAL_2 fields
Table 578. key_manager.OTP_SEP_SIP_ID_VAL_3 fields
Table 579. key_manager.OTP_SEP_SIP_ID_VAL_4 fields
Table 580. key_manager.OTP_SEP_SIP_ID_VAL_5 fields
Table 581. key_manager.OTP_SEP_SIP_ID_VAL_6 fields
Table 582. key_manager.OTP_SEP_SIP_ID_VAL_7 fields
Table 583. key_manager.OTP_SEP_SIP_ID_CPL_0 fields
Table 584. key_manager.OTP_SEP_SIP_ID_CPL_1 fields
Table 585. key_manager.OTP_SEP_SIP_ID_CPL_2 fields
Table 586. key_manager.OTP_SEP_SIP_ID_CPL_3 fields
Table 587. key_manager.OTP_SEP_SIP_ID_CPL_4 fields
Table 588. key_manager.OTP_SEP_SIP_ID_CPL_5 fields
Table 589. key_manager.OTP_SEP_SIP_ID_CPL_6 fields
Table 590. key_manager.OTP_SEP_SIP_ID_CPL_7 fields
Table 591. key_manager.OTP_SEP_SYS_ID_VAL_0 fields
Table 592. key_manager.OTP_SEP_SYS_ID_VAL_1 fields
Table 593. key_manager.OTP_SEP_SYS_ID_VAL_2 fields
Table 594. key_manager.OTP_SEP_SYS_ID_VAL_3 fields
Table 595. key_manager.OTP_SEP_SYS_ID_VAL_4 fields
Table 596. key_manager.OTP_SEP_SYS_ID_VAL_5 fields
Table 597. key_manager.OTP_SEP_SYS_ID_VAL_6 fields
Table 598. key_manager.OTP_SEP_SYS_ID_VAL_7 fields
Table 599. key_manager.OTP_SEP_SYS_ID_CPL_0 fields
Table 600. key_manager.OTP_SEP_SYS_ID_CPL_1 fields
Table 601. key_manager.OTP_SEP_SYS_ID_CPL_2 fields
Table 602. key_manager.OTP_SEP_SYS_ID_CPL_3 fields
Table 603. key_manager.OTP_SEP_SYS_ID_CPL_4 fields
Table 604. key_manager.OTP_SEP_SYS_ID_CPL_5 fields
Table 605. key_manager.OTP_SEP_SYS_ID_CPL_6 fields
Table 606. key_manager.OTP_SEP_SYS_ID_CPL_7 fields
Table 607. key_manager.DATA fields
Table 608. key_manager.CFG fields
Table 609. key_manager.STATUS fields
Table 610. key_manager.PREFETCH_DATA fields

Table 611. key_manager.KEY_SHARE0[12] fields
Table 612. key_manager.KEY_SHARE1[12] fields
Table 613. key_manager.otbn_wrapper_key.KEY_CTRL fields
Table 614. key_manager.aes_wrapper_key.KEY_SHARE0[8] fields
Table 615. key_manager.aes_wrapper_key.KEY_SHARE1[8] fields
Table 616. key_manager.aes_wrapper_key.KEY_CTRL fields
Table 617. key_manager.kmac_wrapper_key.KEY_SHARE0[8] fields
Table 618. key_manager.kmac_wrapper_key.KEY_SHARE1[8] fields
Table 619. key_manager.kmac_wrapper_key.KEY_CTRL fields
Table 620. key_manager.hmac_wrapper_key.KEY_SHARE0[8] fields
Table 621. key_manager.hmac_wrapper_key.KEY_SHARE1[8] fields
Table 622. key_manager.hmac_wrapper_key.KEY_CTRL fields
Table 623. key_manager.abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8] fields
Table 624. key_manager.abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8] fields
Table 625. key_manager.abr_wrapper_key.MLDSA_SEED.KEY_CTRL fields
Table 626. key_manager.abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8] fields
Table 627. key_manager.abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8] fields
Table 628. key_manager.abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL fields
Table 629. key_manager.abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8] fields
Table 630. key_manager.abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8] fields
Table 631. key_manager.abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL fields
Table 632. key_manager.abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8] fields
Table 633. key_manager.abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8] fields
Table 634. key_manager.abr_wrapper_key.MLKEM_MSG.KEY_CTRL fields
Table 635. key_manager.KEY[8] fields
Table 636. key_manager.abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL fields
Table 637. key_manager.abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_STATUS fields
Table 638. key_manager.abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_ENABLE fields
Table 639. Key Manager Control and Status Registers register list
Table 640. km_csr.VERSION fields
Table 641. km_csr.CTRL fields
Table 642. km_csr.SOFT_RST_CODE fields
Table 643. km_csr.IRQ_STATUS fields
Table 644. km_csr.IRQ_ENABLE fields
Table 645. km_csr.SCRAMBLER_KEY fields
Table 646. km_csr.SCRAMBLER_CTRL fields

Table 647. km_csr.SRAM_LOCK fields

Table 648. km_csr.IRQ_SET fields

Table 649. km_csr.SRAM_WRITE_LOCK_VIOLATION fields

Table 650. km_csr.RECOVERABLE_ERR fields

Table 651. km_csr.BOOT_STATUS fields

Table 652. km_csr.OTP_LIFE_CYCLE fields

Table 653. km_csr.OTP_DEMOTION_STATE fields

Table 654. km_csr.SRAM_EXEC_MODE fields

Table 655. km_csr.IRQ_ENTRY_ADDR fields

Table 656. km_csr.IRQ_ENTRY_LOCK fields

Table 657. km_csr.VUART_TX fields

Table 658. km_csr.VUART_RX fields

Table 659. km_csr.VUART_STATUS fields

Table 660. km_csr.TB_RESULT fields

Table 661. km_csr.TB_SIGNATURE fields

Table 662. km_csr.TB_ERRCODE fields

Table 663. km_csr.TB_SUBTEST fields

Table 664. km_csr.TB_CMD fields

Table 665. km_csr.TB_CMD_ARG fields

Table 666. km_csr.TB_CMD_STATUS fields

Table 667. km_csr.TB_CMD_RESULT fields

Table 668. km_csr.DEBUG fields

Table 669. km_csr.OTP_CHIPLET_UID_VAL_0 fields

Table 670. km_csr.OTP_CHIPLET_UID_VAL_1 fields

Table 671. km_csr.OTP_CHIPLET_UID_VAL_2 fields

Table 672. km_csr.OTP_CHIPLET_UID_VAL_3 fields

Table 673. km_csr.OTP_CHIPLET_UID_VAL_4 fields

Table 674. km_csr.OTP_CHIPLET_UID_VAL_5 fields

Table 675. km_csr.OTP_CHIPLET_UID_VAL_6 fields

Table 676. km_csr.OTP_CHIPLET_UID_VAL_7 fields

Table 677. km_csr.OTP_CHIPLET_UID_CPL_0 fields

Table 678. km_csr.OTP_CHIPLET_UID_CPL_1 fields

Table 679. km_csr.OTP_CHIPLET_UID_CPL_2 fields

Table 680. km_csr.OTP_CHIPLET_UID_CPL_3 fields

Table 681. km_csr.OTP_CHIPLET_UID_CPL_4 fields

Table 682. km_csr.OTP_CHIPLET_UID_CPL_5 fields

Table 683. km_csr.OTP_CHIPLET_UID_CPL_6 fields
Table 684. km_csr.OTP_CHIPLET_UID_CPL_7 fields
Table 685. km_csr.OTP_SIP_UID_VAL_0 fields
Table 686. km_csr.OTP_SIP_UID_VAL_1 fields
Table 687. km_csr.OTP_SIP_UID_VAL_2 fields
Table 688. km_csr.OTP_SIP_UID_VAL_3 fields
Table 689. km_csr.OTP_SIP_UID_VAL_4 fields
Table 690. km_csr.OTP_SIP_UID_VAL_5 fields
Table 691. km_csr.OTP_SIP_UID_VAL_6 fields
Table 692. km_csr.OTP_SIP_UID_VAL_7 fields
Table 693. km_csr.OTP_SIP_UID_CPL_0 fields
Table 694. km_csr.OTP_SIP_UID_CPL_1 fields
Table 695. km_csr.OTP_SIP_UID_CPL_2 fields
Table 696. km_csr.OTP_SIP_UID_CPL_3 fields
Table 697. km_csr.OTP_SIP_UID_CPL_4 fields
Table 698. km_csr.OTP_SIP_UID_CPL_5 fields
Table 699. km_csr.OTP_SIP_UID_CPL_6 fields
Table 700. km_csr.OTP_SIP_UID_CPL_7 fields
Table 701. km_csr.OTP_SYS_UID_VAL_0 fields
Table 702. km_csr.OTP_SYS_UID_VAL_1 fields
Table 703. km_csr.OTP_SYS_UID_VAL_2 fields
Table 704. km_csr.OTP_SYS_UID_VAL_3 fields
Table 705. km_csr.OTP_SYS_UID_VAL_4 fields
Table 706. km_csr.OTP_SYS_UID_VAL_5 fields
Table 707. km_csr.OTP_SYS_UID_VAL_6 fields
Table 708. km_csr.OTP_SYS_UID_VAL_7 fields
Table 709. km_csr.OTP_SYS_UID_CPL_0 fields
Table 710. km_csr.OTP_SYS_UID_CPL_1 fields
Table 711. km_csr.OTP_SYS_UID_CPL_2 fields
Table 712. km_csr.OTP_SYS_UID_CPL_3 fields
Table 713. km_csr.OTP_SYS_UID_CPL_4 fields
Table 714. km_csr.OTP_SYS_UID_CPL_5 fields
Table 715. km_csr.OTP_SYS_UID_CPL_6 fields
Table 716. km_csr.OTP_SYS_UID_CPL_7 fields
Table 717. km_csr.OTP_CLASS_KEY_VAL_0 fields
Table 718. km_csr.OTP_CLASS_KEY_VAL_1 fields

Table 719. km_csr.OTP_CLASS_KEY_VAL_2 fields
Table 720. km_csr.OTP_CLASS_KEY_VAL_3 fields
Table 721. km_csr.OTP_CLASS_KEY_VAL_4 fields
Table 722. km_csr.OTP_CLASS_KEY_VAL_5 fields
Table 723. km_csr.OTP_CLASS_KEY_VAL_6 fields
Table 724. km_csr.OTP_CLASS_KEY_VAL_7 fields
Table 725. km_csr.OTP_CLASS_KEY_CPL_0 fields
Table 726. km_csr.OTP_CLASS_KEY_CPL_1 fields
Table 727. km_csr.OTP_CLASS_KEY_CPL_2 fields
Table 728. km_csr.OTP_CLASS_KEY_CPL_3 fields
Table 729. km_csr.OTP_CLASS_KEY_CPL_4 fields
Table 730. km_csr.OTP_CLASS_KEY_CPL_5 fields
Table 731. km_csr.OTP_CLASS_KEY_CPL_6 fields
Table 732. km_csr.OTP_CLASS_KEY_CPL_7 fields
Table 733. km_csr.OTP_READ_LOCK fields
Table 734. km_csr.OTP_CHANGE_STATUS fields
Table 735. km_csr.OTP_READ_LOCK_COLD fields
Table 736. km_csr.OTP_SEP_CHIPLET_ID_VAL_0 fields
Table 737. km_csr.OTP_SEP_CHIPLET_ID_VAL_1 fields
Table 738. km_csr.OTP_SEP_CHIPLET_ID_VAL_2 fields
Table 739. km_csr.OTP_SEP_CHIPLET_ID_VAL_3 fields
Table 740. km_csr.OTP_SEP_CHIPLET_ID_VAL_4 fields
Table 741. km_csr.OTP_SEP_CHIPLET_ID_VAL_5 fields
Table 742. km_csr.OTP_SEP_CHIPLET_ID_VAL_6 fields
Table 743. km_csr.OTP_SEP_CHIPLET_ID_VAL_7 fields
Table 744. km_csr.OTP_SEP_CHIPLET_ID_CPL_0 fields
Table 745. km_csr.OTP_SEP_CHIPLET_ID_CPL_1 fields
Table 746. km_csr.OTP_SEP_CHIPLET_ID_CPL_2 fields
Table 747. km_csr.OTP_SEP_CHIPLET_ID_CPL_3 fields
Table 748. km_csr.OTP_SEP_CHIPLET_ID_CPL_4 fields
Table 749. km_csr.OTP_SEP_CHIPLET_ID_CPL_5 fields
Table 750. km_csr.OTP_SEP_CHIPLET_ID_CPL_6 fields
Table 751. km_csr.OTP_SEP_CHIPLET_ID_CPL_7 fields
Table 752. km_csr.OTP_SEP_SIP_ID_VAL_0 fields
Table 753. km_csr.OTP_SEP_SIP_ID_VAL_1 fields
Table 754. km_csr.OTP_SEP_SIP_ID_VAL_2 fields

Table 755. km_csr.OTP_SEP_SIP_ID_VAL_3 fields
Table 756. km_csr.OTP_SEP_SIP_ID_VAL_4 fields
Table 757. km_csr.OTP_SEP_SIP_ID_VAL_5 fields
Table 758. km_csr.OTP_SEP_SIP_ID_VAL_6 fields
Table 759. km_csr.OTP_SEP_SIP_ID_VAL_7 fields
Table 760. km_csr.OTP_SEP_SIP_ID_CPL_0 fields
Table 761. km_csr.OTP_SEP_SIP_ID_CPL_1 fields
Table 762. km_csr.OTP_SEP_SIP_ID_CPL_2 fields
Table 763. km_csr.OTP_SEP_SIP_ID_CPL_3 fields
Table 764. km_csr.OTP_SEP_SIP_ID_CPL_4 fields
Table 765. km_csr.OTP_SEP_SIP_ID_CPL_5 fields
Table 766. km_csr.OTP_SEP_SIP_ID_CPL_6 fields
Table 767. km_csr.OTP_SEP_SIP_ID_CPL_7 fields
Table 768. km_csr.OTP_SEP_SYS_ID_VAL_0 fields
Table 769. km_csr.OTP_SEP_SYS_ID_VAL_1 fields
Table 770. km_csr.OTP_SEP_SYS_ID_VAL_2 fields
Table 771. km_csr.OTP_SEP_SYS_ID_VAL_3 fields
Table 772. km_csr.OTP_SEP_SYS_ID_VAL_4 fields
Table 773. km_csr.OTP_SEP_SYS_ID_VAL_5 fields
Table 774. km_csr.OTP_SEP_SYS_ID_VAL_6 fields
Table 775. km_csr.OTP_SEP_SYS_ID_VAL_7 fields
Table 776. km_csr.OTP_SEP_SYS_ID_CPL_0 fields
Table 777. km_csr.OTP_SEP_SYS_ID_CPL_1 fields
Table 778. km_csr.OTP_SEP_SYS_ID_CPL_2 fields
Table 779. km_csr.OTP_SEP_SYS_ID_CPL_3 fields
Table 780. km_csr.OTP_SEP_SYS_ID_CPL_4 fields
Table 781. km_csr.OTP_SEP_SYS_ID_CPL_5 fields
Table 782. km_csr.OTP_SEP_SYS_ID_CPL_6 fields
Table 783. km_csr.OTP_SEP_SYS_ID_CPL_7 fields
Table 784. Key and Policy Vault (KM Port) register list
Table 785. km_kpv.KEY_ENTRY[64].WORD[16] fields
Table 786. km_kpv.CTRL[64] fields
Table 787. km_kpv.KPV_SCRAMBLER_KEY fields
Table 788. km_kpv.KPV_SCRAMBLER_CTRL fields
Table 789. DRBG Sampler register list
Table 790. km_drbg_sampler.DATA fields

Table 791. km_drbg_sampler.CFG fields
Table 792. km_drbg_sampler.STATUS fields
Table 793. km_drbg_sampler.PREFETCH_DATA fields
Table 794. Key Manager Mailbox KM Side register list
Table 795. km_mailbox_km.KM_WRITE_DATA fields
Table 796. km_mailbox_km.KM_WRITE_SEPARATOR fields
Table 797. km_mailbox_km.KM_READ_DATA fields
Table 798. km_mailbox_km.KM_STATUS fields
Table 799. km_mailbox_km.KM_IRQ_STATUS fields
Table 800. km_mailbox_km.KM_IRQ_ENABLE fields
Table 801. km_mailbox_km.KM_CTRL fields
Table 802. Key Manager Mailbox SEP Side register list
Table 803. km_mailbox_sep.SEP_WRITE_DATA fields
Table 804. km_mailbox_sep.SEP_WRITE_SEPARATOR fields
Table 805. km_mailbox_sep.SEP_READ_DATA fields
Table 806. km_mailbox_sep.SEP_STATUS fields
Table 807. km_mailbox_sep.SEP_IRQ_STATUS fields
Table 808. km_mailbox_sep.SEP_IRQ_ENABLE fields
Table 809. km_mailbox_sep.SEP_CTRL fields
Table 810. Adams Bridge Key Sideload Registers register list
Table 811. abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8] fields
Table 812. abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8] fields
Table 813. abr_wrapper_key.MLDSA_SEED.KEY_CTRL fields
Table 814. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8] fields
Table 815. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8] fields
Table 816. abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL fields
Table 817. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8] fields
Table 818. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8] fields
Table 819. abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL fields
Table 820. abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8] fields
Table 821. abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8] fields
Table 822. abr_wrapper_key.MLKEM_MSG.KEY_CTRL fields
Table 823. abr_wrapper_key.KEY[8] fields
Table 824. abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL fields
Table 825. abr_wrapper_key.IRQ_STATUS fields
Table 826. abr_wrapper_key.IRQ_ENABLE fields

Table 827. AES Wrapper Key Registers register list
Table 828. aes_wrapper_key.KEY_SHARE0[8] fields
Table 829. aes_wrapper_key.KEY_SHARE1[8] fields
Table 830. aes_wrapper_key.KEY_CTRL fields
Table 831. HMAC Wrapper Key Registers register list
Table 832. hmac_wrapper_key.KEY_SHARE0[8] fields
Table 833. hmac_wrapper_key.KEY_SHARE1[8] fields
Table 834. hmac_wrapper_key.KEY_CTRL fields
Table 835. KMAC Wrapper Key Registers register list
Table 836. kmac_wrapper_key.KEY_SHARE0[8] fields
Table 837. kmac_wrapper_key.KEY_SHARE1[8] fields
Table 838. kmac_wrapper_key.KEY_CTRL fields
Table 839. OTBN Wrapper Key Registers register list
Table 840. otbn_wrapper_key.KEY_SHARE0[12] fields
Table 841. otbn_wrapper_key.KEY_SHARE1[12] fields
Table 842. otbn_wrapper_key.KEY_CTRL fields
Table 843. SEP CPU Logical Address Space
Table 844. SEP EL2 CPU Resources
Table 845. SEP Component Address Map
Table 846. SEP External register list
Table 847. sep_external.EFUSE_BANK_INIT_TIME fields
Table 848. SMC clock-domain responsibilities
Table 849. SMC reset sources and effects
Table 850. Reset synchronization domains
Table 851. Reset Unit Address Map register list
Table 852. reset_unit.SS_CONFIG fields
Table 853. reset_unit.SS_CONFIG_LOCK fields
Table 854. reset_unit.SS_COLD_RESET_N fields
Table 855. reset_unit.SS_WARM_RESET_N fields
Table 856. reset_unit.SS_CONFIG_HOLD fields
Table 857. reset_unit.SS_SRAM_HOLD fields
Table 858. reset_unit.SS_CRITICAL_HOLD fields
Table 859. reset_unit.SS_DEBUG_HOLD fields
Table 860. reset_unit.SS_RESET_COMPLETE fields
Table 861. reset_unit.SS_COLD_RESET_LOCK fields
Table 862. reset_unit.SS_FORCE_TO_REF_CLK fields

Table 863. reset_unit.SYNC_REG fields
Table 864. reset_unit.ISOLATE_REQ_REG fields
Table 865. reset_unit.ISOLATE_REQ_PINEN_REG fields
Table 866. reset_unit.ISOLATE_REQ_SMC_REG fields
Table 867. reset_unit.ISOLATE_REQ_SMCEN_REG fields
Table 868. reset_unit.ISOLATE_REQ_VIS fields
Table 869. reset_unit.ISOLATE_REQ_FLR_COUNTER_VALUE fields
Table 870. reset_unit.ISOLATE_REQ_FLR_RESET_COUNTER_VALUE fields
Table 871. SMC processor core features
Table 872. SMC cache and memory hierarchy
Table 873. SMC CPU system interfaces
Table 874. SMC Debug Module capability readbacks
Table 875. SMC Debug Module DMI register inventory
Table 876. CPU Control Address Map register list
Table 877. cpu_ctrl.RESET_VECTOR[4] fields
Table 878. cpu_ctrl.RESET_CTRL fields
Table 879. cpu_ctrl.CORE_RESET_PULSE_COUNT fields
Table 880. cpu_ctrl.RESET_TIMEOUT fields
Table 881. cpu_ctrl.REFERENCE_COUNTER fields
Table 882. cpu_ctrl.WDT_TIMEOUT fields
Table 883. cpu_ctrl.WDT_TIMEOUT_RESET fields
Table 884. cpu_ctrl.TEST_CTRL fields
Table 885. cpu_ctrl.SCRATCH[16] fields
Table 886. cpu_ctrl.WB_PC_CORE0[8] fields
Table 887. cpu_ctrl.WB_PC_CORE1[8] fields
Table 888. cpu_ctrl.WB_PC_CORE2[8] fields
Table 889. cpu_ctrl.WB_PC_CORE3[8] fields
Table 890. cpu_ctrl.SMC_ATTRIBUTES fields
Table 891. cpu_ctrl.MUTEX[4] fields
Table 892. cpu_ctrl.SEMA[4] fields
Table 893. cpu_ctrl.DUMMY_ROM_0 fields
Table 894. cpu_ctrl.DUMMY_ROM_1 fields
Table 895. cpu_ctrl.DUMMY_ROM_2 fields
Table 896. cpu_ctrl.DUMMY_ROM_3 fields
Table 897. cpu_ctrl.DUMMY_ROM_NULL[4] fields
Table 898. CLINT Address Map register list

Table 899. clint.MSIP[4] fields
Table 900. clint.MTIMECMP[4] fields
Table 901. clint.MTIME fields
Table 902. Debug Module Hart Interface register list
Table 903. debug_module.HALTED fields
Table 904. debug_module.GOING fields
Table 905. debug_module.RESUMING fields
Table 906. debug_module.EXCEPTION fields
Table 907. debug_module.WHERETO fields
Table 908. debug_module.ABSTRACT[5] fields
Table 909. debug_module.PROGBUF[16] fields
Table 910. debug_module.IMPEBREAK fields
Table 911. debug_module.DATA[4] fields
Table 912. debug_module.FLAGS fields
Table 913. debug_module.ROM[26] fields
Table 914. Bus Error Unit Address Map register list
Table 915. bus_error_unit.CAUSE fields
Table 916. bus_error_unit.PHYS_ADDR fields
Table 917. bus_error_unit.ENABLE fields
Table 918. bus_error_unit.PLIC_ENABLE fields
Table 919. bus_error_unit.ACCRUED_ENABLE fields
Table 920. bus_error_unit.LOCAL_ENABLE fields
Table 921. SMC Fabric Transaction Limits
Table 922. SMC Network Characteristics
Table 923. AXI Common Signal Widths
Table 924. AXI ID Widths by Fabric Stage
Table 925. SMC Fabric Traffic Managers
Table 926. SMC Fabric Traffic Subordinates
Table 927. SMC AXI Protection Bit Encoding
Table 928. SMC Source ID by Traffic Path
Table 929. AXI Alias Remap Address Map register list
Table 930. alias_remap.region_start fields
Table 931. alias_remap.region_end fields
Table 932. alias_remap.region_attrs fields
Table 933. Output Remap Address Map register list
Table 934. output_remap.region_attrs fields

Table 935. AXI Filter Control Address Map register list
Table 936. filter_ctrl.FILTER_CONFIG fields
Table 937. filter_ctrl.START_ADDR fields
Table 938. filter_ctrl.END_ADDR fields
Table 939. SMC interrupt-controller addresses
Table 940. PLIC input groups
Table 941. SMC indexed interrupt map
Table 942. PLIC Address Map register list
Table 943. plic.PRIORITY[337] fields
Table 944. plic.PENDING[11] fields
Table 945. plic.CORE0_MEIP_ENABLE[11] fields
Table 946. plic.CORE1_MEIP_ENABLE[11] fields
Table 947. plic.CORE2_MEIP_ENABLE[11] fields
Table 948. plic.CORE3_MEIP_ENABLE[11] fields
Table 949. plic.CORE0_SEIP_ENABLE[11] fields
Table 950. plic.CORE1_SEIP_ENABLE[11] fields
Table 951. plic.CORE2_SEIP_ENABLE[11] fields
Table 952. plic.CORE3_SEIP_ENABLE[11] fields
Table 953. plic.CORE0_MEIP_THRESHOLD fields
Table 954. plic.CORE0_MEIP_CLAIM_COMPLETE fields
Table 955. plic.CORE1_MEIP_THRESHOLD fields
Table 956. plic.CORE1_MEIP_CLAIM_COMPLETE fields
Table 957. plic.CORE2_MEIP_THRESHOLD fields
Table 958. plic.CORE2_MEIP_CLAIM_COMPLETE fields
Table 959. plic.CORE3_MEIP_THRESHOLD fields
Table 960. plic.CORE3_MEIP_CLAIM_COMPLETE fields
Table 961. plic.CORE0_SEIP_THRESHOLD fields
Table 962. plic.CORE0_SEIP_CLAIM_COMPLETE fields
Table 963. plic.CORE1_SEIP_THRESHOLD fields
Table 964. plic.CORE1_SEIP_CLAIM_COMPLETE fields
Table 965. plic.CORE2_SEIP_THRESHOLD fields
Table 966. plic.CORE2_SEIP_CLAIM_COMPLETE fields
Table 967. plic.CORE3_SEIP_THRESHOLD fields
Table 968. plic.CORE3_SEIP_CLAIM_COMPLETE fields
Table 969. SMC Peripheral Summary
Table 970. SMC DMA integration

Table 971. SMC DMA elaboration settings

Table 972. DMA register storage and effective field widths

Table 973. DMA status and notification

Table 974. iDMA Controller Address Map register list

Table 975. dma_ctrl.CONFIG fields

Table 976. dma_ctrl.STATUS_0 fields

Table 977. dma_ctrl.STATUS_1 fields

Table 978. dma_ctrl.STATUS_2 fields

Table 979. dma_ctrl.STATUS_3 fields

Table 980. dma_ctrl.STATUS_4 fields

Table 981. dma_ctrl.STATUS_5 fields

Table 982. dma_ctrl.STATUS_6 fields

Table 983. dma_ctrl.STATUS_7 fields

Table 984. dma_ctrl.STATUS_8 fields

Table 985. dma_ctrl.STATUS_9 fields

Table 986. dma_ctrl.STATUS_10 fields

Table 987. dma_ctrl.STATUS_11 fields

Table 988. dma_ctrl.STATUS_12 fields

Table 989. dma_ctrl.STATUS_13 fields

Table 990. dma_ctrl.STATUS_14 fields

Table 991. dma_ctrl.STATUS_15 fields

Table 992. dma_ctrl.NEXT_ID_0 fields

Table 993. dma_ctrl.NEXT_ID_1 fields

Table 994. dma_ctrl.NEXT_ID_2 fields

Table 995. dma_ctrl.NEXT_ID_3 fields

Table 996. dma_ctrl.NEXT_ID_4 fields

Table 997. dma_ctrl.NEXT_ID_5 fields

Table 998. dma_ctrl.NEXT_ID_6 fields

Table 999. dma_ctrl.NEXT_ID_7 fields

Table 1000. dma_ctrl.NEXT_ID_8 fields

Table 1001. dma_ctrl.NEXT_ID_9 fields

Table 1002. dma_ctrl.NEXT_ID_10 fields

Table 1003. dma_ctrl.NEXT_ID_11 fields

Table 1004. dma_ctrl.NEXT_ID_12 fields

Table 1005. dma_ctrl.NEXT_ID_13 fields

Table 1006. dma_ctrl.NEXT_ID_14 fields

Table 1007. dma_ctrl.NEXT_ID_15 fields
Table 1008. dma_ctrl.DONE_0 fields
Table 1009. dma_ctrl.DONE_1 fields
Table 1010. dma_ctrl.DONE_2 fields
Table 1011. dma_ctrl.DONE_3 fields
Table 1012. dma_ctrl.DONE_4 fields
Table 1013. dma_ctrl.DONE_5 fields
Table 1014. dma_ctrl.DONE_6 fields
Table 1015. dma_ctrl.DONE_7 fields
Table 1016. dma_ctrl.DONE_8 fields
Table 1017. dma_ctrl.DONE_9 fields
Table 1018. dma_ctrl.DONE_10 fields
Table 1019. dma_ctrl.DONE_11 fields
Table 1020. dma_ctrl.DONE_12 fields
Table 1021. dma_ctrl.DONE_13 fields
Table 1022. dma_ctrl.DONE_14 fields
Table 1023. dma_ctrl.DONE_15 fields
Table 1024. dma_ctrl.DST_ADDRESS_LO fields
Table 1025. dma_ctrl.DST_ADDRESS_HI fields
Table 1026. dma_ctrl.SRC_ADDRESS_LO fields
Table 1027. dma_ctrl.SRC_ADDRESS_HI fields
Table 1028. dma_ctrl.LENGTH_LO fields
Table 1029. dma_ctrl.LENGTH_HI fields
Table 1030. dma_ctrl.DST_STRIDE_LO fields
Table 1031. dma_ctrl.DST_STRIDE_HI fields
Table 1032. dma_ctrl.SRC_STRIDE_LO fields
Table 1033. dma_ctrl.SRC_STRIDE_HI fields
Table 1034. dma_ctrl.NUM_REPETITIONS_LO fields
Table 1035. dma_ctrl.NUM_REPETITIONS_HI fields
Table 1036. SMC Memory Zeroer Integration
Table 1037. SMC zeroer state machine
Table 1038. SMC zeroer AXI4 Master Characteristics
Table 1039. SMC zeroer Clock Domain Characteristics
Table 1040. SMC zeroer Clock Gating Control
Table 1041. SMC zeroer Configuration and Control
Table 1042. SMC zeroer Data Generation and Control

Table 1043. Zeroer Control Address Map register list
Table 1044. zeroer_ctrl.DEST_ADDR fields
Table 1045. zeroer_ctrl.SIZE fields
Table 1046. zeroer_ctrl.CTRL_STATUS fields
Table 1047. Watchdog Timer Address Map register list
Table 1048. wdt.CTRL fields
Table 1049. wdt.COUNT fields
Table 1050. wdt.COUNT_HI fields
Table 1051. wdt.SCALED_COUNT fields
Table 1052. wdt.FEED fields
Table 1053. wdt.KEY fields
Table 1054. wdt.CMP fields
Table 1055. Mailbox interrupt sources
Table 1056. Mailbox access results
Table 1057. SMC Mailbox Aperture Layout
Table 1058. SEP Mailbox Aperture Layout
Table 1059. AXI-Lite Mailbox Address Map register list
Table 1060. axil_mailbox.WRITE_DATA fields
Table 1061. axil_mailbox.READ_DATA fields
Table 1062. axil_mailbox.STATUS fields
Table 1063. axil_mailbox.ERROR_FLAGS fields
Table 1064. axil_mailbox.WIRQT fields
Table 1065. axil_mailbox.RIRQT fields
Table 1066. axil_mailbox.IRQS fields
Table 1067. axil_mailbox.IRQEN fields
Table 1068. axil_mailbox.IRQP fields
Table 1069. axil_mailbox.CTRL fields
Table 1070. SMC AXI-Lite Mailbox Wrapper Address Map register list
Table 1071. axil_mailbox_smc_wrap.outbound_mailbox_0.WRITE_DATA fields
Table 1072. axil_mailbox_smc_wrap.outbound_mailbox_0.READ_DATA fields
Table 1073. axil_mailbox_smc_wrap.outbound_mailbox_0.STATUS fields
Table 1074. axil_mailbox_smc_wrap.outbound_mailbox_0.ERROR_FLAGS fields
Table 1075. axil_mailbox_smc_wrap.outbound_mailbox_0.WIRQT fields
Table 1076. axil_mailbox_smc_wrap.outbound_mailbox_0.RIRQT fields
Table 1077. axil_mailbox_smc_wrap.outbound_mailbox_0.IRQS fields
Table 1078. axil_mailbox_smc_wrap.outbound_mailbox_0.IRQEN fields

Table 1079. axil_mailbox_smc_wrap.outbound_mailbox_0.IRQP fields
Table 1080. axil_mailbox_smc_wrap.outbound_mailbox_0.CTRL fields
Table 1081. axil_mailbox_smc_wrap.inbound_mailbox_0.WRITE_DATA fields
Table 1082. axil_mailbox_smc_wrap.inbound_mailbox_0.READ_DATA fields
Table 1083. axil_mailbox_smc_wrap.inbound_mailbox_0.STATUS fields
Table 1084. axil_mailbox_smc_wrap.inbound_mailbox_0.ERROR_FLAGS fields
Table 1085. axil_mailbox_smc_wrap.inbound_mailbox_0.WIRQT fields
Table 1086. axil_mailbox_smc_wrap.inbound_mailbox_0.RIRQT fields
Table 1087. axil_mailbox_smc_wrap.inbound_mailbox_0.IRQS fields
Table 1088. axil_mailbox_smc_wrap.inbound_mailbox_0.IRQEN fields
Table 1089. axil_mailbox_smc_wrap.inbound_mailbox_0.IRQP fields
Table 1090. axil_mailbox_smc_wrap.inbound_mailbox_0.CTRL fields
Table 1091. axil_mailbox_smc_wrap.outbound_mailbox_1.WRITE_DATA fields
Table 1092. axil_mailbox_smc_wrap.outbound_mailbox_1.READ_DATA fields
Table 1093. axil_mailbox_smc_wrap.outbound_mailbox_1.STATUS fields
Table 1094. axil_mailbox_smc_wrap.outbound_mailbox_1.ERROR_FLAGS fields
Table 1095. axil_mailbox_smc_wrap.outbound_mailbox_1.WIRQT fields
Table 1096. axil_mailbox_smc_wrap.outbound_mailbox_1.RIRQT fields
Table 1097. axil_mailbox_smc_wrap.outbound_mailbox_1.IRQS fields
Table 1098. axil_mailbox_smc_wrap.outbound_mailbox_1.IRQEN fields
Table 1099. axil_mailbox_smc_wrap.outbound_mailbox_1.IRQP fields
Table 1100. axil_mailbox_smc_wrap.outbound_mailbox_1.CTRL fields
Table 1101. axil_mailbox_smc_wrap.inbound_mailbox_1.WRITE_DATA fields
Table 1102. axil_mailbox_smc_wrap.inbound_mailbox_1.READ_DATA fields
Table 1103. axil_mailbox_smc_wrap.inbound_mailbox_1.STATUS fields
Table 1104. axil_mailbox_smc_wrap.inbound_mailbox_1.ERROR_FLAGS fields
Table 1105. axil_mailbox_smc_wrap.inbound_mailbox_1.WIRQT fields
Table 1106. axil_mailbox_smc_wrap.inbound_mailbox_1.RIRQT fields
Table 1107. axil_mailbox_smc_wrap.inbound_mailbox_1.IRQS fields
Table 1108. axil_mailbox_smc_wrap.inbound_mailbox_1.IRQEN fields
Table 1109. axil_mailbox_smc_wrap.inbound_mailbox_1.IRQP fields
Table 1110. axil_mailbox_smc_wrap.inbound_mailbox_1.CTRL fields
Table 1111. axil_mailbox_smc_wrap.outbound_mailbox_2.WRITE_DATA fields
Table 1112. axil_mailbox_smc_wrap.outbound_mailbox_2.READ_DATA fields
Table 1113. axil_mailbox_smc_wrap.outbound_mailbox_2.STATUS fields
Table 1114. axil_mailbox_smc_wrap.outbound_mailbox_2.ERROR_FLAGS fields

Table 1115. axil_mailbox_smc_wrap.outbound_mailbox_2.WIRQT fields
Table 1116. axil_mailbox_smc_wrap.outbound_mailbox_2.RIRQT fields
Table 1117. axil_mailbox_smc_wrap.outbound_mailbox_2.IRQS fields
Table 1118. axil_mailbox_smc_wrap.outbound_mailbox_2.IRQEN fields
Table 1119. axil_mailbox_smc_wrap.outbound_mailbox_2.IRQP fields
Table 1120. axil_mailbox_smc_wrap.outbound_mailbox_2.CTRL fields
Table 1121. axil_mailbox_smc_wrap.inbound_mailbox_2.WRITE_DATA fields
Table 1122. axil_mailbox_smc_wrap.inbound_mailbox_2.READ_DATA fields
Table 1123. axil_mailbox_smc_wrap.inbound_mailbox_2.STATUS fields
Table 1124. axil_mailbox_smc_wrap.inbound_mailbox_2.ERROR_FLAGS fields
Table 1125. axil_mailbox_smc_wrap.inbound_mailbox_2.WIRQT fields
Table 1126. axil_mailbox_smc_wrap.inbound_mailbox_2.RIRQT fields
Table 1127. axil_mailbox_smc_wrap.inbound_mailbox_2.IRQS fields
Table 1128. axil_mailbox_smc_wrap.inbound_mailbox_2.IRQEN fields
Table 1129. axil_mailbox_smc_wrap.inbound_mailbox_2.IRQP fields
Table 1130. axil_mailbox_smc_wrap.inbound_mailbox_2.CTRL fields
Table 1131. axil_mailbox_smc_wrap.outbound_mailbox_3.WRITE_DATA fields
Table 1132. axil_mailbox_smc_wrap.outbound_mailbox_3.READ_DATA fields
Table 1133. axil_mailbox_smc_wrap.outbound_mailbox_3.STATUS fields
Table 1134. axil_mailbox_smc_wrap.outbound_mailbox_3.ERROR_FLAGS fields
Table 1135. axil_mailbox_smc_wrap.outbound_mailbox_3.WIRQT fields
Table 1136. axil_mailbox_smc_wrap.outbound_mailbox_3.RIRQT fields
Table 1137. axil_mailbox_smc_wrap.outbound_mailbox_3.IRQS fields
Table 1138. axil_mailbox_smc_wrap.outbound_mailbox_3.IRQEN fields
Table 1139. axil_mailbox_smc_wrap.outbound_mailbox_3.IRQP fields
Table 1140. axil_mailbox_smc_wrap.outbound_mailbox_3.CTRL fields
Table 1141. axil_mailbox_smc_wrap.inbound_mailbox_3.WRITE_DATA fields
Table 1142. axil_mailbox_smc_wrap.inbound_mailbox_3.READ_DATA fields
Table 1143. axil_mailbox_smc_wrap.inbound_mailbox_3.STATUS fields
Table 1144. axil_mailbox_smc_wrap.inbound_mailbox_3.ERROR_FLAGS fields
Table 1145. axil_mailbox_smc_wrap.inbound_mailbox_3.WIRQT fields
Table 1146. axil_mailbox_smc_wrap.inbound_mailbox_3.RIRQT fields
Table 1147. axil_mailbox_smc_wrap.inbound_mailbox_3.IRQS fields
Table 1148. axil_mailbox_smc_wrap.inbound_mailbox_3.IRQEN fields
Table 1149. axil_mailbox_smc_wrap.inbound_mailbox_3.IRQP fields
Table 1150. axil_mailbox_smc_wrap.inbound_mailbox_3.CTRL fields

Table 1151. axil_mailbox_smc_wrap.outbound_mailbox_4.WRITE_DATA fields
Table 1152. axil_mailbox_smc_wrap.outbound_mailbox_4.READ_DATA fields
Table 1153. axil_mailbox_smc_wrap.outbound_mailbox_4.STATUS fields
Table 1154. axil_mailbox_smc_wrap.outbound_mailbox_4.ERROR_FLAGS fields
Table 1155. axil_mailbox_smc_wrap.outbound_mailbox_4.WIRQT fields
Table 1156. axil_mailbox_smc_wrap.outbound_mailbox_4.RIRQT fields
Table 1157. axil_mailbox_smc_wrap.outbound_mailbox_4.IRQS fields
Table 1158. axil_mailbox_smc_wrap.outbound_mailbox_4.IRQEN fields
Table 1159. axil_mailbox_smc_wrap.outbound_mailbox_4.IRQP fields
Table 1160. axil_mailbox_smc_wrap.outbound_mailbox_4.CTRL fields
Table 1161. axil_mailbox_smc_wrap.inbound_mailbox_4.WRITE_DATA fields
Table 1162. axil_mailbox_smc_wrap.inbound_mailbox_4.READ_DATA fields
Table 1163. axil_mailbox_smc_wrap.inbound_mailbox_4.STATUS fields
Table 1164. axil_mailbox_smc_wrap.inbound_mailbox_4.ERROR_FLAGS fields
Table 1165. axil_mailbox_smc_wrap.inbound_mailbox_4.WIRQT fields
Table 1166. axil_mailbox_smc_wrap.inbound_mailbox_4.RIRQT fields
Table 1167. axil_mailbox_smc_wrap.inbound_mailbox_4.IRQS fields
Table 1168. axil_mailbox_smc_wrap.inbound_mailbox_4.IRQEN fields
Table 1169. axil_mailbox_smc_wrap.inbound_mailbox_4.IRQP fields
Table 1170. axil_mailbox_smc_wrap.inbound_mailbox_4.CTRL fields
Table 1171. axil_mailbox_smc_wrap.outbound_mailbox_5.WRITE_DATA fields
Table 1172. axil_mailbox_smc_wrap.outbound_mailbox_5.READ_DATA fields
Table 1173. axil_mailbox_smc_wrap.outbound_mailbox_5.STATUS fields
Table 1174. axil_mailbox_smc_wrap.outbound_mailbox_5.ERROR_FLAGS fields
Table 1175. axil_mailbox_smc_wrap.outbound_mailbox_5.WIRQT fields
Table 1176. axil_mailbox_smc_wrap.outbound_mailbox_5.RIRQT fields
Table 1177. axil_mailbox_smc_wrap.outbound_mailbox_5.IRQS fields
Table 1178. axil_mailbox_smc_wrap.outbound_mailbox_5.IRQEN fields
Table 1179. axil_mailbox_smc_wrap.outbound_mailbox_5.IRQP fields
Table 1180. axil_mailbox_smc_wrap.outbound_mailbox_5.CTRL fields
Table 1181. axil_mailbox_smc_wrap.inbound_mailbox_5.WRITE_DATA fields
Table 1182. axil_mailbox_smc_wrap.inbound_mailbox_5.READ_DATA fields
Table 1183. axil_mailbox_smc_wrap.inbound_mailbox_5.STATUS fields
Table 1184. axil_mailbox_smc_wrap.inbound_mailbox_5.ERROR_FLAGS fields
Table 1185. axil_mailbox_smc_wrap.inbound_mailbox_5.WIRQT fields
Table 1186. axil_mailbox_smc_wrap.inbound_mailbox_5.RIRQT fields

Table 1187. axil_mailbox_smc_wrap.inbound_mailbox_5.IRQS fields
Table 1188. axil_mailbox_smc_wrap.inbound_mailbox_5.IRQEN fields
Table 1189. axil_mailbox_smc_wrap.inbound_mailbox_5.IRQP fields
Table 1190. axil_mailbox_smc_wrap.inbound_mailbox_5.CTRL fields
Table 1191. axil_mailbox_smc_wrap.outbound_mailbox_6.WRITE_DATA fields
Table 1192. axil_mailbox_smc_wrap.outbound_mailbox_6.READ_DATA fields
Table 1193. axil_mailbox_smc_wrap.outbound_mailbox_6.STATUS fields
Table 1194. axil_mailbox_smc_wrap.outbound_mailbox_6.ERROR_FLAGS fields
Table 1195. axil_mailbox_smc_wrap.outbound_mailbox_6.WIRQT fields
Table 1196. axil_mailbox_smc_wrap.outbound_mailbox_6.RIRQT fields
Table 1197. axil_mailbox_smc_wrap.outbound_mailbox_6.IRQS fields
Table 1198. axil_mailbox_smc_wrap.outbound_mailbox_6.IRQEN fields
Table 1199. axil_mailbox_smc_wrap.outbound_mailbox_6.IRQP fields
Table 1200. axil_mailbox_smc_wrap.outbound_mailbox_6.CTRL fields
Table 1201. axil_mailbox_smc_wrap.inbound_mailbox_6.WRITE_DATA fields
Table 1202. axil_mailbox_smc_wrap.inbound_mailbox_6.READ_DATA fields
Table 1203. axil_mailbox_smc_wrap.inbound_mailbox_6.STATUS fields
Table 1204. axil_mailbox_smc_wrap.inbound_mailbox_6.ERROR_FLAGS fields
Table 1205. axil_mailbox_smc_wrap.inbound_mailbox_6.WIRQT fields
Table 1206. axil_mailbox_smc_wrap.inbound_mailbox_6.RIRQT fields
Table 1207. axil_mailbox_smc_wrap.inbound_mailbox_6.IRQS fields
Table 1208. axil_mailbox_smc_wrap.inbound_mailbox_6.IRQEN fields
Table 1209. axil_mailbox_smc_wrap.inbound_mailbox_6.IRQP fields
Table 1210. axil_mailbox_smc_wrap.inbound_mailbox_6.CTRL fields
Table 1211. axil_mailbox_smc_wrap.outbound_mailbox_7.WRITE_DATA fields
Table 1212. axil_mailbox_smc_wrap.outbound_mailbox_7.READ_DATA fields
Table 1213. axil_mailbox_smc_wrap.outbound_mailbox_7.STATUS fields
Table 1214. axil_mailbox_smc_wrap.outbound_mailbox_7.ERROR_FLAGS fields
Table 1215. axil_mailbox_smc_wrap.outbound_mailbox_7.WIRQT fields
Table 1216. axil_mailbox_smc_wrap.outbound_mailbox_7.RIRQT fields
Table 1217. axil_mailbox_smc_wrap.outbound_mailbox_7.IRQS fields
Table 1218. axil_mailbox_smc_wrap.outbound_mailbox_7.IRQEN fields
Table 1219. axil_mailbox_smc_wrap.outbound_mailbox_7.IRQP fields
Table 1220. axil_mailbox_smc_wrap.outbound_mailbox_7.CTRL fields
Table 1221. axil_mailbox_smc_wrap.inbound_mailbox_7.WRITE_DATA fields
Table 1222. axil_mailbox_smc_wrap.inbound_mailbox_7.READ_DATA fields

Table 1223. axil_mailbox_smc_wrap.inbound_mailbox_7.STATUS fields
Table 1224. axil_mailbox_smc_wrap.inbound_mailbox_7.ERROR_FLAGS fields
Table 1225. axil_mailbox_smc_wrap.inbound_mailbox_7.WIRQT fields
Table 1226. axil_mailbox_smc_wrap.inbound_mailbox_7.RIRQT fields
Table 1227. axil_mailbox_smc_wrap.inbound_mailbox_7.IRQS fields
Table 1228. axil_mailbox_smc_wrap.inbound_mailbox_7.IRQEN fields
Table 1229. axil_mailbox_smc_wrap.inbound_mailbox_7.IRQP fields
Table 1230. axil_mailbox_smc_wrap.inbound_mailbox_7.CTRL fields
Table 1231. axil_mailbox_smc_wrap.outbound_mailbox_8.WRITE_DATA fields
Table 1232. axil_mailbox_smc_wrap.outbound_mailbox_8.READ_DATA fields
Table 1233. axil_mailbox_smc_wrap.outbound_mailbox_8.STATUS fields
Table 1234. axil_mailbox_smc_wrap.outbound_mailbox_8.ERROR_FLAGS fields
Table 1235. axil_mailbox_smc_wrap.outbound_mailbox_8.WIRQT fields
Table 1236. axil_mailbox_smc_wrap.outbound_mailbox_8.RIRQT fields
Table 1237. axil_mailbox_smc_wrap.outbound_mailbox_8.IRQS fields
Table 1238. axil_mailbox_smc_wrap.outbound_mailbox_8.IRQEN fields
Table 1239. axil_mailbox_smc_wrap.outbound_mailbox_8.IRQP fields
Table 1240. axil_mailbox_smc_wrap.outbound_mailbox_8.CTRL fields
Table 1241. axil_mailbox_smc_wrap.inbound_mailbox_8.WRITE_DATA fields
Table 1242. axil_mailbox_smc_wrap.inbound_mailbox_8.READ_DATA fields
Table 1243. axil_mailbox_smc_wrap.inbound_mailbox_8.STATUS fields
Table 1244. axil_mailbox_smc_wrap.inbound_mailbox_8.ERROR_FLAGS fields
Table 1245. axil_mailbox_smc_wrap.inbound_mailbox_8.WIRQT fields
Table 1246. axil_mailbox_smc_wrap.inbound_mailbox_8.RIRQT fields
Table 1247. axil_mailbox_smc_wrap.inbound_mailbox_8.IRQS fields
Table 1248. axil_mailbox_smc_wrap.inbound_mailbox_8.IRQEN fields
Table 1249. axil_mailbox_smc_wrap.inbound_mailbox_8.IRQP fields
Table 1250. axil_mailbox_smc_wrap.inbound_mailbox_8.CTRL fields
Table 1251. axil_mailbox_smc_wrap.outbound_mailbox_9.WRITE_DATA fields
Table 1252. axil_mailbox_smc_wrap.outbound_mailbox_9.READ_DATA fields
Table 1253. axil_mailbox_smc_wrap.outbound_mailbox_9.STATUS fields
Table 1254. axil_mailbox_smc_wrap.outbound_mailbox_9.ERROR_FLAGS fields
Table 1255. axil_mailbox_smc_wrap.outbound_mailbox_9.WIRQT fields
Table 1256. axil_mailbox_smc_wrap.outbound_mailbox_9.RIRQT fields
Table 1257. axil_mailbox_smc_wrap.outbound_mailbox_9.IRQS fields
Table 1258. axil_mailbox_smc_wrap.outbound_mailbox_9.IRQEN fields

Table 1259. axil_mailbox_smc_wrap.outbound_mailbox_9.IRQP fields
Table 1260. axil_mailbox_smc_wrap.outbound_mailbox_9.CTRL fields
Table 1261. axil_mailbox_smc_wrap.inbound_mailbox_9.WRITE_DATA fields
Table 1262. axil_mailbox_smc_wrap.inbound_mailbox_9.READ_DATA fields
Table 1263. axil_mailbox_smc_wrap.inbound_mailbox_9.STATUS fields
Table 1264. axil_mailbox_smc_wrap.inbound_mailbox_9.ERROR_FLAGS fields
Table 1265. axil_mailbox_smc_wrap.inbound_mailbox_9.WIRQT fields
Table 1266. axil_mailbox_smc_wrap.inbound_mailbox_9.RIRQT fields
Table 1267. axil_mailbox_smc_wrap.inbound_mailbox_9.IRQS fields
Table 1268. axil_mailbox_smc_wrap.inbound_mailbox_9.IRQEN fields
Table 1269. axil_mailbox_smc_wrap.inbound_mailbox_9.IRQP fields
Table 1270. axil_mailbox_smc_wrap.inbound_mailbox_9.CTRL fields
Table 1271. axil_mailbox_smc_wrap.outbound_mailbox_10.WRITE_DATA fields
Table 1272. axil_mailbox_smc_wrap.outbound_mailbox_10.READ_DATA fields
Table 1273. axil_mailbox_smc_wrap.outbound_mailbox_10.STATUS fields
Table 1274. axil_mailbox_smc_wrap.outbound_mailbox_10.ERROR_FLAGS fields
Table 1275. axil_mailbox_smc_wrap.outbound_mailbox_10.WIRQT fields
Table 1276. axil_mailbox_smc_wrap.outbound_mailbox_10.RIRQT fields
Table 1277. axil_mailbox_smc_wrap.outbound_mailbox_10.IRQS fields
Table 1278. axil_mailbox_smc_wrap.outbound_mailbox_10.IRQEN fields
Table 1279. axil_mailbox_smc_wrap.outbound_mailbox_10.IRQP fields
Table 1280. axil_mailbox_smc_wrap.outbound_mailbox_10.CTRL fields
Table 1281. axil_mailbox_smc_wrap.inbound_mailbox_10.WRITE_DATA fields
Table 1282. axil_mailbox_smc_wrap.inbound_mailbox_10.READ_DATA fields
Table 1283. axil_mailbox_smc_wrap.inbound_mailbox_10.STATUS fields
Table 1284. axil_mailbox_smc_wrap.inbound_mailbox_10.ERROR_FLAGS fields
Table 1285. axil_mailbox_smc_wrap.inbound_mailbox_10.WIRQT fields
Table 1286. axil_mailbox_smc_wrap.inbound_mailbox_10.RIRQT fields
Table 1287. axil_mailbox_smc_wrap.inbound_mailbox_10.IRQS fields
Table 1288. axil_mailbox_smc_wrap.inbound_mailbox_10.IRQEN fields
Table 1289. axil_mailbox_smc_wrap.inbound_mailbox_10.IRQP fields
Table 1290. axil_mailbox_smc_wrap.inbound_mailbox_10.CTRL fields
Table 1291. axil_mailbox_smc_wrap.outbound_mailbox_11.WRITE_DATA fields
Table 1292. axil_mailbox_smc_wrap.outbound_mailbox_11.READ_DATA fields
Table 1293. axil_mailbox_smc_wrap.outbound_mailbox_11.STATUS fields
Table 1294. axil_mailbox_smc_wrap.outbound_mailbox_11.ERROR_FLAGS fields

Table 1295. axil_mailbox_smc_wrap.outbound_mailbox_11.WIRQT fields
Table 1296. axil_mailbox_smc_wrap.outbound_mailbox_11.RIRQT fields
Table 1297. axil_mailbox_smc_wrap.outbound_mailbox_11.IRQS fields
Table 1298. axil_mailbox_smc_wrap.outbound_mailbox_11.IRQEN fields
Table 1299. axil_mailbox_smc_wrap.outbound_mailbox_11.IRQP fields
Table 1300. axil_mailbox_smc_wrap.outbound_mailbox_11.CTRL fields
Table 1301. axil_mailbox_smc_wrap.inbound_mailbox_11.WRITE_DATA fields
Table 1302. axil_mailbox_smc_wrap.inbound_mailbox_11.READ_DATA fields
Table 1303. axil_mailbox_smc_wrap.inbound_mailbox_11.STATUS fields
Table 1304. axil_mailbox_smc_wrap.inbound_mailbox_11.ERROR_FLAGS fields
Table 1305. axil_mailbox_smc_wrap.inbound_mailbox_11.WIRQT fields
Table 1306. axil_mailbox_smc_wrap.inbound_mailbox_11.RIRQT fields
Table 1307. axil_mailbox_smc_wrap.inbound_mailbox_11.IRQS fields
Table 1308. axil_mailbox_smc_wrap.inbound_mailbox_11.IRQEN fields
Table 1309. axil_mailbox_smc_wrap.inbound_mailbox_11.IRQP fields
Table 1310. axil_mailbox_smc_wrap.inbound_mailbox_11.CTRL fields
Table 1311. axil_mailbox_smc_wrap.outbound_mailbox_12.WRITE_DATA fields
Table 1312. axil_mailbox_smc_wrap.outbound_mailbox_12.READ_DATA fields
Table 1313. axil_mailbox_smc_wrap.outbound_mailbox_12.STATUS fields
Table 1314. axil_mailbox_smc_wrap.outbound_mailbox_12.ERROR_FLAGS fields
Table 1315. axil_mailbox_smc_wrap.outbound_mailbox_12.WIRQT fields
Table 1316. axil_mailbox_smc_wrap.outbound_mailbox_12.RIRQT fields
Table 1317. axil_mailbox_smc_wrap.outbound_mailbox_12.IRQS fields
Table 1318. axil_mailbox_smc_wrap.outbound_mailbox_12.IRQEN fields
Table 1319. axil_mailbox_smc_wrap.outbound_mailbox_12.IRQP fields
Table 1320. axil_mailbox_smc_wrap.outbound_mailbox_12.CTRL fields
Table 1321. axil_mailbox_smc_wrap.inbound_mailbox_12.WRITE_DATA fields
Table 1322. axil_mailbox_smc_wrap.inbound_mailbox_12.READ_DATA fields
Table 1323. axil_mailbox_smc_wrap.inbound_mailbox_12.STATUS fields
Table 1324. axil_mailbox_smc_wrap.inbound_mailbox_12.ERROR_FLAGS fields
Table 1325. axil_mailbox_smc_wrap.inbound_mailbox_12.WIRQT fields
Table 1326. axil_mailbox_smc_wrap.inbound_mailbox_12.RIRQT fields
Table 1327. axil_mailbox_smc_wrap.inbound_mailbox_12.IRQS fields
Table 1328. axil_mailbox_smc_wrap.inbound_mailbox_12.IRQEN fields
Table 1329. axil_mailbox_smc_wrap.inbound_mailbox_12.IRQP fields
Table 1330. axil_mailbox_smc_wrap.inbound_mailbox_12.CTRL fields

Table 1331. axil_mailbox_smc_wrap.outbound_mailbox_13.WRITE_DATA fields
Table 1332. axil_mailbox_smc_wrap.outbound_mailbox_13.READ_DATA fields
Table 1333. axil_mailbox_smc_wrap.outbound_mailbox_13.STATUS fields
Table 1334. axil_mailbox_smc_wrap.outbound_mailbox_13.ERROR_FLAGS fields
Table 1335. axil_mailbox_smc_wrap.outbound_mailbox_13.WIRQT fields
Table 1336. axil_mailbox_smc_wrap.outbound_mailbox_13.RIRQT fields
Table 1337. axil_mailbox_smc_wrap.outbound_mailbox_13.IRQS fields
Table 1338. axil_mailbox_smc_wrap.outbound_mailbox_13.IRQEN fields
Table 1339. axil_mailbox_smc_wrap.outbound_mailbox_13.IRQP fields
Table 1340. axil_mailbox_smc_wrap.outbound_mailbox_13.CTRL fields
Table 1341. axil_mailbox_smc_wrap.inbound_mailbox_13.WRITE_DATA fields
Table 1342. axil_mailbox_smc_wrap.inbound_mailbox_13.READ_DATA fields
Table 1343. axil_mailbox_smc_wrap.inbound_mailbox_13.STATUS fields
Table 1344. axil_mailbox_smc_wrap.inbound_mailbox_13.ERROR_FLAGS fields
Table 1345. axil_mailbox_smc_wrap.inbound_mailbox_13.WIRQT fields
Table 1346. axil_mailbox_smc_wrap.inbound_mailbox_13.RIRQT fields
Table 1347. axil_mailbox_smc_wrap.inbound_mailbox_13.IRQS fields
Table 1348. axil_mailbox_smc_wrap.inbound_mailbox_13.IRQEN fields
Table 1349. axil_mailbox_smc_wrap.inbound_mailbox_13.IRQP fields
Table 1350. axil_mailbox_smc_wrap.inbound_mailbox_13.CTRL fields
Table 1351. axil_mailbox_smc_wrap.outbound_mailbox_14.WRITE_DATA fields
Table 1352. axil_mailbox_smc_wrap.outbound_mailbox_14.READ_DATA fields
Table 1353. axil_mailbox_smc_wrap.outbound_mailbox_14.STATUS fields
Table 1354. axil_mailbox_smc_wrap.outbound_mailbox_14.ERROR_FLAGS fields
Table 1355. axil_mailbox_smc_wrap.outbound_mailbox_14.WIRQT fields
Table 1356. axil_mailbox_smc_wrap.outbound_mailbox_14.RIRQT fields
Table 1357. axil_mailbox_smc_wrap.outbound_mailbox_14.IRQS fields
Table 1358. axil_mailbox_smc_wrap.outbound_mailbox_14.IRQEN fields
Table 1359. axil_mailbox_smc_wrap.outbound_mailbox_14.IRQP fields
Table 1360. axil_mailbox_smc_wrap.outbound_mailbox_14.CTRL fields
Table 1361. axil_mailbox_smc_wrap.inbound_mailbox_14.WRITE_DATA fields
Table 1362. axil_mailbox_smc_wrap.inbound_mailbox_14.READ_DATA fields
Table 1363. axil_mailbox_smc_wrap.inbound_mailbox_14.STATUS fields
Table 1364. axil_mailbox_smc_wrap.inbound_mailbox_14.ERROR_FLAGS fields
Table 1365. axil_mailbox_smc_wrap.inbound_mailbox_14.WIRQT fields
Table 1366. axil_mailbox_smc_wrap.inbound_mailbox_14.RIRQT fields

Table 1367. axil_mailbox_smc_wrap.inbound_mailbox_14.IRQS fields
Table 1368. axil_mailbox_smc_wrap.inbound_mailbox_14.IRQEN fields
Table 1369. axil_mailbox_smc_wrap.inbound_mailbox_14.IRQP fields
Table 1370. axil_mailbox_smc_wrap.inbound_mailbox_14.CTRL fields
Table 1371. axil_mailbox_smc_wrap.outbound_mailbox_15.WRITE_DATA fields
Table 1372. axil_mailbox_smc_wrap.outbound_mailbox_15.READ_DATA fields
Table 1373. axil_mailbox_smc_wrap.outbound_mailbox_15.STATUS fields
Table 1374. axil_mailbox_smc_wrap.outbound_mailbox_15.ERROR_FLAGS fields
Table 1375. axil_mailbox_smc_wrap.outbound_mailbox_15.WIRQT fields
Table 1376. axil_mailbox_smc_wrap.outbound_mailbox_15.RIRQT fields
Table 1377. axil_mailbox_smc_wrap.outbound_mailbox_15.IRQS fields
Table 1378. axil_mailbox_smc_wrap.outbound_mailbox_15.IRQEN fields
Table 1379. axil_mailbox_smc_wrap.outbound_mailbox_15.IRQP fields
Table 1380. axil_mailbox_smc_wrap.outbound_mailbox_15.CTRL fields
Table 1381. axil_mailbox_smc_wrap.inbound_mailbox_15.WRITE_DATA fields
Table 1382. axil_mailbox_smc_wrap.inbound_mailbox_15.READ_DATA fields
Table 1383. axil_mailbox_smc_wrap.inbound_mailbox_15.STATUS fields
Table 1384. axil_mailbox_smc_wrap.inbound_mailbox_15.ERROR_FLAGS fields
Table 1385. axil_mailbox_smc_wrap.inbound_mailbox_15.WIRQT fields
Table 1386. axil_mailbox_smc_wrap.inbound_mailbox_15.RIRQT fields
Table 1387. axil_mailbox_smc_wrap.inbound_mailbox_15.IRQS fields
Table 1388. axil_mailbox_smc_wrap.inbound_mailbox_15.IRQEN fields
Table 1389. axil_mailbox_smc_wrap.inbound_mailbox_15.IRQP fields
Table 1390. axil_mailbox_smc_wrap.inbound_mailbox_15.CTRL fields
Table 1391. axil_mailbox_smc_wrap.outbound_mailbox_16.WRITE_DATA fields
Table 1392. axil_mailbox_smc_wrap.outbound_mailbox_16.READ_DATA fields
Table 1393. axil_mailbox_smc_wrap.outbound_mailbox_16.STATUS fields
Table 1394. axil_mailbox_smc_wrap.outbound_mailbox_16.ERROR_FLAGS fields
Table 1395. axil_mailbox_smc_wrap.outbound_mailbox_16.WIRQT fields
Table 1396. axil_mailbox_smc_wrap.outbound_mailbox_16.RIRQT fields
Table 1397. axil_mailbox_smc_wrap.outbound_mailbox_16.IRQS fields
Table 1398. axil_mailbox_smc_wrap.outbound_mailbox_16.IRQEN fields
Table 1399. axil_mailbox_smc_wrap.outbound_mailbox_16.IRQP fields
Table 1400. axil_mailbox_smc_wrap.outbound_mailbox_16.CTRL fields
Table 1401. axil_mailbox_smc_wrap.inbound_mailbox_16.WRITE_DATA fields
Table 1402. axil_mailbox_smc_wrap.inbound_mailbox_16.READ_DATA fields

Table 1403. axil_mailbox_smc_wrap.inbound_mailbox_16.STATUS fields
Table 1404. axil_mailbox_smc_wrap.inbound_mailbox_16.ERROR_FLAGS fields
Table 1405. axil_mailbox_smc_wrap.inbound_mailbox_16.WIRQT fields
Table 1406. axil_mailbox_smc_wrap.inbound_mailbox_16.RIRQT fields
Table 1407. axil_mailbox_smc_wrap.inbound_mailbox_16.IRQS fields
Table 1408. axil_mailbox_smc_wrap.inbound_mailbox_16.IRQEN fields
Table 1409. axil_mailbox_smc_wrap.inbound_mailbox_16.IRQP fields
Table 1410. axil_mailbox_smc_wrap.inbound_mailbox_16.CTRL fields
Table 1411. axil_mailbox_smc_wrap.outbound_mailbox_17.WRITE_DATA fields
Table 1412. axil_mailbox_smc_wrap.outbound_mailbox_17.READ_DATA fields
Table 1413. axil_mailbox_smc_wrap.outbound_mailbox_17.STATUS fields
Table 1414. axil_mailbox_smc_wrap.outbound_mailbox_17.ERROR_FLAGS fields
Table 1415. axil_mailbox_smc_wrap.outbound_mailbox_17.WIRQT fields
Table 1416. axil_mailbox_smc_wrap.outbound_mailbox_17.RIRQT fields
Table 1417. axil_mailbox_smc_wrap.outbound_mailbox_17.IRQS fields
Table 1418. axil_mailbox_smc_wrap.outbound_mailbox_17.IRQEN fields
Table 1419. axil_mailbox_smc_wrap.outbound_mailbox_17.IRQP fields
Table 1420. axil_mailbox_smc_wrap.outbound_mailbox_17.CTRL fields
Table 1421. axil_mailbox_smc_wrap.inbound_mailbox_17.WRITE_DATA fields
Table 1422. axil_mailbox_smc_wrap.inbound_mailbox_17.READ_DATA fields
Table 1423. axil_mailbox_smc_wrap.inbound_mailbox_17.STATUS fields
Table 1424. axil_mailbox_smc_wrap.inbound_mailbox_17.ERROR_FLAGS fields
Table 1425. axil_mailbox_smc_wrap.inbound_mailbox_17.WIRQT fields
Table 1426. axil_mailbox_smc_wrap.inbound_mailbox_17.RIRQT fields
Table 1427. axil_mailbox_smc_wrap.inbound_mailbox_17.IRQS fields
Table 1428. axil_mailbox_smc_wrap.inbound_mailbox_17.IRQEN fields
Table 1429. axil_mailbox_smc_wrap.inbound_mailbox_17.IRQP fields
Table 1430. axil_mailbox_smc_wrap.inbound_mailbox_17.CTRL fields
Table 1431. axil_mailbox_smc_wrap.outbound_mailbox_18.WRITE_DATA fields
Table 1432. axil_mailbox_smc_wrap.outbound_mailbox_18.READ_DATA fields
Table 1433. axil_mailbox_smc_wrap.outbound_mailbox_18.STATUS fields
Table 1434. axil_mailbox_smc_wrap.outbound_mailbox_18.ERROR_FLAGS fields
Table 1435. axil_mailbox_smc_wrap.outbound_mailbox_18.WIRQT fields
Table 1436. axil_mailbox_smc_wrap.outbound_mailbox_18.RIRQT fields
Table 1437. axil_mailbox_smc_wrap.outbound_mailbox_18.IRQS fields
Table 1438. axil_mailbox_smc_wrap.outbound_mailbox_18.IRQEN fields

Table 1439. axil_mailbox_smc_wrap.outbound_mailbox_18.IRQP fields
Table 1440. axil_mailbox_smc_wrap.outbound_mailbox_18.CTRL fields
Table 1441. axil_mailbox_smc_wrap.inbound_mailbox_18.WRITE_DATA fields
Table 1442. axil_mailbox_smc_wrap.inbound_mailbox_18.READ_DATA fields
Table 1443. axil_mailbox_smc_wrap.inbound_mailbox_18.STATUS fields
Table 1444. axil_mailbox_smc_wrap.inbound_mailbox_18.ERROR_FLAGS fields
Table 1445. axil_mailbox_smc_wrap.inbound_mailbox_18.WIRQT fields
Table 1446. axil_mailbox_smc_wrap.inbound_mailbox_18.RIRQT fields
Table 1447. axil_mailbox_smc_wrap.inbound_mailbox_18.IRQS fields
Table 1448. axil_mailbox_smc_wrap.inbound_mailbox_18.IRQEN fields
Table 1449. axil_mailbox_smc_wrap.inbound_mailbox_18.IRQP fields
Table 1450. axil_mailbox_smc_wrap.inbound_mailbox_18.CTRL fields
Table 1451. axil_mailbox_smc_wrap.outbound_mailbox_19.WRITE_DATA fields
Table 1452. axil_mailbox_smc_wrap.outbound_mailbox_19.READ_DATA fields
Table 1453. axil_mailbox_smc_wrap.outbound_mailbox_19.STATUS fields
Table 1454. axil_mailbox_smc_wrap.outbound_mailbox_19.ERROR_FLAGS fields
Table 1455. axil_mailbox_smc_wrap.outbound_mailbox_19.WIRQT fields
Table 1456. axil_mailbox_smc_wrap.outbound_mailbox_19.RIRQT fields
Table 1457. axil_mailbox_smc_wrap.outbound_mailbox_19.IRQS fields
Table 1458. axil_mailbox_smc_wrap.outbound_mailbox_19.IRQEN fields
Table 1459. axil_mailbox_smc_wrap.outbound_mailbox_19.IRQP fields
Table 1460. axil_mailbox_smc_wrap.outbound_mailbox_19.CTRL fields
Table 1461. axil_mailbox_smc_wrap.inbound_mailbox_19.WRITE_DATA fields
Table 1462. axil_mailbox_smc_wrap.inbound_mailbox_19.READ_DATA fields
Table 1463. axil_mailbox_smc_wrap.inbound_mailbox_19.STATUS fields
Table 1464. axil_mailbox_smc_wrap.inbound_mailbox_19.ERROR_FLAGS fields
Table 1465. axil_mailbox_smc_wrap.inbound_mailbox_19.WIRQT fields
Table 1466. axil_mailbox_smc_wrap.inbound_mailbox_19.RIRQT fields
Table 1467. axil_mailbox_smc_wrap.inbound_mailbox_19.IRQS fields
Table 1468. axil_mailbox_smc_wrap.inbound_mailbox_19.IRQEN fields
Table 1469. axil_mailbox_smc_wrap.inbound_mailbox_19.IRQP fields
Table 1470. axil_mailbox_smc_wrap.inbound_mailbox_19.CTRL fields
Table 1471. axil_mailbox_smc_wrap.outbound_mailbox_20.WRITE_DATA fields
Table 1472. axil_mailbox_smc_wrap.outbound_mailbox_20.READ_DATA fields
Table 1473. axil_mailbox_smc_wrap.outbound_mailbox_20.STATUS fields
Table 1474. axil_mailbox_smc_wrap.outbound_mailbox_20.ERROR_FLAGS fields

Table 1475. axil_mailbox_smc_wrap.outbound_mailbox_20.WIRQT fields
Table 1476. axil_mailbox_smc_wrap.outbound_mailbox_20.RIRQT fields
Table 1477. axil_mailbox_smc_wrap.outbound_mailbox_20.IRQS fields
Table 1478. axil_mailbox_smc_wrap.outbound_mailbox_20.IRQEN fields
Table 1479. axil_mailbox_smc_wrap.outbound_mailbox_20.IRQP fields
Table 1480. axil_mailbox_smc_wrap.outbound_mailbox_20.CTRL fields
Table 1481. axil_mailbox_smc_wrap.inbound_mailbox_20.WRITE_DATA fields
Table 1482. axil_mailbox_smc_wrap.inbound_mailbox_20.READ_DATA fields
Table 1483. axil_mailbox_smc_wrap.inbound_mailbox_20.STATUS fields
Table 1484. axil_mailbox_smc_wrap.inbound_mailbox_20.ERROR_FLAGS fields
Table 1485. axil_mailbox_smc_wrap.inbound_mailbox_20.WIRQT fields
Table 1486. axil_mailbox_smc_wrap.inbound_mailbox_20.RIRQT fields
Table 1487. axil_mailbox_smc_wrap.inbound_mailbox_20.IRQS fields
Table 1488. axil_mailbox_smc_wrap.inbound_mailbox_20.IRQEN fields
Table 1489. axil_mailbox_smc_wrap.inbound_mailbox_20.IRQP fields
Table 1490. axil_mailbox_smc_wrap.inbound_mailbox_20.CTRL fields
Table 1491. axil_mailbox_smc_wrap.outbound_mailbox_21.WRITE_DATA fields
Table 1492. axil_mailbox_smc_wrap.outbound_mailbox_21.READ_DATA fields
Table 1493. axil_mailbox_smc_wrap.outbound_mailbox_21.STATUS fields
Table 1494. axil_mailbox_smc_wrap.outbound_mailbox_21.ERROR_FLAGS fields
Table 1495. axil_mailbox_smc_wrap.outbound_mailbox_21.WIRQT fields
Table 1496. axil_mailbox_smc_wrap.outbound_mailbox_21.RIRQT fields
Table 1497. axil_mailbox_smc_wrap.outbound_mailbox_21.IRQS fields
Table 1498. axil_mailbox_smc_wrap.outbound_mailbox_21.IRQEN fields
Table 1499. axil_mailbox_smc_wrap.outbound_mailbox_21.IRQP fields
Table 1500. axil_mailbox_smc_wrap.outbound_mailbox_21.CTRL fields
Table 1501. axil_mailbox_smc_wrap.inbound_mailbox_21.WRITE_DATA fields
Table 1502. axil_mailbox_smc_wrap.inbound_mailbox_21.READ_DATA fields
Table 1503. axil_mailbox_smc_wrap.inbound_mailbox_21.STATUS fields
Table 1504. axil_mailbox_smc_wrap.inbound_mailbox_21.ERROR_FLAGS fields
Table 1505. axil_mailbox_smc_wrap.inbound_mailbox_21.WIRQT fields
Table 1506. axil_mailbox_smc_wrap.inbound_mailbox_21.RIRQT fields
Table 1507. axil_mailbox_smc_wrap.inbound_mailbox_21.IRQS fields
Table 1508. axil_mailbox_smc_wrap.inbound_mailbox_21.IRQEN fields
Table 1509. axil_mailbox_smc_wrap.inbound_mailbox_21.IRQP fields
Table 1510. axil_mailbox_smc_wrap.inbound_mailbox_21.CTRL fields

Table 1511. axil_mailbox_smc_wrap.outbound_mailbox_22.WRITE_DATA fields
Table 1512. axil_mailbox_smc_wrap.outbound_mailbox_22.READ_DATA fields
Table 1513. axil_mailbox_smc_wrap.outbound_mailbox_22.STATUS fields
Table 1514. axil_mailbox_smc_wrap.outbound_mailbox_22.ERROR_FLAGS fields
Table 1515. axil_mailbox_smc_wrap.outbound_mailbox_22.WIRQT fields
Table 1516. axil_mailbox_smc_wrap.outbound_mailbox_22.RIRQT fields
Table 1517. axil_mailbox_smc_wrap.outbound_mailbox_22.IRQS fields
Table 1518. axil_mailbox_smc_wrap.outbound_mailbox_22.IRQEN fields
Table 1519. axil_mailbox_smc_wrap.outbound_mailbox_22.IRQP fields
Table 1520. axil_mailbox_smc_wrap.outbound_mailbox_22.CTRL fields
Table 1521. axil_mailbox_smc_wrap.inbound_mailbox_22.WRITE_DATA fields
Table 1522. axil_mailbox_smc_wrap.inbound_mailbox_22.READ_DATA fields
Table 1523. axil_mailbox_smc_wrap.inbound_mailbox_22.STATUS fields
Table 1524. axil_mailbox_smc_wrap.inbound_mailbox_22.ERROR_FLAGS fields
Table 1525. axil_mailbox_smc_wrap.inbound_mailbox_22.WIRQT fields
Table 1526. axil_mailbox_smc_wrap.inbound_mailbox_22.RIRQT fields
Table 1527. axil_mailbox_smc_wrap.inbound_mailbox_22.IRQS fields
Table 1528. axil_mailbox_smc_wrap.inbound_mailbox_22.IRQEN fields
Table 1529. axil_mailbox_smc_wrap.inbound_mailbox_22.IRQP fields
Table 1530. axil_mailbox_smc_wrap.inbound_mailbox_22.CTRL fields
Table 1531. axil_mailbox_smc_wrap.outbound_mailbox_23.WRITE_DATA fields
Table 1532. axil_mailbox_smc_wrap.outbound_mailbox_23.READ_DATA fields
Table 1533. axil_mailbox_smc_wrap.outbound_mailbox_23.STATUS fields
Table 1534. axil_mailbox_smc_wrap.outbound_mailbox_23.ERROR_FLAGS fields
Table 1535. axil_mailbox_smc_wrap.outbound_mailbox_23.WIRQT fields
Table 1536. axil_mailbox_smc_wrap.outbound_mailbox_23.RIRQT fields
Table 1537. axil_mailbox_smc_wrap.outbound_mailbox_23.IRQS fields
Table 1538. axil_mailbox_smc_wrap.outbound_mailbox_23.IRQEN fields
Table 1539. axil_mailbox_smc_wrap.outbound_mailbox_23.IRQP fields
Table 1540. axil_mailbox_smc_wrap.outbound_mailbox_23.CTRL fields
Table 1541. axil_mailbox_smc_wrap.inbound_mailbox_23.WRITE_DATA fields
Table 1542. axil_mailbox_smc_wrap.inbound_mailbox_23.READ_DATA fields
Table 1543. axil_mailbox_smc_wrap.inbound_mailbox_23.STATUS fields
Table 1544. axil_mailbox_smc_wrap.inbound_mailbox_23.ERROR_FLAGS fields
Table 1545. axil_mailbox_smc_wrap.inbound_mailbox_23.WIRQT fields
Table 1546. axil_mailbox_smc_wrap.inbound_mailbox_23.RIRQT fields

Table 1547. axil_mailbox_smc_wrap.inbound_mailbox_23.IRQS fields
Table 1548. axil_mailbox_smc_wrap.inbound_mailbox_23.IRQEN fields
Table 1549. axil_mailbox_smc_wrap.inbound_mailbox_23.IRQP fields
Table 1550. axil_mailbox_smc_wrap.inbound_mailbox_23.CTRL fields
Table 1551. axil_mailbox_smc_wrap.outbound_mailbox_24.WRITE_DATA fields
Table 1552. axil_mailbox_smc_wrap.outbound_mailbox_24.READ_DATA fields
Table 1553. axil_mailbox_smc_wrap.outbound_mailbox_24.STATUS fields
Table 1554. axil_mailbox_smc_wrap.outbound_mailbox_24.ERROR_FLAGS fields
Table 1555. axil_mailbox_smc_wrap.outbound_mailbox_24.WIRQT fields
Table 1556. axil_mailbox_smc_wrap.outbound_mailbox_24.RIRQT fields
Table 1557. axil_mailbox_smc_wrap.outbound_mailbox_24.IRQS fields
Table 1558. axil_mailbox_smc_wrap.outbound_mailbox_24.IRQEN fields
Table 1559. axil_mailbox_smc_wrap.outbound_mailbox_24.IRQP fields
Table 1560. axil_mailbox_smc_wrap.outbound_mailbox_24.CTRL fields
Table 1561. axil_mailbox_smc_wrap.inbound_mailbox_24.WRITE_DATA fields
Table 1562. axil_mailbox_smc_wrap.inbound_mailbox_24.READ_DATA fields
Table 1563. axil_mailbox_smc_wrap.inbound_mailbox_24.STATUS fields
Table 1564. axil_mailbox_smc_wrap.inbound_mailbox_24.ERROR_FLAGS fields
Table 1565. axil_mailbox_smc_wrap.inbound_mailbox_24.WIRQT fields
Table 1566. axil_mailbox_smc_wrap.inbound_mailbox_24.RIRQT fields
Table 1567. axil_mailbox_smc_wrap.inbound_mailbox_24.IRQS fields
Table 1568. axil_mailbox_smc_wrap.inbound_mailbox_24.IRQEN fields
Table 1569. axil_mailbox_smc_wrap.inbound_mailbox_24.IRQP fields
Table 1570. axil_mailbox_smc_wrap.inbound_mailbox_24.CTRL fields
Table 1571. axil_mailbox_smc_wrap.outbound_mailbox_25.WRITE_DATA fields
Table 1572. axil_mailbox_smc_wrap.outbound_mailbox_25.READ_DATA fields
Table 1573. axil_mailbox_smc_wrap.outbound_mailbox_25.STATUS fields
Table 1574. axil_mailbox_smc_wrap.outbound_mailbox_25.ERROR_FLAGS fields
Table 1575. axil_mailbox_smc_wrap.outbound_mailbox_25.WIRQT fields
Table 1576. axil_mailbox_smc_wrap.outbound_mailbox_25.RIRQT fields
Table 1577. axil_mailbox_smc_wrap.outbound_mailbox_25.IRQS fields
Table 1578. axil_mailbox_smc_wrap.outbound_mailbox_25.IRQEN fields
Table 1579. axil_mailbox_smc_wrap.outbound_mailbox_25.IRQP fields
Table 1580. axil_mailbox_smc_wrap.outbound_mailbox_25.CTRL fields
Table 1581. axil_mailbox_smc_wrap.inbound_mailbox_25.WRITE_DATA fields
Table 1582. axil_mailbox_smc_wrap.inbound_mailbox_25.READ_DATA fields

Table 1583. axil_mailbox_smc_wrap.inbound_mailbox_25.STATUS fields
Table 1584. axil_mailbox_smc_wrap.inbound_mailbox_25.ERROR_FLAGS fields
Table 1585. axil_mailbox_smc_wrap.inbound_mailbox_25.WIRQT fields
Table 1586. axil_mailbox_smc_wrap.inbound_mailbox_25.RIRQT fields
Table 1587. axil_mailbox_smc_wrap.inbound_mailbox_25.IRQS fields
Table 1588. axil_mailbox_smc_wrap.inbound_mailbox_25.IRQEN fields
Table 1589. axil_mailbox_smc_wrap.inbound_mailbox_25.IRQP fields
Table 1590. axil_mailbox_smc_wrap.inbound_mailbox_25.CTRL fields
Table 1591. axil_mailbox_smc_wrap.outbound_mailbox_26.WRITE_DATA fields
Table 1592. axil_mailbox_smc_wrap.outbound_mailbox_26.READ_DATA fields
Table 1593. axil_mailbox_smc_wrap.outbound_mailbox_26.STATUS fields
Table 1594. axil_mailbox_smc_wrap.outbound_mailbox_26.ERROR_FLAGS fields
Table 1595. axil_mailbox_smc_wrap.outbound_mailbox_26.WIRQT fields
Table 1596. axil_mailbox_smc_wrap.outbound_mailbox_26.RIRQT fields
Table 1597. axil_mailbox_smc_wrap.outbound_mailbox_26.IRQS fields
Table 1598. axil_mailbox_smc_wrap.outbound_mailbox_26.IRQEN fields
Table 1599. axil_mailbox_smc_wrap.outbound_mailbox_26.IRQP fields
Table 1600. axil_mailbox_smc_wrap.outbound_mailbox_26.CTRL fields
Table 1601. axil_mailbox_smc_wrap.inbound_mailbox_26.WRITE_DATA fields
Table 1602. axil_mailbox_smc_wrap.inbound_mailbox_26.READ_DATA fields
Table 1603. axil_mailbox_smc_wrap.inbound_mailbox_26.STATUS fields
Table 1604. axil_mailbox_smc_wrap.inbound_mailbox_26.ERROR_FLAGS fields
Table 1605. axil_mailbox_smc_wrap.inbound_mailbox_26.WIRQT fields
Table 1606. axil_mailbox_smc_wrap.inbound_mailbox_26.RIRQT fields
Table 1607. axil_mailbox_smc_wrap.inbound_mailbox_26.IRQS fields
Table 1608. axil_mailbox_smc_wrap.inbound_mailbox_26.IRQEN fields
Table 1609. axil_mailbox_smc_wrap.inbound_mailbox_26.IRQP fields
Table 1610. axil_mailbox_smc_wrap.inbound_mailbox_26.CTRL fields
Table 1611. axil_mailbox_smc_wrap.outbound_mailbox_27.WRITE_DATA fields
Table 1612. axil_mailbox_smc_wrap.outbound_mailbox_27.READ_DATA fields
Table 1613. axil_mailbox_smc_wrap.outbound_mailbox_27.STATUS fields
Table 1614. axil_mailbox_smc_wrap.outbound_mailbox_27.ERROR_FLAGS fields
Table 1615. axil_mailbox_smc_wrap.outbound_mailbox_27.WIRQT fields
Table 1616. axil_mailbox_smc_wrap.outbound_mailbox_27.RIRQT fields
Table 1617. axil_mailbox_smc_wrap.outbound_mailbox_27.IRQS fields
Table 1618. axil_mailbox_smc_wrap.outbound_mailbox_27.IRQEN fields

Table 1619. axil_mailbox_smc_wrap.outbound_mailbox_27.IRQP fields
Table 1620. axil_mailbox_smc_wrap.outbound_mailbox_27.CTRL fields
Table 1621. axil_mailbox_smc_wrap.inbound_mailbox_27.WRITE_DATA fields
Table 1622. axil_mailbox_smc_wrap.inbound_mailbox_27.READ_DATA fields
Table 1623. axil_mailbox_smc_wrap.inbound_mailbox_27.STATUS fields
Table 1624. axil_mailbox_smc_wrap.inbound_mailbox_27.ERROR_FLAGS fields
Table 1625. axil_mailbox_smc_wrap.inbound_mailbox_27.WIRQT fields
Table 1626. axil_mailbox_smc_wrap.inbound_mailbox_27.RIRQT fields
Table 1627. axil_mailbox_smc_wrap.inbound_mailbox_27.IRQS fields
Table 1628. axil_mailbox_smc_wrap.inbound_mailbox_27.IRQEN fields
Table 1629. axil_mailbox_smc_wrap.inbound_mailbox_27.IRQP fields
Table 1630. axil_mailbox_smc_wrap.inbound_mailbox_27.CTRL fields
Table 1631. axil_mailbox_smc_wrap.outbound_mailbox_28.WRITE_DATA fields
Table 1632. axil_mailbox_smc_wrap.outbound_mailbox_28.READ_DATA fields
Table 1633. axil_mailbox_smc_wrap.outbound_mailbox_28.STATUS fields
Table 1634. axil_mailbox_smc_wrap.outbound_mailbox_28.ERROR_FLAGS fields
Table 1635. axil_mailbox_smc_wrap.outbound_mailbox_28.WIRQT fields
Table 1636. axil_mailbox_smc_wrap.outbound_mailbox_28.RIRQT fields
Table 1637. axil_mailbox_smc_wrap.outbound_mailbox_28.IRQS fields
Table 1638. axil_mailbox_smc_wrap.outbound_mailbox_28.IRQEN fields
Table 1639. axil_mailbox_smc_wrap.outbound_mailbox_28.IRQP fields
Table 1640. axil_mailbox_smc_wrap.outbound_mailbox_28.CTRL fields
Table 1641. axil_mailbox_smc_wrap.inbound_mailbox_28.WRITE_DATA fields
Table 1642. axil_mailbox_smc_wrap.inbound_mailbox_28.READ_DATA fields
Table 1643. axil_mailbox_smc_wrap.inbound_mailbox_28.STATUS fields
Table 1644. axil_mailbox_smc_wrap.inbound_mailbox_28.ERROR_FLAGS fields
Table 1645. axil_mailbox_smc_wrap.inbound_mailbox_28.WIRQT fields
Table 1646. axil_mailbox_smc_wrap.inbound_mailbox_28.RIRQT fields
Table 1647. axil_mailbox_smc_wrap.inbound_mailbox_28.IRQS fields
Table 1648. axil_mailbox_smc_wrap.inbound_mailbox_28.IRQEN fields
Table 1649. axil_mailbox_smc_wrap.inbound_mailbox_28.IRQP fields
Table 1650. axil_mailbox_smc_wrap.inbound_mailbox_28.CTRL fields
Table 1651. axil_mailbox_smc_wrap.outbound_mailbox_29.WRITE_DATA fields
Table 1652. axil_mailbox_smc_wrap.outbound_mailbox_29.READ_DATA fields
Table 1653. axil_mailbox_smc_wrap.outbound_mailbox_29.STATUS fields
Table 1654. axil_mailbox_smc_wrap.outbound_mailbox_29.ERROR_FLAGS fields

Table 1655. axil_mailbox_smc_wrap.outbound_mailbox_29.WIRQT fields
Table 1656. axil_mailbox_smc_wrap.outbound_mailbox_29.RIRQT fields
Table 1657. axil_mailbox_smc_wrap.outbound_mailbox_29.IRQS fields
Table 1658. axil_mailbox_smc_wrap.outbound_mailbox_29.IRQEN fields
Table 1659. axil_mailbox_smc_wrap.outbound_mailbox_29.IRQP fields
Table 1660. axil_mailbox_smc_wrap.outbound_mailbox_29.CTRL fields
Table 1661. axil_mailbox_smc_wrap.inbound_mailbox_29.WRITE_DATA fields
Table 1662. axil_mailbox_smc_wrap.inbound_mailbox_29.READ_DATA fields
Table 1663. axil_mailbox_smc_wrap.inbound_mailbox_29.STATUS fields
Table 1664. axil_mailbox_smc_wrap.inbound_mailbox_29.ERROR_FLAGS fields
Table 1665. axil_mailbox_smc_wrap.inbound_mailbox_29.WIRQT fields
Table 1666. axil_mailbox_smc_wrap.inbound_mailbox_29.RIRQT fields
Table 1667. axil_mailbox_smc_wrap.inbound_mailbox_29.IRQS fields
Table 1668. axil_mailbox_smc_wrap.inbound_mailbox_29.IRQEN fields
Table 1669. axil_mailbox_smc_wrap.inbound_mailbox_29.IRQP fields
Table 1670. axil_mailbox_smc_wrap.inbound_mailbox_29.CTRL fields
Table 1671. axil_mailbox_smc_wrap.outbound_mailbox_30.WRITE_DATA fields
Table 1672. axil_mailbox_smc_wrap.outbound_mailbox_30.READ_DATA fields
Table 1673. axil_mailbox_smc_wrap.outbound_mailbox_30.STATUS fields
Table 1674. axil_mailbox_smc_wrap.outbound_mailbox_30.ERROR_FLAGS fields
Table 1675. axil_mailbox_smc_wrap.outbound_mailbox_30.WIRQT fields
Table 1676. axil_mailbox_smc_wrap.outbound_mailbox_30.RIRQT fields
Table 1677. axil_mailbox_smc_wrap.outbound_mailbox_30.IRQS fields
Table 1678. axil_mailbox_smc_wrap.outbound_mailbox_30.IRQEN fields
Table 1679. axil_mailbox_smc_wrap.outbound_mailbox_30.IRQP fields
Table 1680. axil_mailbox_smc_wrap.outbound_mailbox_30.CTRL fields
Table 1681. axil_mailbox_smc_wrap.inbound_mailbox_30.WRITE_DATA fields
Table 1682. axil_mailbox_smc_wrap.inbound_mailbox_30.READ_DATA fields
Table 1683. axil_mailbox_smc_wrap.inbound_mailbox_30.STATUS fields
Table 1684. axil_mailbox_smc_wrap.inbound_mailbox_30.ERROR_FLAGS fields
Table 1685. axil_mailbox_smc_wrap.inbound_mailbox_30.WIRQT fields
Table 1686. axil_mailbox_smc_wrap.inbound_mailbox_30.RIRQT fields
Table 1687. axil_mailbox_smc_wrap.inbound_mailbox_30.IRQS fields
Table 1688. axil_mailbox_smc_wrap.inbound_mailbox_30.IRQEN fields
Table 1689. axil_mailbox_smc_wrap.inbound_mailbox_30.IRQP fields
Table 1690. axil_mailbox_smc_wrap.inbound_mailbox_30.CTRL fields

Table 1691. axil_mailbox_smc_wrap.outbound_mailbox_31.WRITE_DATA fields
Table 1692. axil_mailbox_smc_wrap.outbound_mailbox_31.READ_DATA fields
Table 1693. axil_mailbox_smc_wrap.outbound_mailbox_31.STATUS fields
Table 1694. axil_mailbox_smc_wrap.outbound_mailbox_31.ERROR_FLAGS fields
Table 1695. axil_mailbox_smc_wrap.outbound_mailbox_31.WIRQT fields
Table 1696. axil_mailbox_smc_wrap.outbound_mailbox_31.RIRQT fields
Table 1697. axil_mailbox_smc_wrap.outbound_mailbox_31.IRQS fields
Table 1698. axil_mailbox_smc_wrap.outbound_mailbox_31.IRQEN fields
Table 1699. axil_mailbox_smc_wrap.outbound_mailbox_31.IRQP fields
Table 1700. axil_mailbox_smc_wrap.outbound_mailbox_31.CTRL fields
Table 1701. axil_mailbox_smc_wrap.inbound_mailbox_31.WRITE_DATA fields
Table 1702. axil_mailbox_smc_wrap.inbound_mailbox_31.READ_DATA fields
Table 1703. axil_mailbox_smc_wrap.inbound_mailbox_31.STATUS fields
Table 1704. axil_mailbox_smc_wrap.inbound_mailbox_31.ERROR_FLAGS fields
Table 1705. axil_mailbox_smc_wrap.inbound_mailbox_31.WIRQT fields
Table 1706. axil_mailbox_smc_wrap.inbound_mailbox_31.RIRQT fields
Table 1707. axil_mailbox_smc_wrap.inbound_mailbox_31.IRQS fields
Table 1708. axil_mailbox_smc_wrap.inbound_mailbox_31.IRQEN fields
Table 1709. axil_mailbox_smc_wrap.inbound_mailbox_31.IRQP fields
Table 1710. axil_mailbox_smc_wrap.inbound_mailbox_31.CTRL fields
Table 1711. SEP AXI-Lite Mailbox Wrapper Address Map register list
Table 1712. axil_mailbox_sep_wrap.outbound_mailbox_0.WRITE_DATA fields
Table 1713. axil_mailbox_sep_wrap.outbound_mailbox_0.READ_DATA fields
Table 1714. axil_mailbox_sep_wrap.outbound_mailbox_0.STATUS fields
Table 1715. axil_mailbox_sep_wrap.outbound_mailbox_0.ERROR_FLAGS fields
Table 1716. axil_mailbox_sep_wrap.outbound_mailbox_0.WIRQT fields
Table 1717. axil_mailbox_sep_wrap.outbound_mailbox_0.RIRQT fields
Table 1718. axil_mailbox_sep_wrap.outbound_mailbox_0.IRQS fields
Table 1719. axil_mailbox_sep_wrap.outbound_mailbox_0.IRQEN fields
Table 1720. axil_mailbox_sep_wrap.outbound_mailbox_0.IRQP fields
Table 1721. axil_mailbox_sep_wrap.outbound_mailbox_0.CTRL fields
Table 1722. axil_mailbox_sep_wrap.inbound_mailbox_0.WRITE_DATA fields
Table 1723. axil_mailbox_sep_wrap.inbound_mailbox_0.READ_DATA fields
Table 1724. axil_mailbox_sep_wrap.inbound_mailbox_0.STATUS fields
Table 1725. axil_mailbox_sep_wrap.inbound_mailbox_0.ERROR_FLAGS fields
Table 1726. axil_mailbox_sep_wrap.inbound_mailbox_0.WIRQT fields

Table 1727. axil_mailbox_sep_wrap.inbound_mailbox_0.RIRQT fields
Table 1728. axil_mailbox_sep_wrap.inbound_mailbox_0.IRQS fields
Table 1729. axil_mailbox_sep_wrap.inbound_mailbox_0.IRQEN fields
Table 1730. axil_mailbox_sep_wrap.inbound_mailbox_0.IRQP fields
Table 1731. axil_mailbox_sep_wrap.inbound_mailbox_0.CTRL fields
Table 1732. axil_mailbox_sep_wrap.outbound_mailbox_1.WRITE_DATA fields
Table 1733. axil_mailbox_sep_wrap.outbound_mailbox_1.READ_DATA fields
Table 1734. axil_mailbox_sep_wrap.outbound_mailbox_1.STATUS fields
Table 1735. axil_mailbox_sep_wrap.outbound_mailbox_1.ERROR_FLAGS fields
Table 1736. axil_mailbox_sep_wrap.outbound_mailbox_1.WIRQT fields
Table 1737. axil_mailbox_sep_wrap.outbound_mailbox_1.RIRQT fields
Table 1738. axil_mailbox_sep_wrap.outbound_mailbox_1.IRQS fields
Table 1739. axil_mailbox_sep_wrap.outbound_mailbox_1.IRQEN fields
Table 1740. axil_mailbox_sep_wrap.outbound_mailbox_1.IRQP fields
Table 1741. axil_mailbox_sep_wrap.outbound_mailbox_1.CTRL fields
Table 1742. axil_mailbox_sep_wrap.inbound_mailbox_1.WRITE_DATA fields
Table 1743. axil_mailbox_sep_wrap.inbound_mailbox_1.READ_DATA fields
Table 1744. axil_mailbox_sep_wrap.inbound_mailbox_1.STATUS fields
Table 1745. axil_mailbox_sep_wrap.inbound_mailbox_1.ERROR_FLAGS fields
Table 1746. axil_mailbox_sep_wrap.inbound_mailbox_1.WIRQT fields
Table 1747. axil_mailbox_sep_wrap.inbound_mailbox_1.RIRQT fields
Table 1748. axil_mailbox_sep_wrap.inbound_mailbox_1.IRQS fields
Table 1749. axil_mailbox_sep_wrap.inbound_mailbox_1.IRQEN fields
Table 1750. axil_mailbox_sep_wrap.inbound_mailbox_1.IRQP fields
Table 1751. axil_mailbox_sep_wrap.inbound_mailbox_1.CTRL fields
Table 1752. axil_mailbox_sep_wrap.outbound_mailbox_2.WRITE_DATA fields
Table 1753. axil_mailbox_sep_wrap.outbound_mailbox_2.READ_DATA fields
Table 1754. axil_mailbox_sep_wrap.outbound_mailbox_2.STATUS fields
Table 1755. axil_mailbox_sep_wrap.outbound_mailbox_2.ERROR_FLAGS fields
Table 1756. axil_mailbox_sep_wrap.outbound_mailbox_2.WIRQT fields
Table 1757. axil_mailbox_sep_wrap.outbound_mailbox_2.RIRQT fields
Table 1758. axil_mailbox_sep_wrap.outbound_mailbox_2.IRQS fields
Table 1759. axil_mailbox_sep_wrap.outbound_mailbox_2.IRQEN fields
Table 1760. axil_mailbox_sep_wrap.outbound_mailbox_2.IRQP fields
Table 1761. axil_mailbox_sep_wrap.outbound_mailbox_2.CTRL fields
Table 1762. axil_mailbox_sep_wrap.inbound_mailbox_2.WRITE_DATA fields

Table 1763. axil_mailbox_sep_wrap.inbound_mailbox_2.READ_DATA fields
Table 1764. axil_mailbox_sep_wrap.inbound_mailbox_2.STATUS fields
Table 1765. axil_mailbox_sep_wrap.inbound_mailbox_2.ERROR_FLAGS fields
Table 1766. axil_mailbox_sep_wrap.inbound_mailbox_2.WIRQT fields
Table 1767. axil_mailbox_sep_wrap.inbound_mailbox_2.RIRQT fields
Table 1768. axil_mailbox_sep_wrap.inbound_mailbox_2.IRQS fields
Table 1769. axil_mailbox_sep_wrap.inbound_mailbox_2.IRQEN fields
Table 1770. axil_mailbox_sep_wrap.inbound_mailbox_2.IRQP fields
Table 1771. axil_mailbox_sep_wrap.inbound_mailbox_2.CTRL fields
Table 1772. axil_mailbox_sep_wrap.outbound_mailbox_3.WRITE_DATA fields
Table 1773. axil_mailbox_sep_wrap.outbound_mailbox_3.READ_DATA fields
Table 1774. axil_mailbox_sep_wrap.outbound_mailbox_3.STATUS fields
Table 1775. axil_mailbox_sep_wrap.outbound_mailbox_3.ERROR_FLAGS fields
Table 1776. axil_mailbox_sep_wrap.outbound_mailbox_3.WIRQT fields
Table 1777. axil_mailbox_sep_wrap.outbound_mailbox_3.RIRQT fields
Table 1778. axil_mailbox_sep_wrap.outbound_mailbox_3.IRQS fields
Table 1779. axil_mailbox_sep_wrap.outbound_mailbox_3.IRQEN fields
Table 1780. axil_mailbox_sep_wrap.outbound_mailbox_3.IRQP fields
Table 1781. axil_mailbox_sep_wrap.outbound_mailbox_3.CTRL fields
Table 1782. axil_mailbox_sep_wrap.inbound_mailbox_3.WRITE_DATA fields
Table 1783. axil_mailbox_sep_wrap.inbound_mailbox_3.READ_DATA fields
Table 1784. axil_mailbox_sep_wrap.inbound_mailbox_3.STATUS fields
Table 1785. axil_mailbox_sep_wrap.inbound_mailbox_3.ERROR_FLAGS fields
Table 1786. axil_mailbox_sep_wrap.inbound_mailbox_3.WIRQT fields
Table 1787. axil_mailbox_sep_wrap.inbound_mailbox_3.RIRQT fields
Table 1788. axil_mailbox_sep_wrap.inbound_mailbox_3.IRQS fields
Table 1789. axil_mailbox_sep_wrap.inbound_mailbox_3.IRQEN fields
Table 1790. axil_mailbox_sep_wrap.inbound_mailbox_3.IRQP fields
Table 1791. axil_mailbox_sep_wrap.inbound_mailbox_3.CTRL fields
Table 1792. axil_mailbox_sep_wrap.outbound_mailbox_4.WRITE_DATA fields
Table 1793. axil_mailbox_sep_wrap.outbound_mailbox_4.READ_DATA fields
Table 1794. axil_mailbox_sep_wrap.outbound_mailbox_4.STATUS fields
Table 1795. axil_mailbox_sep_wrap.outbound_mailbox_4.ERROR_FLAGS fields
Table 1796. axil_mailbox_sep_wrap.outbound_mailbox_4.WIRQT fields
Table 1797. axil_mailbox_sep_wrap.outbound_mailbox_4.RIRQT fields
Table 1798. axil_mailbox_sep_wrap.outbound_mailbox_4.IRQS fields

Table 1799. axil_mailbox_sep_wrap.outbound_mailbox_4.IRQEN fields
Table 1800. axil_mailbox_sep_wrap.outbound_mailbox_4.IRQP fields
Table 1801. axil_mailbox_sep_wrap.outbound_mailbox_4.CTRL fields
Table 1802. axil_mailbox_sep_wrap.inbound_mailbox_4.WRITE_DATA fields
Table 1803. axil_mailbox_sep_wrap.inbound_mailbox_4.READ_DATA fields
Table 1804. axil_mailbox_sep_wrap.inbound_mailbox_4.STATUS fields
Table 1805. axil_mailbox_sep_wrap.inbound_mailbox_4.ERROR_FLAGS fields
Table 1806. axil_mailbox_sep_wrap.inbound_mailbox_4.WIRQT fields
Table 1807. axil_mailbox_sep_wrap.inbound_mailbox_4.RIRQT fields
Table 1808. axil_mailbox_sep_wrap.inbound_mailbox_4.IRQS fields
Table 1809. axil_mailbox_sep_wrap.inbound_mailbox_4.IRQEN fields
Table 1810. axil_mailbox_sep_wrap.inbound_mailbox_4.IRQP fields
Table 1811. axil_mailbox_sep_wrap.inbound_mailbox_4.CTRL fields
Table 1812. axil_mailbox_sep_wrap.outbound_mailbox_5.WRITE_DATA fields
Table 1813. axil_mailbox_sep_wrap.outbound_mailbox_5.READ_DATA fields
Table 1814. axil_mailbox_sep_wrap.outbound_mailbox_5.STATUS fields
Table 1815. axil_mailbox_sep_wrap.outbound_mailbox_5.ERROR_FLAGS fields
Table 1816. axil_mailbox_sep_wrap.outbound_mailbox_5.WIRQT fields
Table 1817. axil_mailbox_sep_wrap.outbound_mailbox_5.RIRQT fields
Table 1818. axil_mailbox_sep_wrap.outbound_mailbox_5.IRQS fields
Table 1819. axil_mailbox_sep_wrap.outbound_mailbox_5.IRQEN fields
Table 1820. axil_mailbox_sep_wrap.outbound_mailbox_5.IRQP fields
Table 1821. axil_mailbox_sep_wrap.outbound_mailbox_5.CTRL fields
Table 1822. axil_mailbox_sep_wrap.inbound_mailbox_5.WRITE_DATA fields
Table 1823. axil_mailbox_sep_wrap.inbound_mailbox_5.READ_DATA fields
Table 1824. axil_mailbox_sep_wrap.inbound_mailbox_5.STATUS fields
Table 1825. axil_mailbox_sep_wrap.inbound_mailbox_5.ERROR_FLAGS fields
Table 1826. axil_mailbox_sep_wrap.inbound_mailbox_5.WIRQT fields
Table 1827. axil_mailbox_sep_wrap.inbound_mailbox_5.RIRQT fields
Table 1828. axil_mailbox_sep_wrap.inbound_mailbox_5.IRQS fields
Table 1829. axil_mailbox_sep_wrap.inbound_mailbox_5.IRQEN fields
Table 1830. axil_mailbox_sep_wrap.inbound_mailbox_5.IRQP fields
Table 1831. axil_mailbox_sep_wrap.inbound_mailbox_5.CTRL fields
Table 1832. axil_mailbox_sep_wrap.outbound_mailbox_6.WRITE_DATA fields
Table 1833. axil_mailbox_sep_wrap.outbound_mailbox_6.READ_DATA fields
Table 1834. axil_mailbox_sep_wrap.outbound_mailbox_6.STATUS fields

Table 1835. axil_mailbox_sep_wrap.outbound_mailbox_6.ERROR_FLAGS fields
Table 1836. axil_mailbox_sep_wrap.outbound_mailbox_6.WIRQT fields
Table 1837. axil_mailbox_sep_wrap.outbound_mailbox_6.RIRQT fields
Table 1838. axil_mailbox_sep_wrap.outbound_mailbox_6.IRQS fields
Table 1839. axil_mailbox_sep_wrap.outbound_mailbox_6.IRQEN fields
Table 1840. axil_mailbox_sep_wrap.outbound_mailbox_6.IRQP fields
Table 1841. axil_mailbox_sep_wrap.outbound_mailbox_6.CTRL fields
Table 1842. axil_mailbox_sep_wrap.inbound_mailbox_6.WRITE_DATA fields
Table 1843. axil_mailbox_sep_wrap.inbound_mailbox_6.READ_DATA fields
Table 1844. axil_mailbox_sep_wrap.inbound_mailbox_6.STATUS fields
Table 1845. axil_mailbox_sep_wrap.inbound_mailbox_6.ERROR_FLAGS fields
Table 1846. axil_mailbox_sep_wrap.inbound_mailbox_6.WIRQT fields
Table 1847. axil_mailbox_sep_wrap.inbound_mailbox_6.RIRQT fields
Table 1848. axil_mailbox_sep_wrap.inbound_mailbox_6.IRQS fields
Table 1849. axil_mailbox_sep_wrap.inbound_mailbox_6.IRQEN fields
Table 1850. axil_mailbox_sep_wrap.inbound_mailbox_6.IRQP fields
Table 1851. axil_mailbox_sep_wrap.inbound_mailbox_6.CTRL fields
Table 1852. axil_mailbox_sep_wrap.outbound_mailbox_7.WRITE_DATA fields
Table 1853. axil_mailbox_sep_wrap.outbound_mailbox_7.READ_DATA fields
Table 1854. axil_mailbox_sep_wrap.outbound_mailbox_7.STATUS fields
Table 1855. axil_mailbox_sep_wrap.outbound_mailbox_7.ERROR_FLAGS fields
Table 1856. axil_mailbox_sep_wrap.outbound_mailbox_7.WIRQT fields
Table 1857. axil_mailbox_sep_wrap.outbound_mailbox_7.RIRQT fields
Table 1858. axil_mailbox_sep_wrap.outbound_mailbox_7.IRQS fields
Table 1859. axil_mailbox_sep_wrap.outbound_mailbox_7.IRQEN fields
Table 1860. axil_mailbox_sep_wrap.outbound_mailbox_7.IRQP fields
Table 1861. axil_mailbox_sep_wrap.outbound_mailbox_7.CTRL fields
Table 1862. axil_mailbox_sep_wrap.inbound_mailbox_7.WRITE_DATA fields
Table 1863. axil_mailbox_sep_wrap.inbound_mailbox_7.READ_DATA fields
Table 1864. axil_mailbox_sep_wrap.inbound_mailbox_7.STATUS fields
Table 1865. axil_mailbox_sep_wrap.inbound_mailbox_7.ERROR_FLAGS fields
Table 1866. axil_mailbox_sep_wrap.inbound_mailbox_7.WIRQT fields
Table 1867. axil_mailbox_sep_wrap.inbound_mailbox_7.RIRQT fields
Table 1868. axil_mailbox_sep_wrap.inbound_mailbox_7.IRQS fields
Table 1869. axil_mailbox_sep_wrap.inbound_mailbox_7.IRQEN fields
Table 1870. axil_mailbox_sep_wrap.inbound_mailbox_7.IRQP fields

Table 1871. axil_mailbox_sep_wrap.inbound_mailbox_7.CTRL fields
Table 1872. OCTS credit management
Table 1873. OCTS pulse states
Table 1874. OCTS register offsets and reset values
Table 1875. OCTS System Timer Address Map register list
Table 1876. system_timer_octs.TIMER_START fields
Table 1877. system_timer_octs.CTRL fields
Table 1878. system_timer_octs.STATUS fields
Table 1879. system_timer_octs.TIMER_PRESET_LO fields
Table 1880. system_timer_octs.TIMER_PRESET_HI fields
Table 1881. system_timer_octs.TIMER_COUNT_LO fields
Table 1882. system_timer_octs.TIMER_COUNT_HI fields
Table 1883. system_timer_octs.CREDIT_EXPIRED fields
Table 1884. system_timer_octs.TIMER_GPIO_ENABLE fields
Table 1885. eFuse destination endpoints
Table 1886. eFuse shadow-register features
Table 1887. eFuse command type macros
Table 1888. Example Hardware Interfaces by OTP Variant
Table 1889. eFuse lock-field encoding
Table 1890. eFuse hardware and software locks
Table 1891. eFuse security-disable behavior
Table 1892. eFuse lifecycle encodings
Table 1893. eFuse JTAG permissions (SMC)
Table 1894. eFuse secure-test behavior
Table 1895. SEP eFuse Placement
Table 1896. SMC eFuse Placement
Table 1897. Key Manager eFuse Pass-Through
Table 1898. Efuse address map of physical efuse macro register list
Table 1899. smc_efuse_map.LOCKS fields
Table 1900. smc_efuse_map.JTAG_PUBLIC_IDENTITY fields
Table 1901. smc_efuse_map.I2C_I3C_ID[9] fields
Table 1902. smc_efuse_map.SMC_CONFIG fields
Table 1903. smc_efuse_map.OCCP_TRANSPORT_TIMEOUT fields
Table 1904. smc_efuse_map.SPARE[28] fields
Table 1905. eFuse Token Registers Address Map register list
Table 1906. efuse_mmr.RMA_SIP_TOKEN_I[8] fields

Table 1907. efuse_mmr.RMA_CHIPLET_TOKEN_I[8] fields
Table 1908. efuse_mmr.SEC_DISABLE_TOKEN_I[8] fields
Table 1909. efuse_mmr.TOKEN_EOP fields
Table 1910. efuse_mmr.RMA_SIP_TOKEN_MATCH fields
Table 1911. efuse_mmr.RMA_CHIPLET_TOKEN_MATCH fields
Table 1912. efuse_mmr.SEC_DISABLE_TOKEN_MATCH fields
Table 1913. efuse_mmr.TOKEN_MATCH_FAULT fields
Table 1914. eFuse Interface Control Address Map register list
Table 1915. efuse_interface_ctrl.EFUSE_INTERFACE_CTRL_STATUS fields
Table 1916. efuse_interface_ctrl.EFUSE_PROGRAM_CTRL fields
Table 1917. efuse_interface_ctrl.EFUSE_READ_CTRL fields
Table 1918. efuse_interface_ctrl.EFUSE_PROGRAM_INTERFACE_READ_DATA fields
Table 1919. efuse_interface_ctrl.EFUSE_READ_INTERFACE_READ_DATA fields
Table 1920. efuse_interface_ctrl.EFUSE_READ_REQ_TIMEOUT fields
Table 1921. efuse_interface_ctrl.EFUSE_PROGRAM_REQ_TIMEOUT fields
Table 1922. eFuse SHIM Control Model Address Map register list
Table 1923. efuse_shim_ctrl.EFUSE_BANK_INIT_TIME fields
Table 1924. UART serial errors
Table 1925. UART interrupt priority and service
Table 1926. UART 16550 Main Address Map register list
Table 1927. uart_16550_main.RBR fields
Table 1928. uart_16550_main.IER fields
Table 1929. uart_16550_main.IIR fields
Table 1930. uart_16550_main.LCR fields
Table 1931. uart_16550_main.MCR fields
Table 1932. uart_16550_main.LSR fields
Table 1933. uart_16550_main.MSR fields
Table 1934. uart_16550_main.SCR fields
Table 1935. uart_16550_main.ECR fields
Table 1936. uart_16550_main.ITR fields
Table 1937. UART 16550 Main Write-Only Address Map register list
Table 1938. uart_16550_main_wo.THR fields
Table 1939. uart_16550_main_wo.FCR fields
Table 1940. UART 16550 Divisor Latch Address Map register list
Table 1941. uart_16550_dl.DLL fields
Table 1942. uart_16550_dl.DLM fields

Table 1943. Log-engine configuration
Table 1944. Log-engine register summary
Table 1945. Log Engine Address Map register list
Table 1946. log_engine.CTRL fields
Table 1947. log_engine.LOG_REGION_SIZE fields
Table 1948. log_engine.LOG_REGION_ADDR fields
Table 1949. log_engine.LOG_WRITE_ADDR fields
Table 1950. log_engine.INTR_STATUS fields
Table 1951. log_engine.INTR_ENABLE fields
Table 1952. log_engine.INTR_TEST fields
Table 1953. log_engine.LOG_CTRL[16] fields
Table 1954. I2C Address Map register list
Table 1955. i2c.INTR_STATE fields
Table 1956. i2c.INTR_ENABLE fields
Table 1957. i2c.INTR_TEST fields
Table 1958. i2c.SMBUS_CTRL fields
Table 1959. i2c.CTRL fields
Table 1960. i2c.STATUS fields
Table 1961. i2c.RDATA fields
Table 1962. i2c.FDATA fields
Table 1963. i2c.FIFO_CTRL fields
Table 1964. i2c.HOST_FIFO_CONFIG fields
Table 1965. i2c.TARGET_FIFO_CONFIG fields
Table 1966. i2c.HOST_FIFO_STATUS fields
Table 1967. i2c.TARGET_FIFO_STATUS fields
Table 1968. i2c.OVRD fields
Table 1969. i2c.VAL fields
Table 1970. i2c.TIMING0 fields
Table 1971. i2c.TIMING1 fields
Table 1972. i2c.TIMING2 fields
Table 1973. i2c.TIMING3 fields
Table 1974. i2c.TIMING4 fields
Table 1975. i2c.TIMEOUT_CTRL fields
Table 1976. i2c.TARGET_ID fields
Table 1977. i2c.ACQDATA fields
Table 1978. i2c.TXDATA fields

Table 1979. i2c.HOST_TIMEOUT_CTRL fields
Table 1980. i2c.TARGET_TIMEOUT_CTRL fields
Table 1981. i2c.TARGET_NACK_COUNT fields
Table 1982. i2c.TARGET_ACK_CTRL fields
Table 1983. i2c.ACQ_FIFO_NEXT_DATA fields
Table 1984. i2c.HOST_NACK_HANDLER_TIMEOUT fields
Table 1985. i2c.CONTROLLER_EVENTS fields
Table 1986. i2c.TARGET_EVENTS fields
Table 1987. i2c.SMBUS_STATUS fields
Table 1988. I2C Control Address Map register list
Table 1989. i2c_ctrl.I2C_CTRL[3] fields
Table 1990. I2C Wrapper Address Map register list
Table 1991. i2c_wrap.i2c[3].INTR_STATE fields
Table 1992. i2c_wrap.i2c[3].INTR_ENABLE fields
Table 1993. i2c_wrap.i2c[3].INTR_TEST fields
Table 1994. i2c_wrap.i2c[3].SMBUS_CTRL fields
Table 1995. i2c_wrap.i2c[3].CTRL fields
Table 1996. i2c_wrap.i2c[3].STATUS fields
Table 1997. i2c_wrap.i2c[3].RDATA fields
Table 1998. i2c_wrap.i2c[3].FDATA fields
Table 1999. i2c_wrap.i2c[3].FIFO_CTRL fields
Table 2000. i2c_wrap.i2c[3].HOST_FIFO_CONFIG fields
Table 2001. i2c_wrap.i2c[3].TARGET_FIFO_CONFIG fields
Table 2002. i2c_wrap.i2c[3].HOST_FIFO_STATUS fields
Table 2003. i2c_wrap.i2c[3].TARGET_FIFO_STATUS fields
Table 2004. i2c_wrap.i2c[3].OVRD fields
Table 2005. i2c_wrap.i2c[3].VAL fields
Table 2006. i2c_wrap.i2c[3].TIMING0 fields
Table 2007. i2c_wrap.i2c[3].TIMING1 fields
Table 2008. i2c_wrap.i2c[3].TIMING2 fields
Table 2009. i2c_wrap.i2c[3].TIMING3 fields
Table 2010. i2c_wrap.i2c[3].TIMING4 fields
Table 2011. i2c_wrap.i2c[3].TIMEOUT_CTRL fields
Table 2012. i2c_wrap.i2c[3].TARGET_ID fields
Table 2013. i2c_wrap.i2c[3].ACQDATA fields
Table 2014. i2c_wrap.i2c[3].TXDATA fields

Table 2015. i2c_wrap.i2c[3].HOST_TIMEOUT_CTRL fields

Table 2016. i2c_wrap.i2c[3].TARGET_TIMEOUT_CTRL fields

Table 2017. i2c_wrap.i2c[3].TARGET_NACK_COUNT fields

Table 2018. i2c_wrap.i2c[3].TARGET_ACK_CTRL fields

Table 2019. i2c_wrap.i2c[3].ACQ_FIFO_NEXT_DATA fields

Table 2020. i2c_wrap.i2c[3].HOST_NACK_HANDLER_TIMEOUT fields

Table 2021. i2c_wrap.i2c[3].CONTROLLER_EVENTS fields

Table 2022. i2c_wrap.i2c[3].TARGET_EVENTS fields

Table 2023. i2c_wrap.i2c[3].SMBUS_STATUS fields

Table 2024. i2c_wrap.I2C_CTRL[3] fields

Table 2025. OCA I3C Controller Wrapper Address Map register list

Table 2026. oca_i3c_wrap.i3c_csr[6].I3CBase.HCI_VERSION fields

Table 2027. oca_i3c_wrap.i3c_csr[6].I3CBase.HC_CONTROL fields

Table 2028. oca_i3c_wrap.i3c_csr[6].I3CBase.CONTROLLER_DEVICE_ADDR fields

Table 2029. oca_i3c_wrap.i3c_csr[6].I3CBase.HC_CAPABILITIES fields

Table 2030. oca_i3c_wrap.i3c_csr[6].I3CBase.RESET_CONTROL fields

Table 2031. oca_i3c_wrap.i3c_csr[6].I3CBase.PRESENT_STATE fields

Table 2032. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_STATUS fields

Table 2033. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_STATUS_ENABLE fields

Table 2034. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_SIGNAL_ENABLE fields

Table 2035. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_FORCE fields

Table 2036. oca_i3c_wrap.i3c_csr[6].I3CBase.DAT_SECTION_OFFSET fields

Table 2037. oca_i3c_wrap.i3c_csr[6].I3CBase.DCT_SECTION_OFFSET fields

Table 2038. oca_i3c_wrap.i3c_csr[6].I3CBase.RING_HEADERS_SECTION_OFFSET fields

Table 2039. oca_i3c_wrap.i3c_csr[6].I3CBase.PIO_SECTION_OFFSET fields

Table 2040. oca_i3c_wrap.i3c_csr[6].I3CBase.EXT_CAPS_SECTION_OFFSET fields

Table 2041. oca_i3c_wrap.i3c_csr[6].I3CBase.INT_CTRL_CMDS_EN fields

Table 2042. oca_i3c_wrap.i3c_csr[6].I3CBase.IBI_NOTIFY_CTRL fields

Table 2043. oca_i3c_wrap.i3c_csr[6].I3CBase.IBI_DATA_ABORT_CTRL fields

Table 2044. oca_i3c_wrap.i3c_csr[6].I3CBase.DEV_CTX_BASE_LO fields

Table 2045. oca_i3c_wrap.i3c_csr[6].I3CBase.DEV_CTX_BASE_HI fields

Table 2046. oca_i3c_wrap.i3c_csr[6].I3CBase.DEV_CTX_SG fields

Table 2047. oca_i3c_wrap.i3c_csr[6].PIOControl.COMMAND_PORT fields

Table 2048. oca_i3c_wrap.i3c_csr[6].PIOControl.RESPONSE_PORT fields

Table 2049. oca_i3c_wrap.i3c_csr[6].PIOControl.TX_DATA_PORT fields

Table 2050. oca_i3c_wrap.i3c_csr[6].PIOControl.RX_DATA_PORT fields

Table 2051. oca_i3c_wrap.i3c_csr[6].PIOControl.IBI_PORT fields
Table 2052. oca_i3c_wrap.i3c_csr[6].PIOControl.QUEUE_THLD_CTRL fields
Table 2053. oca_i3c_wrap.i3c_csr[6].PIOControl.DATA_BUFFER_THLD_CTRL fields
Table 2054. oca_i3c_wrap.i3c_csr[6].PIOControl.QUEUE_SIZE fields
Table 2055. oca_i3c_wrap.i3c_csr[6].PIOControl.ALT_QUEUE_SIZE fields
Table 2056. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_STATUS fields
Table 2057. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_STATUS_ENABLE fields
Table 2058. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_SIGNAL_ENABLE fields
Table 2059. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_FORCE fields
Table 2060. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_CONTROL fields
Table 2061. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.EXTCAP_HEADER fields
Table 2062. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_0 fields
Table 2063. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_1 fields
Table 2064. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_2 fields
Table 2065. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_3 fields
Table 2066. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_0 fields
Table 2067. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_1 fields
Table 2068. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_2 fields
Table 2069. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_3 fields
Table 2070. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_4 fields
Table 2071. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_5 fields
Table 2072. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_RESERVED fields
Table 2073. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_0 fields
Table 2074. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_1 fields
Table 2075. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_RESET fields
Table 2076. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_CTRL fields
Table 2077. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_STATUS fields
Table 2078. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.HW_STATUS fields
Table 2079. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_0 fields
Table 2080. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_1 fields
Table 2081. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_0 fields
Table 2082. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_1 fields
Table 2083. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_2 fields
Table 2084. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_3 fields
Table 2085. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_4 fields
Table 2086. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_RESERVED fields

Table 2087. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_DATA fields
Table 2088. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.EXTCAP_HEADER fields
Table 2089. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL fields
Table 2090. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_ADDR fields
Table 2091. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES fields
Table 2092. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_CHAR fields
Table 2093. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_STATUS fields
Table 2094. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_CHAR fields
Table 2095. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_PID_LO fields
Table 2096. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_STATUS fields
Table 2097. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_PID_LO fields
Table 2098. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_SIGNAL_ENABLE fields
Table 2099. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_FORCE fields
Table 2100. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_GETCAPS fields
Table 2101. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS fields
Table 2102. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRT_DEVICE_ADDR fields
Table 2103. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MWL fields
Table 2104. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MRL fields
Table 2105. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.EXTCAP_HEADER fields
Table 2106. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.CONTROL fields
Table 2107. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.STATUS fields
Table 2108. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.RESET_CONTROL fields
Table 2109. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.QUEUE_STATUS fields
Table 2110. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.DESC_QUEUE_DEPTH fields
Table 2111. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.DATA_QUEUE_DEPTH fields
Table 2112. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_DEPTH fields
Table 2113. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.INTERRUPT_STATUS fields
Table 2114. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.INTERRUPT_ENABLE fields
Table 2115. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.INTERRUPT_FORCE fields
Table 2116. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CTRL fields
Table 2117. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_STATUS fields
Table 2118. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_ENABLE fields
Table 2119. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_FORCE fields
Table 2120. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE0 fields
Table 2121. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE1 fields
Table 2122. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE2 fields

Table 2123. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE3 fields
Table 2124. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE4 fields
Table 2125. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE5 fields
Table 2126. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_FRAMING fields
Table 2127. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_PEC fields
Table 2128. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_LENGTH fields
Table 2129. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_READONLY fields
Table 2130. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_UNSUPPORTED fields
Table 2131. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW fields
Table 2132. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW fields
Table 2133. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.RX_DESC_QUEUE_PORT fields
Table 2134. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.RX_DATA_PORT fields
Table 2135. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TX_DESC_QUEUE_PORT fields
Table 2136. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TX_DATA_PORT fields
Table 2137. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.IBI_PORT fields
Table 2138. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.QUEUE_SIZE fields
Table 2139. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_SIZE fields
Table 2140. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.QUEUE_THLD_CTRL fields
Table 2141. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.DATA_BUFFER_THLD_CTRL fields
Table 2142. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.EXTCAP_HEADER fields
Table 2143. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_CONTROL fields
Table 2144. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_STATUS fields
Table 2145. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_CFG fields
Table 2146. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_REG_W1C_ACCESS fields
Table 2147. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_2 fields
Table 2148. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_3 fields
Table 2149. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_CONF fields
Table 2150. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_ATTR fields
Table 2151. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_2 fields
Table 2152. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_3 fields
Table 2153. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_R_REG fields
Table 2154. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_F_REG fields
Table 2155. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_REG fields
Table 2156. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_I2C_REG fields
Table 2157. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_DAT_REG fields
Table 2158. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_REG fields

Table 2159. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_OD_REG fields
Table 2160. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_INIT_OD_REG fields
Table 2161. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_I2C_REG fields
Table 2162. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_REG fields
Table 2163. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_OD_REG fields
Table 2164. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_I2C_REG fields
Table 2165. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_REG fields
Table 2166. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_I2C_REG fields
Table 2167. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_RSTA_REG fields
Table 2168. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_REG fields
Table 2169. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_I2C_REG fields
Table 2170. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_REG fields
Table 2171. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_I2C_REG fields
Table 2172. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_DS_OD_REG fields
Table 2173. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_REG fields
Table 2174. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_I2C_REG fields
Table 2175. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_AVAL_REG fields
Table 2176. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_IDLE_REG fields
Table 2177. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.HDR_TIMEOUT_EN_REG fields
Table 2178. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HDR_TIMEOUT_REG fields
Table 2179. oca_i3c_wrap.i3c_csr[6].I3C_EC.CtrlCfg.EXTCAP_HEADER fields
Table 2180. oca_i3c_wrap.i3c_csr[6].I3C_EC.CtrlCfg.CONTROLLER_CONFIG fields
Table 2181. oca_i3c_wrap.i3c_csr[6].I3C_EC.TERMINATION_EXTCAP_HEADER fields
Table 2182. oca_i3c_wrap.i3c_csr[6].DAT.DAT_MEMORY[128] fields
Table 2183. oca_i3c_wrap.i3c_csr[6].DCT.DCT_MEMORY[128] fields
Table 2184. AVSBus clock sources
Table 2185. AVSBus command and readback FIFOs
Table 2186. AVSBus protocol state encodings
Table 2187. AVSBus error handling
Table 2188. AVSBus Master Subframe
Table 2189. AVSBus Command Codes (Command Group 0)
Table 2190. AVSBus Slave Subframe
Table 2191. AVS_CLOCK_SELECT settings
Table 2192. AVS Clock Configuration Fields
Table 2193. AVSBus Reset Domains
Table 2194. AVSBus Interrupt Sources

Table 2195. AVSBus Protocol Timing
Table 2196. AVSBus Controller Address Map register list
Table 2197. avsbus_controller.AVS_CMD fields
Table 2198. avsbus_controller.AVS_READBACK fields
Table 2199. avsbus_controller.AVS_DEBUG_READBACK fields
Table 2200. avsbus_controller.AVS_LATEST_SLAVE_SUBFRAME fields
Table 2201. avsbus_controller.AVS_NORMAL_STATUS fields
Table 2202. avsbus_controller.AVS_SLAVE_STATUS fields
Table 2203. avsbus_controller.AVS_FIFOS_STATUS fields
Table 2204. avsbus_controller.AVS_INTERRUPT fields
Table 2205. avsbus_controller.AVS_INTERRUPT_MASK fields
Table 2206. avsbus_controller.AVS_INTERRUPT_CLEAR fields
Table 2207. avsbus_controller.AVS_CFG_0 fields
Table 2208. avsbus_controller.AVS_CFG_1 fields
Table 2209. avsbus_controller.AVS_CONFIG fields
Table 2210. GPIO data and direction selection
Table 2211. GPIO interrupt modes
Table 2212. GPIO Interface Address Map register list
Table 2213. gpio_intf.DATA_CTRL fields
Table 2214. gpio_intf.DATA_CTRL_ENABLE fields
Table 2215. gpio_intf.ACCESS_FILTER fields
Table 2216. GPIO Control Address Map register list
Table 2217. gpio_ctrl.CONTROL fields
Table 2218. GPIO Wrapper Address Map register list
Table 2219. gpio_wrap.DATA_CTRL fields
Table 2220. gpio_wrap.DATA_CTRL_ENABLE fields
Table 2221. gpio_wrap.ACCESS_FILTER fields
Table 2222. gpio_wrap.CONTROL fields
Table 2223. Telemetry packet fields
Table 2224. Telemetry interrupt conditions
Table 2225. Telemetry Receiver Address Map register list
Table 2226. telemetry_receiver.CTRL fields
Table 2227. telemetry_receiver.STATUS fields
Table 2228. telemetry_receiver.INTR_STATUS fields
Table 2229. telemetry_receiver.INTR_ENABLE fields
Table 2230. telemetry_receiver.INTR_TEST fields

Table 2231. telemetry_receiver.TELEMETRY_PROBE_ID fields

Table 2232. telemetry_receiver.TELEMETRY_COUNTER_VLDS fields

Table 2233. telemetry_receiver.TELEMETRY_COUNTER[32] fields

Table 2234. Telemetry Receiver Wrapper Address Map register list

Table 2235. telemetry_receiver_wrap.telemetry_receiver[3].CTRL fields

Table 2236. telemetry_receiver_wrap.telemetry_receiver[3].STATUS fields

Table 2237. telemetry_receiver_wrap.telemetry_receiver[3].INTR_STATUS fields

Table 2238. telemetry_receiver_wrap.telemetry_receiver[3].INTR_ENABLE fields

Table 2239. telemetry_receiver_wrap.telemetry_receiver[3].INTR_TEST fields

Table 2240. telemetry_receiver_wrap.telemetry_receiver[3].TELEMETRY_PROBE_ID fields

Table 2241. telemetry_receiver_wrap.telemetry_receiver[3].TELEMETRY_COUNTER_VLDS fields

Table 2242. telemetry_receiver_wrap.telemetry_receiver[3].TELEMETRY_COUNTER[32] fields

Table 2243. UART Wrapper Address Map register list

Table 2244. uart_wrap.uart_log_engine_wrap[4].uart_log_engine_ctrl.CTRL fields

Table 2245. uart_wrap.uart_log_engine_wrap[4].uart.RBR fields

Table 2246. uart_wrap.uart_log_engine_wrap[4].uart.IER fields

Table 2247. uart_wrap.uart_log_engine_wrap[4].uart.IIR fields

Table 2248. uart_wrap.uart_log_engine_wrap[4].uart.LCR fields

Table 2249. uart_wrap.uart_log_engine_wrap[4].uart.MCR fields

Table 2250. uart_wrap.uart_log_engine_wrap[4].uart.LSR fields

Table 2251. uart_wrap.uart_log_engine_wrap[4].uart.MSR fields

Table 2252. uart_wrap.uart_log_engine_wrap[4].uart.SCR fields

Table 2253. uart_wrap.uart_log_engine_wrap[4].uart.ECR fields

Table 2254. uart_wrap.uart_log_engine_wrap[4].uart.ITR fields

Table 2255. uart_wrap.uart_log_engine_wrap[4].log_engine.CTRL fields

Table 2256. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_REGION_SIZE fields

Table 2257. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_REGION_ADDR fields

Table 2258. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_WRITE_ADDR fields

Table 2259. uart_wrap.uart_log_engine_wrap[4].log_engine.INTR_STATUS fields

Table 2260. uart_wrap.uart_log_engine_wrap[4].log_engine.INTR_ENABLE fields

Table 2261. uart_wrap.uart_log_engine_wrap[4].log_engine.INTR_TEST fields

Table 2262. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_CTRL[16] fields

Table 2263. UART Log Engine Control Address Map register list

Table 2264. uart_log_engine_ctrl.CTRL fields

Table 2265. UART Log Engine Wrapper Address Map register list

Table 2266. uart_log_engine_wrap.uart_log_engine_ctrl.CTRL fields

Table 2267. uart_log_engine_wrap.RBR fields
Table 2268. uart_log_engine_wrap.IER fields
Table 2269. uart_log_engine_wrap.IIR fields
Table 2270. uart_log_engine_wrap.LCR fields
Table 2271. uart_log_engine_wrap.MCR fields
Table 2272. uart_log_engine_wrap.LSR fields
Table 2273. uart_log_engine_wrap.MSR fields
Table 2274. uart_log_engine_wrap.SCR fields
Table 2275. uart_log_engine_wrap.ECR fields
Table 2276. uart_log_engine_wrap.ITR fields
Table 2277. uart_log_engine_wrap.log_engine.CTRL fields
Table 2278. uart_log_engine_wrap.LOG_REGION_SIZE fields
Table 2279. uart_log_engine_wrap.LOG_REGION_ADDR fields
Table 2280. uart_log_engine_wrap.LOG_WRITE_ADDR fields
Table 2281. uart_log_engine_wrap.INTR_STATUS fields
Table 2282. uart_log_engine_wrap.INTR_ENABLE fields
Table 2283. uart_log_engine_wrap.INTR_TEST fields
Table 2284. uart_log_engine_wrap.LOG_CTRL[16] fields
Table 2285. SMC Peripheral Parameter Overrides
Table 2286. SMC CLA event types
Table 2287. SMC DFD MMR Aperture Address Map register list
Table 2288. smc_cla.Trdstramcontrol fields
Table 2289. smc_cla.Trdstramimpl fields
Table 2290. smc_cla.Trdstramstartlow fields
Table 2291. smc_cla.Trdstramstarthigh fields
Table 2292. smc_cla.Trdstramlimitlow fields
Table 2293. smc_cla.Trdstramlimithigh fields
Table 2294. smc_cla.Trdstramwplow fields
Table 2295. smc_cla.Trdstramwphigh fields
Table 2296. smc_cla.Trdstramrplow fields
Table 2297. smc_cla.Trdstramrphigh fields
Table 2298. smc_cla.Trdstramdata fields
Table 2299. smc_cla.dst_sink.ScratchLo fields
Table 2300. smc_cla.dst_sink.ScratchHi fields
Table 2301. smc_cla.Trfunnelcontrol fields
Table 2302. smc_cla.Trfunnelimpl fields

Table 2303. smc_cla.Trfunneldisinput fields

Table 2304. smc_cla.funnel.ScratchLo fields

Table 2305. smc_cla.funnel.ScratchHi fields

Table 2306. smc_cla.CDbgClaCounter0Cfg fields

Table 2307. smc_cla.CDbgClaCounter1Cfg fields

Table 2308. smc_cla.CDbgClaCounter2Cfg fields

Table 2309. smc_cla.CDbgClaCounter3Cfg fields

Table 2310. smc_cla.CDbgNode0Eap0 fields

Table 2311. smc_cla.CDbgNode0Eap1 fields

Table 2312. smc_cla.CDbgNode1Eap0 fields

Table 2313. smc_cla.CDbgNode1Eap1 fields

Table 2314. smc_cla.CDbgNode2Eap0 fields

Table 2315. smc_cla.CDbgNode2Eap1 fields

Table 2316. smc_cla.CDbgNode3Eap0 fields

Table 2317. smc_cla.CDbgNode3Eap1 fields

Table 2318. smc_cla.CDbgSignalMask0Lo fields

Table 2319. smc_cla.CDbgSignalMatch0Lo fields

Table 2320. smc_cla.CDbgSignalMask1Lo fields

Table 2321. smc_cla.CDbgSignalMatch1Lo fields

Table 2322. smc_cla.CDbgSignalEdgeDetectCfg fields

Table 2323. smc_cla.CDbgEapStatus fields

Table 2324. smc_cla.CDbgClaCtrlStatus fields

Table 2325. smc_cla.CDbgMuxSelLo fields

Table 2326. smc_cla.CDbgRsvd1 fields

Table 2327. smc_cla.CDbgRsvd2 fields

Table 2328. smc_cla.CDbgTransitionMaskLo fields

Table 2329. smc_cla.CDbgTransitionFromValueLo fields

Table 2330. smc_cla.CDbgTransitionToValueLo fields

Table 2331. smc_cla.CDbgOnesCountMaskLo fields

Table 2332. smc_cla.CDbgOnesCountValue fields

Table 2333. smc_cla.CDbgAnyChangeLo fields

Table 2334. smc_cla.CDbgSignalSnapshotNode0Eap0Lo fields

Table 2335. smc_cla.CDbgSignalSnapshotNode0Eap1Lo fields

Table 2336. smc_cla.CDbgSignalSnapshotNode1Eap0Lo fields

Table 2337. smc_cla.CDbgSignalSnapshotNode1Eap1Lo fields

Table 2338. smc_cla.CDbgSignalSnapshotNode2Eap0Lo fields

Table 2339. smc_cla.CDbgSignalSnapshotNode2Eap1Lo fields
Table 2340. smc_cla.CDbgSignalSnapshotNode3Eap0Lo fields
Table 2341. smc_cla.CDbgSignalSnapshotNode3Eap1Lo fields
Table 2342. smc_cla.CDbgClaTimeMatch fields
Table 2343. smc_cla.CDbgSignalMask2Lo fields
Table 2344. smc_cla.CDbgSignalMatch2Lo fields
Table 2345. smc_cla.CDbgSignalMask3Lo fields
Table 2346. smc_cla.CDbgSignalMatch3Lo fields
Table 2347. smc_cla.CDbgNode0Eap2 fields
Table 2348. smc_cla.CDbgNode0Eap3 fields
Table 2349. smc_cla.CDbgNode1Eap2 fields
Table 2350. smc_cla.CDbgNode1Eap3 fields
Table 2351. smc_cla.CDbgNode2Eap2 fields
Table 2352. smc_cla.CDbgNode2Eap3 fields
Table 2353. smc_cla.CDbgNode3Eap2 fields
Table 2354. smc_cla.CDbgNode3Eap3 fields
Table 2355. smc_cla.CDbgSignalSnapshotNode0Eap2Lo fields
Table 2356. smc_cla.CDbgSignalSnapshotNode0Eap3Lo fields
Table 2357. smc_cla.CDbgSignalSnapshotNode1Eap2Lo fields
Table 2358. smc_cla.CDbgSignalSnapshotNode1Eap3Lo fields
Table 2359. smc_cla.CDbgSignalSnapshotNode2Eap2Lo fields
Table 2360. smc_cla.CDbgSignalSnapshotNode2Eap3Lo fields
Table 2361. smc_cla.CDbgSignalSnapshotNode3Eap2Lo fields
Table 2362. smc_cla.CDbgSignalSnapshotNode3Eap3Lo fields
Table 2363. smc_cla.CDbgSignalDelayMuxSel fields
Table 2364. smc_cla.CDbgClaXtriggerTimestretch fields
Table 2365. smc_cla.CDbgClaTimestamp fields
Table 2366. smc_cla.CDbgClaTimestampSync fields
Table 2367. smc_cla.CDbgClaTimestampConfig fields
Table 2368. smc_cla.CDbgClaTimestampOffset fields
Table 2369. smc_cla.CDbgSignalMask0Hi fields
Table 2370. smc_cla.CDbgSignalMatch0Hi fields
Table 2371. smc_cla.CDbgSignalMask1Hi fields
Table 2372. smc_cla.CDbgSignalMatch1Hi fields
Table 2373. smc_cla.CDbgSignalMask2Hi fields
Table 2374. smc_cla.CDbgSignalMatch2Hi fields

Table 2375. smc_cla.CDbgSignalMask3Hi fields
Table 2376. smc_cla.CDbgSignalMatch3Hi fields
Table 2377. smc_cla.CDbgMuxSelHi fields
Table 2378. smc_cla.CDbgTransitionMaskHi fields
Table 2379. smc_cla.CDbgTransitionFromValueHi fields
Table 2380. smc_cla.CDbgTransitionToValueHi fields
Table 2381. smc_cla.CDbgOnesCountMaskHi fields
Table 2382. smc_cla.CDbgAnyChangeHi fields
Table 2383. smc_cla.CDbgSignalSnapshotNode0Eap0Hi fields
Table 2384. smc_cla.CDbgSignalSnapshotNode0Eap1Hi fields
Table 2385. smc_cla.CDbgSignalSnapshotNode1Eap0Hi fields
Table 2386. smc_cla.CDbgSignalSnapshotNode1Eap1Hi fields
Table 2387. smc_cla.CDbgSignalSnapshotNode2Eap0Hi fields
Table 2388. smc_cla.CDbgSignalSnapshotNode2Eap1Hi fields
Table 2389. smc_cla.CDbgSignalSnapshotNode3Eap0Hi fields
Table 2390. smc_cla.CDbgSignalSnapshotNode3Eap1Hi fields
Table 2391. smc_cla.CDbgSignalSnapshotNode0Eap2Hi fields
Table 2392. smc_cla.CDbgSignalSnapshotNode0Eap3Hi fields
Table 2393. smc_cla.CDbgSignalSnapshotNode1Eap2Hi fields
Table 2394. smc_cla.CDbgSignalSnapshotNode1Eap3Hi fields
Table 2395. smc_cla.CDbgSignalSnapshotNode2Eap2Hi fields
Table 2396. smc_cla.CDbgSignalSnapshotNode2Eap3Hi fields
Table 2397. smc_cla.CDbgSignalSnapshotNode3Eap2Hi fields
Table 2398. smc_cla.CDbgSignalSnapshotNode3Eap3Hi fields
Table 2399. smc_cla.CDbgLfsr fields
Table 2400. smc_cla.CDbgLfsrMask fields
Table 2401. smc_cla.CDbgTimestampCapture fields
Table 2402. smc_cla.CDbgCompare0Lo fields
Table 2403. smc_cla.CDbgCompare0MaskLo fields
Table 2404. smc_cla.CDbgCompare1Lo fields
Table 2405. smc_cla.CDbgCompare1MaskLo fields
Table 2406. smc_cla.CDbgCompare2Lo fields
Table 2407. smc_cla.CDbgCompare2MaskLo fields
Table 2408. smc_cla.CDbgCompare3Lo fields
Table 2409. smc_cla.CDbgCompare3MaskLo fields
Table 2410. smc_cla.CDbgCompare0Hi fields

Table 2411. smc_cla.CDbgCompare0MaskHi fields
Table 2412. smc_cla.CDbgCompare1Hi fields
Table 2413. smc_cla.CDbgCompare1MaskHi fields
Table 2414. smc_cla.CDbgCompare2Hi fields
Table 2415. smc_cla.CDbgCompare2MaskHi fields
Table 2416. smc_cla.CDbgCompare3Hi fields
Table 2417. smc_cla.CDbgCompare3MaskHi fields
Table 2418. smc_cla.Scratch fields
Table 2419. smc_cla.Trdstcontrol fields
Table 2420. smc_cla.Trdstimpl fields
Table 2421. smc_cla.Trdstinstfeatures fields
Table 2422. smc_cla.CDbgDebugTraceCfg fields
Table 2423. smc_cla.dst.ScratchLo fields
Table 2424. smc_cla.dst.ScratchHi fields
Table 2425. SMC eFuse shadow register classification
Table 2426. SMC shadow word allocation
Table 2427. SMC Functional Address-Space Organization
Table 2428. SMC Component Address Map
Table 2429. SMC Register Interface Standards
Table 2430. SMC Access Control Mechanisms
Table 2431. PLL Wrapper Placeholder Address Map register list
Table 2432. pll_wrap.mem_array[954] fields
Table 2433. PVT Wrapper Placeholder Address Map register list
Table 2434. pvt_wrap.mem_array[594] fields
Table 2435. Straps Address Map register list
Table 2436. straps.STRAPS_LO fields
Table 2437. straps.STRAPS_HI fields
Table 2438. Chip Configuration Address Map register list
Table 2439. chip_config.VERSION_LO fields
Table 2440. chip_config.VERSION_HI fields
Table 2441. chip_config.CHIP_ID fields
Table 2442. chip_config.LC_STATE fields
Table 2443. Scratch Address Map register list
Table 2444. scratch.SCRATCH[8] fields
Table 2445. NDM Reset Control Address Map register list
Table 2446. ndm_reset.NDMRESET_REQUEST fields

Table 2447. ndm_reset.NDMRESET_PROCESS fields
Table 2448. ndm_reset.NDMRESET_CLUSTER_COUNT fields
Table 2449. SMC Miscellaneous Wrapper Address Map register list
Table 2450. misc_wrap.scratch_cold.SCRATCH[8] fields
Table 2451. misc_wrap.scratch_cold_warm.SCRATCH[8] fields
Table 2452. misc_wrap.VERSION_LO fields
Table 2453. misc_wrap.VERSION_HI fields
Table 2454. misc_wrap.CHIP_ID fields
Table 2455. misc_wrap.LC_STATE fields
Table 2456. misc_wrap.NDMRESET_REQUEST fields
Table 2457. misc_wrap.NDMRESET_PROCESS fields
Table 2458. misc_wrap.NDMRESET_CLUSTER_COUNT fields
Table 2459. SMC Base Configuration Address Map register list
Table 2460. smc_base_config.GLOBAL_BASE fields
Table 2461. smc_base_config.LOCAL_BASE fields
Table 2462. smc_base_config.REGION_SIZE fields
Table 2463. smc_base_config.CLOCK_GATE_CONTROL fields
Table 2464. smc_base_config.HANG_DET_SYS_AXI_CTRL fields
Table 2465. smc_base_config.HANG_DET_SYS_AXI_TIMEOUT_THRESHOLD fields
Table 2466. smc_base_config.HANG_DET_SEP_AXI_CTRL fields
Table 2467. smc_base_config.HANG_DET_SEP_AXI_TIMEOUT_THRESHOLD fields
Table 2468. smc_base_config.HANG_DET_DATA_ACCEL_CTRL fields
Table 2469. smc_base_config.HANG_DET_DATA_ACCEL_TIMEOUT_THRESHOLD fields
Table 2470. DFX Control and Status Address Map register list
Table 2471. dfx_ctrl_status.STATUS_SMU fields
Table 2472. dfx_ctrl_status.DEBUG_CTRL fields
Table 2473. dfx_ctrl_status.DEBUG_BUS_MUX fields
Table 2474. SMC Component Documentation
Table 2475. DTP clock domains
Table 2476. DTP reset signals
Table 2477. DTP JTAG2AXI bridges
Table 2478. DTP debug-disable paths
Table 2479. JIU STAP chain hierarchy
Table 2480. JIU debug-disable fields
Table 2481. JIU iJTAG DR with every SIB closed
Table 2482. JIU instruction encodings

Table 2483. PTAP module hierarchy
Table 2484. PTAP state encodings
Table 2485. PTAP reset hierarchy
Table 2486. PTAP IDCODE fields
Table 2487. PTAP DEBUG_CONTROL fields
Table 2488. PTAP JTAG_CAPS fields
Table 2489. PTAP TMP_STATUS fields
Table 2490. PTAP 3DCR fields
Table 2491. PTAP IC_RESET fields
Table 2492. PTAP JTAG2AXI capability fields
Table 2493. JTAG2AXI single-operation fields
Table 2494. JTAG2AXI series-control fields
Table 2495. JTAG2AXI incrementing data fields
Table 2496. JTAG2AXI non-incrementing data fields
Table 2497. JTAG2AXI data and error-status fields
Table 2498. PTAP debug-disable inputs
Table 2499. PTAP instruction encodings
Table 2500. STAP module hierarchy
Table 2501. STAP 3DCR fields
Table 2502. DTP STAP allocation
Table 2503. STAP debug-disable behavior
Table 2504. CTN address allocation
Table 2505. External and internal CTP comparison
Table 2506. Internal CTP wire-OR connections
Table 2507. Internal CTP point-to-point connections
Table 2508. CTN matrix port indices
Table 2509. Cross Trigger Network Address Map
Table 2510. Cross Trigger Matrix Address Map register list
Table 2511. cross_trigger_matrix.CT_SRC[26].CONFIG_0 fields
Table 2512. Cross Trigger Port Address Map register list
Table 2513. cross_trigger_port.CONFIG fields
Table 2514. cross_trigger_port.STATUS fields
Table 2515. cross_trigger_port.STRETCH_MULT fields
Table 2516. Cross Trigger Network Address Map register list
Table 2517. cross_trigger_network.CT_SRC[26].CONFIG_0 fields
Table 2518. cross_trigger_network.ctp[16].CONFIG fields

Table 2519. cross_trigger_network.ctp[16].STATUS fields

Table 2520. cross_trigger_network.ctp[16].STRETCH_MULT fields

Table 2521. CTP configuration registers

Table 2522. CTP submodules

Table 2523. CTP signal synchronization

Table 2524. CTP sender state transitions

Table 2525. CTP receiver state transitions

Table 2526. CTM configuration constants

Table 2527. CTM routing stages

Table 2528. CTM port indices

Table 2529. DTP Port Declaration

Table 2530. AoU width-adaptation paths

Table 2531. AoU burst-splitting limits

Table 2532. AoU burst-splitter SFR controls

Table 2533. AoU early-response tracking fields

Table 2534. AoU early-response SFR fields

Table 2535. AoU aggregation SFR fields

Table 2536. WriteData Credit Calculation

Table 2537. WriteDataFull Credit Calculation

Table 2538. ReadData Credit Calculation

Table 2539. AoU flit-cancel cases

Table 2540. Interrupt Sources

Table 2541. AOU_CORE Initial Latency (Cycles)

Table 2542. AOU_CORE Data Transfer Efficiency

Table 2543. AOU_CORE Area (measured at an FDI_CFG_SP_64B-equivalent configuration; numbers will scale up for FDI_CFG_*_128B configurations due to the 88 -> 140 R/W FIFO depth bump.)

Table 2544. Referenced Documents

Table 2545. Traffic filter instances

Table 2546. Granule widening examples

Table 2547. Register field access tokens

Table 2548. OCAH documentation references

Table 2549. OCA specification references

Table 2550. Interface and security standard references

Table 2551. External design documentation references

Chapter 1. OCAH Architecture & Design

This section provides an overview of the OCAH architecture including its subsystem composition, power and clock domains, reset hierarchy, and memory map. It is organised into focused topic pages; subsequent chapters provide detailed microarchitectural documentation for each subsystem.

1.1. Platform Overview

1.1.1. OCAH High-Level Features

- **Security Processor (SEP)** — Root of Trust (RoT) with the highest security privilege. Provides a physically isolated RISC-V execution environment for secure boot, lifecycle control, device attestation, and hardware-accelerated cryptography (OTBN PKA, AES, HMAC-SHA2, KMAC-SHA3, TRNG, DRBG, Key Manager). A security hierarchy across chiplets enables SiP-wide security management. The inclusion of the SEP is an elaboration option, controlled by the SMU's `CFG.SEP` field. The system integrator selects which chiplets include an SEP as part of the SiP security architecture.
- **System Management Controller (SMC)** — Firmware-driven orchestration engine responsible for clock, voltage, and reset management, platform bootstrapping, system initialisation, and power/thermal management. Built around a RISC-V micro-controller with hardware accelerators (DMA, memory zeroer) where firmware alone cannot meet timing requirements. Inter-chiplet management hierarchy via I2C/I3C and OCMI channels.
- **Debug & Test Ports (DTP)** — Standardised debug and test access across heterogeneous, multi-vendor chiplet systems. Layered architecture separating physical transport from logical access, with cross-chiplet event triggering, synchronised clock control for trace, and coordinated resets.
- **System Management Unit (SMU)** — The composite module combining SEP, SMC, and DTP into a single instantiable subsystem.
- **System Management Network (SMN)** — Internal communication fabric (point-to-point or packetised) providing the management backbone for configuration, status reporting, and firmware-driven coordination between SMU, user logic, and D2D interfaces.
- **AXI-over-UCIe Bridge (AoU)** — Protocol bridge between the AXI-based internal fabric and the UCIe die-to-die physical interface, enabling inter-chiplet system management traffic and application-level transaction forwarding.
- **Application-Specific Logic** — OCAH treats the application layer as a black box: the harness services are agnostic to whether the application is a CPU complex, NoC, DSA, memory controller, or high-speed IO. The application logic is outside the scope of OCAH.
- **Safety Monitor (SMO)** — External entity that collects error signals and diagnostic logging from OCAH subsystems to implement fault reaction policies. The SMO is outside the scope of OCAH; its interface requirements are specified separately as part of OCAH's functional safety documentation.

1.1.2. Top Block Diagram

Figure 1 presents the OCAH top-level block diagram showing the relationship between the subsystems described above.




Figure 1. OCAH Top-Level Block Diagram

The SMU crossbar permits each initiator to reach the other two targets; self-directed paths are not connected. The detailed connectivity is shown in SMU AXI Crossbar.

Hatched blocks are future: the SMN, the safety bus and the safety monitor. The crossbar ports that would connect the safety monitor are proposed and are not part of the implemented crossbar. Dashed outlines without hatching mark the blocks present only when the SMU `CFG.SEP` field is 1: the SEP and the SMU crossbar.

1.2. OCAH Memory Map

OCAH separates the chiplet-visible SMU aperture from the internal address maps used by SEP and SMC firmware. The chiplet integrator decides which system address range reaches the SMU external AXI input. Firmware then programs the SEP and SMC global base/size CSRs so the SMU crossbar can route incoming traffic to the correct inbound port.

Table 1 distinguishes the chiplet envelope, programmable apertures, and internal address maps.

Table 1. OCAH address-map configuration layers

Concept	Configured by	Purpose	Example
Chiplet NoC envelope	Integrator / chiplet address map	Controls which external-master addresses reach SMU `ext_in`	Example only: 64 MiB total SMU aperture
SEP global aperture	SEP firmware via `SEP_GLOBAL_BASE_ADDR` / `SEP_REGION_SIZE`	Controls SMU `ext_in` to `sep_in` routing and SEP inbound global-to-local remap	Example only: 32 MiB SEP slot in a 32 MiB + 32 MiB SEP/SMC partition
SMC global aperture	SMC firmware via `GLOBAL_BASE` / `REGION_SIZE`	Controls SMU `ext_in` to `smc_in` routing and SEP-to-SMC decode	Example only: 32 MiB SMC slot in a 32 MiB + 32 MiB SEP/SMC partition

External masters use chiplet-global addresses and are bounded first by the chiplet NoC decode. The SMU crossbar applies the firmware-programmed SEP and SMC global apertures to route those transactions to `sep_in` or `smc_in`. Subsystem-internal CPU maps and local aliases are described in the SEP and SMC chapters.

At reset, `SEP_GLOBAL_BASE_ADDR` is `0x0000_0000` and the SMC's `GLOBAL_BASE` register is `0x4000_0000`. Their separate size registers, `SEP_REGION_SIZE` and SMC `REGION_SIZE`, both reset to `0x0100_0000` (16 MiB). The corresponding half-open address ranges are therefore `[0x0000_0000, 0x0100_0000)` for SEP and `[0x4000_0000, 0x4100_0000)` for SMC.

The global base addresses and region sizes are software-programmed and must not overlap. The hardware does not derive them from a chiplet ID. The Programmer's Guide gives the aperture programming sequence for early boot.

Register tables throughout this manual report each field's software access as a compact token in their **Access** column; Register Field Access Notation decodes that notation.

1.2.1. Decode Response Codes

The SMC, SEP, Key Manager and cross-trigger network address maps state, for each unit, how a 32-bit access that no register or memory backs is answered. A cell reads *read response*, *read data / write response*, for example `DECERR, 0xBADCAB1E / SLVERR`. `OKAY`, `SLVERR` and `DECERR` are the AXI response codes returned on `RRESP` and `BRESP`. The read data is the word a 32-bit read returns in either half of a 64-bit data bus. Where the two halves differ, a note on the cell gives the word returned when address bit 2 is set.

- The *Hole in Extent* column covers an unbacked offset inside the unit's decoded extent. Where the space between a wrapper's sub-blocks, or the padding after each element of an array, answers differently, the cell names it separately as `between sub-blocks` or `between instances`.
- The *Past Extent* column covers the rest of the unit's aperture, the range its Size column gives.
- A `Reserved` row is an address between unit apertures.

Table 2. Decode response codes

Code	Meaning
`OKAY`	The access completes. A read returns the listed data, and a write has no effect.
`SLVERR`	The access reaches a component that refuses it.
`DECERR`	No unit or sub-block claims the address, and a decoder refuses the access before it reaches one.
Aliases registers	The access reaches a live register at another offset, which answers it.
Forwarded	The subsystem passes the access on without decoding it, and its target answers.
Adopter-defined	The adopter's implementation answers.
`-`	The region does not exist: the unit is memory, its registers fill its extent, or its aperture ends at its extent.

1.3. Power Domains

The SMU, SMN, and AXI-over-UCIe bridge (AoU) reside in the same always-on power domain. This domain remains powered whenever the chiplet has supply, ensuring that platform management, inter-chiplet communication, and security services are available even when application logic is powered down.

Vendor-specific macros and subsystems that are outside the scope of OCAH — such as OTP/eFuse controllers, PLLs, die-to-die PHYs (e.g. UCIe PHY), analogue sensors, and application-specific tiles — typically reside in their own dedicated power and voltage domains defined by the adopter's power architecture. OCAH provides the isolation and sequencing infrastructure (`isolate_req_o[31:0]`, `ss_reset_ctrl_o[31:0]`) that the SMC firmware uses to coordinate power transitions for these external domains, but their supply rail definitions, power gating decisions, and leakage budgets are adopter-specific.

The SMC provides runtime power management services for the application logic, including dynamic voltage and frequency scaling (DVFS) through AVSBus-based voltage regulator control and firmware-driven Performance State (P-State) management. At the RTL level, the SMU accepts a `powergood_i` input that indicates supply stability and exposes `isolate_req_o[31:0]` to request isolation of individual subsystem domains before power transitions.

1.4. Clock Domains

OCAH distinguishes low-level management timing from functional application clocks. The SMC receives an always-on reference clock (`clk_ref_i`) that is available from power-on, before any PLL is locked. Using this reference clock, the SMC controls the PLLs during early bring-up and generates the primary system clock (`clk_smu_i`) that is then distributed to the SMC itself, the SEP, and the DTP.

The `clk_smn_i` input is architecturally independent of `clk_smu_i`; when they are asynchronous, CDCs at this boundary are an integration responsibility. OCAH does not supply synchronizer cells at the SMN interface.

Figure 2 overlays the clock domains on the OCAH top-level block diagram. Each zone boundary runs through the CDCs that separate the domains. The AoU bridges, the D2D macros and the future safety monitor are not assigned a zone. The SMN reaches each AoU through its APB register port, whose clock is asynchronous to the AoU core clock; the CDC marker inside each AoU is the bridge's own APB synchroniser. The SMU zone marks `clk_smu_i`, which clocks the DTP, the crossbar, the SEP and the SMC. Pills inside the SEP and SMC list their clock inputs: both also use `clk_ref_i`. The SMC uses `clk_periph_i` for its peripherals and `clk_telemetry_i` for ATB telemetry. The SEP uses `entropy_rosc_sample_clk_i`, shown as "entropy rosc", for its entropy source and `clk_sep_wdt_i` for its watchdog.




Figure 2. OCAH Clock-Domain Zones

Table 3 summarises the clock domains present in OCAH.

Table 3. OCAH Clock Domains

Clock	Subsystem	Description
`clk_smu_i`	SMU (SMC, SEP, DTP)	Primary system clock, generated by the PLL under SMC control. Distributed internally to the SMC, SEP, and DTP subsystems. Drives the CPU cluster, fabric interconnect, peripheral controllers, and DTP cross-trigger / AXI bridges.
`clk_smn_i`	SMN (integration context)	System Management Network clock. An integration-level input independent of `clk_smu_i`; when the two are asynchronous, the integrator is responsible for placing CDCs at this boundary. OCAH does not supply synchronizer cells at the SMN interface. Not an SMU port.

Clock	Subsystem	Description
clk_ref_i	SMC, SEP	Always-on reference clock, available before PLL lock. Used by the SMC for early bring-up, PLL control, reset synchronisation, and peripherals requiring a stable, lower-frequency source. The SEP also clocks its reference counter from this clock.
clk_periph_i	SMC	Peripheral clock domain. Drives SMC peripheral subsystems. The reset unit generates a dedicated synchronised reset (rst_primary_periph_clk) in this domain.
clk_telemetry_i	SMC	ATB telemetry clock domain. Separate clock for Advanced Trace Bus data collection, with its own reset (rst_telemetry_ni).
clk_sep_wdt_i	SEP	Low-frequency watchdog timer clock. Must be independent of the system clock so the WDT can detect system clock failures.
jtag_tck	DTP / SEP	JTAG Test Clock. Drives PTAP, STAP state machines, and all JTAG-domain scan logic inside the DTP/SMC/SEP.
entropy_rosc_sample_clk_i	SEP	Ring-oscillator sample clock for the entropy source (TRNG). Must be asynchronous to clk_i and typically runs between 100 and 400 MHz.

1.4.1. Reference Counter

Both the SMC and the SEP expose a free-running 64-bit reference counter in their CPU control register block (the REFERENCE_COUNTER CSR), clocked by the always-on reference clock (clk_ref_i). It advances continuously from reset, independent of the system clock (clk_smu_i) frequency or PLL state. Its value is synchronised into the CPU clock domain for software reads, and software may write the CSR to reload the counter, after which it resumes counting from the loaded value. Both subsystems share the same implementation (prim_refclk_count_w_cdc) and behave identically.

A reload crosses into the reference-clock domain through a one-entry asynchronous FIFO, and a second write issued before the first has crossed is dropped without an error indication. The Programmer's Guide gives the reload sequence.

1.5. Reset

Reset is handled hierarchically so that the management infrastructure comes out of reset first and then releases dependent domains in a controlled order. A global power-on reset (rst_cold_ni) establishes a known state for the entire chiplet, but the always-on domain is intended to be released first so that early control logic is live immediately. From there, the SMC sequences reset deassertion for the SMN and for downstream managed blocks according to platform dependencies, boot policy, and fault conditions. This staged reset model also supports partial and warm-reset behaviours in which application domains can be reset or recovered without fully tearing down the always-on management infrastructure.

The reset hierarchy within the SMU proceeds as follows:

1. **Power-on / cold reset.** The external rst_cold_ni is asserted during power-up and deasserted synchronously after supply voltages stabilise. The powergood_i input indicates that supplies are stable.
2. **SMC reset synchronisation.** The SMC reset unit (smc_reset_unit) generates domain-specific synchronised resets from the single cold reset input:
   - rst_primary_smc_clk_no — synchronised to the primary SMC clock domain
   - rst_primary_ref_clk_no — synchronised to the reference clock domain
   - rst_primary_periph_clk_no — synchronised to the peripheral clock domain
   - rst_cold_stable_ref_clk_no — stable cold reset in the reference domain
3. **DTP reset.** The DTP is held in reset by the SMC's primary synchronised reset (rst_primary_smc_clk_no). In addition,

the JTAG state machine requires a power-on reset that remains asserted until supplies are stable; at the SMU level this is the `powergood_stable` signal generated by the SMC.

4. **SEP reset.** The SEP is held in reset by the same SMC primary reset (`rst_primary_smc_clk_no`). The SEP watchdog timer also drives a shared warm-reset path (`rst_wdt_n` at the SMU level); its blast radius is limited to the SEP CPU and the SEP warm scratch registers, plus the parts of the SMC that the SMC reset unit routes through the warm-reset path.
5. **Downstream subsystem sequencing.** The SMC sequences reset deassertion for up to 32 managed subsystems through `ss_reset_ctrl_o[31:0]` and isolation through `isolate_req_o[31:0]`. Subsystems report completion via `ss_reset_complete_i[31:0]`.
6. **Function Level Reset (FLR).** Asserting `cfg_flr_pf_active_i` triggers a warm reset sequence that isolates subsystems through `isolate_req_o` and performs controlled reset propagation without tearing down the always-on infrastructure.
7. **Debug reset overrides.** The DTP provides JTAG IC_RESET controls that can override the fuse, cold, cool, warm, and per-subsystem reset domains independently for debug scenarios. These are wired through the SMU into the SMC reset unit and the SEP reset controller. The Programmer's Guide gives the programming order these overrides require.

1.5.1. IC_RESET TDR

The primary TAP implements the IEEE 1149.1-2013 §17 IC_RESET TDR as three slices on the scan chain from TDI to TDO, followed by a single `reset_hold` bit nearest TDO:

- **SMC slice** (nearest TDI). Fuse, cold, cool, and warm resets, plus cold and warm resets for each of the 32 managed subsystems. The SMU consumes this slice internally.
- **SEP slice.** SEP main reset and the Adams Bridge, TRNG, KMAC, HMAC, AES, OTBN, and Key Manager resets. Present when SEP is instantiated; omitted otherwise. The SMU consumes this slice internally.
- **External slice.** Reset overrides for logic outside the SMU. The ports in this slice are adopter-defined: the integrator supplies the slice type and routes the SMU output to that logic. OCAH does not name the external bits. The default type is a single-override stub.

Each port carries an override-enable bit and an active-low reset value. The Integrator Guide records the SMU port map, including how to size the external slice.

For the detailed reset controller design, sequencing FSM, reset register interface, and clock-reset interaction, refer to the Clock and Reset Management chapter:

Clock and Reset Management

For integration-level reset procedures, refer to the Integrator Guide. The Programmer's Guide lists the resets that software requests in its SMC and SEP reset overviews.

1.6. RTL Assertions

First-party RTL uses the `OCAH_ASSERT*` macros; OpenTitan-derived blocks use `OCAH_OT_ASSERT*`; PULP-vendored cells (`common_cells`, AXI, iDMA) use `OCAH_PULP_ASSERT*`. The checks live in the module that owns the behavior and cover known-value hygiene, illegal parameter combinations, and local protocol or FSM invariants. They compile out of synthesis and fire on four-state simulators.

Table 4 identifies the header for each assertion macro family.

Table 4. RTL assertion macro families

Family	Header
`OCAH_ASSERT*`	`hw/common/assert/ocah_assert.svh`
`OCAH_OT_ASSERT*`	`vendor/lowRISC/opentitan/upstream/hw/ip/prim/rtl/prim_assert.sv`
`OCAH_PULP_ASSERT*`	`vendor/pulp-platform/common_cells/upstream/include/common_cells/assertions.svh`

Chapter 2. OCAH Platform Components

2.1. System Management Unit (SMU)

The System Management Unit (SMU) is the chiplet's system-management subsystem. It integrates three functional blocks around a runtime-programmable AXI crossbar and presents a single boundary to the System Management Network (SMN).

2.1.1. Composition

The SMU combines:

- **Security Processor (SEP)** — Root of Trust with a physically isolated RISC-V execution environment for secure boot, lifecycle control, device attestation and hardware-accelerated cryptography (OTBN PKA, AES, HMAC-SHA2, KMAC-SHA3, TRNG, DRBG, Key Manager). See [security-processor-sep].
- **System Management Controller (SMC)** — Firmware-driven orchestration engine responsible for clock, voltage and reset management, platform bootstrapping, system initialisation, and power/thermal management. Built on a RISC-V micro-controller with DMA and memory-zeroer accelerators. See [system-management-controller].
- **Debug and Test Ports (DTP)** — Standardised debug and test access across heterogeneous, multi-vendor chiplet systems. Covers JTAG scan chains, JTAG2AXI debug bridges, cross-trigger network and synchronised clock control. See Debug and Test Ports (DTP).

These three subsystems share a single primary clock domain (`clk_smu_i`) and are released from reset by the SMC's reset unit in a controlled sequence. Platform-wide clock, power and reset behaviour is described in the Clock Domains chapter.




Figure 3. SMU composition with the optional SEP subsystem

The SMU composition is shown in Figure 3. Dashed outlines mark the blocks present only when `CFG.SEP` is 1: the SEP and the AXI4 crossbar. Memory capacities in the diagram describe the illustrated configuration. Hatched blocks are future: the safety bus and the safety monitor, whose connections to the SEP and SMC are drawn dashed.

2.1.2. AXI Crossbar

Inside the SMU, the `smu_axi_xbar` module is the system-level arbitration fabric between SEP, SMC, and the rest of the chiplet (reached through the `smu_axi_in` / `smu_axi_out` boundary pair). It is a 3×3 AXI4 crossbar with non-reflexive connectivity: each master can reach the other two subordinates but never its own inbound port.

The SMU instantiates the crossbar only when `CFG.SEP` is 1. When `CFG.SEP` is 0, AXI ID-width converters connect the SMC system AXI ports to the `smu_axi_in` / `smu_axi_out` pair: every SMC-initiated transaction leaves through `smu_axi_out`, and every `smu_axi_in` transaction targets the SMC.

Crossbar targets	Initiators		
	SEP sep_out	SMC smc_out	Chiplet fabric ext_in
sep_in (SEP)	—	●	●
smc_in (SMC)	●	—	●
ext_out (catch-all)	●	●	—

● Connected — Not connected

Figure 4. SMU AXI crossbar connectivity

Table 5 lists the permitted initiator-to-subordinate paths and their purposes.

Table 5. SMU AXI crossbar ports

Master (from)	Subordinate (to)	Purpose
`sep_out`	`smc_in`	SEP-initiated transactions into SMC resources
`sep_out`	`ext_out`	SEP-initiated transactions leaving the SMU
`smc_out`	`sep_in`	SMC-initiated transactions into SEP resources
`smc_out`	`ext_out`	SMC-initiated transactions leaving the SMU
`ext_in`	`sep_in`	External transactions targeting SEP
`ext_in`	`smc_in`	External transactions targeting SMC

Routing decisions use a runtime address map with two programmable rules, the SEP and SMC apertures. `ext_out` has no address rule; it is the default subordinate for `sep_out` and `smc_out` requests that match neither aperture. See OCAH Memory Map for the fixed-vs-programmable split and the reference envelope convention, and see the SMU AXI Crossbar Address Map section in the Integrator Guide for firmware programming order.




Figure 5. SMU aperture decode and routing

Figure 5 shows the independent SEP and SMC address comparisons for each read or write request. Each aperture includes its base address and excludes `base + size`; the addition uses 57 bits to preserve carry from the 56-bit address, and the address is zero-extended to 57 bits for the comparison. The SEP and SMC ranges must not overlap.

The decoded aperture and the connectivity in Figure 4 together determine where each request goes, as Table 6 shows.

Table 6. SMU AXI crossbar routing by initiator and decoded aperture

Initiator	SEP aperture	SMC aperture	Neither aperture
sep_out	DECERR	smc_in	ext_out
smc_out	sep_in	DECERR	ext_out
ext_in	sep_in	smc_in	DECERR

- A sep_out or smc_out request that matches neither aperture is forwarded to ext_out.
- A sep_out request that matches the SEP aperture, or an smc_out request that matches the SMC aperture, returns DECERR, because no initiator is connected to its own subsystem's inbound port.
- An ext_in request that matches neither aperture returns DECERR, because ext_in is not connected to ext_out.

The crossbar generates each DECERR response itself; the request reaches no subordinate.

2.1.3. Clocks and Resets

Figure 6 and Figure 7 show the clock and reset distribution from the SMU boundary to DTP, SEP, SMC, and the shared AXI infrastructure. Boundary inputs enter on the left and boundary outputs leave on the right; nets generated inside the SMU run in the channel to the right of the instances. A dot marks fan-out, and a gap in a line marks a crossing without a connection. Labels at an instance's right edge name the net it drives or the port that receives a generated net. Instance names match the SMU RTL hierarchy, and paths to the SEP exist only when CFG.SEP is 1.

Active-low resets use the _ni, _no or trst_n suffixes; the SMC CPU JTAG reset is active-high, so dtp_smc_stap_tap_ctrl.trst_n passes through an inverter. Figure 7 shows reset distribution within the SMU, not the reset logic inside each subsystem.




Figure 6. SMU clock distribution




Figure 7. SMU reset distribution

2.1.4. Lifecycle and Feature Control

SEP lifecycle state and feature controls constrain the debug paths in DTP and the management functions in SMC, as shown in Figure 8.




Figure 8. SEP lifecycle and feature-control propagation to SMC and DTP

In Figure 8, the OTP shadow registers, the demotion CSRs and the security-disable token feed the Life Cycle Controller, and each named output runs to the block that consumes it; a slashed line carries its bus width. Table 7 gives the effect of each control on its consumer. The demotion CSRs clear on SEP cold reset, and security disable overrides the normal feature restrictions.

Table 7. SEP lifecycle and feature-control effects

Control	Consumer and effect
`dbg_disable_o`	DTP: disables selected STAPs, SIBs and SMC-fabric JTAG2AXI access
`lc_state_o`	SMC: eFuse JTAG access policy and the `LC_STATE` CSR. Also an SMU boundary output.
`security_disable_o`	SMC `sep_security_disable_i`: security-disable override for the eFuse wrapper
`sep_fuse_dft_disable_o`, `smc_fuse_dft_disable_o`	SMU boundary outputs for adopter DFT insertion; each gates its DFT OTP access paths
`feat_ctrl.sep_debug`	SEP inbound AXI filter: `1` bypasses the filter; `0` filters external traffic
`LC_STATE`, `lcc_demote_state_1/2`	Key Manager: lifecycle and demotion context. The demotion state also reaches the SMU boundary.

The subsystem chapters (SEP, SMC, DTP) follow immediately; see the Composition section above for roles and cross-references.

2.1.5. Security Processor (SEP)

The Security Processor (SEP) is the chiplet Root of Trust. Its documentation is organized into focused topic pages so architecture, security policy, software interfaces, and generated register details can be read independently.

2.1.5.1. Overview

SEP combines a VeeR CPU, boot ROM, system peripherals, lifecycle controls, and cryptographic accelerators. The chapters below describe these functions in reading order; the block diagram shows their hardware connections.




Figure 9. SEP top-level microarchitecture

Every AXI4 link carries a manager port (M) at the initiating end and a subordinate port (S) at the other. The local crossbar has five managers: the CPU IFU, LSU and debug ports, the DMA, and inbound SMN traffic after the system peripherals' inbound filter. Its ten subordinates are the CPU TCM port, the SRAM interface, the DMA registers, the SPI host, the watchdog, the system peripherals, the reset controller, the entropy pool, the crypto subsystem and the eFuse shim demux. SEP AXI4 connectivity gives the permitted paths. The IFU and LSU reach the boot ROM through a dedicated AXI mux rather than the crossbar, and the IFU crossbar port reaches only the SRAM. The eFuse shim demux sends accesses in the eFuse shim CSR window to the crypto subsystem and the rest of the external aperture to the AXI4 extension port.

The grey boxes are the memory macros and IP that the integration layer instantiates outside the SEP. The Adams Bridge and its SRAMs are present only when the build defines `SEP_ABR_EN`; the Adams Bridge uses nine SRAMs, plus four masked copies when `ABR_MASKING_EN` is set. The external TRNG is an adopter choice. Interrupt lines to the CPU PIC are not drawn; see Interrupts.

2.1.5.1.1. Responsibilities

SEP is the Root of Trust (RoT) of the chiplet with the highest security privilege. SEP provides a physically isolated execution environment for highly sensitive security services. The following are some examples:

- **Secure boot**: The SEP ROM BL0 image uses non-volatile public keys to conduct authentication verification on the loaded BL1 software images.
- **Secure lifecycle control**: SEP implements a secure lifecycle controller to manage function, debug and test access to the chiplet according to fuse configuration, in-field demotion, and secret token inputs.
- **Device attestation**: SEP offers support to device attestation by recording the boot process and device configuration followed attestation using public key infrastructure.
- **Cryptography service**: SEP offers secure key services to the rest of the system together with cryptography acceleration. SEP also implements True Random Number Generator (TRNG) to provide random numbers for SEP itself and the rest of the system.
- **User authentication**: Similar to secure boot, user authentication is another authentication service SEP offers. Besides feature control that can be tied to the authentication result, SEP software can also tie the authentication result to the secret key derivation to ensure that bypass of the user authentication leads to a useless system.

The SEP is responsible for ensuring that the chiplet and overall packaged system composed of multiple chiplets remains secure from adversaries. This means that SEP ensures the system

- Runs correctly with the intended firmware and data protected by digital signatures
- Guards against malicious data input to SEP, SMC and the debug/test infrastructure
- Prevents exfiltration of private or secret data on all exits, including side channels
- Prevents privilege escalation which would enable illegal operations

A consolidated description of OCAH use cases is available in Use Cases.

2.1.5.1.2. Threat Model

The threat model defines the attacks considered by SEP.

2.1.5.1.3. Attack Countermeasures

Attack Countermeasures describes the corresponding architectural, debug and test protections.

2.1.5.1.4. Clocks and Resets

SEP uses one system clock (`clk_i`) that clocks the CPU, interconnect and all cryptographic subsystems. Additional clock roots supply reference counter (`clk_ref_i`), watchdog timer (`clk_wdt_i`), entropy sampler (`entropy_rosc_sample_clk_i`) and CPU debug (`jtag_tck_i`). Clocks and Resets describes their distribution and links to software reset sequencing.

2.1.5.1.5. CPU

The CPU provides a JTAG debug interface, tightly coupled instruction and data memories, and two scratch register banks. The proposed Alarm Aggregation Processor is deferred to a later generation.

2.1.5.1.6. Boot ROM

The immutable BL0 firmware starts the SEP and authenticates the next boot stage. The Boot ROM chapter owns the hardware layout and boot-flow summary.

2.1.5.1.7. Interconnect

AXI4 connects the CPU, system peripherals and cryptographic subsystem. External interfaces include inbound and outbound system AXI paths, the peripheral extension and JTAG. UART and GPIO services can be reached through SMC.

2.1.5.1.8. Interrupts

The interrupt chapter identifies PIC sources and the separate NMI, timer, software-interrupt and memory-error paths.

2.1.5.1.9. Peripherals

DMA provides data movement and inline hashing. Mailboxes carry host service requests. SPI supplies flash access; the watchdog provides bark and bite events. The peripheral subsystem chapter describes their integration and extension interface.

2.1.5.1.10. Security and Lifecycle

The OTP fuse controller, token processing, security-disable logic, lifecycle controller and test-mode controls govern access to security assets and debug.

2.1.5.1.11. Cryptographic Subsystem

AES, HMAC-SHA2, KMAC-SHA3, OTBN and Adams Bridge provide acceleration. Entropy Source, DRBG and entropy distribution supply random material. Key Manager owns the Key and Policy Vault and accelerator key-sideload interfaces.

2.1.5.1.12. Memory Map

The memory map summarizes CPU and external address views and links to each block's register reference. Technology-specific ROM, SRAM, OTP and entropy macros sit outside SEP and connect through its dedicated interfaces. These include BL0 ROM, ICCM, DCCM, scratch SRAM, KM ROM/SRAM and OTBN IMEM/DMEM.

2.1.5.2. Threat Model

The SEP threat model considers remote software attacks, physical attacks and supply-chain attacks. These categories describe the threats considered; the explicit limits of protection are listed below.

Software attacks apply across deployments and are the primary attack vector for data center implementations. Physical attacks are localized and require close proximity; they are relevant to automotive and robotics applications. Supply-chain attacks involve changes to the design, production or provisioning of chips.

2.1.5.2.1. Software Attacks

- Malicious firmware modification during boot, overlay or application loading, or updates.
- Modification or exfiltration of private data, such as ML model weights and cryptographic keys.
- Forged attestation that mimics legitimate device behavior.

2.1.5.2.2. Physical Attacks

The model assumes that an attacker has full visibility of SRAM and OTP data state.

Physical threats considered include:

- Fault injection to bypass security checks, including clock and voltage glitching, laser and electromagnetic (EM) energy injection, and thermal gradients. The model also groups logically induced faults, such as Row Hammer DRAM attacks, in this category.
- Differential cryptanalysis for key recovery, and side-channel attacks to extract keys or other secret data.
- Hardware probing to observe or control data within a chiplet or in communication between chiplets.

2.1.5.2.3. Supply-Chain Attacks

- Insider modification of the design to disable or weaken security features or insert backdoors, and theft of hardware secrets such as security tokens.
- Modification of IC design masks to change behavior or insert trojans. For example, modified BL0 boot ROM contents could disable secure boot.
- Corruption of fuse provisioning to enable or disable features without authorization or leak device-unique secrets.

2.1.5.2.4. Limits of Protection

SEP does not explicitly protect against the following threats, even though some appear in the categories above:

- Hardware probing of communications between chiplets inside the package.
- Hardware probing of chiplets inside the package and certain physical attacks, such as bias fault injection.
- Thermal gradients used to influence the entropy source or induce timing faults.
- Supply-chain attacks.

2.1.5.3. Attack Countermeasures

Countermeasures include:

- Protection of BL0 boot ROM and subsequent secure boot via digital signature verification
- Glitch and error detection
    - SRAMs and other memory structures such as FIFOs and register files are protected by parity (byte-wise) or SECDED
- Temporal noise injection, masking, secret splitting and obfuscation on sensitive operations
- Transaction filtering and firewalling
- Functional and physical isolation of private data assets e.g. cryptographic keys
- Anti-replay facilities e.g. non-volatile counterj in OTP
- Obfuscate data stored in SRAM and OTP memories

2.1.5.3.1. Debug and DFT Security Considerations

The debug facilities and DFT share the scan chain infrastructure for their respective tasks. This is a security hazard as

certain secret values will be resident in the registers: tokens, secrets, cryptographic keys. Unless prevented, an attacker could halt the chip execution and extract the register state containing these secrets. This section describes the countermeasures we take to prevent this from happening.

One debug feature is scandump which provides access to all internal register states. We must ensure that a certain subset of registers holding secrets are never dumped out in this mode.

There are three scenarios of how registers are handled for DFT scan test and debug scandump:

1. Full DFT and Debug access
2. DFT access but no Debug access
3. No DFT and no Debug access

Consequently there will be two discrete scan chains to handle the registers in groups 1 and 2. The register instances (or module instances) will be labelled as belonging to one of the three groups and the DFT scan insertion tool will group the registers into the respective scan chains which will be managed for security in the TAP controller.

These three groups correspond to the SEP asset classes defined authoritatively in the Lifecycle Controller chapter (*Asset and Scan-Chain Protection*): group 1 = Class 3 (general), group 2 = Class 2 (crypto / KM secret-bearing, plus the fuse program path), group 3 = Class 1 (secrets and integrity-critical control fields).

2.1.5.3.1.1. Debug and Scan Dump

Debug mode is enabled when in-field debug is granted, via demotion (DEMOTE_1 / DEMOTE_2) or an RMA debug state (RMA_SIP / RMA_CHIPLET). In this mode, the user has near full control and observability of the chip state, but we must enforce security restrictions.

General logic (Class 3) scan dump is gated by the `*_DBG` feature-control bits (sourced from the OTP DIS vectors; `1'b0` = enabled, `1'b1` = disabled, irreversible) and the LC state — a scope's general logic is dumpable only when its local gate (`SEP_DBG` / `CHIPLET_DBG`), the `SIP_DBG` debug-access path into the chiplet, and the LC state permit it.

Secret-bearing logic (Class 2) — crypto-engine key / round-key storage and the Key Manager key vault / shared key storage — is placed on a **dedicated secure scan chain** so DFT keeps coverage, but is **never scan-dumpable**, for any owner or LC state. The `_DBG bits decide whether that chain is reachable, as they do for any chain; what makes it undumpable is the command class. The DFT controller admits a *test` command on it only when `secure_tm = 1`, admits nothing at `secure_tm = 0`, and never admits a **dump** command at all. Under `secure_tm = 1` the secret sources (UID / `CLASS_KEY`) are disconnected from these consumers, so a permitted test shift moves no real secret.

Secrets and integrity-critical fields (Class 1) are excluded from every scan chain (never scannable):

- Class 1a (confidentiality): UIDs, `CLASS_KEY`, token-plaintext input registers (`*_TOKEN_I`), raw fuse read-back data.
- Class 1b (integrity): `LOCKS`/`LOCKS_SPARE`, `LC_STATE`, `SIP_DIS`, `SYS_DIS`, `*_TOKEN_DIGEST` shadow registers.

2.1.5.3.1.2. Class 2 Asset Manifest and Naming

The authoritative class definitions, scan-chain policy, and gating rules are in the Lifecycle Controller chapter (*Asset and Scan-Chain Protection*); Key Manager specifics are in the Key Manager chapter (*Scan and Scan-Dump Protection*). This section records the implementation manifest. A complete module instance is classified as Class **2a** when it is the Key Manager, a device-secret-consuming cryptographic engine, an entropy engine, or sequential distribution logic that retains key, seed, random, digest-working, or round-key state. Classifying complete instances deliberately includes their control flops and avoids fragile per-register marking.

The current SEP implementation has exactly 11 Class 2a RTL scan roots:

- `u_sep_crypto.u_hmac_wrapper_s3c_scan`
- `u_sep_crypto.u_sep_crypto_otbn_wrapper_s3c_scan`
- `u_sep_crypto.u_aes_wrapper_s3c_scan`
- `u_sep_crypto.u_kmac_wrapper_s3c_scan`
- `u_sep_crypto.u_sep_crypto_abr_wrapper_s3c_scan`
- `u_sep_crypto.u_sep_trng.u_entropy_source_s3c_scan`
- `u_sep_crypto.u_sep_trng.u_drbg_s3c_scan`
- `u_sep_crypto.u_axis_edn_crypto_s3c_scan`
- `u_sep_crypto.u_axis_edn_pool_s3c_scan`
- `u_sep_crypto.u_key_manager_s3c_scan`
- `u_trng_wrapper_s3c_scan`

The `_s3c_scan` suffix is reserved for Class 2 instance and generate-scope names. It is not a module-name or per-flop suffix. A nested `_n0_scan` name remains Class 1 and takes precedence over an enclosing `_s3c_scan` hierarchy.

Three writable companion SRAMs are also Class 2a assets: `u_km_sram`, `u_otbn_imem_sram`, and `u_otbn_dmem_sram`. Their macro instance names remain unchanged because `_s3c_scan` identifies RTL scan hierarchies; the owning memory-DFT/MBIST policy must provide the same never-dump outcome. `u_km_rom` is explicitly excluded because immutable executable contents cannot retain runtime secrets. The vendor TRNG core keeps its delivered DFT view beneath `u_trng_wrapper_s3c_scan`.

Class **2b** covers the fuse programming **control** and **status** MMRs of the SEP fuse controller. These hold no secret; they are never-dumpable because scan shifting drives arbitrary transient values through them, and a program-control register reached during an ordinary dump could burn fuses (see the Lifecycle Controller chapter, *Asset Classes*). Class 2b shares the secure chain and the command-class rule with Class 2a, so the `_s3c_scan` suffix applies to it as well. Unlike Class 2a it is **not** a whole-instance classification: the remainder of the fuse controller stays Class 3, so the implementation must identify the program-path scan roots and name them accordingly.

2.1.5.3.1.3. Secure Test Mode (SECURE_TM)

We assert a GPIO pin strap to enable secure test mode. This generates the SECURE_TM signal which is consumed by

- The DFT controller, which admits a **test** command on the Class 2 secure chain only while SECURE_TM is asserted. SECURE_TM does not enable scan test and authorizes nothing; it is the condition under which that chain will accept a test command at all.
  - Shadow registers of LOCKS/LOCKS_SPARE, LC_STATE, SIP_DIS, and SYS_DIS are non-scannable registers
  - Any downstream registers in the path from these registers to the feature control outputs or the fuse write-enable signals are also non-scannable, as are the SECURE_TM latch and the command-admission logic that consumes it
    - Dedicated test registers may be inserted in the path while in SECURE_TM mode to enable testing of downstream logic
  - During scan test (`secure_tm = 1`) the secret-source outputs (UID / `CLASS_KEY`) are disconnected from the Class 2 consumers, so no real secret is shifted. On the Class 2 secure chain the DFT controller admits a test command only at `secure_tm = 1`, admits no command at `secure_tm = 0`, and never admits a dump command (never

dumpable). See the Lifecycle Controller chapter, *`secure_tm` and the Secure Scan Chain*.

- Disable writing to any OTP fuse state to prevent updates.

- OTP controller
  - Disable *writing* of shadow registers: LOCKS/LOCKS_SPARE, LC_STATE, SIP_DIS and SYS_DIS
  - Other shadow register fields may optionally also have write disabled

2.1.5.4. Clocks and Resets

2.1.5.4.1. Clock Distribution

The SEP system fabric, CPU and cryptographic subsystem receive `clk_i`. The CPU and some cryptographic blocks gate branches of this clock locally; these branches do not provide independently programmable CPU or accelerator frequencies. The other clock inputs serve reference counting, watchdog timing, entropy sampling and JTAG debug.

Table 8. SEP clock inputs

Input	Use
`clk_i`	Main functional clock for the fabric, CPU, cryptographic subsystem and register interfaces.
`clk_ref_i`	Free-running reference clock counted by `REFERENCE_COUNTER`; the count crosses into `clk_i` for software access.
`clk_wdt_i`	Watchdog timer clock. The watchdog register interface uses `clk_i`, with clock-domain crossings to the timer core.
`entropy_rosc_sample_clk_i`	External entropy-sampling clock option. Each noise-source sampler selects between this input and the internal shared ring oscillator, then applies its sample-clock divider.
`jtag_tck_i`	CPU JTAG TAP clock; debug requests cross into `clk_i` through the debug-interface handshake.

Figure 10 overlays these clock domains on the SEP top-level diagram. The CPU TAP runs on `jtag_tck_i`; local clock gating and derived clocks are described below. The CPU has a free-running branch and a pipeline branch gated according to halt/pause state, flush activity and clock override. SPI generates its serial clock locally. Entropy-source oscillators and sample clocks are distinct from the main functional clock. The diagram describes connectivity; operating frequencies and timing constraints belong to the platform integration.




Figure 10. SEP clock tree and clock domains

2.1.5.4.2. Reset Architecture

Reset scope determines which state survives a restart. In normal operation (with debug and scan overrides inactive), SEP uses the following reset boundaries.

Table 9. SEP reset boundaries

Reset	Scope and release condition
Cold reset (`rst_ni`)	Resets the early infrastructure, including the local AXI crossbar, OTP controller, watchdog and reset-isolation sequencers. This infrastructure can operate before the boot-qualified SEP reset is released.

Reset	Scope and release condition
Boot-qualified SEP reset (`sep_reset_n`)	The OTP controller qualifies release with fuse sensing complete, cold reset released and `ext_boot_seq_done_i` asserted. The SEP Reset Controller applies the SEP JTAG override and synchronizes release to `clk_i`. This reset feeds system peripherals and the reset-controller registers, and qualifies the software-controlled engine resets.
CPU reset (`sep_cpu_reset_n`)	Combines `sep_reset_n` with the aggregated SMC/SEP watchdog reset input, `wdt_rst_ni`. A watchdog reset restarts the CPU without asserting the boot-qualified SEP reset or the software-controlled cryptographic resets. It also clears the warm scratch register bank through the system CSR warm-reset input.
Software-controlled engine resets	Separate requests for Key Manager, OTBN, AES, HMAC, KMAC, Adams Bridge and the shared TRNG domain. Each sequencer isolates its required AXI paths and waits for the isolation acknowledgements before asserting reset.

A watchdog restart therefore does not return the cryptographic engines or their software reset requests to cold-reset defaults; see the software reset section of the Programmer's Guide. The watchdog itself uses cold reset; its timer-domain reset release is synchronized to `clk_wdt_i`.

JTAG can override the SEP and individual engine resets. These overrides do not perform the software-request isolation sequence. Scan test enable selects `scan_rst_ni` at the SEP reset synchronizer and the final engine reset outputs. These debug/test paths are separate from normal software recovery.

The Platform Reset chapter describes the shared reset sources and subsystem effects. The SEP Reset Controller owns the software programming sequence, AXI isolation behavior and shared TRNG-domain details, including the distinction between the entropy subsystem and the Key Manager sampler.

Platform Reset

SEP Reset Controller

2.1.5.4.3. SEP Reset Controller

The SEP Reset Controller provides software-controllable resets for the Key Manager, crypto accelerators, and internal TRNG complex. It is accessible via AXI4 at generated base address `0x1080_3000`.

Figure 11 shows the reset domains controlled by the SEP Reset Controller.




Figure 11. SEP reset domains and reset sequencing

Boundary reset inputs enter on the left and the generated resets run in the channel on the right, each net in its own colour, with the port it drives named at the instance edge. Inside each instance the figure shows which sub-instances each reset reaches. Figure 12 shows the logic inside `u_sep_efuse_wrapper` and `u_sep_reset_ctrl`, and Figure 32 shows the resets inside `u_sep_crypto`.

`u_sep_efuse_wrapper`, part of `u_sep_crypto`, ANDs `rst_ni`, `ext_boot_seq_done_i` and fuse-sense done and synchronizes the

result into sep_intermediate_reset_n. The Reset Controller builds its three outputs from it, as Figure 12 shows. The stacked row repeats once for each SW_RESET_N bit.




Figure 12. SEP Reset Controller reset logic

- sep_reset_no: the JTAG sep_reset_n override mux (u_sep_reset_ovrd_mux) selects sep_intermediate_reset_n or the JTAG value, and the 2-flop u_sep_reset_sync asserts the result asynchronously and releases it synchronously to clk_i. It resets the Reset Controller's own register block, the Key Manager cold domain, the system peripherals, the SPI host, the DMA and the SRAM and boot ROM interfaces.
- sep_cpu_reset_no: sep_reset_n ANDed with wdt_rst_ni (u_sep_cpu_rst_and), then the scan bypass u_sep_cpu_rst_scan_bypass. It resets the EL2 core (rst_l) and the warm scratch registers.
- sep_crypto_gated_rst_no[6:0]: for each bit, the output of u_<blk>_isolate_seq ANDed with sep_reset_n (u_<blk>_rst_and), then the per-IP JTAG override mux u_<blk>_rst_ovrd_mux, then the scan bypass u_<blk>_rst_scan_bypass. The per-IP override bits reach the muxes through the 2-flop synchronizers u_jtag_ip_ovrd_sync and u_jtag_ip_val_sync. The seven bits reset OTBN, AES, HMAC, KMAC, the TRNG, Adams Bridge and the Key Manager warm domain.

rst_ni resets the isolation sequencers and the JTAG override synchronizers. It also resets, directly, the crypto interconnect, life cycle controller, eFuse shim mux, alert receivers, encoders and EDN AXIS adapters, the TRNG power-on reset por_rst_ni, the watchdog, the local crossbar, the eFuse shim demux and the entropy pool. When the build does not define SEP_ABR_EN, the Adams Bridge error responders take rst_ni in place of the Adams Bridge wrapper. The watchdog synchronizes rst_ni into clk_wdt_i for its counter, and its bite leaves the SEP on wdt_timer_rst_req_o. dbg_rstb_i resets the EL2 debug module and u_mpc_reset_run_req_sync, and jtag_trst_ni resets the EL2 JTAG TAP. While test_en_i is high, scan_rst_ni replaces the outputs of u_sep_reset_sync, each scan bypass mux, u_rst_wdt_sync and both Key Manager reset conditioner paths.

2.1.5.4.3.1. Software Reset Register

Table 10 defines the software reset controls and their reset values.

Table 10. SEP SW_RESET_N fields

Bit	Field	Access	Default	Description
0	km_sw_rst_n	RW	0	KM reset (0=assert, 1=release)
1	otbn_sw_rst_n	RW	1	OTBN reset (0=assert, 1=release)
2	aes_sw_rst_n	RW	1	AES reset (0=assert, 1=release)
3	hmac_sw_rst_n	RW	1	HMAC reset (0=assert, 1=release)
4	kmac_sw_rst_n	RW	1	KMAC reset (0=assert, 1=release)
5	trng_sw_rst_n	RW	1	Shared entropy-source (ESRC), CSRNG, EDN and internal DRBG endpoint reset request (0=assert, 1=release); excludes the KM sampler
6	abr_sw_rst_n	RW	1	Adams Bridge reset (0=assert, 1=release)

On power-up, `SW_RESET_N` resets to `0x7E`: KM is held in reset, while OTBN, AES, HMAC, KMAC, the TRNG, and Adams Bridge are released. The SEP host firmware writes `1` to release an IP from reset and writes `0` to request its software reset.

2.1.5.4.3.2. Isolation and Reset Sequencing

Each `SW_RESET_N` bit drives a per-domain sequencer that isolates the domain's AXI paths before asserting its reset, so no transaction is in flight when reset asserts. Figure 13 shows every isolate stage in the crypto AXI interconnect and the sequencer that requests it.




Figure 13. SEP crypto AXI isolation

Host paths leave `u_axi_demux` on the left, with the bus type after conversion above each arrow. Key Manager paths leave `u_xbar` on the right. Both kinds of isolate stage sit in `u_sep_crypto_axi_interconnect`, whose outline wraps around the engine wrappers it serves. The italic line in an isolate stage names the `u_sep_reset_ctrl` sequencer that requests it: `otbn seq` is `u_otbn_isolate_seq`, and `otbn or km seq` means that either sequencer requests it. The eFuse, lifecycle, Key Manager mailbox and external TRNG ports have no isolate stage. The coloured bar at the left of each instance shows its reset. The interconnect and all its isolate stages run on `rst_ni`, so they stay out of reset while a domain behind them is reset. Each engine wrapper, `u_sep_trng` and the Key Manager crossbar are reset by their `gated_rst_ni` bit, and the mailbox by both the Key Manager cold reset `sep_reset_ni` and its warm reset. Without `SEP_ABR_EN`, error responders that return DECERR replace the Adams Bridge wrapper behind both of its isolate stages.

A software reset proceeds as follows:

1. Firmware writes `0` to the domain's `SW_RESET_N` bit.

2. The sequencer requests isolation on the domain's paths. New transactions on them complete with SLVERR and read data `0x1501A7ED`.
3. Each isolate unit drains its accepted transactions, then reports isolated.
4. Once all of the domain's paths report isolated, the domain's reset asserts.
5. Firmware writes `1`. Reset and isolation are released together.

Table 11 lists the paths each domain isolates.

Table 11. Paths isolated before each software reset

Domain	Paths isolated
OTBN, AES, HMAC, KMAC, Adams Bridge	Host path and Key Manager key path
Key Manager	All five key paths and the eFuse path
TRNG	ESRC, CSRNG, and EDN host paths

A key path isolates when either endpoint is reset, so neither end can enter reset mid-transfer.

An OTBN, AES or KMAC software reset also cancels that engine's endpoints in the shared crypto EDN adapter, from the cycle its paths report isolated until its reset releases. EDN therefore keeps serving the engine while it drains. A word committed to the engine but not yet acknowledged is discarded rather than delivered to another client; other clients are unaffected.

The Key Manager mailbox, eFuse wrapper, lifecycle controller, and external TRNG ports are not isolated. None of these targets has its own software reset domain; the mailbox's SEP-facing side is in the Key Manager's cold domain. No `SW_RESET_N` request can therefore reset one mid-transaction.

The sequenced resets are ANDed with `sep_reset_n`, which holds every IP in reset until eFuse sensing completes during boot. JTAG can drive `sep_reset_n` in place of the eFuse reset through the SEP slice of the IC_RESET TDR (see Section 2.1.7.3.3 in the DTP chapter), which releases it on a part whose fuse sensing does not complete. The per-IP JTAG override muxes are applied last, allowing debug to force reset without waiting for isolation.

2.1.5.4.3.3. Resetting the Key Manager

The sequenced Key Manager reset drives the Key Manager's warm reset, which restarts its CPU and volatile state but leaves its cold domain intact. That domain includes the SEP-facing side of the mailbox, so the SEP host can still reach the mailbox during the reset.

A soft reset requested through the Key Manager's `SOFT_RST_CODE` register takes the same warm path without isolation; the software reset section of the Programmer's Guide covers both requests. None is needed: the Key Manager CPU is the only master on its key and eFuse paths and completes each access before issuing the next, so no transaction is in flight when it writes `SOFT_RST_CODE`.

2.1.5.4.3.4. Resetting the TRNG

The TRNG reset bit controls one reset domain containing the entropy source, CSRNG, EDN, and DRBG endpoint state. ESRC, CSRNG, and EDN occupy three independent demux ports, so the TRNG sequencer isolates all three host paths and does not assert the TRNG reset until all three report isolated. Reset and isolation are released together.

The fabric entropy-pool AXI responder is not reset, so accesses remain responsive. While the TRNG reset is active, both post-mux EDN adapters and the pool synchronously clear their pending and buffered state, including the pool's half-packed word, FIFO contents, and fill-stall state.

Consumers are not part of the reset coordinator. Native EDN requests from AES, KMAC, and OTBN receive no acknowledgement while the post-mux adapter is clearing, remain asserted, and are serviced with fresh entropy after the chain restarts. Software may wait for those consumers to become idle and hold them in reset when policy requires aborting in-flight operations, but that is not required to assert the TRNG reset.

The Key Manager stream has no post-mux adapter, so TRNG reset does not scrub it. If the DRBG sampler is requesting or assembling a word when the reset asserts, the next DATA read can mix leftover bytes with new beats, or the sampler can flag a stream error. The SEP host must keep the Key Manager idle before asserting the TRNG reset. Holding KM in software reset is sufficient; hardware does not enforce the ordering.

The TRNG recovery sequence in the Programmer's Guide gives the firmware steps around this reset.

2.1.5.4.3.5. Memory Map and Register Reference

2.1.5.4.3.5.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.4.3.5.2. Detailed Register Map

2.1.5.4.3.5.2.1. SEP Reset Control Address Map

Software resets for KM, OTBN, AES, HMAC, KMAC, the internal TRNG, and Adams Bridge.

Table 12. SEP Reset Control Address Map register list

Address	Name	Access	Description
0x0	SW_RESET_N	RW	-

2.1.5.4.3.5.2.1.1. SW_RESET_N

Table 13. sep_reset_ctrl.SW_RESET_N fields

Bits	Field	Access	Reset	Description
63:7	Reserved	-	-	Reserved
6	abr_sw_rst_n	RW	0x1	Adams Bridge reset (0=assert, 1=release)
5	trng_sw_rst_n	RW	0x1	Internal TRNG reset request (0=assert, 1=release). Hardware drains and isolates the entropy-source, CSRNG, and EDN AXI ports before asserting the shared TRNG reset.
4	kmac_sw_rst_n	RW	0x1	KMAC reset (0=assert, 1=release)
3	hmac_sw_rst_n	RW	0x1	HMAC reset (0=assert, 1=release)
2	aes_sw_rst_n	RW	0x1	AES reset (0=assert, 1=release)
1	otbn_sw_rst_n	RW	0x1	OTBN reset (0=assert, 1=release)
0	km_sw_rst_n	RW	0x0	KM reset (0=assert, 1=release)

2.1.5.5. CPU

SEP uses the 32-bit RISC-V VeeR EL2 CPU to run boot and security-service firmware. This chapter describes the SEP configuration, local memories, reset vector and debug integration. The EL2 Programmer's Reference Manual defines the core programming model. The Programmer's Guide gives the programming guidance for this block.

Figure 14 shows the CPU subsystem and its instruction, data, and external memory interfaces.




Figure 14. SEP VeeR EL2 CPU subsystem and memory interfaces

`sep_cpu` holds the VeeR EL2 core complex, `u_el2_veer_wrapper`, and the fabric elements on its bus masters; the figure uses the notation of the fabric figures. The ICCM and DCCM controllers are part of the core complex, but their RAM macros sit outside `sep_cpu` in `sep_tcm_wrapper`, each bank 32 data bits plus 7 ECC bits wide. The instruction cache is not configured. The DMA slave port is the local crossbar's `cpu_tcm` target, the backdoor through which the secure DMA preloads the ICCM and DCCM. The IFU, LSU and debug system-bus masters are AXI4 with 64-bit data and 3-bit IDs, and each carries `SepSourceId` in AxUSER. The debug master's 1-bit ID is zero-extended to 3 bits. Each master passes a local alias remap that rewrites the 768 MiB window at `SEP_LOCAL_BASE_ADDR` to `0x1000_0000`. The IFU demux then sends boot ROM addresses to the boot ROM mux, SEP SRAM addresses to the local crossbar and everything else to a DECERR responder, and the LSU demux sends boot ROM addresses to the boot ROM mux and everything else to the local crossbar. The core and its buses run on the SEP clock. `mpc_reset_run_req_i` passes a two-flop synchronizer in `sep_cpu`; the core synchronizes the NMI, timer, software interrupt and the other halt and run requests itself.

Every SEP bus master drives a fixed AxPROT, shown in Table 14. The value does not follow the hart's privilege mode, so a U-mode load still issues as privileged. The upstream VeeR EL2 port documentation lists `0b100` for IFU reads and `0b000` for the LSU and debug masters; the core drives the values in the table. The core ignores AxPROT on its DMA slave port.

Table 14. AxPROT driven by the SEP bus masters

Master	AWPROT	ARPROT	Meaning
IFU, to the boot ROM and SEP SRAM	not issued	`0b101`	Privileged, secure, instruction
LSU, to the boot ROM and local crossbar	`0b001`	`0b001`	Privileged, secure, data
Debug system bus	`0b001`	`0b001`	Privileged, secure, data

Master	AWPROT	ARPROT	Meaning
Secure DMA master	0b001	0b001	Privileged, secure, data

2.1.5.5.1. Processor Core

The SEP build configures the core as follows. Optional VeeR capabilities must not be assumed to be present merely because the core supports them.

Table 15. SEP processor configuration

Feature	SEP configuration
Instruction set	RV32IMC. The bit-manipulation build options enable Zba, Zbb, Zbc and Zbe; Zbf, Zbp, Zbr and Zbs are disabled.
Pipeline and privilege	Four-stage pipeline; user-mode support enabled.
Memory protection	16 Physical Memory Protection (PMP) entries with Smepmp enabled. `pmpcfg` and `pmpaddr` CSRs control address ranges and access permissions.
Memory attributes	`mrac` independently selects cacheability and side-effect attributes for sixteen fixed 256 MiB regions. These attributes do not grant read, write or execute permission.
Interrupts and timers	Programmable Interrupt Controller (PIC), configured for 255 external sources, plus two internal timers that can operate independently or be linked. The timers use VeeR-specific `mip.MITIP0` and `mip.MITIP1` interrupts.
Debug	JTAG debug interface and an AXI4 debug master connected to the SEP fabric.
Dual Core Lock Step (DCLS)	Disabled in the checked-in SEP configuration. The integration exposes lockstep controls and status for builds that enable it; this does not establish functional-safety compliance.

The Interrupts chapter owns the source-by-source PIC mapping: Section 2.1.5.8.2.1. The Boot ROM chapter describes secure boot and execution unlock.

2.1.5.5.2. Local Memory

The configured closely coupled memories provide separate instruction and data storage. Their memory macros connect through the SEP CPU memory interface. The instruction cache is disabled in this configuration.

Table 16. SEP closely coupled memories

Memory	Capacity	CPU base address	Protection
Instruction Closely Coupled Memory (ICCM)	256 KiB	0xC000_0000	7 ECC bits per 32-bit word
Data Closely Coupled Memory (DCCM)	128 KiB	0xC004_0000	7 ECC bits per 32-bit word

2.1.5.5.2.1. Dual Scratch Register Banks

The system CSR block supplies two software read/write scratch banks. Each contains eight 32-bit data fields in 64-bit register slots, giving an 8-byte stride. Both banks reset their data to zero. Hardware exposes the field values, but the current system CSR logic does not use them to control behavior.

Table 17. Scratch-bank reset behavior

Bank	Reset and retention
Set 0, cold scratch	Cleared by `sep_reset_n`. Retains data through a watchdog-only CPU reset; retention is not guaranteed across reassertion of the boot-qualified SEP reset.
Set 1, warm scratch	Cleared by either `sep_reset_n` or `sep_cpu_reset_n`, so an aggregated SMC/SEP watchdog reset also clears this bank.

The names distinguish watchdog-reset behavior; they do not mean that set 0 can only be cleared by a power-on event. The Clocks and Resets chapter defines these reset boundaries.

2.1.5.5.2.1.1. Scratch Register Reference

2.1.5.5.2.1.1.1. SEP Scratch Address Map

General-purpose SEP scratch register bank.

NOTE	**Register Arrays:** • **SCRATCH[8]**: 8 registers, base 0x0, stride 0x8

Table 18. SEP Scratch Address Map register list

Address	Name	Access	Description
0x0 - 0x38	SCRATCH[8]	RW	-

2.1.5.5.2.1.1.1.1. SCRATCH[8]

Table 19. sep_scratch.SCRATCH[8] fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	data	RW	0x0	Scratch register for the CPU

2.1.5.5.3. Reset and Boot

The default reset vector points to BL0 in the Boot ROM. The debugger can change that vector as described below. Boot ROM owns the ROM layout, integrity limitations and BL0-to-BL1 boot sequence.

SEP Boot ROM.

2.1.5.5.3.1. Configuration Straps

The platform boot-interface requirement is at least eight static configuration straps, preferably sixteen. This is a platform requirement, not a count of strap inputs on the CPU core. How the straps are sourced and captured is up to the adopter; firmware reads their values from the SMC strap registers (STRAPS_LO and STRAPS_HI).

BL0 uses platform configuration to select startup options, such as primary or secondary chiplet operation and normal or recovery boot. The board and boot firmware define the assignment of those options to pins; the configuration strap section of the Programmer's Guide describes reading them.

2.1.5.5.3.2. Reset Vector

The SEP CPU reset vector is held in a test data register (TDR) in the EL2 debug TAP, selected by JTAG instruction opcode 0x18. The TDR resets to the Boot ROM base address on JTAG reset (TRST assertion or the Test-Logic-Reset TAP state). With that default vector, the CPU starts in the BL0 Root-of-Trust code.

An alternate address shifted into the TDR while the SEP CPU is held in reset redirects the first instruction fetch, which supports bring-up and failure analysis flows that execute from a memory other than the Boot ROM. The TDR stores address bits [31:1]; bit 0 is zero. The programmed value persists until it is rewritten or the TAP is reset; CPU reset alone

does not restore the default. The Programmer's Guide gives the redirect procedure.

2.1.5.5.4. System Interfaces

2.1.5.5.4.1. DMA Interface

The DMA engine is described under Peripherals: Direct Memory Access (DMA)

2.1.5.5.5. Debug

The VeeR EL2 debug module is reached from the DTP SEP debug STAP through the core's JTAG TAP. TAP access is already gated by lifecycle state, so the DMI core aperture is left enabled at the SMU and does not take a second lifecycle check. The DMI uncore aperture is unused: the debug module's AXI master already reaches the rest of the SEP fabric.

2.1.5.5.6. Alarm Aggregation Processor (AGP)

The AGP is a proposed addition for a later SEP generation, aimed at edge applications such as automotive and robotics. It is not implemented in the first-generation SEP.

The proposed CPU-programmed monitor would collect and filter alarm events, detect suspected attacks and request countermeasures: wiping sensitive state or resetting selected components, subsystems or the SEP. These are future capabilities, not available alarm-response controls in the current integration.

2.1.5.5.7. Memory Map and Register Reference

2.1.5.5.7.1. Memory Map

The SEP subsystem memory map gives the base addresses of the CPU-control and scratch banks. Offsets below are relative to the CPU-control block base. The detailed map describes the memory-mapped SEP CPU-control registers; RISC-V core CSRs such as `pmpcfg` and `mrac` are accessed by CSR instructions. The scratch-bank register layout appears under Local Memory above.

2.1.5.5.7.2. Detailed Register Map

2.1.5.5.7.2.1. SEP CPU Control Address Map

SEP CPU control and status registers: PKA and crypto configuration, boot and fast-memory enables, fuse-sense status, and interrupt controls.

Table 20. SEP CPU Control Address Map register list

Address	Name	Access	Description
0x8	CLOCK_GATE_CTRL	RW	TODO: clock-gate control - placeholder fields, not yet implemented.
0x10	REFERENCE_COUNTER	RW	-
0x18	TIMEOUT_INTERRUPT	R	Reserved - per-block timeout interrupt not yet implemented.
0x20	PKA_CTRL	RW	TODO: PKA control - placeholder fields, not yet implemented.
0x28	TIMEOUT_COUNT_DMA	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x30	TIMEOUT_COUNT_SYS_IN	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x38	TIMEOUT_COUNT_MAILBOX_INBOUND	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x40	TIMEOUT_COUNT_MAILBOX_OUTBOUND	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x48	TIMEOUT_COUNT_ENTROPY_WRITE	RW	Reserved - per-block timeout count/threshold not yet implemented.

Address	Name	Access	Description
0x50	TIMEOUT_COUNT_ENTROPY_READ	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x58	TIMEOUT_COUNT_FILTER_OUT	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x60	TIMEOUT_COUNT_ALIAS_REMAP	RW	Reserved - per-block timeout count/threshold not yet implemented.
0x68	TIMEOUT_ENABLE	RW	Reserved - per-block timeout enable not yet implemented.
0x70	TIMEOUT_CLEAR	W	Reserved - per-block timeout interrupt-clear not yet implemented.
0x78	TIMEOUT_MODE	W	Reserved - per-block timeout mode not yet implemented.
0xB0	SEP_TEST_CTRL	R	-
0xC0	SEP_GLOBAL_BASE_ADDR	RW	-
0xC8	SEP_LOCAL_BASE_ADDR	RW	-
0xD0	SEP_REGION_SIZE	RW	-
0x100	SMU_GLOBAL_BASE_ADDR	RW	-
0x110	SMU_REGION_SIZE	RW	-
0x140	SMC_FUSE_SENSE_STATUS	R	-
0x150	SEP_FUSE_SENSE_STATUS	R	-
0x178	SEP_SW_DEBUG	RW	-
0x180	SEP_NMI_VEC	RW	NMI vector address for VeeR-EL2 CPU. The default value is 0xC000_0100. The NMI interrupt is used for the WDT Bark interrupt. **WARNING** the reset value is a placeholder, not a usable handler. Firmware must program this register with the address of its own NMI handler, and then set SEP_NMI_VEC_LOCK, before enabling any NMI source (the WDT bark in particular). If a bark arrives while the reset value is still in place, the CPU jumps to 0xC000_0100 in ICCM and executes whatever is there: arbitrary instructions if the loaded image covers that location, or an uncorrectable ICCM ECC error (which itself re-raises NMI) if it does not.
0x188	SEP_NMI_VEC_LOCK	RW	Lock the NMI vector address. Once locked, the NMI vector address cannot be changed. The NMI interrupt is used for the WDT Bark interrupt.
0x190	EXT_TRNG_SRC_SEL	RW	Per-stream external TRNG source selection for crypto subsystem entropy muxes.
0x198	EXT_TRNG_SRC_SEL_LOCK	RW	Lock the TRNG source selection. Once locked, EXT_TRNG_SRC_SEL cannot be changed until reset.
0x1A0	KM_WIPE_CTRL	RW	Key Manager emergency wipe control.
0x1A8	DMA_BUS_ERR_STATUS	R	Secure DMA bridge fault status. Each bit is latched in hardware and held until the corresponding DMA_BUS_ERR_CLEAR write. These bits also drive dedicated PIC sources. Neither bit is cleared by a CPU-only reset (the WDT resets the CPU without resetting the DMA), so a bit read as set immediately after boot may describe a fault from before that reset rather than a new one.
0x1B0	DMA_BUS_ERR_CLEAR	W	Clear the DMA_BUS_ERR_STATUS bits. Writing 1 emits a single-cycle clear pulse to both latches. A fault arriving in the same cycle as the clear still latches, so acknowledging cannot drop a concurrent fault.

Address	Name	Access	Description
0x1B8	PERIPH_BUS_ERR_STATUS	R	Peripheral register-bridge fault status, one bit per block. Each bit latches when a CPU access to that block's registers returned a TL-UL error response (unmapped or misaligned offset), and is held until the matching PERIPH_BUS_ERR_CLEAR bit is written. The faulting access also received SLVERR synchronously. All bits OR together into a single PIC source, so read this register to identify which block faulted. No bit is cleared by a CPU-only reset (the WDT resets the CPU without resetting the peripherals), so a bit read as set immediately after boot may describe a fault from before that reset rather than a new one.
0x1C0	PERIPH_BUS_ERR_CLEAR	W	Clear PERIPH_BUS_ERR_STATUS bits. Writing 1 to a bit emits a single-cycle clear pulse to that block's latch; bit order matches PERIPH_BUS_ERR_STATUS. Clears are per-block so acknowledging one block cannot discard a fault another block raised between the status read and this write. A fault arriving in the same cycle as its own clear still latches.
0x1000	SEP_VERSION_ID	R	-

2.1.5.5.7.2.1.1. CLOCK_GATE_CTRL

Table 21. sep_cpu_ctrl.CLOCK_GATE_CTRL fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	pka_cg_enable	RW	0x0	Reserved - PKA clock-gate enable, not yet implemented.

2.1.5.5.7.2.1.2. REFERENCE_COUNTER

Table 22. sep_cpu_ctrl.REFERENCE_COUNTER fields

Bits	Field	Access	Reset	Description
63:0	rc	RW	0x0	SEP REFERENCE COUNTER, counting after deassert of cold reset. Write once, then poll this register until the readback reflects the written value before writing again. The counter keeps advancing, so the readback is at or just above the written value rather than equal to it.

2.1.5.5.7.2.1.3. TIMEOUT_INTERRUPT

Table 23. sep_cpu_ctrl.TIMEOUT_INTERRUPT fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	R	0x0	Reserved - timeout interrupt status not yet implemented.

2.1.5.5.7.2.1.4. PKA_CTRL

Table 24. sep_cpu_ctrl.PKA_CTRL fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	pka_noise_src_valid	RW	0x0	Reserved - PKA noise source valid, not yet implemented.
1	pka_noise_src	RW	0x0	Reserved - PKA noise source select, not yet implemented.

Bits	Field	Access	Reset	Description
0	pka_dpa_disable	RW	0x0	Reserved - disable DPA countermeasures in PKA, not yet implemented.

2.1.5.5.7.2.1.5. TIMEOUT_COUNT_DMA

Table 25. sep_cpu_ctrl.TIMEOUT_COUNT_DMA fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.6. TIMEOUT_COUNT_SYS_IN

Table 26. sep_cpu_ctrl.TIMEOUT_COUNT_SYS_IN fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.7. TIMEOUT_COUNT_MAILBOX_INBOUND

Table 27. sep_cpu_ctrl.TIMEOUT_COUNT_MAILBOX_INBOUND fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.8. TIMEOUT_COUNT_MAILBOX_OUTBOUND

Table 28. sep_cpu_ctrl.TIMEOUT_COUNT_MAILBOX_OUTBOUND fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.9. TIMEOUT_COUNT_ENTROPY_WRITE

Table 29. sep_cpu_ctrl.TIMEOUT_COUNT_ENTROPY_WRITE fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.10. TIMEOUT_COUNT_ENTROPY_READ

Table 30. sep_cpu_ctrl.TIMEOUT_COUNT_ENTROPY_READ fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.11. TIMEOUT_COUNT_FILTER_OUT

Table 31. sep_cpu_ctrl.TIMEOUT_COUNT_FILTER_OUT fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.12. TIMEOUT_COUNT_ALIAS_REMAP

Table 32. sep_cpu_ctrl.TIMEOUT_COUNT_ALIAS_REMAP fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout count not yet implemented.

2.1.5.5.7.2.1.13. TIMEOUT_ENABLE

Table 33. sep_cpu_ctrl.TIMEOUT_ENABLE fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	RW	0x0	Reserved - timeout monitors not yet implemented.

2.1.5.5.7.2.1.14. TIMEOUT_CLEAR

Table 34. sep_cpu_ctrl.TIMEOUT_CLEAR fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	W 1P	0x0	Reserved - timeout monitors not yet implemented.

2.1.5.5.7.2.1.15. TIMEOUT_MODE

Table 35. sep_cpu_ctrl.TIMEOUT_MODE fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	reserved	W	0x0	Reserved - timeout monitors not yet implemented.

2.1.5.5.7.2.1.16. SEP_TEST_CTRL

Table 36. sep_cpu_ctrl.SEP_TEST_CTRL fields

Bits	Field	Access	Reset	Description
31	fast_spi_en	R	0x0	Fast SPI Enable
30	fast_iccm_en	R	0x0	Fast ICCM Enable
29	fast_dccm_en	R	0x0	Fast DCCM Enable
28	fast_sram_en	R	0x0	Fast SRAM Enable
27	fast_pka_en	R	0x0	Fast PKA Enable
26	sep_standalone	R	0x0	SEP is standalone (not part of eg SMU)

Bits	Field	Access	Reset	Description
25:0	Reserved	-	-	Reserved

2.1.5.5.7.2.1.17. SEP_GLOBAL_BASE_ADDR

Table 37. sep_cpu_ctrl.SEP_GLOBAL_BASE_ADDR fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	addr	RW	0x0	-

2.1.5.5.7.2.1.18. SEP_LOCAL_BASE_ADDR

Table 38. sep_cpu_ctrl.SEP_LOCAL_BASE_ADDR fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	addr	RW	0xD0000000	-

2.1.5.5.7.2.1.19. SEP_REGION_SIZE

Table 39. sep_cpu_ctrl.SEP_REGION_SIZE fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	size	RW	0x1000000	-

2.1.5.5.7.2.1.20. SMU_GLOBAL_BASE_ADDR

Table 40. sep_cpu_ctrl.SMU_GLOBAL_BASE_ADDR fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	addr	RW	0x80000000	-

2.1.5.5.7.2.1.21. SMU_REGION_SIZE

Table 41. sep_cpu_ctrl.SMU_REGION_SIZE fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	size	RW	0x40000000	-

2.1.5.5.7.2.1.22. SMC_FUSE_SENSE_STATUS

Table 42. sep_cpu_ctrl.SMC_FUSE_SENSE_STATUS fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
0	smc_fuse_sense_done	R	0x0	This bit indicates when SMC's fuse sense is completed. While fuse sense if ongoing, SMC fabric will be in reset. Any requests to the SMC will hang. When this is 1, it is safe to send requests to the SMC.

2.1.5.5.7.2.1.23. SEP_FUSE_SENSE_STATUS

Table 43. sep_cpu_ctrl.SEP_FUSE_SENSE_STATUS fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	sep_fuse_sense_done	R	0x0	This reg is used to indicate the fuse sense status of SEP.

2.1.5.5.7.2.1.24. SEP_SW_DEBUG

Table 44. sep_cpu_ctrl.SEP_SW_DEBUG fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	sep_sw_debug	RW	0x0	software writtable debug information. This reg is routed to CLA

2.1.5.5.7.2.1.25. SEP_NMI_VEC

Table 45. sep_cpu_ctrl.SEP_NMI_VEC fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:1	nmi_vec	RW	0x60000080	NMI vector address [31:1] for VeeR-EL2 CPU. Bit 0 is always 0 (aligned). Address where CPU jumps on Non-Maskable Interrupt. This is used for the WDT Bark interrupt. The reset value does not point at a valid handler — see the register description for the required programming order.
0	rsvd	R	0x0	Reserved, bit 0 is always 0 (aligned)

2.1.5.5.7.2.1.26. SEP_NMI_VEC_LOCK

Table 46. sep_cpu_ctrl.SEP_NMI_VEC_LOCK fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	lock	RW1S	0x0	Lock the NMI vector address. Once locked, the NMI vector address cannot be changed. The NMI interrupt is used for the WDT Bark interrupt.

2.1.5.5.7.2.1.27. EXT_TRNG_SRC_SEL

Table 47. sep_cpu_ctrl.EXT_TRNG_SRC_SEL fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2:0	sel	RW	0x7	TRNG source select per stream. Bit N selects the source for stream N (bit0 = Key Manager, bit1 = crypto blocks, bit2 = entropy pool). 0 = internal DRBG output, 1 = external TRNG (default).

2.1.5.5.7.2.1.28. EXT_TRNG_SRC_SEL_LOCK

Table 48. sep_cpu_ctrl.EXT_TRNG_SRC_SEL_LOCK fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	lock	RW1S	0x0	Lock TRNG source selection. Once set, cannot be cleared by software.

2.1.5.5.7.2.1.29. KM_WIPE_CTRL

Table 49. sep_cpu_ctrl.KM_WIPE_CTRL fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	wipe_state	RW	0x0	Key Manager wipe state. A rising edge zeroes all KPV entries and sets the WIPE_STATE interrupt status.

2.1.5.5.7.2.1.30. DMA_BUS_ERR_STATUS

Table 50. sep_cpu_ctrl.DMA_BUS_ERR_STATUS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	host_path_err	R	0x0	DMA-master-path fault: either the fabric returned a non-OKAY AXI response to a DMA transfer, or a TL-UL command-integrity check failed on a command issued by the DMA. The latter is a fault-detection event with no other reporting path.
0	reg_path_err	R	0x0	Register-path bus error: a CPU access to a Secure DMA register returned a TL-UL error response (unmapped or misaligned offset). The faulting access also received SLVERR synchronously.

2.1.5.5.7.2.1.31. DMA_BUS_ERR_CLEAR

Table 51. sep_cpu_ctrl.DMA_BUS_ERR_CLEAR fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	clr	W 1P	0x0	Write 1 to clear both DMA_BUS_ERR_STATUS bits. Always reads 0.

2.1.5.5.7.2.1.32. PERIPH_BUS_ERR_STATUS

Table 52. sep_cpu_ctrl.PERIPH_BUS_ERR_STATUS fields

Bits	Field	Access	Reset	Description
63:7	Reserved	-	-	Reserved
6	wdt	R	0x0	Watchdog timer register bridge error.
5	edn	R	0x0	EDN register bridge error (DRBG EDN path).
4	csrng	R	0x0	CSRNG register bridge error (DRBG CSRNG path).
3	otbn	R	0x0	OTBN register bridge error.
2	kmac	R	0x0	KMAC register bridge error.
1	hmac	R	0x0	HMAC register bridge error.
0	aes	R	0x0	AES register bridge error.

2.1.5.5.7.2.1.33. PERIPH_BUS_ERR_CLEAR

Table 53. sep_cpu_ctrl.PERIPH_BUS_ERR_CLEAR fields

Bits	Field	Access	Reset	Description
63:7	Reserved	-	-	Reserved
6	wdt	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.wdt. Always reads 0.
5	edn	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.edn. Always reads 0.
4	csrng	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.csrng. Always reads 0.
3	otbn	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.otbn. Always reads 0.
2	kmac	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.kmac. Always reads 0.
1	hmac	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.hmac. Always reads 0.
0	aes	W 1P	0x0	Write 1 to clear PERIPH_BUS_ERR_STATUS.aes. Always reads 0.

2.1.5.5.7.2.1.34. SEP_VERSION_ID

Table 54. sep_cpu_ctrl.SEP_VERSION_ID fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	version_id	R	0xDEADBEEF	Version ID for the CPU

2.1.5.6. Boot ROM

The SEP maps a 64 KiB immutable Boot ROM aperture at `0x1004_0000` through `0x1004_FFFF`. The SEP CPU wrapper sets the VeeR EL2 `RESET_VEC` parameter to the base of this region, so a cold boot begins in the BL0 Root-of-Trust firmware.

2.1.5.6.1. ROM Architecture

The CPU instruction-fetch and load/store interfaces reach the Boot ROM over a dedicated path outside the SEP local AXI crossbar. The SEP ROM interface shim converts the CPU memory request into the request, 64-bit word address, and read-data signals used by the ROM macro. Stores receive a response but are not forwarded to the macro and do not modify the ROM.

The open integration instantiates a 16K-by-64-bit generic ROM, a physical 128 KiB array. The generated SEP address map and production linker expose only the first 64 KiB. The unused physical capacity is not part of the BL0 software address contract.

The ROM stores executable code, immutable metadata, read-only data, and the initial image of writable data; writable data, the stack and the BL0-to-BL1 state run from the 128 KiB DCCM at `0xC004_0000`. The memory and security section of the SEP Boot ROM appendix in the Programmer's Guide gives the linker layout.

BL0 stages the selected manifest and payload in SEP SRAM beginning at `0x1000_0000`. A validated SEP BL1 image is copied by the secure DMA to the 256 KiB ICCM at `0xC000_0000`, where the instruction-fetch unit executes it. The CPU load/store unit cannot access ICCM, so BL0 cannot populate it with an ordinary software copy.

2.1.5.6.2. Hardware Configuration and Integrity

A future ROM patching facility using OTP backup storage is planned for the second generation; it is not implemented in the first generation.

The open generic ROM model has a 64-bit data path and no ECC or integrity-error sideband. Technology-specific integrity behavior is therefore outside this integration's visible hardware contract.

2.1.5.6.3. Boot Flow

The production BL0 firmware selects SPI flash or an SMC-staged image from the captured boot straps. It validates the manifest, applies the lifecycle and secure-boot policy, checks the payload, locks sensitive fuse reads, and transfers control to BL1. The SEP Boot ROM appendix of the Programmer's Guide describes that behavior and its build artifacts in detail.

2.1.5.6.3.1. BL0 Secure Boot and BL1 Execution Unlock

BL0 brings the SEP into a runnable state after power-on reset, validates a boot manifest and its payload, unlocks BL1 execution in the CPU PMP and jumps to it. Any failed check ends the boot: a failure the backup manifest slot recovers from is a warning, and exhausting every slot leaves the processor in a fail loop until reset. The ordered steps (CPU and PMP setup, fuse and lifecycle evaluation, SMC synchronization, boot-source selection, manifest and payload validation, secure boot, demotion, attestation and hand-off), their requirement identifiers and the implementation-status matrix are in the SEP Boot ROM appendix of the Programmer's Guide.

2.1.5.6.4. Firmware Reference

The production ROM firmware is documented in the SEP Boot ROM appendix of the Programmer's Guide.

2.1.5.7. Interconnect

SEP uses a hierarchical AXI4 crossbar fabric. Masters initiate transactions; slaves connect directly or through bridges for AXI4-Lite and OpenTitan TL-UL interfaces. The `axi_to_axi_lite` bridge splits bursts into individual transactions and retains the AXI IDs needed for responses; register regions accept single beats only (Section 2.1.5.12.2). Write strobes remain available on AXI4-Lite; `axi_lite_to_tlul` translates them into TL-UL byte masks. Each peripheral's register definition determines which writes are permitted.

2.1.5.7.1. Topology

2.1.5.7.1.1. Top Level AXI4

Figure 15 shows the crossbar connectivity implemented in `hw/sys/sep/rtl/crossbars/sep_local_axi_xbar.sv`, along with the dedicated Boot ROM path that lies outside the crossbar. The crossbar has five initiators (CPU IFU, CPU LSU, CPU DBG, DMA, and the System Interface) and ten targets. The CPU masters and the DMA issue single-beat transactions only; the System Interface may issue bursts.

A few access paths are intentionally outside this crossbar:

- **Boot ROM** is accessed by the CPU IFU and LSU through a dedicated point-to-point path, not through this crossbar.
- The CPU's own **ICCM/DCCM** are tightly coupled to the core and are not reached through this crossbar by the IFU/LSU. The **CPU TCM** target below is a backdoor AXI path into the ICCM/DCCM, used by the DMA engine to preload code/data.
- The *Alarm AGP is a feature deferred to the next generation* and is not present.

The **System Periph** target aggregates the System Bus interface, the dual scratch register bank, the AP/STEE remap regions, and the outbound routing to SMC/SMN resources.

The **Entropy Pool** target is `sep_entropy_fifo` (0x1095_0000): a 64-bit read-only entropy drain aperture, filled

autonomously by a native EDN endpoint on a separate hardware path (not this crossbar). Writes to it terminate with `BRESP=SLVERR`.

The **SRAM** target serves INCR bursts of every length and single-beat bursts of every type. A multi-beat FIXED or WRAP burst is refused before it reaches the memory: the write terminates with `BRESP=SLVERR` and leaves SRAM unchanged, and every beat of the read returns `RRESP=SLVERR`.

The **System Interface** initiator is the external inbound master. It does not attach to this crossbar directly; it enters SEP through the dedicated `smn_inbound` port and the inbound traffic filter (block-by-default), then through the `sep_system_peripherals` inner crossbar. That inner crossbar reaches the **mailboxes** and **system CSRs** directly, and loops everything else back into this crossbar's System Interface initiator. The inbound filter controls which addresses the external master may reach; it is block-by-default after POR and configured by SEP firmware.

Table 55. SEP AXI4 connectivity terms

Label	Meaning
CPU IFU	CPU instruction-fetch unit; initiates instruction reads.
CPU LSU	CPU load/store unit; initiates data reads and writes.
CPU debug (`dbg`)	CPU debug access path.
DMA	Direct memory access engine; moves data without CPU load/store instructions.
CPU TCM	Tightly coupled memory backdoor: DMA access to the instruction closely coupled memory (ICCM) and data closely coupled memory (DCCM).
SRAM (`sram`)	Static random-access memory used for SEP working storage.
DMA registers (`dma_csr`)	DMA control and status registers.
Watchdog (`sep_wdt`)	Watchdog timer.
Reset controller (`sep_reset_ctrl`)	SEP software reset controller.
Crypto (`sep_crypto`)	Cryptographic accelerators (AES, HMAC, KMAC, OTBN), entropy-source registers, eFuse controller, lifecycle controller, Key Manager mailbox, and external TRNG window.
System peripherals (`sep_system_peripherals`)	System-peripheral routing, remapping, mailboxes and system registers.
SPI host (`sep_io`)	Local input/output peripheral path, including SPI boot-flash access.
Entropy pool (`entropy_fifo`)	Read-only aperture for entropy supplied by the entropy distribution network (EDN).
Extension, eFuse shim (`sep_external`)	Outbound AXI4 port for resources outside the local crossbar; the eFuse shim CSR window is diverted by `u_efuse_shim_demux` to the eFuse wrapper.
SMN inbound (`ext`)	Filtered inbound path from the System Management Network (SMN).
Boot ROM	Read-only boot memory on the dedicated CPU fetch/load path.

Crossbar targets	Initiators				
	CPU IFU ifu_sram	CPU LSU lsu	CPU debug dbg	DMA dma	SMN inbound ext
cpu_tcm (CPU TCM)	—	—	—	●	—
sram (SEP SRAM)	●	●	●	●	●
dma_csr (DMA registers)	—	●	●	—	●
sep_wdt (watchdog)	—	●	●	●	●
sep_reset_ctrl (reset controller)	—	●	●	●	—
sep_crypto (crypto)	—	●	●	●	●
sep_system_peripherals (system peripherals)	—	●	●	●	—
sep_io (SPI host)	—	●	●	●	●
entropy_fifo (entropy pool)	—	●	●	—	●
sep_external (extension, eFuse shim)	—	●	●	●	●
Dedicated path, outside the crossbar					
boot ROM (u_boot_rom_axi_mux)	●	●	—	—	—

● Connected — Not connected

Figure 15. SEP AXI4 connectivity. Filled circles indicate connections; dashes indicate no connection.

2.1.5.7.1.2. Fabric Topology

The input fabric admits external traffic through the inbound filter and system-peripheral decode. The local fabric connects SEP initiators to local resources, while the output fabric selects remapped or direct outbound paths.

In the fabric diagrams, labels such as `ID 3 to 4` give the input and output AXI transaction-ID widths in bits; they do not count ports or data bits. The wider side of the symbol indicates the side with multiple ports. Bus labels identify address and ID widths where they change. The filter wrapper checks reads and writes independently, forwards permitted requests, and routes rejected requests to an AXI error responder.

The input paths are shown in Figure 16, the local resource connections in Figure 17, and the outbound paths in Figure 18. The three figures share one notation. Crossbars are rectangles, muxes and demuxes are trapezoids with the wide side towards the many ports, address remaps are hexagons and traffic filters are octagons. Green boxes are converters: address-width, data-width, ID-width and protocol conversion, and register cuts. Thick lines are AXI4 and thin lines AXI-Lite or TL-UL; every AXI data path is 64 bits wide unless a converter narrows it. The labels give the address and ID widths where they change, and the port badges mark where a path crosses the module boundary.




Figure 16. SEP input fabric

Figure 16 follows a request from the system interconnect through `sep_system_peripherals`. The inbound filter checks it first; while SEP-scope debug is enabled, `SEP_DBG` bypasses the filter. The global-to-local remap then rebases the `SEP_REGION_SIZE` window at `SEP_GLOBAL_BASE_ADDR` to address 0 and passes every other address unchanged. The peripheral crossbar has a second initiator, the `SEP_LOCAL` port of the output fabric's route demux, so local masters reach the mailboxes and system CSRs through the same decode. Addresses outside the mailbox and system CSR windows but below `0x4000_0000` are truncated to 32 bits, their IDs reduced from 7 to 3 bits, and forwarded to the `ext` initiator of the local crossbar. Inside the system CSR windows the crossbar decodes each register block separately and answers the addresses between them with DECERR on reads and writes, as it does any address at or above `0x4000_0000`. The system CSRs program the inbound filter entries and the SEP aperture, as well as the output fabric's remaps and outbound filter.




Figure 17. SEP local fabric

Figure 17 shows the local crossbar with its initiators on the left and its targets on the right, in crossbar port order. Each CPU master and the secure DMA master pass a local alias remap before the crossbar; the remap rewrites the 768 MiB window at `SEP_LOCAL_BASE_ADDR` to `0x1000_0000`. The IFU and LSU demuxes inside `sep_cpu` send boot ROM addresses to the boot ROM mux, which reaches the ROM macro without passing the crossbar, and the IFU demux answers addresses outside the boot ROM and SEP SRAM with DECERR. The chain on each target row is the conversion the target needs: the secure DMA registers and the watchdog are reached as 32-bit TL-UL, and the IO block, reset controller and entropy pool as AXI-Lite. The `sep_external` demux diverts the eFuse shim CSR window to the eFuse wrapper; every other address in the `0x2000_0000` to `0x3FFF_FFFF` aperture leaves SEP on the AXI extension port. Figure 15 gives the initiator-to-target connections.




Figure 18. SEP output fabric

Figure 18 follows local-master traffic that the local crossbar sends to `sep_system_peripherals`. The address is zero-extended from 32 to 56 bits, passes the 16-region alias remap and a register cut, and reaches the route demux. The demux takes the first match in the order shown: the SMC aperture, supplied by the SMC, goes straight to the SMC without filtering; the SMU aperture from `SMU_GLOBAL_BASE_ADDR` and `SMU_REGION_SIZE`, and any address at or above `0x1_0000_0000`, goes to the outbound mux; the AP and STEE regions pass their output remaps, which replace the address with the programmed region offset and set the source ID to `OTHERS`, before the same mux; and every other address returns to the peripheral crossbar of the input fabric. The outbound mux widens the ID from 6 to 8 bits, and the outbound filter, which has no bypass, guards the path to the system interconnect.

2.1.5.7.2. Interfaces

- Memory interfaces: BL0 ROM, DCCM, ICCM, Scratch SRAM, KM SRAM, KM ROM, OTBN IMEM, OTBN DMEM
- Fuse controller interface
- Entropy source interface

- JTAG interfaces
- *RAS Interface - Alarm Processor is deferred to next generation*

2.1.5.7.3. Address Remapping

Sixteen remap regions are available, each supported by an address remapper. Remappers define the following attributes:

- Input address range
- Remapped output address offset
- AxCACHE value, which replaces the transaction's own on a hit

The programmable remap regions accomplish several jobs. First, they expand local 32-bit addresses to the global 56-bit address space. Second, they provide software-programmed translation and cacheability attributes for locally initiated transactions. Out of reset, these programmable remap entries are invalid and therefore behave as transparent pass-through entries until firmware programs them.

After the alias remap, traffic routing is done as follows:

- External or cross-subsystem traffic reaches SEP through the global aperture described by `SEP_GLOBAL_BASE_ADDR` and `SEP_REGION_SIZE`. The current `SEP_REGION_SIZE` reset is `0x0100_0000` (16 MiB); the runtime value is software-programmed to match the chiplet map.
- SEP CPU local-alias traffic is an internal CPU-side view of the SEP map. It exists so software can use high alias addresses such as `0xD000_0000` for resources whose direct internal addresses begin at `0x1000_0000`. This high local alias span has a fixed SEP-local size of 768 MiB.
- Any transaction that doesn't get routed to local resources is directly routed out to the SMN.

Both the chiplet ID and chiplet BAR are available in SMC as MMRs. The Programmer's Guide gives the aperture programming sequence.

2.1.5.7.4. Filtering and Protection

Both SEP filters are instances of the common `axi_filter_wrap` block. The inbound filter has 16 entries and the outbound filter has 32; each entry is one `filter_ctrl` register triple (`FILTER_CONFIG`, `START_ADDR`, `END_ADDR`). Both carry 56-bit addresses on a 64-bit data bus, both enable NS and source ID matching, and both block traffic that matches no entry.

The inbound filter is bypassed in its entirety, admitting all inbound traffic, while SEP-scope debug is enabled; see Section 2.1.5.10.4.3.1 for the `SEP_DBG` control. The outbound filter has no bypass and is always in effect.

Register regions accept single-beat accesses only (Section 2.1.5.12.2), so an inbound entry covering one with `allow_burst` set admits bursts the target rejects. The Programmer's Guide gives the filter programming rules.

The decode algorithm — entry priority, the match conditions, the address range granule and its widening direction, and the response returned to a blocked initiator — is common to SEP and SMC. It is documented once with the IP in AXI Traffic Filter.

2.1.5.7.5. Routing




Figure 19. SEP system-peripheral traffic management

Figure 19 illustrates the AXI4 traffic management performed by the system peripherals block. Its left edge faces the SEP local crossbar and its right edge the SMU; the upper lane is the outbound path and the lower lane the inbound path, drawn in the notation of Section 2.1.5.7.1.2. The figure is an overview: Figure 18 and Figure 16 give every element with its instance name and address window. The AXI4 subordinate port on the left is driven by the local masters that the local crossbar connects to it: the CPU LSU, the CPU debug master and the secure DMA. Traffic may be local to the SEP or outbound to external resources either within the SMU or beyond the SMU. Traffic beyond the SMU to the rest of the chiplet or remote chiplets will bridge to the system NOC also known as the SMN.

2.1.5.7.5.1. Transaction Routing

Local SEP resources include peripheral CSRs, SRAM and the AP- and STEE-controlled remappers. SEP CPU direct addresses, the CPU local-alias view and the external global aperture are distinct views, as described in Address Remapping.

Neighboring SMC resources are accessed through the SMC global aperture programmed by SMC firmware and supplied to SEP/SMU integration logic. That aperture is independent from the SEP CPU local-alias range.

Traffic not routed to local SEP or neighboring SMC resources goes to the SMN system NoC, either through the AP- or STEE-controlled remappers, which external software such as the Ascalon AP controls, or through the direct SMN path.

SEP outbound traffic carries a source ID in AxUSER. Both AP- and STEE-controlled remappers replace it with `OTHERS`. Other traffic retains the initiator's ID: the CPU masters drive SEP's ID, while the secure DMA master leaves AxUSER at zero (`OTHERS`). AxPROT, including NS, passes unchanged; the initiators' values are in Table 14. The outbound filter checks address, NS and source ID after remapping. The Programmer's Guide describes how to select the outbound path and restrict `OTHERS` traffic.

The inbound filter blocks traffic by default. Its entries reside in the system CSRs, reached directly by local masters and by external masters only through an enabled inbound filter entry (or the stated SEP debug bypass). Matching rules are in Filtering and Protection.

See Mailboxes under Peripherals for host mailbox operation.

2.1.5.7.6. Memory Map and Register Reference

2.1.5.7.6.1. Memory Map

The Memory Map chapter lists the address windows. The common AXI Traffic Filter reference describes the filter register layout and programming rules.

Memory Map; AXI Traffic Filter.

2.1.5.7.6.2. Detailed Register Map

See the owning register references linked above.

2.1.5.8. Interrupts

2.1.5.8.1. Controllers

The SEP integrates a VeeR EL2 core with a built-in **Programmable Interrupt Controller (PIC)**. All maskable external interrupt sources feed a single `extintsrc_req` bus; the memory-mapped `meipl`, `meie`, and `meigwctrl` registers configure priority, enable, and gateway polarity per source.

The PIC base address is `0xC008_0000`; its register layout is described in the Register Interfaces section below.

2.1.5.8.2. Sources and Routing

The vector driven to the core, `sep_internal_interrupts`, is indexed from 0. Bit `i` of that vector is PIC source `i + 1`. The core's `extintsrc_req` port is numbered from 1, and the core ties source 0 to zero, so the low bit of the driven vector is the first programmable source. The comment directly above `NUM_INTERNAL_IRQS` in `sep_pkg.sv` numbers sources by that vector index, one less than the PIC source in Table 56.

2.1.5.8.2.1. SEP CPU Interrupt Vector Map

The PIC supports 255 external sources. Slots 1–43 are individually assigned to specific peripherals and subsystems connected to the SEP, including both SEP-internal blocks (crypto engines, DMA, entropy) and cross-block sources (SMC mailboxes, SPI). Slots 44–255 are reserved for chip-level external inputs passed in at the SEP block boundary.

Table 56 lists the assigned PIC sources and the range reserved for chip-level inputs.

Table 56. SEP PIC source assignments

PIC source	Source	Description
1	Mailbox interrupt 0	SMC-to-SEP mailbox channel 0 interrupt
2	Mailbox interrupt 1	SMC-to-SEP mailbox channel 1 interrupt
3	Mailbox interrupt 2	SMC-to-SEP mailbox channel 2 interrupt
4	Mailbox interrupt 3	SMC-to-SEP mailbox channel 3 interrupt
5	Mailbox interrupt 4	SMC-to-SEP mailbox channel 4 interrupt

PIC source	Source	Description
6	Mailbox interrupt 5	SMC-to-SEP mailbox channel 5 interrupt
7	Mailbox interrupt 6	SMC-to-SEP mailbox channel 6 interrupt
8	Mailbox interrupt 7	SMC-to-SEP mailbox channel 7 interrupt
9	DMA transfer done	Secure DMA full-transfer-complete interrupt
10	DMA chunk done	Secure DMA chunk-transfer-complete interrupt
11	DMA error	Secure DMA error interrupt
12	DMA alert	Secure DMA aggregated alert (fault)
13	WDT alert	Watchdog timer aggregated alert. Note: the WDT **bark** goes to the NMI pin, not here; see Section 2.1.5.8.2.2.
14	SPI IRQ	SPI host controller interrupt
15	KM mailbox IRQ	Key Manager-to-SEP mailbox interrupt
16	Entropy source IRQ	OpenTitan entropy source interrupt
17	External TRNG IRQ	External TRNG interrupt; driven to zero in the current OSS integration
18	HMAC done	HMAC operation complete interrupt
19	HMAC FIFO empty	HMAC message FIFO empty interrupt
20	HMAC error	HMAC error interrupt
21	KMAC done	KMAC operation complete interrupt
22	KMAC FIFO empty	KMAC message FIFO empty interrupt
23	KMAC error	KMAC error interrupt
24	CSRNG command request done	CSRNG command request complete interrupt
25	CSRNG entropy request	CSRNG entropy request interrupt
26	CSRNG HW instance exception	CSRNG hardware instance exception interrupt
27	CSRNG fatal error	CSRNG fatal error interrupt
28	EDN command request done	Entropy Distribution Network command request complete interrupt
29	EDN fatal error	Entropy Distribution Network fatal error interrupt
30	OTBN done	OpenTitan Big Number Accelerator operation complete interrupt
31	KM unrecoverable error	Key Manager unrecoverable error interrupt; also exported as a SEP output port
32	KM recoverable error	Key Manager recoverable error interrupt; also exported as a SEP output port
33	Crypto alert	Combined OpenTitan crypto alert. SEP has no `alert_handler`; each accelerator has its own `prim_alert_receiver` channel(s) with ping disabled, and those pulses plus integrity-fails share this source. See Section 2.1.5.11.1.
34	Locked field access	eFuse locked-field access violation interrupt
35	Adams Bridge error	Adams Bridge (post-quantum accelerator) error interrupt
36	Adams Bridge notification	Adams Bridge (post-quantum accelerator) operation notification interrupt
37	Entropy pool low	Entropy pool FIFO low-water condition (informational: pool draining faster than filling)
38	Entropy pool fill stall	Entropy pool FIFO fill-path stall (fault: EDN not making progress)
39	Entropy pool pointer fault	Entropy pool FIFO read/write pointer integrity fault (fault). The pool's pointer-integrity check is not built in the current configuration, so this source is tied to zero and never asserts; the slot is assigned anyway so that enabling the check later does not renumber the map. When live it is level-sensitive and holds until a `TRNG_ENTROPY_CLEAR` pool scrub resets the pointers; there is no write-one-to-clear.
40	Token match fault	eFuse token comparator redundancy fault (fault). The OR of the three sticky `TOKEN_MATCH_FAULT` bits. Those bits are software-read-only and clear only on reset, so this source stays asserted; there is no write-one-to-clear.

PIC source	Source	Description
41	DMA register-path bus error	A CPU access to a Secure DMA register returned a TL-UL error response (unmapped or misaligned offset). The faulting access also received SLVERR synchronously. Latched and held until firmware writes DMA_BUS_ERR_CLEAR.clr.
42	DMA host-path integrity/bus fault	Either the fabric returned a non-OKAY AXI response to a DMA transfer, or a TL-UL command-integrity check failed on a command issued by the DMA. The integrity case is a fault-detection event with no other reporting path. Cleared by the same DMA_BUS_ERR_CLEAR.clr write.
43	Peripheral register-bridge fault	The OR of the per-block register-bridge error bits for AES, HMAC, KMAC, OTBN, CSRNG, EDN and the watchdog timer. PERIPH_BUS_ERR_STATUS identifies the block, and PERIPH_BUS_ERR_CLEAR clears one block's bit at a time, so acknowledging one cannot discard another block's fault. See Crypto Register-Bridge Faults.
[44255]	Reserved (external band)	Chip-level external interrupt inputs

2.1.5.8.2.2. Non-PIC Interrupt Paths

Three CPU interrupt pins bypass the EL2 PIC entirely. The core also reports its own memory errors through a path that is neither a pin nor a PIC source; see Section 2.1.5.8.2.2.3.

2.1.5.8.2.2.1. NMI — Watchdog Timer Bark

The VeeR EL2 nmi_int pin is wired to the watchdog timer bark signal from sep_wdt_wrap. When the bark fires, the CPU jumps to the NMI vector address held in the SEP_NMI_VEC register. The SEP_NMI_VEC_LOCK register prevents runtime modification of the vector once locked.

The NMI is non-maskable: it cannot be suppressed by mstatus.MIE or any PIC configuration register.

2.1.5.8.2.2.2. Timer and Software Interrupts

The timer_int and soft_int pins of the VeeR EL2 core are tied to zero at the SMU integration boundary. There is no external CLINT-style delivery path. The external pins drive mip.MTIP and mip.MSIP, respectively, so these pending bits remain inactive in this integration.

The two internal timers instead report mip.MITIP0 (bit 29) and mip.MITIP1 (bit 28). Enable them through mie.MITIE0 and mie.MITIE1 at the corresponding bit positions, together with mstatus.MIE. Their interrupt cause codes are 0x1D and 0x1C, respectively (with the interrupt bit set in mcause). Enabling mie.MTIE or mie.MSIE does not enable the internal timers.

2.1.5.8.2.2.3. Memory ECC Errors

The ICCM and DCCM are SECDED-protected. Neither reaches the PIC: the core reports these errors itself, correctable ones as a local interrupt and uncorrectable ones as a synchronous trap. No PIC register affects either, and there is no PIC source to enable or mask.

The SEP core is configured without an I-cache, so the I-cache parity counter MICECT (0x7F0) never increments. Only the two tightly-coupled-memory counters below are live.

2.1.5.8.2.2.3.1. Correctable (single-bit) errors

Hardware corrects the data and the access is retried, so no data is lost and no trap is taken. Each protected memory has a counter CSR (Table 57).

Table 57. SEP correctable-error counters

CSR	Address	Counts
MICCMECT	0x7F1	ICCM single-bit corrections
MDCCMECT	0x7F2	DCCM single-bit corrections

Bits [26:0] are the running count. Bits [31:27] hold a threshold exponent: the counter raises a request once the count reaches $2^{\text{threshold}}$. A written threshold above 26 is clamped to 26. The requests from both counters are ORed into mip[30] (MCEIP) and delivered when mie[30] (MCEIE) and mstatus.MIE are both set, with mcause = 0x8000_001E.

Counters and thresholds reset to zero, so a zero threshold raises the request on the first corrected error. mie[30] is clear at reset, and until it is set corrected errors are counted silently. MCEIP follows the threshold comparator and has no write-one-to-clear: it stays asserted until the count drops below the threshold. The memory error handling section of the Programmer's Guide gives the enable and service sequence.

2.1.5.8.2.2.3.2. Uncorrectable (double-bit) errors

These cannot be masked and have no enable bit. The access returned no valid data, so the core traps on the instruction that hit the error (Table 58).

Table 58. SEP uncorrectable-error traps

Access	mcause	Trap
Instruction fetch from ICCM	0x0000_0001	Instruction access fault
Load from DCCM	0x0000_0005	Load access fault
Store to DCCM	0x0000_0007	Store access fault
DCCM access on the fast-interrupt path	0xF000_1000	NMI, taken through SEP_NMI_VEC like the watchdog bark

mcause alone does not identify these as memory failures — a bad pointer and a failing SRAM both raise a load access fault. mscause (0x7FF) is what separates them: on an access fault, mscause = 1 means uncorrectable ECC. A handler that does not read mscause cannot distinguish a software bug from failing hardware.

The faulting access cannot be completed, and retrying it re-reads the same corrupted location.

An uncorrectable error on an externally initiated (DMA) access to either memory is not a CPU trap at all. It is returned as an error response on that transaction, and the initiator is responsible for reporting it.

2.1.5.8.2.2.3.3. Debug bus mirror

The ICCM and DCCM single- and double-bit error signals are also mirrored onto ext_debug_bus_o[367:364], most significant first: ICCM single, ICCM double, DCCM single, DCCM double. These are single-cycle pulses with no latch and no handshake, provided for external trace and bring-up observability. They are not a delivery path, so software must not rely on sampling them; use the CSRs above.

2.1.5.8.3. Software Handling

Interrupt source IDs are **1-based** inside the PIC. Source 0 is permanently tied to zero inside the core. Firmware programs source N through the per-source arrays, each indexed at an offset of N * 4 from its region base: meipl at PIC base +0x0000, meie at +0x2000, meigwctrl at +0x4000 and meigwclr at +0x5000. Pending status is the exception — meip at +0x1000 is a bitmap rather than a per-source array, so source N is bit N % 32 of meip[N / 32].

Each per-source array carries an entry 0, so that the array index is the source ID and no off-by-one applies: meipl[7] is source 7. That entry is reserved and has no hardware behind it — the PIC decodes the address but ties the register off, so +0x0000, +0x2000, +0x4000 and +0x5000 read as zero and discard writes. It appears in the RDL, the generated headers and

the UVM RAL only to preserve the indexing. The PIC section of the Programmer's Guide gives the programming and per-source service rules.

NOTE Register tests that walk the whole PIC map must skip index 0 of `meipl`, `meie`, `meigwctrl` and `meigwclr`. The register model declares those entries read-write like every other element, but the hardware treats them as reserved, so a read-write check on them fails.

2.1.5.8.4. Memory Map and Register Reference

2.1.5.8.4.1. Memory Map

The EL2 PIC register block (`meipl`, `meie`, `meigwctrl`, `meigwclr`, and related registers) is documented in the register reference below.

The per-source arrays in that table are listed from index 0. Index 0 is the reserved entry described in Interrupts: it exists so the array index equals the interrupt source ID, and the first programmable source is index 1.

2.1.5.8.4.2. Detailed Register Map

2.1.5.8.4.2.1. EL2_PIC

VeeR EL2 Programmable Interrupt Controller (PIC) memory-mapped registers. Supports up to PIC_TOTAL_INT external interrupt sources with 15 priority levels.

NOTE

Register Arrays:

- **meipl[256]**: 256 registers, base 0x0, stride 0x4
- **meip[8]**: 8 registers, base 0x1000, stride 0x4
- **meie[256]**: 256 registers, base 0x2000, stride 0x4
- **meigwctrl[256]**: 256 registers, base 0x4000, stride 0x4
- **meigwclr[256]**: 256 registers, base 0x5000, stride 0x4

Table 59. EL2_PIC register list

Address	Name	Access	Description
0x0 - 0x3FC	meipl[256]	RW	External Interrupt Priority Level Register. Sets the priority level for an interrupt source.
0x1000 - 0x101C	meip[8]	R	External Interrupt Pending Register. Reports pending status of up to 32 interrupt sources.
0x2000 - 0x23FC	meie[256]	RW	External Interrupt Enable Register. Controls interrupt enable for a single source.
0x3000	mpiccfg	RW	PIC Configuration Register. Used to select the operational parameters of the PIC.
0x4000 - 0x43FC	meigwctrl[256]	RW	External Interrupt Gateway Configuration Register. Controls interrupt type and polarity.
0x5000 - 0x53FC	meigwclr[256]	W	External Interrupt Gateway Clear Register. Writing any value clears the gateway's interrupt pending (IP) bit for edge-triggered interrupts.

2.1.5.8.4.2.1.1. meipl[256]

Table 60. el2_pic.meipl[256] fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3:0	intpriority	RW	0x0	External interrupt priority level: RISC-V standard order: 0=Never interrupt, 1..15=Priority (1 lowest, 15 highest) Reverse order: 15=Never interrupt, 14..0=Priority (14 lowest, 0 highest)

2.1.5.8.4.2.1.2. meip[8]

Table 61. el2_pic.meip[8] fields

Bits	Field	Access	Reset	Description
31:0	intpend	R	0x0	External interrupt pending bits. Bit Y indicates pending status for source X*32+Y. 0: Interrupt not pending 1: Interrupt pending

2.1.5.8.4.2.1.3. meie[256]

Table 62. el2_pic.meie[256] fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	inten	RW	0x0	External interrupt enable: 0: Interrupt disabled 1: Interrupt enabled

2.1.5.8.4.2.1.4. mpiccfg

Table 63. el2_pic.mpiccfg fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	priord	RW	0x0	Priority order: 0: RISC-V standard compliant priority order (0=lowest to 15=highest) 1: Reverse priority order (15=lowest to 0=highest)

2.1.5.8.4.2.1.5. meigwctrl[256]

Table 64. el2_pic.meigwctrl[256] fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	irq_type	RW	0x0	External interrupt type: 0: Level-triggered interrupt 1: Edge-triggered interrupt
0	polarity	RW	0x0	External interrupt polarity: 0: Active-high interrupt 1: Active-low interrupt

2.1.5.8.4.2.1.6. meigwclr[256]

Table 65. el2_pic.meigwclr[256] fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	clear	W	0x0	Write any value to clear the interrupt pending bit in the gateway. This register is write-only; reads return 0.

2.1.5.9. Peripherals

SEP peripherals provide data movement, mailboxes, external I/O and watchdog services. Reset control is described in Clocks and Resets; OTP and lifecycle controls are described in Security and Lifecycle.

2.1.5.9.1. Direct Memory Access (DMA)

The SEP DMA copies data between addressable memories and peripheral registers, with optional inline SHA-256, SHA-384 or SHA-512 hashing. It uses the OpenTitan DMA Controller inside an AXI wrapper. The integration below defines which upstream ports and hardware triggers are available in SEP. The Programmer's Guide gives the programming guidance for this block.

Source and destination addresses independently support incrementing, fixed address and wrap-at-chunk-boundary operation. Use incrementing addresses for memory and a fixed address for a peripheral FIFO. Transfers use 1-, 2- or 4-byte accesses; inline hashing requires 4-byte transfers. The core issues individual TL-UL transactions, so the AXI wrapper does not turn a copy into a burst transfer. Hash results are read from the DMA digest registers.




Figure 20. OpenTitan DMA core and inline hashing reference architecture

Figure 20 shows the upstream DMA core. SEP adapts the host register interface to its AXI fabric as described below.

2.1.5.9.1.1. OCAH Modifications

Figure 21 shows how `sep_dma_wrap` connects the DMA core to the SEP local crossbar. The register path runs left to right along the top and the host path right to left along the bottom; green boxes are converters, and the dashed ports are tied

off.




Figure 21. SEP secure DMA integration

The wrapper exposes separate AXI4 register-slave and DMA-master interfaces, both with 32-bit addresses and 64-bit data. Internally, the register path converts AXI4 to 32-bit AXI4-Lite and then TL-UL; the data path converts the core's TL-UL host port back to AXI4. A local-alias remapper precedes the SEP crossbar and leaves the CPU TCM backdoor range available to DMA.

Address-space ID `0x7` selects the core's internal host port, the only route in this wrapper. The upstream SoC control and system ports are tied off; their ASIDs do not provide additional SEP routes. Reachability is governed by the SEP fabric and filters.

The master path leaves AxUSER at zero and drives AxPROT `0b001` (privileged, secure, data), the value the SEP CPU's LSU drives; TL-UL carries no protection attributes, so the wrapper sets it. The register and host bridges latch faults on `dma_reg_bus_err_o` and `dma_host_intg_err_o`, cleared through `DMA_BUS_ERR_CLEAR`; local alert receivers aggregate the core alerts into `dma_alert_o`. Selecting the tied-off CTN or SYS address space does not complete.

Only handshake input 0 is connected, to the SPI host's LSIO trigger. All other trigger inputs are tied low; SEP does not wire UART or I3C handshake paths. This does not prevent software-initiated accesses to reachable peripheral registers.

2.1.5.9.1.1.1. Completion Reporting

The core reports transaction completion, chunk completion and error separately. Chunk completion applies to multi-chunk transfers without hardware handshake; it is not a per-trigger interrupt in handshake mode. Status completion and error bits are write-one-to-clear; the detailed register map defines each bit. Inline hashing requires 4-byte transfers, and `DIGEST_SWAP` controls byte order within each digest register, not register order. The SEP DMA section of the Programmer's Guide gives the copy, hashing, handshake and abort sequences.

2.1.5.9.1.2. Future Enhancements

The following are proposals, not capabilities of the current SEP integration:

- Inline AES encryption or decryption (with/without inline hashing)
- Inline hashing with only digest written to target slave
- Optimize implementation by using cryptographic resources (AES, HMAC-SHA2) engines inside the cryptographic subsystem and adding streaming interfaces
- Replace the FSM controller with a microsequencer or simple CPU, potentially shared with the Key Manager

2.1.5.9.1.3. Memory Map and Register Reference

2.1.5.9.1.3.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.9.1.3.2. Detailed Register Map

2.1.5.9.1.3.2.1. DMA Controller

DMA Controller for the integrated OpenTitan.

NOTE

Register Arrays:

- **SHA2_DIGEST_0[16]**: 16 registers, base 0x58, stride 0x4
- **INTR_SRC_ADDR_0[11]**: 11 registers, base 0xA4, stride 0x4
- **INTR_SRC_WR_VAL_0[11]**: 11 registers, base 0x124, stride 0x4

Table 66. DMA Controller register list

Address	Name	Access	Description
0x0	INTR_STATE	R	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-
0xC	ALERT_TEST	W	-
0x10	SRC_ADDR_LO	RW	-
0x14	SRC_ADDR_HI	RW	-
0x18	DST_ADDR_LO	RW	-
0x1C	DST_ADDR_HI	RW	-
0x20	ADDR_SPACE_ID	RW	-
0x24	ENABLED_MEMORY_RANGE_BASE	RW	-
0x28	ENABLED_MEMORY_RANGE_LIMIT	RW	-
0x2C	RANGE_VALID	RW	-
0x30	RANGE_REGWEN	RW	-
0x34	CFG_REGWEN	R	-
0x38	TOTAL_DATA_SIZE	RW	-

Address	Name	Access	Description
0x3C	CHUNK_DATA_SIZE	RW	-
0x40	TRANSFER_WIDTH	RW	-
0x44	CONTROL	RW	-
0x48	SRC_CONFIG	RW	-
0x4C	DST_CONFIG	RW	-
0x50	STATUS	RW	-
0x54	ERROR_CODE	R	-
0x58 - 0x94	SHA2_DIGEST_0[16]	R	-
0x98	HANDSHAKE_INTR_ENABLE	RW	-
0x9C	CLEAR_INTR_SRC	RW	-
0xA0	CLEAR_INTR_BUS	RW	-
0xA4 - 0xCC	INTR_SRC_ADDR_0[11]	RW	-
0x124 - 0x14C	INTR_SRC_WR_VAL_0[11]	RW	-

2.1.5.9.1.3.2.1.1. INTR_STATE

Table 67. secure_dma.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	DMA_ERROR	R	0x0	DMA error has occurred. DMA_STATUS.error_code register shows the details.
1	DMA_CHUNK_DONE	R	0x0	Indicates the transfer of a single chunk has been completed.
0	DMA_DONE	R	0x0	DMA operation has been completed.

2.1.5.9.1.3.2.1.2. INTR_ENABLE

Table 68. secure_dma.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	DMA_ERROR	RW	0x0	Enable interrupt when !!INTR_STATE.dma_error is set.
1	DMA_CHUNK_DONE	RW	0x0	Enable interrupt when !!INTR_STATE.dma_chunk_done is set.
0	DMA_DONE	RW	0x0	Enable interrupt when !!INTR_STATE.dma_done is set.

2.1.5.9.1.3.2.1.3. INTR_TEST

Table 69. secure_dma.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	DMA_ERROR	W	0x0	Write 1 to force !!INTR_STATE.dma_error to 1.
1	DMA_CHUNK_DONE	W	0x0	Write 1 to force !!INTR_STATE.dma_chunk_done to 1.
0	DMA_DONE	W	0x0	Write 1 to force !!INTR_STATE.dma_done to 1.

2.1.5.9.1.3.2.1.4. ALERT_TEST

Table 70. secure_dma.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	FATAL_FAULT	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.9.1.3.2.1.5. SRC_ADDR_LO

Table 71. secure_dma.SRC_ADDR_LO fields

Bits	Field	Access	Reset	Description
31:0	SRC_ADDR_LO	RW	0x0	Lower 32 bits of the source address. Must be aligned to the transfer width.

2.1.5.9.1.3.2.1.6. SRC_ADDR_HI

Table 72. secure_dma.SRC_ADDR_HI fields

Bits	Field	Access	Reset	Description
31:0	SRC_ADDR_HI	RW	0x0	Upper 32 bits of the physical or virtual address of memory location within SoC memory address map or physical address within OT non-secure memory space. Must be aligned to the transfer width. Source and destination address must have the same alignment.

2.1.5.9.1.3.2.1.7. DST_ADDR_LO

Table 73. secure_dma.DST_ADDR_LO fields

Bits	Field	Access	Reset	Description
31:0	DST_ADDR_LO	RW	0x0	Lower 32 bits of the destination address. Must be aligned to the transfer width. Source and destination address must have the same alignment.

2.1.5.9.1.3.2.1.8. DST_ADDR_HI

Table 74. secure_dma.DST_ADDR_HI fields

Bits	Field	Access	Reset	Description
31:0	DST_ADDR_HI	RW	0x0	Upper 32 bits of the physical or virtual address of memory location within SoC memory address map or physical address within OT non-secure memory space. Must be aligned to the transfer width. Source and destination address must have the same alignment.

2.1.5.9.1.3.2.1.9. ADDR_SPACE_ID

Table 75. secure_dma.ADDR_SPACE_ID fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:4	DST_ASID	RW	0x7	Target address space that the destination address pointer refers to.
3:0	SRC_ASID	RW	0x7	Target address space that the source address pointer refers to.

2.1.5.9.1.3.2.1.10. ENABLED_MEMORY_RANGE_BASE

Table 76. secure_dma.ENABLED_MEMORY_RANGE_BASE fields

Bits	Field	Access	Reset	Description
31:0	BASE	RW	0x0	Base Address to mark the start of the DMA enabled memory range within the OT internal memory space.

2.1.5.9.1.3.2.1.11. ENABLED_MEMORY_RANGE_LIMIT

Table 77. secure_dma.ENABLED_MEMORY_RANGE_LIMIT fields

Bits	Field	Access	Reset	Description
31:0	LIMIT	RW	0x0	Limit Address to mark the end of the DMA enabled memory range within the OT internal memory space; inclusive.

2.1.5.9.1.3.2.1.12. RANGE_VALID

Table 78. secure_dma.RANGE_VALID fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	RANGE_VALID	RW	0x0	Once set the enabled memory base and limit registers are valid.

2.1.5.9.1.3.2.1.13. RANGE_REGWEN

Table 79. secure_dma.RANGE_REGWEN fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3:0	REGWEN	RW0C	0x6	Used by firmware to lock the DMA enabled memory range configuration registers from further modification. Once this register is set to kMultiBitBool4False, it can only be set to kMultiBitBool4True through a reset event. Default Value = kMultiBitBool4True → Unlocked at reset.

2.1.5.9.1.3.2.1.14. CFG_REGWEN

Table 80. secure_dma.CFG_REGWEN fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3:0	REGWEN	R	0x6	Used by hardware to lock the DMA configuration registers. This register is purely managed by hardware and only software readable.

2.1.5.9.1.3.2.1.15. TOTAL_DATA_SIZE

Table 81. secure_dma.TOTAL_DATA_SIZE fields

Bits	Field	Access	Reset	Description
31:0	DATA_SIZE	RW	0x0	Total size (in bytes) of the data to be transferred. The complete transfer operation may consist of multiple chunks of data as specified by the CHUNK_DATA_SIZE register. Minimum: 1 byte. Maximum: May be restricted to a maximum pre-defined size based on OT DMA enabled memory space allocation. Works in conjunction with the TRANSFER_WIDTH register.

2.1.5.9.1.3.2.1.16. CHUNK_DATA_SIZE

Table 82. secure_dma.CHUNK_DATA_SIZE fields

Bits	Field	Access	Reset	Description
31:0	DATA_SIZE	RW	0x0	Size (in bytes) for a single DMA transfer. In hardware handshake mode, the DMA reads in chunks of CHUNK_DATA_SIZE from the peripheral. For a single memory transfer CHUNK_DATA_SIZE and TOTAL_DATA_SIZE are set to the same value. Minimum: 1 byte. Maximum: May be restricted to a maximum pre-defined size based on OT DMA enabled memory space allocation. Works in conjunction with the TRANSFER_WIDTH register.

2.1.5.9.1.3.2.1.17. TRANSFER_WIDTH

Table 83. secure_dma.TRANSFER_WIDTH fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1:0	TRANSACTION_WIDTH	RW	0x2	Denotes the width of each transaction that the DMA shall issue during the data movement. Multiple transactions of this width will be issued until TOTAL_DATA_SIZE bytes have been transferred. Note that firmware may need to set a different value if a receiving IP supports a read / write transaction width that is less than 1 DWORD. This does not affect the wrap-around mechanism. Note that the value 3 for this register represents an invalid configuration that leads to an error.

2.1.5.9.1.3.2.1.18. CONTROL

Table 84. secure_dma.CONTROL fields

Bits	Field	Access	Reset	Description
31	GO	RW	0x0	Setting this bit triggers the DMA operation. For normal operation, the DMA engine clears the go bit automatically after the configured operation is complete. For Hardware handshake operation, DMA engine does not auto clear the Go bit. Firmware shall clear the Go bit when it intends to stop the hardware handshake operation.
30:28	Reserved	-	-	Reserved
27	ABORT	W	0x0	Aborts the DMA operation if this bit is set. Sets the corresponding bit in the status register once abort operation is complete. Any OpenTitan-internal transactions are guaranteed to complete, but there are no guarantees on the SoC interface.
26:9	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
8	INITIAL_TRANSFER	RW	0x0	Marks the initial transfer to initialize the DMA and SHA engine for one transfer that can span over multiple single DMA transfers. Used for hardware handshake and ordinary transfers, in which multiple transfers contribute to a final digest. Note, for non-handshake transfers with inline hashing mode enabled, this bit must be set to also mark the first transfer.
7:6	Reserved	-	-	Reserved
5	DIGEST_SWAP	RW	0x0	Digest register byte swap. If 1 the value in each digest output register is converted to big-endian byte order. This setting does not affect the order of the digest output registers, !!SHA2_DIGEST_0 still contains the first 4 bytes of the digest.
4	HARDWARE_HANDSHAKE_ENABLE	RW	0x0	Enable hardware handshake mode. Used to clear FIFOs from low speed IO peripherals receiving data, e.g., I3C receive buffer. Listen to an input trigger signal. Read data from source address location. Copy to destination address. Number of bytes specified in size register. Note assumption is the peripheral lowers input once FIFO is cleared. No explicit clearing necessary.
3:0	OPCODE	RW	0x0	Defines the type of DMA operations.

2.1.5.9.1.3.2.1.19. SRC_CONFIG

Table 85. secure_dma.SRC_CONFIG fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	WRAP	RW	0x0	When 0: Chunks occupy contiguous ascending addresses. When 1: Source address wraps back to the starting address when finishing a chunk.
0	INCREMENT	RW	0x0	Defines the increment behavior after every DMA read. When 0: Source address is not changed. All reads are done from the same address. When 1: Source address is incremented by transfer_width after each read.

2.1.5.9.1.3.2.1.20. DST_CONFIG

Table 86. secure_dma.DST_CONFIG fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	WRAP	RW	0x0	When 0: Chunks occupy contiguous ascending addresses. When 1: Destination address wraps back to the starting address when finishing a chunk.
0	INCREMENT	RW	0x0	Defines the increment behavior after every DMA write. When 0: Destination address is not changed. All writes are done to the same address. When 1: Destination address is incremented by transfer_width after each write.

2.1.5.9.1.3.2.1.21. STATUS

Table 87. secure_dma.STATUS fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	CHUNK_DONE	RW1C	0x0	Transfer of a single chunk is complete. Only raised for multi-chunk memory-to-memory transfers. Cleared automatically by the hardware when starting the transfer of a new chunk.

Bits	Field	Access	Reset	Description
4	SHA2_DIGEST_VALID	R	0x0	Indicates whether the SHA2_DIGEST register contains a valid digest. This value is cleared on the initial transfer and set when the digest is written.
3	ERROR	RW1C	0x0	Error occurred during the operation. ERROR_CODE register denotes the source of the error.
2	ABORTED	RW1C	0x0	Set once aborted operation drains.
1	DONE	RW1C	0x0	Configured DMA operation is complete. Cleared automatically by the hardware when starting a new transfer.
0	BUSY	R	0x0	DMA operation is active if this bit is set. DMA engine clears this bit when operation is complete. This bit may be set as long as hardware handshake mode is active and triggered.

2.1.5.9.1.3.2.1.22. ERROR_CODE

Table 88. secure_dma.ERROR_CODE fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ASID_ERROR	R	0x0	The source or destination ASID contains an invalid value.
6	RANGE_VALID_ERROR	R	0x0	The DMA enabled memory range is not configured.
5	BASE_LIMIT_ERROR	R	0x0	The base and limit addresses contain an invalid value.
4	BUS_ERROR	R	0x0	The bus transfer returned an error.
3	SIZE_ERROR	R	0x0	TRANSFER_WIDTH encodes an invalid value, TOTAL_DATA_SIZE or CHUNK_SIZE are zero, or inline hashing is not using 32-bit transfer width
2	OPCODE_ERROR	R	0x0	Opcode is invalid.
1	DST_ADDR_ERROR	R	0x0	Destination address is invalid.
0	SRC_ADDR_ERROR	R	0x0	Source address is invalid.

2.1.5.9.1.3.2.1.23. SHA2_DIGEST_0[16]

Table 89. secure_dma.SHA2_DIGEST_0[16] fields

Bits	Field	Access	Reset	Description
31:0	DATA_0	R	0x0	SHA2 digest data

2.1.5.9.1.3.2.1.24. HANDSHAKE_INTR_ENABLE

Table 90. secure_dma.HANDSHAKE_INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10:0	MASK	RW	0x7FF	Enable bits for incoming handshake interrupt wires.

2.1.5.9.1.3.2.1.25. CLEAR_INTR_SRC

Table 91. secure_dma.CLEAR_INTR_SRC fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10:0	SOURCE	RW	0x0	Source N needs interrupt cleared

2.1.5.9.1.3.2.1.26. CLEAR_INTR_BUS

Table 92. secure_dma.CLEAR_INTR_BUS fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10:0	BUS	RW	0x0	Bus selection bit for source N.

2.1.5.9.1.3.2.1.27. INTR_SRC_ADDR_0[11]

Table 93. secure_dma.INTR_SRC_ADDR_0[11] fields

Bits	Field	Access	Reset	Description
31:0	ADDR_0	RW	0x0	Destination address for interrupt source clearing write.

2.1.5.9.1.3.2.1.28. INTR_SRC_WR_VAL_0[11]

Table 94. secure_dma.INTR_SRC_WR_VAL_0[11] fields

Bits	Field	Access	Reset	Description
31:0	WR_VAL_0	RW	0x0	Write value for interrupt clearing write.

2.1.5.9.2. Mailboxes

Figure 22 shows the host mailbox connections and interrupt routing.




Figure 22. SEP host mailbox architecture and interrupt routing

The mailbox unit takes one AXI-Lite port from the peripheral crossbar, and its demux selects one of sixteen 2 kB port

apertures from address bits 14 to 11. Mailbox *m* occupies the 4 kB at `0x10A0_0000` + *m* × `0x1000`, with its outbound port at offset `0x000` and its inbound port at offset `0x800`. The figure draws mailboxes 0 and 7; mailboxes 1 to 6 are identical. Each mailbox holds two FIFOs of eight 64-bit entries, and `WRITE_DATA` in one port pushes the FIFO that `READ_DATA` in the other port pops. Every port has its own level-sensitive, active-high interrupt. The eight inbound-port interrupts are SEP CPU PIC sources 1 to 8. The eight outbound-port interrupts leave SEP on `smc_mailbox_interrupt_o` and reach the SMC as its peripheral interrupts 7 to 0.

SEP uses mailboxes to exchange service requests with system clients, such as software running on application-processor (AP) cores. A client is the requester whose communication context software wants to keep separate; it need not be an entire processor. The system's firmware policy assigns mailbox apertures to clients and configures the inbound traffic filter to control their access. The hardware does not establish a fixed one-client-per-core allocation.

Each mailbox occupies a 4 KiB aperture and has an inbox/outbox pair. Its privacy depends on the programmed access policy, not on a distinct hardware mailbox type. When the inbox is written, an interrupt is sent to the SEP CPU to notify it of an incoming service request. Similarly, when the outbox is written by the SEP, an interrupt is sent to the SMC. The outbox is only used for communication with AP cores. For all other resources we only use inboxes on both ends of the transaction.

The SEP mailboxes have 64-bit data registers while SEP is a 32-bit system. Registers sit on an 8-byte stride and are decoded by which 8-byte slot the address falls in, so a register's low and high halves alias to the same register. The SEP CPU is RV32 and can reach only one half per instruction, which makes every half-word access a full-register access at the mailbox:

- A read of `READ_DATA` at either half pops one FIFO entry. The mailbox drives the whole entry; the CPU keeps the half selected by address bit 2 and discards the other. Reading both halves consumes two entries.
- A write of `WRITE_DATA` at either half pushes one entry, with bytes outside the write strobe pushed as zero. A 32-bit store to the low half enqueues `{32'h0, data}`.

SEP can use either half, but never both halves of one entry, so a SEP-visible payload is 32 bits per entry and both ends must agree on which half carries it. SEP firmware uses the low half at the register base offset.

NOTE This depends on the mailbox aperture staying side-effect in `mrac`. Clearing side-effect enables the core's load-to-load forwarding and speculative accesses, both of which pop entries unpredictably. The Programmer's Guide lists it among the mailbox usage rules.

Mailbox type is a configuration, not a hardware variant. Every mailbox is an identical instance of the same block; what makes one an ISS mailbox and another an STEE or Regular mailbox is the inbound traffic filter entry that covers its 4 kB aperture. The filter blocks by default, so a mailbox with no enabled entry over its aperture is unreachable from the fabric, and reprogramming an entry retypes that mailbox at run time. An entry pairs an address range with the qualification criteria below, plus separate read and write permissions and a write-once lock bit. See Filtering and Protection for the SEP filter instances and AXI Traffic Filter for the entry registers and the decode algorithm used to program them.

Table 95 describes the traffic qualifications used to distinguish mailbox types.

Table 95. SEP mailbox qualification

Mailbox Type	Description
ISS	Uses fabric source ID to qualify incoming transactions. Legal source ID is programmable, lockable and reset by SEP reset.
STEE	Relies on STEE indicator in the transactions (NS bit) to qualify incoming transactions.
DTEE	Reserved. Would rely on the DTEE indicator in the transactions (confidential bit) to qualify incoming transactions. TODO: Confidential bit will be defined in future revisions, right now there is no hardware to qualify this.

Mailbox Type	Description
Regular	Relies on PMA/PMP or page table for protection. No special action required by SEP.

2.1.5.9.3. Peripheral Subsystem

SEP reaches the serial-I/O peripherals in SMC over a dedicated AXI4 port, `sep_ext_to_smc_axi_req_o`, split off by the route demux in `sep_system_peripherals` and wired to SMC's `sep_axi_in`. It reaches every SMC local target without passing the SEP outbound filter. SEP also has a local SPI host for boot-flash access. The SPI chapter describes that controller; SMC documents the shared peripherals.

SEP boot uses configuration straps, which it reads from the SMC strap registers. For their role in selecting boot options, see Configuration Straps and BL0 Boot Flow.

Figure 23 shows the connection from SEP to peripherals shared with SMC.




Figure 23. SEP peripheral extension port

The figure reads from the SEP local crossbar outwards. The SPI host sits behind the `sep_io` target, which downsizes the 64-bit AXI4 request to 32 bits and converts it to AXI-Lite; the quad SPI signals leave for the SPI pads. The local crossbar sends only the SPI host register extent to `sep_io` and answers the rest of its aperture with DECERR on reads and writes. The error responder in `sep_io` answers only the beats of a burst that run past the extent. Requests in the SMC aperture take the route demux of `sep_system_peripherals` (see Figure 18) onto the SMC port, which the SMU wires directly to the SMC's `sep_axi_in` port with no crossbar and no clock-domain crossing. The SMC flow is drawn right to left. The SMC input fabric passes addresses in the SMC local or global window, truncated to 32 bits, and answers others with DECERR. The SMC local fabric rebases them onto the SMC local base, and the `sep_in` initiator of the SMC local crossbar reaches

every target, including the peripheral port, which is converted to 32-bit AXI-Lite for the SMC peripheral crossbar. The UART, I2C and AVSBus controllers sit behind clock-domain crossings into the peripheral clock.

2.1.5.9.4. Serial Peripheral Interface (SPI)

SEP instantiates one OpenTitan SPI Host for software-controlled access to external devices. NOR flash is the primary source of the BL1 boot image. The controller uses commands and transmit/receive FIFOs; it does not provide a memory-mapped flash window for execute-in-place (XIP) access.

2.1.5.9.4.1. Use Cases

- Read the BL1 boot image from external NOR flash.
- Connect to sensors, particularly in automotive applications.

The intended flash interface uses the x1 and x4 modes of MT25-class devices. The host cannot drive the octal x8 DDR interface of MT35-class devices. Select a flash device and command protocol compatible with the supported modes below.

2.1.5.9.4.2. Features

Table 96. Features

Capability	SEP implementation
Transfer width	Standard (x1), dual (x2) and quad (x4), selected per command segment.
Transfer rate	Single transfer rate only. No octal (x8), DDR or DQS read-data strobe.
Chip select	One chip-select output. The wrapper parameter `NUM_CS` supports other counts, but `sep_io` instantiates it with `NUM_CS = 1`.
Data buffering	Separate transmit and receive FIFOs, with independently defined depths in the core configuration.
Register interface	32-bit AXI4-Lite converted to the core's native TL-UL interface.
External signals	SCK, active-low chip select and four bidirectional data lines, with output enables.

The frequency targets are up to 80 MHz in x1 mode and 166 MHz in x4 mode. These are design targets, not guaranteed operating limits for an integrated platform. Software sets the serial clock through `CONFIGOPTS.CLKDIV`: `f_SCK = f_clk_i / (2 * (CLKDIV + 1))`. Select the divider and sampling timing for the attached device and the platform's validated clock and I/O timing.

2.1.5.9.4.3. Integration and Register Access

`sep_io` narrows the 64-bit peripheral AXI bus to 32 bits. The `sep_ot_spi_wrap` wrapper then converts AXI4-Lite accesses to TL-UL for the vendored OpenTitan SPI Host. Software submits command segments and moves data through the FIFOs; controller activity is available in `STATUS.ACTIVE`, not on a separate busy output.

An 8-byte write is split into two 4-byte writes. If the byte strobes select only one half, the other reaches the AXI4-Lite bridge with all strobes clear. The bridge completes that no-op locally with OKAY and sends no TL-UL request. Forwarding it to the core would set `ERROR_STATUS.ACCESSINVAL` and return an error.

The core's access-control (RACL) interface is disabled and its SPI pass-through interface is tied inactive. SEP contains no SPI slave device and does not use the pass-through arrangement that lets a discrete secure element interpose on another SPI device's traffic. An integration requiring XIP, octal or DDR operation needs a different controller; `sep_io_spi` is the existing SPI integration boundary.

2.1.5.9.4.4. Interrupts

The core's error and SPI-event interrupt outputs are ORed onto one line. The `irq` field of `sep_io_spi_req_t` carries that line to `sep_internal_interrupts` and the SEP PIC. Software reads `INTR_STATE` to identify the source.

Table 97. Interrupts

`INTR_STATE` bit	Behavior and clearing
`ERROR`	Latched event. An enabled error event or an `INTR_TEST` write sets it. It remains set after the cause disappears or `INTR_TEST` is written back to zero. Clear it by writing 1 to the state bit; clearing `ERROR_STATUS` alone does not clear it.
`SPI_EVENT`	Level-sensitive status of the conditions selected by `EVENT_ENABLE`. Service the condition or change its selection to remove the source; it is not a latched error event.

`INTR_ENABLE` qualifies only the outgoing interrupt line. It does not gate either state bit. `ERROR_ENABLE` selects the configurable error events; invalid register accesses always generate an error event.

2.1.5.9.4.5. DMA Trigger

The host's `lsio_trigger_o` connects to Secure DMA handshake input 0. It is the registered OR of the transmit and receive watermark conditions: `TXQD < TX_WATERMARK` or `RXQD >= RX_WATERMARK`. These thresholds are in 32-bit FIFO words. The trigger does not depend on `EVENT_ENABLE` or `INTR_ENABLE`; interrupt selection and DMA pacing are separate controls. Configure the FIFO watermarks for the intended transfer direction and use the DMA chapter's handshake setup.

2.1.5.9.4.6. Core Reference

The OpenTitan SPI Host documentation describes core operation and command sequencing. The register map below records the integrated core's registers and fields. The Programmer's Guide gives the programming guidance for this block.

2.1.5.9.4.7. Memory Map and Register Reference

2.1.5.9.4.7.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.9.4.7.2. Detailed Register Map

2.1.5.9.4.7.2.1. SPI Host

Serial peripheral interface for host mode, suitable for interfacing external serial NOR flash devices

Table 98. SPI Host register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-
0xC	ALERT_TEST	W	-
0x10	CONTROL	RW	-
0x14	STATUS	R	-
0x18	CONFIGOPTS	RW	-

Address	Name	Access	Description
0x1C	CSID	RW	-
0x20	COMMAND	W	-
0x2C	ERROR_ENABLE	RW	-
0x30	ERROR_STATUS	RW	-
0x34	EVENT_ENABLE	RW	-

2.1.5.9.4.7.2.1.1. INTR_STATE

Table 99. spi_controller.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	SPI_EVENT	R	0x0	Event-related interrupts, see !!EVENT_ENABLE register for more information.
0	ERROR	RW1C	0x0	Error-related interrupts, see !!ERROR_ENABLE register for more information.

2.1.5.9.4.7.2.1.2. INTR_ENABLE

Table 100. spi_controller.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	SPI_EVENT	RW	0x0	Enable interrupt when !!INTR_STATE.spi_event is set.
0	ERROR	RW	0x0	Enable interrupt when !!INTR_STATE.error is set.

2.1.5.9.4.7.2.1.3. INTR_TEST

Table 101. spi_controller.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	SPI_EVENT	W	0x0	Write 1 to force !!INTR_STATE.spi_event to 1.
0	ERROR	W	0x0	Write 1 to force !!INTR_STATE.error to 1.

2.1.5.9.4.7.2.1.4. ALERT_TEST

Table 102. spi_controller.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	FATAL_FAULT	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.9.4.7.2.1.5. CONTROL

Table 103. spi_controller.CONTROL fields

Bits	Field	Access	Reset	Description
31	SPIEN	RW	0x0	Enables the SPI host. On reset, this field is 0, meaning that no transactions can proceed.

Bits	Field	Access	Reset	Description
30	SW_RST	RW	0x0	Clears the internal state (not registers) to the reset state when set to 1, including the FIFOs, the CDC's, the core state machine and the shift register. In the current implementation, the CDC FIFOs are drained not reset. Therefore software must confirm that both FIFO's empty before releasing the IP from reset.
29	OUTPUT_EN	RW	0x0	Enable the SPI host output buffers for the sck, csb, and sd lines. This allows the SPI_HOST IP to connect to the same bus as other SPI controllers without interference.
28:16	Reserved	-	-	Reserved
15:8	TX_WATERMARK	RW	0x0	If !!EVENT_ENABLE.TXWM is set, the IP will send an interrupt when the depth of the TX FIFO drops below TX_WATERMARK words (32b each).
7:0	RX_WATERMARK	RW	0x7F	If !!EVENT_ENABLE.RXWM is set, the IP will send an interrupt when the depth of the RX FIFO reaches RX_WATERMARK words (32b each).

2.1.5.9.4.7.2.1.6. STATUS

Table 104. spi_controller.STATUS fields

Bits	Field	Access	Reset	Description
31	READY	R	0x0	When high, indicates the SPI host is ready to receive commands. Writing to COMMAND when READY is low is an error, and will trigger an interrupt.
30	ACTIVE	R	0x0	When high, indicates the SPI host is processing a previously issued command.
29	TXFULL	R	0x0	When high, indicates that the transmit data fifo is full. Any further writes to !!TXDATA will create an error interrupt.
28	TXEMPTY	R	0x0	When high, indicates that the transmit data fifo is empty.
27	TXSTALL	R	0x0	If high, signifies that an ongoing transaction has stalled due to lack of data in the TX FIFO
26	TXWM	R	0x0	If high, the amount of data in the TX FIFO has fallen below the level of !!CONTROL.TX_WATERMARK words (32b each).
25	RXFULL	R	0x0	When high, indicates that the receive fifo is full. Any ongoing transactions will stall until firmware reads some data from !!RXDATA.
24	RXEMPTY	R	0x0	When high, indicates that the receive fifo is empty. Any reads from RX FIFO will cause an error interrupt.
23	RXSTALL	R	0x0	If high, signifies that an ongoing transaction has stalled due to lack of available space in the RX FIFO
22	BYTEORDER	R	0x0	The value of the ByteOrder parameter, provided so that firmware can confirm proper IP configuration.
21	Reserved	-	-	Reserved
20	RXWM	R	0x0	If high, the number of 32-bits in the RX FIFO now exceeds the !!CONTROL.RX_WATERMARK entries (32b each).
19:16	CMDQD	R	0x0	Command queue depth. Indicates how many unread 32-bit words are currently in the command segment queue.
15:8	RXQD	R	0x0	Receive queue depth. Indicates how many unread 32-bit words are currently in the RX FIFO. When active, this result may an underestimate due to synchronization delays.
7:0	TXQD	R	0x0	Transmit queue depth. Indicates how many unsent 32-bit words are currently in the TX FIFO. When active, this result may be an overestimate due to synchronization delays.

2.1.5.9.4.7.2.1.7. CONFIGOPTS

Table 105. spi_controller.CONFIGOPTS fields

Bits	Field	Access	Reset	Description
31	CPOL	RW	0x0	The polarity of the sck clock signal. When CPOL is 0, sck is low when idle, and emits high pulses. When CPOL is 1, sck is high when idle, and emits a series of low pulses.
30	CPHA	RW	0x0	The phase of the sck clock signal relative to the data. When CPHA = 0, the data changes on the trailing edge of sck and is typically sampled on the leading edge. Conversely if CPHA = 1 high, data lines change on the leading edge of sck and are typically sampled on the trailing edge. CPHA should be chosen to match the phase of the selected device. The sampling behavior is modified by the !!CONFIGOPTS.FULLCYC bit.
29	FULLCYC	RW	0x0	Full cycle. Modifies the CPHA sampling behaviour to allow for longer device logic setup times. Rather than sampling the SD bus a half cycle after shifting out data, the data is sampled a full cycle after shifting data out. This means that if CPHA = 0, data is shifted out on the trailing edge, and sampled a full cycle later. If CPHA = 1, data is shifted and sampled with the trailing edge, also separated by a full cycle.
28	Reserved	-	-	Reserved
27:24	CSNLEAD	RW	0x0	CS_N Leading Time. Indicates the number of half sck cycles, CSNLEAD+1, to leave between the falling edge of cs_n and the first edge of sck. Setting this register to zero corresponds to the minimum delay of one-half sck cycle
23:20	CSNTRAIL	RW	0x0	CS_N Trailing Time. Indicates the number of half sck cycles, CSNTRAIL+1, to leave between last edge of sck and the rising edge of cs_n. Setting this register to zero corresponds to the minimum delay of one-half sck cycle.
19:16	CSNIDLE	RW	0x0	Minimum idle time between commands. Indicates the minimum number of sck half-cycles to hold cs_n high between commands. Setting this register to zero creates a minimally-wide CS_N-high pulse of one-half sck cycle.
15:0	CLKDIV	RW	0x0	Core clock divider. Slows down subsequent SPI transactions by a factor of (CLKDIV+1) relative to the core clock frequency. The period of sck, T(sck) then becomes `2*(CLK_DIV+1)*T(core)`

2.1.5.9.4.7.2.1.8. CSID

Table 106. spi_controller.CSID fields

Bits	Field	Access	Reset	Description
31:0	CSID	RW	0x0	Chip Select ID

2.1.5.9.4.7.2.1.9. COMMAND

Table 107. spi_controller.COMMAND fields

Bits	Field	Access	Reset	Description
31:25	Reserved	-	-	Reserved
24:5	LEN	W	0x0	Segment Length. For read or write segments, this field controls the number of 1-byte bursts to transmit and or receive in this command segment. The number of cycles required to send or received a byte will depend on !!COMMAND.SPEED. For dummy segments, (!!COMMAND.DIRECTION == 0), this register controls the number of dummy cycles to issue. The number of bytes (or dummy cycles) in the segment will be equal to !!COMMAND.LEN + 1.

Bits	Field	Access	Reset	Description
4:3	DIRECTION	W	0x0	The direction for the following command: "0" = Dummy cycles (no TX/RX). "1" = Rx only, "2" = Tx only, "3" = Bidirectional Tx/Rx (Standard SPI mode only).
2:1	SPEED	W	0x0	The speed for this command segment: "0" = Standard SPI. "1" = Dual SPI. "2"=Quad SPI, "3": RESERVED.
0	CSAAT	W	0x0	**C**hip **S**elect **A**ctive **A**fter **T**ransaction. If !!COMMAND.CSAAT = 0, the chip select line is raised immediately at the end of the command segment. If !!COMMAND.CSAAT = 1, the chip select line is left low at the end of the current transaction segment. This allows the creation of longer, more complete SPI transactions, consisting of several separate segments for issuing instructions, pausing for dummy cycles, and transmitting or receiving data from the device.

2.1.5.9.4.7.2.1.10. ERROR_ENABLE

Table 108. spi_controller.ERROR_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	CSIDINVAL	RW	0x1	Invalid CSID: If this bit is set, the block sends an error interrupt whenever a command is submitted, but CSID exceeds NumCS.
3	CMDINVAL	RW	0x1	Invalid Command Errors: If this bit is set, the block sends an error interrupt whenever a command is sent with invalid values for !!COMMAND.SPEED or !!COMMAND.DIRECTION.
2	UNDERFLOW	RW	0x1	Underflow Errors: If this bit is set, the block sends an error interrupt whenever there is a read from !!RXDATA but the RX FIFO is empty.
1	OVERFLOW	RW	0x1	Overflow Errors: If this bit is set, the block sends an error interrupt whenever the TX FIFO overflows.
0	CMDBUSY	RW	0x1	Command Error: If this bit is set, the block sends an error interrupt whenever a command is issued while busy (i.e. a 1 is when !!STATUS.READY is not asserted.)

2.1.5.9.4.7.2.1.11. ERROR_STATUS

Table 109. spi_controller.ERROR_STATUS fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	ACCESSINVAL	RW1C	0x0	Indicates that TLUL attempted to write to TXDATA with no bytes enabled. Such 'zero byte' writes are not supported.
4	CSIDINVAL	RW1C	0x0	Indicates a command was attempted with an invalid value for !!CSID.
3	CMDINVAL	RW1C	0x0	Indicates an invalid command segment, meaning either an invalid value of !!COMMAND.SPEED or a request for bidirectional data transfer at dual or quad speed
2	UNDERFLOW	RW1C	0x0	Indicates that firmware has attempted to read from !!RXDATA when the RX FIFO is empty.
1	OVERFLOW	RW1C	0x0	Indicates that firmware has overflowed the TX FIFO
0	CMDBUSY	RW1C	0x0	Indicates a write to !!COMMAND when !!STATUS.READY = 0.

2.1.5.9.4.7.2.1.12. EVENT_ENABLE

Table 110. spi_controller.EVENT_ENABLE fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	IDLE	RW	0x0	Assert to send a spi_event interrupt whenever !!STATUS.ACTIVE goes low
4	READY	RW	0x0	Assert to send a spi_event interrupt whenever !!STATUS.READY goes high
3	TXWM	RW	0x0	Assert to send a spi_event interrupt whenever the number of 32-bit words in the TX FIFO is less than !!CONTROL.TX_WATERMARK. To prevent the reassertion of this interrupt add more data to the TX FIFO, or reduce !!CONTROL.TX_WATERMARK.
2	RXWM	RW	0x0	Assert to send a spi_event interrupt whenever the number of 32-bit words in the RX FIFO is greater than !!CONTROL.RX_WATERMARK. To prevent the reassertion of this interrupt, read more data from the RX FIFO, or increase !!CONTROL.RX_WATERMARK.
1	TXEMPTY	RW	0x0	Assert to send a spi_event interrupt whenever !!STATUS.TXEMPTY goes high
0	RXFULL	RW	0x0	Assert to send a spi_event interrupt whenever !!STATUS.RXFULL goes high

2.1.5.9.5. Watchdog Timer (WDT)

The Watchdog timer is a component used to enhance reliability and ensure that the system is notified if the SEP subsystem is ``hanging''. The SEP CPU must periodically visit the WDT and reset its counter, proving that the CPU is still alive and well i.e. not hanging. If the WDT timer counts up to its bark threshold it fires an external interrupt, and if it counts up to its bite threshold it requests a reset, both indicating a timeout has expired and there is a problem within the SEP.

2.1.5.9.5.1. Bus Interface

The `sep_wdt_wrap` module integrates the OpenTitan `aon_timer` IP as the watchdog timer. The 64-bit AXI slave port from the system crossbar is narrowed to 32-bit AXI through an `axi_dw_converter`. The address path subtracts the WDT base address so that the internal TL-UL decoder sees zero-based offsets. After `axi_to_axi_lite` and `axi_lite_to_tlul` conversion, the TL-UL bus drives the standard `aon_timer` register block.

2.1.5.9.5.2. Clock, Reset, and Debug Behavior

The wrapper provides a dedicated watchdog clock input (`clk_wdt_i`) that is synchronized through a `prim_sync_reset` to produce the `rst_aon_ni` reset for the always-on timer domain. The `wdt_debug_sleep_mode_i` input controls whether the timer continues to count during debug halt. Life-cycle escalation is tied to its inactive state. Alert receivers are initialized to the idle encoding to avoid spurious integrity errors; alert outputs are left unconnected since the SEP aggregates watchdog events through the interrupt path.

2.1.5.9.5.3. Bark Interrupt and Bite Reset

The wrapper exports two signals: `intr_wdog_timer_bark_o`, the watchdog bark interrupt that fires when the first timeout stage expires, and `wdt_timer_rst_req_o`, the bite reset request that fires when the second timeout stage expires and the system failed to respond to the bark.

2.1.5.9.5.4. Programming Reference

Consult the OpenTitan Always-On Timer documentation for the authoritative core functionality of the IP. The Programmer's Guide gives the programming guidance for this block. The register map follows below.

2.1.5.9.5.5. Memory Map and Register Reference

2.1.5.9.5.5.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.9.5.5.2. Detailed Register Map

2.1.5.9.5.5.2.1. Always-On Timer

Wakeup and watchdog timers running on a low-power, always-on clock

Table 111. Always-On Timer register list

Address	Name	Access	Description
0x0	ALERT_TEST	W	-
0x4	WKUP_CTRL	RW	-
0x8	WKUP_THOLD_HI	RW	-
0xC	WKUP_THOLD_LO	RW	-
0x10	WKUP_COUNT_HI	RW	-
0x14	WKUP_COUNT_LO	RW	-
0x18	WDOG_REGWEN	RW	-
0x1C	WDOG_CTRL	RW	-
0x20	WDOG_BARK_THOLD	RW	-
0x24	WDOG_BITE_THOLD	RW	-
0x28	WDOG_COUNT	RW	-
0x2C	INTR_STATE	RW	-
0x30	INTR_TEST	W	-
0x34	WKUP_CAUSE	RW	-

2.1.5.9.5.5.2.1.1. ALERT_TEST

Table 112. aon_timer.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	fatal_fault	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.9.5.5.2.1.2. WKUP_CTRL

Table 113. aon_timer.WKUP_CTRL fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved
12:1	prescaler	RW	0x0	Pre-scaler value for wakeup timer count
0	enable	RW	0x0	When set to 1, the wakeup timer will count

2.1.5.9.5.5.2.1.3. WKUP_THOLD_HI

Table 114. aon_timer.WKUP_THOLD_HI fields

Bits	Field	Access	Reset	Description
31:0	threshold_hi	RW	0x0	The count at which a wakeup interrupt should be generated, top 32 bits.

2.1.5.9.5.5.2.1.4. WKUP_THOLD_LO

Table 115. aon_timer.WKUP_THOLD_LO fields

Bits	Field	Access	Reset	Description
31:0	threshold_lo	RW	0x0	The count at which a wakeup interrupt should be generated, bottom 32 bits.

2.1.5.9.5.5.2.1.5. WKUP_COUNT_HI

Table 116. aon_timer.WKUP_COUNT_HI fields

Bits	Field	Access	Reset	Description
31:0	count_hi	RW	0x0	The current wakeup counter value, top 32 bits.

2.1.5.9.5.5.2.1.6. WKUP_COUNT_LO

Table 117. aon_timer.WKUP_COUNT_LO fields

Bits	Field	Access	Reset	Description
31:0	count_lo	RW	0x0	The current wakeup counter value, bottom 32 bits.

2.1.5.9.5.5.2.1.7. WDOG_REGWEN

Table 118. aon_timer.WDOG_REGWEN fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	regwen	RW0C	0x1	Once cleared, the watchdog configuration will be locked until the next reset.

2.1.5.9.5.5.2.1.8. WDOG_CTRL

Table 119. aon_timer.WDOG_CTRL fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	pause_in_sleep	RW	0x0	When set to 1, the watchdog timer will not count during sleep.
0	enable	RW	0x0	When set to 1, the watchdog timer will count.

2.1.5.9.5.5.2.1.9. WDOG_BARK_THOLD

Table 120. aon_timer.WDOG_BARK_THOLD fields

Bits	Field	Access	Reset	Description
31:0	threshold	RW	0x0	The count at which a watchdog bark interrupt should be generated.

2.1.5.9.5.5.2.1.10. WDOG_BITE_THOLD

Table 121. aon_timer.WDOG_BITE_THOLD fields

Bits	Field	Access	Reset	Description
31:0	threshold	RW	0x0	The count at which a watchdog bite reset should be generated.

2.1.5.9.5.5.2.1.11. WDOG_COUNT

Table 122. aon_timer.WDOG_COUNT fields

Bits	Field	Access	Reset	Description
31:0	count	RW	0x0	The current watchdog counter value.

2.1.5.9.5.5.2.1.12. INTR_STATE

Table 123. aon_timer.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	wdog_timer_bark	RW1C	0x0	Raised if the watchdog timer has hit the bark threshold.
0	wkup_timer_expired	RW1C	0x0	Raised if the wakeup timer has hit the specified threshold.

2.1.5.9.5.5.2.1.13. INTR_TEST

Table 124. aon_timer.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	wdog_timer_bark	W	-	Write 1 to force wdog_timer_bark interrupt.
0	wkup_timer_expired	W	-	Write 1 to force wkup_timer_expired interrupt.

2.1.5.9.5.5.2.1.14. WKUP_CAUSE

Table 125. aon_timer.WKUP_CAUSE fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	cause	RW0C	0x0	AON timer requested wakeup, write 0 to clear.

2.1.5.10. Security and Lifecycle

These blocks establish the chiplet's lifecycle state, process authorization tokens and control access to security assets, debug and test facilities. The Threat Model and Attack Countermeasures chapters describe the security objectives and protections.

2.1.5.10.1. OTP Fuse Controller

The One-Time Programmable (OTP) fuse controller stores persistent chiplet policy. At cold reset it senses the fuse bank into shadow registers for software access and hardware policy enforcement. Programming a fuse and updating its shadow are separate operations.

Figure 24 shows the fuse-bank organization.




Figure 24. SEP OTP fuse bank

Each row of Figure 24 is 32 bytes, eight 32-bit words, at the offset given on the left from the base of the MAP window; a field that crosses a row boundary continues at the start of the next row. The shading gives the storage class of each field's shadow register. The lock field, the lifecycle state, the two disable vectors and the two RMA token digests are held in non-scannable storage. CLASS_KEY, CHIPLET_UID, SIP_UID and SYS_UID are non-scannable as well and read as zero downstream while SECURE_TM is 1. The nine spare fields fill the last nine rows and are drawn as one band.

Figure 25 shows the controller boundary and the technology-specific fuse interface.




Figure 25. eFuse controller and technology-specific interface shim

The figure reads from the bus ports on the left to the fuse bank at the bottom. Thick arrows are AXI4, AXI-Lite or APB, and thin double-headed arrows carry a fuse command and its response. The dashed line separates the OCAH controller from the interface shim, which an adopter replaces with one for its fuse technology.

Both wrappers pass the OTP JTAG port through a lifecycle filter that answers a blocked access with an error response. Inside the controller, an AXI-Lite multiplexer merges the functional and JTAG ports. Addresses from the MAP window to the end of the last register window go through the AXI-Lite to APB bridge, and all others go to the shim's bank control registers. The APB decode answers any address in that span outside the register windows with SLVERR. The command multiplexer gives automatic sensing priority until it completes, then gives programming priority over reading, and `efuse_guard` filters every command before it reaches the shim.

The SMC reuses the controller in `smc_efuse_wrapper` with `HAS_LC_STATE=0`, so the logic with a dashed outline is absent there:

- The MMR window and `efuse_token_processing`: the SMC address map has no MMR window, and `security_disable_o` and `token_match_fault_o` are tied low.
- The LC_STATE handling in `efuse_shadow_regs`: the held INVALID output before sensing, the token-gated LC_STATE writes and the secret masking in secure test mode. The SMC has no secret-shadow ranges and ties `secure_tm_i` low.

- The RMA token-bit gate in `efuse_guard`.
- The width converter and the Key Manager port of `sep_efuse_wrapper`: the SMC functional port is a 32-bit AXI-Lite port connected to the controller directly.

The SMC has no local lifecycle controller. Its JTAG lifecycle filter decodes the lifecycle state received from SEP, and its `security_disable_i` input takes the SEP security-disable status, which skips fuse sensing and opens the shadow registers to software.

2.1.5.10.1.1. Fuse Sensing and Boot Sequencing

When SEP is released from reset (chiplet_cold_reset), the sensing FSM automatically copies each fuse field into its dedicated memory-mapped shadow register.

The logical `LC_STATE` output remains `4'b1111` until fuse sensing completes; only then is the LC_STATE value sensed from the fuses driven to downstream logic such as the lifecycle controller. Table 126 defines whether software can read and write the shadow register of each fuse field. Shadow registers that are not software-visible drive their fuse values directly to downstream hardware. All fuse fields other than LOCKS and LC_STATE are made available to downstream logic as soon as they are ready.

After the fuses have been read into their shadow registers, a sense-completion indicator is generated. This triggers the DFT-based memory-repair machine for the SEP SRAMs. Once memory repair completes or is bypassed, the SEP CPU is enabled and fetches its first instruction from the SEP ROM.

Figure 26 shows the fuse-sensing sequence and shadow-register timing.




Figure 26. eFuse sensing state machine and shadow-register timing

The upper part of Figure 26 shows the four states of the sensing FSM in `efuse_shadow_regs`, and the lower part shows one sensing run cycle by cycle. ST_READ issues a single READ command for all 256 shadow words. The shim then returns one `fuse_command_resp.valid` strobe per word, and strobes may arrive on consecutive cycles. Each strobe stores its data

in the shadow word indexed by `words_received_q` and increments the counter; a strobe with its status bit set still advances the counter but leaves that word unwritten. The strobe that arrives while the counter is 255 stores the last word and moves the FSM to ST_FINISHED, and `fuse_sense_done_o` rises one cycle later. Until then, APB accesses to the MAP window return SLVERR.

2.1.5.10.1.2. Shadow Register and JTAG Access Control

Each assigned lock slot contains an independent write-lock and read-lock bit. A write-lock blocks fuse programming and shadow writes; a read-lock blocks software and JTAG reads of both the fuse field and its shadow. The sensing FSM can still read locked fuses to populate the shadows.

There are two exceptions: the `LOCKS` and `LOCKS_SPARE` registers have no lock slot of their own, and `LC_STATE` ignores its assigned lock bits. Lifecycle transition and token checks still apply to `LC_STATE`. The slot numbers and bit positions are defined in Table 126.

The fuse block's internal space, including the fuse-programming configuration space, is accessible through both a JTAG interface and an AXI interface, as shown in the figure, and each interface has its own access control. In addition to the shadow-register access control defined by Table 126, the JTAG port shall be further restricted: in the PROD and RMA_SIP states it may reach only the eFuse MMR token block. That block is the three token-input arrays (RMA_SIP_TOKEN_I, RMA_CHIPLET_TOKEN_I and SEC_DISABLE_TOKEN_I), the TOKEN_EOP register that triggers a match, and the three match-status registers. Every other JTAG access to the fuse block — the shadow registers, the interface control registers and the SHIM — shall complete with an error response.

2.1.5.10.1.3. Fuse Programming and RMA Authorization

The fuse-programming protection shall enable the fuse-programming function only after the LOCKS field has been sensed, and shall honor the write-lock value of each field. Programming LC_STATE is subject to additional restrictions: LC_STATE[2:1] indicate whether the chiplet is in an RMA state (see the LC State Machine section of the Life Cycle Controller). The SEP fuse controller implements two 256-bit registers, RMA_SIP_TOKEN_I and RMA_CHIPLET_TOKEN_I.

These two registers can be populated by both SEP software and JTAG. Each input is hashed (SHA-256) and compared with the stored RMA_SIP_TOKEN_DIGEST and RMA_CHIPLET_TOKEN_DIGEST, respectively. Only on a match can LC_STATE[1] and LC_STATE[2] be programmed; the token matching section of the Programmer's Guide gives the firmware sequence. For the matching mechanism, see Token Matching Mechanism and Attack Countermeasures.

2.1.5.10.1.3.1. Programming Voltage

The fuse bank shall support keeping the programming-voltage rail active for an unlimited lifetime. This is achieved by using only the internal charge-pump-generated programming voltage rather than the external programming voltage.

The charge pump is calibrated early in wafer test, and its calibration values are burned into the corresponding fuse bits; this is the only time the external fuse-programming voltage is used. Consequently, software-initiated fuse programming never needs to configure the programming voltage.

2.1.5.10.1.4. Shadow Register Updates and Test-Mode Protection

- Programming a fuse does not update its shadow register until the next fuse sensing occurs.
- The shadow registers of LOCK (both the LOCKS and LOCKS_SPARE windows), LC_STATE, SIP_DIS, and SYS_DIS are non-scannable. Any register on the path from these registers to the feature control outputs or the fuse write-enable signals is likewise non-scannable.
- When SECURE_TM is 1 (see the Test Mode section), the shadow registers of LOCK (both the LOCKS and LOCKS_SPARE windows), LC_STATE, SIP_DIS, and SYS_DIS shall be blocked from any update, from every

source — software, JTAG, and TRoot. This list is normative and exhaustive: these are the fields whose perturbation could enable a feature that a DIS vector or the lifecycle state has disabled. An implementation may block further fields, but no other requirement in this specification depends on it.

To prevent test patterns from accidentally or maliciously changing or reading out the fuse values:

- When SECURE_TM is 1, the fuse write-enable inputs to the fuse IP block are tied inactive, and the fuse-bank outputs are disconnected from downstream logic. If needed, dedicated test registers can be added to drive the downstream logic during test.

2.1.5.10.1.5. Fuse Fields

Table 126 lists lock slots, field sizes, shadow access permissions and purposes. Slot numbers select lock bits; they are neither OTP word offsets nor register addresses. Access permissions remain subject to the lock and lifecycle rules above.

Table 126. SEP fuse fields

Field	Lock slot	Size (bits)	SW writable	SW readable	Description
LOCK	—	96	set-only	true	Lock state occupies OTP words 0–2: `LOCKS` (64 bits at `0x0`) covers slots 0–31: write-lock at bit `2n`, read-lock at bit `2n+1` for slot `n`. `LOCKS_SPARE` (32 bits at `0x8`) covers slots 32–40: write-lock at bit `2(n-32)`, read-lock at bit `2(n-32)+1`. Bits [31:18] are unassigned slots 41–47. Firmware reads the complete state as three consecutive 32-bit words. There are 41 assigned slots (0–40); slot 0 belongs to `LC_STATE`, which ignores both lock bits. LOCK has no lock-bit pair and cannot lock itself.
LC_STATE	0	32 (4-bit state, 8-bit encoding)	set-only	true	Life-cycle state of the chiplet. The shadow encodes the logical state as `{~raw[3:0], raw[3:0]}` in bits [7:0]; the bit numbers below refer to the logical state. ***LC_STATE shall never be write-locked or read-locked by the corresponding LOCKS bits***. LC_STATE[3] and LC_STATE[0] are set-only. LC_STATE[2:1] shall be set-only when the corresponding *_TOKEN has a match. Setting bit 2 also requires bit 1 to be set in the pre-write state; one write cannot establish both RMA stages. Invalid lifecycle encodings are terminal. Otherwise, LC_STATE[2:1] cannot be updated.
SBOOT_DIS	1	32 (use only 1 bit)	true	true	Disables secure boot when set to 1, in any lifecycle state. It overrides lifecycle enforcement in PROD and PROD_END and the TEST_DEV / RMA_SiP debug-lock rule, but not a signed manifest's request for verification; see Firmware Authorization in the Lifecycle Controller section.
TRANSIENT_RMA_EN	2	32 (use only 1 bit)	true	true	Enables automatic RMA shadow-state updates after token matching, without requiring a reset. It does not enable the token matcher itself. The chiplet-token path has priority and requires an already established RMA_SIP state; a chiplet match without that state blocks the transition rather than falling through to a simultaneous SiP match. When 0, token matches do not automatically update `LC_STATE`; explicit shadow writes remain subject to token and transition checks.
SIP_DIS	3	64	set-only	true	SiP owner's feature-control disable vector, provisioned by the chiplet owner. A bit set to 1 disables the corresponding feature.
SYS_DIS	4	64	set-only	true	System owner's feature-control disable vector, provisioned by the SiP owner. A bit set to 1 disables the corresponding feature.
RMA_SIP_TOKEN_DIGEST	5	256	true	true	Hash digest of the secret RMA_SIP_TOKEN, that enables entering RMA_SIP Life Cycle state

Field	Lock slot	Size (bits)	SW writable	SW readable	Description
RMA_CHIPLET_TOKEN_DIGEST	6	256	true	true	Hash digest of the secret RMA_CHIPLET_TOKEN that enables entering RMA_CHIPLET Life Cycle state
CLASS_KEY	7	256	true	true	Can be used for firmware encryption and decryption.
CHIPLET_PUBK_REVOKE	8	32	set-only	true	Global public-key revocation vector covering every boot-verification key of every owner (classical and PQC). SEP ROM embeds a set of public-key hash digests and accesses additional fused key hashes; each key entry maps to one bit here. Once set, SEP ROM rejects the corresponding key. Bit map: [7:0] ROM chiplet-creator classical keys (bits 0,1 are development keys); [15:8] ROM chiplet-creator PQC keys; [16]/[17] CHIPLET_PUBK_HASH0/1; [18]/[19] CHIPLET_PUBK_PQC_HASH0/1; [20]/[21] SIP_PUBK_HASH0 / SIP_PUBK_PQC_HASH0; [22]/[23] SYS_PUBK_HASH / SYS_PUBK_PQC_HASH; [24]/[25] SIP_PUBK_HASH1 / SIP_PUBK_PQC_HASH1; [31:26] reserved. Before the chiplet owner transfers a part to the customer, the development-key bits shall be set (revoked). (Name retained for compatibility; scope is now all owners.)
BL1_VERSION	9	256	set-only	true	BL1 anti-rollback storage. The production ROM supplies the low 128 raw bits as security-version flags to the manifest validator; the upper 128 bits do not participate in that check. See Section 2.1.5.10.1.6.
BL2_VERSION	10	256	set-only	true	BL2 anti-rollback storage for later-stage firmware policy. This bank is not the production ROM's BL1 security-version input; software using it must define its encoding and enforcement policy.
CHIPLET_UID	11	256	true	true	Silicon creator's *secret* device unique ID (also referred to as the UDS, Unique Device Secret). The chiplet creator is responsible for CHIPLET_UID provisioning and public identity enrollment. Write-lock and read-lock independently control modification and software visibility. Hardware recording of provisioning measurements is a proposed enhancement.
SIP_PUBK_HASH0	12	256	true	true	Hash digest of SiP owner's root public key for secure boot (slot 0). Note: The chiplet creator's actual root public key is embedded in the SEPROM. The digest is used to validate that public key.
SIP_UID	13	256	true	true	SiP owner's *secret* device unique ID. The SiP owner is responsible for SIP_UID provisioning and public identity enrollment. Write-lock and read-lock independently control modification and software visibility. Hardware recording of provisioning measurements and retention of prior-owner key/UID pairs in the derivation hierarchy are proposed enhancements.
SYS_PUBK_HASH	14	256	true	true	Hash digest of system owner's root public key for secure boot.
SYS_UID	15	256	true	true	System owner's *secret* device unique ID. The system owner is responsible for SYS_UID provisioning and public identity enrollment. Write-lock and read-lock independently control modification and software visibility.
STATUS_RPT	16	32 (2 used)	true	true	When STATUS_RPT[1:0] == 2'b00, the boot ROM samples an SMC GPIO (STATUS_RPT) to determine whether to report status. When STATUS_RPT[1:0] == 2'b01, the boot ROM reports status; otherwise, it does not.
ROM_CTL	17	32	true	true	ROM_CTL[0]: 0 = little-endian, 1 = big-endian. ROM_CTL[5:1]: row-swap control; swaps ROM slices when set. ROM_CTL[31:6]: reserved.
SYSCLK_FREQ_MHZ	18	32 (11 used)	true	true	Configured sysclk PLL frequency in MHz (`sysclk_freq_mhz[10:0]`). Ignored when 0. Consumed by boot ROM clock math (PLL selection and SPI `CLKDIV` derivation).
CHIPLET_PUBK_HASH0	19	256	true	true	Hash of chiplet-owner authentication key 0, fused. These fused chiplet-owner key hashes can be used in addition to the hashes embedded in the ROM to authenticate manifests.

Field	Lock slot	Size (bits)	SW writable	SW readable	Description
CHIPLET_PUBK_HASH1	20	256	true	true	Hash of chiplet-owner authentication key 1, fused.
REQUIRED_SIGNERS	21	32 (use only 2 bits)	true	true	Owners whose signature a manifest must carry to be authenticated by SEP ROM. Per owner, 1 = required, 0 = not-required; the default all-zero value requires no additional owner. [0] SiP owner, [1] system owner, [31:2] reserved. The chiplet creator is the root of trust — its classical and PQC root digests are embedded in SEP ROM and always authenticate BL1 — so it has no bit here. Burning a fuse bit only ever adds a required signer, so the fuse is monotonic: the standard LOCK bits exist but locking this field is unnecessary, since a later burn can never weaken security. The value is applied via the shadow register (loaded from the fuse at cold reset, SW-writable): firmware may update the shadow to set the required signers for each manifest it verifies (BL1, BL2, runtime, …). See Secure-Boot Signing Model in the Life Cycle Controller section.
REQUIRED_ALGS	22	32 (use only 12 bits)	set-only	true	Per-owner required signature algorithms, applied only when that owner is required. Each owner has a 4-bit nibble; bit 0 = classical (ECDSA P-384 or RSA), bit 1 = post-quantum (ML-DSA), bits 3:2 reserved. The specific classical scheme and ML-DSA parameter set (e.g., ML-DSA-44/65/87) are set by the owner's provisioned keys, not mandated here. [3:0] chiplet, [7:4] SiP owner, [11:8] system owner, [31:12] reserved. For each required (owner, algorithm) the manifest must carry a signature verified against that owner's burned, non-revoked key of that type; all required pairs must verify, and any signature from a non-required owner is ignored.
CHIPLET_PUBK_PQC_HASH0	23	256	true	true	Chiplet owner ML-DSA PQC authentication key 0 hash, fused. PQC counterpart of CHIPLET_PUBK_HASH0.
CHIPLET_PUBK_PQC_HASH1	24	256	true	true	Chiplet owner ML-DSA PQC authentication key 1 hash, fused. PQC counterpart of CHIPLET_PUBK_HASH1.
SIP_PUBK_PQC_HASH0	25	256	true	true	Hash digest of the SiP owner's ML-DSA PQC root public key for secure boot (slot 0). PQC counterpart of SIP_PUBK_HASH0.
SYS_PUBK_PQC_HASH	26	256	true	true	Hash digest of the system owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SYS_PUBK_HASH.
SIP_PUBK_HASH1	27	256	true	true	Hash digest of the SiP owner's root public key for secure boot, slot 1. Second slot so the SiP owner retains a usable root key after revoking slot 0 via CHIPLET_PUBK_REVOKE[24].
SIP_PUBK_PQC_HASH1	28	256	true	true	Hash digest of the SiP owner's ML-DSA PQC root public key for secure boot, slot 1. PQC counterpart of SIP_PUBK_HASH1; revocable via CHIPLET_PUBK_REVOKE[25].
SEP_CHIPLET_ID	29	256	true	true	Per-owner chiplet public identity fuse used as a public identity input to the Key Manager. No read protection is required.
SEP_SIP_ID	30	256	true	true	SiP-owner public identity fuse used as a public identity input to the Key Manager. No read protection is required.
SEP_SYS_ID	31	256	true	true	System-owner public identity fuse used as a public identity input to the Key Manager. No read protection is required.
spare0	32	256	true	true	Spare field 0 for future use.
spare1	33	256	true	true	Spare field 1 for future use.
spare2	34	256	true	true	Spare field 2 for future use.
spare3	35	256	true	true	Spare field 3 for future use.
spare4	36	256	true	true	Spare field 4 for future use.
spare5	37	256	true	true	Spare field 5 for future use.
spare6	38	256	true	true	Spare field 6 for future use.
spare7	39	256	true	true	Spare field 7 for future use.

Field	Lock slot	Size (bits)	SW writable	SW readable	Description
spare8	40	256	true	true	Spare field 8 for future use.

The fuse map is exactly 8192 bits with exclusive end address `0x400` (1024 bytes, 256 × 32-bit words).

The JTAG_ID field has been removed from the fuse map and will be implemented as a top-level port.

2.1.5.10.1.6. Anti-Rollback Security-Version Flags

`BL1_VERSION` holds the device security-version flags for BL1. They are independent flags rather than a counter, and the production ROM uses bits `[127:0]`. `BL2_VERSION` is separate storage whose interpretation belongs to later-stage firmware. Both fields are set-only, so a burned flag stays set.

The Anti-Rollback requirements of the SEP Boot ROM appendix in the Programmer's Guide define the check a manifest must pass and how firmware commits new flags.

2.1.5.10.1.7. RTL Integration

`sep_crypto` instantiates `sep_efuse_wrapper`. The wrapper converts the 64-bit SEP AXI interface to 32-bit AXI4-Lite through `axi_dw_converter` and `axi_to_axi_lite`, then connects to the shared `efuse_interface_controller`. A separate JTAG AXI4-Lite port provides manufacturing and lifecycle-restricted access.

The controller uses `HAS_LC_STATE=1`. Its four-bit logical lifecycle state starts at bit 96 in the shadow map and uses an eight-bit differential encoding. `sep_lifecycle_ctrl` decodes that state with `prim_diff_decode_multi`, derives feature controls from `SIP_DIS` and `SYS_DIS`, and differentially encodes its two demotion outputs. The pre-sense invalid-state behavior is described under Fuse Sensing and Boot Sequencing above.

`sep_crypto` assembles the Key Manager's `km_otp_data_t` input from:

- The encoded lifecycle shadow and the lifecycle controller's two demotion outputs; demotion is not read directly from fuses.
- The secret shadows `chiplet_uid`, `sip_uid`, `sys_uid` and `class_key`.
- The public identity shadows `sep_chiplet_id`, `sep_sip_id` and `sep_sys_id`.

`BL1_VERSION`, `BL2_VERSION`, RMA token digests and public-key hashes are not part of that Key Manager interface. SEP firmware accesses them through the shadow interface; the token matcher also consumes the RMA digests internally.

For simulation, adopters need to provide an external eFuse macro model behind the shim interface. Only the generic controller and the shim interfaces are defined here.

For the canonical eFuse IP documentation covering the `efuse_interface_controller` internals, sensing FSM, and programming protocol, see `hw/ip/efuse/doc/index.adoc` (included in the SMC documentation via `hw/sys/smc/doc/periphs.adoc`).

2.1.5.10.1.8. Memory Map and Register Reference

2.1.5.10.1.8.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.10.1.8.2. Detailed Register Map

2.1.5.10.1.8.2.1. SEP eFuse Map Address Map

Per-field write-lock and read-lock registers for the SEP eFuse map.

Table 127. SEP eFuse Map Address Map register list

Address	Name	Access	Description
0x0	LOCKS	RW	-
0x8	LOCKS_SPARE	RW	-
0xC	LC_STATE	R	-
0x10	SBOOT_DIS	R	-
0x14	TRANSIENT_RMA_EN	R	-
0x18	SIP_DIS	RW	An owner's feature control vector. When set (1'b1), the corresponding feature is disabled. Layout: see the Disable Vector Format section of lifecycle_controller.adoc.
0x20	SYS_DIS	RW	An owner's feature control vector. When set (1'b1), the corresponding feature is disabled. Layout: see the Disable Vector Format section of lifecycle_controller.adoc.
0x28	RMA_SIP_TOKEN_DIGEST	R	-
0x48	RMA_CHIPLET_TOKEN_DIGEST	R	-
0x68	CLASS_KEY	R	-
0x88	CHIPLET_PUBK_REVOKE	R	-
0x8C	BL1_VERSION	R	-
0xAC	BL2_VERSION	R	-
0xCC	CHIPLET_UID	R	-
0xEC	SIP_PUBK_HASH0	R	-
0x10C	SIP_UID	R	-
0x12C	SYS_PUBK_HASH	R	-
0x14C	SYS_UID	R	-
0x16C	STATUS_RPT	R	-
0x170	ROM_CTL	R	-
0x174	SYSCLK_FREQ_MHZ	R	-
0x178	CHIPLET_PUBK_HASH0	R	-
0x198	CHIPLET_PUBK_HASH1	R	-
0x1B8	REQUIRED_SIGNERS	RW	-
0x1BC	REQUIRED_ALGS	RW	-
0x1C0	CHIPLET_PUBK_PQC_HASH0	R	-
0x1E0	CHIPLET_PUBK_PQC_HASH1	R	-
0x200	SIP_PUBK_PQC_HASH0	R	-
0x220	SYS_PUBK_PQC_HASH	R	-
0x240	SIP_PUBK_HASH1	R	-
0x260	SIP_PUBK_PQC_HASH1	R	-
0x280	SEP_CHIPLET_ID	R	-
0x2A0	SEP_SIP_ID	R	-

Address	Name	Access	Description
0x2C0	SEP_SYS_ID	R	-
0x2E0	spare0	R	-
0x300	spare1	R	-
0x320	spare2	R	-
0x340	spare3	R	-
0x360	spare4	R	-
0x380	spare5	R	-
0x3A0	spare6	R	-
0x3C0	spare7	R	-
0x3E0	spare8	R	-

2.1.5.10.1.8.2.1.1. LOCKS

Table 128. sep_efuse_map.LOCKS fields

Bits	Field	Access	Reset	Description
63	SEP_SYS_ID_READ_LOCK	RW1S	0x0	sep_sys_id_read_lock (slot 31): when set, SEP_SYS_ID is not read-able.
62	SEP_SYS_ID_WRITE_LOCK	RW1S	0x0	sep_sys_id_write_lock (slot 31): when set, SEP_SYS_ID is not write-able.
61	SEP_SIP_ID_READ_LOCK	RW1S	0x0	sep_sip_id_read_lock (slot 30): when set, SEP_SIP_ID is not read-able.
60	SEP_SIP_ID_WRITE_LOCK	RW1S	0x0	sep_sip_id_write_lock (slot 30): when set, SEP_SIP_ID is not write-able.
59	SEP_CHIPLET_ID_READ_LOCK	RW1S	0x0	sep_chiplet_id_read_lock (slot 29): when set, SEP_CHIPLET_ID is not read-able.
58	SEP_CHIPLET_ID_WRITE_LOCK	RW1S	0x0	sep_chiplet_id_write_lock (slot 29): when set, SEP_CHIPLET_ID is not write-able.
57	SIP_PUBK_PQC_HASH1_READ_LOCK	RW1S	0x0	sip_pubk_pqc_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
56	SIP_PUBK_PQC_HASH1_WRITE_LOCK	RW1S	0x0	sip_pubk_pqc_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
55	SIP_PUBK_HASH1_READ_LOCK	RW1S	0x0	sip_pubk_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
54	SIP_PUBK_HASH1_WRITE_LOCK	RW1S	0x0	sip_pubk_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
53	SYS_PUBK_PQC_HASH_READ_LOCK	RW1S	0x0	sys_pubk_pqc_hash_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
52	SYS_PUBK_PQC_HASH_WRITE_LOCK	RW1S	0x0	sys_pubk_pqc_hash_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
51	SIP_PUBK_PQC_HASH0_READ_LOCK	RW1S	0x0	sip_pubk_pqc_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
50	SIP_PUBK_PQC_HASH0_WRITE_LOCK	RW1S	0x0	sip_pubk_pqc_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
49	CHIPLET_PUBK_PQC_HASH1_READ_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
48	CHIPLET_PUBK_PQC_HASH1_WRITE_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
47	CHIPLET_PUBK_PQC_HASH0_READ_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
46	CHIPLET_PUBK_PQC_HASH0_WRITE_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)

Bits	Field	Access	Reset	Description
45	REQUIRED_ALGS_READ_LOCK	RW1S	0x0	required_algs_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
44	REQUIRED_ALGS_WRITE_LOCK	RW1S	0x0	required_algs_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
43	REQUIRED_SIGNERS_READ_LOCK	RW1S	0x0	required_signers_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
42	REQUIRED_SIGNERS_WRITE_LOCK	RW1S	0x0	required_signers_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
41	CHIPLET_PUBK_HASH1_READ_LOCK	RW1S	0x0	chiplet_pubk_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
40	CHIPLET_PUBK_HASH1_WRITE_LOCK	RW1S	0x0	chiplet_pubk_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
39	CHIPLET_PUBK_HASH0_READ_LOCK	RW1S	0x0	chiplet_pubk_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
38	CHIPLET_PUBK_HASH0_WRITE_LOCK	RW1S	0x0	chiplet_pubk_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
37	SYSCLK_FREQ_MHZ_READ_LOCK	RW1S	0x0	sysclk_freq_mhz_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
36	SYSCLK_FREQ_MHZ_WRITE_LOCK	RW1S	0x0	sysclk_freq_mhz_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
35	ROM_CTL_READ_LOCK	RW1S	0x0	rom_ctl_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
34	ROM_CTL_WRITE_LOCK	RW1S	0x0	rom_ctl_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
33	STATUS_RPT_READ_LOCK	RW1S	0x0	status_rpt_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
32	STATUS_RPT_WRITE_LOCK	RW1S	0x0	status_rpt_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
31	SYS_UID_READ_LOCK	RW1S	0x0	sys_uid_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
30	SYS_UID_WRITE_LOCK	RW1S	0x0	sys_uid_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
29	SYS_PUBK_HASH_READ_LOCK	RW1S	0x0	sys_pubk_hash_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
28	SYS_PUBK_HASH_WRITE_LOCK	RW1S	0x0	sys_pubk_hash_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
27	SIP_UID_READ_LOCK	RW1S	0x0	sip_uid_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
26	SIP_UID_WRITE_LOCK	RW1S	0x0	sip_uid_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
25	SIP_PUBK_HASH0_READ_LOCK	RW1S	0x0	sip_pubk_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
24	SIP_PUBK_HASH0_WRITE_LOCK	RW1S	0x0	sip_pubk_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
23	CHIPLET_UID_READ_LOCK	RW1S	0x0	chiplet_uid_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
22	CHIPLET_UID_WRITE_LOCK	RW1S	0x0	chiplet_uid_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
21	BL2_VERSION_READ_LOCK	RW1S	0x0	bl2_version_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)

Bits	Field	Access	Reset	Description
20	BL2_VERSION_WRITE_LOCK	RW1S	0x0	bl2_version_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
19	BL1_VERSION_READ_LOCK	RW1S	0x0	bl1_version_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
18	BL1_VERSION_WRITE_LOCK	RW1S	0x0	bl1_version_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
17	CHIPLET_PUBK_REVOKE_READ_LOCK	RW1S	0x0	chiplet_pubk_revoke_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
16	CHIPLET_PUBK_REVOKE_WRITE_LOCK	RW1S	0x0	chiplet_pubk_revoke_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
15	CLASS_KEY_READ_LOCK	RW1S	0x0	class_key_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
14	CLASS_KEY_WRITE_LOCK	RW1S	0x0	class_key_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
13	RMA_CHIPLET_TOKEN_DIGEST_READ_LOCK	RW1S	0x0	rma_chiplet_token_digest_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
12	RMA_CHIPLET_TOKEN_DIGEST_WRITE_LOCK	RW1S	0x0	rma_chiplet_token_digest_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
11	RMA_SIP_TOKEN_DIGEST_READ_LOCK	RW1S	0x0	rma_sip_token_digest_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
10	RMA_SIP_TOKEN_DIGEST_WRITE_LOCK	RW1S	0x0	rma_sip_token_digest_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
9	SYS_DIS_READ_LOCK	RW1S	0x0	sys_dis_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
8	SYS_DIS_WRITE_LOCK	RW1S	0x0	sys_dis_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
7	SIP_DIS_READ_LOCK	RW1S	0x0	sip_dis_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
6	SIP_DIS_WRITE_LOCK	RW1S	0x0	sip_dis_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
5	TRANSIENT_RMA_EN_READ_LOCK	RW1S	0x0	TRANSIENT_RMA_EN_READ_LOCK, when set, this field is not read-able (neither the eFuse nor the shadow register)
4	TRANSIENT_RMA_EN_WRITE_LOCK	RW1S	0x0	TRANSIENT_RMA_EN_WRITE_LOCK, when set, this field is not write-able (neither the eFuse nor the shadow register)
3	SBOOT_DIS_READ_LOCK	RW1S	0x0	sboot_dis_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
2	SBOOT_DIS_WRITE_LOCK	RW1S	0x0	sboot_dis_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
1	LC_STATE_READ_LOCK	RW1S	0x0	lc_state_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
0	LC_STATE_WRITE_LOCK	RW1S	0x0	lc_state_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)

2.1.5.10.1.8.2.1.2. LOCKS_SPARE

Table 129. sep_efuse_map.LOCKS_SPARE fields

Bits	Field	Access	Reset	Description
31:18	SPARE_LOCK_RSVD	RW1S	0x0	Unassigned lock slots 41-47. Reserved for future field lock assignments.
17	SPARE8_READ_LOCK	RW1S	0x0	spare8_read_lock (slot 40): when set, spare8 is not read-able.

Bits	Field	Access	Reset	Description
16	SPARE8_WRITE_LOCK	RW1S	0x0	spare8_write_lock (slot 40): when set, spare8 is not write-able.
15	SPARE7_READ_LOCK	RW1S	0x0	spare7_read_lock (slot 39): when set, spare7 is not read-able.
14	SPARE7_WRITE_LOCK	RW1S	0x0	spare7_write_lock (slot 39): when set, spare7 is not write-able.
13	SPARE6_READ_LOCK	RW1S	0x0	spare6_read_lock (slot 38): when set, spare6 is not read-able.
12	SPARE6_WRITE_LOCK	RW1S	0x0	spare6_write_lock (slot 38): when set, spare6 is not write-able.
11	SPARE5_READ_LOCK	RW1S	0x0	spare5_read_lock (slot 37): when set, spare5 is not read-able.
10	SPARE5_WRITE_LOCK	RW1S	0x0	spare5_write_lock (slot 37): when set, spare5 is not write-able.
9	SPARE4_READ_LOCK	RW1S	0x0	spare4_read_lock (slot 36): when set, spare4 is not read-able.
8	SPARE4_WRITE_LOCK	RW1S	0x0	spare4_write_lock (slot 36): when set, spare4 is not write-able.
7	SPARE3_READ_LOCK	RW1S	0x0	spare3_read_lock (slot 35): when set, spare3 is not read-able.
6	SPARE3_WRITE_LOCK	RW1S	0x0	spare3_write_lock (slot 35): when set, spare3 is not write-able.
5	SPARE2_READ_LOCK	RW1S	0x0	spare2_read_lock (slot 34): when set, spare2 is not read-able.
4	SPARE2_WRITE_LOCK	RW1S	0x0	spare2_write_lock (slot 34): when set, spare2 is not write-able.
3	SPARE1_READ_LOCK	RW1S	0x0	spare1_read_lock (slot 33): when set, spare1 is not read-able.
2	SPARE1_WRITE_LOCK	RW1S	0x0	spare1_write_lock (slot 33): when set, spare1 is not write-able.
1	SPARE0_READ_LOCK	RW1S	0x0	spare0_read_lock (slot 32): when set, spare0 is not read-able.
0	SPARE0_WRITE_LOCK	RW1S	0x0	spare0_write_lock (slot 32): when set, spare0 is not write-able.

2.1.5.10.1.8.2.1.3. LC_STATE

Table 130. sep_efuse_map.LC_STATE fields

Bits	Field	Access	Reset	Description
31:8	rsvd	R	0x0	Unused
7:0	lc_state	R	0xF0	Life cycle manufacturing state, differentially encoded: {~raw[3:0], raw[3:0]}

2.1.5.10.1.8.2.1.4. SBOOT_DIS

Table 131. sep_efuse_map.SBOOT_DIS fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Unused
0	disable_secure_boot	R	0x0	Chicken bit to disable secure boot in SEP ROM.

2.1.5.10.1.8.2.1.5. TRANSIENT_RMA_EN

Table 132. sep_efuse_map.TRANSIENT_RMA_EN fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Unused
0	transient_rma_en	R	0x0	When Transient RMA EN is 1, matching on corresponding *_Tokens will automatically transfer the chip to the corresponding RMA state by setting the LC_STATE reg

2.1.5.10.1.8.2.1.6. SIP_DIS

Table 133. sep_efuse_map.SIP_DIS fields

Bits	Field	Access	Reset	Description
63:48	func_reserved	RW1S	0x0	Reserved for adopter-defined functional feature gating (bits 63:48).
47:25	debug_reserved_dbg2	RW1S	0x0	Reserved for adopter-defined inter-chiplet-bypass (DBG_2) debug scan chains (bits 47:25).
24	sip_debug	RW1S	0x0	SIP_DBG (bit 24): Coarse-grained debug enable for the SiP scope: the inter-chiplet debug-bypass gate that admits external (PTAP) debug traffic into this chiplet and forwards it onward to the next chiplet via the outbound JTAG PTAP. 1'b1: disabled. 1'b0: enabled.
23:4	debug_reserved_dbg1	RW1S	0x0	Reserved for adopter-defined local (DBG_1) debug scan chains (bits 23:4).
3	smc_fuse_dbg	RW1S	0x0	SMC_FUSE_DBG (bit 3): 1'b1: the DFT-inserted access path into the SMC OTP is disabled. 1'b0: enabled. Produced by SEP-LCC feat_ctrl_o, exported on the SEP boundary, and consumed by SMC to gate its own inserted fuse path.
2	sep_fuse_dbg	RW1S	0x0	SEP_FUSE_DBG (bit 2): 1'b1: the DFT-inserted access path into the SEP OTP is disabled. 1'b0: enabled. Also covers the OTP IP-vendor test and calibration interface, which is reachable only over that inserted path. The functional JTAG2AXIL path to the OTP is always available and is not gated by this bit.
1	chiplet_dbg	RW1S	0x0	CHIPLET_DBG (bit 1): Coarse-grained debug enable for the chiplet scope. 1'b1: chiplet-scope debug/scan-dump access disabled. 1'b0: enabled. Never acts alone: an external debugger reaches chiplet-internal resources only when SIP_DBG is open as well. Contributes to the reachability of the crypto/KM secure chain but never authorizes a dump from it.
0	sep_debug	RW1S	0x0	SEP_DBG (bit 0): Coarse-grained debug enable for the SEP scope. 1'b1: SEP-scope debug/scan-dump access disabled and external inbound traffic is filtered. 1'b0: enabled. A local gate only: reaching SEP internal state from an external debugger additionally requires SIP_DBG and CHIPLET_DBG.

2.1.5.10.1.8.2.1.7. SYS_DIS

Table 134. sep_efuse_map.SYS_DIS fields

Bits	Field	Access	Reset	Description
63:48	func_reserved	RW1S	0x0	Reserved for adopter-defined functional feature gating (bits 63:48).
47:25	debug_reserved_dbg2	RW1S	0x0	Reserved for adopter-defined inter-chiplet-bypass (DBG_2) debug scan chains (bits 47:25).
24	sip_debug	RW1S	0x0	SIP_DBG (bit 24): Coarse-grained debug enable for the SiP scope: the inter-chiplet debug-bypass gate that admits external (PTAP) debug traffic into this chiplet and forwards it onward to the next chiplet via the outbound JTAG PTAP. 1'b1: disabled. 1'b0: enabled.
23:4	debug_reserved_dbg1	RW1S	0x0	Reserved for adopter-defined local (DBG_1) debug scan chains (bits 23:4).
3	smc_fuse_dbg	RW1S	0x0	SMC_FUSE_DBG (bit 3): 1'b1: the DFT-inserted access path into the SMC OTP is disabled. 1'b0: enabled. Produced by SEP-LCC feat_ctrl_o, exported on the SEP boundary, and consumed by SMC to gate its own inserted fuse path.
2	sep_fuse_dbg	RW1S	0x0	SEP_FUSE_DBG (bit 2): 1'b1: the DFT-inserted access path into the SEP OTP is disabled. 1'b0: enabled. Also covers the OTP IP-vendor test and calibration interface, which is reachable only over that inserted path. The functional JTAG2AXIL path to the OTP is always available and is not gated by this bit.
1	chiplet_dbg	RW1S	0x0	CHIPLET_DBG (bit 1): Coarse-grained debug enable for the chiplet scope. 1'b1: chiplet-scope debug/scan-dump access disabled. 1'b0: enabled. Never acts alone: an external debugger reaches chiplet-internal resources only when SIP_DBG is open as well. Contributes to the reachability of the crypto/KM secure chain but never authorizes a dump from it.

Bits	Field	Access	Reset	Description
0	sep_debug	RW1S	0x0	SEP_DBG (bit 0): Coarse-grained debug enable for the SEP scope. 1'b1: SEP-scope debug/scan-dump access disabled and external inbound traffic is filtered. 1'b0: enabled. A local gate only: reaching SEP internal state from an external debugger additionally requires SIP_DBG and CHIPLET_DBG.

2.1.5.10.1.8.2.1.8. RMA_SIP_TOKEN_DIGEST

Table 135. sep_efuse_map.RMA_SIP_TOKEN_DIGEST fields

Bits	Field	Access	Reset	Description
255:0	token_digest	R	0x0	Hash digest of life cycle secret that allows entering RMA_SIP state / Note this is a 256 bit field

2.1.5.10.1.8.2.1.9. RMA_CHIPLET_TOKEN_DIGEST

Table 136. sep_efuse_map.RMA_CHIPLET_TOKEN_DIGEST fields

Bits	Field	Access	Reset	Description
255:0	token_digest	R	0x0	Hash digest of life cycle secret that allows entering RMA_CHIPLET state/ Note this is a 256 bit field

2.1.5.10.1.8.2.1.10. CLASS_KEY

Table 137. sep_efuse_map.CLASS_KEY fields

Bits	Field	Access	Reset	Description
255:0	key	R	0x0	Class key that could be used for FW encryption/decryption

2.1.5.10.1.8.2.1.11. CHIPLET_PUBK_REVOKE

Table 138. sep_efuse_map.CHIPLET_PUBK_REVOKE fields

Bits	Field	Access	Reset	Description
31:0	select	R	0x0	Global public-key revocation vector covering every boot-verification key of every owner (classical and PQC). SEP ROM embeds a set of public-key hash digests and accesses additional fused key hashes; each key entry maps to one bit here. Once set, SEP ROM rejects the corresponding key. Bit map: [7:0] ROM chiplet-creator classical keys (bits 0,1 are development keys); [15:8] ROM chiplet-creator PQC keys; [16]/[17] CHIPLET_PUBK_HASH0/1; [18]/[19] CHIPLET_PUBK_PQC_HASH0/1; [20]/[21] SIP_PUBK_HASH0 / SIP_PUBK_PQC_HASH0; [22]/[23] SYS_PUBK_HASH / SYS_PUBK_PQC_HASH; [24]/[25] SIP_PUBK_HASH1 / SIP_PUBK_PQC_HASH1; [31:26] reserved. Before the chiplet owner transfers a part to the customer, the development-key bits shall be set (revoked).

2.1.5.10.1.8.2.1.12. BL1_VERSION

Table 139. sep_efuse_map.BL1_VERSION fields

Bits	Field	Access	Reset	Description
255:0	version	R	0x0	Minimum BL1 version that can be loaded by SEPROM

2.1.5.10.1.8.2.1.13. BL2_VERSION

Table 140. sep_efuse_map.BL2_VERSION fields

Bits	Field	Access	Reset	Description
255:0	version	R	0x0	Minimum BL2 version that can be loaded by BL1. If more boot stages exist, rollback protection can be implemented by BL2.

2.1.5.10.1.8.2.1.14. CHIPLET_UID

Table 141. sep_efuse_map.CHIPLET_UID fields

Bits	Field	Access	Reset	Description
255:0	uid	R	0x0	Silicon creator's secret device unique ID (also referred to as UDS - Unique Device Secret). The chiplet creator is responsible for CHIPLET_UID provisioning and public identity enrollment. When read-locked, both writability and software visibility are disabled.

2.1.5.10.1.8.2.1.15. SIP_PUBK_HASH0

Table 142. sep_efuse_map.SIP_PUBK_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of SiP owner's root public key for secure boot. The chiplet creator's actual root public key is embedded in the SEPROM; this digest is used to validate that public key.

2.1.5.10.1.8.2.1.16. SIP_UID

Table 143. sep_efuse_map.SIP_UID fields

Bits	Field	Access	Reset	Description
255:0	uid	R	0x0	SiP owner's secret device unique ID. The SiP owner is responsible for SIP_UID provisioning and public identity enrollment. When read-locked, both writability and software visibility are disabled.

2.1.5.10.1.8.2.1.17. SYS_PUBK_HASH

Table 144. sep_efuse_map.SYS_PUBK_HASH fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of system owner's root public key for secure boot.

2.1.5.10.1.8.2.1.18. SYS_UID

Table 145. sep_efuse_map.SYS_UID fields

Bits	Field	Access	Reset	Description
255:0	uid	R	0x0	System owner's secret device unique ID. The system owner is responsible for SYS_UID provisioning and public identity enrollment. When read-locked, both writability and software visibility are disabled.

2.1.5.10.1.8.2.1.19. STATUS_RPT

Table 146. sep_efuse_map.STATUS_RPT fields

Bits	Field	Access	Reset	Description
31:2	reserved	R	0x0	reserved
1:0	rpt	R	0x0	BOOTROM report status based on the bit. 2'b00→ bootrom report status based on GPIO; 2'b01→bootrom report status;otherwise, bootrom does not report status

2.1.5.10.1.8.2.1.20. ROM_CTL

Table 147. sep_efuse_map.ROM_CTL fields

Bits	Field	Access	Reset	Description
31:6	reserved	R	0x0	reserved
5:1	rom_swap_ctrl	R	0x0	controls how the rom slices are swapped
0	rom_endianness_ctrl	R	0x0	controls the endianness of the rom data out. 0→little endian; 1→big endian

2.1.5.10.1.8.2.1.21. SYSCLK_FREQ_MHZ

Table 148. sep_efuse_map.SYSCLK_FREQ_MHZ fields

Bits	Field	Access	Reset	Description
31:11	rsvd	R	0x0	Reserved
10:0	sysclk_freq_mhz	R	0x0	Configured sysclk PLL frequency in MHz; ignored if 0. Consumed by boot ROM clock math.

2.1.5.10.1.8.2.1.22. CHIPLET_PUBK_HASH0

Table 149. sep_efuse_map.CHIPLET_PUBK_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner authentication key hash digest, fused. These chiplet owner fused key hashes can be used in addition to the hashes in the ROM itself to authenticate manifests.

2.1.5.10.1.8.2.1.23. CHIPLET_PUBK_HASH1

Table 150. sep_efuse_map.CHIPLET_PUBK_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner authentication key hash digest, fused. These chiplet owner fused key hashes can be used in addition to the hashes in the ROM itself to authenticate manifests.

2.1.5.10.1.8.2.1.24. REQUIRED_SIGNERS

Table 151. sep_efuse_map.REQUIRED_SIGNERS fields

Bits	Field	Access	Reset	Description
31:2	reserved	R	0x0	Reserved
1:0	required_signers	RW1S	0x0	Owners whose signature is required to authenticate any image loadable by SEP ROM. Per owner, 1 = required, 0 = not-required; the default all-zero value requires no additional owner. [0] SiP owner, [1] system owner. The chiplet creator is the root of trust and always authenticates BL1, so it has no bit here.

2.1.5.10.1.8.2.1.25. REQUIRED_ALGS

Table 152. sep_efuse_map.REQUIRED_ALGS fields

Bits	Field	Access	Reset	Description
31:12	reserved	R	0x0	Reserved
11:8	sys_algs	RW1S	0x0	Per-owner required signature algorithms for system owner. bit 0 = classical, bit 1 = post-quantum (ML-DSA), bits 3:2 reserved.
7:4	sip_algs	RW1S	0x0	Per-owner required signature algorithms for SiP owner. bit 0 = classical, bit 1 = post-quantum (ML-DSA), bits 3:2 reserved.
3:0	chiplet_algs	RW1S	0x0	Per-owner required signature algorithms for chiplet. Each nibble: bit 0 = classical (ECDSA P-384 or RSA), bit 1 = post-quantum (ML-DSA), bits 3:2 reserved.

2.1.5.10.1.8.2.1.26. CHIPLET_PUBK_PQC_HASH0

Table 153. sep_efuse_map.CHIPLET_PUBK_PQC_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner ML-DSA PQC authentication key hash digest, fused. PQC counterpart of the corresponding CHIPLET_PUBK_HASH.

2.1.5.10.1.8.2.1.27. CHIPLET_PUBK_PQC_HASH1

Table 154. sep_efuse_map.CHIPLET_PUBK_PQC_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner ML-DSA PQC authentication key hash digest, fused. PQC counterpart of the corresponding CHIPLET_PUBK_HASH.

2.1.5.10.1.8.2.1.28. SIP_PUBK_PQC_HASH0

Table 155. sep_efuse_map.SIP_PUBK_PQC_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of the SiP owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SIP_PUBK_HASH.

2.1.5.10.1.8.2.1.29. SYS_PUBK_PQC_HASH

Table 156. sep_efuse_map.SYS_PUBK_PQC_HASH fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of the system owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SYS_PUBK_HASH.

2.1.5.10.1.8.2.1.30. SIP_PUBK_HASH1

Table 157. sep_efuse_map.SIP_PUBK_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of SiP owner's root public key for secure boot. The chiplet creator's actual root public key is embedded in the SEPROM; this digest is used to validate that public key.

2.1.5.10.1.8.2.1.31. SIP_PUBK_PQC_HASH1

Table 158. sep_efuse_map.SIP_PUBK_PQC_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of the SiP owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SIP_PUBK_HASH.

2.1.5.10.1.8.2.1.32. SEP_CHIPLET_ID

Table 159. sep_efuse_map.SEP_CHIPLET_ID fields

Bits	Field	Access	Reset	Description
255:0	id	R	0x0	Per-owner public identity fuse. Personalization input for the Key Manager identity root. Being public, no read protection is required. Individually lockable via LOCKS[58:63] (slots 29-31).

2.1.5.10.1.8.2.1.33. SEP_SIP_ID

Table 160. sep_efuse_map.SEP_SIP_ID fields

Bits	Field	Access	Reset	Description
255:0	id	R	0x0	Per-owner public identity fuse. Personalization input for the Key Manager identity root. Being public, no read protection is required. Individually lockable via LOCKS[58:63] (slots 29-31).

2.1.5.10.1.8.2.1.34. SEP_SYS_ID

Table 161. sep_efuse_map.SEP_SYS_ID fields

Bits	Field	Access	Reset	Description
255:0	id	R	0x0	Per-owner public identity fuse. Personalization input for the Key Manager identity root. Being public, no read protection is required. Individually lockable via LOCKS[58:63] (slots 29-31).

2.1.5.10.1.8.2.1.35. spare0

Table 162. sep_efuse_map.spare0 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.36. spare1

Table 163. sep_efuse_map.spare1 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.37. spare2

Table 164. sep_efuse_map.spare2 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.38. spare3

Table 165. sep_efuse_map.spare3 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.39. spare4

Table 166. sep_efuse_map.spare4 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.40. spare5

Table 167. sep_efuse_map.spare5 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.41. spare6

Table 168. sep_efuse_map.spare6 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.42. spare7

Table 169. sep_efuse_map.spare7 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.1.8.2.1.43. spare8

Table 170. sep_efuse_map.spare8 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.10.2. Token Processing

SEP uses 256-bit tokens to authorize RMA lifecycle transitions and emergency security disable. The OTP controller hashes each submitted token with SHA-256 and compares the digest with the expected value. Plaintext tokens are held in three separate, non-scannable eight-word arrays in the eFuse MMR block. These arrays have no reset; reset is not a token-erasure operation.

2.1.5.10.2.1. Token Generation, Storage and Provisioning

Generate and retain plaintext tokens within a hardware security module (HSM), using its secure random-generation and derivation facilities. Keep token processing inside the HSM except for final provisioning, and protect transfer to the manufacturing tester. Provision the RMA token digests, not plaintext tokens, into OTP at manufacturing test. Provisioning policy may use a common token or a distinct token per device; the matching mechanism supports either.

Track each token and its SHA-256 digest separately. Token confidentiality and entropy protect authorization; expected-digest integrity prevents substitution of a digest for a token an attacker knows. The hardware-embedded SEC_DIS digest is common to devices using that design. Bind it under controlled implementation procedures; it does not require the plaintext token in the RTL database.

2.1.5.10.2.2. Token Matching Mechanism and Attack Countermeasures

Table 171. Token roles and expected digests

Token	Purpose	Expected digest
RMA_SIP_TOKEN	Authorize SiP RMA transitions	`RMA_SIP_TOKEN_DIGEST` in OTP
RMA_CHIPLET_TOKEN	Authorize chiplet RMA transitions	`RMA_CHIPLET_TOKEN_DIGEST` in OTP
SEC_DIS_TOKEN	Emergency debug access to a part whose fuse sensing fails	Hardware constant, independent of OTP

Each token has a dedicated SHA-256 engine and three redundant digest comparators:

```
match = (SHA256(token[255:0]) == expected_digest[255:0])
```

Hashing is sequential; the digest comparison is combinational. The computed digest and its valid bit survive reset. A new start clears validity; hash completion replaces the digest. Test enable freezes those retained latches. The presented token and expected digest must not enter scannable storage.

RMA comparisons require both a valid computed digest and completed fuse sensing, because their expected values come from OTP shadows. SEC_DIS requires only a valid digest: its expected value is implemented in gates, so a SEC_DIS match holds before fuse sensing completes. A match forces feature control on, stops fuse sensing, and opens eFuse shadow-map reads. It does not release SEP reset; the IC_RESET `sep_reset_n` override does. The SEC_DIS recovery sequence is in the Programmer's Guide. SEC_DIS follows the feature-control rules in the Lifecycle Controller chapter, with the metal-programmable enable also required. The design requirement is A0-only use and permanent removal by a metal-mask ECO in later A1/B0 revisions; this is not a software-disable mechanism. See Security Disable (SEC_DIS).

2.1.5.10.2.3. Token Submission

SEP software or JTAG submits tokens through the eFuse MMR interface, subject to its access policy. Register names and start bits are:

Table 172. Token submission registers

Eight-word input array	TOKEN_EOP bit	Result register
RMA_SIP_TOKEN_I	0	RMA_SIP_TOKEN_MATCH
RMA_CHIPLET_TOKEN_I	8	RMA_CHIPLET_TOKEN_MATCH
SEC_DISABLE_TOKEN_I	16	SEC_DISABLE_TOKEN_MATCH

Index 0 of an input array holds token[31:0] and index 7 holds token[255:224]; the hash engine consumes index 7 first, down to index 0, without a byte swap. A write of 1 to a TOKEN_EOP bit generates a start pulse, and the engine then streams the array rather than taking a snapshot. RMA results remain idle until fuse sensing completes. The token submission sequence is in the Programmer's Guide.

There is no submission queue: the feeder accepts a new operation only while idle. Starting a hash clears retained digest validity, so comparison returns idle while the new digest is unavailable. The result register follows the comparator through a clocked output stage; writing the token words alone does not invalidate the previous result or launch a comparison.

Table 173. Token result encodings

Result	Six-bit value	Meaning
Idle	0x00 (000000)	No valid comparison; hashing or fuse sensing may be pending
Match	0x15 (010101)	All three comparators report equal digests
Mismatch	0x2a (101010)	All three comparators report unequal digests
Error	0x3f (111111)	A differential-pair or comparator-agreement fault is present

Reset clears the registered result and sticky fault flags, but does not erase the input arrays, retained digest or digest-valid state. A retained digest can therefore produce a result again after reset once its comparison prerequisites hold, so reset alone does not revoke a prior token authorization.

2.1.5.10.2.4. Matching Logic Countermeasures

The three comparators provide differential outputs. When comparison is valid, each pair must contain opposite values and all three instances must agree. A collapsed pair or disagreement raises a redundancy fault and forces the current comparator result to 0x3f, which does not satisfy a match check. This is not majority voting: two matching instances cannot overrule a third.

Each fault also sets a software-read-only flag in TOKEN_MATCH_FAULT: bit 0 for SiP RMA, bit 8 for chiplet RMA and bit 16 for SEC_DIS. These flags remain set until reset and combine into SEP CPU PIC source 40; there is no write-one-to-clear operation to deassert the source. See SEP CPU Interrupt Vector Map.

The sticky flag records fault history; it does not latch the comparator into an error state. A later valid comparison can report match or mismatch while the fault flag and interrupt remain asserted.

The detector does not cover common-mode faults. If all three instances flip in the same way while retaining legal differential pairs, they still agree. Inverting a mismatch can therefore produce an undetected match (fail-open); inverting a match produces a mismatch. The countermeasure detects collapsed pairs and disagreement, not every possible fault-injection outcome.

Figure 27 shows the processing path. The six-bit RMA match codes are checked by the lifecycle and fuse-programming consumers. SEC_DIS has a separate bypass output qualified by the revision enable.




Figure 27. SEP token processing

Each of the three rows in Figure 27 is one token lane, from its token array and go bit in `efuse_mmr_reg`, through its SHA-256 engine, to its comparator. The expected digests and `fuse_sense_done_i` are named at their point of use; both come from the eFuse shadow registers at the lower left. `fuse_sense_done_i` gates only the two RMA comparators. The comparators' match codes and the sticky fault bits are also readable in the `*_TOKEN_MATCH` and `TOKEN_MATCH_FAULT` status registers. The RMA_CHIPLET match line crosses the RMA_SIP fault line without connecting; the gap marks the crossing.

2.1.5.10.2.5. Post Token Matching Handling

An RMA match authorizes a lifecycle change; it does not itself burn a fuse. The controller gates RMA fuse programming with the corresponding token match. For shadow-state transitions, software can request an explicit update, or `TRANSIENT_RMA_EN` can enable automatic updates. The chiplet-RMA shadow transition also requires RMA_SIP to be established first. See OTP Fuse Controller for lock exceptions and transition rules. SEC_DIS instead activates the emergency bypass while its match and revision-enable conditions hold.

2.1.5.10.3. Security Disable (SEC_DIS)

Security Disable (SEC_DIS) is an emergency bring-up bypass for early (A0) silicon. On deassertion of power-on reset, the fuse sense logic runs before anything else, and a malfunction there — the fuse state machine hanging, or invalid values being written into the shadow register bank — would leave the life-cycle control closed and turn the chiplet into a disabled ``brick''. SEC_DIS provides a secure unlock mechanism to recover such a part for debug: it overrides the life-cycle control, forcing all feature-control bits on regardless of the LC state and the SIP_DIS / SYS_DIS disables.

SECURE_TM is not a term in the feature-control computation, so SEC_DIS neither qualifies nor overrides it. In particular,

SEC_DIS does not open the secure scan chain to a dump: that chain admits only test commands, and only at `secure_tm = 1`, independently of the feature-control bits (see the Lifecycle Controller chapter, *`secure_tm` and the Secure Scan Chain*).

2.1.5.10.3.1. Token Activation

SEC_DIS is activated by presenting a secret token: SEC_DIS_TOKEN_I is passed into the SEP via the JTAG port, hashed, and redundantly compared against an embedded hash constant. On a match, i.e. hash(SEC_DIS_TOKEN_I) == SEP_SEC_DISABLE_TOKEN_DIGEST, the life-cycle control is overridden to open debug access, and the feature-control output follows the SEC_DIS rules in the Lifecycle Controller chapter. A match does not release the SEP reset, which stays held until fuse sensing completes. To boot a part whose fuse sensing does not complete, override `sep_reset_n` through the SEP slice of the IC_RESET TDR (see Section 2.1.7.3.3 in the DTP chapter). The override and the token match are independent JTAG steps: the override alone releases the reset but leaves the life-cycle control closed, so recovering such a part for debug takes both.

2.1.5.10.3.2. Fuse Sensing and the Shadow Map

While a SEC_DIS match holds:

- Automatic fuse sensing does not start, and sensing already in progress stops. No further fuse words are loaded into the shadow registers, and fuse sensing does not complete.
- A read of the eFuse shadow map over the SEP bus completes with OKAY.
- The SMC eFuse controller receives the SEP security-disable status, so SMC fuse sensing stops and the SMC shadow map opens in the same way.

2.1.5.10.3.3. Reset Persistence

The token arrays, the computed digest and its valid bit survive reset, so a match established before a cold reset holds from cold-reset release. Fuse sensing then does not start, every shadow register keeps its reset value instead of the partial contents of an interrupted sense, and SEP samples the secure test-mode request one cycle after cold-reset release instead of at fuse-sensing completion. A match established without a following cold reset leaves the shadow registers holding whatever the failed sense loaded, and the secure test-mode request is never sampled. The SEC_DIS recovery sequence is in the Programmer's Guide.

2.1.5.10.3.4. Silicon Revision Scope

SEC_DIS is intended for A0 silicon only and is removed in later revisions (A1/B0) by a simple metal-mask ECO: the token comparator's enable is implemented in a metal-programmable revision cell, strapped to 1 (comparator enabled) in A0 silicon and re-strapped to 0 at top metal in later revisions, so the feature is killed without a re-spin.

2.1.5.10.3.5. Implementation Requirements

- The token secret itself is never stored in RTL; the RTL stores only the token hash value, and the hardware forces every presented token through the hash engine before the digest comparison — there is no path that presents a digest to the comparator directly. The 256-bit SEP_SEC_DISABLE_TOKEN_DIGEST constant is therefore not itself a secret (recovering the token from it requires a SHA-256 preimage): it may be publicly known and may be carried in plain RTL. It resides in the fuse controller component hardware gates (*not the OTP fuse bank*).
- The comparison logic must be purely combinational, and the SEP_SEC_DISABLE_TOKEN_DIGEST constant must never be latched into any potentially scannable register. This is an integrity requirement, not confidentiality: the expected digest must not be perturbable — for example scan-shifted — into a value whose preimage an attacker knows.

- The JTAG-accessible register holding the token input values (SEC_DIS_TOKEN_I, RMA_SIP_TOKEN_I, and RMA_CHIPLET_TOKEN_I) ***shall not have a reset***, so that the SEC_DIS state is retained across reset for early-event debug. That register must also not be scannable: DFT scan tests may be running while SEC_DIS is asserted, and a scan pattern must not inadvertently overwrite the register — dropping the security unlock and stopping the test.
- The secrecy of the scheme rests entirely on the SEC_DIS_TOKEN value, never on the hash. The token shall be a full-entropy 256-bit random value, and knowledge of it shall be strictly controlled: it shall be generated and stored in a secure database (HSM). Because only its integrity matters, the SEP_SEC_DISABLE_TOKEN_DIGEST may be bound at any convenient point in the implementation flow — for example as an RTL parameter passed down the instance hierarchy (chiplet top to SMU to SEP to fuse controller). One member of the DV team shall perform final verification of the SEC_DIS_TOKEN functionality on the post-layout extracted netlist with ***gate-level simulation***.

2.1.5.10.4. Life Cycle Controller (LCC)

The Life Cycle Controller (LCC) converts the OTP lifecycle state and owner restrictions into `feat_ctrl_o`, the 64-bit vector that enables debug and functional features. Two volatile demotion controls can change the debug profile for the current boot without changing OTP.

The OTP controller supplies `LC_STATE`, `SIP_DIS` and `SYS_DIS` after fuse sensing. The LCC checks the differentially encoded state and disables features on an integrity error, except when the final `SEC_DIS` override forces them on. Downstream logic uses these outputs to gate debug, test and functional paths.

The sections below explain states and security domains, feature-control rules, demotion, scan protection and firmware authorization. Hardware gating is implemented; the multi-owner signing model in Firmware Authorization is a deferred firmware design. Do not use that model as a description of current ROM verification.

Figure 28 shows a high-level view of the Life Cycle Controller components.




Figure 28. SEP lifecycle controller

In Figure 28, the inputs enter on the left and the outputs leave on the right, each labelled with its consumer.

u_lc_state_dec decodes the differentially encoded LC_STATE from the eFuse shadow registers and raises lc_sigint_err on a non-complementary codeword, which forces the feature control decode to all zeros. While security_disable_i is high, the multiplexer replaces the decoded vector with all ones, even on an integrity error. The lc_sigint_err line crosses the security_disable_i line without connecting; the gap marks the crossing.

The debug and DFT disable derivation turns the sip_debug, chiplet_dbg, sep_debug, sep_fuse_dbg and smc_fuse_dbg bits of the result into the 11 debug disables for the DTP and the two fuse DFT disables. No functional logic consumes the fuse DFT disables; they leave the SMU for adopter DFT insertion. The demote and lock bits of DEMOTE_1 and DEMOTE_2 are set-only: firmware can set demote only while lock is clear, and both hold until SEP cold reset. The demote bits feed the feature control decode and, through the differential encoders, the Key Manager and the SEP outputs.

2.1.5.10.4.1. Lifecycle States

The LCC decodes the OTP controller's LC_STATE shadow output; it does not sequence lifecycle transitions itself. Before fuse sensing completes, that output holds INVALID (4'b1111). The LCC then follows the sensed state and its feature-control profile.

The raw four-bit OTP value is carried as a complementary code in the shadow path. A failed integrity check sets lc_sigint_err and forces the base feature vector to zero. SEC_DIS is applied afterward and can override that result; see Section 2.1.5.10.4.3.5.

Hardware orders the RMA token transitions: RMA_SIP_TOKEN first admits RMA_SIP, then RMA_CHIPLET_TOKEN admits RMA_CHIPLET. Volatile demotion is separate from those transitions and does not change the OTP state.

Key Manager includes DEMOTE_1/2 with CHIPLET_UID, SIP_UID, SYS_UID and LC_STATE in key derivation, separating demoted-state keys from non-demoted production keys.

Figure 29 shows the lifecycle states and transition paths.




Figure 29. SEP lifecycle state machine

Each rounded box in Figure 29 is a lifecycle state with its raw OTP encoding, where X marks a bit that does not change the state. LC_STATE bits can only be set, so each arrow names the bit that it sets. Setting LC_STATE[1] requires an RMA_SIP token match. Setting LC_STATE[2] requires an RMA_CHIPLET token match and a state that already has LC_STATE[1] set. Every other encoding is INVALID and permanent: for example, setting LC_STATE[3] in any state other than TEST_DEV, or setting any further bit in PROD_END. Before fuse sensing completes, the shadow output holds the INVALID encoding 4'b1111. The dashed box is the volatile demotion overlay, which acts in TEST_DEV and PROD without changing the encoding.

Table 174 lists the raw OTP encodings. The complementary shadow encoding is a transport integrity check, not an additional lifecycle state.

Table 174. SEP lifecycle state encodings

LC State Name	Encoding	Description
TEST_DEV	4'b0000	Default silicon state at manufacturing time. The chip is open for ATE/SLT testing, fuse provisioning, and mission-mode software development, with certain chiplet features disabled as defined by the chiplet creator, the SiP owner, and the system owner. In this state, the hash digests of the secret tokens (RMA_CHIPLET_TOKEN and RMA_SIP_TOKEN) are programmed into OTP by the chiplet creator and the SiP owner, respectively. The disable vectors (SIP_DIS and SYS_DIS) are likewise programmed into OTP by the chiplet creator and the SiP owner.

LC State Name	Encoding	Description
PROD	4'b0001	Product functioning state. In-field debug is enabled by the volatile DEMOTE_1 / DEMOTE_2 registers (not a separate LC encoding): DEMOTE_1 opens the local debug group (DBG_1) and DEMOTE_2 opens the inter-chiplet debug-bypass group (DBG_2). See Section 2.1.5.10.4.4.
PROD_END	4'b1000	Terminal product state; the only permitted transition is to INVALID. This state is entered from TEST_DEV for special use cases in which RMA is not allowed.
RMA_SIP	4'b001X	Enables the SiP owner to debug and test the part. The secret token (RMA_SIP_TOKEN) must be presented to enable the transition from PROD or TEST_DEV.
RMA_CHIPLET	4'b011X	Enables the chiplet owner to debug and test the part. All features are enabled (neither SIP_DIS nor SYS_DIS applies), unlike TEST_DEV, which still honors SIP_DIS/SYS_DIS. The secret token (RMA_CHIPLET_TOKEN) must be presented to enable the transition from RMA_SIP.
INVALID	All other values	Disables all features unless SEC_DIS overrides it. Also used before fuse sensing completes; observing this profile alone does not establish that the OTP has been programmed to an end-of-life state.

2.1.5.10.4.2. Multiple Security Domains

The SiP owner controls the debug-access network between chiplets. Each chiplet owner controls access to its own local assets. A system has one shared SiP-owner domain and a local domain for each chiplet with independently protected assets.

`SIP_DBG` admits and forwards external debug traffic at each chiplet with a local SEP/LCC. Access to local resources additionally requires `CHIPLET_DBG`; SEP resources also require `SEP_DBG`. Opening another chiplet's local debug gate is unnecessary when traffic only passes through it.

A chiplet without a local SEP/LCC contributes no local disable vector. The preceding LCC-bearing chiplet controls forwarding to it, as described in Section 2.1.5.10.4.6.




Figure 30. SEP security domains

In Figure 30, each chiplet with a SEP gates the debug path from its PTAP downwards: SIP_DBG opens the Case 1 targets, CHIPLET_DBG adds the Case 2 targets and SEP_DBG adds the Case 3 targets, each listed to the right of its gate. The targets are the debug paths that `sep_lifecycle_ctrl` disables through `dbg_disable_o` and the two fuse DFT disables, as given in Section 2.1.5.10.4.5.4; the fuse DFT paths also need their own SEP_FUSE_DBG or SMC_FUSE_DBG bit. The green gate belongs to the SiP-owner domain and is a DBG_2 bit, opened in the field by Demotion 2. The cream gates belong to the chiplet-owner domain and are DBG_1 bits, opened by Demotion 1. The I/O STAP forwards the chain to the next chiplet's PTAP.

In Figure 30, chiplet 1 is primary, chiplet 2 has no SEP, and chiplet 3 has its own LCC:

- Chiplet 1 local debug requires `SIP_DBG(1)` and `CHIPLET_DBG(1)`.
- Chiplet 2 access requires `SIP_DBG(1)`; chiplet 2 adds no local gate.
- Chiplet 3 local debug requires `SIP_DBG(1)`, `SIP_DBG(3)` and `CHIPLET_DBG(3)`. It does not require `CHIPLET_DBG(1)`.

The per-path conjunctions are listed in Section 2.1.5.10.4.5.4.

2.1.5.10.4.3. Debug and Functional Feature Control

`feat_ctrl_o` uses positive logic: 1 enables a feature. The 64-bit `SIP_DIS` and `SYS_DIS` shadows use negative logic: 1 restricts a feature. The applicable masks depend on lifecycle state and demotion. Where both apply, the enable is `~(SIP_DIS | SYS_DIS)`.

Table 177 gives the complete state-dependent formulas. The final `SEC_DIS` override is described in Section 2.1.5.10.4.3.5.

2.1.5.10.4.3.1. Disable Vector Format (SIP_DIS / SYS_DIS)

Table 175 defines the **disable** vector format — the bit layout shared by both SIP_DIS and SYS_DIS (each is 64 bits). Each defined bit gates a specific feature or its associated scan chain; the remaining bits are reserved for adopter extension (see Section 2.1.5.10.4.5 and Section 2.1.5.10.4.7).

In the policy tables, T means enabled and F means disabled. A clear disable bit permits a feature only where the lifecycle profile allows it; it does not by itself open a production debug path.

DBG_1 covers [23:0] and is controlled by Demotion 1. DBG_2 covers [47:24] and is controlled by Demotion 2. Function bits occupy [63:48].

Table 175. SEP feature-disable vector

DIS bit index	Feature Category	Feature Name	Feature Description (1'b1 disables the feature; 1'b0 enables it)
0	debug (DBG_1)	SEP_DBG	Coarse-grained debug enable for the **SEP** scope: the local gate for SEP internal state. 1'b1: SEP-scope debug / scan-dump access disabled and inbound (ext) traffic is filtered before it can reach SEP internal state. 1'b0: enabled — inbound traffic bypasses the filter and scan dump is allowed. SEP_DBG is a local gate, not the chiplet ingress: SIP_DBG (bit 24) admits external debug traffic into the chiplet, CHIPLET_DBG (bit 1) admits it to chiplet-internal resources, and SEP_DBG then governs whether it can reach SEP internal state. Debugging SEP assets from an external debugger therefore requires **all three** — Case 3 of Section 2.1.5.10.4.5.4 — not SEP_DBG alone.
1	debug (DBG_1)	CHIPLET_DBG	Coarse-grained debug enable for the **chiplet** scope. 1'b1: chiplet-scope debug / scan-dump access disabled. 1'b0: enabled. Never acts alone: an external debugger reaches chiplet-internal resources only when SIP_DBG is open as well (Case 2 of Section 2.1.5.10.4.5.4). Contributes to the reachability of the crypto / KM secure chain but never authorizes a dump from it: that chain admits only test commands, and only while secure_tm = 1. In TEST_DEV and RMA_SiP, this bit set in SIP_DIS or SYS_DIS makes the production ROM enforce secure boot; it has no such effect in RMA_CHIPLET. See Firmware Authorization.
2	debug (DBG_1)	SEP_FUSE_DBG	1'b1: the DFT-inserted access path into the SEP OTP is disabled. 1'b0: enabled. This gate also covers the OTP IP-vendor test and calibration interface (used during ATE for vendor-specific OTP test functions and internal-voltage calibration), which is reachable only over that inserted path. The functional JTAG2AXIL path to the OTP is always available and is not gated by this bit.
3	debug (DBG_1)	SMC_FUSE_DBG	1'b1: the DFT-inserted access path into the SMC OTP is disabled. 1'b0: enabled. (The bit is produced by SEP-LCC's feat_ctrl_o, exported on the SEP boundary, and consumed by SMC to gate its own inserted fuse path.)
4-23	debug (DBG_1)	*Reserved*	Available for adopter-defined local (DBG_1) debug scan chains. See Section 2.1.5.10.4.7.
24	debug (DBG_2)	SIP_DBG	Coarse-grained debug enable for the **SiP** scope: the inter-chiplet debug-bypass gate (DBG_2, gated by Demotion 2) that admits external (PTAP) debug traffic into this chiplet and forwards it onward to the next chiplet via the outbound JTAG PTAP. Debugging a chiplet's assets requires SIP_DBG enabled on each LCC-bearing chiplet along the debug path, including the target itself when it has its own LCC; chiplets without a local SEP/LCC contribute no gate (see Section 2.1.5.10.4.2). 1'b1: disabled. 1'b0: enabled.
25-47	debug (DBG_2)	*Reserved*	Available for adopter-defined inter-chiplet debug / DFT forwarding paths. Each allocated bit is consumed on the LCC-bearing chiplet to gate the corresponding traffic before it is forwarded downstream. See Section 2.1.5.10.4.7.
48-63	function	*Reserved*	Available for adopter-defined functional feature gating. See Section 2.1.5.10.4.7.

2.1.5.10.4.3.2. DIS Vector Ownership: Predecessor-Programs-Disables

The vector name identifies the receiving owner, not the programmer:

- The chiplet creator programs SIP_DIS before SiP handoff. Its restrictions remain effective in RMA_SIP and are bypassed in RMA_CHIPLET.
- The SiP owner programs SYS_DIS before system handoff. Its restrictions are bypassed in RMA_SIP and RMA_CHIPLET.

RMA bypass does not erase either fuse vector. The system owner has no successor and therefore no third disable vector.

It provisions its own SYS_PUBK_HASH and SYS_UID before TEST_DEV-to-PROD transition; see the OTP Fuse Controller chapter for the provisioning sequence.

2.1.5.10.4.3.3. Combining Rule: OR then Invert

Where both owner masks apply, a feature is disabled if either mask has its bit set. OR combines the restrictions; inversion produces the positive-logic enable. Since an OTP bit can only change from 0 to 1, a later owner cannot erase an earlier owner's programmed restriction. Lifecycle profiles can bypass masks for RMA access without changing OTP.

2.1.5.10.4.3.4. When Each DIS Vector Applies

The table below gives mask applicability before demotion and the final overrides. In TEST_DEV, demotion can bypass the masks for its debug group; in PROD, demotion opens that group only subject to both masks. See Table 177 for those exceptions.

Table 176 identifies which disable vectors apply in each lifecycle state.

Table 176. SEP disable-vector applicability

LC state	Applicable DIS vectors
TEST_DEV	Both SIP_DIS and SYS_DIS apply. TEST_DEV is the shared phase the part passes through under the chiplet creator, SiP owner, and system owner in turn.
PROD / PROD_END	Both SIP_DIS and SYS_DIS apply.
RMA_SIP	Only SIP_DIS applies. At the SiP-owner level, the SiP owner sits **above** the system owner, so its own SYS_DIS — which restricts the system owner — does not bind it; only the chiplet creator's SIP_DIS restriction remains in force.
RMA_CHIPLET	Neither SIP_DIS nor SYS_DIS apply (all features enabled).
INVALID	Neither applies (all features disabled by fail-closed default).
(any) with SEC_DIS = 1	Neither DIS vector applies (all features enabled).

2.1.5.10.4.3.5. Overrides and Final Gates (SEC_DIS)

Two controls sit **on top of** the per-LC-state / DIS-vector computation, applied in this order (a later step overrides an earlier one):

1. **Signal-integrity fail-closed (base):** if the differentially encoded LC_STATE fails its integrity check (`lc_sigint_err`), the base `feat_ctrl` is forced to all-0s (all features disabled).
2. **SEC_DIS override:** when `SEC_DIS = 1`, `feat_ctrl` is forced to all-1s — every feature enabled, regardless of the LC state, the DIS vectors, or the sigint result (an emergency bring-up bypass on A0 silicon; see the Security Disable section).

`SECURE_TM` is **not** a term in `feat_ctrl_o`. No feature control bit is qualified by secure test mode: the debug group `[47:0]` and the function group `[63:48]` are both determined solely by the LC state, the DIS vectors, and the SEC_DIS override. `secure_tm` acts on the scan path and on the fuse controller rather than on feature control — see Section 2.1.5.10.4.5.2.

2.1.5.10.4.3.6. Per-LC-state Feature Control Profile

The output is shown as DBG_1 / DBG_2 / Function. `T` enables all bits of a group; `F` disables them. A formula applies the indicated disable masks. Demotion has no effect on Function.

Table 177. Per-LC-state feature control profile

LC_STATE	SEC_DIS	DEMOTE (1 / 2)	Feature Control: \{DBG_1 / DBG_2 / Function}	Description
TEST_DEV (4'b0000)	0	0 / 0	~(SIP_DIS.DBG_1 | SYS_DIS.DBG_1) / ~(SIP_DIS.DBG_2 | SYS_DIS.DBG_2) / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	ATE/SLT test, fuse provisioning (SIP_DIS / SYS_DIS and the RMA tokens), and product firmware development. Both SIP_DIS and SYS_DIS apply; a demotion forces its debug group open, overriding the DIS vectors. Function is not affected by demotion.
	0	1 / 0	T / ~(SIP_DIS.DBG_2 | SYS_DIS.DBG_2) / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	
	0	0 / 1	~(SIP_DIS.DBG_1 | SYS_DIS.DBG_1) / T / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	
	0	1 / 1	T / T / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	
	1	X	T / T / T	
PROD (4'b0001)	0	0 / 0	F / F / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	Product state. A demotion relaxes its debug group to honor the DIS vectors (one level down from disabled). Both SIP_DIS and SYS_DIS still apply; Function is not affected by demotion.
	0	1 / 0	~(SIP_DIS.DBG_1 | SYS_DIS.DBG_1) / F / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	
	0	0 / 1	F / ~(SIP_DIS.DBG_2 | SYS_DIS.DBG_2) / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	
	0	1 / 1	~(SIP_DIS.DBG_1 | SYS_DIS.DBG_1) / ~(SIP_DIS.DBG_2 | SYS_DIS.DBG_2) / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	
	1	X	T / T / T	
PROD_END (4'b1000)	0	—	F / F / ~(SIP_DIS.FUNC | SYS_DIS.FUNC)	Terminal product state — normal function only; the only permitted transition is to INVALID. Demotion has no effect.
	1	—	T / T / T	
RMA_SIP (4'b001X)	0	—	~SIP_DIS.DBG_1 / ~SIP_DIS.DBG_2 / ~SIP_DIS.FUNC	SiP-owner debug/test. Honors SIP_DIS only (SYS_DIS does not bind the SiP owner). Entered via RMA_SIP_TOKEN. Demotion has no effect.
	1	—	T / T / T	
RMA_CHIPLET (4'b011X)	X	—	T / T / T	Chiplet-owner debug/test — all features enabled. Entered via RMA_CHIPLET_TOKEN.
INVALID (others)	0	—	F / F / F	The chip is not live: end of life, immediately after reset, or an invalid LC_STATE.
	1	—	T / T / T	

In the DEMOTE column, a dash means the state ignores demotion; X means SEC_DIS makes its value irrelevant. The two demotions act independently.

2.1.5.10.4.4. In-Field Debug Demotion

`DEMOTE_1` and `DEMOTE_2` each contain a `demote` bit and a `lock` bit. They are two registers, not separate demotion and lock register banks. Cold reset clears both and removes the volatile debug profile.

Table 178. SEP demotion controls

Register	Feature group	Scope
`DEMOTE_1`	DBG_1, bits `[23:0]`	Local debug, including SEP and chiplet gates.
`DEMOTE_2`	DBG_2, bits `[47:24]`	Inter-chiplet debug access and forwarding, including `SIP_DBG`.

The controls are independent: either may be set first or used alone. In TEST_DEV, demotion forces its group open; in PROD, it enables the group subject to the disable vectors. Other lifecycle profiles and function bits are unchanged. The complete formulas are in Table 177.

Opening local debug does not open the external access path. For example, a Case 3 SEP debug path requires both groups;

see Section 2.1.5.10.4.5.4. The LCC applies register values without authenticating the writer or a manifest. Firmware authorization is discussed under Firmware Authorization.

2.1.5.10.4.4.1. Programming and Locking

Both `demote` (bit 0) and `lock` (bit 1) are write-one-to-set fields. Writing zero does not clear them. While `lock` is zero, firmware can set `demote`; once locked, the demotion decision cannot change until cold reset. The lock can commit either a demoted or a non-demoted state. The demotion sequence is in the Programmer's Guide.

This is the hardware mechanism. The current ROM's manifest handling is documented in the Boot ROM chapter; the multi-owner authorization model above remains deferred.

2.1.5.10.4.4.2. Reset Behavior

SEP cold reset clears the `demote` and `lock` fields in both registers. The LCC then applies the profile of the sensed OTP state without demotion.

2.1.5.10.4.5. Asset and Scan-Chain Protection

Two distinct DFT operations use the scan chains, and the protection model treats them differently:

- **Scan test** — shift in a test pattern, run the functional clock for one or two cycles, then shift the result out. Used for manufacturing / DFT coverage.
- **Scan dump** — shift the live internal state out directly. Used for debug.

The integration must preserve test coverage without exposing live secrets. The rules below define the required scan partitioning and command gates; feature-vector generation alone does not implement or verify DFT insertion.

2.1.5.10.4.5.1. Asset Classes

SEP assets are partitioned into three classes. Class 1 (non-scannable) and Class 2 (scannable for test coverage but **never** scan-dumpable) are each split by protection rationale — **a** for confidentiality and **b** for integrity. Class 3 is everything else.

Table 179 relates the asset classes to scan and scan-dump treatment.

Table 179. SEP security asset classes

Class	Asset Examples	Scannable (test)	Scan-dumpable (debug)	Gate & Scan-Chain Treatment
1a (non-scannable; confidentiality)	UIDs (`CHIPLET_UID`, `SIP_UID`, `SYS_UID`); `*_TOKEN_I` JTAG input registers (`SEC_DIS_TOKEN_I`, `RMA_SIP_TOKEN_I`, `RMA_CHIPLET_TOKEN_I`); `CLASS_KEY`; raw fuse read-back data.	No	No	**Excluded** from all scan chains. **Confidentiality** rationale: these registers hold the actual secrets; the data lives **in** them, so the only safe option is to keep them off every scan chain.
1b (non-scannable; integrity)	`LOCKS`/`LOCKS_SPARE`, `LC_STATE`, `SIP_DIS`, `SYS_DIS` shadow registers; `*_TOKEN_DIGEST` shadow registers; token-hash digest/valid and RMA match state	No	No	**Excluded** from all scan chains. **Integrity** rationale: the values are not secret (digests are SHA-256 preimage-resistant), but scan shifting could change them and illegitimately enable a disabled feature or make an attacker-presented token match. Stability against scan-induced perturbation is required.

Class	Asset Examples	Scannable (test)	Scan-dumpable (debug)	Gate & Scan-Chain Treatment
2a (secret-bearing; confidentiality)	The complete Key Manager; AES, HMAC-SHA2, KMAC-SHA3, OTBN, entropy, DRBG/EDN, Adams Bridge, and TRNG sequential state; KM/OTBN companion SRAMs (see Class 2 Asset Manifest and Naming)	Yes	**Never**	**Dedicated secure scan chain.** Reachable when its SIB is opened by the `_DBG feature control bits; a *test` command is then admitted only when `secure_tm = 1`, and at `secure_tm = 0` no command is admitted at all. The secret-bearing shadow registers (UIDs / `CLASS_KEY`) are disconnected from downstream while `secure_tm = 1`, so these consumers hold no real secret during scan test. **Scan dump is never permitted — for any owner or LC state**: a dump command is never admitted on this chain (see Section 2.1.5.10.4.5.2).
2b (fuse program path; integrity)	Fuse programming **control** MMRs and **status** MMRs of the SEP fuse controller	Yes	**Never**	**Dedicated secure scan chain**, alongside Class 2a, under the same command-class rule. **Integrity** rationale: shifting is not read-only with respect to the flops it passes through. During a dump every flop in the chain takes on a succession of arbitrary transient values, so a program-control register on a dumpable chain would pass through the encoding for "program" during an ordinary dump, and the dump itself could burn fuses. Status registers are included because spoofed status can steer the program sequencer. Class 2 rather than Class 1 so the fuse controller keeps manufacturing defect coverage; at `secure_tm = 1` the OTP write-enable inputs are tied inactive, so scan toggling cannot reach the fuse array.
3 (general logic)	The rest of the logic not classified above	Yes	Yes (gated)	**General scan chains.** Scannable and scan-dumpable when permitted by the `*_DBG` feature control bits (the scope's local gate — `SEP_DBG` or `CHIPLET_DBG` — plus the `SIP_DBG` debug-access path; see Section 2.1.5.10.4.2) and the LC state. `secure_tm` plays no part here: these chains hold no secret, so both command classes are admitted whenever the chain is reachable.

2.1.5.10.4.5.2. `secure_tm` and the Secure Scan Chain

`secure_tm` is the secure-test-mode indicator: the `TEST_EN` strap latched into the internal `SECURE_TM` signal. It is latched when SEP fuse sensing completes if `SEC_DIS` is not asserted, or on chiplet cold-reset release if `SEC_DIS` is asserted (see the Test Mode section).

`secure_tm` establishes the required test configuration; it does not identify or authenticate the owner at the JTAG port. The protection rules require it to:

1. Admit test commands on the secure chain only while asserted.
2. Block updates to `LOCKS`, `LC_STATE`, `SIP_DIS` and `SYS_DIS` from SEP, OTP, JTAG and TRoot while the part is shiftable.
3. Hold OTP write-enable inputs inactive.
4. Disconnect UID and `CLASS_KEY` shadow outputs from downstream consumers.

Secure-chain access requires both an open SIB, under the feature gates in Section 2.1.5.10.4.5.4, and an allowed command. Test commands require `secure_tm = 1`; dump commands are never allowed, for any owner or lifecycle state. With `secure_tm = 0`, no command is admitted on that chain.

These conditions distinguish Class 1 from Class 2. Class 1 registers contain secrets or state that directly controls protection, so they are excluded from scan. Class 2 consumers and fuse-program controls may be scanned only with their secret sources disconnected and the fuse-write path blocked. The feature bits control reachability; they do not waive these command rules.

The adopter's DFT implementation must enforce this separation. General Class 3 chains follow their debug gates and do not use `secure_tm` as an additional gate.

2.1.5.10.4.5.3. Feature-Bit to Scan-Chain Mapping

Each **general** (Class 3) scan chain is gated by a per-scope `*_DBG` feature control bit in `feat_ctrl_o`; the bit's owner — which predecessor DIS vector sets its default (see Section 2.1.5.10.4.3.2) — sets the multi-owner default policy. External access to any general chain additionally requires the `SIP_DBG` debug-access path into the chiplet to be open (see Section 2.1.5.10.4.2). The Class 2 secure chain is reached through its own SIB, which the feature control bits gate in the same way; what distinguishes it is that reaching it never permits a dump, because the DFT controller admits only test commands there and only while `secure_tm = 1`.

Table 180 maps each asset class to its scan chain and dump gate.

Table 180. SEP scan-chain gates

Asset Class	Scan Chain	Dump Gate	Notes
1a / 1b (non-scannable)	—	—	Excluded from all scan chains.
2a (secret-bearing) + 2b (fuse program path)	Shared dedicated secure chain	Command class — a dump command is never admitted; a test command requires `secure_tm = 1`	Never scan-dumpable, any owner / LC state. Its SIB is feature-bit gated like any other chain, but opening it grants test access only — with the shadow secrets disconnected (2a) and the OTP write-enables tied inactive (2b).
3 (general logic)	Per-scope general chains	Local scope `*_DBG` bit (`SEP_DBG`, `CHIPLET_DBG`) + `SIP_DBG` access path + LC state	Coarse-grained: a scope's general logic is scan-dumpable only when its local `*_DBG` bit enables it, the `SIP_DBG` debug-access path is open, and the LC state permits.

Reserved-bit ranges available for adopter-defined scan chains (see Section 2.1.5.10.4.7):

- Debug group: bits 4-23 (DBG_1, 20 reserved bits) and bits 25-47 (DBG_2, 23 reserved bits)
- Function group: bits 48-63 (16 reserved bits)

2.1.5.10.4.5.4. Debug and Test Port Path Gating

DTP reachability uses three nested combinations of feature bits. A granular fuse-debug bit adds another AND term; it never replaces the case's required bits.

Table 181 defines the three cases used to determine debug-path access.

Table 181. DTP access cases

Case	Condition	Applies to
1	`SIP_DBG`	Paths that only enter or traverse the chiplet without reaching chiplet-internal resources.
2	`SIP_DBG & CHIPLET_DBG`	Paths reaching chiplet-internal resources.
3	`SIP_DBG & CHIPLET_DBG & SEP_DBG`	Paths reaching the SEP or the secure domain.

Case 1 admits traffic, Case 2 reaches chiplet resources, and Case 3 reaches SEP resources. Every bit in the applicable case must be enabled. For example, leaving SEP_DBG open while CHIPLET_DBG is closed does not grant SEP access.

Table 182 lists the feature-control terms required for each DTP path.

Table 182. DTP path feature gates

DTP path	Gating	Notes
I/O S-TAP host path	Case 1	
External S-TAP return path	Case 1	Onward forwarding to a downstream chiplet is part of the SiP-owner domain (see Section 2.1.5.10.4.2).
DFD iJTAG path	Case 1	
SMC debug S-TAP host path	Case 2	No dedicated SMC debug bit exists; see the note below.
DTP configurable (extra) S-TAP host paths	Case 2	
Non-secure external DFT iJTAG path	Case 2	The DFT non-secure chain SIB. Not gated by `secure_tm` — see Section 2.1.5.10.4.5.2.
SMC fabric JTAG2AXI path	Case 2	
SEP debug S-TAP host path	Case 3	Requires the full Case 3 conjunction; `SEP_DBG` alone is not sufficient.
Secure external DFT iJTAG path	Case 3	The DFT secure chain SIB. Reaching it grants test access only, under the command-class rule of Section 2.1.5.10.4.5.2.
DFT-inserted SEP fuse path	Case 3 `&` `SEP_FUSE_DBG`	Includes the OTP IP-vendor test and calibration interface, which is reachable only over this path.
DFT-inserted SMC fuse path	Case 2 `&` `SMC_FUSE_DBG`	
SEP OTP JTAG2AXIL path	**Ungated**	Reaches the whole SEP eFuse interface: the shadow register map, the token-input MMRs, and the eFuse interface control registers, fuse program and read controls included. No feature control bit gates it. Enforcement is per-field `LOCKS` plus a wrapper access policy that, in PROD, RMA_SIP, or on an LC differential-decode integrity error, admits only the MMR region for both reads and writes, so an RMA token can still be presented. `LOCKS` is only in force once sensed, so this depends on nothing on this path being able to execute before fuse sensing completes.
SMC OTP JTAG2AXIL path	**Ungated**	Reaches the whole SMC eFuse interface on the same terms, under a stricter access policy. SMC holds no `LC_STATE` fuse field of its own; its wrapper decodes the state forwarded from SEP. In PROD or RMA_SIP it admits no writes at all and only reads of `CHIPLET_ID` and `PACKAGE_ID`; on an integrity error it admits nothing.

Case 3 spans both demotion groups: SEP_DBG and CHIPLET_DBG are in DBG_1, while SIP_DBG is in DBG_2. In PROD, enabling only one demotion leaves a Case 3 path closed.

There is no separate SMC_DBG bit. SMC debug shares Case 2, so opening CHIPLET_DBG also admits SMC debug when SIP_DBG is open. A separate SMC policy would require an adopter-defined bit and corresponding path gating.

2.1.5.10.4.6. Non-Primary Chiplets

Primary chiplets always include a local SEP and LCC; the asset partitioning described in Section 2.1.5.10.4.5 applies directly. **Non-primary** chiplets may not include a local SEP, in which case debug access is governed by the **SiP-owner domain**. The primary chiplet's SiP-owner feature control gates the DFT traffic before forwarding it to the non-primary chiplet (see Section 2.1.5.10.4.2).

For non-primary chiplets, the adopter is responsible for:

- Identifying which non-primary chiplet assets require protection.
- Partitioning those assets across scan chains analogous to the class scheme in Section 2.1.5.10.4.5.1 (1a/1b, 2, 3).
- Routing the non-primary chiplet's scan / DFT traffic through the appropriate DTP path on the primary chiplet, where SiP-owner feature control gates forwarding.
- Applying the same scan-protection treatment to any non-primary chiplet logic that handles secrets: Class 1 excluded from scan chains, Class 2 never scan-dumpable.

The SIP_DBG mechanism documented in Section 2.1.5.10.4.3.1 gates the DTP path on the primary chiplet. The primary LCC therefore governs debug access to a non-primary chiplet by controlling whether DFT traffic is forwarded to it.

2.1.5.10.4.7. Adopter Extension

If an adopter integrates SEP into a chiplet with assets that require their own scan-chain protection — assets not covered by the chiplet-scope SEP scan chain or the general-logic scan chain in Section 2.1.5.10.4.5 — the LCC architecture accommodates this via the **reserved bits** in feat_ctrl_o (and the matching positions in SIP_DIS / SYS_DIS):

- Debug group: bits 4-23 (DBG_1, 20 reserved bits) and bits 25-47 (DBG_2, 23 reserved bits)
- Function group: bits 48-63 (16 reserved bits)

OCAH assigns no standard function to these reserved bits. An adopter may allocate a DBG_2 bit to an additional inter-chiplet DFT forwarding path; the bit is consumed on the LCC-bearing chiplet to gate the corresponding traffic before it is forwarded downstream.

Each new scan chain or forwarding path is gated by exactly one reserved bit. The corresponding bit position in SIP_DIS or SYS_DIS (chosen by which predecessor owner sets the default policy — see Section 2.1.5.10.4.3.2) determines the default OTP-programmed restriction.

Constraints any adopter extension must satisfy:

- **One feature control bit per scan chain.**
- **Asset-class compliance.** Secret-bearing fields used by the new chain must follow the asset-class scheme (see Section 2.1.5.10.4.5): actual secrets and integrity-critical state are excluded from scan chains (Class 1). A Class 2 chain must never admit a dump command. It may admit test commands only while secure_tm = 1, with secret sources disconnected and fuse programming blocked as specified above. The chain's feature-control bit controls reachability; it does not authorize a dump.
- **Per-LC-state policy.** The new bit follows the standard per-LC-state formulas for its group (see Table 177). DBG_1 and DBG_2 are disabled in undemoted PROD and in PROD_END; their respective demotion controls relax PROD to honor the disable vectors. Function bits continue to honor ~(SIP_DIS.FUNC | SYS_DIS.FUNC) in both production states and are unaffected by demotion. All groups follow their listed TEST_DEV and RMA policies and the SEC_DIS override.

NOTE	The specific bit-allocation convention — which reserved bits are reserved for which adopters, and how bit assignments are advertised in the RDL / package outputs — is currently **open** and will be defined in a future revision of this specification.

2.1.5.10.4.8. Firmware Authorization

The LCC does not inspect manifests or signatures. It supplies the lifecycle state, and the OTP Fuse Controller chapter defines the fuse fields that govern firmware authorization: SBOOT_DIS, the SIP_DIS and SYS_DIS debug vectors, the public-key digests, CHIPLET_PUBK_REVOKE, and the REQUIRED_SIGNERS and REQUIRED_ALGS fields reserved for a deferred multi-owner signing model. Firmware, not the LCC, interprets them. The SEP Boot ROM reads CHIPLET_DBG from the SIP_DIS and SYS_DIS fuse shadows rather than from FEAT_CTRL, because SEC_DIS and demotion can force FEAT_CTRL open on a part whose fuses disable debug.

The Secure Boot Decision section of the SEP Boot ROM appendix in the Programmer's Guide specifies when the ROM requires a verified manifest, including the rule that a debug-locked TEST_DEV or RMA_SiP part is treated as PROD. The SiP Secure Boot application note summarizes that decision and describes the multi-owner model, which the current ROM does not implement, under deferred multi-owner signing model there.

2.1.5.10.4.9. Memory Map and Register Reference

2.1.5.10.4.9.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.10.4.9.2. Detailed Register Map

2.1.5.10.4.9.2.1. SEP Lifecycle Control Address Map

Lifecycle feature-control and demotion registers with their associated locks.

Table 183. SEP Lifecycle Control Address Map register list

Address	Name	Access	Description
0x0	FEAT_CTRL	R	-
0x8	DEMOTE_1	RW	-
0x10	DEMOTE_2	RW	-

2.1.5.10.4.9.2.1.1. FEAT_CTRL

Table 184. sep_lifecycle_ctrl.FEAT_CTRL fields

Bits	Field	Access	Reset	Description
63:0	feature_control	R	0x0	Lifecycle feature control bits,

2.1.5.10.4.9.2.1.2. DEMOTE_1

Table 185. sep_lifecycle_ctrl.DEMOTE_1 fields

Bits	Field	Access	Reset	Description
63:2	rsvd	RW1S	0x0	Not used
1	lock	RW1S	0x0	Demote lock bit. Once locked, demote can no longer be changed
0	demote	RW1S	0x0	Demote bit to enter PROD_DBG state

2.1.5.10.4.9.2.1.3. DEMOTE_2

Table 186. sep_lifecycle_ctrl.DEMOTE_2 fields

Bits	Field	Access	Reset	Description
63:2	rsvd	RW1S	0x0	Not used
1	lock	RW1S	0x0	Demote lock bit. Once locked, demote can no longer be changed
0	demote	RW1S	0x0	Demote bit to enter PROD_DBG state

2.1.5.10.5. Test Mode Entry

SECURE_TM selects the protected configuration required for secure scan tests. It does not authenticate a JTAG owner or enable debug access. Lifecycle state, SIP_DIS, SYS_DIS and the SEC_DIS override determine the debug and function bits of feat_ctrl_o; SECURE_TM does not qualify those bits.

2.1.5.10.5.1. Entry and Exit

Connect the chiplet's TEST_EN strap to the SEP wrapper's secure_tm_req_i. Hold it stable through reset release, fuse sensing and the test session. The entry contract requires the sampled SECURE_TM value to remain asserted until chiplet cold reset ends the session; software has no clear operation.

Table 187. Secure test-mode sampling in the SEP wrapper

Condition	Action
Cold reset asserted	Clear SECURE_TM to 0.
SEC_DIS asserted at the early capture point	Sample the strap on the second rising clock edge after wrapper cold-reset release.
Fuse-sense completion rises	Sample the strap, including when SEC_DIS is asserted.
Neither sampling event	Retain the sampled value.

The early capture counter saturates after that opportunity: asserting SEC_DIS later does not itself sample the strap. A subsequent fuse-sense completion can sample it again. The current wrapper loads the strap value at each sampling event; it is not a set-only latch. If the strap changes from 1 to 0 between captures, the later capture can clear SECURE_TM without reset. The stable-strap requirement is therefore necessary to meet the reset-only exit contract; that contract is not an unconditional hardware guarantee for a changing strap.

2.1.5.10.5.2. Protection While Active

The secure-test configuration must enforce all four protections below. The adopter's DFT integration remains responsible for secure-chain separation and command admission.

Table 188. Required secure-test protections

Protected resource	Requirement while SECURE_TM=1
Dedicated secure scan chain	Admit test commands only through an open, feature-gated scan path. Never admit dump commands. At SECURE_TM=0, admit no command on this chain.
Protection shadows	Block all updates to LOCKS, LOCKS_SPARE, LC_STATE, SIP_DIS and SYS_DIS.
OTP programming path	Hold the fuse macro's write-enable inputs inactive.
Secret outputs	Disconnect CHIPLET_UID, SIP_UID, SYS_UID and CLASS_KEY from downstream consumers.

The eFuse controller implements request blocking and masks the designated secret shadow outputs to zero. Masking does not erase the stored fuse or shadow values, and register reads retain their normal access controls. It must not be treated as proof that every downstream consumer has been cleared. These protections allow testing without exposing persistent secrets that cannot be erased before RMA.

General scan chains follow their ordinary debug gates; the dedicated secure chain has the additional command restrictions above. For the normative scan classes and access rules, see secure_tm and the Secure Scan Chain.

2.1.5.11. Cryptographic Subsystem

The cryptographic accelerators use separate paths for data and secret keys:

- The SEP system fabric drives the AXI4 data and CSR bus.
- Key Manager drives the AXI4-Lite secret-key buses.

The accelerators are derived from OpenTitan, except for the Adams Bridge post-quantum accelerator from Caliptra. The firmware is based on the OpenTitan cryptographic library. Each block's reference page includes its available register maps; the Detailed Register Map links to those pages.

OCAH adds bus adapters and separate key-delivery paths to the accelerator wrappers. Key Manager writes keys through AXI4-Lite interfaces; the wrappers connect them to the accelerators' key inputs. The following sections describe the shared integration rules and accelerator-specific differences.

Adams Bridge requires 13 SRAM macros with masking enabled (default), or 9 with masking disabled.

Figure 31 shows the accelerator interconnect, Key Manager paths, and external memory interfaces.




Figure 31. SEP cryptographic subsystem and external memory interfaces

In Figure 31, dark lines are host AXI4 and AXI4-Lite paths from the crypto AXI interconnect, and brown lines are the Key Manager private key buses. Each accelerator's key CSR block is the `<accelerator>_wrapper_key_reg` block that receives the `KEY_SHARE0`, `KEY_SHARE1` and `KEY_CTRL` writes described in Section 2.1.5.11.3 and drives the core's sideload key port. The Key Manager reaches the key CSR blocks through its internal crossbar; the Adams Bridge key bus leaves on the right, beside the ML-KEM shared-key interrupt that Adams Bridge returns. The host paths to the Key Manager mailbox, the external TRNG registers, the eFuse wrapper and the lifecycle controller are not isolated, and the eFuse and lifecycle legs leave the interconnect as AXI4. All six Key Manager paths, including its eFuse access, pass an isolation stage in `sep_crypto_axi_interconnect`.

The Key Manager also receives OTP data: the eFuse shadow registers supply the lifecycle state and the identity and class-key fields, and the lifecycle controller supplies the two demotion states. Grey arrows carry entropy, OTP data and status one way; the three entropy streams from the DRBG pass through a source select that can take the external TRNG instead, as the TRNG and DRBG page describes. Grey boxes are outside `sep_crypto`: the memory macros live in the integration layer, and the entropy pool is `u_entropy_fifo` in `sep`. The Adams Bridge SRAMs are 13 macros with masking enabled and 9 without. Interrupts and OpenTitan alerts are not drawn; Table 189 lists them.

The integrator must instantiate the Adams Bridge working SRAMs outside SEP and connect them through the dedicated `abr_mem` request/response interface. For the memory interface and configuration requirements, see SEP Memory Interfaces in the Integrator Guide.

The `sep_crypto` module implements the integration layer, with `sep_crypto_axi_interconnect` centralizing its bus infrastructure. A single 64-bit AXI slave port from the SEP system fabric is decoded to the accelerators and internal peripherals. The host paths to OTBN, HMAC, AES, KMAC, ESRC, CSRNG, and EDN are converted to AXI4-Lite before isolation, with data-width conversion where required by the endpoint. The OpenTitan wrappers then bridge the isolated AXI4-Lite paths to TL-UL.

The Key Manager drives private AXI4-Lite key buses to the accelerator wrappers, which map key words into the sideload structures expected by the OpenTitan cores. These buses are independently isolated so that they drain before either the Key Manager or the destination accelerator enters software reset.

Each accelerator has its own software-controllable reset. The SEP Reset Controller drains and isolates both its host and Key Manager paths before asserting reset; a Key Manager reset similarly drains all of its key paths. The entropy source, CSRNG, and EDN share one coordinated reset. See SEP Reset Controller and Section 2.1.5.4.3.4.

Figure 32 shows how the resets from the SEP Reset Controller reach the instances inside `u_sep_crypto`.




Figure 32. SEP cryptographic subsystem resets

Inside `u_sep_trng`, `por_rst_ni` resets a 2-flop synchronizer that samples the inverted TRNG reset and drives `trng_reset_active`. That signal synchronously clears both EDN AXIS adapters and, as `trng_entropy_clear_o`, the entropy pool. Both adapters take `rst_ni`. An OTBN, AES or KMAC software reset cancels that engine's endpoints in the crypto adapter (see SEP Reset Controller). The Key Manager conditions `sep_reset_n` into its cold domain through `u_cold_rst_sync`, and the gated Key Manager reset or its software reset `soft_rst_n` into a warm reset held for at least 10 cycles, as Figure 44 shows in more detail.

2.1.5.11.1. OpenTitan Alert Termination

SEP does not instantiate OpenTitan's `alert_handler`. Each OpenTitan crypto alert channel is terminated locally by a `prim_alert_receiver` in `sep_crypto`. That primitive decodes the sender's differential `alert_p`/`alert_n` handshake and pulses `alert_o` when the handshake starts; a malformed encoding raises `integ_fail_o`. Alert ping is disabled (`ping_req_i` tied 0); `ping_ok_o` is unused.

PIC sources are in Section 2.1.5.8.2.1. A receiver's pulse and integrity-fail stay per-block at the receiver. Table 189 shows which of those, the native error IRQs, and the bridge faults are OR'd onto a PIC source and which are not.

Table 189. SEP crypto alert and fault routing

Block	OT alert channels	Alert PIC	Native error IRQ	Bridge `err_o`
HMAC	`[0]` fatal	OR into Crypto alert	dedicated PIC	STATUS bit; OR into Peripheral register-bridge fault
OTBN	`[2:1]`	OR into Crypto alert	none	STATUS bit; OR into Peripheral register-bridge fault
AES	`[4:3]` recoverable, fatal	OR into Crypto alert	none	STATUS bit; OR into Peripheral register-bridge fault
KMAC	`[6:5]`	OR into Crypto alert	dedicated PIC	STATUS bit; OR into Peripheral register-bridge fault
CSRNG	`[8:7]`	OR into Crypto alert	dedicated PIC	STATUS bit; OR into Peripheral register-bridge fault
EDN	`[10:9]`	OR into Crypto alert	dedicated PIC	STATUS bit; OR into Peripheral register-bridge fault

Adams Bridge and the entropy source do not go through this conversion.

The Crypto alert source is the OR of every receiver pulse and integrity-fail, so that interrupt does not name the block. Native error IRQs are not OR'd. HMAC, AES, KMAC, OTBN, CSRNG, and EDN convert isolated AXI4-Lite to TL-UL through `axi_lite_to_tlul`; each bridge's sticky `err_o` is that wrapper's `bus_err_o`, visible as one bit in `PERIPH_BUS_ERR_STATUS` and cleared with the matching `PERIPH_BUS_ERR_CLEAR` bit. The Peripheral register-bridge fault source is the OR of those bits and the watchdog timer's bridge fault. Acknowledging one STATUS bit cannot discard another.

The crypto complex uses whole-instance Class 2 scan boundaries so all sequential key, round-key, digest-working, seed, and random-distribution state is covered without per-register marking. The marked roots in `sep_crypto` are `u_hmac_wrapper_s3c_scan`, `u_sep_crypto_otbn_wrapper_s3c_scan`, `u_aes_wrapper_s3c_scan`, `u_kmac_wrapper_s3c_scan`, `u_sep_crypto_abr_wrapper_s3c_scan`, `u_entropy_source_s3c_scan`, `u_drbg_s3c_scan`, `u_axis_edn_crypto_s3c_scan`, `u_axis_edn_pool_s3c_scan`, and `u_key_manager_s3c_scan`. The integration module itself, public bus infrastructure, and combinational entropy muxes are not Class 2 roots.

2.1.5.11.2. Single-Beat Access Only

The `sep_crypto` demux enforces single-beat access to the crypto region (Section 2.1.5.12.2). Any access whose `AxLEN` is non-zero is routed to the internal error slave and answered with DECERR on every beat, whatever its address; no beat reaches an accelerator.

2.1.5.11.3. Key Manager Key Delivery

The Key Manager delivers keys and seeds to the crypto accelerators over a private key interface that software cannot read. Every delivery uses the same format: the value is carried as two shares whose XOR is the value, and each share is presented as a sequence of 32-bit words in the `KEY_SHARE0` and `KEY_SHARE1` registers of the destination. Within a share, word index N carries value bits `[32N+31:32N]`, so index 0 is the least-significant word and the highest index is the most-

significant.

Both shares are always consumed. Delivering a value V therefore requires two shares whose XOR is V; writing a single share delivers V only because the unwritten share reads as zero. KEY_CTRL.KEY_VALID qualifies the delivered value, and while it is 0 the destination has no valid key or seed.

The words per share, whether software must select the delivered key in preference to the accelerator's own software key registers, whether software must also declare the key length, and the behavior on an invalid or mismatched key are accelerator-specific. They are stated in the accelerator reference pages and summarized in Table 190; the delivered-key section of the Programmer's Guide gives the corresponding software configuration.

Table 190. Key Manager key delivery per accelerator

Accelerator	Words per share	Select delivered key	Key length	Invalid or mismatched key
HMAC	8 (256-bit)	Not required	CFG.key_length, set by software	Digest is wrong but repeatable; no error
AES	8 (256-bit)	CTRL_SHADOWED.sideload	CTRL_SHADOWED.key_len, set by software	Delivered key ignored while the select bit is 0; no error
KMAC	8 (256-bit)	CFG_SHADOWED.sideload	Applied automatically	Keyed operation raises an error
OTBN	12 (384-bit)	Not required	Not applicable	ERR_BITS.KEY_INVALID; the program stops
ABR	8 per block (256-bit)	Seed read enable	Not applicable	Seed read does not complete

2.1.5.11.4. TRNG and DRBG

SEP separates physical entropy generation from deterministic random-data production and distribution. The internal path is:

- Entropy Source (ESRC): ring-oscillator sampling, extraction, health checks and SHA-256 conditioning.
- Cryptographically Secure Random Number Generator (CSRNG): an AES-CTR deterministic random bit generator (DRBG), seeded by ESRC.
- Entropy Distribution Network (EDN): requests generated data from CSRNG and supplies the three SEP sink paths below.

Each sink can instead select an external stream. The source muxes sit after EDN, so external data bypasses the internal ESRC/CSRNG/EDN chain. Stream availability and FIPS tags do not establish entropy quality or certification.




Figure 33. SEP TRNG and DRBG entropy distribution

Figure 33 reads left to right. Inside `u_sep_trng`, the entropy source drives a 32-bit stream into the DRBG, whose seed packer collects twelve words into each 384-bit CSRNG seed. EDN draws from CSRNG and fills one 8-entry AXI-Stream FIFO per endpoint. The crypto AXI interconnect reaches the entropy source, CSRNG and EDN registers, and the external TRNG register window. The source select holds one 2:1 mux per stream; each bit of `EXT_TRNG_SRC_SEL` chooses the internal DRBG (0) or the external TRNG (1, the reset value) for its stream. Streams 0, 1 and 2 go to the Key Manager DRBG sampler, to the crypto EDN adapter and to the pool EDN adapter. The entropy pool sits in `sep`, outside `sep_crypto`, and packs the 32-bit words into a 32-entry FIFO of 64-bit words that software reads through the SEP local crossbar. The CSRNG and EDN cores are OpenTitan IP; their internal structure and register semantics are described in the OpenTitan CSRNG and EDN documentation. The Programmer's Guide gives the programming guidance for this block.

2.1.5.11.4.1. Entropy Generation

The internal ESRC samples ring oscillators, decorrelates/extracts their output and conditions it with SHA-256. Its gating health test observes the extracted 32-bit stream before SHA-256; per-generator health results provide additional monitoring. The health tests include repetition, adaptive-proportion and Markov checks. This is not a test of each DRBG output word.

Startup health testing gates release into the normal output path. The stream to DRBG is the ESRC output selected by its configuration: normally SHA-256 output, but compressor-bypass mode selects uncompressed generator data and disables the gating 32-bit health test. Do not treat bypass or diagnostic settings as equivalent to the qualified operating configuration.

Source characterization, health-test thresholds and permitted configurations belong to the entropy-source qualification. Conditioning does not by itself establish the amount of physical entropy in a seed. The source requirements are described by NIST SP 800-90B.

See Entropy Source for the source controls, startup status, health monitoring and configuration locks.

2.1.5.11.4.2. Distribution and Source Selection

SEP instantiates drbg with three AXI-Stream outputs and no direct native EDN endpoints. The crypto and pool paths convert the selected streams back to native EDN requests/responses outside that wrapper.

Table 191. SEP entropy sink paths

Stream / select bit	Sink	Connection after the source mux
0	Key Manager	Direct stream to the KM DRBG sampler.
1	AES, KMAC, OTBN	u_axis_edn_crypto_s3c_scan distributes words to native clients 0 = AES, 1 = KMAC, 2 = OTBN RND, 3 = OTBN URND, using round-robin arbitration.
2	Fabric entropy pool	u_axis_edn_pool_s3c_scan supplies the single native EDN fill port of u_entropy_fifo in sep.sv.

SEP_CPU_CTRL.EXT_TRNG_SRC_SEL selects each path independently: 0 selects internal DRBG data and 1 selects external data. Its reset value is 0b111, so all three paths initially select external inputs. The write-once-set EXT_TRNG_SRC_SEL_LOCK prevents selection changes until the CPU-control bank is reset; resetting the internal TRNG alone does not unlock it.

The selected source receives the sink's ready signal. An unselected internal endpoint is backpressured and retains queued data; an unselected external input receives ready high and its beats are discarded. Selection is combinational: there is no switch-complete handshake or automatic flush of previously queued words.

Table 192. SEP random-data stream contract

Signal	Direction / width	Meaning
tvalid	Source / 1	A word is available; transfer occurs with tready high.
tready	Sink / 1	The sink can accept the word. Hold valid data stable while stalled.
tdata	Source / 32	One random-data word.
tstrb	Source / 4	Byte strobes. Internal endpoints drive 0xF; the crypto and pool adapters accept only full words (0xF). Partial strobes stall those adapters.
tuser	Internal source / 1	Per-word FIPS provenance from EDN. The external input has no provenance bit; its source mux supplies a constant 1.

There is no stream address: each physical output selects its sink path. The pool packs received words for its 64-bit read aperture and reports entropy_pool_low, entropy_pool_fill_stall and entropy_pool_err.

See Section 2.1.5.8.2.1 for source assignments.

2.1.5.11.4.2.1. FIPS Provenance

The internal seed adapter attaches the provisional constant DrbgCsrngSeedFipsProvisional = 1. CSRNG/EDN output provenance is retained in each endpoint FIFO and forwarded through tuser into the native client's edn_fips. OTBN RND checks the returned tag and can report rnd_fips_chk_fail. The external mux also attaches 1 unconditionally. Neither constant measures source quality, validates an external producer, or establishes FIPS compliance; qualification must justify the source and its operating configuration separately.

2.1.5.11.4.3. Reset and Recovery Boundaries

SEP_RESET_CTRL.SW_RESET_N.TRNG_SW_RST_N controls one internal reset domain: ESRC, CSRNG, EDN and the DRBG endpoint queues. The TRNG sequencer isolates all three host paths to drain and safely reset their converted AXI4-Lite CSR transactions. This protects register transactions; it does not wait for entropy consumers to become idle.

Table 193. TRNG reset effects outside the internal domain

Block	Effect
Post-mux crypto and pool adapters	Synchronously clear pending and buffered state while the internal TRNG reset is active, even if external inputs are selected.
Fabric entropy pool	Clears its partial word, queued entropy and fill-stall state. Its AXI responder remains accessible; this is not a reset of that responder.
AES, KMAC and OTBN	Not reset by the TRNG coordinator. Native requests receive no acknowledgement during adapter clear and can resume after fresh data arrives. Their software resets cancel the corresponding adapter endpoints; OTBN owns RND and URND.
Key Manager sampler	Not scrubbed by TRNG reset: there is no post-mux adapter on this path. Keep KM idle before asserting TRNG reset; holding KM in software reset is sufficient. Hardware does not enforce this ordering.
External TRNG CSR path	Not included in the internal TRNG reset/isolation boundary.

An in-progress KM sample can otherwise combine old and new stream data or report a stream error. The reset is therefore not an atomic restart of all entropy consumers, and after release the internal chain produces no data until ESRC, CSRNG and EDN are reinitialized. External crypto/pool traffic also pauses during adapter clear; it can resume when that clear ends, independently of internal generator initialization. The TRNG recovery sequence is in the Programmer's Guide.

See Section 2.1.5.4.3.4 for the coordinator and recovery contract.

2.1.5.11.4.3.1. Scan Protection Boundary

The Class 2 entropy boundary starts at `u_trng_wrapper_s3c_scan`: its sequencer, 128-bit release stage and stream FIFOs retain seed material; the vendor core uses its delivered DFT view. Within `u_sep_crypto.u_sep_trng`, `u_entropy_source_s3c_scan` covers entropy FIFO/SHA-256 state and `u_drbg_s3c_scan` covers CSRNG, EDN and endpoint state. The post-mux `u_axis_edn_crypto_s3c_scan` covers staging outside the DRBG root. Source-selection muxes are combinational, not scan assets.

2.1.5.11.4.4. DRBG Deterministic Random Bit Generator

This module is NIST 800-90A compliant. The module is based on the OpenTitan design.

The DRBG is seeded by the TRNG entropy stream and generates an arbitrary length bitstream which is used as foundational random data by the Key Generator.

This component uses the AES-CTR-DRBG version of the 800-90A.

The `drbg` top-level module wraps the OpenTitan CSRNG and EDN blocks with bus-protocol adapters. It accepts a raw 32-bit entropy stream from the entropy source, feeds it directly into the CSRNG seed path, and exposes AXI-Stream (and optionally native) EDN endpoints for deterministic random data delivery.

2.1.5.11.4.4.1. Parameters

The DRBG is configured through its seed FIFO depth, its AXI-Stream and native EDN endpoint counts, and the depth of each AXI-Stream endpoint FIFO.

The parameters of `drbg` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.5.11.4.4.2. External Interfaces

The DRBG presents several interface types to the rest of the SEP subsystem.

Table 194 describes the entropy ingress, random-data endpoints, and control interfaces.

Table 194. DRBG external interfaces

Interface	Description
Entropy ingress	Fire-and-forget: `entropy_stream_data_i[31:0]` and `entropy_stream_vld_i` from the entropy source. There is no backpressure; each valid word feeds the CSRNG seed-packing path directly on the cycle it arrives.
EDN AXI-Stream	`edn_axis_o` / `edn_axis_i` (one pair per endpoint). Carries deterministic random data generated by CSRNG through the EDN. This is the primary interface consumed by the Key Manager DRBG sampler.
Native EDN	`edn_native_req_i` / `edn_native_rsp_o` (one pair per native endpoint, present when `EDN_NATIVE_ENDPOINT_COUNT > 0`). Raw `edn_pkg` req/rsp handshake for consumers that bypass AXI-Stream buffering, such as the SEP entropy-pool FIFO fill path.
CSRNG AXI-Lite (64-bit)	`csrng_axil_req_i` / `csrng_axil_rsp_o`. Control-plane access to the CSRNG register set for instantiation, reseeding, and status monitoring.
EDN AXI-Lite (64-bit)	`edn_axil_req_i` / `edn_axil_rsp_o`. Control-plane access to the EDN register set for mode configuration and status.
Life-cycle / OTP	`otp_en_csrng_sw_app_read_i` (MuBi8) and `lc_hw_debug_en_i` (lc_tx_t). These signals gate CSRNG software application read access based on device life-cycle state.
Alerts	Two alert pairs (CSRNG and EDN) following the OpenTitan alert protocol.
Interrupts	CSRNG: command done, entropy request, hardware instance exception, fatal error. EDN: command done, fatal error.

2.1.5.11.4.4.3. Seed Assembly

The `drbg_csrng_seed_adapter` receives one 32-bit entropy word per valid cycle directly from the entropy source (there is no upstream routing or distribution FIFO) and packs the words into full CSRNG-width seeds using an OpenTitan `prim_packer_fifo`. The packed seed is pushed into a shallow FIFO (default depth 1) along with a FIPS compliance flag set to a provisional value (`DrbgCsrngSeedFipsProvisional = 1`). The CSRNG pulls seeds through the standard `entropy_src_hw_if` handshake: `es_req` / `es_ack` / `es_bits` / `es_fips`. Because ingress is fire-and-forget with no backpressure, the producer must supply entropy no faster than the seed adapter can pack it.

2.1.5.11.4.4.4. OpenTitan CSRNG and EDN

The CSRNG and EDN instances are standard OpenTitan IP blocks. The CSRNG implements AES-CTR-DRBG per NIST SP 800-90A. It accepts entropy seeds from the hardware interface, processes firmware-issued commands (instantiate, reseed, generate, uninstantiate) through TL-UL, and serves random data to multiple hardware application ports. In this integration, EDN is connected to CSRNG hardware application port 0; any additional hardware application ports are tied off.

The EDN automates generate and reseed command sequences so that downstream consumers receive a continuous stream of random data without firmware intervention. The EDN endpoint interface uses a simple request/acknowledge handshake. The `drbg_edn_axis_adapter` converts this into the AXI-Stream protocol expected by the rest of the SEP fabric, buffering data in per-endpoint FIFOs.

Consult the OpenTitan documentation at CSRNG and EDN for the authoritative core functionality of those IPs.

2.1.5.11.4.4.5. Bus Protocol Adaptation

The CSRNG and EDN register interfaces use TL-UL, following the OpenTitan convention. The DRBG wrapper provides two levels of adaptation. The `drbg_axil64_lane_adapter` accepts 64-bit AXI4-Lite transactions from the SoC interconnect and narrows them to 32-bit AXI-Lite by selecting the appropriate data lane based on address bit [2]. Only aligned single-lane accesses with strobe `0x0F` or `0xF0` are forwarded; all others are rejected with SLVERR. Write address, write data, and read address are independent channels. The adapter holds a single downstream 32-bit slot: it accepts each write half as soon as that half is not already pending, and it accepts a read only when neither write half is pending. When a read address and a complete write handshake in the same idle cycle, the adapter forwards the read and holds the write until

it returns to idle. The downstream `axi_lite_to_tlul` bridge then converts 32-bit AXI-Lite into TL-UL for the CSRNG and EDN register blocks.

The CSRNG and EDN register maps are reported in the SEP detailed register map.

2.1.5.11.4.5. Memory Map and Register Reference

2.1.5.11.4.5.1. Memory Map

CSRNG and EDN occupy separate apertures in the SEP memory map. Their register offsets and access rules are given in the generated maps below.

2.1.5.11.4.5.2. Detailed Register Map

2.1.5.11.4.5.2.1. CSRNG Registers

####### 2.1.5.11.4.5.2.1.1. Cryptographically Secure Random Number Generator

Takes entropy bits to produce cryptographically secure random numbers for consumption by hardware blocks and by software

Table 195. Cryptographically Secure Random Number Generator register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-
0xC	ALERT_TEST	W	-
0x10	REGWEN	RW	-
0x14	CTRL	RW	-
0x18	CMD_REQ	W	-
0x1C	RESEED_INTERVAL	RW	-
0x20	RESEED_COUNTER_0	R	-
0x24	RESEED_COUNTER_1	R	-
0x28	RESEED_COUNTER_2	R	-
0x2C	SW_CMD_STS	R	-
0x30	GENBITS_VLD	R	-
0x34	GENBITS	R	-
0x38	INT_STATE_READ_ENABLE	RW	-
0x3C	INT_STATE_READ_ENABLE_REGWEN	RW	-
0x40	INT_STATE_NUM	RW	-
0x44	INT_STATE_VAL	R	-
0x48	FIPS_FORCE	RW	-
0x4C	HW_EXC_STS	RW	-
0x50	RECOV_ALERT_STS	RW	-
0x54	ERR_CODE	R	-
0x58	ERR_CODE_TEST	RW	-

Address	Name	Access	Description
0x5C	MAIN_SM_STATE	R	-

2.1.5.11.4.5.2.1.1.1. INTR_STATE

Table 196. csrng.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	CS_FATAL_ERR	RW1C	0x0	Asserted when a FIFO error or a fatal alert occurs. Check the !!ERR_CODE register to get more information.
2	CS_HW_INST_EXC	RW1C	0x0	Asserted when a hardware-attached CSRNG instance encounters a command exception
1	CS_ENTROPY_REQ	RW1C	0x0	Asserted when a request for entropy has been made.
0	CS_CMD_REQ_DONE	RW1C	0x0	Asserted when a command request is completed.

2.1.5.11.4.5.2.1.1.2. INTR_ENABLE

Table 197. csrng.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	CS_FATAL_ERR	RW	0x0	Enable interrupt when !!INTR_STATE.cs_fatal_err is set.
2	CS_HW_INST_EXC	RW	0x0	Enable interrupt when !!INTR_STATE.cs_hw_inst_exc is set.
1	CS_ENTROPY_REQ	RW	0x0	Enable interrupt when !!INTR_STATE.cs_entropy_req is set.
0	CS_CMD_REQ_DONE	RW	0x0	Enable interrupt when !!INTR_STATE.cs_cmd_req_done is set.

2.1.5.11.4.5.2.1.1.3. INTR_TEST

Table 198. csrng.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	CS_FATAL_ERR	W	0x0	Write 1 to force !!INTR_STATE.cs_fatal_err to 1.
2	CS_HW_INST_EXC	W	0x0	Write 1 to force !!INTR_STATE.cs_hw_inst_exc to 1.
1	CS_ENTROPY_REQ	W	0x0	Write 1 to force !!INTR_STATE.cs_entropy_req to 1.
0	CS_CMD_REQ_DONE	W	0x0	Write 1 to force !!INTR_STATE.cs_cmd_req_done to 1.

2.1.5.11.4.5.2.1.1.4. ALERT_TEST

Table 199. csrng.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	FATAL_ALERT	W	0x0	Write 1 to trigger one alert event of this kind.
0	RECOV_ALERT	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.11.4.5.2.1.1.5. REGWEN

Table 200. csrng.REGWEN fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	REGWEN	RW0C	0x1	When true, all writeable registers can be modified. When false, they become read-only.

2.1.5.11.4.5.2.1.1.6. CTRL

Table 201. csrng.CTRL fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:12	FIPS_FORCE_ENABLE	RW	0x9	Setting this field to kMultiBitBool4True enables forcing the FIPS/CC compliance flag to true via the !!FIPS_FORCE register.
11:8	READ_INT_STATE	RW	0x9	Setting this field to kMultiBitBool4True will enable reading from the !!INT_STATE_VAL register. Reading the internal state of the enable instances will be enabled only if the otp_en_csrng_sw_app_read input vector is set to the enable encoding. Also, the !!INT_STATE_READ_ENABLE bit of the selected instance needs to be set to true for this to work.
7:4	SW_APP_ENABLE	RW	0x9	Setting this field to kMultiBitBool4True will enable reading from the !!GENBITS register. This application interface for software (register based) will be enabled only if the otp_en_csrng_sw_app_read input vector is set to the enable encoding.
3:0	ENABLE	RW	0x9	Setting this field to kMultiBitBool4True will enable the CSRNG module. The modules of the entropy complex may only be enabled and disabled in a specific order, see Programmers Guide for details.

2.1.5.11.4.5.2.1.1.7. CMD_REQ

Table 202. csrng.CMD_REQ fields

Bits	Field	Access	Reset	Description
31:0	CMD_REQ	W	0x0	Writing this request with defined CSRNG commands will initiate all possible CSRNG actions. The application interface must wait for the "ack" to return before issuing new commands.

2.1.5.11.4.5.2.1.1.8. RESEED_INTERVAL

Table 203. csrng.RESEED_INTERVAL fields

Bits	Field	Access	Reset	Description
31:0	RESEED_INTERVAL	RW	0xFFFFFFFF	Setting this field will set the number of generate requests that can be made to CSRNG before a reseed request needs to be made. This register supports a maximum of 2^32 requests between reseeds. This register will be compared to a counter, which counts the number of generate commands between reseed or instantiate commands. If the counter reaches the value of this register, the violating command will be acknowledged with a status error. If the violating command was issued by a HW instance, an interrupt will be triggered.

2.1.5.11.4.5.2.1.1.9. RESEED_COUNTER_0

Table 204. csrng.RESEED_COUNTER_0 fields

Bits	Field	Access	Reset	Description
31:0	RESEED_COUNTER_0	R	0x0	Reseed Counter indicating the number of completed Generate requests since the last Instantiate or Reseed command.

2.1.5.11.4.5.2.1.1.10. RESEED_COUNTER_1

Table 205. csrng.RESEED_COUNTER_1 fields

Bits	Field	Access	Reset	Description
31:0	RESEED_COUNTER_0	R	0x0	For RESEED_COUNTER1

2.1.5.11.4.5.2.1.1.11. RESEED_COUNTER_2

Table 206. csrng.RESEED_COUNTER_2 fields

Bits	Field	Access	Reset	Description
31:0	RESEED_COUNTER_0	R	0x0	For RESEED_COUNTER2

2.1.5.11.4.5.2.1.1.12. SW_CMD_STS

Table 207. csrng.SW_CMD_STS fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:3	CMD_STS	R	0x0	This field represents the status code returned with the application command ack. It is updated each time a command ack is asserted on the internal application interface for software use. To check whether a command was successful, wait for !!INTR_STATE.CS_CMD_REQ_DONE or !!SW_CMD_STS.CMD_ACK to be high and then check the value of this field.
2	CMD_ACK	R	0x0	This one bit field indicates when a SW command has been acknowledged by the CSRNG. It is set to low each time a new command is written to !!CMD_REQ. The field is set to high once a SW command request has been acknowledged by the CSRNG. 0b0: The last SW command has not been acknowledged yet. 0b1: The last SW command has been acknowledged. In case of a generate command the acknowledgement goes high after all of the requested entropy is consumed.
1	CMD_RDY	R	0x0	This bit indicates when the command interface is ready to accept commands. Before starting to write a new command to !!SW_CMD_REQ, this field needs to be polled. 0b0: CSRNG is not ready to accept commands or the last command hasn't been acked yet. 0b1: CSRNG is ready to accept the next command.
0	Reserved	-	-	Reserved

2.1.5.11.4.5.2.1.1.13. GENBITS_VLD

Table 208. csrng.GENBITS_VLD fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	GENBITS_FIPS	R	-	This bit is set when genbits are FIPS/CC compliant.
0	GENBITS_VLD	R	-	This bit is set when genbits are available on this application interface after a generate command has been issued.

2.1.5.11.4.5.2.1.1.14. GENBITS

Table 209. csrng.GENBITS fields

Bits	Field	Access	Reset	Description
31:0	GENBITS	R	-	Reading this register will get the generated bits that were requested with the generate request. This register must be read four times for each request made. For example, an application command generate request with a clen value of 4 requires this register to be read 16 times to get all of the data out of the FIFO path. Note that for !!GENBITS to be able to deliver random numbers, also !!CTRL.SW_APP_ENABLE needs to be set to kMultiBitBool4True. In addition, the otp_en_csrng_sw_app_read input needs to be set to kMultiBitBool8True. Otherwise, the register reads as 0.

2.1.5.11.4.5.2.1.1.15. INT_STATE_READ_ENABLE

Table 210. csrng.INT_STATE_READ_ENABLE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	INT_STATE_READ_ENABLE	RW	0x7	Per-instance internal state read enable. Defines whether the internal state of the corresponding instance is readable via !!INT_STATE_VAL. Note that for !!INT_STATE_VAL to provide read access to the internal state, also !!CTRL.READ_INT_STATE needs to be set to kMultiBitBool4True. In addition, the otp_en_csrng_sw_app_read input needs to be set to kMultiBitBool8True.

2.1.5.11.4.5.2.1.1.16. INT_STATE_READ_ENABLE_REGWEN

Table 211. csrng.INT_STATE_READ_ENABLE_REGWEN fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	INT_STATE_READ_ENABLE_REGWEN	RW0C	0x1	INT_STATE_READ_ENABLE register configuration enable bit. If this is cleared to 0, the INT_STATE_READ_ENABLE register cannot be written anymore.

2.1.5.11.4.5.2.1.1.17. INT_STATE_NUM

Table 212. csrng.INT_STATE_NUM fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3:0	INT_STATE_NUM	RW	0x0	Setting this field will set the number for which internal state can be selected for a read access. Up to 16 internal state values can be chosen from this register. The actual number of valid internal state fields is set by parameter NumHwApps plus 1 software app. For those selections that point to reserved locations (greater than NumHwApps plus 1), the returned value will be zero. Writing this register will also reset the internal read pointer for the !!INT_STATE_VAL register. Note: This register should be read back after being written to ensure that the !!INT_STATE_VAL read back is accurate.

2.1.5.11.4.5.2.1.1.18. INT_STATE_VAL

Table 213. csrng.INT_STATE_VAL fields

Bits	Field	Access	Reset	Description
31:0	INT_STATE_VAL	R	-	Reading this register will dump out the contents of the selected internal state field. Since the internal state field is 448 bits wide, it will require 14 reads from this register to gather the entire field. Once 14 reads have been done, the internal read pointer (selects 32 bits of the 448 bit field) will reset to zero. The !!INT_STATE_NUM can be re-written at this time (internal read pointer is also reset), and then another internal state field can be read. Note that for !!INT_STATE_VAL to provide read access to the internal state, also !!CTRL.READ_INT_STATE needs to be set to kMultiBitBool4True. In addition, the otp_en_csrng_sw_app_read input needs to be set to kMultiBitBool8True. Also, the !!INT_STATE_READ_ENABLE bit of the selected instance needs to be set to true for this to work. Otherwise, the register reads as 0.

2.1.5.11.4.5.2.1.1.19. FIPS_FORCE

Table 214. csrng.FIPS_FORCE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	FIPS_FORCE	RW	0x0	Force the FIPS/CC compliance flag of individual instances to true. This allows CSRNG to set the output FIPS/CC compliance flag to true despite running in fully deterministic mode (flag0 being true). This can be useful e.g. for known-answer testing through entropy consumers accepting FIPS/CC compliant entropy only, or when firmware is used to derive FIPS/CC compliant entropy seeds. After setting a particular bit to 1, the FIPS/CC compliance flag of the corresponding instance will be forced to true upon the next Instantiate or Reseed command. Note that for this to work, !!CTRL.FIPS_FORCE_ENABLE needs to be set to kMultiBitBool4True.

2.1.5.11.4.5.2.1.1.20. HW_EXC_STS

Table 215. csrng.HW_EXC_STS fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	HW_EXC_STS	RW0C	0x0	Reading this register indicates whether one of the CSRNG HW instances has encountered an exception. Each bit corresponds to a particular hardware instance, with bit 0 corresponding to instance HW0, bit 1 corresponding to instance HW1, and so forth. (To monitor the status of requests made to the SW instance, check the !!SW_CMD_STS register). Writing a zero to this register resets the status bits.

2.1.5.11.4.5.2.1.1.21. RECOV_ALERT_STS

Table 216. csrng.RECOV_ALERT_STS fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15	CMD_STAGE_RESEED_CNT_ALERT	RW0C	0x0	This bit is set when the maximum number of generate requests between reseeds is exceeded. The invalid generate command is ignored and CSRNG continues to operate. Writing a zero resets this status bit.

Bits	Field	Access	Reset	Description
14	CMD_STAGE_INVALID_CMD_SEQ_ALERT	RW0C	0x0	This bit is set when an out of order command is received by the main state machine. This happens when an instantiate command is sent for a state that was already instantiated or when any command other than instantiate is sent for a state that wasn't instantiated yet. The invalid command is ignored and CSRNG continues to operate. Writing a zero resets this status bit.
13	CMD_STAGE_INVALID_ACMD_ALERT	RW0C	0x0	This bit is set when an unsupported/illegal CSRNG command is received by the main state machine. The invalid command is ignored and CSRNG continues to operate. Writing a zero resets this status bit.
12	CS_BUS_CMP_ALERT	RW0C	0x0	This bit is set when the software application port genbits bus value is equal to the prior valid value on the bus, indicating a possible attack. Writing a zero resets this status bit.
11:5	Reserved	-	-	Reserved
4	ACMD_FLAG0_FIELD_ALERT	RW0C	0x0	This bit is set when the FLAG0 field in the Application Command is set to a value other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
3	FIPS_FORCE_ENABLE_FIELD_ALERT	RW0C	0x0	This bit is set when the FIPS_FORCE_ENABLE field in the !!CTRL register is set to a value other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
2	READ_INT_STATE_FIELD_ALERT	RW0C	0x0	This bit is set when the READ_INT_STATE field in the !!CTRL register is set to a value other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
1	SW_APP_ENABLE_FIELD_ALERT	RW0C	0x0	This bit is set when the SW_APP_ENABLE field in the !!CTRL register is set to a value other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
0	ENABLE_FIELD_ALERT	RW0C	0x0	This bit is set when the ENABLE field in the !!CTRL register is set to a value other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.

2.1.5.11.4.5.2.1.1.22. ERR_CODE

Table 217. csrng.ERR_CODE fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30	FIFO_STATE_ERR	R	0x0	This bit will be set to one when any of the source bits (bits 0 through 15 of this this register) are asserted as a result of an error pulse generated from any FIFO where both the empty and full status bits are set. This bit will stay set until the next reset.
29	FIFO_READ_ERR	R	0x0	This bit will be set to one when any of the source bits (bits 0 through 15 of this this register) are asserted as a result of an error pulse generated from any empty FIFO that has received a read pulse. This bit will stay set until the next reset.
28	FIFO_WRITE_ERR	R	0x0	This bit will be set to one when any of the source bits (bits 0 through 15 of this this register) are asserted as a result of an error pulse generated from any full FIFO that has been received a write pulse. This bit will stay set until the next reset.
27	Reserved	-	-	Reserved
26	CTR_ERR	R	0x0	This bit will be set to one when a mismatch in any of the hardened counters has been detected. This error will signal a fatal alert, and also an interrupt if enabled. This bit will stay set until the next reset.
25	AES_CIPHER_SM_ERR	R	0x0	This bit will be set to one when an AES fatal error has been detected. This error will signal a fatal alert, and also an interrupt if enabled. This bit will stay set until the next reset.

Bits	Field	Access	Reset	Description
24:23	Reserved	-	-	Reserved
22	CTR_DRBG_SM_ERR	R	0x0	This bit will be set to one when an illegal state has been detected for the ctr_drbg state machine. This error will signal a fatal alert, and also an interrupt if enabled. This bit will stay set until the next reset.
21	MAIN_SM_ERR	R	0x0	This bit will be set to one when an illegal state has been detected for the main state machine. This error will signal a fatal alert, and also an interrupt if enabled. This bit will stay set until the next reset.
20	CMD_STAGE_SM_ERR	R	0x0	This bit will be set to one when an illegal state has been detected for the command stage state machine. This error will signal a fatal alert, and also an interrupt if enabled. This bit will stay set until the next reset.
19:2	Reserved	-	-	Reserved
1	SFIFO_GENBITS_ERR	R	0x0	This bit will be set to one when an error has been detected for the command stage genbits FIFO. The type of error is reflected in the type status bits (bits 28 through 30 of this register). This bit will stay set until the next reset.
0	SFIFO_CMD_ERR	R	0x0	This bit will be set to one when an error has been detected for the command stage command FIFO. The type of error is reflected in the type status bits (bits 28 through 30 of this register). This bit will stay set until the next reset.

2.1.5.11.4.5.2.1.1.23. ERR_CODE_TEST

Table 218. csrng.ERR_CODE_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	ERR_CODE_TEST	RW	0x0	Setting this field will set the bit number for which an error will be forced in the hardware. This bit number is that same one found in the !!ERR_CODE register. The action of writing this register will force an error pulse. The sole purpose of this register is to test that any error properly propagates to either an interrupt or an alert.

2.1.5.11.4.5.2.1.1.24. MAIN_SM_STATE

Table 219. csrng.MAIN_SM_STATE fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	MAIN_SM_STATE	R	0x37	This is the state of the CSRNG main state machine. See the RTL file csrng_main_sm for the meaning of the values.

2.1.5.11.4.5.2.2. EDN Registers

2.1.5.11.4.5.2.2.1. Entropy Distribution Network

Distributes random numbers produced by CSRNG to hardware blocks

Table 220. Entropy Distribution Network register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-

Address	Name	Access	Description
0xC	ALERT_TEST	W	-
0x10	REGWEN	RW	-
0x14	CTRL	RW	-
0x18	BOOT_INS_CMD	RW	-
0x1C	BOOT_GEN_CMD	RW	-
0x20	SW_CMD_REQ	W	-
0x24	SW_CMD_STS	R	-
0x28	HW_CMD_STS	R	-
0x2C	RESEED_CMD	W	-
0x30	GENERATE_CMD	W	-
0x34	MAX_NUM_REQS_BETWEEN_RESEEDS	RW	-
0x38	RECOV_ALERT_STS	RW	-
0x3C	ERR_CODE	R	-
0x40	ERR_CODE_TEST	RW	-
0x44	MAIN_SM_STATE	R	-

2.1.5.11.4.5.2.2.1.1. INTR_STATE

Table 221. edn.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	edn_fatal_err	RW1C	0x0	Asserted when a FIFO error occurs.
0	edn_cmd_req_done	RW1C	0x0	Asserted when a software CSRNG request has completed.

2.1.5.11.4.5.2.2.1.2. INTR_ENABLE

Table 222. edn.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	edn_fatal_err	RW	0x0	Enable interrupt when !!INTR_STATE.edn_fatal_err is set.
0	edn_cmd_req_done	RW	0x0	Enable interrupt when !!INTR_STATE.edn_cmd_req_done is set.

2.1.5.11.4.5.2.2.1.3. INTR_TEST

Table 223. edn.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	edn_fatal_err	W	0x0	Write 1 to force !!INTR_STATE.edn_fatal_err to 1.
0	edn_cmd_req_done	W	0x0	Write 1 to force !!INTR_STATE.edn_cmd_req_done to 1.

2.1.5.11.4.5.2.2.1.4. ALERT_TEST

Table 224. edn.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	fatal_alert	W	0x0	Write 1 to trigger one alert event of this kind.
0	recov_alert	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.11.4.5.2.2.1.5. REGWEN

Table 225. edn.REGWEN fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	REGWEN	RW0C	0x1	When true, the CTRL can be written by software. When false, this field read-only. Defaults true, write zero to clear. Note that this needs to be cleared after initial configuration at boot in order to lock in the listed register settings.

2.1.5.11.4.5.2.2.1.6. CTRL

Table 226. edn.CTRL fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:12	CMD_FIFO_RST	RW	0x9	Setting this field to kMultiBitBool4True clears the two command FIFOs: the RESEED_CMD FIFO and the GENERATE_CMD FIFO. This field must be set to the reset state by software before any further commands can be issued to these FIFOs.
11:8	AUTO_REQ_MODE	RW	0x9	Setting this field to kMultiBitBool4True enables auto request mode. In this mode, EDN automatically sends `generate` and `reseed` command requests to the CSRNG application interface. The purpose of this mode is to continuously deliver entropy to endpoints without firmware intervention. For this to work, firmware has to 1) configure the !!GENERATE_CMD, !!RESEED_CMD, and !!MAX_NUM_REQS_BETWEEN_RESEEDS registers, and 2) to issue the first `instantiate` command via the !!SW_CMD_REQ register. Once this command has been acknowledged by CSRNG, the first `generate` command is sent out automatically, and a `reseed` command is sent after every MAX_NUM_REQS_BETWEEN_RESEEDS number of `generate` commands. Note that the BOOT_REQ_MODE field takes precedence over this field: If both fields are set, EDN enters boot-time request mode. If none of the fields are set, EDN enters Software Port Mode upon enabling.
7:4	BOOT_REQ_MODE	RW	0x9	Setting this field to kMultiBitBool4True enables the boot-time request mode. In this mode, EDN automatically sends a boot-time request to the CSRNG application interface. The purpose of this mode is to request entropy as fast as possible after reset, and during chip boot time. Note that this takes precedence over the AUTO_REQ_MODE field: If both fields are set, EDN enters boot-time request mode. If none of the fields are set, EDN enters Software Port Mode upon enabling.
3:0	EDN_ENABLE	RW	0x9	Setting this field to kMultiBitBool4True enables the EDN module. The modules of the entropy complex may only be enabled and disabled in a specific order, see Programmers Guide for details.

2.1.5.11.4.5.2.2.1.7. BOOT_INS_CMD

Table 227. edn.BOOT_INS_CMD fields

Bits	Field	Access	Reset	Description
31:0	BOOT_INS_CMD	RW	0x901	This field is used as the value for the instantiate command at boot time. See [Command Header](../../csrng/doc/theory_of_operation.md#command-header) for the meaning of the individual bits. Note that the hardware only supports a value of 0 for the clen field. If clen has a different value, EDN will hang. Fixing this requires disabling and restarting both EDN and CSRNG.

2.1.5.11.4.5.2.2.1.8. BOOT_GEN_CMD

Table 228. edn.BOOT_GEN_CMD fields

Bits	Field	Access	Reset	Description
31:0	BOOT_GEN_CMD	RW	0xFFF003	This field is used as the value for the generate command at boot time. See [Command Header](../../csrng/doc/theory_of_operation.md#command-header) for the meaning of the individual bits. Note that the hardware only supports a value of 0 for the clen field. If clen has a different value, EDN will hang. Fixing this requires disabling and restarting both EDN and CSRNG.

2.1.5.11.4.5.2.2.1.9. SW_CMD_REQ

Table 229. edn.SW_CMD_REQ fields

Bits	Field	Access	Reset	Description
31:0	SW_CMD_REQ	W	-	Any CSRNG action can be initiated by writing a CSRNG command to this register. Before any write operation to this register, firmware must read !!SW_CMD_STS to check whether EDN is ready to receive a new command or the next word of a previously started command. While !!CTRL.AUTO_REQ_MODE is set, only the first instantiate command has any effect. After that command has been processed, writes to this register will have no effect on operation, until !!CTRL.AUTO_REQ_MODE is de-asserted and the state machine of EDN enters the SwPortMode state. Refer to the [CSRNG documentation](../../csrng/doc/theory_of_operation.md#general-command-format) for details on the command format.

2.1.5.11.4.5.2.2.1.10. SW_CMD_STS

Table 230. edn.SW_CMD_STS fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:3	CMD_STS	R	0x0	This field represents the status code returned with the CSRNG application command ack. It is updated each time a SW command is acknowledged by CSRNG. To check whether a command was successful, wait for !!INTR_STATE.EDN_CMD_REQ_DONE or !!SW_CMD_STS.CMD_ACK to be high and then check the value of this field. A description of the command status types can be found [here](../../csrng/doc/registers.md#sw_cmd_sts—cmd_sts).

Bits	Field	Access	Reset	Description
2	CMD_ACK	R	0x0	This one bit field indicates when a SW command has been acknowledged by the CSRNG. It is set to low each time a new command is written to !!SW_CMD_REQ. The field is set to high once a SW command request has been acknowledged by the CSRNG. 0b0: The last SW command has not been acknowledged yet. 0b1: The last SW command has been acknowledged.
1	CMD_RDY	R	0x0	This bit indicates when the EDN is ready to accept the next command. Before starting to write a new command to !!SW_CMD_REQ, this field needs to be polled. 0b0: The EDN is not ready to accept commands or the last command hasn't been acked yet. 0b1: The EDN is ready to accept the next command.
0	CMD_REG_RDY	R	0x0	This bit indicates when !!SW_CMD_REQ is ready to accept the next word. This bit has to be polled before each word of a command is written to !!SW_CMD_REQ. 0b0: The EDN is not ready to accept the next word yet. 0b1: The EDN is ready to accept the next word.

2.1.5.11.4.5.2.2.1.11. HW_CMD_STS

Table 231. edn.HW_CMD_STS fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:7	CMD_STS	R	0x0	This field represents the status code returned with the CSRNG application command ack. It is updated each time a HW command is acknowledged by CSRNG. A description of the command status types can be found [here](../../csrng/doc/registers.md#sw_cmd_sts—cmd_sts).
6	CMD_ACK	R	0x0	This one bit field indicates when a HW command has been acknowledged by the CSRNG. It is set to low each time a new command is sent to the CSRNG. The field is set to high once a HW command request has been acknowledged by the CSRNG. 0b0: The last HW command has not been acknowledged yet. 0b1: The last HW command has been acknowledged.
5:2	CMD_TYPE	R	0x0	This field contains the application command type of the hardware controlled command issued last. The application command selects one of five operations to perform. A description of the application command types can be found [here](../../csrng/doc/theory_of_operation.md#command-description).
1	AUTO_MODE	R	0x0	This one bit field indicates whether the EDN is in the hardware controlled part of auto mode. The instantiate command is issued via SW interface and is thus not part of the hardware controlled part of auto mode. 0b0: The EDN is not in the hardware controlled part of auto mode. 0b1: The EDN is in the hardware controlled part of auto mode.
0	BOOT_MODE	R	0x0	This one bit field indicates whether the EDN is in the hardware controlled boot mode. 0b0: The EDN is not in boot mode. 0b1: The EDN is in boot mode.

2.1.5.11.4.5.2.2.1.12. RESEED_CMD

Table 232. edn.RESEED_CMD fields

Bits	Field	Access	Reset	Description
31:0	RESEED_CMD	W	-	Writing this register will fill a FIFO with up to 13 command words (32b words). When running in auto request mode, this FIFO is used to automatically send out a reseed command to the CSRNG application interface after every MAX_NUM_REQS_BETWEEN_RESEEDS number of generate commands. See [General Command Format](../../csrng/doc/theory_of_operation.md#general-command-format) for details about the command format. Note that the number of additional data words provided must match the value of the clen field of the first word. Otherwise, undefined behavior may result. If more than 13 entries are written to the FIFO, they are ignored and EDN signals an edn_fatal_err interrupt as well as a fatal alert.

2.1.5.11.4.5.2.2.1.13. GENERATE_CMD

Table 233. edn.GENERATE_CMD fields

Bits	Field	Access	Reset	Description
31:0	GENERATE_CMD	W	-	Writing this register will fill a FIFO with up to 13 command words (32b words). When running auto request mode, this FIFO is used to automatically send out generate commands to the CSRNG application interface. See [General Command Format](../../csrng/doc/theory_of_operation.md#general-command-format) for details about the command format. Note that the number of additional data words provided must match the value of the clen field of the first word. Otherwise, undefined behavior may result. If more than 13 entries are written to the FIFO, they are ignored and EDN signals an edn_fatal_err interrupt as well as a fatal alert.

2.1.5.11.4.5.2.2.1.14. MAX_NUM_REQS_BETWEEN_RESEEDS

Table 234. edn.MAX_NUM_REQS_BETWEEN_RESEEDS fields

Bits	Field	Access	Reset	Description
31:0	MAX_NUM_REQS_BETWEEN_RESEEDS	RW	0x0	Setting this field will set the number of generate command requests that are made to CSRNG before a reseed request is made. This value only has meaning when running in auto request mode. This register supports a maximum of 2^32 generate requests between reseeds. This register will be used by a counter that counts down, triggering an automatic reseed request when it reaches zero. Note that this value must be chosen smaller than or equal to the value configured in the [RESEED_INTERVAL register of CSRNG](../../csrng/doc/registers.md#reseed-interval).

2.1.5.11.4.5.2.2.1.15. RECOV_ALERT_STS

Table 235. edn.RECOV_ALERT_STS fields

Bits	Field	Access	Reset	Description
31:14	Reserved	-	-	Reserved
13	CSRNG_ACK_ERR	RW0C	0x0	This bit is set when the CSRNG returns an acknowledgement where the status signal is non-zero. Writing a zero resets this status bit.

Bits	Field	Access	Reset	Description
12	EDN_BUS_CMP_ALERT	RW0C	0x0	This bit is set when the interal entropy bus value is equal to the prior valid value on the bus, indicating a possible attack. Writing a zero resets this status bit.
11:4	Reserved	-	-	Reserved
3	CMD_FIFO_RST_FIELD_ALERT	RW0C	0x0	This bit is set when the CMD_FIFO_RST field is set to an illegal value, something other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
2	AUTO_REQ_MODE_FIELD_ALERT	RW0C	0x0	This bit is set when the !!CTRL.AUTO_REQ_MODE field is set to an illegal value, something other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
1	BOOT_REQ_MODE_FIELD_ALERT	RW0C	0x0	This bit is set when the BOOT_REQ_MODE field is set to an illegal value, something other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.
0	EDN_ENABLE_FIELD_ALERT	RW0C	0x0	This bit is set when the EDN_ENABLE field is set to an illegal value, something other than kMultiBitBool4True or kMultiBitBool4False. Writing a zero resets this status bit.

2.1.5.11.4.5.2.2.1.16. ERR_CODE

Table 236. edn.ERR_CODE fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30	FIFO_STATE_ERR	R	0x0	This bit will be set to one when any of the source bits (bits 0 through 1 of this register) are asserted as a result of an error pulse generated from any FIFO where both the empty and full status bits are set or in case of error conditions inside the hardened counters. This bit will stay set until the next reset.
29	FIFO_READ_ERR	R	0x0	This bit will be set to one when any of the source bits (bits 0 through 1 of this register) are asserted as a result of an error pulse generated from any empty FIFO that has received a read pulse. This bit will stay set until the next reset.
28	FIFO_WRITE_ERR	R	0x0	This bit will be set to one when any of the source bits (bits 0 through 1 of this register) are asserted as a result of an error pulse generated from any full FIFO that has received a write pulse. This bit will stay set until the next reset.
27:23	Reserved	-	-	Reserved
22	EDN_CNTR_ERR	R	0x0	This bit will be set to one when a hardened counter has detected an error condition. This error will signal a fatal alert. This bit will stay set until the next reset.
21	EDN_MAIN_SM_ERR	R	0x0	This bit will be set to one when an illegal state has been detected for the EDN main stage state machine. This error will signal a fatal alert. This bit will stay set until the next reset.
20	EDN_ACK_SM_ERR	R	0x0	This bit will be set to one when an illegal state has been detected for the EDN ack stage state machine. This error will signal a fatal alert. This bit will stay set until the next reset.
19:2	Reserved	-	-	Reserved
1	SFIFO_GENCMD_ERR	R	0x0	This bit will be set to one when an error has been detected for the generate command FIFO. The type of error is reflected in the type status bits (bits 28 through 30 of this register). When this bit is set, a fatal error condition will result. This bit will stay set until the next reset.

Bits	Field	Access	Reset	Description
0	SFIFO_RESCMD_ERR	R	0x0	This bit will be set to one when an error has been detected for the reseed command FIFO. The type of error is reflected in the type status bits (bits 28 through 30 of this register). When this bit is set, a fatal error condition will result.

2.1.5.11.4.5.2.2.1.17. ERR_CODE_TEST

Table 237. edn.ERR_CODE_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	ERR_CODE_TEST	RW	0x0	Setting this field will set the bit number for which an error will be forced in the hardware. This bit number is that same one found in the !!ERR_CODE register. The action of writing this register will force an error pulse. The sole purpose of this register is to test that any error properly propagates to either an interrupt or an alert.

2.1.5.11.4.5.2.2.1.18. MAIN_SM_STATE

Table 238. edn.MAIN_SM_STATE fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8:0	MAIN_SM_STATE	R	0xC1	This is the state of the EDN main state machine. See the RTL file edn_main_sm for the meaning of the values.

2.1.5.11.5. Entropy Source

The entropy source component is a random number generator which is based on multiple asynchronous ring oscillators sampled in such a way to generate random bits from the jitter noise and metastable latching behavior. It forms the basis of a True Random Number Generator (TRNG).

The generated stream is ``raw'' noise in the sense that there may still be some statistical biases present which need to be filtered out by an optional entropy conditioner post processing unit which would consume the output noise bits. NIST specifies a set of acceptable conditioners. Common conditioners are based on standard hash functions such as SHA256 and ASCON as well as standard keyed hash functions such as AES-CMAC and HMAC.

The source includes a configurable SHA-256 whitener. Software can bypass whitening to observe the unconditioned stream; health tests also monitor the individual noise generators and the combined stream.




Figure 34. Entropy source microarchitecture

Figure 34 shows the entropy source and its conditioning pipeline. The client controls the component via the AXI4-Lite bus interface which provides access to a set of memory mapped configuration and status registers (CSRs) described later in this document. The noise generators feed the decorrelation, mixing, health-test, and optional whitening stages. Each word written into the main FIFO also leaves the block as `entropy_stream_data_o`, qualified by `entropy_stream_vld_o`, towards the DRBG; the FIFO itself is drained through the `FIFO_RDATA` register.

The main datapath in the figure runs left to right along the top row. The generator lane stands for all twelve lanes, and Figure 35 shows its noise source and sample clock in detail. The boot gate passes entropy only after the main state machine has seen a passing boot health-test window; it qualifies the whitener input, the uncompressed-byte path and the BIW observe FIFO, while the 32-bit health test and the noise observe FIFO see the stream ungated. The output select takes the whitener output, or, when `CTRL.BYPASS_ENTROPY_COMPRESSOR` is set, the twelve uncompressed decorrelator bytes as three 32-bit words, downsampled by `CTRL.DOWNSAMPLE_RATE`. The 32-bit health test is clock-gated off in that mode. The register block configures every stage; its connections to individual stages are not drawn. The debug monitor routes one of 256 internal signals to `signal_monitor_o`.

The health-test modules are OpenTitan's `entropy_src` repetition count, adaptive proportion and Markov tests, and the main state machine is OpenTitan's `entropy_src_main_sm`. Their internal structure is described in the OpenTitan entropy source documentation. The Programmer's Guide gives the programming guidance for this block.

The entropy source is designed according to guidelines set forth in the NIST SP800-90B specification and is planned to be ready for FIPS 140-2 and 140-3 certification. It will also be compliant with AIS31 statistical requirements specified by the BSI agency.

2.1.5.11.5.1. Noise Generation

The entropy source uses 12 independent ring oscillators as its noise source. Each ring oscillator is constructed from the

shared OCAH primitives (prim_clock_nand2, prim_buf, prim_stdmux2) to preserve the asynchronous feedback-loop structure through technology mapping. Each oscillator has two configurable lengths: a TOTAL_LENGTH and a TAPPED_LENGTH, where a multiplexer selects between the short and long feedback paths. The entropy_rosc_tune_fsm toggles between these two lengths on a rising edge of any health test failure, providing a rudimentary frequency detuning mechanism.

The oscillator output is sampled by a metastable D flip-flop (prim_flop) clocked by a sampling clock. The sampled bit is then synchronized to the system clock domain through a two-stage synchronizer. Each lane can be clocked either by an external sampling clock (rosc_sample_clk_i) or by a shared internal ring oscillator (total length 109, tapped length 53). A per-lane ripple divider provides division ratios of 1, 2, 4, 8, 16, and 32, selected through the CSR. Both selects are clock mux cells. Software changes a lane's source or division only while that generator is disabled. A division value outside 0-5 selects divide-by-4.

Figure 35 shows the ring oscillators, sampling paths, and clock selection used to generate noise.




Figure 35. Entropy source ring-oscillator complex

Figure 35 has three bands. The top band builds one sample clock per lane: RING_OSC_CTRL.SAMPLE_CLK_SELECT bit *i* chooses rosc_sample_clk_i (0) or the shared ring oscillator (1), and GENERATOR_i_SAMPLE_CLK_CONFIG.SAMPLE_CLK_DIVIDE picks one ripple-divider tap. The middle band is one of the twelve noise lanes; when CTRL.AUTOTUNE_ENABLE is set the lane detune follows the auto-tune FSM, otherwise RING_OSC_TUNE.DETUNE bit *i*. The bottom band is the ring oscillator used both in each lane and, with 109 and 53 stages, as the shared sampling oscillator. Green lines carry asynchronous oscillator signals, brown lines are in the sample-clock domain and grey lines are in the clk_i domain or are controls. Table 239 lists the lane ring lengths.

Table 239. Noise ring-oscillator lengths per lane

Lane	0	1	2	3	4	5	6	7	8	9	10	11
TOTAL_LENGTH (detune 1)	5	7	11	13	17	19	6	8	12	15	18	23
TAPPED_LENGTH (detune 0)	3	5	9	10	14	16	4	7	11	13	15	21

2.1.5.11.5.2. Decorrelation and BIW Mixing

Each sampled noise bit enters a serial decorrelator (`entropy_decorrelator`), which shifts bits through a 29-stage shift register with XOR feedback from the last stage, as Figure 36 shows. A downsample counter reloaded from `DECORRELATOR_CTRL.SAMPLE_CLK_DIV` latches the top 8 bits of the shift register as an entropy byte every `SAMPLE_CLK_DIV` + 1 `clk_i` cycles, 64 cycles at the reset value of 63, and pulses the byte-valid strobe for one cycle. The byte is ANDed with `DECORRELATOR_MASK.ENTROPY_BYTE_MASK`, so a cleared mask bit reads as zero; the mask and the divider are shared by all 12 lanes. Setting a lane's bit in `DECORRELATOR_CTRL.BYPASS` forces the feedback to zero, so raw noise bits shift through the chain unmixed; the byte is still taken from the top 8 stages, downsampled and masked.




Figure 36. Entropy source decorrelator

Figure 36 shows one lane's decorrelator. The chain shifts on every `clk_i` cycle while `enable_i` is high, and the eight taps from `ff_stage[21]` to `ff_stage[28]` join into one byte-wide bundle. The output register loads when the counter reaches zero. While `enable_i` is low, the chain holds its contents and the counter reloads from `sample_clk_div_i`.

The 12 decorrelated byte streams are combined by the Barak-Impagliazzo-Wigderson (BIW) stage, which uses four `gf_muladd` instances performing y = a*b + c in GF(2^8) with the AES field polynomial (0x1B). The 12 input bytes are grouped into three sets of four and reduced to a single 32-bit word. This mixing step improves the statistical independence of the output without introducing significant latency.

2.1.5.11.5.3. Health Testing

Health tests operate at two levels. Each of the 12 `entropy_generator` instances runs an 8-bit `entropy_health_test` on its individual decorrelated output. At the top level, a second 32-bit `entropy_health_test` instance monitors the post-BIW (or post-bypass) stream.

The health test wrapper instantiates three OpenTitan-derived test modules. The repetition count test (`entropy_src_repcnt_ht`) tracks consecutive identical values per bit lane and flags when a threshold is exceeded. The adaptive proportion test (`entropy_src_adaptp_ht`) accumulates per-bit ones counts within a configurable window and compares the maximum and minimum lane counts against high and low thresholds. The Markov test (`entropy_src_markov_ht`) counts bit-pair transitions and compares to high and low thresholds at window boundaries. Window synchronization is driven by a `prim_count` counter in the `entropy_generator_complex`.

Health test thresholds, enable bits, and window sizes are all programmable through the CSR interface. Test status is reported as an 8-bit vector where bit 0 indicates a repetition count failure, bit 3 an adaptive proportion failure, and bits

4-5 Markov high/low failures.

2.1.5.11.5.4. Health Test Watermark

HT_WATERMARK is one shared register whose source and maximum/minimum direction are selected by HT_WATERMARK_NUM; there is no independent storage per selector. A selector write changes which counter updates the shared register but does not clear it, so changing only the selector carries the value recorded by the previous mode.

The shared watermark is armed by a CTRL.MODULE_ENABLE 0-to-1 transition. High modes (REPCNT_HI, APT_HI, and MARKOV_HI) arm to 0x0000; low modes (APT_LO and MARKOV_LO) arm to 0xFFFF. A hardware reset restores the selector and watermark together, so a deterministic baseline requires HT_WATERMARK_NUM to be written before the MODULE_ENABLE toggle. With the reset-default MODULE_ENABLE=1, the power-on enable pulse performs the first mode-aware arm automatically.

2.1.5.11.5.5. Persistent Failure and AlertHang

The health-test subsystem includes a persistent-failure path that halts entropy output when failures persist beyond a programmed threshold. A saturating counter (ALERT_SUMMARY_FAIL_COUNTS.ANY_FAIL_COUNT) records one count per health-test window in which any test failed; a mid-window failure of the continuous repetition-count test is captured and counted once for that window. When the counter reaches ALERT_THRESHOLD.THRESHOLD (default 4, i.e. four failing windows, locked by FIPS_LOCK), alert_thresh_fail is asserted and the main FSM transitions through AlertState into AlertHang, halting entropy output. AlertHang persists until the FSM is reset by rst_ni or software clears CTRL.MODULE_ENABLE. The event sets MAIN_SM_STATUS.ALERT and raises INTR_STATUS.PERSISTENT_FAILURE. The sticky MAIN_SM_STATUS.ALERT and MAIN_SM_STATUS.ERR status bits are cleared by writing 1 (W1C) or by the full entropy-source reset.

Setting ALERT_THRESHOLD.THRESHOLD to zero disables the comparator, leaving the counter accumulating without ever asserting alert_thresh_fail.

2.1.5.11.5.6. SHA-256 Whitening

When the SHA-256 whitener is enabled via the CSR, the 32-bit BIW output stream feeds into the entropy_sha256_whitener module. This module accumulates 16 consecutive 32-bit words (one SHA-256 block of 512 bits), computes the SHA-256 digest using the OpenTitan prim_sha2_32 primitive, and emits the 8-word (256-bit) digest. The compression ratio is 2:1 (16 input words produce 8 output words). When the whitener is disabled, the BIW output passes through to the FIFO without modification.

2.1.5.11.5.7. Output FIFO

The conditioned entropy stream is stored in a 64-entry FIFO (entropy_fifo). Each entry is 36 bits wide: 32 data bits plus 4 byte-wise odd parity bits. The FIFO includes pointer integrity checking (normal and inverted pointer pairs with mismatch detection) and parity verification on reads. An optional churn mode XORs the incoming data with a word read from the diametrically opposite FIFO position, improving entropy distribution. Overflow, underflow, parity error, and pointer error conditions are all reported to the CSR block and can trigger interrupts.

The entropy_stream_data_o and entropy_stream_vld_o top-level ports carry each word as it is written into the FIFO, not the FIFO read data, and there is no backpressure. In SEP they connect to the DRBG seed path, which distributes the generated random data to the entropy consumers.

Because the FIFO holds the same words that seed the DRBG, FIFO_CTRL.ENABLE is covered by FIPS_LOCK. The field gates only the FIFO write, so the DRBG seed stream continues whatever its value. It resets to one, keeping the FIFO_RDATA read path live out of reset; the TRNG bring-up sequence in the Programmer's Guide closes it before FIPS_LOCK. Reads remain available while writes are disabled, so words already in the FIFO stay readable until they are drained.

2.1.5.11.5.8. Reset

The entropy source `rst_ni` input resets its register block, health-test/FSM state, conditioning pipeline, counters, and FIFOs. Reserved `CTRL[0]` reads as zero and ignores writes.

At SEP integration level, `SEP_RESET_CTRL.SW_RESET_N.TRNG_SW_RST_N` requests a shared reset of the entropy source and DRBG. Hardware first drains and isolates the ESRC, CSRNG, and EDN AXI ports, then asserts the common reset. This is a full-IP reset: all entropy-source CSRs and `FIPS_LOCK` return to reset values. Post-mux EDN adapters and the fabric entropy pool remain in the POR reset domain; they synchronously clear buffered entropy while the internal reset is active. After reset release, `MODULE_ENABLE` returning to one produces the normal enable pulse and restarts startup health testing before entropy is released.

2.1.5.11.5.9. Debug Observation Pin

`DEBUG_CTRL.SELECT_SIGNAL` routes one of 256 internal signals to the `signal_monitor_o` output, and `DEBUG_CTRL.SELECT_FREQ_DIV` divides it down for external observation. Some selections expose entropy ahead of conditioning: the raw per-generator noise bits, the compressed 32-bit entropy stream, and the uncompressed per-generator entropy bytes.

Both fields are covered by `FIPS_LOCK`: once `FIPS_LOCK.LOCK` is set, software can no longer retarget the pin or change its divider, so a locked, certified part cannot route pre-conditioning entropy to the observation pin. The raw and BIW observe-FIFO capture enables (`NOISE_OBS_CTRL.RAW_ENABLE`, `BIW_OBS_CTRL.RAW_ENABLE`) are held under the lock the same way. SP 800-90B treats this pre-conditioning observation as a validation-time interface that may be disabled in the field, which the lock enforces. As defense in depth, SEP also leaves `signal_monitor_o` unconnected and false-paths the port in synthesis; an integration that routes the pin off-chip still owns restricting access to the lifecycle or debug states in which observing pre-conditioning entropy is acceptable.

2.1.5.11.5.10. Memory Map and Register Reference

2.1.5.11.5.10.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.11.5.10.2. Detailed Register Map

2.1.5.11.5.10.2.1. Entropy Source Address Map

Entropy-source configuration, status, and data registers.

Table 240. Entropy Source Address Map register list

Address	Name	Access	Description
0x0	COMPONENT_ID	R	Identifies the entropy-source register interface.
0x4	CTRL	RW	Controls entropy generation and conditioning.
0xC	DEBUG_CTRL	RW	Controls the external debug observation pin. FIPS_LOCK.LOCK prevents software changes to the signal selection and divider.
0x10	INTR_STATUS	RW	Reports latched interrupt status; write one to clear a bit.
0x14	INTR_ENABLE	RW	Enables individual interrupt sources.
0x18	INTR_TEST	W	Triggers individual interrupt sources for testing.
0x1C	SHA256_STATUS	R	Reports SHA-256 conditioner progress.

Address	Name	Access	Description
0x20	FIFO_CTRL	RW	Controls the 64-entry main entropy FIFO.
0x24	FIFO_STATUS	R	Reports main FIFO occupancy and pointers.
0x28	FIFO_RDATA	R	Provides the next main FIFO word.
0x30	HEALTH_TEST_CTRL	RW	Controls continuous entropy health tests.
0x34	HEALTH_TEST_WINDOW_SIZE	RW	Sets the APT and Markov window length.
0x38	MARKOV_TEST_PROB_THRESHOLDS	RW	Sets high and low Markov alternation-count thresholds.
0x40	HEALTH_TEST_STATUS	RW	Latches 32-bit stream health-test failures: repetition [0], APT high or low [3], Markov high [4], and Markov low [5]. Write one to clear.
0x44	REPETITION_TEST_COUNT	R	Reports the highest current repetition count.
0x50	APT_PATTERN_COUNT_1BIT	R	Reports the highest per-lane APT one-count in the current window.
0x54	APT_PATTERN_COUNT_2BIT	R	Reports the lowest per-lane APT one-count in the current window.
0x60	APT_PROPORTION_1BIT	RW	Sets the APT high one-count threshold.
0x70	APT_PROPORTION_LO	RW	Sets the APT low one-count threshold.
0x80	MARKOV_TEST_COUNTS_0	R	Reports the highest and lowest per-lane alternation counts in the current Markov window.
0x90	RING_OSC_ENABLE	RW	Controls noise and sample-clock ring oscillators.
0x94	RING_OSC_TUNE	RW	Selects detuned ring-oscillator tap points.
0x98	RING_OSC_CTRL	RW	Selects each generator sample-clock source.
0xA0	DECORRELATOR_CTRL	RW	Controls generator decorrelation and byte cadence.
0xA4	DECORRELATOR_MASK	RW	Masks bits in every generator entropy byte.
0xB4	MAIN_SM_STATUS	RW	Reports the startup health-test gate state machine.
0xC0	GENERATOR_0_HEALTH_STATUS	RW	Latches generator 0 health-test failures; write one to clear.
0xC4	GENERATOR_1_HEALTH_STATUS	RW	Latches generator 1 health-test failures; write one to clear.
0xC8	GENERATOR_2_HEALTH_STATUS	RW	Latches generator 2 health-test failures; write one to clear.
0xCC	GENERATOR_3_HEALTH_STATUS	RW	Latches generator 3 health-test failures; write one to clear.
0xD0	GENERATOR_4_HEALTH_STATUS	RW	Latches generator 4 health-test failures; write one to clear.
0xD4	GENERATOR_5_HEALTH_STATUS	RW	Latches generator 5 health-test failures; write one to clear.
0xD8	GENERATOR_6_HEALTH_STATUS	RW	Latches generator 6 health-test failures; write one to clear.
0xDC	GENERATOR_7_HEALTH_STATUS	RW	Latches generator 7 health-test failures; write one to clear.
0xE0	GENERATOR_8_HEALTH_STATUS	RW	Latches generator 8 health-test failures; write one to clear.
0xE4	GENERATOR_9_HEALTH_STATUS	RW	Latches generator 9 health-test failures; write one to clear.
0xE8	GENERATOR_10_HEALTH_STATUS	RW	Latches generator 10 health-test failures; write one to clear.
0xEC	GENERATOR_11_HEALTH_STATUS	RW	Latches generator 11 health-test failures; write one to clear.
0x100	GENERATOR_0_SAMPLE_CLK_CONFIG	RW	Controls generator 0 sample-clock division.
0x104	GENERATOR_1_SAMPLE_CLK_CONFIG	RW	Controls generator 1 sample-clock division.
0x108	GENERATOR_2_SAMPLE_CLK_CONFIG	RW	Controls generator 2 sample-clock division.
0x10C	GENERATOR_3_SAMPLE_CLK_CONFIG	RW	Controls generator 3 sample-clock division.
0x110	GENERATOR_4_SAMPLE_CLK_CONFIG	RW	Controls generator 4 sample-clock division.
0x114	GENERATOR_5_SAMPLE_CLK_CONFIG	RW	Controls generator 5 sample-clock division.
0x118	GENERATOR_6_SAMPLE_CLK_CONFIG	RW	Controls generator 6 sample-clock division.
0x11C	GENERATOR_7_SAMPLE_CLK_CONFIG	RW	Controls generator 7 sample-clock division.
0x120	GENERATOR_8_SAMPLE_CLK_CONFIG	RW	Controls generator 8 sample-clock division.

Address	Name	Access	Description
0x124	GENERATOR_9_SAMPLE_CLK_CONFIG	RW	Controls generator 9 sample-clock division.
0x128	GENERATOR_10_SAMPLE_CLK_CONFIG	RW	Controls generator 10 sample-clock division.
0x12C	GENERATOR_11_SAMPLE_CLK_CONFIG	RW	Controls generator 11 sample-clock division.
0x130	HT_WATERMARK_NUM	RW	Selects the counter and direction for the shared health-test watermark. Changing the selection preserves the current watermark.
0x134	HT_WATERMARK	R	Reports one selector-dependent watermark. A CTRL.MODULE_ENABLE rising edge arms high modes to zero and low modes to 0xFFFF.
0x138	REPCNT_TOTAL_FAILS	R	Counts repetition-test failures since the last CTRL.MODULE_ENABLE rising edge.
0x13C	APT_HI_TOTAL_FAILS	R	Counts APT high-threshold failures since the last CTRL.MODULE_ENABLE rising edge.
0x140	APT_LO_TOTAL_FAILS	R	Counts APT low-threshold failures since the last CTRL.MODULE_ENABLE rising edge.
0x144	MARKOV_HI_TOTAL_FAILS	R	Counts Markov high-threshold failures since the last CTRL.MODULE_ENABLE rising edge.
0x148	MARKOV_LO_TOTAL_FAILS	R	Counts Markov low-threshold failures since the last CTRL.MODULE_ENABLE rising edge.
0x14C	ALERT_SUMMARY_FAIL_COUNTS	R	Counts consecutive health-test windows containing any failure and clears after an accepted passing window.
0x150	ALERT_FAIL_COUNTS	R	Reports saturating per-test failure counts for the current alert sequence.
0x154	FIPS_LOCK	RW	Locks entropy generation, conditioning, and health-test configuration against software writes until hardware reset.
0x158	ALERT_THRESHOLD	RW	Sets the failing-window count that enters the persistent-failure alert path.
0x15C	MIN_ENTROPY_H	RW	Stores assessed per-sample min-entropy in unsigned Q4.4 format for advisory threshold calculation.
0x160	RECOMMENDED_THRESHOLDS	R	Reports advisory repetition and APT thresholds derived from MIN_ENTROPY_H.
0x164	BIW_OBS_CTRL	RW	Controls copy-only capture of the post-BIW, pre-SHA stream.
0x168	BIW_OBS_STATUS	R	Reports BIW observe FIFO occupancy and pointers.
0x16C	BIW_OBS_RDATA	R	Provides the next post-BIW, pre-SHA observe word.
0x170	NOISE_OBS_CTRL	RW	Controls copy-only capture of one pre-decorrelator generator lane.
0x174	NOISE_OBS_STATUS	R	Reports raw-noise observe FIFO occupancy and pointers.
0x178	NOISE_OBS_RDATA	R	Provides the next packed raw-noise observe word.

2.1.5.11.5.10.2.1.1. COMPONENT_ID

Table 241. entropy_source.COMPONENT_ID fields

Bits	Field	Access	Reset	Description
31:28	MAJOR_VERSION	R	0x0	Major interface version.
27:24	MINOR_VERSION	R	0x1	Minor interface version.
23:16	Reserved	-	-	Reserved
15:0	NAME	R	0x1	Entropy-source component identifier.

2.1.5.11.5.10.2.1.2. CTRL

Table 242. entropy_source.CTRL fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	SHA256_WHITENING_ENABLE	RW	0x1	Enables SHA-256 conditioning of each 512-bit BIW input block into a 256-bit digest. When clear, BIW words pass directly to the FIFO. FIPS_LOCK.LOCK prevents software changes.
27:26	Reserved	-	-	Reserved
25:16	DOWNSAMPLE_RATE	RW	0x0	Selects every (N+1)th decorrelator output while BIW extraction is bypassed. FIPS_LOCK.LOCK prevents software changes.
15:9	Reserved	-	-	Reserved
8	BYPASS_ENTROPY_COMPRESSOR	RW	0x0	Bypasses BIW extraction and writes the twelve generator bytes to the FIFO as three 32-bit words. FIPS_LOCK.LOCK prevents software changes.
7:5	Reserved	-	-	Reserved
4	AUTOTUNE_ENABLE	RW	0x0	Enables per-generator automatic detuning after a lane health-test failure. FIPS_LOCK.LOCK prevents software changes.
3:2	Reserved	-	-	Reserved
1	MODULE_ENABLE	RW	0x1	Enables startup health testing and entropy output. Clearing this field holds the main state machine idle. FIPS_LOCK.LOCK prevents software changes.
0	RSVD0	R	0x0	Reserved; reads zero and ignores writes.

2.1.5.11.5.10.2.1.3. DEBUG_CTRL

Table 243. entropy_source.DEBUG_CTRL fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10:8	SELECT_FREQ_DIV	RW	0x0	Selects observation division by 1, 2, 4, 8, 16, 32, 64, or 128. FIPS_LOCK.LOCK prevents software changes.
7:0	SELECT_SIGNAL	RW	0x0	Selects the observed signal: generator noise bits [11:0], sample clocks [27:16], BIW data [63:32], FIFO input [95:64], or generator bytes [223:128]. Other selections drive the divider input low. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.4. INTR_STATUS

Table 244. entropy_source.INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	NOISE_OBS_OVERFLOW	RW1C	0x0	Indicates that a raw-noise observe FIFO word was discarded while full. Write one to clear.
27:25	Reserved	-	-	Reserved
24	BIW_OBS_OVERFLOW	RW1C	0x0	Indicates that a BIW observe FIFO word was discarded while full. Write one to clear.
23:21	Reserved	-	-	Reserved
20	AUTOTUNE_FAIL	RW1C	0x0	Indicates a per-generator health-test failure while automatic detuning is enabled. Write one to clear.
19:17	Reserved	-	-	Reserved
16	PERSISTENT_FAILURE	RW1C	0x0	Indicates a persistent health-test failure or health-test counter error. Write one to clear.
15:13	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
12	FIFO_UNDERFLOW	RW1C	0x0	Indicates that software read the empty main FIFO. Write one to clear.
11:9	Reserved	-	-	Reserved
8	FIFO_OVERFLOW	RW1C	0x0	Indicates that a main FIFO write was discarded while full. Write one to clear.
7:5	Reserved	-	-	Reserved
4	FIFO_ERROR	RW1C	0x0	Indicates a FIFO integrity error. Write one to clear.
3:1	Reserved	-	-	Reserved
0	HEALTH_TEST_FAILED	RW1C	0x0	Indicates a failure in the 32-bit entropy-stream health tests. Write one to clear.

2.1.5.11.5.10.2.1.5. INTR_ENABLE

Table 245. entropy_source.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	NOISE_OBS_OVERFLOW	RW	0x0	Enables the raw-noise observe FIFO overflow interrupt.
27:25	Reserved	-	-	Reserved
24	BIW_OBS_OVERFLOW	RW	0x0	Enables the BIW observe FIFO overflow interrupt.
23:21	Reserved	-	-	Reserved
20	AUTOTUNE_FAIL	RW	0x0	Enables the automatic-detuning failure interrupt.
19:17	Reserved	-	-	Reserved
16	PERSISTENT_FAILURE	RW	0x0	Enables the persistent-failure interrupt.
15:13	Reserved	-	-	Reserved
12	FIFO_UNDERFLOW	RW	0x0	Enables the main FIFO underflow interrupt.
11:9	Reserved	-	-	Reserved
8	FIFO_OVERFLOW	RW	0x0	Enables the main FIFO overflow interrupt.
7:5	Reserved	-	-	Reserved
4	FIFO_ERROR	RW	0x0	Enables the FIFO integrity-error interrupt.
3:1	Reserved	-	-	Reserved
0	HEALTH_TEST_FAILED	RW	0x0	Enables the health-test failure interrupt.

2.1.5.11.5.10.2.1.6. INTR_TEST

Table 246. entropy_source.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	NOISE_OBS_OVERFLOW	W 1P	0x0	Write one to pulse the raw-noise observe FIFO overflow interrupt source.
27:25	Reserved	-	-	Reserved
24	BIW_OBS_OVERFLOW	W 1P	0x0	Write one to pulse the BIW observe FIFO overflow interrupt source.
23:21	Reserved	-	-	Reserved
20	AUTOTUNE_FAIL	W 1P	0x0	Write one to pulse the automatic-detuning failure interrupt source.
19:17	Reserved	-	-	Reserved
16	PERSISTENT_FAILURE	W 1P	0x0	Write one to pulse the persistent-failure interrupt source.

Bits	Field	Access	Reset	Description
15:13	Reserved	-	-	Reserved
12	FIFO_UNDERFLOW	W 1P	0x0	Write one to pulse the main FIFO underflow interrupt source.
11:9	Reserved	-	-	Reserved
8	FIFO_OVERFLOW	W 1P	0x0	Write one to pulse the main FIFO overflow interrupt source.
7:5	Reserved	-	-	Reserved
4	FIFO_ERROR	W 1P	0x0	Write one to pulse the FIFO integrity-error interrupt source.
3:1	Reserved	-	-	Reserved
0	HEALTH_TEST_FAILED	W 1P	0x0	Write one to pulse the health-test failure interrupt source.

2.1.5.11.5.10.2.1.7. SHA256_STATUS

Table 247. entropy_source.SHA256_STATUS fields

Bits	Field	Access	Reset	Description
31:12	Reserved	-	-	Reserved
11:8	OUTPUT_COUNT	R	0x0	Number of 32-bit digest words remaining for output. Reports 8 when a digest becomes available, decrements through 0 as words are accepted, and remains 0 while idle or bypassed.
7:4	INPUT_COUNT	R	0x0	Number of 32-bit words currently accumulated in the 512-bit input block.
3:1	Reserved	-	-	Reserved
0	BUSY	R	0x0	Indicates that SHA-256 processing or digest output is active.

2.1.5.11.5.10.2.1.8. FIFO_CTRL

Table 248. entropy_source.FIFO_CTRL fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	ENTROPY_CHURN_ENABLE	RW	0x0	XORs each incoming word with the FIFO entry 32 positions ahead of the write pointer. FIPS_LOCK.LOCK prevents software changes.
3:1	Reserved	-	-	Reserved
0	ENABLE	RW	0x1	Enables FIFO writes. Reads remain available while writes are disabled. Words offered to the FIFO are also the DRBG seed stream, which this field does not gate. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.9. FIFO_STATUS

Table 249. entropy_source.FIFO_STATUS fields

Bits	Field	Access	Reset	Description
31:22	Reserved	-	-	Reserved
21:16	RPTR	R	0x0	Current FIFO read pointer.
15:14	Reserved	-	-	Reserved
13:8	WPTR	R	0x0	Current FIFO write pointer.
7	Reserved	-	-	Reserved
6:0	LEVEL	R	0x0	Number of valid 32-bit words in the FIFO.

2.1.5.11.5.10.2.1.10. FIFO_RDATA

Table 250. entropy_source.FIFO_RDATA fields

Bits	Field	Access	Reset	Description
31:0	RDATA	R RMOD	0x0	Returns and removes the next FIFO word. Reading an empty FIFO sets INTR_STATUS.FIFO_UNDERFLOW and returns undefined data.

2.1.5.11.5.10.2.1.11. HEALTH_TEST_CTRL

Table 251. entropy_source.HEALTH_TEST_CTRL fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:8	REPETITION_LIMIT	RW	0x19	Maximum allowed per-lane repetition count before the test fails. FIPS_LOCK.LOCK prevents software changes.
7:3	Reserved	-	-	Reserved
2:0	ENABLE	RW	0x7	Enables the repetition-count, adaptive-proportion, and Markov tests in bits 0, 1, and 2. Disabling a test clears its state.

2.1.5.11.5.10.2.1.12. HEALTH_TEST_WINDOW_SIZE

Table 252. entropy_source.HEALTH_TEST_WINDOW_SIZE fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	SIZE	RW	0x800	Number of valid entropy words per APT and Markov window. FIPS_LOCK.LOCK requires a value of at least 1024 and prevents software changes.

2.1.5.11.5.10.2.1.13. MARKOV_TEST_PROB_THRESHOLDS

Table 253. entropy_source.MARKOV_TEST_PROB_THRESHOLDS fields

Bits	Field	Access	Reset	Description
31:16	PROB_10_THRESHOLD	RW	0x64	Minimum allowed per-lane alternation count at the window boundary. FIPS_LOCK.LOCK prevents software changes.
15:0	PROB_01_THRESHOLD	RW	0x4B0	Maximum allowed per-lane alternation count at the window boundary. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.14. HEALTH_TEST_STATUS

Table 254. entropy_source.HEALTH_TEST_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	HEALTH_STATUS	RW1C	0x0	Latched health-test failure bits; write one to clear.

2.1.5.11.5.10.2.1.15. REPETITION_TEST_COUNT

Table 255. entropy_source.REPETITION_TEST_COUNT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
15:0	REPETITION_COUNT	R	0x0	Highest current repetition count among the 32 entropy lanes.

2.1.5.11.5.10.2.1.16. APT_PATTERN_COUNT_1BIT

Table 256. entropy_source.APT_PATTERN_COUNT_1BIT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	PATTERN_COUNT	R	0x0	Highest current one-count among the 32 entropy lanes.

2.1.5.11.5.10.2.1.17. APT_PATTERN_COUNT_2BIT

Table 257. entropy_source.APT_PATTERN_COUNT_2BIT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	PATTERN_COUNT	R	0x0	Lowest current one-count among the 32 entropy lanes.

2.1.5.11.5.10.2.1.18. APT_PROPORTION_1BIT

Table 258. entropy_source.APT_PROPORTION_1BIT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	LIMIT	RW	0x4B0	Maximum allowed per-lane one-count at the window boundary. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.19. APT_PROPORTION_LO

Table 259. entropy_source.APT_PROPORTION_LO fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	LIMIT	RW	0x350	Minimum allowed per-lane one-count at the window boundary. Zero disables the low-side test. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.20. MARKOV_TEST_COUNTS_0

Table 260. entropy_source.MARKOV_TEST_COUNTS_0 fields

Bits	Field	Access	Reset	Description
31:16	COUNT_10	R	0x0	Lowest current per-lane alternation count.
15:0	COUNT_01	R	0x0	Highest current per-lane alternation count.

2.1.5.11.5.10.2.1.21. RING_OSC_ENABLE

Table 261. entropy_source.RING_OSC_ENABLE fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
23:12	SAMPLE_CLK_ENABLE	RW	0xFFF	Enables the shared sample-clock ring oscillator when any bit is set. FIPS_LOCK.LOCK prevents software changes.
11:0	ENABLE	RW	0xFFF	Enables each generator noise ring oscillator. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.22. RING_OSC_TUNE

Table 262. entropy_source.RING_OSC_TUNE fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:12	SAMPLE_CLK_DETUNE	RW	0x0	Selects the full-length (longer) shared sample-clock oscillator tap, lowering its frequency, when any bit is set. FIPS_LOCK.LOCK prevents software changes.
11:0	DETUNE	RW	0x0	Selects the full-length (longer) tap for each noise ring oscillator, lowering its frequency, while automatic tuning is disabled; the reset value (clear) selects the shorter tap. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.23. RING_OSC_CTRL

Table 263. entropy_source.RING_OSC_CTRL fields

Bits	Field	Access	Reset	Description
31:12	Reserved	-	-	Reserved
11:0	SAMPLE_CLK_SELECT	RW	0xFFF	Selects the shared internal sample clock when set and the external sample clock when clear. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.24. DECORRELATOR_CTRL

Table 264. entropy_source.DECORRELATOR_CTRL fields

Bits	Field	Access	Reset	Description
31:12	SAMPLE_CLK_DIV	RW	0x3F	Sets the generator byte-output period to this value plus one sample-clock cycles. FIPS_LOCK.LOCK prevents software changes.
11:0	BYPASS	RW	0x0	Bypasses the LFSR feedback path independently for each generator. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.25. DECORRELATOR_MASK

Table 265. entropy_source.DECORRELATOR_MASK fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	ENTROPY_BYTE_MASK	RW	0xFF	Enables corresponding entropy-byte bits when set. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.26. MAIN_SM_STATUS

Table 266. entropy_source.MAIN_SM_STATUS fields

Bits	Field	Access	Reset	Description
31:14	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
13	ALERT_CNTR_CLR_OK	R	0x0	Indicates that a passing window may clear alert failure counters.
12	BOOT_PHASE_DONE	R	0x0	Indicates successful completion of startup health testing and permits entropy output.
11	ERR	RW1C	0x0	Latches an illegal state or health-test counter integrity error. Write one or reset the block to clear.
10	ALERT	RW1C	0x0	Latches entry into the persistent-failure alert path, which halts entropy output. Write one or reset the block to clear.
9	IDLE	R	0x0	Indicates that the state machine is idle.
8:0	STATE	R	0x0	Current sparse-encoded state-machine state.

2.1.5.11.5.10.2.1.27. GENERATOR_0_HEALTH_STATUS

Table 267. entropy_source.GENERATOR_0_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 0 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.28. GENERATOR_1_HEALTH_STATUS

Table 268. entropy_source.GENERATOR_1_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 1 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.29. GENERATOR_2_HEALTH_STATUS

Table 269. entropy_source.GENERATOR_2_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 2 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.30. GENERATOR_3_HEALTH_STATUS

Table 270. entropy_source.GENERATOR_3_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 3 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.31. GENERATOR_4_HEALTH_STATUS

Table 271. entropy_source.GENERATOR_4_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 4 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.32. GENERATOR_5_HEALTH_STATUS

Table 272. entropy_source.GENERATOR_5_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 5 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.33. GENERATOR_6_HEALTH_STATUS

Table 273. entropy_source.GENERATOR_6_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 6 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.34. GENERATOR_7_HEALTH_STATUS

Table 274. entropy_source.GENERATOR_7_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 7 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.35. GENERATOR_8_HEALTH_STATUS

Table 275. entropy_source.GENERATOR_8_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 8 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.36. GENERATOR_9_HEALTH_STATUS

Table 276. entropy_source.GENERATOR_9_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 9 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.37. GENERATOR_10_HEALTH_STATUS

Table 277. entropy_source.GENERATOR_10_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 10 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.38. GENERATOR_11_HEALTH_STATUS

Table 278. entropy_source.GENERATOR_11_HEALTH_STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	STATUS	RW1C	0x0	Generator 11 failure bits use the HEALTH_TEST_STATUS allocation.

2.1.5.11.5.10.2.1.39. GENERATOR_0_SAMPLE_CLK_CONFIG

Table 279. entropy_source.GENERATOR_0_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x0	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.40. GENERATOR_1_SAMPLE_CLK_CONFIG

Table 280. entropy_source.GENERATOR_1_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x0	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.41. GENERATOR_2_SAMPLE_CLK_CONFIG

Table 281. entropy_source.GENERATOR_2_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x1	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.42. GENERATOR_3_SAMPLE_CLK_CONFIG

Table 282. entropy_source.GENERATOR_3_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x1	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.43. GENERATOR_4_SAMPLE_CLK_CONFIG

Table 283. entropy_source.GENERATOR_4_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x2	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.44. GENERATOR_5_SAMPLE_CLK_CONFIG

Table 284. entropy_source.GENERATOR_5_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x2	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.45. GENERATOR_6_SAMPLE_CLK_CONFIG

Table 285. entropy_source.GENERATOR_6_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x0	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.46. GENERATOR_7_SAMPLE_CLK_CONFIG

Table 286. entropy_source.GENERATOR_7_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x0	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.47. GENERATOR_8_SAMPLE_CLK_CONFIG

Table 287. entropy_source.GENERATOR_8_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x1	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.48. GENERATOR_9_SAMPLE_CLK_CONFIG

Table 288. entropy_source.GENERATOR_9_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x1	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.49. GENERATOR_10_SAMPLE_CLK_CONFIG

Table 289. entropy_source.GENERATOR_10_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x2	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.50. GENERATOR_11_SAMPLE_CLK_CONFIG

Table 290. entropy_source.GENERATOR_11_SAMPLE_CLK_CONFIG fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	SAMPLE_CLK_DIVIDE	RW	0x2	Selects division by 1, 2, 4, 8, 16, or 32. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.51. HT_WATERMARK_NUM

Table 291. entropy_source.HT_WATERMARK_NUM fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3:0	WATERMARK_NUM	RW	0x0	Selects the watermark source. Unsupported values select REPCNT_HI.

2.1.5.11.5.10.2.1.52. HT_WATERMARK

Table 292. entropy_source.HT_WATERMARK fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	WATERMARK_VALUE	R	0x0	Current shared watermark value.

2.1.5.11.5.10.2.1.53. REPCNT_TOTAL_FAILS

Table 293. entropy_source.REPCNT_TOTAL_FAILS fields

Bits	Field	Access	Reset	Description
31:0	FAIL_COUNT	R	0x0	Total repetition-test failure pulses.

2.1.5.11.5.10.2.1.54. APT_HI_TOTAL_FAILS

Table 294. entropy_source.APT_HI_TOTAL_FAILS fields

Bits	Field	Access	Reset	Description
31:0	FAIL_COUNT	R	0x0	Total APT high-threshold failure pulses.

2.1.5.11.5.10.2.1.55. APT_LO_TOTAL_FAILS

Table 295. entropy_source.APT_LO_TOTAL_FAILS fields

Bits	Field	Access	Reset	Description
31:0	FAIL_COUNT	R	0x0	Total APT low-threshold failure pulses.

2.1.5.11.5.10.2.1.56. MARKOV_HI_TOTAL_FAILS

Table 296. entropy_source.MARKOV_HI_TOTAL_FAILS fields

Bits	Field	Access	Reset	Description
31:0	FAIL_COUNT	R	0x0	Total Markov high-threshold failure pulses.

2.1.5.11.5.10.2.1.57. MARKOV_LO_TOTAL_FAILS

Table 297. entropy_source.MARKOV_LO_TOTAL_FAILS fields

Bits	Field	Access	Reset	Description
31:0	FAIL_COUNT	R	0x0	Total Markov low-threshold failure pulses.

2.1.5.11.5.10.2.1.58. ALERT_SUMMARY_FAIL_COUNTS

Table 298. entropy_source.ALERT_SUMMARY_FAIL_COUNTS fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	ANY_FAIL_COUNT	R	0x0	Number of consecutive failing health-test windows.

2.1.5.11.5.10.2.1.59. ALERT_FAIL_COUNTS

Table 299. entropy_source.ALERT_FAIL_COUNTS fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:16	REPCNT_FAIL_COUNT	R	0x0	Saturating repetition-test failure count.
15:12	MARKOV_HI_FAIL_COUNT	R	0x0	Saturating Markov high-threshold failure count.
11:8	MARKOV_LO_FAIL_COUNT	R	0x0	Saturating Markov low-threshold failure count.
7:4	APT_HI_FAIL_COUNT	R	0x0	Saturating APT high-threshold failure count.
3:0	APT_LO_FAIL_COUNT	R	0x0	Saturating APT low-threshold failure count.

2.1.5.11.5.10.2.1.60. FIPS_LOCK

Table 300. entropy_source.FIPS_LOCK fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	LOCK	RW1S	0x0	Write one to set the configuration lock. Only hardware reset clears it.

2.1.5.11.5.10.2.1.61. ALERT_THRESHOLD

Table 301. entropy_source.ALERT_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	THRESHOLD	RW	0x4	Number of consecutive failing windows that triggers the alert; zero disables this trigger. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.62. MIN_ENTROPY_H

Table 302. entropy_source.MIN_ENTROPY_H fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	H	RW	0xC	Assessed min-entropy in bits per sample. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.63. RECOMMENDED_THRESHOLDS

Table 303. entropy_source.RECOMMENDED_THRESHOLDS fields

Bits	Field	Access	Reset	Description
31:16	APT_LIMIT	R	0x0	Advisory APT high cutoff derived for a 1024-sample window.
15:0	RCT_LIMIT	R	0x0	Advisory repetition-count cutoff C = 1 + ceil(20 / H).

2.1.5.11.5.10.2.1.64. BIW_OBS_CTRL

Table 304. entropy_source.BIW_OBS_CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	RAW_ENABLE	RW	0x0	Enables capture after startup health testing completes. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.65. BIW_OBS_STATUS

Table 305. entropy_source.BIW_OBS_STATUS fields

Bits	Field	Access	Reset	Description
31:22	Reserved	-	-	Reserved
21:16	RPTR	R	0x0	Current BIW observe FIFO read pointer.
15:14	Reserved	-	-	Reserved
13:8	WPTR	R	0x0	Current BIW observe FIFO write pointer.
7	Reserved	-	-	Reserved
6:0	LEVEL	R	0x0	Number of valid 32-bit words in the BIW observe FIFO.

2.1.5.11.5.10.2.1.66. BIW_OBS_RDATA

Table 306. entropy_source.BIW_OBS_RDATA fields

Bits	Field	Access	Reset	Description
31:0	RDATA	R RMOD	0x0	Returns and removes the next BIW observe FIFO word.

2.1.5.11.5.10.2.1.67. NOISE_OBS_CTRL

Table 307. entropy_source.NOISE_OBS_CTRL fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:4	LANE_SEL	RW	0x0	Selects generator lane 0 through 11; other values select lane 0. Changing lanes restarts packing and flushes buffered words.
3:2	Reserved	-	-	Reserved
1	FLUSH	W 1P	0x0	Write one to discard buffered raw-noise words. Changing LANE_SEL also flushes the FIFO.
0	RAW_ENABLE	RW	0x0	Enables LSB-first packing of selected-lane samples into 32-bit observe words. FIPS_LOCK.LOCK prevents software changes.

2.1.5.11.5.10.2.1.68. NOISE_OBS_STATUS

Table 308. entropy_source.NOISE_OBS_STATUS fields

Bits	Field	Access	Reset	Description
31:22	Reserved	-	-	Reserved
21:16	RPTR	R	0x0	Current raw-noise observe FIFO read pointer.
15:14	Reserved	-	-	Reserved
13:8	WPTR	R	0x0	Current raw-noise observe FIFO write pointer.
7	Reserved	-	-	Reserved
6:0	LEVEL	R	0x0	Number of valid 32-bit words in the raw-noise observe FIFO.

2.1.5.11.5.10.2.1.69. NOISE_OBS_RDATA

Table 309. entropy_source.NOISE_OBS_RDATA fields

Bits	Field	Access	Reset	Description
31:0	RDATA	R RMOD	0x0	Returns and removes 32 LSB-first pre-decorrelator samples from the selected lane.

2.1.5.11.6. Entropy Pool

The entropy pool (sep_entropy_fifo) is a read-only 64-bit AXI aperture through which software drains conditioned entropy. It is a top-level block in sep, reached as a target on the SEP local crossbar; see the Memory Map for its address window. The pool is filled autonomously by a native EDN endpoint on a separate hardware path, not through the crossbar; see the TRNG and DRBG chapter for the fill path and the entropy it carries.

2.1.5.11.6.1. Access Policy

- A read of DATA pops one 64-bit conditioned word. Reading an empty pool returns SLVERR rather than OKAY, so an empty pool is distinguishable from a genuine zero word.
- STATUS and IRQ_CAUSE are non-destructive reads. STATUS reports pool occupancy (fifo_level), the low-watermark condition (pool_low), an EDN fill stall (fill_stall) and a FIFO integrity fault (pool_error); the latter three are also raised to the PIC (see the Interrupts chapter).
- The pool is read-only. A write to any offset terminates with BRESP=SLVERR and changes no state.
- All three registers are 64-bit access-width (STATUS, IRQ_CAUSE and DATA each occupy one 8-byte slot) and are read with a single 64-bit access. A 32-bit read of a register's upper word (offset +4) is not decoded: it returns SLVERR with zero data, and for DATA it does not pop the pool. Read the full 64-bit word to obtain a register's value. The exact decode response codes are tabulated with the aperture in the Memory Map.
- The aperture accepts single-beat accesses only (Section 2.1.5.12.2). An access to an unmapped offset within the aperture likewise returns SLVERR with zero data.

2.1.5.11.6.2. Memory Map and Register Reference

2.1.5.11.6.2.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.11.6.2.2. Detailed Register Map

2.1.5.11.6.2.2.1. SEP Entropy Pool

Read-only entropy pool FIFO; DATA reads drain conditioned entropy supplied by the native EDN, and writes return SLVERR.

Table 310. SEP Entropy Pool register list

Address	Name	Access	Description
0x0	STATUS	R	-
0x8	IRQ_CAUSE	R	-
0x10	DATA	R	-

2.1.5.11.6.2.2.1.1. STATUS

Table 311. sep_entropy_pool.STATUS fields

Bits	Field	Access	Reset	Description
63:9	Reserved	-	-	Reserved
8	pool_error	R	-	The pool detected a FIFO integrity error
7	fill_stall	R	-	The EDN fill request exceeded the configured stall threshold
6	pool_low	R	-	The pool occupancy is below the configured low watermark
5:0	fifo_level	R	-	Current number of available 64-bit entropy words

2.1.5.11.6.2.2.1.2. IRQ_CAUSE

Table 312. sep_entropy_pool.IRQ_CAUSE fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	pool_error	R	-	-
1	fill_stall	R	-	-
0	pool_low	R	-	-

2.1.5.11.6.2.2.1.3. DATA

Table 313. sep_entropy_pool.DATA fields

Bits	Field	Access	Reset	Description
63:0	entropy	R	-	Pops one conditioned entropy word; an empty pool returns SLVERR

2.1.5.11.7. AES Cipher

The module is based on the OpenTitan AES design.

Key sizes: 128, 192 and 256 Modes: ECB, CBC, CFB, OFB, CTR, CTR-GCM




Figure 37. OpenTitan AES core reference architecture

Figure 37 shows the upstream core. The OCAH bus, key-delivery, and entropy connections are described in the integration details below.

2.1.5.11.7.1. OCAH Modifications

- AXI4-lite key bus slave interface replaces side loading interface
- AXI4-lite control/status bus slave interface

The AES host path follows the standard conversion and isolation sequence in the crypto interconnect (64-bit AXI → 32-bit AXI → AXI-Lite → isolate), without address adjustment or cache-attribute patching. `aes_wrapper` bridges the isolated path to TL-UL. EDN requests are served by the shared `drbg_axis_edn_adapter` instance `u_axis_edn_crypto_s3c_scan`, which converts the post-CSRNG DRBG AXI-Stream feed for the crypto sink domain into AES's native-protocol EDN response. The adapter forwards the per-beat FIPS bit from the stream's `tuser` sideband into `edn_fips`; AES itself does not consume the flag. The AES core uses `rst_ni` for both the main and shadow reset domains. Life-cycle escalation is tied to its inactive state. AES occupies alert indices `[4:3]` in Section 2.1.5.11.1 and exports an `idle_o` status output but no interrupt.

The Key Manager delivers a 256-bit AES key as eight words per share, in the format given in Section 2.1.5.11.3. In AES, `CTRL_SHADOWED.sideload` selects the delivered key. While that bit is 0 the engine uses its software key registers and the delivered key has no effect, and no error is reported. `CTRL_SHADOWED.key_len` is independent of the delivery path: only its 256-bit encoding consumes the whole delivered key, and a shorter setting consumes only part of it. AES carries the two shares into the cipher datapath as a masked pair and does not combine them on the delivery path.

Consult the OpenTitan AES documentation for the authoritative core functionality of the IP. The Programmer's Guide gives the programming guidance for this block. The register map follows below.

2.1.5.11.7.2. Memory Map and Register Reference

2.1.5.11.7.2.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.11.7.2.2. Detailed Register Map

2.1.5.11.7.2.2.1. AES Accelerator

AES encryption and decryption engine with SCA and FI countermeasures

NOTE

Register Arrays:

- **KEY_SHARE0[8]**: 8 registers, base 0x4, stride 0x4
- **KEY_SHARE1[8]**: 8 registers, base 0x24, stride 0x4
- **IV[4]**: 4 registers, base 0x44, stride 0x4
- **DATA_IN[4]**: 4 registers, base 0x54, stride 0x4
- **DATA_OUT[4]**: 4 registers, base 0x64, stride 0x4

Table 314. AES Accelerator register list

Address	Name	Access	Description
0x0	ALERT_TEST	W	-
0x4 - 0x20	KEY_SHARE0[8]	W	-
0x24 - 0x40	KEY_SHARE1[8]	W	-
0x44 - 0x50	IV[4]	RW	-
0x54 - 0x60	DATA_IN[4]	W	-
0x64 - 0x70	DATA_OUT[4]	R	-
0x74	CTRL_SHADOWED	RW	-
0x78	CTRL_AUX_SHADOWED	RW	-
0x7C	CTRL_AUX_REGWEN	RW	-
0x80	TRIGGER	W	-
0x84	STATUS	R	-
0x88	CTRL_GCM_SHADOWED	RW	-

2.1.5.11.7.2.2.1.1. ALERT_TEST

Table 315. aes.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	FATAL_FAULT	W	0x0	Write 1 to trigger one alert event of this kind.
0	RECOV_CTRL_UPDATE_ERR	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.11.7.2.2.1.2. KEY_SHARE0[8]

Table 316. aes.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	KEY_SHARE0	W	0x0	Initial Key Share 0

2.1.5.11.7.2.2.1.3. KEY_SHARE1[8]

Table 317. aes.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	KEY_SHARE1	W	0x0	Initial Key Share 1

2.1.5.11.7.2.2.1.4. IV[4]

Table 318. aes.IV[4] fields

Bits	Field	Access	Reset	Description
31:0	IV	RW	0x0	Initialization Vector

2.1.5.11.7.2.2.1.5. DATA_IN[4]

Table 319. aes.DATA_IN[4] fields

Bits	Field	Access	Reset	Description
31:0	DATA_IN	W	0x0	Input Data

2.1.5.11.7.2.2.1.6. DATA_OUT[4]

Table 320. aes.DATA_OUT[4] fields

Bits	Field	Access	Reset	Description
31:0	DATA_OUT	R	0x0	Output Data

2.1.5.11.7.2.2.1.7. CTRL_SHADOWED

Table 321. aes.CTRL_SHADOWED fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15	MANUAL_OPERATION	RW	0x0	Controls whether the AES unit is operated in normal/automatic mode (0) or fully manual mode (1). In automatic mode (0), the AES unit automatically i) starts to encrypt/decrypt when it receives new input data, and ii) stalls during the last encryption/decryption cycle if the previous output data has not yet been read. This is the most efficient mode to operate in. Note that the corresponding status tracking is automatically cleared upon a write to the Control Register. In manual mode (1), the AES unit i) only starts to encrypt/decrypt after receiving a start trigger (see Trigger Register), and ii) overwrites previous output data irrespective of whether it has been read out or not. This mode is useful if software needs full control over the AES unit.
14:12	PRNG_RESEED_RATE	RW	0x1	3-bit one-hot field to control the reseeding rate of the internal pseudo-random number generator (PRNG) used for masking. Invalid input values, i.e., values with multiple bits set and value 3'b000 are mapped to the highest reseeding rate PER_1 (3'b001).
11	SIDELOAD	RW	0x0	Controls whether the AES unit uses the key provided by the key manager via key sideload interface (1) or the key provided by software via Initial Key Registers KEY_SHARE1_0 - KEY_SHARE1_7 (0).
10:8	KEY_LEN	RW	0x1	3-bit one-hot field to select AES key length. Invalid input values, i.e., values with multiple bits set, value 3'b000, and value 3'b010 in case 192-bit keys are not supported (because disabled at compile time) are mapped to AES_256 (3'b100).

Bits	Field	Access	Reset	Description
7:2	MODE	RW	0x3F	6-bit one-hot field to select AES block cipher mode. Invalid input values, i.e., values with multiple bits set and value 6'b00_0000, are mapped to AES_NONE (6'b11_1111).
1:0	OPERATION	RW	0x1	2-bit one-hot field to select the operation of AES unit. Invalid input values, i.e., values with multiple bits set and value 2'b00, are mapped to AES_ENC (2'b01).

2.1.5.11.7.2.2.1.8. CTRL_AUX_SHADOWED

Table 322. aes.CTRL_AUX_SHADOWED fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	FORCE_MASKS	RW	0x0	Allow the internal masking PRNG to advance (0) or force its internal state (1) leading to constant masks. Setting all masks to constant value can be useful when performing SCA. To completely disable the masking, the second key share (KEY_SHARE1_0 - KEY_SHARE1_7) must be zero as well. In addition, a special seed needs to be loaded into the masking PRNG using the EDN interface. Only applicable if both the Masking parameter and the SecAllowForcingMasks parameter are set to one.
0	KEY_TOUCH_FORCES_RESEED	RW	0x1	Controls whether providing a new key triggers the reseeding of internal pseudo-random number generators used for clearing and masking (1) or not (0).

2.1.5.11.7.2.2.1.9. CTRL_AUX_REGWEN

Table 323. aes.CTRL_AUX_REGWEN fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	CTRL_AUX_REGWEN	RW0C	0x1	Auxiliary Control Register configuration enable bit. If this is cleared to 0, the Auxiliary Control Register cannot be written anymore.

2.1.5.11.7.2.2.1.10. TRIGGER

Table 324. aes.TRIGGER fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	PRNG_RESEED	W	0x1	Keep continuing with the current states of the internal pseudo-random number generators used for register clearing and masking (0) or perform a reseed of the internal states from the connected entropy source (1). If the KEY_TOUCH_FORCES_RESEED bit in the Auxiliary Control Register is set to one, this trigger will automatically get set after providing a new initial key.
2	DATA_OUT_CLEAR	W	0x1	Keep current values in Output Data registers (0) or clear those registers with pseudo-random data (1).
1	KEY_IV_DATA_IN_CLEAR	W	0x1	Keep current values in Initial Key, internal Full Key and Decryption Key registers, IV registers and Input Data registers (0) or clear all those registers with pseudo-random data (1).
0	START	W	0x0	Keep AES unit paused (0) or trigger the encryption/decryption of one data block (1). This trigger is cleared to 0 if MANUAL_OPERATION=0 or if MODE=AES_NONE (see Control Register).

2.1.5.11.7.2.2.1.11. STATUS

Table 325. aes.STATUS fields

Bits	Field	Access	Reset	Description
31:7	Reserved	-	-	Reserved
6	ALERT_FATAL_FAULT	R	0x0	No fatal fault has occurred inside the AES unit (0). A fatal fault has occurred and the AES unit needs to be reset (1). Examples for fatal faults include i) storage errors in the Control Register, ii) if any internal FSM enters an invalid state, iii) if any sparsely encoded signal takes on an invalid value, iv) errors in the internal round counter, v) escalations triggered by the life cycle controller, and vi) fatal integrity failures on the TL-UL bus.
5	ALERT_RECOV_CTRL_UPDATE_ERR	R	0x0	An update error has not occurred (0) or has occurred (1) in the shadowed Control Register. AES operation needs to be restarted by re-writing the Control Register.
4	INPUT_READY	R	0x0	The AES unit is ready (1) or not ready (0) to receive new data input via the DATA_IN registers. If the present values in the DATA_IN registers have not yet been loaded into the module this flag is 0 (not ready).
3	OUTPUT_VALID	R	0x0	The AES unit has no valid output (0) or has valid output data (1).
2	OUTPUT_LOST	R	0x0	All previous output data has been fully read by the processor (0) or at least one previous output data block has been lost (1). It has been overwritten by the AES unit before the processor could fully read it. Once set to 1, this flag remains set until AES operation is restarted by re-writing the Control Register. The primary use of this flag is for design verification. This flag is not meaningful if MANUAL_OPERATION=0 (see Control Register).
1	STALL	R	0x0	The AES unit is not stalled (0) or stalled (1) because there is previous output data that must be read by the processor before the AES unit can overwrite this data. This flag is not meaningful if MANUAL_OPERATION=1 (see Control Register).
0	IDLE	R	0x0	The AES unit is idle (1) or busy (0). This flag is 0 if one of the following operations is currently running: i) encryption/decryption, ii) register clearing or iii) PRNG reseeding. This flag is also 0 if an encryption/decryption is running but the AES unit is stalled.

2.1.5.11.7.2.2.1.12. CTRL_GCM_SHADOWED

Table 326. aes.CTRL_GCM_SHADOWED fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10:6	NUM_VALID_BYTES	RW	0x10	Number of valid bytes of the current input block. Only the last block in the GCM_AAD and GCM_TEXT phases are expected to have not all bytes marked as valid. For all other blocks, the number of valid bytes should be set to 16. Invalid input values, i.e., the value 5'b0_0000, and all other values different from 5'b1_0000 in case GCM is not supported (because disabled at compile time) are mapped to 5'b1_0000.
5:0	PHASE	RW	0x1	6-bit one-hot field to select the phase of the Galois/Counter Mode (GCM) of operation. Invalid input values, i.e., values with multiple bits set and value 6'b00_0000, are mapped to GCM_INIT (6'b00_0001). In case support for GCM has been disabled at compile time, this field is not writable and always reads as GCM_INIT (6'b00_0001).

2.1.5.11.8. HMAC-SHA2

The HMAC component is based on the OpenTitan HMAC design.




Figure 38. OpenTitan HMAC core reference architecture

Figure 38 shows the upstream core. The OCAH bus, key-delivery, and entropy connections are described in the integration details below.

2.1.5.11.8.1. OCAH Modifications

- AXI4-lite key bus slave interface replaces side loading interface
- AXI4-lite control/status bus slave interface

The crypto interconnect narrows HMAC's host path from 64-bit AXI to 32-bit AXI, converts and isolates it as AXI-Lite, then `hmac_wrapper` bridges it to TL-UL for the `tt_hmac` core. The address path subtracts the HMAC base address and masks to a 13-bit window (8 KB), accommodating both the register space and the message FIFO window at offset `0x1000`. HMAC exposes a single fatal alert channel (index `[0]` in Section 2.1.5.11.1), three interrupts (`done`, `fifo_empty`, `err`), and an `idle_o` status output. Unlike the other crypto wrappers, HMAC has no EDN connection.

The Key Manager delivers a 256-bit HMAC key as eight words per share, in the format given in Section 2.1.5.11.3. HMAC has no select bit: the delivered key is used in preference to the engine's software key registers whenever `KEY_CTRL.KEY_VALID` is set.

The delivered key is most-significant-bit justified in the engine's 1024-bit key field, and the engine takes its key length from `CFG.key_length`, which the delivery path does not write; only the 256-bit encoding matches the delivered key. An unset or unsupported length raises a configuration error when hashing starts. A supported length that disagrees with the delivered key does not raise an error: the engine takes key material from the top of the 1024-bit field, so the padding below the delivered key is mixed into the key and the resulting digest is wrong but repeatable.

Consult the OpenTitan HMAC documentation for the authoritative core functionality of the IP. The Programmer's Guide gives the programming guidance for this block. The register map follows below.

2.1.5.11.8.2. Memory Map and Register Reference

2.1.5.11.8.2.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each

register and its fields.

2.1.5.11.8.2.2. Detailed Register Map

2.1.5.11.8.2.2.1. HMAC Accelerator

Accelerator for SHA-2 256/384/512-based keyed HMAC and the hash function

NOTE

Register Arrays:

- **KEY[32]**: 32 registers, base 0x24, stride 0x4
- **DIGEST[16]**: 16 registers, base 0xA4, stride 0x4

Table 327. HMAC Accelerator register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-
0xC	ALERT_TEST	W	-
0x10	CFG	RW	-
0x14	CMD	W	-
0x18	STATUS	R	-
0x1C	ERR_CODE	R	-
0x20	WIPE_SECRET	W	-
0x24 - 0xA0	KEY[32]	W	-
0xA4 - 0xE0	DIGEST[16]	RW	-
0xE4	MSG_LENGTH_LOWER	RW	-
0xE8	MSG_LENGTH_UPPER	RW	-

2.1.5.11.8.2.2.1.1. INTR_STATE

Table 328. hmac.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	hmac_err	RW1C	0x0	HMAC error has occurred. ERR_CODE register shows which error occurred.
1	fifo_empty	R	0x0	The message FIFO is empty. This interrupt is raised only if the message FIFO is actually writable by software, i.e., if all of the following conditions are met: i) The HMAC block is not running in HMAC mode and performing the second round of computing the final hash of the outer key as well as the result of the first round using the inner key. ii) Software has not yet written the Process or Stop command to finish the hashing operation. For the interrupt to be raised, the message FIFO must also have been full previously. Otherwise, the hardware empties the FIFO faster than software can fill it and there is no point in interrupting the software to inform it about the message FIFO being empty.
0	hmac_done	RW1C	0x0	HMAC/SHA-2 has completed.

2.1.5.11.8.2.2.1.2. INTR_ENABLE

Table 329. hmac.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	hmac_err	RW	0x0	Enable interrupt when !!INTR_STATE.hmac_err is set.
1	fifo_empty	RW	0x0	Enable interrupt when !!INTR_STATE.fifo_empty is set.
0	hmac_done	RW	0x0	Enable interrupt when !!INTR_STATE.hmac_done is set.

2.1.5.11.8.2.2.1.3. INTR_TEST

Table 330. hmac.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	hmac_err	W	0x0	Write 1 to force !!INTR_STATE.hmac_err to 1.
1	fifo_empty	W	0x0	Write 1 to force !!INTR_STATE.fifo_empty to 1.
0	hmac_done	W	0x0	Write 1 to force !!INTR_STATE.hmac_done to 1.

2.1.5.11.8.2.2.1.4. ALERT_TEST

Table 331. hmac.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	fatal_fault	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.11.8.2.2.1.5. CFG

Table 332. hmac.CFG fields

Bits	Field	Access	Reset	Description
31:15	Reserved	-	-	Reserved
14:9	key_length	RW	0x20	Key length configuration. This is a 6-bit one-hot encoded field to configure the key length for HMAC. The HMAC can be programmed with the following key lengths: 128-bit, 256-bit, 384-bit, 512-bit and 1024-bit. But the HMAC supports any arbitrary key length: the software should configure the HMAC with the next largest supported key length and concatenate zeros to reach the programmed key length. The position of these zeros depends on the endianness, thus on the programmed [CFG.key_swap](registers.md#cfg—key_swap). For example, for an 80-bit key, HMAC should be configured with an 128-bit key length, fed with the 80-bit key and with 48 zero-bits. Note that the key length cannot be greater than the block size: up to 1024-bit for SHA-2 384/512 and up to 512-bit for SHA-2 256. The value of this register is irrelevant when only SHA-2 (not keyed HMAC) is configured. However, for HMAC mode (hmac_en == 1), when HMAC is triggered to start while !!KEY_LENGTH holds Key_None or !!KEY_LENGTH holds Key_1024 for !!DIGEST_SIZE = SHA2_256, starting is blocked and an error is signalled to SW.

Bits	Field	Access	Reset	Description
8:5	digest_size	RW	0x8	Digest size configuration. This is a 4-bit one-hot encoded field to select digest size for either HMAC or SHA-2. Invalid/unsupported values, i.e., values that don't correspond to SHA2_256, SHA2_384, or SHA2_512, are mapped to SHA2_None.
4	key_swap	RW	0x0	Key register byte swap (deprecated: KEY path is for DV only; production uses key manager sideload). If 1 the endianness of each KEY_* register is swapped. Default value (value 0) is big endian representation of the KEY_* CSRs.
3	digest_swap	RW	0x0	Digest register byte swap. If 1 the value in each digest output register is converted to big-endian byte order. This setting does not affect the order of the digest output registers, !!DIGEST_0 still contains the first 4 bytes of the digest.
2	endian_swap	RW	0x0	Endian swap. If 0, each value will be added to the message in little-endian byte order. The value is written to MSG_FIFO same to the SW writes. If 1, then each individual multi-byte value, regardless of its alignment, written to !!MSG_FIFO will be added to the message in big-endian byte order. A message written to !!MSG_FIFO one byte at a time will not be affected by this setting. From a hardware perspective byte swaps are performed on a TL-UL word granularity.
1	sha_en	RW	-	SHA-2 enable. If 0, the SHA engine will not initiate compression, this is used to stop operation of the SHA-2 engine until configuration has been done. When the SHA-2 engine is disabled the digest is cleared.
0	hmac_en	RW	-	HMAC datapath enable. If this bit is 1, HMAC operates when hash_start toggles.

2.1.5.11.8.2.2.1.6. CMD

Table 333. hmac.CMD fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	hash_continue	W1C	-	When 1 is written to this field, SHA-2 or HMAC will continue hashing based on the current hash in the digest registers and the message length, which both have to be restored to switch context.
2	hash_stop	W1C	-	When 1 is written to this field, SHA-2 or HMAC will afterwards set the hmac_done interrupt as soon as the current block has been hashed. The hash can then be read from the registers !!DIGEST_0 to !!DIGEST_15. Together with the message length in !!MSG_LENGTH_LOWER and !!MSG_LENGTH_UPPER, this forms the information that has to be saved before switching context.
1	hash_process	W1C	-	If 1 is written to this field, SHA-2 or HMAC calculates the digest or signing based on currently received message.
0	hash_start	W1C	-	If 1 is written into this field, SHA-2 or HMAC begins its operation. CPU must configure relative information first, such as the digest size, secret key and the key length.

2.1.5.11.8.2.2.1.7. STATUS

Table 334. hmac.STATUS fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:4	fifo_depth	R	-	FIFO entry count.
3	Reserved	-	-	Reserved
2	fifo_full	R	-	FIFO full. Data written to the FIFO whilst it is full will cause back-pressure on the interconnect
1	fifo_empty	R	0x1	FIFO empty
0	hmac_idle	R	0x1	HMAC idle status. When IDLE, the DIGEST and the MSG_LENGTH_LOWER /MSG_LENGTH_UPPER can be written to from SW which enables restoring context (to support context switching).

2.1.5.11.8.2.2.1.8. ERR_CODE

Table 335. hmac.ERR_CODE fields

Bits	Field	Access	Reset	Description
31:0	err_code	R	0x0	If an error interrupt occurs, this register has information of error cause. Please take a look at `hw/ip/prim/rtl/prim_sha2_pkg.sv:err_code_e enum type.

2.1.5.11.8.2.2.1.9. WIPE_SECRET

Table 336. hmac.WIPE_SECRET fields

Bits	Field	Access	Reset	Description
31:0	secret	W	-	Secret value

2.1.5.11.8.2.2.1.10. KEY[32]

Table 337. hmac.KEY[32] fields

Bits	Field	Access	Reset	Description
31:0	key_0	W	-	32-bit chunk of 1024-bit secret key

2.1.5.11.8.2.2.1.11. DIGEST[16]

Table 338. hmac.DIGEST[16] fields

Bits	Field	Access	Reset	Description
31:0	digest_0	RW	-	32-bit chunk of 512-bit digest

2.1.5.11.8.2.2.1.12. MSG_LENGTH_LOWER

Table 339. hmac.MSG_LENGTH_LOWER fields

Bits	Field	Access	Reset	Description
31:0	v	RW	-	Message Length [31:0]

2.1.5.11.8.2.2.1.13. MSG_LENGTH_UPPER

Table 340. hmac.MSG_LENGTH_UPPER fields

Bits	Field	Access	Reset	Description
31:0	v	RW	-	Message Length [63:32]

2.1.5.11.9. KMAC-SHA3

The module is based on the OpenTitan KMAC design.




Figure 39. OpenTitan KMAC core reference architecture

Figure 39 shows the upstream core. The OCAH bus, key-delivery, and entropy connections are described in the integration details below.

2.1.5.11.9.1. OCAH Modifications

- AXI4-lite key bus slave interface replaces side loading interface
- AXI4-lite control/status bus slave interface

The KMAC host path uses the same conversion and isolation sequence as AES. The address path subtracts the KMAC base address and masks to a 12-bit window (4 KB) before the `axi_to_axi_lite` stage, aligning the internal decoder with the OpenTitan register block. `kmac_wrapper` bridges the isolated AXI-Lite path to TL-UL. EDN is handled identically to AES: KMAC is one of the four clients arbitrated by `u_axis_edn_crypto_s3c_scan` (the shared `drbg_axis_edn_adapter`), served from the same post-CSRNG DRBG AXI-Stream feed. The `app_i` application interface is tied off since the SEP does not use the KMAC hardware application path. Life-cycle escalation is inactive. KMAC occupies alert indices `[6:5]` in Section 2.1.5.11.1 and exports three interrupts: `done`, `fifo_empty`, and `err`.

The Key Manager delivers a 256-bit KMAC key as eight words per share, in the format given in Section 2.1.5.11.3. In KMAC, `CFG_SHADOWED.sideload` selects the delivered key; while that bit is 0 the engine uses its software key registers. Unlike AES and HMAC, software does not declare a key length for a delivered key: the engine applies the delivered key's length automatically and ignores its key-length register for that operation. Beginning a keyed operation that uses the delivered key while `KEY_CTRL.KEY_VALID` is 0 raises an error instead of producing a digest; OTBN also reports an invalid key error.

Consult the OpenTitan KMAC documentation for the authoritative core functionality of the IP. The Programmer's Guide

gives the programming guidance for this block. The register map follows below.

2.1.5.11.9.2. Memory Map and Register Reference

2.1.5.11.9.2.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.11.9.2.2. Detailed Register Map

2.1.5.11.9.2.2.1. KMAC Accelerator

Accelerator for Keccak-based keyed hash message authentication code and SHA-3 hash functions; with SCA and FI countermeasures

NOTE

Register Arrays:

- **KEY_SHARE0[16]**: 16 registers, base 0x30, stride 0x4
- **KEY_SHARE1[16]**: 16 registers, base 0x70, stride 0x4
- **PREFIX[11]**: 11 registers, base 0xB4, stride 0x4

Table 341. KMAC Accelerator register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-
0xC	ALERT_TEST	W	-
0x10	CFG_REGWEN	R	-
0x14	CFG_SHADOWED	RW	-
0x18	CMD	W	-
0x1C	STATUS	R	-
0x20	ENTROPY_PERIOD	RW	-
0x24	ENTROPY_REFRESH_HASH_CNT	R	-
0x28	ENTROPY_REFRESH_THRESHOLD_SHADOWED	RW	-
0x2C	ENTROPY_SEED	W	-
0x30 - 0x6C	KEY_SHARE0[16]	W	-
0x70 - 0xAC	KEY_SHARE1[16]	W	-
0xB0	KEY_LEN	W	-
0xB4 - 0xDC	PREFIX[11]	RW	-
0xE0	ERR_CODE	R	-

2.1.5.11.9.2.2.1.1. INTR_STATE

Table 342. kmac.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	kmac_err	RW1C	0x0	KMAC/SHA3 error occurred. ERR_CODE register shows the details
1	fifo_empty	R	0x0	The message FIFO is empty. This interrupt is raised only if the message FIFO is actually writable by software, i.e., if all of the following conditions are met: i) The KMAC block is not exercised by a hardware application interface. ii) The SHA3 block is in the Absorb state. iii) Software has not yet written the Process command to finish the absorption process. For the interrupt to be raised, the message FIFO must also have been full previously. Otherwise, the hardware empties the FIFO faster than software can fill it and there is no point in interrupting the software to inform it about the message FIFO being empty.
0	kmac_done	RW1C	0x0	KMAC/SHA3 absorbing has been completed

2.1.5.11.9.2.2.1.2. INTR_ENABLE

Table 343. kmac.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	kmac_err	RW	0x0	Enable interrupt when !!INTR_STATE.kmac_err is set.
1	fifo_empty	RW	0x0	Enable interrupt when !!INTR_STATE.fifo_empty is set.
0	kmac_done	RW	0x0	Enable interrupt when !!INTR_STATE.kmac_done is set.

2.1.5.11.9.2.2.1.3. INTR_TEST

Table 344. kmac.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	kmac_err	W	0x0	Write 1 to force !!INTR_STATE.kmac_err to 1.
1	fifo_empty	W	0x0	Write 1 to force !!INTR_STATE.fifo_empty to 1.
0	kmac_done	W	0x0	Write 1 to force !!INTR_STATE.kmac_done to 1.

2.1.5.11.9.2.2.1.4. ALERT_TEST

Table 345. kmac.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	fatal_fault_err	W	0x0	Write 1 to trigger one alert event of this kind.
0	recov_operation_err	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.11.9.2.2.1.5. CFG_REGWEN

Table 346. kmac.CFG_REGWEN fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	en	R	0x1	Configuration enable.

2.1.5.11.9.2.2.1.6. CFG_SHADOWED

Table 347. kmac.CFG_SHADOWED fields

Bits	Field	Access	Reset	Description
31:27	Reserved	-	-	Reserved
26	en_unsupported_modestrength	RW	0x0	Enable Unsupported Mode and Strength configs. SW may set this field for KMAC to move forward with unsupported Keccak Mode and Strength configurations, such as cSHAKE512. If not set, KMAC won't propagate the SW command (CmdStart) to the rest of the blocks (AppIntf, KMAC Core, SHA3).
25	Reserved	-	-	Reserved
24	entropy_ready	RW	0x0	Entropy Ready status. Software sets this field to allow the entropy generator in KMAC to fetch the entropy and run.
23:21	Reserved	-	-	Reserved
20	msg_mask	RW	0x0	Message Masking with PRNG. If 1, KMAC applies PRNG to the input messages to the Keccak module when KMAC mode is on.
19	entropy_fast_process	RW	0x0	Entropy Fast process mode. If 1, entropy logic uses garbage data while not processing the KMAC key block. It will re-use previous entropy value and will not expand the entropy when it is consumed. Only it refreshes the entropy while processing the secret key block. This process should not be used if SCA resistance is required because it may cause side channel leakage.
18	Reserved	-	-	Reserved
17:16	entropy_mode	RW	0x0	Entropy Mode Using this field, software can configure mode of operation of the internal pseudo-random number generator (PRNG). Note that once software has configured a value different from idle_mode after reset, and set the !!CFG_SHADOWED.entropy_ready bit afterwards, the PRNG configuration cannot be changed anymore (unless an EDN request timeout occurs when running in EDN mode). Further writes to this field will change the value received upon reading the register, but they will be ignored by the internal hardware.
15:13	Reserved	-	-	Reserved
12	sideload	RW	0x1	Sideloaded Key. Deprecated: defaults to 1 (sideload). Set to 0 for DV testing with SW key path only. If 1, KMAC uses KeyMgr sideloaded key for SW initiated KMAC operation. KMAC uses the sideloaded key regardless of this configuration when KeyMgr initiates the KMAC operation for Key Derivation Function (KDF).
11:10	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
9	state_endianness	RW	0x0	State Endianness. If 1 then each individual word in the !!STATE output register is converted to big-endian byte order. The order of the words in relation to one another is not changed. This setting does not affect how the state is interpreted during computation.
8	msg_endianness	RW	0x0	Message Endianness. If 1 then each individual multi-byte value, regardless of its alignment, written to !!MSG_FIFO will be added to the message in big-endian byte order. If 0, each value will be added to the message in little-endian byte order. A message written to !!MSG_FIFO one byte at a time will not be affected by this setting. From a hardware perspective byte swaps are performed on a TL-UL word granularity.
7:6	Reserved	-	-	Reserved
5:4	mode	RW	0x0	Keccak hashing mode. This module supports SHA3 main hashing algorithm and the part of its derived functions, SHAKE and cSHAKE with limitations. This field is to select the mode.
3:1	kstrength	RW	0x0	Hashing Strength 3 bit field to select the security strength of SHA3 hashing engine. If mode field is set to SHAKE or cSHAKE, only 128 and 256 strength can be selected. Other value will result error when hashing starts.
0	kmac_en	RW	0x0	KMAC datapath enable. If this bit is 1, the KMAC mode is active and the secret key is prepended to the incoming message.

2.1.5.11.9.2.2.1.7. CMD

Table 348. kmac.CMD fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10	err_processed	W1C	-	When error occurs and one of the state machine stays at Error handling state, SW may process the error based on ERR_CODE, then let FSM back to the reset state
9	hash_cnt_clr	W1C	-	Software can set this bit to 1 to manually clear !!ENTROPY_REFRESH_HASH_CNT.
8	entropy_req	W1C	-	Software can set this bit to 1 to manually trigger the reseeding of the internal PRNG when running in EDN mode. This will also clear !!ENTROPY_REFRESH_HASH_CNT. Note that the hardware may miss the trigger pulse if the module is not idle, or if the module is currently performing a reseed operation.
7:6	Reserved	-	-	Reserved
5:0	cmd	W1C	-	Issue a command to the KMAC/SHA3 IP. The command is sparse encoded. To prevent sw from writing multiple commands at once, the field is defined as enum.

2.1.5.11.9.2.2.1.8. STATUS

Table 349. kmac.STATUS fields

Bits	Field	Access	Reset	Description
31:18	Reserved	-	-	Reserved
17	ALERT_RECOV_CTRL_UPDATE_ERR	R	0x0	An update error has not occurred (0) or has occurred (1) in the shadowed Control Register. KMAC operation needs to be restarted by re-writing the Control Register.
16	ALERT_FATAL_FAULT	R	0x0	No fatal fault has occurred inside the KMAC unit (0). A fatal fault has occurred and the KMAC unit needs to be reset (1), Examples for such faults include i) TL-UL bus integrity fault ii) storage errors in the shadow registers iii) errors in the message, round, or key counter iv) any internal FSM entering an invalid state v) an error in the redundant lfsr
15	fifo_full	R	-	Message FIFO Full indicator
14	fifo_empty	R	0x1	Message FIFO Empty indicator. The FIFO's Pass parameter is set to 1'b 1. So, by default, if the SHA engine is ready, the write data to FIFO just passes through. In this case, fifo_depth remains **0**. fifo_empty, however, lowers the value to **0** for a cycle, then goes back to the empty state, **1**. See the "Message FIFO" section in the spec for the reason.
13	Reserved	-	-	Reserved
12:8	fifo_depth	R	-	Count of occupied entries in the message FIFO.
7:3	Reserved	-	-	Reserved
2	sha3_squeeze	R	-	If 1, SHA3 completes sponge absorbing stage. In this stage, SW can manually run the hashing engine.
1	sha3_absorb	R	-	If 1, SHA3 is receiving message stream and processing it
0	sha3_idle	R	0x1	If 1, SHA3 hashing engine is in idle state.

2.1.5.11.9.2.2.1.9. ENTROPY_PERIOD

Table 350. kmac.ENTROPY_PERIOD fields

Bits	Field	Access	Reset	Description
31:16	wait_timer	RW	0x0	EDN request wait timer. The entropy module in KMAC waits up to this field in the timer pulse after it sends request to EDN module. If the timer expires, the entropy module moves to an error state and notifies to the system. If there is a pending EDN request during wait timer update, then this update is delayed until the EDN request is complete. If 0, the entropy module waits the EDN response always. If EDN does not respond in this configuration, the software shall reset the IP.
15:10	Reserved	-	-	Reserved
9:0	prescaler	RW	0x0	EDN Wait timer prescaler. EDN Wait timer has 16 bit value. The timer value is increased when the timer pulse is generated. Timer pulse is raises when the number of the clock cycles hit this prescaler value. The exact period of the timer pulse is unknown as the KMAC input clock may contain jitters.

2.1.5.11.9.2.2.1.10. ENTROPY_REFRESH_HASH_CNT

Table 351. kmac.ENTROPY_REFRESH_HASH_CNT fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	hash_cnt	R	0x0	Hash (KMAC) counter

2.1.5.11.9.2.2.1.11. ENTROPY_REFRESH_THRESHOLD_SHADOWED

Table 352. kmac.ENTROPY_REFRESH_THRESHOLD_SHADOWED fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	threshold	RW	0x0	Hash Threshold

2.1.5.11.9.2.2.1.12. ENTROPY_SEED

Table 353. kmac.ENTROPY_SEED fields

Bits	Field	Access	Reset	Description
31:0	seed	W	-	32-bit chunk of the entropy generator seed

2.1.5.11.9.2.2.1.13. KEY_SHARE0[16]

Table 354. kmac.KEY_SHARE0[16] fields

Bits	Field	Access	Reset	Description
31:0	key_0	W	-	32-bit chunk of up-to 512-bit Secret Key

2.1.5.11.9.2.2.1.14. KEY_SHARE1[16]

Table 355. kmac.KEY_SHARE1[16] fields

Bits	Field	Access	Reset	Description
31:0	key_0	W	-	32-bit chunk of up-to 512-bit Secret Key

2.1.5.11.9.2.2.1.15. KEY_LEN

Table 356. kmac.KEY_LEN fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	len	W	0x0	Key length choice

2.1.5.11.9.2.2.1.16. PREFIX[11]

Table 357. kmac.PREFIX[11] fields

Bits	Field	Access	Reset	Description
31:0	prefix_0	RW	0x0	32-bit chunk of Encoded NS Prefix

2.1.5.11.9.2.2.1.17. ERR_CODE

Table 358. kmac.ERR_CODE fields

Bits	Field	Access	Reset	Description
31:0	err_code	R	0x0	If the kmac_err interrupt occurs, this register has information on the error cause. Bits 31:24 contain the error code (please refer to err_code_e in hw/ip/kmac/rtl/kmac_pkg.sv) for the encoding, and bits 23:0 contain additional debug information. This register does **not** get cleared when the kmac_err interrupt state gets cleared.

2.1.5.11.10. Adams Bridge (ABR)

The module is a post-quantum accelerator based on the Caliptra Adams Bridge design.

Algorithms:

- ML-DSA-87 (FIPS 204) — key generation, signature generation and verification
- ML-KEM-1024 (FIPS 203) — key generation, encapsulation and decapsulation

ML-DSA is the post-quantum signature path intended for secure boot: each owner may be provisioned with an ML-DSA root public key alongside its classical key, with REQUIRED_SIGNERS selecting which owners must sign and REQUIRED_ALGS selecting, per owner, which of the two algorithms it must sign with (see [life-cycle-controller-lcc-life-cycle-controller-lcc]). SEP ROM does not use this path today — it verifies a single classical RSA-3072 signature, and combined classical + PQC signing is deferred to a later release.

The upstream ML-DSA and ML-KEM algorithm datapaths are shown in Figure 40 and Figure 41, respectively.




Figure 40. Adams Bridge ML-DSA reference architecture




Figure 41. Adams Bridge ML-KEM reference architecture

These upstream diagrams describe the algorithm datapaths. The OCAH wrapper provides the AXI and key interfaces and exposes the working SRAM ports to the integrator, as described below.

2.1.5.11.10.1. OCAH Modifications

- AXI4-lite key bus slave interface replaces the Caliptra Key Vault
- AXI4 control/status bus slave interface, bridged to the core's native AHB-lite

ABR is the one accelerator in the subsystem that is not an OpenTitan TL-UL design, so its bus pipeline ends in AHB-lite rather than TL-UL. `sep_crypto_abr_wrapper` narrows its 64-bit AXI4 slave port to 32 bits, converts it to AXI4-lite, and

drives abr_top through axi_lite_to_ahb, which issues one single AHB transfer at a time and returns its response before it accepts the next access. The wrapper is port SEP_CRYPTO_AXI_ABR of the crypto demux and occupies a 64 kB aperture at 0x1094_0000.

Every ABR register is 32 bits wide, and the aperture is accessed in words:

- A 32-bit access reads or writes one register.
- A 64-bit access at an 8-byte-aligned address is carried out as two 32-bit accesses to the two registers it covers, low address first. A 64-bit access whose address has bit 2 set reaches only the upper register.
- Each word of a write is taken by its own strobe. A word whose strobe is empty is not written, so a 64-bit write that strobes one word writes that word alone, with OKAY. A word whose strobe is partial is not written, and the access is answered with SLVERR; in a 64-bit write the other word is still written when its strobe is full. abr_top ties the register block's byte enables high and the AHB slave zero-extends a narrow write, so a partial write would otherwise overwrite the rest of the register.
- A narrow read is performed as a read of the whole register that contains it. Only the bytes it names are returned; the other byte lanes read as zero.

Any number of reads and writes may be outstanding on the aperture from any mix of masters. They are performed one at a time, and each returns the value of the address it names.

The crypto demux decodes the aperture only as far as the register map extends. It forwards an offset inside that extent to ABR and answers every access past it with DECERR itself, whatever its size or strobes.

Inside the extent there is no further decode. The vendored register block consumes every offset bit and applies no address-validity or permission check, so the extent is fully consumed but not fully populated: register objects sit at coarse offsets with unused space between them.

The SEP memory map states how a word access to an unpopulated offset answers, inside the extent and past it. A partial-word write inside the extent is answered with SLVERR wherever it lands (ABR access size). ABR never drives hresp to error, so the AHB error response its slave interface implements is unreachable. A burst is answered with DECERR by the demux (Section 2.1.5.11.2). A malformed ABR register address inside the extent therefore returns no bus error.

NOTE

The absence of decode inside the extent follows from the vendored collateral rather than a SEP decision. abr_reg.sv is generated in the Adams Bridge repository, not by the OCAH register flow, and address-validity decode is a PeakRDL-regblock exporter option rather than a SystemRDL property; the committed file predates that option. Changing it is an upstream change.

Upstream, Adams Bridge draws its secrets from the Caliptra Key Vault. OCAH does not instantiate that vault. The Key Manager's private AXI4-Lite key bus terminates inside the wrapper at the abr_wrapper_key_reg CSR block — the same convention as the AES and OTBN wrappers — and sep_abr_kv_shim presents the recovered dual-share secrets to abr_top over the Caliptra kv_read / kv_write port protocol. Only the Key Vault client helpers are vendored; the vault storage block is not compiled. This leaves the vendored core unmodified while giving ABR the same kind of key path as every other accelerator, one mastered by the Key Manager.

ABR is delivered seeds rather than keys, and is the only accelerator with more than one delivery destination. Four blocks are qualified independently — MLDSA_SEED, MLKEM_SEED_D, MLKEM_SEED_Z and MLKEM_MSG — each carrying eight words per share with its own KEY_CTRL.KEY_VALID, in the format given in Section 2.1.5.11.3. The ML-DSA seed and the ML-KEM message are read as single 256-bit values. The ML-KEM seed is read as one 512-bit value formed by concatenating MLKEM_SEED_D followed by MLKEM_SEED_Z, so that read completes only when both blocks are valid. An operation consumes a delivered seed only once its seed read is enabled.

Word order is the same as for every other accelerator: word `i` of a delivered block is register index `i` of the corresponding software register array (`MLDSA_SEED[i]`, `MLKEM_SEED_D[i]`, `MLKEM_SEED_Z[i]` or `MLKEM_MSG` word `i`), so a value delivered by the Key Manager and the same eight words written by software present the same seed or message to the engine. Index 0 holds the first four bytes of the FIPS 203 or FIPS 204 byte string, with byte 0 in bits `[7:0]`, as upstream Adams Bridge defines for its registers.

The ML-KEM shared key travels in the opposite direction, making this the only delivery destination that is also a source: the accelerator writes the shared key into `MLKEM_SHARED_KEY.KEY`, and on the final word sets that block's `KEY_CTRL.KEY_VALID` and `IRQ_STATUS.KEY_VALID`, which raises the gated shared-key interrupt consumed by the Key Manager. `KEY[i]` holds bytes `4i` to `4i+3` of the FIPS 203 shared key, in the same order as the engine's own `MLKEM_SHARED_KEY` register array.

NOTE

This word order differs from the upstream Caliptra integration. The Caliptra Key Vault stores an entry most-significant word first, and the vendored controller reverses word index on its Key Vault read and write ports to match. `sep_abr_kv_shim` applies the inverse reversal, so Caliptra's documentation of Key Vault word order does not apply to the Key Manager path.

The working SRAM is brought out of the wrapper as packed `abr_mem_req_t` / `abr_mem_rsp_t` structs. Word-write channels are `we` / `re` / address / data; `sig_z` and `pk` also carry one-bit-per-byte `wstrobe`. `SEP_ABR_SRAM_LATENCY` is the macros' native registered-read latency (default 1). `SEP_ABR_MASKING_EN` (default 1) selects Adams Bridge 2-share DOM: thirteen 1R1W macros versus nine, plus a second NTT. That choice changes ABR internal behavior (sequencing, SCA, memory topology), not merely throughput.

ABR has no alert channel — it is the only crypto accelerator that reports faults solely by interrupt (Adams Bridge error and notification in Section 2.1.5.8.2.1), plus a gated ML-KEM shared-key interrupt consumed directly by the Key Manager. Whether the block is present in a build is controlled by `SEP_ABR_EN`, which always implies the vendored RTL's `CALIPTRA` define; when it is absent, both the crypto crossbar port and the Key Manager key bus are terminated with AXI4-Lite error slaves.

NOTE

Adams Bridge does not auto-return to its RESET state when an operation finishes. The sequencer parks at the operation's end state with `STATUS.VALID` set, and `STATUS.READY` re-asserts only after a `zeroize` or a reset, so completion is visible in `VALID` and back-to-back operations need a `zeroize` between them.

Consult the Adams Bridge documentation for the authoritative core functionality of the IP. The Programmer's Guide gives the programming guidance for this block. Its CSRs are defined by the vendored Caliptra register package rather than by an OCAH PeakRDL source, so unlike the other accelerators they do not appear in Detailed Register Map.

2.1.5.11.11. OTBN PKA Public Key Accelerator

The module is based on the OpenTitan OTBN design.

Features:

- Fully programmable big integer processor
  - 256-bit data path with 32 entry register file
  - 32-bit control path with 32 entry register file
  - Complex flow control: conditional branching, loops, call/return with optimized hardware for performance
  - Dual status control bits to assist in big integer computation
  - Optimized modular arithmetic on big integers

- Access to entropy noise stream from the TRNG

The OTBN is programmed in assembly and its runtime driver library currently supports the following algorithms:

- ECDSA P256, P384
- ECDH P256, P384
- Ed25519
- X25519
- RSA 2k, 3k, 4k
  - Key generation, signature generation and signature verification
- SHA256, SHA-512

Since the OTBN is programmable, more algorithms can easily be developed at a later time. The microcode is loaded into SRAM based instruction memory allowing firmware updates to be made in the field.




Figure 42. OpenTitan OTBN core reference architecture

Figure 42 shows the upstream core. The OCAH bus, key-delivery, and entropy connections are described in the

integration details below.

2.1.5.11.11.1. OCAH Modifications

- AXI4-lite key bus slave interface replaces side loading interface
- AXI4-lite control/status bus slave interface

The OTBN host path is the most complex OpenTitan path. The crypto interconnect applies a `CACHE_MODIFIABLE` bit fix before the `axi_dw_converter`, because the VeeR CPU may emit non-modifiable cache attributes for MMIO accesses that would be rejected by the AXI-to-AXI-Lite converter. After data-width conversion and AXI-Lite isolation, `sep_crypto_otbn_wrapper` bridges the request to TL-UL and drives the standard `otbn` core configured with `Stub = 0` and `RegFile = RegFileFF`.

OTBN's instruction and data memories are external SRAM macros; the IMEM and DMEM `prim_ram_1p_scr` ports are brought out of the wrapper to the `sep_crypto` top level. The two random-number request ports (`edn_rnd`, `edn_urnd`) are served over native-protocol EDN by the shared `drbg_axis_edn_adapter` instance `u_axis_edn_crypto_s3c_scan` in `sep_crypto`, which converts the post-CSRNG DRBG AXI-Stream feed assigned to the crypto sink domain into per-client EDN responses. The adapter forwards the per-beat FIPS tag through a generic AXI-Stream `tuser` sideband. The CSRNG seed tag and external entropy mux tag are tied high by the integration's provisional policy. A high tag prevents a FIPS-tag failure for that response but does not prove that the entropy is FIPS compliant. The OTP scramble key handshake is tied to fixed values. Life-cycle escalation and RMA request signals are tied to their inactive state. OTBN occupies alert indices `[2:1]` in Section 2.1.5.11.1 and exports a single `intr_done_o` interrupt.

The Key Manager delivers a 384-bit OTBN key as twelve words per share, the widest delivery in the subsystem, in the format given in Section 2.1.5.11.3. OTBN is the only accelerator that does not combine the shares in hardware. The shares are exposed to the executing program through the `KEY_S0_L` / `KEY_S0_H` and `KEY_S1_L` / `KEY_S1_H` special registers, each share split into a 256-bit low and a 128-bit high half, and the program is responsible for reconstructing the key as the XOR of the two shares. Each share is qualified independently: reading a share whose key is not valid sets `ERR_BITS.KEY_INVALID` and stops the program rather than returning key material.

Consult the OpenTitan OTBN documentation for the authoritative core functionality of the IP. The Programmer's Guide gives the programming guidance for this block. The register map follows below.

2.1.5.11.11.2. Memory Map and Register Reference

2.1.5.11.11.2.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.5.11.11.2.2. Detailed Register Map

2.1.5.11.11.2.2.1. OpenTitan Big Number Accelerator

Programmable coprocessor for asymmetric cryptography with SCA and FI countermeasures

Table 359. OpenTitan Big Number Accelerator register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	-
0x4	INTR_ENABLE	RW	-
0x8	INTR_TEST	W	-

Address	Name	Access	Description
0xC	ALERT_TEST	W	-
0x10	CMD	W	-
0x14	CTRL	RW	-
0x18	STATUS	R	-
0x1C	ERR_BITS	RW	-
0x20	FATAL_ALERT_CAUSE	R	-
0x24	INSN_CNT	RW	-
0x28	LOAD_CHECKSUM	RW	-

2.1.5.11.11.2.2.1.1. INTR_STATE

Table 360. otbn.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	done	RW1C	0x0	OTBN has completed the operation.

2.1.5.11.11.2.2.1.2. INTR_ENABLE

Table 361. otbn.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	done	RW	0x0	Enable interrupt when !!INTR_STATE.done is set.

2.1.5.11.11.2.2.1.3. INTR_TEST

Table 362. otbn.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	done	W	0x0	Write 1 to force !!INTR_STATE.done to 1.

2.1.5.11.11.2.2.1.4. ALERT_TEST

Table 363. otbn.ALERT_TEST fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	recov	W	0x0	Write 1 to trigger one alert event of this kind.
0	fatal	W	0x0	Write 1 to trigger one alert event of this kind.

2.1.5.11.11.2.2.1.5. CMD

Table 364. otbn.CMD fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	cmd	W	0x0	The operation to perform. | Value | Name | Description | |:------|:----------|:----------| | 0xd8 | EXECUTE | Starts the execution of the program stored in the instruction memory, starting at address zero. | | 0xc3 | SEC_WIPE_DMEM | Securely removes all contents from the data memory. | | 0x1e | SEC_WIPE_IMEM | Securely removes all contents from the instruction memory. |

2.1.5.11.11.2.2.1.6. CTRL

Table 365. otbn.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	software_errs_fatal	RW	0x0	Controls the reaction to software errors. When set software errors produce fatal errors, rather than recoverable errors. Writes are ignored if OTBN is not idle.

2.1.5.11.11.2.2.1.7. STATUS

Table 366. otbn.STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	status	R	0x4	Indicates the current operational state OTBN is in. All BUSY values represent an operation started by a write to the !!CMD register. | Value | Name | Description | |:------|:----------|:----------| | 0x00 | IDLE | OTBN is idle: it is not performing any action. | | 0x01 | BUSY_EXECUTE | OTBN is busy executing software. | | 0x02 | BUSY_SEC_WIPE_DMEM | OTBN is busy securely wiping the data memory. | | 0x03 | BUSY_SEC_WIPE_IMEM | OTBN is busy securely wiping the instruction memory. | | 0x04 | BUSY_SEC_WIPE_INT | OTBN is busy securely wiping the internal state. | | 0xFF | LOCKED | OTBN is locked as reaction to a fatal error, and must be reset to unlock it again. See also the section "Reaction to Fatal Errors". |

2.1.5.11.11.2.2.1.8. ERR_BITS

Table 367. otbn.ERR_BITS fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23	fatal_software	RW	0x0	A FATAL_SOFTWARE error was observed.
22	lifecycle_escalation	RW	0x0	A LIFECYCLE_ESCALATION error was observed.
21	illegal_bus_access	RW	0x0	An ILLEGAL_BUS_ACCESS error was observed.
20	bad_internal_state	RW	0x0	A BAD_INTERNAL_STATE error was observed.
19	bus_intg_violation	RW	0x0	A BUS_INTG_VIOLATION error was observed.
18	reg_intg_violation	RW	0x0	A REG_INTG_VIOLATION error was observed.

Bits	Field	Access	Reset	Description
17	dmem_intg_violation	RW	0x0	A DMEM_INTG_VIOLATION error was observed.
16	imem_intg_violation	RW	0x0	A IMEM_INTG_VIOLATION error was observed.
15:9	Reserved	-	-	Reserved
8	mai_software_error	RW	0x0	An MAI_SOFTWARE_ERROR error was observed.
7	rnd_fips_chk_fail	RW	0x0	An RND_FIPS_CHK_FAIL error was observed.
6	rnd_rep_chk_fail	RW	0x0	An RND_REP_CHK_FAIL error was observed.
5	key_invalid	RW	0x0	A KEY_INVALID error was observed.
4	loop	RW	0x0	A LOOP error was observed.
3	illegal_insn	RW	0x0	An ILLEGAL_INSN error was observed.
2	call_stack	RW	0x0	A CALL_STACK error was observed.
1	bad_insn_addr	RW	0x0	A BAD_INSN_ADDR error was observed.
0	bad_data_addr	RW	0x0	A BAD_DATA_ADDR error was observed.

2.1.5.11.11.2.2.1.9. FATAL_ALERT_CAUSE

Table 368. otbn.FATAL_ALERT_CAUSE fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	fatal_software	R	0x0	A FATAL_SOFTWARE error was observed.
6	lifecycle_escalation	R	0x0	A LIFECYCLE_ESCALATION error was observed.
5	illegal_bus_access	R	0x0	A ILLEGAL_BUS_ACCESS error was observed.
4	bad_internal_state	R	0x0	A BAD_INTERNAL_STATE error was observed.
3	bus_intg_violation	R	0x0	A BUS_INTG_VIOLATION error was observed.
2	reg_intg_violation	R	0x0	A REG_INTG_VIOLATION error was observed.
1	dmem_intg_violation	R	0x0	A DMEM_INTG_VIOLATION error was observed.
0	imem_intg_violation	R	0x0	A IMEM_INTG_VIOLATION error was observed.

2.1.5.11.11.2.2.1.10. INSN_CNT

Table 369. otbn.INSN_CNT fields

Bits	Field	Access	Reset	Description
31:0	insn_cnt	RW	0x0	The number of executed instructions.

2.1.5.11.11.2.2.1.11. LOAD_CHECKSUM

Table 370. otbn.LOAD_CHECKSUM fields

Bits	Field	Access	Reset	Description
31:0	checksum	RW	0x0	Checksum accumulator

2.1.5.11.12. Key Manager (KM)

The Key Manager provides isolated key storage, random key generation, explicit revocation, and delivery to the cryptographic accelerators. The following sections describe its hardware architecture and firmware interface.

The immutable ROM firmware first initializes the Key Manager, then remains active to process SEP mailbox commands and service interrupts. It is both startup firmware and the resident runtime; "boot ROM" names the memory, not its only function. On an explicit firmware-load/execute command, ROM can hand control to mutable firmware in SRAM. The Key Manager Application ROM appendix of the Programmer's Guide defines the implemented services, command protocol and handover rules.

2.1.5.11.12.1. Architecture

The Key Manager (KM) uses a PicoRV32 CPU, private memories and a Key and Policy Vault (KPV) to separate key management from SEP host execution. The host submits commands and supplied key material through a mailbox; KM firmware validates requests, accesses the vault and writes accelerator sideload registers. The host has no direct bus access to KM key storage.

The ROM is the resident command processor as well as the startup firmware. Its mailbox commands report the hardware, ROM and SRAM firmware versions and the recoverable-error status, generate keys from the DRBG, load SEP-supplied keys, revoke keys, transfer keys to the accelerators, shred accelerator sideload keys, capture the Adams Bridge ML-KEM shared key into the vault, set cold-domain OTP read-locks, and either load and execute mutable firmware in SRAM or keep the ROM running (the command summary in the Programmer's Guide).

A single KM-mastered AXI4-Lite crossbar connects KMCSR, KPV, the DRBG sampler and mailbox to the private accelerator key interfaces and the SEP OTP/eFuse access path. The accelerator interfaces serve AES, HMAC, KMAC, OTBN and Adams Bridge. Address decoding separates their windows; command and key policy checks belong to KM firmware.

The Memory Map and Register Reference at the end of the chapter defines the address windows and all generated fields. The Key Manager Application ROM appendix of the Programmer's Guide defines commands, validation and responses. ROM/SRAM parity detects errors but does not correct them; the ROM fault handler can report an unrecoverable fault and halt the CPU.

Figure 43 shows the Key Manager CPU, vault, mailbox, and accelerator interfaces.




Figure 43. Key Manager architecture

White boxes are `key_manager` instances, cream boxes are interconnect or glue logic, and grey boxes lie outside `key_manager`. M and S mark the manager and subordinate side of each AXI4-Lite or AXI-Stream connection.

The CPU reaches the ROM and SRAM through direct memory ports rather than the crossbar. The ROM and SRAM hard macros are instantiated at integration level, so `key_manager` exposes `rom_mem_*` and `sram_mem_*` ports to them. Every other CPU access leaves the PicoRV32 AXI4-Lite master and is decoded by `u_xbar`.

The five engine ports reach only the key CSRs of each engine wrapper. In SEP each passes through its own isolation stage and carries no host traffic; the SEP host reaches the engines' data registers through the crypto interconnect, a path the KM does not see. For offsets in the MAP, CTRL and MMR register maps, the OTP/eFuse port replaces address bits `[31:12]` with `OTP_EFUSE_REMAP_BASE[31:12]` before driving `efuse_req_o`; it answers every other offset in the window with SLVERR.

A rising edge on `wipe_state_i`, or a CPU trap, zeroes the KPV and sets `IRQ_STATUS.WIPE_STATE` in KMCSR. The CPU trap also

drives `unrecoverable_err_o`. `u_kmcsr` drives `soft_rst_n` into `u_reset_conditioner` (Figure 44). `test_en_i` selects the scan reset in `u_reset_conditioner` and drives the test inputs of `u_xbar` and `u_mailbox`.

2.1.5.11.12.1.1. Parameters

The Key Manager is configured through its ROM and SRAM sizes, the mailbox FIFO depth, the read-data behaviour of its memories, and the address of the eFuse controller. The main KM SRAM is 32 KB (8192 × 32-bit words), implemented with the scrambler macro `scrambler_8192x32`. The SRAM macro must return read data (`rvalid`) at least one cycle after the cycle in which it grants the read, because the SRAM interface descrambles and parity-checks each response with the address and byte strobes it captures at the grant.

The parameters of `key_manager` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.5.11.12.1.2. Reset Conditioning

Figure 44 shows how cold and warm reset requests are conditioned for the Key Manager.




Figure 44. Key Manager cold and warm reset conditioning

Each reset net keeps its own colour. The cold and warm outputs of `u_reset_conditioner` run in two spines beside the instances, with the port name at each instance edge. A solid warm line drives a reset pin; a dashed warm line is a synchronous clear, which the instance samples on `clk_i` rather than using as a reset. Junction dots mark fan-out, and a gap in a line marks a crossing without connection. In test mode, `test_en_i` selects `scan_rst_ni` in both scan multiplexers.

Cold and warm resets have different scopes. Warm reset restarts the CPU and its control interfaces while retaining cold-domain state and memory contents. Retention across warm reset does not make SRAM or registers non-volatile, and reset must not be treated as a key-data wipe.

Table 371 identifies the two external reset inputs and their SEP connections.

Table 371. Key Manager reset inputs

Input port	Polarity	Synchronicity	Integration tie-off (SEP)
cold_rst_ni	Active-low	Asynchronous	SEP system cold reset (sep_reset_n).
warm_rst_ni	Active-low	Synchronous to clk_i	SEP KM sub-component software-reset CSR bit (km_sw_rst_ni).

SEP isolates the Key Manager's AXI paths before asserting the warm reset; see Section 2.1.5.4.3.3.

km_reset_conditioner produces two active-low outputs:

- rst_cold_aasd_no: cold_rst_ni passes through prim_rst_sync for asynchronous assertion and synchronous release. There is no cold-path hold counter. Cold reset also asserts the warm path.
- rst_warm_sync_no: either synchronous input, warm_rst_ni or KMCSR soft_rst_ni, triggers a hold counter. Reset remains asserted for at least MIN_RESET_CYCLES clocks (default 10) after the trigger releases. The cold output asynchronously resets this counter; cold reset is not sampled as a synchronous trigger.

scanmode_i selects scan_rst_ni to override both paths for DFT. Table 372 identifies resettable state; it does not imply that key-data flops or memory arrays have reset values.

Table 372. Key Manager reset-domain assignment

Reset domain	Components
Cold only (rst_cold_aasd_no)	ROM/SRAM memory interfaces and parity logic; SRAM scrambler lock state (SCRAMBLER_CTRL.lock, SCRAMBLER_KEY); the SEP-facing mailbox FIFOs and state machines; shared mailbox separator/status bits; the BOOT_STATUS.COLD_BOOT_DONE flag; the OTP_READ_LOCK_COLD register; KPV scrambler enable/lock state.
Warm + cold (rst_warm_sync_no)	PicoRV32 CPU core; the KM-internal AXI4-Lite crossbar/fabric transaction state; the KMCSR warm subset (IRQ_STATUS/IRQ_ENABLE/IRQ_SET, SOFT_RST_CODE, RECOVERABLE_ERR, SRAM_LOCK write-lock bits, SRAM_LOCK violation bits, SRAM_EXEC_MODE, the ROM lockout latch, IRQ_ENTRY_ADDR/IRQ_ENTRY_LOCK, OTP_READ_LOCK, OTP_CHANGE_STATUS, and the firmware test-bench registers); DRBG sampler configuration/status controls and request state (datapath storage has no reset value); the KPV per-slot lock bits (lock_write, lock_use, seal); and the KM-side mailbox write/read state machines, IRQ, control, and status fields.

The internal AXI4-Lite fabric and generated register CPU interfaces reset on warm reset, discarding their in-flight transaction state. This is an internal reset boundary, not a completion or cancellation guarantee for an external accelerator transaction. Mailbox FIFO contents survive warm reset; ROM flushes the mailbox during boot before accepting new commands.

Writing 0x53525354 (ASCII "SRST") to KMCSR SOFT_RST_CODE triggers the warm path. BOOT_STATUS.COLD_BOOT_DONE survives it: ROM sets this flag after cold-boot initialization and reads it on subsequent boots to distinguish warm restart from cold initialization.

2.1.5.11.12.1.3. Mailbox Transport

The mailbox is a raw 32-bit word transport with two FIFOs: inbound SEP-to-KM and outbound KM-to-SEP, each at least 16 words deep. Hardware does not parse commands, validate CRCs or enforce key policy. Firmware defines the framing in Table 373 and Table 374; use the firmware reference for command legality, sequencing and error responses.

Table 373. Key Manager message with payload

header_crc8[31:24]	message_length[23:16]	function_id[15:8]	sequence_number[7:0]
Data_1[31:0]			
Data_2[31:0]			
...			
Data_N[31:0]			

header_crc8[31:24]	message_length[23:16]	function_id[15:8]	sequence_number[7:0]
CRC32[31:0] - checksum			

Command/response messages without a data payload (message_length = 0x00) drop the payload CRC32 and only contain the header (Table 374).

Table 374. Key Manager header-only message

header_crc8[31:24]	0x00	function_id[15:8]	sequence_number[7:0]

Each FIFO word carries a separator bit that the sender sets on the last word of a message. The receiver uses it with the header length to check framing. Reads pop words; writes push words. Status reports fill level and empty/full conditions.

A write to a full FIFO drops the incoming word without changing queued data. An empty read has no data to consume. Both return SLVERR by default, with configuration allowing OKAY, and set the corresponding sticky overflow or underflow status. Each side has write-one-to-trigger flush control: either side flushes **both** FIFOs and sets the peer's flushed-by-other status.

Each side independently enables its interrupt sources. Receive-data-available and transmit-space-available are level conditions; overflow, underflow and peer-flush are sticky conditions. Their enabled OR drives one interrupt to each side: directly to the KM CPU for the KM side, and to the SEP interrupt controller for the SEP side. KM firmware validates received words before executing a command and uses the outbound FIFO for responses and fault notifications. Error handling and resynchronization are firmware operations, not hardware command filtering.

Figure 45 shows the mailbox paths used for SEP commands and Key Manager responses.




Figure 45. Key Manager mailbox transport

The KM CPU enters at the top and the SEP host at the bottom. Each side's decode sends its `WRITE_DATA` address to a FIFO push and its `READ_DATA` address to a FIFO pop, and every other address to its own register block. Words therefore travel upwards through `u_inbound_fifo` and downwards through `u_outbound_fifo`. Each register block reads the status of both FIFOs, and a `FLUSH` from either block clears both of them. `MAILBOX_DEPTH` sets the depth of each FIFO; SEP instantiates the KM with 16 words.

2.1.5.11.12.1.4. Key Delivery

Keys reside in the KPV and reach accelerator sideload registers through the KM-mastered key path. Host-supplied material enters through mailbox commands; generated secret material is not returned through a direct host read path. The generated Section 2.1.5.11.12.3.1 defines the KM's allocated windows.

Figure 46 separates the key-delivery path on the top row from the host-accessible data path on the bottom row. This separation does not establish resistance to physical fault injection or side-channel attacks. Firmware's key-data CRC detects corruption; it is not a substitute for access control or a physical-attack guarantee.




Figure 46. Key Manager accelerator key path

The figure shows one engine wrapper; `<eng>` stands for `otbn`, `aes`, `kmac` or `hmac`. The KM port for that engine (`otbn_req_o`, `aes_req_o`, `kmac_req_o` or `hmac_req_o`) is a point-to-point 32-bit AXI4-Lite path. It passes only through `u_<eng>_key_isolate` in `sep_crypto_axi_interconnect`, which drains the path when `sep_reset_ctrl` requests isolation, and ends on the wrapper's generated `<eng>_wrapper_key_reg` block. The `KEY_SHARE0` and `KEY_SHARE1` words are write-only, and reads return zero. The two shares and `KEY_CTRL.KEY_VALID` drive the engine's `keymgr_key_i` sideload port; the XOR of the two shares is the key. The shares are 8 words each, or 12 words for OTBN.

The SEP host reaches the engine's own registers on a separate path: the crypto interconnect demultiplexes the 64-bit AXI4 host bus in `u_axi_demux`, converts it to 32 bits in `u_<eng>_axi_dw_converter` and to AXI4-Lite in `u_<eng>_axi_to_axi_lite`, and passes it through `u_<eng>_host_isolate`, and the wrapper bridges it to the engine's TL-UL port. `isolate_req_i` from `sep_reset_ctrl` drives both isolation stages. The host path does not reach the key registers, and the KM path does not reach the engine's control registers. Adams Bridge follows the same pattern through `u_abr_key_isolate` and `abr_wrapper_key_reg`, where `sep_abr_kv_shim` turns the registers into Adams Bridge key-vault reads (see Section 2.1.5.11.12.1.5).

2.1.5.11.12.1.5. Adams Bridge Key Sideload Interfaces

The KM provides dedicated sideload interfaces to the Adams Bridge (ABR) post-quantum engine, exposed as a single AXI4-Lite register block mapped at `0x0001_C000`–`0x0001_C7FF`. The block has two directions: four seed inputs the KM drives into ABR, and one shared-key output ABR drives back into the KM.

Seed sideload inputs (KM → ABR). The four seed inputs carry key material the KM side-loads into ABR (Table 375).

Table 375. Adams Bridge seed sideload inputs

Interface	Width	Description
ML-DSA seed	256-bit	Seed for ML-DSA key generation.
ML-KEM seed D	256-bit	ML-KEM seed D.
ML-KEM seed Z	256-bit	ML-KEM seed Z.
ML-KEM message	256-bit	ML-KEM message input.

Each seed uses the two-share masked layout (two key-share register banks whose XOR is the real value, plus a `key_valid` bit) and is write-only to KM firmware. The seeds are valid `dest_valid` destinations (bits 4–7), so they are targets of `CMD_KEY_TRANSFER` and `CMD_ENGINE_SHRED`, and ROM shreds them during the mutable-firmware handover. Word order matches the other engines: share word `i` is word `i` of the seed the engine consumes, as stated in ABR seed word order.

ML-KEM shared-key output (ABR → KM). ABR computes an ML-KEM shared key and presents it to the KM. The interface comprises a 256-bit (8-word) key register array, a `KEY_CTRL` register holding `key_valid`, and an `IRQ_STATUS` / `IRQ_ENABLE` interrupt pair.

- The key words and `KEY_CTRL.key_valid` are read-only to KM firmware: hardware sets `key_valid` and loads the key words when ABR delivers a new shared key. Firmware consumes the key by writing `KEY_CTRL = 0`, which clears `key_valid` and hardware-zeroizes (`hwclr`) the key words. Software can clear `key_valid` but cannot set it.
- `IRQ_STATUS.key_valid` is a sticky, write-one-to-clear bit (`hwset stickybit` + `onwrite=woclr`). Hardware sets it on the key-ready event; firmware clears it by writing 1. The masked interrupt to the KM CPU is `IRQ_STATUS & IRQ_ENABLE`, on a dedicated PicoRV32 interrupt (bit 5).

The KM firmware ISR acknowledges the IRQ by clearing `IRQ_STATUS` and flags the main loop; it does not consume the key. The shared key is later captured into a KPV slot in response to a SEP `CMD_ABR_SK_TRANSFER` command (see the firmware documentation).

2.1.5.11.12.1.6. Key Manager CPU Interrupt Processing

The PicoRV32 receives three separate external interrupt groups:

Table 376. KM CPU interrupt routing

CPU IRQ bit	Source	Service boundary
3	KMCSR	Sticky hardware events, masked by `IRQ_ENABLE`; see Table 379.
4	Mailbox	Enabled level and sticky FIFO conditions; independent of KMCSR `IRQ_STATUS`.
5	Adams Bridge shared key	Shared-key-ready status; see Section 2.1.5.11.12.1.5.

KMCSR `IRQ_SET` injects its corresponding status events for ISR testing. Mailbox and Adams Bridge interrupts retain their own status/enable controls. The CPU's interrupt mask is an additional level of control. A reported event, an enabled interrupt and a CPU trap are distinct; see Unrecoverable Faults.

2.1.5.11.12.1.7. Host Coordination

The SEP host submits key-load and key-transfer commands through the mailbox. The Key Manager validates the request and policy before accessing the vault or delivering key material to a cryptographic engine.

Figure 47 shows the command, validation, vault-access, and key-delivery sequence.




Figure 47. SEP host and Key Manager key-load and key-transfer sequence

Time runs downwards. Each arrow is a mailbox word push or pop, a register write or read, or an interrupt, and each white box is a check or action the KM firmware performs without leaving the CPU. The figure shows the success path. A failed check ends the command with a RESP_CMD error code and leaves the KPV and the key registry unchanged.

On a key load, the firmware registers the handle before it writes the KPV, and destroys the handle again if a KPV write fails. On a key transfer, the firmware reads the key slots twice: once to check their CRC-32C against the key registry, and again to write the key. Each requested engine receives the key as two key shares whose XOR is the key, the first a DRBG mask, before its key-valid bit is set. The engines are written in the order of their DEST_ENGINE bits, and the first failed write ends the transfer.

2.1.5.11.12.1.8. Key and Policy Vault (KPV)

The KPV exposes 64 slots through one KM-only AXI4-Lite interface. Each slot contains 512 bits (16 words) of key data and a 32-bit CTRL register. Multi-slot keys, such as RSA3K material, require consecutive slots; the firmware registry tracks the span and the used words in the final slot. Hardware has no span field.

Table 377. KPV per-slot controls

Field	Behavior
lock_write[0]	Write-one-to-set. Blocks key-data writes with SLVERR; does not block CTRL writes or erase. Hardware holds it set while seal is set.
lock_use[1]	Write-one-to-set. Key-data reads return zero with SLVERR. Also set when an erase completes on a sealed slot.
erase[2]	Write one to overwrite all 16 words with pseudorandom data. No lock blocks erase. Poll until hardware clears the bit. If the slot is unsealed at completion, all CTRL bits clear and the slot is reusable. If sealed at completion, it is retired: lock_write, lock_use and seal remain set.
seal[3]	Write-one-to-set. Implies a write lock. Erase destroys the contents without making the slot reusable; taking a seal during an erase also causes retirement.
[31:4]	Reserved.

The lock/seal bits clear on warm or cold reset. Erase uses the shared scrambler and key-data write port, so key-data accesses during an erase are not defined. The KPV driver in the Key Manager Application ROM appendix of the Programmer's Guide gives the erase sequence.

Sealed and retired slots. A slot with *seal* set is **sealed**: readable, but not writable, because hardware holds *lock_write* set alongside the seal. That surviving *lock_write* is evidence that the slot holds what it held when the seal was taken, which is what lets firmware that inherits the vault after a handover trust material provisioned before it. A write lock on its own would prove nothing, since an erase clears it and frees the slot to be rewritten with chosen material and re-locked.

Erasing a sealed slot is still permitted, and leaves it **retired**: *lock_write* held, *lock_use* set, *seal* still set, and the data destroyed. A retired slot can be neither read, rewritten nor reused until the next warm reset, and repeating the erase changes nothing. Revocation and reuse are therefore separate: firmware can destroy a sealed key it no longer trusts without handing the slot to whoever asked for the destruction.

An emergency wipe also releases sealed and retired slots by clearing key data and all CTRL bits. The safety of that release depends on CPU containment: a trap already halts the CPU, whereas an externally requested wipe requires firmware or host coordination (Section 2.1.5.11.12.1.10). Do not assume that asserting wipe_state_i directly halts CPU execution.

CTRL resets to zero. Key-entry data flops have no reset value and power up undefined; cold or warm reset alone does not overwrite their contents.

2.1.5.11.12.1.9. KPV Scrambling

The KPV supports address and data scrambling during normal operation for all key entry data reads and writes, using the same PRESENT-based approach as SRAM scrambling. When enabled, the stored representation of key data is scrambled; the KM port sees the logical (unscrambled) data on the bus, with scrambling/descrambling performed transparently by the KPV.

The KPV has a scrambler key register (32-bit) and a scrambler control register with an enable bit and a lock bit. These registers are accessible only via the KM port. The lock bit is write-one-only (0→1): software sets lock by writing 1; writing 0 has no effect; lock cannot be cleared until the next **cold** KM reset. The KPV scrambler enable and lock are state in the cold reset domain — they are preserved across a warm reset and cleared only by a cold reset. Scrambling is disabled by default after a cold reset.

When scrambling is enabled, the KPV uses the same scrambler algorithm as SRAM but sized for 1024×32 words (64 slots × 16 words). The scrambler address input is the linear register index (0..1023): *slot_index* × 16 *word_index*. Address scrambling maps the logical index to a scrambled physical storage index. Data is scrambled before storage and descrambled after retrieval. Only key entry data words are scrambled; CTRL registers are not scrambled.

The KPV scrambler key register has no reset value (powers up random/undefined for security). The scrambler control register (enable and lock) resets to 0. On an emergency wipe (rising edge of *wipe_state*), the entire KPV is reset to zero including key data, control registers, and the KPV scrambler key and control registers.

2.1.5.11.12.1.10. Wipe State

Hardware forms a wipe event from `wipe_state_i | cpu_trap` and detects its rising edge. The resulting pulse clears all 1024 KPV data words, all 64 slot CTRL registers, and KPV scrambler key/enable/lock state on the clock edge. It also records the KMCSR wipe event. This hardware action covers the KPV; it does not itself scrub SRAM, mailbox data or accelerator sideload registers.

In SEP, `sep_cpu_ctrl.KM_WIPE_CTRL.wipe_state` drives the external input. Hold it high for at least one complete KM clock period. Return it to zero before requesting another rising edge; the software-controlled registered level provides the required hold. SEP does not connect a hardware tamper or alarm source to this input. A CPU trap independently triggers the same KPV wipe and asserts `unrecoverable_err_o` while the CPU is halted.

An external wipe does **not** force a CPU trap in hardware. The ROM enables the wipe interrupt and treats it as an unrecoverable fault, but that response depends on interrupt delivery and execution of its handler. Software that masks the event or replaces ROM must not assume the CPU has stopped. The host/integrator must prevent continued use of the released vault after an external wipe until recovery resets the CPU. Warm reset clears the trap and re-enters ROM; it is not itself the KPV data erase mechanism.

2.1.5.11.12.1.11. Scan and Scan-Dump Protection

The complete KM is **Class 2** under SEP's scan-chain protection policy: processor, vault, KMCSR, mailbox, entropy sampler, scramblers, internal fabric, reset logic and register blocks. Including non-secret control state avoids relying on a per-register classification.

- **Test scanning is permitted only in secure test mode.** The dedicated-chain DFT controller admits test commands only with `secure_tm = 1`. At the eFuse shadow boundary, this mode replaces the four Class 1 sources (`*_UID` and `CLASS_KEY`) with valid zero values before KM captures them. Those source assets remain outside every scan chain. Public identities, lifecycle and demotion policy remain available.
- **Scan dump is never permitted.** No lifecycle state, owner or combination of `*_DBG` feature enables may turn a test command into a dump. Feature controls determine whether the chain is reachable; the command-class restriction enforces the no-dump policy. General-logic debug enablement does not grant access to the KM secret-bearing chain.

KM-local copies of the UIDs, class key and public identities clear on cold and warm reset (including firmware soft reset) and reload from the shadow bus after release. Lifecycle/demotion captures persist across warm reset. Firmware access locks are independent of scan protection.

Writable KM SRAM is a Class 2 companion memory because it can retain key, message and firmware working state. Its memory-test policy must also forbid dump. Immutable ROM cannot retain runtime secrets and is excluded. These requirements define the integration boundary; the local KM RTL alone does not establish implementation of the external DFT controller.

2.1.5.11.12.1.12. Key Manager Control and Status Registers (KMCSR)

KMCSR manages interrupts, reset requests, execution permissions, memory protection and OTP shadow readout. It is separate from the KPV and DRBG sampler banks. `km_csr` supplies the behavior around generated `km_csr_reg`; Section 2.1.5.11.12.3.2.2 supplies every offset and field definition. The operating contracts below supplement that generated map.

The `VERSION` register (offset `0x000`) is a read-only register that reports the Key Manager hardware revision using semantic versioning. It uses the following canonical 32-bit layout, mandated so all software and testbenches decode the version identically (Table 378).

Table 378. Key Manager VERSION fields

Bits	Field	Description
`[7:0]`	`PATCH`	Patch version component.
`[15:8]`	`MINOR`	Minor version component.
`[23:16]`	`MAJOR`	Major version component.
`[31:24]`	`RESERVED`	Reserved; reads as 0.

The current hardware revision reads as version `1.0.0` (`MAJOR=1`, `MINOR=0`, `PATCH=0`) after reset with no software initialization. The register is read-only: a write completes with an AXI SLVERR response and does not change the value.

The interrupt aggregation logic collects twelve hardware event sources into a single CPU interrupt. Each source has a sticky status bit in `IRQ_STATUS` (write-one-to-clear), a mask bit in `IRQ_ENABLE`, and a software-trigger bit in `IRQ_SET` for ISR testing. The aggregated interrupt output is the logical OR of the masked status bits (`IRQ_STATUS & IRQ_ENABLE`).

Table 379 maps hardware events to the sticky interrupt-status bits.

Table 379. Key Manager interrupt sources

Bit	Source	Description
0	ROM Parity Error	Parity mismatch detected on a ROM read.
1	SRAM Parity Error	Parity mismatch detected on an SRAM read.
2	ROM Write Error	A write was attempted to the read-only ROM region.
3	SRAM Write-Lock Violation	A write targeted a locked 1 KB SRAM region.
4	AXI SLVERR	An AXI4-Lite slave returned SLVERR.
5	AXI DECERR	An AXI4-Lite slave returned DECERR.
6	DRBG Error	The DRBG sampler reported a timeout or stream error.
7	Wipe State	Rising edge detected on the `wipe_state_i` input or a CPU trap.
8	OTP Change	A monitored OTP readout field's decoded value changed (see `OTP_CHANGE_STATUS`).
9	OTP Integrity Violation	OTP dual-rail integrity violation (value and complement not complementary).

Bit	Source	Description
10	Execute Violation	Instruction fetch from a non-whitelisted (non-executable) memory region, excluding the ROM.
11	ROM Access Violation	ROM instruction fetch or data read attempted after the ROM lockout engaged.

Bits [31:12] of IRQ_STATUS are reserved. Two interrupt sources are not part of the KMCSR IRQ_STATUS aggregation and are serviced separately: the mailbox sources (FIFO data-available/space-available and overflow/underflow/flush conditions), and the Adams Bridge ML-KEM shared-key interrupt on its own PicoRV32 interrupt (bit 5, see Section 2.1.5.11.12.1.5).

The CPU IRQ entry vector is programmable through two registers. IRQ_ENTRY_ADDR holds the effective IRQ entry address and resets to the built-in default 0x0000_0010; firmware may write any 32-bit value (the hardware performs no alignment or validity checking) and the register is always readable, returning the current effective entry address. IRQ_ENTRY_LOCK is a write-one-only lock bit that can only transition from 0 to 1: while it is 0 firmware may reprogram IRQ_ENTRY_ADDR freely; once it is 1, writes to IRQ_ENTRY_ADDR are ignored (the value remains readable and unchanged) and further writes to IRQ_ENTRY_LOCK have no effect. Both registers are in the warm reset domain: every reset that re-enters ROM (cold, external warm, and KM soft reset) restores IRQ_ENTRY_ADDR to 0x0000_0010 and clears IRQ_ENTRY_LOCK.

SRAM_LOCK controls writes to 32 SRAM regions of 1 KB each; see Section 2.1.5.11.12.1.18 for reset and handover policy. SRAM scrambling key/enable/lock state is cold-domain state and survives warm reset. The soft-reset code and cold-boot flag are described under Reset Conditioning.

Execute-Permission Whitelist (NX)

The PicoRV32 enforces a whitelist of executable memory regions on every committed instruction fetch (mem_valid && mem_instr). Any fetch from outside the whitelist immediately pulses KMCSR.IRQ_STATUS.EXEC_VIOLATION, which (if unmasked) routes to the ISR and triggers the unrecoverable fault ROM_KM_UFAULT_EXEC. A ROM fetch refused by the ROM lockout described below is reported on ROM_ACCESS_VIOLATION instead, so the two bits are disjoint.

The whitelist mode is controlled by the KMCSR.SRAM_EXEC_MODE.enable bit (write-1-only, warm-reset domain) (Table 380).

Table 380. Key Manager executable regions

enable	Executable regions	Forbidden regions
0 (ROM mode)	ROM (0x0000–0x3FFF) and VROM*	All SRAM; Peripheral/AXI
1 (SRAM mode)	Write-locked 1 KB SRAM regions (SRAM_LOCK.lock_bits), VROM*, and the ROM until the lockout engages	Unlocked SRAM; Peripheral/AXI; the ROM once the lockout engages

The fetch-region index is a plain slice of the byte address, which works only because the SRAM base (0x0000_8000) is aligned to the SRAM size; it is the same slice km_sram_interface uses to check data writes, so the two views of a region can never disagree.

- VROM is the virtual ROM window, 0x1000_0000–0x1000_FFFF. Only a simulation build that defines OCAH_KM_VROM decodes it; there it is executable in both modes and exempt from the ROM lockout, and it carries no security requirement. Without the define the window is an unmapped address: a load or store answers DECERR, and a fetch pulses EXEC_VIOLATION.

For the define and the builds it is rejected in, see Key manager defines in the Integrator Guide.

SRAM_EXEC_MODE.enable is set by the stack-less handover assembly (rom_handover_jump.S) immediately before the jalr to mutable firmware, after SRAM write-lock regions have already been committed. This minimises the window between enabling SRAM execution and the first fetch from SRAM. The bit is write-1-only and cleared by warm reset, so the ROM-only whitelist is re-applied on every boot cycle.

ROM Lockout

Setting SRAM_EXEC_MODE.enable exchanges the ROM for write-locked SRAM rather than adding to the whitelist. Were it purely additive, mutable firmware would inherit read and fetch access to the ROM that handed control to it, leaving the ROM's key-management routines and its rom_persist structure reachable by code the ROM does not trust.

The exchange is staged so that the handover can complete. Writing the bit only **arms** the lockout; the lockout **engages** on the first committed instruction fetch from a write-locked SRAM address, which is the point at which mutable firmware actually begins executing. Everything the handover assembly runs after its arming store — the store itself, the register clears, the jalr — is ROM code, and remains legal precisely because the lockout has not engaged yet. Engaging on a fetch rather than on any ROM access also keeps the rule independent of incidental data traffic: ROM code reads rom_persist, which itself lives in a write-locked SRAM region.

Once engaged, the lockout blocks ROM instruction fetches and ROM data reads until the next warm or cold reset. The latch is in the warm reset domain, the same domain as SRAM_EXEC_MODE.enable, so the transition is one-way within a boot and every reset that re-enters ROM restores ROM access. ROM **writes** are unaffected and continue to raise ROM_WRITE_ERR.

Blocked access behaviour. A blocked access returns zeros; ROM content is never delivered. What follows depends on the access type:

- A blocked **data read** raises ROM_ACCESS_VIOLATION and nothing else. Zero is a legitimate data value, so no decode and no trap occur.
- A blocked **instruction fetch** raises ROM_ACCESS_VIOLATION and additionally feeds an all-zeros instruction stream, which the PicoRV32 CATCH_ILLINSN logic traps as an illegal instruction.

The two reports are ordered by causality rather than by arbitration. The violation is combinational in the cycle of the blocked access, whereas the illegal instruction cannot be detected until the zero word has been returned and decoded, which is strictly later. Since IRQ_STATUS is sticky, the violation bit is always recorded first.

Which mechanism **acts** depends on the interrupt mask, and after handover only one does. Handover leaves all CPU interrupts masked, so the illegal instruction takes the PicoRV32 trap state rather than an interrupt: the core halts, unrecoverable_err_o asserts, and the KPV is wiped. The ROM_ACCESS_VIOLATION interrupt is inert in that state — it sets its sticky bit but has nowhere to vector, because the ROM ISR it would have vectored to is itself in the ROM the lockout has just revoked. A real post-handover breach therefore halts the KM without emitting a mailbox fault code; ROM_KM_UFAULT_ROM_ACCESS is reportable only while the ROM is still live (via IRQ_SET) or through a vector that mutable firmware installed itself.

Both mechanisms are retained because they do different jobs. The violation bit is the diagnostic that distinguishes a lockout breach from any other illegal-instruction halt; the trap is the containment, and it requires no firmware cooperation, no enabled interrupt, and no reachable handler.

Error Events

Unrecoverable Faults

These events cause the CPU to halt when the corresponding interrupt is unmasked and the ISR determines recovery is not possible. They include, but are not limited to, the following conditions:

- CPU trap events
- ROM or SRAM parity errors
- Invalid writes to ROM or SRAM

- AXI bus faults (SLVERR or DECERR)
- Instruction fetch from a non-whitelisted (non-executable) memory region
- ROM instruction fetch or data read after the ROM lockout engaged
- Any other unhandled exception or fault

The PicoRV32 includes a trap state that asserts a trap signal. When the CPU enters this state execution halts. The CPU will enter this state under the following conditions:

- An EBREAK or other illegal instruction is encountered *and* the associated interrupt is masked.
- The CPU encounters a misaligned access *and* the associated interrupt is masked.
- An EBREAK or other illegal instruction is encountered within an ISR.

If an ISR determines that an error event is not recoverable, it will call the EBREAK instruction to trap and halt the core. The CPU trap signal is passed out of KM to indicate an unrecoverable fault. This signal indicates the KM has encountered an unrecoverable fault and is no longer executing (it will not respond to further commands). The signal remains asserted for as long as the KM remains in the trap state. The trap is cleared by resetting the KM CPU — either a cold reset or a warm reset (the PicoRV32 core is in the warm reset domain) restarts the core and clears this signal.

Recoverable Faults

These events do not cause the CPU to halt. They include:

- Receiving corrupt or malformed command messages.
- Detection of possible tampering or attack conditions that are not immediately terminal.
- Any one of the previously listed error interrupts from which the corresponding ISR is able to gracefully recover.

The KM provides an output signal that indicates when a recoverable fault has been successfully handled. This signal is driven by a dedicated register bit in the KMCSR. When an ISR recovers gracefully from an error, it sets this register bit. The bit remains set until the SEP sends a firmware command to the KM to clear it (KM firmware clears the register bit in response to that command).

2.1.5.11.12.1.13. DRBG Sampler

The sampler bridges a CPU `DATA` read to the selected 32-bit entropy stream. It is an AXI4-Stream sink: `TREADY` is an output, and `TVALID`, `TDATA[31:0]` and `TSTRB[3:0]` are inputs. Availability is not guaranteed; a pending read waits for a word or an enabled timeout.

2.1.5.11.12.1.13.1. Reads, prefetch and register access

A `DATA` read consumes a prefetched word if one is available. Otherwise the sampler asserts `TREADY` and assembles four valid bytes before completing the AXI read. `TSTRB` selects bytes to pack in beat order, walking lanes 0 through 3; partial beats require further handshakes. Bytes beyond the four needed for the current word are not carried into the next word.

`CFG.PREFETCH` enables a single prefetched word. Consuming it through `DATA` invalidates it; prefetch alone does not increment the direct-read success counter. Disabling prefetch clears its data/valid state. The read-only `PREFETCH_DATA` register exposes the stored word for debugging and does not consume it, so repeated debug reads are not fresh random samples.

Table 381. DRBG sampler register behavior

Register or field	Access and meaning
DATA	Read obtains a sample; writes return SLVERR.
CFG.PREFETCH[0]	Read/write; reset 0 (disabled).
CFG.TIMEOUT[31:16]	Read/write active-read wait budget in clocks; reset 256. The counter loads TIMEOUT - 1 and times out after exactly TIMEOUT active cycles. Zero disables timeout. Background prefetch has no timeout.
STATUS.DRBG_READY[0]	Read-only indication of input TVALID.
STATUS.PREFETCHED[1]	Read-only indication that a prefetched word is available.
STATUS.TIMEOUT_ERR[2]	Sticky timeout indication; write one to clear.
STATUS.STREAM_ERR[3]	Sticky stream-protocol error; write one to clear.
STATUS.COUNT_BAD[15:8]	Timeout/stream-error count, saturating at 0xFF. Write nonzero to clear; zero has no effect.
STATUS.COUNT_GOOD[31:16]	Counts only reads completed through ST_RESPOND, excluding prefetched words, saturating at 0xFFFF. Write nonzero to clear; zero has no effect.
PREFETCH_DATA	Read-only debug view; writes return SLVERR.

Because prefetched reads bypass ST_RESPOND, COUNT_GOOD is not a total of all DATA reads when prefetch is enabled.

2.1.5.11.12.1.13.2. Errors and reset

Timeout completes an active read with SLVERR and zero data. The protocol monitor detects a different event: previous-cycle TVALID=1, TREADY=0, followed by TVALID=0 (withdrawal before handshake). It sets STREAM_ERR, increments COUNT_BAD and pulses the KMCSR DRBG error source even when no read is active. If the active FSM is requesting or assembling a word, it also returns SLVERR with zero data. A prefetch in progress is discarded. A TVALID drop after a completed handshake is not this violation.

The sampler is in the KM warm-reset domain, not the TRNG reset domain. Quiesce KM before resetting the TRNG. Resetting the producer alone can withdraw an unaccepted beat or interrupt byte assembly; it does not clear partial bytes held by the sampler. Holding KM in software reset clears sampler control/assembly state before the source restarts.

Warm or cold KM reset restores configuration defaults, counters, error bits, valid flags and request/assembly control. Data registers (prefetch data, assembly storage and the response slot) have no reset value; invalidating their control state is not a guaranteed data scrub.

Table 382. Key Manager DRBG sampler states

State	Active DATA-read behavior
ST_IDLE	Returns an available prefetch without entering ST_RESPOND; otherwise enters ST_REQUEST for a pending read.
ST_REQUEST	Asserts TREADY. A full word advances to ST_RESPOND; partial data advances to ST_BYTE_ASSEMBLY.
ST_BYTE_ASSEMBLY	Keeps TREADY asserted and packs valid bytes until four are available.
ST_RESPOND	Completes the assembled read with OKAY and increments COUNT_GOOD; returns to idle.
ST_TIMEOUT	Completes with SLVERR and zero data after the active wait budget expires; returns to idle.
ST_STREAM_ERR	Completes with SLVERR and zero data after a detected withdrawal during request/assembly; returns to idle.

A separate prefetch FSM uses the request/assembly states. It accepts beats only when there is no active CPU DATA read. In the active request/assembly states, a stream error takes priority over timeout, and timeout takes priority over accepting a completing beat.

2.1.5.11.12.1.14. OTP Inputs and Readout

The KM consumes OTP-derived material over a private hardwired bundle so the values cannot be spoofed by software. SEP dual-rail-encodes each 256-bit field at the SEP-to-KM boundary (`{~value, value}`) from the sensed eFuse shadow:

- the fuse-provisioned secrets — `CHIPLET_UID`, `SIP_UID`, `SYS_UID`, `CLASS_KEY`;
- the three 256-bit public identities — `SEP_CHIPLET_ID`, `SEP_SIP_ID`, `SEP_SYS_ID` — one per owner;
- the life-cycle state.

UID delivery and protection. The UIDs are held in a KM-local copy. The KM's own warm-domain read-lock protects that copy at mutable-firmware handover (see UID provisioning and access) so mutable firmware cannot read it. This KM-local lock is separate from, and additional to, the eFuse controller's own locks.

Public identity delivery. The three public identity fuses take the same dual-rail encode as the secrets. They remain on the KM port in secure test mode: the eFuse controller blanks only the four secrets on the hardware shadow output. The eFuse per-field read-lock bits (`LOCKS[59]`, `[61]`, `[63]`) hide software and JTAG shadow reads; they do not blank the hardwired KM port. The KM's own `OTP_READ_LOCK` and `OTP_READ_LOCK_COLD` bits zero the KMCSR readout words only.

Life-cycle state. The life-cycle state is hardwired into the KM as authoritative, software-readable status. Being non-secret it is neither locked nor wiped. The key registry does not bind keys to it.

eFuse access path. The KM also has a programmatic (AXI-Lite) path to the eFuse controller — for example to request a read or a program operation. That path is treated exactly like a system-host access: same access filtering, and it honors the eFuse controller's native per-field read/write locks, so the KM gains no read privilege over the fuse array beyond the SEP host's.

Demotion and PCR. The owner demotion state is hardwired from the Life Cycle Controller (LCC). A PCR Vault (PCRV) and PCR-change interrupt are not present in this integration.

KMCSR readout registers. The OTP-derived fields above are exposed to KM firmware in the KMCSR region as hardware-driven, read-only registers. Each field is delivered to the KMCSR as dual-rail complementary values (`{~value, value}`) and decoded within the KMCSR, which continuously verifies the complement relationship.

Table 383 lists the OTP-derived fields exposed to Key Manager firmware.

Table 383. Key Manager OTP readout registers

Register	Width	Contents
`OTP_LIFE_CYCLE`	8-bit	Differential-encoded life-cycle state `{~lc[3:0], lc[3:0]}`.
`OTP_DEMOTION_STATE`	4-bit	Two 1-bit demotion flags, each differentially encoded into 2 bits: `{demote_2[1:0], demote_1[1:0]}`.
`OTP_CHIPLET_UID_VAL/CPL_0..7`	8 × 32-bit	256-bit CHIPLET_UID dual-rail words.
`OTP_SIP_UID_VAL/CPL_0..7`	8 × 32-bit	256-bit SIP_UID dual-rail words.
`OTP_SYS_UID_VAL/CPL_0..7`	8 × 32-bit	256-bit SYS_UID dual-rail words.
`OTP_CLASS_KEY_VAL/CPL_0..7`	8 × 32-bit	256-bit CLASS_KEY dual-rail words.
`OTP_SEP_CHIPLET_ID_VAL/CPL_0..7`	8 × 32-bit	256-bit SEP_CHIPLET_ID dual-rail words.
`OTP_SEP_SIP_ID_VAL/CPL_0..7`	8 × 32-bit	256-bit SEP_SIP_ID dual-rail words.
`OTP_SEP_SYS_ID_VAL/CPL_0..7`	8 × 32-bit	256-bit SEP_SYS_ID dual-rail words.
`OTP_READ_LOCK`	9-bit	Write-one-to-set read-lock bits (warm reset domain), one per field. Cleared by warm or cold reset.

Register	Width	Contents
OTP_READ_LOCK_COLD	9-bit	Write-one-to-set read-lock bits (cold reset domain), one per field. Survives warm reset; cleared only by cold reset. Effective lock = OTP_READ_LOCK | OTP_READ_LOCK_COLD.
OTP_CHANGE_STATUS	9-bit	Sticky write-1-to-clear flags: set when a monitored field's decoded value changes.

Dual-rail integrity. The hardware continuously checks that each value word is the bitwise inverse of its complement word. Any violation raises the OTP_SIGINT interrupt, which ROM firmware treats as an unrecoverable fault. This applies to the public identity fields as much as to the secrets.

Change detection. When a monitored field's decoded value changes, the hardware sets the corresponding OTP_CHANGE_STATUS bit and raises the OTP_CHANGE interrupt. ROM firmware reads the status, invokes an overridable change hook, and clears the flag. Spurious change events are suppressed until the capture history is valid after cold or warm reset.

Unique Identifiers (UID) — provisioning and access

The KM receives three fuse-provisioned Unique Identifiers — CHIPLET_UID, SIP_UID, and SYS_UID (256 bits each) — provisioned respectively by the chiplet creator, the SiP owner, and the system owner. ROM does not derive keys from them.

The CPU services mailbox commands from ROM and supports loading and executing SRAM firmware. Before handing control to that firmware, ROM applies the OTP read locks and wipes secrets from the shared execution environment. A warm reset returns the CPU to ROM, where the handover protections are re-established.

Concretely, this safeguard is the OTP_READ_LOCK register: one write-one-to-set bit per OTP readout field (life-cycle, demotion, the four 256-bit secrets, and the three 256-bit public identities). Setting a bit causes the hardware to return zero for that field's value and complement words. ROM applies the lock using a triple-write convention (three consecutive writes) so it commits even under a single-bit glitch. OTP_CHANGE_STATUS shares the same warm reset domain for the same reasons.

ROM does not lock the public identity fields at handover, since concealing them buys nothing. Their lock bits suppress KMCSR readback like those of the secret fields.

A parallel **cold-reset-domain** register, OTP_READ_LOCK_COLD, provides the same write-one-to-set, per-field locking semantics but survives warm reset (including soft reset) and is cleared only by cold reset. The effective read-lock for each field is the OR of the corresponding bits in OTP_READ_LOCK and OTP_READ_LOCK_COLD; either register alone is sufficient to suppress CSR readback. The SEP host can set cold-domain lock bits at any time by issuing CMD_OTP_READ_LOCK_COLD (0x28) over the KM mailbox. This allows the SEP host to establish read-locks that persist across warm resets for the entire duration of a power cycle, independently of the warm-reset lock applied by ROM firmware.

2.1.5.11.12.1.15. CRC Accelerator

The KM CPU is fitted with a CRC accelerator attached through the PicoRV32 PCPI (Pico Co-Processor Interface). It provides hardware versions of the CRC functions the firmware uses on its high-value integrity paths — message header CRC-8/ROHC, message payload CRC-32C, and key-data integrity CRC-32C — so these computations consume far less CPU time than a software loop. The accelerator is always present in the KM build; firmware invokes it unconditionally and does not retain a software fallback path.

The accelerator exposes three R-type custom instructions on the PicoRV32 custom0 opcode. Each instruction takes two operands — the current CRC chaining state (rs1) and the next input unit (rs2) — and writes the updated chaining state to rd.

Table 384 lists the instruction encodings and input units for the hardware CRC updates.

Table 384. CRC Accelerator Instructions

Instruction	funct7	funct3	opcode	Input unit
CRC-32C word update	7'b0101100	3'b000	custom0	rs2[31:0], four bytes little-endian
CRC-32C byte update	7'b0101100	3'b001	custom0	rs2[7:0] (rs2[31:8] ignored)
CRC-8/ROHC byte update	7'b0101100	3'b010	custom0	rs2[7:0] (rs2[31:8] ignored)

Behavioral properties:

- The CRC-32C word-update instruction consumes its 32-bit operand as four bytes in little-endian order ([7:0], [15:8], [23:16], [31:24]).
- The CRC-32C instructions expose the internal running remainder **before** the final XOR. Firmware seeds the chaining state with 0xFFFF_FFFF and applies the final XOR only when it needs the externally visible CRC value, so word updates, byte updates, and intermediate states chain freely.
- For non-word-sized buffers, firmware processes whole words with the word-update instruction and any remaining 1–3 tail bytes with the byte-update instruction; no software tail path is used.
- The CRC-8/ROHC instruction carries its 8-bit state in rd[7:0] and zero-extends rd[31:8].
- Empty-input results are identical to the software definitions: with no input units consumed, the seeded state (after the firmware's final XOR for CRC-32C) is the empty-input CRC.

The three instructions share a single byte-update datapath. CRC-32C word mode runs four byte-update cycles per operation; the two byte modes run one cycle each. The datapath uses reflected CRC update behavior with the reflected polynomial 0x82F6_3B78 for CRC-32C and 0x0000_00E0 for CRC-8/ROHC (the reflection of the 0x07 CRC-8/ROHC polynomial), and never applies the CRC-32C final XOR. The CRC parameter definitions (init, reflection, and final XOR) are given in the firmware CRC function library documentation.

Any other encoding in the custom0 CRC instruction family is not recognized by the accelerator: it does not assert the PCPI ready/wait/write handshakes, so PicoRV32's normal illegal-instruction handling is preserved. The feature introduces no new top-level KM ports or CSRs, and the PicoRV32 built-in multiply/divide support remains enabled and unchanged.

2.1.5.11.12.1.16. ROM and SRAM Error Detection

ROM and SRAM use one odd-parity bit per byte: four parity bits accompany each 32-bit data word. Checking cannot be disabled and performs no correction. Interrupt enables control reporting to the CPU; masking an event does not repair the affected data or make it safe to use.

2.1.5.11.12.1.17. Parity Error Protection

Parity bits are stored out-of-band, outside the scrambled data word. This keeps parity storage separate from the scramble/descramble data path.

2.1.5.11.12.1.18. SRAM Write Locking

The SRAM interface incorporates a write-locking mechanism to designate specific 1 KB memory regions as read-only; 32 regions cover the whole 32 KB SRAM, one per SRAM_LOCK bit. This feature is primarily designed to protect dynamically loaded KM firmware from unauthorized modification.

Control of this functionality resides within the Key Manager Control and Status Registers (KMCSR). Once a memory region is locked, it cannot be unlocked within the current boot session. It will remain in the read-only state until the

next warm or cold reset of the KM. The write-lock state is in the warm reset domain and is cleared on every warm or cold reset.

Protection across warm resets is maintained by the ROM, which is responsible for re-applying the full write-lock policy on every boot (both cold and warm) before handing control to mutable firmware. Because the KM CPU always re-enters ROM after a warm reset, mutable firmware never executes against an unlocked SRAM region.

2.1.5.11.12.1.19. ROM Warm-Persistent SRAM Region

The highest 1 KB of KM SRAM (region 31, `0x0000_FC00`–`0x0000_FFFF`) are reserved as a ROM-managed warm-persistent data structure (`rom_persist`). The mutable-firmware load area, stack, and BSS/data occupy the SRAM below it.

This region is owned exclusively by ROM firmware: it holds ROM state that must survive warm reset and is not general-purpose scratch for mutable (SRAM-loaded) firmware. Mutable firmware must not place its own data here, and once ROM write-locks the region it cannot write it at all (see **Write-lock policy** below).

SRAM contents survive warm or soft reset. Reset of the memory interface does not itself specify an array erase. ROM carries state across warm resets and initializes this structure on cold boot; this is volatile SRAM retention, not non-volatile storage.

Cold initialization. On every cold boot, `rom_boot_init()` detects a cold boot via the `COLD_BOOT_DONE` flag (reads 0 before it is set at the end of boot) and calls `rom_persist_cold_init()`, which writes known-zero values to all fields. On a warm or soft reset, `COLD_BOOT_DONE` already reads 1 and `rom_persist_cold_init()` is skipped, preserving the contents of the region.

Contents. The `rom_persist_t` structure currently contains one field (Table 385).

Table 385. Key Manager warm-persistent SRAM contents

Field	Type	Description
`sram_fw_size`	`uint32_t`	Byte count of the mutable firmware image currently loaded in SRAM (`FW_WORDS x 4`). Zero means no mutable firmware is present. Written by `CMD_SRAM_LOAD_EXEC` on a successful load and verified by `CMD_SRAM_EXEC` before jumping.

Write-lock policy. Before handing control to mutable (SRAM-loaded) firmware, ROM must call `rom_persist_lock()`, which sets SRAM_LOCK bit 31 via a triple write for glitch resistance. After locking, any write into `0xFC00`–`0xFFFF` is silently dropped and a `SRAM_WRITE_LOCK_VIOLATION` IRQ is raised. The lock is cleared on the next warm or cold reset; ROM re-establishes it before transferring control to mutable code.

2.1.5.11.12.1.20. Mutable Firmware Model

The KM ROM can load a mutable image into SRAM and hand control to it, through the `CMD_SRAM_LOAD_EXEC` and `CMD_SRAM_EXEC` mailbox commands. The image is loaded at `0x8000`, which is also its entry point, and must fit below a static load ceiling aligned to a 1 KB write-lock region, so the image never shares a region with the ROM stack or data. The load bounds, the key shred, the KPV read-lock, the image write-lock, the mailbox flush, the SRAM scramble and the jump are ROM behaviour, defined in the SRAM Firmware Handover sequence of the Key Manager Application ROM appendix in the Programmer's Guide.

The handover relies on the following hardware behaviour:

- `SRAM_LOCK` is in the warm-reset domain. A warm reset clears the image write-lock, and ROM re-applies it before every handover, including a `CMD_SRAM_EXEC` restart.
- `IRQ_ENTRY_ADDR` and `IRQ_ENTRY_LOCK` are warm-reset-domain registers. Every reset that re-enters ROM (cold, external warm, and KM soft reset) restores the vector to the ROM default (`0x10`) and clears the lock, so ROM never executes

with a vector chosen by mutable firmware.

- KPV key data has no warm reset and is descrambled on KM-port reads. `lock_use` is independent of `lock_write` and makes KM-port key reads return zero.
- The crypto-engine sideload key registers lie outside the SRAM address space, so scrambling SRAM does not reach them.
- Writes to a write-locked SRAM region are dropped and raise `SRAM_WRITE_LOCK_VIOLATION`, which is sticky until cleared.

2.1.5.11.12.1.21. SRAM Scrambling

Both the address as well as data can optionally be scrambled. The goal of the scrambler is not secure data encryption but rather basic obfuscation to impede simple memory dumping by an attacker aiming to recover secrets. The algorithm would be straight forward to break by a trained cryptanalyst. The implementation is intentionally very simple so that the timing overhead on memory read and write transactions is minimal.

The scrambler is disabled by default, but a configuration register field can be set to turn this feature on after booting and the scrambling key is installed. When it is on, all write data transactions will have both the address and data scrambled before performing a write to memory. On read operations, the address will be scrambled in the same fashion as for writes so we have an equivalent address mapping. The read data however must be descrambled. Address data tweaks the key, which means it is mixed in to ensure that the same data at different address locations has a different scrambled value.

The KM ROM writes DRBG output into the key register and then enables and locks the scrambler; the Memory Scrambler Provisioning section of the Key Manager Application ROM appendix in the Programmer's Guide gives the order.

The scrambler IP consists of a generic top-level module (`scrambler`) and a set of pre-configured size-specific wrappers that fix the address width to match a particular SRAM depth. The generic module selects the correct address scrambling function at elaboration time through generate blocks keyed on `ADDR_WIDTH`. The `scrambler_addr_tweak` submodule expands and mixes the memory address into a 32-bit round key. All cryptographic primitives (S-boxes, permutations, and address scramble functions) are declared as `automatic` functions in `scrambler_pkg`.

2.1.5.11.12.1.21.1. Parameters

The scrambler module accepts three parameters. Only 32-bit data widths are supported in the current implementation.

The parameters and ports of `scrambler` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.5.11.12.1.21.2. Port Interface

The scrambler is purely combinational. It has no clock or reset ports.

2.1.5.11.12.1.21.3. Data Scrambling Algorithm

The scrambling algorithm is an extremely rudimentary, round reduced, block cipher inspired by the PRESENT cipher. PRESENT works on 64 bit blocks, while this scrambler works on 32-bit blocks. PRESENT operates on 32 repeated rounds, while this scrambler performs only a single round. The player (permutation function) is also altered to accommodate the reduced block size i.e. word length.

The data path implements the PRESENT 4-bit S-box (`sbox4`) from `scrambler_pkg`. Eight parallel S-box instances process the 32-bit word one nibble at a time. The S-box mapping is shown in Table 386.

Table 386. SRAM scrambler S-box

x	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
S(x)	C	5	6	B	9	0	A	D	3	E	F	8	4	7	1	2

The inverse S-box (`ibox4`) reverses the mapping and is used on the descramble path.

The permutation layer follows the PRESENT structure with progressive offsets of 8 bits rather than 16. Index *i* indicates the input bit position and *P(i)* indicates the output bit position.

Table 387 maps input bits 31 through 16 to their output positions.

Table 387. SRAM scrambler permutation for bits 31 to 16

i	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
P(i)	0	4	8	12	16	20	24	28	1	5	9	13	17	21	25	29

Table 388 maps input bits 15 through 0 to their output positions.

Table 388. SRAM scrambler permutation for bits 15 to 0

i	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
P(i)	2	6	10	14	18	22	26	30	3	7	11	15	19	23	27	31

Scrambling Procedure

First the tweaked key is xor'ed with the input write data. The output is split into 8 4-bit nibble lanes and each is fed into an sbox function. The resulting values are concatenated and fed into the player permutation function to form the final scrambled data value which is written to memory.

Descrambling Procedure

The descrambling process is exactly the reverse as scrambling. The scrambled data value is read from memory and we first perform the iplayer inverse permutation operation. This is followed by inverse sbox functions applied to each 4-bit lane, with the outputs concatenated. This word is then xor'ed with the tweaked key to recover the unscrambled read data.

Address Tweaking:

```
Rkey = scrambler_key[31:0] ^ {addr[N-1:0] repeated to fill 32-bits}
```

Scrambling:

```
Write_data_sbi = Write_data ^ Rkey
Write_data_sb = {
    sbox(write_data_ak[31:28]),
    sbox(write_data_ak[27:24]),
    sbox(write_data_ak[23:20]),
    sbox(write_data_ak[19:16]),
    sbox(write_data_ak[15:12]),
    sbox(write_data_ak[11:8]),
```

```
    sbox(write_data_ak[7:4]),
    sbox(write_data_ak[3:0])}
Scrambled_write_data = player(Write_data_sb)
```

Descrambling:

```
Read_data_sbi = iplayer(Scrambled_read_data)
Read_data_sbo = {
    ibox(Read_data_sbi[31:28]),
    ibox(Read_data_sbi[27:24]),
    ibox(Read_data_sbi[23:20]),
    ibox(Read_data_sbi[19:16]),
    ibox(Read_data_sbi[15:12]),
    ibox(Read_data_sbi[11:8]),
    ibox(Read_data_sbi[7:4]),
    ibox(Read_data_sbi[3:0])}
Read_data = Read_data_sbo ^ Rkey
```

2.1.5.11.12.1.21.4. Address Tweaking

As previously mentioned, address tweaking is necessary so that the same data at different addresses scrambles to unique values. Tweaking is performed by simply xor mixing the address with the random scrambler key to form the round key. If the address is less than 32 bits wide, then we just repeatedly concatenate the address with itself until we have 32 bits, truncating any excess bits.

The `scrambler_addr_tweak` submodule implements this expansion. For power-of-two-aligned widths (8 and 16), the address is replicated exactly to fill 32 bits. For non-power-of-two widths, the address is concatenated three times and the upper portion of the third copy is truncated to produce exactly 32 bits. Table 389 lists the expansion formula used for each supported width.

Table 389. SRAM scrambler address expansion

ADDR_WIDTH	Expansion to 32 bits
8	`{addr, addr, addr, addr}`
9	`{addr, addr, addr, addr[8:4]}` (9+9+9+5 = 32)
10	`{addr, addr, addr, addr[9:8]}` (10+10+10+2 = 32)
11	`{addr, addr, addr[10:1]}` (11+11+10 = 32)
12	`{addr, addr, addr[11:4]}` (12+12+8 = 32)
13	`{addr, addr, addr[12:7]}` (13+13+6 = 32)
16	`{addr, addr}`
32	Identity (no expansion).

The expanded address is XORed with `scrambler_key_i` to produce the 32-bit `round_key_o`.

2.1.5.11.12.1.21.5. Address Scrambling

Address scrambling is done in a similar fashion as data scrambling with an arbitrary permutation function. The address

bits are first xor'ed with the key bits according to the address width. The result is then split into 3 or 4 bit lanes, and passed through one sbox per lane. Finally the sbox results are concatenated and fed through a linear permutation network. There is *no descrambling operation on the address*, only scrambling.

Each supported address width has a dedicated `addr_scrambleN` function in `scrambler_pkg`. These functions partition the address-key-XOR result into lanes of 3 or 4 bits, apply `sbox3` (Pyjamask) or `sbox4` (PRESENT) to each lane, concatenate the S-box outputs, and pass the result through the corresponding `permN` fixed permutation. The lane partitioning varies by width to ensure the full address is covered without padding.

Table 390 identifies the S-box lanes and permutation used at each address width.

Table 390. SRAM scrambler address lanes

Width	S-box Lane Partition	S-box Types	Permutation
6	`[5:3], [2:0]`	`sbox3`, `sbox3`	`perm6`
7	`[6:3], [2:0]`	`sbox4`, `sbox3`	`perm7`
8	`[7:4], [3:0]`	`sbox4`, `sbox4`	`perm8`
9	`[8:6], [5:3], [2:0]`	`sbox3` x3	`perm9`
10	`[9:6], [5:3], [2:0]`	`sbox4`, `sbox3` x2	`perm10`
11	`[10:8], [7:4], [3:0]`	`sbox3`, `sbox4` x2	`perm11`
12	`[11:8], [7:4], [3:0]`	`sbox4` x3	`perm12`
13	`[12:9], [8:6], [5:3], [2:0]`	`sbox4`, `sbox3` x3	`perm13`

2.1.5.11.12.1.21.6. Byte-Wise Scrambling Mode

When the `BYTE_WISE` parameter is set to 1, the permutation layer operates on each byte independently rather than across the full 32-bit word. On the write path, the eight S-box outputs are grouped into four byte lanes and each lane is permuted with `perm8`. On the read path, `iperm8` is applied per byte lane before the inverse S-box stage. The S-box and round-key XOR stages are identical regardless of the `BYTE_WISE` setting.

This mode is used in the Key Manager SRAM interface where byte-level write strobes require that scrambling of one byte lane does not depend on data in other lanes.

2.1.5.11.12.1.21.7. Instantiation Variants

Five pre-configured modules are provided, each fixing the `ADDR_WIDTH` parameter for a specific SRAM depth. All variants default to `DATA_WIDTH` = 32 and `BYTE_WISE` = 0, though the `BYTE_WISE` parameter can be overridden at instantiation.

Table 391 relates each preconfigured module to its SRAM depth and address-scramble function.

Table 391. SRAM scrambler module variants

Module	ADDR_WIDTH	SRAM Depth	Address Scramble Function
`scrambler_512x32`	9	512 words	`addr_scramble9`
`scrambler_1024x32`	10	1024 words	`addr_scramble10`
`scrambler_2048x32`	11	2048 words	`addr_scramble11`
`scrambler_4096x32`	12	4096 words	`addr_scramble12`
`scrambler_8192x32`	13	8192 words	`addr_scramble13`

2.1.5.11.12.1.21.8. Integration in the Key Manager

The Key Manager SRAM interface (km_sram_interface) instantiates two scrambler_8192x32 instances with BYTE_WISE = 1, whose 13-bit address covers the 8192 words of the 32 KiB SRAM. The first instance (u_req_scrambler) scrambles the write data and address on the request path. The second instance (u_rsp_descrambler) descrambles read data on the response path using the address captured when the SRAM accepts the read.

The scrambler is controlled through the SCRAMBLER_KEY and SCRAMBLER_CTRL registers in the Key Manager CSR block (km_csr). The SCRAMBLER_CTRL register has two fields: enable at bit 0 and lock at bit 1. When lock is written to 1, the transition is permanent until the next reset. Once locked, the key register reads as zero, writes to it are ignored, and the scrambler is forced into the enabled state. This prevents firmware from disabling scrambling or reading back the key after provisioning.

A bypass multiplexer gates the scrambled data path. When scrambler_en_i is deasserted, addresses and data pass through unmodified. Parity is always computed on the plaintext data before scrambling, ensuring that the parity check on the read path operates on the descrambled value.

Figure 48 shows the address and data scrambling paths at the SRAM interface.




Figure 48. SRAM scrambler datapath

Inputs enter on the left and the memory side is on the right. The write path runs left to right along the middle row and the read path right to left along the bottom row. Both paths use the same round_key from u_addr_tweak, so the read path must be given the address the read data was fetched from. BYTE_WISE selects between the whole-word permutations and the per-byte permutations shown in each permutation box. The enable multiplexer and the parity logic belong to the caller, not to scrambler.

The Key and Policy Vault (km_kpv) also instantiates scrambler_1024x32 (u_scrambler_km, BYTE_WISE = 0) in front of its key register file, keyed by the KPV's own scrambler key.

2.1.5.11.12.2. Firmware

The KM ROM and any mutable firmware it hands over to run on the PicoRV32. The Key Manager Application ROM appendix of the Programmer's Guide is the firmware reference: initialization, the mailbox command and response protocol, interrupt handling, key management and the SRAM handover rules.

2.1.5.11.12.3. Memory Map and Register Reference

2.1.5.11.12.3.1. Memory Map

The KM CPU addresses its internal peripherals through a flat 32-bit address space. The AXI4-Lite crossbar decodes the address and routes transactions to the corresponding slave port.

Every window except OTP/eFuse spans exactly the address bits its register block decodes, so no register is reachable from a second address. The last two columns of the map state how the crossbar and the register blocks answer an access that no register or memory backs, and Decode Response Codes defines them and their codes. The KM CPU does not see these responses: an error sets `AXI_SLVERR` or `AXI_DECERR` in the KMCSR `IRQ_STATUS` register.

The OTP/eFuse window is the exception: hardware preserves its lower 12 address bits and replaces the upper bits with the integration parameter `OTP_EFUSE_REMAP_BASE` before forwarding the transaction to SEP. Only the MAP, CTRL and MMR register maps are forwarded. The Key Manager answers any other offset in the window with SLVERR, so the KM CPU cannot reach the eFuse shim control registers.

Table 392. Key Manager CPU Memory Map

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x00000000	0x00003FFF	16 KiB	16 KiB	Key Manager ROM	Key Manager boot ROM	-[1]	-
0x00004000	0x00007FFF	16 KiB	16 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x00008000	0x0000FFFF	32 KiB	32 KiB	Key Manager SRAM	Key Manager data and executable SRAM	-	-
0x00010000	0x0001001F	32 B	28 B	Key Manager Mailbox KM Side	Register interface for KM CPU to access mailbox (write to outbound FIFO, read from inbound FIFO)	-	SLVERR, 0x0 / SLVERR
0x00010020	0x00010FFF	4064 B	4064 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x00011000	0x000113FF	1 KiB	1 KiB	SEP eFuse Map Address Map	SEP eFuse shadow-register pass-through.	Forwarded	-
0x00011400	0x000114FF	256 B	28 B	eFuse Interface Control Address Map	SEP eFuse command and status pass-through.	Forwarded	SLVERR, 0xBADCAB1E / SLVERR
0x00011500	0x000115FF	256 B	116 B	eFuse Token Registers Address Map	SEP eFuse security-token pass-through.	Forwarded	SLVERR, 0xBADCAB1E / SLVERR

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x00011600	0x00011FFF	2560 B	2560 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR[2]	-
0x00012000	0x00013FFF	8 KiB	4360 B	Key and Policy Vault (KM Port)	Key entry storage and KM control registers. Access conditioned by lock_write/lock_use.	-	SLVERR, 0x0 / SLVERR
0x00014000	0x000147FF	2 KiB	1216 B	Key Manager Control and Status Registers	Control and status registers for the Key Manager subsystem	SLVERR, 0x0 / SLVERR	SLVERR, 0x0 / SLVERR
0x00014800	0x00014FFF	2 KiB	2 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x00015000	0x0001500F	16 B	16 B	DRBG Sampler	DRBG random data interface and configuration/status registers	-	-
0x00015010	0x00017FFF	12272 B	12272 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x00018000	0x0001807F	128 B	100 B	OTBN Wrapper Key Registers	Key storage registers for the OTBN sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT OTBN core.	-	SLVERR, 0x0 / SLVERR
0x00018080	0x00018FFF	3968 B	3968 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x00019000	0x0001907F	128 B	68 B	AES Wrapper Key Registers	Key storage registers for the AES sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT AES core.	-	SLVERR, 0x0 / SLVERR
0x00019080	0x00019FFF	3968 B	3968 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x0001A000	0x0001A07F	128 B	68 B	KMAC Wrapper Key Registers	Key storage registers for the KMAC sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT KMAC core.	-	SLVERR, 0x0 / SLVERR
0x0001A080	0x0001AFFF	3968 B	3968 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x0001B000	0x0001B07F	128 B	68 B	HMAC Wrapper Key Registers	Key storage registers for the HMAC sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT HMAC core.	-	SLVERR, 0x0 / SLVERR
0x0001B080	0x0001BFFF	3968 B	3968 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x0001C000	0x0001C7FF	2 KiB	1068 B	Adams Bridge Key Sideload Registers	Single AXI4-Lite window for all KM sideload interfaces to Adams Bridge. Contains four dual-share secret-seed inputs and one shared-key output.	SLVERR, 0x0 / SLVERR	SLVERR, 0x0 / SLVERR
0x0001C800	0x0001CFFF	2 KiB	2 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-

Notes

[1] A write completes without an error response, is dropped, and sets IRQ_STATUS.ROM_WRITE_ERR.
[2] This range is inside the OTP/eFuse window, which answers every offset outside its register maps with SLVERR and read data 0xBADCAB1E rather than DECERR.

2.1.5.11.12.3.2. Detailed Register Map

2.1.5.11.12.3.2.1. Address Summary Registers

2.1.5.11.12.3.2.1.1. Key Manager Top-Level Address Map

Complete memory map for the Key Manager subsystem, including ROM, SRAM, control/status registers, mailbox, and external crypto engine ports. This address map is from the perspective of the KM CPU (PicoRV32).

NOTE **Register Arrays:**

- **RMA_SIP_TOKEN_I[8]**: 8 registers, base 0x11500, stride 0x4
- **RMA_CHIPLET_TOKEN_I[8]**: 8 registers, base 0x11520, stride 0x4
- **SEC_DISABLE_TOKEN_I[8]**: 8 registers, base 0x11540, stride 0x4
- **KEY_ENTRY[64].WORD[16]**: 1024 registers, base 0x12000 (KEY_ENTRY x64 stride 0x40, WORD x16 stride 0x4)
- **CTRL[64]**: 64 registers, base 0x13000, stride 0x4
- **KEY_SHARE0[12]**: 12 registers, base 0x18000, stride 0x4
- **KEY_SHARE1[12]**: 12 registers, base 0x18030, stride 0x4
- **aes_wrapper_key.KEY_SHARE0[8]**: 8 registers, base 0x19000, stride 0x4
- **aes_wrapper_key.KEY_SHARE1[8]**: 8 registers, base 0x19020, stride 0x4
- **kmac_wrapper_key.KEY_SHARE0[8]**: 8 registers, base 0x1A000, stride 0x4
- **kmac_wrapper_key.KEY_SHARE1[8]**: 8 registers, base 0x1A020, stride 0x4
- **hmac_wrapper_key.KEY_SHARE0[8]**: 8 registers, base 0x1B000, stride 0x4
- **hmac_wrapper_key.KEY_SHARE1[8]**: 8 registers, base 0x1B020, stride 0x4
- **abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8]**: 8 registers, base 0x1C000, stride 0x4
- **abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8]**: 8 registers, base 0x1C020, stride 0x4
- **abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8]**: 8 registers, base 0x1C100, stride 0x4
- **abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8]**: 8 registers, base 0x1C120, stride 0x4
- **abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8]**: 8 registers, base 0x1C200, stride 0x4
- **abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8]**: 8 registers, base 0x1C220, stride 0x4
- **abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8]**: 8 registers, base 0x1C300, stride 0x4
- **abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8]**: 8 registers, base 0x1C320, stride 0x4
- **KEY[8]**: 8 registers, base 0x1C400, stride 0x4

Table 393. Key Manager Top-Level Address Map register list

Address	Name	Access	Description
0x10000	KM_WRITE_DATA	W	Write data to outbound FIFO (KM→SEP messages)
0x10004	KM_WRITE_SEPARATOR	RW	Write 1 to set message separator on next outbound (KM→SEP) write. Cleared by hardware when that write completes.
0x10008	KM_READ_DATA	R	Read data from inbound FIFO (SEP→KM messages)
0x1000C	KM_STATUS	RW	FIFO status information
0x10010	KM_IRQ_STATUS	RW	Interrupt status register
0x10014	KM_IRQ_ENABLE	RW	Interrupt enable register for KM CPU
0x10018	KM_CTRL	RW	Control register for mailbox behavior configuration
0x11000	LOCKS	RW	-
0x11008	LOCKS_SPARE	RW	-
0x1100C	LC_STATE	R	-
0x11010	SBOOT_DIS	R	-
0x11014	TRANSIENT_RMA_EN	R	-

Address	Name	Access	Description
0x11018	SIP_DIS	RW	An owner's feature control vector. When set (1'b1), the corresponding feature is disabled. Layout: see the Disable Vector Format section of lifecycle_controller.adoc.
0x11020	SYS_DIS	RW	An owner's feature control vector. When set (1'b1), the corresponding feature is disabled. Layout: see the Disable Vector Format section of lifecycle_controller.adoc.
0x11028	RMA_SIP_TOKEN_DIGEST	R	-
0x11048	RMA_CHIPLET_TOKEN_DIGEST	R	-
0x11068	CLASS_KEY	R	-
0x11088	CHIPLET_PUBK_REVOKE	R	-
0x1108C	BL1_VERSION	R	-
0x110AC	BL2_VERSION	R	-
0x110CC	CHIPLET_UID	R	-
0x110EC	SIP_PUBK_HASH0	R	-
0x1110C	SIP_UID	R	-
0x1112C	SYS_PUBK_HASH	R	-
0x1114C	SYS_UID	R	-
0x1116C	STATUS_RPT	R	-
0x11170	ROM_CTL	R	-
0x11174	SYSCLK_FREQ_MHZ	R	-
0x11178	CHIPLET_PUBK_HASH0	R	-
0x11198	CHIPLET_PUBK_HASH1	R	-
0x111B8	REQUIRED_SIGNERS	RW	-
0x111BC	REQUIRED_ALGS	RW	-
0x111C0	CHIPLET_PUBK_PQC_HASH0	R	-
0x111E0	CHIPLET_PUBK_PQC_HASH1	R	-
0x11200	SIP_PUBK_PQC_HASH0	R	-
0x11220	SYS_PUBK_PQC_HASH	R	-
0x11240	SIP_PUBK_HASH1	R	-
0x11260	SIP_PUBK_PQC_HASH1	R	-
0x11280	SEP_CHIPLET_ID	R	-
0x112A0	SEP_SIP_ID	R	-
0x112C0	SEP_SYS_ID	R	-
0x112E0	spare0	R	-
0x11300	spare1	R	-
0x11320	spare2	R	-
0x11340	spare3	R	-
0x11360	spare4	R	-
0x11380	spare5	R	-
0x113A0	spare6	R	-
0x113C0	spare7	R	-
0x113E0	spare8	R	-

Address	Name	Access	Description
0x11400	EFUSE_INTERFACE_CTRL_STATUS	RW	eFuse interface status and error-clear register. Reports the sense-done flag and request/address error conditions, and provides write-1 strobes to clear those errors.
0x11404	EFUSE_PROGRAM_CTRL	RW	eFuse program control and status. Configures the program address and data, triggers a program (optionally with read-back), and reports program progress and completion status.
0x11408	EFUSE_READ_CTRL	RW	eFuse read control and status. Configures the read address, triggers a read, and reports read progress and completion status.
0x1140C	EFUSE_PROGRAM_INTERFACE_READ_DATA	R	Read data captured through the program interface. Hardware debug only; valid only while the program interface state machine is in its capture-data state.
0x11410	EFUSE_READ_INTERFACE_READ_DATA	R	Read data returned through the eFuse read interface.
0x11414	EFUSE_READ_REQ_TIMEOUT	RW	Read interface timeout configuration. Sets the number of cycles the read interface waits for a SHIM response and enables the read timeout.
0x11418	EFUSE_PROGRAM_REQ_TIMEOUT	RW	Program interface timeout configuration. Sets the number of cycles the program interface waits for a SHIM response and enables the program timeout.
0x11500 - 0x1151C	RMA_SIP_TOKEN_I[8]	RW	Software-writeable RMA token word. The assembled token is hashed and compared against the fused value to authorize lifecycle (LC) state transitions.
0x11520 - 0x1153C	RMA_CHIPLET_TOKEN_I[8]	RW	Software-writeable RMA token word. The assembled token is hashed and compared against the fused value to authorize lifecycle (LC) state transitions.
0x11540 - 0x1155C	SEC_DISABLE_TOKEN_I[8]	RW	Software-writeable security-disable token word. The assembled token is hashed and compared against the post-silicon injected value to authorize security_disable.
0x11560	TOKEN_EOP	W	Token end-of-packet control. Writing the per-token go bit signals that all token words have been written and triggers a pulse to begin token hashing.
0x11564	RMA_SIP_TOKEN_MATCH	R	Token match status. Reports the result of the token hash comparison (match, mismatch, or error).
0x11568	RMA_CHIPLET_TOKEN_MATCH	R	Token match status. Reports the result of the token hash comparison (match, mismatch, or error).
0x1156C	SEC_DISABLE_TOKEN_MATCH	R	Token match status. Reports the result of the token hash comparison (match, mismatch, or error).
0x11570	TOKEN_MATCH_FAULT	R	Token comparator redundancy fault status. The token match logic is triple redundant and is not a majority vote: all three comparators must agree and each must drive a legal differential pair. A bit sets when the comparators for that token disagree, which may indicate a fault injection or FIB attack. The corresponding token_match_status then reads the error code 6'b111111 and an interrupt is raised to the SEP CPU. Bits are sticky until reset.
0x12000 - 0x12FFC	KEY_ENTRY[64].WORD[16]	RW	One 32-bit word of a key entry (512-bit key = 16 words). No reset; powers up random.
0x13000 - 0x130FC	CTRL[64]	RW	Per-slot control: lock bits (W1S) and the erase trigger
0x13100	KPV_SCRAMBLER_KEY	RW	32-bit key for KPV key entry scrambling. No reset; powers up random. Locked when KPV_SCRAMBLER_CTRL.LOCK=1.
0x13104	KPV_SCRAMBLER_CTRL	RW	KPV scrambler enable and lock. Reset to 0 on KM reset. LOCK is write-one-only.
0x14000	VERSION	R	Hardware version register (semantic versioning: major.minor.patch)
0x14004	CTRL	R	Control register (reserved for future use)
0x14008	SOFT_RST_CODE	RW	Software reset code register. Write 0x53525354 ('SRST') to trigger soft reset. Any other value has no effect.

Address	Name	Access	Description
0x1400C	kmcsr.IRQ_STATUS	RW	Interrupt status register. Sticky bits cleared by writing 1.
0x14010	kmcsr.IRQ_ENABLE	RW	Interrupt enable/mask register
0x14014	SCRAMBLER_KEY	RW	32-bit scrambler key for SRAM address/data scrambling. When locked: writes ignored, reads return 0. No reset; powers up random.
0x14018	SCRAMBLER_CTRL	RW	Scrambler control register
0x1401C	SRAM_LOCK	RW	SRAM write-lock bits. Bit[i]=1 locks region i (1 KB each, 32 regions). Write-1-only: writing 1 sets the bit, writing 0 has no effect. Cleared by warm or cold reset (warm reset domain); ROM re-applies the lock policy on every boot before handover to mutable firmware.
0x14020	IRQ_SET	W	Interrupt set register. Write 1 to trigger corresponding interrupt (for ISR testing). Write-only, reads return 0.
0x14024	SRAM_WRITE_LOCK_VIOLATION	RW	Which SRAM region(s) had write attempts while locked. Bit[i]=region i. Sticky, write 1 to clear each bit.
0x14028	RECOVERABLE_ERR	RW	Recoverable error status. Firmware writes 1 to set (after recovering in ISR), writes 0 to clear (e.g. when SEP requests clear). Drives recoverable error event output.
0x1402C	BOOT_STATUS	RW	Boot status. Firmware writes 1 to COLD_BOOT_DONE after cold-boot init completes; bit remains set until next cold reset.
0x14030	OTP_LIFE_CYCLE	R	Life cycle state. 8-bit (4-bit value differentially encoded). Read-through from OTP port; no reset.
0x14034	OTP_DEMOTION_STATE	R	Demotion state. 2-bit, differentially encoded. Read-through from OTP port; no reset.
0x14038	SRAM_EXEC_MODE	RW	Execute-permission whitelist mode. Write-1-only (woset); cleared by warm or cold reset. 0=ROM executable; 1=write-locked SRAM regions executable, and the ROM lockout is armed. Set by ROM stack-less handover immediately before jumping to mutable firmware.
0x140B8	IRQ_ENTRY_ADDR	RW	Effective IRQ entry address for subsequent interrupts. Writable while unlocked; any 32-bit value accepted.
0x140BC	IRQ_ENTRY_LOCK	RW	Write-one-only lock for IRQ_ENTRY_ADDR. Separate readable register; cleared only on KM reset.
0x14100	VUART_TX	RW	Virtual UART transmit register. Write a byte to send to testbench. DATA_VALID is set on write and self-clears.
0x14104	VUART_RX	R	Virtual UART receive register. Testbench writes bytes here for firmware to read.
0x14108	VUART_STATUS	R	Virtual UART status register for flow control
0x14110	TB_RESULT	RW	Test result register. Firmware writes 0=fail, 1=pass.
0x14114	TB_SIGNATURE	RW	Test completion signature. Firmware writes 0x600D600D (pass) or 0xBADBADBA (fail).
0x14118	TB_ERRCODE	RW	Test error code register. Firmware writes optional error code for debugging.
0x1411C	TB_SUBTEST	RW	Current subtest number register. Firmware increments for each subtest.
0x14120	TB_CMD	RW	Testbench command register. Firmware writes command, testbench reads and clears.
0x14124	TB_CMD_ARG	RW	Testbench command argument register. Firmware writes optional argument.
0x14128	TB_CMD_STATUS	RW	Testbench command status register. Testbench writes status, firmware reads.
0x1412C	TB_CMD_RESULT	R	Testbench command result register. Testbench writes result value.
0x141FC	DEBUG	R	Debug register with known constant value for verification

Address	Name	Access	Description
0x14200	OTP_CHIPLET_UID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14204	OTP_CHIPLET_UID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14208	OTP_CHIPLET_UID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1420C	OTP_CHIPLET_UID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14210	OTP_CHIPLET_UID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14214	OTP_CHIPLET_UID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14218	OTP_CHIPLET_UID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1421C	OTP_CHIPLET_UID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14220	OTP_CHIPLET_UID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14224	OTP_CHIPLET_UID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14228	OTP_CHIPLET_UID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1422C	OTP_CHIPLET_UID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14230	OTP_CHIPLET_UID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14234	OTP_CHIPLET_UID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14238	OTP_CHIPLET_UID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1423C	OTP_CHIPLET_UID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14240	OTP_SIP_UID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14244	OTP_SIP_UID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x14248	OTP_SIP_UID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1424C	OTP_SIP_UID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14250	OTP_SIP_UID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14254	OTP_SIP_UID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14258	OTP_SIP_UID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1425C	OTP_SIP_UID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14260	OTP_SIP_UID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14264	OTP_SIP_UID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14268	OTP_SIP_UID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1426C	OTP_SIP_UID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14270	OTP_SIP_UID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14274	OTP_SIP_UID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14278	OTP_SIP_UID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1427C	OTP_SIP_UID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14280	OTP_SYS_UID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14284	OTP_SYS_UID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14288	OTP_SYS_UID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1428C	OTP_SYS_UID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x14290	OTP_SYS_UID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14294	OTP_SYS_UID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14298	OTP_SYS_UID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1429C	OTP_SYS_UID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142A0	OTP_SYS_UID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142A4	OTP_SYS_UID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142A8	OTP_SYS_UID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142AC	OTP_SYS_UID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142B0	OTP_SYS_UID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142B4	OTP_SYS_UID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142B8	OTP_SYS_UID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142BC	OTP_SYS_UID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142C0	OTP_CLASS_KEY_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142C4	OTP_CLASS_KEY_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142C8	OTP_CLASS_KEY_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142CC	OTP_CLASS_KEY_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142D0	OTP_CLASS_KEY_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142D4	OTP_CLASS_KEY_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x142D8	OTP_CLASS_KEY_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142DC	OTP_CLASS_KEY_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142E0	OTP_CLASS_KEY_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142E4	OTP_CLASS_KEY_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142E8	OTP_CLASS_KEY_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142EC	OTP_CLASS_KEY_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142F0	OTP_CLASS_KEY_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142F4	OTP_CLASS_KEY_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142F8	OTP_CLASS_KEY_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x142FC	OTP_CLASS_KEY_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14300	OTP_READ_LOCK	RW	OTP field warm-reset-domain read-lock bits. Write 1 to set; writing 0 has no effect. Locked reads of the corresponding OTP field return zero (effective lock = OTP_READ_LOCK | OTP_READ_LOCK_COLD). Warm-reset domain: cleared by warm or cold reset.
0x14304	OTP_CHANGE_STATUS	RW	OTP field change status. A bit is set when the corresponding field's decoded value changes. Sticky, write 1 to clear. Valid after IRQ_STATUS.OTP_CHANGE fires.
0x14308	OTP_READ_LOCK_COLD	RW	OTP field cold-reset-domain read-lock bits. Write 1 to set; writing 0 has no effect. Locked reads of the corresponding OTP field return zero (effective lock = OTP_READ_LOCK | OTP_READ_LOCK_COLD). Cold-reset domain: survives warm reset.
0x14400	OTP_SEP_CHIPLET_ID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14404	OTP_SEP_CHIPLET_ID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14408	OTP_SEP_CHIPLET_ID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1440C	OTP_SEP_CHIPLET_ID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x14410	OTP_SEP_CHIPLET_ID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14414	OTP_SEP_CHIPLET_ID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14418	OTP_SEP_CHIPLET_ID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1441C	OTP_SEP_CHIPLET_ID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14420	OTP_SEP_CHIPLET_ID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14424	OTP_SEP_CHIPLET_ID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14428	OTP_SEP_CHIPLET_ID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1442C	OTP_SEP_CHIPLET_ID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14430	OTP_SEP_CHIPLET_ID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14434	OTP_SEP_CHIPLET_ID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14438	OTP_SEP_CHIPLET_ID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1443C	OTP_SEP_CHIPLET_ID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14440	OTP_SEP_SIP_ID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14444	OTP_SEP_SIP_ID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14448	OTP_SEP_SIP_ID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1444C	OTP_SEP_SIP_ID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14450	OTP_SEP_SIP_ID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14454	OTP_SEP_SIP_ID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x14458	OTP_SEP_SIP_ID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1445C	OTP_SEP_SIP_ID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14460	OTP_SEP_SIP_ID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14464	OTP_SEP_SIP_ID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14468	OTP_SEP_SIP_ID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1446C	OTP_SEP_SIP_ID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14470	OTP_SEP_SIP_ID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14474	OTP_SEP_SIP_ID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14478	OTP_SEP_SIP_ID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1447C	OTP_SEP_SIP_ID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14480	OTP_SEP_SYS_ID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14484	OTP_SEP_SYS_ID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14488	OTP_SEP_SYS_ID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1448C	OTP_SEP_SYS_ID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14490	OTP_SEP_SYS_ID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14494	OTP_SEP_SYS_ID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x14498	OTP_SEP_SYS_ID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x1449C	OTP_SEP_SYS_ID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x144A0	OTP_SEP_SYS_ID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144A4	OTP_SEP_SYS_ID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144A8	OTP_SEP_SYS_ID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144AC	OTP_SEP_SYS_ID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144B0	OTP_SEP_SYS_ID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144B4	OTP_SEP_SYS_ID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144B8	OTP_SEP_SYS_ID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x144BC	OTP_SEP_SYS_ID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x15000	DATA	R	One word of random data. Read triggers request or returns prefetch. Writes return SLVERR. No reset.
0x15004	CFG	RW	Configuration: PREFETCH enable, TIMEOUT cycles for active CPU read.
0x15008	STATUS	RW	Status: DRBG_READY, PREFETCHED, TIMEOUT_ERR (W1C), STREAM_ERR (W1C), COUNT_BAD, COUNT_GOOD.
0x1500C	PREFETCH_DATA	R	Prefetched word (read-only, for debugging). Cleared when PREFETCH=0. No reset; power-up undefined.
0x18000 - 0x1802C	KEY_SHARE0[12]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x18030 - 0x1805C	KEY_SHARE1[12]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x18060	otbn_wrapper_key.KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the OTBN core.
0x19000 - 0x1901C	aes_wrapper_key.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x19020 - 0x1903C	aes_wrapper_key.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x19040	aes_wrapper_key.KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the AES core.
0x1A000 - 0x1A01C	kmac_wrapper_key.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1A020 - 0x1A03C	kmac_wrapper_key.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1A040	kmac_wrapper_key.KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the KMAC core.
0x1B000 - 0x1B01C	hmac_wrapper_key.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.

Address	Name	Access	Description
0x1B020 - 0x1B03C	hmac_wrapper_key.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1B040	hmac_wrapper_key.KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the HMAC core.
0x1C000 - 0x1C01C	abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C020 - 0x1C03C	abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C040	abr_wrapper_key.MLDSA_SEED.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x1C100 - 0x1C11C	abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C120 - 0x1C13C	abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C140	abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x1C200 - 0x1C21C	abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C220 - 0x1C23C	abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C240	abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x1C300 - 0x1C31C	abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C320 - 0x1C33C	abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x1C340	abr_wrapper_key.MLKEM_MSG.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x1C400 - 0x1C41C	KEY[8]	R	One 32-bit word of ML-KEM shared key output. Written by hardware when key is ready; read by KM firmware to consume. Hardware clears all words to 0 when KEY_CTRL.KEY_VALID is cleared (via hwclr).
0x1C420	abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL	RW	Shared-key control. HW sets KEY_VALID when a new key is ready. Firmware writes 0 to clear (consume and zeroize).
0x1C424	abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_STATUS	RW	Interrupt status for ML-KEM shared key. Sticky bit set by hardware when a new shared key becomes valid; cleared by writing 1.
0x1C428	abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_ENABLE	RW	Interrupt enable for ML-KEM shared key. Mask for the PicoRV32 IRQ vector bit driven by the shared-key-valid event.

2.1.5.11.12.3.2.1.1.1. KM_WRITE_DATA

Table 394. key_manager.KM_WRITE_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	W	0x0	32-bit data word to write to outbound FIFO

2.1.5.11.12.3.2.1.1.2. KM_WRITE_SEPARATOR

Table 395. key_manager.KM_WRITE_SEPARATOR fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	set	RW	0x0	Write 1 to set message separator on next outbound write. Cleared by hardware when that write completes.

2.1.5.11.12.3.2.1.1.3. KM_READ_DATA

Table 396. key_manager.KM_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	0x0	32-bit data word read from inbound FIFO

2.1.5.11.12.3.2.1.1.4. KM_STATUS

Table 397. key_manager.KM_STATUS fields

Bits	Field	Access	Reset	Description
31:26	rsvd	R	0x0	Reserved
25	outbound_separator	R	0x0	Message separator: 1 if the last word read from outbound FIFO had the separator bit set (last word of message). Read-only, not sticky.
24	inbound_separator	R	0x0	Message separator: 1 if the last word read from inbound FIFO had the separator bit set (last word of message). Read-only, not sticky.
23	outbound_underflow	RW1C	0x0	Outbound FIFO underflow detected (read attempted when empty). Sticky, write 1 to clear.
22	inbound_underflow	RW1C	0x0	Inbound FIFO underflow detected (read attempted when empty). Sticky, write 1 to clear.
21	outbound_overflow	RW1C	0x0	Outbound FIFO overflow detected (write attempted when full). Sticky, write 1 to clear.
20	inbound_overflow	RW1C	0x0	Inbound FIFO overflow detected (write attempted when full). Sticky, write 1 to clear.
19:12	outbound_depth	R	0x0	Outbound FIFO fill level (number of words in FIFO)
11:4	inbound_depth	R	0x0	Inbound FIFO fill level (number of words in FIFO)
3	outbound_full	R	0x0	Outbound FIFO is full (cannot write more data)
2	outbound_empty	R	0x1	Outbound FIFO is empty (no data available for SEP to read)
1	inbound_full	R	0x0	Inbound FIFO is full
0	inbound_empty	R	0x1	Inbound FIFO is empty (no data available for KM to read)

2.1.5.11.12.3.2.1.1.5. KM_IRQ_STATUS

Table 398. key_manager.KM_IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:5	rsvd	R	0x0	Reserved
4	flushed_by_sep	RW1C	0x0	SEP performed a mailbox flush. Sticky, write 1 to clear.
3	inbound_underflow	RW1C	0x0	Inbound FIFO underflow detected. Sticky, write 1 to clear.
2	outbound_overflow	RW1C	0x0	Outbound FIFO overflow detected. Sticky, write 1 to clear.
1	outbound_write_space_avail	R	0x0	Outbound FIFO has space available for KM to write (level-sensitive). 1 = space available, 0 = full.
0	inbound_read_data_avail	R	0x0	Inbound FIFO has data available for KM to read (level-sensitive). 1 = data available, 0 = empty.

2.1.5.11.12.3.2.1.1.6. KM_IRQ_ENABLE

Table 399. key_manager.KM_IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	rsvd	R	0x0	Reserved
4	flushed_by_sep_en	RW	0x0	Enable interrupt to KM when SEP performs a mailbox flush
3	inbound_underflow_en	RW	0x0	Enable interrupt to KM when inbound FIFO underflow is detected
2	outbound_overflow_en	RW	0x0	Enable interrupt to KM when outbound FIFO overflow is detected
1	outbound_write_space_avail_en	RW	0x0	Enable interrupt to KM when outbound FIFO has space available (KM→SEP messages)
0	inbound_read_data_avail_en	RW	0x0	Enable interrupt to KM when inbound FIFO has data available (SEP→KM messages)

2.1.5.11.12.3.2.1.1.7. KM_CTRL

Table 400. key_manager.KM_CTRL fields

Bits	Field	Access	Reset	Description
31:3	rsvd	R	0x0	Reserved
2	flush	RW	0x0	Write 1 to flush all mailbox FIFOs (inbound and outbound). Cleared by hardware when flush completes.
1	inbound_underflow_resp	RW	0x0	Response type for inbound FIFO underflow: 0=SLVERR (default), 1=OKAY
0	outbound_overflow_resp	RW	0x0	Response type for outbound FIFO overflow: 0=SLVERR (default), 1=OKAY

2.1.5.11.12.3.2.1.1.8. LOCKS

Table 401. key_manager.LOCKS fields

Bits	Field	Access	Reset	Description
63	SEP_SYS_ID_READ_LOCK	RW1S	0x0	sep_sys_id_read_lock (slot 31): when set, SEP_SYS_ID is not read-able.
62	SEP_SYS_ID_WRITE_LOCK	RW1S	0x0	sep_sys_id_write_lock (slot 31): when set, SEP_SYS_ID is not write-able.
61	SEP_SIP_ID_READ_LOCK	RW1S	0x0	sep_sip_id_read_lock (slot 30): when set, SEP_SIP_ID is not read-able.
60	SEP_SIP_ID_WRITE_LOCK	RW1S	0x0	sep_sip_id_write_lock (slot 30): when set, SEP_SIP_ID is not write-able.
59	SEP_CHIPLET_ID_READ_LOCK	RW1S	0x0	sep_chiplet_id_read_lock (slot 29): when set, SEP_CHIPLET_ID is not read-able.
58	SEP_CHIPLET_ID_WRITE_LOCK	RW1S	0x0	sep_chiplet_id_write_lock (slot 29): when set, SEP_CHIPLET_ID is not write-able.
57	SIP_PUBK_PQC_HASH1_READ_LOCK	RW1S	0x0	sip_pubk_pqc_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
56	SIP_PUBK_PQC_HASH1_WRITE_LOCK	RW1S	0x0	sip_pubk_pqc_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
55	SIP_PUBK_HASH1_READ_LOCK	RW1S	0x0	sip_pubk_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
54	SIP_PUBK_HASH1_WRITE_LOCK	RW1S	0x0	sip_pubk_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
53	SYS_PUBK_PQC_HASH_READ_LOCK	RW1S	0x0	sys_pubk_pqc_hash_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
52	SYS_PUBK_PQC_HASH_WRITE_LOCK	RW1S	0x0	sys_pubk_pqc_hash_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)

Bits	Field	Access	Reset	Description
51	SIP_PUBK_PQC_HASH0_READ_LOCK	RW1S	0x0	sip_pubk_pqc_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
50	SIP_PUBK_PQC_HASH0_WRITE_LOCK	RW1S	0x0	sip_pubk_pqc_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
49	CHIPLET_PUBK_PQC_HASH1_READ_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
48	CHIPLET_PUBK_PQC_HASH1_WRITE_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
47	CHIPLET_PUBK_PQC_HASH0_READ_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
46	CHIPLET_PUBK_PQC_HASH0_WRITE_LOCK	RW1S	0x0	chiplet_pubk_pqc_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
45	REQUIRED_ALGS_READ_LOCK	RW1S	0x0	required_algs_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
44	REQUIRED_ALGS_WRITE_LOCK	RW1S	0x0	required_algs_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
43	REQUIRED_SIGNERS_READ_LOCK	RW1S	0x0	required_signers_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
42	REQUIRED_SIGNERS_WRITE_LOCK	RW1S	0x0	required_signers_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
41	CHIPLET_PUBK_HASH1_READ_LOCK	RW1S	0x0	chiplet_pubk_hash1_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
40	CHIPLET_PUBK_HASH1_WRITE_LOCK	RW1S	0x0	chiplet_pubk_hash1_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
39	CHIPLET_PUBK_HASH0_READ_LOCK	RW1S	0x0	chiplet_pubk_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
38	CHIPLET_PUBK_HASH0_WRITE_LOCK	RW1S	0x0	chiplet_pubk_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
37	SYSCLK_FREQ_MHZ_READ_LOCK	RW1S	0x0	sysclk_freq_mhz_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
36	SYSCLK_FREQ_MHZ_WRITE_LOCK	RW1S	0x0	sysclk_freq_mhz_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
35	ROM_CTL_READ_LOCK	RW1S	0x0	rom_ctl_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
34	ROM_CTL_WRITE_LOCK	RW1S	0x0	rom_ctl_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
33	STATUS_RPT_READ_LOCK	RW1S	0x0	status_rpt_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
32	STATUS_RPT_WRITE_LOCK	RW1S	0x0	status_rpt_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
31	SYS_UID_READ_LOCK	RW1S	0x0	sys_uid_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
30	SYS_UID_WRITE_LOCK	RW1S	0x0	sys_uid_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
29	SYS_PUBK_HASH_READ_LOCK	RW1S	0x0	sys_pubk_hash_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
28	SYS_PUBK_HASH_WRITE_LOCK	RW1S	0x0	sys_pubk_hash_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
27	SIP_UID_READ_LOCK	RW1S	0x0	sip_uid_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)

Bits	Field	Access	Reset	Description
26	SIP_UID_WRITE_LOCK	RW1S	0x0	sip_uid_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
25	SIP_PUBK_HASH0_READ_LOCK	RW1S	0x0	sip_pubk_hash0_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
24	SIP_PUBK_HASH0_WRITE_LOCK	RW1S	0x0	sip_pubk_hash0_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
23	CHIPLET_UID_READ_LOCK	RW1S	0x0	chiplet_uid_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
22	CHIPLET_UID_WRITE_LOCK	RW1S	0x0	chiplet_uid_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
21	BL2_VERSION_READ_LOCK	RW1S	0x0	bl2_version_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
20	BL2_VERSION_WRITE_LOCK	RW1S	0x0	bl2_version_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
19	BL1_VERSION_READ_LOCK	RW1S	0x0	bl1_version_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
18	BL1_VERSION_WRITE_LOCK	RW1S	0x0	bl1_version_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
17	CHIPLET_PUBK_REVOKE_READ_LOCK	RW1S	0x0	chiplet_pubk_revoke_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
16	CHIPLET_PUBK_REVOKE_WRITE_LOCK	RW1S	0x0	chiplet_pubk_revoke_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
15	CLASS_KEY_READ_LOCK	RW1S	0x0	class_key_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
14	CLASS_KEY_WRITE_LOCK	RW1S	0x0	class_key_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
13	RMA_CHIPLET_TOKEN_DIGEST_READ_LOCK	RW1S	0x0	rma_chiplet_token_digest_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
12	RMA_CHIPLET_TOKEN_DIGEST_WRITE_LOCK	RW1S	0x0	rma_chiplet_token_digest_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
11	RMA_SIP_TOKEN_DIGEST_READ_LOCK	RW1S	0x0	rma_sip_token_digest_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
10	RMA_SIP_TOKEN_DIGEST_WRITE_LOCK	RW1S	0x0	rma_sip_token_digest_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
9	SYS_DIS_READ_LOCK	RW1S	0x0	sys_dis_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
8	SYS_DIS_WRITE_LOCK	RW1S	0x0	sys_dis_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
7	SIP_DIS_READ_LOCK	RW1S	0x0	sip_dis_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
6	SIP_DIS_WRITE_LOCK	RW1S	0x0	sip_dis_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)
5	TRANSIENT_RMA_EN_READ_LOCK	RW1S	0x0	TRANSIENT_RMA_EN_READ_LOCK, when set, this field is not read-able (neither the eFuse nor the shadow register)
4	TRANSIENT_RMA_EN_WRITE_LOCK	RW1S	0x0	TRANSIENT_RMA_EN_WRITE_LOCK, when set, this field is not write-able (neither the eFuse nor the shadow register)
3	SBOOT_DIS_READ_LOCK	RW1S	0x0	sboot_dis_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
2	SBOOT_DIS_WRITE_LOCK	RW1S	0x0	sboot_dis_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)

Bits	Field	Access	Reset	Description
1	LC_STATE_READ_LOCK	RW1S	0x0	lc_state_read_lock, when set, this field is not read-able (neither the eFuse nor the shadow register)
0	LC_STATE_WRITE_LOCK	RW1S	0x0	lc_state_write_lock, when set, this field is not write-able (neither the eFuse nor the shadow register)

2.1.5.11.12.3.2.1.1.9. LOCKS_SPARE

Table 402. key_manager.LOCKS_SPARE fields

Bits	Field	Access	Reset	Description
31:18	SPARE_LOCK_RSVD	RW1S	0x0	Unassigned lock slots 41-47. Reserved for future field lock assignments.
17	SPARE8_READ_LOCK	RW1S	0x0	spare8_read_lock (slot 40): when set, spare8 is not read-able.
16	SPARE8_WRITE_LOCK	RW1S	0x0	spare8_write_lock (slot 40): when set, spare8 is not write-able.
15	SPARE7_READ_LOCK	RW1S	0x0	spare7_read_lock (slot 39): when set, spare7 is not read-able.
14	SPARE7_WRITE_LOCK	RW1S	0x0	spare7_write_lock (slot 39): when set, spare7 is not write-able.
13	SPARE6_READ_LOCK	RW1S	0x0	spare6_read_lock (slot 38): when set, spare6 is not read-able.
12	SPARE6_WRITE_LOCK	RW1S	0x0	spare6_write_lock (slot 38): when set, spare6 is not write-able.
11	SPARE5_READ_LOCK	RW1S	0x0	spare5_read_lock (slot 37): when set, spare5 is not read-able.
10	SPARE5_WRITE_LOCK	RW1S	0x0	spare5_write_lock (slot 37): when set, spare5 is not write-able.
9	SPARE4_READ_LOCK	RW1S	0x0	spare4_read_lock (slot 36): when set, spare4 is not read-able.
8	SPARE4_WRITE_LOCK	RW1S	0x0	spare4_write_lock (slot 36): when set, spare4 is not write-able.
7	SPARE3_READ_LOCK	RW1S	0x0	spare3_read_lock (slot 35): when set, spare3 is not read-able.
6	SPARE3_WRITE_LOCK	RW1S	0x0	spare3_write_lock (slot 35): when set, spare3 is not write-able.
5	SPARE2_READ_LOCK	RW1S	0x0	spare2_read_lock (slot 34): when set, spare2 is not read-able.
4	SPARE2_WRITE_LOCK	RW1S	0x0	spare2_write_lock (slot 34): when set, spare2 is not write-able.
3	SPARE1_READ_LOCK	RW1S	0x0	spare1_read_lock (slot 33): when set, spare1 is not read-able.
2	SPARE1_WRITE_LOCK	RW1S	0x0	spare1_write_lock (slot 33): when set, spare1 is not write-able.
1	SPARE0_READ_LOCK	RW1S	0x0	spare0_read_lock (slot 32): when set, spare0 is not read-able.
0	SPARE0_WRITE_LOCK	RW1S	0x0	spare0_write_lock (slot 32): when set, spare0 is not write-able.

2.1.5.11.12.3.2.1.1.10. LC_STATE

Table 403. key_manager.LC_STATE fields

Bits	Field	Access	Reset	Description
31:8	rsvd	R	0x0	Unused
7:0	lc_state	R	0xF0	Life cycle manufacturing state, differentially encoded: {~raw[3:0], raw[3:0]}

2.1.5.11.12.3.2.1.1.11. SBOOT_DIS

Table 404. key_manager.SBOOT_DIS fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Unused
0	disable_secure_boot	R	0x0	Chicken bit to disable secure boot in SEP ROM.

2.1.5.11.12.3.2.1.1.12. TRANSIENT_RMA_EN

Table 405. key_manager.TRANSIENT_RMA_EN fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Unused
0	transient_rma_en	R	0x0	When Transient RMA EN is 1, matching on corresponding *_Tokens will automatically transfer the chip to the corresponding RMA state by setting the LC_STATE reg

2.1.5.11.12.3.2.1.1.13. SIP_DIS

Table 406. key_manager.SIP_DIS fields

Bits	Field	Access	Reset	Description
63:48	func_reserved	RW1S	0x0	Reserved for adopter-defined functional feature gating (bits 63:48).
47:25	debug_reserved_dbg2	RW1S	0x0	Reserved for adopter-defined inter-chiplet-bypass (DBG_2) debug scan chains (bits 47:25).
24	sip_debug	RW1S	0x0	SIP_DBG (bit 24): Coarse-grained debug enable for the SiP scope: the inter-chiplet debug-bypass gate that admits external (PTAP) debug traffic into this chiplet and forwards it onward to the next chiplet via the outbound JTAG PTAP. 1'b1: disabled. 1'b0: enabled.
23:4	debug_reserved_dbg1	RW1S	0x0	Reserved for adopter-defined local (DBG_1) debug scan chains (bits 23:4).
3	smc_fuse_dbg	RW1S	0x0	SMC_FUSE_DBG (bit 3): 1'b1: the DFT-inserted access path into the SMC OTP is disabled. 1'b0: enabled. Produced by SEP-LCC feat_ctrl_o, exported on the SEP boundary, and consumed by SMC to gate its own inserted fuse path.
2	sep_fuse_dbg	RW1S	0x0	SEP_FUSE_DBG (bit 2): 1'b1: the DFT-inserted access path into the SEP OTP is disabled. 1'b0: enabled. Also covers the OTP IP-vendor test and calibration interface, which is reachable only over that inserted path. The functional JTAG2AXIL path to the OTP is always available and is not gated by this bit.
1	chiplet_dbg	RW1S	0x0	CHIPLET_DBG (bit 1): Coarse-grained debug enable for the chiplet scope. 1'b1: chiplet-scope debug/scan-dump access disabled. 1'b0: enabled. Never acts alone: an external debugger reaches chiplet-internal resources only when SIP_DBG is open as well. Contributes to the reachability of the crypto/KM secure chain but never authorizes a dump from it.
0	sep_debug	RW1S	0x0	SEP_DBG (bit 0): Coarse-grained debug enable for the SEP scope. 1'b1: SEP-scope debug/scan-dump access disabled and external inbound traffic is filtered. 1'b0: enabled. A local gate only: reaching SEP internal state from an external debugger additionally requires SIP_DBG and CHIPLET_DBG.

2.1.5.11.12.3.2.1.1.14. SYS_DIS

Table 407. key_manager.SYS_DIS fields

Bits	Field	Access	Reset	Description
63:48	func_reserved	RW1S	0x0	Reserved for adopter-defined functional feature gating (bits 63:48).
47:25	debug_reserved_dbg2	RW1S	0x0	Reserved for adopter-defined inter-chiplet-bypass (DBG_2) debug scan chains (bits 47:25).
24	sip_debug	RW1S	0x0	SIP_DBG (bit 24): Coarse-grained debug enable for the SiP scope: the inter-chiplet debug-bypass gate that admits external (PTAP) debug traffic into this chiplet and forwards it onward to the next chiplet via the outbound JTAG PTAP. 1'b1: disabled. 1'b0: enabled.
23:4	debug_reserved_dbg1	RW1S	0x0	Reserved for adopter-defined local (DBG_1) debug scan chains (bits 23:4).

Bits	Field	Access	Reset	Description
3	smc_fuse_dbg	RW1S	0x0	SMC_FUSE_DBG (bit 3): 1'b1: the DFT-inserted access path into the SMC OTP is disabled. 1'b0: enabled. Produced by SEP-LCC feat_ctrl_o, exported on the SEP boundary, and consumed by SMC to gate its own inserted fuse path.
2	sep_fuse_dbg	RW1S	0x0	SEP_FUSE_DBG (bit 2): 1'b1: the DFT-inserted access path into the SEP OTP is disabled. 1'b0: enabled. Also covers the OTP IP-vendor test and calibration interface, which is reachable only over that inserted path. The functional JTAG2AXIL path to the OTP is always available and is not gated by this bit.
1	chiplet_dbg	RW1S	0x0	CHIPLET_DBG (bit 1): Coarse-grained debug enable for the chiplet scope. 1'b1: chiplet-scope debug/scan-dump access disabled. 1'b0: enabled. Never acts alone: an external debugger reaches chiplet-internal resources only when SIP_DBG is open as well. Contributes to the reachability of the crypto/KM secure chain but never authorizes a dump from it.
0	sep_debug	RW1S	0x0	SEP_DBG (bit 0): Coarse-grained debug enable for the SEP scope. 1'b1: SEP-scope debug/scan-dump access disabled and external inbound traffic is filtered. 1'b0: enabled. A local gate only: reaching SEP internal state from an external debugger additionally requires SIP_DBG and CHIPLET_DBG.

2.1.5.11.12.3.2.1.1.15. RMA_SIP_TOKEN_DIGEST

Table 408. key_manager.RMA_SIP_TOKEN_DIGEST fields

Bits	Field	Access	Reset	Description
255:0	token_digest	R	0x0	Hash digest of life cycle secret that allows entering RMA_SIP state / Note this is a 256 bit field

2.1.5.11.12.3.2.1.1.16. RMA_CHIPLET_TOKEN_DIGEST

Table 409. key_manager.RMA_CHIPLET_TOKEN_DIGEST fields

Bits	Field	Access	Reset	Description
255:0	token_digest	R	0x0	Hash digest of life cycle secret that allows entering RMA_CHIPLET state/ Note this is a 256 bit field

2.1.5.11.12.3.2.1.1.17. CLASS_KEY

Table 410. key_manager.CLASS_KEY fields

Bits	Field	Access	Reset	Description
255:0	key	R	0x0	Class key that could be used for FW encryption/decryption

2.1.5.11.12.3.2.1.1.18. CHIPLET_PUBK_REVOKE

Table 411. key_manager.CHIPLET_PUBK_REVOKE fields

Bits	Field	Access	Reset	Description
31:0	select	R	0x0	Global public-key revocation vector covering every boot-verification key of every owner (classical and PQC). SEP ROM embeds a set of public-key hash digests and accesses additional fused key hashes; each key entry maps to one bit here. Once set, SEP ROM rejects the corresponding key. Bit map: [7:0] ROM chiplet-creator classical keys (bits 0,1 are development keys); [15:8] ROM chiplet-creator PQC keys; [16]/[17] CHIPLET_PUBK_HASH0/1; [18]/[19] CHIPLET_PUBK_PQC_HASH0/1; [20]/[21] SIP_PUBK_HASH0 / SIP_PUBK_PQC_HASH0; [22]/[23] SYS_PUBK_HASH / SYS_PUBK_PQC_HASH; [24]/[25] SIP_PUBK_HASH1 / SIP_PUBK_PQC_HASH1; [31:26] reserved. Before the chiplet owner transfers a part to the customer, the development-key bits shall be set (revoked).

2.1.5.11.12.3.2.1.1.19. BL1_VERSION

Table 412. key_manager.BL1_VERSION fields

Bits	Field	Access	Reset	Description
255:0	version	R	0x0	Minimum BL1 version that can be loaded by SEPROM

2.1.5.11.12.3.2.1.1.20. BL2_VERSION

Table 413. key_manager.BL2_VERSION fields

Bits	Field	Access	Reset	Description
255:0	version	R	0x0	Minimum BL2 version that can be loaded by BL1. If more boot stages exist, rollback protection can be implemented by BL2.

2.1.5.11.12.3.2.1.1.21. CHIPLET_UID

Table 414. key_manager.CHIPLET_UID fields

Bits	Field	Access	Reset	Description
255:0	uid	R	0x0	Silicon creator's secret device unique ID (also referred to as UDS - Unique Device Secret). The chiplet creator is responsible for CHIPLET_UID provisioning and public identity enrollment. When read-locked, both writability and software visibility are disabled.

2.1.5.11.12.3.2.1.1.22. SIP_PUBK_HASH0

Table 415. key_manager.SIP_PUBK_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of SiP owner's root public key for secure boot. The chiplet creator's actual root public key is embedded in the SEPROM; this digest is used to validate that public key.

2.1.5.11.12.3.2.1.1.23. SIP_UID

Table 416. key_manager.SIP_UID fields

Bits	Field	Access	Reset	Description
255:0	uid	R	0x0	SiP owner's secret device unique ID. The SiP owner is responsible for SIP_UID provisioning and public identity enrollment. When read-locked, both writability and software visibility are disabled.

2.1.5.11.12.3.2.1.1.24. SYS_PUBK_HASH

Table 417. key_manager.SYS_PUBK_HASH fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of system owner's root public key for secure boot.

2.1.5.11.12.3.2.1.1.25. SYS_UID

Table 418. key_manager.SYS_UID fields

Bits	Field	Access	Reset	Description
255:0	uid	R	0x0	System owner's secret device unique ID. The system owner is responsible for SYS_UID provisioning and public identity enrollment. When read-locked, both writability and software visibility are disabled.

2.1.5.11.12.3.2.1.1.26. STATUS_RPT

Table 419. key_manager.STATUS_RPT fields

Bits	Field	Access	Reset	Description
31:2	reserved	R	0x0	reserved
1:0	rpt	R	0x0	BOOTROM report status based on the bit. 2'b00→ bootrom report status based on GPIO; 2'b01→bootrom report status;otherwise, bootrom does not report status

2.1.5.11.12.3.2.1.1.27. ROM_CTL

Table 420. key_manager.ROM_CTL fields

Bits	Field	Access	Reset	Description
31:6	reserved	R	0x0	reserved
5:1	rom_swap_ctrl	R	0x0	controls how the rom slices are swapped
0	rom_endianness_ctrl	R	0x0	controls the endianness of the rom data out. 0→little endian; 1→big endian

2.1.5.11.12.3.2.1.1.28. SYSCLK_FREQ_MHZ

Table 421. key_manager.SYSCLK_FREQ_MHZ fields

Bits	Field	Access	Reset	Description
31:11	rsvd	R	0x0	Reserved
10:0	sysclk_freq_mhz	R	0x0	Configured sysclk PLL frequency in MHz; ignored if 0. Consumed by boot ROM clock math.

2.1.5.11.12.3.2.1.1.29. CHIPLET_PUBK_HASH0

Table 422. key_manager.CHIPLET_PUBK_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner authentication key hash digest, fused. These chiplet owner fused key hashes can be used in addition to the hashes in the ROM itself to authenticate manifests.

2.1.5.11.12.3.2.1.1.30. CHIPLET_PUBK_HASH1

Table 423. key_manager.CHIPLET_PUBK_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner authentication key hash digest, fused. These chiplet owner fused key hashes can be used in addition to the hashes in the ROM itself to authenticate manifests.

2.1.5.11.12.3.2.1.1.31. REQUIRED_SIGNERS

Table 424. key_manager.REQUIRED_SIGNERS fields

Bits	Field	Access	Reset	Description
31:2	reserved	R	0x0	Reserved
1:0	required_signers	RW1S	0x0	Owners whose signature is required to authenticate any image loadable by SEP ROM. Per owner, 1 = required, 0 = not-required; the default all-zero value requires no additional owner. [0] SiP owner, [1] system owner. The chiplet creator is the root of trust and always authenticates BL1, so it has no bit here.

2.1.5.11.12.3.2.1.1.32. REQUIRED_ALGS

Table 425. key_manager.REQUIRED_ALGS fields

Bits	Field	Access	Reset	Description
31:12	reserved	R	0x0	Reserved
11:8	sys_algs	RW1S	0x0	Per-owner required signature algorithms for system owner. bit 0 = classical, bit 1 = post-quantum (ML-DSA), bits 3:2 reserved.
7:4	sip_algs	RW1S	0x0	Per-owner required signature algorithms for SiP owner. bit 0 = classical, bit 1 = post-quantum (ML-DSA), bits 3:2 reserved.
3:0	chiplet_algs	RW1S	0x0	Per-owner required signature algorithms for chiplet. Each nibble: bit 0 = classical (ECDSA P-384 or RSA), bit 1 = post-quantum (ML-DSA), bits 3:2 reserved.

2.1.5.11.12.3.2.1.1.33. CHIPLET_PUBK_PQC_HASH0

Table 426. key_manager.CHIPLET_PUBK_PQC_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner ML-DSA PQC authentication key hash digest, fused. PQC counterpart of the corresponding CHIPLET_PUBK_HASH.

2.1.5.11.12.3.2.1.1.34. CHIPLET_PUBK_PQC_HASH1

Table 427. key_manager.CHIPLET_PUBK_PQC_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Chiplet owner ML-DSA PQC authentication key hash digest, fused. PQC counterpart of the corresponding CHIPLET_PUBK_HASH.

2.1.5.11.12.3.2.1.1.35. SIP_PUBK_PQC_HASH0

Table 428. key_manager.SIP_PUBK_PQC_HASH0 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of the SiP owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SIP_PUBK_HASH.

2.1.5.11.12.3.2.1.1.36. SYS_PUBK_PQC_HASH

Table 429. key_manager.SYS_PUBK_PQC_HASH fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of the system owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SYS_PUBK_HASH.

2.1.5.11.12.3.2.1.1.37. SIP_PUBK_HASH1

Table 430. key_manager.SIP_PUBK_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of SiP owner's root public key for secure boot. The chiplet creator's actual root public key is embedded in the SEPROM; this digest is used to validate that public key.

2.1.5.11.12.3.2.1.1.38. SIP_PUBK_PQC_HASH1

Table 431. key_manager.SIP_PUBK_PQC_HASH1 fields

Bits	Field	Access	Reset	Description
255:0	key_hash	R	0x0	Hash digest of the SiP owner's ML-DSA PQC root public key for secure boot. PQC counterpart of SIP_PUBK_HASH.

2.1.5.11.12.3.2.1.1.39. SEP_CHIPLET_ID

Table 432. key_manager.SEP_CHIPLET_ID fields

Bits	Field	Access	Reset	Description
255:0	id	R	0x0	Per-owner public identity fuse. Personalization input for the Key Manager identity root. Being public, no read protection is required. Individually lockable via LOCKS[58:63] (slots 29-31).

2.1.5.11.12.3.2.1.1.40. SEP_SIP_ID

Table 433. key_manager.SEP_SIP_ID fields

Bits	Field	Access	Reset	Description
255:0	id	R	0x0	Per-owner public identity fuse. Personalization input for the Key Manager identity root. Being public, no read protection is required. Individually lockable via LOCKS[58:63] (slots 29-31).

2.1.5.11.12.3.2.1.1.41. SEP_SYS_ID

Table 434. key_manager.SEP_SYS_ID fields

Bits	Field	Access	Reset	Description
255:0	id	R	0x0	Per-owner public identity fuse. Personalization input for the Key Manager identity root. Being public, no read protection is required. Individually lockable via LOCKS[58:63] (slots 29-31).

2.1.5.11.12.3.2.1.1.42. spare0

Table 435. key_manager.spare0 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.43. spare1

Table 436. key_manager.spare1 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.44. spare2

Table 437. key_manager.spare2 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.45. spare3

Table 438. key_manager.spare3 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.46. spare4

Table 439. key_manager.spare4 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.47. spare5

Table 440. key_manager.spare5 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.48. spare6

Table 441. key_manager.spare6 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.49. spare7

Table 442. key_manager.spare7 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.50. spare8

Table 443. key_manager.spare8 fields

Bits	Field	Access	Reset	Description
255:0	rsvd	R	0x0	Spare region for future use. Individually lockable via LOCKS_SPARE (slots 32-40).

2.1.5.11.12.3.2.1.1.51. EFUSE_INTERFACE_CTRL_STATUS

Table 444. key_manager.EFUSE_INTERFACE_CTRL_STATUS fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10	efuse_read_addr_error_clear	W 1P	0x0	Clears the read out of bounds error bit (efuse_read_addr_error) in efuse_ctrl_status
9	efuse_program_addr_error_clear	W 1P	0x0	Clears the program out of bounds error bit (efuse_program_addr_error) in efuse_ctrl_status
8	efuse_req_error_clear	W 1P	0x0	Clears the blocked request error bit in efuse_ctrl_status
7	Reserved	-	-	Reserved
6	efuse_read_addr_error	R	0x0	Indicates that an invalid eFuse read address was used (address exceeds the implemented eFuse size). The error must be cleared by writing 1 to efuse_read_addr_error_clear.
5	efuse_program_addr_error	R	0x0	Indicates that an invalid eFuse program address was used (address exceeds the implemented eFuse size). The error must be cleared by writing 1 to efuse_program_addr_error_clear.
4	efuse_req_error	R	0x0	Indicates that the eFuse was blocked because of either read or a program lock. The error must be cleared by writing 1 to efuse_req_error_clear to this register
3:1	Reserved	-	-	Reserved
0	efuse_sense_done	R	-	Indicates if the eFuse state machine has completed

2.1.5.11.12.3.2.1.1.52. EFUSE_PROGRAM_CTRL

Table 445. key_manager.EFUSE_PROGRAM_CTRL fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27	program_enable	RW	0x0	When set, enables the program request
26	program_status	R	0x0	0: No Error. 1: Error
25	program_done	R	0x0	When set, the program has completed, the status of which is in program_status
24	program_busy	R	0x0	When set, the program is in progress
23:19	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
18	efuse_program_read_back	RW	0x0	When set, trigger a read back after a program
17	efuse_program_go	RW 1P	0x0	When set, triggers a program to the eFuse. This will be ignored if the lock bit is set
16	efuse_data	RW	0x0	Data to program to eFuse. If this bit is 0, the program request will be ignored
15:0	efuse_addr	RW	0x0	Bit address to program

2.1.5.11.12.3.2.1.1.53. EFUSE_READ_CTRL

Table 446. key_manager.EFUSE_READ_CTRL fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	read_enable	RW	0x0	When set, enables the read request
27	Reserved	-	-	Reserved
26	read_status	R	0x0	0: No Error. 1: Error. Set when read_go is asserted while read is not enabled, the address is out of bounds, or the read request times out.
25	read_done	R	0x0	When set, the read has completed, the status of which is in read_status
24	read_busy	R	0x0	When set, the read is in progress
23:17	Reserved	-	-	Reserved
16	efuse_read_go	RW 1P	0x0	When set, triggers a read to efuse.
15:0	efuse_addr	RW	0x0	Bit address to read

2.1.5.11.12.3.2.1.1.54. EFUSE_PROGRAM_INTERFACE_READ_DATA

Table 447. key_manager.EFUSE_PROGRAM_INTERFACE_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	dout	R	0x0	Read Data from eFuse through program interface. This field is only valid when the efuse programming interface is utilized to burn the efuse IP and only when the state machine is during ST_CAPTUER_DATA state. Hardware debug only

2.1.5.11.12.3.2.1.1.55. EFUSE_READ_INTERFACE_READ_DATA

Table 448. key_manager.EFUSE_READ_INTERFACE_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	dout	R	0x0	Read Data from eFuse through READ interface.

2.1.5.11.12.3.2.1.1.56. EFUSE_READ_REQ_TIMEOUT

Table 449. key_manager.EFUSE_READ_REQ_TIMEOUT fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	read_req_timout_enable	RW	0x0	Enable timeout on read interface
27:0	read_req_timeout_cycles	RW	0x800000	Number of cycles the read interface will wait for a response from the shim. At 100MHz this can count ~= 2.5 seconds.

2.1.5.11.12.3.2.1.1.57. EFUSE_PROGRAM_REQ_TIMEOUT

Table 450. key_manager.EFUSE_PROGRAM_REQ_TIMEOUT fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	program_req_timeout_enable	RW	0x0	Enable timeout on program interface.
27:0	program_req_timeout_cycles	RW	0x800000	Number of cycles the program interface will wait for a response from the shim. At 100MHz this can count ~= 2.5 seconds.

2.1.5.11.12.3.2.1.1.58. RMA_SIP_TOKEN_I[8]

Table 451. key_manager.RMA_SIP_TOKEN_I[8] fields

Bits	Field	Access	Reset	Description
31:0	token	RW	-	Portion of writeable version of RMA_*_TOKEN, hashed, and compared with fused value to allow LC to change states.

2.1.5.11.12.3.2.1.1.59. RMA_CHIPLET_TOKEN_I[8]

Table 452. key_manager.RMA_CHIPLET_TOKEN_I[8] fields

Bits	Field	Access	Reset	Description
31:0	token	RW	-	Portion of writeable version of RMA_*_TOKEN, hashed, and compared with fused value to allow LC to change states.

2.1.5.11.12.3.2.1.1.60. SEC_DISABLE_TOKEN_I[8]

Table 453. key_manager.SEC_DISABLE_TOKEN_I[8] fields

Bits	Field	Access	Reset	Description
31:0	token	RW	-	Portion of writeable version of SEC_DISABLE_TOKEN, hashed, and compared with the post silicon injected values to allow security_disable.

2.1.5.11.12.3.2.1.1.61. TOKEN_EOP

Table 454. key_manager.TOKEN_EOP fields

Bits	Field	Access	Reset	Description
31:17	Reserved	-	-	Reserved
16	secure_disable_token_go	W 1P	0x0	Write 1 to indicate that all token data has been written; this generates a pulse to begin token hashing.
15:9	Reserved	-	-	Reserved
8	rma_chiplet_token_go	W 1P	0x0	Write 1 to indicate that all token data has been written; this generates a pulse to begin token hashing.
7:1	Reserved	-	-	Reserved
0	rma_sip_token_go	W 1P	0x0	Write 1 to indicate that all token data has been written; this generates a pulse to begin token hashing.

2.1.5.11.12.3.2.1.1.62. RMA_SIP_TOKEN_MATCH

Table 455. key_manager.RMA_SIP_TOKEN_MATCH fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	token_match_status	R	0x0	Store the status of the token match. Match = 6'b010101, Mismatch = 6'b101010, Error = 6'b111111

2.1.5.11.12.3.2.1.1.63. RMA_CHIPLET_TOKEN_MATCH

Table 456. key_manager.RMA_CHIPLET_TOKEN_MATCH fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	token_match_status	R	0x0	Store the status of the token match. Match = 6'b010101, Mismatch = 6'b101010, Error = 6'b111111

2.1.5.11.12.3.2.1.1.64. SEC_DISABLE_TOKEN_MATCH

Table 457. key_manager.SEC_DISABLE_TOKEN_MATCH fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	token_match_status	R	0x0	Store the status of the token match. Match = 6'b010101, Mismatch = 6'b101010, Error = 6'b111111

2.1.5.11.12.3.2.1.1.65. TOKEN_MATCH_FAULT

Table 458. key_manager.TOKEN_MATCH_FAULT fields

Bits	Field	Access	Reset	Description
31:17	Reserved	-	-	Reserved
16	secure_disable_token_fault	R	0x0	A redundancy fault was detected in the SEC_DISABLE_TOKEN comparators.
15:9	Reserved	-	-	Reserved
8	rma_chiplet_token_fault	R	0x0	A redundancy fault was detected in the RMA_CHIPLET_TOKEN comparators.
7:1	Reserved	-	-	Reserved
0	rma_sip_token_fault	R	0x0	A redundancy fault was detected in the RMA_SIP_TOKEN comparators.

2.1.5.11.12.3.2.1.1.66. KEY_ENTRY[64].WORD[16]

Table 459. key_manager.KEY_ENTRY[64].WORD[16] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	-	32-bit key data word. No reset for security; power-up value undefined. Actual storage is in km_kpv_regfile; CSR field is a protocol placeholder.

2.1.5.11.12.3.2.1.1.67. CTRL[64]

Table 460. key_manager.CTRL[64] fields

Bits	Field	Access	Reset	Description
31:4	rsvd_31_4	R	0x0	Reserved

Bits	Field	Access	Reset	Description
3	seal	RW1S	0x0	Seals this key entry until warm reset. Read-any, write-1-only. Setting this bit also sets lock_write in hardware, so a single write seals the slot: its data can be read but not overwritten. Erase remains available, and erasing a sealed slot retires it rather than freeing it (see ERASE), so a sealed slot's material can be destroyed but its slot never reused.
2	erase	RW1S	0x0	Write-1 to start hardware erase of this slot: an LFSR fills all 16 key words (through the KPV scrambler). Hardware self-clears this bit when the erase completes. Never blocked: neither lock_write, lock_use nor seal prevents an erase. The slot's seal state when the erase completes decides the outcome. Unsealed, the slot CTRL register is cleared and the slot is reusable. Sealed, lock_write stays set and lock_use is set, retiring the slot: its data is destroyed and it can be neither read, rewritten nor reused until warm reset. A seal taken while an erase is already in flight therefore still retires the slot.
1	lock_use	RW1S	0x0	Prevents KM read of this key entry data until reset. Read-any, write-1-only. Hardware sets this bit when an erase of a sealed slot completes, retiring the slot: its destroyed contents cannot be read back.
0	lock_write	RW1S	0x0	Prevents KM write to this key entry data until reset; this register stays writable so that a locked slot can still be read-locked and erased. Read-any, write-1-only. Hardware holds this bit set for as long as SEAL is set, so sealing a slot write-locks it without a separate write here.

2.1.5.11.12.3.2.1.1.68. KPV_SCRAMBLER_KEY

Table 461. key_manager.KPV_SCRAMBLER_KEY fields

Bits	Field	Access	Reset	Description
31:0	key	RW	-	Scrambler key. No reset for security. HW clears to 0 on wipe via hwclr.

2.1.5.11.12.3.2.1.1.69. KPV_SCRAMBLER_CTRL

Table 462. key_manager.KPV_SCRAMBLER_CTRL fields

Bits	Field	Access	Reset	Description
31:2	rsvd	R	0x0	Reserved
1	lock	RW1S	0x0	Write-one-only. When 1, key and ENABLE cannot be modified until KM reset.
0	enable	RW	0x0	1 = scramble key entry data on write, descramble on read; 0 = passthrough.

2.1.5.11.12.3.2.1.1.70. VERSION

Table 463. key_manager.VERSION fields

Bits	Field	Access	Reset	Description
31:24	rsvd	R	0x0	Reserved; must read as zero
23:16	major	R	0x1	Major version number
15:8	minor	R	0x0	Minor version number
7:0	patch	R	0x0	Patch version number

2.1.5.11.12.3.2.1.1.71. CTRL

Table 464. key_manager.CTRL fields

Bits	Field	Access	Reset	Description
31:0	rsvd	R	0x0	Reserved

2.1.5.11.12.3.2.1.1.72. SOFT_RST_CODE

Table 465. key_manager.SOFT_RST_CODE fields

Bits	Field	Access	Reset	Description
31:0	code	RW	0x0	32-bit reset code. Write 0x53525354 to trigger soft reset.

2.1.5.11.12.3.2.1.1.73. kmcsr.IRQ_STATUS

Table 466. key_manager.kmcsr.IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:12	rsvd	R	0x0	Reserved
11	rom_access_violation	RW1C	0x0	KM ROM instruction fetch or data read attempted after the ROM lockout engaged. The lockout engages on the first committed instruction fetch from write-locked SRAM once SRAM_EXEC_MODE.enable is set, and clears only on warm or cold reset. Sticky, write 1 to clear.
10	exec_violation	RW1C	0x0	Instruction fetch from a non-whitelisted (non-executable) memory region detected, excluding the KM ROM. Sticky, write 1 to clear.
9	otp_sigint	RW1C	0x0	OTP dual-rail encoding integrity violation: value and complement are not complementary on at least one field. Sticky, write 1 to clear.
8	otp_change	RW1C	0x0	An OTP readout field value changed (decoded value differs from prior cycle). Sticky, write 1 to clear. Check OTP_CHANGE_STATUS for the specific field(s).
7	wipe_state	RW1C	0x0	Wipe state event (rising edge of wipe_state input). Sticky, write 1 to clear.
6	drbg_err	RW1C	0x0	DRBG Sampler error (timeout or AXI-Stream error). Sticky, write 1 to clear.
5	axi_decerr	RW1C	0x0	AXI DECERR (decode error) response detected on CPU bus transaction. Sticky, write 1 to clear.
4	axi_slverr	RW1C	0x0	AXI SLVERR (slave error) response detected on CPU bus transaction. Sticky, write 1 to clear.
3	sram_write_lock_err	RW1C	0x0	SRAM write attempt to a write-locked region detected. Sticky, write 1 to clear.
2	rom_write_err	RW1C	0x0	ROM write attempt detected (ROM is read-only). Sticky, write 1 to clear.
1	sram_parity_err	RW1C	0x0	SRAM parity error detected. Sticky, write 1 to clear.
0	rom_parity_err	RW1C	0x0	ROM parity error detected. Sticky, write 1 to clear.

2.1.5.11.12.3.2.1.1.74. kmcsr.IRQ_ENABLE

Table 467. key_manager.kmcsr.IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:12	rsvd	R	0x0	Reserved
11	rom_access_violation_en	RW	0x0	Enable ROM lockout violation interrupt
10	exec_violation_en	RW	0x0	Enable execute-permission whitelist violation interrupt
9	otp_sigint_en	RW	0x0	Enable OTP dual-rail integrity violation interrupt
8	otp_change_en	RW	0x0	Enable OTP field change interrupt
7	wipe_state_en	RW	0x0	Enable wipe state interrupt

Bits	Field	Access	Reset	Description
6	drbg_err_en	RW	0x0	Enable DRBG Sampler error interrupt
5	axi_decerr_en	RW	0x0	Enable AXI DECERR error interrupt
4	axi_slverr_en	RW	0x0	Enable AXI SLVERR error interrupt
3	sram_write_lock_en	RW	0x0	Enable SRAM write-lock violation interrupt
2	rom_write_en	RW	0x0	Enable ROM write error interrupt
1	sram_parity_en	RW	0x0	Enable SRAM parity error interrupt
0	rom_parity_en	RW	0x0	Enable ROM parity error interrupt

2.1.5.11.12.3.2.1.1.75. SCRAMBLER_KEY

Table 468. key_manager.SCRAMBLER_KEY fields

Bits	Field	Access	Reset	Description
31:0	key	RW	-	Scrambler key value. Not readable when SCRAMBLER_CTRL.LOCK=1 (returns 0). No reset for security; power-up value undefined.

2.1.5.11.12.3.2.1.1.76. SCRAMBLER_CTRL

Table 469. key_manager.SCRAMBLER_CTRL fields

Bits	Field	Access	Reset	Description
31:2	rsvd	R	0x0	Reserved
1	lock	RW	0x0	Lock scrambler key and enable bit. Once set, key and enable cannot be modified until reset. Write-once (0→1 only). Security requirement: prevents disabling scrambling after key provisioning.
0	enable	RW	0x0	Enable SRAM scrambling. When 0, data passes through unmodified. Locked when LOCK=1 (security requirement).

2.1.5.11.12.3.2.1.1.77. SRAM_LOCK

Table 470. key_manager.SRAM_LOCK fields

Bits	Field	Access	Reset	Description
31:0	lock_bits	RW1S	0x0	One bit per 1 KB SRAM region. Region 0 = 0x8000-0x83FF, region 31 = 0xFC00-0xFFFF. Write 1 to lock; 0 has no effect. Warm reset domain: cleared by warm or cold reset.

2.1.5.11.12.3.2.1.1.78. IRQ_SET

Table 471. key_manager.IRQ_SET fields

Bits	Field	Access	Reset	Description
31:12	rsvd	W	0x0	Reserved (write-only; reads trigger SLVERR via err_if_bad_rw)
11	rom_access_violation_set	W 1P	0x0	Write 1 to set IRQ_STATUS.ROM_ACCESS_VIOLATION (triggers ROM lockout violation interrupt for testing)
10	exec_violation_set	W 1P	0x0	Write 1 to set IRQ_STATUS.EXEC_VIOLATION (triggers exec-permission violation interrupt for testing)
9	otp_sigint_set	W 1P	0x0	Write 1 to set IRQ_STATUS.OTP_SIGINT (triggers OTP sigint interrupt for testing)
8	otp_change_set	W 1P	0x0	Write 1 to set IRQ_STATUS.OTP_CHANGE (triggers OTP change interrupt for testing)

Bits	Field	Access	Reset	Description
7	wipe_state_set	W 1P	0x0	Write 1 to set IRQ_STATUS.WIPE_STATE (triggers wipe state interrupt for testing)
6	drbg_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.DRBG_ERR (triggers DRBG Sampler interrupt for testing)
5	axi_decerr_set	W 1P	0x0	Write 1 to set IRQ_STATUS.AXI_DECERR (triggers AXI DECERR interrupt for testing)
4	axi_slverr_set	W 1P	0x0	Write 1 to set IRQ_STATUS.AXI_SLVERR (triggers AXI SLVERR interrupt for testing)
3	sram_write_lock_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.SRAM_WRITE_LOCK_ERR (triggers SRAM write-lock interrupt for testing)
2	rom_write_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.ROM_WRITE_ERR (triggers ROM write interrupt for testing)
1	sram_parity_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.SRAM_PARITY_ERR (triggers SRAM parity interrupt for testing)
0	rom_parity_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.ROM_PARITY_ERR (triggers ROM parity interrupt for testing)

2.1.5.11.12.3.2.1.1.79. SRAM_WRITE_LOCK_VIOLATION

Table 472. key_manager.SRAM_WRITE_LOCK_VIOLATION fields

Bits	Field	Access	Reset	Description
31:0	violation_bits	RW1C	0x0	Bit[i]=1 if region i had attempted write while locked. Sticky, write 1 to clear each bit.

2.1.5.11.12.3.2.1.1.80. RECOVERABLE_ERR

Table 473. key_manager.RECOVERABLE_ERR fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	recoverable_err	RW	0x0	1 = recoverable fault occurred and was handled by ISR; 0 = clear. Write 1 to set, write 0 to clear.

2.1.5.11.12.3.2.1.1.81. BOOT_STATUS

Table 474. key_manager.BOOT_STATUS fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	cold_boot_done	RW1S	0x0	Write-1-only: set by ROM firmware at end of cold boot. Reads 0 after cold reset; reads 1 after firmware sets it. Sticky until next cold reset (preserved across warm resets).

2.1.5.11.12.3.2.1.1.82. OTP_LIFE_CYCLE

Table 475. key_manager.OTP_LIFE_CYCLE fields

Bits	Field	Access	Reset	Description
31:8	rsvd	R	0x0	Reserved
7:0	value	R	-	8-bit life cycle state from OTP. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.83. OTP_DEMOTION_STATE

Table 476. key_manager.OTP_DEMOTION_STATE fields

Bits	Field	Access	Reset	Description
31:4	rsvd	R	0x0	Reserved
3:2	demote_2_value	R	-	2-bit demotion 2 state from OTP. No reset; power-up value undefined.
1:0	demote_1_value	R	-	2-bit demotion 1 state from OTP. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.84. SRAM_EXEC_MODE

Table 477. key_manager.SRAM_EXEC_MODE fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	enable	RW1S	0x0	Execute-permission mode: 0=ROM-only whitelist; 1=write-locked SRAM whitelist, arming the ROM lockout. Write 1 to set; write 0 has no effect. Warm reset domain: cleared by warm or cold reset.

2.1.5.11.12.3.2.1.1.85. IRQ_ENTRY_ADDR

Table 478. key_manager.IRQ_ENTRY_ADDR fields

Bits	Field	Access	Reset	Description
31:0	addr	RW	0x10	IRQ handler entry PC. Reset matches ROM vector at 0x10. When locked, SW writes do not update storage.

2.1.5.11.12.3.2.1.1.86. IRQ_ENTRY_LOCK

Table 479. key_manager.IRQ_ENTRY_LOCK fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved; reads as zero.
0	lock	RW1S	0x0	Write 1 to set; write 0 has no effect; sticky until reset.

2.1.5.11.12.3.2.1.1.87. VUART_TX

Table 480. key_manager.VUART_TX fields

Bits	Field	Access	Reset	Description
31	data_valid	RW	0x0	Data valid strobe. Set by firmware on write, cleared by hardware after one cycle.
30:8	rsvd0	R	0x0	Reserved
7:0	tx_byte	RW	0x0	Byte to transmit (write to send character to testbench)

2.1.5.11.12.3.2.1.1.88. VUART_RX

Table 481. key_manager.VUART_RX fields

Bits	Field	Access	Reset	Description
31	data_valid	R	0x0	RX data valid. Set by testbench, cleared by firmware read.
30:8	rsvd0	R	0x0	Reserved

Bits	Field	Access	Reset	Description
7:0	rx_byte	R	0x0	Received byte from testbench

2.1.5.11.12.3.2.1.1.89. VUART_STATUS

Table 482. key_manager.VUART_STATUS fields

Bits	Field	Access	Reset	Description
31:3	rsvd	R	0x0	Reserved
2	print_enable	R	0x0	Enable VUART printing. Set by testbench to enable printf output. Disabled by default to save simulation time.
1	rx_valid	R	0x0	RX has valid data available
0	tx_ready	R	0x1	TX ready to accept data (always 1 in simulation)

2.1.5.11.12.3.2.1.1.90. TB_RESULT

Table 483. key_manager.TB_RESULT fields

Bits	Field	Access	Reset	Description
31:0	result	RW	0x0	Test result: 0=fail, 1=pass

2.1.5.11.12.3.2.1.1.91. TB_SIGNATURE

Table 484. key_manager.TB_SIGNATURE fields

Bits	Field	Access	Reset	Description
31:0	signature	RW	0x0	Completion signature value

2.1.5.11.12.3.2.1.1.92. TB_ERRCODE

Table 485. key_manager.TB_ERRCODE fields

Bits	Field	Access	Reset	Description
31:0	errcode	RW	0x0	Error code value

2.1.5.11.12.3.2.1.1.93. TB_SUBTEST

Table 486. key_manager.TB_SUBTEST fields

Bits	Field	Access	Reset	Description
31:0	subtest	RW	0x0	Current subtest number

2.1.5.11.12.3.2.1.1.94. TB_CMD

Table 487. key_manager.TB_CMD fields

Bits	Field	Access	Reset	Description
31:0	cmd	RW	0x0	Command code (0=NOP, 1=ROM_PARITY_EN, 2=ROM_PARITY_DIS, 3=SRAM_PARITY_EN, 4=SRAM_PARITY_DIS)

2.1.5.11.12.3.2.1.1.95. TB_CMD_ARG

Table 488. key_manager.TB_CMD_ARG fields

Bits	Field	Access	Reset	Description
31:0	arg	RW	0x0	Command argument value

2.1.5.11.12.3.2.1.1.96. TB_CMD_STATUS

Table 489. key_manager.TB_CMD_STATUS fields

Bits	Field	Access	Reset	Description
31:0	status	RW	0x0	Command status: 0=IDLE, 1=ACK, 0xFFFFFFFF=ERR

2.1.5.11.12.3.2.1.1.97. TB_CMD_RESULT

Table 490. key_manager.TB_CMD_RESULT fields

Bits	Field	Access	Reset	Description
31:0	result	R	0x0	Command result value

2.1.5.11.12.3.2.1.1.98. DEBUG

Table 491. key_manager.DEBUG fields

Bits	Field	Access	Reset	Description
31:0	magic	R	0xCAFEBEEF	Magic constant: 0xCAFEBEEF

2.1.5.11.12.3.2.1.1.99. OTP_CHIPLET_UID_VAL_0

Table 492. key_manager.OTP_CHIPLET_UID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.100. OTP_CHIPLET_UID_VAL_1

Table 493. key_manager.OTP_CHIPLET_UID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.101. OTP_CHIPLET_UID_VAL_2

Table 494. key_manager.OTP_CHIPLET_UID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.102. OTP_CHIPLET_UID_VAL_3

Table 495. key_manager.OTP_CHIPLET_UID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.103. OTP_CHIPLET_UID_VAL_4

Table 496. key_manager.OTP_CHIPLET_UID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.104. OTP_CHIPLET_UID_VAL_5

Table 497. key_manager.OTP_CHIPLET_UID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.105. OTP_CHIPLET_UID_VAL_6

Table 498. key_manager.OTP_CHIPLET_UID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.106. OTP_CHIPLET_UID_VAL_7

Table 499. key_manager.OTP_CHIPLET_UID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.107. OTP_CHIPLET_UID_CPL_0

Table 500. key_manager.OTP_CHIPLET_UID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.108. OTP_CHIPLET_UID_CPL_1

Table 501. key_manager.OTP_CHIPLET_UID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.109. OTP_CHIPLET_UID_CPL_2

Table 502. key_manager.OTP_CHIPLET_UID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.110. OTP_CHIPLET_UID_CPL_3

Table 503. key_manager.OTP_CHIPLET_UID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.111. OTP_CHIPLET_UID_CPL_4

Table 504. key_manager.OTP_CHIPLET_UID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.112. OTP_CHIPLET_UID_CPL_5

Table 505. key_manager.OTP_CHIPLET_UID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.113. OTP_CHIPLET_UID_CPL_6

Table 506. key_manager.OTP_CHIPLET_UID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.114. OTP_CHIPLET_UID_CPL_7

Table 507. key_manager.OTP_CHIPLET_UID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.115. OTP_SIP_UID_VAL_0

Table 508. key_manager.OTP_SIP_UID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.116. OTP_SIP_UID_VAL_1

Table 509. key_manager.OTP_SIP_UID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.117. OTP_SIP_UID_VAL_2

Table 510. key_manager.OTP_SIP_UID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.118. OTP_SIP_UID_VAL_3

Table 511. key_manager.OTP_SIP_UID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.119. OTP_SIP_UID_VAL_4

Table 512. key_manager.OTP_SIP_UID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.120. OTP_SIP_UID_VAL_5

Table 513. key_manager.OTP_SIP_UID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.121. OTP_SIP_UID_VAL_6

Table 514. key_manager.OTP_SIP_UID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.122. OTP_SIP_UID_VAL_7

Table 515. key_manager.OTP_SIP_UID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.123. OTP_SIP_UID_CPL_0

Table 516. key_manager.OTP_SIP_UID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.124. OTP_SIP_UID_CPL_1

Table 517. key_manager.OTP_SIP_UID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.125. OTP_SIP_UID_CPL_2

Table 518. key_manager.OTP_SIP_UID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.126. OTP_SIP_UID_CPL_3

Table 519. key_manager.OTP_SIP_UID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.127. OTP_SIP_UID_CPL_4

Table 520. key_manager.OTP_SIP_UID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.128. OTP_SIP_UID_CPL_5

Table 521. key_manager.OTP_SIP_UID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.129. OTP_SIP_UID_CPL_6

Table 522. key_manager.OTP_SIP_UID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.130. OTP_SIP_UID_CPL_7

Table 523. key_manager.OTP_SIP_UID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.131. OTP_SYS_UID_VAL_0

Table 524. key_manager.OTP_SYS_UID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.132. OTP_SYS_UID_VAL_1

Table 525. key_manager.OTP_SYS_UID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.133. OTP_SYS_UID_VAL_2

Table 526. key_manager.OTP_SYS_UID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.134. OTP_SYS_UID_VAL_3

Table 527. key_manager.OTP_SYS_UID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.135. OTP_SYS_UID_VAL_4

Table 528. key_manager.OTP_SYS_UID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.136. OTP_SYS_UID_VAL_5

Table 529. key_manager.OTP_SYS_UID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.137. OTP_SYS_UID_VAL_6

Table 530. key_manager.OTP_SYS_UID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.138. OTP_SYS_UID_VAL_7

Table 531. key_manager.OTP_SYS_UID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.139. OTP_SYS_UID_CPL_0

Table 532. key_manager.OTP_SYS_UID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.140. OTP_SYS_UID_CPL_1

Table 533. key_manager.OTP_SYS_UID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.141. OTP_SYS_UID_CPL_2

Table 534. key_manager.OTP_SYS_UID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.142. OTP_SYS_UID_CPL_3

Table 535. key_manager.OTP_SYS_UID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.143. OTP_SYS_UID_CPL_4

Table 536. key_manager.OTP_SYS_UID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.144. OTP_SYS_UID_CPL_5

Table 537. key_manager.OTP_SYS_UID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.145. OTP_SYS_UID_CPL_6

Table 538. key_manager.OTP_SYS_UID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.146. OTP_SYS_UID_CPL_7

Table 539. key_manager.OTP_SYS_UID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.147. OTP_CLASS_KEY_VAL_0

Table 540. key_manager.OTP_CLASS_KEY_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.148. OTP_CLASS_KEY_VAL_1

Table 541. key_manager.OTP_CLASS_KEY_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.149. OTP_CLASS_KEY_VAL_2

Table 542. key_manager.OTP_CLASS_KEY_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.150. OTP_CLASS_KEY_VAL_3

Table 543. key_manager.OTP_CLASS_KEY_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.151. OTP_CLASS_KEY_VAL_4

Table 544. key_manager.OTP_CLASS_KEY_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.152. OTP_CLASS_KEY_VAL_5

Table 545. key_manager.OTP_CLASS_KEY_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.153. OTP_CLASS_KEY_VAL_6

Table 546. key_manager.OTP_CLASS_KEY_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.154. OTP_CLASS_KEY_VAL_7

Table 547. key_manager.OTP_CLASS_KEY_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.155. OTP_CLASS_KEY_CPL_0

Table 548. key_manager.OTP_CLASS_KEY_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.156. OTP_CLASS_KEY_CPL_1

Table 549. key_manager.OTP_CLASS_KEY_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.157. OTP_CLASS_KEY_CPL_2

Table 550. key_manager.OTP_CLASS_KEY_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.158. OTP_CLASS_KEY_CPL_3

Table 551. key_manager.OTP_CLASS_KEY_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.159. OTP_CLASS_KEY_CPL_4

Table 552. key_manager.OTP_CLASS_KEY_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.160. OTP_CLASS_KEY_CPL_5

Table 553. key_manager.OTP_CLASS_KEY_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.161. OTP_CLASS_KEY_CPL_6

Table 554. key_manager.OTP_CLASS_KEY_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.162. OTP_CLASS_KEY_CPL_7

Table 555. key_manager.OTP_CLASS_KEY_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.163. OTP_READ_LOCK

Table 556. key_manager.OTP_READ_LOCK fields

Bits	Field	Access	Reset	Description
31:9	rsvd	R	0x0	Reserved
8	sep_sys_id	RW1S	0x0	Lock OTP_SEP_SYS_ID_VAL/CPL reads (returns zero when locked)
7	sep_sip_id	RW1S	0x0	Lock OTP_SEP_SIP_ID_VAL/CPL reads (returns zero when locked)
6	sep_chiplet_id	RW1S	0x0	Lock OTP_SEP_CHIPLET_ID_VAL/CPL reads (returns zero when locked)
5	class_key	RW1S	0x0	Lock OTP_CLASS_KEY_VAL/CPL reads (returns zero when locked)
4	sys_uid	RW1S	0x0	Lock OTP_SYS_UID_VAL/CPL reads (returns zero when locked)
3	sip_uid	RW1S	0x0	Lock OTP_SIP_UID_VAL/CPL reads (returns zero when locked)
2	chiplet_uid	RW1S	0x0	Lock OTP_CHIPLET_UID_VAL/CPL reads (returns zero when locked)
1	demotion	RW1S	0x0	Lock OTP_DEMOTION_STATE reads (returns zero when locked)
0	life_cycle	RW1S	0x0	Lock OTP_LIFE_CYCLE reads (returns zero when locked)

2.1.5.11.12.3.2.1.1.164. OTP_CHANGE_STATUS

Table 557. key_manager.OTP_CHANGE_STATUS fields

Bits	Field	Access	Reset	Description
31:9	rsvd	R	0x0	Reserved
8	sep_sys_id	RW1C	0x0	OTP_SEP_SYS_ID value changed since last cycle. Sticky, write 1 to clear.
7	sep_sip_id	RW1C	0x0	OTP_SEP_SIP_ID value changed since last cycle. Sticky, write 1 to clear.
6	sep_chiplet_id	RW1C	0x0	OTP_SEP_CHIPLET_ID value changed since last cycle. Sticky, write 1 to clear.
5	class_key	RW1C	0x0	OTP_CLASS_KEY value changed since last cycle. Sticky, write 1 to clear.
4	sys_uid	RW1C	0x0	OTP_SYS_UID value changed since last cycle. Sticky, write 1 to clear.
3	sip_uid	RW1C	0x0	OTP_SIP_UID value changed since last cycle. Sticky, write 1 to clear.
2	chiplet_uid	RW1C	0x0	OTP_CHIPLET_UID value changed since last cycle. Sticky, write 1 to clear.
1	demotion	RW1C	0x0	OTP_DEMOTION_STATE value changed since last cycle. Sticky, write 1 to clear.
0	life_cycle	RW1C	0x0	OTP_LIFE_CYCLE value changed since last cycle. Sticky, write 1 to clear.

2.1.5.11.12.3.2.1.1.165. OTP_READ_LOCK_COLD

Table 558. key_manager.OTP_READ_LOCK_COLD fields

Bits	Field	Access	Reset	Description
31:9	rsvd	R	0x0	Reserved
8	sep_sys_id	RW1S	0x0	Cold-reset read-lock for OTP_SEP_SYS_ID_VAL/CPL. Effective lock = OTP_READ_LOCK.sep_sys_id | OTP_READ_LOCK_COLD.sep_sys_id.
7	sep_sip_id	RW1S	0x0	Cold-reset read-lock for OTP_SEP_SIP_ID_VAL/CPL. Effective lock = OTP_READ_LOCK.sep_sip_id | OTP_READ_LOCK_COLD.sep_sip_id.

Bits	Field	Access	Reset	Description
6	sep_chiplet_id	RW1S	0x0	Cold-reset read-lock for OTP_SEP_CHIPLET_ID_VAL/CPL. Effective lock = OTP_READ_LOCK.sep_chiplet_id | OTP_READ_LOCK_COLD.sep_chiplet_id.
5	class_key	RW1S	0x0	Cold-reset read-lock for OTP_CLASS_KEY_VAL/CPL. Effective lock = OTP_READ_LOCK.class_key | OTP_READ_LOCK_COLD.class_key.
4	sys_uid	RW1S	0x0	Cold-reset read-lock for OTP_SYS_UID_VAL/CPL. Effective lock = OTP_READ_LOCK.sys_uid | OTP_READ_LOCK_COLD.sys_uid.
3	sip_uid	RW1S	0x0	Cold-reset read-lock for OTP_SIP_UID_VAL/CPL. Effective lock = OTP_READ_LOCK.sip_uid | OTP_READ_LOCK_COLD.sip_uid.
2	chiplet_uid	RW1S	0x0	Cold-reset read-lock for OTP_CHIPLET_UID_VAL/CPL. Effective lock = OTP_READ_LOCK.chiplet_uid | OTP_READ_LOCK_COLD.chiplet_uid.
1	demotion	RW1S	0x0	Cold-reset read-lock for OTP_DEMOTION_STATE. Effective lock = OTP_READ_LOCK.demotion | OTP_READ_LOCK_COLD.demotion.
0	life_cycle	RW1S	0x0	Cold-reset read-lock for OTP_LIFE_CYCLE. Effective lock = OTP_READ_LOCK.life_cycle | OTP_READ_LOCK_COLD.life_cycle.

2.1.5.11.12.3.2.1.1.166. OTP_SEP_CHIPLET_ID_VAL_0

Table 559. key_manager.OTP_SEP_CHIPLET_ID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.167. OTP_SEP_CHIPLET_ID_VAL_1

Table 560. key_manager.OTP_SEP_CHIPLET_ID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.168. OTP_SEP_CHIPLET_ID_VAL_2

Table 561. key_manager.OTP_SEP_CHIPLET_ID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.169. OTP_SEP_CHIPLET_ID_VAL_3

Table 562. key_manager.OTP_SEP_CHIPLET_ID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.170. OTP_SEP_CHIPLET_ID_VAL_4

Table 563. key_manager.OTP_SEP_CHIPLET_ID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.171. OTP_SEP_CHIPLET_ID_VAL_5

Table 564. key_manager.OTP_SEP_CHIPLET_ID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.172. OTP_SEP_CHIPLET_ID_VAL_6

Table 565. key_manager.OTP_SEP_CHIPLET_ID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.173. OTP_SEP_CHIPLET_ID_VAL_7

Table 566. key_manager.OTP_SEP_CHIPLET_ID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.174. OTP_SEP_CHIPLET_ID_CPL_0

Table 567. key_manager.OTP_SEP_CHIPLET_ID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.175. OTP_SEP_CHIPLET_ID_CPL_1

Table 568. key_manager.OTP_SEP_CHIPLET_ID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.176. OTP_SEP_CHIPLET_ID_CPL_2

Table 569. key_manager.OTP_SEP_CHIPLET_ID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.177. OTP_SEP_CHIPLET_ID_CPL_3

Table 570. key_manager.OTP_SEP_CHIPLET_ID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.178. OTP_SEP_CHIPLET_ID_CPL_4

Table 571. key_manager.OTP_SEP_CHIPLET_ID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.179. OTP_SEP_CHIPLET_ID_CPL_5

Table 572. key_manager.OTP_SEP_CHIPLET_ID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.180. OTP_SEP_CHIPLET_ID_CPL_6

Table 573. key_manager.OTP_SEP_CHIPLET_ID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.181. OTP_SEP_CHIPLET_ID_CPL_7

Table 574. key_manager.OTP_SEP_CHIPLET_ID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.182. OTP_SEP_SIP_ID_VAL_0

Table 575. key_manager.OTP_SEP_SIP_ID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.183. OTP_SEP_SIP_ID_VAL_1

Table 576. key_manager.OTP_SEP_SIP_ID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.184. OTP_SEP_SIP_ID_VAL_2

Table 577. key_manager.OTP_SEP_SIP_ID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.185. OTP_SEP_SIP_ID_VAL_3

Table 578. key_manager.OTP_SEP_SIP_ID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.186. OTP_SEP_SIP_ID_VAL_4

Table 579. key_manager.OTP_SEP_SIP_ID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.187. OTP_SEP_SIP_ID_VAL_5

Table 580. key_manager.OTP_SEP_SIP_ID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.188. OTP_SEP_SIP_ID_VAL_6

Table 581. key_manager.OTP_SEP_SIP_ID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.189. OTP_SEP_SIP_ID_VAL_7

Table 582. key_manager.OTP_SEP_SIP_ID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.190. OTP_SEP_SIP_ID_CPL_0

Table 583. key_manager.OTP_SEP_SIP_ID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.191. OTP_SEP_SIP_ID_CPL_1

Table 584. key_manager.OTP_SEP_SIP_ID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.192. OTP_SEP_SIP_ID_CPL_2

Table 585. key_manager.OTP_SEP_SIP_ID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.193. OTP_SEP_SIP_ID_CPL_3

Table 586. key_manager.OTP_SEP_SIP_ID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.194. OTP_SEP_SIP_ID_CPL_4

Table 587. key_manager.OTP_SEP_SIP_ID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.195. OTP_SEP_SIP_ID_CPL_5

Table 588. key_manager.OTP_SEP_SIP_ID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.196. OTP_SEP_SIP_ID_CPL_6

Table 589. key_manager.OTP_SEP_SIP_ID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.197. OTP_SEP_SIP_ID_CPL_7

Table 590. key_manager.OTP_SEP_SIP_ID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.198. OTP_SEP_SYS_ID_VAL_0

Table 591. key_manager.OTP_SEP_SYS_ID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.199. OTP_SEP_SYS_ID_VAL_1

Table 592. key_manager.OTP_SEP_SYS_ID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.200. OTP_SEP_SYS_ID_VAL_2

Table 593. key_manager.OTP_SEP_SYS_ID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.201. OTP_SEP_SYS_ID_VAL_3

Table 594. key_manager.OTP_SEP_SYS_ID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.202. OTP_SEP_SYS_ID_VAL_4

Table 595. key_manager.OTP_SEP_SYS_ID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.203. OTP_SEP_SYS_ID_VAL_5

Table 596. key_manager.OTP_SEP_SYS_ID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.204. OTP_SEP_SYS_ID_VAL_6

Table 597. key_manager.OTP_SEP_SYS_ID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.205. OTP_SEP_SYS_ID_VAL_7

Table 598. key_manager.OTP_SEP_SYS_ID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.206. OTP_SEP_SYS_ID_CPL_0

Table 599. key_manager.OTP_SEP_SYS_ID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.207. OTP_SEP_SYS_ID_CPL_1

Table 600. key_manager.OTP_SEP_SYS_ID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.208. OTP_SEP_SYS_ID_CPL_2

Table 601. key_manager.OTP_SEP_SYS_ID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.209. OTP_SEP_SYS_ID_CPL_3

Table 602. key_manager.OTP_SEP_SYS_ID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.210. OTP_SEP_SYS_ID_CPL_4

Table 603. key_manager.OTP_SEP_SYS_ID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.211. OTP_SEP_SYS_ID_CPL_5

Table 604. key_manager.OTP_SEP_SYS_ID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.212. OTP_SEP_SYS_ID_CPL_6

Table 605. key_manager.OTP_SEP_SYS_ID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.213. OTP_SEP_SYS_ID_CPL_7

Table 606. key_manager.OTP_SEP_SYS_ID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.1.1.214. DATA

Table 607. key_manager.DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	32-bit random data from DRBG. No reset for security; power-up value undefined.

2.1.5.11.12.3.2.1.1.215. CFG

Table 608. key_manager.CFG fields

Bits	Field	Access	Reset	Description
31:16	timeout	RW	0x100	Cycles to wait for DRBG on active CPU read; 0 = disable. Default 256.
15:1	rsvd	RW	0x0	Reserved

Bits	Field	Access	Reset	Description
0	prefetch	RW	0x0	Enable prefetch. When 0, prefetch data register is cleared.

2.1.5.11.12.3.2.1.1.216. STATUS

Table 609. key_manager.STATUS fields

Bits	Field	Access	Reset	Description
31:16	count_good	RW	0x0	Counts only reads completed through ST_RESPOND, excluding prefetched words. Saturates at 0xFFFF. Writing any non-zero value clears the field to 0; writing 0 has no effect.
15:8	count_bad	RW	0x0	Failed transactions (timeout or error). Saturates at 0xFF. Writing any non-zero value clears the field to 0; writing 0 has no effect.
7:4	rsvd	R	0x0	Reserved
3	stream_err	RW1C	0x0	Set when there is an error on the DRBG AXI-Stream interface (e.g. TVALID deasserted before TREADY). Write 1 to clear.
2	timeout_err	RW1C	0x0	Set when a DRBG read from the KM CPU times out. Write 1 to clear.
1	prefetched	R	0x0	Prefetched data available
0	drbg_ready	R	0x0	TVALID asserted from DRBG

2.1.5.11.12.3.2.1.1.217. PREFETCH_DATA

Table 610. key_manager.PREFETCH_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	Prefetched 32-bit random data. No reset for security; power-up value undefined.

2.1.5.11.12.3.2.1.1.218. KEY_SHARE0[12]

Table 611. key_manager.KEY_SHARE0[12] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.219. KEY_SHARE1[12]

Table 612. key_manager.KEY_SHARE1[12] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.220. otbn_wrapper_key.KEY_CTRL

Table 613. key_manager.otbn_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.1.1.221. aes_wrapper_key.KEY_SHARE0[8]

Table 614. key_manager.aes_wrapper_key.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.222. aes_wrapper_key.KEY_SHARE1[8]

Table 615. key_manager.aes_wrapper_key.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.223. aes_wrapper_key.KEY_CTRL

Table 616. key_manager.aes_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.1.1.224. kmac_wrapper_key.KEY_SHARE0[8]

Table 617. key_manager.kmac_wrapper_key.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.225. kmac_wrapper_key.KEY_SHARE1[8]

Table 618. key_manager.kmac_wrapper_key.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.226. kmac_wrapper_key.KEY_CTRL

Table 619. key_manager.kmac_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.1.1.227. hmac_wrapper_key.KEY_SHARE0[8]

Table 620. key_manager.hmac_wrapper_key.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.228. hmac_wrapper_key.KEY_SHARE1[8]

Table 621. key_manager.hmac_wrapper_key.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.229. hmac_wrapper_key.KEY_CTRL

Table 622. key_manager.hmac_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.1.1.230. abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8]

Table 623. key_manager.abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.231. abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8]

Table 624. key_manager.abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.232. abr_wrapper_key.MLDSA_SEED.KEY_CTRL

Table 625. key_manager.abr_wrapper_key.MLDSA_SEED.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.1.1.233. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8]

Table 626. key_manager.abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.234. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8]

Table 627. key_manager.abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.235. abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL

Table 628. key_manager.abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.1.1.236. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8]

Table 629. key_manager.abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.237. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8]

Table 630. key_manager.abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.238. abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL

Table 631. key_manager.abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.1.1.239. abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8]

Table 632. key_manager.abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.240. abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8]

Table 633. key_manager.abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.1.1.241. abr_wrapper_key.MLKEM_MSG.KEY_CTRL

Table 634. key_manager.abr_wrapper_key.MLKEM_MSG.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.1.1.242. KEY[8]

Table 635. key_manager.KEY[8] fields

Bits	Field	Access	Reset	Description
31:0	data	R	0x0	32-bit shared-key word. Hardware writes on key-ready event; hardware clears to 0 on key-consume event (KEY_VALID cleared).

2.1.5.11.12.3.2.1.1.243. abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL

Table 636. key_manager.abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW0C	0x0	1 = shared key is valid and ready for firmware consumption. Hardware sets this bit on key-ready event. Write 0 to clear; write 1 has no effect (software cannot set this bit).

2.1.5.11.12.3.2.1.1.244. abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_STATUS

Table 637. key_manager.abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW1C	0x0	ML-KEM shared key valid. Sticky, write 1 to clear.

2.1.5.11.12.3.2.1.1.245. abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_ENABLE

Table 638. key_manager.abr_wrapper_key.MLKEM_SHARED_KEY.IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid_en	RW	0x0	1 = enable PicoRV32 IRQ when ML-KEM shared key is valid. 0 = mask the interrupt (KEY_CTRL.KEY_VALID can still be polled).

2.1.5.11.12.3.2.2. Control and Status Registers

2.1.5.11.12.3.2.2.1. Key Manager Control and Status Registers

Control and status registers for the Key Manager subsystem

Table 639. Key Manager Control and Status Registers register list

Address	Name	Access	Description
0x0	VERSION	R	Hardware version register (semantic versioning: major.minor.patch)
0x4	CTRL	R	Control register (reserved for future use)
0x8	SOFT_RST_CODE	RW	Software reset code register. Write 0x53525354 ('SRST') to trigger soft reset. Any other value has no effect.
0xC	IRQ_STATUS	RW	Interrupt status register. Sticky bits cleared by writing 1.
0x10	IRQ_ENABLE	RW	Interrupt enable/mask register
0x14	SCRAMBLER_KEY	RW	32-bit scrambler key for SRAM address/data scrambling. When locked: writes ignored, reads return 0. No reset; powers up random.
0x18	SCRAMBLER_CTRL	RW	Scrambler control register

Address	Name	Access	Description
0x1C	SRAM_LOCK	RW	SRAM write-lock bits. Bit[i]=1 locks region i (1 KB each, 32 regions). Write-1-only: writing 1 sets the bit, writing 0 has no effect. Cleared by warm or cold reset (warm reset domain); ROM re-applies the lock policy on every boot before handover to mutable firmware.
0x20	IRQ_SET	W	Interrupt set register. Write 1 to trigger corresponding interrupt (for ISR testing). Write-only, reads return 0.
0x24	SRAM_WRITE_LOCK_VIOLATION	RW	Which SRAM region(s) had write attempts while locked. Bit[i]=region i. Sticky, write 1 to clear each bit.
0x28	RECOVERABLE_ERR	RW	Recoverable error status. Firmware writes 1 to set (after recovering in ISR), writes 0 to clear (e.g. when SEP requests clear). Drives recoverable error event output.
0x2C	BOOT_STATUS	RW	Boot status. Firmware writes 1 to COLD_BOOT_DONE after cold-boot init completes; bit remains set until next cold reset.
0x30	OTP_LIFE_CYCLE	R	Life cycle state. 8-bit (4-bit value differentially encoded). Read-through from OTP port; no reset.
0x34	OTP_DEMOTION_STATE	R	Demotion state. 2-bit, differentially encoded. Read-through from OTP port; no reset.
0x38	SRAM_EXEC_MODE	RW	Execute-permission whitelist mode. Write-1-only (woset); cleared by warm or cold reset. 0=ROM executable; 1=write-locked SRAM regions executable, and the ROM lockout is armed. Set by ROM stack-less handover immediately before jumping to mutable firmware.
0xB8	IRQ_ENTRY_ADDR	RW	Effective IRQ entry address for subsequent interrupts. Writable while unlocked; any 32-bit value accepted.
0xBC	IRQ_ENTRY_LOCK	RW	Write-one-only lock for IRQ_ENTRY_ADDR. Separate readable register; cleared only on KM reset.
0x100	VUART_TX	RW	Virtual UART transmit register. Write a byte to send to testbench. DATA_VALID is set on write and self-clears.
0x104	VUART_RX	R	Virtual UART receive register. Testbench writes bytes here for firmware to read.
0x108	VUART_STATUS	R	Virtual UART status register for flow control
0x110	TB_RESULT	RW	Test result register. Firmware writes 0=fail, 1=pass.
0x114	TB_SIGNATURE	RW	Test completion signature. Firmware writes 0x600D600D (pass) or 0xBADBADBA (fail).
0x118	TB_ERRCODE	RW	Test error code register. Firmware writes optional error code for debugging.
0x11C	TB_SUBTEST	RW	Current subtest number register. Firmware increments for each subtest.
0x120	TB_CMD	RW	Testbench command register. Firmware writes command, testbench reads and clears.
0x124	TB_CMD_ARG	RW	Testbench command argument register. Firmware writes optional argument.
0x128	TB_CMD_STATUS	RW	Testbench command status register. Testbench writes status, firmware reads.
0x12C	TB_CMD_RESULT	R	Testbench command result register. Testbench writes result value.
0x1FC	DEBUG	R	Debug register with known constant value for verification
0x200	OTP_CHIPLET_UID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field’s bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x204	OTP_CHIPLET_UID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field’s bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x208	OTP_CHIPLET_UID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x20C	OTP_CHIPLET_UID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x210	OTP_CHIPLET_UID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x214	OTP_CHIPLET_UID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x218	OTP_CHIPLET_UID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x21C	OTP_CHIPLET_UID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x220	OTP_CHIPLET_UID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x224	OTP_CHIPLET_UID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x228	OTP_CHIPLET_UID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x22C	OTP_CHIPLET_UID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x230	OTP_CHIPLET_UID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x234	OTP_CHIPLET_UID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x238	OTP_CHIPLET_UID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x23C	OTP_CHIPLET_UID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x240	OTP_SIP_UID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x244	OTP_SIP_UID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x248	OTP_SIP_UID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x24C	OTP_SIP_UID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x250	OTP_SIP_UID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x254	OTP_SIP_UID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x258	OTP_SIP_UID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x25C	OTP_SIP_UID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x260	OTP_SIP_UID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x264	OTP_SIP_UID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x268	OTP_SIP_UID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x26C	OTP_SIP_UID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x270	OTP_SIP_UID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x274	OTP_SIP_UID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x278	OTP_SIP_UID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x27C	OTP_SIP_UID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x280	OTP_SYS_UID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x284	OTP_SYS_UID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x288	OTP_SYS_UID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x28C	OTP_SYS_UID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x290	OTP_SYS_UID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x294	OTP_SYS_UID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x298	OTP_SYS_UID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x29C	OTP_SYS_UID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2A0	OTP_SYS_UID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2A4	OTP_SYS_UID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2A8	OTP_SYS_UID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2AC	OTP_SYS_UID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2B0	OTP_SYS_UID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2B4	OTP_SYS_UID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2B8	OTP_SYS_UID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2BC	OTP_SYS_UID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2C0	OTP_CLASS_KEY_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2C4	OTP_CLASS_KEY_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2C8	OTP_CLASS_KEY_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2CC	OTP_CLASS_KEY_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2D0	OTP_CLASS_KEY_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2D4	OTP_CLASS_KEY_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2D8	OTP_CLASS_KEY_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2DC	OTP_CLASS_KEY_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x2E0	OTP_CLASS_KEY_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2E4	OTP_CLASS_KEY_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2E8	OTP_CLASS_KEY_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2EC	OTP_CLASS_KEY_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2F0	OTP_CLASS_KEY_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2F4	OTP_CLASS_KEY_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2F8	OTP_CLASS_KEY_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x2FC	OTP_CLASS_KEY_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x300	OTP_READ_LOCK	RW	OTP field warm-reset-domain read-lock bits. Write 1 to set; writing 0 has no effect. Locked reads of the corresponding OTP field return zero (effective lock = OTP_READ_LOCK | OTP_READ_LOCK_COLD). Warm-reset domain: cleared by warm or cold reset.
0x304	OTP_CHANGE_STATUS	RW	OTP field change status. A bit is set when the corresponding field's decoded value changes. Sticky, write 1 to clear. Valid after IRQ_STATUS.OTP_CHANGE fires.
0x308	OTP_READ_LOCK_COLD	RW	OTP field cold-reset-domain read-lock bits. Write 1 to set; writing 0 has no effect. Locked reads of the corresponding OTP field return zero (effective lock = OTP_READ_LOCK | OTP_READ_LOCK_COLD). Cold-reset domain: survives warm reset.
0x400	OTP_SEP_CHIPLET_ID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x404	OTP_SEP_CHIPLET_ID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x408	OTP_SEP_CHIPLET_ID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x40C	OTP_SEP_CHIPLET_ID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x410	OTP_SEP_CHIPLET_ID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x414	OTP_SEP_CHIPLET_ID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x418	OTP_SEP_CHIPLET_ID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x41C	OTP_SEP_CHIPLET_ID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x420	OTP_SEP_CHIPLET_ID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x424	OTP_SEP_CHIPLET_ID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x428	OTP_SEP_CHIPLET_ID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x42C	OTP_SEP_CHIPLET_ID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x430	OTP_SEP_CHIPLET_ID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x434	OTP_SEP_CHIPLET_ID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x438	OTP_SEP_CHIPLET_ID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x43C	OTP_SEP_CHIPLET_ID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x440	OTP_SEP_SIP_ID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x444	OTP_SEP_SIP_ID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x448	OTP_SEP_SIP_ID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x44C	OTP_SEP_SIP_ID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x450	OTP_SEP_SIP_ID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x454	OTP_SEP_SIP_ID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x458	OTP_SEP_SIP_ID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x45C	OTP_SEP_SIP_ID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x460	OTP_SEP_SIP_ID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x464	OTP_SEP_SIP_ID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x468	OTP_SEP_SIP_ID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x46C	OTP_SEP_SIP_ID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x470	OTP_SEP_SIP_ID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x474	OTP_SEP_SIP_ID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x478	OTP_SEP_SIP_ID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x47C	OTP_SEP_SIP_ID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x480	OTP_SEP_SYS_ID_VAL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x484	OTP_SEP_SYS_ID_VAL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x488	OTP_SEP_SYS_ID_VAL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x48C	OTP_SEP_SYS_ID_VAL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x490	OTP_SEP_SYS_ID_VAL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x494	OTP_SEP_SYS_ID_VAL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x498	OTP_SEP_SYS_ID_VAL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x49C	OTP_SEP_SYS_ID_VAL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4A0	OTP_SEP_SYS_ID_CPL_0	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4A4	OTP_SEP_SYS_ID_CPL_1	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

Address	Name	Access	Description
0x4A8	OTP_SEP_SYS_ID_CPL_2	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4AC	OTP_SEP_SYS_ID_CPL_3	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4B0	OTP_SEP_SYS_ID_CPL_4	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4B4	OTP_SEP_SYS_ID_CPL_5	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4B8	OTP_SEP_SYS_ID_CPL_6	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.
0x4BC	OTP_SEP_SYS_ID_CPL_7	R	Dual-rail OTP readout word (value or complement half). Read-through from OTP port; no reset. Returns zero when the field's bit is set in either OTP_READ_LOCK or OTP_READ_LOCK_COLD.

2.1.5.11.12.3.2.2.1.1. VERSION

Table 640. km_csr.VERSION fields

Bits	Field	Access	Reset	Description
31:24	rsvd	R	0x0	Reserved; must read as zero
23:16	major	R	0x1	Major version number
15:8	minor	R	0x0	Minor version number
7:0	patch	R	0x0	Patch version number

2.1.5.11.12.3.2.2.1.2. CTRL

Table 641. km_csr.CTRL fields

Bits	Field	Access	Reset	Description
31:0	rsvd	R	0x0	Reserved

2.1.5.11.12.3.2.2.1.3. SOFT_RST_CODE

Table 642. km_csr.SOFT_RST_CODE fields

Bits	Field	Access	Reset	Description
31:0	code	RW	0x0	32-bit reset code. Write 0x53525354 to trigger soft reset.

2.1.5.11.12.3.2.2.1.4. IRQ_STATUS

Table 643. km_csr.IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:12	rsvd	R	0x0	Reserved
11	rom_access_violation	RW1C	0x0	KM ROM instruction fetch or data read attempted after the ROM lockout engaged. The lockout engages on the first committed instruction fetch from write-locked SRAM once SRAM_EXEC_MODE.enable is set, and clears only on warm or cold reset. Sticky, write 1 to clear.

Bits	Field	Access	Reset	Description
10	exec_violation	RW1C	0x0	Instruction fetch from a non-whitelisted (non-executable) memory region detected, excluding the KM ROM. Sticky, write 1 to clear.
9	otp_sigint	RW1C	0x0	OTP dual-rail encoding integrity violation: value and complement are not complementary on at least one field. Sticky, write 1 to clear.
8	otp_change	RW1C	0x0	An OTP readout field value changed (decoded value differs from prior cycle). Sticky, write 1 to clear. Check OTP_CHANGE_STATUS for the specific field(s).
7	wipe_state	RW1C	0x0	Wipe state event (rising edge of wipe_state input). Sticky, write 1 to clear.
6	drbg_err	RW1C	0x0	DRBG Sampler error (timeout or AXI-Stream error). Sticky, write 1 to clear.
5	axi_decerr	RW1C	0x0	AXI DECERR (decode error) response detected on CPU bus transaction. Sticky, write 1 to clear.
4	axi_slverr	RW1C	0x0	AXI SLVERR (slave error) response detected on CPU bus transaction. Sticky, write 1 to clear.
3	sram_write_lock_err	RW1C	0x0	SRAM write attempt to a write-locked region detected. Sticky, write 1 to clear.
2	rom_write_err	RW1C	0x0	ROM write attempt detected (ROM is read-only). Sticky, write 1 to clear.
1	sram_parity_err	RW1C	0x0	SRAM parity error detected. Sticky, write 1 to clear.
0	rom_parity_err	RW1C	0x0	ROM parity error detected. Sticky, write 1 to clear.

2.1.5.11.12.3.2.2.1.5. IRQ_ENABLE

Table 644. km_csr.IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:12	rsvd	R	0x0	Reserved
11	rom_access_violation_en	RW	0x0	Enable ROM lockout violation interrupt
10	exec_violation_en	RW	0x0	Enable execute-permission whitelist violation interrupt
9	otp_sigint_en	RW	0x0	Enable OTP dual-rail integrity violation interrupt
8	otp_change_en	RW	0x0	Enable OTP field change interrupt
7	wipe_state_en	RW	0x0	Enable wipe state interrupt
6	drbg_err_en	RW	0x0	Enable DRBG Sampler error interrupt
5	axi_decerr_en	RW	0x0	Enable AXI DECERR error interrupt
4	axi_slverr_en	RW	0x0	Enable AXI SLVERR error interrupt
3	sram_write_lock_en	RW	0x0	Enable SRAM write-lock violation interrupt
2	rom_write_en	RW	0x0	Enable ROM write error interrupt
1	sram_parity_en	RW	0x0	Enable SRAM parity error interrupt
0	rom_parity_en	RW	0x0	Enable ROM parity error interrupt

2.1.5.11.12.3.2.2.1.6. SCRAMBLER_KEY

Table 645. km_csr.SCRAMBLER_KEY fields

Bits	Field	Access	Reset	Description
31:0	key	RW	-	Scrambler key value. Not readable when SCRAMBLER_CTRL.LOCK=1 (returns 0). No reset for security; power-up value undefined.

2.1.5.11.12.3.2.2.1.7. SCRAMBLER_CTRL

Table 646. km_csr.SCRAMBLER_CTRL fields

Bits	Field	Access	Reset	Description
31:2	rsvd	R	0x0	Reserved
1	lock	RW	0x0	Lock scrambler key and enable bit. Once set, key and enable cannot be modified until reset. Write-once (0→1 only). Security requirement: prevents disabling scrambling after key provisioning.
0	enable	RW	0x0	Enable SRAM scrambling. When 0, data passes through unmodified. Locked when LOCK=1 (security requirement).

2.1.5.11.12.3.2.2.1.8. SRAM_LOCK

Table 647. km_csr.SRAM_LOCK fields

Bits	Field	Access	Reset	Description
31:0	lock_bits	RW1S	0x0	One bit per 1 KB SRAM region. Region 0 = 0x8000-0x83FF, region 31 = 0xFC00-0xFFFF. Write 1 to lock; 0 has no effect. Warm reset domain: cleared by warm or cold reset.

2.1.5.11.12.3.2.2.1.9. IRQ_SET

Table 648. km_csr.IRQ_SET fields

Bits	Field	Access	Reset	Description
31:12	rsvd	W	0x0	Reserved (write-only; reads trigger SLVERR via err_if_bad_rw)
11	rom_access_violation_set	W 1P	0x0	Write 1 to set IRQ_STATUS.ROM_ACCESS_VIOLATION (triggers ROM lockout violation interrupt for testing)
10	exec_violation_set	W 1P	0x0	Write 1 to set IRQ_STATUS.EXEC_VIOLATION (triggers exec-permission violation interrupt for testing)
9	otp_sigint_set	W 1P	0x0	Write 1 to set IRQ_STATUS.OTP_SIGINT (triggers OTP sigint interrupt for testing)
8	otp_change_set	W 1P	0x0	Write 1 to set IRQ_STATUS.OTP_CHANGE (triggers OTP change interrupt for testing)
7	wipe_state_set	W 1P	0x0	Write 1 to set IRQ_STATUS.WIPE_STATE (triggers wipe state interrupt for testing)
6	drbg_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.DRBG_ERR (triggers DRBG Sampler interrupt for testing)
5	axi_decerr_set	W 1P	0x0	Write 1 to set IRQ_STATUS.AXI_DECERR (triggers AXI DECERR interrupt for testing)
4	axi_slverr_set	W 1P	0x0	Write 1 to set IRQ_STATUS.AXI_SLVERR (triggers AXI SLVERR interrupt for testing)
3	sram_write_lock_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.SRAM_WRITE_LOCK_ERR (triggers SRAM write-lock interrupt for testing)
2	rom_write_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.ROM_WRITE_ERR (triggers ROM write interrupt for testing)
1	sram_parity_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.SRAM_PARITY_ERR (triggers SRAM parity interrupt for testing)
0	rom_parity_err_set	W 1P	0x0	Write 1 to set IRQ_STATUS.ROM_PARITY_ERR (triggers ROM parity interrupt for testing)

2.1.5.11.12.3.2.2.1.10. SRAM_WRITE_LOCK_VIOLATION

Table 649. km_csr.SRAM_WRITE_LOCK_VIOLATION fields

Bits	Field	Access	Reset	Description
31:0	violation_bits	RW1C	0x0	Bit[i]=1 if region i had attempted write while locked. Sticky, write 1 to clear each bit.

2.1.5.11.12.3.2.2.1.11. RECOVERABLE_ERR

Table 650. km_csr.RECOVERABLE_ERR fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	recoverable_err	RW	0x0	1 = recoverable fault occurred and was handled by ISR; 0 = clear. Write 1 to set, write 0 to clear.

2.1.5.11.12.3.2.2.1.12. BOOT_STATUS

Table 651. km_csr.BOOT_STATUS fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	cold_boot_done	RW1S	0x0	Write-1-only: set by ROM firmware at end of cold boot. Reads 0 after cold reset; reads 1 after firmware sets it. Sticky until next cold reset (preserved across warm resets).

2.1.5.11.12.3.2.2.1.13. OTP_LIFE_CYCLE

Table 652. km_csr.OTP_LIFE_CYCLE fields

Bits	Field	Access	Reset	Description
31:8	rsvd	R	0x0	Reserved
7:0	value	R	-	8-bit life cycle state from OTP. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.14. OTP_DEMOTION_STATE

Table 653. km_csr.OTP_DEMOTION_STATE fields

Bits	Field	Access	Reset	Description
31:4	rsvd	R	0x0	Reserved
3:2	demote_2_value	R	-	2-bit demotion 2 state from OTP. No reset; power-up value undefined.
1:0	demote_1_value	R	-	2-bit demotion 1 state from OTP. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.15. SRAM_EXEC_MODE

Table 654. km_csr.SRAM_EXEC_MODE fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	enable	RW1S	0x0	Execute-permission mode: 0=ROM-only whitelist; 1=write-locked SRAM whitelist, arming the ROM lockout. Write 1 to set; write 0 has no effect. Warm reset domain: cleared by warm or cold reset.

2.1.5.11.12.3.2.2.1.16. IRQ_ENTRY_ADDR

Table 655. km_csr.IRQ_ENTRY_ADDR fields

Bits	Field	Access	Reset	Description
31:0	addr	RW	0x10	IRQ handler entry PC. Reset matches ROM vector at 0x10. When locked, SW writes do not update storage.

2.1.5.11.12.3.2.2.1.17. IRQ_ENTRY_LOCK

Table 656. km_csr.IRQ_ENTRY_LOCK fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved; reads as zero.
0	lock	RW1S	0x0	Write 1 to set; write 0 has no effect; sticky until reset.

2.1.5.11.12.3.2.2.1.18. VUART_TX

Table 657. km_csr.VUART_TX fields

Bits	Field	Access	Reset	Description
31	data_valid	RW	0x0	Data valid strobe. Set by firmware on write, cleared by hardware after one cycle.
30:8	rsvd0	R	0x0	Reserved
7:0	tx_byte	RW	0x0	Byte to transmit (write to send character to testbench)

2.1.5.11.12.3.2.2.1.19. VUART_RX

Table 658. km_csr.VUART_RX fields

Bits	Field	Access	Reset	Description
31	data_valid	R	0x0	RX data valid. Set by testbench, cleared by firmware read.
30:8	rsvd0	R	0x0	Reserved
7:0	rx_byte	R	0x0	Received byte from testbench

2.1.5.11.12.3.2.2.1.20. VUART_STATUS

Table 659. km_csr.VUART_STATUS fields

Bits	Field	Access	Reset	Description
31:3	rsvd	R	0x0	Reserved
2	print_enable	R	0x0	Enable VUART printing. Set by testbench to enable printf output. Disabled by default to save simulation time.
1	rx_valid	R	0x0	RX has valid data available
0	tx_ready	R	0x1	TX ready to accept data (always 1 in simulation)

2.1.5.11.12.3.2.2.1.21. TB_RESULT

Table 660. km_csr.TB_RESULT fields

Bits	Field	Access	Reset	Description
31:0	result	RW	0x0	Test result: 0=fail, 1=pass

2.1.5.11.12.3.2.2.1.22. TB_SIGNATURE

Table 661. km_csr.TB_SIGNATURE fields

Bits	Field	Access	Reset	Description
31:0	signature	RW	0x0	Completion signature value

2.1.5.11.12.3.2.2.1.23. TB_ERRCODE

Table 662. km_csr.TB_ERRCODE fields

Bits	Field	Access	Reset	Description
31:0	errcode	RW	0x0	Error code value

2.1.5.11.12.3.2.2.1.24. TB_SUBTEST

Table 663. km_csr.TB_SUBTEST fields

Bits	Field	Access	Reset	Description
31:0	subtest	RW	0x0	Current subtest number

2.1.5.11.12.3.2.2.1.25. TB_CMD

Table 664. km_csr.TB_CMD fields

Bits	Field	Access	Reset	Description
31:0	cmd	RW	0x0	Command code (0=NOP, 1=ROM_PARITY_EN, 2=ROM_PARITY_DIS, 3=SRAM_PARITY_EN, 4=SRAM_PARITY_DIS)

2.1.5.11.12.3.2.2.1.26. TB_CMD_ARG

Table 665. km_csr.TB_CMD_ARG fields

Bits	Field	Access	Reset	Description
31:0	arg	RW	0x0	Command argument value

2.1.5.11.12.3.2.2.1.27. TB_CMD_STATUS

Table 666. km_csr.TB_CMD_STATUS fields

Bits	Field	Access	Reset	Description
31:0	status	RW	0x0	Command status: 0=IDLE, 1=ACK, 0xFFFFFFFF=ERR

2.1.5.11.12.3.2.2.1.28. TB_CMD_RESULT

Table 667. km_csr.TB_CMD_RESULT fields

Bits	Field	Access	Reset	Description
31:0	result	R	0x0	Command result value

2.1.5.11.12.3.2.2.1.29. DEBUG

Table 668. km_csr.DEBUG fields

Bits	Field	Access	Reset	Description
31:0	magic	R	0xCAFEBEEF	Magic constant: 0xCAFEBEEF

2.1.5.11.12.3.2.2.1.30. OTP_CHIPLET_UID_VAL_0

Table 669. km_csr.OTP_CHIPLET_UID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.31. OTP_CHIPLET_UID_VAL_1

Table 670. km_csr.OTP_CHIPLET_UID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.32. OTP_CHIPLET_UID_VAL_2

Table 671. km_csr.OTP_CHIPLET_UID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.33. OTP_CHIPLET_UID_VAL_3

Table 672. km_csr.OTP_CHIPLET_UID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.34. OTP_CHIPLET_UID_VAL_4

Table 673. km_csr.OTP_CHIPLET_UID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.35. OTP_CHIPLET_UID_VAL_5

Table 674. km_csr.OTP_CHIPLET_UID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.36. OTP_CHIPLET_UID_VAL_6

Table 675. km_csr.OTP_CHIPLET_UID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.37. OTP_CHIPLET_UID_VAL_7

Table 676. km_csr.OTP_CHIPLET_UID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.38. OTP_CHIPLET_UID_CPL_0

Table 677. km_csr.OTP_CHIPLET_UID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.39. OTP_CHIPLET_UID_CPL_1

Table 678. km_csr.OTP_CHIPLET_UID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.40. OTP_CHIPLET_UID_CPL_2

Table 679. km_csr.OTP_CHIPLET_UID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.41. OTP_CHIPLET_UID_CPL_3

Table 680. km_csr.OTP_CHIPLET_UID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.42. OTP_CHIPLET_UID_CPL_4

Table 681. km_csr.OTP_CHIPLET_UID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.43. OTP_CHIPLET_UID_CPL_5

Table 682. km_csr.OTP_CHIPLET_UID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.44. OTP_CHIPLET_UID_CPL_6

Table 683. km_csr.OTP_CHIPLET_UID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.45. OTP_CHIPLET_UID_CPL_7

Table 684. km_csr.OTP_CHIPLET_UID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.46. OTP_SIP_UID_VAL_0

Table 685. km_csr.OTP_SIP_UID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.47. OTP_SIP_UID_VAL_1

Table 686. km_csr.OTP_SIP_UID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.48. OTP_SIP_UID_VAL_2

Table 687. km_csr.OTP_SIP_UID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.49. OTP_SIP_UID_VAL_3

Table 688. km_csr.OTP_SIP_UID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.50. OTP_SIP_UID_VAL_4

Table 689. km_csr.OTP_SIP_UID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.51. OTP_SIP_UID_VAL_5

Table 690. km_csr.OTP_SIP_UID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.52. OTP_SIP_UID_VAL_6

Table 691. km_csr.OTP_SIP_UID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.53. OTP_SIP_UID_VAL_7

Table 692. km_csr.OTP_SIP_UID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.54. OTP_SIP_UID_CPL_0

Table 693. km_csr.OTP_SIP_UID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.55. OTP_SIP_UID_CPL_1

Table 694. km_csr.OTP_SIP_UID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.56. OTP_SIP_UID_CPL_2

Table 695. km_csr.OTP_SIP_UID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.57. OTP_SIP_UID_CPL_3

Table 696. km_csr.OTP_SIP_UID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.58. OTP_SIP_UID_CPL_4

Table 697. km_csr.OTP_SIP_UID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.59. OTP_SIP_UID_CPL_5

Table 698. km_csr.OTP_SIP_UID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.60. OTP_SIP_UID_CPL_6

Table 699. km_csr.OTP_SIP_UID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.61. OTP_SIP_UID_CPL_7

Table 700. km_csr.OTP_SIP_UID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.62. OTP_SYS_UID_VAL_0

Table 701. km_csr.OTP_SYS_UID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.63. OTP_SYS_UID_VAL_1

Table 702. km_csr.OTP_SYS_UID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.64. OTP_SYS_UID_VAL_2

Table 703. km_csr.OTP_SYS_UID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.65. OTP_SYS_UID_VAL_3

Table 704. km_csr.OTP_SYS_UID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.66. OTP_SYS_UID_VAL_4

Table 705. km_csr.OTP_SYS_UID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.67. OTP_SYS_UID_VAL_5

Table 706. km_csr.OTP_SYS_UID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.68. OTP_SYS_UID_VAL_6

Table 707. km_csr.OTP_SYS_UID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.69. OTP_SYS_UID_VAL_7

Table 708. km_csr.OTP_SYS_UID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.70. OTP_SYS_UID_CPL_0

Table 709. km_csr.OTP_SYS_UID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.71. OTP_SYS_UID_CPL_1

Table 710. km_csr.OTP_SYS_UID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.72. OTP_SYS_UID_CPL_2

Table 711. km_csr.OTP_SYS_UID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.73. OTP_SYS_UID_CPL_3

Table 712. km_csr.OTP_SYS_UID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.74. OTP_SYS_UID_CPL_4

Table 713. km_csr.OTP_SYS_UID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.75. OTP_SYS_UID_CPL_5

Table 714. km_csr.OTP_SYS_UID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.76. OTP_SYS_UID_CPL_6

Table 715. km_csr.OTP_SYS_UID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.77. OTP_SYS_UID_CPL_7

Table 716. km_csr.OTP_SYS_UID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.78. OTP_CLASS_KEY_VAL_0

Table 717. km_csr.OTP_CLASS_KEY_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.79. OTP_CLASS_KEY_VAL_1

Table 718. km_csr.OTP_CLASS_KEY_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.80. OTP_CLASS_KEY_VAL_2

Table 719. km_csr.OTP_CLASS_KEY_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.81. OTP_CLASS_KEY_VAL_3

Table 720. km_csr.OTP_CLASS_KEY_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.82. OTP_CLASS_KEY_VAL_4

Table 721. km_csr.OTP_CLASS_KEY_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.83. OTP_CLASS_KEY_VAL_5

Table 722. km_csr.OTP_CLASS_KEY_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.84. OTP_CLASS_KEY_VAL_6

Table 723. km_csr.OTP_CLASS_KEY_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.85. OTP_CLASS_KEY_VAL_7

Table 724. km_csr.OTP_CLASS_KEY_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.86. OTP_CLASS_KEY_CPL_0

Table 725. km_csr.OTP_CLASS_KEY_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.87. OTP_CLASS_KEY_CPL_1

Table 726. km_csr.OTP_CLASS_KEY_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.88. OTP_CLASS_KEY_CPL_2

Table 727. km_csr.OTP_CLASS_KEY_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.89. OTP_CLASS_KEY_CPL_3

Table 728. km_csr.OTP_CLASS_KEY_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.90. OTP_CLASS_KEY_CPL_4

Table 729. km_csr.OTP_CLASS_KEY_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.91. OTP_CLASS_KEY_CPL_5

Table 730. km_csr.OTP_CLASS_KEY_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.92. OTP_CLASS_KEY_CPL_6

Table 731. km_csr.OTP_CLASS_KEY_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.93. OTP_CLASS_KEY_CPL_7

Table 732. km_csr.OTP_CLASS_KEY_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.94. OTP_READ_LOCK

Table 733. km_csr.OTP_READ_LOCK fields

Bits	Field	Access	Reset	Description
31:9	rsvd	R	0x0	Reserved
8	sep_sys_id	RW1S	0x0	Lock OTP_SEP_SYS_ID_VAL/CPL reads (returns zero when locked)
7	sep_sip_id	RW1S	0x0	Lock OTP_SEP_SIP_ID_VAL/CPL reads (returns zero when locked)
6	sep_chiplet_id	RW1S	0x0	Lock OTP_SEP_CHIPLET_ID_VAL/CPL reads (returns zero when locked)
5	class_key	RW1S	0x0	Lock OTP_CLASS_KEY_VAL/CPL reads (returns zero when locked)
4	sys_uid	RW1S	0x0	Lock OTP_SYS_UID_VAL/CPL reads (returns zero when locked)
3	sip_uid	RW1S	0x0	Lock OTP_SIP_UID_VAL/CPL reads (returns zero when locked)
2	chiplet_uid	RW1S	0x0	Lock OTP_CHIPLET_UID_VAL/CPL reads (returns zero when locked)
1	demotion	RW1S	0x0	Lock OTP_DEMOTION_STATE reads (returns zero when locked)
0	life_cycle	RW1S	0x0	Lock OTP_LIFE_CYCLE reads (returns zero when locked)

2.1.5.11.12.3.2.2.1.95. OTP_CHANGE_STATUS

Table 734. km_csr.OTP_CHANGE_STATUS fields

Bits	Field	Access	Reset	Description
31:9	rsvd	R	0x0	Reserved
8	sep_sys_id	RW1C	0x0	OTP_SEP_SYS_ID value changed since last cycle. Sticky, write 1 to clear.
7	sep_sip_id	RW1C	0x0	OTP_SEP_SIP_ID value changed since last cycle. Sticky, write 1 to clear.
6	sep_chiplet_id	RW1C	0x0	OTP_SEP_CHIPLET_ID value changed since last cycle. Sticky, write 1 to clear.
5	class_key	RW1C	0x0	OTP_CLASS_KEY value changed since last cycle. Sticky, write 1 to clear.
4	sys_uid	RW1C	0x0	OTP_SYS_UID value changed since last cycle. Sticky, write 1 to clear.
3	sip_uid	RW1C	0x0	OTP_SIP_UID value changed since last cycle. Sticky, write 1 to clear.
2	chiplet_uid	RW1C	0x0	OTP_CHIPLET_UID value changed since last cycle. Sticky, write 1 to clear.
1	demotion	RW1C	0x0	OTP_DEMOTION_STATE value changed since last cycle. Sticky, write 1 to clear.
0	life_cycle	RW1C	0x0	OTP_LIFE_CYCLE value changed since last cycle. Sticky, write 1 to clear.

2.1.5.11.12.3.2.2.1.96. OTP_READ_LOCK_COLD

Table 735. km_csr.OTP_READ_LOCK_COLD fields

Bits	Field	Access	Reset	Description
31:9	rsvd	R	0x0	Reserved
8	sep_sys_id	RW1S	0x0	Cold-reset read-lock for OTP_SEP_SYS_ID_VAL/CPL. Effective lock = OTP_READ_LOCK.sep_sys_id | OTP_READ_LOCK_COLD.sep_sys_id.
7	sep_sip_id	RW1S	0x0	Cold-reset read-lock for OTP_SEP_SIP_ID_VAL/CPL. Effective lock = OTP_READ_LOCK.sep_sip_id | OTP_READ_LOCK_COLD.sep_sip_id.
6	sep_chiplet_id	RW1S	0x0	Cold-reset read-lock for OTP_SEP_CHIPLET_ID_VAL/CPL. Effective lock = OTP_READ_LOCK.sep_chiplet_id | OTP_READ_LOCK_COLD.sep_chiplet_id.
5	class_key	RW1S	0x0	Cold-reset read-lock for OTP_CLASS_KEY_VAL/CPL. Effective lock = OTP_READ_LOCK.class_key | OTP_READ_LOCK_COLD.class_key.
4	sys_uid	RW1S	0x0	Cold-reset read-lock for OTP_SYS_UID_VAL/CPL. Effective lock = OTP_READ_LOCK.sys_uid | OTP_READ_LOCK_COLD.sys_uid.
3	sip_uid	RW1S	0x0	Cold-reset read-lock for OTP_SIP_UID_VAL/CPL. Effective lock = OTP_READ_LOCK.sip_uid | OTP_READ_LOCK_COLD.sip_uid.
2	chiplet_uid	RW1S	0x0	Cold-reset read-lock for OTP_CHIPLET_UID_VAL/CPL. Effective lock = OTP_READ_LOCK.chiplet_uid | OTP_READ_LOCK_COLD.chiplet_uid.
1	demotion	RW1S	0x0	Cold-reset read-lock for OTP_DEMOTION_STATE. Effective lock = OTP_READ_LOCK.demotion | OTP_READ_LOCK_COLD.demotion.
0	life_cycle	RW1S	0x0	Cold-reset read-lock for OTP_LIFE_CYCLE. Effective lock = OTP_READ_LOCK.life_cycle | OTP_READ_LOCK_COLD.life_cycle.

2.1.5.11.12.3.2.2.1.97. OTP_SEP_CHIPLET_ID_VAL_0

Table 736. km_csr.OTP_SEP_CHIPLET_ID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.98. OTP_SEP_CHIPLET_ID_VAL_1

Table 737. km_csr.OTP_SEP_CHIPLET_ID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.99. OTP_SEP_CHIPLET_ID_VAL_2

Table 738. km_csr.OTP_SEP_CHIPLET_ID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.100. OTP_SEP_CHIPLET_ID_VAL_3

Table 739. km_csr.OTP_SEP_CHIPLET_ID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.101. OTP_SEP_CHIPLET_ID_VAL_4

Table 740. km_csr.OTP_SEP_CHIPLET_ID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.102. OTP_SEP_CHIPLET_ID_VAL_5

Table 741. km_csr.OTP_SEP_CHIPLET_ID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.103. OTP_SEP_CHIPLET_ID_VAL_6

Table 742. km_csr.OTP_SEP_CHIPLET_ID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.104. OTP_SEP_CHIPLET_ID_VAL_7

Table 743. km_csr.OTP_SEP_CHIPLET_ID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.105. OTP_SEP_CHIPLET_ID_CPL_0

Table 744. km_csr.OTP_SEP_CHIPLET_ID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.106. OTP_SEP_CHIPLET_ID_CPL_1

Table 745. km_csr.OTP_SEP_CHIPLET_ID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.107. OTP_SEP_CHIPLET_ID_CPL_2

Table 746. km_csr.OTP_SEP_CHIPLET_ID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.108. OTP_SEP_CHIPLET_ID_CPL_3

Table 747. km_csr.OTP_SEP_CHIPLET_ID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.109. OTP_SEP_CHIPLET_ID_CPL_4

Table 748. km_csr.OTP_SEP_CHIPLET_ID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.110. OTP_SEP_CHIPLET_ID_CPL_5

Table 749. km_csr.OTP_SEP_CHIPLET_ID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.111. OTP_SEP_CHIPLET_ID_CPL_6

Table 750. km_csr.OTP_SEP_CHIPLET_ID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.112. OTP_SEP_CHIPLET_ID_CPL_7

Table 751. km_csr.OTP_SEP_CHIPLET_ID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.113. OTP_SEP_SIP_ID_VAL_0

Table 752. km_csr.OTP_SEP_SIP_ID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.114. OTP_SEP_SIP_ID_VAL_1

Table 753. km_csr.OTP_SEP_SIP_ID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.115. OTP_SEP_SIP_ID_VAL_2

Table 754. km_csr.OTP_SEP_SIP_ID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.116. OTP_SEP_SIP_ID_VAL_3

Table 755. km_csr.OTP_SEP_SIP_ID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.117. OTP_SEP_SIP_ID_VAL_4

Table 756. km_csr.OTP_SEP_SIP_ID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.118. OTP_SEP_SIP_ID_VAL_5

Table 757. km_csr.OTP_SEP_SIP_ID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.119. OTP_SEP_SIP_ID_VAL_6

Table 758. km_csr.OTP_SEP_SIP_ID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.120. OTP_SEP_SIP_ID_VAL_7

Table 759. km_csr.OTP_SEP_SIP_ID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.121. OTP_SEP_SIP_ID_CPL_0

Table 760. km_csr.OTP_SEP_SIP_ID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.122. OTP_SEP_SIP_ID_CPL_1

Table 761. km_csr.OTP_SEP_SIP_ID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.123. OTP_SEP_SIP_ID_CPL_2

Table 762. km_csr.OTP_SEP_SIP_ID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.124. OTP_SEP_SIP_ID_CPL_3

Table 763. km_csr.OTP_SEP_SIP_ID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.125. OTP_SEP_SIP_ID_CPL_4

Table 764. km_csr.OTP_SEP_SIP_ID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.126. OTP_SEP_SIP_ID_CPL_5

Table 765. km_csr.OTP_SEP_SIP_ID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.127. OTP_SEP_SIP_ID_CPL_6

Table 766. km_csr.OTP_SEP_SIP_ID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.128. OTP_SEP_SIP_ID_CPL_7

Table 767. km_csr.OTP_SEP_SIP_ID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.129. OTP_SEP_SYS_ID_VAL_0

Table 768. km_csr.OTP_SEP_SYS_ID_VAL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.130. OTP_SEP_SYS_ID_VAL_1

Table 769. km_csr.OTP_SEP_SYS_ID_VAL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.131. OTP_SEP_SYS_ID_VAL_2

Table 770. km_csr.OTP_SEP_SYS_ID_VAL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.132. OTP_SEP_SYS_ID_VAL_3

Table 771. km_csr.OTP_SEP_SYS_ID_VAL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.133. OTP_SEP_SYS_ID_VAL_4

Table 772. km_csr.OTP_SEP_SYS_ID_VAL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.134. OTP_SEP_SYS_ID_VAL_5

Table 773. km_csr.OTP_SEP_SYS_ID_VAL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.135. OTP_SEP_SYS_ID_VAL_6

Table 774. km_csr.OTP_SEP_SYS_ID_VAL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.136. OTP_SEP_SYS_ID_VAL_7

Table 775. km_csr.OTP_SEP_SYS_ID_VAL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.137. OTP_SEP_SYS_ID_CPL_0

Table 776. km_csr.OTP_SEP_SYS_ID_CPL_0 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.138. OTP_SEP_SYS_ID_CPL_1

Table 777. km_csr.OTP_SEP_SYS_ID_CPL_1 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.139. OTP_SEP_SYS_ID_CPL_2

Table 778. km_csr.OTP_SEP_SYS_ID_CPL_2 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.140. OTP_SEP_SYS_ID_CPL_3

Table 779. km_csr.OTP_SEP_SYS_ID_CPL_3 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.141. OTP_SEP_SYS_ID_CPL_4

Table 780. km_csr.OTP_SEP_SYS_ID_CPL_4 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.142. OTP_SEP_SYS_ID_CPL_5

Table 781. km_csr.OTP_SEP_SYS_ID_CPL_5 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.143. OTP_SEP_SYS_ID_CPL_6

Table 782. km_csr.OTP_SEP_SYS_ID_CPL_6 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.2.1.144. OTP_SEP_SYS_ID_CPL_7

Table 783. km_csr.OTP_SEP_SYS_ID_CPL_7 fields

Bits	Field	Access	Reset	Description
31:0	value	R	-	32-bit OTP word. No reset; power-up value undefined.

2.1.5.11.12.3.2.3. Key and Policy Vault Registers

2.1.5.11.12.3.2.3.1. Key and Policy Vault (KM Port)

Key entry storage and KM control registers. Access conditioned by lock_write/lock_use.

NOTE

Register Arrays:

- **KEY_ENTRY[64].WORD[16]**: 1024 registers, base 0x0 (KEY_ENTRY x64 stride 0x40, WORD x16 stride 0x4)
- **CTRL[64]**: 64 registers, base 0x1000, stride 0x4

Table 784. Key and Policy Vault (KM Port) register list

Address	Name	Access	Description
0x0 - 0xFFC	KEY_ENTRY[64].WORD[16]	RW	One 32-bit word of a key entry (512-bit key = 16 words). No reset; powers up random.
0x1000 - 0x10FC	CTRL[64]	RW	Per-slot control: lock bits (W1S) and the erase trigger
0x1100	KPV_SCRAMBLER_KEY	RW	32-bit key for KPV key entry scrambling. No reset; powers up random. Locked when KPV_SCRAMBLER_CTRL.LOCK=1.
0x1104	KPV_SCRAMBLER_CTRL	RW	KPV scrambler enable and lock. Reset to 0 on KM reset. LOCK is write-one-only.

2.1.5.11.12.3.2.3.1.1. KEY_ENTRY[64].WORD[16]

Table 785. km_kpv.KEY_ENTRY[64].WORD[16] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	-	32-bit key data word. No reset for security; power-up value undefined. Actual storage is in km_kpv_regfile; CSR field is a protocol placeholder.

2.1.5.11.12.3.2.3.1.2. CTRL[64]

Table 786. km_kpv.CTRL[64] fields

Bits	Field	Access	Reset	Description
31:4	rsvd_31_4	R	0x0	Reserved
3	seal	RW1S	0x0	Seals this key entry until warm reset. Read-any, write-1-only. Setting this bit also sets lock_write in hardware, so a single write seals the slot: its data can be read but not overwritten. Erase remains available, and erasing a sealed slot retires it rather than freeing it (see ERASE), so a sealed slot's material can be destroyed but its slot never reused.

Bits	Field	Access	Reset	Description
2	erase	RW1S	0x0	Write-1 to start hardware erase of this slot: an LFSR fills all 16 key words (through the KPV scrambler). Hardware self-clears this bit when the erase completes. Never blocked: neither lock_write, lock_use nor seal prevents an erase. The slot's seal state when the erase completes decides the outcome. Unsealed, the slot CTRL register is cleared and the slot is reusable. Sealed, lock_write stays set and lock_use is set, retiring the slot: its data is destroyed and it can be neither read, rewritten nor reused until warm reset. A seal taken while an erase is already in flight therefore still retires the slot.
1	lock_use	RW1S	0x0	Prevents KM read of this key entry data until reset. Read-any, write-1-only. Hardware sets this bit when an erase of a sealed slot completes, retiring the slot: its destroyed contents cannot be read back.
0	lock_write	RW1S	0x0	Prevents KM write to this key entry data until reset; this register stays writable so that a locked slot can still be read-locked and erased. Read-any, write-1-only. Hardware holds this bit set for as long as SEAL is set, so sealing a slot write-locks it without a separate write here.

2.1.5.11.12.3.2.3.1.3. KPV_SCRAMBLER_KEY

Table 787. km_kpv.KPV_SCRAMBLER_KEY fields

Bits	Field	Access	Reset	Description
31:0	key	RW	-	Scrambler key. No reset for security. HW clears to 0 on wipe via hwclr.

2.1.5.11.12.3.2.3.1.4. KPV_SCRAMBLER_CTRL

Table 788. km_kpv.KPV_SCRAMBLER_CTRL fields

Bits	Field	Access	Reset	Description
31:2	rsvd	R	0x0	Reserved
1	lock	RW1S	0x0	Write-one-only. When 1, key and ENABLE cannot be modified until KM reset.
0	enable	RW	0x0	1 = scramble key entry data on write, descramble on read; 0 = passthrough.

2.1.5.11.12.3.2.4. DRBG Sampler Registers

2.1.5.11.12.3.2.4.1. DRBG Sampler

DRBG random data interface and configuration/status registers

Table 789. DRBG Sampler register list

Address	Name	Access	Description
0x0	DATA	R	One word of random data. Read triggers request or returns prefetch. Writes return SLVERR. No reset.
0x4	CFG	RW	Configuration: PREFETCH enable, TIMEOUT cycles for active CPU read.
0x8	STATUS	RW	Status: DRBG_READY, PREFETCHED, TIMEOUT_ERR (W1C), STREAM_ERR (W1C), COUNT_BAD, COUNT_GOOD.
0xC	PREFETCH_DATA	R	Prefetched word (read-only, for debugging). Cleared when PREFETCH=0. No reset; power-up undefined.

2.1.5.11.12.3.2.4.1.1. DATA

Table 790. km_drbg_sampler.DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	32-bit random data from DRBG. No reset for security; power-up value undefined.

2.1.5.11.12.3.2.4.1.2. CFG

Table 791. km_drbg_sampler.CFG fields

Bits	Field	Access	Reset	Description
31:16	timeout	RW	0x100	Cycles to wait for DRBG on active CPU read; 0 = disable. Default 256.
15:1	rsvd	RW	0x0	Reserved
0	prefetch	RW	0x0	Enable prefetch. When 0, prefetch data register is cleared.

2.1.5.11.12.3.2.4.1.3. STATUS

Table 792. km_drbg_sampler.STATUS fields

Bits	Field	Access	Reset	Description
31:16	count_good	RW	0x0	Counts only reads completed through ST_RESPOND, excluding prefetched words. Saturates at 0xFFFF. Writing any non-zero value clears the field to 0; writing 0 has no effect.
15:8	count_bad	RW	0x0	Failed transactions (timeout or error). Saturates at 0xFF. Writing any non-zero value clears the field to 0; writing 0 has no effect.
7:4	rsvd	R	0x0	Reserved
3	stream_err	RW1C	0x0	Set when there is an error on the DRBG AXI-Stream interface (e.g. TVALID deasserted before TREADY). Write 1 to clear.
2	timeout_err	RW1C	0x0	Set when a DRBG read from the KM CPU times out. Write 1 to clear.
1	prefetched	R	0x0	Prefetched data available
0	drbg_ready	R	0x0	TVALID asserted from DRBG

2.1.5.11.12.3.2.4.1.4. PREFETCH_DATA

Table 793. km_drbg_sampler.PREFETCH_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	Prefetched 32-bit random data. No reset for security; power-up value undefined.

2.1.5.11.12.3.2.5. KM Mailbox Registers

2.1.5.11.12.3.2.5.1. Key Manager Mailbox KM Side

Register interface for KM CPU to access mailbox (write to outbound FIFO, read from inbound FIFO)

Table 794. Key Manager Mailbox KM Side register list

Address	Name	Access	Description
0x0	KM_WRITE_DATA	W	Write data to outbound FIFO (KM→SEP messages)

Address	Name	Access	Description
0x4	KM_WRITE_SEPARATOR	RW	Write 1 to set message separator on next outbound (KM→SEP) write. Cleared by hardware when that write completes.
0x8	KM_READ_DATA	R	Read data from inbound FIFO (SEP→KM messages)
0xC	KM_STATUS	RW	FIFO status information
0x10	KM_IRQ_STATUS	RW	Interrupt status register
0x14	KM_IRQ_ENABLE	RW	Interrupt enable register for KM CPU
0x18	KM_CTRL	RW	Control register for mailbox behavior configuration

2.1.5.11.12.3.2.5.1.1. KM_WRITE_DATA

Table 795. km_mailbox_km.KM_WRITE_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	W	0x0	32-bit data word to write to outbound FIFO

2.1.5.11.12.3.2.5.1.2. KM_WRITE_SEPARATOR

Table 796. km_mailbox_km.KM_WRITE_SEPARATOR fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	set	RW	0x0	Write 1 to set message separator on next outbound write. Cleared by hardware when that write completes.

2.1.5.11.12.3.2.5.1.3. KM_READ_DATA

Table 797. km_mailbox_km.KM_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	0x0	32-bit data word read from inbound FIFO

2.1.5.11.12.3.2.5.1.4. KM_STATUS

Table 798. km_mailbox_km.KM_STATUS fields

Bits	Field	Access	Reset	Description
31:26	rsvd	R	0x0	Reserved
25	outbound_separator	R	0x0	Message separator: 1 if the last word read from outbound FIFO had the separator bit set (last word of message). Read-only, not sticky.
24	inbound_separator	R	0x0	Message separator: 1 if the last word read from inbound FIFO had the separator bit set (last word of message). Read-only, not sticky.
23	outbound_underflow	RW1C	0x0	Outbound FIFO underflow detected (read attempted when empty). Sticky, write 1 to clear.
22	inbound_underflow	RW1C	0x0	Inbound FIFO underflow detected (read attempted when empty). Sticky, write 1 to clear.
21	outbound_overflow	RW1C	0x0	Outbound FIFO overflow detected (write attempted when full). Sticky, write 1 to clear.
20	inbound_overflow	RW1C	0x0	Inbound FIFO overflow detected (write attempted when full). Sticky, write 1 to clear.
19:12	outbound_depth	R	0x0	Outbound FIFO fill level (number of words in FIFO)

Bits	Field	Access	Reset	Description
11:4	inbound_depth	R	0x0	Inbound FIFO fill level (number of words in FIFO)
3	outbound_full	R	0x0	Outbound FIFO is full (cannot write more data)
2	outbound_empty	R	0x1	Outbound FIFO is empty (no data available for SEP to read)
1	inbound_full	R	0x0	Inbound FIFO is full
0	inbound_empty	R	0x1	Inbound FIFO is empty (no data available for KM to read)

2.1.5.11.12.3.2.5.1.5. KM_IRQ_STATUS

Table 799. km_mailbox_km.KM_IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:5	rsvd	R	0x0	Reserved
4	flushed_by_sep	RW1C	0x0	SEP performed a mailbox flush. Sticky, write 1 to clear.
3	inbound_underflow	RW1C	0x0	Inbound FIFO underflow detected. Sticky, write 1 to clear.
2	outbound_overflow	RW1C	0x0	Outbound FIFO overflow detected. Sticky, write 1 to clear.
1	outbound_write_space_avail	R	0x0	Outbound FIFO has space available for KM to write (level-sensitive). 1 = space available, 0 = full.
0	inbound_read_data_avail	R	0x0	Inbound FIFO has data available for KM to read (level-sensitive). 1 = data available, 0 = empty.

2.1.5.11.12.3.2.5.1.6. KM_IRQ_ENABLE

Table 800. km_mailbox_km.KM_IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	rsvd	R	0x0	Reserved
4	flushed_by_sep_en	RW	0x0	Enable interrupt to KM when SEP performs a mailbox flush
3	inbound_underflow_en	RW	0x0	Enable interrupt to KM when inbound FIFO underflow is detected
2	outbound_overflow_en	RW	0x0	Enable interrupt to KM when outbound FIFO overflow is detected
1	outbound_write_space_avail_en	RW	0x0	Enable interrupt to KM when outbound FIFO has space available (KM→SEP messages)
0	inbound_read_data_avail_en	RW	0x0	Enable interrupt to KM when inbound FIFO has data available (SEP→KM messages)

2.1.5.11.12.3.2.5.1.7. KM_CTRL

Table 801. km_mailbox_km.KM_CTRL fields

Bits	Field	Access	Reset	Description
31:3	rsvd	R	0x0	Reserved
2	flush	RW	0x0	Write 1 to flush all mailbox FIFOs (inbound and outbound). Cleared by hardware when flush completes.
1	inbound_underflow_resp	RW	0x0	Response type for inbound FIFO underflow: 0=SLVERR (default), 1=OKAY
0	outbound_overflow_resp	RW	0x0	Response type for outbound FIFO overflow: 0=SLVERR (default), 1=OKAY

2.1.5.11.12.3.2.6. SEP Mailbox Registers

2.1.5.11.12.3.2.6.1. Key Manager Mailbox SEP Side

Register interface for SEP host to access mailbox (write to inbound FIFO, read from outbound FIFO)

Table 802. Key Manager Mailbox SEP Side register list

Address	Name	Access	Description
0x0	SEP_WRITE_DATA	W	Write data to inbound FIFO (SEP→KM messages)
0x4	SEP_WRITE_SEPARATOR	RW	Write 1 to set message separator on next inbound (SEP→KM) write. Cleared by hardware when that write completes.
0x8	SEP_READ_DATA	R	Read data from outbound FIFO (KM→SEP messages)
0xC	SEP_STATUS	RW	FIFO status information
0x10	SEP_IRQ_STATUS	RW	Interrupt status register
0x14	SEP_IRQ_ENABLE	RW	Interrupt enable register for SEP host
0x18	SEP_CTRL	RW	Control register for mailbox behavior configuration

2.1.5.11.12.3.2.6.1.1. SEP_WRITE_DATA

Table 803. km_mailbox_sep.SEP_WRITE_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	W	0x0	32-bit data word to write to inbound FIFO

2.1.5.11.12.3.2.6.1.2. SEP_WRITE_SEPARATOR

Table 804. km_mailbox_sep.SEP_WRITE_SEPARATOR fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	set	RW	0x0	Write 1 to set message separator on next inbound write. Cleared by hardware when that write completes.

2.1.5.11.12.3.2.6.1.3. SEP_READ_DATA

Table 805. km_mailbox_sep.SEP_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	data	R	0x0	32-bit data word read from outbound FIFO

2.1.5.11.12.3.2.6.1.4. SEP_STATUS

Table 806. km_mailbox_sep.SEP_STATUS fields

Bits	Field	Access	Reset	Description
31:26	rsvd	R	0x0	Reserved
25	outbound_separator	R	0x0	Message separator: 1 if the last word read from outbound FIFO had the separator bit set (last word of message). Read-only, not sticky.
24	inbound_separator	R	0x0	Message separator: 1 if the last word read from inbound FIFO had the separator bit set (last word of message). Read-only, not sticky.
23	outbound_underflow	RW1C	0x0	Outbound FIFO underflow detected (read attempted when empty). Sticky, write 1 to clear.

Bits	Field	Access	Reset	Description
22	inbound_underflow	RW1C	0x0	Inbound FIFO underflow detected (read attempted when empty). Sticky, write 1 to clear.
21	outbound_overflow	RW1C	0x0	Outbound FIFO overflow detected (write attempted when full). Sticky, write 1 to clear.
20	inbound_overflow	RW1C	0x0	Inbound FIFO overflow detected (write attempted when full). Sticky, write 1 to clear.
19:12	outbound_depth	R	0x0	Outbound FIFO fill level (number of words in FIFO)
11:4	inbound_depth	R	0x0	Inbound FIFO fill level (number of words in FIFO)
3	outbound_full	R	0x0	Outbound FIFO is full
2	outbound_empty	R	0x1	Outbound FIFO is empty (no data available for SEP to read)
1	inbound_full	R	0x0	Inbound FIFO is full (cannot write more data)
0	inbound_empty	R	0x1	Inbound FIFO is empty (no data available for KM to read)

2.1.5.11.12.3.2.6.1.5. SEP_IRQ_STATUS

Table 807. km_mailbox_sep.SEP_IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:5	rsvd	R	0x0	Reserved
4	flushed_by_km	RW1C	0x0	KM performed a mailbox flush. Sticky, write 1 to clear.
3	outbound_underflow	RW1C	0x0	Outbound FIFO underflow detected. Sticky, write 1 to clear.
2	inbound_overflow	RW1C	0x0	Inbound FIFO overflow detected. Sticky, write 1 to clear.
1	inbound_write_space_avail	R	0x0	Inbound FIFO has space available for SEP to write (level-sensitive). 1 = space available, 0 = full.
0	outbound_read_data_avail	R	0x0	Outbound FIFO has data available for SEP to read (level-sensitive). 1 = data available, 0 = empty.

2.1.5.11.12.3.2.6.1.6. SEP_IRQ_ENABLE

Table 808. km_mailbox_sep.SEP_IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	rsvd	R	0x0	Reserved
4	flushed_by_km_en	RW	0x0	Enable interrupt to SEP when KM performs a mailbox flush
3	outbound_underflow_en	RW	0x0	Enable interrupt to SEP when outbound FIFO underflow is detected
2	inbound_overflow_en	RW	0x0	Enable interrupt to SEP when inbound FIFO overflow is detected
1	inbound_write_space_avail_en	RW	0x0	Enable interrupt to SEP when inbound FIFO has space available (SEP→KM messages)
0	outbound_read_data_avail_en	RW	0x0	Enable interrupt to SEP when outbound FIFO has data available (KM→SEP messages)

2.1.5.11.12.3.2.6.1.7. SEP_CTRL

Table 809. km_mailbox_sep.SEP_CTRL fields

Bits	Field	Access	Reset	Description
31:3	rsvd	R	0x0	Reserved
2	flush	RW	0x0	Write 1 to flush all mailbox FIFOs (inbound and outbound). Cleared by hardware when flush completes.

Bits	Field	Access	Reset	Description
1	outbound_underflow_resp	RW	0x0	Response type for outbound FIFO underflow: 0=SLVERR (default), 1=OKAY
0	inbound_overflow_resp	RW	0x0	Response type for inbound FIFO overflow: 0=SLVERR (default), 1=OKAY

2.1.5.11.12.3.2.7. Adams Bridge Key Interface Registers

2.1.5.11.12.3.2.7.1. Adams Bridge Key Sideload Registers

Single AXI4-Lite window for all KM sideload interfaces to Adams Bridge. Contains four dual-share secret-seed inputs and one shared-key output.

NOTE

Register Arrays:

- **MLDSA_SEED.KEY_SHARE0[8]**: 8 registers, base 0x0, stride 0x4
- **MLDSA_SEED.KEY_SHARE1[8]**: 8 registers, base 0x20, stride 0x4
- **MLKEM_SEED_D.KEY_SHARE0[8]**: 8 registers, base 0x100, stride 0x4
- **MLKEM_SEED_D.KEY_SHARE1[8]**: 8 registers, base 0x120, stride 0x4
- **MLKEM_SEED_Z.KEY_SHARE0[8]**: 8 registers, base 0x200, stride 0x4
- **MLKEM_SEED_Z.KEY_SHARE1[8]**: 8 registers, base 0x220, stride 0x4
- **MLKEM_MSG.KEY_SHARE0[8]**: 8 registers, base 0x300, stride 0x4
- **MLKEM_MSG.KEY_SHARE1[8]**: 8 registers, base 0x320, stride 0x4
- **KEY[8]**: 8 registers, base 0x400, stride 0x4

Table 810. Adams Bridge Key Sideload Registers register list

Address	Name	Access	Description
0x0 - 0x1C	MLDSA_SEED.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x20 - 0x3C	MLDSA_SEED.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x40	MLDSA_SEED.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x100 - 0x11C	MLKEM_SEED_D.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x120 - 0x13C	MLKEM_SEED_D.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x140	MLKEM_SEED_D.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x200 - 0x21C	MLKEM_SEED_Z.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x220 - 0x23C	MLKEM_SEED_Z.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x240	MLKEM_SEED_Z.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.

Address	Name	Access	Description
0x300 - 0x31C	MLKEM_MSG.KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x320 - 0x33C	MLKEM_MSG.KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x340	MLKEM_MSG.KEY_CTRL	RW	Seed control register. Writing KEY_VALID=1 marks the seed as loaded. Write 0 to invalidate. The KV shim gates the AB kv_read response on this bit.
0x400 - 0x41C	KEY[8]	R	One 32-bit word of ML-KEM shared key output. Written by hardware when key is ready; read by KM firmware to consume. Hardware clears all words to 0 when KEY_CTRL.KEY_VALID is cleared (via hwclr).
0x420	MLKEM_SHARED_KEY.KEY_CTRL	RW	Shared-key control. HW sets KEY_VALID when a new key is ready. Firmware writes 0 to clear (consume and zeroize).
0x424	IRQ_STATUS	RW	Interrupt status for ML-KEM shared key. Sticky bit set by hardware when a new shared key becomes valid; cleared by writing 1.
0x428	IRQ_ENABLE	RW	Interrupt enable for ML-KEM shared key. Mask for the PicoRV32 IRQ vector bit driven by the shared-key-valid event.

2.1.5.11.12.3.2.7.1.1. MLDSA_SEED.KEY_SHARE0[8]

Table 811. abr_wrapper_key.MLDSA_SEED.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.2. MLDSA_SEED.KEY_SHARE1[8]

Table 812. abr_wrapper_key.MLDSA_SEED.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.3. MLDSA_SEED.KEY_CTRL

Table 813. abr_wrapper_key.MLDSA_SEED.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.7.1.4. MLKEM_SEED_D.KEY_SHARE0[8]

Table 814. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.5. MLKEM_SEED_D.KEY_SHARE1[8]

Table 815. abr_wrapper_key.MLKEM_SEED_D.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.6. MLKEM_SEED_D.KEY_CTRL

Table 816. abr_wrapper_key.MLKEM_SEED_D.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.7.1.7. MLKEM_SEED_Z.KEY_SHARE0[8]

Table 817. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.8. MLKEM_SEED_Z.KEY_SHARE1[8]

Table 818. abr_wrapper_key.MLKEM_SEED_Z.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.9. MLKEM_SEED_Z.KEY_CTRL

Table 819. abr_wrapper_key.MLKEM_SEED_Z.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.7.1.10. MLKEM_MSG.KEY_SHARE0[8]

Table 820. abr_wrapper_key.MLKEM_MSG.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.11. MLKEM_MSG.KEY_SHARE1[8]

Table 821. abr_wrapper_key.MLKEM_MSG.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.7.1.12. MLKEM_MSG.KEY_CTRL

Table 822. abr_wrapper_key.MLKEM_MSG.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, the seed is loaded and the KV shim will serve it to Adams Bridge. Write 0 to invalidate and allow a new seed to be written.

2.1.5.11.12.3.2.7.1.13. KEY[8]

Table 823. abr_wrapper_key.KEY[8] fields

Bits	Field	Access	Reset	Description
31:0	data	R	0x0	32-bit shared-key word. Hardware writes on key-ready event; hardware clears to 0 on key-consume event (KEY_VALID cleared).

2.1.5.11.12.3.2.7.1.14. MLKEM_SHARED_KEY.KEY_CTRL

Table 824. abr_wrapper_key.MLKEM_SHARED_KEY.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW0C	0x0	1 = shared key is valid and ready for firmware consumption. Hardware sets this bit on key-ready event. Write 0 to clear; write 1 has no effect (software cannot set this bit).

2.1.5.11.12.3.2.7.1.15. IRQ_STATUS

Table 825. abr_wrapper_key.IRQ_STATUS fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW1C	0x0	ML-KEM shared key valid. Sticky, write 1 to clear.

2.1.5.11.12.3.2.7.1.16. IRQ_ENABLE

Table 826. abr_wrapper_key.IRQ_ENABLE fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid_en	RW	0x0	1 = enable PicoRV32 IRQ when ML-KEM shared key is valid. 0 = mask the interrupt (KEY_CTRL.KEY_VALID can still be polled).

2.1.5.11.12.3.2.8. AES Key Interface Registers

2.1.5.11.12.3.2.8.1. AES Wrapper Key Registers

Key storage registers for the AES sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT AES core.

NOTE

Register Arrays:

- **KEY_SHARE0[8]**: 8 registers, base 0x0, stride 0x4
- **KEY_SHARE1[8]**: 8 registers, base 0x20, stride 0x4

Table 827. AES Wrapper Key Registers register list

Address	Name	Access	Description
0x0 - 0x1C	KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x20 - 0x3C	KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x40	KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the AES core.

2.1.5.11.12.3.2.8.1.1. KEY_SHARE0[8]

Table 828. aes_wrapper_key.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.8.1.2. KEY_SHARE1[8]

Table 829. aes_wrapper_key.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.8.1.3. KEY_CTRL

Table 830. aes_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.9. HMAC Key Interface Registers

2.1.5.11.12.3.2.9.1. HMAC Wrapper Key Registers

Key storage registers for the HMAC sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT HMAC core.

NOTE

Register Arrays:

- **KEY_SHARE0[8]**: 8 registers, base 0x0, stride 0x4
- **KEY_SHARE1[8]**: 8 registers, base 0x20, stride 0x4

Table 831. HMAC Wrapper Key Registers register list

Address	Name	Access	Description
0x0 - 0x1C	KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x20 - 0x3C	KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.

Address	Name	Access	Description
0x40	KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the HMAC core.

2.1.5.11.12.3.2.9.1.1. KEY_SHARE0[8]

Table 832. hmac_wrapper_key.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.9.1.2. KEY_SHARE1[8]

Table 833. hmac_wrapper_key.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.9.1.3. KEY_CTRL

Table 834. hmac_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.10. KMAC Key Interface Registers

2.1.5.11.12.3.2.10.1. KMAC Wrapper Key Registers

Key storage registers for the KMAC sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT KMAC core.

NOTE

Register Arrays:

- **KEY_SHARE0[8]**: 8 registers, base 0x0, stride 0x4
- **KEY_SHARE1[8]**: 8 registers, base 0x20, stride 0x4

Table 835. KMAC Wrapper Key Registers register list

Address	Name	Access	Description
0x0 - 0x1C	KEY_SHARE0[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x20 - 0x3C	KEY_SHARE1[8]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x40	KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the KMAC core.

2.1.5.11.12.3.2.10.1.1. KEY_SHARE0[8]

Table 836. kmac_wrapper_key.KEY_SHARE0[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.10.1.2. KEY_SHARE1[8]

Table 837. kmac_wrapper_key.KEY_SHARE1[8] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.10.1.3. KEY_CTRL

Table 838. kmac_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.11.12.3.2.11. OTBN Key Interface Registers

2.1.5.11.12.3.2.11.1. OTBN Wrapper Key Registers

Key storage registers for the OTBN sideload interface. Written by Key Manager CPU, drives keymgr_key_i on the OT OTBN core.

NOTE

Register Arrays:

- **KEY_SHARE0[12]**: 12 registers, base 0x0, stride 0x4
- **KEY_SHARE1[12]**: 12 registers, base 0x30, stride 0x4

Table 839. OTBN Wrapper Key Registers register list

Address	Name	Access	Description
0x0 - 0x2C	KEY_SHARE0[12]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x30 - 0x5C	KEY_SHARE1[12]	W	One 32-bit word of key data. Write-only; reads return 0. No reset; powers up with undefined value.
0x60	KEY_CTRL	RW	Key control register. Writing KEY_VALID=1 asserts the sideload valid signal to the OTBN core.

2.1.5.11.12.3.2.11.1.1. KEY_SHARE0[12]

Table 840. otbn_wrapper_key.KEY_SHARE0[12] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.11.1.2. KEY_SHARE1[12]

Table 841. otbn_wrapper_key.KEY_SHARE1[12] fields

Bits	Field	Access	Reset	Description
31:0	data	W	-	32-bit key data word. Write-only for security.

2.1.5.11.12.3.2.11.1.3. KEY_CTRL

Table 842. otbn_wrapper_key.KEY_CTRL fields

Bits	Field	Access	Reset	Description
31:1	rsvd	R	0x0	Reserved
0	key_valid	RW	0x0	When 1, asserts keymgr_key_i.valid to indicate key is loaded. Write 0 to invalidate the current key.

2.1.5.12. Memory Map and Register Reference

2.1.5.12.1. Memory Map

SEP uses 32-bit addressing. The following table outlines the SEP CPU's logical view of the SEP-local address space. External masters use the chiplet-global base programmed in SEP_GLOBAL_BASE_ADDR; SEP CPU software uses either direct internal addresses (0x1000_0000, 0x1080_0000, and so on) or the local alias view described below.

Table 843. SEP CPU Logical Address Space

Base Address	End Address	Size	Unit	Description
0x00000000	0x0FFFFFFF	256 MiB	External	External to the chiplet but outside SMU.
0x10000000	0x1FFFFFFF	256 MiB	SEP Local	Direct SEP-local resources.
0x20000000	0x3FFFFFFF	512 MiB	SEP External	Reserved adopter extension aperture.
0x40000000	0x7FFFFFFF	1 GiB	SMC	SMC resources.
0x80000000	0xBFFFFFFF	1 GiB	SMU	SMU resources, including DTP.
0xC0000000	0xCFFFFFFF	256 MiB	SEP CPU Resources	EL2 ICCM, DCCM, and interrupt-controller resources.
0xD0000000	0xFFFFFFFF	768 MiB	SEP Local Alias	CPU-local alias of the direct 0x10000000–0x3FFFFFFF range.

The SEP Local Alias row is an alternate CPU-side name for the same hardware listed in the SEP Local and SEP External rows. For example, 0xD000_0000 aliases 0x1000_0000 and 0xD080_2000 aliases 0x1080_2000. This alias range is used by SEP-local masters, while external masters use chiplet-global addresses.

The EL2 CPU resources are mapped into a separate segment than the SEP Local resources due to constraints on the CPU memory map. The ICCM, DCCM, and PIC addresses in the 0xC000_0000 region are statically configured in the CPU core module and are reached through the CPU's internal wiring. The high local-alias mapping covers the 0xD000_0000 and above alias view. CPU CSRs are accessed with dedicated RISC-V instructions and do not appear in the address map.

The high local alias span has a fixed SEP-local size of 768 MiB (0xD000_0000 through 0xFFFF_FFFF), corresponding to the direct internal range 0x1000_0000 through 0x3FFF_FFFF. The chiplet-global SEP aperture configured by SEP_GLOBAL_BASE_ADDR / SEP_REGION_SIZE controls the SMU xbar and inbound global-to-local remap.

Table 844. SEP EL2 CPU Resources

Base Address	End Address	Size	Unit	Description
0xC0000000	0xC003FFFF	256 KiB	ICCM	Tightly coupled instruction SRAM for the SEP CPU.
0xC0040000	0xC005FFFF	128 KiB	DCCM	Tightly coupled data SRAM for the SEP CPU.
0xC0060000	0xC007FFFF	128 KiB	Reserved	Reserved
0xC0080000	0xC0087FFF	32 KiB	PIC	VeeR EL2 Programmable Interrupt Controller (PIC) memory-mapped registers. Supports up to PIC_TOTAL_INT external interrupt sources with 15 priority levels.
0xC0088000	0xCFFFFFFF	261600 KiB	Reserved	Reserved

The remaining subsystems are mapped into regions 1 and 2 for the EL2 CPU.

Each row below is the aperture reserved for a unit, and the Decoded Extent column gives the part of it that registers or memory back. The last two columns state how SEP answers a 32-bit access that no register or memory backs, as seen at its inbound AXI port, and Decode Response Codes defines them and their codes.

The TRNG aperture is forwarded in full to an adopter-defined external IP. SEP does not decode offsets inside that window, so every access reaches the external TRNG slave. Intra-aperture decode is then an integrator constraint: when an adopter TRNG is connected, an address that owns no register must return an error and must not alias onto a live register. When no external TRNG is connected, the window is terminated with a DECERR slave, so single-beat reads and writes both return DECERR, refuse the access and never alias onto a live register. See the Integrator Guide.

2.1.5.12.2. Single-Beat Register Access

Register regions support single-beat transactions only. Bursts are supported into ICCM, DCCM, SRAM, the extension port and the outbound SMN windows. The fabric routes a burst on its first address only, so the later beats of a burst to a register region may be answered with errors or alias onto other registers. The crypto region, which spans OTBN through ABR in the generated memory map below, refuses bursts (Single-Beat Access Only).

2.1.5.12.3. Units Unreachable from the Inbound Port

Several SEP units are not connected to the external inbound port and answer `DECERR` to any external access attempt. These units include the Boot ROM, Reset Control, ICCM, DCCM, PIC, and AP/STEE remap regions. The inbound port serves the mailbox and system CSR windows, and forwards all other addresses below 0x4000_0000 (outside the mailbox and system CSR windows) to the SEP local crossbar. Addresses above 0x4000_0000 and the units listed above are not reachable through this external path and receive error responses from the `smn_inbound` port. Their rows in the table below state what the SEP CPU sees.

Table 845. SEP Component Address Map

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x10000000	0x1003FFFF	256 KiB	256 KiB	sep_sram	SEP scratch SRAM.	-	-
0x10040000	0x1004FFFF	64 KiB	64 KiB	sep_boot_rom	BL0 immutable instruction memory.	-	-

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x10050000	0x107FFFFF	7872 KiB	7872 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10800000	0x10800FFF	4 KiB	336 B	DMA Controller	Secure DMA control and status registers.	SLVERR, 0xFFFFFFFF / SLVERR[1]	DECERR, 0xBADCAB1E / DECERR
0x10801000	0x10801FFF	4 KiB	56 B	Always-On Timer	Wakeup and watchdog timers running on a low-power, always-on clock	-	DECERR, 0xBADCAB1E / DECERR
0x10802000	0x1080203F	64 B	64 B	SEP Scratch Address Map	Cold-reset scratch register bank.	-	-
0x10802040	0x1080207F	64 B	64 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10802080	0x108020BF	64 B	64 B	SEP Scratch Address Map	Warm-reset scratch register bank.	-	-
0x108020C0	0x10802FFF	3904 B	3904 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10803000	0x10803FFF	4 KiB	8 B	SEP Reset Control Address Map	Software resets for KM, OTBN, AES, HMAC, KMAC, the internal TRNG, and Adams Bridge.	-	DECERR, 0xBADCAB1E / DECERR
0x10804000	0x108FFFFF	1008 KiB	1008 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10900000	0x1090FFFF	64 KiB	48 KiB	OpenTitan Big Number Accelerator	Programmable coprocessor for asymmetric cryptography with SCA and FI countermeasures	SLVERR, 0xFFFFFFFF / SLVERR	DECERR, 0xBADCAB1E / DECERR
0x10910000	0x10910FFF	4 KiB	140 B	AES Accelerator	AES block-cipher accelerator.	-	DECERR, 0xBADCAB1E / DECERR
0x10911000	0x10912FFF	8 KiB	8 KiB	HMAC Accelerator	Accelerator for SHA-2 256/384/512-based keyed HMAC and the hash function	SLVERR, 0xFFFFFFFF / SLVERR	-
0x10913000	0x10913FFF	4 KiB	4 KiB	KMAC Accelerator	Accelerator for Keccak-based keyed hash message authentication code and SHA-3 hash functions; with SCA and FI countermeasures	SLVERR, 0xFFFFFFFF / SLVERR	-

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x10914000	0x10914FFF	4 KiB	4 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10915000	0x109157FF	2 KiB	96 B	Cryptographically Secure Random Number Generator	Takes entropy bits to produce cryptographically secure random numbers for consumption by hardware blocks and by software	-	DECERR, 0xBADCAB1E / DECERR
0x10915800	0x10915FFF	2 KiB	72 B	Entropy Distribution Network	Distributes random numbers produced by CSRNG to hardware blocks	-	DECERR, 0xBADCAB1E / DECERR
0x10916000	0x10916FFF	4 KiB	380 B	Entropy Source Address Map	Entropy-source configuration, status, and data registers.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
0x10917000	0x10917FFF	4 KiB	4 KiB	External TRNG	External TRNG register passthrough; the register layout is adopter-defined	Adopter-defined[2]	-
0x10918000	0x1091FFFF	32 KiB	24 B	SEP Lifecycle Control Address Map	Lifecycle state and transition control.	-	DECERR, 0xBADCAB1E / DECERR
0x10920000	0x10920FFF	4 KiB	28 B	Key Manager Mailbox SEP Side	Register interface for SEP host to access mailbox (write to inbound FIFO, read from outbound FIFO)	-	DECERR, 0xBADCAB1E / DECERR
0x10921000	0x1092FFFF	60 KiB	60 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10930000	0x109303FF	1 KiB	1 KiB	SEP eFuse Map Address Map	Cached eFuse shadow registers.	-	-
0x10930400	0x109304FF	256 B	28 B	eFuse Interface Control Address Map	eFuse command and status registers.	-	SLVERR, 0xBADCAB1E / SLVERR
0x10930500	0x109305FF	256 B	116 B	eFuse Token Registers Address Map	eFuse security-token registers.	-	DECERR, 0xBADCAB1E / DECERR
0x10930600	0x1093FFFF	64000 B	64000 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10940000	0x1094FFFF	64 KiB	49176 B	abr	Adams Bridge post-quantum accelerator for ML-DSA and ML-KEM.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x10950000	0x1095FFFF	64 KiB	24 B	SEP Entropy Pool	Read-only entropy pool FIFO; DATA reads drain conditioned entropy supplied by the native EDN, and writes return SLVERR.	-	SLVERR, 0x0 / SLVERR[3]
0x10960000	0x109FFFFF	640 KiB	640 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10A00000	0x10A0FFFF	64 KiB	30800 B	SEP AXI-Lite Mailbox Wrapper Address Map	Eight bidirectional mailbox pairs.	SLVERR, 0x0 / SLVERR	SLVERR, 0x0 / SLVERR
0x10A10000	0x10A101FF	512 B	512 B	AXI Alias Remap Address Map	TLB Registers for address remapping and attribute tagging	OKAY, 0x0 / OKAY	-
0x10A10200	0x10A1027F	128 B	128 B	Output Remap Address Map	Address-translation registers that remap outbound transactions and tag their attributes.	-	-
0x10A10280	0x10A102FF	128 B	128 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10A10300	0x10A1037F	128 B	128 B	Output Remap Address Map	Address-translation registers that remap outbound transactions and tag their attributes.	-	-
0x10A10380	0x10A1FFFF	64640 B	64640 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10A20000	0x10A203FF	1 KiB	1 KiB	AXI Filter Control Address Map	Per-filter access-control registers defining permitted address ranges and transaction attributes.	OKAY, 0x0 / OKAY	-
0x10A20400	0x10A20FFF	3 KiB	3 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10A21000	0x10A211FF	512 B	512 B	AXI Filter Control Address Map	Per-filter access-control registers defining permitted address ranges and transaction attributes.	OKAY, 0x0 / OKAY	-

Base Address	End Address	Size	Decoded Extent	Unit	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x10A21200	0x10A2FFFF	60928 B	60928 B	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10A30000	0x10A31FFF	8 KiB	4104 B	SEP CPU Control Address Map	SEP CPU control and interrupt registers.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
0x10A32000	0x10AFFFFF	824 KiB	824 KiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x10B00000	0x10BFFFFF	1 MiB	56 B	SPI Host	External I/O SPI controller bridge.	-	DECERR, 0xBADCAB1E / DECERR
0x10C00000	0x10FFFFFF	4 MiB	4 MiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x11000000	0x117FFFFF	8 MiB	8 MiB	ap_region	Address region whose accesses an output remap redirects.	Forwarded	-
0x11800000	0x11FFFFFF	8 MiB	8 MiB	stee_region	Address region whose accesses an output remap redirects.	Forwarded	-
0x12000000	0x1FFFFFFF	224 MiB	224 MiB	Reserved	Reserved	DECERR, 0xBADCAB1E / DECERR	-
0x20000000	0x3FFFFFFF	512 MiB	512 MiB	SEP External	SEP external address map (eFuse SHIM control and execute-in-place window).	Adopter-defined	-
0xC0000000	0xC003FFFF	256 KiB	256 KiB	sep_iccm	Tightly coupled instruction SRAM for the SEP CPU.	-	-
0xC0040000	0xC005FFFF	128 KiB	128 KiB	sep_dccm	Tightly coupled data SRAM for the SEP CPU.	-	-
0xC0080000	0xC0087FFF	32 KiB	21 KiB	EL2_PIC	VeeR EL2 Programmable Interrupt Controller (PIC) memory-mapped registers. Supports up to PIC_TOTAL_INT external interrupt sources with 15 priority levels.	OKAY, 0x0 / OKAY	OKAY, 0x0 / OKAY

Notes

[1] An access to an unmapped offset also latches PIC source 41.

[2] With no TRNG fitted, the reference integration answers DECERR, 0xBADCAB1E / DECERR.

[3] A 32-bit read of the upper word of a register also answers SLVERR, 0x0.

2.1.5.12.4. Detailed Register Map

The address tables above identify each aperture. Detailed registers are published with the owning block:

See the register references in the CPU, Interrupts, SEP Reset Controller, Life Cycle Controller, OTP Fuse Controller, Watchdog Timer, Cryptographic Subsystem (including AES Cipher, HMAC-SHA2, KMAC-SHA3, OTBN and TRNG and DRBG), DMA, Serial Peripheral Interface, Key Manager and Entropy Source chapters. The shared eFuse IP chapter owns the eFuse MMR reference.

2.1.5.12.4.1. External Window Reference Model

The SEP external-window model supplies the eFuse SHIM control register below. The `efuse_shim_ctrl` instance at offset `0x0` fixes where that block sits. `EFUSE_SHIM_SIZE` bytes from that base (`CFG.SEP_EFUSE_SHIM_SIZE` at the SMU, default `0x4`) are routed to the eFuse controller, which forwards them unchanged on `efuse_bank_ctrl` to the adopter's SHIM rather than out the external port. An adopter external map must keep an `efuse_shim_ctrl` instance at that offset. Its execute-in-place region is a memory window rather than a register bank. Adopter-specific external devices require their own register documentation.

2.1.5.12.4.1.1. SEP External

SEP external address map (eFuse SHIM control and execute-in-place window).

Table 846. SEP External register list

Address	Name	Access	Description
0x0	EFUSE_BANK_INIT_TIME	RW	eFuse bank initialization time. Number of cycles to wait for the OTP macro to initialize before sensing can begin.

2.1.5.12.4.1.1.1. EFUSE_BANK_INIT_TIME

Table 847. sep_external.EFUSE_BANK_INIT_TIME fields

Bits	Field	Access	Reset	Description
31:0	init_time	RW	0x20	Most OTP have a initialization time before sensing can be done

2.1.6. System Management Controller (SMC)

The System Management Controller (SMC) performs firmware-driven platform management for each chiplet. Its documentation is organized into focused topic pages covering the subsystem architecture, hardware services, and programming interfaces.

2.1.6.1. Overview

The System Management Controller (SMC) is a subsystem in a chiplet that takes on the system management tasks, including managing clock/voltage/reset, configuring the hardware platform, bringing up the system, and reporting system status.

Given its essential role, a SiP with multiple chiplets integrates one SMC per chiplet. Each SMC instance in a chiplet is responsible for system management of the local chiplet. On top of that, a management hierarchy is expected to be built among different SMC instances, according to the OCA hierarchical system architecture, , Sec. 3.1 and 3.2. This means an SMC instance in the primary chiplet is expected to play additional roles to manage SiP level tasks for the secondary chiplets.

The SMC consists of a micro-controller and different facilitative components for various purposes. At high level, SMC's main control logic is implemented in the firmware running on the micro-controller. Hardware facilitative components are added only when certain tasks cannot be implemented by firmware.

Figure 49 shows the SMC microarchitectural diagram.




Figure 49. SMC top-level microarchitecture

The `smc` module holds three blocks: the CPU cluster `smc_cpu_wrapper`, `smc_base` and `smc_peripherals`. The CPU cluster is drawn as a single block; the CPU and memory system section describes its contents. Every AXI4 and AXI-Lite link carries a manager port (M) at the initiating end and a subordinate port (S) at the other.

The input fabric takes six initiators: the system inbound port, the SEP inbound port, the JTAG debug port from the DTP, the CPU MMIO port, the UART log-engine fetch port and the data accelerator. Traffic inside the SMC window reaches the local fabric on three paths. System traffic passes the inbound filter first, and SEP traffic is not filtered. The CPU MMIO, JTAG, log and data accelerator traffic is alias-remapped and shares the third path. The input fabric forwards other addresses from those four initiators to the output fabric. The output fabric applies the M-mode and Xvisor remaps and the outbound filter, then drives the system outbound port. System and SEP requests outside the SMC window receive a decode error.

The local fabric, `smc_local_xbar`, serves five targets: the CPU front port, the data accelerator control port, the internal CSRs, the DFD registers and the peripheral port. Its internal AXI-Lite crossbar splits the internal CSRs into eight blocks in `smc_internal_regs`: base configuration, the alias, M-mode and Xvisor remaps, the inbound and outbound filters, the mailboxes and the DFX CSRs. `smc_base` also builds the CPU interrupt vector from the external, peripheral, mailbox and internal sources. Its three AXI hang detectors, marked HD on the links they watch, observe the system inbound, SEP inbound and data accelerator AXI links without sitting in the data path; their combined interrupt reaches the PLIC through `smc_peripherals`.

The peripheral crossbar, `smc_periph_axi_lite_xbar`, has twelve targets. Ten of them are inside `smc_peripherals`. The UART, I2C, I3C and AVSBus register paths, and the log-engine fetch path, cross between the SMC clock and the peripheral clock (CDC). The remaining two targets leave the SMC: the DTP control registers and the `smc_external` window. In the reference top `smc_wrapper`, `smc_ip_integration` supplies the grey blocks: the CPU memory macros, the trace RAMs, the eFuse shim and bank model, the GPIO pad shims, and the PLL, PVT and strap register models behind `smc_external`.

The rest of this documentation describes architectural requirements and microarchitectural implementation of SMC's components in OCAH. A consolidated description of OCAH use cases is available in Use Cases.

2.1.6.1.1. Clocks and Resets

SMC coordinates clock, voltage and reset control. Its processing, reference timing and peripheral interfaces use distinct clock branches. Clocks and Resets describes the domains and reset sequencing.

2.1.6.1.2. CPU

The RISC-V CPU cluster executes management firmware using its caches and local memories. The CPU chapter describes its configuration, interfaces, isolation, error reporting and debug support.

2.1.6.1.3. Boot ROM

Boot ROM contains the startup firmware. Scratchpad memory provides runtime storage. The Boot ROM chapter describes the hardware and links to the production firmware manual.

2.1.6.1.4. Interconnect

AXI4 and AXI4-Lite connect the CPU and management blocks. Remapping, traffic filters and crossbars provide address translation, access control and routing.

2.1.6.1.5. Interrupts

The PLIC routes system events; CLINT supplies core-local timer and software interrupts. The interrupt chapter describes their integration and handling.

2.1.6.1.6. Peripherals

DMA performs bulk transfers and Zeroer clears memory. Communication and control services include mailboxes, GPIO, I2C, I3C, UART and AVSBus. Telemetry receivers collect performance data; OCTS supports multi-chiplet timekeeping. PVT sensors provide environmental monitoring through adopter integration.

2.1.6.1.7. Design-for-Debug and CLA

JTAG, the RISC-V debug module and the Core Logic Analyzer support observation, triggering and trace capture.

2.1.6.1.8. eFuse Scan Protection

Scan protection controls access to eFuse shadow-register assets. Its dedicated chapter describes the asset classes and access restrictions.

2.1.6.1.9. Memory Map

The memory map summarizes the address space and points to the block pages for register details.

2.1.6.2. Clocks and Resets

SMC separates CPU/fabric operation, peripheral timing, reference-clock reset control and incoming telemetry into distinct clock domains. Reset sources are combined before release is synchronized into each destination domain. Subsystem isolation and reset-retention controls require support in the receiving subsystem.

2.1.6.2.1. Clock Architecture




Figure 50. SMC clock tree and clock domains in u_smc_base




Figure 51. SMC clock tree and clock domains in u_smc_cpu_wrapper and u_smc_peripherals

The two figures split the SMC clock tree at its subsystem instances. Each clock input enters on the left in its own colour, with one arrow into each of `u_smc_base`, `u_smc_cpu_wrapper` and `u_smc_peripherals` that it reaches; an arrow into an instance means the clock reaches the logic inside it. Each box is an RTL instance, tinted with the colour of the clock that runs it, and a box split into bands runs on several clocks. A clock gate is drawn as a CG tab coloured by the clock it gates, with the gate's instance name in italics. A dashed arrow runs from the gate to every instance its gated clock reaches, branching at a junction dot. A count such as ×16 is the number of instances a generate loop creates. A box that no gate arrow reaches runs on the ungated clock.

Most gates in u_smc_base are activity-based: each watches the AXI or AXI-Lite port of the logic it clocks and stops the clock once the port has been idle for the programmed hysteresis. Each filter and remap register gate clocks the AXI-Lite demux in front of its register set as well as the registers, and each filter gate also clocks the error slave that answers writes to a locked filter. u_fabric_cg and the instances inside the dashed outline exist only when NO_ADDR_REMAP is 0, the default in smc_config_pkg. u_dfd_clk_gate clocks the debug bus muxes, u_dfd_top and u_ref_cnt_sync, which receives the Gray-coded count of the reference counter beside u_ref_rst_sync and forms the CLA time tick. u_axi_clk_gater clocks logic written directly in u_zeroer rather than an instance.

u_debug_clock_gate runs the debug module clock, the debug_clock port of u_digital_top, while the debugger holds dmactive. The I2C, UART, I3C, AVSBus and telemetry gates are controlled by CLOCK_GATE_CONTROL in u_smc_base. u_smc_peripherals_cdc is drawn as one row per synchroniser or CDC instance, or per group of instances that cross the same way, with the source clock on the left half and the destination clock on the right half. The clock-gate enable synchronisers carry each enable into the ungated clock of the gate it controls. u_ndmreset_request_sync has no source clock: ndmreset_request_i is asynchronous.

Each of the five peripheral enables also steers that peripheral's leg of the register crossbar into an error slave (u_avsbus_access_gate, u_i2c_access_gate, u_uart_access_gate, u_telemetry_access_gate and u_i3c_access_gate in u_smc_peripherals, all on clk_smc_i): while the enable is set, a read of the gated peripheral's window completes with SLVERR and data 0xBADCAB1E and a write completes with SLVERR, instead of waiting on a register block whose clock has stopped. The leg is redirected as soon as the CLOCK_GATE_CONTROL write completes; an access the peripheral has already accepted finishes there, since its clock stops only after the enable has crossed into its domain.

The AVSBus clock starts at u_avs_clk_ref_gater and u_avs_clk_periph_gater, which drive the clk_ref_i and clk_reg_i ports of u_avsbus_controller. Inside it, u_refclk_clkgate and u_apbclk_clkgate feed the glitch-free mux u_refclk_apbclk_mux, selected by avs_clock_select[1]. The test mux u_test_clkmux2_0 takes that output on clk0_i and the test clock input clk_test_i on clk1_i, and selects the test clock in test mode; u_smc_peripherals connects clk_test_i to clk_periph_i. The divider u_clk_div, used while avs_clock_select[0] is set, divides by a programmable value, 4 after reset, and u_avs_bus_clkgate stops the result on idle. The output, avs_clock, leaves through u_smc_padring on GPIO 49. spi_clk_i reaches only the SPI pad datapath in u_smc_padring.

Table 848. SMC clock-domain responsibilities

Clock	Logic and boundary
clk_smc_i	CPU cluster, local fabric, remapping/filtering, register crossbar, OCTS, and telemetry decoding/message storage. Individual blocks may gate this clock.
clk_ref_i	Power-good/reset conditioning, FLR countdowns, DFD local time tick and peripheral reference-clock inputs.
clk_periph_i	AVSBus, I2C, UART/log-engine and I3C operation. Register accesses cross through per-port AXI-Lite CDC bridges after the SMC-domain crossbar.
clk_telemetry_i	Incoming ATB side of each telemetry crossing FIFO. The receiver core and its CSRs operate in the SMC domain; the external telemetry reset is rst_telemetry_ni.

2.1.6.2.1.1. Timer and Debug Timebases

- OCTS uses clk_smc_i.
- CLINT receives one tick per 1000 CPU-cluster cbus cycles; the uncore input uses the main SMC clock. This timer tick is not the reference-clock input.
- The CPU debug module uses a gated CPU-wrapper clock, enabled by debug activation with a test override. JTAG TCK clocks the scan interface separately.

2.1.6.2.1.2. Peripheral Timing Requirements

The integrator supplies `clk_periph_i` at a frequency satisfying every enabled peripheral. A minimum frequency of 100 MHz applies; the upper limit is not fixed and is set by the integrator according to timing closure, peripheral IP limits, and system power and performance goals.

The I3C target's worst-case internal SCL-to-SDA turnaround is four core-clock cycles. Meeting the 12 ns target turnaround limit therefore requires a clock period no greater than 3 ns (approximately 333.3 MHz or faster) before allowing for pad and routing delays. The integrator must include those delays in the timing budget and select a higher frequency where needed. See the CHIPS Alliance I3C PHY timing requirements. This is a target-mode requirement; controller-mode timing configuration does not establish target compliance.

2.1.6.2.2. Reset Architecture




Figure 52. SMC reset unit architecture

Reset inputs enter on the left and the unit's outputs leave on the right. Each reset net has its own colour, listed in the

legend. The blue mux symbols are JTAG override muxes: jtag_reset_ctrl_i drives their input 1 and select, drawn as short stubs, and each mux passes the value on input 1 while its override bit is set.

In u_smc_reset_ctrl, powergood_i is stretched by 32 reference clock cycles into powergood_stable, which leaves as powergood_stable_o, clears the de-glitchers while low and holds the cold-reset extender. The cold reset, after its JTAG override, must stay low for 32 reference clock cycles to pass the de-glitcher, and its release is extended by 255 cycles. The cool-reset pin passes its own 32-cycle de-glitcher. The primary reset is the AND of the stable cold reset, the de-glitched cool-reset pin and the FLR cool reset. The watchdog reset is the AND of rst_ext_wdt_ni, which comes from the SEP watchdog, and the inverted SMC watchdog second timeout; smc_wdt_first_timeout_i does not reach the reset logic. The warm reset is the AND of the watchdog reset, the primary reset and the fuse reset, which the eFuse wrapper releases once fuse sensing completes and any boot stall ends. Debug-initiated resets are the JTAG overrides of the cold, cool, warm, fuse and per-subsystem resets.

u_smc_reset_sync gives each output an asynchronous assertion and a deassertion synchronised to its clock. u_smc_cool_reset_wrap runs the FLR sequence and isolation logic described in Section 2.1.6.2.3. Its gates act on each of the 32 bits; the inputs labelled SMCEN, REG and PINEN are the ISOLATE_REQ_SMCEN_REG, ISOLATE_REQ_REG and ISOLATE_REQ_PINEN_REG bits. skip_mem_repair_o is high while the synchronised isolation pin or ISOLATE_REQ_SMC is set. u_reset_unit_reg is reset by rst_primary_smc_clk_no, as are the SS_CONFIG and SS_COLD_RESET_N registers in u_smc_subsystem_resets; the isolation registers and FLR counters are reset only by the stable cold reset, so they survive a cool reset. The per-subsystem cold and warm resets leave ss_reset_ctrl_o unsynchronised, and each subsystem synchronises them. In test mode, scan_rst_ni replaces the stretched powergood, the de-glitched cold reset and every synchroniser output.

2.1.6.2.2.1. Power-Good and Cold Reset

BP_POWERGOOD is the POR root. A 32-stage reference-clock synchronizer produces powergood_stable. Cold reset from BP_RESETN is filtered through a 32-bit shift register: once released, assertion requires 32 consecutive low samples. A 255-cycle reference-clock extension holds cold reset after the filtered input releases. Incoming cool reset has the same low-sample filter but no cold-reset extension. These are clock-cycle conditions, not fixed nanosecond delays.

Power-good also enters JTAG/DTP as pwr_on_rst_ni. The primary TAP combines it with pad TRST, so loss of power-good resets TAP/TDR state even if TRST is released. Functional cold reset alone does not reset that state.

Table 849. SMC reset sources and effects

Source	Functional effect
Power-good low	Holds functional reset and resets the JTAG/TDR POR path.
BP_RESETN	Filtered and extended cold reset feeds primary reset.
Incoming cool reset	Filtered pin request feeds primary reset.
FLR cool reset	Reference-domain timed reset feeds primary reset; isolation is controlled separately as described below.
External watchdog reset / second SMC watchdog timeout	Assert the watchdog reset term, which also asserts warm reset. The first-timeout input does not enter the reset equation in smc_reset_ctrl.
Fuse reset	Holds warm reset until released by the fuse-control path.
JTAG reset overrides	Select alternate fuse, cold, cool or warm reset values; normal functional equations below assume these overrides and scan mode are inactive.

2.1.6.2.2.2. Primary and Warm Reset

In normal operation the active-low reset equations are:

```
rst_primary_n = stable_cold_rst_n AND stable_cool_rst_n
```

```
                AND rst_cool_from_flr_n
rst_wdt_n     = rst_ext_wdt_ni AND NOT smc_wdt_second_timeout_i
rst_warm_n    = rst_primary_n AND rst_wdt_n AND fuse_reset_ni
```

Primary reset covers the main SMC functional fabric, peripheral control and configuration paths. Warm reset drives CPU core/uncore reset control, including the cluster's interrupt and timer logic, without resetting every primary-domain peripheral. CPU control registers also provide per-core/uncore reset controls; debug reset requests and JTAG overrides should not be treated as one unconditional warm-reset input. See the CPU chapter for its isolation/reset interlock.

2.1.6.2.2.3. Reset Synchronization

`smc_reset_sync` uses four-stage `prim_sync_reset` instances for asynchronous assertion and destination-clock-synchronous release. Scan mode selects the scan reset. A stopped destination clock cannot complete functional reset release.

Table 850. Reset synchronization domains

Output from `smc_reset_sync`	**Clock**	**Reset source**
`rst_cold_smc_no`	SMC	Stable cold reset; exported by the unit as `rst_cold_stable_smc_clk_no`.
`rst_primary_smc_clk_no`	SMC	Primary reset.
`rst_warm_smc_clk_no`	SMC	Warm reset after JTAG override selection.
`rst_wdt_smc_clk_no`	SMC	Watchdog reset term.
`rst_cold_ref_clk_no`	Reference	Stable cold reset; exported as `rst_cold_stable_ref_clk_no`.
`rst_primary_ref_clk_no`	Reference	Primary reset.
`rst_primary_periph_clk_no`	Peripheral	Primary reset.

JTAG overrides for outgoing per-subsystem cold/warm controls leave the unit unsynchronized. The receiving subsystem must synchronize release at its boundary. The separate telemetry input reset belongs to its integration domain.

2.1.6.2.3. Function Level Reset and Isolation

PCIe `cfg_flr_pf_active_i` crosses independently into the SMC and reference clock domains. Its synchronized rising edge sets the SMC isolation latch and starts the reference-domain reset sequence when enabled by a nonzero hold count. The reset state machine has no isolation-complete input: its delay must be chosen to accommodate the system's isolation requirements.

2.1.6.2.3.1. Isolation Controls

Each of the 32 `isolate_req_o` bits is the OR of three requests:

```
ISOLATE_REQ_REG[i]
OR (ISOLATE_REQ_PINEN_REG[i] AND synchronized isolate_req_pin_i)
OR (ISOLATE_REQ_SMCEN_REG[i] AND ISOLATE_REQ_SMC_REG)
```

The FLR edge sets `ISOLATE_REQ_SMC_REG`. After recovery, a write to that register with any write strobe asserted clears the latch; write data is ignored. An FLR edge in the same cycle takes priority. Ending the timed cool reset does not clear the latch or release isolation automatically. Clearing one source does not cancel an isolation request held by either of the others.

The isolation registers and FLR count storage are cold-reset state, so they survive cool reset. ISOLATE_REQ_PINEN_REG has a conditional synchronous clear: it clears on cold reset only while the synchronized isolation pin is low. Do not assume an uninitialized pin-enable mask becomes known while that pin is high.

2.1.6.2.3.2. Timing and Recovery

The FLR count values cross from SMC to the reference domain through handshaked synchronizers; readback in the SMC domain does not acknowledge arrival in the reference domain. ISOLATE_REQ_FLR_COUNTER_VALUE selects the pre-reset countdown; zero allows assertion without that countdown. ISOLATE_REQ_FLR_RESET_COUNTER_VALUE selects the cool-reset hold count, and must be nonzero to start the timed flow.

On a synchronized FLR edge, the sequencer counts in reference-clock cycles, asserts cool reset, then releases it after the hold countdown. Destination reset synchronizers add their release latency. The sequencer is not a queue of overlapping FLR requests. The FLR preparation and recovery sequence is in the Programmer's Guide.

A zero hold count disables the timed reset sequence, but does not prevent the SMC-domain FLR edge from setting the isolation latch. ISOLATE_REQ_VIS reports synchronized pin and cool-reset levels; it is not an isolation-completion handshake.

skip_mem_repair_o is the OR of the synchronized isolation pin and the FLR isolation latch. It does not depend on the per-subsystem masks, and a software-only ISOLATE_REQ_REG request does not assert it. The receiving logic determines how this request bypasses memory repair/MBIST; it is not a general SRAM-retention guarantee.

2.1.6.2.3.3. Isolation Connections

Figure 53 shows cool-reset and isolation connections between primary and secondary chiplets. The next three figures repeat the same drawing and highlight the path that each kind of request activates, so they can be compared directly.




Figure 53. SMC FLR isolation connections between chiplets

Each chiplet's SMC takes its cold reset from the board `BP_RESET_N` and its cool reset from its `BP_COOL_RESET_N_I` input; the primary reset is the AND of these and the FLR cool reset. The FLR cool reset also drives the open-drain `BP_COOL_RESET_N_O` pad, GPIO 62, which pulls the line low while the reset is asserted and leaves it undriven otherwise. The primary chiplet's `BP_COOL_RESET_N_O` connects to the secondary chiplet's `BP_COOL_RESET_N_I`, so an FLR on the primary chiplet cool-resets the secondary. To the secondary chiplet, a cold reset on `BP_RESET_N` and a cool reset on `BP_COOL_RESET_N_I` are the same: both assert its primary reset. Only its FLR and isolation registers are reset by the cold reset alone, and the secondary chiplet does not use them. The primary chiplet's `BP_COOL_RESET_N_I` and the secondary chiplet's `BP_COOL_RESET_N_O` are not connected. The board drives `ISOLATE_REQ`, sampled on GPIO 53, into the primary chiplet only; the secondary chiplet ties its `ISOLATE_REQ` and `cfg_flr_pf_active_i` low and leaves its `isolate_req_o` unconnected. The labels REG, PINEN and SMCEN on the isolation OR's inputs name the registers that qualify each source. The drawing leaves out the de-glitchers and synchronisers shown in Figure 52.

Figure 54 shows isolation propagation for an SMC software request. Software sets bits of `ISOLATE_REQ_REG`, which reach `isolate_req_o` directly. Software cannot start the FLR counters, so this request isolates tiles without a cool reset.




Figure 54. SMC-driven FLR isolation

Figure 55 shows isolation propagation for a tile request. A tile such as the PCIe controller raises `cfg_flr_pf_active_i`. Its synchronised rising edge sets `ISOLATE_REQ_SMC`, which isolates the subsystems enabled in `ISOLATE_REQ_SMCEN_REG`, and starts the FLR counters. When they expire, the FLR cool reset asserts the primary reset of the primary chiplet and, through `BP_COOL_RESET_N_O`, of the secondary chiplet.




Figure 55. Tile-request-driven FLR isolation

Figure 56 shows isolation propagation for a GPIO request, in two numbered steps. First the board raises `ISOLATE_REQ`, which isolates the subsystems enabled in `ISOLATE_REQ_PINEN_REG`; then it asserts `BP_RESET_N`, which cold-resets both chiplets. `ISOLATE_REQ_PINEN_REG` is not reset by the cold reset while the pin is high, so the isolation holds across it.




Figure 56. GPIO-driven FLR isolation

2.1.6.2.4. Subsystem Controls and Clock Gating

The reset unit exports cold/warm reset, force-to-reference-clock and configuration, SRAM, debug and critical-signal hold controls for 32 subsystems. These are requests to the receiving subsystem, whose implementation defines the retained state. `SS_CONFIG_LOCK` and `SS_COLD_RESET_LOCK` mask writes to the corresponding configuration and cold-reset bits. `SS_RESET_COMPLETE` samples the return vector through a three-stage synchronizer; the unit does not sequence releases from it. The subsystem reset sequences are in the Programmer's Guide.

SMC blocks have their own clock-gating enables, activity detection and hysteresis controls. For example, DMA uses a six-bit hysteresis input and bus-aware wakeup. A gate suppresses clock transitions; it does not itself create a power island or establish that outstanding bus traffic is drained. Follow the owning block's quiescence requirements before reset, isolation or clock changes. The I2C, UART, I3C, AVSBus and telemetry windows answer `SLVERR` with read data `0xBADCAB1E` while their `CLOCK_GATE_CONTROL` enable is set, so software can detect an access to a gated peripheral rather than stall on it; the other gated blocks wake on bus activity and need no such response.

2.1.6.2.5. Memory Map and Register Reference

2.1.6.2.5.1. Memory Map

The following reset-unit map defines subsystem controls, isolation masks, visibility and FLR timing registers. Offsets are relative to the reset-unit base in the subsystem memory map. External state in the cool-reset wrapper follows the cold-reset behavior described above rather than the primary reset of the register-interface logic.

2.1.6.2.5.2. Detailed Register Map

2.1.6.2.5.2.1. Reset Unit Address Map

Subsystem reset control, hold and isolation controls, and reset-sequencing status registers.

Table 851. Reset Unit Address Map register list

Address	Name	Access	Description
0x20	SS_CONFIG	RW	-
0x24	SS_CONFIG_LOCK	RW	-
0x40	SS_COLD_RESET_N	RW	-
0x44	SS_WARM_RESET_N	RW	-
0x48	SS_CONFIG_HOLD	RW	-
0x4C	SS_SRAM_HOLD	RW	-
0x50	SS_CRITICAL_HOLD	RW	-
0x54	SS_DEBUG_HOLD	RW	-
0x60	SS_RESET_COMPLETE	R	-
0x70	SS_COLD_RESET_LOCK	RW	-
0x80	SS_FORCE_TO_REF_CLK	RW	-
0xA8	SYNC_REG	RW	-
0xB0	ISOLATE_REQ_REG	RW	-
0xB4	ISOLATE_REQ_PINEN_REG	RW	-
0xB8	ISOLATE_REQ_SMC_REG	RW	-
0xBC	ISOLATE_REQ_SMCEN_REG	RW	-
0xC0	ISOLATE_REQ_VIS	R	-
0xC4	ISOLATE_REQ_FLR_COUNTER_VALUE	RW	-
0xC8	ISOLATE_REQ_FLR_RESET_COUNTER_VALUE	RW	-

2.1.6.2.5.2.1.1. SS_CONFIG

Table 852. reset_unit.SS_CONFIG fields

Bits	Field	Access	Reset	Description
31:0	ss_config	RW	0x0	Configuration registers to setup system configuration. Usage is integration-specific; see the adopter chiplet specification.

2.1.6.2.5.2.1.2. SS_CONFIG_LOCK

Table 853. reset_unit.SS_CONFIG_LOCK fields

Bits	Field	Access	Reset	Description
31:0	config_lock	RW1S	0x0	Written to lock down SS config. If bit 0 is written, then bit 0 of other SS config cannot be written to again

2.1.6.2.5.2.1.3. SS_COLD_RESET_N

Table 854. reset_unit.SS_COLD_RESET_N fields

Bits	Field	Access	Reset	Description
31:0	reset_n_n0_scan	RW	0x0	Subsystem active low cold resets

2.1.6.2.5.2.1.4. SS_WARM_RESET_N

Table 855. reset_unit.SS_WARM_RESET_N fields

Bits	Field	Access	Reset	Description
31:0	reset_n_n0_scan	RW	0xFFFFFFFF	Subsystem active low warm resets

2.1.6.2.5.2.1.5. SS_CONFIG_HOLD

Table 856. reset_unit.SS_CONFIG_HOLD fields

Bits	Field	Access	Reset	Description
31:0	configuration_state_hold	RW	0x0	Used with warm_reset_n. Asserting ensures all registers configured during boot, including fuse values for export compliance, SRAM repair, other fuse values, etc. are preserved

2.1.6.2.5.2.1.6. SS_SRAM_HOLD

Table 857. reset_unit.SS_SRAM_HOLD fields

Bits	Field	Access	Reset	Description
31:0	sram_hold	RW	0x0	Used with warm_reset_n. Asserting ensures SRAMs, latch arrays and anything else that MBIST is used to test and initialize during cold reset are preserved

2.1.6.2.5.2.1.7. SS_CRITICAL_HOLD

Table 858. reset_unit.SS_CRITICAL_HOLD fields

Bits	Field	Access	Reset	Description
31:0	critical_signal_hold	RW	0x0	Used with warm_reset_n. Asserting ensures security, RAS, NMIs, perf counters, debug/trace and other subsystem specific registers are preserved

2.1.6.2.5.2.1.8. SS_DEBUG_HOLD

Table 859. reset_unit.SS_DEBUG_HOLD fields

Bits	Field	Access	Reset	Description
31:0	debug_hold	RW	0x0	Used with warm_reset_n. Debug hold signal to ensure any debug registers are preserved

2.1.6.2.5.2.1.9. SS_RESET_COMPLETE

Table 860. reset_unit.SS_RESET_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	reset_complete	R	0x0	Response signal from subsystem to indicate reset (or some other critical step) has completed. Bitwise write 1 to clear

2.1.6.2.5.2.1.10. SS_COLD_RESET_LOCK

Table 861. reset_unit.SS_COLD_RESET_LOCK fields

Bits	Field	Access	Reset	Description
31:0	cold_reset_lock	RW1S	0x0	Written to lock down SS cold reset. If bit 0 is written, then bit 0 of other SS cold reset cannot be written to again

2.1.6.2.5.2.1.11. SS_FORCE_TO_REF_CLK

Table 862. reset_unit.SS_FORCE_TO_REF_CLK fields

Bits	Field	Access	Reset	Description
31:0	force_ss_to_ref_clk_n	RW	0x0	Forces clock to be ref clk. The ensures reset reaches all FFs within a subsystem in same clock cycle

2.1.6.2.5.2.1.12. SYNC_REG

Table 863. reset_unit.SYNC_REG fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	sync	RW	0x0	Set to assert global sync bit

2.1.6.2.5.2.1.13. ISOLATE_REQ_REG

Table 864. reset_unit.ISOLATE_REQ_REG fields

Bits	Field	Access	Reset	Description
31:0	isolate_req_reg	RW	0x0	Isolate request. This prevents reset from being propagated to SS, keeping them alive in case of a cold reset

2.1.6.2.5.2.1.14. ISOLATE_REQ_PINEN_REG

Table 865. reset_unit.ISOLATE_REQ_PINEN_REG fields

Bits	Field	Access	Reset	Description
31:0	isolate_req_pinen_reg	RW	0x0	Isolate request pin enable. This enables the external isolate request pin to have an effect on ss isolate requests

2.1.6.2.5.2.1.15. ISOLATE_REQ_SMC_REG

Table 866. reset_unit.ISOLATE_REQ_SMC_REG fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
0	isolate_req_smc_reg	RW	0x0	Isolate request smc. Asserted once cfg_flr_pf_active is asserted, de-asserted by sw

2.1.6.2.5.2.1.16. ISOLATE_REQ_SMCEN_REG

Table 867. reset_unit.ISOLATE_REQ_SMCEN_REG fields

Bits	Field	Access	Reset	Description
31:0	isolate_req_smcen_reg	RW	0x0	Isolate request smc enable. This enables the FLR lock to have an effect on ss isolate requests

2.1.6.2.5.2.1.17. ISOLATE_REQ_VIS

Table 868. reset_unit.ISOLATE_REQ_VIS fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	cool_reset_n_o	R	0x1	Visibility bit for cool reset output
7:5	Reserved	-	-	Reserved
4	cool_reset_n_i	R	0x1	Visibility bit for cool reset input
3:1	Reserved	-	-	Reserved
0	isolate_req_pin	R	0x1	Visibility bit for isolate request pin

2.1.6.2.5.2.1.18. ISOLATE_REQ_FLR_COUNTER_VALUE

Table 869. reset_unit.ISOLATE_REQ_FLR_COUNTER_VALUE fields

Bits	Field	Access	Reset	Description
31:0	isolate_req_flr_counter_value	RW	0x0	Number of cycles post cfg_flr_pf_active assertion is waited until cool_reset_n is asserted

2.1.6.2.5.2.1.19. ISOLATE_REQ_FLR_RESET_COUNTER_VALUE

Table 870. reset_unit.ISOLATE_REQ_FLR_RESET_COUNTER_VALUE fields

Bits	Field	Access	Reset	Description
31:0	isolate_req_flr_reset_counter_value	RW	0x0	Number of cycles cool_reset_n is asserted for. NOTE: The cool reset flow requires this value to be greater than 0; a value of 0 will prevent initiation, regardless of ISOLATE_REQ_FLR_COUNTER_VALUE's value

2.1.6.3. CPU

The SMC CPU subsystem contains four Rocket RV64GC cores, each with private instruction and data caches. The cores share a 1 MiB scratchpad and a 128 KiB boot ROM through the Chipyard-generated TileLink interconnect. AXI4 bridges connect the cluster to the SMC fabric.

This chapter describes the generated configuration, memory interfaces and CPU reset boundary. The Rocket Chip documentation provides background on the core and generator.

Figure 57 shows the CPU cluster, memory hierarchy, and fabric bridge.




Figure 57. SMC CPU cluster and TileLink-to-AXI integration

The figure separates three implementation boundaries:

- `u_digital_top` contains the generated cluster and TileLink buses.
- `u_smc_cpu` adds AXI isolation, reset sequencing and scratchpad zero-fill.
- `u_smc_cpu_wrapper` adds the front-port demultiplexer, `cpu_ctrl` registers and boot ROM bridge.

Each tile connects to the system bus (`sbus`) as a manager and to the control bus (`cbus`) through its Bus Error Unit (BEU) subordinate port. Debug system bus accesses and the L2 frontend port enter `sbus` through the front bus (`fbus`). The coherence manager (`coh_wrapper`, a TileLink broadcast hub) connects to the memory bus (`mbus`), which serves the scratchpad and boot ROM. The PLIC receives four watchdog and four BEU interrupt sources; these paths are omitted from the figure.

Thick lines denote AXI4; thin dark lines denote TileLink, except for the AXI-Lite link to `cpu_ctrl`. The scratchpad contains 32 TLRAM banks with SECDED encode/decode logic. The SRAM macros, L1 tag/data arrays and boot ROM macro sit outside SMC. Memory interface ports carry their requests through the SMC boundary, including one 72-bit port for

each scratchpad bank.

2.1.6.3.1. Processor Core

Table 871 summarizes the processor configuration.

Table 871. SMC processor core features

Attribute	Description
Cores	4, Rocket RV64GC
Base ISA	RV64GC (I, M, A, F, D, C extensions)
Additional configured extensions	Zba, Zbb, Zbs and conditional-zero instructions
Microarchitecture	In-order, 5-stage pipeline
Privilege Levels	M/S/U
Phys. Address	56 bits
Reset Vector	Per-core, independently configurable (56b)

2.1.6.3.2. Local Memory

Table 872 lists the memory geometry in the generated cluster and the associated macro controls.

Table 872. SMC cache and memory hierarchy

Component	Configured Size	Protection / role	Macro controls
L1 I-Cache per core	4 KiB (32 sets × 2 ways)	Read-only instruction cache; tag/data parity	`icache_tag_cfg` / `icache_data_cfg`
L1 D-Cache per core	4 KiB (32 sets × 2 ways)	Write-back data cache; tag/data SECDED ECC	`dcache_tag_cfg` / `dcache_data_cfg`
Local SRAM/Scratchpad	1 MiB (32 banks)	Shared local memory; SECDED ECC	`scratch_ram_cfg`
Boot ROM	128 KiB	Read-only, stores boot firmware	`rom_cfg`

The sizes and associativity above are set by the Chipyard configuration and its generated memory interfaces. Changing them requires a matching generated cluster and memory implementation. The `*_cfg` signals configure the external memory macros; they are passed unchanged to each macro and do not resize caches or the scratchpad. Macro-specific repair and power controls depend on the selected memory implementation.

The cluster uses TileLink internally for the scratchpad and boot ROM, for the PLIC, CLINT and BEUs on the control bus, and for watchdog timers on the peripheral bus. At its boundary, the MMIO manager bridge converts TileLink to AXI4; the L2 frontend bridge converts incoming AXI4 to TileLink. The front-port branch serving `cpu_ctrl` uses AXI4-Lite. Both AXI4 ports connect to the SMC Fabric.

2.1.6.3.3. Reset and Boot

`CPU_CTRL.RESET_CTRL` provides per-core reset controls and reset-pulse requests, plus separate uncore and debug-module reset controls. Each core has a 56-bit `RESET_VECTOR` register, reset to the boot ROM base `0xC004_0000`. The wrapper supplies these values to the generated cluster. While warm reset is asserted, it selects `0xC004_0000` instead of the programmed vectors.

Individual core reset clears the core's private L1 cache and TileLink client state without resetting the shared coherence manager. The current SMC Rocket integration provides no reset-aware coherence mechanism to drain outstanding transactions or preserve dirty cache data. The AXI boundary drain described below does not remove this limitation.

The scratchpad zero-fill sequencer starts when its memory-initialization reset releases. It writes zeros across the

scratchpad banks and holds the cores in reset until initialization completes. smc_disable_sram_auto_init_i bypasses this operation. smc_init_mem_done_o reports either completion or bypass; it does not certify memory repair, MBIST success or initialized contents when zero-fill is skipped. The integrator must provide suitable memory contents and ECC state before use when bypassing initialization.

2.1.6.3.4. Memory Repair

Memory repair and memory built-in self-test (MBIST) are external DFT responsibilities. The external repair controller applies redundant memory elements as required by the selected SRAM implementation. The SMC fuse map provides no repair-data storage; the integrator supplies the repair data and its storage location.

The intended cold-boot sequence is fuse sensing, external repair, then MBIST before normal CPU use. SMC supplies the following sequencing and status interfaces; it does not implement the external repair algorithm.

smc_fuse_sense_done_o
: Signals completion of fuse sensing into shadow registers. External DFT logic can use it to begin the repair/MBIST sequence.

ext_boot_seq_done_i
: Reports completion of the external boot sequence. Its qualified value gates fuse-reset release together with fuse sensing; the repair and MBIST status bits themselves are not this handshake.

skip_mem_repair_o
: Asserted by the synchronized isolation pin or the FLR-set ISOLATE_REQ_SMC_REG latch. Software writes can clear this latch but cannot set it. A request through the separate ISOLATE_REQ_REG register does not assert this output. External logic determines how it bypasses repair/MBIST.

BYPASS_SRAM_REPAIR (STRAPS_LO[13])
: Requests repair bypass. The ROM skips its repair-status check when this strap is set; the external integration owns the repair bypass behavior.

mem_repair_done / mem_repair_success
: External completion and success status, visible in DFX_CTRL_STATUS.STATUS_SMU at 0xC000_B800.

The ROM checks repair status during early startup, before normal stack use. It treats a clear mem_repair_done as repair not required rather than waiting for completion. When repair reports done, the ROM checks success; the SMC_CONFIG DFT-ignore-error setting can permit boot to continue after a reported failure. These firmware checks do not establish that repair has completed successfully. The external sequencer must enforce the platform's repair and MBIST requirements before reporting boot-sequence completion.

2.1.6.3.5. System Interfaces

Table 873 identifies the protocols and roles of the CPU cluster interfaces.

Table 873. SMC CPU system interfaces

Interface	Protocol	Description
MMIO	AXI4	Manager port to the SMC fabric; 56-bit address, 64-bit data, 3-bit ID
L2 Frontend	AXI4	Subordinate port into the cluster through the front bus; 32-bit SMC-local address, 64-bit data, 8-bit ID
Debug	JTAG	JTAG debug transport module into the debug module on the control bus; system bus access through the front bus

2.1.6.3.6. CPU AXI Isolation

The cluster is reset independently of the surrounding SMC fabric. If the cluster were reset while a transaction on one of its AXI ports was still in flight, the fabric on the other side would be left waiting on a response that never returns, hanging the bus, and could sample boundary signals while they glitch through reset. To avoid this, each AXI port is wrapped in an `axi_isolate` block that drains the outstanding transactions and holds the boundary at safe values before the reset is allowed to take effect.

Two instances wrap the AXI ports listed above, each sized for up to four outstanding transactions:

- the **L2 frontend** slave port, which blocks new transactions rather than terminating them, and
- the **MMIO** master port, which terminates new transactions presented while isolated with SLVERR responses to keep reset-time X values from propagating into the fabric.

The non-AXI status crossings (`wb_pc_valid`, `wb_reg_pc`, and the per-core `wdt_reset`) are clamped to constants over the same window so they cannot leak glitches either. The boundary also self-isolates on cold boot, releasing four cycles after SRAM initialization completes and the cores and uncore are out of reset.

The boundary is shared by all cores and stays isolated while any core or the uncore is in reset. Holding one core in reset therefore also terminates the other cores' MMIO accesses with SLVERR and stalls L2 frontend traffic until every core is released.

2.1.6.3.6.1. Drain Handshake

The per-core reset sequence in the Programmer's Guide gives the firmware steps. A software reset through `CPU_CTRL.RESET_CTRL`, whether a core or uncore reset bit or a core reset pulse, proceeds as follows:

1. Firmware writes `RESET_CTRL`.
2. The control logic (`smc_cpu_ctrl_wrap`) raises `isolate_req_i` and withholds the reset.
3. Both `axi_isolate` instances drain their outstanding transactions and isolate.
4. The cluster raises `drained_o`, and the control logic applies the reset.
5. `isolate_req_i` stays high until every reset bit is released and every pulse completes. The boundary then reconnects.

2.1.6.3.6.2. Timeout Recovery

`CPU_CTRL.RESET_TIMEOUT` limits how long a software-requested reset waits for the drain handshake. A `timeout_value` of zero disables the timer. When the timer expires, `timeout_mode=0` reports the timeout and continues to withhold the reset. `timeout_mode=1` forces the reset and flushes both AXI isolation blocks.

`reset_timeout` remains high until the software reset request is removed, including after a recovery flush completes. `reset_applied` is high once the reset is applied by a completed drain or a force-mode timeout.

The flush clears outstanding-transaction records at the cluster boundary and discards late responses and write data until isolation is released. This lets the reset complete when the CPU cluster is unresponsive but the surrounding fabric remains operational.

WARNING	The flush cannot cancel an address request or write-data beat while `VALID` is high and `READY` is low. It waits for that transfer before flushing the channel. If `READY` never goes high, isolation cannot complete. The flush clears only the CPU isolation blocks. It does not clear state elsewhere in the SMC fabric.

> The cluster reset may complete while another block remains unresponsive or holds a response, leaving that route or AXI ID blocked, so that block must be recovered separately or through the eventual cold reset.

2.1.6.3.6.3. Reset-Domain Crossing

The flops driving the isolate-control logic are held by the cluster's uncore/core reset, while the flops inside `axi_isolate` are held by the Primary Reset (see Clock and Reset Management). The uncore/core reset is driven from two sources:

- a Warm Reset from a watchdog timeout, which is **asynchronous** to the isolate logic, and
- a CPU CSR write (the reset-control register in `smc_cpu_ctrl_wrap`), which is **synchronous**.

Because the two sets of flops sit in different reset domains, the asynchronous warm-reset path is a reset-domain crossing into `axi_isolate`. This is acceptable: only the watchdog asserts the warm reset asynchronously, and a watchdog timeout is followed by a cold reset, so the brief crossing window has no functional consequence. The CSR path is synchronous and crosses no domains.

2.1.6.3.7. Interrupt Integration

All interrupt wiring—MMIO bases for PLIC, CLINT, watchdog, and bus-error units; the authoritative `cpu_interrupts_o` map; PLIC/CLINT register documentation; and BEU direct interrupt delivery—is documented in Interrupts.

2.1.6.3.8. Watchdog Interface

Each core has a watchdog. See Watchdog Timers for operation and the register reference.

2.1.6.3.9. Bus Error Reporting

Each core has a Bus Error Unit (BEU) at `0xC801_0000 + N * 0x1000`, for N = 0 through 3. It reports errors seen by that core's L1 caches:

- instruction-cache correctable errors,
- instruction-cache bus errors,
- data-cache correctable errors,
- data-cache uncorrectable errors, and
- data-cache bus errors.

An error response from the SMC fabric reaches the BEU only as a cache bus error; the BEU does not distinguish decode, slave or timeout errors. It is not a general AXI transaction monitor and has no independent AXI timeout detector or transaction-data log.

`ENABLE` selects events that capture `CAUSE` and `PHYS_ADDR` while `CAUSE` is zero. Instruction-cache correctable errors capture a physical address of zero. The register named `ACCRUED_ENABLE` is instead sticky event status: events accumulate independently of `ENABLE`, and ordinary software writes replace the bits. `PLIC_ENABLE` and `LOCAL_ENABLE` select from that accrued status for the PLIC and direct-core interrupt paths. Capture the diagnostic state before clearing status or rearming cause capture. The generated register map below lists the implemented fields. Delivery and clearing are described in Bus Error Units.

2.1.6.3.10. Debug

The generated memory map below describes the hart-facing Debug Module memory region. Only the harts of the CPU cluster reach it, over the cluster's own control bus. The SMC fabric does not route it, so system, SEP and other SMC initiators receive DECERR at every address in the region. Debugger-facing registers such as `dmcontrol`, `dmstatus`, `abstractcs` and `sbcs` are accessed through the Debug Module Interface (DMI), not through that memory region. Section 2.1.6.3.10.1 describes them.

JTAG reaches the cluster's debug transport module and debug module. The configured debug facilities provide per-core register access, program-buffer execution, breakpoints and system bus access. Debug system bus transactions enter through `fbus` and use the cluster's interconnect and reset/isolation conditions.

Debug-module reset is separately controlled by `CPU_CTRL.RESET_CTRL`; its reset value holds the debug module in reset. Separate control does not make debug memory accesses independent of cluster reset or boundary isolation. Per-core boot addresses are controlled by the `RESET_VECTOR` registers described above.

2.1.6.3.10.1. Debug Module Configuration

The Debug Module implements version 0.13 of the RISC-V External Debug Support specification for the four harts of the CPU cluster. A debugger discovers its configuration by reading DMI registers. Table 874 lists the fixed capability values those registers return, and Table 875 lists which DMI registers are implemented.

Table 874. SMC Debug Module capability readbacks

Register	Field	Value	Meaning
`dmstatus`	`version`	2	Debug Specification 0.13
`dmstatus`	`authenticated`	1	No authentication is required
`dmstatus`	`hasresethaltreq`	1	Halt-on-reset is supported
`dmstatus`	`confstrptrvalid`	0	No configuration string
`dmstatus`	`impebreak`	1	An implicit `ebreak` follows the program buffer
`dmcontrol`	`hartsello`	2 bits	Harts 0 to 3; `hartselhi` reads 0
`abstractcs`	`progbufsize`	16	`progbuf0` to `progbuf15`
`abstractcs`	`datacount`	4	`data0` to `data3`
`abstractauto`	`autoexecdata`	4 bits	Auto-execution from `data0` to `data3`
`abstractauto`	`autoexecprogbuf`	16 bits	Auto-execution from `progbuf0` to `progbuf15`
`sbcs`	`sbversion`	1	System bus access as defined by Debug Specification 0.13
`sbcs`	`sbasize`	56	System bus address width in bits
`sbcs`	`sbaccess8`, `sbaccess16`, `sbaccess32`, `sbaccess64`	1	8-, 16-, 32- and 64-bit system bus accesses
`sbcs`	`sbaccess128`	0	No 128-bit system bus access

The `command` register accepts only the Access Register command (`cmdtype` 0). With `transfer` set, Access Register reaches the general-purpose registers `x0` to `x31` (`regno` 0x1000 to 0x101F) with an `aarsize` of 2 or 3 (32 or 64 bits). With `transfer` clear, any `regno` and size is accepted. Any other command type, and any transfer outside those registers and sizes, sets `abstractcs.cmderr` to 2 (not supported). The debugger reaches CSRs and floating-point registers by executing instructions from the program buffer. Reading `command` returns the last value written.

`hawindowsel` reads 0 and ignores writes, so `hawindow` bits 3:0 hold the hart array mask for harts 0 to 3. `setresethaltreq` and `clrresethaltreq` in `dmcontrol` set and clear halt-on-reset for the selected harts.

DMI address 0x32 provides the halt-group fields of the `dmcs2` register, which later versions of the specification define. A

write with hgwrite set, hgselect clear and haltgroup 0 or 1 removes the selected harts from halt group 1 or adds them to it. When one hart in halt group 1 halts, the Debug Module halts the other harts in that group. A read returns the group of the hart selected by hartsel in haltgroup. External trigger groups (hgselect set) are not supported.

DMI registers that the Debug Module does not implement read as 0 and ignore writes.

Table 875. SMC Debug Module DMI register inventory

DMI address	Register	Implementation
0x04-0x07	data0-data3	Implemented
0x08-0x0F	data4-data11	Not implemented
0x10	dmcontrol	Implemented; hartsello bits 17:16 only, hartselhi reads 0
0x11	dmstatus	Implemented
0x12	hartinfo	Not implemented
0x13	haltsum1	Implemented; bit 0 only
0x14	hawindowsel	Reads 0
0x15	hawindow	Implemented; bits 3:0 only
0x16	abstractcs	Implemented
0x17	command	Implemented; Access Register only
0x18	abstractauto	Implemented; autoexecdata bits 3:0 only
0x19-0x1C	confstrptr0-confstrptr3	Not implemented
0x1D	nextdm	Not implemented; this is the only Debug Module
0x20-0x2F	progbuf0-progbuf15	Implemented
0x30	authdata	Not implemented
0x32	dmcs2	Implemented; halt groups 0 and 1 only
0x34	haltsum2	Not implemented
0x35	haltsum3	Not implemented
0x37	sbaddress3	Not implemented
0x38	sbcs	Implemented
0x39-0x3A	sbaddress0-sbaddress1	Implemented
0x3B	sbaddress2	Not implemented
0x3C-0x3D	sbdata0-sbdata1	Implemented
0x3E-0x3F	sbdata2-sbdata3	Not implemented
0x40	haltsum0	Implemented; bits 3:0 only

2.1.6.3.10.2. Abstract Command Writes While cmderr Is Set

The Debug Module departs from the RISC-V External Debug Support specification (version 0.13) for writes to command while abstractcs.cmderr is nonzero. The specification ignores those writes. In this Debug Module, a command write made while no abstract command is executing (abstractcs.busy is 0) has two effects:

- the written value replaces the stored command, whatever cmderr holds, and
- a command type other than Access Register (cmdtype other than 0) sets cmderr to 2 (not supported), replacing the error code it held.

No abstract command executes while cmderr is nonzero. Once cmderr is cleared, an access that abstractauto selects re-executes the stored command, which is the last value written to command.

A `command` write therefore discards the error code of a failed command unless `abstractcs` was read first. The Programmer's Guide gives the debugger sequence for clearing `cmderr`.

2.1.6.3.11. Memory Map and Register Reference

2.1.6.3.11.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.6.3.11.2. Detailed Register Map

2.1.6.3.11.2.1. CPU Control Address Map

Per-core reset control and status, reset timing, chip configuration, mailbox, and boot-ROM stub registers for the SMC CPU cluster.

NOTE

Register Arrays:

- **RESET_VECTOR[4]**: 4 registers, base 0x0, stride 0x8
- **SCRATCH[16]**: 16 registers, base 0x80, stride 0x8
- **WB_PC_CORE0[8]**: 8 registers, base 0x100, stride 0x8
- **WB_PC_CORE1[8]**: 8 registers, base 0x140, stride 0x8
- **WB_PC_CORE2[8]**: 8 registers, base 0x180, stride 0x8
- **WB_PC_CORE3[8]**: 8 registers, base 0x1C0, stride 0x8
- **MUTEX[4]**: 4 registers, base 0x240, stride 0x8
- **SEMA[4]**: 4 registers, base 0x260, stride 0x8
- **DUMMY_ROM_NULL[4]**: 4 registers, base 0x2A0, stride 0x8

Table 876. CPU Control Address Map register list

Address	Name	Access	Description
0x0 - 0x18	RESET_VECTOR[4]	RW	-
0x20	RESET_CTRL	RW	-
0x28	CORE_RESET_PULSE_COUNT	RW	-
0x30	RESET_TIMEOUT	RW	-
0x40	REFERENCE_COUNTER	RW	-
0x50	WDT_TIMEOUT	RW	-
0x58	WDT_TIMEOUT_RESET	RW	-
0x60	TEST_CTRL	R	-
0x80 - 0xF8	SCRATCH[16]	RW	-
0x100 - 0x138	WB_PC_CORE0[8]	R	-
0x140 - 0x178	WB_PC_CORE1[8]	R	-

Address	Name	Access	Description
0x180 - 0x1B8	WB_PC_CORE2[8]	R	-
0x1C0 - 0x1F8	WB_PC_CORE3[8]	R	-
0x200	SMC_ATTRIBUTES	R	-
0x240 - 0x258	MUTEX[4]	RW	-
0x260 - 0x278	SEMA[4]	RW	-
0x280	DUMMY_ROM_0	RW	-
0x288	DUMMY_ROM_1	RW	-
0x290	DUMMY_ROM_2	RW	-
0x298	DUMMY_ROM_3	RW	-
0x2A0 - 0x2B8	DUMMY_ROM_NULL[4]	RW	-

2.1.6.3.11.2.1.1. RESET_VECTOR[4]

Table 877. cpu_ctrl.RESET_VECTOR[4] fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	vector	RW	0xC0040000	-

2.1.6.3.11.2.1.2. RESET_CTRL

Table 878. cpu_ctrl.RESET_CTRL fields

Bits	Field	Access	Reset	Description
63:25	Reserved	-	-	Reserved
24	debug_reset_n_n0_scan	RW	0x0	Debug Module Reset, active low
23:9	Reserved	-	-	Reserved
8	uncore_reset_n_n0_scan	RW	0x1	Cluster Uncore Reset, active low. Writing this register will only reset the uncore portion in the chipyard cluster. WARNING: using this can cause any outstanding axi requests to and from the cluster to cause timeouts/exceptions.
7	core3_reset_pulse_start_n0_scan	RW	0x0	Writing a 1 to this register triggers a core reset pulse on core 3, timed by CORE_RESET_PULSE_COUNT. A 0 in core3_reset_n_n0_scan holds the core in reset for the whole pulse.
6	core2_reset_pulse_start_n0_scan	RW	0x0	Writing a 1 to this register triggers a core reset pulse on core 2, timed by CORE_RESET_PULSE_COUNT. A 0 in core2_reset_n_n0_scan holds the core in reset for the whole pulse.
5	core1_reset_pulse_start_n0_scan	RW	0x0	Writing a 1 to this register triggers a core reset pulse on core 1, timed by CORE_RESET_PULSE_COUNT. A 0 in core1_reset_n_n0_scan holds the core in reset for the whole pulse.
4	core0_reset_pulse_start_n0_scan	RW	0x0	Writing a 1 to this register triggers a core reset pulse on core 0, timed by CORE_RESET_PULSE_COUNT. A 0 in core0_reset_n_n0_scan holds the core in reset for the whole pulse.
3	core3_reset_n_n0_scan	RW	0x1	Reset control for the CPU, active low.

Bits	Field	Access	Reset	Description
2	core2_reset_n_n0_scan	RW	0x1	Reset control for the CPU, active low.
1	core1_reset_n_n0_scan	RW	0x1	Reset control for the CPU, active low.
0	core0_reset_n_n0_scan	RW	0x1	Reset control for the CPU, active low.

2.1.6.3.11.2.1.3. CORE_RESET_PULSE_COUNT

Table 879. cpu_ctrl.CORE_RESET_PULSE_COUNT fields

Bits	Field	Access	Reset	Description
63:36	Reserved	-	-	Reserved
35:32	core_resets_done	R	0xF	Logic low while performing core reset, logic high otherwise.
31:16	post_reset_count	RW	0x10	Cycles (clk_smc), minus one, that a core reset pulse holds the core in reset.
15:0	pre_reset_count	RW	0x8	Cycles (clk_smc), minus one, from the start of a core reset pulse to reset assertion.

2.1.6.3.11.2.1.4. RESET_TIMEOUT

Table 880. cpu_ctrl.RESET_TIMEOUT fields

Bits	Field	Access	Reset	Description
63:37	Reserved	-	-	Reserved
36	reset_timeout	R	0x0	Status for the active software reset request: high after the request exceeds timeout_value and remains high until the request is deasserted. Set in both modes.
35:33	Reserved	-	-	Reserved
32	reset_applied	R	0x0	Live status: high while a requested software reset is applied at the cluster, either after drain completes or after a force-mode timeout.
31:17	Reserved	-	-	Reserved
16	timeout_mode	RW	0x0	Timeout mode: 0 = give up and report error (stay withheld, do not apply); 1 = force the reset on timeout.
15:0	timeout_value	RW	0x0	Cycles (clk_smc) a software reset may stay pending (withheld, waiting for drain) before timeout. 0 = disabled, wait indefinitely.

2.1.6.3.11.2.1.5. REFERENCE_COUNTER

Table 881. cpu_ctrl.REFERENCE_COUNTER fields

Bits	Field	Access	Reset	Description
63:0	rc	RW	0x0	Reference counter for the CPU. Write once, then poll this register until the readback reflects the written value before writing again. The counter keeps advancing, so the readback is at or just above the written value rather than equal to it.

2.1.6.3.11.2.1.6. WDT_TIMEOUT

Table 882. cpu_ctrl.WDT_TIMEOUT fields

Bits	Field	Access	Reset	Description
31:0	data	RW	0x4000	Cycle count value that 2nd stage watchdog timer timeout should occur at. Defaults to 16384 cycles

2.1.6.3.11.2.1.7. WDT_TIMEOUT_RESET

Table 883. cpu_ctrl.WDT_TIMEOUT_RESET fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	reset_cycle_count_3	RW 1P	0x0	Reset current cycle count value in 2nd stage watchdog timer
2	reset_cycle_count_2	RW 1P	0x0	Reset current cycle count value in 2nd stage watchdog timer
1	reset_cycle_count_1	RW 1P	0x0	Reset current cycle count value in 2nd stage watchdog timer
0	reset_cycle_count_0	RW 1P	0x0	Reset current cycle count value in 2nd stage watchdog timer

2.1.6.3.11.2.1.8. TEST_CTRL

Table 884. cpu_ctrl.TEST_CTRL fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	data	R	0x0	Test control register for the CPU

2.1.6.3.11.2.1.9. SCRATCH[16]

Table 885. cpu_ctrl.SCRATCH[16] fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	data	RW	0x0	Scratch register for the CPU

2.1.6.3.11.2.1.10. WB_PC_CORE0[8]

Table 886. cpu_ctrl.WB_PC_CORE0[8] fields

Bits	Field	Access	Reset	Description
63:58	Reserved	-	-	Reserved
57:0	pc	R	0x0	Writeback PC value

2.1.6.3.11.2.1.11. WB_PC_CORE1[8]

Table 887. cpu_ctrl.WB_PC_CORE1[8] fields

Bits	Field	Access	Reset	Description
63:58	Reserved	-	-	Reserved
57:0	pc	R	0x0	Writeback PC value

2.1.6.3.11.2.1.12. WB_PC_CORE2[8]

Table 888. cpu_ctrl.WB_PC_CORE2[8] fields

Bits	Field	Access	Reset	Description
63:58	Reserved	-	-	Reserved
57:0	pc	R	0x0	Writeback PC value

2.1.6.3.11.2.1.13. WB_PC_CORE3[8]

Table 889. cpu_ctrl.WB_PC_CORE3[8] fields

Bits	Field	Access	Reset	Description
63:58	Reserved	-	-	Reserved
57:0	pc	R	0x0	Writeback PC value

2.1.6.3.11.2.1.14. SMC_ATTRIBUTES

Table 890. cpu_ctrl.SMC_ATTRIBUTES fields

Bits	Field	Access	Reset	Description
63:46	Reserved	-	-	Reserved
45:40	num_mailboxes	R	-	-
39:36	mailbox_depth	R	-	-
35:33	num_cores	R	-	-
32	no_output_remap	R	-	-
31:26	sram_size	R	-	Total SRAM size is 2 ^ value bytes
25:17	num_cpu_interrupts	R	-	-
16:8	num_ext_interrupts	R	-	-
7:1	Reserved	-	-	Reserved
0	chiplet_is_primary	R	-	Indicates if this chiplet is primary (1) or secondary (0). Driven by strap.

2.1.6.3.11.2.1.15. MUTEX[4]

Table 891. cpu_ctrl.MUTEX[4] fields

Bits	Field	Access	Reset	Description
63:1	Reserved	-	-	Reserved
0	mutex	RW	0x1	HW mutex. Reads will attempt to acquire mutex, 1 on success. If the mutex is already acquired, the read will return 0. To release the mutex, write any value to the register.

2.1.6.3.11.2.1.16. SEMA[4]

Table 892. cpu_ctrl.SEMA[4] fields

Bits	Field	Access	Reset	Description
63:16	Reserved	-	-	Reserved
15:0	sema	RW	0x0	16-bit semaphore value to inc/dec. Writing to this register will inc/dec the semaphore value. The written value is treated as a signed number using 2s compliment.

2.1.6.3.11.2.1.17. DUMMY_ROM_0

Table 893. cpu_ctrl.DUMMY_ROM_0 fields

Bits	Field	Access	Reset	Description
63:0	dummy_rom_word_0	RW	0x1450513 00000517	Word 0 of WFI loop

2.1.6.3.11.2.1.18. DUMMY_ROM_1

Table 894. cpu_ctrl.DUMMY_ROM_1 fields

Bits	Field	Access	Reset	Description
63:0	dummy_rom_word_1	RW	0xFFF0069330551073	Word 1 of WFI loop

2.1.6.3.11.2.1.19. DUMMY_ROM_2

Table 895. cpu_ctrl.DUMMY_ROM_2 fields

Bits	Field	Access	Reset	Description
63:0	dummy_rom_word_2	RW	0x105000733046B073	Word 2 of WFI loop

2.1.6.3.11.2.1.20. DUMMY_ROM_3

Table 896. cpu_ctrl.DUMMY_ROM_3 fields

Bits	Field	Access	Reset	Description
63:0	dummy_rom_word_3	RW	0xFFDFF06F	Word 3 of WFI loop

2.1.6.3.11.2.1.21. DUMMY_ROM_NULL[4]

Table 897. cpu_ctrl.DUMMY_ROM_NULL[4] fields

Bits	Field	Access	Reset	Description
63:0	dummy_rom_null	RW	0x0	Cache line size is 64 bytes so want to ensure no random data is read when reading dummy rom

2.1.6.3.11.2.2. CLINT Address Map

Core-Local Interruptor: software-interrupt, timer-compare, and machine-time registers.

NOTE

Register Arrays:

- **MSIP[4]**: 4 registers, base 0x0, stride 0x4
- **MTIMECMP[4]**: 4 registers, base 0x4000, stride 0x8

Table 898. CLINT Address Map register list

Address	Name	Access	Description
0x0 - 0xC	MSIP[4]	RW	-
0x4000 - 0x4018	MTIMECMP[4]	RW	-
0xBFF8	MTIME	RW	-

2.1.6.3.11.2.2.1. MSIP[4]

Table 899. clint.MSIP[4] fields

Bits	Field	Access	Reset	Description
31:1	rsvd0	R	0x0	Reserved
0	value	RW	0x0	MSIP bit for core

2.1.6.3.11.2.2.2. MTIMECMP[4]

Table 900. clint.MTIMECMP[4] fields

Bits	Field	Access	Reset	Description
63:0	count	RW	-	Timer compare value. The core's machine timer interrupt is asserted while MTIME is greater than or equal to this value, and deasserts when software sets this value above MTIME.

2.1.6.3.11.2.2.3. MTIME

Table 901. clint.MTIME fields

Bits	Field	Access	Reset	Description
63:0	count	RW	-	Cycle count (time) value

2.1.6.3.11.2.3. Debug Module Hart Interface

Memory region through which a hart in Debug Mode exchanges state with the Debug Module: handshake mailboxes, generated instructions, program buffer, data registers, per-hart flags and the debug ROM. Only the harts of the CPU cluster reach this region; SMC bus initiators outside the cluster do not. The debugger-facing Debug Module registers (dmcontrol, dmstatus, abstractcs, sbcs, …) are reached over the Debug Module Interface and do not appear in this map.

NOTE

Register Arrays:

- **ABSTRACT[5]**: 5 registers, base 0x328, stride 0x4
- **PROGBUF[16]**: 16 registers, base 0x33C, stride 0x4
- **DATA[4]**: 4 registers, base 0x380, stride 0x4
- **ROM[26]**: 26 registers, base 0x800, stride 0x4

Table 902. Debug Module Hart Interface register list

Address	Name	Access	Description
0x100	HALTED	W	-
0x104	GOING	W	-
0x108	RESUMING	W	-
0x10C	EXCEPTION	W	-
0x300	WHERETO	R	-
0x328 - 0x338	ABSTRACT[5]	R	-
0x33C - 0x378	PROGBUF[16]	RW	-
0x37C	IMPEBREAK	R	-
0x380 - 0x38C	DATA[4]	RW	-

Address	Name	Access	Description
0x400	FLAGS	R	One flag byte per hart, at byte offset equal to the hart ID. Bit 0 is go (execute the command at WHERETO); bit 1 is resume (leave Debug Mode). Bits 7:2 read as 0.
0x800 - 0x864	ROM[26]	R	-

2.1.6.3.11.2.3.1. HALTED

Table 903. debug_module.HALTED fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	hartid	W	-	Debug ROM causes the hart to write its hart ID here when it is in Debug Mode.

2.1.6.3.11.2.3.2. GOING

Table 904. debug_module.GOING fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	hartid	W	-	Debug ROM causes the hart to write 0 here when it begins executing Debug Mode instructions.

2.1.6.3.11.2.3.3. RESUMING

Table 905. debug_module.RESUMING fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	hartid	W	-	Debug ROM causes the hart to write its hart ID here when it leaves Debug Mode.

2.1.6.3.11.2.3.4. EXCEPTION

Table 906. debug_module.EXCEPTION fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	hartid	W	-	Debug ROM causes the hart to write 0 here if it takes an exception in Debug Mode.

2.1.6.3.11.2.3.5. WHERETO

Table 907. debug_module.WHERETO fields

Bits	Field	Access	Reset	Description
31:0	instr	R	-	Jump instruction filled in by the Debug Module to direct the hart in Debug Mode.

2.1.6.3.11.2.3.6. ABSTRACT[5]

Table 908. debug_module.ABSTRACT[5] fields

Bits	Field	Access	Reset	Description
31:0	instr	R	-	Instruction generated by the Debug Module for the current abstract command.

2.1.6.3.11.2.3.7. PROGBUF[16]

Table 909. debug_module.PROGBUF[16] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	0x0	Program buffer word shared with the debugger. Byte accesses are supported.

2.1.6.3.11.2.3.8. IMPEBREAK

Table 910. debug_module.IMPEBREAK fields

Bits	Field	Access	Reset	Description
31:0	instr	R	0x100073	Implicit EBREAK instruction following the program buffer.

2.1.6.3.11.2.3.9. DATA[4]

Table 911. debug_module.DATA[4] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	0x0	Abstract command data word shared with the debugger. Byte accesses are supported.

2.1.6.3.11.2.3.10. FLAGS

Table 912. debug_module.FLAGS fields

Bits	Field	Access	Reset	Description
31:24	flags_3	R	-	Hart 3 go/resume flags.
23:16	flags_2	R	-	Hart 2 go/resume flags.
15:8	flags_1	R	-	Hart 1 go/resume flags.
7:0	flags_0	R	-	Hart 0 go/resume flags.

2.1.6.3.11.2.3.11. ROM[26]

Table 913. debug_module.ROM[26] fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	Debug ROM word. Holds the fixed Debug Mode entry, exception and resume handlers.

2.1.6.3.11.2.4. Bus Error Unit Address Map

Status registers reporting correctable and uncorrectable I-cache, D-cache, and TileLink bus errors.

Table 914. Bus Error Unit Address Map register list

Address	Name	Access	Description
0x0	CAUSE	RW	-
0x8	PHYS_ADDR	RW	-
0x10	ENABLE	RW	-
0x18	PLIC_ENABLE	RW	-
0x20	ACCRUED_ENABLE	RW	Sticky accrued error status. The legacy name ACCRUED_ENABLE does not denote an enable mask. Error events set these bits independently of ENABLE. Ordinary software writes replace the bits (write zero to clear) and take priority over simultaneous events. PLIC_ENABLE and LOCAL_ENABLE mask this status for interrupt delivery.
0x28	LOCAL_ENABLE	RW	-

2.1.6.3.11.2.4.1. CAUSE

Table 915. bus_error_unit.CAUSE fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2:0	data	RW	0x0	Cause register. Enumerates different kinds of errors

2.1.6.3.11.2.4.2. PHYS_ADDR

Table 916. bus_error_unit.PHYS_ADDR fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	value	RW	-	Physical address captured with CAUSE when an enabled error arrives and CAUSE is zero. Software may overwrite the value; writes take priority over capture. No reset value

2.1.6.3.11.2.4.3. ENABLE

Table 917. bus_error_unit.ENABLE fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7	dcache_uncorrectable	RW	0x1	Enable recording error information for DCache ECC uncorrectable bus error. Enabled on reset.
6	dcache_correctable	RW	0x1	Enable recording error information for DCache ECC correctable bus error. Enabled on reset.
5	dcache_tlbus	RW	0x1	Enable recording error information for DCache Tilelink bus error. Enabled on reset.
4	rsvd4	RW	0x0	Reserved
3	rsvd3	RW	0x0	Reserved
2	icache_correctable	RW	0x1	Enable recording error information for ICache ECC correctable bus error. Enabled on reset.
1	icache_tlbus	RW	0x1	Enable recording error information for ICache Tilelink bus error. Enabled on reset.
0	rsvd0	RW	0x0	Reserved

2.1.6.3.11.2.4.4. PLIC_ENABLE

Table 918. bus_error_unit.PLIC_ENABLE fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7	dcache_uncorrectable	RW	0x0	PLIC interrupt enable mask for DCache ECC uncorrectable bus error.
6	dcache_correctable	RW	0x0	PLIC interrupt enable mask for DCache ECC correctable bus error.
5	dcache_tlbus	RW	0x0	PLIC interrupt enable mask for DCache Tilelink bus error.
4	rsvd4	RW	0x0	Reserved
3	rsvd3	RW	0x0	Reserved
2	icache_correctable	RW	0x0	PLIC interrupt enable mask for ICache ECC correctable bus error.
1	icache_tlbus	RW	0x0	PLIC interrupt enable mask for ICache Tilelink bus error.
0	rsvd0	RW	0x0	Reserved

2.1.6.3.11.2.4.5. ACCRUED_ENABLE

Table 919. bus_error_unit.ACCRUED_ENABLE fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7	dcache_uncorrectable	RW	0x0	Sticky accrued status for DCache ECC uncorrectable bus error.
6	dcache_correctable	RW	0x0	Sticky accrued status for DCache ECC correctable bus error.
5	dcache_tlbus	RW	0x0	Sticky accrued status for DCache Tilelink bus error.
4	rsvd4	RW	0x0	Reserved
3	rsvd3	RW	0x0	Reserved
2	icache_correctable	RW	0x0	Sticky accrued status for ICache ECC correctable bus error.
1	icache_tlbus	RW	0x0	Sticky accrued status for ICache Tilelink bus error.
0	rsvd0	RW	0x0	Reserved

2.1.6.3.11.2.4.6. LOCAL_ENABLE

Table 920. bus_error_unit.LOCAL_ENABLE fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7	dcache_uncorrectable	RW	0x0	Core local interrupt enable mask for DCache ECC uncorrectable bus error.
6	dcache_correctable	RW	0x0	Core local interrupt enable mask for DCache ECC correctable bus error.
5	dcache_tlbus	RW	0x0	Core local interrupt enable mask for DCache Tilelink bus error.
4	rsvd4	RW	0x0	Reserved
3	rsvd3	RW	0x0	Reserved
2	icache_correctable	RW	0x0	Core local interrupt enable mask for ICache ECC correctable bus error.
1	icache_tlbus	RW	0x0	Core local interrupt enable mask for ICache Tilelink bus error.
0	rsvd0	RW	0x0	Reserved

2.1.6.4. Boot ROM

The SMC maps a 128 KiB read-only region at `0xC004_0000` through `0xC005_FFFF`. The cold-reset CPU vector is `0xC004_0000`.

2.1.6.4.1. ROM Architecture

In the current four-core implementation, the CPU reaches the ROM over its internal TileLink memory path. `smc_cpu_wrapper` converts that path to the macro-facing `smc_rom_intf_req_o` and `smc_rom_intf_rsp_i` interface. Requests carry a clock, enable, and 14-bit 64-bit-word address; the write controls are tied to read mode. Responses return one 64-bit word. The ROM macro boundary is not an AXI-Lite interface and is separate from the CPU MMIO AXI and SMC peripheral AXI-Lite paths.

2.1.6.4.2. Hardware Configuration and Integrity

`OCAH4CORECluster_mems` passes the 11-bit `rom_cfg_i` value unchanged to the ROM wrapper's `mem_cfg_i`, where it is cast to `prim_rom_pkg::rom_cfg_t` and forwarded to `prim_rom`. The OCAH logic assigns no repair or technology-specific meaning to those bits. The reference `smc_ip_integration.sv` ties the value to zero.

On the response path, asserted `rom_flip_endianness_i` reverses the order of the eight bytes in each 64-bit ROM word; deasserted passes the word through unchanged. In `smc.sv`, this control comes from the ROM endianness bit in the eFuse shadow-register output.

2.1.6.4.3. Boot Flow

The production ROM initializes SRAM and the C runtime, then services OCCP requests over target-mode I2C and I3C. The SMC Boot ROM appendix of the Programmer's Guide describes the startup checks, lifecycle policy and boot-handoff commands.

The production ROM image fills the 128 KiB hardware region; its writable data runs from SRAM at `0xC006_0000`. The SMC CPU bring-up section of the Programmer's Guide gives the linker layout and the initialization it requires.

2.1.6.4.4. Firmware Reference

The production ROM firmware is documented in the SMC Boot ROM appendix of the Programmer's Guide.

2.1.6.5. Interconnect

The SMC fabric provides interconnect infrastructure with address management, traffic filtering, and security enforcement mechanisms.

2.1.6.5.1. Topology

2.1.6.5.1.1. Fabric Topology

The input fabric merges the SMC's own initiators, filters the system AXI input and splits traffic between the SMC window and the rest of the system. The local fabric connects the traffic for the SMC window to the CPU front port and the SMC register islands, and the output fabric remaps and filters the traffic that leaves the SMC.

The input paths are shown in Figure 58, the local resource connections in Figure 59, and the outbound path in Figure 60. The three figures share the notation of the SEP fabric figures. Crossbars are rectangles, muxes and demuxes are trapezoids with the wide side towards the many ports, address remaps and rebases are hexagons and traffic filters are octagons. Green boxes are converters: address-width, data-width, ID-width and protocol conversion. Thick lines are

AXI4 and thin lines AXI-Lite; every AXI data path is 64 bits wide unless a converter narrows it. The labels give the address and ID widths where they change, and the port badges mark where a path crosses the module boundary.




Figure 58. SMC input fabric topology and routing

Figure 58 has the six inputs of `smc_input_fabric` along the top and its four outputs along the bottom. The CPU MMIO and JTAG ports have their IDs widened to 4 bits and the log engine's AXI-Lite port is converted to AXI4. Each of the four SMC-internal initiators then passes its own alias remap; the four remaps share one table of eight regions with a 4 KiB granule. The input mux merges them, widens the ID to 6 bits and registers every channel. The demux behind it sends addresses inside the SMC window, at either the local or the global base and `REGION_SIZE` long, to the `local_in` initiator of the local fabric with the address truncated to 32 bits, and every other address to the output fabric. The system AXI input passes the inbound traffic filter, whose clock can be gated while the port is idle. The system and SEP inputs then each pass a region demux: the SMC window continues to the local fabric, truncated to 32 bits, and every other address receives DECERR. The SEP input is not filtered.




Figure 59. SMC local fabric and peripheral islands

Figure 59 shows `smc_local_fabric` in the upper left, the `smc_internal_regs` island on the right and the `smc_peripherals` island along the bottom. The three initiators arrive from the input fabric. Each is rebased onto the local base: the offset within `REGION_SIZE` is kept and the upper address bits are replaced by those of `LOCAL_BASE`, so a request for the global window reaches the same register as one for the local window. The local crossbar `u_smc_local_xbar` connects every initiator to every target, widens the ID to 8 bits, registers every port and answers unmapped addresses with DECERR, as do the internal CSR and peripheral crossbars. Its targets, in port order, are the CPU cluster front port, the data accelerator control port, the internal CSR crossbar, the peripheral crossbar and the CLA register window of the DFD block, which is reached over APB. The converters in front of the last three belong to `smc_local_xbar`. In the peripheral island, the AVSBus, I2C, UART and I3C register ports cross to the peripheral clock, the DTP CSR window is rebased to zero, and the eFuse registers have a second AXI-Lite port for JTAG access. The last peripheral crossbar target leaves the SMC as the AXI-Lite extension port.




Figure 60. SMC output fabric and remapping paths

Figure 60 follows a request from the input fabric to the system AXI output. The route demux selects by address. The 8 MiB M-mode window at `0x0100_0000` and the 8 MiB Xvisor window at `0x0180_0000`, each above either the local or the global SMC base, go through their output remaps; every other address goes straight through. Each output remap divides its window into eight 1 MiB regions and replaces address bits [55:20] with the region's offset. Each path also sets the AxUSER source ID (Table 928). The output mux merges the three paths and widens the ID to 8 bits. The dashed outline marks the stage that the `NO_ADDR_REMAP` parameter removes: `smc_config_pkg` clears it, so the remap stage is present, and setting it leaves only an ID converter from 6 to 8 bits, without the source ID override. The outbound traffic filter passes traffic that matches no entry.

2.1.6.5.1.2. Configuration Parameters

The fabric modules take parameters for the number of inbound and outbound filter entries, filter pipelining, the outstanding-transaction limit of the output fabric remap path, alias address remap enablement, and the M-mode and Xvisor remap region bases.

The parameters of `smc_fabric` are listed in the HTML edition of this manual, under RTL Modules Reference.

The parameters of `smc_output_fabric` are listed in the HTML edition of this manual, under RTL Modules Reference.

Further outstanding-transaction limits are fixed by package constants rather than module parameters (Table 921).

Table 921. SMC Fabric Transaction Limits

Constant	Value	Description
AXI4 Network		
`smc_pkg::FabricMaxTrans`	32	Maximum outstanding transactions per AXI ID bucket in the fabric demultiplexers and traffic filters
`smc_pkg::ErrSlvMaxTrans`	32	Maximum outstanding transactions for each error subordinate, across all IDs
`smc_local_xbar_pkg::XbarCfg.MaxMstTrans`	8	Maximum outstanding transactions each manager connected to the local AXI4 crossbar `u_smc_local_xbar` can have in flight
`smc_local_xbar_pkg::XbarCfg.MaxSlvTrans`	8	Maximum outstanding transactions each subordinate connected to the local AXI4 crossbar `u_smc_local_xbar` can have in flight
AXI4-Lite Network		
`smc_internal_axi_lite_xbar_pkg::XbarCfg.MaxMstTrans`	4	Maximum outstanding transactions each manager connected to the local fabric AXI4-Lite crossbar can have in flight
`smc_internal_axi_lite_xbar_pkg::XbarCfg.MaxSlvTrans`	4	Maximum outstanding transactions each subordinate connected to the local fabric AXI4-Lite crossbar can have in flight

These limits set the buffering depth of the fabric. The AXI4 limits bound the outstanding high-performance traffic, while the AXI4-Lite limits bound outstanding transactions to peripherals and configuration registers.

2.1.6.5.1.3. Dual-Network Architecture

The SMC fabric implements two separate networks optimized for different traffic types (Table 922).

Table 922. SMC Network Characteristics

Network	Connected Components	Protocol	Optimization Target
High-Performance	CPU cluster, SRAM, DMA, filtering, external AXI ports	AXI4	Bandwidth, low latency
Low-Performance	Peripherals, sensors, configuration registers	AXI4-Lite	Reliability, deterministic access

Both networks use 64-bit data bus width for consistent data handling. The CPU cluster connects to the fabric through AXI4 (high-bandwidth data path) and AXI4-Lite (MMIO) interfaces; internally, the cluster uses a TileLink bus that is protocol-bridged at the cluster boundary.

2.1.6.5.2. Interfaces

2.1.6.5.2.1. AXI Interface Widths

Table 923 lists the common AXI signal widths shared across all AXI4 fabric interfaces.

Table 923. AXI Common Signal Widths

Signal	Width (bits)	Description
DATA_WIDTH	64	Data bus width for all AXI4 interfaces
STRB_WIDTH	8	Write strobe width (DATA_WIDTH / 8)
ADDR_WIDTH (system)	56	Address width on system-facing external ports
ADDR_WIDTH (local)	32	Address width on SMC-internal interfaces
USER_WIDTH	12	User sideband width for all AXI4 channels

The AXI transaction ID width varies at each fabric stage because crossbars and multiplexers prepend additional bits to distinguish the originating port. Table 924 lists the ID width at each point in the fabric.

Table 924. AXI ID Widths by Fabric Stage

Fabric Stage / Port	ID Width (bits)	Direction
System AXI input (sys_axi_in)	6	Inbound
JTAG AXI input (jtag_axi_in)	2	Inbound
SEP AXI input (sep_axi_in)	6	Inbound
Input fabric (slave side)	4	Internal
Local / Output fabric (slave side)	6	Internal
Local fabric crossbar (master side)	8	Internal
Output fabric (master side)	8	Outbound
System AXI output (output_axi)	8	Outbound

Some internal paths also use a 32-bit data width for AXI4-Lite peripheral access, with corresponding STRB_WIDTH of 4 bits.

2.1.6.5.2.2. Traffic Managers and Subordinates

The SMC fabric supports multiple traffic sources (managers) and destinations (subordinates), providing flexible routing with security enforcement.

2.1.6.5.2.2.1. Traffic Managers

Traffic managers initiate transactions on the fabric, accessing both local and remote resources through the dual-network architecture.

Table 925 identifies the transaction initiators and their primary paths.

Table 925. SMC Fabric Traffic Managers

Manager	Count	Primary Paths	Key Features
CPU Cluster	1	Local (SRAM, PLIC, CLINT, WDT), External (filtered/remapped)	Dual routing paths, privilege-based control, L2 coherent access
DMA Controller	1	Alias remap → filtering → destination	High-bandwidth data movement, security enforcement
JTAG2AXI Bridge	1	Alias remap → filtering → destination	Debug and test access, privilege control
Log Engine	1	Alias remap → filtering → destination	System logging, telemetry collection

The CPU cluster provides multiple interface types: the local path optimized for minimal latency to local resources, the external path with filtering and remapping for system-wide access, the MMIO interface for register access with privilege-based control, and the L2 coherent path for cache-coherent high-bandwidth operations.

Traffic from DMA, Log Engine, JTAG2AXI, and CPU external path passes through alias remap logic before reaching their destination, enabling flexible address management between local and global address spaces.

2.1.6.5.2.2.2. Traffic Subordinates

Traffic subordinates respond to transactions initiated by the managers, organized by network type and function.

Table 926 identifies the transaction targets and their network connections.

Table 926. SMC Fabric Traffic Subordinates

Subordinate	Count	Network	Function
SRAM	1	AXI4 (High-Performance)	Local instruction and data memory
PLIC	1	AXI4 (High-Performance)	Platform-level interrupt controller
CLINT	1	AXI4 (High-Performance)	Core-local interrupt controller, timer
Watchdog Timer	1	AXI4 (High-Performance)	System integrity monitoring
Local Peripherals	Multiple	AXI4-Lite (Low-Performance)	SMC peripheral blocks (UART, I2C, GPIO, etc.)
Configuration Registers	Multiple	AXI4-Lite (Low-Performance)	Fabric control, filtering, remapping
External AXI Input Ports	3	AXI4 (High-Performance)	System NoC (sys_axi_in), JTAG debug (jtag_axi_in), SEP (sep_axi_in)
External AXI Output Port	1	AXI4 (High-Performance)	System NoC interface (output_axi)
Error Slave	1	Both networks	Invalid address response generation

The subordinates are distributed across both networks based on their performance requirements and access patterns. High-performance subordinates (SRAM, PLIC, CLINT, WDT, external ports) connect to the AXI4 network for maximum bandwidth and minimal latency, while low-performance subordinates (peripherals, configuration registers) use the AXI4-Lite network for reliable, deterministic access.

2.1.6.5.3. Address Remapping

The SMC fabric implements two complementary address remapping mechanisms: alias remapping in the input fabric and privilege-controlled remapping in the output fabric.

2.1.6.5.3.1. Alias Remapping

Alias remapping translates local SMC addresses to global system addresses, decoupling software-visible addresses from physical assignments. This simplifies integration and software portability, letting local agents access resources consistently across different SoC mappings.

The alias remap logic organizes eight independently configurable regions, each specifying an input address range, a remap offset for translation, and an AxCACHE value that replaces the transaction's own on a hit. This enables:

- Translation between local alias addresses (0xC000_0000 at reset) and global addresses, ensuring compatibility with both internal and external software
- Support for multiple software images by allowing address regions to be reassigned for different execution instances
- Setting cacheable attributes on locally initiated transactions for optimal performance

At reset, remap logic defaults to transparent mapping (no remap), using the local alias base address (0xC000_0000) for local resources until programmed. The Programmer's Guide gives the aperture programming sequence.

2.1.6.5.3.2. Privilege-Controlled Remapping

Privilege-controlled address remapping enables programmable translation of outbound SMC transactions for software running at different privilege levels. The output fabric selects a remap by the address window a request targets, not by the initiator's AxPROT privilege bit, and each remap sets its own source ID.

The fabric provides separate remap regions for Machine-mode (highest privilege) and Xvisor/Hypervisor (intermediate privilege) operations. When accessing shared resources like shared memory, SMC traffic passes through the appropriate privilege-controlled remap stage to ensure proper address translation and privilege enforcement.

2.1.6.5.4. Filtering and Protection

The filtering system (`filter_ctrl.rdl`) provides security control for both inbound and outbound traffic, examining transaction attributes to enforce access policies.

The SMC inbound and outbound filters are instances of the same `axi_filter_wrap` block used by SEP, and share its decode algorithm: entry priority, the match conditions, the address range granule and its widening direction, and the response returned to a blocked initiator. That algorithm is documented once with the IP.

See AXI Traffic Filter.

Both SMC filters have 16 entries, carry 56-bit addresses on a 64-bit data bus, and enable NS and source ID matching. They differ in how they treat traffic that matches no entry: the inbound filter blocks it, and the outbound filter permits it.

2.1.6.5.4.1. Inbound Filtering

Figure 61 shows the decode that both filters implement. Their places in the fabric are in Figure 58 and Figure 60.




Figure 61. SMC inbound and outbound traffic-filter mechanism

The figure draws primitive logic with gate symbols and keeps labelled boxes for comparisons and larger blocks. The upper part of Figure 61 is one `traffic_filter`, instantiated for every entry on each of the AW and AR channels. The entry hits when all five conditions on the left hold, which the AND gate with the extended input bar combines; the source ID and burst conditions are each an OR of two terms. Its permission bit, ANDed with the channel's valid, is evaluated separately. The lower part is one channel of `axi_filter_wrap`. A priority encoder picks the lowest-numbered entry that hits, a 16:1 mux selects that entry's permission bit, and the inverted bit requests a block. When no entry hits, the next mux takes `BLOCK_BY_DEFAULT` instead. The last mux forces the block bit to 0 when `filter_skip_i` is set; `filter_skip_i` is tied low in both SMC instances. Group ID matching is not built into either instance. The block bit steers the transaction through a demux either to the filtered output or to an error responder that returns DECERR.

Inbound filtering protects SMC resources from unauthorized external access by evaluating three dimensions of each transaction:

- **Address-based control**: Defines precise access zones, protecting memory-mapped registers and internal memory from unauthorized external requests
- **Source ID authorization**: Permits or blocks accesses based on the originating system component's identity, ensuring only trusted sources access sensitive resources
- **Protection attribute filtering**: Examines AXI protection signals (security and privilege attributes) to differentiate between secure vs. non-secure or privileged vs. user transactions

The default filter configuration varies by chiplet type. Most SMC instances default to blocking all external transactions until access policies are configured. The Programmer's Guide gives the filter programming rules.

The inbound filter interface provides 16 independent filter instances, each configurable with its own address ranges, source ID matching, and protection attribute policies.

2.1.6.5.4.2. Outbound Filtering

The outbound filter uses explicit matching entries to allow or block SMC-initiated requests. Unmatched requests pass because this instance uses `BLOCK_BY_DEFAULT = 0`. An allow entry is therefore not an allowlist: denying traffic requires a matching entry whose read or write permission is clear.

Address, source ID, and NS matching select an entry. The filter does not infer software privilege or grant broader access to a higher privilege mode.

All outbound traffic, after passing through any privilege remap stages, is subject to outbound filtering enforcement based on address, security attributes (NS), and source ID. The outbound filters use the same register structure as inbound filters.

2.1.6.5.4.3. Protection Requirements

The SMC fabric implements two types of protection-based filtering mechanisms to enforce security policies based on AXI protection attributes:

2.1.6.5.4.3.1. AXI Protection Bit Encoding

AXI protection bits (`aw.prot` and `ar.prot`) are 3-bit fields that encode transaction security and privilege attributes (Table 927).

Table 927. SMC AXI Protection Bit Encoding

Bit [2]	Bit [1]	Bit [0]	Value	Description
0	0	0	0x0	Data, Secure, User
0	0	1	0x1	Data, Secure, Privileged
0	1	0	0x2	Data, Non-Secure, User
0	1	1	0x3	Data, Non-Secure, Privileged
1	0	0	0x4	Instruction, Secure, User
1	0	1	0x5	Instruction, Secure, Privileged
1	1	0	0x6	Instruction, Non-Secure, User
1	1	1	0x7	Instruction, Non-Secure, Privileged

2.1.6.5.4.3.2. Non-Secure Bit Filtering (AXI4 Filters)

The primary protection filtering mechanism for AXI4 full interfaces examines the Non-Secure (NS) bit (`prot[1]`) to control secure vs. non-secure access. This filtering is implemented in both inbound and outbound traffic filters.

Each filter entry in the 16 inbound and 16 outbound filter instances includes an `allow_ns` configuration field. It is an equality test against the transaction's NS bit, not a permission grant, so an entry covers one security state only:

- When `allow_ns = 0`: the entry matches secure transactions (`prot[1] = 0`) only
- When `allow_ns = 1`: the entry matches non-secure transactions (`prot[1] = 1`) only

Covering both security states over one address range therefore takes two entries. An entry whose `allow_ns` does not match the transaction does not deny it; the transaction falls through to the remaining entries, as described in the AXI Traffic Filter decode section referenced above.

This filtering occurs in `axi_filter_wrap`, where each transaction's `aw.prot[1]` (write) or `ar.prot[1]` (read) is compared against the filter's `allow_ns` configuration. A matching deny entry routes the transaction to an error slave, which returns a decode error. With no matching entry, the inbound instance blocks the transaction and the outbound instance passes it.

2.1.6.5.4.3.3. Full 3-Bit Protection Matching (AXI-Lite)

The fabric filters examine only the NS bit. Exact matching on all three protection bits is performed by an AXI-Lite peripheral that provides its own `ACCESS_FILTER` register, after the fabric has routed the transaction to it. In the SMC, the GPIO interface bank performs this check; see GPIO. Adopter blocks in the external window that carry an `ACCESS_FILTER` register define the same fields.

The full protection matching requires an exact match between the transaction's protection bits and a configured requirement:

- `awprot_requirement[2:0]`: Required protection value for write transactions
- `arprot_requirement[2:0]`: Required protection value for read transactions
- `write_filter_enable`: Enable write protection filtering
- `read_filter_enable`: Enable read protection filtering

When filtering is enabled, only transactions with matching protection values are allowed through. All other transactions receive an error response. The protection bits are transaction attributes, not an initiator identity, so this check alone does not restrict a block to one initiator.

2.1.6.5.4.3.4. Protection Bit Pass-Through

All protection bits are passed through the fabric without modification. The filters only block or allow transactions based on their protection attributes; they do not alter the protection bits themselves. This ensures that downstream slaves receive the original protection attributes from the originating master.

2.1.6.5.4.3.5. Configuration Examples

The Programmer's Guide gives filter configuration examples, including secure-only and AXI-Lite PROT policies.

2.1.6.5.5. Routing

2.1.6.5.5.1. Local and Remote Resource Access

The SMC fabric routing logic determines how transactions reach their intended destinations, supporting both local SMC resources and remote system components. Local resources can be addressed using either their global address or a local alias address.

The `GLOBAL_BASE`, `LOCAL_BASE`, and `REGION_SIZE` CSRs describe the SMC aperture. `REGION_SIZE` resets to `0x0100_0000` (16 MiB), and firmware may reprogram it during early boot to match the chiplet address assignment.

The SMC input fabric's local/global split is sized by the same `REGION_SIZE` CSR used by SMU-level routing and SEP-to-SMC decode, so the internal local-alias window and the chiplet-facing global aperture stay the same size by construction. A `REGION_SIZE` of zero collapses both windows and routes SMC CPU accesses to its own resources out through the output fabric.

After global-aperture reconfiguration, software may use global addresses for accesses that leave the local SMC view. Global address derivation requires the chiplet-global aperture base, which firmware reads from the `GLOBAL_BASE` CSR described above.

2.1.6.5.5.2. Outbound Traffic Flow

SMC outbound traffic serves dual purposes: accessing shared system services and extending the SMC's private domain across the system.

For shared resources (e.g., shared memory), traffic passes through privilege-controlled remap logic—Xvisor-controlled for hypervisor-managed resources or M-mode-controlled for machine-mode resources. For private memory or memory-mapped I/O resources, traffic bypasses remap stages and goes directly to the system NoC, reducing latency.

Each outbound transaction carries a Source ID identifying its privilege level and routing path (Table 928). A transaction that hits an alias remap region carries that region's AxCACHE value; any other keeps the AxCACHE its initiator issued.

Table 928. SMC Source ID by Traffic Path

Traffic Path	Source ID
Direct to NoC	SMC_ID
Through Xvisor remap	OTHER_ID
Through M-mode remap	MMODE_ID

2.1.6.5.6. Memory Map and Register Reference

2.1.6.5.6.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.6.5.6.2. Detailed Register Map

2.1.6.5.6.2.1. Alias Remap Registers

The alias remap registers control local address aliasing and attribute mapping for SMC-initiated transactions. These registers configure how local resources are accessed and which address translation is applied.

2.1.6.5.6.2.1.1. AXI Alias Remap Address Map

TLB Registers for address remapping and attribute tagging

Table 929. AXI Alias Remap Address Map register list

Address	Name	Access	Description
0x0	region_start	RW	-
0x8	region_end	RW	-
0x10	region_attrs	RW	-

####### 2.1.6.5.6.2.1.1.1. region_start

Table 930. alias_remap.region_start fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:12	start_addr	RW	0x0	Start of remap region
11:0	Reserved	-	-	Reserved

####### 2.1.6.5.6.2.1.1.2. region_end

Table 931. alias_remap.region_end fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:12	end_addr	RW	0x0	End of remap region (non-inclusive).
11:0	Reserved	-	-	Reserved

####### 2.1.6.5.6.2.1.1.3. region_attrs

Table 932. alias_remap.region_attrs fields

Bits	Field	Access	Reset	Description
63	valid	RW	0x0	If set, this remap will be active
62:60	Reserved	-	-	Reserved
59:56	cacheable	RW	0x0	Set to change the value of the axcache field of the transaction. This field will override all existing axcache bits.

Bits	Field	Access	Reset	Description
55:12	offset	RW	0x0	The value of this field is added to bits [55:12] of the input address when it falls within the remap region. The lower 12 bits of the address are preserved unchanged.
11:0	Reserved	-	-	Reserved

2.1.6.5.6.2.2. Output Remap Registers

The output remap registers control privilege-controlled address remapping for outbound transactions. The fabric provides separate remap regions for Machine-mode (highest privilege) and Xvisor/Hypervisor (intermediate privilege) operations. Each region carries a REGION_ATTRS.valid bit (reset 0): when set, accesses selecting the region are remapped through its offset; when clear, they pass through with their address unchanged, so an unprogrammed entry acts as an identity mapping rather than forcing every access to offset 0.

2.1.6.5.6.2.2.1. Output Remap Address Map

Address-translation registers that remap outbound transactions and tag their attributes.

Table 933. Output Remap Address Map register list

Address	Name	Access	Description
0x0	region_attrs	RW	-

2.1.6.5.6.2.2.1.1. region_attrs

Table 934. output_remap.region_attrs fields

Bits	Field	Access	Reset	Description
63	valid	RW	0x0	If set, accesses to this region are remapped by offset; if clear, they pass through with their address unchanged
62:56	Reserved	-	-	Reserved
55:0	offset	RW	0x0	Address translation for remap region. RTL will use the number of bits appropriate for region granulaity. e.g. SMC: 8 * 1MB regions -→ 20 bits of address space per region, 36 MSBs from this register used SEP: 16 * 512KB regions -→ 19 bits of address space per region, 37 MSBs from this register used

2.1.6.5.6.2.3. Inbound Traffic Filter Control Registers

The inbound filter control registers protect SMC resources from unauthorized external access. Each of the 16 independent filter instances can be configured with address ranges, source ID matching, and protection attribute policies to control inbound traffic.

2.1.6.5.6.2.3.1. AXI Filter Control Address Map

Per-filter access-control registers defining permitted address ranges and transaction attributes.

Table 935. AXI Filter Control Address Map register list

Address	Name	Access	Description
0x0	FILTER_CONFIG	RW	-
0x8	START_ADDR	RW	-
0x10	END_ADDR	RW	-

2.1.6.5.6.2.3.1.1. FILTER_CONFIG

Table 936. filter_ctrl.FILTER_CONFIG fields

Bits	Field	Access	Reset	Description
63	locked	RW1S	0x0	Lock filter configurations. Write once register. Once set, this bit cannot be cleared, and every subsequent write to this filter entry's FILTER_CONFIG, START_ADDR and END_ADDR registers is steered to the AXI error subordinate and terminates with a DECERR response; reads still return the locked configuration.
62:25	Reserved	-	-	Reserved
24	allow_burst	RW	0x0	Filter entry will match if this field is 1 or if this field is 0 and the burst len AxLEN is 0. This field also selects the granule of the address range: 4KB when it is 1, 2^data_bus_width bytes when it is 0. See start_addr and end_addr for how the range is widened to that granule.
23:20	group_id	RW	0x0	Group ID field to match. Filter entry will match if the transactions group_id matches the value in this field. Note the corner case is the opposite of src_id: the bypass keys off the transaction, not this field. A transaction whose group_id is 0 matches regardless of this field, and a value of 0 here is not a wildcard. Unused for SEP/SMC, where group_id filtering is disabled at build time and this field has no effect
19:16	src_id	RW	0x0	Source ID field to match. Filter entry will match if the transactions src_id matches the value in this field. A value of 0 in this field is a wildcard: src_id matching is bypassed and the entry matches any src_id. Consequently there is no way to match only transactions whose src_id is 0.
15	Reserved	-	-	Reserved
14:12	data_bus_width	R	0x3	Data bus width in bytes, encoded as 2^value
11:9	Reserved	-	-	Reserved
8	allow_ns	RW	0x0	Secure and Non-secure is categorized as AxPROT[1] in the AXI protocol, where AxPROT[1] == 0 means secure and AxPROT[1] == 1 means Non-secure. Filter entry will match if AxPROT[1] matches the value in this field
7:5	Reserved	-	-	Reserved
4	entry_enabled	RW	0x0	Filter entry enabled. A = 0 means this entry is disabled, A = 1 means this entry is enabled and will be used to filter
3:2	Reserved	-	-	Reserved
1	write_allowed	RW	0x0	Upon match of transaction to filter fields, whether the transaction has write permissions
0	read_allowed	RW	0x0	Upon match of transaction to filter fields, whether the transaction has read permissions

2.1.6.5.6.2.3.1.2. START_ADDR

Table 937. filter_ctrl.START_ADDR fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	start_addr	RW	0x0	Start of the allowable address range, rounded down to the base of its granule. The granule is 4KB when allow_burst is 1, and 2^data_bus_width bytes when allow_burst is 0. Address matching ignores the address bits below the granule, so the accepted range always spans whole granules and is never narrower than one: a range shorter than the granule, start_addr == end_addr included, still admits the whole granule, and two granules if it straddles a granule boundary. Hardware writes the rounded start_addr and end_addr back into these fields only when both land in the same granule; otherwise readback returns the programmed values even though matching is still granule-aligned.

2.1.6.5.6.2.3.1.3. END_ADDR

Table 938. filter_ctrl.END_ADDR fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	end_addr	RW	0x7	End of the allowable address range, rounded up to the top of its granule. The granule and the write-back behaviour are described under start_addr. Defaults to 7 on reset to match the 8B granule that applies while bursts are disabled.

2.1.6.5.6.2.4. Outbound Traffic Filter Control Registers

The outbound filter control registers determine which external resources the SMC can access, restricting SMC-initiated requests to defined system peripherals or memory regions. These registers are implemented as 16 independent outbound filter instances, each structured as a 32-byte control block and accessible via an AXI4-Lite interface. The outbound filters use the same register structure as the inbound filters (documented above).

2.1.6.6. Interrupts

SMC external interrupts pass through the Platform-Level Interrupt Controller (PLIC). CLINT supplies per-core timer and software interrupts. Each bus error unit (BEU) has both a direct core output and a separately selected PLIC output. This chapter distinguishes raw SMC vector bits from software-visible PLIC IDs.

2.1.6.6.1. Controllers

2.1.6.6.1.1. Controller Addresses

These addresses use the SMC-local view. N ranges from 0 through 3 for the per-core watchdog and BEU apertures.

Table 939. SMC interrupt-controller addresses

Block	Base Addr	Size	Interface
CPU Control Regs	0xC003_9000	4 KB	AXI4-Lite
PLIC	0xC400_0000	64 MB	TileLink (cluster control bus)
CLINT	0xC800_0000	64 KB	TileLink (cluster control bus)
Watchdog Timers (N)	0xC000_0000 + (N * 0x400)	1 KB x4	TileLink (cluster peripheral bus)
Bus Error Units (N)	0xC801_0000 + (N * 0x1000)	4 KB x4	TileLink (cluster control bus)

2.1.6.6.1.2. PLIC Sources and Contexts

The four-core implementation has 336 PLIC inputs with source IDs 1–336. ID 0 means no interrupt. The inputs comprise:

Table 940. PLIC input groups

Input group	PLIC IDs	Origin
Raw SMC vector bits 0–327	1–328	cpu_interrupts_o; detailed below.
Cluster watchdogs 0–3	329–332	Added by the cluster interrupt crossbar.
Core BEU PLIC outputs 0–3	333–336	Added within the PLIC clock domain.

Reserved raw-vector positions remain reserved PLIC IDs. The 256 external input meanings come from the enclosing SoC integration; an input count is not a promise that every position is an active source.

There are eight delivery contexts: machine contexts for cores 0–3, then supervisor contexts for cores 0–3. Priorities are shared per source; enable masks, thresholds and claim/complete registers are per context. A priority must exceed the context threshold to raise its external-interrupt output. Priority zero suppresses a source. See the generated map for context offsets and priority range. These settings route interrupts; they do not themselves enforce MMIO access policy.

The gateways are active-high and level-sensitive, with no selectable edge mode. External SMC pins pass through `prim_sync3` before the raw vector. A short pulse can be missed if it is not sampled; stretch it or hold the request until serviced. A gateway admits one request and waits for completion before accepting another. It does not count repeated pulses while one request is in flight.

2.1.6.6.1.3. CLINT

CLINT provides a shared 64-bit timer, per-core compare registers and per-core software-interrupt state. Timer and software interrupts go directly to the cores rather than through PLIC claim/complete. The timer advances on the cluster's periodic tick; see the Clocks and Resets chapter for its clock relationship.

2.1.6.6.1.4. Bus Error Units

A Bus Error Unit (BEU) accumulates error events for one core. The register named `ACCRUED_ENABLE` is sticky status, not an enable mask: events set its bits independently of `ENABLE`. Ordinary writes replace those bits; write zero to clear them. `ENABLE` instead gates capture of the first error's `CAUSE` and `PHYS_ADDR` while `CAUSE` is zero. Software can also write `PHYS_ADDR`.

`LOCAL_ENABLE` selects accrued errors for direct delivery to the core, bypassing the PLIC and the ordinary per-source `mie` bits. This is not an unconditionally non-maskable interrupt: in machine mode, `mstatus.MIE = 0` suppresses delivery. The machine interrupt is enabled while executing in lower privilege modes. The BEU also has a separate output selected by `PLIC_ENABLE`. The Bus Error Unit service sequence is in the Programmer's Guide.

2.1.6.6.2. Sources and Routing

2.1.6.6.2.1. Raw Vector and PLIC Numbering

Raw bit N maps to PLIC source ID N+1. For example, DMA completion is raw bit 322 and PLIC ID 323. Watchdog IDs 329–332 and BEU IDs 333–336 are not additional bits on the 328-bit raw SMC vector.

2.1.6.6.2.2. SMC CPU Interrupt Vector Map

This section documents the raw `cpu_interrupts_o` vector assembled in `hw/sys/smc/rtl/smc_base.sv`. The vector is built from four sources:

- `smc_ext_interrupts_i`
- `peripheral_interrupts_i[31:0]`
- `mailbox_interrupts[31:0]`
- four internal interrupt signals

Unless otherwise noted, the bit numbers below are raw `cpu_interrupts_o` bit indices, not PLIC source IDs. When these signals feed the PLIC, the PLIC source ID is `cpu_interrupts_o` bit index + 1.

The vector layout is:

```
cpu_interrupts_o[NumExtInterrupts-1:0]        = ext_interrupts_smc_clk; //
smc_ext_interrupts_i after 3-stage sync to clk_smc
cpu_interrupts_o[NumExtInterrupts+:32]        = peripheral_interrupts_i;
cpu_interrupts_o[(NumExtInterrupts+32)+:32]   = mailbox_interrupts;
cpu_interrupts_o[(NumExtInterrupts+64)]       = tdr_dbg_ctrl_clocks_stopped_by_cla_o;
cpu_interrupts_o[(NumExtInterrupts+64)+1]     = cla_interrupt;
cpu_interrupts_o[(NumExtInterrupts+64)+2]     = dma_intp;
cpu_interrupts_o[(NumExtInterrupts+64)+3]     = zeroer_intp;
```

`NumExtInterrupts = 256` and `NumCpuInterrupts = 328`.

2.1.6.6.2.2.1. Exact Indexed Map

Table 941 shows the exact raw `cpu_interrupts_o` indexing. The `Source` column is intentionally human-readable; implementation signal names are called out in the `RTL trace` column instead.

Table 941. SMC indexed interrupt map

Bit(s)	Source	Description	RTL trace
`[255:0]`	External interrupts	Integration-defined external interrupt inputs	`hw/sys/smc/rtl/smc_base.sv` synchronizes `ext_interrupts_i` to `clk_smc` (`prim_sync3 u_ext_interrupts_sync3`; wired from `smc.sv smc_ext_interrupts_i`) and drives `cpu_interrupts_o[NumExtInterrupts-1:0] = ext_interrupts_smc_clk`.
`256`	SEP mailbox interrupt 0	SEP-to-SMC mailbox channel 0 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[0] = sep_mailbox_interrupts_i[0]`.
`257`	SEP mailbox interrupt 1	SEP-to-SMC mailbox channel 1 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[1] = sep_mailbox_interrupts_i[1]`.
`258`	SEP mailbox interrupt 2	SEP-to-SMC mailbox channel 2 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[2] = sep_mailbox_interrupts_i[2]`.
`259`	SEP mailbox interrupt 3	SEP-to-SMC mailbox channel 3 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[3] = sep_mailbox_interrupts_i[3]`.
`260`	SEP mailbox interrupt 4	SEP-to-SMC mailbox channel 4 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[4] = sep_mailbox_interrupts_i[4]`.
`261`	SEP mailbox interrupt 5	SEP-to-SMC mailbox channel 5 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[5] = sep_mailbox_interrupts_i[5]`.
`262`	SEP mailbox interrupt 6	SEP-to-SMC mailbox channel 6 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[6] = sep_mailbox_interrupts_i[6]`.
`263`	SEP mailbox interrupt 7	SEP-to-SMC mailbox channel 7 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[7] = sep_mailbox_interrupts_i[7]`.
`264`	Telemetry interrupt 0	Telemetry receiver instance 0 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[8] = telemetry_irq[0]`.
`265`	Telemetry interrupt 1	Telemetry receiver instance 1 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[9] = telemetry_irq[1]`.
`266`	Telemetry interrupt 2	Telemetry receiver instance 2 interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[10] = telemetry_irq[2]`.
`267`	NDM Reset Request	OR-reduced synchronized NDM reset request interrupt	`smc_peripherals.sv` drives `peripheral_interrupts_o[11] = |ndmreset_request_smc_clk`.

Bit(s)	Source	Description	RTL trace
268	I3C interrupt 0	I3C controller instance 0 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[12] = i3c_irqs_smc_clk[0]; sourced from the I3C wrapper through the peripheral CDC block.
269	I3C interrupt 1	I3C controller instance 1 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[13] = i3c_irqs_smc_clk[1]; sourced from the I3C wrapper through the peripheral CDC block.
270	I3C interrupt 2	I3C controller instance 2 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[14] = i3c_irqs_smc_clk[2]; sourced from the I3C wrapper through the peripheral CDC block.
271	I3C interrupt 3	I3C controller instance 3 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[15] = i3c_irqs_smc_clk[3]; sourced from the I3C wrapper through the peripheral CDC block.
272	I3C interrupt 4	I3C controller instance 4 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[16] = i3c_irqs_smc_clk[4]; sourced from the I3C wrapper through the peripheral CDC block.
273	I3C interrupt 5	I3C controller instance 5 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[17] = i3c_irqs_smc_clk[5]; sourced from the I3C wrapper through the peripheral CDC block.
274	UART/Log Engine interrupt 0	Combined UART IRQ, UART error, and log-engine interrupt for instance 0	smc_peripherals.sv drives peripheral_interrupts_o[18] = uart_irq_combined_smc_clk[0]; the combined signal is formed in smc_peripherals_cdc.sv.
275	UART/Log Engine interrupt 1	Combined UART IRQ, UART error, and log-engine interrupt for instance 1	smc_peripherals.sv drives peripheral_interrupts_o[19] = uart_irq_combined_smc_clk[1]; the combined signal is formed in smc_peripherals_cdc.sv.
276	UART/Log Engine interrupt 2	Combined UART IRQ, UART error, and log-engine interrupt for instance 2	smc_peripherals.sv drives peripheral_interrupts_o[20] = uart_irq_combined_smc_clk[2]; the combined signal is formed in smc_peripherals_cdc.sv.
277	UART/Log Engine interrupt 3	Combined UART IRQ, UART error, and log-engine interrupt for instance 3	smc_peripherals.sv drives peripheral_interrupts_o[21] = uart_irq_combined_smc_clk[3]; the combined signal is formed in smc_peripherals_cdc.sv.
278	AVSBus interrupt	Adaptive voltage scaling interrupt	smc_peripherals.sv drives peripheral_interrupts_o[22] = avsbus_irq_smc_clk.
279	I2C interrupt 0	I2C controller instance 0 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[23] = i2c_irqs_smc_clk[0].
280	I2C interrupt 1	I2C controller instance 1 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[24] = i2c_irqs_smc_clk[1].
281	I2C interrupt 2	I2C controller instance 2 interrupt	smc_peripherals.sv drives peripheral_interrupts_o[25] = i2c_irqs_smc_clk[2].
282	SEP watchdog reset	External watchdog reset indication from SEP path	smc_peripherals.sv synchronizes ~rst_ext_wdt_ni through u_rst_ext_wdt_irq_sync and drives peripheral_interrupts_o[26] = rst_ext_wdt_smc_clk.
283	Locked field access	eFuse locked-field access violation interrupt	smc_peripherals.sv drives peripheral_interrupts_o[27] = locked_field_access_interrupt, sourced from the eFuse controller path.
284	GPIO interrupt OR, lower half	OR-reduction across GPIO interrupt sources 0-31	smc_peripherals.sv drives peripheral_interrupts_o[28] = |gpio_interrupt[smc_pkg::NumGpioWraps/2-1:0].
285	GPIO interrupt OR, upper half	OR-reduction across GPIO interrupt sources 32-64	smc_peripherals.sv drives peripheral_interrupts_o[29] = |gpio_interrupt[smc_pkg::NumGpioWraps-1:smc_pkg::NumGpioWraps/2].

Bit(s)	Source	Description	RTL trace
286	AXI hang detector OR	OR of the three AXI hang detectors (sys_axi, sep_axi, data_accel). Asserts while any detector's irq_o is high, either from a timeout or from its irq_test bit, so software must read SMC_BASE_CONFIG.HANG_DET_{SYS_AXI,SEP_AXI,DATA_ACCEL}_CTRL.irq to identify the stalled master. There is no status latch to clear: a timeout drops when that master's bus makes progress, a test assertion drops when irq_test is cleared, and either drops when the detector's enable or irq_en is cleared. The CPU AXI master is not covered here; it is covered by the watchdog.	smc_base.sv OR-reduces hang_irq_sys_axi | hang_irq_sep_axi | hang_irq_data_accel onto axi_hang_irq_o; smc.sv routes that back into u_smc_peripherals, and smc_peripherals.sv drives peripheral_interrupts_o[30] = axi_hang_irq_i.
287	Reserved	Unused peripheral interrupt slots; tied to zero	peripheral_interrupts_o is initialized to '0, and bit 31 is never overwritten in smc_peripherals.sv.
[319:288]	SMC mailbox interrupts [31:0]	Inbound SMC mailbox interrupt channels 31:0	smc_base.sv drives cpu_interrupts_o[(NumExtInterrupts+32)+:32] = mailbox_interrupts; mailbox.sv drives inbound_interrupt_o[m] per mailbox channel.
320	CLA Clock Stop	DFD CLA clock-stop status interrupt	smc_base.sv drives this bit from tdr_dbg_ctrl_clocks_stopped_by_cla_o, sourced through u_smc_dfd_wrap in smc_internal_regs.sv.
321	CLA Interrupt	DFD CLA interrupt	smc_base.sv drives this bit from cla_interrupt, sourced from external_action_debug_interrupt_o on u_smc_dfd_wrap in smc_internal_regs.sv.
322	DMA transfer complete	Falling-edge pulse when DMA busy deasserts	smc_base.sv drives this bit from dma_intp; idma_wrapper.sv generates dma_intp_o as a falling-edge pulse of dma_busy_o.
323	Zeroer transfer complete	Falling-edge pulse when Zeroer busy deasserts	smc_base.sv drives this bit from zeroer_intp; zeroer.sv generates zeroer_intp_o on the falling edge of zeroer_busy_o.
[327:324]	Reserved	Unused tail bits; tied to zero	cpu_interrupts_o is initialized to '0, and no RTL overwrites these tail bits in smc_base.sv.

2.1.6.6.2.2.2. Routing Notes

smc_base.sv assembles the raw vector; smc_peripherals.sv assembles its 32-bit peripheral slice. The AXI hang-detector OR enters peripheral bit 30 (raw bit 286), while bit 31 is reserved. The table preserves the individual sources behind combined GPIO, UART/log-engine and hang-detector indications; software must inspect their local status to identify and service the cause.

The six I3C entries are connected through the peripheral CDC block. The AVSBus and external-watchdog indications are also synchronized into the SMC domain. Do not infer pulse-capture guarantees merely from the presence of a synchronizer. DMA and zeroer completion indications are busy-falling pulses, not counted queues.

2.1.6.6.3. Software Handling

The PLIC priority, enable and threshold registers are not reset by hardware. A source's priority is shared by every context that enables it. Completion releases the source's gateway, so a still-asserted source pends again; claim and complete do not clear a peripheral's own sticky status. CLINT timer and software interrupts do not use PLIC completion.

The Interrupt Control section of the Programmer's Guide gives the PLIC initialization and claim/complete sequence, CLINT timer and software interrupt service, and Bus Error Unit service. Watchdog recovery and CPU reset/isolation ordering are described in the Watchdog Timers and CPU chapters. For CPU cluster context, see [cpu-memory-system].

2.1.6.6.4. Memory Map and Register Reference

2.1.6.6.4.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.6.6.4.2. Detailed Register Map

2.1.6.6.4.2.1. PLIC Address Map

Platform-Level Interrupt Controller register interface.

NOTE

Register Arrays:

- **PRIORITY[337]**: 337 registers, base 0x0, stride 0x4
- **PENDING[11]**: 11 registers, base 0x1000, stride 0x4
- **CORE0_MEIP_ENABLE[11]**: 11 registers, base 0x2000, stride 0x4
- **CORE1_MEIP_ENABLE[11]**: 11 registers, base 0x2080, stride 0x4
- **CORE2_MEIP_ENABLE[11]**: 11 registers, base 0x2100, stride 0x4
- **CORE3_MEIP_ENABLE[11]**: 11 registers, base 0x2180, stride 0x4
- **CORE0_SEIP_ENABLE[11]**: 11 registers, base 0x2200, stride 0x4
- **CORE1_SEIP_ENABLE[11]**: 11 registers, base 0x2280, stride 0x4
- **CORE2_SEIP_ENABLE[11]**: 11 registers, base 0x2300, stride 0x4
- **CORE3_SEIP_ENABLE[11]**: 11 registers, base 0x2380, stride 0x4

Table 942. PLIC Address Map register list

Address	Name	Access	Description
0x0 - 0x540	PRIORITY[337]	RW	-
0x1000 - 0x1028	PENDING[11]	R	-
0x2000 - 0x2028	CORE0_MEIP_ENABLE[11]	RW	-
0x2080 - 0x20A8	CORE1_MEIP_ENABLE[11]	RW	-
0x2100 - 0x2128	CORE2_MEIP_ENABLE[11]	RW	-
0x2180 - 0x21A8	CORE3_MEIP_ENABLE[11]	RW	-
0x2200 - 0x2228	CORE0_SEIP_ENABLE[11]	RW	-
0x2280 - 0x22A8	CORE1_SEIP_ENABLE[11]	RW	-
0x2300 - 0x2328	CORE2_SEIP_ENABLE[11]	RW	-
0x2380 - 0x23A8	CORE3_SEIP_ENABLE[11]	RW	-

Address	Name	Access	Description
0x200000	CORE0_MEIP_THRESHOLD	RW	-
0x200004	CORE0_MEIP_CLAIM_COMPLETE	RW	-
0x201000	CORE1_MEIP_THRESHOLD	RW	-
0x201004	CORE1_MEIP_CLAIM_COMPLETE	RW	-
0x202000	CORE2_MEIP_THRESHOLD	RW	-
0x202004	CORE2_MEIP_CLAIM_COMPLETE	RW	-
0x203000	CORE3_MEIP_THRESHOLD	RW	-
0x203004	CORE3_MEIP_CLAIM_COMPLETE	RW	-
0x204000	CORE0_SEIP_THRESHOLD	RW	-
0x204004	CORE0_SEIP_CLAIM_COMPLETE	RW	-
0x205000	CORE1_SEIP_THRESHOLD	RW	-
0x205004	CORE1_SEIP_CLAIM_COMPLETE	RW	-
0x206000	CORE2_SEIP_THRESHOLD	RW	-
0x206004	CORE2_SEIP_CLAIM_COMPLETE	RW	-
0x207000	CORE3_SEIP_THRESHOLD	RW	-
0x207004	CORE3_SEIP_CLAIM_COMPLETE	RW	-

2.1.6.6.4.2.1.1. PRIORITY[337]

Table 943. plic.PRIORITY[337] fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Priority of interrupt. The higher the set value, the higher the priority. For interrupts with the same priority, the tie is broken by interrupt ID; interrupts with the lowest ID has highest effective priority. Interrupts start counting at 1.

2.1.6.6.4.2.1.2. PENDING[11]

Table 944. plic.PENDING[11] fields

Bits	Field	Access	Reset	Description
31:0	value	R	0x0	Set to 1 if interrupt source 1 is pending, regardless of its enable or priority setting. Interrupts start counting at 1.

2.1.6.6.4.2.1.3. CORE0_MEIP_ENABLE[11]

Table 945. plic.CORE0_MEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.4. CORE1_MEIP_ENABLE[11]

Table 946. plic.CORE1_MEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.5. CORE2_MEIP_ENABLE[11]

Table 947. plic.CORE2_MEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.6. CORE3_MEIP_ENABLE[11]

Table 948. plic.CORE3_MEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.7. CORE0_SEIP_ENABLE[11]

Table 949. plic.CORE0_SEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.8. CORE1_SEIP_ENABLE[11]

Table 950. plic.CORE1_SEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.9. CORE2_SEIP_ENABLE[11]

Table 951. plic.CORE2_SEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.10. CORE3_SEIP_ENABLE[11]

Table 952. plic.CORE3_SEIP_ENABLE[11] fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Set bits to 1 if interrupt should be enabled. Interrupts start counting at 1.

2.1.6.6.4.2.1.11. CORE0_MEIP_THRESHOLD

Table 953. plic.CORE0_MEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.12. CORE0_MEIP_CLAIM_COMPLETE

Table 954. plic.CORE0_MEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.13. CORE1_MEIP_THRESHOLD

Table 955. plic.CORE1_MEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.14. CORE1_MEIP_CLAIM_COMPLETE

Table 956. plic.CORE1_MEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.15. CORE2_MEIP_THRESHOLD

Table 957. plic.CORE2_MEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.16. CORE2_MEIP_CLAIM_COMPLETE

Table 958. plic.CORE2_MEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.17. CORE3_MEIP_THRESHOLD

Table 959. plic.CORE3_MEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.18. CORE3_MEIP_CLAIM_COMPLETE

Table 960. plic.CORE3_MEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.19. CORE0_SEIP_THRESHOLD

Table 961. plic.CORE0_SEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.20. CORE0_SEIP_CLAIM_COMPLETE

Table 962. plic.CORE0_SEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.21. CORE1_SEIP_THRESHOLD

Table 963. plic.CORE1_SEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.22. CORE1_SEIP_CLAIM_COMPLETE

Table 964. plic.CORE1_SEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.23. CORE2_SEIP_THRESHOLD

Table 965. plic.CORE2_SEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.24. CORE2_SEIP_CLAIM_COMPLETE

Table 966. plic.CORE2_SEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.6.4.2.1.25. CORE3_SEIP_THRESHOLD

Table 967. plic.CORE3_SEIP_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2:0	value	RW	-	Interrupt notification threshold. Maximum value is 7. The context's external interrupt is raised only while the highest-priority pending, enabled source has a priority strictly greater than the threshold. The threshold does not gate claims: a claim read returns the highest-priority pending, enabled source regardless of the threshold.

2.1.6.6.4.2.1.26. CORE3_SEIP_CLAIM_COMPLETE

Table 968. plic.CORE3_SEIP_CLAIM_COMPLETE fields

Bits	Field	Access	Reset	Description
31:0	value	RW	-	Claim/Complete register. Reading this register returns the claimed interrupt number and makes it no longer pending. Writing the interrupt number back completes the interrupt.

2.1.6.7. Peripherals

This section documents the main peripherals integrated within the System Management Controller (SMC). These peripherals provide essential I/O and communication capabilities for the OCAH system, supporting various protocols and interfaces required for system operation and external connectivity.

Table 969 summarizes the key peripherals, their communication protocols, and default instance counts:

Table 969. SMC Peripheral Summary

Peripheral	Description	Protocol	Instances
Mailbox	FIFO-based bidirectional communication channels for inter-processor or inter-chiplet communication.	AXI4-Lite	32
System Timer OCTS	64-bit timer for multi-chiplet time synchronization with PRIMARY/SECONDARY modes.	APB4/AXI4-Lite	1
eFuse	Secure access to One-Time Programmable (OTP) memory with layered security architecture.	APB4/AXI4-Lite	1
UART 16550	Industry-standard UART with enhanced FIFO capabilities and comprehensive interrupt support.	AXI4-Lite	4
Log Engine	DMA-based logging system for efficient transfer of log messages to UART interface.	AXI4-Lite	4
I2C	Full I2C/SMBus/PMBus communication controller supporting both controller and target modes.	AXI4-Lite	3
I3C	CHIPS Alliance i3c-core with an OCAH AXI4-Lite wrapper. Integration verification remains a work in progress.	AXI4-Lite	6
AVSBus Controller	Adaptive voltage scaling communication controller for managing voltage rails and power conditions.	APB4/AXI4-Lite	1
GPIO	General Purpose Input/Output with dual-mode operation and comprehensive interrupt system (61 bonded + 4 unbonded).	AXI4-Lite	65
Telemetry Receiver	Hardware component for decoding and processing telemetry data from multi-chiplet systems.	AXI4-Lite	3
Reset Unit	Reset control and synchronization, deals with SMC resets (core, primary), subsystem (chiplet) resets, and the cool reset sequence.	AXI4-Lite	1
SMC Misc	Wrapper for miscellaneous registers: scratch registers, chip config and NDM reset.	AXI4-Lite	1

2.1.6.7.1. Direct Memory Access (DMA) Engine

The SMC DMA copies data through an AXI master using register-programmed linear or two-dimensional transfers. Software supplies one shared configuration and submits it by reading `NEXT_ID_0`. The engine does not fetch descriptor lists. SMC instantiates one control interface, one stream and one DMA master.

Table 970. SMC DMA integration

Item	SMC configuration
Control aperture	`0xC003_8000`–`0xC003_81FF` (512 bytes, SMC-local view).
Control path	AXI, 9-bit local address and 64-bit data, 8-bit ID, converted internally to 32-bit register accesses. This is not an AXI4-Lite-only wrapper.
Data path	56-bit addresses, 64-bit data; 3-bit ID at the DMA wrapper and 4-bit ID after the shared DMA/zeroer mux. Backend internal IDs are 2 bits.
Access policy	Transfers pass through SMC fabric remapping/filtering; program addresses permitted by that integration.

2.1.6.7.1.1. Architecture and Configuration

The frontend captures register state into a request FIFO. The 2D midend expands each command into linear transfers, and the backend performs the AXI reads and writes. The DMA and zeroer share the outgoing fabric path shown below.




Figure 62. SMC DMA frontend, backend and shared fabric path

The DMA and the zeroer share `smc_data_accelerator_wrap`. Its control demux sends the zeroer register window to the zeroer and every other address to the DMA, and each control path narrows the address to its own register window. Its master mux merges the two master ports onto the port to the input fabric and adds one ID bit to tell their responses apart. In the figure, thick lines are AXI4, thin dark lines are the register bus, and grey lines are iDMA requests and responses, gated clocks and status outputs. The dashed box is the manager-to-backend FIFO, which is absent because SMC sets `M2B_FIFO_DEPTH` to 0. With one control interface and one master interface, the request manager is a passthrough, so the arbitration described under [smc-dma-request-arbitration] is not instantiated.

The generic request manager can arbitrate multiple control/master interfaces with round-robin selection, per-master origin tracking and buffered response routing. In the instantiated one-control/one-master SMC configuration it is a passthrough; these generic arbitration features add no extra SMC streams.

Table 971. SMC DMA elaboration settings

Parameter	SMC value	Meaning
`NUM_CTRL_INTERFACES`, `NUM_CTRL_STREAMS`, `NUM_MST_INTERFACES`	1 each	One shared configuration, one functional stream and one DMA master.
`DMA_MST_MAX_TXNS`	32	Backend in-flight AXI limit, from `FabricMaxTrans`. The generic DMA wrapper default is 16.
`F2M_FIFO_DEPTH`	4	Request FIFO between frontend and 2D midend.
`M2B_FIFO_DEPTH`	0	Midend-to-backend FIFO bypassed.

Parameter	SMC value	Meaning
BUFFER_DEPTH	16	Backend realignment buffer depth in beats; the generic wrapper default is 3. It is not a reorder-buffer entry count.
EN_R_AW_COUPLING	1	Backend read/write address coupling enabled.
BYPASS_DMA_CTRL_FLOPS, BYPASS_DMA_MST_FLOPS	0 each	Interface cuts retained.
CG_HYSTERESIS_W	6	Width of the runtime clock-gating hysteresis input.

The parameters of idma_wrapper are listed in the HTML edition of this manual, under RTL Modules Reference.

The frontend has a bus-aware clock gate; the request manager and backend use a separate activity/hysteresis gate. cg_enable_i=0 keeps them awake, and test mode overrides gating. Clock gating does not abort transfers or isolate the bus.

2.1.6.7.1.2. Transfer Configuration

2.1.6.7.1.2.1. Stream and Register Ownership

The generated map contains NEXT_ID, STATUS and DONE banks for 16 streams, but only bank 0 is functional in SMC. Reads of NEXT_ID_1..15 complete with zero and launch nothing; their STATUS and DONE registers also read zero. A read of NEXT_ID_0 is a command, not a status read: any read whose bytes include NEXT_ID_0, such as a 64-bit read at 0x48, launches a transfer; a 32-bit read of the unused word at 0x4C does not.

Source, destination, length, strides, repetitions and CONFIG are registers shared by all software contexts, with no configuration-lock register. The 64-bit fields use low/high 32-bit register halves, which the register path does not update atomically.

Table 972. DMA register storage and effective field widths

Field	CSR storage	Effective width	Use
SRC_ADDRESS_LO/HI, DST_ADDRESS_LO/HI	64 bits each	56 bits each	Byte addresses.
LENGTH_LO/HI	64 bits	56 bits	Bytes per linear copy or per 2D row. Zero-length transfers are rejected.
SRC_STRIDE_LO/HI, DST_STRIDE_LO/HI	64 bits each	56 bits each	Address increment between consecutive row starts; source and destination increments are independent.
NUM_REPETITIONS_LO/HI	64 bits	32 bits	Number of rows, including the first.

The frontend casts register values to these effective widths: upper bits are discarded, not validated as an out-of-range access. Program unused upper bits as zero and ensure all row addresses and lengths fit the permitted address range. Address stepping uses the effective address width.

2.1.6.7.1.2.2. Linear and Two-Dimensional Copies

A linear copy is one repetition with CONFIG.ENABLED_ND set; a 2D copy adds source/destination strides and a repetition count. Strides can gather or scatter evenly spaced rows; there is no linked-list walker.

Clearing CONFIG.ENABLED_ND forces the midend repetition count to zero. A zero-repetition command produces an internal midend error response without data movement; that response still retires a transfer ID. The control aperture does not expose the error payload, so a retired ID alone is not proof that valid data was copied.

The names above follow the published register map. The RTL frontend calls the configuration conf, the ND-enable field enable_nd, and the repetition pair reps_2_low/high; these refer to the same fields.

The frontend requests incrementing AXI bursts and sets the cache attribute to modifiable. CONFIG supplies decoupling, maximum burst-length and length-reduction options; the CONFIG register description gives each field's effect. The backend handles alignment and burst splitting; these mechanisms do not grant permission to access a filtered or otherwise invalid address.

2.1.6.7.1.3. Submission and Completion

The DMA Engine section of the Programmer's Guide gives the submission and completion sequence.

Table 973. DMA status and notification

Indication	Meaning
STATUS_0[7:0]	Eight copies of frontend request readiness: 0xFF means room to accept a command. These are not per-channel backend busy bits.
STATUS_0[8] / [9]	Bit 8 is the midend activity indication; bit 9 is zero.
DONE_0	Most recently retired transfer ID. No byte-progress or classified software error-status register is provided.
DMA interrupt	One-cycle pulse on a falling edge of combined frontend/backend busy, routed to raw CPU vector bit 322 (PLIC ID 323). No local enable, mask or pending register; this is not one interrupt per submitted descriptor.

Frontend readiness and a zero STATUS value do not indicate completion. The transfer-ID generator resets NEXT_ID to 2 and DONE to 1 and skips zero on wrap. PLIC gateway behavior does not turn successive busy-falling pulses into a counted queue.

2.1.6.7.1.4. Memory Map and Register Reference

2.1.6.7.1.4.1. Memory Map

NOTE The register map below covers all 16 stream banks because the register file is generated at the maximum stream count. With NUM_CTRL_STREAMS = 1, only the _0 bank of NEXT_ID, STATUS, and DONE has any effect; see Section 2.1.6.7.1.2.1.

2.1.6.7.1.4.2. Detailed Register Map

2.1.6.7.1.4.2.1. iDMA Controller Address Map

Source, destination, length, and control registers for the iDMA data-mover engine.

Table 974. iDMA Controller Address Map register list

Address	Name	Access	Description
0x0	CONFIG	RW	-
0x4	STATUS_0	R	-
0x8	STATUS_1	R	-
0xC	STATUS_2	R	-
0x10	STATUS_3	R	-
0x14	STATUS_4	R	-
0x18	STATUS_5	R	-
0x1C	STATUS_6	R	-
0x20	STATUS_7	R	-
0x24	STATUS_8	R	-

Address	Name	Access	Description
0x28	STATUS_9	R	-
0x2C	STATUS_10	R	-
0x30	STATUS_11	R	-
0x34	STATUS_12	R	-
0x38	STATUS_13	R	-
0x3C	STATUS_14	R	-
0x40	STATUS_15	R	-
0x48	NEXT_ID_0	R	-
0x50	NEXT_ID_1	R	-
0x58	NEXT_ID_2	R	-
0x60	NEXT_ID_3	R	-
0x68	NEXT_ID_4	R	-
0x70	NEXT_ID_5	R	-
0x78	NEXT_ID_6	R	-
0x80	NEXT_ID_7	R	-
0x88	NEXT_ID_8	R	-
0x90	NEXT_ID_9	R	-
0x98	NEXT_ID_10	R	-
0xA0	NEXT_ID_11	R	-
0xA8	NEXT_ID_12	R	-
0xB0	NEXT_ID_13	R	-
0xB8	NEXT_ID_14	R	-
0xC0	NEXT_ID_15	R	-
0xC8	DONE_0	R	-
0xCC	DONE_1	R	-
0xD0	DONE_2	R	-
0xD4	DONE_3	R	-
0xD8	DONE_4	R	-
0xDC	DONE_5	R	-
0xE0	DONE_6	R	-
0xE4	DONE_7	R	-
0xE8	DONE_8	R	-
0xEC	DONE_9	R	-
0xF0	DONE_10	R	-
0xF4	DONE_11	R	-
0xF8	DONE_12	R	-
0xFC	DONE_13	R	-
0x100	DONE_14	R	-
0x104	DONE_15	R	-
0x108	DST_ADDRESS_LO	RW	-
0x10C	DST_ADDRESS_HI	RW	-

Address	Name	Access	Description
0x110	SRC_ADDRESS_LO	RW	-
0x114	SRC_ADDRESS_HI	RW	-
0x118	LENGTH_LO	RW	-
0x11C	LENGTH_HI	RW	-
0x120	DST_STRIDE_LO	RW	-
0x124	DST_STRIDE_HI	RW	-
0x128	SRC_STRIDE_LO	RW	-
0x12C	SRC_STRIDE_HI	RW	-
0x130	NUM_REPETITIONS_LO	RW	-
0x134	NUM_REPETITIONS_HI	RW	-

2.1.6.7.1.4.2.1.1. CONFIG

Table 975. dma_ctrl.CONFIG fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10	ENABLED_ND	RW	0x0	Repetition enable. 1: the copy is performed NUM_REPETITIONS times, with SRC_STRIDE and DST_STRIDE added to the addresses between rows; set it for every transfer, including a linear copy with NUM_REPETITIONS = 1. 0: the repetition count is forced to zero, so the command completes with an error response, moves no data, and still retires its transfer ID.
9:7	DST_MAX_LLEN	RW	0x0	Base-2 logarithm of the maximum write burst length in 64-bit beats, applied when DST_REDUCE_LEN is 1. A write burst does not cross a boundary aligned to 2^(DST_MAX_LLEN+3) bytes; 0 gives single-beat bursts. Ignored when DST_REDUCE_LEN is 0.
6:4	SRC_MAX_LLEN	RW	0x0	Base-2 logarithm of the maximum read burst length in 64-bit beats, applied when SRC_REDUCE_LEN is 1. A read burst does not cross a boundary aligned to 2^(SRC_MAX_LLEN+3) bytes; 0 gives single-beat bursts. Ignored when SRC_REDUCE_LEN is 0.
3	DST_REDUCE_LEN	RW	0x0	Destination burst-length reduction. 1: write bursts are limited by DST_MAX_LLEN. 0: a write burst is at most 256 beats and does not cross a 2 KiB-aligned boundary.
2	SRC_REDUCE_LEN	RW	0x0	Source burst-length reduction. 1: read bursts are limited by SRC_MAX_LLEN. 0: a read burst is at most 256 beats and does not cross a 2 KiB-aligned boundary.
1	DECOUPLE_RW	RW	0x0	Read/write decoupling. 0: read and write bursts are formed in lockstep, one write burst per read burst. 1: read and write bursts are formed and issued independently; this mode can deadlock.
0	DECOUPLE_AW	RW	0x0	Write-address decoupling. 0: the write address of each burst is held until the first read data beat of the matching read burst returns. 1: write addresses are issued without waiting for read data.

2.1.6.7.1.4.2.1.2. STATUS_0

Table 976. dma_ctrl.STATUS_0 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.3. STATUS_1

Table 977. dma_ctrl.STATUS_1 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.4. STATUS_2

Table 978. dma_ctrl.STATUS_2 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.5. STATUS_3

Table 979. dma_ctrl.STATUS_3 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.6. STATUS_4

Table 980. dma_ctrl.STATUS_4 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.7. STATUS_5

Table 981. dma_ctrl.STATUS_5 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.8. STATUS_6

Table 982. dma_ctrl.STATUS_6 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.9. STATUS_7

Table 983. dma_ctrl.STATUS_7 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.10. STATUS_8

Table 984. dma_ctrl.STATUS_8 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.11. STATUS_9

Table 985. dma_ctrl.STATUS_9 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.12. STATUS_10

Table 986. dma_ctrl.STATUS_10 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.13. STATUS_11

Table 987. dma_ctrl.STATUS_11 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.14. STATUS_12

Table 988. dma_ctrl.STATUS_12 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.15. STATUS_13

Table 989. dma_ctrl.STATUS_13 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.16. STATUS_14

Table 990. dma_ctrl.STATUS_14 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.17. STATUS_15

Table 991. dma_ctrl.STATUS_15 fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9:0	BUSY	R	0x0	Status for the active stream: bits [7:0] each indicate readiness to accept another command, bit 8 indicates midend activity, and bit 9 is zero. These bits do not report backend busy or prove transfer completion; use DONE for completed transfer IDs. Unused streams read zero.

2.1.6.7.1.4.2.1.18. NEXT_ID_0

Table 992. dma_ctrl.NEXT_ID_0 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.19. NEXT_ID_1

Table 993. dma_ctrl.NEXT_ID_1 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.20. NEXT_ID_2

Table 994. dma_ctrl.NEXT_ID_2 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.21. NEXT_ID_3

Table 995. dma_ctrl.NEXT_ID_3 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.22. NEXT_ID_4

Table 996. dma_ctrl.NEXT_ID_4 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.23. NEXT_ID_5

Table 997. dma_ctrl.NEXT_ID_5 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.24. NEXT_ID_6

Table 998. dma_ctrl.NEXT_ID_6 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.25. NEXT_ID_7

Table 999. dma_ctrl.NEXT_ID_7 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.26. NEXT_ID_8

Table 1000. dma_ctrl.NEXT_ID_8 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.27. NEXT_ID_9

Table 1001. dma_ctrl.NEXT_ID_9 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.28. NEXT_ID_10

Table 1002. dma_ctrl.NEXT_ID_10 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.29. NEXT_ID_11

Table 1003. dma_ctrl.NEXT_ID_11 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.30. NEXT_ID_12

Table 1004. dma_ctrl.NEXT_ID_12 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.31. NEXT_ID_13

Table 1005. dma_ctrl.NEXT_ID_13 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.32. NEXT_ID_14

Table 1006. dma_ctrl.NEXT_ID_14 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.33. NEXT_ID_15

Table 1007. dma_ctrl.NEXT_ID_15 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Reading this register starts the DMA transfer. Returns an ID value for the cumulative number of transfers. Returns 0 if command was not set up correctly

2.1.6.7.1.4.2.1.34. DONE_0

Table 1008. dma_ctrl.DONE_0 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.35. DONE_1

Table 1009. dma_ctrl.DONE_1 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.36. DONE_2

Table 1010. dma_ctrl.DONE_2 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.37. DONE_3

Table 1011. dma_ctrl.DONE_3 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.38. DONE_4

Table 1012. dma_ctrl.DONE_4 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.39. DONE_5

Table 1013. dma_ctrl.DONE_5 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.40. DONE_6

Table 1014. dma_ctrl.DONE_6 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.41. DONE_7

Table 1015. dma_ctrl.DONE_7 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.42. DONE_8

Table 1016. dma_ctrl.DONE_8 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.43. DONE_9

Table 1017. dma_ctrl.DONE_9 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.44. DONE_10

Table 1018. dma_ctrl.DONE_10 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.45. DONE_11

Table 1019. dma_ctrl.DONE_11 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.46. DONE_12

Table 1020. dma_ctrl.DONE_12 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.47. DONE_13

Table 1021. dma_ctrl.DONE_13 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.48. DONE_14

Table 1022. dma_ctrl.DONE_14 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.49. DONE_15

Table 1023. dma_ctrl.DONE_15 fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	Holds the cumulative number of completed transfers. Only accumulates when response is seen

2.1.6.7.1.4.2.1.50. DST_ADDRESS_LO

Table 1024. dma_ctrl.DST_ADDRESS_LO fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Destination address for DMA to write to, lower 32 bits

2.1.6.7.1.4.2.1.51. DST_ADDRESS_HI

Table 1025. dma_ctrl.DST_ADDRESS_HI fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Destination address for DMA to write to, upper 32 bits. Bits [31:24] (combined address bits [63:56]) are discarded, not checked; program them as zero.

2.1.6.7.1.4.2.1.52. SRC_ADDRESS_LO

Table 1026. dma_ctrl.SRC_ADDRESS_LO fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Source address for DMA to read from, lower 32 bits.

2.1.6.7.1.4.2.1.53. SRC_ADDRESS_HI

Table 1027. dma_ctrl.SRC_ADDRESS_HI fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Source address for DMA to read from, upper 32 bits. Bits [31:24] (combined address bits [63:56]) are discarded, not checked; program them as zero.

2.1.6.7.1.4.2.1.54. LENGTH_LO

Table 1028. dma_ctrl.LENGTH_LO fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Number of bytes to move, lower 32 bits.

2.1.6.7.1.4.2.1.55. LENGTH_HI

Table 1029. dma_ctrl.LENGTH_HI fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Number of bytes to move, upper 32 bits. Bits [31:24] (combined length bits [63:56]) are discarded, not checked; program them as zero.

2.1.6.7.1.4.2.1.56. DST_STRIDE_LO

Table 1030. dma_ctrl.DST_STRIDE_LO fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Stride amount on destination address side, lower 32 bits

2.1.6.7.1.4.2.1.57. DST_STRIDE_HI

Table 1031. dma_ctrl.DST_STRIDE_HI fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Stride amount on destination address side, upper 32 bits. Bits [31:24] (combined stride bits [63:56]) are discarded, not checked; program them as zero.

2.1.6.7.1.4.2.1.58. SRC_STRIDE_LO

Table 1032. dma_ctrl.SRC_STRIDE_LO fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Stride amount on source address side, lower 32 bits

2.1.6.7.1.4.2.1.59. SRC_STRIDE_HI

Table 1033. dma_ctrl.SRC_STRIDE_HI fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Stride amount on source address side, upper 32 bits. Bits [31:24] (combined stride bits [63:56]) are discarded, not checked; program them as zero.

2.1.6.7.1.4.2.1.60. NUM_REPETITIONS_LO

Table 1034. dma_ctrl.NUM_REPETITIONS_LO fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Number of rows to copy, including the first, lower 32 bits. SRC_STRIDE and DST_STRIDE are added to the addresses between rows. Takes effect only when CONFIG.ENABLED_ND is 1.

2.1.6.7.1.4.2.1.61. NUM_REPETITIONS_HI

Table 1035. dma_ctrl.NUM_REPETITIONS_HI fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	Number of rows to copy, upper 32 bits. The DMA uses only the low 32 bits of the row count, so this register is discarded, not checked; program it as zero.

2.1.6.7.2. Zeroer

The SMC Memory Zeroer efficiently initializes large memory regions to zero without CPU intervention. The unit uses a state machine-based architecture with dual clock domains.

Table 1036 summarises the zeroer control aperture and fabric integration.

Table 1036. SMC Memory Zeroer Integration

Parameter	Description
Address Range	0xC003_8200 - 0xC003_83FF (512 bytes)
Control Interface	AXI4 (5-bit address, 64-bit data, 8-bit ID), converted internally to AXI4-Lite for the registers
Data Interface	AXI4 Master (56-bit address, 64-bit data, 3-bit ID; 4-bit ID after the shared DMA/zeroer mux)
Maximum Burst Length	256 beats (`AWLEN = 255`)
Outstanding Transactions	Counted by a 32-bit counter; no 32-transaction issuance limit or counter-based back-pressure

2.1.6.7.2.1. Use Cases

- **System Initialization**: Clear memory regions during boot or reset sequences
- **Security Operations**: Sanitize sensitive data areas
- **Memory Management**: Initialize allocated memory blocks
- **Error Recovery**: Clear corrupted memory regions

2.1.6.7.2.2. Architecture

The DMA and zeroer share the data-accelerator fabric path shown in SMC DMA frontend, backend and shared fabric path.

2.1.6.7.2.2.1. State Machine

The zeroer state machine has three operating states and an error state (Table 1037).

Table 1037. SMC zeroer state machine

State	Description
ST_IDLE (3'b001)	Idle state waiting for configuration and trigger
ST_ISSUE_ADDR (3'b010)	Address phase - issuing AXI write addresses
ST_ISSUE_DATA (3'b100)	Data phase - streaming zero data for all beats
ST_ERROR (3'b000)	Entered from any illegal state encoding; holds the zeroer busy, with no interrupt, until reset

Figure 63 shows the state machine and its AXI write flow.




Figure 63. SMC memory zeroer state machine and AXI write flow

Rounded boxes are the states of the clear state machine, with their encodings; grey arrows are transitions, labelled with their conditions. A write to `CTRL_STATUS` while `SIZE` is non-zero leaves `ST_IDLE`. Each pass through `ST_ISSUE_ADDR` and `ST_ISSUE_DATA` issues one write burst of zeros, and the machine returns to `ST_IDLE` once no bytes remain. `ST_ERROR` is entered only from an illegal state encoding and is left only by reset. The write-response channel is always ready and its response code is not checked; the outstanding-request count decides when the zeroer stops being busy.

2.1.6.7.2.2.2. Operation Flow

1. **Configuration**: Software writes destination address and size to registers
2. **Trigger**: Write to control/status register initiates operation
3. **Address Phase**: Hardware calculates optimal burst patterns and issues write addresses
4. **Data Phase**: Hardware streams zero data matching issued address beats
5. **Completion**: State machine returns to idle with status update and optional interrupt

2.1.6.7.2.2.3. AXI Master Interface

Table 1038 summarises the zeroer's AXI master interface.

Table 1038. SMC zeroer AXI4 Master Characteristics

Parameter	Specification
Address Width	56-bit addressing for large system integration

Parameter	Specification
Data Width	64-bit data path
ID Width	4-bit transaction ID (internal 3-bit usage)
User Signals	12-bit user field for system-specific attributes
Maximum Burst Length	256 beats (`AWLEN = 255`)
Burst Calculation	Automatic optimal burst sizing
Address Alignment	Intelligent handling of unaligned start addresses
Boundary Handling	Automatic burst fragmentation at page boundaries

2.1.6.7.2.2.4. Outstanding Transaction Management

The zeroer counts accepted write addresses and consumed write responses in a 32-bit outstanding-request counter. The counter determines whether responses remain pending; it does not impose a limit of 32 transactions or throttle address issuance. AXI `AWREADY` and `WREADY` provide downstream back-pressure.

The response channel is consumed without checking `BRESP`. Completion means that all responses have arrived, not that every write succeeded. The internal error state handles an illegal state-machine encoding, not AXI bus errors. The Memory Zeroer procedure in the Programmer's Guide covers validating a request and verifying a clear.

2.1.6.7.2.2.5. Dual Clock Domain Architecture

The zeroer implements dual clock domain operation for power management and interface isolation.

2.1.6.7.2.2.6. Clock Domains

Table 1039 identifies the AXI and APB clock domains and their roles.

Table 1039. SMC zeroer Clock Domain Characteristics

Clock Domain	Description
AXI Clock (axi_clk)	Dedicated clock for AXI master operations, enabled only during active zeroing
Register Clock (reg_clk)	Separate clock for register interface, independent of AXI activity

2.1.6.7.2.2.7. Clock Gating

Table 1040 gives the gating conditions for each clock domain.

Table 1040. SMC zeroer Clock Gating Control

Domain	Gating Logic
AXI Clock	axi_clk_enable = disable_cg | zeroer_busy_o | ~rst_ni
Register Clock	reg_clk_enable = disable_cg | register_activity | ~rst_ni
Implementation	prim_clock_gating for glitch-free operation
Test Support	Test enable override for manufacturing test
Reset Override	Ensures proper reset domain operation

2.1.6.7.2.2.8. Control and Status

2.1.6.7.2.2.8.1. Operation Control

Table 1041 defines the registers used to configure and start a zeroing operation.

Table 1041. SMC zeroer Configuration and Control

Register	Description
DEST_ADDR	64-bit byte address for destination memory region
SIZE	64-bit byte count for zeroing operation
CTRL_STATUS	Control and status register (trigger, busy status)
CTRL_STATUS.INT_EN	Enables the completion pulse

2.1.6.7.2.2.8.2. Status Features

- **Busy Status**: Real-time indication of zeroing operation in progress
- **Completion Status**: Updates when all write responses received
- **Error Reporting**: No software-visible AXI error report; failed write responses are not distinguished from successful responses
- **Interrupt Generation**: Optional interrupt on operation completion

2.1.6.7.2.3. Operation Details

Table 1042 summarises zero-data generation and transfer control.

Table 1042. SMC zeroer Data Generation and Control

Feature	Description
Zero Data Generation	Hardware generates zero data for all beats
Strobe Calculation	Correct byte strobes for partial transfers and unaligned addresses
Last Beat Handling	Proper w_last assertion for burst completion
Size Tracking	Accurate remaining size calculation throughout operation
Overflow Protection	Overflow assertions are simulation checks; there is no hardware overflow-rejection status or recovery control
Abort	No software abort control or guarantee that a reset safely drains outstanding writes

2.1.6.7.2.4. Memory Map and Register Reference

2.1.6.7.2.4.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.6.7.2.4.2. Detailed Register Map

2.1.6.7.2.4.2.1. Zeroer Control Address Map

Control and status registers for the AXI memory-zeroing engine.

Table 1043. Zeroer Control Address Map register list

Address	Name	Access	Description
0x0	DEST_ADDR	RW	-
0x8	SIZE	RW	-
0x10	CTRL_STATUS	RW	Writing this register will trigger start of zeroer. The write is ignored while SIZE is 0.

2.1.6.7.2.4.2.1.1. DEST_ADDR

Table 1044. zeroer_ctrl.DEST_ADDR fields

Bits	Field	Access	Reset	Description
63:0	DEST_ADDR	RW	0x0	Byte address to write zeros to

2.1.6.7.2.4.2.1.2. SIZE

Table 1045. zeroer_ctrl.SIZE fields

Bits	Field	Access	Reset	Description
63:0	SIZE	RW	0x0	Size in bytes of zeros to write

2.1.6.7.2.4.2.1.3. CTRL_STATUS

Table 1046. zeroer_ctrl.CTRL_STATUS fields

Bits	Field	Access	Reset	Description
63:33	Reserved	-	-	Reserved
32	STATUS	R	0x0	Indicates whether the zeroer is busy. 1 means the zeroer is active, has pending work, or is in an error state; 0 means it is idle with no pending or outstanding work, including after completion.
31:1	Reserved	-	-	Reserved
0	INT_EN	RW	0x0	If enabled, an interrupt will be outputted once zeroer completes.

2.1.6.7.3. Watchdog Timers

2.1.6.7.3.1. Operation

Each CPU core includes a dedicated watchdog timer (at 0xC000_0000 + N * 0x400), providing per-core timeout monitoring. Reset effects are described in Clocks and Resets. Base addresses and interrupt-related context for the WDT are summarized in Interrupts.

Timeouts are configurable to suit different workloads, and staged warnings (followed by reset) allow software intervention before hardware reset is triggered.

Watchdog monitoring can be disabled during debugging to prevent false triggers, supporting uninterrupted development and troubleshooting.

The watchdog interrupt is `CTRL.wdogip0`. Hardware sets it on every cycle the scaled count is at or above `CMP`, so it cannot be cleared while that holds. Feeding the watchdog resets the count but leaves `wdogip0` set. The watchdog interrupt clear sequence is in the Programmer's Guide.

2.1.6.7.3.1.1. Register Access

Each watchdog is locked out of reset, and a write to any register other than KEY locks it again. Software changes one register at a time:

1. Write `0x51F15E` to KEY. KEY reads 1 while the watchdog is unlocked.
2. Write the target register. The watchdog locks again on this write, so the next write needs a new KEY write first.

A write acts only when its byte enables cover the register's width, and a narrower write completes with an OKAY response without changing anything, so software cannot detect a dropped write from the response. Software uses 32-bit stores for every register except CTRL, which accepts byte writes. The Detailed Register Map below gives the width each register requires.

2.1.6.7.3.2. Memory Map and Register Reference

2.1.6.7.3.2.1. Memory Map

Register offsets are relative to the block base in the subsystem memory map. The detailed map below defines each register and its fields.

2.1.6.7.3.2.2. Detailed Register Map

2.1.6.7.3.2.2.1. Watchdog Timer Address Map

Watchdog timer configuration, counter, compare, and feed and key registers.

A write takes effect only if its byte enables cover all four bytes of COUNT, COUNT_HI, FEED or KEY, or bytes 0 and 1 of SCALED_COUNT or CMP; each CTRL byte is written on its own. Any other write returns OKAY and changes nothing, not even the lock.

Each effective write to a register other than KEY locks the watchdog, and changes no field if it was already locked. A 64-bit write at 0x18 writes FEED and KEY together and leaves the watchdog locked.

Table 1047. Watchdog Timer Address Map register list

Address	Name	Access	Description
0x0	CTRL	RW	KEY reg must be written to before any other register in this addrmap can be written to, unlocking the WDT. After writing to another register, the WDT will be locked again, and KEY must be written to again to unlock it.
0x8	COUNT	RW	-
0xC	COUNT_HI	W	-
0x10	SCALED_COUNT	RW	-
0x18	FEED	RW	-
0x1C	KEY	RW	-
0x20	CMP	RW	-

2.1.6.7.3.2.2.1.1. CTRL

Table 1048. wdt.CTRL fields

Bits	Field	Access	Reset	Description
31:29	rsvd3	R	0x0	Reserved

Bits	Field	Access	Reset	Description
28	wdogip0	RW	0x0	Pending interrupt. Hardware sets this bit on every cycle the scaled count has reached the compare value. To clear it, write KEY and then write 0 to this bit while the scaled count is below the compare value. Writing FEED does not clear it.
27:14	rsvd2	R	0x0	Reserved
13	wdogcoreawake	RW	0x0	Enable WDT to only count when the core is not in reset
12	wdogenalways	RW	0x0	Enable WDT to always count. This has priority over wdogcoreawake
11:10	rsvd1	R	0x0	Reserved
9	wdogzerocmp	RW	0x0	Enable cycle counter to be reset to 0 when compare value has been reached
8	wdogrsten	RW	0x0	Enables a sticky reset signal to outputted to top level, can be used for a second stage wdt
7:4	rsvd0	R	0x0	Reserved
3:0	wdogscale	RW	0x0	WDT counter scale value. Scales the current cycle count (time) by count / 2 ^ wdogscale value

2.1.6.7.3.2.2.1.2. COUNT

Table 1049. wdt.COUNT fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30:0	wdogcount	RW	0x0	31 bit wdt counter registers. On write, the counter will be set to the written value, then continue counting up. KEY reg must be written to before any other register in this addrmap can be written to, unlocking the WDT. After writing to another register, the WDT will be locked again, and KEY must be written to again to unlock it.

2.1.6.7.3.2.2.1.3. COUNT_HI

Table 1050. wdt.COUNT_HI fields

Bits	Field	Access	Reset	Description
31:0	wdogcounthi	W	0x0	Upper word of the counter. The counter is 31 bits wide and lies entirely in COUNT, so this register has no storage and reads 0. A write covering all four bytes leaves the counter unchanged but locks the WDT, so KEY must be written again before the next write.

2.1.6.7.3.2.2.1.4. SCALED_COUNT

Table 1051. wdt.SCALED_COUNT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	wdogs	RW	0x0	Scaled value of wdt counter. (i.e. count >> wdogscale). Writing to this reg has no effect, but will lock the WDT (meaning KEY must be written to KEY reg to unlock it again). KEY reg must be written to before any other register in this addrmap can be written to, unlocking the WDT. After writing to another register, the WDT will be locked again, and KEY must be written to again to unlock it.

2.1.6.7.3.2.2.1.5. FEED

Table 1052. wdt.FEED fields

Bits	Field	Access	Reset	Description
31:0	wdogfeed	RW	0x0	Feed register. Writing 0xD09F00D will reset the counter value back to 0. Feeding does not clear CTRL.wdogip0. KEY reg must be written to before any other register in this addrmap can be written to, unlocking the WDT. After writing to another register, the WDT will be locked again, and KEY must be written to again to unlock it.

2.1.6.7.3.2.2.1.6. KEY

Table 1053. wdt.KEY fields

Bits	Field	Access	Reset	Description
31:0	wdogkey	RW	0x0	Key register. Magic key (0x51F15E) must be written to this register before a write to any other register in this addrmap. Must be written every time. Reading this reg returns 1 if key has been written to it and it is unlocked, 0 otherwise.

2.1.6.7.3.2.2.1.7. CMP

Table 1054. wdt.CMP fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	wdogcmp0	RW	0x1000	Compare register. Value that gets compared to wdogs. KEY reg must be written to before any other register in this addrmap can be written to, unlocking the WDT. After writing to another register, the WDT will be locked again, and KEY must be written to again to unlock it.

2.1.6.7.4. Mailbox Unit

2.1.6.7.4.1. Overview

The Mailbox Unit connects two software endpoints through a pair of FIFOs. Each endpoint has a register aperture: writing WRITE_DATA sends one word to the peer, and reading READ_DATA consumes one word sent by the peer. A single AXI4-Lite slave port serves all pairs.

NUM_MAILBOXES counts bidirectional pairs, each with two directional apertures and two interrupt outputs. The SMC instance provides 32 pairs (64 apertures); the SEP instance provides 8 pairs (16 apertures). Aperture names describe intended use; both ends remain reachable through the same slave port. Access isolation is the subsystem's responsibility, not a property conferred by naming an aperture inbound or outbound.




Figure 64. SMC mailbox wrapper and interrupt routing

Figure 64 shows the SMC instance of the mailbox, `u_smc_axil_mailbox`, and its interrupt connections. The SMC configures 32 mailboxes of depth 2, with 32-bit address and 64-bit data. The port comes from the mailbox target of `smc_internal_axi_lite_xbar`, and the unit runs on a copy of the SMC clock that `u_mailbox_cg` gates while the port is idle. The demux `u_mailbox_demux`, a PULP `axi_lite_demux`, selects one of 64 ports from address bits [16:11] above `0xC001_8000`. Each mailbox, `gen_mailbox[m].u_axi_lite_mailbox`, is a PULP `axi_lite_mailbox`; the figure puts the source project in parentheses. Mailbox `m` places its outbound port at `0xC001_8000` + `m` × `0x1000` and its inbound port `0x800` above it.

Within a mailbox, the arrows between the ports show the direction of data: `WRITE_DATA` in one port pushes the FIFO that `READ_DATA` in the other port pops. The 32 inbound-port interrupts are SMC CPU interrupts 288 to 319. The 32 outbound-port interrupts leave the SMC on `smc_ext_mailbox_interrupts_o`, which the SMU passes out of its boundary.

The SEP holds a second instance of this unit with eight mailboxes, described in the SEP fabric chapter. The outbound interrupts of that instance reach the SMC as peripheral interrupts 0 to 7, SMC CPU interrupts 256 to 263.

2.1.6.7.4.2. Architecture

The parameters and ports of `axi_lite_mailbox_unit` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.6.7.4.2.1. Paired FIFOs

An `axi_lite_demux` selects one of `2 * NUM_MAILBOXES` register apertures. Within pair N, the outbound aperture writes FIFO A and reads FIFO B; the inbound aperture writes FIFO B and reads FIFO A. The FIFOs are internal to the unit. Flushing an aperture's write FIFO therefore discards data its peer would read; flushing its read FIFO discards data the peer has already sent.

WRITE_DATA enqueues one word when space is available. Inactive AXI byte lanes are written as zero; a partial write does not merge with an existing FIFO word. READ_DATA returns and pops the oldest received word. Software must use status to avoid full writes and empty reads; the interface reports errors rather than waiting for FIFO space or data. The error responses are described below.

2.1.6.7.4.2.2. Interrupts

Each aperture has its own WIRQT, RIRQT, IRQS, IRQEN and IRQP. inbound_interrupt_o[N] and outbound_interrupt_o[N] are active-high level outputs. Each is the OR of IRQP = IRQS & IRQEN for its aperture.

Table 1055. Mailbox interrupt sources

IRQS bit	Source	Set condition
0	Write threshold	Occupancy of the aperture's write FIFO is strictly greater than WIRQT. This indicates queued outbound data, not successful peer receipt.
1	Read threshold	Occupancy of its read FIFO is strictly greater than RIRQT.
2	Access error	A full-FIFO write or empty-FIFO read. ERROR_FLAGS distinguishes which access failed.

These status bits latch independently of IRQEN. Acknowledge selected bits by writing ones to IRQS; reading it does not clear them. Threshold status can reassert if the occupancy condition remains true. WIRQT and RIRQT writes are clamped to MAILBOX_DEPTH - 1, so a threshold of zero detects any queued word and the maximum threshold detects a full FIFO.

STATUS exposes live FIFO-empty/full and threshold conditions. It is distinct from the latched IRQS. Reading ERROR_FLAGS clears the detailed error flags, but does not acknowledge the shared IRQS error bit.

2.1.6.7.4.2.3. Clock and Reset

The unit and its FIFOs use clk_i; there is no internal clock-domain crossing. rst_ni is asynchronous and active low. Reset empties the FIFOs and clears thresholds, error flags, interrupt status and enables. test_en_i supplies the AXI demultiplexer's test input. Follow subsystem reset and access-isolation requirements when either endpoint is active.

2.1.6.7.4.3. Interface and Programming

2.1.6.7.4.3.1. External Interface

A single AXI4-Lite slave (mailbox_axi_req_i / mailbox_axi_resp_o) serves all apertures; its address/data widths and channel/aggregate struct types are elaboration parameters. The inbound_interrupt_o and outbound_interrupt_o vectors each carry NUM_MAILBOXES active-high level interrupts, one per aperture.

The full parameter and port list of axi_lite_mailbox_unit is in the HTML edition of this manual, under RTL Modules Reference.

The per-aperture B and R responses pass through spill registers. Request arbitration, arrival of both write channels, and response backpressure also affect observed latency; software must not assume a fixed completion cycle. Reads and writes use separate AXI4-Lite channels but operate on the same FIFO and status state.

2.1.6.7.4.3.2. Access Results

Table 1056. Mailbox access results

Access	Result
Read READ_DATA while empty	SLVERR, data 0xFEEDDEAD; sets the read-error flag and IRQS[2].

Access	Result
Write WRITE_DATA while full	SLVERR; data discarded; sets the write-error flag and IRQS[2].
Read write-only WRITE_DATA	OKAY, data 0xFEEDC0DE; no FIFO access or error flag.
Write READ_DATA, STATUS, ERROR_FLAGS or IRQP	Ignored with SLVERR.
Access to an unmapped offset inside an aperture (0x50 and above)	Stated in the SMC and SEP memory maps
Read ERROR_FLAGS	Returns and clears both detailed error flags. A new error in the same cycle is retained.
Write CTRL flush bits	Pulses the selected FIFO flush; the bits are not stored configuration and read back as zero.

2.1.6.7.4.3.3. Sending and Receiving

The register interface does not allocate FIFO ownership to clients, and status and data accesses are not one atomic operation. The Programmer's Guide gives the mailbox usage rules.

2.1.6.7.4.4. Memory Map and Register Reference

2.1.6.7.4.4.1. Memory Map

With the default MAILBOX_SIZE=0x800, each directional aperture occupies 2 KiB and each pair occupies 4 KiB. The SMC 32-pair map spans 0x20000 bytes, and the SEP 8-pair map spans 0x8000 bytes; the generic unit's span is 2 * MAILBOX_SIZE * NUM_MAILBOXES. The SMC and SEP wrapper layouts are generated from their SystemRDL compositions:

Table 1057. SMC Mailbox Aperture Layout

Address Range	Size	Decoded Extent	Unit	Instances	Stride
BASE + 0x0 – BASE + 0x7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x800 – BASE + 0xFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1000 – BASE + 0x17FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1800 – BASE + 0x1FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x2000 – BASE + 0x27FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x2800 – BASE + 0x2FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x3000 – BASE + 0x37FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x3800 – BASE + 0x3FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x4000 – BASE + 0x47FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x4800 – BASE + 0x4FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x5000 – BASE + 0x57FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x5800 – BASE + 0x5FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x6000 – BASE + 0x67FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-

Address Range	Size	Decoded Extent	Unit	Instances	Stride
BASE + 0x6800 – BASE + 0x6FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x7000 – BASE + 0x77FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x7800 – BASE + 0x7FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x8000 – BASE + 0x87FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x8800 – BASE + 0x8FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x9000 – BASE + 0x97FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x9800 – BASE + 0x9FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xA000 – BASE + 0xA7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xA800 – BASE + 0xAFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xB000 – BASE + 0xB7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xB800 – BASE + 0xBFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xC000 – BASE + 0xC7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xC800 – BASE + 0xCFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xD000 – BASE + 0xD7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xD800 – BASE + 0xDFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xE000 – BASE + 0xE7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xE800 – BASE + 0xEFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xF000 – BASE + 0xF7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0xF800 – BASE + 0xFFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x10000 – BASE + 0x107FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x10800 – BASE + 0x10FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x11000 – BASE + 0x117FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x11800 – BASE + 0x11FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x12000 – BASE + 0x127FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x12800 – BASE + 0x12FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-

Address Range	Size	Decoded Extent	Unit	Instances	Stride
BASE + 0x13000 – BASE + 0x137FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x13800 – BASE + 0x13FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x14000 – BASE + 0x147FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x14800 – BASE + 0x14FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x15000 – BASE + 0x157FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x15800 – BASE + 0x15FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x16000 – BASE + 0x167FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x16800 – BASE + 0x16FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x17000 – BASE + 0x177FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x17800 – BASE + 0x17FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x18000 – BASE + 0x187FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x18800 – BASE + 0x18FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x19000 – BASE + 0x197FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x19800 – BASE + 0x19FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1A000 – BASE + 0x1A7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1A800 – BASE + 0x1AFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1B000 – BASE + 0x1B7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1B800 – BASE + 0x1BFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1C000 – BASE + 0x1C7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1C800 – BASE + 0x1CFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1D000 – BASE + 0x1D7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1D800 – BASE + 0x1DFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1E000 – BASE + 0x1E7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1E800 – BASE + 0x1EFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1F000 – BASE + 0x1F7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-

Address Range	Size	Decoded Extent	Unit	Instances	Stride
BASE + 0x1F800 – BASE + 0x1FFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-

Table 1058. SEP Mailbox Aperture Layout

Address Range	Size	Decoded Extent	Unit	Instances	Stride
BASE + 0x0 – BASE + 0x7FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x800 – BASE + 0xFFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1000 – BASE + 0x17FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x1800 – BASE + 0x1FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x2000 – BASE + 0x27FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x2800 – BASE + 0x2FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x3000 – BASE + 0x37FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x3800 – BASE + 0x3FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x4000 – BASE + 0x47FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x4800 – BASE + 0x4FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x5000 – BASE + 0x57FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x5800 – BASE + 0x5FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x6000 – BASE + 0x67FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x6800 – BASE + 0x6FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x7000 – BASE + 0x77FF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-
BASE + 0x7800 – BASE + 0x7FFF	2 KiB	80 B	AXI-Lite Mailbox Address Map	1 instance	-

2.1.6.7.4.4.1.1. Per-Mailbox Register Map

Each aperture contains ten registers. Offsets are spaced by `DATA_WIDTH`/8, so they are 8 bytes apart in the 64-bit configurations used today. The generated detailed register map below is authoritative for offsets, widths, access, and field descriptions. The `CTRL` flush bits are pulses rather than stored state, so reads return zero with an OKAY response.

The SMC and SEP memory maps state how an offset above the registers answers.

2.1.6.7.4.4.1.2. Address Examples

For mailbox pair `N`, the outbound aperture begins at `BASE + N * 0x1000`; the inbound aperture begins 0x800 bytes later. A register address is the aperture base plus the generated register offset. For example, in pair zero, `READ_DATA` is at `BASE +`

0x8 outbound and BASE + 0x808 inbound.

2.1.6.7.4.4.2. Detailed Register Map

2.1.6.7.4.4.2.1. AXI-Lite Mailbox Address Map

Register interface for a single AXI-Lite mailbox: data FIFOs, level and status flags, and interrupt controls.

Table 1059. AXI-Lite Mailbox Address Map register list

Address	Name	Access	Description
0x0	WRITE_DATA	W	-
0x8	READ_DATA	R	-
0x10	STATUS	R	-
0x18	ERROR_FLAGS	R	-
0x20	WIRQT	RW	-
0x28	RIRQT	RW	-
0x30	IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x38	IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x40	IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x48	CTRL	W	-

2.1.6.7.4.4.2.1.1. WRITE_DATA

Table 1060. axil_mailbox.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.1.2. READ_DATA

Table 1061. axil_mailbox.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.1.3. STATUS

Table 1062. axil_mailbox.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.1.4. ERROR_FLAGS

Table 1063. axil_mailbox.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.1.5. WIRQT

Table 1064. axil_mailbox.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.1.6. RIRQT

Table 1065. axil_mailbox.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.1.7. IRQS

Table 1066. axil_mailbox.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.1.8. IRQEN

Table 1067. axil_mailbox.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.1.9. IRQP

Table 1068. axil_mailbox.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.1.10. CTRL

Table 1069. axil_mailbox.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2. Subsystem Wrapper Maps

The wrapper maps describe the generated SMC and SEP mailbox compositions. Their offsets are relative to the corresponding wrapper aperture.

2.1.6.7.4.4.2.2.1. SMC AXI-Lite Mailbox Wrapper Address Map

SMC-side wrapper instantiating the AXI-Lite mailbox pairs. Each outbound_mailbox_N / inbound_mailbox_N pair is the two apertures of one bidirectional mailbox and shares a single pair of FIFOs: data written through WRITE_DATA in one aperture is what READ_DATA in the other aperture returns. The outbound/inbound naming reflects intended use, not an access restriction.

Table 1070. SMC AXI-Lite Mailbox Wrapper Address Map register list

Address	Name	Access	Description
0x0	outbound_mailbox_0.WRITE_DATA	W	-
0x8	outbound_mailbox_0.READ_DATA	R	-
0x10	outbound_mailbox_0.STATUS	R	-
0x18	outbound_mailbox_0.ERROR_FLAGS	R	-
0x20	outbound_mailbox_0.WIRQT	RW	-
0x28	outbound_mailbox_0.RIRQT	RW	-
0x30	outbound_mailbox_0.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x38	outbound_mailbox_0.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.

Address	Name	Access	Description
0x40	outbound_mailbox_0.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x48	outbound_mailbox_0.CTRL	W	-
0x800	inbound_mailbox_0.WRITE_DATA	W	-
0x808	inbound_mailbox_0.READ_DATA	R	-
0x810	inbound_mailbox_0.STATUS	R	-
0x818	inbound_mailbox_0.ERROR_FLAGS	R	-
0x820	inbound_mailbox_0.WIRQT	RW	-
0x828	inbound_mailbox_0.RIRQT	RW	-
0x830	inbound_mailbox_0.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x838	inbound_mailbox_0.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x840	inbound_mailbox_0.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x848	inbound_mailbox_0.CTRL	W	-
0x1000	outbound_mailbox_1.WRITE_DATA	W	-
0x1008	outbound_mailbox_1.READ_DATA	R	-
0x1010	outbound_mailbox_1.STATUS	R	-
0x1018	outbound_mailbox_1.ERROR_FLAGS	R	-
0x1020	outbound_mailbox_1.WIRQT	RW	-
0x1028	outbound_mailbox_1.RIRQT	RW	-
0x1030	outbound_mailbox_1.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1038	outbound_mailbox_1.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1040	outbound_mailbox_1.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1048	outbound_mailbox_1.CTRL	W	-
0x1800	inbound_mailbox_1.WRITE_DATA	W	-
0x1808	inbound_mailbox_1.READ_DATA	R	-
0x1810	inbound_mailbox_1.STATUS	R	-
0x1818	inbound_mailbox_1.ERROR_FLAGS	R	-
0x1820	inbound_mailbox_1.WIRQT	RW	-
0x1828	inbound_mailbox_1.RIRQT	RW	-
0x1830	inbound_mailbox_1.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1838	inbound_mailbox_1.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1840	inbound_mailbox_1.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1848	inbound_mailbox_1.CTRL	W	-
0x2000	outbound_mailbox_2.WRITE_DATA	W	-
0x2008	outbound_mailbox_2.READ_DATA	R	-
0x2010	outbound_mailbox_2.STATUS	R	-

Address	Name	Access	Description
0x2018	outbound_mailbox_2.ERROR_FLAGS	R	-
0x2020	outbound_mailbox_2.WIRQT	RW	-
0x2028	outbound_mailbox_2.RIRQT	RW	-
0x2030	outbound_mailbox_2.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x2038	outbound_mailbox_2.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x2040	outbound_mailbox_2.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x2048	outbound_mailbox_2.CTRL	W	-
0x2800	inbound_mailbox_2.WRITE_DATA	W	-
0x2808	inbound_mailbox_2.READ_DATA	R	-
0x2810	inbound_mailbox_2.STATUS	R	-
0x2818	inbound_mailbox_2.ERROR_FLAGS	R	-
0x2820	inbound_mailbox_2.WIRQT	RW	-
0x2828	inbound_mailbox_2.RIRQT	RW	-
0x2830	inbound_mailbox_2.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x2838	inbound_mailbox_2.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x2840	inbound_mailbox_2.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x2848	inbound_mailbox_2.CTRL	W	-
0x3000	outbound_mailbox_3.WRITE_DATA	W	-
0x3008	outbound_mailbox_3.READ_DATA	R	-
0x3010	outbound_mailbox_3.STATUS	R	-
0x3018	outbound_mailbox_3.ERROR_FLAGS	R	-
0x3020	outbound_mailbox_3.WIRQT	RW	-
0x3028	outbound_mailbox_3.RIRQT	RW	-
0x3030	outbound_mailbox_3.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x3038	outbound_mailbox_3.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x3040	outbound_mailbox_3.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x3048	outbound_mailbox_3.CTRL	W	-
0x3800	inbound_mailbox_3.WRITE_DATA	W	-
0x3808	inbound_mailbox_3.READ_DATA	R	-
0x3810	inbound_mailbox_3.STATUS	R	-
0x3818	inbound_mailbox_3.ERROR_FLAGS	R	-
0x3820	inbound_mailbox_3.WIRQT	RW	-
0x3828	inbound_mailbox_3.RIRQT	RW	-
0x3830	inbound_mailbox_3.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.

Address	Name	Access	Description
0x3838	inbound_mailbox_3.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x3840	inbound_mailbox_3.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x3848	inbound_mailbox_3.CTRL	W	-
0x4000	outbound_mailbox_4.WRITE_DATA	W	-
0x4008	outbound_mailbox_4.READ_DATA	R	-
0x4010	outbound_mailbox_4.STATUS	R	-
0x4018	outbound_mailbox_4.ERROR_FLAGS	R	-
0x4020	outbound_mailbox_4.WIRQT	RW	-
0x4028	outbound_mailbox_4.RIRQT	RW	-
0x4030	outbound_mailbox_4.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x4038	outbound_mailbox_4.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x4040	outbound_mailbox_4.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x4048	outbound_mailbox_4.CTRL	W	-
0x4800	inbound_mailbox_4.WRITE_DATA	W	-
0x4808	inbound_mailbox_4.READ_DATA	R	-
0x4810	inbound_mailbox_4.STATUS	R	-
0x4818	inbound_mailbox_4.ERROR_FLAGS	R	-
0x4820	inbound_mailbox_4.WIRQT	RW	-
0x4828	inbound_mailbox_4.RIRQT	RW	-
0x4830	inbound_mailbox_4.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x4838	inbound_mailbox_4.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x4840	inbound_mailbox_4.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x4848	inbound_mailbox_4.CTRL	W	-
0x5000	outbound_mailbox_5.WRITE_DATA	W	-
0x5008	outbound_mailbox_5.READ_DATA	R	-
0x5010	outbound_mailbox_5.STATUS	R	-
0x5018	outbound_mailbox_5.ERROR_FLAGS	R	-
0x5020	outbound_mailbox_5.WIRQT	RW	-
0x5028	outbound_mailbox_5.RIRQT	RW	-
0x5030	outbound_mailbox_5.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x5038	outbound_mailbox_5.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x5040	outbound_mailbox_5.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x5048	outbound_mailbox_5.CTRL	W	-
0x5800	inbound_mailbox_5.WRITE_DATA	W	-

Address	Name	Access	Description
0x5808	inbound_mailbox_5.READ_DATA	R	-
0x5810	inbound_mailbox_5.STATUS	R	-
0x5818	inbound_mailbox_5.ERROR_FLAGS	R	-
0x5820	inbound_mailbox_5.WIRQT	RW	-
0x5828	inbound_mailbox_5.RIRQT	RW	-
0x5830	inbound_mailbox_5.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x5838	inbound_mailbox_5.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x5840	inbound_mailbox_5.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x5848	inbound_mailbox_5.CTRL	W	-
0x6000	outbound_mailbox_6.WRITE_DATA	W	-
0x6008	outbound_mailbox_6.READ_DATA	R	-
0x6010	outbound_mailbox_6.STATUS	R	-
0x6018	outbound_mailbox_6.ERROR_FLAGS	R	-
0x6020	outbound_mailbox_6.WIRQT	RW	-
0x6028	outbound_mailbox_6.RIRQT	RW	-
0x6030	outbound_mailbox_6.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x6038	outbound_mailbox_6.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x6040	outbound_mailbox_6.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x6048	outbound_mailbox_6.CTRL	W	-
0x6800	inbound_mailbox_6.WRITE_DATA	W	-
0x6808	inbound_mailbox_6.READ_DATA	R	-
0x6810	inbound_mailbox_6.STATUS	R	-
0x6818	inbound_mailbox_6.ERROR_FLAGS	R	-
0x6820	inbound_mailbox_6.WIRQT	RW	-
0x6828	inbound_mailbox_6.RIRQT	RW	-
0x6830	inbound_mailbox_6.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x6838	inbound_mailbox_6.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x6840	inbound_mailbox_6.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x6848	inbound_mailbox_6.CTRL	W	-
0x7000	outbound_mailbox_7.WRITE_DATA	W	-
0x7008	outbound_mailbox_7.READ_DATA	R	-
0x7010	outbound_mailbox_7.STATUS	R	-
0x7018	outbound_mailbox_7.ERROR_FLAGS	R	-
0x7020	outbound_mailbox_7.WIRQT	RW	-
0x7028	outbound_mailbox_7.RIRQT	RW	-

Address	Name	Access	Description
0x7030	outbound_mailbox_7.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x7038	outbound_mailbox_7.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x7040	outbound_mailbox_7.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x7048	outbound_mailbox_7.CTRL	W	-
0x7800	inbound_mailbox_7.WRITE_DATA	W	-
0x7808	inbound_mailbox_7.READ_DATA	R	-
0x7810	inbound_mailbox_7.STATUS	R	-
0x7818	inbound_mailbox_7.ERROR_FLAGS	R	-
0x7820	inbound_mailbox_7.WIRQT	RW	-
0x7828	inbound_mailbox_7.RIRQT	RW	-
0x7830	inbound_mailbox_7.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x7838	inbound_mailbox_7.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x7840	inbound_mailbox_7.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x7848	inbound_mailbox_7.CTRL	W	-
0x8000	outbound_mailbox_8.WRITE_DATA	W	-
0x8008	outbound_mailbox_8.READ_DATA	R	-
0x8010	outbound_mailbox_8.STATUS	R	-
0x8018	outbound_mailbox_8.ERROR_FLAGS	R	-
0x8020	outbound_mailbox_8.WIRQT	RW	-
0x8028	outbound_mailbox_8.RIRQT	RW	-
0x8030	outbound_mailbox_8.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x8038	outbound_mailbox_8.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x8040	outbound_mailbox_8.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x8048	outbound_mailbox_8.CTRL	W	-
0x8800	inbound_mailbox_8.WRITE_DATA	W	-
0x8808	inbound_mailbox_8.READ_DATA	R	-
0x8810	inbound_mailbox_8.STATUS	R	-
0x8818	inbound_mailbox_8.ERROR_FLAGS	R	-
0x8820	inbound_mailbox_8.WIRQT	RW	-
0x8828	inbound_mailbox_8.RIRQT	RW	-
0x8830	inbound_mailbox_8.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x8838	inbound_mailbox_8.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x8840	inbound_mailbox_8.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x8848	inbound_mailbox_8.CTRL	W	-

Address	Name	Access	Description
0x9000	outbound_mailbox_9.WRITE_DATA	W	-
0x9008	outbound_mailbox_9.READ_DATA	R	-
0x9010	outbound_mailbox_9.STATUS	R	-
0x9018	outbound_mailbox_9.ERROR_FLAGS	R	-
0x9020	outbound_mailbox_9.WIRQT	RW	-
0x9028	outbound_mailbox_9.RIRQT	RW	-
0x9030	outbound_mailbox_9.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x9038	outbound_mailbox_9.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x9040	outbound_mailbox_9.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x9048	outbound_mailbox_9.CTRL	W	-
0x9800	inbound_mailbox_9.WRITE_DATA	W	-
0x9808	inbound_mailbox_9.READ_DATA	R	-
0x9810	inbound_mailbox_9.STATUS	R	-
0x9818	inbound_mailbox_9.ERROR_FLAGS	R	-
0x9820	inbound_mailbox_9.WIRQT	RW	-
0x9828	inbound_mailbox_9.RIRQT	RW	-
0x9830	inbound_mailbox_9.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x9838	inbound_mailbox_9.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x9840	inbound_mailbox_9.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x9848	inbound_mailbox_9.CTRL	W	-
0xA000	outbound_mailbox_10.WRITE_DATA	W	-
0xA008	outbound_mailbox_10.READ_DATA	R	-
0xA010	outbound_mailbox_10.STATUS	R	-
0xA018	outbound_mailbox_10.ERROR_FLAGS	R	-
0xA020	outbound_mailbox_10.WIRQT	RW	-
0xA028	outbound_mailbox_10.RIRQT	RW	-
0xA030	outbound_mailbox_10.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xA038	outbound_mailbox_10.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xA040	outbound_mailbox_10.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xA048	outbound_mailbox_10.CTRL	W	-
0xA800	inbound_mailbox_10.WRITE_DATA	W	-
0xA808	inbound_mailbox_10.READ_DATA	R	-
0xA810	inbound_mailbox_10.STATUS	R	-
0xA818	inbound_mailbox_10.ERROR_FLAGS	R	-
0xA820	inbound_mailbox_10.WIRQT	RW	-
0xA828	inbound_mailbox_10.RIRQT	RW	-

Address	Name	Access	Description
0xA830	inbound_mailbox_10.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xA838	inbound_mailbox_10.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xA840	inbound_mailbox_10.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xA848	inbound_mailbox_10.CTRL	W	-
0xB000	outbound_mailbox_11.WRITE_DATA	W	-
0xB008	outbound_mailbox_11.READ_DATA	R	-
0xB010	outbound_mailbox_11.STATUS	R	-
0xB018	outbound_mailbox_11.ERROR_FLAGS	R	-
0xB020	outbound_mailbox_11.WIRQT	RW	-
0xB028	outbound_mailbox_11.RIRQT	RW	-
0xB030	outbound_mailbox_11.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xB038	outbound_mailbox_11.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xB040	outbound_mailbox_11.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xB048	outbound_mailbox_11.CTRL	W	-
0xB800	inbound_mailbox_11.WRITE_DATA	W	-
0xB808	inbound_mailbox_11.READ_DATA	R	-
0xB810	inbound_mailbox_11.STATUS	R	-
0xB818	inbound_mailbox_11.ERROR_FLAGS	R	-
0xB820	inbound_mailbox_11.WIRQT	RW	-
0xB828	inbound_mailbox_11.RIRQT	RW	-
0xB830	inbound_mailbox_11.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xB838	inbound_mailbox_11.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xB840	inbound_mailbox_11.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xB848	inbound_mailbox_11.CTRL	W	-
0xC000	outbound_mailbox_12.WRITE_DATA	W	-
0xC008	outbound_mailbox_12.READ_DATA	R	-
0xC010	outbound_mailbox_12.STATUS	R	-
0xC018	outbound_mailbox_12.ERROR_FLAGS	R	-
0xC020	outbound_mailbox_12.WIRQT	RW	-
0xC028	outbound_mailbox_12.RIRQT	RW	-
0xC030	outbound_mailbox_12.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xC038	outbound_mailbox_12.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xC040	outbound_mailbox_12.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xC048	outbound_mailbox_12.CTRL	W	-

Address	Name	Access	Description
0xC800	inbound_mailbox_12.WRITE_DATA	W	-
0xC808	inbound_mailbox_12.READ_DATA	R	-
0xC810	inbound_mailbox_12.STATUS	R	-
0xC818	inbound_mailbox_12.ERROR_FLAGS	R	-
0xC820	inbound_mailbox_12.WIRQT	RW	-
0xC828	inbound_mailbox_12.RIRQT	RW	-
0xC830	inbound_mailbox_12.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xC838	inbound_mailbox_12.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xC840	inbound_mailbox_12.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xC848	inbound_mailbox_12.CTRL	W	-
0xD000	outbound_mailbox_13.WRITE_DATA	W	-
0xD008	outbound_mailbox_13.READ_DATA	R	-
0xD010	outbound_mailbox_13.STATUS	R	-
0xD018	outbound_mailbox_13.ERROR_FLAGS	R	-
0xD020	outbound_mailbox_13.WIRQT	RW	-
0xD028	outbound_mailbox_13.RIRQT	RW	-
0xD030	outbound_mailbox_13.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xD038	outbound_mailbox_13.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xD040	outbound_mailbox_13.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xD048	outbound_mailbox_13.CTRL	W	-
0xD800	inbound_mailbox_13.WRITE_DATA	W	-
0xD808	inbound_mailbox_13.READ_DATA	R	-
0xD810	inbound_mailbox_13.STATUS	R	-
0xD818	inbound_mailbox_13.ERROR_FLAGS	R	-
0xD820	inbound_mailbox_13.WIRQT	RW	-
0xD828	inbound_mailbox_13.RIRQT	RW	-
0xD830	inbound_mailbox_13.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xD838	inbound_mailbox_13.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xD840	inbound_mailbox_13.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xD848	inbound_mailbox_13.CTRL	W	-
0xE000	outbound_mailbox_14.WRITE_DATA	W	-
0xE008	outbound_mailbox_14.READ_DATA	R	-
0xE010	outbound_mailbox_14.STATUS	R	-
0xE018	outbound_mailbox_14.ERROR_FLAGS	R	-
0xE020	outbound_mailbox_14.WIRQT	RW	-
0xE028	outbound_mailbox_14.RIRQT	RW	-

Address	Name	Access	Description
0xE030	outbound_mailbox_14.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xE038	outbound_mailbox_14.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xE040	outbound_mailbox_14.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xE048	outbound_mailbox_14.CTRL	W	-
0xE800	inbound_mailbox_14.WRITE_DATA	W	-
0xE808	inbound_mailbox_14.READ_DATA	R	-
0xE810	inbound_mailbox_14.STATUS	R	-
0xE818	inbound_mailbox_14.ERROR_FLAGS	R	-
0xE820	inbound_mailbox_14.WIRQT	RW	-
0xE828	inbound_mailbox_14.RIRQT	RW	-
0xE830	inbound_mailbox_14.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xE838	inbound_mailbox_14.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xE840	inbound_mailbox_14.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xE848	inbound_mailbox_14.CTRL	W	-
0xF000	outbound_mailbox_15.WRITE_DATA	W	-
0xF008	outbound_mailbox_15.READ_DATA	R	-
0xF010	outbound_mailbox_15.STATUS	R	-
0xF018	outbound_mailbox_15.ERROR_FLAGS	R	-
0xF020	outbound_mailbox_15.WIRQT	RW	-
0xF028	outbound_mailbox_15.RIRQT	RW	-
0xF030	outbound_mailbox_15.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xF038	outbound_mailbox_15.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xF040	outbound_mailbox_15.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xF048	outbound_mailbox_15.CTRL	W	-
0xF800	inbound_mailbox_15.WRITE_DATA	W	-
0xF808	inbound_mailbox_15.READ_DATA	R	-
0xF810	inbound_mailbox_15.STATUS	R	-
0xF818	inbound_mailbox_15.ERROR_FLAGS	R	-
0xF820	inbound_mailbox_15.WIRQT	RW	-
0xF828	inbound_mailbox_15.RIRQT	RW	-
0xF830	inbound_mailbox_15.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0xF838	inbound_mailbox_15.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0xF840	inbound_mailbox_15.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0xF848	inbound_mailbox_15.CTRL	W	-

Address	Name	Access	Description
0x10000	outbound_mailbox_16.WRITE_DATA	W	-
0x10008	outbound_mailbox_16.READ_DATA	R	-
0x10010	outbound_mailbox_16.STATUS	R	-
0x10018	outbound_mailbox_16.ERROR_FLAGS	R	-
0x10020	outbound_mailbox_16.WIRQT	RW	-
0x10028	outbound_mailbox_16.RIRQT	RW	-
0x10030	outbound_mailbox_16.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x10038	outbound_mailbox_16.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x10040	outbound_mailbox_16.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x10048	outbound_mailbox_16.CTRL	W	-
0x10800	inbound_mailbox_16.WRITE_DATA	W	-
0x10808	inbound_mailbox_16.READ_DATA	R	-
0x10810	inbound_mailbox_16.STATUS	R	-
0x10818	inbound_mailbox_16.ERROR_FLAGS	R	-
0x10820	inbound_mailbox_16.WIRQT	RW	-
0x10828	inbound_mailbox_16.RIRQT	RW	-
0x10830	inbound_mailbox_16.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x10838	inbound_mailbox_16.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x10840	inbound_mailbox_16.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x10848	inbound_mailbox_16.CTRL	W	-
0x11000	outbound_mailbox_17.WRITE_DATA	W	-
0x11008	outbound_mailbox_17.READ_DATA	R	-
0x11010	outbound_mailbox_17.STATUS	R	-
0x11018	outbound_mailbox_17.ERROR_FLAGS	R	-
0x11020	outbound_mailbox_17.WIRQT	RW	-
0x11028	outbound_mailbox_17.RIRQT	RW	-
0x11030	outbound_mailbox_17.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x11038	outbound_mailbox_17.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x11040	outbound_mailbox_17.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x11048	outbound_mailbox_17.CTRL	W	-
0x11800	inbound_mailbox_17.WRITE_DATA	W	-
0x11808	inbound_mailbox_17.READ_DATA	R	-
0x11810	inbound_mailbox_17.STATUS	R	-
0x11818	inbound_mailbox_17.ERROR_FLAGS	R	-
0x11820	inbound_mailbox_17.WIRQT	RW	-
0x11828	inbound_mailbox_17.RIRQT	RW	-

Address	Name	Access	Description
0x11830	inbound_mailbox_17.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x11838	inbound_mailbox_17.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x11840	inbound_mailbox_17.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x11848	inbound_mailbox_17.CTRL	W	-
0x12000	outbound_mailbox_18.WRITE_DATA	W	-
0x12008	outbound_mailbox_18.READ_DATA	R	-
0x12010	outbound_mailbox_18.STATUS	R	-
0x12018	outbound_mailbox_18.ERROR_FLAGS	R	-
0x12020	outbound_mailbox_18.WIRQT	RW	-
0x12028	outbound_mailbox_18.RIRQT	RW	-
0x12030	outbound_mailbox_18.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x12038	outbound_mailbox_18.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x12040	outbound_mailbox_18.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x12048	outbound_mailbox_18.CTRL	W	-
0x12800	inbound_mailbox_18.WRITE_DATA	W	-
0x12808	inbound_mailbox_18.READ_DATA	R	-
0x12810	inbound_mailbox_18.STATUS	R	-
0x12818	inbound_mailbox_18.ERROR_FLAGS	R	-
0x12820	inbound_mailbox_18.WIRQT	RW	-
0x12828	inbound_mailbox_18.RIRQT	RW	-
0x12830	inbound_mailbox_18.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x12838	inbound_mailbox_18.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x12840	inbound_mailbox_18.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x12848	inbound_mailbox_18.CTRL	W	-
0x13000	outbound_mailbox_19.WRITE_DATA	W	-
0x13008	outbound_mailbox_19.READ_DATA	R	-
0x13010	outbound_mailbox_19.STATUS	R	-
0x13018	outbound_mailbox_19.ERROR_FLAGS	R	-
0x13020	outbound_mailbox_19.WIRQT	RW	-
0x13028	outbound_mailbox_19.RIRQT	RW	-
0x13030	outbound_mailbox_19.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x13038	outbound_mailbox_19.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x13040	outbound_mailbox_19.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x13048	outbound_mailbox_19.CTRL	W	-

Address	Name	Access	Description
0x13800	inbound_mailbox_19.WRITE_DATA	W	-
0x13808	inbound_mailbox_19.READ_DATA	R	-
0x13810	inbound_mailbox_19.STATUS	R	-
0x13818	inbound_mailbox_19.ERROR_FLAGS	R	-
0x13820	inbound_mailbox_19.WIRQT	RW	-
0x13828	inbound_mailbox_19.RIRQT	RW	-
0x13830	inbound_mailbox_19.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x13838	inbound_mailbox_19.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x13840	inbound_mailbox_19.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x13848	inbound_mailbox_19.CTRL	W	-
0x14000	outbound_mailbox_20.WRITE_DATA	W	-
0x14008	outbound_mailbox_20.READ_DATA	R	-
0x14010	outbound_mailbox_20.STATUS	R	-
0x14018	outbound_mailbox_20.ERROR_FLAGS	R	-
0x14020	outbound_mailbox_20.WIRQT	RW	-
0x14028	outbound_mailbox_20.RIRQT	RW	-
0x14030	outbound_mailbox_20.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x14038	outbound_mailbox_20.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x14040	outbound_mailbox_20.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x14048	outbound_mailbox_20.CTRL	W	-
0x14800	inbound_mailbox_20.WRITE_DATA	W	-
0x14808	inbound_mailbox_20.READ_DATA	R	-
0x14810	inbound_mailbox_20.STATUS	R	-
0x14818	inbound_mailbox_20.ERROR_FLAGS	R	-
0x14820	inbound_mailbox_20.WIRQT	RW	-
0x14828	inbound_mailbox_20.RIRQT	RW	-
0x14830	inbound_mailbox_20.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x14838	inbound_mailbox_20.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x14840	inbound_mailbox_20.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x14848	inbound_mailbox_20.CTRL	W	-
0x15000	outbound_mailbox_21.WRITE_DATA	W	-
0x15008	outbound_mailbox_21.READ_DATA	R	-
0x15010	outbound_mailbox_21.STATUS	R	-
0x15018	outbound_mailbox_21.ERROR_FLAGS	R	-
0x15020	outbound_mailbox_21.WIRQT	RW	-
0x15028	outbound_mailbox_21.RIRQT	RW	-

Address	Name	Access	Description
0x15030	outbound_mailbox_21.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x15038	outbound_mailbox_21.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x15040	outbound_mailbox_21.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x15048	outbound_mailbox_21.CTRL	W	-
0x15800	inbound_mailbox_21.WRITE_DATA	W	-
0x15808	inbound_mailbox_21.READ_DATA	R	-
0x15810	inbound_mailbox_21.STATUS	R	-
0x15818	inbound_mailbox_21.ERROR_FLAGS	R	-
0x15820	inbound_mailbox_21.WIRQT	RW	-
0x15828	inbound_mailbox_21.RIRQT	RW	-
0x15830	inbound_mailbox_21.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x15838	inbound_mailbox_21.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x15840	inbound_mailbox_21.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x15848	inbound_mailbox_21.CTRL	W	-
0x16000	outbound_mailbox_22.WRITE_DATA	W	-
0x16008	outbound_mailbox_22.READ_DATA	R	-
0x16010	outbound_mailbox_22.STATUS	R	-
0x16018	outbound_mailbox_22.ERROR_FLAGS	R	-
0x16020	outbound_mailbox_22.WIRQT	RW	-
0x16028	outbound_mailbox_22.RIRQT	RW	-
0x16030	outbound_mailbox_22.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x16038	outbound_mailbox_22.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x16040	outbound_mailbox_22.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x16048	outbound_mailbox_22.CTRL	W	-
0x16800	inbound_mailbox_22.WRITE_DATA	W	-
0x16808	inbound_mailbox_22.READ_DATA	R	-
0x16810	inbound_mailbox_22.STATUS	R	-
0x16818	inbound_mailbox_22.ERROR_FLAGS	R	-
0x16820	inbound_mailbox_22.WIRQT	RW	-
0x16828	inbound_mailbox_22.RIRQT	RW	-
0x16830	inbound_mailbox_22.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x16838	inbound_mailbox_22.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x16840	inbound_mailbox_22.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x16848	inbound_mailbox_22.CTRL	W	-

Address	Name	Access	Description
0x17000	outbound_mailbox_23.WRITE_DATA	W	-
0x17008	outbound_mailbox_23.READ_DATA	R	-
0x17010	outbound_mailbox_23.STATUS	R	-
0x17018	outbound_mailbox_23.ERROR_FLAGS	R	-
0x17020	outbound_mailbox_23.WIRQT	RW	-
0x17028	outbound_mailbox_23.RIRQT	RW	-
0x17030	outbound_mailbox_23.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x17038	outbound_mailbox_23.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x17040	outbound_mailbox_23.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x17048	outbound_mailbox_23.CTRL	W	-
0x17800	inbound_mailbox_23.WRITE_DATA	W	-
0x17808	inbound_mailbox_23.READ_DATA	R	-
0x17810	inbound_mailbox_23.STATUS	R	-
0x17818	inbound_mailbox_23.ERROR_FLAGS	R	-
0x17820	inbound_mailbox_23.WIRQT	RW	-
0x17828	inbound_mailbox_23.RIRQT	RW	-
0x17830	inbound_mailbox_23.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x17838	inbound_mailbox_23.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x17840	inbound_mailbox_23.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x17848	inbound_mailbox_23.CTRL	W	-
0x18000	outbound_mailbox_24.WRITE_DATA	W	-
0x18008	outbound_mailbox_24.READ_DATA	R	-
0x18010	outbound_mailbox_24.STATUS	R	-
0x18018	outbound_mailbox_24.ERROR_FLAGS	R	-
0x18020	outbound_mailbox_24.WIRQT	RW	-
0x18028	outbound_mailbox_24.RIRQT	RW	-
0x18030	outbound_mailbox_24.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x18038	outbound_mailbox_24.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x18040	outbound_mailbox_24.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x18048	outbound_mailbox_24.CTRL	W	-
0x18800	inbound_mailbox_24.WRITE_DATA	W	-
0x18808	inbound_mailbox_24.READ_DATA	R	-
0x18810	inbound_mailbox_24.STATUS	R	-
0x18818	inbound_mailbox_24.ERROR_FLAGS	R	-
0x18820	inbound_mailbox_24.WIRQT	RW	-
0x18828	inbound_mailbox_24.RIRQT	RW	-

Address	Name	Access	Description
0x18830	inbound_mailbox_24.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x18838	inbound_mailbox_24.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x18840	inbound_mailbox_24.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x18848	inbound_mailbox_24.CTRL	W	-
0x19000	outbound_mailbox_25.WRITE_DATA	W	-
0x19008	outbound_mailbox_25.READ_DATA	R	-
0x19010	outbound_mailbox_25.STATUS	R	-
0x19018	outbound_mailbox_25.ERROR_FLAGS	R	-
0x19020	outbound_mailbox_25.WIRQT	RW	-
0x19028	outbound_mailbox_25.RIRQT	RW	-
0x19030	outbound_mailbox_25.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x19038	outbound_mailbox_25.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x19040	outbound_mailbox_25.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x19048	outbound_mailbox_25.CTRL	W	-
0x19800	inbound_mailbox_25.WRITE_DATA	W	-
0x19808	inbound_mailbox_25.READ_DATA	R	-
0x19810	inbound_mailbox_25.STATUS	R	-
0x19818	inbound_mailbox_25.ERROR_FLAGS	R	-
0x19820	inbound_mailbox_25.WIRQT	RW	-
0x19828	inbound_mailbox_25.RIRQT	RW	-
0x19830	inbound_mailbox_25.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x19838	inbound_mailbox_25.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x19840	inbound_mailbox_25.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x19848	inbound_mailbox_25.CTRL	W	-
0x1A000	outbound_mailbox_26.WRITE_DATA	W	-
0x1A008	outbound_mailbox_26.READ_DATA	R	-
0x1A010	outbound_mailbox_26.STATUS	R	-
0x1A018	outbound_mailbox_26.ERROR_FLAGS	R	-
0x1A020	outbound_mailbox_26.WIRQT	RW	-
0x1A028	outbound_mailbox_26.RIRQT	RW	-
0x1A030	outbound_mailbox_26.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1A038	outbound_mailbox_26.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1A040	outbound_mailbox_26.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1A048	outbound_mailbox_26.CTRL	W	-

Address	Name	Access	Description
0x1A800	inbound_mailbox_26.WRITE_DATA	W	-
0x1A808	inbound_mailbox_26.READ_DATA	R	-
0x1A810	inbound_mailbox_26.STATUS	R	-
0x1A818	inbound_mailbox_26.ERROR_FLAGS	R	-
0x1A820	inbound_mailbox_26.WIRQT	RW	-
0x1A828	inbound_mailbox_26.RIRQT	RW	-
0x1A830	inbound_mailbox_26.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1A838	inbound_mailbox_26.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1A840	inbound_mailbox_26.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1A848	inbound_mailbox_26.CTRL	W	-
0x1B000	outbound_mailbox_27.WRITE_DATA	W	-
0x1B008	outbound_mailbox_27.READ_DATA	R	-
0x1B010	outbound_mailbox_27.STATUS	R	-
0x1B018	outbound_mailbox_27.ERROR_FLAGS	R	-
0x1B020	outbound_mailbox_27.WIRQT	RW	-
0x1B028	outbound_mailbox_27.RIRQT	RW	-
0x1B030	outbound_mailbox_27.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1B038	outbound_mailbox_27.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1B040	outbound_mailbox_27.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1B048	outbound_mailbox_27.CTRL	W	-
0x1B800	inbound_mailbox_27.WRITE_DATA	W	-
0x1B808	inbound_mailbox_27.READ_DATA	R	-
0x1B810	inbound_mailbox_27.STATUS	R	-
0x1B818	inbound_mailbox_27.ERROR_FLAGS	R	-
0x1B820	inbound_mailbox_27.WIRQT	RW	-
0x1B828	inbound_mailbox_27.RIRQT	RW	-
0x1B830	inbound_mailbox_27.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1B838	inbound_mailbox_27.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1B840	inbound_mailbox_27.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1B848	inbound_mailbox_27.CTRL	W	-
0x1C000	outbound_mailbox_28.WRITE_DATA	W	-
0x1C008	outbound_mailbox_28.READ_DATA	R	-
0x1C010	outbound_mailbox_28.STATUS	R	-
0x1C018	outbound_mailbox_28.ERROR_FLAGS	R	-
0x1C020	outbound_mailbox_28.WIRQT	RW	-
0x1C028	outbound_mailbox_28.RIRQT	RW	-

Address	Name	Access	Description
0x1C030	outbound_mailbox_28.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1C038	outbound_mailbox_28.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1C040	outbound_mailbox_28.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1C048	outbound_mailbox_28.CTRL	W	-
0x1C800	inbound_mailbox_28.WRITE_DATA	W	-
0x1C808	inbound_mailbox_28.READ_DATA	R	-
0x1C810	inbound_mailbox_28.STATUS	R	-
0x1C818	inbound_mailbox_28.ERROR_FLAGS	R	-
0x1C820	inbound_mailbox_28.WIRQT	RW	-
0x1C828	inbound_mailbox_28.RIRQT	RW	-
0x1C830	inbound_mailbox_28.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1C838	inbound_mailbox_28.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1C840	inbound_mailbox_28.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1C848	inbound_mailbox_28.CTRL	W	-
0x1D000	outbound_mailbox_29.WRITE_DATA	W	-
0x1D008	outbound_mailbox_29.READ_DATA	R	-
0x1D010	outbound_mailbox_29.STATUS	R	-
0x1D018	outbound_mailbox_29.ERROR_FLAGS	R	-
0x1D020	outbound_mailbox_29.WIRQT	RW	-
0x1D028	outbound_mailbox_29.RIRQT	RW	-
0x1D030	outbound_mailbox_29.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1D038	outbound_mailbox_29.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1D040	outbound_mailbox_29.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1D048	outbound_mailbox_29.CTRL	W	-
0x1D800	inbound_mailbox_29.WRITE_DATA	W	-
0x1D808	inbound_mailbox_29.READ_DATA	R	-
0x1D810	inbound_mailbox_29.STATUS	R	-
0x1D818	inbound_mailbox_29.ERROR_FLAGS	R	-
0x1D820	inbound_mailbox_29.WIRQT	RW	-
0x1D828	inbound_mailbox_29.RIRQT	RW	-
0x1D830	inbound_mailbox_29.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1D838	inbound_mailbox_29.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1D840	inbound_mailbox_29.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1D848	inbound_mailbox_29.CTRL	W	-

Address	Name	Access	Description
0x1E000	outbound_mailbox_30.WRITE_DATA	W	-
0x1E008	outbound_mailbox_30.READ_DATA	R	-
0x1E010	outbound_mailbox_30.STATUS	R	-
0x1E018	outbound_mailbox_30.ERROR_FLAGS	R	-
0x1E020	outbound_mailbox_30.WIRQT	RW	-
0x1E028	outbound_mailbox_30.RIRQT	RW	-
0x1E030	outbound_mailbox_30.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1E038	outbound_mailbox_30.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1E040	outbound_mailbox_30.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1E048	outbound_mailbox_30.CTRL	W	-
0x1E800	inbound_mailbox_30.WRITE_DATA	W	-
0x1E808	inbound_mailbox_30.READ_DATA	R	-
0x1E810	inbound_mailbox_30.STATUS	R	-
0x1E818	inbound_mailbox_30.ERROR_FLAGS	R	-
0x1E820	inbound_mailbox_30.WIRQT	RW	-
0x1E828	inbound_mailbox_30.RIRQT	RW	-
0x1E830	inbound_mailbox_30.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1E838	inbound_mailbox_30.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1E840	inbound_mailbox_30.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1E848	inbound_mailbox_30.CTRL	W	-
0x1F000	outbound_mailbox_31.WRITE_DATA	W	-
0x1F008	outbound_mailbox_31.READ_DATA	R	-
0x1F010	outbound_mailbox_31.STATUS	R	-
0x1F018	outbound_mailbox_31.ERROR_FLAGS	R	-
0x1F020	outbound_mailbox_31.WIRQT	RW	-
0x1F028	outbound_mailbox_31.RIRQT	RW	-
0x1F030	outbound_mailbox_31.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1F038	outbound_mailbox_31.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1F040	outbound_mailbox_31.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1F048	outbound_mailbox_31.CTRL	W	-
0x1F800	inbound_mailbox_31.WRITE_DATA	W	-
0x1F808	inbound_mailbox_31.READ_DATA	R	-
0x1F810	inbound_mailbox_31.STATUS	R	-
0x1F818	inbound_mailbox_31.ERROR_FLAGS	R	-
0x1F820	inbound_mailbox_31.WIRQT	RW	-
0x1F828	inbound_mailbox_31.RIRQT	RW	-

Address	Name	Access	Description
0x1F830	inbound_mailbox_31.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1F838	inbound_mailbox_31.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1F840	inbound_mailbox_31.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1F848	inbound_mailbox_31.CTRL	W	-

2.1.6.7.4.4.2.2.1.1. outbound_mailbox_0.WRITE_DATA

Table 1071. axil_mailbox_smc_wrap.outbound_mailbox_0.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.2. outbound_mailbox_0.READ_DATA

Table 1072. axil_mailbox_smc_wrap.outbound_mailbox_0.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.3. outbound_mailbox_0.STATUS

Table 1073. axil_mailbox_smc_wrap.outbound_mailbox_0.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.4. outbound_mailbox_0.ERROR_FLAGS

Table 1074. axil_mailbox_smc_wrap.outbound_mailbox_0.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.5. outbound_mailbox_0.WIRQT

Table 1075. axil_mailbox_smc_wrap.outbound_mailbox_0.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.6. outbound_mailbox_0.RIRQT

Table 1076. axil_mailbox_smc_wrap.outbound_mailbox_0.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.7. outbound_mailbox_0.IRQS

Table 1077. axil_mailbox_smc_wrap.outbound_mailbox_0.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.8. outbound_mailbox_0.IRQEN

Table 1078. axil_mailbox_smc_wrap.outbound_mailbox_0.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.9. outbound_mailbox_0.IRQP

Table 1079. axil_mailbox_smc_wrap.outbound_mailbox_0.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.10. outbound_mailbox_0.CTRL

Table 1080. axil_mailbox_smc_wrap.outbound_mailbox_0.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.11. inbound_mailbox_0.WRITE_DATA

Table 1081. axil_mailbox_smc_wrap.inbound_mailbox_0.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.12. inbound_mailbox_0.READ_DATA

Table 1082. axil_mailbox_smc_wrap.inbound_mailbox_0.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.13. inbound_mailbox_0.STATUS

Table 1083. axil_mailbox_smc_wrap.inbound_mailbox_0.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.14. inbound_mailbox_0.ERROR_FLAGS

Table 1084. axil_mailbox_smc_wrap.inbound_mailbox_0.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.15. inbound_mailbox_0.WIRQT

Table 1085. axil_mailbox_smc_wrap.inbound_mailbox_0.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.16. inbound_mailbox_0.RIRQT

Table 1086. axil_mailbox_smc_wrap.inbound_mailbox_0.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.17. inbound_mailbox_0.IRQS

Table 1087. axil_mailbox_smc_wrap.inbound_mailbox_0.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.18. inbound_mailbox_0.IRQEN

Table 1088. axil_mailbox_smc_wrap.inbound_mailbox_0.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.19. inbound_mailbox_0.IRQP

Table 1089. axil_mailbox_smc_wrap.inbound_mailbox_0.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.20. inbound_mailbox_0.CTRL

Table 1090. axil_mailbox_smc_wrap.inbound_mailbox_0.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.21. outbound_mailbox_1.WRITE_DATA

Table 1091. axil_mailbox_smc_wrap.outbound_mailbox_1.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.22. outbound_mailbox_1.READ_DATA

Table 1092. axil_mailbox_smc_wrap.outbound_mailbox_1.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.23. outbound_mailbox_1.STATUS

Table 1093. axil_mailbox_smc_wrap.outbound_mailbox_1.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.24. outbound_mailbox_1.ERROR_FLAGS

Table 1094. axil_mailbox_smc_wrap.outbound_mailbox_1.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.25. outbound_mailbox_1.WIRQT

Table 1095. axil_mailbox_smc_wrap.outbound_mailbox_1.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.26. outbound_mailbox_1.RIRQT

Table 1096. axil_mailbox_smc_wrap.outbound_mailbox_1.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.27. outbound_mailbox_1.IRQS

Table 1097. axil_mailbox_smc_wrap.outbound_mailbox_1.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.28. outbound_mailbox_1.IRQEN

Table 1098. axil_mailbox_smc_wrap.outbound_mailbox_1.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.29. outbound_mailbox_1.IRQP

Table 1099. axil_mailbox_smc_wrap.outbound_mailbox_1.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.30. outbound_mailbox_1.CTRL

Table 1100. axil_mailbox_smc_wrap.outbound_mailbox_1.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.31. inbound_mailbox_1.WRITE_DATA

Table 1101. axil_mailbox_smc_wrap.inbound_mailbox_1.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.32. inbound_mailbox_1.READ_DATA

Table 1102. axil_mailbox_smc_wrap.inbound_mailbox_1.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.33. inbound_mailbox_1.STATUS

Table 1103. axil_mailbox_smc_wrap.inbound_mailbox_1.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.34. inbound_mailbox_1.ERROR_FLAGS

Table 1104. axil_mailbox_smc_wrap.inbound_mailbox_1.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.35. inbound_mailbox_1.WIRQT

Table 1105. axil_mailbox_smc_wrap.inbound_mailbox_1.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.36. inbound_mailbox_1.RIRQT

Table 1106. axil_mailbox_smc_wrap.inbound_mailbox_1.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.37. inbound_mailbox_1.IRQS

Table 1107. axil_mailbox_smc_wrap.inbound_mailbox_1.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.38. inbound_mailbox_1.IRQEN

Table 1108. axil_mailbox_smc_wrap.inbound_mailbox_1.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.39. inbound_mailbox_1.IRQP

Table 1109. axil_mailbox_smc_wrap.inbound_mailbox_1.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.40. inbound_mailbox_1.CTRL

Table 1110. axil_mailbox_smc_wrap.inbound_mailbox_1.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.41. outbound_mailbox_2.WRITE_DATA

Table 1111. axil_mailbox_smc_wrap.outbound_mailbox_2.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.42. outbound_mailbox_2.READ_DATA

Table 1112. axil_mailbox_smc_wrap.outbound_mailbox_2.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.43. outbound_mailbox_2.STATUS

Table 1113. axil_mailbox_smc_wrap.outbound_mailbox_2.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.44. outbound_mailbox_2.ERROR_FLAGS

Table 1114. axil_mailbox_smc_wrap.outbound_mailbox_2.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.45. outbound_mailbox_2.WIRQT

Table 1115. axil_mailbox_smc_wrap.outbound_mailbox_2.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.46. outbound_mailbox_2.RIRQT

Table 1116. axil_mailbox_smc_wrap.outbound_mailbox_2.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.47. outbound_mailbox_2.IRQS

Table 1117. axil_mailbox_smc_wrap.outbound_mailbox_2.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.48. outbound_mailbox_2.IRQEN

Table 1118. axil_mailbox_smc_wrap.outbound_mailbox_2.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.49. outbound_mailbox_2.IRQP

Table 1119. axil_mailbox_smc_wrap.outbound_mailbox_2.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.50. outbound_mailbox_2.CTRL

Table 1120. axil_mailbox_smc_wrap.outbound_mailbox_2.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.51. inbound_mailbox_2.WRITE_DATA

Table 1121. axil_mailbox_smc_wrap.inbound_mailbox_2.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.52. inbound_mailbox_2.READ_DATA

Table 1122. axil_mailbox_smc_wrap.inbound_mailbox_2.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.53. inbound_mailbox_2.STATUS

Table 1123. axil_mailbox_smc_wrap.inbound_mailbox_2.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.54. inbound_mailbox_2.ERROR_FLAGS

Table 1124. axil_mailbox_smc_wrap.inbound_mailbox_2.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.55. inbound_mailbox_2.WIRQT

Table 1125. axil_mailbox_smc_wrap.inbound_mailbox_2.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.56. inbound_mailbox_2.RIRQT

Table 1126. axil_mailbox_smc_wrap.inbound_mailbox_2.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.57. inbound_mailbox_2.IRQS

Table 1127. axil_mailbox_smc_wrap.inbound_mailbox_2.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.58. inbound_mailbox_2.IRQEN

Table 1128. axil_mailbox_smc_wrap.inbound_mailbox_2.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.59. inbound_mailbox_2.IRQP

Table 1129. axil_mailbox_smc_wrap.inbound_mailbox_2.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.60. inbound_mailbox_2.CTRL

Table 1130. axil_mailbox_smc_wrap.inbound_mailbox_2.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.61. outbound_mailbox_3.WRITE_DATA

Table 1131. axil_mailbox_smc_wrap.outbound_mailbox_3.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.62. outbound_mailbox_3.READ_DATA

Table 1132. axil_mailbox_smc_wrap.outbound_mailbox_3.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.63. outbound_mailbox_3.STATUS

Table 1133. axil_mailbox_smc_wrap.outbound_mailbox_3.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.64. outbound_mailbox_3.ERROR_FLAGS

Table 1134. axil_mailbox_smc_wrap.outbound_mailbox_3.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.65. outbound_mailbox_3.WIRQT

Table 1135. axil_mailbox_smc_wrap.outbound_mailbox_3.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.66. outbound_mailbox_3.RIRQT

Table 1136. axil_mailbox_smc_wrap.outbound_mailbox_3.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.67. outbound_mailbox_3.IRQS

Table 1137. axil_mailbox_smc_wrap.outbound_mailbox_3.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.68. outbound_mailbox_3.IRQEN

Table 1138. axil_mailbox_smc_wrap.outbound_mailbox_3.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.69. outbound_mailbox_3.IRQP

Table 1139. axil_mailbox_smc_wrap.outbound_mailbox_3.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.70. outbound_mailbox_3.CTRL

Table 1140. axil_mailbox_smc_wrap.outbound_mailbox_3.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.71. inbound_mailbox_3.WRITE_DATA

Table 1141. axil_mailbox_smc_wrap.inbound_mailbox_3.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.72. inbound_mailbox_3.READ_DATA

Table 1142. axil_mailbox_smc_wrap.inbound_mailbox_3.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.73. inbound_mailbox_3.STATUS

Table 1143. axil_mailbox_smc_wrap.inbound_mailbox_3.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.74. inbound_mailbox_3.ERROR_FLAGS

Table 1144. axil_mailbox_smc_wrap.inbound_mailbox_3.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.75. inbound_mailbox_3.WIRQT

Table 1145. axil_mailbox_smc_wrap.inbound_mailbox_3.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.76. inbound_mailbox_3.RIRQT

Table 1146. axil_mailbox_smc_wrap.inbound_mailbox_3.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.77. inbound_mailbox_3.IRQS

Table 1147. axil_mailbox_smc_wrap.inbound_mailbox_3.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.78. inbound_mailbox_3.IRQEN

Table 1148. axil_mailbox_smc_wrap.inbound_mailbox_3.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.79. inbound_mailbox_3.IRQP

Table 1149. axil_mailbox_smc_wrap.inbound_mailbox_3.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.80. inbound_mailbox_3.CTRL

Table 1150. axil_mailbox_smc_wrap.inbound_mailbox_3.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.81. outbound_mailbox_4.WRITE_DATA

Table 1151. axil_mailbox_smc_wrap.outbound_mailbox_4.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.82. outbound_mailbox_4.READ_DATA

Table 1152. axil_mailbox_smc_wrap.outbound_mailbox_4.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.83. outbound_mailbox_4.STATUS

Table 1153. axil_mailbox_smc_wrap.outbound_mailbox_4.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.84. outbound_mailbox_4.ERROR_FLAGS

Table 1154. axil_mailbox_smc_wrap.outbound_mailbox_4.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.85. outbound_mailbox_4.WIRQT

Table 1155. axil_mailbox_smc_wrap.outbound_mailbox_4.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.86. outbound_mailbox_4.RIRQT

Table 1156. axil_mailbox_smc_wrap.outbound_mailbox_4.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.87. outbound_mailbox_4.IRQS

Table 1157. axil_mailbox_smc_wrap.outbound_mailbox_4.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.88. outbound_mailbox_4.IRQEN

Table 1158. axil_mailbox_smc_wrap.outbound_mailbox_4.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.89. outbound_mailbox_4.IRQP

Table 1159. axil_mailbox_smc_wrap.outbound_mailbox_4.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.90. outbound_mailbox_4.CTRL

Table 1160. axil_mailbox_smc_wrap.outbound_mailbox_4.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.91. inbound_mailbox_4.WRITE_DATA

Table 1161. axil_mailbox_smc_wrap.inbound_mailbox_4.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.92. inbound_mailbox_4.READ_DATA

Table 1162. axil_mailbox_smc_wrap.inbound_mailbox_4.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.93. inbound_mailbox_4.STATUS

Table 1163. axil_mailbox_smc_wrap.inbound_mailbox_4.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.94. inbound_mailbox_4.ERROR_FLAGS

Table 1164. axil_mailbox_smc_wrap.inbound_mailbox_4.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.95. inbound_mailbox_4.WIRQT

Table 1165. axil_mailbox_smc_wrap.inbound_mailbox_4.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.96. inbound_mailbox_4.RIRQT

Table 1166. axil_mailbox_smc_wrap.inbound_mailbox_4.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.97. inbound_mailbox_4.IRQS

Table 1167. axil_mailbox_smc_wrap.inbound_mailbox_4.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.98. inbound_mailbox_4.IRQEN

Table 1168. axil_mailbox_smc_wrap.inbound_mailbox_4.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.99. inbound_mailbox_4.IRQP

Table 1169. axil_mailbox_smc_wrap.inbound_mailbox_4.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.100. inbound_mailbox_4.CTRL

Table 1170. axil_mailbox_smc_wrap.inbound_mailbox_4.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.101. outbound_mailbox_5.WRITE_DATA

Table 1171. axil_mailbox_smc_wrap.outbound_mailbox_5.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.102. outbound_mailbox_5.READ_DATA

Table 1172. axil_mailbox_smc_wrap.outbound_mailbox_5.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.103. outbound_mailbox_5.STATUS

Table 1173. axil_mailbox_smc_wrap.outbound_mailbox_5.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.104. outbound_mailbox_5.ERROR_FLAGS

Table 1174. axil_mailbox_smc_wrap.outbound_mailbox_5.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.105. outbound_mailbox_5.WIRQT

Table 1175. axil_mailbox_smc_wrap.outbound_mailbox_5.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.106. outbound_mailbox_5.RIRQT

Table 1176. axil_mailbox_smc_wrap.outbound_mailbox_5.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.107. outbound_mailbox_5.IRQS

Table 1177. axil_mailbox_smc_wrap.outbound_mailbox_5.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.108. outbound_mailbox_5.IRQEN

Table 1178. axil_mailbox_smc_wrap.outbound_mailbox_5.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.109. outbound_mailbox_5.IRQP

Table 1179. axil_mailbox_smc_wrap.outbound_mailbox_5.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.110. outbound_mailbox_5.CTRL

Table 1180. axil_mailbox_smc_wrap.outbound_mailbox_5.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.111. inbound_mailbox_5.WRITE_DATA

Table 1181. axil_mailbox_smc_wrap.inbound_mailbox_5.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.112. inbound_mailbox_5.READ_DATA

Table 1182. axil_mailbox_smc_wrap.inbound_mailbox_5.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.113. inbound_mailbox_5.STATUS

Table 1183. axil_mailbox_smc_wrap.inbound_mailbox_5.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.114. inbound_mailbox_5.ERROR_FLAGS

Table 1184. axil_mailbox_smc_wrap.inbound_mailbox_5.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.115. inbound_mailbox_5.WIRQT

Table 1185. axil_mailbox_smc_wrap.inbound_mailbox_5.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.116. inbound_mailbox_5.RIRQT

Table 1186. axil_mailbox_smc_wrap.inbound_mailbox_5.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.117. inbound_mailbox_5.IRQS

Table 1187. axil_mailbox_smc_wrap.inbound_mailbox_5.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.118. inbound_mailbox_5.IRQEN

Table 1188. axil_mailbox_smc_wrap.inbound_mailbox_5.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.119. inbound_mailbox_5.IRQP

Table 1189. axil_mailbox_smc_wrap.inbound_mailbox_5.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.120. inbound_mailbox_5.CTRL

Table 1190. axil_mailbox_smc_wrap.inbound_mailbox_5.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.121. outbound_mailbox_6.WRITE_DATA

Table 1191. axil_mailbox_smc_wrap.outbound_mailbox_6.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.122. outbound_mailbox_6.READ_DATA

Table 1192. axil_mailbox_smc_wrap.outbound_mailbox_6.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.123. outbound_mailbox_6.STATUS

Table 1193. axil_mailbox_smc_wrap.outbound_mailbox_6.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.124. outbound_mailbox_6.ERROR_FLAGS

Table 1194. axil_mailbox_smc_wrap.outbound_mailbox_6.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.125. outbound_mailbox_6.WIRQT

Table 1195. axil_mailbox_smc_wrap.outbound_mailbox_6.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.126. outbound_mailbox_6.RIRQT

Table 1196. axil_mailbox_smc_wrap.outbound_mailbox_6.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.127. outbound_mailbox_6.IRQS

Table 1197. axil_mailbox_smc_wrap.outbound_mailbox_6.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.128. outbound_mailbox_6.IRQEN

Table 1198. axil_mailbox_smc_wrap.outbound_mailbox_6.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.129. outbound_mailbox_6.IRQP

Table 1199. axil_mailbox_smc_wrap.outbound_mailbox_6.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.130. outbound_mailbox_6.CTRL

Table 1200. axil_mailbox_smc_wrap.outbound_mailbox_6.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.131. inbound_mailbox_6.WRITE_DATA

Table 1201. axil_mailbox_smc_wrap.inbound_mailbox_6.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.132. inbound_mailbox_6.READ_DATA

Table 1202. axil_mailbox_smc_wrap.inbound_mailbox_6.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.133. inbound_mailbox_6.STATUS

Table 1203. axil_mailbox_smc_wrap.inbound_mailbox_6.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.134. inbound_mailbox_6.ERROR_FLAGS

Table 1204. axil_mailbox_smc_wrap.inbound_mailbox_6.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.135. inbound_mailbox_6.WIRQT

Table 1205. axil_mailbox_smc_wrap.inbound_mailbox_6.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.136. inbound_mailbox_6.RIRQT

Table 1206. axil_mailbox_smc_wrap.inbound_mailbox_6.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.137. inbound_mailbox_6.IRQS

Table 1207. axil_mailbox_smc_wrap.inbound_mailbox_6.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.138. inbound_mailbox_6.IRQEN

Table 1208. axil_mailbox_smc_wrap.inbound_mailbox_6.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.139. inbound_mailbox_6.IRQP

Table 1209. axil_mailbox_smc_wrap.inbound_mailbox_6.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.140. inbound_mailbox_6.CTRL

Table 1210. axil_mailbox_smc_wrap.inbound_mailbox_6.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.141. outbound_mailbox_7.WRITE_DATA

Table 1211. axil_mailbox_smc_wrap.outbound_mailbox_7.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.142. outbound_mailbox_7.READ_DATA

Table 1212. axil_mailbox_smc_wrap.outbound_mailbox_7.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.143. outbound_mailbox_7.STATUS

Table 1213. axil_mailbox_smc_wrap.outbound_mailbox_7.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.144. outbound_mailbox_7.ERROR_FLAGS

Table 1214. axil_mailbox_smc_wrap.outbound_mailbox_7.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.145. outbound_mailbox_7.WIRQT

Table 1215. axil_mailbox_smc_wrap.outbound_mailbox_7.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.146. outbound_mailbox_7.RIRQT

Table 1216. axil_mailbox_smc_wrap.outbound_mailbox_7.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.147. outbound_mailbox_7.IRQS

Table 1217. axil_mailbox_smc_wrap.outbound_mailbox_7.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.148. outbound_mailbox_7.IRQEN

Table 1218. axil_mailbox_smc_wrap.outbound_mailbox_7.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.149. outbound_mailbox_7.IRQP

Table 1219. axil_mailbox_smc_wrap.outbound_mailbox_7.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.150. outbound_mailbox_7.CTRL

Table 1220. axil_mailbox_smc_wrap.outbound_mailbox_7.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.151. inbound_mailbox_7.WRITE_DATA

Table 1221. axil_mailbox_smc_wrap.inbound_mailbox_7.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.152. inbound_mailbox_7.READ_DATA

Table 1222. axil_mailbox_smc_wrap.inbound_mailbox_7.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.153. inbound_mailbox_7.STATUS

Table 1223. axil_mailbox_smc_wrap.inbound_mailbox_7.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.154. inbound_mailbox_7.ERROR_FLAGS

Table 1224. axil_mailbox_smc_wrap.inbound_mailbox_7.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.155. inbound_mailbox_7.WIRQT

Table 1225. axil_mailbox_smc_wrap.inbound_mailbox_7.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.156. inbound_mailbox_7.RIRQT

Table 1226. axil_mailbox_smc_wrap.inbound_mailbox_7.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.157. inbound_mailbox_7.IRQS

Table 1227. axil_mailbox_smc_wrap.inbound_mailbox_7.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.158. inbound_mailbox_7.IRQEN

Table 1228. axil_mailbox_smc_wrap.inbound_mailbox_7.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.159. inbound_mailbox_7.IRQP

Table 1229. axil_mailbox_smc_wrap.inbound_mailbox_7.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.160. inbound_mailbox_7.CTRL

Table 1230. axil_mailbox_smc_wrap.inbound_mailbox_7.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.161. outbound_mailbox_8.WRITE_DATA

Table 1231. axil_mailbox_smc_wrap.outbound_mailbox_8.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.162. outbound_mailbox_8.READ_DATA

Table 1232. axil_mailbox_smc_wrap.outbound_mailbox_8.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.163. outbound_mailbox_8.STATUS

Table 1233. axil_mailbox_smc_wrap.outbound_mailbox_8.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.164. outbound_mailbox_8.ERROR_FLAGS

Table 1234. axil_mailbox_smc_wrap.outbound_mailbox_8.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.165. outbound_mailbox_8.WIRQT

Table 1235. axil_mailbox_smc_wrap.outbound_mailbox_8.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.166. outbound_mailbox_8.RIRQT

Table 1236. axil_mailbox_smc_wrap.outbound_mailbox_8.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.167. outbound_mailbox_8.IRQS

Table 1237. axil_mailbox_smc_wrap.outbound_mailbox_8.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.168. outbound_mailbox_8.IRQEN

Table 1238. axil_mailbox_smc_wrap.outbound_mailbox_8.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.169. outbound_mailbox_8.IRQP

Table 1239. axil_mailbox_smc_wrap.outbound_mailbox_8.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.170. outbound_mailbox_8.CTRL

Table 1240. axil_mailbox_smc_wrap.outbound_mailbox_8.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.171. inbound_mailbox_8.WRITE_DATA

Table 1241. axil_mailbox_smc_wrap.inbound_mailbox_8.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.172. inbound_mailbox_8.READ_DATA

Table 1242. axil_mailbox_smc_wrap.inbound_mailbox_8.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.173. inbound_mailbox_8.STATUS

Table 1243. axil_mailbox_smc_wrap.inbound_mailbox_8.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.174. inbound_mailbox_8.ERROR_FLAGS

Table 1244. axil_mailbox_smc_wrap.inbound_mailbox_8.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.175. inbound_mailbox_8.WIRQT

Table 1245. axil_mailbox_smc_wrap.inbound_mailbox_8.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.176. inbound_mailbox_8.RIRQT

Table 1246. axil_mailbox_smc_wrap.inbound_mailbox_8.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.177. inbound_mailbox_8.IRQS

Table 1247. axil_mailbox_smc_wrap.inbound_mailbox_8.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.178. inbound_mailbox_8.IRQEN

Table 1248. axil_mailbox_smc_wrap.inbound_mailbox_8.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.179. inbound_mailbox_8.IRQP

Table 1249. axil_mailbox_smc_wrap.inbound_mailbox_8.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.180. inbound_mailbox_8.CTRL

Table 1250. axil_mailbox_smc_wrap.inbound_mailbox_8.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.181. outbound_mailbox_9.WRITE_DATA

Table 1251. axil_mailbox_smc_wrap.outbound_mailbox_9.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.182. outbound_mailbox_9.READ_DATA

Table 1252. axil_mailbox_smc_wrap.outbound_mailbox_9.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.183. outbound_mailbox_9.STATUS

Table 1253. axil_mailbox_smc_wrap.outbound_mailbox_9.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.184. outbound_mailbox_9.ERROR_FLAGS

Table 1254. axil_mailbox_smc_wrap.outbound_mailbox_9.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.185. outbound_mailbox_9.WIRQT

Table 1255. axil_mailbox_smc_wrap.outbound_mailbox_9.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.186. outbound_mailbox_9.RIRQT

Table 1256. axil_mailbox_smc_wrap.outbound_mailbox_9.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.187. outbound_mailbox_9.IRQS

Table 1257. axil_mailbox_smc_wrap.outbound_mailbox_9.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.188. outbound_mailbox_9.IRQEN

Table 1258. axil_mailbox_smc_wrap.outbound_mailbox_9.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.189. outbound_mailbox_9.IRQP

Table 1259. axil_mailbox_smc_wrap.outbound_mailbox_9.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.190. outbound_mailbox_9.CTRL

Table 1260. axil_mailbox_smc_wrap.outbound_mailbox_9.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.191. inbound_mailbox_9.WRITE_DATA

Table 1261. axil_mailbox_smc_wrap.inbound_mailbox_9.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.192. inbound_mailbox_9.READ_DATA

Table 1262. axil_mailbox_smc_wrap.inbound_mailbox_9.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.193. inbound_mailbox_9.STATUS

Table 1263. axil_mailbox_smc_wrap.inbound_mailbox_9.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.194. inbound_mailbox_9.ERROR_FLAGS

Table 1264. axil_mailbox_smc_wrap.inbound_mailbox_9.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.195. inbound_mailbox_9.WIRQT

Table 1265. axil_mailbox_smc_wrap.inbound_mailbox_9.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.196. inbound_mailbox_9.RIRQT

Table 1266. axil_mailbox_smc_wrap.inbound_mailbox_9.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.197. inbound_mailbox_9.IRQS

Table 1267. axil_mailbox_smc_wrap.inbound_mailbox_9.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.198. inbound_mailbox_9.IRQEN

Table 1268. axil_mailbox_smc_wrap.inbound_mailbox_9.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.199. inbound_mailbox_9.IRQP

Table 1269. axil_mailbox_smc_wrap.inbound_mailbox_9.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.200. inbound_mailbox_9.CTRL

Table 1270. axil_mailbox_smc_wrap.inbound_mailbox_9.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.201. outbound_mailbox_10.WRITE_DATA

Table 1271. axil_mailbox_smc_wrap.outbound_mailbox_10.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.202. outbound_mailbox_10.READ_DATA

Table 1272. axil_mailbox_smc_wrap.outbound_mailbox_10.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.203. outbound_mailbox_10.STATUS

Table 1273. axil_mailbox_smc_wrap.outbound_mailbox_10.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.204. outbound_mailbox_10.ERROR_FLAGS

Table 1274. axil_mailbox_smc_wrap.outbound_mailbox_10.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.205. outbound_mailbox_10.WIRQT

Table 1275. axil_mailbox_smc_wrap.outbound_mailbox_10.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.206. outbound_mailbox_10.RIRQT

Table 1276. axil_mailbox_smc_wrap.outbound_mailbox_10.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.207. outbound_mailbox_10.IRQS

Table 1277. axil_mailbox_smc_wrap.outbound_mailbox_10.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.208. outbound_mailbox_10.IRQEN

Table 1278. axil_mailbox_smc_wrap.outbound_mailbox_10.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.209. outbound_mailbox_10.IRQP

Table 1279. axil_mailbox_smc_wrap.outbound_mailbox_10.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.210. outbound_mailbox_10.CTRL

Table 1280. axil_mailbox_smc_wrap.outbound_mailbox_10.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.211. inbound_mailbox_10.WRITE_DATA

Table 1281. axil_mailbox_smc_wrap.inbound_mailbox_10.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.212. inbound_mailbox_10.READ_DATA

Table 1282. axil_mailbox_smc_wrap.inbound_mailbox_10.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.213. inbound_mailbox_10.STATUS

Table 1283. axil_mailbox_smc_wrap.inbound_mailbox_10.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.214. inbound_mailbox_10.ERROR_FLAGS

Table 1284. axil_mailbox_smc_wrap.inbound_mailbox_10.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.215. inbound_mailbox_10.WIRQT

Table 1285. axil_mailbox_smc_wrap.inbound_mailbox_10.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.216. inbound_mailbox_10.RIRQT

Table 1286. axil_mailbox_smc_wrap.inbound_mailbox_10.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.217. inbound_mailbox_10.IRQS

Table 1287. axil_mailbox_smc_wrap.inbound_mailbox_10.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.218. inbound_mailbox_10.IRQEN

Table 1288. axil_mailbox_smc_wrap.inbound_mailbox_10.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.219. inbound_mailbox_10.IRQP

Table 1289. axil_mailbox_smc_wrap.inbound_mailbox_10.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.220. inbound_mailbox_10.CTRL

Table 1290. axil_mailbox_smc_wrap.inbound_mailbox_10.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.221. outbound_mailbox_11.WRITE_DATA

Table 1291. axil_mailbox_smc_wrap.outbound_mailbox_11.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.222. outbound_mailbox_11.READ_DATA

Table 1292. axil_mailbox_smc_wrap.outbound_mailbox_11.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.223. outbound_mailbox_11.STATUS

Table 1293. axil_mailbox_smc_wrap.outbound_mailbox_11.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.224. outbound_mailbox_11.ERROR_FLAGS

Table 1294. axil_mailbox_smc_wrap.outbound_mailbox_11.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.225. outbound_mailbox_11.WIRQT

Table 1295. axil_mailbox_smc_wrap.outbound_mailbox_11.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.226. outbound_mailbox_11.RIRQT

Table 1296. axil_mailbox_smc_wrap.outbound_mailbox_11.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.227. outbound_mailbox_11.IRQS

Table 1297. axil_mailbox_smc_wrap.outbound_mailbox_11.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.228. outbound_mailbox_11.IRQEN

Table 1298. axil_mailbox_smc_wrap.outbound_mailbox_11.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.229. outbound_mailbox_11.IRQP

Table 1299. axil_mailbox_smc_wrap.outbound_mailbox_11.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.230. outbound_mailbox_11.CTRL

Table 1300. axil_mailbox_smc_wrap.outbound_mailbox_11.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.231. inbound_mailbox_11.WRITE_DATA

Table 1301. axil_mailbox_smc_wrap.inbound_mailbox_11.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.232. inbound_mailbox_11.READ_DATA

Table 1302. axil_mailbox_smc_wrap.inbound_mailbox_11.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.233. inbound_mailbox_11.STATUS

Table 1303. axil_mailbox_smc_wrap.inbound_mailbox_11.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.234. inbound_mailbox_11.ERROR_FLAGS

Table 1304. axil_mailbox_smc_wrap.inbound_mailbox_11.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.235. inbound_mailbox_11.WIRQT

Table 1305. axil_mailbox_smc_wrap.inbound_mailbox_11.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.236. inbound_mailbox_11.RIRQT

Table 1306. axil_mailbox_smc_wrap.inbound_mailbox_11.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.237. inbound_mailbox_11.IRQS

Table 1307. axil_mailbox_smc_wrap.inbound_mailbox_11.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.238. inbound_mailbox_11.IRQEN

Table 1308. axil_mailbox_smc_wrap.inbound_mailbox_11.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.239. inbound_mailbox_11.IRQP

Table 1309. axil_mailbox_smc_wrap.inbound_mailbox_11.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.240. inbound_mailbox_11.CTRL

Table 1310. axil_mailbox_smc_wrap.inbound_mailbox_11.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.241. outbound_mailbox_12.WRITE_DATA

Table 1311. axil_mailbox_smc_wrap.outbound_mailbox_12.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.242. outbound_mailbox_12.READ_DATA

Table 1312. axil_mailbox_smc_wrap.outbound_mailbox_12.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.243. outbound_mailbox_12.STATUS

Table 1313. axil_mailbox_smc_wrap.outbound_mailbox_12.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.244. outbound_mailbox_12.ERROR_FLAGS

Table 1314. axil_mailbox_smc_wrap.outbound_mailbox_12.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.245. outbound_mailbox_12.WIRQT

Table 1315. axil_mailbox_smc_wrap.outbound_mailbox_12.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.246. outbound_mailbox_12.RIRQT

Table 1316. axil_mailbox_smc_wrap.outbound_mailbox_12.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.247. outbound_mailbox_12.IRQS

Table 1317. axil_mailbox_smc_wrap.outbound_mailbox_12.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.248. outbound_mailbox_12.IRQEN

Table 1318. axil_mailbox_smc_wrap.outbound_mailbox_12.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.249. outbound_mailbox_12.IRQP

Table 1319. axil_mailbox_smc_wrap.outbound_mailbox_12.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.250. outbound_mailbox_12.CTRL

Table 1320. axil_mailbox_smc_wrap.outbound_mailbox_12.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.251. inbound_mailbox_12.WRITE_DATA

Table 1321. axil_mailbox_smc_wrap.inbound_mailbox_12.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.252. inbound_mailbox_12.READ_DATA

Table 1322. axil_mailbox_smc_wrap.inbound_mailbox_12.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.253. inbound_mailbox_12.STATUS

Table 1323. axil_mailbox_smc_wrap.inbound_mailbox_12.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.254. inbound_mailbox_12.ERROR_FLAGS

Table 1324. axil_mailbox_smc_wrap.inbound_mailbox_12.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.255. inbound_mailbox_12.WIRQT

Table 1325. axil_mailbox_smc_wrap.inbound_mailbox_12.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.256. inbound_mailbox_12.RIRQT

Table 1326. axil_mailbox_smc_wrap.inbound_mailbox_12.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.257. inbound_mailbox_12.IRQS

Table 1327. axil_mailbox_smc_wrap.inbound_mailbox_12.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.258. inbound_mailbox_12.IRQEN

Table 1328. axil_mailbox_smc_wrap.inbound_mailbox_12.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.259. inbound_mailbox_12.IRQP

Table 1329. axil_mailbox_smc_wrap.inbound_mailbox_12.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.260. inbound_mailbox_12.CTRL

Table 1330. axil_mailbox_smc_wrap.inbound_mailbox_12.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.261. outbound_mailbox_13.WRITE_DATA

Table 1331. axil_mailbox_smc_wrap.outbound_mailbox_13.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.262. outbound_mailbox_13.READ_DATA

Table 1332. axil_mailbox_smc_wrap.outbound_mailbox_13.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.263. outbound_mailbox_13.STATUS

Table 1333. axil_mailbox_smc_wrap.outbound_mailbox_13.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.264. outbound_mailbox_13.ERROR_FLAGS

Table 1334. axil_mailbox_smc_wrap.outbound_mailbox_13.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.265. outbound_mailbox_13.WIRQT

Table 1335. axil_mailbox_smc_wrap.outbound_mailbox_13.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.266. outbound_mailbox_13.RIRQT

Table 1336. axil_mailbox_smc_wrap.outbound_mailbox_13.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.267. outbound_mailbox_13.IRQS

Table 1337. axil_mailbox_smc_wrap.outbound_mailbox_13.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.268. outbound_mailbox_13.IRQEN

Table 1338. axil_mailbox_smc_wrap.outbound_mailbox_13.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.269. outbound_mailbox_13.IRQP

Table 1339. axil_mailbox_smc_wrap.outbound_mailbox_13.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.270. outbound_mailbox_13.CTRL

Table 1340. axil_mailbox_smc_wrap.outbound_mailbox_13.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.271. inbound_mailbox_13.WRITE_DATA

Table 1341. axil_mailbox_smc_wrap.inbound_mailbox_13.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.272. inbound_mailbox_13.READ_DATA

Table 1342. axil_mailbox_smc_wrap.inbound_mailbox_13.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.273. inbound_mailbox_13.STATUS

Table 1343. axil_mailbox_smc_wrap.inbound_mailbox_13.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.274. inbound_mailbox_13.ERROR_FLAGS

Table 1344. axil_mailbox_smc_wrap.inbound_mailbox_13.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.275. inbound_mailbox_13.WIRQT

Table 1345. axil_mailbox_smc_wrap.inbound_mailbox_13.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.276. inbound_mailbox_13.RIRQT

Table 1346. axil_mailbox_smc_wrap.inbound_mailbox_13.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.277. inbound_mailbox_13.IRQS

Table 1347. axil_mailbox_smc_wrap.inbound_mailbox_13.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.278. inbound_mailbox_13.IRQEN

Table 1348. axil_mailbox_smc_wrap.inbound_mailbox_13.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.279. inbound_mailbox_13.IRQP

Table 1349. axil_mailbox_smc_wrap.inbound_mailbox_13.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.280. inbound_mailbox_13.CTRL

Table 1350. axil_mailbox_smc_wrap.inbound_mailbox_13.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.281. outbound_mailbox_14.WRITE_DATA

Table 1351. axil_mailbox_smc_wrap.outbound_mailbox_14.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.282. outbound_mailbox_14.READ_DATA

Table 1352. axil_mailbox_smc_wrap.outbound_mailbox_14.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.283. outbound_mailbox_14.STATUS

Table 1353. axil_mailbox_smc_wrap.outbound_mailbox_14.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.284. outbound_mailbox_14.ERROR_FLAGS

Table 1354. axil_mailbox_smc_wrap.outbound_mailbox_14.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.285. outbound_mailbox_14.WIRQT

Table 1355. axil_mailbox_smc_wrap.outbound_mailbox_14.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.286. outbound_mailbox_14.RIRQT

Table 1356. axil_mailbox_smc_wrap.outbound_mailbox_14.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.287. outbound_mailbox_14.IRQS

Table 1357. axil_mailbox_smc_wrap.outbound_mailbox_14.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.288. outbound_mailbox_14.IRQEN

Table 1358. axil_mailbox_smc_wrap.outbound_mailbox_14.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.289. outbound_mailbox_14.IRQP

Table 1359. axil_mailbox_smc_wrap.outbound_mailbox_14.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.290. outbound_mailbox_14.CTRL

Table 1360. axil_mailbox_smc_wrap.outbound_mailbox_14.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.291. inbound_mailbox_14.WRITE_DATA

Table 1361. axil_mailbox_smc_wrap.inbound_mailbox_14.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.292. inbound_mailbox_14.READ_DATA

Table 1362. axil_mailbox_smc_wrap.inbound_mailbox_14.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.293. inbound_mailbox_14.STATUS

Table 1363. axil_mailbox_smc_wrap.inbound_mailbox_14.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.294. inbound_mailbox_14.ERROR_FLAGS

Table 1364. axil_mailbox_smc_wrap.inbound_mailbox_14.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.295. inbound_mailbox_14.WIRQT

Table 1365. axil_mailbox_smc_wrap.inbound_mailbox_14.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.296. inbound_mailbox_14.RIRQT

Table 1366. axil_mailbox_smc_wrap.inbound_mailbox_14.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.297. inbound_mailbox_14.IRQS

Table 1367. axil_mailbox_smc_wrap.inbound_mailbox_14.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.298. inbound_mailbox_14.IRQEN

Table 1368. axil_mailbox_smc_wrap.inbound_mailbox_14.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.299. inbound_mailbox_14.IRQP

Table 1369. axil_mailbox_smc_wrap.inbound_mailbox_14.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.300. inbound_mailbox_14.CTRL

Table 1370. axil_mailbox_smc_wrap.inbound_mailbox_14.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.301. outbound_mailbox_15.WRITE_DATA

Table 1371. axil_mailbox_smc_wrap.outbound_mailbox_15.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.302. outbound_mailbox_15.READ_DATA

Table 1372. axil_mailbox_smc_wrap.outbound_mailbox_15.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.303. outbound_mailbox_15.STATUS

Table 1373. axil_mailbox_smc_wrap.outbound_mailbox_15.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.304. outbound_mailbox_15.ERROR_FLAGS

Table 1374. axil_mailbox_smc_wrap.outbound_mailbox_15.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.305. outbound_mailbox_15.WIRQT

Table 1375. axil_mailbox_smc_wrap.outbound_mailbox_15.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.306. outbound_mailbox_15.RIRQT

Table 1376. axil_mailbox_smc_wrap.outbound_mailbox_15.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.307. outbound_mailbox_15.IRQS

Table 1377. axil_mailbox_smc_wrap.outbound_mailbox_15.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.308. outbound_mailbox_15.IRQEN

Table 1378. axil_mailbox_smc_wrap.outbound_mailbox_15.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.309. outbound_mailbox_15.IRQP

Table 1379. axil_mailbox_smc_wrap.outbound_mailbox_15.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.310. outbound_mailbox_15.CTRL

Table 1380. axil_mailbox_smc_wrap.outbound_mailbox_15.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.311. inbound_mailbox_15.WRITE_DATA

Table 1381. axil_mailbox_smc_wrap.inbound_mailbox_15.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.312. inbound_mailbox_15.READ_DATA

Table 1382. axil_mailbox_smc_wrap.inbound_mailbox_15.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.313. inbound_mailbox_15.STATUS

Table 1383. axil_mailbox_smc_wrap.inbound_mailbox_15.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.314. inbound_mailbox_15.ERROR_FLAGS

Table 1384. axil_mailbox_smc_wrap.inbound_mailbox_15.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.315. inbound_mailbox_15.WIRQT

Table 1385. axil_mailbox_smc_wrap.inbound_mailbox_15.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.316. inbound_mailbox_15.RIRQT

Table 1386. axil_mailbox_smc_wrap.inbound_mailbox_15.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.317. inbound_mailbox_15.IRQS

Table 1387. axil_mailbox_smc_wrap.inbound_mailbox_15.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.318. inbound_mailbox_15.IRQEN

Table 1388. axil_mailbox_smc_wrap.inbound_mailbox_15.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.319. inbound_mailbox_15.IRQP

Table 1389. axil_mailbox_smc_wrap.inbound_mailbox_15.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.320. inbound_mailbox_15.CTRL

Table 1390. axil_mailbox_smc_wrap.inbound_mailbox_15.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.321. outbound_mailbox_16.WRITE_DATA

Table 1391. axil_mailbox_smc_wrap.outbound_mailbox_16.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.322. outbound_mailbox_16.READ_DATA

Table 1392. axil_mailbox_smc_wrap.outbound_mailbox_16.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.323. outbound_mailbox_16.STATUS

Table 1393. axil_mailbox_smc_wrap.outbound_mailbox_16.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.324. outbound_mailbox_16.ERROR_FLAGS

Table 1394. axil_mailbox_smc_wrap.outbound_mailbox_16.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.325. outbound_mailbox_16.WIRQT

Table 1395. axil_mailbox_smc_wrap.outbound_mailbox_16.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.326. outbound_mailbox_16.RIRQT

Table 1396. axil_mailbox_smc_wrap.outbound_mailbox_16.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.327. outbound_mailbox_16.IRQS

Table 1397. axil_mailbox_smc_wrap.outbound_mailbox_16.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.328. outbound_mailbox_16.IRQEN

Table 1398. axil_mailbox_smc_wrap.outbound_mailbox_16.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.329. outbound_mailbox_16.IRQP

Table 1399. axil_mailbox_smc_wrap.outbound_mailbox_16.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.330. outbound_mailbox_16.CTRL

Table 1400. axil_mailbox_smc_wrap.outbound_mailbox_16.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.331. inbound_mailbox_16.WRITE_DATA

Table 1401. axil_mailbox_smc_wrap.inbound_mailbox_16.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.332. inbound_mailbox_16.READ_DATA

Table 1402. axil_mailbox_smc_wrap.inbound_mailbox_16.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.333. inbound_mailbox_16.STATUS

Table 1403. axil_mailbox_smc_wrap.inbound_mailbox_16.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.334. inbound_mailbox_16.ERROR_FLAGS

Table 1404. axil_mailbox_smc_wrap.inbound_mailbox_16.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.335. inbound_mailbox_16.WIRQT

Table 1405. axil_mailbox_smc_wrap.inbound_mailbox_16.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.336. inbound_mailbox_16.RIRQT

Table 1406. axil_mailbox_smc_wrap.inbound_mailbox_16.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.337. inbound_mailbox_16.IRQS

Table 1407. axil_mailbox_smc_wrap.inbound_mailbox_16.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.338. inbound_mailbox_16.IRQEN

Table 1408. axil_mailbox_smc_wrap.inbound_mailbox_16.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.339. inbound_mailbox_16.IRQP

Table 1409. axil_mailbox_smc_wrap.inbound_mailbox_16.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.340. inbound_mailbox_16.CTRL

Table 1410. axil_mailbox_smc_wrap.inbound_mailbox_16.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.341. outbound_mailbox_17.WRITE_DATA

Table 1411. axil_mailbox_smc_wrap.outbound_mailbox_17.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.342. outbound_mailbox_17.READ_DATA

Table 1412. axil_mailbox_smc_wrap.outbound_mailbox_17.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.343. outbound_mailbox_17.STATUS

Table 1413. axil_mailbox_smc_wrap.outbound_mailbox_17.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.344. outbound_mailbox_17.ERROR_FLAGS

Table 1414. axil_mailbox_smc_wrap.outbound_mailbox_17.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.345. outbound_mailbox_17.WIRQT

Table 1415. axil_mailbox_smc_wrap.outbound_mailbox_17.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.346. outbound_mailbox_17.RIRQT

Table 1416. axil_mailbox_smc_wrap.outbound_mailbox_17.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.347. outbound_mailbox_17.IRQS

Table 1417. axil_mailbox_smc_wrap.outbound_mailbox_17.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.348. outbound_mailbox_17.IRQEN

Table 1418. axil_mailbox_smc_wrap.outbound_mailbox_17.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.349. outbound_mailbox_17.IRQP

Table 1419. axil_mailbox_smc_wrap.outbound_mailbox_17.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.350. outbound_mailbox_17.CTRL

Table 1420. axil_mailbox_smc_wrap.outbound_mailbox_17.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.351. inbound_mailbox_17.WRITE_DATA

Table 1421. axil_mailbox_smc_wrap.inbound_mailbox_17.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.352. inbound_mailbox_17.READ_DATA

Table 1422. axil_mailbox_smc_wrap.inbound_mailbox_17.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.353. inbound_mailbox_17.STATUS

Table 1423. axil_mailbox_smc_wrap.inbound_mailbox_17.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.354. inbound_mailbox_17.ERROR_FLAGS

Table 1424. axil_mailbox_smc_wrap.inbound_mailbox_17.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.355. inbound_mailbox_17.WIRQT

Table 1425. axil_mailbox_smc_wrap.inbound_mailbox_17.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.356. inbound_mailbox_17.RIRQT

Table 1426. axil_mailbox_smc_wrap.inbound_mailbox_17.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.357. inbound_mailbox_17.IRQS

Table 1427. axil_mailbox_smc_wrap.inbound_mailbox_17.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.358. inbound_mailbox_17.IRQEN

Table 1428. axil_mailbox_smc_wrap.inbound_mailbox_17.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.359. inbound_mailbox_17.IRQP

Table 1429. axil_mailbox_smc_wrap.inbound_mailbox_17.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.360. inbound_mailbox_17.CTRL

Table 1430. axil_mailbox_smc_wrap.inbound_mailbox_17.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.361. outbound_mailbox_18.WRITE_DATA

Table 1431. axil_mailbox_smc_wrap.outbound_mailbox_18.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.362. outbound_mailbox_18.READ_DATA

Table 1432. axil_mailbox_smc_wrap.outbound_mailbox_18.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.363. outbound_mailbox_18.STATUS

Table 1433. axil_mailbox_smc_wrap.outbound_mailbox_18.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.364. outbound_mailbox_18.ERROR_FLAGS

Table 1434. axil_mailbox_smc_wrap.outbound_mailbox_18.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.365. outbound_mailbox_18.WIRQT

Table 1435. axil_mailbox_smc_wrap.outbound_mailbox_18.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.366. outbound_mailbox_18.RIRQT

Table 1436. axil_mailbox_smc_wrap.outbound_mailbox_18.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.367. outbound_mailbox_18.IRQS

Table 1437. axil_mailbox_smc_wrap.outbound_mailbox_18.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.368. outbound_mailbox_18.IRQEN

Table 1438. axil_mailbox_smc_wrap.outbound_mailbox_18.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.369. outbound_mailbox_18.IRQP

Table 1439. axil_mailbox_smc_wrap.outbound_mailbox_18.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.370. outbound_mailbox_18.CTRL

Table 1440. axil_mailbox_smc_wrap.outbound_mailbox_18.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.371. inbound_mailbox_18.WRITE_DATA

Table 1441. axil_mailbox_smc_wrap.inbound_mailbox_18.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.372. inbound_mailbox_18.READ_DATA

Table 1442. axil_mailbox_smc_wrap.inbound_mailbox_18.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.373. inbound_mailbox_18.STATUS

Table 1443. axil_mailbox_smc_wrap.inbound_mailbox_18.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.374. inbound_mailbox_18.ERROR_FLAGS

Table 1444. axil_mailbox_smc_wrap.inbound_mailbox_18.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.375. inbound_mailbox_18.WIRQT

Table 1445. axil_mailbox_smc_wrap.inbound_mailbox_18.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.376. inbound_mailbox_18.RIRQT

Table 1446. axil_mailbox_smc_wrap.inbound_mailbox_18.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.377. inbound_mailbox_18.IRQS

Table 1447. axil_mailbox_smc_wrap.inbound_mailbox_18.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.378. inbound_mailbox_18.IRQEN

Table 1448. axil_mailbox_smc_wrap.inbound_mailbox_18.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.379. inbound_mailbox_18.IRQP

Table 1449. axil_mailbox_smc_wrap.inbound_mailbox_18.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.380. inbound_mailbox_18.CTRL

Table 1450. axil_mailbox_smc_wrap.inbound_mailbox_18.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.381. outbound_mailbox_19.WRITE_DATA

Table 1451. axil_mailbox_smc_wrap.outbound_mailbox_19.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.382. outbound_mailbox_19.READ_DATA

Table 1452. axil_mailbox_smc_wrap.outbound_mailbox_19.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.383. outbound_mailbox_19.STATUS

Table 1453. axil_mailbox_smc_wrap.outbound_mailbox_19.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.384. outbound_mailbox_19.ERROR_FLAGS

Table 1454. axil_mailbox_smc_wrap.outbound_mailbox_19.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.385. outbound_mailbox_19.WIRQT

Table 1455. axil_mailbox_smc_wrap.outbound_mailbox_19.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.386. outbound_mailbox_19.RIRQT

Table 1456. axil_mailbox_smc_wrap.outbound_mailbox_19.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.387. outbound_mailbox_19.IRQS

Table 1457. axil_mailbox_smc_wrap.outbound_mailbox_19.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.388. outbound_mailbox_19.IRQEN

Table 1458. axil_mailbox_smc_wrap.outbound_mailbox_19.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.389. outbound_mailbox_19.IRQP

Table 1459. axil_mailbox_smc_wrap.outbound_mailbox_19.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.390. outbound_mailbox_19.CTRL

Table 1460. axil_mailbox_smc_wrap.outbound_mailbox_19.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.391. inbound_mailbox_19.WRITE_DATA

Table 1461. axil_mailbox_smc_wrap.inbound_mailbox_19.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.392. inbound_mailbox_19.READ_DATA

Table 1462. axil_mailbox_smc_wrap.inbound_mailbox_19.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.393. inbound_mailbox_19.STATUS

Table 1463. axil_mailbox_smc_wrap.inbound_mailbox_19.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.394. inbound_mailbox_19.ERROR_FLAGS

Table 1464. axil_mailbox_smc_wrap.inbound_mailbox_19.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.395. inbound_mailbox_19.WIRQT

Table 1465. axil_mailbox_smc_wrap.inbound_mailbox_19.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.396. inbound_mailbox_19.RIRQT

Table 1466. axil_mailbox_smc_wrap.inbound_mailbox_19.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.397. inbound_mailbox_19.IRQS

Table 1467. axil_mailbox_smc_wrap.inbound_mailbox_19.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.398. inbound_mailbox_19.IRQEN

Table 1468. axil_mailbox_smc_wrap.inbound_mailbox_19.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.399. inbound_mailbox_19.IRQP

Table 1469. axil_mailbox_smc_wrap.inbound_mailbox_19.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.400. inbound_mailbox_19.CTRL

Table 1470. axil_mailbox_smc_wrap.inbound_mailbox_19.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.401. outbound_mailbox_20.WRITE_DATA

Table 1471. axil_mailbox_smc_wrap.outbound_mailbox_20.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.402. outbound_mailbox_20.READ_DATA

Table 1472. axil_mailbox_smc_wrap.outbound_mailbox_20.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.403. outbound_mailbox_20.STATUS

Table 1473. axil_mailbox_smc_wrap.outbound_mailbox_20.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.404. outbound_mailbox_20.ERROR_FLAGS

Table 1474. axil_mailbox_smc_wrap.outbound_mailbox_20.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.405. outbound_mailbox_20.WIRQT

Table 1475. axil_mailbox_smc_wrap.outbound_mailbox_20.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.406. outbound_mailbox_20.RIRQT

Table 1476. axil_mailbox_smc_wrap.outbound_mailbox_20.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.407. outbound_mailbox_20.IRQS

Table 1477. axil_mailbox_smc_wrap.outbound_mailbox_20.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.408. outbound_mailbox_20.IRQEN

Table 1478. axil_mailbox_smc_wrap.outbound_mailbox_20.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.409. outbound_mailbox_20.IRQP

Table 1479. axil_mailbox_smc_wrap.outbound_mailbox_20.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.410. outbound_mailbox_20.CTRL

Table 1480. axil_mailbox_smc_wrap.outbound_mailbox_20.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.411. inbound_mailbox_20.WRITE_DATA

Table 1481. axil_mailbox_smc_wrap.inbound_mailbox_20.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.412. inbound_mailbox_20.READ_DATA

Table 1482. axil_mailbox_smc_wrap.inbound_mailbox_20.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.413. inbound_mailbox_20.STATUS

Table 1483. axil_mailbox_smc_wrap.inbound_mailbox_20.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.414. inbound_mailbox_20.ERROR_FLAGS

Table 1484. axil_mailbox_smc_wrap.inbound_mailbox_20.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.415. inbound_mailbox_20.WIRQT

Table 1485. axil_mailbox_smc_wrap.inbound_mailbox_20.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.416. inbound_mailbox_20.RIRQT

Table 1486. axil_mailbox_smc_wrap.inbound_mailbox_20.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.417. inbound_mailbox_20.IRQS

Table 1487. axil_mailbox_smc_wrap.inbound_mailbox_20.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.418. inbound_mailbox_20.IRQEN

Table 1488. axil_mailbox_smc_wrap.inbound_mailbox_20.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.419. inbound_mailbox_20.IRQP

Table 1489. axil_mailbox_smc_wrap.inbound_mailbox_20.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.420. inbound_mailbox_20.CTRL

Table 1490. axil_mailbox_smc_wrap.inbound_mailbox_20.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.421. outbound_mailbox_21.WRITE_DATA

Table 1491. axil_mailbox_smc_wrap.outbound_mailbox_21.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.422. outbound_mailbox_21.READ_DATA

Table 1492. axil_mailbox_smc_wrap.outbound_mailbox_21.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.423. outbound_mailbox_21.STATUS

Table 1493. axil_mailbox_smc_wrap.outbound_mailbox_21.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.424. outbound_mailbox_21.ERROR_FLAGS

Table 1494. axil_mailbox_smc_wrap.outbound_mailbox_21.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.425. outbound_mailbox_21.WIRQT

Table 1495. axil_mailbox_smc_wrap.outbound_mailbox_21.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.426. outbound_mailbox_21.RIRQT

Table 1496. axil_mailbox_smc_wrap.outbound_mailbox_21.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.427. outbound_mailbox_21.IRQS

Table 1497. axil_mailbox_smc_wrap.outbound_mailbox_21.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.428. outbound_mailbox_21.IRQEN

Table 1498. axil_mailbox_smc_wrap.outbound_mailbox_21.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.429. outbound_mailbox_21.IRQP

Table 1499. axil_mailbox_smc_wrap.outbound_mailbox_21.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.430. outbound_mailbox_21.CTRL

Table 1500. axil_mailbox_smc_wrap.outbound_mailbox_21.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.431. inbound_mailbox_21.WRITE_DATA

Table 1501. axil_mailbox_smc_wrap.inbound_mailbox_21.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.432. inbound_mailbox_21.READ_DATA

Table 1502. axil_mailbox_smc_wrap.inbound_mailbox_21.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.433. inbound_mailbox_21.STATUS

Table 1503. axil_mailbox_smc_wrap.inbound_mailbox_21.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.434. inbound_mailbox_21.ERROR_FLAGS

Table 1504. axil_mailbox_smc_wrap.inbound_mailbox_21.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.435. inbound_mailbox_21.WIRQT

Table 1505. axil_mailbox_smc_wrap.inbound_mailbox_21.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.436. inbound_mailbox_21.RIRQT

Table 1506. axil_mailbox_smc_wrap.inbound_mailbox_21.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.437. inbound_mailbox_21.IRQS

Table 1507. axil_mailbox_smc_wrap.inbound_mailbox_21.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.438. inbound_mailbox_21.IRQEN

Table 1508. axil_mailbox_smc_wrap.inbound_mailbox_21.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.439. inbound_mailbox_21.IRQP

Table 1509. axil_mailbox_smc_wrap.inbound_mailbox_21.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.440. inbound_mailbox_21.CTRL

Table 1510. axil_mailbox_smc_wrap.inbound_mailbox_21.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.441. outbound_mailbox_22.WRITE_DATA

Table 1511. axil_mailbox_smc_wrap.outbound_mailbox_22.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.442. outbound_mailbox_22.READ_DATA

Table 1512. axil_mailbox_smc_wrap.outbound_mailbox_22.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.443. outbound_mailbox_22.STATUS

Table 1513. axil_mailbox_smc_wrap.outbound_mailbox_22.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.444. outbound_mailbox_22.ERROR_FLAGS

Table 1514. axil_mailbox_smc_wrap.outbound_mailbox_22.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.445. outbound_mailbox_22.WIRQT

Table 1515. axil_mailbox_smc_wrap.outbound_mailbox_22.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.446. outbound_mailbox_22.RIRQT

Table 1516. axil_mailbox_smc_wrap.outbound_mailbox_22.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.447. outbound_mailbox_22.IRQS

Table 1517. axil_mailbox_smc_wrap.outbound_mailbox_22.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.448. outbound_mailbox_22.IRQEN

Table 1518. axil_mailbox_smc_wrap.outbound_mailbox_22.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.449. outbound_mailbox_22.IRQP

Table 1519. axil_mailbox_smc_wrap.outbound_mailbox_22.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.450. outbound_mailbox_22.CTRL

Table 1520. axil_mailbox_smc_wrap.outbound_mailbox_22.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.451. inbound_mailbox_22.WRITE_DATA

Table 1521. axil_mailbox_smc_wrap.inbound_mailbox_22.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.452. inbound_mailbox_22.READ_DATA

Table 1522. axil_mailbox_smc_wrap.inbound_mailbox_22.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.453. inbound_mailbox_22.STATUS

Table 1523. axil_mailbox_smc_wrap.inbound_mailbox_22.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.454. inbound_mailbox_22.ERROR_FLAGS

Table 1524. axil_mailbox_smc_wrap.inbound_mailbox_22.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.455. inbound_mailbox_22.WIRQT

Table 1525. axil_mailbox_smc_wrap.inbound_mailbox_22.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.456. inbound_mailbox_22.RIRQT

Table 1526. axil_mailbox_smc_wrap.inbound_mailbox_22.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.457. inbound_mailbox_22.IRQS

Table 1527. axil_mailbox_smc_wrap.inbound_mailbox_22.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.458. inbound_mailbox_22.IRQEN

Table 1528. axil_mailbox_smc_wrap.inbound_mailbox_22.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.459. inbound_mailbox_22.IRQP

Table 1529. axil_mailbox_smc_wrap.inbound_mailbox_22.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.460. inbound_mailbox_22.CTRL

Table 1530. axil_mailbox_smc_wrap.inbound_mailbox_22.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.461. outbound_mailbox_23.WRITE_DATA

Table 1531. axil_mailbox_smc_wrap.outbound_mailbox_23.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.462. outbound_mailbox_23.READ_DATA

Table 1532. axil_mailbox_smc_wrap.outbound_mailbox_23.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.463. outbound_mailbox_23.STATUS

Table 1533. axil_mailbox_smc_wrap.outbound_mailbox_23.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.464. outbound_mailbox_23.ERROR_FLAGS

Table 1534. axil_mailbox_smc_wrap.outbound_mailbox_23.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.465. outbound_mailbox_23.WIRQT

Table 1535. axil_mailbox_smc_wrap.outbound_mailbox_23.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.466. outbound_mailbox_23.RIRQT

Table 1536. axil_mailbox_smc_wrap.outbound_mailbox_23.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.467. outbound_mailbox_23.IRQS

Table 1537. axil_mailbox_smc_wrap.outbound_mailbox_23.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.468. outbound_mailbox_23.IRQEN

Table 1538. axil_mailbox_smc_wrap.outbound_mailbox_23.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.469. outbound_mailbox_23.IRQP

Table 1539. axil_mailbox_smc_wrap.outbound_mailbox_23.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.470. outbound_mailbox_23.CTRL

Table 1540. axil_mailbox_smc_wrap.outbound_mailbox_23.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.471. inbound_mailbox_23.WRITE_DATA

Table 1541. axil_mailbox_smc_wrap.inbound_mailbox_23.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.472. inbound_mailbox_23.READ_DATA

Table 1542. axil_mailbox_smc_wrap.inbound_mailbox_23.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.473. inbound_mailbox_23.STATUS

Table 1543. axil_mailbox_smc_wrap.inbound_mailbox_23.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.474. inbound_mailbox_23.ERROR_FLAGS

Table 1544. axil_mailbox_smc_wrap.inbound_mailbox_23.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.475. inbound_mailbox_23.WIRQT

Table 1545. axil_mailbox_smc_wrap.inbound_mailbox_23.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.476. inbound_mailbox_23.RIRQT

Table 1546. axil_mailbox_smc_wrap.inbound_mailbox_23.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.477. inbound_mailbox_23.IRQS

Table 1547. axil_mailbox_smc_wrap.inbound_mailbox_23.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.478. inbound_mailbox_23.IRQEN

Table 1548. axil_mailbox_smc_wrap.inbound_mailbox_23.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.479. inbound_mailbox_23.IRQP

Table 1549. axil_mailbox_smc_wrap.inbound_mailbox_23.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.480. inbound_mailbox_23.CTRL

Table 1550. axil_mailbox_smc_wrap.inbound_mailbox_23.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.481. outbound_mailbox_24.WRITE_DATA

Table 1551. axil_mailbox_smc_wrap.outbound_mailbox_24.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.482. outbound_mailbox_24.READ_DATA

Table 1552. axil_mailbox_smc_wrap.outbound_mailbox_24.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.483. outbound_mailbox_24.STATUS

Table 1553. axil_mailbox_smc_wrap.outbound_mailbox_24.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.484. outbound_mailbox_24.ERROR_FLAGS

Table 1554. axil_mailbox_smc_wrap.outbound_mailbox_24.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.485. outbound_mailbox_24.WIRQT

Table 1555. axil_mailbox_smc_wrap.outbound_mailbox_24.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.486. outbound_mailbox_24.RIRQT

Table 1556. axil_mailbox_smc_wrap.outbound_mailbox_24.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.487. outbound_mailbox_24.IRQS

Table 1557. axil_mailbox_smc_wrap.outbound_mailbox_24.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.488. outbound_mailbox_24.IRQEN

Table 1558. axil_mailbox_smc_wrap.outbound_mailbox_24.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.489. outbound_mailbox_24.IRQP

Table 1559. axil_mailbox_smc_wrap.outbound_mailbox_24.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.490. outbound_mailbox_24.CTRL

Table 1560. axil_mailbox_smc_wrap.outbound_mailbox_24.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.491. inbound_mailbox_24.WRITE_DATA

Table 1561. axil_mailbox_smc_wrap.inbound_mailbox_24.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.492. inbound_mailbox_24.READ_DATA

Table 1562. axil_mailbox_smc_wrap.inbound_mailbox_24.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.493. inbound_mailbox_24.STATUS

Table 1563. axil_mailbox_smc_wrap.inbound_mailbox_24.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.494. inbound_mailbox_24.ERROR_FLAGS

Table 1564. axil_mailbox_smc_wrap.inbound_mailbox_24.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.495. inbound_mailbox_24.WIRQT

Table 1565. axil_mailbox_smc_wrap.inbound_mailbox_24.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.496. inbound_mailbox_24.RIRQT

Table 1566. axil_mailbox_smc_wrap.inbound_mailbox_24.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.497. inbound_mailbox_24.IRQS

Table 1567. axil_mailbox_smc_wrap.inbound_mailbox_24.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.498. inbound_mailbox_24.IRQEN

Table 1568. axil_mailbox_smc_wrap.inbound_mailbox_24.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.499. inbound_mailbox_24.IRQP

Table 1569. axil_mailbox_smc_wrap.inbound_mailbox_24.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.500. inbound_mailbox_24.CTRL

Table 1570. axil_mailbox_smc_wrap.inbound_mailbox_24.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.501. outbound_mailbox_25.WRITE_DATA

Table 1571. axil_mailbox_smc_wrap.outbound_mailbox_25.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.502. outbound_mailbox_25.READ_DATA

Table 1572. axil_mailbox_smc_wrap.outbound_mailbox_25.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.503. outbound_mailbox_25.STATUS

Table 1573. axil_mailbox_smc_wrap.outbound_mailbox_25.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.504. outbound_mailbox_25.ERROR_FLAGS

Table 1574. axil_mailbox_smc_wrap.outbound_mailbox_25.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.505. outbound_mailbox_25.WIRQT

Table 1575. axil_mailbox_smc_wrap.outbound_mailbox_25.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.506. outbound_mailbox_25.RIRQT

Table 1576. axil_mailbox_smc_wrap.outbound_mailbox_25.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.507. outbound_mailbox_25.IRQS

Table 1577. axil_mailbox_smc_wrap.outbound_mailbox_25.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.508. outbound_mailbox_25.IRQEN

Table 1578. axil_mailbox_smc_wrap.outbound_mailbox_25.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.509. outbound_mailbox_25.IRQP

Table 1579. axil_mailbox_smc_wrap.outbound_mailbox_25.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.510. outbound_mailbox_25.CTRL

Table 1580. axil_mailbox_smc_wrap.outbound_mailbox_25.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.511. inbound_mailbox_25.WRITE_DATA

Table 1581. axil_mailbox_smc_wrap.inbound_mailbox_25.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.512. inbound_mailbox_25.READ_DATA

Table 1582. axil_mailbox_smc_wrap.inbound_mailbox_25.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.513. inbound_mailbox_25.STATUS

Table 1583. axil_mailbox_smc_wrap.inbound_mailbox_25.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.514. inbound_mailbox_25.ERROR_FLAGS

Table 1584. axil_mailbox_smc_wrap.inbound_mailbox_25.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.515. inbound_mailbox_25.WIRQT

Table 1585. axil_mailbox_smc_wrap.inbound_mailbox_25.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.516. inbound_mailbox_25.RIRQT

Table 1586. axil_mailbox_smc_wrap.inbound_mailbox_25.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.517. inbound_mailbox_25.IRQS

Table 1587. axil_mailbox_smc_wrap.inbound_mailbox_25.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.518. inbound_mailbox_25.IRQEN

Table 1588. axil_mailbox_smc_wrap.inbound_mailbox_25.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.519. inbound_mailbox_25.IRQP

Table 1589. axil_mailbox_smc_wrap.inbound_mailbox_25.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.520. inbound_mailbox_25.CTRL

Table 1590. axil_mailbox_smc_wrap.inbound_mailbox_25.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.521. outbound_mailbox_26.WRITE_DATA

Table 1591. axil_mailbox_smc_wrap.outbound_mailbox_26.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.522. outbound_mailbox_26.READ_DATA

Table 1592. axil_mailbox_smc_wrap.outbound_mailbox_26.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.523. outbound_mailbox_26.STATUS

Table 1593. axil_mailbox_smc_wrap.outbound_mailbox_26.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.524. outbound_mailbox_26.ERROR_FLAGS

Table 1594. axil_mailbox_smc_wrap.outbound_mailbox_26.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.525. outbound_mailbox_26.WIRQT

Table 1595. axil_mailbox_smc_wrap.outbound_mailbox_26.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.526. outbound_mailbox_26.RIRQT

Table 1596. axil_mailbox_smc_wrap.outbound_mailbox_26.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.527. outbound_mailbox_26.IRQS

Table 1597. axil_mailbox_smc_wrap.outbound_mailbox_26.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.528. outbound_mailbox_26.IRQEN

Table 1598. axil_mailbox_smc_wrap.outbound_mailbox_26.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.529. outbound_mailbox_26.IRQP

Table 1599. axil_mailbox_smc_wrap.outbound_mailbox_26.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.530. outbound_mailbox_26.CTRL

Table 1600. axil_mailbox_smc_wrap.outbound_mailbox_26.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.531. inbound_mailbox_26.WRITE_DATA

Table 1601. axil_mailbox_smc_wrap.inbound_mailbox_26.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.532. inbound_mailbox_26.READ_DATA

Table 1602. axil_mailbox_smc_wrap.inbound_mailbox_26.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.533. inbound_mailbox_26.STATUS

Table 1603. axil_mailbox_smc_wrap.inbound_mailbox_26.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.534. inbound_mailbox_26.ERROR_FLAGS

Table 1604. axil_mailbox_smc_wrap.inbound_mailbox_26.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.535. inbound_mailbox_26.WIRQT

Table 1605. axil_mailbox_smc_wrap.inbound_mailbox_26.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.536. inbound_mailbox_26.RIRQT

Table 1606. axil_mailbox_smc_wrap.inbound_mailbox_26.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.537. inbound_mailbox_26.IRQS

Table 1607. axil_mailbox_smc_wrap.inbound_mailbox_26.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.538. inbound_mailbox_26.IRQEN

Table 1608. axil_mailbox_smc_wrap.inbound_mailbox_26.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.539. inbound_mailbox_26.IRQP

Table 1609. axil_mailbox_smc_wrap.inbound_mailbox_26.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.540. inbound_mailbox_26.CTRL

Table 1610. axil_mailbox_smc_wrap.inbound_mailbox_26.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.541. outbound_mailbox_27.WRITE_DATA

Table 1611. axil_mailbox_smc_wrap.outbound_mailbox_27.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.542. outbound_mailbox_27.READ_DATA

Table 1612. axil_mailbox_smc_wrap.outbound_mailbox_27.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.543. outbound_mailbox_27.STATUS

Table 1613. axil_mailbox_smc_wrap.outbound_mailbox_27.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.544. outbound_mailbox_27.ERROR_FLAGS

Table 1614. axil_mailbox_smc_wrap.outbound_mailbox_27.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.545. outbound_mailbox_27.WIRQT

Table 1615. axil_mailbox_smc_wrap.outbound_mailbox_27.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.546. outbound_mailbox_27.RIRQT

Table 1616. axil_mailbox_smc_wrap.outbound_mailbox_27.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.547. outbound_mailbox_27.IRQS

Table 1617. axil_mailbox_smc_wrap.outbound_mailbox_27.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.548. outbound_mailbox_27.IRQEN

Table 1618. axil_mailbox_smc_wrap.outbound_mailbox_27.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.549. outbound_mailbox_27.IRQP

Table 1619. axil_mailbox_smc_wrap.outbound_mailbox_27.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.550. outbound_mailbox_27.CTRL

Table 1620. axil_mailbox_smc_wrap.outbound_mailbox_27.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.551. inbound_mailbox_27.WRITE_DATA

Table 1621. axil_mailbox_smc_wrap.inbound_mailbox_27.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.552. inbound_mailbox_27.READ_DATA

Table 1622. axil_mailbox_smc_wrap.inbound_mailbox_27.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.553. inbound_mailbox_27.STATUS

Table 1623. axil_mailbox_smc_wrap.inbound_mailbox_27.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.554. inbound_mailbox_27.ERROR_FLAGS

Table 1624. axil_mailbox_smc_wrap.inbound_mailbox_27.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.555. inbound_mailbox_27.WIRQT

Table 1625. axil_mailbox_smc_wrap.inbound_mailbox_27.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.556. inbound_mailbox_27.RIRQT

Table 1626. axil_mailbox_smc_wrap.inbound_mailbox_27.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.557. inbound_mailbox_27.IRQS

Table 1627. axil_mailbox_smc_wrap.inbound_mailbox_27.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.558. inbound_mailbox_27.IRQEN

Table 1628. axil_mailbox_smc_wrap.inbound_mailbox_27.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.559. inbound_mailbox_27.IRQP

Table 1629. axil_mailbox_smc_wrap.inbound_mailbox_27.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.560. inbound_mailbox_27.CTRL

Table 1630. axil_mailbox_smc_wrap.inbound_mailbox_27.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.561. outbound_mailbox_28.WRITE_DATA

Table 1631. axil_mailbox_smc_wrap.outbound_mailbox_28.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.562. outbound_mailbox_28.READ_DATA

Table 1632. axil_mailbox_smc_wrap.outbound_mailbox_28.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.563. outbound_mailbox_28.STATUS

Table 1633. axil_mailbox_smc_wrap.outbound_mailbox_28.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.564. outbound_mailbox_28.ERROR_FLAGS

Table 1634. axil_mailbox_smc_wrap.outbound_mailbox_28.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.565. outbound_mailbox_28.WIRQT

Table 1635. axil_mailbox_smc_wrap.outbound_mailbox_28.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.566. outbound_mailbox_28.RIRQT

Table 1636. axil_mailbox_smc_wrap.outbound_mailbox_28.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.567. outbound_mailbox_28.IRQS

Table 1637. axil_mailbox_smc_wrap.outbound_mailbox_28.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.568. outbound_mailbox_28.IRQEN

Table 1638. axil_mailbox_smc_wrap.outbound_mailbox_28.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.569. outbound_mailbox_28.IRQP

Table 1639. axil_mailbox_smc_wrap.outbound_mailbox_28.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.570. outbound_mailbox_28.CTRL

Table 1640. axil_mailbox_smc_wrap.outbound_mailbox_28.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.571. inbound_mailbox_28.WRITE_DATA

Table 1641. axil_mailbox_smc_wrap.inbound_mailbox_28.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.572. inbound_mailbox_28.READ_DATA

Table 1642. axil_mailbox_smc_wrap.inbound_mailbox_28.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.573. inbound_mailbox_28.STATUS

Table 1643. axil_mailbox_smc_wrap.inbound_mailbox_28.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.574. inbound_mailbox_28.ERROR_FLAGS

Table 1644. axil_mailbox_smc_wrap.inbound_mailbox_28.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.575. inbound_mailbox_28.WIRQT

Table 1645. axil_mailbox_smc_wrap.inbound_mailbox_28.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.576. inbound_mailbox_28.RIRQT

Table 1646. axil_mailbox_smc_wrap.inbound_mailbox_28.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.577. inbound_mailbox_28.IRQS

Table 1647. axil_mailbox_smc_wrap.inbound_mailbox_28.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.578. inbound_mailbox_28.IRQEN

Table 1648. axil_mailbox_smc_wrap.inbound_mailbox_28.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.579. inbound_mailbox_28.IRQP

Table 1649. axil_mailbox_smc_wrap.inbound_mailbox_28.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.580. inbound_mailbox_28.CTRL

Table 1650. axil_mailbox_smc_wrap.inbound_mailbox_28.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.581. outbound_mailbox_29.WRITE_DATA

Table 1651. axil_mailbox_smc_wrap.outbound_mailbox_29.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.582. outbound_mailbox_29.READ_DATA

Table 1652. axil_mailbox_smc_wrap.outbound_mailbox_29.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.583. outbound_mailbox_29.STATUS

Table 1653. axil_mailbox_smc_wrap.outbound_mailbox_29.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.584. outbound_mailbox_29.ERROR_FLAGS

Table 1654. axil_mailbox_smc_wrap.outbound_mailbox_29.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.585. outbound_mailbox_29.WIRQT

Table 1655. axil_mailbox_smc_wrap.outbound_mailbox_29.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.586. outbound_mailbox_29.RIRQT

Table 1656. axil_mailbox_smc_wrap.outbound_mailbox_29.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.587. outbound_mailbox_29.IRQS

Table 1657. axil_mailbox_smc_wrap.outbound_mailbox_29.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.588. outbound_mailbox_29.IRQEN

Table 1658. axil_mailbox_smc_wrap.outbound_mailbox_29.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.589. outbound_mailbox_29.IRQP

Table 1659. axil_mailbox_smc_wrap.outbound_mailbox_29.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.590. outbound_mailbox_29.CTRL

Table 1660. axil_mailbox_smc_wrap.outbound_mailbox_29.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.591. inbound_mailbox_29.WRITE_DATA

Table 1661. axil_mailbox_smc_wrap.inbound_mailbox_29.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.592. inbound_mailbox_29.READ_DATA

Table 1662. axil_mailbox_smc_wrap.inbound_mailbox_29.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.593. inbound_mailbox_29.STATUS

Table 1663. axil_mailbox_smc_wrap.inbound_mailbox_29.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.594. inbound_mailbox_29.ERROR_FLAGS

Table 1664. axil_mailbox_smc_wrap.inbound_mailbox_29.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.595. inbound_mailbox_29.WIRQT

Table 1665. axil_mailbox_smc_wrap.inbound_mailbox_29.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.596. inbound_mailbox_29.RIRQT

Table 1666. axil_mailbox_smc_wrap.inbound_mailbox_29.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.597. inbound_mailbox_29.IRQS

Table 1667. axil_mailbox_smc_wrap.inbound_mailbox_29.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.598. inbound_mailbox_29.IRQEN

Table 1668. axil_mailbox_smc_wrap.inbound_mailbox_29.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.599. inbound_mailbox_29.IRQP

Table 1669. axil_mailbox_smc_wrap.inbound_mailbox_29.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.600. inbound_mailbox_29.CTRL

Table 1670. axil_mailbox_smc_wrap.inbound_mailbox_29.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.601. outbound_mailbox_30.WRITE_DATA

Table 1671. axil_mailbox_smc_wrap.outbound_mailbox_30.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.602. outbound_mailbox_30.READ_DATA

Table 1672. axil_mailbox_smc_wrap.outbound_mailbox_30.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.603. outbound_mailbox_30.STATUS

Table 1673. axil_mailbox_smc_wrap.outbound_mailbox_30.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.604. outbound_mailbox_30.ERROR_FLAGS

Table 1674. axil_mailbox_smc_wrap.outbound_mailbox_30.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.605. outbound_mailbox_30.WIRQT

Table 1675. axil_mailbox_smc_wrap.outbound_mailbox_30.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.606. outbound_mailbox_30.RIRQT

Table 1676. axil_mailbox_smc_wrap.outbound_mailbox_30.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.607. outbound_mailbox_30.IRQS

Table 1677. axil_mailbox_smc_wrap.outbound_mailbox_30.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.608. outbound_mailbox_30.IRQEN

Table 1678. axil_mailbox_smc_wrap.outbound_mailbox_30.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.609. outbound_mailbox_30.IRQP

Table 1679. axil_mailbox_smc_wrap.outbound_mailbox_30.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.610. outbound_mailbox_30.CTRL

Table 1680. axil_mailbox_smc_wrap.outbound_mailbox_30.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.611. inbound_mailbox_30.WRITE_DATA

Table 1681. axil_mailbox_smc_wrap.inbound_mailbox_30.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.612. inbound_mailbox_30.READ_DATA

Table 1682. axil_mailbox_smc_wrap.inbound_mailbox_30.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.613. inbound_mailbox_30.STATUS

Table 1683. axil_mailbox_smc_wrap.inbound_mailbox_30.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.614. inbound_mailbox_30.ERROR_FLAGS

Table 1684. axil_mailbox_smc_wrap.inbound_mailbox_30.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.615. inbound_mailbox_30.WIRQT

Table 1685. axil_mailbox_smc_wrap.inbound_mailbox_30.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.616. inbound_mailbox_30.RIRQT

Table 1686. axil_mailbox_smc_wrap.inbound_mailbox_30.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.617. inbound_mailbox_30.IRQS

Table 1687. axil_mailbox_smc_wrap.inbound_mailbox_30.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.618. inbound_mailbox_30.IRQEN

Table 1688. axil_mailbox_smc_wrap.inbound_mailbox_30.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.619. inbound_mailbox_30.IRQP

Table 1689. axil_mailbox_smc_wrap.inbound_mailbox_30.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.620. inbound_mailbox_30.CTRL

Table 1690. axil_mailbox_smc_wrap.inbound_mailbox_30.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.621. outbound_mailbox_31.WRITE_DATA

Table 1691. axil_mailbox_smc_wrap.outbound_mailbox_31.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.622. outbound_mailbox_31.READ_DATA

Table 1692. axil_mailbox_smc_wrap.outbound_mailbox_31.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.623. outbound_mailbox_31.STATUS

Table 1693. axil_mailbox_smc_wrap.outbound_mailbox_31.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.624. outbound_mailbox_31.ERROR_FLAGS

Table 1694. axil_mailbox_smc_wrap.outbound_mailbox_31.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.625. outbound_mailbox_31.WIRQT

Table 1695. axil_mailbox_smc_wrap.outbound_mailbox_31.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.626. outbound_mailbox_31.RIRQT

Table 1696. axil_mailbox_smc_wrap.outbound_mailbox_31.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.627. outbound_mailbox_31.IRQS

Table 1697. axil_mailbox_smc_wrap.outbound_mailbox_31.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.628. outbound_mailbox_31.IRQEN

Table 1698. axil_mailbox_smc_wrap.outbound_mailbox_31.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.629. outbound_mailbox_31.IRQP

Table 1699. axil_mailbox_smc_wrap.outbound_mailbox_31.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.630. outbound_mailbox_31.CTRL

Table 1700. axil_mailbox_smc_wrap.outbound_mailbox_31.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.1.631. inbound_mailbox_31.WRITE_DATA

Table 1701. axil_mailbox_smc_wrap.inbound_mailbox_31.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.1.632. inbound_mailbox_31.READ_DATA

Table 1702. axil_mailbox_smc_wrap.inbound_mailbox_31.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.1.633. inbound_mailbox_31.STATUS

Table 1703. axil_mailbox_smc_wrap.inbound_mailbox_31.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.1.634. inbound_mailbox_31.ERROR_FLAGS

Table 1704. axil_mailbox_smc_wrap.inbound_mailbox_31.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.1.635. inbound_mailbox_31.WIRQT

Table 1705. axil_mailbox_smc_wrap.inbound_mailbox_31.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.1.636. inbound_mailbox_31.RIRQT

Table 1706. axil_mailbox_smc_wrap.inbound_mailbox_31.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.1.637. inbound_mailbox_31.IRQS

Table 1707. axil_mailbox_smc_wrap.inbound_mailbox_31.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.1.638. inbound_mailbox_31.IRQEN

Table 1708. axil_mailbox_smc_wrap.inbound_mailbox_31.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.1.639. inbound_mailbox_31.IRQP

Table 1709. axil_mailbox_smc_wrap.inbound_mailbox_31.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.1.640. inbound_mailbox_31.CTRL

Table 1710. axil_mailbox_smc_wrap.inbound_mailbox_31.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2. SEP AXI-Lite Mailbox Wrapper Address Map

SEP-side wrapper instantiating the AXI-Lite mailbox pairs. Each outbound_mailbox_N / inbound_mailbox_N pair is the two apertures of one bidirectional mailbox and shares a single pair of FIFOs: data written through WRITE_DATA in one aperture is what READ_DATA in the other aperture returns. The outbound/inbound naming reflects intended use, not an access restriction.

Table 1711. SEP AXI-Lite Mailbox Wrapper Address Map register list

Address	Name	Access	Description
0x0	outbound_mailbox_0.WRITE_DATA	W	-
0x8	outbound_mailbox_0.READ_DATA	R	-
0x10	outbound_mailbox_0.STATUS	R	-
0x18	outbound_mailbox_0.ERROR_FLAGS	R	-
0x20	outbound_mailbox_0.WIRQT	RW	-
0x28	outbound_mailbox_0.RIRQT	RW	-
0x30	outbound_mailbox_0.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x38	outbound_mailbox_0.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x40	outbound_mailbox_0.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x48	outbound_mailbox_0.CTRL	W	-
0x800	inbound_mailbox_0.WRITE_DATA	W	-
0x808	inbound_mailbox_0.READ_DATA	R	-
0x810	inbound_mailbox_0.STATUS	R	-
0x818	inbound_mailbox_0.ERROR_FLAGS	R	-
0x820	inbound_mailbox_0.WIRQT	RW	-
0x828	inbound_mailbox_0.RIRQT	RW	-
0x830	inbound_mailbox_0.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x838	inbound_mailbox_0.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x840	inbound_mailbox_0.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x848	inbound_mailbox_0.CTRL	W	-
0x1000	outbound_mailbox_1.WRITE_DATA	W	-
0x1008	outbound_mailbox_1.READ_DATA	R	-
0x1010	outbound_mailbox_1.STATUS	R	-

Address	Name	Access	Description
0x1018	outbound_mailbox_1.ERROR_FLAGS	R	-
0x1020	outbound_mailbox_1.WIRQT	RW	-
0x1028	outbound_mailbox_1.RIRQT	RW	-
0x1030	outbound_mailbox_1.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1038	outbound_mailbox_1.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1040	outbound_mailbox_1.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1048	outbound_mailbox_1.CTRL	W	-
0x1800	inbound_mailbox_1.WRITE_DATA	W	-
0x1808	inbound_mailbox_1.READ_DATA	R	-
0x1810	inbound_mailbox_1.STATUS	R	-
0x1818	inbound_mailbox_1.ERROR_FLAGS	R	-
0x1820	inbound_mailbox_1.WIRQT	RW	-
0x1828	inbound_mailbox_1.RIRQT	RW	-
0x1830	inbound_mailbox_1.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x1838	inbound_mailbox_1.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x1840	inbound_mailbox_1.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x1848	inbound_mailbox_1.CTRL	W	-
0x2000	outbound_mailbox_2.WRITE_DATA	W	-
0x2008	outbound_mailbox_2.READ_DATA	R	-
0x2010	outbound_mailbox_2.STATUS	R	-
0x2018	outbound_mailbox_2.ERROR_FLAGS	R	-
0x2020	outbound_mailbox_2.WIRQT	RW	-
0x2028	outbound_mailbox_2.RIRQT	RW	-
0x2030	outbound_mailbox_2.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x2038	outbound_mailbox_2.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x2040	outbound_mailbox_2.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x2048	outbound_mailbox_2.CTRL	W	-
0x2800	inbound_mailbox_2.WRITE_DATA	W	-
0x2808	inbound_mailbox_2.READ_DATA	R	-
0x2810	inbound_mailbox_2.STATUS	R	-
0x2818	inbound_mailbox_2.ERROR_FLAGS	R	-
0x2820	inbound_mailbox_2.WIRQT	RW	-
0x2828	inbound_mailbox_2.RIRQT	RW	-
0x2830	inbound_mailbox_2.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.

Address	Name	Access	Description
0x2838	inbound_mailbox_2.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x2840	inbound_mailbox_2.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x2848	inbound_mailbox_2.CTRL	W	-
0x3000	outbound_mailbox_3.WRITE_DATA	W	-
0x3008	outbound_mailbox_3.READ_DATA	R	-
0x3010	outbound_mailbox_3.STATUS	R	-
0x3018	outbound_mailbox_3.ERROR_FLAGS	R	-
0x3020	outbound_mailbox_3.WIRQT	RW	-
0x3028	outbound_mailbox_3.RIRQT	RW	-
0x3030	outbound_mailbox_3.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x3038	outbound_mailbox_3.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x3040	outbound_mailbox_3.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x3048	outbound_mailbox_3.CTRL	W	-
0x3800	inbound_mailbox_3.WRITE_DATA	W	-
0x3808	inbound_mailbox_3.READ_DATA	R	-
0x3810	inbound_mailbox_3.STATUS	R	-
0x3818	inbound_mailbox_3.ERROR_FLAGS	R	-
0x3820	inbound_mailbox_3.WIRQT	RW	-
0x3828	inbound_mailbox_3.RIRQT	RW	-
0x3830	inbound_mailbox_3.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x3838	inbound_mailbox_3.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x3840	inbound_mailbox_3.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x3848	inbound_mailbox_3.CTRL	W	-
0x4000	outbound_mailbox_4.WRITE_DATA	W	-
0x4008	outbound_mailbox_4.READ_DATA	R	-
0x4010	outbound_mailbox_4.STATUS	R	-
0x4018	outbound_mailbox_4.ERROR_FLAGS	R	-
0x4020	outbound_mailbox_4.WIRQT	RW	-
0x4028	outbound_mailbox_4.RIRQT	RW	-
0x4030	outbound_mailbox_4.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x4038	outbound_mailbox_4.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x4040	outbound_mailbox_4.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x4048	outbound_mailbox_4.CTRL	W	-
0x4800	inbound_mailbox_4.WRITE_DATA	W	-

Address	Name	Access	Description
0x4808	inbound_mailbox_4.READ_DATA	R	-
0x4810	inbound_mailbox_4.STATUS	R	-
0x4818	inbound_mailbox_4.ERROR_FLAGS	R	-
0x4820	inbound_mailbox_4.WIRQT	RW	-
0x4828	inbound_mailbox_4.RIRQT	RW	-
0x4830	inbound_mailbox_4.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x4838	inbound_mailbox_4.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x4840	inbound_mailbox_4.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x4848	inbound_mailbox_4.CTRL	W	-
0x5000	outbound_mailbox_5.WRITE_DATA	W	-
0x5008	outbound_mailbox_5.READ_DATA	R	-
0x5010	outbound_mailbox_5.STATUS	R	-
0x5018	outbound_mailbox_5.ERROR_FLAGS	R	-
0x5020	outbound_mailbox_5.WIRQT	RW	-
0x5028	outbound_mailbox_5.RIRQT	RW	-
0x5030	outbound_mailbox_5.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x5038	outbound_mailbox_5.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x5040	outbound_mailbox_5.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x5048	outbound_mailbox_5.CTRL	W	-
0x5800	inbound_mailbox_5.WRITE_DATA	W	-
0x5808	inbound_mailbox_5.READ_DATA	R	-
0x5810	inbound_mailbox_5.STATUS	R	-
0x5818	inbound_mailbox_5.ERROR_FLAGS	R	-
0x5820	inbound_mailbox_5.WIRQT	RW	-
0x5828	inbound_mailbox_5.RIRQT	RW	-
0x5830	inbound_mailbox_5.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x5838	inbound_mailbox_5.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x5840	inbound_mailbox_5.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x5848	inbound_mailbox_5.CTRL	W	-
0x6000	outbound_mailbox_6.WRITE_DATA	W	-
0x6008	outbound_mailbox_6.READ_DATA	R	-
0x6010	outbound_mailbox_6.STATUS	R	-
0x6018	outbound_mailbox_6.ERROR_FLAGS	R	-
0x6020	outbound_mailbox_6.WIRQT	RW	-
0x6028	outbound_mailbox_6.RIRQT	RW	-

Address	Name	Access	Description
0x6030	outbound_mailbox_6.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x6038	outbound_mailbox_6.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x6040	outbound_mailbox_6.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x6048	outbound_mailbox_6.CTRL	W	-
0x6800	inbound_mailbox_6.WRITE_DATA	W	-
0x6808	inbound_mailbox_6.READ_DATA	R	-
0x6810	inbound_mailbox_6.STATUS	R	-
0x6818	inbound_mailbox_6.ERROR_FLAGS	R	-
0x6820	inbound_mailbox_6.WIRQT	RW	-
0x6828	inbound_mailbox_6.RIRQT	RW	-
0x6830	inbound_mailbox_6.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x6838	inbound_mailbox_6.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x6840	inbound_mailbox_6.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x6848	inbound_mailbox_6.CTRL	W	-
0x7000	outbound_mailbox_7.WRITE_DATA	W	-
0x7008	outbound_mailbox_7.READ_DATA	R	-
0x7010	outbound_mailbox_7.STATUS	R	-
0x7018	outbound_mailbox_7.ERROR_FLAGS	R	-
0x7020	outbound_mailbox_7.WIRQT	RW	-
0x7028	outbound_mailbox_7.RIRQT	RW	-
0x7030	outbound_mailbox_7.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x7038	outbound_mailbox_7.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x7040	outbound_mailbox_7.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x7048	outbound_mailbox_7.CTRL	W	-
0x7800	inbound_mailbox_7.WRITE_DATA	W	-
0x7808	inbound_mailbox_7.READ_DATA	R	-
0x7810	inbound_mailbox_7.STATUS	R	-
0x7818	inbound_mailbox_7.ERROR_FLAGS	R	-
0x7820	inbound_mailbox_7.WIRQT	RW	-
0x7828	inbound_mailbox_7.RIRQT	RW	-
0x7830	inbound_mailbox_7.IRQS	RW	This register is used to read and clear interrupt requests, regardless of IRQEN register and whether the interrupt is enabled or disabled.
0x7838	inbound_mailbox_7.IRQEN	RW	This register is used to enable and disable which interrupts are sent to the CPU.
0x7840	inbound_mailbox_7.IRQP	R	This register is used to read the current status of the interrupts sent to the CPU.
0x7848	inbound_mailbox_7.CTRL	W	-

2.1.6.7.4.4.2.2.2.1. outbound_mailbox_0.WRITE_DATA

Table 1712. axil_mailbox_sep_wrap.outbound_mailbox_0.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.2. outbound_mailbox_0.READ_DATA

Table 1713. axil_mailbox_sep_wrap.outbound_mailbox_0.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.3. outbound_mailbox_0.STATUS

Table 1714. axil_mailbox_sep_wrap.outbound_mailbox_0.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.4. outbound_mailbox_0.ERROR_FLAGS

Table 1715. axil_mailbox_sep_wrap.outbound_mailbox_0.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.5. outbound_mailbox_0.WIRQT

Table 1716. axil_mailbox_sep_wrap.outbound_mailbox_0.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.6. outbound_mailbox_0.RIRQT

Table 1717. axil_mailbox_sep_wrap.outbound_mailbox_0.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.7. outbound_mailbox_0.IRQS

Table 1718. axil_mailbox_sep_wrap.outbound_mailbox_0.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.8. outbound_mailbox_0.IRQEN

Table 1719. axil_mailbox_sep_wrap.outbound_mailbox_0.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.9. outbound_mailbox_0.IRQP

Table 1720. axil_mailbox_sep_wrap.outbound_mailbox_0.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.10. outbound_mailbox_0.CTRL

Table 1721. axil_mailbox_sep_wrap.outbound_mailbox_0.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.11. inbound_mailbox_0.WRITE_DATA

Table 1722. axil_mailbox_sep_wrap.inbound_mailbox_0.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.12. inbound_mailbox_0.READ_DATA

Table 1723. axil_mailbox_sep_wrap.inbound_mailbox_0.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.13. inbound_mailbox_0.STATUS

Table 1724. axil_mailbox_sep_wrap.inbound_mailbox_0.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.14. inbound_mailbox_0.ERROR_FLAGS

Table 1725. axil_mailbox_sep_wrap.inbound_mailbox_0.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.15. inbound_mailbox_0.WIRQT

Table 1726. axil_mailbox_sep_wrap.inbound_mailbox_0.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.16. inbound_mailbox_0.RIRQT

Table 1727. axil_mailbox_sep_wrap.inbound_mailbox_0.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.17. inbound_mailbox_0.IRQS

Table 1728. axil_mailbox_sep_wrap.inbound_mailbox_0.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.18. inbound_mailbox_0.IRQEN

Table 1729. axil_mailbox_sep_wrap.inbound_mailbox_0.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.19. inbound_mailbox_0.IRQP

Table 1730. axil_mailbox_sep_wrap.inbound_mailbox_0.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.20. inbound_mailbox_0.CTRL

Table 1731. axil_mailbox_sep_wrap.inbound_mailbox_0.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.21. outbound_mailbox_1.WRITE_DATA

Table 1732. axil_mailbox_sep_wrap.outbound_mailbox_1.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.22. outbound_mailbox_1.READ_DATA

Table 1733. axil_mailbox_sep_wrap.outbound_mailbox_1.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.23. outbound_mailbox_1.STATUS

Table 1734. axil_mailbox_sep_wrap.outbound_mailbox_1.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.24. outbound_mailbox_1.ERROR_FLAGS

Table 1735. axil_mailbox_sep_wrap.outbound_mailbox_1.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.25. outbound_mailbox_1.WIRQT

Table 1736. axil_mailbox_sep_wrap.outbound_mailbox_1.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.26. outbound_mailbox_1.RIRQT

Table 1737. axil_mailbox_sep_wrap.outbound_mailbox_1.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.27. outbound_mailbox_1.IRQS

Table 1738. axil_mailbox_sep_wrap.outbound_mailbox_1.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.28. outbound_mailbox_1.IRQEN

Table 1739. axil_mailbox_sep_wrap.outbound_mailbox_1.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.29. outbound_mailbox_1.IRQP

Table 1740. axil_mailbox_sep_wrap.outbound_mailbox_1.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.30. outbound_mailbox_1.CTRL

Table 1741. axil_mailbox_sep_wrap.outbound_mailbox_1.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.31. inbound_mailbox_1.WRITE_DATA

Table 1742. axil_mailbox_sep_wrap.inbound_mailbox_1.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.32. inbound_mailbox_1.READ_DATA

Table 1743. axil_mailbox_sep_wrap.inbound_mailbox_1.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.33. inbound_mailbox_1.STATUS

Table 1744. axil_mailbox_sep_wrap.inbound_mailbox_1.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.34. inbound_mailbox_1.ERROR_FLAGS

Table 1745. axil_mailbox_sep_wrap.inbound_mailbox_1.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.35. inbound_mailbox_1.WIRQT

Table 1746. axil_mailbox_sep_wrap.inbound_mailbox_1.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.36. inbound_mailbox_1.RIRQT

Table 1747. axil_mailbox_sep_wrap.inbound_mailbox_1.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.37. inbound_mailbox_1.IRQS

Table 1748. axil_mailbox_sep_wrap.inbound_mailbox_1.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.38. inbound_mailbox_1.IRQEN

Table 1749. axil_mailbox_sep_wrap.inbound_mailbox_1.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.39. inbound_mailbox_1.IRQP

Table 1750. axil_mailbox_sep_wrap.inbound_mailbox_1.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.40. inbound_mailbox_1.CTRL

Table 1751. axil_mailbox_sep_wrap.inbound_mailbox_1.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.41. outbound_mailbox_2.WRITE_DATA

Table 1752. axil_mailbox_sep_wrap.outbound_mailbox_2.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.42. outbound_mailbox_2.READ_DATA

Table 1753. axil_mailbox_sep_wrap.outbound_mailbox_2.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.43. outbound_mailbox_2.STATUS

Table 1754. axil_mailbox_sep_wrap.outbound_mailbox_2.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.44. outbound_mailbox_2.ERROR_FLAGS

Table 1755. axil_mailbox_sep_wrap.outbound_mailbox_2.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.45. outbound_mailbox_2.WIRQT

Table 1756. axil_mailbox_sep_wrap.outbound_mailbox_2.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.46. outbound_mailbox_2.RIRQT

Table 1757. axil_mailbox_sep_wrap.outbound_mailbox_2.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.47. outbound_mailbox_2.IRQS

Table 1758. axil_mailbox_sep_wrap.outbound_mailbox_2.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.48. outbound_mailbox_2.IRQEN

Table 1759. axil_mailbox_sep_wrap.outbound_mailbox_2.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.49. outbound_mailbox_2.IRQP

Table 1760. axil_mailbox_sep_wrap.outbound_mailbox_2.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.50. outbound_mailbox_2.CTRL

Table 1761. axil_mailbox_sep_wrap.outbound_mailbox_2.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.51. inbound_mailbox_2.WRITE_DATA

Table 1762. axil_mailbox_sep_wrap.inbound_mailbox_2.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.52. inbound_mailbox_2.READ_DATA

Table 1763. axil_mailbox_sep_wrap.inbound_mailbox_2.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.53. inbound_mailbox_2.STATUS

Table 1764. axil_mailbox_sep_wrap.inbound_mailbox_2.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.54. inbound_mailbox_2.ERROR_FLAGS

Table 1765. axil_mailbox_sep_wrap.inbound_mailbox_2.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.55. inbound_mailbox_2.WIRQT

Table 1766. axil_mailbox_sep_wrap.inbound_mailbox_2.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.56. inbound_mailbox_2.RIRQT

Table 1767. axil_mailbox_sep_wrap.inbound_mailbox_2.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.57. inbound_mailbox_2.IRQS

Table 1768. axil_mailbox_sep_wrap.inbound_mailbox_2.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.58. inbound_mailbox_2.IRQEN

Table 1769. axil_mailbox_sep_wrap.inbound_mailbox_2.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.59. inbound_mailbox_2.IRQP

Table 1770. axil_mailbox_sep_wrap.inbound_mailbox_2.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.60. inbound_mailbox_2.CTRL

Table 1771. axil_mailbox_sep_wrap.inbound_mailbox_2.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.61. outbound_mailbox_3.WRITE_DATA

Table 1772. axil_mailbox_sep_wrap.outbound_mailbox_3.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.62. outbound_mailbox_3.READ_DATA

Table 1773. axil_mailbox_sep_wrap.outbound_mailbox_3.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.63. outbound_mailbox_3.STATUS

Table 1774. axil_mailbox_sep_wrap.outbound_mailbox_3.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.64. outbound_mailbox_3.ERROR_FLAGS

Table 1775. axil_mailbox_sep_wrap.outbound_mailbox_3.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.65. outbound_mailbox_3.WIRQT

Table 1776. axil_mailbox_sep_wrap.outbound_mailbox_3.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.66. outbound_mailbox_3.RIRQT

Table 1777. axil_mailbox_sep_wrap.outbound_mailbox_3.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.67. outbound_mailbox_3.IRQS

Table 1778. axil_mailbox_sep_wrap.outbound_mailbox_3.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.68. outbound_mailbox_3.IRQEN

Table 1779. axil_mailbox_sep_wrap.outbound_mailbox_3.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.69. outbound_mailbox_3.IRQP

Table 1780. axil_mailbox_sep_wrap.outbound_mailbox_3.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.70. outbound_mailbox_3.CTRL

Table 1781. axil_mailbox_sep_wrap.outbound_mailbox_3.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.71. inbound_mailbox_3.WRITE_DATA

Table 1782. axil_mailbox_sep_wrap.inbound_mailbox_3.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.72. inbound_mailbox_3.READ_DATA

Table 1783. axil_mailbox_sep_wrap.inbound_mailbox_3.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.73. inbound_mailbox_3.STATUS

Table 1784. axil_mailbox_sep_wrap.inbound_mailbox_3.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.74. inbound_mailbox_3.ERROR_FLAGS

Table 1785. axil_mailbox_sep_wrap.inbound_mailbox_3.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.75. inbound_mailbox_3.WIRQT

Table 1786. axil_mailbox_sep_wrap.inbound_mailbox_3.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.76. inbound_mailbox_3.RIRQT

Table 1787. axil_mailbox_sep_wrap.inbound_mailbox_3.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.77. inbound_mailbox_3.IRQS

Table 1788. axil_mailbox_sep_wrap.inbound_mailbox_3.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.78. inbound_mailbox_3.IRQEN

Table 1789. axil_mailbox_sep_wrap.inbound_mailbox_3.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.79. inbound_mailbox_3.IRQP

Table 1790. axil_mailbox_sep_wrap.inbound_mailbox_3.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.80. inbound_mailbox_3.CTRL

Table 1791. axil_mailbox_sep_wrap.inbound_mailbox_3.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.81. outbound_mailbox_4.WRITE_DATA

Table 1792. axil_mailbox_sep_wrap.outbound_mailbox_4.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.82. outbound_mailbox_4.READ_DATA

Table 1793. axil_mailbox_sep_wrap.outbound_mailbox_4.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.83. outbound_mailbox_4.STATUS

Table 1794. axil_mailbox_sep_wrap.outbound_mailbox_4.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.84. outbound_mailbox_4.ERROR_FLAGS

Table 1795. axil_mailbox_sep_wrap.outbound_mailbox_4.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.85. outbound_mailbox_4.WIRQT

Table 1796. axil_mailbox_sep_wrap.outbound_mailbox_4.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.86. outbound_mailbox_4.RIRQT

Table 1797. axil_mailbox_sep_wrap.outbound_mailbox_4.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.87. outbound_mailbox_4.IRQS

Table 1798. axil_mailbox_sep_wrap.outbound_mailbox_4.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.88. outbound_mailbox_4.IRQEN

Table 1799. axil_mailbox_sep_wrap.outbound_mailbox_4.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.89. outbound_mailbox_4.IRQP

Table 1800. axil_mailbox_sep_wrap.outbound_mailbox_4.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.90. outbound_mailbox_4.CTRL

Table 1801. axil_mailbox_sep_wrap.outbound_mailbox_4.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.91. inbound_mailbox_4.WRITE_DATA

Table 1802. axil_mailbox_sep_wrap.inbound_mailbox_4.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.92. inbound_mailbox_4.READ_DATA

Table 1803. axil_mailbox_sep_wrap.inbound_mailbox_4.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.93. inbound_mailbox_4.STATUS

Table 1804. axil_mailbox_sep_wrap.inbound_mailbox_4.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.94. inbound_mailbox_4.ERROR_FLAGS

Table 1805. axil_mailbox_sep_wrap.inbound_mailbox_4.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.95. inbound_mailbox_4.WIRQT

Table 1806. axil_mailbox_sep_wrap.inbound_mailbox_4.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.96. inbound_mailbox_4.RIRQT

Table 1807. axil_mailbox_sep_wrap.inbound_mailbox_4.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.97. inbound_mailbox_4.IRQS

Table 1808. axil_mailbox_sep_wrap.inbound_mailbox_4.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.98. inbound_mailbox_4.IRQEN

Table 1809. axil_mailbox_sep_wrap.inbound_mailbox_4.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.99. inbound_mailbox_4.IRQP

Table 1810. axil_mailbox_sep_wrap.inbound_mailbox_4.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.100. inbound_mailbox_4.CTRL

Table 1811. axil_mailbox_sep_wrap.inbound_mailbox_4.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.101. outbound_mailbox_5.WRITE_DATA

Table 1812. axil_mailbox_sep_wrap.outbound_mailbox_5.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.102. outbound_mailbox_5.READ_DATA

Table 1813. axil_mailbox_sep_wrap.outbound_mailbox_5.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.103. outbound_mailbox_5.STATUS

Table 1814. axil_mailbox_sep_wrap.outbound_mailbox_5.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.104. outbound_mailbox_5.ERROR_FLAGS

Table 1815. axil_mailbox_sep_wrap.outbound_mailbox_5.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.105. outbound_mailbox_5.WIRQT

Table 1816. axil_mailbox_sep_wrap.outbound_mailbox_5.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.106. outbound_mailbox_5.RIRQT

Table 1817. axil_mailbox_sep_wrap.outbound_mailbox_5.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.107. outbound_mailbox_5.IRQS

Table 1818. axil_mailbox_sep_wrap.outbound_mailbox_5.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.108. outbound_mailbox_5.IRQEN

Table 1819. axil_mailbox_sep_wrap.outbound_mailbox_5.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.109. outbound_mailbox_5.IRQP

Table 1820. axil_mailbox_sep_wrap.outbound_mailbox_5.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.110. outbound_mailbox_5.CTRL

Table 1821. axil_mailbox_sep_wrap.outbound_mailbox_5.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.111. inbound_mailbox_5.WRITE_DATA

Table 1822. axil_mailbox_sep_wrap.inbound_mailbox_5.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.112. inbound_mailbox_5.READ_DATA

Table 1823. axil_mailbox_sep_wrap.inbound_mailbox_5.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.113. inbound_mailbox_5.STATUS

Table 1824. axil_mailbox_sep_wrap.inbound_mailbox_5.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.114. inbound_mailbox_5.ERROR_FLAGS

Table 1825. axil_mailbox_sep_wrap.inbound_mailbox_5.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.115. inbound_mailbox_5.WIRQT

Table 1826. axil_mailbox_sep_wrap.inbound_mailbox_5.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.116. inbound_mailbox_5.RIRQT

Table 1827. axil_mailbox_sep_wrap.inbound_mailbox_5.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.117. inbound_mailbox_5.IRQS

Table 1828. axil_mailbox_sep_wrap.inbound_mailbox_5.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.118. inbound_mailbox_5.IRQEN

Table 1829. axil_mailbox_sep_wrap.inbound_mailbox_5.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.119. inbound_mailbox_5.IRQP

Table 1830. axil_mailbox_sep_wrap.inbound_mailbox_5.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.120. inbound_mailbox_5.CTRL

Table 1831. axil_mailbox_sep_wrap.inbound_mailbox_5.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.121. outbound_mailbox_6.WRITE_DATA

Table 1832. axil_mailbox_sep_wrap.outbound_mailbox_6.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.122. outbound_mailbox_6.READ_DATA

Table 1833. axil_mailbox_sep_wrap.outbound_mailbox_6.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.123. outbound_mailbox_6.STATUS

Table 1834. axil_mailbox_sep_wrap.outbound_mailbox_6.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.124. outbound_mailbox_6.ERROR_FLAGS

Table 1835. axil_mailbox_sep_wrap.outbound_mailbox_6.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.125. outbound_mailbox_6.WIRQT

Table 1836. axil_mailbox_sep_wrap.outbound_mailbox_6.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.126. outbound_mailbox_6.RIRQT

Table 1837. axil_mailbox_sep_wrap.outbound_mailbox_6.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.127. outbound_mailbox_6.IRQS

Table 1838. axil_mailbox_sep_wrap.outbound_mailbox_6.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.128. outbound_mailbox_6.IRQEN

Table 1839. axil_mailbox_sep_wrap.outbound_mailbox_6.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.129. outbound_mailbox_6.IRQP

Table 1840. axil_mailbox_sep_wrap.outbound_mailbox_6.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.130. outbound_mailbox_6.CTRL

Table 1841. axil_mailbox_sep_wrap.outbound_mailbox_6.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.131. inbound_mailbox_6.WRITE_DATA

Table 1842. axil_mailbox_sep_wrap.inbound_mailbox_6.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.132. inbound_mailbox_6.READ_DATA

Table 1843. axil_mailbox_sep_wrap.inbound_mailbox_6.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.133. inbound_mailbox_6.STATUS

Table 1844. axil_mailbox_sep_wrap.inbound_mailbox_6.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.134. inbound_mailbox_6.ERROR_FLAGS

Table 1845. axil_mailbox_sep_wrap.inbound_mailbox_6.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.135. inbound_mailbox_6.WIRQT

Table 1846. axil_mailbox_sep_wrap.inbound_mailbox_6.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.136. inbound_mailbox_6.RIRQT

Table 1847. axil_mailbox_sep_wrap.inbound_mailbox_6.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.137. inbound_mailbox_6.IRQS

Table 1848. axil_mailbox_sep_wrap.inbound_mailbox_6.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.138. inbound_mailbox_6.IRQEN

Table 1849. axil_mailbox_sep_wrap.inbound_mailbox_6.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.139. inbound_mailbox_6.IRQP

Table 1850. axil_mailbox_sep_wrap.inbound_mailbox_6.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.140. inbound_mailbox_6.CTRL

Table 1851. axil_mailbox_sep_wrap.inbound_mailbox_6.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.141. outbound_mailbox_7.WRITE_DATA

Table 1852. axil_mailbox_sep_wrap.outbound_mailbox_7.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.142. outbound_mailbox_7.READ_DATA

Table 1853. axil_mailbox_sep_wrap.outbound_mailbox_7.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.143. outbound_mailbox_7.STATUS

Table 1854. axil_mailbox_sep_wrap.outbound_mailbox_7.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.144. outbound_mailbox_7.ERROR_FLAGS

Table 1855. axil_mailbox_sep_wrap.outbound_mailbox_7.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.145. outbound_mailbox_7.WIRQT

Table 1856. axil_mailbox_sep_wrap.outbound_mailbox_7.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.146. outbound_mailbox_7.RIRQT

Table 1857. axil_mailbox_sep_wrap.outbound_mailbox_7.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.147. outbound_mailbox_7.IRQS

Table 1858. axil_mailbox_sep_wrap.outbound_mailbox_7.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.148. outbound_mailbox_7.IRQEN

Table 1859. axil_mailbox_sep_wrap.outbound_mailbox_7.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.149. outbound_mailbox_7.IRQP

Table 1860. axil_mailbox_sep_wrap.outbound_mailbox_7.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.150. outbound_mailbox_7.CTRL

Table 1861. axil_mailbox_sep_wrap.outbound_mailbox_7.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.4.4.2.2.2.151. inbound_mailbox_7.WRITE_DATA

Table 1862. axil_mailbox_sep_wrap.inbound_mailbox_7.WRITE_DATA fields

Bits	Field	Access	Reset	Description
63:0	write_data	W WMOD	0x0	Write data to mailbox fifo

2.1.6.7.4.4.2.2.2.152. inbound_mailbox_7.READ_DATA

Table 1863. axil_mailbox_sep_wrap.inbound_mailbox_7.READ_DATA fields

Bits	Field	Access	Reset	Description
63:0	read_data	R RMOD	-	Read data from mailbox fifo

2.1.6.7.4.4.2.2.2.153. inbound_mailbox_7.STATUS

Table 1864. axil_mailbox_sep_wrap.inbound_mailbox_7.STATUS fields

Bits	Field	Access	Reset	Description
63:4	Reserved	-	-	Reserved
3	read_level_above_thresh	R	0x0	If set, read fifo level is higher than threshold set in RIRQT
2	write_level_above_thresh	R	0x0	If set, write fifo level is higher than threshold set in WIRQT
1	full	R	0x0	0: Space is available to write, 1: Space is not available to write
0	empty	R	0x1	0: Data is available to read, 1: Data is not available to read

2.1.6.7.4.4.2.2.2.154. inbound_mailbox_7.ERROR_FLAGS

Table 1865. axil_mailbox_sep_wrap.inbound_mailbox_7.ERROR_FLAGS fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	write_error	R RC	0x0	Attempted write to a full mailbox
0	read_error	R RC	0x0	Attempted read from an empty mailbox

2.1.6.7.4.4.2.2.2.155. inbound_mailbox_7.WIRQT

Table 1866. axil_mailbox_sep_wrap.inbound_mailbox_7.WIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved
7:0	wirqt	RW	0x0	When the usage pointer of the FIFO connected to the W channel exceeds this value, a write threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the write FIFO is full.

2.1.6.7.4.4.2.2.2.156. inbound_mailbox_7.RIRQT

Table 1867. axil_mailbox_sep_wrap.inbound_mailbox_7.RIRQT fields

Bits	Field	Access	Reset	Description
63:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:0	rirqt	RW	0x0	When the fill pointer of the FIFO connected to the R channel exceeds this value, a read threshold IRQ is triggered and the corresponding STATUS register bit is set. When a value larger than or equal to the MailboxDepth parameter is written to this register, it gets reduced to MailboxDepth - 1 to ensure an IRQ is triggered when the read FIFO is full.

2.1.6.7.4.4.2.2.2.157. inbound_mailbox_7.IRQS

Table 1868. axil_mailbox_sep_wrap.inbound_mailbox_7.IRQS fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Error on mailbox access On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
1	rtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in read mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request
0	wtirq	RW1C	0x0	On read: [0]: No interrupt request [1]: Usage level threshold in write mailbox exceeded On write: [0]: No acknowledge [1]: Acknowledge and clear interrupt request

2.1.6.7.4.4.2.2.2.158. inbound_mailbox_7.IRQEN

Table 1869. axil_mailbox_sep_wrap.inbound_mailbox_7.IRQEN fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	RW	0x0	[0]: Error IRQ disabled [1]: Error IRQ enabled
1	rtirq	RW	0x0	[0]: Read threshold IRQ disabled [1]: Read threshold IRQ enabled
0	wtirq	RW	0x0	[0]: Write threshold IRQ disabled [1]: Write threshold IRQ enabled

2.1.6.7.4.4.2.2.2.159. inbound_mailbox_7.IRQP

Table 1870. axil_mailbox_sep_wrap.inbound_mailbox_7.IRQP fields

Bits	Field	Access	Reset	Description
63:3	Reserved	-	-	Reserved
2	eirq	R	0x0	[0]: No error IRQ pending [1]: Error IRQ pending
1	rtirq	R	0x0	[0]: No read threshold IRQ pending [1]: Read threshold IRQ pending
0	wtirq	R	0x0	[0]: No write threshold IRQ pending [1]: Write threshold IRQ pending

2.1.6.7.4.4.2.2.2.160. inbound_mailbox_7.CTRL

Table 1871. axil_mailbox_sep_wrap.inbound_mailbox_7.CTRL fields

Bits	Field	Access	Reset	Description
63:2	Reserved	-	-	Reserved
1	rflush	W WMOD	0x0	Flush the read FIFO for this port
0	wflush	W WMOD	0x0	Flush the write FIFO for this port

2.1.6.7.5. System Timer OCTS

2.1.6.7.5.1. Overview

The System Timer implements Open Chiplet Time Synchronization (OCTS). A primary timer counts local clock cycles and sends load and credit pulses to secondary timers. Each secondary advances between pulses, then corrects its count at the next credit boundary.

The counter is 64 bits. Its time unit depends on the primary clock; resolution and alignment accuracy also depend on the clock ratios, pulse routing and synchronization delay. The block does not guarantee nanosecond accuracy or simultaneous sampling across chiplets.

Software configures the timer through a 32-bit AXI4-Lite interface. The `is_primary_i` input selects its role. The sections below cover counting, synchronization constraints, setup and register access.

2.1.6.7.5.2. Operation

Figure 65 shows how primary and secondary timers exchange synchronization information. The dashed groups hold the logic that acts in only one mode, as `is_primary_i` selects it; the enable and the 64-bit count serve both. The inbound sync-load and credit pulses cross into `clk_i` through a flop and a `prim_edge_detector`, which synchronizes them with two flops and turns each rising edge into a one-cycle pulse; an AND gate with `is_primary_i` on its inverted input masks each pulse in PRIMARY mode. The enable flop is sticky: an OR gate holds it set once a PRIMARY-mode `TIMER_START.START` or a sync-load pulse has set it. In SECONDARY mode, the sync-load pulse loads the preset, a credit pulse moves the count to the expected count plus CREDIT_VAL, and between pulses the count advances by `CTRL.STEP`, which drives the core's `timer_cnt_step_i`, while credits are left. The credit tracking block holds the `cur_credits` accumulator, which adds STEP each cycle while it is below CREDIT_VAL (`credits_left`); the expected count, which `u_adder_expected_credit` advances by CREDIT_VAL on each credit pulse; and the `credit_expired_o` counter of cycles spent without credits. Both inbound pulses reset `cur_credits` and `credit_expired_o`. In PRIMARY mode, the count advances by one, and the credit counter and pulse state machine drive the outbound pulses. The wrapper keeps the longest credit-starved run reported by the core in a flop that loads the larger of its own value and `credit_expired_o`, and reads it back as `CREDIT_EXPIRED`; a write to `CREDIT_EXPIRED` clears both. In the SMC, the timer pulses use GPIO pads 55 and 56, which drive them on the primary chiplet and sample them on a secondary one.




Figure 65. System Timer OCTS primary/secondary synchronization and credit CDC

2.1.6.7.5.2.1. Counting and Synchronization

A write of 1 to `TIMER_START.START` starts the primary and loads `TIMER_PRESET_HI:LO`. The primary then increments by one on each `clk_i` cycle. It ignores synchronization inputs and generates load and credit pulses for the secondaries.

A secondary loads its own preset when it detects a rising edge on `timer_sync_load_i`. On each credit edge, it advances its expected count by `CTRL.CREDIT_VAL` and replaces its actual count with that expected value. Between edges, it increments by `CTRL.STEP` while credits remain. This replacement is a correction, not just a diagnostic comparison: a secondary count can move backward if its previous increments overshot the boundary.

Table 1872. OCTS credit management

Role	Behavior
Primary	An 8-bit interval counter generates a credit event every `CREDIT_VAL` cycles while enabled. START clears this interval counter.
Secondary	A 9-bit consumed-credit counter starts at zero on load or credit edges. While it is less than `CREDIT_VAL`, both it and the timer advance by `STEP`. Counting pauses once the credit limit is reached.

Choose a nonzero secondary `STEP` appropriate to the clock ratio. The limit is checked before adding the step, so the last increment can cross it. A lost credit pulse also leaves the expected count behind the primary; receiving a later credit does not recover the missing interval.

2.1.6.7.5.2.2. Pulse Generation and Clock Crossing

Table 1873. OCTS pulse states

State	Behavior
PULSE_IDLE	Accept START, or a credit event while enabled. START has priority.
PULSE_SYNC_LOAD	Assert the primary load output for the configured width.
PULSE_CREDIT	Assert the primary credit output for the configured width.

CTRL.PULSE_WIDTH sets the high duration in primary clock cycles; zero is treated as one. CREDIT_VAL must exceed this effective width. The FSM accepts triggers only while idle and does not queue them. In particular, START can reload the primary count while an active pulse prevents a new load pulse; use a coordinated reset and setup sequence for restarting.

Each synchronization input passes through an input flop, a two-flop synchronizer and an edge detector in the receiving clock domain. Pulses must stay high long enough to be sampled and low long enough to distinguish successive events. Determine those intervals from the destination clock, routing delay and CDC analysis; the RTL defines no universal frequency ratio, nanosecond timing guarantee or fixed system-wide alignment bound.

2.1.6.7.5.2.3. Status and Credit Expiration

STATUS.MODE is 0 for primary and 1 for secondary. STATUS.RUNNING is set when the internal enable is set and the count is nonzero. It can therefore remain set while a secondary is paused for lack of credit, or remain clear immediately after loading a zero preset. It is not a synchronization check.

The secondary core counts cycles spent without credit. Load and credit edges clear this interval counter. The register wrapper retains the largest observed value in CREDIT_EXPIRED; writing any value clears the saved maximum, while only a load or credit pulse clears the running interval counter in the core. Normal credit reception does not clear the saved maximum. In a primary configured from reset, it stays zero.

Use this value to detect waiting for credit, with thresholds derived from the clock ratio and pulse interval. It does not directly measure timestamp error or prove that all credit pulses arrived.

2.1.6.7.5.2.4. Reset

rst_ni asynchronously clears the counter, enable, pulse state and registers. Reset release must meet the integration's timing requirements; this block does not synchronize reset deassertion internally.

Enable is sticky after a PRIMARY-mode START or a received load edge. There is no stop CSR; writing START=0 does not stop counting. Configure role and timing before starting, and use system reset when a coordinated reconfiguration is needed.

2.1.6.7.5.3. Interface

The System Timer OCTS IP has a 32-bit AXI4-Lite register interface. The is_primary_i input selects PRIMARY or SECONDARY mode at runtime. All signals are synchronous to clk_i except timer_sync_load_i and timer_cnt_credit_i, which are synchronized internally as described in Section 2.1.6.7.5.2.2.

2.1.6.7.5.3.1. Ports

The ports of system_timer_octs are listed in the HTML edition of this manual, under RTL Modules Reference.

system_timer_octs has no parameters. Its AXI4-Lite request and response types, with 32-bit address and data, are defined

in system_timer_octs_pkg.

2.1.6.7.5.3.2. OCTS Synchronization Interface

When operating in PRIMARY mode, the timer generates synchronization pulses: timer_sync_load_o is asserted for CTRL.PULSE_WIDTH cycles when the START register is written, and timer_cnt_credit_o is asserted for CTRL.PULSE_WIDTH cycles every CTRL.CREDIT_VAL cycles. Any synchronization input signals are ignored in PRIMARY mode. In contrast, SECONDARY mode relies on input from the PRIMARY: timer_sync_load_i directs the timer to initialize using a preset value, and timer_cnt_credit_i delivers credit pulses that allow continuous synchronization. In this mode, the outputs remain inactive.

2.1.6.7.5.3.3. Timer Count

timer_count_o is the live 64-bit count, also readable through TIMER_COUNT_LO and TIMER_COUNT_HI. A PRIMARY advances it by one each clk_i cycle. A SECONDARY advances it by CTRL.STEP each cycle while credits remain.

2.1.6.7.5.3.4. Timing

The RTL defines no setup, hold or clock-to-output limit, maximum clock frequency or frequency ratio between OCTS clock domains. Clock frequency, jitter, reset timing and physical timing constraints must come from the integration timing specification.

Synchronization inputs cross into clk_i as described in Section 2.1.6.7.5.2.2; derive the required pulse high and low intervals from the destination clock and CDC analysis. Reset behavior is described in Section 2.1.6.7.5.2.4.

2.1.6.7.5.4. Memory Map and Register Reference

2.1.6.7.5.4.1. Memory Map

The register bank occupies 0x00–0x23 and uses 32-bit AXI4-Lite accesses. Use the enclosing subsystem's memory map for its base address.

Table 1874. OCTS register offsets and reset values

Register	Offset	Reset	Meaning
TIMER_START	0x00	0	START is a single-cycle command.
CTRL	0x04	0x0001020A	STEP=1, PULSE_WIDTH=2, CREDIT_VAL=10.
STATUS	0x08	0	MODE subsequently reflects the role input; RUNNING reflects enable and nonzero count.
TIMER_PRESET_LO/HI	0x0C/0x10	0	Two independently writable preset halves.
TIMER_COUNT_LO/HI	0x14/0x18	0	Live count halves, with no snapshot latch; the timestamp read sequence is in the Programmer's Guide.
CREDIT_EXPIRED	0x1C	0	Saved maximum wait for credit; any write clears it.
TIMER_GPIO_ENABLE	0x20	0	Timer GPIO LSIO selection starts disabled.

2.1.6.7.5.4.2. Detailed Register Map

2.1.6.7.5.4.2.1. OCTS System Timer Address Map

Open Chiplet Time Synchronization (OCTS) System Timer Registers

Table 1875. OCTS System Timer Address Map register list

Address	Name	Access	Description
0x0	TIMER_START	RW	System Timer Start Register
0x4	CTRL	RW	System Timer Control Register
0x8	STATUS	R	System Timer Status Register
0xC	TIMER_PRESET_LO	RW	System Timer Preset Value [31:0]
0x10	TIMER_PRESET_HI	RW	System Timer Preset Value [63:32]
0x14	TIMER_COUNT_LO	R	Current System Timer Count [31:0]
0x18	TIMER_COUNT_HI	R	Current System Timer Count [63:32]
0x1C	CREDIT_EXPIRED	RW	Credit Expired Register
0x20	TIMER_GPIO_ENABLE	RW	System Timer GPIO Enable Register

2.1.6.7.5.4.2.1.1. TIMER_START

Table 1876. system_timer_octs.TIMER_START fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	START	RW 1P	0x0	Start the system timer. In PRIMARY mode, a write of 1 loads the preset and pulses the sync-load output for PULSE_WIDTH cycles. In SECONDARY mode, the write has no effect; a secondary starts on the primary's sync-load pulse, which is what loads its preset. Ensure both primary and secondary are out of reset.

2.1.6.7.5.4.2.1.2. CTRL

Table 1877. system_timer_octs.CTRL fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	STEP	RW	0x1	Step amount for secondary timer
15:8	PULSE_WIDTH	RW	0x2	Pulse width for sync load and credit signals. A value of 0 will be rounded up to 1. WARNING: This value must be less than CREDIT_VAL
7:0	CREDIT_VAL	RW	0xA	Credit value factor. WARNING: This value must be greater than PULSE_WIDTH

2.1.6.7.5.4.2.1.3. STATUS

Table 1878. system_timer_octs.STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	RUNNING	R	0x0	Timer is enabled and its count is nonzero.
3:1	Reserved	-	-	Reserved
0	MODE	R	0x0	Timer mode driven by the is_primary_i input: 0=PRIMARY (is_primary_i=1), 1=SECONDARY (is_primary_i=0).

2.1.6.7.5.4.2.1.4. TIMER_PRESET_LO

Table 1879. system_timer_octs.TIMER_PRESET_LO fields

Bits	Field	Access	Reset	Description
31:0	PRESET_LO	RW	0x0	Lower 32 bits of preset value

2.1.6.7.5.4.2.1.5. TIMER_PRESET_HI

Table 1880. system_timer_octs.TIMER_PRESET_HI fields

Bits	Field	Access	Reset	Description
31:0	PRESET_HI	RW	0x0	Upper 32 bits of preset value

2.1.6.7.5.4.2.1.6. TIMER_COUNT_LO

Table 1881. system_timer_octs.TIMER_COUNT_LO fields

Bits	Field	Access	Reset	Description
31:0	COUNT_LO	R	0x0	Lower 32 bits of current timer count

2.1.6.7.5.4.2.1.7. TIMER_COUNT_HI

Table 1882. system_timer_octs.TIMER_COUNT_HI fields

Bits	Field	Access	Reset	Description
31:0	COUNT_HI	R	0x0	Upper 32 bits of current timer count

2.1.6.7.5.4.2.1.8. CREDIT_EXPIRED

Table 1883. system_timer_octs.CREDIT_EXPIRED fields

Bits	Field	Access	Reset	Description
31:0	MAX_CYCLES_EXPIRED	RW	0x0	Maximum number of clock cycles since a count credit expired (SECONDARY only). To reset the value of this register, write anything to it. If this number is very high (exact value depends on clock speed and credit value), this indicates that the secondary has not received a count credit pulse in a while, and is likely not syncing properly with the primary. This register can also be used to determine the clock skew between the primary and secondary. If PRIMARY, this field is always 0.

2.1.6.7.5.4.2.1.9. TIMER_GPIO_ENABLE

Table 1884. system_timer_octs.TIMER_GPIO_ENABLE fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	GPIO_ENABLE	RW	0x0	Enable the GPIO pad lsio interface for the system timer. This is done to prevent X-prop on reset into the secondary timer, which can cause the secondary timer to start counting early.

2.1.6.7.6. eFuse

NOTE In this chapter, **eFuse** and **OTP** are used interchangeably.

2.1.6.7.6.1. Overview

The eFuse IP provides secure One-Time Programmable (OTP) memory access for the OCAH system. A foundry-agnostic controller caches the array into shadow registers at boot, then exposes program and read operations over AXI4-Lite with layered hardware and software locks. Foundry-specific timing and macro signaling sit behind a replaceable SHIM so the software interface stays the same across OTP technologies.

2.1.6.7.6.2. Description and Features

- **Boot-time fuse sense**: An automatic bulk read loads the full OTP array into shadow registers so later CSR access is not bound to OTP timing.
- **Dual AXI4-Lite paths**: SMC is the functional access path; JTAG is the debug path, with lifecycle-dependent restrictions.
- **Lifecycle and token gating**: SEP instances further restrict access by lifecycle state, secure test mode, and RMA or security-disable tokens.

2.1.6.7.6.3. Architecture

The eFuse IP provides secure One-Time Programmable (OTP) memory management with foundry-agnostic design. The layered architecture separates security control logic from foundry-specific implementation details, enabling deployment across different OTP technologies while maintaining consistent security characteristics and software interfaces.

2.1.6.7.6.3.1. Interface Controller

The eFuse Interface Controller (efuse_interface_controller.sv) provides dual-path access control with security policy enforcement.

2.1.6.7.6.3.2. Access Paths

- **SMC AXI4-Lite Interface**: Functional access for normal system operations
- **JTAG AXI4-Lite Interface**: Debug access for manufacturing test and development

2.1.6.7.6.3.3. Command-path ownership

After fuse sense completes, software program and read requests share one command path to the OTP bank. `EFUSE_PROGRAM_CTRL.program_enable` takes that path in preference to `EFUSE_READ_CTRL.read_enable`, so the two enables must be asserted exclusively; a read issued while `program_enable` is set does not reach the bank. The program and read sequences are in the eFuse section of the Programmer's Guide.

2.1.6.7.6.3.4. Destination Endpoints

Table 1885 identifies the consumers of sensed fuse data.

Table 1885. eFuse destination endpoints

Endpoint	Description
Shadow Registers	High-performance boot-time caching for rapid access without OTP timing constraints
eFuse CSR	Control and status registers for read, program, and verification operations
MMR	Memory-Mapped Registers for SEP security tokens with specialized access control
Interface SHIM CSR	Configuration registers for foundry-specific timing adaptation. Implemented by the adopter, but always accessed via the interface controller.

2.1.6.7.6.3.5. Shadow Register Subsystem

The shadow register subsystem accelerates OTP access by caching eFuse contents at boot time. On power-up, a dedicated FSM automatically issues a bulk read command (with `access_length_words` set to cover the full eFuse bank), copying all OTP data into the shadow registers. This ensures the shadow registers are fully populated and always synchronized with the OTP state at each boot.

2.1.6.7.6.3.6. Features

Table 1886 summarises the shadow-register capacity and access features.

Table 1886. eFuse shadow-register features

Feature	Description
Capacity	Configurable (default: 8192 bits / 1KB, 256 × 32-bit words), set via the `SHADOW_REG_BITS` parameter
Initialization	Automatic boot-time loading via Fuse Sense FSM
Access Control	Multi-tier hardware and software lock mechanisms
Data Consistency	Maintains synchronization with underlying OTP storage upon each power-on reset

2.1.6.7.6.3.7. State Machine Architecture

The read interface FSM (efuse_read_interface.sv) operates in a simple two-state sequence, transitioning from idle to waiting for a response as it handles on-demand eFuse reads that fall outside the shadow register cache. This mechanism works alongside the shadow subsystem, providing direct access only when necessary, and actively reports status to support robust error handling and retry logic.

The program interface FSM (efuse_program_interface.sv) enforces the write-once nature of OTP hardware, ensuring that programmed data cannot be altered once set. It supports write-and-verify procedures for reliability, integrating verification steps that check programmed values against intended data, and fully blocks any unauthorized overwrites to maintain data integrity.

Readback Capture Behavior:

When a read command completes successfully, the read interface captures data from the SHIM response into the read-data CSR during the ST_WAIT_RESP state. This data is retained and continues to be available after the FSM returns to idle, allowing software to retrieve the result without a re-read.

2.1.6.7.6.3.8. Parameterized Command Typedefs

The fuse command request/response structs exchanged between the controller and the SHIM are not declared with fixed types. Instead, they are generated from parameterized preprocessor macros defined in `efuse_typedef.svh`. This keeps the command interface technology-agnostic: each integration supplies its own address, data, access-length, and command types, while the macros guarantee a consistent struct layout and field ordering across all OTP variants.

Table 1887 relates each command macro to its generated type and purpose.

Table 1887. eFuse command type macros

Macro	Generated Type	Purpose
`EFUSE_COMMAND_REQ_T`	`fuse_command_req_t`	Controller-to-SHIM command request
`EFUSE_COMMAND_RESP_T`	`fuse_command_resp_t`	SHIM-to-controller command response

The request macro is parameterized over the struct name plus four payload types (`addr_t`, `data_t`, `access_length_words_t`,

command_t), allowing the controller to size the address space, transfer length, and command encoding to match the target OTP technology:

```
`define EFUSE_COMMAND_REQ_T(fuse_command_req_t, addr_t, data_t, access_length_words_t,
command_t)  \
  typedef struct packed {                                    \
    addr_t                   address;             // Target address       \
    logic                    program_data;        // Data to program (1'b1) \
    access_length_words_t    access_length_words; // Transfer size        \
    command_t                command;             // Command type         \
    logic                    valid;               // Request valid        \
  } fuse_command_req_t;
```

The response macro is parameterized over the struct name and the data_t read-data type:

```
`define EFUSE_COMMAND_RESP_T(fuse_command_resp_t, data_t)       \
  typedef struct packed {                                      \
    data_t              data;       // Read data               \
    logic               status;     // Operation status        \
    logic               valid;      // Response valid           \
  } fuse_command_resp_t;
```

A typical instantiation expands both macros with the integration's local types:

```
`EFUSE_COMMAND_REQ_T(fuse_command_req_t, addr_t, data_t, access_length_words_t,
command_t)
`EFUSE_COMMAND_RESP_T(fuse_command_resp_t, data_t)
```

2.1.6.7.6.3.9. Foundry-Specific Signals

Table 1888 compares the signals required by the supported OTP interface variants.

Table 1888. Example Hardware Interfaces by OTP Variant

OTP Variant	Hardware Interface Signals
Adopter OTP macro	Adopter-defined macro-side signals
Current Example Model	APB interface with register-based control

2.1.6.7.6.3.10. Interface SHIM Layer

The Interface SHIM (efuse_interface_shim.sv) is an example, foundry-specific implementation of the custom fuse command interface. Its role is to translate the controller's generic commands into the signaling expected by a particular OTP macro; in this reference version the macro-side interface is APB, but a real integration would replace this with the foundry's native signals.

The SHIM decodes three command types from the controller:

- **Read** — fetch one or more words from the bank.
- **Program** — burn new bits into the bank.
- **Program/read-back** — program, then read back to verify success.

It implements these with dedicated read and program FSMs that sequence the macro-side transactions and return a `fuse_command_resp_t` to the controller. Foundry-specific timing and configuration (for example, program pulse widths) are exposed through the SHIM Control CSRs, accessed over the `fuse_bank_ctrl` AXI4-Lite interface.

2.1.6.7.6.3.11. eFuse Bank Model

The eFuse bank model (`efuse_bank_model.sv`) is a reference, simulation-only stand-in for the real foundry OTP macro. It is a 3KB (768 x 32-bit word) store fronted by a standard APB interface, and it emulates the set-once behavior of real OTP so the controller and SHIM can be exercised end-to-end without silicon. In a production integration it is replaced by the actual foundry macro driven by the SHIM.

2.1.6.7.6.3.12. Access Permissions and Security

Access control is layered for defense in depth: per-field permissions are described by `efuse_field_map_i`, lock state is enforced by the eFuse guard (`efuse_guard.sv`), security-disable tokens are validated, and access can additionally be gated by the chip lifecycle state.

Each eFuse field is described by a `rule_t` entry that pairs an address range with a 4-bit `lock` permission field:

```
typedef struct packed {
    logic [EfuseFieldMapIdxWidth-1:0] idx;        // Field index
    logic [3:0]                       lock;       // Permission bits
    logic [31:0]                      start_addr; // Field start address
    logic [31:0]                      end_addr;   // Field end address
} rule_t;
```

The `lock` field encodes read, write, and secure-test-mode permissions for the field (Table 1889).

Table 1889. eFuse lock-field encoding

Bits	Function	Encoding
`lock[0]`	Read	`0` = readable, `1` = read-locked
`lock[2:1]`	Write	`00` = unlocked, `10` = set-only (1's may be added, never cleared), `11` = write-locked
`lock[3]`	Secure-test write lock	`1` adds a shadow write lock while secure test mode is active; `0` adds no such lock. Other locks still apply.

2.1.6.7.6.3.13. Hardware vs. Software Locks

The same permission semantics are reached through two independent mechanisms, and the guard enforces whichever is more restrictive (Table 1890).

Table 1890. eFuse hardware and software locks

Property	Hardware Lock	Software Lock
Source	Permission bits fused into the eFuse array (the field map reflects the programmed values)	Runtime writes to the `LOCKS` CSR (write-1-to-set)

Property	Hardware Lock	Software Lock
Persistence	Permanent — backed by one-time-programmable bits and cannot be cleared once set	Volatile — retained only until the next system reset
Reversibility	Irreversible by any means	Cleared by reset, allowing the field to be re-opened
Typical use	Final production lockdown of provisioned secrets	Temporary protection during boot, debug, or staged provisioning

Because software locks are write-1-to-set, firmware can tighten access at runtime but can never loosen a restriction without a reset; hardware locks cannot be loosened at all. On top of these per-field locks, sensitive fields can be further gated by the chip lifecycle state and by secure test mode (`lock[3]`), so a field may be accessible in one operational mode and fully blocked in another even when its read/write bits are clear.

For sensitive functions, such as those governed by the MMR registers, the system enforces token-based security. Only by providing the correct 256-bit tokens, such as the RMA SOP Token for state transitions, the RMA Chiplet Token for chiplet-specific operations, or the Security Disable Token to override protections, can access to these resources be granted.

2.1.6.7.6.3.14. Security Disable Bypass Mechanism

The eFuse interface controller supports a security disable bypass mechanism via the `security_disable_i` input signal. This mechanism is primarily used for test and debug scenarios where the automatic fuse sensing sequence needs to be bypassed.

Behavior when `security_disable_i` is asserted:

Table 1891 describes the sensing behavior when security_disable_i is asserted.

Table 1891. eFuse security-disable behavior

Behavior	Description
FSM Bypass	The automatic fuse sensing state machine is bypassed and does not issue read commands to the physical eFuse bank.
Shadow Register Output	Shadow register values are output directly to downstream logic via `shadow_regs_o`, regardless of `fuse_sense_done` status.
Shadow Register Loading	Shadow registers are not loaded from fuse command responses; they retain their reset values (all zeros for SMC).
APB Access	APB access to shadow registers is permitted without waiting for `fuse_sense_done` completion.
Reset Values	When the system is in reset state with `security_disable_i` asserted, shadow registers are initialized to zero (default reset value for SMC).

For SMC, the internal security disable signal is directly driven by the `security_disable_i` input port.

2.1.6.7.6.3.15. Lifecycle State (LC_STATE) Effects

The eFuse interface controller enforces access restrictions based on the chip's lifecycle state.

Lifecycle State Encoding:

Table 1892 lists the lifecycle encodings used by the eFuse controller.

Table 1892. eFuse lifecycle encodings

State	Encoding	Description
TEST_DEV	0x0	Test/Development state (default)

State	Encoding	Description
PROD	0x1	Production state
PROD_DBG	0x1 + DEMOTE=1	Production Debug (volatile, clears on reset)
RMA_SOP	0x2, 0x3	RMA System-in-Package
RMA_CHIPLET	0x6-0x7	RMA Chiplet level
PROD_END	0x8	Production End (terminal state)
INVALID	All others	Invalid state (error fallback)

JTAG Access Control Based on LC_STATE:

JTAG access policies differ between SMC and SEP variants. The table below describes the SMC variant policy, which restricts JTAG access in production and RMA states. SEP applies a different policy: in restricted states (PROD or RMA_SIP), JTAG accesses to the MMR (token register) space remain allowed for token programming; accesses outside the MMR space are blocked with an error response.

SMC JTAG Policy:

When lifecycle state is PROD (0x1) or RMA_SOP (0x2, 0x3), JTAG access to eFuse registers is restricted (Table 1893).

Table 1893. eFuse JTAG permissions (SMC)

Access Type	PROD/RMA_SOP State	Other States
JTAG Write	**Blocked** (error response)	Allowed
JTAG Read	**Blocked** except JTAG_PUBLIC_IDENTITY	Allowed
JTAG Read JTAG_PUBLIC_IDENTITY	Allowed	Allowed

The access control mechanism uses an AXI-Lite demux that routes blocked requests to an error slave. When a request is blocked, the error slave returns an error response with data value `0xbadcab1e`.

SMC exception for JTAG_PUBLIC_IDENTITY:

Even in PROD or RMA_SOP states, JTAG read access to the JTAG_PUBLIC_IDENTITY register is permitted. This allows identification of the chip for manufacturing and field returns without exposing sensitive eFuse contents.

2.1.6.7.6.3.16. Secure Test Mode (secure_tm_i)

The eFuse interface controller supports a Secure Test Mode via the `secure_tm_i` input signal. This mode provides additional protection for sensitive security assets during secure manufacturing test operations.

Behavior when `secure_tm_i` is asserted:

Table 1894 describes the restrictions applied when secure_tm_i is asserted.

Table 1894. eFuse secure-test behavior

Behavior	Description
Fuse Command Blocking	All fuse commands to the physical eFuse bank are blocked. The guard logic filters incoming requests and returns default responses.
RMA Token Protection	RMA SOP and RMA Chiplet tokens are disconnected from shadow register outputs (set to zero), preventing token exposure during test.
Write Lock Contribution	Secure test mode contributes to write lock status, preventing shadow register modifications.

Behavior	Description
Response Behavior	When fuse commands are blocked, default response values (all zeros) are returned to requesters.

SMC Configuration:

For SMC, `secure_tm_i` is tied to logic `0`, meaning Secure Test Mode is not active during normal SMC operation. This signal is primarily relevant for SEP where sensitive RMA tokens must be protected during manufacturing test flows.

2.1.6.7.6.4. Interface

2.1.6.7.6.4.1. Configuration Parameters

The OTP has a total storage capacity of 1 KB, organized as 256 words of 32 bits.

The parameters and ports of `efuse_interface_controller` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.6.7.6.4.2. Main AXI4-Lite Interfaces

The eFuse controller provides two AXI4-Lite interfaces for register access: functional access from the SMC and debug access from JTAG.

2.1.6.7.6.4.3. Fuse Bank Control Interface

AXI4-Lite interface to the fuse bank control registers in the SHIM, carried on `fuse_bank_ctrl_req_o` and `fuse_bank_ctrl_resp_i` of types `efuse_axil_req_t` and `efuse_axil_resp_t`. The controller forwards accesses outside its own address windows on this interface.

2.1.6.7.6.4.4. Fuse Command Interface

Custom interface for SHIM state machine communication.

2.1.6.7.6.4.5. Security and Control Signals

The controller has no lifecycle-state input port. When `HAS_LC_STATE` is set, it takes the lifecycle state from the fuses: during fuse sensing it loads the low `LC_STATE_WIDTH` bits of shadow word `efuse_pkg::ShadowIdxLcState` and stores them differentially encoded in the shadow map. The shadow word index is fixed in `efuse_pkg`. `LC_STATE_BIT_POSITION` is used only by the guard, which derives the RMA SiP and chiplet token bit addresses from it as `LC_STATE_BIT_POSITION + 1` and `LC_STATE_BIT_POSITION + 2`.

2.1.6.7.6.4.6. Fuse Command Protocol

Custom command interface between controller and SHIM:

Request Structure (`fuse_command_req_t`):

```
typedef struct packed {
    addr_t                  address;           // Target address in bits
    logic                   program_data;      // Data to program (1'b1)
    access_length_words_t   access_length_words; // Transfer size
    command_t               command;           // Command type
```

```
    logic                    valid;            // Request valid
} fuse_command_req_t;
```

Response Structure (`fuse_command_resp_t`):

```
typedef struct packed {
    data_t              data;       // Read data
    logic               status;     // Operation status
    logic               valid;      // Response valid
} fuse_command_resp_t;
```

Command Types:

- `FUSE_COMMAND_READ (2'b00)`: Read operation
- `FUSE_COMMAND_PROGRAM (2'b01)`: Program operation
- `FUSE_COMMAND_PROGRAM_READ_BACK (2'b10)`: Program with verification

2.1.6.7.6.5. Memory Map and Register Reference

2.1.6.7.6.5.1. Memory Map

eFuse is not one universally placed address space. SEP, SMC, and the Key Manager pass-through expose different subsets and placements. The generated tables below compose those integration-specific views from their canonical SystemRDL roots.

Table 1895. SEP eFuse Placement

Base Address	End Address	Size	Decoded Extent	Unit	Description
0x10930000	0x109303FF	1 KiB	1 KiB	Shadow Registers	Cached eFuse shadow registers.
0x10930400	0x109304FF	256 B	28 B	eFuse Control CSR	eFuse command and status registers.
0x10930500	0x109305FF	256 B	116 B	MMR Registers	eFuse security-token registers.

Table 1896. SMC eFuse Placement

Address Range	Size	Decoded Extent	Unit	Description
BASE + 0x7000 – BASE + 0x7FFF	4 KiB	1 KiB	Shadow Registers	Address map for efuse shadow registers providing access to various chip configuration and ID fields
BASE + 0x8000 – BASE + 0x8FFF	4 KiB	28 B	eFuse Control CSR	eFuse command and status registers.

Table 1897. Key Manager eFuse Pass-Through

Base Address	End Address	Size	Decoded Extent	Unit	Description
0x00011000	0x000113FF	1 KiB	1 KiB	Shadow Registers	SEP eFuse shadow-register pass-through.

Base Address	End Address	Size	Decoded Extent	Unit	Description
0x00011400	0x000114FF	256 B	28 B	eFuse Control CSR	SEP eFuse command and status pass-through.
0x00011500	0x000115FF	256 B	116 B	MMR Registers	SEP eFuse security-token pass-through.

At the IP boundary, each region's base address and aperture size are integration parameters; the generated tables show the selected integration values. The MMR region exists only when the eFuse instance includes lifecycle state (`HAS_LC_STATE=1`).

2.1.6.7.6.5.2. Detailed Register Map

2.1.6.7.6.5.2.1. Shadow Registers

The shadow registers provide cached read access to eFuse contents, loaded automatically from the physical eFuse array during boot. The field layout is defined by the SystemRDL sources of the instantiating subsystem; the generated table below is authoritative for addresses, widths, and access rights of the instance documented in this section.

2.1.6.7.6.5.2.1.1. Efuse address map of physical efuse macro

Address map for efuse shadow registers providing access to various chip configuration and ID fields

NOTE

Register Arrays:

- **I2C_I3C_ID[9]**: 9 registers, base 0x28, stride 0x8
- **SPARE[28]**: 28 registers, base 0x80, stride 0x20

Table 1898. Efuse address map of physical efuse macro register list

Address	Name	Access	Description
0x0	LOCKS	RW	Lock controls for each fuse field. When write locked, the corresponding field is not programmable. When read locked, the shadow register is not readable.
0x8	JTAG_PUBLIC_IDENTITY	RW	JTAG-public exception window. In PROD and RMA_SiP, JTAG reads of this range are admitted while JTAG access to every other fuse field is blocked. Encoding is adopter-defined; the harness does not interpret or consume the value. The slot-0 read lock still hides the bits when set.
0x28 - 0x68	I2C_I3C_ID[9]	RW	I2C/I3C interface ID
0x70	SMC_CONFIG	RW	SMC boot and configuration controls sourced from fuse. Only the low word carries assigned bits, so firmware reads it as a single 32-bit access.
0x78	OCCP_TRANSPORT_TIMEOUT	RW	OCCP transport timeout in the low word; upper word reserved.
0x80 - 0x3E0	SPARE[28]	RW	Individually lockable 256-bit spare region, reserved for fields assigned after the RTL is frozen. Each element has its own write/read lock pair in LOCKS.

2.1.6.7.6.5.2.1.1.1. LOCKS

Table 1899. smc_efuse_map.LOCKS fields

Bits	Field	Access	Reset	Description
63	`spare27_read_lock`	RW1S	0x0	Spare 27 read lock (slot 31). When set, SPARE[27] is not readable.

Bits	Field	Access	Reset	Description
62	spare27_write_lock	RW1S	0x0	Spare 27 write lock (slot 31). When set, SPARE[27] is not writable.
61	spare26_read_lock	RW1S	0x0	Spare 26 read lock (slot 30). When set, SPARE[26] is not readable.
60	spare26_write_lock	RW1S	0x0	Spare 26 write lock (slot 30). When set, SPARE[26] is not writable.
59	spare25_read_lock	RW1S	0x0	Spare 25 read lock (slot 29). When set, SPARE[25] is not readable.
58	spare25_write_lock	RW1S	0x0	Spare 25 write lock (slot 29). When set, SPARE[25] is not writable.
57	spare24_read_lock	RW1S	0x0	Spare 24 read lock (slot 28). When set, SPARE[24] is not readable.
56	spare24_write_lock	RW1S	0x0	Spare 24 write lock (slot 28). When set, SPARE[24] is not writable.
55	spare23_read_lock	RW1S	0x0	Spare 23 read lock (slot 27). When set, SPARE[23] is not readable.
54	spare23_write_lock	RW1S	0x0	Spare 23 write lock (slot 27). When set, SPARE[23] is not writable.
53	spare22_read_lock	RW1S	0x0	Spare 22 read lock (slot 26). When set, SPARE[22] is not readable.
52	spare22_write_lock	RW1S	0x0	Spare 22 write lock (slot 26). When set, SPARE[22] is not writable.
51	spare21_read_lock	RW1S	0x0	Spare 21 read lock (slot 25). When set, SPARE[21] is not readable.
50	spare21_write_lock	RW1S	0x0	Spare 21 write lock (slot 25). When set, SPARE[21] is not writable.
49	spare20_read_lock	RW1S	0x0	Spare 20 read lock (slot 24). When set, SPARE[20] is not readable.
48	spare20_write_lock	RW1S	0x0	Spare 20 write lock (slot 24). When set, SPARE[20] is not writable.
47	spare19_read_lock	RW1S	0x0	Spare 19 read lock (slot 23). When set, SPARE[19] is not readable.
46	spare19_write_lock	RW1S	0x0	Spare 19 write lock (slot 23). When set, SPARE[19] is not writable.
45	spare18_read_lock	RW1S	0x0	Spare 18 read lock (slot 22). When set, SPARE[18] is not readable.
44	spare18_write_lock	RW1S	0x0	Spare 18 write lock (slot 22). When set, SPARE[18] is not writable.
43	spare17_read_lock	RW1S	0x0	Spare 17 read lock (slot 21). When set, SPARE[17] is not readable.
42	spare17_write_lock	RW1S	0x0	Spare 17 write lock (slot 21). When set, SPARE[17] is not writable.
41	spare16_read_lock	RW1S	0x0	Spare 16 read lock (slot 20). When set, SPARE[16] is not readable.
40	spare16_write_lock	RW1S	0x0	Spare 16 write lock (slot 20). When set, SPARE[16] is not writable.
39	spare15_read_lock	RW1S	0x0	Spare 15 read lock (slot 19). When set, SPARE[15] is not readable.
38	spare15_write_lock	RW1S	0x0	Spare 15 write lock (slot 19). When set, SPARE[15] is not writable.
37	spare14_read_lock	RW1S	0x0	Spare 14 read lock (slot 18). When set, SPARE[14] is not readable.
36	spare14_write_lock	RW1S	0x0	Spare 14 write lock (slot 18). When set, SPARE[14] is not writable.
35	spare13_read_lock	RW1S	0x0	Spare 13 read lock (slot 17). When set, SPARE[13] is not readable.
34	spare13_write_lock	RW1S	0x0	Spare 13 write lock (slot 17). When set, SPARE[13] is not writable.
33	spare12_read_lock	RW1S	0x0	Spare 12 read lock (slot 16). When set, SPARE[12] is not readable.
32	spare12_write_lock	RW1S	0x0	Spare 12 write lock (slot 16). When set, SPARE[12] is not writable.
31	spare11_read_lock	RW1S	0x0	Spare 11 read lock (slot 15). When set, SPARE[11] is not readable.
30	spare11_write_lock	RW1S	0x0	Spare 11 write lock (slot 15). When set, SPARE[11] is not writable.
29	spare10_read_lock	RW1S	0x0	Spare 10 read lock (slot 14). When set, SPARE[10] is not readable.
28	spare10_write_lock	RW1S	0x0	Spare 10 write lock (slot 14). When set, SPARE[10] is not writable.
27	spare9_read_lock	RW1S	0x0	Spare 9 read lock (slot 13). When set, SPARE[9] is not readable.
26	spare9_write_lock	RW1S	0x0	Spare 9 write lock (slot 13). When set, SPARE[9] is not writable.
25	spare8_read_lock	RW1S	0x0	Spare 8 read lock (slot 12). When set, SPARE[8] is not readable.
24	spare8_write_lock	RW1S	0x0	Spare 8 write lock (slot 12). When set, SPARE[8] is not writable.
23	spare7_read_lock	RW1S	0x0	Spare 7 read lock (slot 11). When set, SPARE[7] is not readable.
22	spare7_write_lock	RW1S	0x0	Spare 7 write lock (slot 11). When set, SPARE[7] is not writable.

Bits	Field	Access	Reset	Description
21	spare6_read_lock	RW1S	0x0	Spare 6 read lock (slot 10). When set, SPARE[6] is not readable.
20	spare6_write_lock	RW1S	0x0	Spare 6 write lock (slot 10). When set, SPARE[6] is not writable.
19	spare5_read_lock	RW1S	0x0	Spare 5 read lock (slot 9). When set, SPARE[5] is not readable.
18	spare5_write_lock	RW1S	0x0	Spare 5 write lock (slot 9). When set, SPARE[5] is not writable.
17	spare4_read_lock	RW1S	0x0	Spare 4 read lock (slot 8). When set, SPARE[4] is not readable.
16	spare4_write_lock	RW1S	0x0	Spare 4 write lock (slot 8). When set, SPARE[4] is not writable.
15	spare3_read_lock	RW1S	0x0	Spare 3 read lock (slot 7). When set, SPARE[3] is not readable.
14	spare3_write_lock	RW1S	0x0	Spare 3 write lock (slot 7). When set, SPARE[3] is not writable.
13	spare2_read_lock	RW1S	0x0	Spare 2 read lock (slot 6). When set, SPARE[2] is not readable.
12	spare2_write_lock	RW1S	0x0	Spare 2 write lock (slot 6). When set, SPARE[2] is not writable.
11	spare1_read_lock	RW1S	0x0	Spare 1 read lock (slot 5). When set, SPARE[1] is not readable.
10	spare1_write_lock	RW1S	0x0	Spare 1 write lock (slot 5). When set, SPARE[1] is not writable.
9	spare0_read_lock	RW1S	0x0	Spare 0 read lock (slot 4). When set, SPARE[0] is not readable.
8	spare0_write_lock	RW1S	0x0	Spare 0 write lock (slot 4). When set, SPARE[0] is not writable.
7	occp_transport_timeout_read_lock	RW1S	0x0	OCCP transport timeout read lock (slot 3). When set, OCCP_TRANSPORT_TIMEOUT is not readable.
6	occp_transport_timeout_write_lock	RW1S	0x0	OCCP transport timeout write lock (slot 3). When set, OCCP_TRANSPORT_TIMEOUT is not writable.
5	smc_config_read_lock	RW1S	0x0	SMC config read lock (slot 2). When set, SMC_CONFIG is not readable.
4	smc_config_write_lock	RW1S	0x0	SMC config write lock (slot 2). When set, SMC_CONFIG is not writable.
3	i2c_i3c_id_read_lock	RW1S	0x0	I2C/I3C ID read lock (slot 1). When set, no I2C_I3C_ID element is readable.
2	i2c_i3c_id_write_lock	RW1S	0x0	I2C/I3C ID write lock (slot 1). When set, no I2C_I3C_ID element is writable.
1	jtag_public_identity_read_lock	RW1S	0x0	JTAG public identity read lock (slot 0). When set, JTAG_PUBLIC_IDENTITY is not readable.
0	jtag_public_identity_write_lock	RW1S	0x0	JTAG public identity write lock (slot 0). When set, JTAG_PUBLIC_IDENTITY is not writable.

2.1.6.7.6.5.2.1.1.2. JTAG_PUBLIC_IDENTITY

Table 1900. smc_efuse_map.JTAG_PUBLIC_IDENTITY fields

Bits	Field	Access	Reset	Description
255:0	value	RW	0x0	Opaque payload. Encoding is adopter-defined; the harness does not interpret it.

2.1.6.7.6.5.2.1.1.3. I2C_I3C_ID[9]

Table 1901. smc_efuse_map.I2C_I3C_ID[9] fields

Bits	Field	Access	Reset	Description
63:0	interface_id	RW	0x0	I2C or I3C ID configuration: * Static ID mode: [6:0] contains ID, [63:7] reserved * Provisional ID mode: [63:0] full ID

2.1.6.7.6.5.2.1.1.4. SMC_CONFIG

Table 1902. smc_efuse_map.SMC_CONFIG fields

Bits	Field	Access	Reset	Description
63:16	config_rsvd_high	RW	0x0	Reserved for future configuration bits.
15	dft_ignore_error	RW	0x0	When set, boot continues despite a reported memory repair or MBIST failure.
14:8	config_rsvd_mid	RW	0x0	Reserved for future configuration bits.
7	sram_auto_zero_disable	RW	0x0	When set, boot skips the SRAM auto-zero initialisation pass.
6:1	config_rsvd_low	RW	0x0	Reserved for future configuration bits.
0	rom_flip_endianness	RW	0x0	When set, the ROM interface swaps byte order on instruction fetch.

2.1.6.7.6.5.2.1.1.5. OCCP_TRANSPORT_TIMEOUT

Table 1903. smc_efuse_map.OCCP_TRANSPORT_TIMEOUT fields

Bits	Field	Access	Reset	Description
63:32	timeout_rsvd	RW	0x0	Reserved for extension of the timeout encoding.
31:0	timeout	RW	0x0	Transport timeout value consumed by the boot ROM OCCP driver.

2.1.6.7.6.5.2.1.1.6. SPARE[28]

Table 1904. smc_efuse_map.SPARE[28] fields

Bits	Field	Access	Reset	Description
255:0	rsvd	RW	0x0	Spare fuse bits for future use.

2.1.6.7.6.5.2.2. MMR Registers

The MMR (Memory Mapped Register) space provides access to security tokens for authentication, including RMA tokens and security disable tokens.

2.1.6.7.6.5.2.2.1. eFuse Token Registers Address Map

Security-token input and match-status registers for RMA and secure-disable eFuse tokens.

NOTE

Register Arrays:

- **RMA_SIP_TOKEN_I[8]**: 8 registers, base 0x0, stride 0x4
- **RMA_CHIPLET_TOKEN_I[8]**: 8 registers, base 0x20, stride 0x4
- **SEC_DISABLE_TOKEN_I[8]**: 8 registers, base 0x40, stride 0x4

Table 1905. eFuse Token Registers Address Map register list

Address	Name	Access	Description
0x0 - 0x1C	RMA_SIP_TOKEN_I[8]	RW	Software-writeable RMA token word. The assembled token is hashed and compared against the fused value to authorize lifecycle (LC) state transitions.
0x20 - 0x3C	RMA_CHIPLET_TOKEN_I[8]	RW	Software-writeable RMA token word. The assembled token is hashed and compared against the fused value to authorize lifecycle (LC) state transitions.
0x40 - 0x5C	SEC_DISABLE_TOKEN_I[8]	RW	Software-writeable security-disable token word. The assembled token is hashed and compared against the post-silicon injected value to authorize security_disable.

Address	Name	Access	Description
0x60	TOKEN_EOP	W	Token end-of-packet control. Writing the per-token go bit signals that all token words have been written and triggers a pulse to begin token hashing.
0x64	RMA_SIP_TOKEN_MATCH	R	Token match status. Reports the result of the token hash comparison (match, mismatch, or error).
0x68	RMA_CHIPLET_TOKEN_MATCH	R	Token match status. Reports the result of the token hash comparison (match, mismatch, or error).
0x6C	SEC_DISABLE_TOKEN_MATCH	R	Token match status. Reports the result of the token hash comparison (match, mismatch, or error).
0x70	TOKEN_MATCH_FAULT	R	Token comparator redundancy fault status. The token match logic is triple redundant and is not a majority vote: all three comparators must agree and each must drive a legal differential pair. A bit sets when the comparators for that token disagree, which may indicate a fault injection or FIB attack. The corresponding token_match_status then reads the error code 6'b111111 and an interrupt is raised to the SEP CPU. Bits are sticky until reset.

2.1.6.7.6.5.2.2.1.1. RMA_SIP_TOKEN_I[8]

Table 1906. efuse_mmr.RMA_SIP_TOKEN_I[8] fields

Bits	Field	Access	Reset	Description
31:0	token	RW	-	Portion of writeable version of RMA_*_TOKEN, hashed, and compared with fused value to allow LC to change states.

2.1.6.7.6.5.2.2.1.2. RMA_CHIPLET_TOKEN_I[8]

Table 1907. efuse_mmr.RMA_CHIPLET_TOKEN_I[8] fields

Bits	Field	Access	Reset	Description
31:0	token	RW	-	Portion of writeable version of RMA_*_TOKEN, hashed, and compared with fused value to allow LC to change states.

2.1.6.7.6.5.2.2.1.3. SEC_DISABLE_TOKEN_I[8]

Table 1908. efuse_mmr.SEC_DISABLE_TOKEN_I[8] fields

Bits	Field	Access	Reset	Description
31:0	token	RW	-	Portion of writeable version of SEC_DISABLE_TOKEN, hashed, and compared with the post silicon injected values to allow security_disable.

2.1.6.7.6.5.2.2.1.4. TOKEN_EOP

Table 1909. efuse_mmr.TOKEN_EOP fields

Bits	Field	Access	Reset	Description
31:17	Reserved	-	-	Reserved
16	secure_disable_token_go	W 1P	0x0	Write 1 to indicate that all token data has been written; this generates a pulse to begin token hashing.
15:9	Reserved	-	-	Reserved
8	rma_chiplet_token_go	W 1P	0x0	Write 1 to indicate that all token data has been written; this generates a pulse to begin token hashing.
7:1	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
0	rma_sip_token_go	W 1P	0x0	Write 1 to indicate that all token data has been written; this generates a pulse to begin token hashing.

2.1.6.7.6.5.2.2.1.5. RMA_SIP_TOKEN_MATCH

Table 1910. efuse_mmr.RMA_SIP_TOKEN_MATCH fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	token_match_status	R	0x0	Store the status of the token match. Match = 6'b010101, Mismatch = 6'b101010, Error = 6'b111111

2.1.6.7.6.5.2.2.1.6. RMA_CHIPLET_TOKEN_MATCH

Table 1911. efuse_mmr.RMA_CHIPLET_TOKEN_MATCH fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	token_match_status	R	0x0	Store the status of the token match. Match = 6'b010101, Mismatch = 6'b101010, Error = 6'b111111

2.1.6.7.6.5.2.2.1.7. SEC_DISABLE_TOKEN_MATCH

Table 1912. efuse_mmr.SEC_DISABLE_TOKEN_MATCH fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:0	token_match_status	R	0x0	Store the status of the token match. Match = 6'b010101, Mismatch = 6'b101010, Error = 6'b111111

2.1.6.7.6.5.2.2.1.8. TOKEN_MATCH_FAULT

Table 1913. efuse_mmr.TOKEN_MATCH_FAULT fields

Bits	Field	Access	Reset	Description
31:17	Reserved	-	-	Reserved
16	secure_disable_token_fault	R	0x0	A redundancy fault was detected in the SEC_DISABLE_TOKEN comparators.
15:9	Reserved	-	-	Reserved
8	rma_chiplet_token_fault	R	0x0	A redundancy fault was detected in the RMA_CHIPLET_TOKEN comparators.
7:1	Reserved	-	-	Reserved
0	rma_sip_token_fault	R	0x0	A redundancy fault was detected in the RMA_SIP_TOKEN comparators.

2.1.6.7.6.5.2.3. eFuse Control Registers

The eFuse Control CSR provides command and status registers for read, write, and verification operations on the eFuse array. program_enable and read_enable are mutually exclusive. The eFuse command-path ownership rules in the Programmer's Guide give the order software follows.

2.1.6.7.6.5.2.3.1. eFuse Interface Control Address Map

Program and read command, address, data, status, and timeout registers for the eFuse interface.

Table 1914. eFuse Interface Control Address Map register list

Address	Name	Access	Description
0x0	EFUSE_INTERFACE_CTRL_STATUS	RW	eFuse interface status and error-clear register. Reports the sense-done flag and request/address error conditions, and provides write-1 strobes to clear those errors.
0x4	EFUSE_PROGRAM_CTRL	RW	eFuse program control and status. Configures the program address and data, triggers a program (optionally with read-back), and reports program progress and completion status.
0x8	EFUSE_READ_CTRL	RW	eFuse read control and status. Configures the read address, triggers a read, and reports read progress and completion status.
0xC	EFUSE_PROGRAM_INTERFACE_READ_DATA	R	Read data captured through the program interface. Hardware debug only; valid only while the program interface state machine is in its capture-data state.
0x10	EFUSE_READ_INTERFACE_READ_DATA	R	Read data returned through the eFuse read interface.
0x14	EFUSE_READ_REQ_TIMEOUT	RW	Read interface timeout configuration. Sets the number of cycles the read interface waits for a SHIM response and enables the read timeout.
0x18	EFUSE_PROGRAM_REQ_TIMEOUT	RW	Program interface timeout configuration. Sets the number of cycles the program interface waits for a SHIM response and enables the program timeout.

2.1.6.7.6.5.2.3.1.1. EFUSE_INTERFACE_CTRL_STATUS

Table 1915. efuse_interface_ctrl.EFUSE_INTERFACE_CTRL_STATUS fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10	efuse_read_addr_error_clear	W 1P	0x0	Clears the read out of bounds error bit (efuse_read_addr_error) in efuse_ctrl_status
9	efuse_program_addr_error_clear	W 1P	0x0	Clears the program out of bounds error bit (efuse_program_addr_error) in efuse_ctrl_status
8	efuse_req_error_clear	W 1P	0x0	Clears the blocked request error bit in efuse_ctrl_status
7	Reserved	-	-	Reserved
6	efuse_read_addr_error	R	0x0	Indicates that an invalid eFuse read address was used (address exceeds the implemented eFuse size). The error must be cleared by writing 1 to efuse_read_addr_error_clear.
5	efuse_program_addr_error	R	0x0	Indicates that an invalid eFuse program address was used (address exceeds the implemented eFuse size). The error must be cleared by writing 1 to efuse_program_addr_error_clear.
4	efuse_req_error	R	0x0	Indicates that the eFuse was blocked because of either read or a program lock. The error must be cleared by writing 1 to efuse_req_error_clear to this register
3:1	Reserved	-	-	Reserved
0	efuse_sense_done	R	-	Indicates if the eFuse state machine has completed

2.1.6.7.6.5.2.3.1.2. EFUSE_PROGRAM_CTRL

Table 1916. efuse_interface_ctrl.EFUSE_PROGRAM_CTRL fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27	program_enable	RW	0x0	When set, enables the program request
26	program_status	R	0x0	0: No Error. 1: Error
25	program_done	R	0x0	When set, the program has completed, the status of which is in program_status
24	program_busy	R	0x0	When set, the program is in progress
23:19	Reserved	-	-	Reserved
18	efuse_program_read_back	RW	0x0	When set, trigger a read back after a program
17	efuse_program_go	RW 1P	0x0	When set, triggers a program to the eFuse. This will be ignored if the lock bit is set
16	efuse_data	RW	0x0	Data to program to eFuse. If this bit is 0, the program request will be ignored
15:0	efuse_addr	RW	0x0	Bit address to program

2.1.6.7.6.5.2.3.1.3. EFUSE_READ_CTRL

Table 1917. efuse_interface_ctrl.EFUSE_READ_CTRL fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	read_enable	RW	0x0	When set, enables the read request
27	Reserved	-	-	Reserved
26	read_status	R	0x0	0: No Error. 1: Error. Set when read_go is asserted while read is not enabled, the address is out of bounds, or the read request times out.
25	read_done	R	0x0	When set, the read has completed, the status of which is in read_status
24	read_busy	R	0x0	When set, the read is in progress
23:17	Reserved	-	-	Reserved
16	efuse_read_go	RW 1P	0x0	When set, triggers a read to efuse.
15:0	efuse_addr	RW	0x0	Bit address to read

2.1.6.7.6.5.2.3.1.4. EFUSE_PROGRAM_INTERFACE_READ_DATA

Table 1918. efuse_interface_ctrl.EFUSE_PROGRAM_INTERFACE_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	dout	R	0x0	Read Data from eFuse through program interface. This field is only valid when the efuse programming interface is utilized to burn the efuse IP and only when the state machine is during ST_CAPTUER_DATA state. Hardware debug only

2.1.6.7.6.5.2.3.1.5. EFUSE_READ_INTERFACE_READ_DATA

Table 1919. efuse_interface_ctrl.EFUSE_READ_INTERFACE_READ_DATA fields

Bits	Field	Access	Reset	Description
31:0	dout	R	0x0	Read Data from eFuse through READ interface.

2.1.6.7.6.5.2.3.1.6. EFUSE_READ_REQ_TIMEOUT

Table 1920. efuse_interface_ctrl.EFUSE_READ_REQ_TIMEOUT fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	read_req_timout_enable	RW	0x0	Enable timeout on read interface
27:0	read_req_timeout_cycles	RW	0x800000	Number of cycles the read interface will wait for a response from the shim. At 100MHz this can count ~= 2.5 seconds.

2.1.6.7.6.5.2.3.1.7. EFUSE_PROGRAM_REQ_TIMEOUT

Table 1921. efuse_interface_ctrl.EFUSE_PROGRAM_REQ_TIMEOUT fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	program_req_timeout_enable	RW	0x0	Enable timeout on program interface.
27:0	program_req_timeout_cycles	RW	0x800000	Number of cycles the program interface will wait for a response from the shim. At 100MHz this can count ~= 2.5 seconds.

2.1.6.7.6.5.2.4. SHIM Control Registers

The SHIM Control CSR provides foundry-specific configuration registers for timing adaptation and eFuse bank initialization. Its placement is adopter-defined within the adopter-owned SMC external aperture; it therefore does not appear at a fixed address in the generated OCAH map.

2.1.6.7.6.5.2.4.1. eFuse SHIM Control Model Address Map

DV model of the eFuse SHIM control interface.

Table 1922. eFuse SHIM Control Model Address Map register list

Address	Name	Access	Description
0x0	EFUSE_BANK_INIT_TIME	RW	eFuse bank initialization time. Number of cycles to wait for the OTP macro to initialize before sensing can begin.

2.1.6.7.6.5.2.4.1.1. EFUSE_BANK_INIT_TIME

Table 1923. efuse_shim_ctrl.EFUSE_BANK_INIT_TIME fields

Bits	Field	Access	Reset	Description
31:0	init_time	RW	0x20	Most OTP have a initialization time before sensing can be done

2.1.6.7.7. UART 16550

2.1.6.7.7.1. Overview

The UART provides a 16550-style programming interface over 32-bit AXI4-Lite. It transmits and receives serial characters, buffers them in independently sized FIFOs, and reports line, modem and FIFO-integrity events. Extensions include larger FIFO depths, FIFO data/pointer parity protection, extended receive thresholds and a FIFO-error interrupt.

The TX and RX FIFOs default to 16 entries each. Software selects FIFO or single-character operation, frame format, baud divisor and interrupt enables. Modem signals provide status and software-controlled outputs; CTS does not stop

transmission and RTS does not automatically throttle reception. DMA-ready outputs indicate service conditions but do not themselves move data. The UART section of the Programmer's Guide gives the configuration, interrupt service and flow-control procedures.




Figure 66. SMC UART wrapper

Figure 66 shows the SMC wrapper around the UART 16550. `uart_wrap` runs on one clock, `clk_i`, which in the SMC is the gated peripheral clock; both of its AXI4-Lite ports cross to the SMC clock in `smc_peripherals_cdc`. The register port has 32-bit address and data. The demux `u_csr_axi_lite_demux` and the mux `u_log_fetch_axi_lite_mux` are PULP blocks, marked by the project name in parentheses. The demux selects the instance whose window, 0x400 bytes apart, contains the address, and sends every other address to an error slave that answers DECERR with read data `0xBADCAB1E`.

Each instance, `gen_uart_log_engine_wraps[i].u_uart_log_engine_wrap`, holds one UART 16550 and, when bit `i` of `GEN_LOG_ENGINES` is set, a log engine; Figure 67 shows its contents. The mux `u_log_fetch_axi_lite_mux` merges the instances' log-fetch manager ports onto the single log-fetch port, with 56-bit address and 64-bit data. The SMC instantiates four UARTs, each with a log engine and 32-entry TX and RX FIFOs.

Every per-instance port is a vector with one bit per instance, and the figure labels the slice that instance 0 drives. In the SMC, `uart_dsr_ni`, `uart_ri_ni` and `uart_dcd_ni` are tied high, and `uart_dtr_no`, `uart_out1_no`, `uart_out2_no`, `uart_rxrdy_o` and `uart_txrdy_o` are unconnected. `uart_irq_o`, `uart_err_o` and `log_engine_irq_o` of each instance are ORed into one interrupt, peripheral interrupts 18 to 21.

2.1.6.7.7.2. Architecture

`uart_16550` selects the register view; `uart_core` manages buffering, baud timing, modem state and interrupts; `uart_tx` and `uart_rx` serialize and sample characters. All core logic uses `clk_i`.

2.1.6.7.7.2.1. Transmit and Receive Paths

With LCR.DLAB=0, a write to THR supplies a transmit byte and a read of RBR consumes a received byte. FIFO mode queues characters; non-FIFO mode uses one holding register per direction. Changing FCR.FIFO_ENABLE clears both FIFOs and the single-character holding state, so changing mode can discard data.

The transmitter runs whenever enabled and data is available, independently of CTS. LSR.THRE means the TX FIFO/holding register is empty; LSR.TEMT also requires the serializer to be idle. Use TEMT when the final character must have left the transmitter before reconfiguration.

The receiver synchronizes rx_i and takes a majority of three consecutive clk_i samples, which rejects single-cycle glitches. It then samples each bit once, at the bit midpoint timed by the 16-times-baud tick. Received parity, framing and break indications accompany characters; software reads line status before consuming their data. In FIFO mode, an overrun drops the newly received character; in non-FIFO mode an unread character can be overwritten in RBR. Frame format supports 5–8 data bits, selectable parity and stop-bit configuration. LCR.SET_BREAK forces the transmit line low.

2.1.6.7.7.2.2. Baud Timing and Register Views

LCR.DLAB selects DLL/DLM at offsets 0x00 and 0x04 for divisor programming. With DLAB clear, these offsets select RBR/THR and IER. Other offsets retain their normal meaning. Serial operation is disabled when the combined divisor is zero; otherwise baud rate is clk_i_frequency / (16 * (divisor + 1)). The smallest usable divisor, 1, gives a maximum baud rate of clk_i_frequency/32.

2.1.6.7.7.2.3. FIFO Protection and Line Errors

FIFO/holding-register data and FIFO pointers have parity protection. An internal parity failure drives err_o and can raise the separately enabled FIFO-error interrupt. This is different from parity in a received serial frame.

Table 1924. UART serial errors

LSR field	Meaning
OE	Receive FIFO overrun: a character arrived while the receive FIFO was full.
PE	Parity error on the character exposed at the receive head.
FE	Invalid stop bit on that character.
BI	Break: the received frame remained low.

In the current RTL, overwriting an unread non-FIFO RBR does not set OE. These error fields clear on an LSR read. Capture the status once for the character being serviced; repeated diagnostic reads can consume error evidence. The generated map specifies the status fields and their access side effects.

2.1.6.7.7.2.4. Interrupt Priority and Service

irq_o reports the OR of the interrupt requests. IIR.INTERRUPT_PENDING=0 means a request is pending; IIR.INTERRUPT_ID identifies the highest-priority source. The following table is ordered highest first; IDs are the three-bit field values, not the full IIR register value.

Table 1925. UART interrupt priority and service

ID	Source	Service / control
7	FIFO integrity error	Investigate err_o; IER.EFEI masks this source. An IIR read does not repair or acknowledge an underlying parity failure.
3	Receiver line status	Capture LSR error fields, then service receive data; controlled by IER.ELSI.

ID	Source	Service / control
6	Receive timeout	Read RBR to clear the latched timeout. It is generated in FIFO mode when the receive FIFO holds data and its occupancy has not changed for roughly four character times. In the current RTL this request is not gated by IER.
2	Received data ready	Drain RBR below the selected FIFO trigger, or consume the non-FIFO character; controlled by `IER.ERBFI`.
1	Transmit holding register empty	Write THR, or read IIR while this is the selected source, to clear its latch. A subsequent transition back to empty re-arms it; controlled by `IER.ETBEI`.
0	Modem status	Read MSR once to capture levels and clear delta bits; controlled by `IER.EDSSI`.

`MCR.OUT2` does not gate `irq_o`; its modem and loopback uses are described in the UART modem status section of the Programmer's Guide. The ITR extension can force interrupt sources for testing. Clear test settings after use. Do not rely on clearing IER alone to silence the unmasked timeout source; use the subsystem interrupt controller when masking all delivery is required.

2.1.6.7.7.3. Interface

2.1.6.7.7.3.1. Configuration Parameters

The UART 16550 module provides configurable parameters to customize FIFO sizes according to system requirements.

The parameters and ports of `uart_16550` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.6.7.7.3.2. Modem Control Interface

The modem control interface provides full RS-232 modem signaling compatibility. All modem signals are active low at the pins, matching the RS-232 convention.

The modem inputs are **status only**. Each one is synchronized and then reported in the `MSR` register in the opposite polarity (a bit reads `1` while its pin is asserted low), and a change on any of them raises the Modem Status Interrupt. None of them gates the datapath: this component implements no automatic flow control, so software must act on the interrupt to throttle traffic. The software flow control procedure is in the Programmer's Guide.

2.1.6.7.7.3.3. DMA Interface

The DMA interface provides signals for Direct Memory Access controllers to manage data transfers automatically. The `rxrdy_o` and `txrdy_o` signals indicate when DMA operations can proceed, with behavior configurable through FIFO control modes.

2.1.6.7.7.3.4. Interface Timing Considerations

2.1.6.7.7.3.5. Clock Domain

All interface signals operate in a single clock domain referenced to `clk_i`. The following timing considerations apply:

- **AXI4-Lite Protocol**: All AXI4-Lite signals must meet setup and hold time requirements relative to `clk_i`
- **Asynchronous Inputs**: `rx_i` and modem control inputs (`cts_ni`, `dsr_ni`, `ri_ni`, `dcd_ni`) are asynchronous and are synchronized internally
- **Reset Requirements**: `rst_ni` should be asserted asynchronously and deasserted synchronously relative to `clk_i`

2.1.6.7.7.3.6. Serial Interface Timing

- **Baud Rate**: Serial data rate is determined by the divisor latch registers (DLL/DLM) and uses 16x oversampling
- **Maximum Baud Rate**: Limited to `system_clock_frequency / 32` - a divisor of `0` disables the transmitter and receiver, so the smallest usable divisor is `1`
- **Data Frame**: Configurable start bit (always 1), 5-8 data bits, optional parity bit, 1-2 stop bits

2.1.6.7.7.3.7. Protocol Support

The interface supports standard UART communication protocols:

- **RS-232**: Full modem control and serial data signaling
- **RS-485**: Can be used with external transceivers (using RTS for direction control)
- **Industrial Protocols**: Compatible with Modbus RTU and other industrial serial protocols
- **Debug Interfaces**: Suitable for system debug and console applications

The comprehensive interface design ensures compatibility with a wide range of serial communication requirements while maintaining the flexibility needed for diverse embedded system applications.

2.1.6.7.7.4. Memory Map and Register Reference

2.1.6.7.7.4.1. Memory Map

The core decodes a 64-byte register space with 32-bit registers on four-byte boundaries. Offsets `0x00` and `0x04` change meaning with `LCR.DLAB`; offset `0x08` reads IIR and writes FCR. See Programming for safe divisor and FIFO configuration. The generated views below retain all field definitions, including ECR extended trigger selection and ITR interrupt tests.

2.1.6.7.7.4.2. Detailed Register Map

The first two register views apply when `LCR.DLAB=0`; read-only and write-only aliases at the same offset are shown separately. Registers outside offsets `0x00` and `0x04`, including FCR at `0x08`, are accessible for either `LCR.DLAB` value. The divisor-latch view applies when `LCR.DLAB=1`.

2.1.6.7.7.4.2.1. UART 16550 Main Address Map

Contains the mode-independent registers and the read-only registers accessible only when `DLAB = 0`.

Table 1926. UART 16550 Main Address Map register list

Address	Name	Access	Description
0x0	RBR	R	Receiver Buffer Register
0x4	IER	RW	Interrupt Enable Register
0x8	IIR	R	Interrupt Identification Register
0xC	LCR	RW	Line Control Register
0x10	MCR	RW	Modem Control Register
0x14	LSR	R	Line Status Register
0x18	MSR	R	Modem Status Register
0x1C	SCR	RW	Scratch Register
0x20	ECR	RW	Extended Control Register

Address	Name	Access	Description
0x24	ITR	RW	Interrupt Test Register

2.1.6.7.7.4.2.1.1. RBR

Table 1927. uart_16550_main.RBR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R RMOD	0x0	Received Data. Contains a received character. If FIFOs are enabled, this field points to the bottom of the RX FIFO. Otherwise, this field points to a single- byte Receiver Buffer Register.

2.1.6.7.7.4.2.1.2. IER

Table 1928. uart_16550_main.IER fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	EFEI	RW	0x0	Enable FIFO Error Interrupt.
3	EDSSI	RW	0x0	Enable (Delta Status of) Modem Status Interrupt.
2	ELSI	RW	0x0	Enable (Receiver) Line Status Interrupt.
1	ETBEI	RW	0x0	Enable Transmitter Buffer Empty (Transmitter Holding Register Empty) Interrupt.
0	ERBFI	RW	0x0	Enable Receiver Buffer Full (Received Data Ready) Interrupt.

2.1.6.7.7.4.2.1.3. IIR

Table 1929. uart_16550_main.IIR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:6	FIFOS_ENABLED	R	0x0	FIFOs Enabled: * 0x0 - FIFOs are disabled * 0x3 - FIFOs are enabled
5:4	Reserved	-	-	Reserved
3:1	INTERRUPT_ID	R	0x0	Interrupt ID: * 0x7 - FIFO Error Interrupt (priority 0) * 0x3 - Receiver Line Status Interrupt (priority 1) * 0x6 - Reception Timeout Interrupt (priority 2) * 0x2 - Received Data Ready Interrupt (priority 3) * 0x1 - Transmitter Holding Register Empty Interrupt (priority 4) * 0x0 - Modem Status Interrupt (priority 5)
0	INTERRUPT_PENDING	R	0x1	Interrupt Pending. Active-low.

2.1.6.7.7.4.2.1.4. LCR

Table 1930. uart_16550_main.LCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	DLAB	RW	0x0	Divisor Latch Access Bit. If set, allows access to the DLL and DLM registers when accessing addresses 0x0 and 0x4, respectively. If unset, allows access to the THR, RBR, and IIR registers.
6	SET_BREAK	RW	0x0	Set Break. If set, forces the tx_o output to 0 to cause a break condition on the receiving UART.

Bits	Field	Access	Reset	Description
5	STICK_PARITY	RW	0x0	Stick Parity. If set, forces the transmit and received parity bits to be 0 if even parity is selected and 1 if odd parity is selected.
4	EPS	RW	0x0	Even Parity Select: * 1 - even parity * 0 - odd parity
3	PEN	RW	0x0	Parity Enable.
2	STB	RW	0x0	Stop Bits: * 0 - 1 stop bit. * 1 - 2 stop bits (or 1.5 stop bits if word length is set to 5 bits)
1:0	WLS	RW	0x0	Word Length Select: * 0x0 - 5 bits per character * 0x1 - 6 bits per character * 0x2 - 7 bits per character * 0x3 - 8 bits per character

2.1.6.7.7.4.2.1.5. MCR

Table 1931. uart_16550_main.MCR fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	LINE_LOOPBACK	RW	0x0	Line Loopback. If set, the rx_i input is internally connected to the tx_o output.
4	LOOP	RW	0x0	System Loopback. If set, the transmitter is internally connected to the receiver. The tx_o output is set to 1.
3	OUT2	RW	0x0	User Output 2. Writing to this bit drives the out2_no in the opposite polarity.
2	OUT1	RW	0x0	User Output 1. Writing to this bit drives the out1_no in the opposite polarity.
1	RTS	RW	0x0	Request to Send. Writing to this bit drives the rts_no output in the opposite polarity.
0	DTR	RW	0x0	Data Terminal Ready. Writing to this bit drives the dtr_no output in the opposite polarity.

2.1.6.7.7.4.2.1.6. LSR

Table 1932. uart_16550_main.LSR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ERROR_IN_RCVR_FIFO	R	0x0	Error in Receiver FIFO. When set, indicates that the receiver FIFO or (RBR in non-FIFO mode) has the parity, framing, or break error. In other words, at least one of the PE, FE, and BI bits is set.
6	TEMT	R	0x1	Transmitter Empty. When set, indicates that the transmitter shift register and the transmitter FIFO (or THR in non-FIFO mode) are empty.
5	THRE	R	0x1	Transmitter Holding Register Empty. When set, indicates that the TX FIFO (or THR in non-FIFO mode) is empty. Clearing the Transmitter Holding Register Empty Interrupt does NOT clear this bit.
4	BI	R RC	0x0	Break Interrupt. When set, indicates that the rx_i input is 0 for an entire frame's time (start + data + parity + stop bits). In FIFO mode, this bit set when the character reaches the top of the receiver FIFO. In non-FIFO mode, this bit is set when the character enters the RBR. This bit triggers the Receiver Line Status Interrupt.
3	FE	R RC	0x0	Framing Error. When set, indicates that the received character is missing a stop bit. In FIFO mode, this bit is set when the character reaches the top of the FIFO. In non-FIFO mode, this bit is set when the character enters the RBR. This bit triggers the Receiver Line Status Interrupt.
2	PE	R RC	0x0	Parity Error. When set, indicates that the character at the top of the receiver FIFO (or RBR in non-FIFO mode) has a parity error. This bit triggers the Receiver Line Status Interrupt.

Bits	Field	Access	Reset	Description
1	OE	R RC	0x0	Overrun Error. When set, indicates that the RX FIFO (or Receiver Buffer Register in Non-FIFO Mode) is full when new character is received. In FIFO Mode, the new character is dropped. In non-FIFO mode, the existing character in the RBR is overwritten. This bit triggers the Receiver Line Status Interrupt.
0	DR	R	0x0	Data Ready. When set, indicates that the RX FIFO (or RBR in non-FIFO mode) contains data.

2.1.6.7.7.4.2.1.7. MSR

Table 1933. uart_16550_main.MSR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	DCD	R	0x0	Data Carrier Detect. This bit reflects the dcd_ni input in the opposite polarity, so it reads 1 while a carrier is detected.
6	RI	R	0x0	Ring Indicator. This bit reflects the ri_ni input in the opposite polarity, so it reads 1 while the remote modem signals an incoming call.
5	DSR	R	0x0	Data Set Ready. This bit reflects the dsr_ni input in the opposite polarity, so it reads 1 while the remote modem is connected and ready.
4	CTS	R	0x0	Clear to Send. This bit reflects the cts_ni input in the opposite polarity, so it reads 1 while the remote device is ready to receive data.
3	DDCD	R RC	0x0	Delta Data Carrier Detect. When set, indicates that the DCD bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.
2	TERI	R RC	0x0	Trailing Edge Ring Indicator. When set, indicates that the RI bit has changed from a 1 to a 0. This bit triggers the Modem Status Interrupt.
1	DDSR	R RC	0x0	Delta Data Set Ready. When set, indicates that the DSR bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.
0	DCTS	R RC	0x0	Delta Clear to Send. When set, indicates that the CTS bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.

2.1.6.7.7.4.2.1.8. SCR

Table 1934. uart_16550_main.SCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	SCR	RW	0x0	Scratch. Holds user data.

2.1.6.7.7.4.2.1.9. ECR

Table 1935. uart_16550_main.ECR fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
1:0	RCVR_TRIGGER_MS2B	RW	0x0	Receiver FIFO Trigger Level Most Significant 2 Bits. To configure the least significant 2 bits, use the FCR.RCVR_TRIGGER register field. The configurations for the trigger levels are: * 0x0 - 1 character * 0x1 - 4 characters * 0x2 - 8 characters * 0x3 - 14 characters * 0x4 - 32 characters * 0x5 - 64 characters * 0x6 - 128 characters * 0x7 - 256 characters * 0x8 - 512 characters * 0x9 - 1024 characters * 0xA - 2048 characters * 0xB - 4096 characters

2.1.6.7.7.4.2.1.10. ITR

Table 1936. uart_16550_main.ITR fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	TRTI	RW	0x0	Test Reception Timeout Interrupt. Writing a 1 forces the interrupt and writing 0 releases it.
4	TFEI	RW	0x0	Test FIFO Error Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
3	TDSSI	RW	0x0	Test (Delta Status of) Modem Status Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
2	TLSI	RW	0x0	Test (Receiver) Line Status Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
1	TTBEI	RW	0x0	Test Transmitter Buffer Empty (Transmitter Holding Register Empty) Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
0	TRBFI	RW	0x0	Test Receiver Buffer Full (Received Data Ready) Interrupt. Writing 1 forces the interrupt and writing 0 releases it.

2.1.6.7.7.4.2.2. UART 16550 Main Write-Only Address Map

Contains the write-only registers. THR is accessible only when LCR.DLAB = 0; FCR is writable for either LCR.DLAB value.

Table 1937. UART 16550 Main Write-Only Address Map register list

Address	Name	Access	Description
0x0	THR	W	Transmitter Holding Register
0x8	FCR	W	FIFO Control Register

2.1.6.7.7.4.2.2.1. THR

Table 1938. uart_16550_main_wo.THR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	W WMOD	0x0	Transmit Data. Holds a character to be transmitted. If FIFOs are enabled, this field points to the top of the TX FIFO. Otherwise, this field points to a single-byte Transmitter Holding Register.

2.1.6.7.7.4.2.2.2. FCR

Table 1939. uart_16550_main_wo.FCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7:6	RCVR_TRIGGER	W	0x0	Receiver FIFO Trigger Level (Least Significant 2 Bits). To configure the most significant 2 bits, use the ECR.RCVR_TRIGGER_MS2B register field. The configurations for the trigger levels are: * 0x0 - 1 character * 0x1 - 4 characters * 0x2 - 8 characters * 0x3 - 14 characters * 0x4 - 32 characters * 0x5 - 64 characters * 0x6 - 128 characters * 0x7 - 256 characters * 0x8 - 512 characters * 0x9 - 1024 characters * 0xA - 2048 characters * 0xB - 4096 characters
5:4	Reserved	-	-	Reserved
3	DMA_MODE_SELECT	W	0x0	DMA mode select: * 0 - DMA Mode 0 * 1 - DMA Mode 1
2	XMIT_FIFO_RESET	W 1P	0x0	Transmitter FIFO Reset. Writing 1 clears the TX FIFO.
1	RCVR_FIFO_RESET	W 1P	0x0	Receiver FIFO Reset. Writing 1 clears the RX FIFO.
0	FIFO_ENABLE	W	0x0	FIFO Enable. When set, enables the TX and RX FIFOs (FIFO Mode). When unset, disables the FIFOs (Non-FIFO Mode).

2.1.6.7.7.4.2.3. UART 16550 Divisor Latch Address Map

Contains the registers accessible only when LCR.DLAB = 1.

Table 1940. UART 16550 Divisor Latch Address Map register list

Address	Name	Access	Description
0x0	DLL	RW	Divisor Latch Least Significant Byte Register
0x4	DLM	RW	Divisor Latch Most Significant Byte Register

2.1.6.7.7.4.2.3.1. DLL

Table 1941. uart_16550_dl.DLL fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DLL	RW	0x0	Divisor Latch Least Significant Byte. Baud rate is calculated as baud_rate = system_clock_frequency / (16 * (divisor + 1)). When the divisor is set to 0, the transmitter and receiver logic are disabled.

2.1.6.7.7.4.2.3.2. DLM

Table 1942. uart_16550_dl.DLM fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DLM	RW	0x0	Divisor Latch Most Significant Byte. Baud rate is calculated as baud_rate = system_clock_frequency / (16 * (divisor + 1)). When the divisor is set to 0, the transmitter and receiver logic are disabled.

2.1.6.7.8. Log Engine

2.1.6.7.8.1. Overview

The Log Engine sends memory-resident messages to a UART without a CPU copying each byte. Software supplies one memory region, divided into 16 slots, and submits each message by writing its slot's length. The engine selects pending slots in round-robin order and completes one message before moving to the next.

A 64-bit AXI4-Lite read path fetches message data into a FIFO. A separate 32-bit AXI4-Lite write path sends one character at a time to a fixed UART address, paced by `uart_tx_ready_i`. The register interface is also 32-bit AXI4-Lite. Fetch addresses are 56 bits; UART addresses are 32 bits. The Log Engine section of the Programmer's Guide gives the configuration, submission and recovery procedures.




Figure 67. SMC log-engine wrapper and data paths

Figure 67 shows the SMC wrapper and its memory-to-UART data paths. Parentheses after an instance name give its module or, for a block taken from another project, that project: the demuxes, the mux and the `axi_lite_from_mem` converters come from PULP, and `u_uart_core`, `u_arbiter_tree` and `u_rdata_fifo` from OpenTitan. `uart_log_engine_wrap` runs on one clock, `clk_i`. Its register port, with 32-bit address and data, comes from `uart_wrap`, and the demux `u_csr_axi_lite_demux` decodes it by base and size onto four maps: the UART, the log engine, the control block and an error slave that answers DECERR. The control block `u_uart_log_engine_ctrl_reg`, generated by PeakRDL from `uart_log_engine_ctrl.rdl`, drives `uart_en_o` from `CTRL.UART_EN`.

The UART register path and the log engine's write path share the UART's register port through the mux `u_log_write_axi_lite_mux`: port 0 carries register accesses and port 1 the log engine's writes. Inside `u_uart_16550`, the demux `u_axi_lite_demux` selects one of three PeakRDL register blocks. While `LCR.DLAB` is set, `DLL` and `DLM` go to the divisor-latch block (`dl`); writes to `THR` and `FCR` go to the write-only block (`main_wo`); everything else goes to the main block. `u_uart_core` holds the TX and RX FIFOs, the transmitter and the receiver, and passes `uart_rx_i` and the modem inputs through two-flop synchronizers, marked by the synchronizer badge on its edge.

The dashed outline marks the log engine, which exists only when GEN_LOG_ENGINE is set; without it the log-fetch port is driven to zero and log_engine_irq_o is low. u_log_engine_reg, generated from log_engine.rdl, holds the 16 LOG_CTRL registers and the interrupt registers, and drives log_engine_irq_o. u_arbiter_tree picks a log entry whose LOG_LEN is non-zero and gives its index and length to the log fetch FSM. The fetch FSM reads 64-bit words through the axi_lite_from_mem converter u_axil_lite_from_log_fetch_fsm on the log-fetch port, which has 56-bit address and 64-bit data, into u_rdata_fifo, whose depth is FIFO_DEPTH (4 in the SMC). The log write FSM takes one byte at a time from the FIFO and writes it, through a second converter, u_axi_lite_from_log_write_fsm, to LOG_WRITE_ADDR over a 32-bit AXI4-Lite port. It waits for uart_txrdy_o before each write.

2.1.6.7.8.2. Operation

2.1.6.7.8.2.1. Memory Slots and Lengths

LOG_REGION_ADDR specifies the start of a shared region. LOG_REGION_SIZE specifies its total size in bytes. Use an 8-byte-aligned base and a nonzero size aligned to 128 bytes, up to 512 KiB. The region is divided equally among 16 slots; it does not provide independently sized buffers.

For supported settings, slot i starts at:

```
LOG_REGION_ADDR + (LOG_REGION_SIZE / 16) * i
```

A nonzero LOG_CTRL[i].LOG_LEN makes that slot pending. The length is in bytes and remains the submitted value until hardware clears it on completion; it is not a bytes-remaining counter. Keep the buffer and its configuration unchanged until completion.

For oversized regions, hardware clamps the effective size to 512 KiB. For a size not aligned to 128 bytes, it divides the effective size by 16 and rounds each slot's transferable capacity down to a multiple of eight. Requested lengths above that capacity are clamped. A zero-capacity slot completes without a transfer. Software should validate size and length instead of relying on truncation.

2.1.6.7.8.2.2. Arbitration and Data Transfer

The arbiter selects among nonzero lengths and advances when the selected message completes. Scheduling is per message, not per byte. A stalled UART or bus response holds up that message and all later entries; round-robin selection does not impose a completion-time bound.

The fetch FSM issues single-beat 64-bit reads and waits for each response. A FIFO_DEPTH-entry FIFO buffers the returned words. The final read still fetches a full eight-byte word when the message length is not a multiple of eight, so the whole fetched word must be readable within the slot.

The write FSM sends bytes in increasing address order, least-significant byte first within each fetched word. It waits for FIFO data and uart_tx_ready_i, writes the character in data bits [7:0] to LOG_WRITE_ADDR, then waits for the response. The current implementation sets all four write strobes; the UART target must accept that access.

Completion clears the selected length and advances arbitration. It means the write responses have returned, not that the UART has finished shifting the final character onto its serial output.

2.1.6.7.8.2.3. Errors and Interrupts

INTR_STATUS.LOG_FETCH_ERR (bit 0) and LOG_WRITE_ERR (bit 4) latch bus response errors whether or not their interrupts are enabled. INTR_ENABLE masks the corresponding contributions to irq_o. Write 1 to a status bit to clear it; INTR_TEST can

force either condition.

The FSMs advance on error responses as well as successful responses. There is no automatic retry or per-slot success flag, and a cleared length alone does not prove successful delivery. Software must inspect error status and choose recovery appropriate to its logging requirements.

2.1.6.7.8.2.4. Reset and Disable

All logic uses `clk_i`. Active-low `rst_ni` asynchronously resets the registers, state machines, counters and FIFO. Reset release timing is the integrator's responsibility; the module does not synchronize it internally.

Clearing `CTRL.EN` returns the fetch/write FSMs and counters to idle and clears the FIFO. It does not clear configuration or pending lengths, and it does not reset the AXI adapters. Disabling an active transfer is not a guaranteed drain or clean cancellation. Configure while idle; following an aborted transfer, reconcile outstanding bus traffic before reusing buffers or restarting the engine.

2.1.6.7.8.3. Interface

The parameters and ports of `log_engine` are listed in the HTML edition of this manual, under RTL Modules Reference.

Table 1943. Log-engine configuration

Setting	Value	Source
`FIFO_DEPTH`	4 by default	Module parameter: buffered 64-bit words.
`NumLogEntries`	16	Package constant and generated register inventory.
Maximum region	512 KiB	Package constant `MaxLogRegionSize`.
Fetch address/data	56/64 bits	Package types.
Write address/data	32/32 bits	Package types.
CSR data	32 bits	Register interface; address width comes from the generated map.

A shared `clk_i` and active-low asynchronous `rst_ni` drive all interfaces and internal logic. The CSR AXI4-Lite slave (`csr_axil_req_i` / `csr_axil_resp_o`) carries register traffic; two AXI4-Lite initiators carry memory reads (`log_fetch_axil_req_o` / `log_fetch_axil_resp_i`) and UART writes (`log_write_axil_req_o` / `log_write_axil_resp_i`). Both initiator adapters use `PROT = 3'b010` (non-secure, unprivileged data) and allow one outstanding request each. They issue no bursts.

`uart_tx_ready_i` permits the write FSM to request the next character transfer. The UART integration supplies readiness in the engine's clock domain and must account for writes already accepted by the bus. See Section 2.1.6.7.8.2.2 for the write data and strobe behavior.

`irq_o` is the active-high OR of enabled, latched fetch and write error status.

2.1.6.7.8.4. Memory Map and Register Reference

2.1.6.7.8.4.1. Memory Map

Offsets below are relative to the Log Engine register bank. All registers reset to zero. The generated map gives field access and side effects.

Table 1944. Log-engine register summary

Register	Offset	Purpose
CTRL	0x00	Engine enable.
LOG_REGION_SIZE	0x04	Total region size in bytes.
LOG_REGION_ADDR	0x08/0x0C	Low/high halves of the 56-bit fetch base.
LOG_WRITE_ADDR	0x10	UART write address.
INTR_STATUS	0x14	Latched fetch/write errors; write 1 to clear.
INTR_ENABLE	0x18	Error interrupt enables.
INTR_TEST	0x1C	Force error status for interrupt testing.
LOG_CTRL[i]	0x40 + 4*i	Submitted byte length for slot 0–15; cleared on completion.

2.1.6.7.8.4.2. Detailed Register Map

2.1.6.7.8.4.2.1. Log Engine Address Map

Configuration and status registers for the UART log engine, including the log region and write pointers.

NOTE

Register Arrays:

- **LOG_CTRL[16]**: 16 registers, base 0x40, stride 0x4

Table 1945. Log Engine Address Map register list

Address	Name	Access	Description
0x0	CTRL	RW	Control Register
0x4	LOG_REGION_SIZE	RW	Log Region Size Register
0x8	LOG_REGION_ADDR	RW	Log Region Address Register
0x10	LOG_WRITE_ADDR	RW	Log Write Address Register
0x14	INTR_STATUS	RW	Interrupt Status Register
0x18	INTR_ENABLE	RW	Interrupt Enable Register
0x1C	INTR_TEST	W	Interrupt Test Register
0x40 - 0x7C	LOG_CTRL[16]	RW	Log Control Register

2.1.6.7.8.4.2.1.1. CTRL

Table 1946. log_engine.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	EN	RW	0x0	Log Engine Enable. When set, enables the Log Engine. When cleared, the engine stops fetching and writing, discards buffered log data and resets transfer progress. Configuration and pending LOG_LEN values are retained, so a pending entry restarts from the start of its slot when the engine is enabled again. Clearing does not wait for outstanding bus responses.

2.1.6.7.8.4.2.1.2. LOG_REGION_SIZE

Table 1947. log_engine.LOG_REGION_SIZE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	LOG_REGION_SIZE	RW	0x0	Log region size in bytes. Supported values are at most 512 KiB and aligned to 128 bytes (16 slots times the 8-byte fetch beat). If software programs a larger value, RTL clamps the effective region to 512 KiB. For a value that is not 128-byte aligned, RTL divides the effective region among the 16 slots and rounds each slot's transferable capacity down to complete 8-byte fetch beats. A requested LOG_LEN above that capacity is clamped to the capacity.

2.1.6.7.8.4.2.1.3. LOG_REGION_ADDR

Table 1948. log_engine.LOG_REGION_ADDR fields

Bits	Field	Access	Reset	Description
63:56	RESERVED	R	0x0	Reserved. Reads as zero; writes are ignored.
55:32	LOG_REGION_ADDR_HI	RW	0x0	Log Region Start Address High. Contains fabric address bits [55:32].
31:0	LOG_REGION_ADDR_LO	RW	0x0	Log Region Start Address Low.

2.1.6.7.8.4.2.1.4. LOG_WRITE_ADDR

Table 1949. log_engine.LOG_WRITE_ADDR fields

Bits	Field	Access	Reset	Description
31:0	LOG_WRITE_ADDR	RW	0x0	Log Write Address. This is the address where the log data is written to.

2.1.6.7.8.4.2.1.5. INTR_STATUS

Table 1950. log_engine.INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	RW1C	0x0	Log Write Error Interrupt. Asserted when the bus for writing log data returns an error.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	RW1C	0x0	Log Fetch Error Interrupt. Asserted when the bus for fetching log data returns an error.

2.1.6.7.8.4.2.1.6. INTR_ENABLE

Table 1951. log_engine.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	RW	0x0	Log Write Error Interrupt Enable.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	RW	0x0	Log Fetch Error Interrupt Enable.

2.1.6.7.8.4.2.1.7. INTR_TEST

Table 1952. log_engine.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	W 1P	0x0	Log Write Error Interrupt Test. Writing 1 forces the interrupt.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	W 1P	0x0	Log Fetch Error Interrupt Test. Writing 1 forces the interrupt.

2.1.6.7.8.4.2.1.8. LOG_CTRL[16]

Table 1953. log_engine.LOG_CTRL[16] fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	LOG_LEN	RW	0x0	Log Length. Writing a nonzero value representing the log length in bytes to this field starts the log transfer process. The field holds the requested length until the transfer completes, when hardware clears it to zero; it is not a remaining-byte counter. There are 16 copies of this register, each representing a log entry. The log entries go through round robin arbitration.

2.1.6.7.9. I2C Controller

The I2C controller is based on the OpenTitan I2C design. Controller and target behavior, clock stretching, arbitration, timing setup, and programming sequences are specified in the OpenTitan theory of operation and the OpenTitan programmer's guide.




Figure 68. OpenTitan I2C core reference architecture

Figure 68 shows the upstream core.

2.1.6.7.9.1. OCAH Modifications

- AXI4-Lite register interface in place of the OpenTitan TileLink host port.
- Wrapper register blocks `i2c_ctrl` and `i2c_wrap` around the OpenTitan register bank.




Figure 69. OCAH I2C wrapper and generated register interface

Figure 69 shows the OCAH wrapper around that core. `i2c_wrap` has one AXI4-Lite slave port, with 32-bit address and data, and runs on a single clock, `clk_i`; in the SMC that is the gated peripheral clock, and the bus reaches it through `smc_peripherals_cdc`. Parentheses after an instance name give its module or, for a block taken from another project, that project. The demux `u_axi_lite_demux`, a PULP `axi_lite_demux`, compares the address against the base and size of each register map and selects one of `NUM_I2CS` + 2 ports: one per instance, the shared control map, and an error slave that answers DECERR with read data `0xBADCAB1E`. The SMC sets `NUM_I2CS` to 3.

Each instance, `gen_i2cs[i].u_i2c`, is the OpenTitan core `u_i2c_core` with its register bank replaced by `u_i2c_reg`, an AXI4-Lite register block that PeakRDL generates from `i2c.rdl`. The register block drives the core through `hwif_out` and takes status back through `hwif_in`. The core keeps the OpenTitan controller and target FSMs, bus monitor and FMT, RX, TX and ACQ FIFOs, sized by the `*_FIFO_DEPTH` parameters, and synchronizes the SCL, SDA, SMBus SUS and SMBus ALERT inputs to `clk_i` with two-flop synchronizers; the synchronizer badge on the edge of `u_i2c_core` marks them. The wrapper adds no synchronizers of its own.

The shared block `u_i2c_ctrl_reg`, generated from `i2c_ctrl.rdl`, holds one `I2C_CTRL` register per instance. Its `SMBUS_EN` field drives that instance's `smbus_en` input, which masks `smbalert_ni` while low. Its `I2C_EN` and `I2C_CONTROLLER_MODE_EN` fields leave the wrapper on `i2c_en_o` and `i2c_controller_mode_en_o` without reaching the instance. The SMC padring uses `I2C_EN` to select the I2C function on the instance's SCL, SDA, SMBus alert and SMBus suspend pads, and `I2C_CONTROLLER_MODE_EN` to set the direction of the SMBus alert and suspend pads. Neither field enables the core: its controller or target role comes from `CTRL.ENABLEHOST` and `CTRL.ENABLETARGET`, and `I2C_CONTROLLER_MODE_EN` should agree with that role.

Every per-instance port of `i2c_wrap` is a vector with one bit, or for `i2c_debug_o` one nibble, per instance. The figure labels the slice that instance 0 drives. The DMA ready outputs are `controller_tx_ready_o`, `controller_rx_ready_o`, `target_tx_ready_o` and `target_rx_ready_o`; the SMC leaves them unconnected. It routes `i2c_irq_o` to peripheral interrupts 23 to 25.

2.1.6.7.9.2. Memory Map and Register Reference

2.1.6.7.9.2.1. Memory Map

The I2C Interface Component provides a comprehensive register interface through an 8-bit address space (0x00-0xFF) accessible via AXI4-Lite protocol. The register map is organized into logical groups covering interrupt management, control configuration, data access, timing parameters, and mode-specific functionality. All registers are 32-bit aligned and support both controller and target operating modes.

2.1.6.7.9.2.1.1. Address Alignment and Access Width

Address Alignment: - All registers are aligned to 32-bit boundaries (addresses are multiples of 4) - 8-bit effective address space: only bits [7:0] of the AXI4-Lite address are used - Upper address bits are ignored

Access Width Requirements: - All registers must be accessed using 32-bit operations - Byte and halfword accesses are not supported - AXI4-Lite write strobe signals should be set to 4'b1111 for all writes

Endianness: - All multi-byte fields use little-endian byte ordering - Bit numbering follows standard convention (bit 0 is LSB)

2.1.6.7.9.2.2. Detailed Register Map

2.1.6.7.9.2.2.1. I2C Address Map

Interrupt status, enable, and test registers for a single I2C controller and target.

Table 1954. I2C Address Map register list

Address	Name	Access	Description
0x0	INTR_STATE	RW	Interrupt Status Register
0x4	INTR_ENABLE	RW	Interrupt Enable Register
0x8	INTR_TEST	RW	Interrupt Test Register
0xC	SMBUS_CTRL	RW	SMBus Control Register
0x10	CTRL	RW	Control Register
0x14	STATUS	R	Status Register
0x18	RDATA	R	Controller RX FIFO Access Register (Controller Mode only)
0x1C	FDATA	W	Controller TX FIFO Access Register (Controller Mode only)
0x20	FIFO_CTRL	W	FIFO Control Register
0x24	HOST_FIFO_CONFIG	RW	Controller FIFO Configuration Register (Controller Mode only)
0x28	TARGET_FIFO_CONFIG	RW	Target FIFOs Configuration Register (Target Mode only)
0x2C	HOST_FIFO_STATUS	R	Controller FIFOs Status Register (Controller Mode only)
0x30	TARGET_FIFO_STATUS	R	Target FIFOs Status Register (Target Mode only)
0x34	OVRD	RW	Override Control Register
0x38	VAL	R	Bus Oversampled Values Register
0x3C	TIMING0	RW	SCL LOW and HIGH Periods Register
0x40	TIMING1	RW	Bus Rise and Fall Times Register
0x44	TIMING2	RW	START Condition Setup and Hold Times Register
0x48	TIMING3	RW	Data Setup and Hold Times Register

Address	Name	Access	Description
0x4C	TIMING4	RW	STOP Condition Setup Time and Bus Free Time Register
0x50	TIMEOUT_CTRL	RW	Timeout Control Register
0x54	TARGET_ID	RW	Target ID Register (Target Mode only)
0x58	ACQDATA	R	Target RX FIFO Access Register (Target Mode only)
0x5C	TXDATA	W	Target TX FIFO Access Register (Target Mode only).
0x60	HOST_TIMEOUT_CTRL	RW	Controller Timeout Control Register
0x64	TARGET_TIMEOUT_CTRL	RW	Target Timeout Control Register (Target Mode only)
0x68	TARGET_NACK_COUNT	RW	Target NACK Count Register (Target Mode only)
0x6C	TARGET_ACK_CTRL	RW	Target ACK Control Register (Target Mode only)
0x70	ACQ_FIFO_NEXT_DATA	R	Target RX FIFO Next Byte Register (Target Mode only)
0x74	HOST_NACK_HANDLER_TIMEOUT	RW	Controller NACK Timeout Register (Controller Mode only)
0x78	CONTROLLER_EVENTS	RW	Controller Events Register (Controller Mode only)
0x7C	TARGET_EVENTS	RW	Target Events Register (Target Mode)
0x80	SMBUS_STATUS	R	SMBus Status Register

2.1.6.7.9.2.2.1.1. INTR_STATE

Table 1955. i2c.INTR_STATE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	TARGET_RX_FIFO_ERROR	RW1C	0x0	Target Mode interrupt: asserted when the Target RX FIFO has a parity error. Write 1 to clear.
18	TARGET_TX_FIFO_ERROR	RW1C	0x0	Target Mode interrupt: asserted when the Target TX FIFO has a parity error. Write 1 to clear.
17	CONTROLLER_RX_FIFO_ERROR	RW1C	0x0	Controller Mode interrupt: asserted when the Controller RX FIFO has a parity error. Write 1 to clear.
16	CONTROLLER_TX_FIFO_ERROR	RW1C	0x0	Controller Mode interrupt: asserted when the Controller TX FIFO has a parity error. Write 1 to clear.
15	SMBALERT	RW1C	0x0	Controller Mode interrupt: asserted when smbalert_ni is asserted. Write 1 to clear.
14	HOST_TIMEOUT	RW1C	0x0	Target Mode interrupt: asserted when the controller stops generating the clock longer than HOST_TIMEOUT_CTRL.VAL. Write 1 to clear.
13	UNEXP_STOP	RW1C	0x0	Target Mode interrupt: asserted when the controller sends this target a STOP before this target NACKs. Write 1 to clear.
12	ACQ_STRETCH	R	0x0	Target Mode interrupt: remains asserted while the target is stretching the clock because 1) the Target RX FIFO is full or 2) the TARGET_ACK_CTRL.NBYTES count has reached 0 (only if CTRL.ACK_CTRL_EN = 1).
11	TX_THRESHOLD	R	0x0	Target Mode interrupt: remains asserted while the Target TX FIFO level is less than TARGET_FIFO_CONFIG.TX_THRESH.
10	TX_STRETCH	R	0x0	Target Mode interrupt: remains asserted while this target is stretching the clock or has halted. The flags in the TARGET_EVENTS register explain the reason(s) for clock stretching/halting. Clearing the TARGET_EVENTS flags clears this interrupt.
9	CMD_COMPLETE	RW1C	0x0	Controller/Target Mode interrupt: asserted when this/the controller finishes generating a STOP or repeated START. Write 1 to clear.
8	SDA_UNSTABLE	RW1C	0x0	Controller Mode interrupt: asserted when the target fails to keep SDA stable during a transmission. Write 1 to clear.

Bits	Field	Access	Reset	Description
7	STRETCH_TIMEOUT	RW1C	0x0	Controller Mode interrupt: asserted when the target stretches the clock longer than TIMEOUT_CTRL.VAL (valid only when TIMEOUT_CTRL.MODE = 0). Write 1 to clear.
6	SDA_INTERFERENCE	RW1C	0x0	Controller Mode interrupt: asserted when SDA is unexpectedly pulled LOW by another controller. Write 1 to clear.
5	SCL_INTERFERENCE	RW1C	0x0	Controller Mode interrupt: asserted when SCL is unexpectedly pulled LOW by another controller. Write 1 to clear.
4	CONTROLLER_HALT	R	0x0	Controller Mode interrupt: remains asserted while this controller halts. The flags in the CONTROLLER_EVENTS register explain the reason(s) for the halting. Clearing the CONTROLLER_EVENTS flags clears this interrupt.
3	RX_OVERFLOW	RW1C	0x0	Controller Mode interrupt: asserted when the Controller RX FIFO overflows. Write 1 to clear.
2	ACQ_THRESHOLD	R	0x0	Target Mode interrupt: remains asserted while the Target RX FIFO level is greater than TARGET_FIFO_CONFIG.ACQ_THRESH.
1	RX_THRESHOLD	R	0x0	Controller Mode interrupt: remains asserted while the Controller RX FIFO level is greater than HOST_FIFO_CONFIG.RX_THRESH.
0	FMT_THRESHOLD	R	0x0	Controller Mode interrupt: remains asserted while the Controller TX FIFO level is less than HOST_FIFO_CONFIG.FMT_THRESH.

2.1.6.7.9.2.2.1.2. INTR_ENABLE

Table 1956. i2c.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	TARGET_RX_FIFO_ERROR	RW	0x0	Enables the TARGET_RX_FIFO_ERROR interrupt.
18	TARGET_TX_FIFO_ERROR	RW	0x0	Enables the TARGET_TX_FIFO_ERROR interrupt.
17	CONTROLLER_RX_FIFO_ERROR	RW	0x0	Enables the CONTROLLER_RX_FIFO_ERROR interrupt.
16	CONTROLLER_TX_FIFO_ERROR	RW	0x0	Enables the CONTROLLER_TX_FIFO_ERROR interrupt.
15	SMBALERT	RW	0x0	Enables the SMBALERT interrupt.
14	HOST_TIMEOUT	RW	0x0	Enables the HOST_TIMEOUT interrupt.
13	UNEXP_STOP	RW	0x0	Enables the UNEXP_STOP interrupt.
12	ACQ_STRETCH	RW	0x0	Enables the ACQ_STRETCH interrupt.
11	TX_THRESHOLD	RW	0x0	Enables the TX_THRESHOLD interrupt.
10	TX_STRETCH	RW	0x0	Enables the TX_STRETCH interrupt.
9	CMD_COMPLETE	RW	0x0	Enables the CMD_COMPLETE interrupt.
8	SDA_UNSTABLE	RW	0x0	Enables the SDA_UNSTABLE interrupt.
7	STRETCH_TIMEOUT	RW	0x0	Enables the STRETCH_TIMEOUT interrupt.
6	SDA_INTERFERENCE	RW	0x0	Enables the SDA_INTERFERENCE interrupt.
5	SCL_INTERFERENCE	RW	0x0	Enables the SCL_INTERFERENCE interrupt.
4	CONTROLLER_HALT	RW	0x0	Enables the CONTROLLER_HALT interrupt.
3	RX_OVERFLOW	RW	0x0	Enables the RX_OVERFLOW interrupt.
2	ACQ_THRESHOLD	RW	0x0	Enables the ACQ_THRESHOLD interrupt.
1	RX_THRESHOLD	RW	0x0	Enables the RX_THRESHOLD interrupt.
0	FMT_THRESHOLD	RW	0x0	Enables the FMT_THRESHOLD interrupt.

2.1.6.7.9.2.2.1.3. INTR_TEST

Table 1957. i2c.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	TARGET_RX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the TARGET_RX_FIFO_ERROR interrupt.
18	TARGET_TX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the TARGET_TX_FIFO_ERROR interrupt.
17	CONTROLLER_RX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the CONTROLLER_RX_FIFO_ERROR interrupt.
16	CONTROLLER_TX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the CONTROLLER_TX_FIFO_ERROR interrupt.
15	SMBALERT	W 1P	0x0	Writing 1 forces the SMBALERT interrupt.
14	HOST_TIMEOUT	W 1P	0x0	Writing 1 forces the HOST_TIMEOUT interrupt.
13	UNEXP_STOP	W 1P	0x0	Writing 1 forces the UNEXP_STOP interrupt.
12	ACQ_STRETCH	RW	0x0	Writing 1 forces the ACQ_STRETCH interrupt. Writing 0 releases it.
11	TX_THRESHOLD	RW	0x0	Writing 1 forces the TX_THRESHOLD interrupt. Writing 0 releases it.
10	TX_STRETCH	RW	0x0	Writing 1 forces the TX_STRETCH interrupt. Writing a 0 releases it.
9	CMD_COMPLETE	W 1P	0x0	Writing 1 forces the CMD_COMPLETE interrupt.
8	SDA_UNSTABLE	W 1P	0x0	Writing 1 forces the SDA_UNSTABLE interrupt.
7	STRETCH_TIMEOUT	W 1P	0x0	Writing 1 forces the STRETCH_TIMEOUT interrupt.
6	SDA_INTERFERENCE	W 1P	0x0	Writing 1 forces the SDA_INTERFERENCE interrupt.
5	SCL_INTERFERENCE	W 1P	0x0	Writing 1 forces the SCL_INTERFERENCE interrupt.
4	CONTROLLER_HALT	RW	0x0	Writing 1 forces the CONTROLLER_HALT interrupt. Writing 0 releases it.
3	RX_OVERFLOW	W 1P	0x0	Writing 1 forces the RX_OVERFLOW interrupt.
2	ACQ_THRESHOLD	RW	0x0	Writing 1 forces the ACQ_THRESHOLD interrupt. Writing 0 releases it.
1	RX_THRESHOLD	RW	0x0	Writing 1 forces the RX_THRESHOLD interrupt. Writing 0 releases it.
0	FMT_THRESHOLD	RW	0x0	Writing 1 forces the FMT_THRESHOLD interrupt. Writing 0 releases it.

2.1.6.7.9.2.2.1.4. SMBUS_CTRL

Table 1958. i2c.SMBUS_CTRL fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	SMBALERT	RW	0x0	Target Mode control: asserts the smbalert_no output. This bit clears itself when the controller addresses this target.
3:1	Reserved	-	-	Reserved
0	SMBSUS	RW	0x0	Controller Mode control: asserts the smbsus_no output.

2.1.6.7.9.2.2.1.5. CTRL

Table 1959. i2c.CTRL fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
7	ACQ_START_STOP_EN	RW	0x0	ACQ FIFO Start/Stop Enable (Target Mode only): * 0 - Start/Stop symbols are NOT written into the ACQ FIFO. The firmware should rely on TARGET_EVENTS.START_DETECT and TARGET_EVENTS.STOP_DETECT flags to detect Start/Stop events. * 1 - Start/Stop symbols ARE written into the ACQ FIFO (legacy behavior). When a START (or repeated START) is detected, an ACQ_START or ACQ_RESTART entry is written. When a STOP is detected, an ACQ_STOP or ACQ_NACK_STOP entry is written.
6	TX_STRETCH_CTRL_EN	RW	0x0	Target mode control: enables the Software TX Stretch Control Mechanism. If this bit is: * 0 - Automatic TX Stretch: When this target receives a READ address byte, it only stretches the clock if the TX FIFO is empty; otherwise, it pops the FIFO and transmits the data byte. The target never sets the TARGET_EVENTS register flags in this mode. * 1 - Software TX Stretch Mode: When this target receives a READ address, it always stretches the clock and sets the TARGET_EVENTS.TX_PENDING flag. The software can: 1. confirm the release and transmission of the TX FIFO data by writing a 1 to clear the TARGET_EVENTS.TX_PENDING flag; or 2. reset the TX FIFO by writing 1 to FIFO_CTRL.TXRST and load in new data via the TXDATA register—useful whenthe READ address is targeting a different function of the target. In this mode, the target always sets the TARGET_EVENTS register flags.
5	MULTI_CONTROLLER_MONITOR_EN	RW	0x0	Global control: enables the Bus Monitor. Set this bit to 1 only in a multi-controller environment. If a 0→`1` transition happens while ENABLEHOST and ENABLETARGET are both 0, the Bus Monitor will enable and begin in the 'Bus Busy' state. To transition to a 'Bus Free' state, HOST_TIMEOUT_CTRL must be nonzero so the Bus Monitor may count out idle cycles to confirm the freedom to transmit. In addition, the Bus Monitor will track whether the bus is free based on the enabled timeouts and detected STOP symbols. For Multi-Controller Mode, ensure MULTI_CONTROLLER_MONITOR_EN becomes 1 no later than ENABLEHOST or ENABLETARGET. This bit can be set at the same time as either or both of the other two, though. Note that if MULTI_CONTROLLER_MONITOR_EN is set after ENABLEHOST or ENABLETARGET, the Bus Monitor will begin in the 'Bus Free' state instead. This would violate the proper protocol for a controller to join a multi-controller environment. However, if this controller is known to be the first to join, this ordering will enable skipping the idle wait. When 0, the bus monitor will report that the bus is always free, so the Controller FSM is never blocked from transmitting.
4	ACK_CTRL_EN	RW	0x0	Target Mode control: enables the Software ACK Control Mechanism. If this bit is: * 0 - This target ACKs a data byte whenever the ACQ FIFO has space. * 1 - This target ACKs the first TARGET_ACK_CTRL.NBYTES bytes. If another byte arrives, this target stretches the clock and awaits software intervention (and asserts STATUS.ACK_CTRL_STRETCH). The software can 1. accept the new byte(s) by reloading the TARGET_ACK_CTRL.NBYTES counter; or 2. reject the new byte(s) by writing 1 to TARGET_ACK_CTRL.NACK (useful for SMBus).
3	NACK_ADDR_AFTER_TIMEOUT	RW	0x0	Target Mode control: NACK address after timeout. If this bit is: * 0 - This target ACKs the address byte even if a Stretch Timeout occurs (useful for SMBus). * 1 - This target NACKs the address byte when a Stretch Timeout occurs.
2	LLPBK	RW	0x0	Global control: enables line loop-back. In Controller Mode, the internal logic sees the smbalert_ni input as deasserted. In Target Mode, this target sends all received SDA data back out, and the internal logic sees received data as all 1's.
1	ENABLETARGET	RW	0x0	Global control: configures this device's operating mode. * ENABLEHOST = 1 and ENABLETARGET = 0 — Controller Mode * ENABLEHOST = 0 and ENABLETARGET = 1 — Target Mode * ENABLEHOST = 1 and ENABLETARGET = 1 — Hybrid Mode * ENABLEHOST = 0 and ENABLETARGET = 0 — Monitor Mode

Bits	Field	Access	Reset	Description
0	ENABLEHOST	RW	0x0	Global control: configures this device's operating mode. * ENABLEHOST = 1 and ENABLETARGET = 0 — Controller Mode * ENABLEHOST = 0 and ENABLETARGET = 1 — Target Mode * ENABLEHOST = 1 and ENABLETARGET = 1 — Hybrid Mode * ENABLEHOST = 0 and ENABLETARGET = 0 — Monitor Mode

2.1.6.7.9.2.2.1.6. STATUS

Table 1960. i2c.STATUS fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10	ACK_CTRL_STRETCH	R	0x0	Target Mode status: indicates that this target is stretching the clock due to the Software ACK Control Mechanism. See CTRL.ACK_CTRL_EN for details.
9	ACQEMPTY	R	0x1	Target Mode status: Target RX FIFO empty.
8	TXEMPTY	R	0x1	Target Mode status: Target TX FIFO empty.
7	ACQFULL	R	0x0	Target Mode status: Target RX FIFO full.
6	TXFULL	R	0x0	Target Mode status: Target TX FIFO full.
5	RXEMPTY	R	0x1	Controller Mode status: Controller RX FIFO empty.
4	TARGETIDLE	R	0x1	Target Mode status: Target FSM idle.
3	HOSTIDLE	R	0x1	Controller Mode status: Controller FSM idle.
2	FMTEMPTY	R	0x1	Controller Mode status: Controller TX FIFO Empty.
1	RXFULL	R	0x0	Controller Mode status: Controller RX FIFO Full.
0	FMTFULL	R	0x0	Controller Mode status: Controller TX FIFO Full.

2.1.6.7.9.2.2.1.7. RDATA

Table 1961. i2c.RDATA fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R RMOD	0x0	Reading this register pops the Controller RX FIFO.

2.1.6.7.9.2.2.1.8. FDATA

Table 1962. i2c.FDATA fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved
12	NAKOK	W	0x0	NACK OK. When set, this controller will not care if this byte is NACKed. It will not halt, set the CONTROLLER_EVENTS.NACK flag, or assert the CONTROLLER_HALT Interrupt. This behavior is useful for protocols like Serial Camera Control Bus (SCCB).
11	RCONT	W	0x0	Read continue/stop: * 0 — Read Stop: The controller NACKs the last data byte. Use this if this is the last READ in a sequence. * 1 — Read Continue: The controller ACKs the last data byte. Use this if this is an intermediate READ in a sequence.
10	READB	W	0x0	Read/write: * 0 - Issue WRITE transaction * 1 - Issue READ transaction
9	STOP	W	0x0	Generate a STOP condition on the bus after sending the byte.
8	START	W	0x0	Generate a START condition on the bus before sending the byte.

Bits	Field	Access	Reset	Description
7:0	FBYTE	W WMOD	0x0	Writing to this register pushes an entry into the Controller TX FIFO. The meaning of this field depends on the value of the READB field: * READB = 0 - This field is the WRITE data byte. * READB = 1 - This field specifies the number of bytes to read from the target. Setting this field to 0 reads 256 bytes.

2.1.6.7.9.2.2.1.9. FIFO_CTRL

Table 1963. i2c.FIFO_CTRL fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	TXRST	W 1P	0x0	Target Mode control: writing 1 resets the Target TX FIFO.
7	ACQRST	W 1P	0x0	Target Mode control: writing 1 resets the Target RX FIFO.
6:2	Reserved	-	-	Reserved
1	FMTRST	W 1P	0x0	Controller Mode control: writing 1 resets the Controller TX FIFO.
0	RXRST	W 1P	0x0	Controller Mode control: writing 1 resets the Controller RX FIFO.

2.1.6.7.9.2.2.1.10. HOST_FIFO_CONFIG

Table 1964. i2c.HOST_FIFO_CONFIG fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	FMT_THRESH	RW	0x0	The FMT_THRESH interrupt remains asserted while the Controller TX FIFO level is less than this setting.
15:12	Reserved	-	-	Reserved
11:0	RX_THRESH	RW	0x0	The RX_THRESH interrupt remains asserted while the Controller RX FIFO level is greater than this setting.

2.1.6.7.9.2.2.1.11. TARGET_FIFO_CONFIG

Table 1965. i2c.TARGET_FIFO_CONFIG fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	ACQ_THRESH	RW	0x0	The ACQ_THRESH interrupt remains asserted while the Target RX FIFO level is greater than this setting.
15:12	Reserved	-	-	Reserved
11:0	TX_THRESH	RW	0x0	The TX_THRESH interrupt remains asserted while the Target TX FIFO level is less than this setting.

2.1.6.7.9.2.2.1.12. HOST_FIFO_STATUS

Table 1966. i2c.HOST_FIFO_STATUS fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	RXLVL	R	-	Controller RX FIFO fill level.
15:12	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
11:0	FMTLVL	R	-	Controller TX FIFO fill level.

2.1.6.7.9.2.2.1.13. TARGET_FIFO_STATUS

Table 1967. i2c.TARGET_FIFO_STATUS fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	ACQLVL	R	0x0	Target RX FIFO fill level.
15:12	Reserved	-	-	Reserved
11:0	TXLVL	R	0x0	Target TX FIFO fill level.

2.1.6.7.9.2.2.1.14. OVRD

Table 1968. i2c.OVRD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	SDAVAL	RW	0x0	Global control: SDA override value: * 0 - Pull the SDA line low * 1 - Release the SDA line
1	SCLVAL	RW	0x0	Global control: SCL override value: * 0 - Pull the SCL line low * 1 - Release the SCL line
0	TXOVRDEN	RW	0x0	Global control: enables control of the SDA and SCL lines through the SDA_VAL and SCL_VAL fields, respectively.

2.1.6.7.9.2.2.1.15. VAL

Table 1969. i2c.VAL fields

Bits	Field	Access	Reset	Description
31:16	SDA_RX	R	0x0	Global status: contains the last 16 SDA over-sampled values. LSB is most recent.
15:0	SCL_RX	R	0x0	Global status: contains the last 16 SCL over-sampled values. LSB is most recent.

2.1.6.7.9.2.2.1.16. TIMING0

Table 1970. i2c.TIMING0 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	TLOW	RW	0x0	Global control: specifies the LOW period of SCL (t_LOW) in system clock cycles. Must be 2. See Table 11 in the I2C Specification for more details. This field is sized to meet the I2C Standard-mode (100 kHz) minimum t_LOW = 4.7 µs requirement, assuming a 1 GHz system clock.
15:13	Reserved	-	-	Reserved
12:0	THIGH	RW	0x0	Global control: specifies the HIGH period of SCL (t_HIGH) in system clock cycles. Must be 2. See Table 11 in the I²C Specification for details. This field is sized to meet the I2C Standard-mode (100 kHz)'s minimum t_HIGH = 4.0 µs requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.1.17. TIMING1

Table 1971. i2c.TIMING1 fields

Bits	Field	Access	Reset	Description
31:25	Reserved	-	-	Reserved
24:16	T_F	RW	0x0	Global control: specifies the fall time of SDA and SCL (t_f) in system clock cycles. The fall time is measured from 70% to 30% of the signal swing. See Table 11 in the I2C Specification for more details. This field is sized to meet I2C Standard-mode (100 kHz)'s maximum t_f = 300 ns requirement, assuming a 1 GHz system clock.
15:10	Reserved	-	-	Reserved
9:0	T_R	RW	0x0	Global control: specifies the rise time of SDA and SCL (t_r) in system clock cycles. The rise time is measured from 30% to 70% of the signal swing. See Table 11 in the I2C Specification for more details. This field is sized to meet I2C Standard-mode (100 kHz)'s maximum t_r = 1000 ns requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.1.18. TIMING2

Table 1972. i2c.TIMING2 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	THD_STA	RW	0x0	Global control: specifies the setup time for a (repeated) START condition (t_HD;STA) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet I2C Standard-mode (100 kHz)'s minimum t_HD;STA = 4.0 µs requirement, assuming a 1 GHz system clock.
15:13	Reserved	-	-	Reserved
12:0	TSU_STA	RW	0x0	Global control: specifies the setup time for a repeated START condition (t_SU;STA) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet I2C Standard-mode (100 kHz)'s minimum t_SU;STA = 4.7 µs requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.1.19. TIMING3

Table 1973. i2c.TIMING3 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	THD_DAT	RW	0x0	Global control: specifies the data and (N)ACK bits hold time (t_HD;DAT) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet the I2C Standard-mode (100 kHz)'s t_HD;DAT = 5.0 µs minimum requirement, assuming a 1 GHz system clock.
15:9	Reserved	-	-	Reserved
8:0	TSU_DAT	RW	0x0	Global control: specifies the data setup time (t_SU;DAT) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet the I2C Standard-mode (100 kHz)'s t_SU;DAT = 250 ns minimum requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.1.20. TIMING4

Table 1974. i2c.TIMING4 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	T_BUF	RW	0x0	Global control: specifies the time between a STOP and START condition (t_BUF) in system clock cycles. See Table 11 in the I²C Specification for details. This field is sized to meet I2C Standard-mode (100kHz)'s t_BUF = 4.7 µs minimum requirement, assuming a 1 GHz system clock.
15:13	Reserved	-	-	Reserved
12:0	TSU_STO	RW	0x0	Global control: specifies the setup time for a STOP condition (t_SU;STO) in system clock cycles. See Table 11 in the I²C Specification for details. This field is sized to meet I2C Standard-mode (100 kHz)'s t_SU;STO = 4.0 µs minimum requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.1.21. TIMEOUT_CTRL

Table 1975. i2c.TIMEOUT_CTRL fields

Bits	Field	Access	Reset	Description
31	EN	RW	0x0	Timeout Enable.
30	MODE	RW	0x0	Global control: timeout mode. * 0 - Stretch Timeout (Controller Mode only). If the target stretches the clock for more time than TIMEOUT_CTRL.VAL, the STRETCH_TIMEOUT interrupt will be asserted. * 1 - Bus Timeout. If SCL is LOW for more time than TIMEOUT_CTRL.VAL: * In Controller Mode, the CONTROLLER_EVENTS.BUS_TIMEOUT flag will be asserted, triggering the CONTROLLER_HALT interrupt. * In Target Mode, the TARGET_EVENTS.BUS_TIMEOUT flag will be set, triggering the TX_STRETCH interrupt.
29:0	VAL	RW	0x0	Global control: Specifies the timeout value in system clock cycles. The meaning of this field depends on MODE.

2.1.6.7.9.2.2.1.22. TARGET_ID

Table 1976. i2c.TARGET_ID fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:21	MASK1	RW	0x0	ADDRESS1 mask.
20:14	ADDRESS1	RW	0x0	Target Address 1. This target responds if the 7-bit address matches ADDRESS1 & MASK1. MASK1 = 0x0 disables this address.
13:7	MASK0	RW	0x0	ADDRESS0 mask.
6:0	ADDRESS0	RW	0x0	Target Address 0. This target responds if the 7-bit address matches ADDRESS0 & MASK0. MASK0 = 0x0 disables this address.

2.1.6.7.9.2.2.1.23. ACQDATA

Table 1977. i2c.ACQDATA fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
10:8	SIGNAL	R	0x0	This field indicates if this FIFO entry represents/is associated with control signal(s): * 0x0 - The entry is an ordinary data byte that has been ACKed. * 0x1 - The entry is an address byte preceded by a START. * 0x2 - The entry is a STOP condition following ACKed data bytes. * 0x3 - The entry is an address byte preceded by a repeated START. * 0x4 - The entry is a NACKed data byte. * 0x5 - The entry is an address byte preceded by a (repeated) START. However, the data bytes that followed this address byte were NACKed. * 0x6 - Error. A transaction preceding ended abnormally, for example, due to an unexpected STOP condition, a Bus or Stretch Timeout, a software NACK, or a lost arbitration. If the FIFO does not have enough space to record a complete transaction, an Error (0x6) entry may appear alone.
7:0	ABYTE	R RMOD	0x0	Reading this register pops the ACQ FIFO. The meaning of this field depends on SIGNAL: * SIGNAL = 0x0, 0x1, 0x3, 0x4, or 0x5 - This field contains an address or data byte sent by the controller. * SIGNAL = 0x2, 0x6 - This field is meaningless.

2.1.6.7.9.2.2.1.24. TXDATA

Table 1978. i2c.TXDATA fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	W WMOD	0x0	Writing to this register pushes data into the Target TX FIFO. The controller reads data from this FIFO during a READ transaction.

2.1.6.7.9.2.2.1.25. HOST_TIMEOUT_CTRL

Table 1979. i2c.HOST_TIMEOUT_CTRL fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30:0	VAL	RW	0x0	Target/Monitor Mode control: controller clock generation timeout value specified in system clock cycles. * Target Mode - If the controller stops generating the clock for more time than this setting, this target asserts the Controller Timeout Interrupt. * Monitor Mode - this field is required to be nonzero for the Bus Monitor to transition out of the initial Busy state. Set this field to 0x0 to disable this behavior.

2.1.6.7.9.2.2.1.26. TARGET_TIMEOUT_CTRL

Table 1980. i2c.TARGET_TIMEOUT_CTRL fields

Bits	Field	Access	Reset	Description
31	EN	RW	0x0	Enable Target Timeout.
30:0	VAL	RW	0x0	When this target has stretched the clock for more time than this setting, this target will NACK incoming data bytes or release the SDA line for outgoing data bytes. The count is cumulative over an entire transaction. In other words, this is SMBus's cumulative target clock extension time. The behavior for the address byte is configurable via CTRL.NACK_ADDR_AFTER_TIMEOUT.

2.1.6.7.9.2.2.1.27. TARGET_NACK_COUNT

Table 1981. i2c.TARGET_NACK_COUNT fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	TARGET_NACK_COUNT	RW RC	0x0	Indicates the number of transactions NACKed by this target since the last read of this register, saturating at 255. This field can be used to track how many transactions were missed when the Target RX FIFO is full.

2.1.6.7.9.2.2.1.28. TARGET_ACK_CTRL

Table 1982. i2c.TARGET_ACK_CTRL fields

Bits	Field	Access	Reset	Description
31	NACK	W 1P	0x0	When STATUS.ACK_CTRL_STRETCH = 1, writing 1 to this field causes this target to NACK all bytes of the transaction. Effective only when CTRL.ACK_CTRL_EN = 1.
30:9	Reserved	-	-	Reserved
8:0	NBYTES	RW	0x0	When STATUS.ACK_CTRL_STRETCH = 1, writing to this register specifies the number of bytes this target should ACK. The count decrements per byte ACKed. Effective only when CTRL.ACK_CTRL_EN = 1. See CTRL.ACK_CTRL_EN for details. This control field is used to implement SMBus's mid-transfer (N)ACK responses.

2.1.6.7.9.2.2.1.29. ACQ_FIFO_NEXT_DATA

Table 1983. i2c.ACQ_FIFO_NEXT_DATA fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R	0x0	This field contains the next byte to be pushed into the Target RX FIFO, allowing software to decide whether to accept or reject it. Valid only when STATUS.ACK_CTRL_STRETCH = 1. See CTRL.ACK_CTRL_EN for details.

2.1.6.7.9.2.2.1.30. HOST_NACK_HANDLER_TIMEOUT

Table 1984. i2c.HOST_NACK_HANDLER_TIMEOUT fields

Bits	Field	Access	Reset	Description
31	EN	RW	0x0	Enables Controller NACK Timeout.
30:0	VAL	RW	0x0	Timeout value (specified in system clock cycles) for this controller Mode to automatically STOP a transaction when CONTROLLER_EVENTS.NACK is set.

2.1.6.7.9.2.2.1.31. CONTROLLER_EVENTS

Table 1985. i2c.CONTROLLER_EVENTS fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	ARBITRATION_LOST	RW1C	0x0	Indicates that the controller has halted due to it losing an arbitration against another controller. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.

Bits	Field	Access	Reset	Description
2	BUS_TIMEOUT	RW1C	0x0	Indicates that this controller has halted due to a Bus Timeout. See TIMEOUT_CTRL for details. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.
1	UNHANDLED_NACK_TIMEOUT	RW1C	0x0	Indicates that this controller has halted due to a Controller NACK Timeout. See HOST_NACK_HANDLER_TIMEOUT for details. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.
0	NACK	RW1C	0x0	Indicates that this controller has halted due to an unexpected NACK sent by the target. This behavior can be disabled by writing 1 to FDATA.NAKOK. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.

2.1.6.7.9.2.2.1.32. TARGET_EVENTS

Table 1986. i2c.TARGET_EVENTS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	STOP_DETECT	RW1C	0x0	Stop Detect Flag (Target Mode only). Set to 1 by hardware when a STOP is detected while CTRL.ENABLETARGET = 1. Cleared when software writes 1.
3	START_DETECT	RW1C	0x0	Start Detect Flag (Target Mode only). Set to 1 by hardware when a START (or repeated START) is detected while CTRL.ENABLETARGET = 1. Cleared when software writes 1.
2	ARBITRATION_LOST	RW1C	0x0	Indicates that a controller has lost arbitration, causing a READ transaction to end. This bit triggers the TX_STRETCH interrupt. Writing 1 clears this bit.
1	BUS_TIMEOUT	RW1C	0x0	Indicates that this target has halted due a Bus Timeout terminating a READ transaction. See TIMEOUT_CTRL for details. This bit triggers the TX_STRETCH interrupt. Writing 1 clears this bit.
0	TX_PENDING	RW1C	0x0	Indicates that the target is stretching the clock due to receiving a READ address byte and waiting for software to confirm the release of the Target TX FIFO data. Valid only if CTRL.TX_STRETCH_CTRL_EN = 1. See CTRL.TX_STRETCH_CTRL_EN for details. This bit triggers the TX_STRETCH interrupt. Writing 1 clears this bit.

2.1.6.7.9.2.2.1.33. SMBUS_STATUS

Table 1987. i2c.SMBUS_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	SMBALERT	R	0x0	Controller Mode status: indicates that the smbalert_ni input is asserted.
3:1	Reserved	-	-	Reserved
0	SMBSUS	R	0x0	Target Mode status: indicates that the smbsus_ni input is asserted.

2.1.6.7.9.2.2.2. I2C Control Address Map

Per-instance pad-function select, SMBus pad direction, and SMBus alert enable.

NOTE

Register Arrays:

- **I2C_CTRL[3]**: 3 registers, base 0x0, stride 0x4

Table 1988. I2C Control Address Map register list

Address	Name	Access	Description
0x0 - 0x8	I2C_CTRL[3]	RW	Control Register

2.1.6.7.9.2.2.2.1. I2C_CTRL[3]

Table 1989. i2c_ctrl.I2C_CTRL[3] fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	SMBUS_EN	RW	0x0	SMBus Enable. Gates the SMBus Alert signal.
7:5	Reserved	-	-	Reserved
4	I2C_CONTROLLER_MODE_EN	RW	0x0	SMBus Pad Direction. When set, the SMBus alert pad is an input and the SMBus suspend pad is an output, as for an SMBus host. When clear, the alert pad is an output and the suspend pad is an input, as for an SMBus target. SCL and SDA are unaffected. Program it to agree with the core's CTRL.ENABLEHOST and CTRL.ENABLETARGET setting.
3:1	Reserved	-	-	Reserved
0	I2C_EN	RW	0x0	I2C Pad Function Select. When set, the integration routes this instance's SCL, SDA, SMBus alert and SMBus suspend signals to their pads. Does not enable the I2C core; CTRL.ENABLEHOST and CTRL.ENABLETARGET select the core's operating mode.

2.1.6.7.9.2.2.3. I2C Wrapper Address Map

Wrapper address map instantiating the per-controller I2C register blocks and shared control.

NOTE

Register Arrays:

- **i2c[3].INTR_STATE**: 3 registers, base 0x0, stride 0x200
- **i2c[3].INTR_ENABLE**: 3 registers, base 0x4, stride 0x200
- **i2c[3].INTR_TEST**: 3 registers, base 0x8, stride 0x200
- **i2c[3].SMBUS_CTRL**: 3 registers, base 0xC, stride 0x200
- **i2c[3].CTRL**: 3 registers, base 0x10, stride 0x200
- **i2c[3].STATUS**: 3 registers, base 0x14, stride 0x200
- **i2c[3].RDATA**: 3 registers, base 0x18, stride 0x200
- **i2c[3].FDATA**: 3 registers, base 0x1C, stride 0x200
- **i2c[3].FIFO_CTRL**: 3 registers, base 0x20, stride 0x200
- **i2c[3].HOST_FIFO_CONFIG**: 3 registers, base 0x24, stride 0x200
- **i2c[3].TARGET_FIFO_CONFIG**: 3 registers, base 0x28, stride 0x200
- **i2c[3].HOST_FIFO_STATUS**: 3 registers, base 0x2C, stride 0x200
- **i2c[3].TARGET_FIFO_STATUS**: 3 registers, base 0x30, stride 0x200
- **i2c[3].OVRD**: 3 registers, base 0x34, stride 0x200
- **i2c[3].VAL**: 3 registers, base 0x38, stride 0x200
- **i2c[3].TIMING0**: 3 registers, base 0x3C, stride 0x200
- **i2c[3].TIMING1**: 3 registers, base 0x40, stride 0x200

- **i2c[3].TIMING2**: 3 registers, base 0x44, stride 0x200
- **i2c[3].TIMING3**: 3 registers, base 0x48, stride 0x200
- **i2c[3].TIMING4**: 3 registers, base 0x4C, stride 0x200
- **i2c[3].TIMEOUT_CTRL**: 3 registers, base 0x50, stride 0x200
- **i2c[3].TARGET_ID**: 3 registers, base 0x54, stride 0x200
- **i2c[3].ACQDATA**: 3 registers, base 0x58, stride 0x200
- **i2c[3].TXDATA**: 3 registers, base 0x5C, stride 0x200
- **i2c[3].HOST_TIMEOUT_CTRL**: 3 registers, base 0x60, stride 0x200
- **i2c[3].TARGET_TIMEOUT_CTRL**: 3 registers, base 0x64, stride 0x200
- **i2c[3].TARGET_NACK_COUNT**: 3 registers, base 0x68, stride 0x200
- **i2c[3].TARGET_ACK_CTRL**: 3 registers, base 0x6C, stride 0x200
- **i2c[3].ACQ_FIFO_NEXT_DATA**: 3 registers, base 0x70, stride 0x200
- **i2c[3].HOST_NACK_HANDLER_TIMEOUT**: 3 registers, base 0x74, stride 0x200
- **i2c[3].CONTROLLER_EVENTS**: 3 registers, base 0x78, stride 0x200
- **i2c[3].TARGET_EVENTS**: 3 registers, base 0x7C, stride 0x200
- **i2c[3].SMBUS_STATUS**: 3 registers, base 0x80, stride 0x200
- **I2C_CTRL[3]**: 3 registers, base 0xE00, stride 0x4

Table 1990. I2C Wrapper Address Map register list

Address	Name	Access	Description
0x0 - 0x400	i2c[3].INTR_STATE	RW	Interrupt Status Register
0x4 - 0x404	i2c[3].INTR_ENABLE	RW	Interrupt Enable Register
0x8 - 0x408	i2c[3].INTR_TEST	RW	Interrupt Test Register
0xC - 0x40C	i2c[3].SMBUS_CTRL	RW	SMBus Control Register
0x10 - 0x410	i2c[3].CTRL	RW	Control Register
0x14 - 0x414	i2c[3].STATUS	R	Status Register
0x18 - 0x418	i2c[3].RDATA	R	Controller RX FIFO Access Register (Controller Mode only)
0x1C - 0x41C	i2c[3].FDATA	W	Controller TX FIFO Access Register (Controller Mode only)
0x20 - 0x420	i2c[3].FIFO_CTRL	W	FIFO Control Register
0x24 - 0x424	i2c[3].HOST_FIFO_CONFIG	RW	Controller FIFO Configuration Register (Controller Mode only)
0x28 - 0x428	i2c[3].TARGET_FIFO_CONFIG	RW	Target FIFOs Configuration Register (Target Mode only)
0x2C - 0x42C	i2c[3].HOST_FIFO_STATUS	R	Controller FIFOs Status Register (Controller Mode only)
0x30 - 0x430	i2c[3].TARGET_FIFO_STATUS	R	Target FIFOs Status Register (Target Mode only)

Address	Name	Access	Description
0x34 - 0x434	i2c[3].OVRD	RW	Override Control Register
0x38 - 0x438	i2c[3].VAL	R	Bus Oversampled Values Register
0x3C - 0x43C	i2c[3].TIMING0	RW	SCL LOW and HIGH Periods Register
0x40 - 0x440	i2c[3].TIMING1	RW	Bus Rise and Fall Times Register
0x44 - 0x444	i2c[3].TIMING2	RW	START Condition Setup and Hold Times Register
0x48 - 0x448	i2c[3].TIMING3	RW	Data Setup and Hold Times Register
0x4C - 0x44C	i2c[3].TIMING4	RW	STOP Condition Setup Time and Bus Free Time Register
0x50 - 0x450	i2c[3].TIMEOUT_CTRL	RW	Timeout Control Register
0x54 - 0x454	i2c[3].TARGET_ID	RW	Target ID Register (Target Mode only)
0x58 - 0x458	i2c[3].ACQDATA	R	Target RX FIFO Access Register (Target Mode only)
0x5C - 0x45C	i2c[3].TXDATA	W	Target TX FIFO Access Register (Target Mode only).
0x60 - 0x460	i2c[3].HOST_TIMEOUT_CTRL	RW	Controller Timeout Control Register
0x64 - 0x464	i2c[3].TARGET_TIMEOUT_CTRL	RW	Target Timeout Control Register (Target Mode only)
0x68 - 0x468	i2c[3].TARGET_NACK_COUNT	RW	Target NACK Count Register (Target Mode only)
0x6C - 0x46C	i2c[3].TARGET_ACK_CTRL	RW	Target ACK Control Register (Target Mode only)
0x70 - 0x470	i2c[3].ACQ_FIFO_NEXT_DATA	R	Target RX FIFO Next Byte Register (Target Mode only)
0x74 - 0x474	i2c[3].HOST_NACK_HANDLER_TIMEOUT	RW	Controller NACK Timeout Register (Controller Mode only)
0x78 - 0x478	i2c[3].CONTROLLER_EVENTS	RW	Controller Events Register (Controller Mode only)
0x7C - 0x47C	i2c[3].TARGET_EVENTS	RW	Target Events Register (Target Mode)
0x80 - 0x480	i2c[3].SMBUS_STATUS	R	SMBus Status Register
0xE00 - 0xE08	I2C_CTRL[3]	RW	Control Register

2.1.6.7.9.2.2.3.1. i2c[3].INTR_STATE

Table 1991. i2c_wrap.i2c[3].INTR_STATE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	TARGET_RX_FIFO_ERROR	RW1C	0x0	Target Mode interrupt: asserted when the Target RX FIFO has a parity error. Write 1 to clear.

Bits	Field	Access	Reset	Description
18	TARGET_TX_FIFO_ERROR	RW1C	0x0	Target Mode interrupt: asserted when the Target TX FIFO has a parity error. Write 1 to clear.
17	CONTROLLER_RX_FIFO_ERROR	RW1C	0x0	Controller Mode interrupt: asserted when the Controller RX FIFO has a parity error. Write 1 to clear.
16	CONTROLLER_TX_FIFO_ERROR	RW1C	0x0	Controller Mode interrupt: asserted when the Controller TX FIFO has a parity error. Write 1 to clear.
15	SMBALERT	RW1C	0x0	Controller Mode interrupt: asserted when smbalert_ni is asserted. Write 1 to clear.
14	HOST_TIMEOUT	RW1C	0x0	Target Mode interrupt: asserted when the controller stops generating the clock longer than HOST_TIMEOUT_CTRL.VAL. Write 1 to clear.
13	UNEXP_STOP	RW1C	0x0	Target Mode interrupt: asserted when the controller sends this target a STOP before this target NACKs. Write 1 to clear.
12	ACQ_STRETCH	R	0x0	Target Mode interrupt: remains asserted while the target is stretching the clock because 1) the Target RX FIFO is full or 2) the TARGET_ACK_CTRL.NBYTES count has reached 0 (only if CTRL.ACK_CTRL_EN = 1).
11	TX_THRESHOLD	R	0x0	Target Mode interrupt: remains asserted while the Target TX FIFO level is less than TARGET_FIFO_CONFIG.TX_THRESH.
10	TX_STRETCH	R	0x0	Target Mode interrupt: remains asserted while this target is stretching the clock or has halted. The flags in the TARGET_EVENTS register explain the reason(s) for clock stretching/halting. Clearing the TARGET_EVENTS flags clears this interrupt.
9	CMD_COMPLETE	RW1C	0x0	Controller/Target Mode interrupt: asserted when this/the controller finishes generating a STOP or repeated START. Write 1 to clear.
8	SDA_UNSTABLE	RW1C	0x0	Controller Mode interrupt: asserted when the target fails to keep SDA stable during a transmission. Write 1 to clear.
7	STRETCH_TIMEOUT	RW1C	0x0	Controller Mode interrupt: asserted when the target stretches the clock longer than TIMEOUT_CTRL.VAL (valid only when TIMEOUT_CTRL.MODE = 0). Write 1 to clear.
6	SDA_INTERFERENCE	RW1C	0x0	Controller Mode interrupt: asserted when SDA is unexpectedly pulled LOW by another controller. Write 1 to clear.
5	SCL_INTERFERENCE	RW1C	0x0	Controller Mode interrupt: asserted when SCL is unexpectedly pulled LOW by another controller. Write 1 to clear.
4	CONTROLLER_HALT	R	0x0	Controller Mode interrupt: remains asserted while this controller halts. The flags in the CONTROLLER_EVENTS register explain the reason(s) for the halting. Clearing the CONTROLLER_EVENTS flags clears this interrupt.
3	RX_OVERFLOW	RW1C	0x0	Controller Mode interrupt: asserted when the Controller RX FIFO overflows. Write 1 to clear.
2	ACQ_THRESHOLD	R	0x0	Target Mode interrupt: remains asserted while the Target RX FIFO level is greater than TARGET_FIFO_CONFIG.ACQ_THRESH.
1	RX_THRESHOLD	R	0x0	Controller Mode interrupt: remains asserted while the Controller RX FIFO level is greater than HOST_FIFO_CONFIG.RX_THRESH.
0	FMT_THRESHOLD	R	0x0	Controller Mode interrupt: remains asserted while the Controller TX FIFO level is less than HOST_FIFO_CONFIG.FMT_THRESH.

2.1.6.7.9.2.2.3.2. i2c[3].INTR_ENABLE

Table 1992. i2c_wrap.i2c[3].INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	TARGET_RX_FIFO_ERROR	RW	0x0	Enables the TARGET_RX_FIFO_ERROR interrupt.

Bits	Field	Access	Reset	Description
18	TARGET_TX_FIFO_ERROR	RW	0x0	Enables the TARGET_TX_FIFO_ERROR interrupt.
17	CONTROLLER_RX_FIFO_ERROR	RW	0x0	Enables the CONTROLLER_RX_FIFO_ERROR interrupt.
16	CONTROLLER_TX_FIFO_ERROR	RW	0x0	Enables the CONTROLLER_TX_FIFO_ERROR interrupt.
15	SMBALERT	RW	0x0	Enables the SMBALERT interrupt.
14	HOST_TIMEOUT	RW	0x0	Enables the HOST_TIMEOUT interrupt.
13	UNEXP_STOP	RW	0x0	Enables the UNEXP_STOP interrupt.
12	ACQ_STRETCH	RW	0x0	Enables the ACQ_STRETCH interrupt.
11	TX_THRESHOLD	RW	0x0	Enables the TX_THRESHOLD interrupt.
10	TX_STRETCH	RW	0x0	Enables the TX_STRETCH interrupt.
9	CMD_COMPLETE	RW	0x0	Enables the CMD_COMPLETE interrupt.
8	SDA_UNSTABLE	RW	0x0	Enables the SDA_UNSTABLE interrupt.
7	STRETCH_TIMEOUT	RW	0x0	Enables the STRETCH_TIMEOUT interrupt.
6	SDA_INTERFERENCE	RW	0x0	Enables the SDA_INTERFERENCE interrupt.
5	SCL_INTERFERENCE	RW	0x0	Enables the SCL_INTERFERENCE interrupt.
4	CONTROLLER_HALT	RW	0x0	Enables the CONTROLLER_HALT interrupt.
3	RX_OVERFLOW	RW	0x0	Enables the RX_OVERFLOW interrupt.
2	ACQ_THRESHOLD	RW	0x0	Enables the ACQ_THRESHOLD interrupt.
1	RX_THRESHOLD	RW	0x0	Enables the RX_THRESHOLD interrupt.
0	FMT_THRESHOLD	RW	0x0	Enables the FMT_THRESHOLD interrupt.

2.1.6.7.9.2.2.3.3. i2c[3].INTR_TEST

Table 1993. i2c_wrap.i2c[3].INTR_TEST fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	TARGET_RX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the TARGET_RX_FIFO_ERROR interrupt.
18	TARGET_TX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the TARGET_TX_FIFO_ERROR interrupt.
17	CONTROLLER_RX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the CONTROLLER_RX_FIFO_ERROR interrupt.
16	CONTROLLER_TX_FIFO_ERROR	W 1P	0x0	Writing 1 forces the CONTROLLER_TX_FIFO_ERROR interrupt.
15	SMBALERT	W 1P	0x0	Writing 1 forces the SMBALERT interrupt.
14	HOST_TIMEOUT	W 1P	0x0	Writing 1 forces the HOST_TIMEOUT interrupt.
13	UNEXP_STOP	W 1P	0x0	Writing 1 forces the UNEXP_STOP interrupt.
12	ACQ_STRETCH	RW	0x0	Writing 1 forces the ACQ_STRETCH interrupt. Writing 0 releases it.
11	TX_THRESHOLD	RW	0x0	Writing 1 forces the TX_THRESHOLD interrupt. Writing 0 releases it.
10	TX_STRETCH	RW	0x0	Writing 1 forces the TX_STRETCH interrupt. Writing a 0 releases it.
9	CMD_COMPLETE	W 1P	0x0	Writing 1 forces the CMD_COMPLETE interrupt.
8	SDA_UNSTABLE	W 1P	0x0	Writing 1 forces the SDA_UNSTABLE interrupt.
7	STRETCH_TIMEOUT	W 1P	0x0	Writing 1 forces the STRETCH_TIMEOUT interrupt.
6	SDA_INTERFERENCE	W 1P	0x0	Writing 1 forces the SDA_INTERFERENCE interrupt.
5	SCL_INTERFERENCE	W 1P	0x0	Writing 1 forces the SCL_INTERFERENCE interrupt.
4	CONTROLLER_HALT	RW	0x0	Writing 1 forces the CONTROLLER_HALT interrupt. Writing 0 releases it.
3	RX_OVERFLOW	W 1P	0x0	Writing 1 forces the RX_OVERFLOW interrupt.

Bits	Field	Access	Reset	Description
2	ACQ_THRESHOLD	RW	0x0	Writing 1 forces the ACQ_THRESHOLD interrupt. Writing 0 releases it.
1	RX_THRESHOLD	RW	0x0	Writing 1 forces the RX_THRESHOLD interrupt. Writing 0 releases it.
0	FMT_THRESHOLD	RW	0x0	Writing 1 forces the FMT_THRESHOLD interrupt. Writing 0 releases it.

2.1.6.7.9.2.2.3.4. i2c[3].SMBUS_CTRL

Table 1994. i2c_wrap.i2c[3].SMBUS_CTRL fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	SMBALERT	RW	0x0	Target Mode control: asserts the smbalert_no output. This bit clears itself when the controller addresses this target.
3:1	Reserved	-	-	Reserved
0	SMBSUS	RW	0x0	Controller Mode control: asserts the smbsus_no output.

2.1.6.7.9.2.2.3.5. i2c[3].CTRL

Table 1995. i2c_wrap.i2c[3].CTRL fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ACQ_START_STOP_EN	RW	0x0	ACQ FIFO Start/Stop Enable (Target Mode only): * 0 - Start/Stop symbols are NOT written into the ACQ FIFO. The firmware should rely on TARGET_EVENTS.START_DETECT and TARGET_EVENTS.STOP_DETECT flags to detect Start/Stop events. * 1 - Start/Stop symbols ARE written into the ACQ FIFO (legacy behavior). When a START (or repeated START) is detected, an ACQ_START or ACQ_RESTART entry is written. When a STOP is detected, an ACQ_STOP or ACQ_NACK_STOP entry is written.
6	TX_STRETCH_CTRL_EN	RW	0x0	Target mode control: enables the Software TX Stretch Control Mechanism. If this bit is: * 0 - Automatic TX Stretch: When this target receives a READ address byte, it only stretches the clock if the TX FIFO is empty; otherwise, it pops the FIFO and transmits the data byte. The target never sets the TARGET_EVENTS register flags in this mode. * 1 - Software TX Stretch Mode: When this target receives a READ address, it always stretches the clock and sets the TARGET_EVENTS.TX_PENDING flag. The software can: 1. confirm the release and transmission of the TX FIFO data by writing a 1 to clear the TARGET_EVENTS.TX_PENDING flag; or 2. reset the TX FIFO by writing 1 to FIFO_CTRL.TXRST and load in new data via the TXDATA register—useful whenthe READ address is targeting a different function of the target. In this mode, the target always sets the TARGET_EVENTS register flags.

Bits	Field	Access	Reset	Description
5	MULTI_CONTROLLER_MONITOR_EN	RW	0x0	Global control: enables the Bus Monitor. Set this bit to 1 only in a multi-controller environment. If a 0→`1` transition happens while ENABLEHOST and ENABLETARGET are both 0, the Bus Monitor will enable and begin in the 'Bus Busy' state. To transition to a 'Bus Free' state, HOST_TIMEOUT_CTRL must be nonzero so the Bus Monitor may count out idle cycles to confirm the freedom to transmit. In addition, the Bus Monitor will track whether the bus is free based on the enabled timeouts and detected STOP symbols. For Multi-Controller Mode, ensure MULTI_CONTROLLER_MONITOR_EN becomes 1 no later than ENABLEHOST or ENABLETARGET. This bit can be set at the same time as either or both of the other two, though. Note that if MULTI_CONTROLLER_MONITOR_EN is set after ENABLEHOST or ENABLETARGET, the Bus Monitor will begin in the 'Bus Free' state instead. This would violate the proper protocol for a controller to join a multi-controller environment. However, if this controller is known to be the first to join, this ordering will enable skipping the idle wait. When 0, the bus monitor will report that the bus is always free, so the Controller FSM is never blocked from transmitting.
4	ACK_CTRL_EN	RW	0x0	Target Mode control: enables the Software ACK Control Mechanism. If this bit is: * 0 - This target ACKs a data byte whenever the ACQ FIFO has space. * 1 - This target ACKs the first TARGET_ACK_CTRL.NBYTES bytes. If another byte arrives, this target stretches the clock and awaits software intervention (and asserts STATUS.ACK_CTRL_STRETCH). The software can 1. accept the new byte(s) by reloading the TARGET_ACK_CTRL.NBYTES counter; or 2. reject the new byte(s) by writing 1 to TARGET_ACK_CTRL.NACK (useful for SMBus).
3	NACK_ADDR_AFTER_TIMEOUT	RW	0x0	Target Mode control: NACK address after timeout. If this bit is: * 0 - This target ACKs the address byte even if a Stretch Timeout occurs (useful for SMBus). * 1 - This target NACKs the address byte when a Stretch Timeout occurs.
2	LLPBK	RW	0x0	Global control: enables line loop-back. In Controller Mode, the internal logic sees the smbalert_ni input as deasserted. In Target Mode, this target sends all received SDA data back out, and the internal logic sees received data as all 1's.
1	ENABLETARGET	RW	0x0	Global control: configures this device's operating mode. * ENABLEHOST = 1 and ENABLETARGET = 0 — Controller Mode * ENABLEHOST = 0 and ENABLETARGET = 1 — Target Mode * ENABLEHOST = 1 and ENABLETARGET = 1 — Hybrid Mode * ENABLEHOST = 0 and ENABLETARGET = 0 — Monitor Mode
0	ENABLEHOST	RW	0x0	Global control: configures this device's operating mode. * ENABLEHOST = 1 and ENABLETARGET = 0 — Controller Mode * ENABLEHOST = 0 and ENABLETARGET = 1 — Target Mode * ENABLEHOST = 1 and ENABLETARGET = 1 — Hybrid Mode * ENABLEHOST = 0 and ENABLETARGET = 0 — Monitor Mode

2.1.6.7.9.2.2.3.6. i2c[3].STATUS

Table 1996. i2c_wrap.i2c[3].STATUS fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10	ACK_CTRL_STRETCH	R	0x0	Target Mode status: indicates that this target is stretching the clock due to the Software ACK Control Mechanism. See CTRL.ACK_CTRL_EN for details.
9	ACQEMPTY	R	0x1	Target Mode status: Target RX FIFO empty.
8	TXEMPTY	R	0x1	Target Mode status: Target TX FIFO empty.
7	ACQFULL	R	0x0	Target Mode status: Target RX FIFO full.
6	TXFULL	R	0x0	Target Mode status: Target TX FIFO full.

Bits	Field	Access	Reset	Description
5	RXEMPTY	R	0x1	Controller Mode status: Controller RX FIFO empty.
4	TARGETIDLE	R	0x1	Target Mode status: Target FSM idle.
3	HOSTIDLE	R	0x1	Controller Mode status: Controller FSM idle.
2	FMTEMPTY	R	0x1	Controller Mode status: Controller TX FIFO Empty.
1	RXFULL	R	0x0	Controller Mode status: Controller RX FIFO Full.
0	FMTFULL	R	0x0	Controller Mode status: Controller TX FIFO Full.

2.1.6.7.9.2.2.3.7. i2c[3].RDATA

Table 1997. i2c_wrap.i2c[3].RDATA fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R RMOD	0x0	Reading this register pops the Controller RX FIFO.

2.1.6.7.9.2.2.3.8. i2c[3].FDATA

Table 1998. i2c_wrap.i2c[3].FDATA fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved
12	NAKOK	W	0x0	NACK OK. When set, this controller will not care if this byte is NACKed. It will not halt, set the CONTROLLER_EVENTS.NACK flag, or assert the CONTROLLER_HALT Interrupt. This behavior is useful for protocols like Serial Camera Control Bus (SCCB).
11	RCONT	W	0x0	Read continue/stop: * 0 — Read Stop: The controller NACKs the last data byte. Use this if this is the last READ in a sequence. * 1 — Read Continue: The controller ACKs the last data byte. Use this if this is an intermediate READ in a sequence.
10	READB	W	0x0	Read/write: * 0 - Issue WRITE transaction * 1 - Issue READ transaction
9	STOP	W	0x0	Generate a STOP condition on the bus after sending the byte.
8	START	W	0x0	Generate a START condition on the bus before sending the byte.
7:0	FBYTE	W WMOD	0x0	Writing to this register pushes an entry into the Controller TX FIFO. The meaning of this field depends on the value of the READB field: * READB = 0 - This field is the WRITE data byte. * READB = 1 - This field specifies the number of bytes to read from the target. Setting this field to 0 reads 256 bytes.

2.1.6.7.9.2.2.3.9. i2c[3].FIFO_CTRL

Table 1999. i2c_wrap.i2c[3].FIFO_CTRL fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	TXRST	W 1P	0x0	Target Mode control: writing 1 resets the Target TX FIFO.
7	ACQRST	W 1P	0x0	Target Mode control: writing 1 resets the Target RX FIFO.
6:2	Reserved	-	-	Reserved
1	FMTRST	W 1P	0x0	Controller Mode control: writing 1 resets the Controller TX FIFO.
0	RXRST	W 1P	0x0	Controller Mode control: writing 1 resets the Controller RX FIFO.

2.1.6.7.9.2.2.3.10. i2c[3].HOST_FIFO_CONFIG

Table 2000. i2c_wrap.i2c[3].HOST_FIFO_CONFIG fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	FMT_THRESH	RW	0x0	The FMT_THRESH interrupt remains asserted while the Controller TX FIFO level is less than this setting.
15:12	Reserved	-	-	Reserved
11:0	RX_THRESH	RW	0x0	The RX_THRESH interrupt remains asserted while the Controller RX FIFO level is greater than this setting.

2.1.6.7.9.2.2.3.11. i2c[3].TARGET_FIFO_CONFIG

Table 2001. i2c_wrap.i2c[3].TARGET_FIFO_CONFIG fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	ACQ_THRESH	RW	0x0	The ACQ_THRESH interrupt remains asserted while the Target RX FIFO level is greater than this setting.
15:12	Reserved	-	-	Reserved
11:0	TX_THRESH	RW	0x0	The TX_THRESH interrupt remains asserted while the Target TX FIFO level is less than this setting.

2.1.6.7.9.2.2.3.12. i2c[3].HOST_FIFO_STATUS

Table 2002. i2c_wrap.i2c[3].HOST_FIFO_STATUS fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	RXLVL	R	-	Controller RX FIFO fill level.
15:12	Reserved	-	-	Reserved
11:0	FMTLVL	R	-	Controller TX FIFO fill level.

2.1.6.7.9.2.2.3.13. i2c[3].TARGET_FIFO_STATUS

Table 2003. i2c_wrap.i2c[3].TARGET_FIFO_STATUS fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:16	ACQLVL	R	0x0	Target RX FIFO fill level.
15:12	Reserved	-	-	Reserved
11:0	TXLVL	R	0x0	Target TX FIFO fill level.

2.1.6.7.9.2.2.3.14. i2c[3].OVRD

Table 2004. i2c_wrap.i2c[3].OVRD fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
2	SDAVAL	RW	0x0	Global control: SDA override value: * 0 - Pull the SDA line low * 1 - Release the SDA line
1	SCLVAL	RW	0x0	Global control: SCL override value: * 0 - Pull the SCL line low * 1 - Release the SCL line
0	TXOVRDEN	RW	0x0	Global control: enables control of the SDA and SCL lines through the SDA_VAL and SCL_VAL fields, respectively.

2.1.6.7.9.2.2.3.15. i2c[3].VAL

Table 2005. i2c_wrap.i2c[3].VAL fields

Bits	Field	Access	Reset	Description
31:16	SDA_RX	R	0x0	Global status: contains the last 16 SDA over-sampled values. LSB is most recent.
15:0	SCL_RX	R	0x0	Global status: contains the last 16 SCL over-sampled values. LSB is most recent.

2.1.6.7.9.2.2.3.16. i2c[3].TIMING0

Table 2006. i2c_wrap.i2c[3].TIMING0 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	TLOW	RW	0x0	Global control: specifies the LOW period of SCL (t_LOW) in system clock cycles. Must be 2. See Table 11 in the I2C Specification for more details. This field is sized to meet the I2C Standard-mode (100 kHz) minimum t_LOW = 4.7 µs requirement, assuming a 1 GHz system clock.
15:13	Reserved	-	-	Reserved
12:0	THIGH	RW	0x0	Global control: specifies the HIGH period of SCL (t_HIGH) in system clock cycles. Must be 2. See Table 11 in the I²C Specification for details. This field is sized to meet the I2C Standard-mode (100 kHz)'s minimum t_HIGH = 4.0 µs requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.3.17. i2c[3].TIMING1

Table 2007. i2c_wrap.i2c[3].TIMING1 fields

Bits	Field	Access	Reset	Description
31:25	Reserved	-	-	Reserved
24:16	T_F	RW	0x0	Global control: specifies the fall time of SDA and SCL (t_f) in system clock cycles. The fall time is measured from 70% to 30% of the signal swing. See Table 11 in the I2C Specification for more details. This field is sized to meet I2C Standard-mode (100 kHz)'s maximum t_f = 300 ns requirement, assuming a 1 GHz system clock.
15:10	Reserved	-	-	Reserved
9:0	T_R	RW	0x0	Global control: specifies the rise time of SDA and SCL (t_r) in system clock cycles. The rise time is measured from 30% to 70% of the signal swing. See Table 11 in the I2C Specification for more details. This field is sized to meet I2C Standard-mode (100 kHz)'s maximum t_r = 1000 ns requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.3.18. i2c[3].TIMING2

Table 2008. i2c_wrap.i2c[3].TIMING2 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	THD_STA	RW	0x0	Global control: specifies the setup time for a (repeated) START condition (t_HD;STA) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet I2C Standard-mode (100 kHz)'s minimum t_HD;STA = 4.0 µs requirement, assuming a 1 GHz system clock.
15:13	Reserved	-	-	Reserved
12:0	TSU_STA	RW	0x0	Global control: specifies the setup time for a repeated START condition (t_SU;STA) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet I2C Standard-mode (100 kHz)'s minimum t_SU;STA = 4.7 µs requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.3.19. i2c[3].TIMING3

Table 2009. i2c_wrap.i2c[3].TIMING3 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	THD_DAT	RW	0x0	Global control: specifies the data and (N)ACK bits hold time (t_HD;DAT) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet the I2C Standard-mode (100 kHz)'s t_HD;DAT = 5.0 µs minimum requirement, assuming a 1 GHz system clock.
15:9	Reserved	-	-	Reserved
8:0	TSU_DAT	RW	0x0	Global control: specifies the data setup time (t_SU;DAT) in system clock cycles. See Table 11 in the I2C Specification for details. This field is sized to meet the I2C Standard-mode (100 kHz)'s t_SU;DAT = 250 ns minimum requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.3.20. i2c[3].TIMING4

Table 2010. i2c_wrap.i2c[3].TIMING4 fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:16	T_BUF	RW	0x0	Global control: specifies the time between a STOP and START condition (t_BUF) in system clock cycles. See Table 11 in the I²C Specification for details. This field is sized to meet I2C Standard-mode (100kHz)'s t_BUF = 4.7 µs minimum requirement, assuming a 1 GHz system clock.
15:13	Reserved	-	-	Reserved
12:0	TSU_STO	RW	0x0	Global control: specifies the setup time for a STOP condition (t_SU;STO) in system clock cycles. See Table 11 in the I²C Specification for details. This field is sized to meet I2C Standard-mode (100 kHz)'s t_SU;STO = 4.0 µs minimum requirement, assuming a 1 GHz system clock.

2.1.6.7.9.2.2.3.21. i2c[3].TIMEOUT_CTRL

Table 2011. i2c_wrap.i2c[3].TIMEOUT_CTRL fields

Bits	Field	Access	Reset	Description
31	EN	RW	0x0	Timeout Enable.

Bits	Field	Access	Reset	Description
30	MODE	RW	0x0	Global control: timeout mode. * 0 - Stretch Timeout (Controller Mode only). If the target stretches the clock for more time than TIMEOUT_CTRL.VAL, the STRETCH_TIMEOUT interrupt will be asserted. * 1 - Bus Timeout. If SCL is LOW for more time than TIMEOUT_CTRL.VAL: * In Controller Mode, the CONTROLLER_EVENTS.BUS_TIMEOUT flag will be asserted, triggering the CONTROLLER_HALT interrupt. * In Target Mode, the TARGET_EVENTS.BUS_TIMEOUT flag will be set, triggering the TX_STRETCH interrupt.
29:0	VAL	RW	0x0	Global control: Specifies the timeout value in system clock cycles. The meaning of this field depends on MODE.

2.1.6.7.9.2.2.3.22. i2c[3].TARGET_ID

Table 2012. i2c_wrap.i2c[3].TARGET_ID fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:21	MASK1	RW	0x0	ADDRESS1 mask.
20:14	ADDRESS1	RW	0x0	Target Address 1. This target responds if the 7-bit address matches ADDRESS1 & MASK1. MASK1 = 0x0 disables this address.
13:7	MASK0	RW	0x0	ADDRESS0 mask.
6:0	ADDRESS0	RW	0x0	Target Address 0. This target responds if the 7-bit address matches ADDRESS0 & MASK0. MASK0 = 0x0 disables this address.

2.1.6.7.9.2.2.3.23. i2c[3].ACQDATA

Table 2013. i2c_wrap.i2c[3].ACQDATA fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved
10:8	SIGNAL	R	0x0	This field indicates if this FIFO entry represents/is associated with control signal(s): * 0x0 - The entry is an ordinary data byte that has been ACKed. * 0x1 - The entry is an address byte preceded by a START. * 0x2 - The entry is a STOP condition following ACKed data bytes. * 0x3 - The entry is an address byte preceded by a repeated START. * 0x4 - The entry is a NACKed data byte. * 0x5 - The entry is an address byte preceded by a (repeated) START. However, the data bytes that followed this address byte were NACKed. * 0x6 - Error. A transaction preceding ended abnormally, for example, due to an unexpected STOP condition, a Bus or Stretch Timeout, a software NACK, or a lost arbitration. If the FIFO does not have enough space to record a complete transaction, an Error (0x6) entry may appear alone.
7:0	ABYTE	R RMOD	0x0	Reading this register pops the ACQ FIFO. The meaning of this field depends on SIGNAL: * SIGNAL = 0x0, 0x1, 0x3, 0x4, or 0x5 - This field contains an address or data byte sent by the controller. * SIGNAL = 0x2, 0x6 - This field is meaningless.

2.1.6.7.9.2.2.3.24. i2c[3].TXDATA

Table 2014. i2c_wrap.i2c[3].TXDATA fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	W WMOD	0x0	Writing to this register pushes data into the Target TX FIFO. The controller reads data from this FIFO during a READ transaction.

2.1.6.7.9.2.2.3.25. i2c[3].HOST_TIMEOUT_CTRL

Table 2015. i2c_wrap.i2c[3].HOST_TIMEOUT_CTRL fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30:0	VAL	RW	0x0	Target/Monitor Mode control: controller clock generation timeout value specified in system clock cycles. * Target Mode - If the controller stops generating the clock for more time than this setting, this target asserts the Controller Timeout Interrupt. * Monitor Mode - this field is required to be nonzero for the Bus Monitor to transition out of the initial Busy state. Set this field to `0x0` to disable this behavior.

2.1.6.7.9.2.2.3.26. i2c[3].TARGET_TIMEOUT_CTRL

Table 2016. i2c_wrap.i2c[3].TARGET_TIMEOUT_CTRL fields

Bits	Field	Access	Reset	Description
31	EN	RW	0x0	Enable Target Timeout.
30:0	VAL	RW	0x0	When this target has stretched the clock for more time than this setting, this target will NACK incoming data bytes or release the SDA line for outgoing data bytes. The count is cumulative over an entire transaction. In other words, this is SMBus's cumulative target clock extension time. The behavior for the address byte is configurable via `CTRL.NACK_ADDR_AFTER_TIMEOUT`.

2.1.6.7.9.2.2.3.27. i2c[3].TARGET_NACK_COUNT

Table 2017. i2c_wrap.i2c[3].TARGET_NACK_COUNT fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	TARGET_NACK_COUNT	RW RC	0x0	Indicates the number of transactions NACKed by this target since the last read of this register, saturating at 255. This field can be used to track how many transactions were missed when the Target RX FIFO is full.

2.1.6.7.9.2.2.3.28. i2c[3].TARGET_ACK_CTRL

Table 2018. i2c_wrap.i2c[3].TARGET_ACK_CTRL fields

Bits	Field	Access	Reset	Description
31	NACK	W 1P	0x0	When `STATUS.ACK_CTRL_STRETCH = 1`, writing `1` to this field causes this target to NACK all bytes of the transaction. Effective only when `CTRL.ACK_CTRL_EN = 1`.
30:9	Reserved	-	-	Reserved
8:0	NBYTES	RW	0x0	When `STATUS.ACK_CTRL_STRETCH = 1`, writing to this register specifies the number of bytes this target should ACK. The count decrements per byte ACKed. Effective only when `CTRL.ACK_CTRL_EN = 1`. See `CTRL.ACK_CTRL_EN` for details. This control field is used to implement SMBus's mid-transfer (N)ACK responses.

2.1.6.7.9.2.2.3.29. i2c[3].ACQ_FIFO_NEXT_DATA

Table 2019. i2c_wrap.i2c[3].ACQ_FIFO_NEXT_DATA fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R	0x0	This field contains the next byte to be pushed into the Target RX FIFO, allowing software to decide whether to accept or reject it. Valid only when STATUS.ACK_CTRL_STRETCH = 1. See CTRL.ACK_CTRL_EN for details.

2.1.6.7.9.2.2.3.30. i2c[3].HOST_NACK_HANDLER_TIMEOUT

Table 2020. i2c_wrap.i2c[3].HOST_NACK_HANDLER_TIMEOUT fields

Bits	Field	Access	Reset	Description
31	EN	RW	0x0	Enables Controller NACK Timeout.
30:0	VAL	RW	0x0	Timeout value (specified in system clock cycles) for this controller Mode to automatically STOP a transaction when CONTROLLER_EVENTS.NACK is set.

2.1.6.7.9.2.2.3.31. i2c[3].CONTROLLER_EVENTS

Table 2021. i2c_wrap.i2c[3].CONTROLLER_EVENTS fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	ARBITRATION_LOST	RW1C	0x0	Indicates that the controller has halted due to it losing an arbitration against another controller. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.
2	BUS_TIMEOUT	RW1C	0x0	Indicates that this controller has halted due to a Bus Timeout. See TIMEOUT_CTRL for details. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.
1	UNHANDLED_NACK_TIMEOUT	RW1C	0x0	Indicates that this controller has halted due to a Controller NACK Timeout. See HOST_NACK_HANDLER_TIMEOUT for details. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.
0	NACK	RW1C	0x0	Indicates that this controller has halted due to an unexpected NACK sent by the target. This behavior can be disabled by writing 1 to FDATA.NAKOK. This bit triggers the CONTROLLER_HALT interrupt. Writing 1 clears this bit.

2.1.6.7.9.2.2.3.32. i2c[3].TARGET_EVENTS

Table 2022. i2c_wrap.i2c[3].TARGET_EVENTS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	STOP_DETECT	RW1C	0x0	Stop Detect Flag (Target Mode only). Set to 1 by hardware when a STOP is detected while CTRL.ENABLETARGET = 1. Cleared when software writes 1.
3	START_DETECT	RW1C	0x0	Start Detect Flag (Target Mode only). Set to 1 by hardware when a START (or repeated START) is detected while CTRL.ENABLETARGET = 1. Cleared when software writes 1.
2	ARBITRATION_LOST	RW1C	0x0	Indicates that a controller has lost arbitration, causing a READ transaction to end. This bit triggers the TX_STRETCH interrupt. Writing 1 clears this bit.
1	BUS_TIMEOUT	RW1C	0x0	Indicates that this target has halted due a Bus Timeout terminating a READ transaction. See TIMEOUT_CTRL for details. This bit triggers the TX_STRETCH interrupt. Writing 1 clears this bit.

Bits	Field	Access	Reset	Description
0	TX_PENDING	RW1C	0x0	Indicates that the target is stretching the clock due to receiving a READ address byte and waiting for software to confirm the release of the Target TX FIFO data. Valid only if CTRL.TX_STRETCH_CTRL_EN = 1. See CTRL.TX_STRETCH_CTRL_EN for details. This bit triggers the TX_STRETCH interrupt. Writing 1 clears this bit.

2.1.6.7.9.2.2.3.33. i2c[3].SMBUS_STATUS

Table 2023. i2c_wrap.i2c[3].SMBUS_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	SMBALERT	R	0x0	Controller Mode status: indicates that the smbalert_ni input is asserted.
3:1	Reserved	-	-	Reserved
0	SMBSUS	R	0x0	Target Mode status: indicates that the smbsus_ni input is asserted.

2.1.6.7.9.2.2.3.34. I2C_CTRL[3]

Table 2024. i2c_wrap.I2C_CTRL[3] fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	SMBUS_EN	RW	0x0	SMBus Enable. Gates the SMBus Alert signal.
7:5	Reserved	-	-	Reserved
4	I2C_CONTROLLER_MODE_EN	RW	0x0	SMBus Pad Direction. When set, the SMBus alert pad is an input and the SMBus suspend pad is an output, as for an SMBus host. When clear, the alert pad is an output and the suspend pad is an input, as for an SMBus target. SCL and SDA are unaffected. Program it to agree with the core's CTRL.ENABLEHOST and CTRL.ENABLETARGET setting.
3:1	Reserved	-	-	Reserved
0	I2C_EN	RW	0x0	I2C Pad Function Select. When set, the integration routes this instance's SCL, SDA, SMBus alert and SMBus suspend signals to their pads. Does not enable the I2C core; CTRL.ENABLEHOST and CTRL.ENABLETARGET select the core's operating mode.

2.1.6.7.10. I3C Controller

The I3C controller is based on the CHIPS Alliance i3c-core. Controller and target behavior, the HCI queues, common command codes, and the bus protocol are specified by that design.




Figure 70. CHIPS Alliance i3c-core reference architecture

Figure 70 shows the upstream core.

2.1.6.7.10.1. OCAH Modifications

When target mode is used, budget four core-clock cycles for the internal SCL-to-SDA response. A 12 ns turnaround limit requires approximately 333.3 MHz or faster before pad and routing allowance; see the Peripheral Timing Requirements section and the upstream PHY timing requirements. Controller-mode timing examples at lower frequencies do not demonstrate compliance with this target-mode limit.

SMC instantiates six controllers. `i3ccore_wrapper` exposes one AXI4-Lite slave and selects the instance from the address. Instances are spaced by `0x1000`, and each instance is presented with a 12-bit offset inside that window.

`i3c_wrapper` drives the core's AXI4 register port as a single beat: `awlen` and `arlen` are 0 and `wlast` is 1. The core's controller-mode SCL and SDA outputs are bus levels. The wrapper turns those into open-drain pad enables: SCL is driven only low, and SDA is driven in both directions while push-pull mode is selected.

Each instance brings out its device-address, device-characteristic, and reverse-lookup memories, one interrupt, and the recovery pins.




Figure 71. OCAH I3C wrapper

Figure 71 shows that wrapper around the CHIPS Alliance core, which it draws as a black box. Parentheses after an instance name give its module or, for a block taken from another project, that project; the demux is a PULP `axi_lite_demux`. `i3ccore_wrapper` runs on one clock, `clk_i`; in the SMC that is the gated peripheral clock, and its AXI4-Lite port, with 32-bit address and data, arrives through `smc_peripherals_cdc`. The demux `u_axil_demux` registers every channel and allows eight outstanding transactions. It has no error slave: an address outside every instance window reaches instance 0. Each generate block subtracts its index times `0x1000` from the address before `i3c_wrapper` sees it.

Inside `i3c_wrapper`, the converter tie-offs are `awlen`/`arlen` 0, `wlast` 1, and zero ID and user. The gates below the core are the pad-enable logic: `scl_o` is tied low and `scl_oe_o` is the inverse of the core's SCL level, so the pad only pulls SCL low; `sda_o` is the core's SDA level and `sda_oe_o` is `sel_od_pp_o` OR the inverse of `sda_o`. The core's own SDA output enable, which it drives only in target mode, is not used.

`irq_o`, the five recovery signals and the DAT, DCT and reverse-lookup memory ports pass straight through to per-instance vectors on the `i3ccore_wrapper` boundary. In the SMC `recovery_payload_available_o`, `recovery_image_activated_o`, `peripheral_reset_o` and `escalated_reset_o` are left unconnected, `peripheral_reset_done_i` is tied low, and the interrupts reach peripheral interrupts 12 to 17.

The register map below reproduces the upstream SystemRDL descriptions; those under `I3C_EC` are upstream's own rather than MIPI I3C HCI text. The fields below differ from or go beyond those descriptions.

These read back the value written but reach no logic:

- `PIOControl.PIO_CONTROL.ENABLE`: the PIO queues are always enabled.

- I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL.TARGET_XACT_ENABLE: target transactions cannot be disabled.
- I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL.RSTACT_DEFBYTE_02: RSTACT with defining byte 0x02 is always ACKed.
- I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS.RESET_TIME_PERIPHERAL and RESET_TIME_TARGET: GET RSTACT with defining byte 0x81 or 0x82 returns 0xFF.
- I3C_EC.SoCMgmtIf.REC_INTF_CFG.REC_INTF_BYPASS: DISABLE_LOOPBACK ties the bypass off, so recovery always goes through the I3C core.

These misreport the core:

- I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES.DAA_ENTDAA_SUPPORT reads 0, but ENTDAA is supported.
- I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL.STBY_CR_ENABLE_INIT mode 2'b11 behaves as 2'b01 (active controller), not Hot-Join-then-standby.

These behave as follows, which the descriptions leave unstated:

- I3C_EC.TTI.TARGET_ERR_CNT_TE3 counts parity errors on the ENTDAA-assigned dynamic address; TARGET_ERR_CNT_TE4 counts reserved bytes other than 7'h7E with R/W=1.
- I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW and TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW: the enable in TARGET_ERR_CTRL gates detection, so an overflow while it is clear is neither counted nor interrupts.
- PIOControl.DATA_BUFFER_THLD_CTRL: RX_START_THLD and TX_BUF_THLD test free space, TX_START_THLD and RX_BUF_THLD stored entries; each encodes 2^(N+1) entries.
- PIOControl.QUEUE_THLD_CTRL: raw entry counts, free for CMD_EMPTY_BUF_THLD and stored for RESP_BUF_THLD and IBI_STATUS_THLD. Only these ready thresholds are implemented; start thresholds are unconnected.
- DCT.DCT_MEMORY: PID_LO holds the first two (most significant) ENTDAA PID bytes and PID_HI the next four. DYNAMIC_ADDRESS holds the address in bits 7:1 and its odd parity in bit 0.

Consult the i3c-core documentation for the controller. The register map of this wrapper follows.

2.1.6.7.10.2. Memory Map and Register Reference

2.1.6.7.10.2.1. Memory Map

2.1.6.7.10.2.1.1. Integration Limits

The SoC Management Interface header at 0x300 reports CAP_LENGTH = 0x1A DWORDs. This is inconsistent with the next capability header at 0x398: the span is 0x98 bytes, or 0x26 DWORDs. A generic walker that trusts the reported length advances to 0x368, inside the timing registers, and misinterprets data as a capability header. Software for this implementation must use the offsets in this paragraph rather than discovering that boundary from CAP_LENGTH.

The DAT and DCT capability fields advertise TABLE_SIZE = 127, but only 16 independent entries are implemented. Index decoding retains four bits, so higher window slots alias lower entries rather than providing extra storage. For example, DAT slot 16 at 0x480 aliases slot 0 at 0x400; DCT slot 16 at 0x900 aliases slot 0 at 0x800. Limit accesses to indexes 0–15. The complete windows in the generated map describe address decoding, not independent 128-entry capacity.

2.1.6.7.10.2.2. Detailed Register Map

2.1.6.7.10.2.2.1. OCA I3C Controller Wrapper Address Map

Wrapper address map instantiating the per-controller I3C CSR blocks.

NOTE

Register Arrays:

- **i3c_csr[6].I3CBase.HCI_VERSION**: 6 registers, base 0x0, stride 0x1000
- **i3c_csr[6].I3CBase.HC_CONTROL**: 6 registers, base 0x4, stride 0x1000
- **i3c_csr[6].I3CBase.CONTROLLER_DEVICE_ADDR**: 6 registers, base 0x8, stride 0x1000
- **i3c_csr[6].I3CBase.HC_CAPABILITIES**: 6 registers, base 0xC, stride 0x1000
- **i3c_csr[6].I3CBase.RESET_CONTROL**: 6 registers, base 0x10, stride 0x1000
- **i3c_csr[6].I3CBase.PRESENT_STATE**: 6 registers, base 0x14, stride 0x1000
- **i3c_csr[6].I3CBase.INTR_STATUS**: 6 registers, base 0x20, stride 0x1000
- **i3c_csr[6].I3CBase.INTR_STATUS_ENABLE**: 6 registers, base 0x24, stride 0x1000
- **i3c_csr[6].I3CBase.INTR_SIGNAL_ENABLE**: 6 registers, base 0x28, stride 0x1000
- **i3c_csr[6].I3CBase.INTR_FORCE**: 6 registers, base 0x2C, stride 0x1000
- **i3c_csr[6].I3CBase.DAT_SECTION_OFFSET**: 6 registers, base 0x30, stride 0x1000
- **i3c_csr[6].I3CBase.DCT_SECTION_OFFSET**: 6 registers, base 0x34, stride 0x1000
- **i3c_csr[6].I3CBase.RING_HEADERS_SECTION_OFFSET**: 6 registers, base 0x38, stride 0x1000
- **i3c_csr[6].I3CBase.PIO_SECTION_OFFSET**: 6 registers, base 0x3C, stride 0x1000
- **i3c_csr[6].I3CBase.EXT_CAPS_SECTION_OFFSET**: 6 registers, base 0x40, stride 0x1000
- **i3c_csr[6].I3CBase.INT_CTRL_CMDS_EN**: 6 registers, base 0x4C, stride 0x1000
- **i3c_csr[6].I3CBase.IBI_NOTIFY_CTRL**: 6 registers, base 0x58, stride 0x1000
- **i3c_csr[6].I3CBase.IBI_DATA_ABORT_CTRL**: 6 registers, base 0x5C, stride 0x1000
- **i3c_csr[6].I3CBase.DEV_CTX_BASE_LO**: 6 registers, base 0x60, stride 0x1000
- **i3c_csr[6].I3CBase.DEV_CTX_BASE_HI**: 6 registers, base 0x64, stride 0x1000
- **i3c_csr[6].I3CBase.DEV_CTX_SG**: 6 registers, base 0x68, stride 0x1000
- **i3c_csr[6].PIOControl.COMMAND_PORT**: 6 registers, base 0x80, stride 0x1000
- **i3c_csr[6].PIOControl.RESPONSE_PORT**: 6 registers, base 0x84, stride 0x1000
- **i3c_csr[6].PIOControl.TX_DATA_PORT**: 6 registers, base 0x88, stride 0x1000
- **i3c_csr[6].PIOControl.RX_DATA_PORT**: 6 registers, base 0x88, stride 0x1000
- **i3c_csr[6].PIOControl.IBI_PORT**: 6 registers, base 0x8C, stride 0x1000
- **i3c_csr[6].PIOControl.QUEUE_THLD_CTRL**: 6 registers, base 0x90, stride 0x1000
- **i3c_csr[6].PIOControl.DATA_BUFFER_THLD_CTRL**: 6 registers, base 0x94, stride 0x1000
- **i3c_csr[6].PIOControl.QUEUE_SIZE**: 6 registers, base 0x98, stride 0x1000
- **i3c_csr[6].PIOControl.ALT_QUEUE_SIZE**: 6 registers, base 0x9C, stride 0x1000
- **i3c_csr[6].PIOControl.PIO_INTR_STATUS**: 6 registers, base 0xA0, stride 0x1000
- **i3c_csr[6].PIOControl.PIO_INTR_STATUS_ENABLE**: 6 registers, base 0xA4, stride 0x1000
- **i3c_csr[6].PIOControl.PIO_INTR_SIGNAL_ENABLE**: 6 registers, base 0xA8, stride 0x1000
- **i3c_csr[6].PIOControl.PIO_INTR_FORCE**: 6 registers, base 0xAC, stride 0x1000
- **i3c_csr[6].PIOControl.PIO_CONTROL**: 6 registers, base 0xB0, stride 0x1000

- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.EXTCAP_HEADER**: 6 registers, base 0x100, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_0**: 6 registers, base 0x104, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_1**: 6 registers, base 0x108, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_2**: 6 registers, base 0x10C, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_3**: 6 registers, base 0x110, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_0**: 6 registers, base 0x114, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_1**: 6 registers, base 0x118, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_2**: 6 registers, base 0x11C, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_3**: 6 registers, base 0x120, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_4**: 6 registers, base 0x124, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_5**: 6 registers, base 0x128, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_RESERVED**: 6 registers, base 0x12C, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_0**: 6 registers, base 0x130, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_1**: 6 registers, base 0x134, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_RESET**: 6 registers, base 0x138, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_CTRL**: 6 registers, base 0x13C, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_STATUS**: 6 registers, base 0x140, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.HW_STATUS**: 6 registers, base 0x144, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_0**: 6 registers, base 0x148, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_1**: 6 registers, base 0x14C, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_0**: 6 registers, base 0x150, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_1**: 6 registers, base 0x154, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_2**: 6 registers, base 0x158, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_3**: 6 registers, base 0x15C, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_4**: 6 registers, base 0x160, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_RESERVED**: 6 registers, base 0x164, stride 0x1000
- **i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_DATA**: 6 registers, base 0x168, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.EXTCAP_HEADER**: 6 registers, base 0x180, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL**: 6 registers, base 0x184, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_ADDR**: 6 registers, base 0x188, stride 0x1000

- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES**: 6 registers, base 0x18C, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_CHAR**: 6 registers, base 0x190, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_STATUS**: 6 registers, base 0x194, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_CHAR**: 6 registers, base 0x198, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_PID_LO**: 6 registers, base 0x19C, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_STATUS**: 6 registers, base 0x1A0, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_PID_LO**: 6 registers, base 0x1A4, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_SIGNAL_ENABLE**: 6 registers, base 0x1A8, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_FORCE**: 6 registers, base 0x1AC, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_GETCAPS**: 6 registers, base 0x1B0, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS**: 6 registers, base 0x1B4, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRT_DEVICE_ADDR**: 6 registers, base 0x1B8, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MWL**: 6 registers, base 0x1BC, stride 0x1000
- **i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MRL**: 6 registers, base 0x1C0, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.EXTCAP_HEADER**: 6 registers, base 0x200, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.CONTROL**: 6 registers, base 0x204, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.STATUS**: 6 registers, base 0x208, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.RESET_CONTROL**: 6 registers, base 0x20C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.QUEUE_STATUS**: 6 registers, base 0x210, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.DESC_QUEUE_DEPTH**: 6 registers, base 0x214, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.DATA_QUEUE_DEPTH**: 6 registers, base 0x218, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_DEPTH**: 6 registers, base 0x21C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.INTERRUPT_STATUS**: 6 registers, base 0x220, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.INTERRUPT_ENABLE**: 6 registers, base 0x224, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.INTERRUPT_FORCE**: 6 registers, base 0x228, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CTRL**: 6 registers, base 0x22C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_STATUS**: 6 registers, base 0x230, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_ENABLE**: 6 registers, base 0x234, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_FORCE**: 6 registers, base 0x238, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE0**: 6 registers, base 0x23C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE1**: 6 registers, base 0x240, stride 0x1000

- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE2**: 6 registers, base 0x244, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE3**: 6 registers, base 0x248, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE4**: 6 registers, base 0x24C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE5**: 6 registers, base 0x250, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_FRAMING**: 6 registers, base 0x254, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_PEC**: 6 registers, base 0x258, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_LENGTH**: 6 registers, base 0x25C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_READONLY**: 6 registers, base 0x260, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_UNSUPPORTED**: 6 registers, base 0x264, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW**: 6 registers, base 0x268, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW**: 6 registers, base 0x26C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.RX_DESC_QUEUE_PORT**: 6 registers, base 0x270, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.RX_DATA_PORT**: 6 registers, base 0x274, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TX_DESC_QUEUE_PORT**: 6 registers, base 0x278, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.TX_DATA_PORT**: 6 registers, base 0x27C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.IBI_PORT**: 6 registers, base 0x280, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.QUEUE_SIZE**: 6 registers, base 0x284, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_SIZE**: 6 registers, base 0x288, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.QUEUE_THLD_CTRL**: 6 registers, base 0x28C, stride 0x1000
- **i3c_csr[6].I3C_EC.TTI.DATA_BUFFER_THLD_CTRL**: 6 registers, base 0x290, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.EXTCAP_HEADER**: 6 registers, base 0x300, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_CONTROL**: 6 registers, base 0x304, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_STATUS**: 6 registers, base 0x308, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_CFG**: 6 registers, base 0x30C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_REG_W1C_ACCESS**: 6 registers, base 0x310, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_2**: 6 registers, base 0x314, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_3**: 6 registers, base 0x318, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_CONF**: 6 registers, base 0x31C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_ATTR**: 6 registers, base 0x320, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_2**: 6 registers, base 0x324, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_3**: 6 registers, base 0x328, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_R_REG**: 6 registers, base 0x32C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_F_REG**: 6 registers, base 0x330, stride 0x1000

- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_REG**: 6 registers, base 0x334, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_I2C_REG**: 6 registers, base 0x338, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_DAT_REG**: 6 registers, base 0x33C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_REG**: 6 registers, base 0x340, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_OD_REG**: 6 registers, base 0x344, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_INIT_OD_REG**: 6 registers, base 0x348, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_I2C_REG**: 6 registers, base 0x34C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_REG**: 6 registers, base 0x350, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_OD_REG**: 6 registers, base 0x354, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_I2C_REG**: 6 registers, base 0x358, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_REG**: 6 registers, base 0x35C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_I2C_REG**: 6 registers, base 0x360, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_RSTA_REG**: 6 registers, base 0x364, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_REG**: 6 registers, base 0x368, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_I2C_REG**: 6 registers, base 0x36C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_REG**: 6 registers, base 0x370, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_I2C_REG**: 6 registers, base 0x374, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_DS_OD_REG**: 6 registers, base 0x378, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_REG**: 6 registers, base 0x37C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_I2C_REG**: 6 registers, base 0x380, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_AVAL_REG**: 6 registers, base 0x384, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_IDLE_REG**: 6 registers, base 0x388, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.HDR_TIMEOUT_EN_REG**: 6 registers, base 0x38C, stride 0x1000
- **i3c_csr[6].I3C_EC.SoCMgmtIf.T_HDR_TIMEOUT_REG**: 6 registers, base 0x390, stride 0x1000
- **i3c_csr[6].I3C_EC.CtrlCfg.EXTCAP_HEADER**: 6 registers, base 0x398, stride 0x1000
- **i3c_csr[6].I3C_EC.CtrlCfg.CONTROLLER_CONFIG**: 6 registers, base 0x39C, stride 0x1000
- **i3c_csr[6].I3C_EC.TERMINATION_EXTCAP_HEADER**: 6 registers, base 0x3A0, stride 0x1000
- **i3c_csr[6].DAT.DAT_MEMORY[128]**: 768 registers, base 0x400 (i3c_csr x6 stride 0x1000, DAT_MEMORY x128 stride 0x8)
- **i3c_csr[6].DCT.DCT_MEMORY[128]**: 768 registers, base 0x800 (i3c_csr x6 stride 0x1000, DCT_MEMORY x128 stride 0x10)

Table 2025. OCA I3C Controller Wrapper Address Map register list

Address	Name	Access	Description
0x0 - 0x5000	i3c_csr[6].I3CBase.HCI_VERSION	R	Identifies the implemented MIPI I3C HCI version.
0x4 - 0x5004	i3c_csr[6].I3CBase.HC_CONTROL	RW	Controls host-controller bus operation, mode selection, transaction abort, and Hot-Join handling.

Address	Name	Access	Description
0x8 - 0x5008	i3c_csr[6].I3CBase.CONTROLLER_DEVICE_ADDR	RW	Configures the controller dynamic address and indicates whether that address is valid.
0xC - 0x500C	i3c_csr[6].I3CBase.HC_CAPABILITIES	R	Reports the host-controller capabilities implemented by this instance.
0x10 - 0x5010	i3c_csr[6].I3CBase.RESET_CONTROL	RW	Requests a controller soft reset or selective PIO queue and FIFO resets. Reset requests are self-clearing.
0x14 - 0x5014	i3c_csr[6].I3CBase.PRESENT_STATE	R	Reports current controller state, including active-controller bus ownership.
0x20 - 0x5020	i3c_csr[6].I3CBase.INTR_STATUS	RW	Reports host-controller error and exceptional-condition status.
0x24 - 0x5024	i3c_csr[6].I3CBase.INTR_STATUS_ENABLE	RW	Enables individual host-controller interrupt status sources.
0x28 - 0x5028	i3c_csr[6].I3CBase.INTR_SIGNAL_ENABLE	RW	Routes enabled host-controller interrupt sources to the interrupt output.
0x2C - 0x502C	i3c_csr[6].I3CBase.INTR_FORCE	W	Forces host-controller interrupts for software testing.
0x30 - 0x5030	i3c_csr[6].I3CBase.DAT_SECTION_OFFSET	R	Reports the Device Address Table section offset and size.
0x34 - 0x5034	i3c_csr[6].I3CBase.DCT_SECTION_OFFSET	RW	Configures the Device Characteristic Table section offset, size, and ENTDAA index.
0x38 - 0x5038	i3c_csr[6].I3CBase.RING_HEADERS_SECTION_OFFSET	R	-
0x3C - 0x503C	i3c_csr[6].I3CBase.PIO_SECTION_OFFSET	R	Reports the PIO section offset.
0x40 - 0x5040	i3c_csr[6].I3CBase.EXT_CAPS_SECTION_OFFSET	R	-
0x4C - 0x504C	i3c_csr[6].I3CBase.INT_CTRL_CMDS_EN	R	-
0x58 - 0x5058	i3c_csr[6].I3CBase.IBI_NOTIFY_CTRL	RW	-
0x5C - 0x505C	i3c_csr[6].I3CBase.IBI_DATA_ABORT_CTRL	RW	-
0x60 - 0x5060	i3c_csr[6].I3CBase.DEV_CTX_BASE_LO	RW	-
0x64 - 0x5064	i3c_csr[6].I3CBase.DEV_CTX_BASE_HI	RW	-
0x68 - 0x5068	i3c_csr[6].I3CBase.DEV_CTX_SG	R	-
0x80 - 0x5080	i3c_csr[6].PIOControl.COMMAND_PORT	W	Accepts a 64-bit command descriptor as two consecutive 32-bit writes. The second write enqueues the descriptor.
0x84 - 0x5084	i3c_csr[6].PIOControl.RESPONSE_PORT	R	Returns one 32-bit response descriptor from the response queue.
0x88 - 0x5088	i3c_csr[6].PIOControl.TX_DATA_PORT	W	Writes transmit data to the TX FIFO. This port shares its address with the read-only RX data port.
0x88 - 0x5088	i3c_csr[6].PIOControl.RX_DATA_PORT	R	Reads received data from the RX FIFO. This port shares its address with the write-only TX data port.
0x8C - 0x508C	i3c_csr[6].PIOControl.IBI_PORT	R	Returns IBI status and payload data. Payload data is padded to a 4-byte boundary.
0x90 - 0x5090	i3c_csr[6].PIOControl.QUEUE_THLD_CTRL	RW	Configures command, response, and IBI queue thresholds as raw entry counts.

Address	Name	Access	Description
0x94 - 0x5094	i3c_csr[6].PIOControl.DATA_BUFFER_THLD_CTRL	RW	Configures TX and RX start and ready thresholds, each encoding 2^(N+1) entries.
0x98 - 0x5098	i3c_csr[6].PIOControl.QUEUE_SIZE	R	Reports command, response, IBI, TX, and RX queue depths.
0x9C - 0x509C	i3c_csr[6].PIOControl.ALT_QUEUE_SIZE	R	Reports extended IBI and alternate response queue sizes.
0xA0 - 0x50A0	i3c_csr[6].PIOControl.PIO_INTR_STATUS	RW	Reports PIO queue-threshold and transfer-event interrupt status.
0xA4 - 0x50A4	i3c_csr[6].PIOControl.PIO_INTR_STATUS_ENABLE	RW	Enables individual PIO interrupt status sources.
0xA8 - 0x50A8	i3c_csr[6].PIOControl.PIO_INTR_SIGNAL_ENABLE	RW	Routes enabled PIO interrupt sources to the interrupt output.
0xAC - 0x50AC	i3c_csr[6].PIOControl.PIO_INTR_FORCE	W	-
0xB0 - 0x50B0	i3c_csr[6].PIOControl.PIO_CONTROL	RW	Controls run/stop and forced abort of enqueued commands.
0x100 - 0x5100	i3c_csr[6].I3C_EC.SecFwRecoveryIf.EXTCAP_HEADER	R	-
0x104 - 0x5104	i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_0	R	-
0x108 - 0x5108	i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_1	R	-
0x10C - 0x510C	i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_2	RW	-
0x110 - 0x5110	i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_3	RW	-
0x114 - 0x5114	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_0	RW	-
0x118 - 0x5118	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_1	RW	-
0x11C - 0x511C	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_2	RW	-
0x120 - 0x5120	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_3	RW	-
0x124 - 0x5124	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_4	RW	-
0x128 - 0x5128	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_5	RW	-
0x12C - 0x512C	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_RESERVED	R	-
0x130 - 0x5130	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_0	RW	-
0x134 - 0x5134	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_1	RW	-
0x138 - 0x5138	i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_RESET	RW	For devices which support reset, this register will reset the device or management entity
0x13C - 0x513C	i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_CTRL	RW	-
0x140 - 0x5140	i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_STATUS	RW	-

Address	Name	Access	Description
0x144 - 0x5144	i3c_csr[6].I3C_EC.SecFwRecoveryIf.HW_STATUS	RW	-
0x148 - 0x5148	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_0	RW	-
0x14C - 0x514C	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_1	RW	-
0x150 - 0x5150	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_0	R	-
0x154 - 0x5154	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_1	R	-
0x158 - 0x5158	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_2	R	-
0x15C - 0x515C	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_3	R	-
0x160 - 0x5160	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_4	R	-
0x164 - 0x5164	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_RESERVED	R	-
0x168 - 0x5168	i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_DATA	R	Indirect memory access to address space configured in INDIRECT_FIFO_CTRL at the Head Pointer offset.
0x180 - 0x5180	i3c_csr[6].I3C_EC.StdbyCtrlMode.EXTCAP_HEADER	R	-
0x184 - 0x5184	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL	RW	Configures standby-controller operation, dynamic-address-assignment methods, target transactions, and controller-role handoff.
0x188 - 0x5188	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_ADDR	RW	Configures standby-controller dynamic and static addresses.
0x18C - 0x518C	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES	R	Reports standby-controller capabilities.
0x190 - 0x5190	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_CHAR	RW	-
0x194 - 0x5194	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_STATUS	RW	-
0x198 - 0x5198	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_CHAR	RW	-
0x19C - 0x519C	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_PID_LO	RW	-
0x1A0 - 0x51A0	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_STATUS	RW	-
0x1A4 - 0x51A4	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_PID_LO	RW	-
0x1A8 - 0x51A8	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_SIGNAL_ENABLE	RW	When set to 1'b1, and the corresponding interrupt status field is set in register STBY_CR_INTR_STATUS, the Host Controller shall assert an interrupt to the Host.
0x1AC - 0x51AC	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_FORCE	RW	For software testing, when set to 1'b1, forces the corresponding interrupt to be sent to the Host, if the corresponding fields are set in register STBY_CR_INTR_SIGNAL_ENABLE
0x1B0 - 0x51B0	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_GETCAPS	RW	-
0x1B4 - 0x51B4	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS	RW	Reports the defining byte of the last RSTACT CCC received and configures the reset recovery times.

Address	Name	Access	Description
0x1B8 - 0x51B8	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRT_DEVICE_ADDR	RW	-
0x1BC - 0x51BC	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MWL	R	-
0x1C0 - 0x51C0	i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MRL	R	-
0x200 - 0x5200	i3c_csr[6].I3C_EC.TTI.EXTCAP_HEADER	R	-
0x204 - 0x5204	i3c_csr[6].I3C_EC.TTI.CONTROL	RW	Control Register
0x208 - 0x5208	i3c_csr[6].I3C_EC.TTI.STATUS	R	Status Register
0x20C - 0x520C	i3c_csr[6].I3C_EC.TTI.RESET_CONTROL	RW	Reset Control for Queues and IBI Retry Counter
0x210 - 0x5210	i3c_csr[6].I3C_EC.TTI.QUEUE_STATUS	R	Dynamic queue full/empty status for debug and monitoring
0x214 - 0x5214	i3c_csr[6].I3C_EC.TTI.DESC_QUEUE_DEPTH	R	Current number of entries in descriptor queues
0x218 - 0x5218	i3c_csr[6].I3C_EC.TTI.DATA_QUEUE_DEPTH	R	Current number of DWORD entries in data queues
0x21C - 0x521C	i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_DEPTH	R	Current number of entries in IBI queue
0x220 - 0x5220	i3c_csr[6].I3C_EC.TTI.INTERRUPT_STATUS	RW	Interrupt Status. How a bit is cleared depends on the bit: • Auto-cleared by hardware on a specific access: RX_DESC_STAT, RX_DESC_THLD_STAT and RX_DATA_THLD_STAT clear when software reads the corresponding RX queue; IBI_DONE clears when software reads STATUS.LAST_IBI_STATUS. These bits are also write-1-to-clear, but the normal servicing access clears them without an explicit write here. • Write-1-to-clear only (no hardware auto-clear): TX_DESC_COMPLETE, TX_DESC_STAT, TX_DESC_THLD_STAT, TX_DATA_THLD_STAT, IBI_THLD_STAT, and the not-implemented TRANSFER_ERR_STAT, TRANSFER_ABORT_STAT, TX_DESC_TIMEOUT, RX_DESC_TIMEOUT. Write 1 to the bit in this register to clear it. • Read-only, hardware-driven level status that cannot be cleared by software: PENDING_IBI and PENDING_INTERRUPT track live conditions.
0x224 - 0x5224	i3c_csr[6].I3C_EC.TTI.INTERRUPT_ENABLE	RW	Interrupt Enable
0x228 - 0x5228	i3c_csr[6].I3C_EC.TTI.INTERRUPT_FORCE	RW	Interrupt Force
0x22C - 0x522C	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CTRL	RW	Target Error Detection Control. Set bits to enable error detection. Clear to disable.
0x230 - 0x5230	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_STATUS	RW	Target Error Interrupt Status. Write 1 to clear individual bits.
0x234 - 0x5234	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_ENABLE	RW	Target Error Interrupt Enable. Set bits to enable corresponding interrupts.
0x238 - 0x5238	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_FORCE	RW	Target Error Interrupt Force. Set bits to force corresponding interrupts for testing.

Address	Name	Access	Description
0x23C - 0x523C	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE0	RW	Counts TE0 errors. Saturates at 255. Write 0 to clear.
0x240 - 0x5240	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE1	RW	Counts TE1 errors. Saturates at 255. Write 0 to clear.
0x244 - 0x5244	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE2	RW	Counts TE2 errors. Saturates at 255. Write 0 to clear.
0x248 - 0x5248	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE3	RW	Counts TE3 errors. Saturates at 255. Write 0 to clear.
0x24C - 0x524C	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE4	RW	Counts TE4 errors. Saturates at 255. Write 0 to clear.
0x250 - 0x5250	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE5	RW	Counts TE5 errors. Saturates at 255. Write 0 to clear.
0x254 - 0x5254	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_FRAMING	RW	Counts framing errors. Saturates at 255. Write 0 to clear.
0x258 - 0x5258	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_PEC	RW	Counts Recovery Interface PEC errors. Saturates at 255. Write 0 to clear.
0x25C - 0x525C	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_LENGTH	RW	Counts Recovery Interface length mismatch errors. Saturates at 255. Write 0 to clear.
0x260 - 0x5260	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_READONLY	RW	Counts Recovery Interface write-to-read-only errors. Saturates at 255. Write 0 to clear.
0x264 - 0x5264	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_UNSUPPORTED	RW	Counts Recovery Interface unsupported command errors. Saturates at 255. Write 0 to clear.
0x268 - 0x5268	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW	RW	Counts Recovery Interface RX FIFO overflow errors. Saturates at 255. Write 0 to clear.
0x26C - 0x526C	i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW	RW	Counts Recovery Interface INDIRECT FIFO overflow errors. Saturates at 255. Write 0 to clear.
0x270 - 0x5270	i3c_csr[6].I3C_EC.TTI.RX_DESC_QUEUE_PORT	R	RX Descriptor Queue Port
0x274 - 0x5274	i3c_csr[6].I3C_EC.TTI.RX_DATA_PORT	R	RX Data Port
0x278 - 0x5278	i3c_csr[6].I3C_EC.TTI.TX_DESC_QUEUE_PORT	W	TX Descriptor Queue Port
0x27C - 0x527C	i3c_csr[6].I3C_EC.TTI.TX_DATA_PORT	W	TX Data Port
0x280 - 0x5280	i3c_csr[6].I3C_EC.TTI.IBI_PORT	W	IBI Data Port
0x284 - 0x5284	i3c_csr[6].I3C_EC.TTI.QUEUE_SIZE	R	Queue Size
0x288 - 0x5288	i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_SIZE	R	IBI Queue Size
0x28C - 0x528C	i3c_csr[6].I3C_EC.TTI.QUEUE_THLD_CTRL	RW	Queue Threshold Control
0x290 - 0x5290	i3c_csr[6].I3C_EC.TTI.DATA_BUFFER_THLD_CTRL	RW	IBI Queue Threshold Control
0x300 - 0x5300	i3c_csr[6].I3C_EC.SoCMgmtIf.EXTCAP_HEADER	R	-
0x304 - 0x5304	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_CONTROL	RW	-
0x308 - 0x5308	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_STATUS	RW	-

Address	Name	Access	Description
0x30C - 0x530C	i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_CFG	RW	Configures the recovery interface and signals payload completion to the recovery handler.
0x310 - 0x5310	i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_REG_W1C_ACCESS	RW	-
0x314 - 0x5314	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_2	RW	-
0x318 - 0x5318	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_3	RW	-
0x31C - 0x531C	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_CONF	RW	-
0x320 - 0x5320	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_ATTR	RW	-
0x324 - 0x5324	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_2	RW	-
0x328 - 0x5328	i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_3	RW	-
0x32C - 0x532C	i3c_csr[6].I3C_EC.SoCMgmtIf.T_R_REG	RW	-
0x330 - 0x5330	i3c_csr[6].I3C_EC.SoCMgmtIf.T_F_REG	RW	-
0x334 - 0x5334	i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_REG	RW	-
0x338 - 0x5338	i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_I2C_REG	RW	-
0x33C - 0x533C	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_DAT_REG	RW	-
0x340 - 0x5340	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_REG	RW	-
0x344 - 0x5344	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_OD_REG	RW	-
0x348 - 0x5348	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_INIT_OD_REG	RW	-
0x34C - 0x534C	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_I2C_REG	RW	-
0x350 - 0x5350	i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_REG	RW	-
0x354 - 0x5354	i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_OD_REG	RW	-
0x358 - 0x5358	i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_I2C_REG	RW	-
0x35C - 0x535C	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_REG	RW	-
0x360 - 0x5360	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_I2C_REG	RW	-
0x364 - 0x5364	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_RSTA_REG	RW	-
0x368 - 0x5368	i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_REG	RW	-
0x36C - 0x536C	i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_I2C_REG	RW	-

Address	Name	Access	Description
0x370 - 0x5370	i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_REG	RW	-
0x374 - 0x5374	i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_I2C_REG	RW	-
0x378 - 0x5378	i3c_csr[6].I3C_EC.SoCMgmtIf.T_DS_OD_REG	RW	-
0x37C - 0x537C	i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_REG	RW	-
0x380 - 0x5380	i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_I2C_REG	RW	-
0x384 - 0x5384	i3c_csr[6].I3C_EC.SoCMgmtIf.T_AVAL_REG	RW	-
0x388 - 0x5388	i3c_csr[6].I3C_EC.SoCMgmtIf.T_IDLE_REG	RW	-
0x38C - 0x538C	i3c_csr[6].I3C_EC.SoCMgmtIf.HDR_TIMEOUT_EN_REG	RW	-
0x390 - 0x5390	i3c_csr[6].I3C_EC.SoCMgmtIf.T_HDR_TIMEOUT_REG	RW	-
0x398 - 0x5398	i3c_csr[6].I3C_EC.CtrlCfg.EXTCAP_HEADER	R	-
0x39C - 0x539C	i3c_csr[6].I3C_EC.CtrlCfg.CONTROLLER_CONFIG	R	-
0x3A0 - 0x53A0	i3c_csr[6].I3C_EC.TERMINATION_EXTCAP_HEADER	R	Register after the last EC must advertise ID == 0. Termination register is added to guarantee that the discovery mechanism reaches termination value.
0x400 - 0x57F8	i3c_csr[6].DAT.DAT_MEMORY[128]	RW	-
0x800 - 0x5FF0	i3c_csr[6].DCT.DCT_MEMORY[128]	R	Holds one Device Characteristic Table entry per device enumerated by ENTDAA.

2.1.6.7.10.2.2.1.1. i3c_csr[6].I3CBase.HCI_VERSION

Table 2026. oca_i3c_wrap.i3c_csr[6].I3CBase.HCI_VERSION fields

Bits	Field	Access	Reset	Description
31:0	VERSION	R	0x120	-

2.1.6.7.10.2.2.1.2. i3c_csr[6].I3CBase.HC_CONTROL

Table 2027. oca_i3c_wrap.i3c_csr[6].I3CBase.HC_CONTROL fields

Bits	Field	Access	Reset	Description
31	BUS_ENABLE	RW	0x0	Host Controller Bus Enable
30	RESUME	RW1C	0x0	Host Controller Resume: 0 - Controller is running 1 - Controller is suspended Write 1 to resume Controller operations.
29	ABORT	RW	0x0	Host Controller Abort when set to 1
28:13	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
12	HALT_ON_CMD_SEQ_TIMEOUT	RW	0x0	Halt on Command Sequence Timeout when set to 1
11:9	Reserved	-	-	Reserved
8	HOT_JOIN_CTRL	RW	0x0	Hot-Join ACK/NACK Control: 0 - ACK Hot-Join request 1 - NACK Hot-Join request and send Broadcast CCC to disable Hot-Join
7	I2C_DEV_PRESENT	RW	0x0	I2C Device Present on Bus: 0 - pure I3C bus 1 - legacy I2C devices on the bus
6	MODE_SELECTOR	R	0x1	DMA/PIO Mode Selector: 0 - DMA 1 - PIO
5	Reserved	-	-	Reserved
4	DATA_BYTE_ORDER_MODE	R	0x0	Data Byte Ordering Mode: 0 - Little Endian 1 - Big Endian
3	AUTOCMD_DATA_RPT	R	0x0	Auto-Command Data Report: 0 - coalesced reporting 1 - separated reporting
2:1	Reserved	-	-	Reserved
0	IBA_INCLUDE	RW	0x0	Include I3C Broadcast Address: 0 - skips I3C Broadcast Address for private transfers 1 - includes I3C Broadcast Address for private transfers

2.1.6.7.10.2.2.1.3. i3c_csr[6].I3CBase.CONTROLLER_DEVICE_ADDR

Table 2028. oca_i3c_wrap.i3c_csr[6].I3CBase.CONTROLLER_DEVICE_ADDR fields

Bits	Field	Access	Reset	Description
31	DYNAMIC_ADDR_VALID	RW	0x0	Dynamic Address is Valid: 0 - dynamic address is invalid 1 - dynamic address is valid
30:23	Reserved	-	-	Reserved
22:16	DYNAMIC_ADDR	RW	0x0	Device Dynamic Address
15:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.4. i3c_csr[6].I3CBase.HC_CAPABILITIES

Table 2029. oca_i3c_wrap.i3c_csr[6].I3CBase.HC_CAPABILITIES fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30	SG_CAPABILITY_DC_EN	R	0x0	Device context memory: 0 - must be physically continuous 1 - controller supports scatter-gather
29	SG_CAPABILITY_IBI_EN	R	0x0	DMA only: IBI status and IBI Data rings memory: 0 - must be physically continuous 1 - controller supports scatter-gather
28	SG_CAPABILITY_CR_EN	R	0x0	DMA only: Command and Response rings memory: 0 - must be physically continuous 1 - controller supports scatter-gather
27:22	Reserved	-	-	Reserved
21:20	CMD_SIZE	R	0x0	Size and structure of the Command Descriptor: 2'b0: 2 DWORDs, all other reserved.
19:14	Reserved	-	-	Reserved
13	SCHEDULED_COMMANDS_EN	R	0x0	Controller command scheduling: 0 - not supported 1 - supported
12	IBI_CREDIT_COUNT_EN	R	0x0	Controller IBI credit count: 0 - not supported 1 - supported
11	IBI_DATA_ABORT_EN	R	0x0	Controller IBI data abort: 0 - not supported 1 - supported
10	CMD_CCC_DEFBYTE	R	0x1	CCC with defining byte: 0 - not supported 1 - supported
9:8	Reserved	-	-	Reserved
7	HDR_TS_EN	R	0x0	HDR-Ternary transfers: 0 - not supported 1 - supported
6	HDR_DDR_EN	R	0x0	HDR-DDR transfers: 0 - not supported 1 - supported

Bits	Field	Access	Reset	Description
5	STANDBY_CR_CAP	R	0x0	Switching from active to standby mode: 0 - not supported, this controller is always active on I3C 1- supported, this controller can hand off I3C to secondary controller
4	Reserved	-	-	Reserved
3	AUTO_COMMAND	R	0x0	Automatic read command on IBI: 0 - not supported 1 - supported
2	COMBO_COMMAND	R	0x0	Controller combined command: 0 - not supported 1 - supported
1:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.5. i3c_csr[6].I3CBase.RESET_CONTROL

Table 2030. oca_i3c_wrap.i3c_csr[6].I3CBase.RESET_CONTROL fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	IBI_QUEUE_RST	RW	0x0	Clear IBI queue from software. Valid only in PIO mode.
4	RX_FIFO_RST	RW	0x0	Clear RX FIFO from software. Valid only in PIO mode.
3	TX_FIFO_RST	RW	0x0	Clear TX FIFO from software. Valid only in PIO mode.
2	RESP_QUEUE_RST	RW	0x0	Clear response queue from software. Valid only in PIO mode.
1	CMD_QUEUE_RST	RW	0x0	Clear command queue from software. Valid only in PIO mode.
0	SOFT_RST	RW	0x0	Reset controller from software. Not supported currently

2.1.6.7.10.2.2.1.6. i3c_csr[6].I3CBase.PRESENT_STATE

Table 2031. oca_i3c_wrap.i3c_csr[6].I3CBase.PRESENT_STATE fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	AC_CURRENT_OWN	R	0x0	Controller I3C state: 0 - not bus owner 1 - bus owner
1:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.7. i3c_csr[6].I3CBase.INTR_STATUS

Table 2032. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:15	Reserved	-	-	Reserved
14	SCHED_CMD_MISSED_TICK_STAT	RW1C	0x0	Scheduled commands could be executed due to controller being busy.

Bits	Field	Access	Reset	Description
13	HC_ERR_CMD_SEQ_TIMEOUT_STAT	RW1C	0x0	Command timeout after prolonged stall.
12	HC_WARN_CMD_SEQ_STALL_STAT	RW1C	0x0	Clock stalled due to lack of commands.
11	HC_SEQ_CANCEL_STAT	RW1C	0x0	Controller had to cancel command sequence.
10	HC_INTERNAL_ERR_STAT	RW1C	0x0	Controller internal unrecoverable error.
9:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.8. i3c_csr[6].I3CBase.INTR_STATUS_ENABLE

Table 2033. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_STATUS_ENABLE fields

Bits	Field	Access	Reset	Description
31:15	Reserved	-	-	Reserved
14	SCHED_CMD_MISSED_TICK_STAT_EN	RW	0x0	Enable SCHED_CMD_MISSED_TICK_STAT monitoring.
13	HC_ERR_CMD_SEQ_TIMEOUT_STAT_EN	RW	0x0	Enable HC_ERR_CMD_SEQ_TIMEOUT_STAT monitoring.
12	HC_WARN_CMD_SEQ_STALL_STAT_EN	RW	0x0	Enable HC_WARN_CMD_SEQ_STALL_STAT monitoring.
11	HC_SEQ_CANCEL_STAT_EN	RW	0x0	Enable HC_SEQ_CANCEL_STAT monitoring.
10	HC_INTERNAL_ERR_STAT_EN	RW	0x0	Enable HC_INTERNAL_ERR_STAT monitoring.
9:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.9. i3c_csr[6].I3CBase.INTR_SIGNAL_ENABLE

Table 2034. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_SIGNAL_ENABLE fields

Bits	Field	Access	Reset	Description
31:15	Reserved	-	-	Reserved
14	SCHED_CMD_MISSED_TICK_SIGNAL_EN	RW	0x0	Enable SCHED_CMD_MISSED_TICK_STAT interrupt.
13	HC_ERR_CMD_SEQ_TIMEOUT_SIGNAL_EN	RW	0x0	Enable HC_ERR_CMD_SEQ_TIMEOUT_STAT interrupt.
12	HC_WARN_CMD_SEQ_STALL_SIGNAL_EN	RW	0x0	Enable HC_WARN_CMD_SEQ_STALL_STAT interrupt.
11	HC_SEQ_CANCEL_SIGNAL_EN	RW	0x0	Enable HC_SEQ_CANCEL_STAT interrupt.
10	HC_INTERNAL_ERR_SIGNAL_EN	RW	0x0	Enable HC_INTERNAL_ERR_STAT interrupt.
9:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.10. i3c_csr[6].I3CBase.INTR_FORCE

Table 2035. oca_i3c_wrap.i3c_csr[6].I3CBase.INTR_FORCE fields

Bits	Field	Access	Reset	Description
31:15	Reserved	-	-	Reserved
14	SCHED_CMD_MISSED_TICK_FORCE	W	0x0	Force SCHED_CMD_MISSED_TICK_STAT interrupt.
13	HC_ERR_CMD_SEQ_TIMEOUT_FORCE	W	0x0	Force HC_ERR_CMD_SEQ_TIMEOUT_STAT interrupt.
12	HC_WARN_CMD_SEQ_STALL_FORCE	W	0x0	Force HC_WARN_CMD_SEQ_STALL_STAT interrupt.
11	HC_SEQ_CANCEL_FORCE	W	0x0	Force HC_SEQ_CANCEL_STAT interrupt.
10	HC_INTERNAL_ERR_FORCE	W	0x0	Force HC_INTERNAL_ERR_STAT interrupt.
9:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.11. i3c_csr[6].I3CBase.DAT_SECTION_OFFSET

Table 2036. oca_i3c_wrap.i3c_csr[6].I3CBase.DAT_SECTION_OFFSET fields

Bits	Field	Access	Reset	Description
31:28	ENTRY_SIZE	R	0x0	Individual DAT entry size. 0 - 2 DWRODs, 1:15 - reserved.
27:19	Reserved	-	-	Reserved
18:12	TABLE_SIZE	R	0x7F	Max number of DAT entries.
11:0	TABLE_OFFSET	R	0x400	DAT entry offset in respect to BASE address.

2.1.6.7.10.2.2.1.12. i3c_csr[6].I3CBase.DCT_SECTION_OFFSET

Table 2037. oca_i3c_wrap.i3c_csr[6].I3CBase.DCT_SECTION_OFFSET fields

Bits	Field	Access	Reset	Description
31:28	ENTRY_SIZE	R	0x0	Individual DCT entry size. 0 - 4 DWORDs, 1:15 - Reserved.
27:24	Reserved	-	-	Reserved
23:19	TABLE_INDEX	RW	0x0	Index to DCT used during ENTDAA.
18:12	TABLE_SIZE	R	0x7F	Max number of DCT entries.
11:0	TABLE_OFFSET	R	0x800	DCT entry offset in respect to BASE address.

2.1.6.7.10.2.2.1.13. i3c_csr[6].I3CBase.RING_HEADERS_SECTION_OFFSET

Table 2038. oca_i3c_wrap.i3c_csr[6].I3CBase.RING_HEADERS_SECTION_OFFSET fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	SECTION_OFFSET	R	0x0	DMA ring headers section offset. Invalid if 0.

2.1.6.7.10.2.2.1.14. i3c_csr[6].I3CBase.PIO_SECTION_OFFSET

Table 2039. oca_i3c_wrap.i3c_csr[6].I3CBase.PIO_SECTION_OFFSET fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	SECTION_OFFSET	R	0x80	PIO section offset. Invalid if 0.

2.1.6.7.10.2.2.1.15. i3c_csr[6].I3CBase.EXT_CAPS_SECTION_OFFSET

Table 2040. oca_i3c_wrap.i3c_csr[6].I3CBase.EXT_CAPS_SECTION_OFFSET fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	SECTION_OFFSET	R	0x100	Extended Capabilities section offset. Invalid if 0.

2.1.6.7.10.2.2.1.16. i3c_csr[6].I3CBase.INT_CTRL_CMDS_EN

Table 2041. oca_i3c_wrap.i3c_csr[6].I3CBase.INT_CTRL_CMDS_EN fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:1	MIPI_CMDS_SUPPORTED	R	0x35	Bitmask of supported MIPI commands.
0	ICC_SUPPORT	R	0x1	Internal Control Commands: 1 - some or all internals commands sub-commands are supported, 0 - illegal.

2.1.6.7.10.2.2.1.17. i3c_csr[6].I3CBase.IBI_NOTIFY_CTRL

Table 2042. oca_i3c_wrap.i3c_csr[6].I3CBase.IBI_NOTIFY_CTRL fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	NOTIFY_IBI_REJECTED	RW	0x0	Notify about rejected IBI: 0 - do not enqueue rejected IBI, 1 = enqueue rejected IBI on IBI queue/ring.
2	Reserved	-	-	Reserved
1	NOTIFY_CRR_REJECTED	RW	0x0	Notify about rejected controller role request: 0 - do not enqueue rejected CRR, 1 = enqueue rejected CRR on IBI queue/ring.
0	NOTIFY_HJ_REJECTED	RW	0x0	Notify about rejected hot-join: 0 - do not enqueue rejected HJ, 1 = enqueue rejected HJ on IBI queue/ring.

2.1.6.7.10.2.2.1.18. i3c_csr[6].I3CBase.IBI_DATA_ABORT_CTRL

Table 2043. oca_i3c_wrap.i3c_csr[6].I3CBase.IBI_DATA_ABORT_CTRL fields

Bits	Field	Access	Reset	Description
31	IBI_DATA_ABORT_MON	RW	0x0	Enable/disable IBI monitoring logic.
30:21	Reserved	-	-	Reserved
20:18	MATCH_STATUS_TYPE	RW	0x0	Define which IBI should be aborted: 3'b000 - Regular IBI, 3'b100 - Autocmd IBI, other values - not supported.
17:16	AFTER_N_CHUNKS	RW	0x0	Number of data chunks to be allowed before forced termination: 0 - immediate, 1:3 - delay by 1-3 data chunks.

Bits	Field	Access	Reset	Description
15:8	MATCH_IBI_ID	RW	0x0	IBI target address: [15:9] - device address, [8] - must always be set to 1'b1
7:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.19. i3c_csr[6].I3CBase.DEV_CTX_BASE_LO

Table 2044. oca_i3c_wrap.i3c_csr[6].I3CBase.DEV_CTX_BASE_LO fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	BASE_LO	RW	0x0	-

2.1.6.7.10.2.2.1.20. i3c_csr[6].I3CBase.DEV_CTX_BASE_HI

Table 2045. oca_i3c_wrap.i3c_csr[6].I3CBase.DEV_CTX_BASE_HI fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	BASE_HI	RW	0x0	-

2.1.6.7.10.2.2.1.21. i3c_csr[6].I3CBase.DEV_CTX_SG

Table 2046. oca_i3c_wrap.i3c_csr[6].I3CBase.DEV_CTX_SG fields

Bits	Field	Access	Reset	Description
31	BLP	R	0x0	Buffer vs list pointer in device context: 0 - continuous physical memory region, 1 - pointer to SG descriptor list.
30:16	Reserved	-	-	Reserved
15:0	LIST_SIZE	R	0x0	Number of SG entries.

2.1.6.7.10.2.2.1.22. i3c_csr[6].PIOControl.COMMAND_PORT

Table 2047. oca_i3c_wrap.i3c_csr[6].PIOControl.COMMAND_PORT fields

Bits	Field	Access	Reset	Description
31:0	COMMAND_DATA	W	-	-

2.1.6.7.10.2.2.1.23. i3c_csr[6].PIOControl.RESPONSE_PORT

Table 2048. oca_i3c_wrap.i3c_csr[6].PIOControl.RESPONSE_PORT fields

Bits	Field	Access	Reset	Description
31:0	RESPONSE_DATA	R	-	-

2.1.6.7.10.2.2.1.24. i3c_csr[6].PIOControl.TX_DATA_PORT

Table 2049. oca_i3c_wrap.i3c_csr[6].PIOControl.TX_DATA_PORT fields

Bits	Field	Access	Reset	Description
31:0	TX_DATA	W	-	-

2.1.6.7.10.2.2.1.25. i3c_csr[6].PIOControl.RX_DATA_PORT

Table 2050. oca_i3c_wrap.i3c_csr[6].PIOControl.RX_DATA_PORT fields

Bits	Field	Access	Reset	Description
31:0	RX_DATA	R	-	-

2.1.6.7.10.2.2.1.26. i3c_csr[6].PIOControl.IBI_PORT

Table 2051. oca_i3c_wrap.i3c_csr[6].PIOControl.IBI_PORT fields

Bits	Field	Access	Reset	Description
31:0	IBI_DATA	R	-	Data Read from IBI Data Buffer. The IBI Port is mapped to the IBI Data Queue. IBI Data is always aligned to a 4-byte boundary and then put into the IBI Queue. If the incoming data is not aligned to a 4-byte boundary, then there will be extra (unused) bytes at the end of the transferred IBI data. This can be determined from the value of field DATA_LENGTH in the IBI Status Descriptor.

2.1.6.7.10.2.2.1.27. i3c_csr[6].PIOControl.QUEUE_THLD_CTRL

Table 2052. oca_i3c_wrap.i3c_csr[6].PIOControl.QUEUE_THLD_CTRL fields

Bits	Field	Access	Reset	Description
31:24	IBI_STATUS_THLD	RW	0x1	Triggers IBI_STATUS_THLD_STAT interrupt when IBI queue has N or more entries. Accepted values are 1:255
23:16	IBI_DATA_SEGMENT_SIZE	RW	0x1	IBI Queue data segment size. Valida values are 1:63
15:8	RESP_BUF_THLD	RW	0x1	Triggers RESP_READY_STAT interrupt when RESP queue has N or more entries. Accepted values are 1:255
7:0	CMD_EMPTY_BUF_THLD	RW	0x1	Triggers CMD_QUEUE_READY_STAT interrupt when CMD queue has N or more free entries. Accepted values are 1:255

2.1.6.7.10.2.2.1.28. i3c_csr[6].PIOControl.DATA_BUFFER_THLD_CTRL

Table 2053. oca_i3c_wrap.i3c_csr[6].PIOControl.DATA_BUFFER_THLD_CTRL fields

Bits	Field	Access	Reset	Description
31:27	Reserved	-	-	Reserved
26:24	RX_START_THLD	RW	0x1	Postpone read command until RX queue has 2^(N+1) free entries
23:19	Reserved	-	-	Reserved
18:16	TX_START_THLD	RW	0x1	Postpone write command until TX queue has 2^(N+1) entries
15:11	Reserved	-	-	Reserved
10:8	RX_BUF_THLD	RW	0x1	Trigger RX_THLD_STAT interrupt when RX queue has 2^(N+1) or more entries
7:3	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
2:0	TX_BUF_THLD	RW	0x1	Trigger TX_THLD_STAT interrupt when TX queue has 2^(N+1) or more free entries

2.1.6.7.10.2.2.1.29. i3c_csr[6].PIOControl.QUEUE_SIZE

Table 2054. oca_i3c_wrap.i3c_csr[6].PIOControl.QUEUE_SIZE fields

Bits	Field	Access	Reset	Description
31:24	TX_DATA_BUFFER_SIZE	R	0x5	TX queue size is equal to 2^(N+1), where N is this field value
23:16	RX_DATA_BUFFER_SIZE	R	0x5	RX queue size is equal to 2^(N+1), where N is this field value
15:8	IBI_STATUS_SIZE	R	0x20	IBI Queue size is equal to N
7:0	CR_QUEUE_SIZE	R	0x40	Command/Response queue size is equal to N

2.1.6.7.10.2.2.1.30. i3c_csr[6].PIOControl.ALT_QUEUE_SIZE

Table 2055. oca_i3c_wrap.i3c_csr[6].PIOControl.ALT_QUEUE_SIZE fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28	EXT_IBI_QUEUE_EN	R	0x0	1 indicates that IBI queue size is equal to 8*IBI_STATUS_SIZE
27:25	Reserved	-	-	Reserved
24	ALT_RESP_QUEUE_EN	R	0x1	If set, response and command queues are not equal lengths, then ALT_RESP_QUEUE_SIZE contains response queue size
23:8	Reserved	-	-	Reserved
7:0	ALT_RESP_QUEUE_SIZE	R	0x20	Valid only if ALT_RESP_QUEUE_EN is set. Contains response queue size

2.1.6.7.10.2.2.1.31. i3c_csr[6].PIOControl.PIO_INTR_STATUS

Table 2056. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9	TRANSFER_ERR_STAT	RW1C	0x0	Transfer error
8:6	Reserved	-	-	Reserved
5	TRANSFER_ABORT_STAT	RW1C	0x0	Transfer aborted
4	RESP_READY_STAT	R	0x0	Response queue fulfils RESP_BUF_THLD
3	CMD_QUEUE_READY_STAT	R	0x0	Command queue fulfils CMD_EMPTY_BUF_THLD
2	IBI_STATUS_THLD_STAT	R	0x0	IBI queue fulfils IBI_STATUS_THLD
1	RX_THLD_STAT	R	0x0	RX queue fulfils RX_BUF_THLD
0	TX_THLD_STAT	R	0x0	TX queue fulfils TX_BUF_THLD

2.1.6.7.10.2.2.1.32. i3c_csr[6].PIOControl.PIO_INTR_STATUS_ENABLE

Table 2057. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_STATUS_ENABLE fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9	TRANSFER_ERR_STAT_EN	RW	0x0	Enable transfer error monitoring

Bits	Field	Access	Reset	Description
8:6	Reserved	-	-	Reserved
5	TRANSFER_ABORT_STAT_EN	RW	0x0	Enable transfer abort monitoring
4	RESP_READY_STAT_EN	RW	0x0	Enable response queue monitoring
3	CMD_QUEUE_READY_STAT_EN	RW	0x0	Enable command queue monitoring
2	IBI_STATUS_THLD_STAT_EN	RW	0x0	Enable IBI queue monitoring
1	RX_THLD_STAT_EN	RW	0x0	Enable RX queue monitoring
0	TX_THLD_STAT_EN	RW	0x0	Enable TX queue monitoring

2.1.6.7.10.2.2.1.33. i3c_csr[6].PIOControl.PIO_INTR_SIGNAL_ENABLE

Table 2058. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_SIGNAL_ENABLE fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9	TRANSFER_ERR_SIGNAL_EN	RW	0x0	Enable transfer error interrupt
8:6	Reserved	-	-	Reserved
5	TRANSFER_ABORT_SIGNAL_EN	RW	0x0	Enable transfer abort interrupt
4	RESP_READY_SIGNAL_EN	RW	0x0	Enable response ready interrupt
3	CMD_QUEUE_READY_SIGNAL_EN	RW	0x0	Enable command queue interrupt
2	IBI_STATUS_THLD_SIGNAL_EN	RW	0x0	Enable IBI queue interrupt
1	RX_THLD_SIGNAL_EN	RW	0x0	Enable RX queue interrupt
0	TX_THLD_SIGNAL_EN	RW	0x0	Enable TX queue interrupt

2.1.6.7.10.2.2.1.34. i3c_csr[6].PIOControl.PIO_INTR_FORCE

Table 2059. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_INTR_FORCE fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9	TRANSFER_ERR_FORCE	W	0x0	Force transfer error
8:6	Reserved	-	-	Reserved
5	TRANSFER_ABORT_FORCE	W	0x0	Force transfer aborted
4	RESP_READY_FORCE	W	0x0	Force response queue interrupt
3	CMD_QUEUE_READY_FORCE	W	0x0	Force command queue interrupt
2	IBI_THLD_FORCE	W	0x0	Force IBI queue interrupt
1	RX_THLD_FORCE	W	0x0	Force RX queue interrupt
0	TX_THLD_FORCE	W	0x0	Force TX queue interrupt

2.1.6.7.10.2.2.1.35. i3c_csr[6].PIOControl.PIO_CONTROL

Table 2060. oca_i3c_wrap.i3c_csr[6].PIOControl.PIO_CONTROL fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	ABORT	RW	0x0	Stop current command descriptor execution forcefully and hold remaining commands. 1 - Request PIO Abort, 0 - Resume PIO execution

Bits	Field	Access	Reset	Description
1	RS	RW	0x0	Run/Stop execution of enqueued commands. When set to 0, it holds execution of enqueued commands and runs current command to completion. 1 - PIO Queue start request, 0 - PIO Queue stop request.
0	ENABLE	RW	0x1	Enables PIO queues. When disabled, SW may not read from/write to PIO queues. 1 - PIO queue enable request, 0 - PIO queue disable request

2.1.6.7.10.2.2.1.36. i3c_csr[6].I3C_EC.SecFwRecoveryIf.EXTCAP_HEADER

Table 2061. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.EXTCAP_HEADER fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:8	CAP_LENGTH	R	0x20	Capability Structure Length in DWORDs
7:0	CAP_ID	R	0xC0	Extended Capability ID

2.1.6.7.10.2.2.1.37. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_0

Table 2062. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_0 fields

Bits	Field	Access	Reset	Description
31:0	REC_MAGIC_STRING_0	R	0x2050434F	Magic string 'OCP ' (1st part of 'OCP RECV') in ASCII code - '0x4f 0x43 0x50 0x20'

2.1.6.7.10.2.2.1.38. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_1

Table 2063. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_1 fields

Bits	Field	Access	Reset	Description
31:0	REC_MAGIC_STRING_1	R	0x56434552	Magic string 'RECV' (2nd part of 'OCP RECV') in ASCII code - '0x52 0x45 0x43 0x56'

2.1.6.7.10.2.2.1.39. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_2

Table 2064. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_2 fields

Bits	Field	Access	Reset	Description
31:16	AGENT_CAPS	RW	0x0	Agent capabilities: • bit 0: Identification (DEVICE_ID structure) • bit 1: Forced Recovery (From RESET) • bit 2: Mgmt reset (From RESET) • bit 3: Device Reset (From RESET) • bit 4: Device status (DEVICE_STATUS) • bit 5: Recovery memory access (INDIRECT_CTRL) • bit 6: Local C-image support • bit 7: Push C-image support • bit 8: Interface isolation • bit 9: Hardware status • bit 10: Vendor command • bit 11: Flashless boot (From RESET) • bit 12: FIFO CMS support (INDIRECT_FIFO_CTRL) • bits 13-15: Reserved
15:0	REC_PROT_VERSION	RW	0x0	• Byte 0: Major version number = 0x1 • Byte 1: Minor version number = 0x1

2.1.6.7.10.2.2.1.40. i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_3

Table 2065. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.PROT_CAP_3 fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	HEARTBEAT_PERIOD	RW	0x0	0-255: Heartbeat period, 2^x microseconds (us), 0 indicates not supported
15:8	MAX_RESP_TIME	RW	0x0	0-255: Maximum response time in 2^x microseconds(us).
7:0	NUM_OF_CMS_REGIONS	RW	0x0	0-255: The total number of component memory space (CMS) regions a device supports. This number includes any logging, code and vendor defined regions

2.1.6.7.10.2.2.1.41. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_0

Table 2066. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_0 fields

Bits	Field	Access	Reset	Description
31:16	DATA	RW	0x0	-
15:8	VENDOR_SPECIFIC_STR_LENGTH	RW	0x0	0x0-0xFF: Total length of Vendor Specific String, 0 indicates not supported

Bits	Field	Access	Reset	Description
7:0	DESC_TYPE	RW	0x0	Based on table 8 from [DMTF PLDM FM]: • 0x00: PCI Vendor • 0x1: IANA • 0x2: UUID • 0x3: PnP Vendor • 0x4: ACPI Vendor • 0x5: IANA Enterprise Type • 0x6-0xFE: Reserved • 0xFF: NVMe-MI

2.1.6.7.10.2.2.1.42. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_1

Table 2067. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_1 fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	-

2.1.6.7.10.2.2.1.43. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_2

Table 2068. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_2 fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	-

2.1.6.7.10.2.2.1.44. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_3

Table 2069. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_3 fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	-

2.1.6.7.10.2.2.1.45. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_4

Table 2070. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_4 fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	-

2.1.6.7.10.2.2.1.46. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_5

Table 2071. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_5 fields

Bits	Field	Access	Reset	Description
31:0	DATA	RW	0x0	-

2.1.6.7.10.2.2.1.47. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_RESERVED

Table 2072. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_ID_RESERVED fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	-

2.1.6.7.10.2.2.1.48. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_0

Table 2073. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_0 fields

Bits	Field	Access	Reset	Description
31:16	REC_REASON_CODE	RW	0x0	• 0x0: No Boot Failure detected (BFNF) • 0x1: Generic hardware error (BFGHWE) • 0x2: Generic hardware soft error (BFGSE) - soft error may be recoverable • 0x3: Self-test failure (BFSTF) (e.g., RSA self test failure, FIPs self test failure,, etc.) • 0x4: Corrupted/missing critical data (BFCD) • 0x5: Missing/corrupt key manifest (BFKMMC) • 0x6: Authentication Failure on key manifest (BFKMAF) • 0x7: Anti-rollback failure on key manifest (BFKIAR) • 0x8: Missing/corrupt boot loader (first mutable code) firmware image (BFFIMC) • 0x9: Authentication failure on boot loader (1st mutable code) firmware image (BFFIAF) • 0xA: Anti-rollback failure boot loader (1st mutable code) firmware image (BFFIAR) • 0xB: Missing/corrupt main/management firmware image (BFMFMC) • 0xC: Authentication Failure main/management firmware image (BFMFAF) • 0xD: Anti-rollback Failure main/management firmware image (BFMFAR) • 0xE: Missing/corrupt recovery firmware (BFRFMC) • 0xF: Authentication Failure recovery firmware (BFRFAF) • 0x10: Anti-rollback Failure on recovery firmware (BFRFAR) • 0x11: Forced Recovery (FR) • 0x12: Flashless/Streaming Boot (FSB) • 0x13-0x7F: Reserved • 0x80-0xFF: Vendor Unique Boot Failure Codes
15:8	PROT_ERROR	RW RC	0x0	• 0x0: No Protocol Error • 0x1: Unsupported/Write Command - command is not support or a write to a RO command • 0x2: Unsupported Parameter • 0x3: Length write error (length of write command is incorrect) • 0x4: CRC Error (if supported) • 0x5-0xFE: Reserved • 0xFF: General Protocol Error - catch all unclassified errors

Bits	Field	Access	Reset	Description
7:0	DEV_STATUS	RW	0x0	• 0x0: Status Pending (Recover Reason Code not populated) • 0x1: Device healthy (Recover Reason Code not populated) • 0x2: Device Error (“soft” error or other error state) - (Recover Reason Code not populated) • 0x3: Recovery mode - ready to accept recovery image - (Recover Reason Code populated) • 0x4: Recovery Pending (waiting for activation) - (Recover Reason Code populated) • 0x5: Running Recovery Image (Recover Reason Code not populated) • 0x6-0xD: Reserved • 0xE: Boot Failure (Recover Reason Code populated) • 0xF: Fatal Error (Recover Reason Code not populated) • 0x10-FF:Reserved

2.1.6.7.10.2.2.1.49. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_1

Table 2074. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_STATUS_1 fields

Bits	Field	Access	Reset	Description
31:25	VENDOR_STATUS	RW	0x0	-
24:16	VENDOR_STATUS_LENGTH	RW	0x0	0-248: Length in bytes of just VENDOR_STATUS. Zero indicates no vendor status and zero additional bytes.
15:0	HEARTBEAT	RW	0x0	0-4095: Incrementing number (counter wraps)

2.1.6.7.10.2.2.1.50. i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_RESET

Table 2075. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.DEVICE_RESET fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	IF_CTRL	RW	0x0	• 0x0: Disable Interface mastering • 0x1: Enable Interface mastering
15:8	FORCED_RECOVERY	RW	0x0	• 0x0: No forced recovery • 0x01-0xD: Reserved • 0xE: Enter flashless boot mode on next platform reset • 0xF: Enter recovery mode on next platform reset • 0x10-FF: Reserved
7:0	RESET_CTRL	RW1C	0x0	• 0x0: No reset • 0x1: Reset Device (PCIe Fundamental Reset or equivalent. This is likely bus disruptive) • 0x2: Reset Management. This reset will reset the management subsystem. If supported, this reset MUST not be bus disruptive (cause re-enumeration) • 0x3-FF: Reserved

2.1.6.7.10.2.2.1.51. i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_CTRL

Table 2076. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_CTRL fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	ACTIVATE_REC_IMG	RW1C	0x0	• 0x0: do not activate recovery image - after activation device will report this code. • 0xF: Activate recovery image • 0x10-FF-reserved
15:8	REC_IMG_SEL	RW	0x0	• 0x0: No operation • 0x1: Use Recovery Image from memory window (CMS) • 0x2: Use Recovery Image stored on device (C-image) • 0x3-FF: reserved
7:0	CMS	RW	0x0	• 0-255: Selects a component memory space where the recovery image is. 0 is the default

2.1.6.7.10.2.2.1.52. i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_STATUS

Table 2077. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.RECOVERY_STATUS fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:8	VENDOR_SPECIFIC_STATUS	RW	0x0	-
7:4	REC_IMG_INDEX	RW	0x0	-
3:0	DEV_REC_STATUS	RW	0x0	• 0x0: Not in recovery mode • 0x1: Awaiting recovery image • 0x2: Booting recovery image • 0x3: Recovery successful • 0xc: Recovery failed • 0xd: Recovery image authentication error • 0xe: Error entering Recovery mode (might be administratively disabled) • 0xf: Invalid component address space

2.1.6.7.10.2.2.1.53. i3c_csr[6].I3C_EC.SecFwRecoveryIf.HW_STATUS

Table 2078. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.HW_STATUS fields

Bits	Field	Access	Reset	Description
31:24	VENDOR_HW_STATUS_LEN	RW	0x0	0-251: Length in bytes of Vendor Specific Hardware Status.

Bits	Field	Access	Reset	Description
23:16	CTEMP	RW	0x0	Current temperatureof device in degrees Celsius: Compatible with NVMe-MI command code 0 offset 3. • 0x00-0x7e: 0 to 126 C • 0x7f: 127 C or higher • 0x80: no temperature data, or data is older than 5 seconds • 0x81: temperature sensor failure • 0x82-0x83: reserved • 0xc4: -60 C or lower • 0xc5-0xff: -59 to -1 C (in two's complement)
15:8	VENDOR_HW_STATUS	RW	0x0	-
7:3	RESERVED_7_3	RW	0x0	-
2	FATAL_ERR	RW	0x0	-
1	SOFT_ERR	RW	0x0	Hardware Soft Error (may need reset to clear)
0	TEMP_CRITICAL	RW	0x0	Device temperature is critical (may need reset to clear)

2.1.6.7.10.2.2.1.54. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_0

Table 2079. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_0 fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:8	RESET	RW	0x0	Reset (Write 1 Clear): • 0x0: idle • 0x1: reset Write Index and Read Index to initial value. • 0x2 to 0xFF: reserved
7:0	CMS	RW	0x0	This register selects a region within the device. Read/write access is through address spaces. Each space represents a FIFO. Component Memory Space (CMS): • 0-255: Address region within a device.

2.1.6.7.10.2.2.1.55. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_1

Table 2080. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_CTRL_1 fields

Bits	Field	Access	Reset	Description
31:0	IMAGE_SIZE	RW	0x0	Image Size: Size of the image to be loaded in 4B units

2.1.6.7.10.2.2.1.56. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_0

Table 2081. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_0 fields

Bits	Field	Access	Reset	Description
31:11	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
10:8	REGION_TYPE	R	0x0	Memory Region Type: • 0b000: Code space for recovery. (write only) • 0b001: Log uses the defined debug format (read only) • 0b100: Vendor Defined Region (write only) • 0b101: Vendor Defined Region (read only) • 0b111: Unsupported Region (address space out of range)
7:2	Reserved	-	-	Reserved
1	FULL	R	0x0	If set, FIFO is full
0	EMPTY	R	0x1	If set, FIFO is empty

2.1.6.7.10.2.2.1.57. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_1

Table 2082. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_1 fields

Bits	Field	Access	Reset	Description
31:0	WRITE_INDEX	R	0x0	Offset incremented for each access by the Recovery Agent in 4B units

2.1.6.7.10.2.2.1.58. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_2

Table 2083. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_2 fields

Bits	Field	Access	Reset	Description
31:0	READ_INDEX	R	0x0	Offset incremented for each access by the device in 4B units

2.1.6.7.10.2.2.1.59. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_3

Table 2084. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_3 fields

Bits	Field	Access	Reset	Description
31:0	FIFO_SIZE	R	0x40	Size of memory window specified in 4B units. Current implementation supports only a constant size of 64.

2.1.6.7.10.2.2.1.60. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_4

Table 2085. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_STATUS_4 fields

Bits	Field	Access	Reset	Description
31:0	MAX_TRANSFER_SIZE	R	0x40	Max size of the data payload in each read/write to INDIRECT_FIFO_DATA in 4B units Enforced to 256 bytes (64 DWORDs) by Caliptra Subsystem Recovery Sequence

2.1.6.7.10.2.2.1.61. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_RESERVED

Table 2086. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_RESERVED fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	-

2.1.6.7.10.2.2.1.62. i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_DATA

Table 2087. oca_i3c_wrap.i3c_csr[6].I3C_EC.SecFwRecoveryIf.INDIRECT_FIFO_DATA fields

Bits	Field	Access	Reset	Description
31:0	DATA	R	0x0	-

2.1.6.7.10.2.2.1.63. i3c_csr[6].I3C_EC.StdbyCtrlMode.EXTCAP_HEADER

Table 2088. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.EXTCAP_HEADER fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:8	CAP_LENGTH	R	0x20	Capability Structure Length in DWORDs
7:0	CAP_ID	R	0x12	Extended Capability ID

2.1.6.7.10.2.2.1.64. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL

Table 2089. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CONTROL fields

Bits	Field	Access	Reset	Description
31:30	STBY_CR_ENABLE_INIT	RW	0x0	Enables or disables the Secondary Controller: 2'b00 - DISABLED: Secondary Controller is disabled. 2'b01 - ACM_INIT: Secondary Controller is enabled, but Host Controller initializes in Active Controller mode. 2'b10 - SCM_RUNNING: Secondary Controller operation is enabled, Host Controller initializes in Standby Controller mode. 2'b11 - SCM_HOT_JOIN: Secondary Controller operation is enabled, Host Controller conditionally becomes a Hot-Joining Device to receive its Dynamic Address before operating in Standby Controller mode.
29:21	Reserved	-	-	Reserved
20	RSTACT_DEFBYTE_02	RW	0x0	Controls whether I3C Secondary Controller Logic supports RSTACT CCC with Defining Byte 0x02. 1'b0: NOT_SUPPORTED: Do not ACK Defining Byte 0x02 1'b1: HANDLE_INTR: Support Defining Byte 0x02
19:16	Reserved	-	-	Reserved
15	DAA_ENTDAA_ENABLE	RW	0x0	Indicates ENTDAA method is enabled. 1'b0: DISABLED: will not respond 1'b1: ENABLED: will respond
14	DAA_SETDASA_ENABLE	RW	0x0	Indicates SETDASA method is enabled. 1'b0: DISABLED: will not respond 1'b1: ENABLED: will respond

Bits	Field	Access	Reset	Description
13	DAA_SETAASA_ENABLE	RW	0x0	Indicates SETAASA method is enabled. 1'b0: DISABLED: will not respond 1'b1: ENABLED: will respond
12	TARGET_XACT_ENABLE	RW	0x1	Indicates whether Read-Type/Write-Type transaction servicing is enabled, via an I3C Target Transaction Interface to software (Section 6.17.3). 1'b0: DISABLED: not available 1'b1: ENABLED: available for software
11	Reserved	-	-	Reserved
10:8	BAST_CCC_IBI_RING	RW	0x0	Indicates which Ring Bundle will be used to capture Broadcast CCC data sent by the Active Controller. The Ring Bundle must be configured and enabled, and its IBI Ring Pair must also be initialized and ready to receive data.
7:6	Reserved	-	-	Reserved
5	CR_REQUEST_SEND	W	0x0	Write of 1'b1 to this field shall instruct the Secondary Controller Logic to attempt to send a Controller Role Request to the I3C Bus.
4	HANDOFF_DEEP_SLEEP	RW WS	0x0	If this field has a value of 1'b1, then the Secondary Controller Logic shall report a return from Deep Sleep state to the Active Controller. Writing 1'b1 to this bit is sticky. This field shall automatically clear to 1'b0 after accepting the Controller Role and transitioning to Active Controller mode.
3	PRIME_ACCEPT_GETACCCR	RW	0x0	-
2	ACR_FSM_OP_SELECT	RW	0x0	-
1	HANDOFF_DELAY_NACK	RW	0x0	-
0	PENDING_RX_NACK	RW	0x0	-

2.1.6.7.10.2.2.1.65. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_ADDR

Table 2090. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_ADDR fields

Bits	Field	Access	Reset	Description
31	DYNAMIC_ADDR_VALID	RW	0x0	Indicates whether or not the value in the DYNAMIC_ADDR field is valid. 1'b0: DYNAMIC_ADDR field is not valid 1'b1: DYNAMIC_ADDR field is valid
30:23	Reserved	-	-	Reserved
22:16	DYNAMIC_ADDR	RW	0x0	Contains the Host Controller Device's Dynamic Address.
15	STATIC_ADDR_VALID	RW	0x0	Indicates whether or not the value in the STATIC_ADDR field is valid. 1'b0: The Static Address field is not valid 1'b1: The Static Address field is valid
14:7	Reserved	-	-	Reserved
6:0	STATIC_ADDR	RW	0x0	This field contains the Host Controller Device's Static Address.

2.1.6.7.10.2.2.1.66. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES

Table 2091. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CAPABILITIES fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
15	DAA_ENTDAA_SUPPORT	R	0x0	Defines whether Dynamic Address Assignment with ENTDAA CCC is supported. 1'b0: DISABLED: Not supported 1'b1: ENABLED: Supported
14	DAA_SETDASA_SUPPORT	R	0x1	Defines whether Dynamic Address Assignment with SETDASA CCC (using Static Address) is supported. 1'b0: DISABLED: Not supported 1'b1: ENABLED: Supported
13	DAA_SETAASA_SUPPORT	R	0x1	Defines whether Dynamic Address Assignment with SETAASA CCC (using Static Address) is supported. 1'b0: DISABLED: Not supported 1'b1: ENABLED: Supported
12	TARGET_XACT_SUPPORT	R	0x1	Defines whether an I3C Target Transaction Interface is supported. 1'b0: DISABLED: Not supported 1'b1: ENABLED: Supported via vendor-defined Extended Capability structure
11:6	Reserved	-	-	Reserved
5	SIMPLE_CRR_SUPPORT	R	0x0	-
4:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.67. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_CHAR

Table 2092. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_CHAR fields

Bits	Field	Access	Reset	Description
31:29	BCR_FIXED	RW	0x1	Bus Characteristics, Fixed Part. Reset value is set to 3'b001, because this device is an I3C Target, which supports extended capabilities. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.
28:24	BCR_VAR	RW	0x10	Bus Characteristics, Variable Part. Reset value is set to 5'b10000, because this device: • [bit4] is a Virtual Target • [bit3] is not Offline Capable • [bit2] does not apply due to bit1 • [bit1] is not capable of IBI requests • [bit0] has no speed limitation This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.

Bits	Field	Access	Reset	Description
23:16	DCR	RW	0xBD	Device Characteristics Register. Value represents an OCP Recovery Device. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.
15:1	PID_HI	RW	0x7FFF	High part of the 48-bit Target Device Provisioned ID. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.
0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.68. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_STATUS

Table 2093. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_STATUS fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	HJ_REQ_STATUS	RW	0x0	-
7:5	SIMPLE_CRR_STATUS	RW	0x0	-
4:3	Reserved	-	-	Reserved
2	AC_CURRENT_OWN	RW	0x0	-
1:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.69. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_CHAR

Table 2094. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_CHAR fields

Bits	Field	Access	Reset	Description
31:29	BCR_FIXED	RW	0x1	Bus Characteristics, Fixed Part. Reset value is set to 3'b001, because this device is an I3C Target, which supports extended capabilities This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.
28:24	BCR_VAR	RW	0x16	Bus Characteristics, Variable Part. Reset value is set to 5'b10110, because this device: • [bit4] exposes a Virtual Target • [bit3] is not Offline Capable • [bit2] (always) uses the MDB in the IBI Payload • [bit1] is capable of IBI requests • [bit0] has no speed limitation This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.
23:16	DCR	RW	0xBD	Device Characteristics Register. Value represents an OCP Recovery Device. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.

Bits	Field	Access	Reset	Description
15:1	PID_HI	RW	0x7FFF	High part of the 48-bit Target Device Provisioned ID. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.
0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.70. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_PID_LO

Table 2095. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_DEVICE_PID_LO fields

Bits	Field	Access	Reset	Description
31:0	PID_LO	RW	0x5A00A5	Low part of the 48-bit Target Device Provisioned ID. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.

2.1.6.7.10.2.2.1.71. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_STATUS

Table 2096. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	CCC_FATAL_RSTDAA_ERR_STAT	RW	0x0	-
18	CCC_UNHANDLED_NACK_STAT	RW	0x0	-
17	CCC_PARAM_MODIFIED_STAT	RW	0x0	-
16	STBY_CR_OP_RSTACT_STAT	RW	0x0	The Host Controller shall write 1'b1 to this field to indicate that the Secondary Controller received a RSTACT CCC from the Active Controller, followed by the Target Reset Pattern.
15	Reserved	-	-	Reserved
14	STBY_CR_ACCEPT_ERR_STAT	RW	0x0	-
13	STBY_CR_ACCEPT_OK_STAT	RW	0x0	-
12	STBY_CR_ACCEPT_NACKED_STAT	RW	0x0	-
11	STBY_CR_DYN_ADDR_STAT	RW	0x0	-
10	CRR_RESPONSE_STAT	RW	0x0	-
9:4	Reserved	-	-	Reserved
3	ACR_HANDOFF_ERR_M3_STAT	RW	0x0	-
2	ACR_HANDOFF_ERR_FAIL_STAT	RW	0x0	-
1	ACR_HANDOFF_OK_PRIMED_STAT	RW	0x0	-
0	ACR_HANDOFF_OK_REMAIN_STAT	RW	0x0	-

2.1.6.7.10.2.2.1.72. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_PID_LO

Table 2097. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRTUAL_DEVICE_PID_LO fields

Bits	Field	Access	Reset	Description
31:0	PID_LO	RW	0x5A10A5	Low part of the 48-bit Target Virtual Device Provisioned ID. This field is Read-Only while the STBY_CR_ENABLE_INIT field in register STBY_CR_CONTROL is not zero.

2.1.6.7.10.2.2.1.73. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_SIGNAL_ENABLE

Table 2098. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_SIGNAL_ENABLE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	CCC_FATAL_RSTDAA_ERR_SIGNAL_EN	RW	0x0	-
18	CCC_UNHANDLED_NACK_SIGNAL_EN	RW	0x0	-
17	CCC_PARAM_MODIFIED_SIGNAL_EN	RW	0x0	-
16	STBY_CR_OP_RSTACT_SIGNAL_EN	RW	0x0	-
15	Reserved	-	-	Reserved
14	STBY_CR_ACCEPT_ERR_SIGNAL_EN	RW	0x0	-
13	STBY_CR_ACCEPT_OK_SIGNAL_EN	RW	0x0	-
12	STBY_CR_ACCEPT_NACKED_SIGNAL_EN	RW	0x0	-
11	STBY_CR_DYN_ADDR_SIGNAL_EN	RW	0x0	-
10	CRR_RESPONSE_SIGNAL_EN	RW	0x0	-
9:4	Reserved	-	-	Reserved
3	ACR_HANDOFF_ERR_M3_SIGNAL_EN	RW	0x0	-
2	ACR_HANDOFF_ERR_FAIL_SIGNAL_EN	RW	0x0	-
1	ACR_HANDOFF_OK_PRIMED_SIGNAL_EN	RW	0x0	-
0	ACR_HANDOFF_OK_REMAIN_SIGNAL_EN	RW	0x0	-

2.1.6.7.10.2.2.1.74. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_FORCE

Table 2099. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_INTR_FORCE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19	CCC_FATAL_RSTDAA_ERR_FORCE	RW	0x0	-
18	CCC_UNHANDLED_NACK_FORCE	RW	0x0	-
17	CCC_PARAM_MODIFIED_FORCE	RW	0x0	-
16	STBY_CR_OP_RSTACT_FORCE	W	0x0	-
15	Reserved	-	-	Reserved
14	STBY_CR_ACCEPT_ERR_FORCE	RW	0x0	-
13	STBY_CR_ACCEPT_OK_FORCE	RW	0x0	-
12	STBY_CR_ACCEPT_NACKED_FORCE	RW	0x0	-
11	STBY_CR_DYN_ADDR_FORCE	RW	0x0	-
10	CRR_RESPONSE_FORCE	RW	0x0	-
9:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.75. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_GETCAPS

Table 2100. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_GETCAPS fields

Bits	Field	Access	Reset	Description
31:12	Reserved	-	-	Reserved
11:8	F2_CRCAP2_DEV_INTERACT	RW	0x0	-

Bits	Field	Access	Reset	Description
7:3	Reserved	-	-	Reserved
2:0	F2_CRCAP1_BUS_CONFIG	RW	0x0	-

2.1.6.7.10.2.2.1.76. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS

Table 2101. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_CCC_CONFIG_RSTACT_PARAMS fields

Bits	Field	Access	Reset	Description
31	RESET_DYNAMIC_ADDR	RW	0x1	If set to 1'b1, then the Secondary Controller Logic must clear its Dynamic Address in register STBY_CR_DEVICE_ADDR after receiving a Target Reset Pattern that followed a Broadcast or Direct SET RSTACT CCC sent to the Dynamic Address, with Defining Byte 0x01 or 0x02. Requires support for Dynamic Address Assignment with at least one supported method, such as the ENTDAA CCC, with field DAA_ENTDAA_ENABLE set to 1'b1 in register STBY_CR_CONTROL. If field ACR_FSM_OP_SELECT in register STBY_CR_CONTROL is set to 1'b1, then this field shall be cleared (i.e., readiness to accept the Controller Role shall be revoked) with this Target Reset Pattern.
30:24	Reserved	-	-	Reserved
23:16	RESET_TIME_TARGET	RW	0x0	For Direct GET CCC, this field is returned for Defining Byte 0x82.
15:8	RESET_TIME_PERIPHERAL	RW	0x0	For Direct GET CCC, this field is returned for Defining Byte 0x81.
7:0	RST_ACTION	R	0x1	Contains the Defining Byte received with the last Direct SET CCC sent by the Active Controller. If not armed (START or RSTACT with unsupported defining byte) set to spec default 0x1.

2.1.6.7.10.2.2.1.77. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRT_DEVICE_ADDR

Table 2102. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_VIRT_DEVICE_ADDR fields

Bits	Field	Access	Reset	Description
31	VIRT_DYNAMIC_ADDR_VALID	RW	0x0	Indicates whether or not the value in the VIRT_DYNAMIC_ADDR field is valid. 1'b0: VIRT_DYNAMIC_ADDR field is not valid 1'b1: VIRT_DYNAMIC_ADDR field is valid
30:23	Reserved	-	-	Reserved
22:16	VIRT_DYNAMIC_ADDR	RW	0x0	Contains the Controller Virtual Device's Dynamic Address.
15	VIRT_STATIC_ADDR_VALID	RW	0x0	Indicates whether or not the value in the VIRT_STATIC_ADDR field is valid. 1'b0: The Virtual Device Static Address field is not valid 1'b1: The Virtual Device Static Address field is valid
14:7	Reserved	-	-	Reserved
6:0	VIRT_STATIC_ADDR	RW	0x0	This field contains the Host Controller Device's Static Address.

2.1.6.7.10.2.2.1.78. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MWL

Table 2103. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MWL fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	MWL	R	0x100	This field contains the maximum write length (MWL) (read-only)

2.1.6.7.10.2.2.1.79. i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MRL

Table 2104. oca_i3c_wrap.i3c_csr[6].I3C_EC.StdbyCtrlMode.STBY_CR_MRL fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	IBIL	R	0x10	This field contains the IBI payload size (IBIL) (read-only)
15:0	MRL	R	0x100	This field contains the maximum read length (MRL) (read-only)

2.1.6.7.10.2.2.1.80. i3c_csr[6].I3C_EC.TTI.EXTCAP_HEADER

Table 2105. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.EXTCAP_HEADER fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:8	CAP_LENGTH	R	0x40	Capability Structure Length in DWORDs
7:0	CAP_ID	R	0xC4	Extended Capability ID

2.1.6.7.10.2.2.1.81. i3c_csr[6].I3C_EC.TTI.CONTROL

Table 2106. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.CONTROL fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:13	IBI_RETRY_NUM	RW	0x0	Number of times the Target Device will try to request an IBI before giving up. Values: 0x0 - Device will never retry. 0x1-0x6 - Device will retry this many times. 0x7 - Device will retry indefinitely until the Active Controller sets DISINT bit in the DISEC command.
12	IBI_EN	RW	0x1	Enable the IBI queue servicing. Values: 0x0 - Device will not service the IBI queue. 0x1 - Device will send IBI requests onto the bus, if possible.
11	CRR_EN	RW	0x0	Enable Controller Role Request. Values: 0x0 - Device is allowed to perform Controller Role Request. 0x1 - Device is not allowed to perform Controller Role Request.
10	HJ_EN	RW	0x1	Enable Hot-Join capability. Values: 0x0 - Device is allowed to attempt Hot-Join. 0x1 - Device is not allowed to attempt Hot-Join.

Bits	Field	Access	Reset	Description
9:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.82. i3c_csr[6].I3C_EC.TTI.STATUS

Table 2107. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.STATUS fields

Bits	Field	Access	Reset	Description
31:15	Reserved	-	-	Reserved
14:12	LAST_IBI_STATUS	R	0x0	Status of last IBI. Should be read after IBI_DONE interrupt. Values: 000 - Success: IBI was transmitted and ACK'd by the Active Controller. 001 - FailureNack: Active Controller NACK'd the IBI before any data was sent. The device will retry sending the IBI as long as permitted by the retry counter. 010 - FailurePartialData: Active Controller NACK'd the IBI after data was partially sent. The remaining part of data in the IBI queue is considered corrupted and will be discarded. 011 - FailureRetry: IBI could not be serviced due to reached retry count. 100 - FailureArbitration:: IBI could not be serviced as arbitration was lost during the address header. The device will retry sending the IBI as long as permitted by the retry counter.
11:9	Reserved	-	-	Reserved
8	PROTOCOL_ERROR	R	0x0	Protocol error occurred in the past. This field can only be reset by the Controller, if it issues the GETSTATUS CCC. Values: 0 - no error occurred 1 - generic protocol error occurred in the past. It will be set until reception of the next GETSTATUS command.
7:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.83. i3c_csr[6].I3C_EC.TTI.RESET_CONTROL

Table 2108. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.RESET_CONTROL fields

Bits	Field	Access	Reset	Description
31:7	Reserved	-	-	Reserved
6	IBI_RETRY_CTR_RST	W 1P	0x0	TTI IBI Retry Counter Software Reset
5	IBI_QUEUE_RST	RW	0x0	TTI IBI Queue Buffer Software Reset
4	RX_DATA_RST	RW	0x0	TTI RX Data Queue Buffer Software Reset
3	TX_DATA_RST	RW	0x0	TTI TX Data Queue Buffer Software Reset. Also resets the tti_conv_Nto8 since first dword is immediately loaded into the converter and can't be cleared otherwise.
2	RX_DESC_RST	RW	0x0	TTI RX Descriptor Queue Buffer Software Reset
1	TX_DESC_RST	RW	0x0	TTI TX Descriptor Queue Buffer Software Reset
0	SOFT_RST	RW	0x0	Target Core Software Reset

2.1.6.7.10.2.2.1.84. i3c_csr[6].I3C_EC.TTI.QUEUE_STATUS

Table 2109. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.QUEUE_STATUS fields

Bits	Field	Access	Reset	Description
31:10	Reserved	-	-	Reserved
9	IBI_QUEUE_EMPTY	R	0x1	IBI Queue is empty
8	IBI_QUEUE_FULL	R	0x0	IBI Queue is full
7	TX_DATA_QUEUE_EMPTY	R	0x1	TX Data Queue is empty
6	TX_DATA_QUEUE_FULL	R	0x0	TX Data Queue is full
5	RX_DATA_QUEUE_EMPTY	R	0x1	RX Data Queue is empty
4	RX_DATA_QUEUE_FULL	R	0x0	RX Data Queue is full
3	TX_DESC_QUEUE_EMPTY	R	0x1	TX Descriptor Queue is empty
2	TX_DESC_QUEUE_FULL	R	0x0	TX Descriptor Queue is full
1	RX_DESC_QUEUE_EMPTY	R	0x1	RX Descriptor Queue is empty
0	RX_DESC_QUEUE_FULL	R	0x0	RX Descriptor Queue is full

2.1.6.7.10.2.2.1.85. i3c_csr[6].I3C_EC.TTI.DESC_QUEUE_DEPTH

Table 2110. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.DESC_QUEUE_DEPTH fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:8	TX_DESC_QUEUE_DEPTH	R	0x0	Number of entries in TX Descriptor Queue
7:0	RX_DESC_QUEUE_DEPTH	R	0x0	Number of entries in RX Descriptor Queue

2.1.6.7.10.2.2.1.86. i3c_csr[6].I3C_EC.TTI.DATA_QUEUE_DEPTH

Table 2111. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.DATA_QUEUE_DEPTH fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:8	TX_DATA_QUEUE_DEPTH	R	0x0	Number of DWORD entries in TX Data Queue
7:0	RX_DATA_QUEUE_DEPTH	R	0x0	Number of DWORD entries in RX Data Queue

2.1.6.7.10.2.2.1.87. i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_DEPTH

Table 2112. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_DEPTH fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	IBI_QUEUE_DEPTH	R	0x0	Number of entries in IBI Queue

2.1.6.7.10.2.2.1.88. i3c_csr[6].I3C_EC.TTI.INTERRUPT_STATUS

Table 2113. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.INTERRUPT_STATUS fields

Bits	Field	Access	Reset	Description
31	TRANSFER_ERR_STAT	RW1C	0x0	NOT IMPLEMENTED. Bus error occurred. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
30:27	Reserved	-	-	Reserved
26	TX_DESC_COMPLETE	RW1C	0x0	Read Transaction on the I3C Bus completed. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).

Bits	Field	Access	Reset	Description
25	TRANSFER_ABORT_STAT	RW1C	0x0	NOT IMPLEMENTED. Bus aborted transaction. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
24:21	Reserved	-	-	Reserved
20	PENDING_IBI	R	0x0	At least one IBI is pending. Read-only, hardware-driven level status: it tracks the live IBI-pending condition and cannot be cleared by software (clears automatically when no IBI is pending).
19:16	PENDING_INTERRUPT	RW	0x0	Contains the interrupt number of any pending interrupt, or 0 if no interrupts are pending. This encoding allows for up to 15 numbered interrupts. If more than one interrupt is set, then the highest priority interrupt shall be returned. Read-only, hardware-driven level status: it cannot be cleared by software and updates as pending conditions change.
15:14	Reserved	-	-	Reserved
13	IBI_DONE	RW1C	0x0	IBI is done, check LAST_IBI_STATUS for result. Clear: auto-cleared by hardware when software reads STATUS.LAST_IBI_STATUS; writing 1 to this bit in INTERRUPT_STATUS also clears it.
12	IBI_THLD_STAT	RW1C	0x0	TTI IBI Buffer Threshold Status, the Target Controller shall set this bit to 1 when the number of available entries in the TTI IBI Queue is >= the value defined in TTI_IBI_THLD. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
11	RX_DESC_THLD_STAT	RW1C	0x0	TTI RX Descriptor Buffer Threshold Status, the Target Controller shall set this bit to 1 when the number of available entries in the TTI RX Descriptor Queue is >= the value defined in TTI_RX_DESC_THLD. Clear: auto-cleared by hardware when software reads the RX Descriptor Queue; writing 1 to this bit in INTERRUPT_STATUS also clears it.
10	TX_DESC_THLD_STAT	RW1C	0x0	TTI TX Descriptor Buffer Threshold Status, the Target Controller shall set this bit to 1 when the number of available entries in the TTI TX Descriptor Queue is >= the value defined in TTI_TX_DESC_THLD. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
9	RX_DATA_THLD_STAT	RW1C	0x0	TTI RX Data Buffer Threshold Status, the Target Controller shall set this bit to 1 when the number of entries in the TTI RX Data Queue is >= the value defined in TTI_RX_DATA_THLD. Clear: auto-cleared by hardware when software reads the RX Data Queue; writing 1 to this bit in INTERRUPT_STATUS also clears it.
8	TX_DATA_THLD_STAT	RW1C	0x0	TTI TX Data Buffer Threshold Status, the Target Controller shall set this bit to 1 when the number of available entries in the TTI TX Data Queue is >= the value defined in TTI_TX_DATA_THLD. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
7:4	Reserved	-	-	Reserved
3	TX_DESC_TIMEOUT	RW1C	0x0	NOT IMPLEMENTED. Pending Read was NACK'ed, because the TX_DESC_STAT event was not handled in time. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
2	RX_DESC_TIMEOUT	RW1C	0x0	NOT IMPLEMENTED. Pending Write was NACK'ed, because the RX_DESC_STAT event was not handled in time. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear).
1	TX_DESC_STAT	RW1C	0x0	There is a pending Read Transaction on the I3C Bus. Software should write data to the TX Descriptor Queue and the TX Data Queue. Clear: write 1 to this bit in INTERRUPT_STATUS (no hardware auto-clear — writing to the TX queues does not clear it).
0	RX_DESC_STAT	RW1C	0x0	There is a pending Write Transaction. Software should read data from the RX Descriptor Queue and the RX Data Queue. Clear: auto-cleared by hardware when software reads the RX Descriptor Queue; writing 1 to this bit in INTERRUPT_STATUS also clears it.

2.1.6.7.10.2.2.1.89. i3c_csr[6].I3C_EC.TTI.INTERRUPT_ENABLE

Table 2114. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.INTERRUPT_ENABLE fields

Bits	Field	Access	Reset	Description
31	TRANSFER_ERR_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TRANSFER_ERR_STAT
30:27	Reserved	-	-	Reserved
26	TX_DESC_COMPLETE_EN	RW	0x0	Enables the corresponding interrupt bit TX_DESC_COMPLETE_EN
25	TRANSFER_ABORT_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TRANSFER_ABORT_STAT
24:14	Reserved	-	-	Reserved
13	IBI_DONE_EN	RW	0x0	Enables the corresponding interrupt bit IBI_DONE
12	IBI_THLD_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TTI_IBI_THLD_STAT
11	RX_DESC_THLD_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TTI_RX_DESC_THLD_STAT
10	TX_DESC_THLD_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TTI_TX_DESC_THLD_STAT
9	RX_DATA_THLD_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TTI_RX_DATA_THLD_STAT
8	TX_DATA_THLD_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TTI_TX_DATA_THLD_STAT
7:4	Reserved	-	-	Reserved
3	TX_DESC_TIMEOUT_EN	RW	0x0	Enables the corresponding interrupt bit TX_DESC_TIMEOUT_EN
2	RX_DESC_TIMEOUT_EN	RW	0x0	Enables the corresponding interrupt bit RX_DESC_TIMEOUT_EN
1	TX_DESC_STAT_EN	RW	0x0	Enables the corresponding interrupt bit TX_DESC_STAT_EN
0	RX_DESC_STAT_EN	RW	0x0	Enables the corresponding interrupt bit RX_DESC_STAT_EN

2.1.6.7.10.2.2.1.90. i3c_csr[6].I3C_EC.TTI.INTERRUPT_FORCE

Table 2115. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.INTERRUPT_FORCE fields

Bits	Field	Access	Reset	Description
31	TRANSFER_ERR_STAT_FORCE	RW	0x0	Enables the corresponding interrupt bit TRANSFER_ERR_STAT_FORCE
30:27	Reserved	-	-	Reserved
26	TX_DESC_COMPLETE_FORCE	RW	0x0	Enables the corresponding interrupt bit TX_DESC_COMPLETE_FORCE
25	TRANSFER_ABORT_STAT_FORCE	RW	0x0	Enables the corresponding interrupt bit TRANSFER_ABORT_STAT_FORCE
24:14	Reserved	-	-	Reserved
13	IBI_DONE_FORCE	RW	0x0	Enables the corresponding interrupt bit IBI_DONE_FORCE
12	IBI_THLD_FORCE	RW	0x0	Forces the corresponding interrupt bit TTI_IBI_THLD_STAT to be set to 1
11	RX_DESC_THLD_FORCE	RW	0x0	Forces the corresponding interrupt bit TTI_RX_DESC_THLD_STAT to be set to 1
10	TX_DESC_THLD_FORCE	RW	0x0	Forces the corresponding interrupt bit TTI_TX_DESC_THLD_STAT to be set to 1
9	RX_DATA_THLD_FORCE	RW	0x0	Forces the corresponding interrupt bit TTI_RX_DATA_THLD_STAT to be set to 1
8	TX_DATA_THLD_FORCE	RW	0x0	Forces the corresponding interrupt bit TTI_TX_DATA_THLD_STAT to be set to 1
7:4	Reserved	-	-	Reserved
3	TX_DESC_TIMEOUT_FORCE	RW	0x0	Enables the corresponding interrupt bit TX_DESC_TIMEOUT_FORCE
2	RX_DESC_TIMEOUT_FORCE	RW	0x0	Enables the corresponding interrupt bit RX_DESC_TIMEOUT_FORCE
1	TX_DESC_STAT_FORCE	RW	0x0	Enables the corresponding interrupt bit TX_DESC_STAT_FORCE
0	RX_DESC_STAT_FORCE	RW	0x0	Enables the corresponding interrupt bit RX_DESC_STAT_FORCE

2.1.6.7.10.2.2.1.91. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CTRL

Table 2116. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CTRL fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved
12	RI_INDIRECT_FIFO_OVERFLOW_ERR_DET_EN	RW	0x1	Enable Recovery Interface INDIRECT FIFO overflow error detection and transition to Error state. Set to 0 to disable (overflow is still recorded in interrupt status).
11	RI_RX_FIFO_OVERFLOW_ERR_DET_EN	RW	0x1	Enable Recovery Interface RX FIFO overflow error detection and transition to Error state. Set to 0 to disable (overflow is still recorded in interrupt status).
10	RI_UNSUPPORTED_ERR_DET_EN	RW	0x1	Enable Recovery Interface unsupported command error detection. Set to 0 to disable.
9	RI_READONLY_ERR_DET_EN	RW	0x1	Enable Recovery Interface write-to-read-only error detection. Set to 0 to disable.
8	RI_LENGTH_ERR_DET_EN	RW	0x1	Enable Recovery Interface length error detection. Set to 0 to disable.
7	RI_PEC_ERR_DET_EN	RW	0x1	Enable Recovery Interface PEC/CRC error detection. Set to 0 to disable.
6	FRAMING_ERR_DET_EN	RW	0x1	Enable framing error detection. Set to 0 to disable.
5	TE5_ERR_DET_EN	RW	0x1	Enable TE5 error detection. Set to 0 to disable.
4	TE4_ERR_DET_EN	RW	0x1	Enable TE4 error detection. Set to 0 to disable.
3	TE3_ERR_DET_EN	RW	0x1	Enable TE3 error detection. Set to 0 to disable.
2	TE2_ERR_DET_EN	RW	0x1	Enable TE2 error detection. Set to 0 to disable.
1	TE1_ERR_DET_EN	RW	0x1	Enable TE1 error detection. Set to 0 to disable.
0	TE0_ERR_DET_EN	RW	0x1	Enable TE0 error detection. Set to 0 to disable.

2.1.6.7.10.2.2.1.92. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_STATUS

Table 2117. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:14	Reserved	-	-	Reserved
13	RI_INDIRECT_FIFO_OVERFLOW_ERR_STAT	RW1C	0x0	Recovery Interface INDIRECT FIFO overflow error detected
12	RI_RX_FIFO_OVERFLOW_ERR_STAT	RW1C	0x0	Recovery Interface RX FIFO overflow error detected
11	RI_UNSUPPORTED_ERR_STAT	RW1C	0x0	Recovery Interface unsupported command error detected
10	RI_READONLY_ERR_STAT	RW1C	0x0	Recovery Interface write-to-read-only error detected
9	RI_LENGTH_ERR_STAT	RW1C	0x0	Recovery Interface length mismatch error detected
8	RI_PEC_ERR_STAT	RW1C	0x0	Recovery Interface PEC/CRC error detected
7	FRAMING_ERR_STAT	RW1C	0x0	DA padding error (Bit[0] != 0 in SETDASA/SETNEWDA)
6	TE5_ERR_STAT	RW1C	0x0	TE5: Broadcast/Direct CCC wrong R/W direction
5	TE4_ERR_STAT	RW1C	0x0	TE4: ENTDAA BCR/DCR mismatch
4	TE3_ERR_STAT	RW1C	0x0	TE3: ENTDAA PID mismatch
3	TE2_ERR_STAT	RW1C	0x0	TE2: CCC or Private Write data parity error
2	TE1_ERR_STAT	RW1C	0x0	TE1: CCC command parity error
1	TE0_ERR_STAT	RW1C	0x0	TE0: Invalid reserved address + RnW combination
0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.93. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_ENABLE

Table 2118. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:14	Reserved	-	-	Reserved
13	RI_INDIRECT_FIFO_OVERFLOW_ERR_EN	RW	0x0	Enables the corresponding interrupt bit RI_INDIRECT_FIFO_OVERFLOW_ERR_STAT
12	RI_RX_FIFO_OVERFLOW_ERR_EN	RW	0x0	Enables the corresponding interrupt bit RI_RX_FIFO_OVERFLOW_ERR_STAT
11	RI_UNSUPPORTED_ERR_EN	RW	0x0	Enables the corresponding interrupt bit RI_UNSUPPORTED_ERR_STAT
10	RI_READONLY_ERR_EN	RW	0x0	Enables the corresponding interrupt bit RI_READONLY_ERR_STAT
9	RI_LENGTH_ERR_EN	RW	0x0	Enables the corresponding interrupt bit RI_LENGTH_ERR_STAT
8	RI_PEC_ERR_EN	RW	0x0	Enables the corresponding interrupt bit RI_PEC_ERR_STAT
7	FRAMING_ERR_EN	RW	0x0	Enables the corresponding interrupt bit FRAMING_ERR_STAT
6	TE5_ERR_EN	RW	0x0	Enables the corresponding interrupt bit TE5_ERR_STAT
5	TE4_ERR_EN	RW	0x0	Enables the corresponding interrupt bit TE4_ERR_STAT
4	TE3_ERR_EN	RW	0x0	Enables the corresponding interrupt bit TE3_ERR_STAT
3	TE2_ERR_EN	RW	0x0	Enables the corresponding interrupt bit TE2_ERR_STAT
2	TE1_ERR_EN	RW	0x0	Enables the corresponding interrupt bit TE1_ERR_STAT
1	TE0_ERR_EN	RW	0x0	Enables the corresponding interrupt bit TE0_ERR_STAT
0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.94. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_FORCE

Table 2119. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_INTR_FORCE fields

Bits	Field	Access	Reset	Description
31:14	Reserved	-	-	Reserved
13	RI_INDIRECT_FIFO_OVERFLOW_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit RI_INDIRECT_FIFO_OVERFLOW_ERR_STAT to be set to 1
12	RI_RX_FIFO_OVERFLOW_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit RI_RX_FIFO_OVERFLOW_ERR_STAT to be set to 1
11	RI_UNSUPPORTED_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit RI_UNSUPPORTED_ERR_STAT to be set to 1
10	RI_READONLY_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit RI_READONLY_ERR_STAT to be set to 1
9	RI_LENGTH_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit RI_LENGTH_ERR_STAT to be set to 1
8	RI_PEC_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit RI_PEC_ERR_STAT to be set to 1
7	FRAMING_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit FRAMING_ERR_STAT to be set to 1
6	TE5_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit TE5_ERR_STAT to be set to 1
5	TE4_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit TE4_ERR_STAT to be set to 1
4	TE3_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit TE3_ERR_STAT to be set to 1
3	TE2_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit TE2_ERR_STAT to be set to 1
2	TE1_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit TE1_ERR_STAT to be set to 1
1	TE0_ERR_FORCE	RW	0x0	Forces the corresponding interrupt bit TE0_ERR_STAT to be set to 1
0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.95. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE0

Table 2120. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE0 fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.96. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE1

Table 2121. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE1 fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.97. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE2

Table 2122. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE2 fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.98. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE3

Table 2123. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE3 fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.99. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE4

Table 2124. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE4 fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.100. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE5

Table 2125. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_TE5 fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.101. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_FRAMING

Table 2126. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_FRAMING fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.102. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_PEC

Table 2127. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_PEC fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.103. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_LENGTH

Table 2128. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_LENGTH fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.104. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_READONLY

Table 2129. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_READONLY fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.105. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_UNSUPPORTED

Table 2130. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_UNSUPPORTED fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.106. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW

Table 2131. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_RX_FIFO_OVERFLOW fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.107. i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW

Table 2132. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TARGET_ERR_CNT_RI_INDIRECT_FIFO_OVERFLOW fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	CNT	RW	0x0	Error count (saturates at 255). Write 0 to clear.

2.1.6.7.10.2.2.1.108. i3c_csr[6].I3C_EC.TTI.RX_DESC_QUEUE_PORT

Table 2133. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.RX_DESC_QUEUE_PORT fields

Bits	Field	Access	Reset	Description
31:0	RX_DESC	R	0x0	RX Data

2.1.6.7.10.2.2.1.109. i3c_csr[6].I3C_EC.TTI.RX_DATA_PORT

Table 2134. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.RX_DATA_PORT fields

Bits	Field	Access	Reset	Description
31:0	RX_DATA	R	0x0	RX Data

2.1.6.7.10.2.2.1.110. i3c_csr[6].I3C_EC.TTI.TX_DESC_QUEUE_PORT

Table 2135. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TX_DESC_QUEUE_PORT fields

Bits	Field	Access	Reset	Description
31:0	TX_DESC	W	0x0	TX Data

2.1.6.7.10.2.2.1.111. i3c_csr[6].I3C_EC.TTI.TX_DATA_PORT

Table 2136. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.TX_DATA_PORT fields

Bits	Field	Access	Reset	Description
31:0	TX_DATA	W	0x0	TX Data

2.1.6.7.10.2.2.1.112. i3c_csr[6].I3C_EC.TTI.IBI_PORT

Table 2137. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.IBI_PORT fields

Bits	Field	Access	Reset	Description
31:0	IBI_DATA	W	0x0	IBI Data

2.1.6.7.10.2.2.1.113. i3c_csr[6].I3C_EC.TTI.QUEUE_SIZE

Table 2138. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.QUEUE_SIZE fields

Bits	Field	Access	Reset	Description
31:24	TX_DATA_BUFFER_SIZE	R	0x5	Transmit Data Buffer Size in DWORDs calculated as 2^(N+1)
23:16	RX_DATA_BUFFER_SIZE	R	0x5	Receive Data Buffer Size in DWORDs calculated as 2^(N+1)
15:8	TX_DESC_BUFFER_SIZE	R	0x4	TX Descriptor Buffer Size in DWORDs calculated as 2^(N+1)
7:0	RX_DESC_BUFFER_SIZE	R	0x4	RX Descriptor Buffer Size in DWORDs calculated as 2^(N+1)

2.1.6.7.10.2.2.1.114. i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_SIZE

Table 2139. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.IBI_QUEUE_SIZE fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	IBI_QUEUE_SIZE	R	0x4	IBI Queue Size in DWORDs calculated as 2^(N+1)

2.1.6.7.10.2.2.1.115. i3c_csr[6].I3C_EC.TTI.QUEUE_THLD_CTRL

Table 2140. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.QUEUE_THLD_CTRL fields

Bits	Field	Access	Reset	Description
31:24	IBI_THLD	RW	0x1	Controls the minimum number of IBI Queue entries needed to trigger the IBI threshold interrupt.
23:16	Reserved	-	-	Reserved
15:8	RX_DESC_THLD	RW	0x1	Controls the minimum number of TTI RX Descriptor Queue entries needed to trigger the TTI RX Descriptor interrupt.
7:0	TX_DESC_THLD	RW	0x1	Controls the minimum number of empty TTI TX Descriptor Queue entries needed to trigger the TTI TX Descriptor interrupt.

2.1.6.7.10.2.2.1.116. i3c_csr[6].I3C_EC.TTI.DATA_BUFFER_THLD_CTRL

Table 2141. oca_i3c_wrap.i3c_csr[6].I3C_EC.TTI.DATA_BUFFER_THLD_CTRL fields

Bits	Field	Access	Reset	Description
31:27	Reserved	-	-	Reserved
26:24	RX_START_THLD	RW	0x1	Minimum number of TTI RX Data queue entries of data received, in DWORDs, that will trigger the TTI RX Data interrupt. Interrupt triggers when 2^(N+1) RX Buffer DWORD entries are received during the Read transfer.
23:19	Reserved	-	-	Reserved
18:16	TX_START_THLD	RW	0x1	Minimum number of available TTI TX Data queue entries, in DWORDs, that will trigger the TTI TX Data interrupt. Interrupt triggers when 2^(N+1) TX Buffer DWORD entries are available.
15:11	Reserved	-	-	Reserved
10:8	RX_DATA_THLD	RW	0x1	Minimum number of TTI RX Data queue entries of data received, in DWORDs, that will trigger the TTI RX Data interrupt. Interrupt triggers when 2^(N+1) RX Buffer DWORD entries are received during the Read transfer.
7:3	Reserved	-	-	Reserved
2:0	TX_DATA_THLD	RW	0x1	Minimum number of available TTI TX Data queue entries, in DWORDs, that will trigger the TTI TX Data interrupt. Interrupt triggers when 2^(N+1) TX Buffer DWORD entries are available.

2.1.6.7.10.2.2.1.117. i3c_csr[6].I3C_EC.SoCMgmtIf.EXTCAP_HEADER

Table 2142. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.EXTCAP_HEADER fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:8	CAP_LENGTH	R	0x1A	Capability Structure Length in DWORDs
7:0	CAP_ID	R	0xC1	Extended Capability ID

2.1.6.7.10.2.2.1.118. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_CONTROL

Table 2143. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_CONTROL fields

Bits	Field	Access	Reset	Description
31:0	PLACEHOLDER	RW	0x0	-

2.1.6.7.10.2.2.1.119. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_STATUS

Table 2144. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_STATUS fields

Bits	Field	Access	Reset	Description
31:0	PLACEHOLDER	RW	0x0	-

2.1.6.7.10.2.2.1.120. i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_CFG

Table 2145. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_CFG fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1	REC_PAYLOAD_DONE	RW	0x0	Inform Recovery Handler that payload transfer is finished.
0	REC_INTF_BYPASS	RW	0x0	Choose Recovery Interface access type: • 0 - I3C Core • 1 - direct AXI

2.1.6.7.10.2.2.1.121. i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_REG_W1C_ACCESS

Table 2146. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.REC_INTF_REG_W1C_ACCESS fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	INDIRECT_FIFO_CTRL_RESET	RW	0x0	Write to 'Indirect memory configuration - reset' register, mocking a hardware access (bypassing 'write 1 to clear' register property).
15:8	RECOVERY_CTRL_ACTIVATE_REC_IMG	RW	0x0	Write to 'Recovery Control - Activate Recovery Image' register, mocking a hardware access (bypassing 'write 1 to clear' register property).
7:0	DEVICE_RESET_CTRL	RW	0x0	Write to 'Reset control - Device Reset Control' register, mocking a hardware access (bypassing 'write 1 to clear' register property).

2.1.6.7.10.2.2.1.122. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_2

Table 2147. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_2 fields

Bits	Field	Access	Reset	Description
31:0	PLACEHOLDER	RW	0x0	-

2.1.6.7.10.2.2.1.123. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_3

Table 2148. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_RSVD_3 fields

Bits	Field	Access	Reset	Description
31:0	PLACEHOLDER	RW	0x0	-

2.1.6.7.10.2.2.1.124. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_CONF

Table 2149. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_CONF fields

Bits	Field	Access	Reset	Description
31:24	PAD_TYPE	RW	0x1	Select pad type 0 - Bidirectional 1 - Open-drain 2 - Input-only 3 - Analog input
23:8	Reserved	-	-	Reserved
7	VIRTUAL_OD_EN	RW	0x0	Enable virtual open drain: 0 - disabled 1 - enabled
6	OD_EN	RW	0x0	Enable Open-Drain: 0 - disabled 1 - enabled
5	IO_INVERSION	RW	0x0	Invert I/O signal: 0 - signals pass-through 1 - signals are inverted
4	PULL_EN	RW	0x0	Enable Pull: 0 - disabled 1 - enabled
3	PULL_DIR	RW	0x0	Direction of the pull: 0 - Pull down 1 - Pull up
2	KEEPER_EN	RW	0x0	Enable the High-Keeper: 0 - disabled 1 - enabled
1	SCHMITT_EN	RW	0x0	Enable the Schmitt Trigger: 0 - disabled 1 - enabled
0	INPUT_ENABLE	RW	0x1	Enable input: 0 - enabled 1 - disabled

2.1.6.7.10.2.2.1.125. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_ATTR

Table 2150. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_PAD_ATTR fields

Bits	Field	Access	Reset	Description
31:24	DRIVE_STRENGTH	RW	0xF	Select driver strength '0 - lowest '1 - highest
23:16	Reserved	-	-	Reserved
15:8	DRIVE_SLEW_RATE	RW	0xF	Select driver slew rate '0 - lowest '1 - highest
7:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.126. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_2

Table 2151. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_2 fields

Bits	Field	Access	Reset	Description
31:0	PLACEHOLDER	RW	0x0	Reserved for: I/O ring and pad configuration

2.1.6.7.10.2.2.1.127. i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_3

Table 2152. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.SOC_MGMT_FEATURE_3 fields

Bits	Field	Access	Reset	Description
31:0	PLACEHOLDER	RW	0x0	Reserved for: I/O ring and pad configuration

2.1.6.7.10.2.2.1.128. i3c_csr[6].I3C_EC.SoCMgmtIf.T_R_REG

Table 2153. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_R_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_R	RW	0x0	Rise time of both SDA and SCL in clock units

2.1.6.7.10.2.2.1.129. i3c_csr[6].I3C_EC.SoCMgmtIf.T_F_REG

Table 2154. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_F_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_F	RW	0x0	Fall time of both SDA and SCL in clock units

2.1.6.7.10.2.2.1.130. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_REG

Table 2155. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_SU_DAT	RW	0x0	Data setup time in clock units

2.1.6.7.10.2.2.1.131. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_I2C_REG

Table 2156. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_DAT_I2C_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_SU_DAT_I2C	RW	0x0	Data setup time in I2C mode in clock units

2.1.6.7.10.2.2.1.132. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_DAT_REG

Table 2157. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_DAT_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HD_DAT	RW	0x0	Data hold time in clock units

2.1.6.7.10.2.2.1.133. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_REG

Table 2158. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HIGH	RW	0x0	-

2.1.6.7.10.2.2.1.134. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_OD_REG

Table 2159. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_OD_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HIGH_OD	RW	0x0	-

2.1.6.7.10.2.2.1.135. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_INIT_OD_REG

Table 2160. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_INIT_OD_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HIGH_INIT_OD	RW	0x0	-

2.1.6.7.10.2.2.1.136. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_I2C_REG

Table 2161. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HIGH_I2C_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HIGH_I2C	RW	0x0	-

2.1.6.7.10.2.2.1.137. i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_REG

Table 2162. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_LOW	RW	0x0	Low period of the SCL in clock units

2.1.6.7.10.2.2.1.138. i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_OD_REG

Table 2163. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_OD_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_LOW_OD	RW	0x0	Low period of the SCL in Open-Drain mode in clock units

2.1.6.7.10.2.2.1.139. i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_I2C_REG

Table 2164. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_LOW_I2C_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_LOW_I2C	RW	0x0	Low period of the SCL in I2C mode in clock units

2.1.6.7.10.2.2.1.140. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_REG

Table 2165. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HD_STA	RW	0x0	Hold time for START in clock units

2.1.6.7.10.2.2.1.141. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_I2C_REG

Table 2166. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_STA_I2C_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HD_STA_I2C	RW	0x0	Hold time for START in I2C mode in clock units

2.1.6.7.10.2.2.1.142. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_RSTA_REG

Table 2167. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HD_RSTA_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HD_RSTA	RW	0x0	Hold time for repeated START in clock units

2.1.6.7.10.2.2.1.143. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_REG

Table 2168. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_SU_STA	RW	0x0	Setup time for repeated START in clock units

2.1.6.7.10.2.2.1.144. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_I2C_REG

Table 2169. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STA_I2C_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_SU_STA_I2C	RW	0x0	Setup time for repeated START in I2C mode in clock units

2.1.6.7.10.2.2.1.145. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_REG

Table 2170. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_SU_STO	RW	0x0	Setup time for STOP in clock units

2.1.6.7.10.2.2.1.146. i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_I2C_REG

Table 2171. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_SU_STO_I2C_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_SU_STO_I2C	RW	0x0	Setup time for STOP in in I2C mode clock units

2.1.6.7.10.2.2.1.147. i3c_csr[6].I3C_EC.SoCMgmtIf.T_DS_OD_REG

Table 2172. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_DS_OD_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_DS_OD	RW	0x0	Setup time for SDA during START in clock units

2.1.6.7.10.2.2.1.148. i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_REG

Table 2173. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_REG fields

Bits	Field	Access	Reset	Description
31:0	T_FREE	RW	0xC	Bus Free Time Between a STOP and a START

2.1.6.7.10.2.2.1.149. i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_I2C_REG

Table 2174. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_FREE_I2C_REG fields

Bits	Field	Access	Reset	Description
31:0	T_FREE_I2C	RW	0xC	Bus Free Time Between a STOP and a START in I2C mode

2.1.6.7.10.2.2.1.150. i3c_csr[6].I3C_EC.SoCMgmtIf.T_AVAL_REG

Table 2175. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_AVAL_REG fields

Bits	Field	Access	Reset	Description
31:0	T_AVAL	RW	0x12C	-

2.1.6.7.10.2.2.1.151. i3c_csr[6].I3C_EC.SoCMgmtIf.T_IDLE_REG

Table 2176. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_IDLE_REG fields

Bits	Field	Access	Reset	Description
31:0	T_IDLE	RW	0xEA60	Time in clock cycles from STOP detection until Bus Idle Condition (tIDLE). Configure based on System Clock

2.1.6.7.10.2.2.1.152. i3c_csr[6].I3C_EC.SoCMgmtIf.HDR_TIMEOUT_EN_REG

Table 2177. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.HDR_TIMEOUT_EN_REG fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	HDR_TIMEOUT_EN	RW	0x0	Enable bit for the optional 60us HDR error recovery timer (I3C spec 5.1.10.1.9). When enabled, the Target can recover from TE0/TE1 errors if both SCL and SDA stay High for a period exceeding the configured threshold. Disabled on reset.

2.1.6.7.10.2.2.1.153. i3c_csr[6].I3C_EC.SoCMgmtIf.T_HDR_TIMEOUT_REG

Table 2178. oca_i3c_wrap.i3c_csr[6].I3C_EC.SoCMgmtIf.T_HDR_TIMEOUT_REG fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	T_HDR_TIMEOUT	RW	0xEA60	Timer threshold in clock cycles for the optional HDR error recovery (I3C spec 5.1.10.1.9). If both SCL and SDA stay High for this many clock cycles during a TE0/TE1 error-induced HDR mode, the Target exits HDR mode and returns to Idle. Configure based on System Clock to achieve 60us.

2.1.6.7.10.2.2.1.154. i3c_csr[6].I3C_EC.CtrlCfg.EXTCAP_HEADER

Table 2179. oca_i3c_wrap.i3c_csr[6].I3C_EC.CtrlCfg.EXTCAP_HEADER fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:8	CAP_LENGTH	R	0x2	Capability Structure Length in DWORDs
7:0	CAP_ID	R	0x2	Extended Capability ID

2.1.6.7.10.2.2.1.155. i3c_csr[6].I3C_EC.CtrlCfg.CONTROLLER_CONFIG

Table 2180. oca_i3c_wrap.i3c_csr[6].I3C_EC.CtrlCfg.CONTROLLER_CONFIG fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5:4	OPERATION_MODE	R	0x1	-
3:0	Reserved	-	-	Reserved

2.1.6.7.10.2.2.1.156. i3c_csr[6].I3C_EC.TERMINATION_EXTCAP_HEADER

Table 2181. oca_i3c_wrap.i3c_csr[6].I3C_EC.TERMINATION_EXTCAP_HEADER fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
23:8	CAP_LENGTH	R	0x1	Capability Structure Length in DWORDs
7:0	CAP_ID	R	0x0	Extended Capability ID

2.1.6.7.10.2.2.1.157. i3c_csr[6].DAT.DAT_MEMORY[128]

Table 2182. oca_i3c_wrap.i3c_csr[6].DAT.DAT_MEMORY[128] fields

Bits	Field	Access	Reset	Description
63:59	Reserved	-	-	Reserved
58:51	AUTOCMD_HDR_CODE	RW	-	Device auto command in HDR mode
50:48	AUTOCMD_MODE	RW	-	Auto command mode and speed
47:40	AUTOCMD_VALUE	RW	-	IBI value that triggers auto command
39:32	AUTOCMD_MASK	RW	-	IBI mask
31	DEVICE	RW	-	Device type: 0 - I3C device, 1 - I2C device.
30:29	DEV_NACK_RETRY_CNT	RW	-	Number of retries before giving up
28:26	RING_ID	RW	-	Send IBI read to ring bundle
25:24	Reserved	-	-	Reserved
23:16	DYNAMIC_ADDRESS	RW	-	I3C dynamic address
15	TS	RW	-	Enable/disable IBI timestamp
14	CRR_REJECT	RW	-	Reject device's request for controller change
13	IBI_REJECT	RW	-	Reject device's request for IBI
12	IBI_PAYLOAD	RW	-	Device's IBI contains data payload
11:7	Reserved	-	-	Reserved
6:0	STATIC_ADDRESS	RW	-	I3C/I2C static device address

2.1.6.7.10.2.2.1.158. i3c_csr[6].DCT.DCT_MEMORY[128]

Table 2183. oca_i3c_wrap.i3c_csr[6].DCT.DCT_MEMORY[128] fields

Bits	Field	Access	Reset	Description
127:104	Reserved	-	-	Reserved
103:96	DYNAMIC_ADDRESS	R	-	Device I3C Dynamic Address after ENTDAA
95:80	Reserved	-	-	Reserved
79:72	BCR	R	-	Value of the I3C device's Bus Characteristics Register
71:64	DCR	R	-	Value of the I3C device's Device Characteristics Register
63:48	Reserved	-	-	Reserved
47:32	PID_LO	R	-	Device Provisional ID Low
31:0	PID_HI	R	-	Device Provisional ID High

2.1.6.7.11. AVSBus Controller

2.1.6.7.11.1. Overview

The AVSBus Controller is a hardware IP that implements the AVSBus 1.3.1 specification for adaptive voltage scaling communication. It acts as a controller (master) that communicates with a single AVS target device (slave) to manage voltage rails, monitor power conditions, and perform real-time voltage adjustments for optimal performance and

energy efficiency. This version supports 32-bit frame-based communication without multi-target addressing.

2.1.6.7.11.2. Description and Features

- **Single-Target Support**: Communicates with a single AVS target device through a two-wire protocol interface
- **AXI4-Lite Register Interface**: A 32-bit AXI4-Lite port, bridged internally to the APB4 register file
- **Command FIFO**: 8-deep command queue, crossing from the register clock domain to the AVS clock domain
- **Readback FIFO**: 8-deep response buffer with automatic hardware retry on a failed acknowledgment or a bad CRC
- **Flexible Clock Configuration**: AVS clock generated from either the register clock or a reference clock, with a programmable divider and duty cycle
- **Maskable Interrupts**: Nine sources covering FIFO overruns, retry exhaustion, an unresponsive target and target-signalled interrupts
- **Slave Resync Operation**: Automatic periodic resynchronization at a configurable interval, or forced by software
- **CRC-3 Protection**: Hardware generation on every command and checking on every response

2.1.6.7.11.3. Architecture

The AVSBus Controller implements an Adaptive Voltage Scaling Bus (AVSBus) 1.3.1 controller for dynamic voltage and frequency scaling (DVFS) in single-target systems, communicating with one AVS target device over a two-wire protocol interface.

The design is a register file, a pair of asynchronous FIFOs that carry commands and responses between the register and AVS clock domains, a protocol FSM that serializes and deserializes subframes, a CRC-3 engine shared between transmit and receive, and the AVS clock generation logic.

Figure 72 shows the FIFO, protocol-engine, and clock-generation paths. The two clock-domain boxes hold the logic clocked by `clk_reg_i` and by the generated `avs_clk`; the FIFOs and synchronizers that straddle the gap between them carry every crossing. The clock generation is drawn in full in Figure 74, and the protocol FSM in Figure 73.




Figure 72. AVSBus controller block diagram

2.1.6.7.11.3.1. AVS Protocol Engine

Software queues commands by writing AVS_CMD, which pushes a 32-bit word into the command FIFO. The protocol FSM pops each command, prepends the fixed preamble, appends a calculated CRC-3, and shifts the resulting 32-bit subframe out on avs_mdata_o. The target's reply arrives one subframe later: it is shifted in from avs_sdata_i during the 32 cycles that carry the next command, checked for a valid frame bit and a good CRC, and pushed into the readback FIFO.

Retries are automatic. A slave acknowledgment of 1 (resource unavailable) or 2 (bad CRC) causes the master to resend the command, up to AVS_CFG_0.MAX_RETRIES times after the original attempt. If the last retry also fails, the failing response is delivered to software and MAX_RETRIES_ATTEMPTED_INT is raised. Setting MAX_RETRIES to 0 suppresses both the retries and that interrupt; the failing response is delivered to software instead. A reply whose frame valid bit is set means the target did not respond at all and raises SLAVE_UNRESPONSIVE_INT. There is no separate programmable response timeout.

The master also issues periodic slave resync operations. The FSM stays in AVS_SLAVE_RESYNC for 35 avs_clk cycles, while its resync counter runs from 0 to 34, and holds avs_mdata_o high throughout. avs_mdata_o is also high in the cycles around that state, through idle or the receive half of a retry beforehand and through the launch cycle afterwards, so the high period on the pin is longer than the resync state itself.

AVS_CFG_0.RESYNC_INTERVAL is the number of clk_reg_i cycles the register domain counts, from when it observes the end of the previous resync, before it requests the next one. AVS_CFG_1.FORCE_SLAVE_RESYNC_OPERATION requests one immediately. Either request is registered in the clk_reg_i domain and crosses into the AVS domain through a three-stage avs_clk synchronizer. The master stops launching new commands once it sees the request, and starts the resync from idle after the frame in flight and its reply complete.

2.1.6.7.11.3.2. Clock Generation and Management

Table 2184 identifies the register, reference, and generated AVS clocks.

Table 2184. AVSBus clock sources

Clock Source	Description
clk_reg_i	Register interface clock, synchronous with register access
clk_ref_i	Reference clock, independent of AVS bus timing
Selection	Software-configurable via AVS_CFG_1.AVS_CLOCK_SELECT

The selected source passes through an anti-glitch mux and then a programmable divider, whose ratio and duty cycle are both 8-bit values in AVS_CFG_1. Out of reset the controller runs on clk_ref_i divided by 4 at a 50% duty cycle. Both divider fields reset to 0, which is a sentinel: the divider keeps its hardware defaults until software writes a non-zero value.

Changing the clock configuration is not glitch-free on its own. Set AVS_CFG_1.TURN_OFF_ALL_PREMUX_CLOCKS to gate both source clocks before changing the source selection or the divider settings, then clear it afterwards.

Power is saved at two levels: AVS_CFG_1.STOP_AVS_CLOCK_ON_IDLE gates the AVS clock whenever the bus is idle, and TURN_OFF_ALL_PREMUX_CLOCKS gates the clocks entering the mux. Restarting a gated AVS clock always begins with a slave resync.

2.1.6.7.11.3.3. CRC Verification Engine

The avsbus_crc3 module computes a 3-bit CRC combinationally over a 32-bit subframe. Two instances are used. The generate instance is fed the outgoing master subframe with its CRC field zeroed, and its output becomes the three bits shifted out last. The check instance is fed the received slave subframe intact, including the CRC the target sent, and reports a good check when the result is zero. A failed check prevents the subframe from updating AVS_LATEST_SLAVE_SUBFRAME and AVS_SLAVE_STATUS, and the retry logic resends the command.

2.1.6.7.11.3.4. Command and Response FIFO System

Table 2185 compares the command and readback FIFO roles and operation.

Table 2185. AVSBus command and readback FIFOs

FIFO	Command FIFO	Readback FIFO
Depth	COMMAND_FIFO_DEPTH, 8 entries by default	READBACK_FIFO_DEPTH, 8 entries by default
Direction	Register clock domain to AVS clock domain	AVS clock domain to register clock domain
Occupancy	AVS_FIFOS_STATUS.CMD_FIFO_*	AVS_FIFOS_STATUS.READBACK_FIFO_*
Overrun behaviour	A write to AVS_CMD when full is dropped, completes with an error response and raises CMD_FIFO_OVERFLOW_INT	A response received when full is dropped and raises READBACK_OVERFLOW_INT

Both are instances of avsbus_async_fifo, which requires a power-of-two depth. Pointers cross between the two clock domains as Gray codes through three-stage synchronizers.

While the readback FIFO is full the master launches no further commands, but replies to commands already launched are still pushed as they arrive. A reply that meets a full FIFO is dropped and raises READBACK_OVERFLOW_INT, so a software reader that stops draining AVS_READBACK stalls new commands and can lose the responses to commands already on the bus.

2.1.6.7.11.3.5. Reset and Initialization

The controller takes three resets. `rst_clk_div_ni` resets the programmable clock divider, `rst_reg_ni` resets the register file and the protocol logic, and `rst_ref_ni` resets the `clk_ref_i` leg of the anti-glitch clock mux.

`rst_clk_div_ni` must be deasserted before `rst_reg_ni`. The divider has to be producing a clock before the logic it feeds leaves reset, otherwise the AVS clock domain never starts.

Because the divider defaults to divide-by-4 on `clk_ref_i` and the protocol FSM starts as soon as reset is released, the controller begins issuing slave resync operations without any software configuration. Configuration is therefore a matter of adjusting defaults rather than enabling the block. The AVSBus configuration sequence is in the Programmer's Guide.

2.1.6.7.11.3.6. Data Flow and Control Path

2.1.6.7.11.3.6.1. Command Path

1. Software writes `AVS_CMD`; the 32-bit word enters the command FIFO. If the FIFO is full, the write is dropped and completes with an error response.
2. The protocol FSM pops a command, builds the master subframe as preamble, `AVS_CMD[29:3]` and CRC-3, and shifts it out on `avs_mdata_o`.
3. The target's reply shifts in on `avs_sdata_i` during the following subframe.
4. A reply that is valid and passes CRC updates `AVS_SLAVE_STATUS` and `AVS_LATEST_SLAVE_SUBFRAME` and is pushed into the readback FIFO; otherwise the retry logic resends the command.
5. Software reads `AVS_READBACK`, which pops the readback FIFO.

A dropped write also raises `CMD_FIFO_OVERFLOW_INT`. `AVS_NORMAL_STATUS.CMD_FIFO_FULL` and `AVS_FIFOS_STATUS.CMD_FIFO_VACANT_SLOTS` report the command FIFO's space.

2.1.6.7.11.3.6.2. Response Inspection

`AVS_READBACK` is the normal path and advances the FIFO on every read that finds it non-empty; a read of an empty FIFO returns 0 with an error response. `AVS_DEBUG_READBACK` mirrors the top of the FIFO without advancing it, and reads 0xFFFFFFFF when the FIFO is empty. `AVS_LATEST_SLAVE_SUBFRAME` holds the most recent valid subframe regardless of FIFO state, which is what to read when the question is what the target is doing now rather than what it said several commands ago.

2.1.6.7.11.3.7. Clock Domain Architecture

Two domains carry functional logic. The register domain, clocked by `clk_reg_i`, holds the AXI4-Lite bridge, the register file, the command FIFO write side, the readback FIFO read side and interrupt generation. The AVS domain, clocked by the generated `avs_clk`, holds the protocol FSM, the shift registers and the CRC engines. `avs_clock_o` is `avs_clk` after the idle clock gate, so the FSM keeps running while `STOP_AVS_CLOCK_ON_IDLE` holds the pin clock stopped.

FIFO pointers cross between the domains as Gray codes. Individual control and status bits cross through `prim_sync3` three-stage synchronizers, and pulses through `prim_sync3_pulse`. The reset synchronizers are six stages deep and take their scan bypass from `scan_rst_ni`.

2.1.6.7.11.3.8. Protocol State Machine

`cur_state_debug_o` exposes the FSM state as a 17-bit one-hot vector, resynchronized to `clk_reg_i`. The states, in bit order

from 0, are (Table 2186).

Table 2186. AVSBus protocol state encodings

Bit	State	Meaning
0	AVS_RESET	Out of reset, before the first resync
1	AVS_SLAVE_RESYNC	Holding `avs_mdata_o` high for 35 cycles while the resync counter runs from 0 to 34
2	AVS_LAUNCH_FRAME_POST_RESYNC	First command launch after a resync
3	AVS_IDLE	No command queued; the AVS clock may be gated
4, 5	AVS_SHIFT_1ST_SUBFRAME, AVS_END_1ST_SUBFRAME	First subframe after idle or resync, launching a command
6, 7	AVS_SHIFT_MID_SUBFRAME, AVS_END_MID_SUBFRAME	Transmitting one command while receiving the reply to the previous one
8, 9	AVS_SHIFT_LAST_SUBFRAME, AVS_END_LAST_SUBFRAME	Final subframe, draining the last reply with no new command to send
10-15	AVS_RETRY_*	The same shift and end pairs used while retrying a failed command, split into transmit-and-receive, transmit-only and receive-only variants
16	AVS_PROCESS_PREVIOUS_SDATA	Evaluating a received subframe

Command transmission and response reception overlap: the reply to a command arrives during the subframe that carries the next command, which is why the mid-subframe states do both at once.

Figure 73 shows the transitions between these states, grouping the 17 states into 11 boxes. Each subframe box stands for a SHIFT state, which holds for the 32 bits of a subframe, and the END state that follows it, where the transition is decided; the three retry boxes pair the six `AVS_RETRY_*` states the same way. The figure omits the self-loops of states that wait: idle, the resync and each SHIFT state. Resync done means that the resync counter has reached 34. RDY means that a command is waiting, the readback FIFO has room and no resync is due. Stop on idle is `AVS_CFG_1.STOP_AVS_CLOCK_ON_IDLE`: with it set, a command waiting in idle restarts the AVS clock through a resync instead of launching directly. A retry transition is taken when the received subframe has a bad CRC, a resource-unavailable or bad-CRC acknowledgment, or no response, and `MAX_RETRIES` is above zero; with `MAX_RETRIES` at zero the RDY and not-RDY transitions apply instead. A reply that arrives during a retry of the preceding command is held and processed after the retries finish. Every retry sequence ends with a slave resync.




Figure 73. AVSBus protocol state machine

2.1.6.7.11.3.9. Error Handling and Diagnostics

Table 2187 describes the controller response to each error condition.

Table 2187. AVSBus error handling

Condition	Handling
Bad CRC from the target	Automatic retry, up to `AVS_CFG_0.MAX_RETRIES`
Resource unavailable acknowledgment	Automatic retry, up to `AVS_CFG_0.MAX_RETRIES`
Bad data, data type or selector acknowledgment	No retry; the response is delivered to software
Retry budget exhausted	`MAX_RETRIES_ATTEMPTED_INT` once the last of `MAX_RETRIES` retries also fails, and the failing response is delivered to software; not raised while `MAX_RETRIES` is 0. `AVS_NORMAL_STATUS.TOTAL_RETRIES` counts every retry attempted
Target not responding	`SLAVE_UNRESPONSIVE_INT`
Command FIFO overrun	Write dropped with an error response, `CMD_FIFO_OVERFLOW_INT`
Readback FIFO overrun	Response dropped, `READBACK_OVERFLOW_INT`
Read of an empty readback FIFO	Returns 0 with an error response, `READBACK_UNDERFLOW_INT`

For diagnosis, AVS_NORMAL_STATUS reports bus idle, resync, retry-in-progress and FIFO states; AVS_FIFOS_STATUS reports occupied and vacant slots in both FIFOs; AVS_SLAVE_STATUS and AVS_LATEST_SLAVE_SUBFRAME report the target's most recent acknowledgment and status response; and cur_state_debug_o exposes the FSM state to the surrounding system.

2.1.6.7.11.4. Interface

The AVSBus Controller presents an AXI4-Lite register interface, a two-wire AVSBus protocol interface, and clock, reset, interrupt and DFT interfaces for system integration. The register file itself is APB4; the controller contains an axi_lite_to_apb bridge, so APB4 is not exposed at the module boundary.

The parameters and ports of avsbus_controller are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.6.7.11.4.1. AVSBus Frame Format

Both subframes are 32 bits: 29 bits of payload followed by a 3-bit CRC. The master subframe carries a fixed 2'b01 preamble in its two most significant bits; the remaining fields occupy the same bit positions as the AVS_CMD register, so software writes a command in wire order.

Table 2188 defines the fields transmitted in a master subframe.

Table 2188. AVSBus Master Subframe

Field Name	Bit Range	Width	Description
Preamble	[31:30]	2	Fixed 2'b01, inserted by hardware
Command Type	[29:28]	2	AVS_CMD.R_OR_W: 0 = commit write, 1 = hold write, 2 = reserved, 3 = read
Command Group	[27]	1	AVS_CMD.CMD_GRP: 0 = standard, 1 = manufacturer-specific
Command Code	[26:23]	4	AVS_CMD.CMD_CODE, see Table 2189
Rail Select	[22:19]	4	AVS_CMD.RAIL_SEL: rail index, 0xF = broadcast
Command Data	[18:3]	16	AVS_CMD.CMD_DATA; 0xFFFF for read commands
CRC-3	[2:0]	3	Calculated by hardware over bits [31:3]

Table 2189 lists the command-group-zero data types, resolutions, and access modes.

Table 2189. AVSBus Command Codes (Command Group 0)

Code	Data Type	Resolution	Description
0x0	Target Rail Voltage	1 mV	16-bit unsigned, read or write
0x1	Vout Transition Rate	1 mV/us	MSByte rise rate, LSByte fall rate
0x2	Rail Current	10 mA	16-bit unsigned, read only
0x3	Temperature	0.1 degC	16-bit signed, read only
0x4	Force Voltage Reset	N/A	Requires a command data field of 0x0000
0x5	Power Mode	N/A	3 bits, LSB aligned: 0x0 maximum efficiency, 0x3 maximum power, 0x4-0x7 manufacturer-specific
0xE	AVSBus Status	N/A	16 bits, encoded per the AVS specification
0xF	AVSBus Version	N/A	4 bits, LSB aligned, read only

With command group 1 the command code is manufacturer-specific and Table 2190 above does not apply.

Table 2190. AVSBus Slave Subframe

Field Name	Bit Range	Width	Description
Slave Acknowledgment	[31:30]	2	0 = action performed, 1 = good CRC but resource unavailable, 2 = bad CRC received, 3 = good CRC but bad data, data type or selector. Codes 1 and 2 trigger a hardware retry
Frame Valid	[29]	1	0 in a valid frame. A 1 means the target did not respond and raises SLAVE_UNRESPONSIVE_INT
Status Response	[28:24]	5	Per the AVS specification: bit 4 VDone, bit 3 StatusAlert, bit 2 AVS_Control, bits 1-0 manufacturer-specific
Response Data	[23:8]	16	Read data; 0xFFFF when the master issued a write
Reserved	[7:3]	5	Reserved
CRC-3	[2:0]	3	CRC received from the target, checked by hardware

A received subframe reaches software by two paths. It is pushed into the readback FIFO and read out of AVS_READBACK, which pops the FIFO, or inspected without popping through AVS_DEBUG_READBACK. Independently of the FIFO, a subframe whose frame valid bit is 0 and whose CRC checks also latches into AVS_LATEST_SLAVE_SUBFRAME and AVS_SLAVE_STATUS, so the current target status is visible without waiting for the FIFO to drain.

2.1.6.7.11.4.2. Clock Architecture

The AVS clock is derived from one of two sources, optionally divided, and optionally gated while the bus is idle.

AVS_CFG_1.AVS_CLOCK_SELECT[1:0] selects both the source and whether the divider is used: bit 1 picks the source (0 = clk_reg_i, 1 = clk_ref_i) and bit 0 picks the divider (0 = bypass, 1 = divided). The reset value is 2'b11, so the controller comes up on a divided clk_ref_i.

Figure 74 shows the clock path. Each source passes a clock gate that TURN_OFF_ALL_PREMUX_CLOCKS closes, then the anti-glitch mux u_refclk_apbclk_mux selects one of them, choosing clk_ref_i while in reset. The test mux substitutes clk_test_i in test mode. Inside u_clk_div, the glitch-free post-divider mux selects either the undivided clock or the divider output. The result, avs_clk, clocks the AVS domain and reaches avs_clock_o through u_avs_bus_clkgate, which the protocol FSM closes while the bus is idle if STOP_AVS_CLOCK_ON_IDLE is set. Each mux passes its input 0 when its select is 0. Table 2191 lists the four settings.




Figure 74. AVSBus clock selection

Table 2191. AVS_CLOCK_SELECT settings

AVS_CLOCK_SELECT	Source mux	Post-divider mux	AVS clock
2'b00	0	0, bypass	clk_reg_i
2'b01	0	1, divided	clk_reg_i divided by CLK_DIVIDER_VALUE
2'b10	1	0, bypass	clk_ref_i
2'b11 (reset)	1	1, divided	clk_ref_i divided by CLK_DIVIDER_VALUE, by 4 until software writes a non-zero value

Table 2192 defines the source-selection and divider configuration fields.

Table 2192. AVS Clock Configuration Fields

Field	Reset	Description
AVS_CFG_1.AVS_CLOCK_SELECT[1:0]	0x3	Clock source and divider bypass
AVS_CFG_1.CLK_DIVIDER_VALUE[23:16]	0x0	Division ratio. A value below 2 is treated as 2. The reset value 0 is a sentinel that leaves the divider at its hardware default of 4
AVS_CFG_1.CLK_DIVIDER_DUTY_CYCLE_NUMERATOR[31:24]	0x0	High-pulse fraction in 1/256 units, so 128 is 50%. A 50% duty cycle is only reachable with an even divider. The reset value 0 is a sentinel that leaves the numerator at its hardware default of 0x80
AVS_CFG_1.STOP_AVS_CLOCK_ON_IDLE[8]	0x0	Gate the AVS clock while the bus is idle. The master issues a slave resync whenever the clock restarts
AVS_CFG_1.TURN_OFF_ALL_PREMUX_CLOCKS[10]	0x0	Gate both clocks feeding the source mux

Gate the clocks with TURN_OFF_ALL_PREMUX_CLOCKS before changing AVS_CLOCK_SELECT, CLK_DIVIDER_VALUE or CLK_DIVIDER_DUTY_CYCLE_NUMERATOR, then release the gate afterwards.

While test_en_i is high the source and divider-bypass muxes ignore AVS_CLOCK_SELECT, and clk_test_i drives the AVS clock directly.

2.1.6.7.11.4.3. Reset Architecture

Table 2193 identifies the logic reset by each AVSBus reset input.

Table 2193. AVSBus Reset Domains

Reset	Scope
rst_clk_div_ni	The programmable clock divider
rst_reg_ni	The register file, the protocol FSM and the reset synchronizers for the register, pre-divider and AVS clock domains
rst_ref_ni	The clk_ref_i leg of the anti-glitch source mux

rst_clk_div_ni must be deasserted before rst_reg_ni. The divider has to be producing a clock before the logic it feeds leaves reset, otherwise the AVS clock domain never starts.

2.1.6.7.11.4.4. Interrupt Interface

interrupt_o is a level output, asserted while any AVS_INTERRUPT bit is set and its corresponding AVS_INTERRUPT_MASK bit is clear.

Table 2194 maps AVS_INTERRUPT bits to the events that set them.

Table 2194. AVSBus Interrupt Sources

Bit	Field	Raised when
8	READBACK_OVERFLOW_INT	A target response was dropped because the readback FIFO was full
7	READBACK_UNDERFLOW_INT	AVS_READBACK was read while the readback FIFO was empty; the read returned 0 with an error response
6	CMD_FIFO_OVERFLOW_INT	AVS_CMD was written while the command FIFO was full, so the command was dropped and the write completed with an error response
5	MAX_RETRIES_ATTEMPTED_INT	A command still failed after AVS_CFG_0.MAX_RETRIES retries, MAX_RETRIES + 1 attempts in all. Never raised while MAX_RETRIES is 0
4	SLAVE_UNRESPONSIVE_INT	The target did not drive a valid subframe
3	READBACK_HAS_DATA_INT	The readback FIFO holds data for software
2	READBACK_FIFO_FULL_INT	The readback FIFO is full; no further commands launch until it drains
1	CMD_FIFO_FULL_INT	The command FIFO is full
0	AVS_SLAVE_ISSUED_INTERRUPT	The target signalled an interrupt

AVS_INTERRUPT_MASK is a **disable** mask and every bit resets to 1, so all sources are masked after reset and software must clear a bit to enable that source. Interrupt bits are cleared by writing 1 to the matching bit of AVS_INTERRUPT_CLEAR; those bits self-clear.

2.1.6.7.11.4.5. Pad Enable Interface

AVS_CONFIG.AVS_GPIO_ENABLE drives avs_gpio_enable_o, which enables the pads carrying the AVSBus signals: output enable for the avs_clock and avs_mdata pins and input enable for the avs_sdata pin. It resets to 1, because the protocol FSM begins running as soon as reset is deasserted.

2.1.6.7.11.4.6. Timing

Table 2195 summarises the subframe and clock timing.

Table 2195. AVSBus Protocol Timing

Parameter	Value
Subframe length	32 avs_clock_o cycles
Slave resync	35 avs_clk cycles in AVS_SLAVE_RESYNC with avs_mdata_o held high; the pin stays high for longer, through the cycles around that state
Minimum AVS clock division	2, when the divider is selected
Resync interval	AVS_CFG_0.RESYNC_INTERVAL clk_reg_i cycles, counted from when the register domain observes the end of the previous resync, plus one clk_reg_i cycle to register the request, three avs_clk cycles to synchronize it, and the time for any frame in flight to complete

The resync counts are avs_clk cycles at the protocol FSM's state register. Pin-level setup, hold and propagation figures are a function of the implementation and are not specified by this IP.

2.1.6.7.11.4.7. Integration Example

The register port takes the AXI4-Lite structs from avsbus_controller_pkg.

```
avsbus_controller #(
    .COMMAND_FIFO_DEPTH  (8),
    .READBACK_FIFO_DEPTH (8)
) u_avs_ctrl (
```

```
    // Clocks and resets
    .clk_reg_i      (reg_clk),
    .clk_ref_i      (ref_clk),
    .rst_ref_ni     (ref_rst_n),
    .rst_reg_ni     (reg_rst_n),
    .rst_clk_div_ni (clk_div_rst_n),  // deassert before rst_reg_ni

    // AVSBus interface
    .avs_sdata_i       (avs_sdata),
    .avs_mdata_o       (avs_mdata),
    .avs_clock_o       (avs_clock),
    .avs_gpio_enable_o (avs_pad_enable),

    // AXI4-Lite register interface
    .axil_req_i  (avs_axil_req),
    .axil_resp_o (avs_axil_resp),

    .interrupt_o (avs_irq),

    // DFT
    .scan_rst_ni (scan_rst_n),
    .test_en_i   (test_en),
    .clk_test_i  (test_clk),

    .cur_state_debug_o (avs_fsm_state)
);
```

2.1.6.7.11.5. Memory Map and Register Reference

2.1.6.7.11.5.1. Memory Map

The AVSBus Controller occupies a 128-byte address space (0x00-0x7F) reached through its AXI4-Lite port. The register map holds the command and readback FIFO windows, status registers for monitoring the bus and the target, interrupt status, mask and clear registers, and configuration registers for the clock, the retry budget and the resync interval.

2.1.6.7.11.5.1.1. Address Alignment and Access Requirements

All registers are 32 bits wide and aligned to a 4-byte boundary. The highest allocated offset is `0x58`; offsets `0x5C` through `0x7F` are unallocated and reserved.

The controller decodes only the low 7 address bits, so the integrating address decoder is responsible for confining the block to its 128-byte window. The SMC memory map states how the SMC answers an access outside it.

Stored registers honour byte strobes, so a partial write updates only the addressed byte lanes. The two FIFO windows do not:

- `AVS_CMD` ignores write strobes and pushes the whole 32-bit write data word into the command FIFO, so it must be written with a single full-width access. A partial write enqueues a malformed command.
- `AVS_READBACK` pops the readback FIFO on any read, whatever the access width, so it must be read exactly once per

response. AVS_DEBUG_READBACK returns the same data without popping.

Neither FIFO window back-pressures the bus; both report a failed access instead. A write to AVS_CMD while the command FIFO is full is dropped, and a read of AVS_READBACK while the readback FIFO is empty returns 0 without popping. Each case raises its interrupt and completes the access with an error response, so software can detect the condition from the bus response alone. An all-zero word is also a well-formed target response, so the read data does not identify an empty read; only the error response or READBACK_UNDERFLOW_INT does. AVS_DEBUG_READBACK reads 0xFFFFFFFF when the FIFO is empty and never errors, which makes it the safer register to poll.

2.1.6.7.11.5.2. Detailed Register Map

2.1.6.7.11.5.2.1. AVSBus Controller Address Map

Command, readback, status, and interrupt registers for the AVSBus (V1.3.1) controller.

Table 2196. AVSBus Controller Address Map register list

Address	Name	Access	Description
0x0	AVS_CMD	W	The command+data to be transferred to the AVS bus
0x4	AVS_READBACK	R	Response data from AVS slave device (updated in response to both AVS read and write commands). Reading this register causes the AVS response readback fifo pointer to advance.
0x8	AVS_DEBUG_READBACK	R	This register mirrors the AVS_READBACK register, but reading it does NOT affect the AVS readback fifo pointer. Provided for debug purposes.
0xC	AVS_LATEST_SLAVE_SUBFRAME	R	This register contains the most recently received subframe from the AVS slave, bypassing the AVS readback fifo. It is provided so that APB can see the current slave StatusResponse and SlaveAck settings in a timely fashion, since the status data from the next entry in the readback fifo might have considerable latency relative to when it was initially received from the AVS Slave.
0x20	AVS_NORMAL_STATUS	R	Various Status bits indicating normal operating conditions for APB2AVS bridge block. These all have corresponding maskable bits in the AVS_INTERRUPT register
0x24	AVS_SLAVE_STATUS	R	Contains the most recent status feedback from the AVS slave device
0x28	AVS_FIFOS_STATUS	R	Contains the number of occupied and vacant slots in the AVS master's command and readback FIFOs
0x30	AVS_INTERRUPT	R	Interrupt register - A '1' indicates an interrupt has occurred for that bit. To clear the interrupt bit, write to the corresponding field in the AVS_INTERRUPT_CLEAR register.
0x34	AVS_INTERRUPT_MASK	RW	Interrupt mask register - Determines which AVS_INTERRUPT bits can trigger an interrupt
0x38	AVS_INTERRUPT_CLEAR	W	Write 1 to clear corresponding interrupt bit
0x50	AVS_CFG_0	RW	Configuration register for APB2AVS bridge block
0x54	AVS_CFG_1	RW	Configuration register for APB2AVS bridge block
0x58	AVS_CONFIG	RW	AVS Configuration Register

2.1.6.7.11.5.2.1.1. AVS_CMD

Table 2197. avsbus_controller.AVS_CMD fields

Bits	Field	Access	Reset	Description
31:30	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
29:28	R_OR_W	W	0x0	Read or write type: [list] **[]0x0 - Commit Write []**0x1 - Hold Write **[]0x2 - Reserved []**0x3 - Read [/list]
27	CMD_GRP	W	0x0	Command group: Set to 1 for manufacturer-specific Command Code (cmd_code), otherwise 0
26:23	CMD_CODE	W	0x0	Command Code (For cmd_group=0. For cmd_group=1, this is manufacturer-specific): [list] **[]0x0 - Target Rail Voltage Read/Write []**0x1 - Vout Transition Rate Read/Write **[]0x2 - Rail Current Read []**0x3 - Temperature Read **[]0x4 - Force Voltage Reset (Requires wr_cmd_data=0x0) []**0x5 - Power Mode Read/Write **[]0xe - AVSBus Status Read/Write []**0xf - AVSBus Version Read [/list]
22:19	RAIL_SEL	W	0x0	Rail Select: 0x0 - Rail 0 0x1 - Rail 1 0xf - Broadcast
18:3	CMD_DATA	W	0x0	Write Cmd Data. Formats: [list] **[]Voltage (cmd_code 0x0): 16-bit unsigned int, 1LSB=1mV []**Transition Rate (cmd_code 0x1): [list] **[]MSByte: Rise Rate, 8-bit unsigned int, 1LSB=1mV/us []**LSByte: Fall Rate, 8-bit unsigned int, 1LSB=1mV/us [/list] **[]Reset Voltage (cmd_code 0x4): 16-bits, all zeroes []**Power Mode (cmd_code 0x5): 3-bits, LSB aligned: [list] **[]0x0 - Maximum Efficiency []**0x3 - Maximum Power **[]0x4-0x7 - Manufacturer-specific [/list] []**AVSBus Status (cmd_code 0xe): 16-bits, encoded per AVS Spec **[]AVSBus Version (cmd_code 0xf): 4 bits encoded per AVS Spec, LSB-aligned []**For read cmd_code's, this is 0xffff [/list]
2:0	Reserved	-	-	Reserved

2.1.6.7.11.5.2.1.2. AVS_READBACK

Table 2198. avsbus_controller.AVS_READBACK fields

Bits	Field	Access	Reset	Description
31:30	SLAVE_ACK	R RMOD	0x0	Indicates whether command executed or not - codes 0x1 and 0x2 trigger automatic retries by hardware: [list] **[]0x0: Action Performed []**0x1: Good CRC received but resource unavailable - hardware will retry **[]0x2: Bad CRC received - hardware will retry []**0x3: Good CRC received but bad data, data type or selector - no hardware retry [/list]
29	CONST0	R RMOD	0x0	Always 0
28:24	STATUS_RESPONSE	R RMOD	0x0	5-bit field indicating general condition of the slave, per AVS spec StatusReponse field: [list] **[]bit 4: VDone - AND of all VDone bits of active rails []**bit 3: StatusAlert - Indicates potential status issue, requiring AVSBus Status read cmd for details **[]bit 2: AVS_Control - 1 if ABSBus is controlling at least 1 device output, 0 otherwise. []**bit 1: MfrSpcfc_Stts1 - Manufacturer-specific [*]bit 0: MfrSpcfc_Stts2 - Manufacturer-specific [/list]
23:8	CMD_DATA	R RMOD	0x0	Read Cmd Data. Format depends on cmd_code in previous master subframe:[list] **[]Voltage (cmd_code 0x0): 16-bit unsigned int, 1LSB=1mV []**Transition Rate (cmd_code 0x1): [list] **[]MSByte: Rise Rate, 8-bit unsigned int, 1LSB=1mV/us []**LSByte: Fall Rate, 8-bit unsigned int, 1LSB=1mV/us [/list] **[]Current (cmd_mode 0x2): 16-bit unsigned, 1LSB=10mA []**Temperature (cmd_code 0x3): 16-bit signed, 1LSB=0.1degC **[]Power Mode (cmd_code 0x5): 3-bits, LSB aligned: [list] []**0x0 - Maximum Efficiency **[]0x3 - Maximum Power []**0x4-0x7 - Manufacturer-specific [/list] **[]AVSBus Status (cmd_code 0xe): 16-bits, encoded per AVS Spec []**AVSBus Version (cmd_code 0xf): 4 bits encoded per AVS Spec, LSB-aligned [*]If master issued a write (rw!=0x3) in previous master subframe, this field is 0xffff [/list]
7:3	Reserved	-	-	Reserved
2:0	CRC	R RMOD	0x0	The CRC-3 code received from slave

2.1.6.7.11.5.2.1.3. AVS_DEBUG_READBACK

Table 2199. avsbus_controller.AVS_DEBUG_READBACK fields

Bits	Field	Access	Reset	Description
31:0	AVS_SLAVE_SUBFRAME	R	0xFFFFFFFF	The current top-of-fifo AVS slave response sub-frame in the readback fifo

2.1.6.7.11.5.2.1.4. AVS_LATEST_SLAVE_SUBFRAME

Table 2200. avsbus_controller.AVS_LATEST_SLAVE_SUBFRAME fields

Bits	Field	Access	Reset	Description
31:0	AVS_SLAVE_SUBFRAME	R	0xFFFF	The most recently received AVS slave response sub-frame

2.1.6.7.11.5.2.1.5. AVS_NORMAL_STATUS

Table 2201. avsbus_controller.AVS_NORMAL_STATUS fields

Bits	Field	Access	Reset	Description
31:23	Reserved	-	-	Reserved
22	AVS_SLAVE_IS_IN_RESYNC	R	0x0	Indicates that the AVS master is issuing a slave resync operation (35 AVS clock cycles of holding mdata high)
21	AVS_BUS_IS_IDLE	R	0x0	Indicates that neither AVS master nor slave is currently driving a transaction on the AVS bus
20	READBACK_HAS_DATA	R	0x0	Indicates AVS_READBACK register has data ready to read on APB
19	READBACK_FIFO_FULL	R	0x0	Indicates read-back fifo is full - no new AVS commands will be launched until space is freed by an AVS_READBACK access
18	CMD_FIFO_FULL	R	0x0	Indicates AVS_CMD fifo is full - any additional APB writes to AVS_CMD will be dropped until the AVS bus can accept the next command, thus freeing space in the cmd fifo
17	CMD_FIFO_EMPTY	R	0x0	Indicates AVS_CMD fifo is empty
16	AVS_MASTER_IS_RETRYING	R	0x0	Master is currently in the middle of retrying a failed command
15:0	TOTAL_RETRIES	R	0x0	Total number of retries attempted by the AVS Master

2.1.6.7.11.5.2.1.6. AVS_SLAVE_STATUS

Table 2202. avsbus_controller.AVS_SLAVE_STATUS fields

Bits	Field	Access	Reset	Description
31:18	Reserved	-	-	Reserved
17:16	AVS_SLAVE_ACK	R	0x0	The SlaveAck bits of the most recent slave subframe received: [list] **[]00: Action Performed []**01:Good CRC received by resource unavailable. No action performed (triggers retry) **[]10: Bad CRC received (triggers retry) []**11: Good CRC received bit bad data, data type, or selector. No action performed [/list]
15:5	Reserved	-	-	Reserved
4:0	AVS_SLAVE_STATUS_RESPONSE	R	0x0	The 5-bit Slave StatusResponse of the most recent slave subframe received, indicating the general condition of the slave, per AVS spec StatusReponse field: [list] **[]bit 4: VDone - AND of all VDone bits of active rails []**bit 3: StatusAlert - Indicates potential status issue, requiring AVSBus Status read cmd for details **[]bit 2: AVS_Control - 1 if ABSBus is controlling at least 1 device output, 0 otherwise. []**bit 1: MfrSpcfc_Stts1 - Manufacturer-specific [*]bit 0: MfrSpcfc_Stts2 - Manufacturer-specific [/list]

2.1.6.7.11.5.2.1.7. AVS_FIFOS_STATUS

Table 2203. avsbus_controller.AVS_FIFOS_STATUS fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:24	READBACK_FIFO_VACANT_SLOTS	R	0x8	Number of vacant slots in the readback FIFO
23:20	Reserved	-	-	Reserved
19:16	READBACK_FIFO_OCCUPIED_SLOTS	R	0x0	Number of occupied slots in the readback FIFO
15:12	Reserved	-	-	Reserved
11:8	CMD_FIFO_VACANT_SLOTS	R	0x8	Number of vacant slots in the command FIFO
7:4	Reserved	-	-	Reserved
3:0	CMD_FIFO_OCCUPIED_SLOTS	R	0x0	Number of occupied slots in the command FIFO

2.1.6.7.11.5.2.1.8. AVS_INTERRUPT

Table 2204. avsbus_controller.AVS_INTERRUPT fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	READBACK_OVERFLOW_INT	R	0x0	Indicates that the response from AVS slave could not be written to readback FIFO due to it being full ⇒ response was dropped
7	READBACK_UNDERFLOW_INT	R	0x0	Indicates that an APB read on the AVS_READBACK reg occurred when the readback fifo was empty (AVS_NORMAL_STATUS:readback_has_data=0)
6	CMD_FIFO_OVERFLOW_INT	R	0x0	Indicates that an APB write to AVS_CMD was attempted when the the command fifo was already full - the command is dropped
5	MAX_RETRIES_ATTEMPTED_INT	R	0x0	Indicates that the AVS Master failed to receive a non-failure acknowledgement from the Slave after a command was retried the maximum allowable number of times (as determined by AVS_CFG_0:max_retries)
4	SLAVE_UNRESPONSIVE_INT	R	0x0	Indicates the AVS Slave device is not responding to command subframes from the Master
3	READBACK_HAS_DATA_INT	R	0x0	Indicates AVS_READBACK register has data ready to read on APB
2	READBACK_FIFO_FULL_INT	R	0x0	Indicates read-back fifo is full - no new AVS commands will be launched until space is freed by an AVS_READBACK access
1	CMD_FIFO_FULL_INT	R	0x0	Indicates AVS_CMD fifo is full - any additional APB writes to AVS_CMD will be dropped until the AVS bus can accept the next command, thus freeing space in the cmd fifo
0	AVS_SLAVE_ISSUED_INTERRUPT	R	0x0	Indicates the AVS slave has signaled an interrupt

2.1.6.7.11.5.2.1.9. AVS_INTERRUPT_MASK

Table 2205. avsbus_controller.AVS_INTERRUPT_MASK fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	DISABLE_READBACK_OVERFLOW_INT	RW	0x1	Disable readback_overflow interrupt
7	DISABLE_READBACK_UNDERFLOW_INT	RW	0x1	Disable readback_underflow interrupt
6	DISABLE_CMD_FIFO_OVERFLOW_INT	RW	0x1	Disable cmd_fifo_overflow interrupt
5	DISABLE_MAX_RETRIES_ATTEMPTED_INT	RW	0x1	Disable max_retries_attempted interrupt

Bits	Field	Access	Reset	Description
4	DISABLE_SLAVE_UNRESPONSIVE_INT	RW	0x1	Disable slave_unresponsive interrupt
3	DISABLE_READBACK_HAS_DATA_INT	RW	0x1	Disable readback_has_data interrupt
2	DISABLE_READBACK_FIFO_FULL_INT	RW	0x1	Disable readback_fifo_full interrupt
1	DISABLE_CMD_FIFO_FULL_INT	RW	0x1	Disable cmd_fifo_full interrupt
0	DISABLE_AVS_SLAVE_ISSUED_INTERRUPT	RW	0x1	Disable notification of AVS slave interrupt

2.1.6.7.11.5.2.1.10. AVS_INTERRUPT_CLEAR

Table 2206. avsbus_controller.AVS_INTERRUPT_CLEAR fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	CLEAR_READBACK_OVERFLOW_INT	W 1P	0x0	Clear readback_overflow interrupt
7	CLEAR_READBACK_UNDERFLOW_INT	W 1P	0x0	Clear readback_underflow interrupt
6	CLEAR_CMD_FIFO_OVERFLOW_INT	W 1P	0x0	Clear cmd_fifo_overflow interrupt
5	CLEAR_MAX_RETRIES_ATTEMPTED_INT	W 1P	0x0	Clear max_retries_attempted interrupt
4	CLEAR_SLAVE_UNRESPONSIVE_INT	W 1P	0x0	Clear slave_unresponsive interrupt
3	CLEAR_READBACK_HAS_DATA_INT	W 1P	0x0	Clear readback_has_data interrupt
2	CLEAR_READBACK_FIFO_FULL_INT	W 1P	0x0	Clear readback_fifo_full interrupt
1	CLEAR_CMD_FIFO_FULL_INT	W 1P	0x0	Clear cmd_fifo_full interrupt
0	CLEAR_AVS_SLAVE_ISSUED_INTERRUPT	W 1P	0x0	Clear avs_slave_issued_interrupt

2.1.6.7.11.5.2.1.11. AVS_CFG_0

Table 2207. avsbus_controller.AVS_CFG_0 fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:16	MAX_RETRIES	RW	0x5	Maximum number of retries, after the original attempt, if an AVS command returns a fail status (either due to targeted resource being busy or CRC failure). A value of 0 disables retries and MAX_RETRIES_ATTEMPTED_INT.
15:0	RESYNC_INTERVAL	RW	0x1000	Interval between periodic slave resync operations on the AVS bus, in APB clock cycles counted from the end of the previous resync. The resulting request then crosses a 3-stage AVS clock synchronizer, and the resync starts once any frame in flight has completed.

2.1.6.7.11.5.2.1.12. AVS_CFG_1

Table 2208. avsbus_controller.AVS_CFG_1 fields

Bits	Field	Access	Reset	Description
31:24	CLK_DIVIDER_DUTY_CYCLE_NUMERATOR	RW	0x0	Determines the desired duty cycle of the divided clock (when avs_clock_select is set to select the divided APB clock or refclk clock). This value will be divided by 256 to determine the high-pulse percentage of the divided clock period. Depending on the clk_divider_value, it may not be possible to precisely achieve the desired duty cycle - in that case, the closest possible fit is used. If this is set to 0, a value of 1 will be assumed. This is set to 0 by default to trick the clock divider into maintaining the HW-default settings (numerator=0x80) by matching the FF default in the resynced version of the signal.

Bits	Field	Access	Reset	Description
23:16	CLK_DIVIDER_VALUE	RW	0x0	Determines the divisor value used to generate the AVS clock (when avs_clock_select is set to select the divided APB clock or divided refclk clock). The duty cycle of the divided clock depends both on the clk_divider_value together with the clk_divider_duty_cycle_numerator value. A 50% duty cycle is only possible on even clk_divider_values with clk_divider_duty_cycle_numerator set to 128. This field requires a minimum value of 2 - for lower values, 2 will be assumed. This is set to 0 by default to trick the clock divider into maintaining the HW-default settings (divider=0x4) by matching the FF default in the resynced version of the signal.
15:11	Reserved	-	-	Reserved
10	TURN_OFF_ALL_PREMUX_CLOCKS	RW	0x0	Gate off all clocks entering the AVS clock mux - do this before changing the mux selection or changing the clock divider settings, then turn back on afterwards
9	FORCE_SLAVE_RESYNC_OPERATION	RW 1P	0x0	Force master to issue a slave resync (35 AVS clock cycles of holding the mdata signal high) at the next possible opportunity. The request crosses a 3-stage AVS clock synchronizer before the master sees it.
8	STOP_AVS_CLOCK_ON_IDLE	RW	0x0	When the AVS bus is idle, gate the avs_clock from running. Restart it when there are new commands to be run. The master always issues a slave resync first when the clock restarts.
7:2	Reserved	-	-	Reserved
1:0	AVS_CLOCK_SELECT	RW	0x3	Selects which clock to use for AVS Clock: [list] **[] 00: Use the APB clock directly as the AVS clock []** 01: Use a divided version of APB clock as the AVS Clock. The clock divider settings are determined by AVS_CFG_1:clk_divider_value and AVS_CFG_1:clk_divider_duty_cycle_numerator **[] 10: Use the refclk clock directly as the AVS clock []** 11: Use a divided version of refclk clock as the AVS Clock. The clock divider settings are determined by AVS_CFG_1:clk_divider_value and AVS_CFG_1:clk_divider_duty_cycle_numerator [/list]

2.1.6.7.11.5.2.1.13. AVS_CONFIG

Table 2209. avsbus_controller.AVS_CONFIG fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	AVS_GPIO_ENABLE	RW	0x1	Enable AVSBus connection to GPIOs. The effective sets OE of the GPIOs dedicated to avs_clock and avs_cdata to 1, sets IE of GPIO dedicated to avs_tdata to 1. By default, this is enabled as the AVSBus state machine immediately starts after reset deassertion.

2.1.6.7.12. GPIO Peripheral

2.1.6.7.12.1. Overview

GPIO connects software and low-speed I/O (LSIO) peripherals to individual pads. Software can drive or sample a pad, select an interrupt trigger, and read its boot strap. Hardware LSIO requests take priority over software control unless software explicitly disables LSIO.

Each pad uses two blocks: `gpio` selects data and direction; `gpio_shim` selects electrical settings and captures the strap. Each has its own 32-bit AXI4-Lite register interface. The surrounding padring instantiates these blocks for its pads and supplies the address mapping and LSIO wiring.

The sections below explain ownership and reset behavior, list the interfaces and give the register maps. The GPIO

section of the Programmer's Guide gives the programming sequences.

2.1.6.7.12.2. Operation

Figure 75 shows the two blocks that serve one pad: the gpio controller in the SMC pad ring, and the gpio_shim that the adopter's pad integration places in front of the technology pad macro. Each block receives its own AXI-Lite register slot. In gpio, the access filter takes its enables and requirements from the ACCESS_FILTER fields of u_gpio_intf_reg (write_filter_enable, read_filter_enable, awprot_requirement and arprot_requirement), the LSIO mux chooses the pad data and enables from the LSIO plane or from DATA_CTRL, and the synchronized pad input feeds both the DATA_CTRL.pad2core readback and the interrupt detector. In gpio_shim, the 2nd-HW override mux can replace the primary plane with the *_ovrd_i inputs. While it does, it also returns the pad input on pad2core_ovrd_o, which is low otherwise; pad2core_o carries the pad input in either case. The electrical mux chooses the drive, pull and glitch-filter settings, and the strap latch captures the pad input at the end of cold reset and presents it both as CONTROL.strap_value and on the captured_strap_o output. Trapezoids are muxes and demuxes, with their selectable ports on the wide side, so the pad input enters the 2nd-HW override mux on its narrow side; the dashed strap latch is present only when INPUT_BY_DEFAULT is set.




Figure 75. GPIO controller, interface shim, LSIO mux and strap-capture path

2.1.6.7.12.2.1. Data and Direction Ownership

After cold reset, the controller selects output data, transmit enable and receive enable independently. For each field, the first applicable row wins:

Table 2210. GPIO data and direction selection

Priority	Condition	Source
1	`lsio_interface_select_i = 1` and `DATA_CTRL.lsio_disable = 0`	Hardware LSIO data and direction inputs.
2	`DATA_CTRL.interface_enable = 1`, or the corresponding `DATA_CTRL_ENABLE.use_reg_*` bit is set	`DATA_CTRL.core2pad`, `enable_rx_tx[0]` (TX), or `enable_rx_tx[1]` (RX).
3	`DATA_CTRL.lsio_select = 1` and `DATA_CTRL.lsio_disable = 0`	Software-forced LSIO, using the same LSIO inputs.

Priority	Condition	Source
4	No preceding condition applies	Output data 0, TX disabled, RX set by INPUT_BY_DEFAULT.

The per-field overrides are use_reg_core2pad, use_reg_tx and use_reg_rx. They allow different sources for data and direction. A hardware LSIO request outranks all three overrides; software-forced LSIO does not. lsio_disable gates both forms of LSIO selection.

DATA_CTRL.lsio_enable reports the hardware request after the disable gate: lsio_interface_select_i && !lsio_disable. It does not report a software-forced selection and is not a general pad-owner indicator.

2.1.6.7.12.2.2. Input Readback

DATA_CTRL.pad2core returns the synchronized input when interface_enable or use_reg_rx selects register readback; otherwise it returns zero. The pad receiver must also be enabled by the selected owner.

The LSIO return path uses the unsynchronized pad input while either LSIO request is active. This return path is independent of the data/direction priority: a software LSIO request can enable readback even when registers own an output field. During cold reset, the LSIO return path also carries the pad input.

2.1.6.7.12.2.3. SMC Pad Ring

The SMC instantiates one gpio controller per pad in u_smc_padring, 65 in all. Figure 76 shows how the controllers are reached and where the shims sit. u_smc_padring sits in u_smc_peripherals beside the peripheral crossbar u_smc_periph_axi_lite_xbar, which receives the peripheral window from the local crossbar u_smc_local_xbar in u_smc_base. The peripheral crossbar sends the GPIO interface window to u_gpio_intf_demux, which decodes one 16-byte slot per pad and answers any other address with DECERR. The LSIO pad map assigns the SPI, UART, I3C, I2C, AVSBus, system-timer, isolate-request, boot-stall and cool-reset functions to fixed pads, and drives the LSIO plane of each controller. The controllers' pad wires leave the SMC; outside it, the adopter's pad integration places a gpio_shim and a pad macro on each pad, and decodes the smc_external window to give each shim its gpio_ctrl slot; the rest of that window reaches adopter-specific targets. The figure draws pads 0, 1 and 64; the ellipses stand for the pads between them.




Figure 76. SMC pad ring GPIO interfaces and adopter pad shims

The open reference integration, `smc_ip_integration`, stands in for the adopter side with one `prim_pad_shim` per pad at fixed electrical settings, and answers the `gpio_ctrl` range of the `smc_external` window with DECERR.

2.1.6.7.12.2.4. Pad Settings and Secondary Function

The shim selects drive strength, pull settings and input conditioning in this order: hardware LSIO request, `CONTROL.config_enable`, software-forced LSIO, then parameter defaults. The LSIO requests use the same disable gate as the controller. In register mode, `CONTROL` supplies `drive_strength`, `pull_enable_n0_scan`, `pull_select` and `schmitt_select`.

A separate mux selects a secondary hardware function when `CONTROL.hw2_ovrd = 1` and `force_primary_i = 0`. It overrides the primary data and direction path. `force_primary_i` restores the primary path regardless of the register setting. The integrator must coordinate switching with both hardware functions.

Electrical effects depend on the connected pad implementation. The supplied `gpio_model` models output drive and

receive enable; it does not model drive strength, pull resistors or input conditioning. Do not interpret the drive_strength encoding as a portable current rating.

2.1.6.7.12.2.5. Interrupts

The input passes through a three-stage synchronizer before interrupt detection. The selected condition is registered on clk_i and gated by DATA_CTRL.interrupt_enable at interrupt_o.

Table 2211. GPIO interrupt modes

interrupt_type	Condition	Output while enabled
00	Input high	Level follows the registered condition.
01	Input low	Level follows the registered condition.
10	Rising edge	One clock-cycle pulse per detected edge.
11	Falling edge	One clock-cycle pulse per detected edge.

There is no sticky interrupt status or acknowledge register in this block. A level condition must cease, or the interrupt must be disabled, to remove the request. Edge pulses are not stretched; the receiving interrupt controller must capture them. Detection uses the synchronized input, independently of whether register readback is selected.

2.1.6.7.12.2.6. Reset and Strap Capture

rst_primary_ni asynchronously resets interface/control registers, the input synchronizer and interrupt state. rst_cold_ni separately forces controller outputs to data 0, TX disabled and RX=INPUT_BY_DEFAULT, and forces the shim's electrical settings to their parameter defaults. The integration supplies reset timing; these modules do not synchronize reset deassertion internally.

With INPUT_BY_DEFAULT = 1, the shim's strap latch follows the pad while cold reset is asserted and holds the level when cold reset is released. This is a level-sensitive latch, not a sample taken on a clk_i edge. With the parameter clear, the captured value is zero.

CONTROL.strap_value and captured_strap_o report that captured level. CONTROL.strap_valid reflects INPUT_BY_DEFAULT; it is not a capture-done flag. Read the strap after the system has released cold reset. Primary reset alone does not recapture it.

2.1.6.7.12.2.7. Register Access Filtering

The interface-bank filter compares all three AXI PROT bits against the configured read or write requirement. Each direction has its own enable. A mismatch is sent to an error responder and completes with DECERR; disabling a filter permits that direction regardless of PROT.

Filtering resets disabled. The stored read and write requirements reset to 3'b001 (secure, privileged data), but apply only when enabled. PROT expresses transaction attributes, not initiator identity: this filter alone does not establish SEP-only access. It protects the interface bank, not the shim's separate control bank. The GPIO access filtering procedure in the Programmer's Guide gives the setup and readback requirements.

2.1.6.7.12.3. Interface

The GPIO peripheral provides bus interfaces for register access, LSIO integration for hardware protocols, and direct GPIO pad connections.

Each gpio instance drives one pad. The peripheral comprises 65 pads: 61 bonded and 4 unbonded.

The parameters and ports of gpio are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.6.7.12.3.1. LSIO Interface

The LSIO (Low Speed Input/Output) interface enables hardware-controlled GPIO operation for protocol processing.

2.1.6.7.12.3.2. LSIO Protocol Specifications

- **Selection Priority**: an asserted lsio_interface_select_i overrides register-driven control, including DATA_CTRL.interface_enable and the DATA_CTRL_ENABLE.use_reg_* per-field overrides. The software force bit DATA_CTRL.lsio_select ranks the other way, below the register interface; DATA_CTRL.lsio_disable gates both
- **Enable Logic**: Active-low enables for both transmit and receive paths
- **Data Latency**: Zero-cycle latency for data path when selected
- **Mode Switching**: Immediate effect, no settling time required
- **Status Reflection**: hardware LSIO request status available in DATA_CTRL.lsio_enable register. The field tracks the hardware request line gated by lsio_disable, so it reads 0 during a software-forced LSIO

2.1.6.7.12.3.3. GPIO Pad Interface

The GPIO pad interface provides direct connection to external pads with bidirectional capabilities.

2.1.6.7.12.3.4. Interrupt Interface

The interrupt interface provides event notification capabilities with configurable trigger modes.

The strap-capture output captured_strap_o is a port of gpio_shim, not of gpio; it holds the pad value captured when the cold reset is released.

2.1.6.7.12.3.5. Interrupt Specifications

- **Polarity**: Active high (asserted when high)
- **Duration**: Level-sensitive, remains asserted based on configuration
- **Trigger Modes**: Level (active-high/low) and edge (rising/falling) detection
- **Clearing**: Automatic clearing based on trigger mode and pad state
- **Latency**: Interrupt assertion within 2-3 clock cycles of triggering event

2.1.6.7.12.4. Memory Map and Register Reference

2.1.6.7.12.4.1. Memory Map

The controller's interface bank contains DATA_CTRL, DATA_CTRL_ENABLE and ACCESS_FILTER; the shim's control bank contains CONTROL. The generated gpio_intf and gpio_ctrl maps in Section 2.1.6.7.12.4.2 define their register offsets, and gpio_wrap defines the bank placement within the composite aperture. The enclosing padring determines their system addresses.

2.1.6.7.12.4.1.1. Reset Values

ACCESS_FILTER resets to 0x00010100: read and write filters are disabled, with each stored protection requirement set to 3'b001. DATA_CTRL and DATA_CTRL_ENABLE software controls reset to zero. Default pad direction and post-reset LSIO ownership are described in Section 2.1.6.7.12.2.1 and Section 2.1.6.7.12.2.6; zeroed software controls do not imply that

every pad path is disabled.

CONTROL resets its drive-strength field to 3'b010 and its software pull, conditioning, configuration-enable and secondary-override controls to zero. The read-only strap fields reflect INPUT_BY_DEFAULT and the captured input, so the complete value is not a single fixed reset word.

2.1.6.7.12.4.2. Detailed Register Map

2.1.6.7.12.4.2.1. GPIO Interface Address Map

GPIO interface configuration: pad/core routing, receive and transmit enables, and interrupt control.

Table 2212. GPIO Interface Address Map register list

Address	Name	Access	Description
0x0	DATA_CTRL	RW	-
0x4	DATA_CTRL_ENABLE	RW	-
0x8	ACCESS_FILTER	RW	GPIO Access Filter Register. WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.

2.1.6.7.12.4.2.1.1. DATA_CTRL

Table 2213. gpio_intf.DATA_CTRL fields

Bits	Field	Access	Reset	Description
31	pad2core	R	0x0	PAD2SOC Value
30:26	Reserved	-	-	Reserved
25	lsio_enable	R	0x0	LSIO hardware request status. Set while lsio_interface_select_i is asserted and lsio_disable is clear. Because the hardware LSIO request outranks interface_enable, a set value also means the LSIO plane is driving this pad's data and direction. This field does not reflect a software-forced selection via lsio_select, which ranks below the register interface - it reads 0 in that case even when LSIO drives the pad.
24:22	Reserved	-	-	Reserved
21:20	interrupt_type	RW	0x0	Interrupt type - 0: active-high level, 1: active-low level, 2: rising edge, 3: falling edge
19	lsio_disable	RW	0x0	When set, LSIO accesses will be blocked from the GPIO interface
18	interrupt_enable	RW	0x0	Interrupt Enable.
17	lsio_select	RW	0x0	Force the LSIO interface to be used from software, when no hardware LSIO request is present on this pad. interface_enable has higher priority over this bit. This ranking applies to this software force bit only: the hardware lsio_interface_select_i input outranks interface_enable. Use lsio_disable to gate both.
16	interface_enable	RW	0x0	Register Interface Enable. Setting this chooses register values to drive the PAD. This includes core2pad, enable_rx_tx, and pad2core
15:6	Reserved	-	-	Reserved
5:4	enable_rx_tx	RW	0x0	Direction control. 2'b00: Neither RX nor TX enabled. 2'b01: TX enabled. 2'b10: RX enabled. 2'b11: Both enabled
3:1	Reserved	-	-	Reserved
0	core2pad	RW	0x0	Register-driven data to send to the pad.

2.1.6.7.12.4.2.1.2. DATA_CTRL_ENABLE

Table 2214. gpio_intf.DATA_CTRL_ENABLE fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	use_reg_rx	RW	0x0	Per-field register override. When set, the RX direction (input enable) is taken from enable_rx_tx[1]. OR'd with interface_enable.
4	use_reg_tx	RW	0x0	Per-field register override. When set, the TX direction (output enable) is taken from enable_rx_tx[0]. OR'd with interface_enable.
3:1	Reserved	-	-	Reserved
0	use_reg_core2pad	RW	0x0	Per-field register override. When set, core2pad is register-driven. OR'd with interface_enable.

2.1.6.7.12.4.2.1.3. ACCESS_FILTER

Table 2215. gpio_intf.ACCESS_FILTER fields

Bits	Field	Access	Reset	Description
31:19	Reserved	-	-	Reserved
18:16	arprot_requirement	RW	0x1	When read_filter_enable is set, only allow read accesses with this prot value WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.
15:11	Reserved	-	-	Reserved
10:8	awprot_requirement	RW	0x1	When write_filter_enable is set, only allow write accesses with this prot value WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.
7:2	Reserved	-	-	Reserved
1	read_filter_enable	RW	0x0	Read Filter Enable. When set, reads require an exact match between AXI ARPROT and arprot_requirement. When clear, reads are unfiltered. PROT does not identify the initiator. WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.
0	write_filter_enable	RW	0x0	Write Filter Enable. When set, writes require an exact match between AXI AWPROT and awprot_requirement. When clear, writes are unfiltered. PROT does not identify the initiator. WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.

2.1.6.7.12.4.2.2. GPIO Control Address Map

Per-pin GPIO pad control registers: drive strength, pull configuration, and strap capture.

Table 2216. GPIO Control Address Map register list

Address	Name	Access	Description
0x0	CONTROL	RW	-

2.1.6.7.12.4.2.2.1. CONTROL

Table 2217. gpio_ctrl.CONTROL fields

Bits	Field	Access	Reset	Description
31:25	Reserved	-	-	Reserved
24	hw2_ovrd	RW	0x0	Setting this register will enable the secondary HW function to override the GPIO enable and data lines.
23:22	Reserved	-	-	Reserved
21	strap_value	R	0x0	This register holds the captured value that was applied to the pad when reset was de-asserted.
20	strap_valid	R	0x1	When set, this bit indicates that the strap value is valid. This field is not set if the GPIO is not an input by default
19:17	Reserved	-	-	Reserved
16	config_enable	RW	0x0	Setting this choosing the register values for PAD settings. This includes pull_enable, pull_select, and schmitt_select
15:11	Reserved	-	-	Reserved
10	schmitt_select	RW	0x0	Register-driven schmitt select.
9	pull_select	RW	0x0	Register-driven pull select - by default we pull down
8	pull_enable_n0_scan	RW	0x0	Register-driven pull enable. Default is disabled
7:3	Reserved	-	-	Reserved
2:0	drive_strength	RW	0x2	Register-driven drive-strength.

2.1.6.7.12.4.2.3. GPIO Wrapper Address Map

Top-level GPIO address map composing the interface and control register blocks.

Table 2218. GPIO Wrapper Address Map register list

Address	Name	Access	Description
0x0	DATA_CTRL	RW	-
0x4	DATA_CTRL_ENABLE	RW	-
0x8	ACCESS_FILTER	RW	GPIO Access Filter Register. WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.
0x10	CONTROL	RW	-

2.1.6.7.12.4.2.3.1. DATA_CTRL

Table 2219. gpio_wrap.DATA_CTRL fields

Bits	Field	Access	Reset	Description
31	pad2core	R	0x0	PAD2SOC Value
30:26	Reserved	-	-	Reserved
25	lsio_enable	R	0x0	LSIO hardware request status. Set while lsio_interface_select_i is asserted and lsio_disable is clear. Because the hardware LSIO request outranks interface_enable, a set value also means the LSIO plane is driving this pad's data and direction. This field does not reflect a software-forced selection via lsio_select, which ranks below the register interface - it reads 0 in that case even when LSIO drives the pad.
24:22	Reserved	-	-	Reserved
21:20	interrupt_type	RW	0x0	Interrupt type - 0: active-high level, 1: active-low level, 2: rising edge, 3: falling edge
19	lsio_disable	RW	0x0	When set, LSIO accesses will be blocked from the GPIO interface

Bits	Field	Access	Reset	Description
18	interrupt_enable	RW	0x0	Interrupt Enable.
17	lsio_select	RW	0x0	Force the LSIO interface to be used from software, when no hardware LSIO request is present on this pad. interface_enable has higher priority over this bit. This ranking applies to this software force bit only: the hardware lsio_interface_select_i input outranks interface_enable. Use lsio_disable to gate both.
16	interface_enable	RW	0x0	Register Interface Enable. Setting this chooses register values to drive the PAD. This includes core2pad, enable_rx_tx, and pad2core
15:6	Reserved	-	-	Reserved
5:4	enable_rx_tx	RW	0x0	Direction control. 2'b00: Neither RX nor TX enabled. 2'b01: TX enabled. 2'b10: RX enabled. 2'b11: Both enabled
3:1	Reserved	-	-	Reserved
0	core2pad	RW	0x0	Register-driven data to send to the pad.

2.1.6.7.12.4.2.3.2. DATA_CTRL_ENABLE

Table 2220. gpio_wrap.DATA_CTRL_ENABLE fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	use_reg_rx	RW	0x0	Per-field register override. When set, the RX direction (input enable) is taken from enable_rx_tx[1]. OR'd with interface_enable.
4	use_reg_tx	RW	0x0	Per-field register override. When set, the TX direction (output enable) is taken from enable_rx_tx[0]. OR'd with interface_enable.
3:1	Reserved	-	-	Reserved
0	use_reg_core2pad	RW	0x0	Per-field register override. When set, core2pad is register-driven. OR'd with interface_enable.

2.1.6.7.12.4.2.3.3. ACCESS_FILTER

Table 2221. gpio_wrap.ACCESS_FILTER fields

Bits	Field	Access	Reset	Description
31:19	Reserved	-	-	Reserved
18:16	arprot_requirement	RW	0x1	When read_filter_enable is set, only allow read accesses with this prot value WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.
15:11	Reserved	-	-	Reserved
10:8	awprot_requirement	RW	0x1	When write_filter_enable is set, only allow write accesses with this prot value WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.
7:2	Reserved	-	-	Reserved
1	read_filter_enable	RW	0x0	Read Filter Enable. When set, reads require an exact match between AXI ARPROT and arprot_requirement. When clear, reads are unfiltered. PROT does not identify the initiator. WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.

Bits	Field	Access	Reset	Description
0	write_filter_enable	RW	0x0	Write Filter Enable. When set, writes require an exact match between AXI AWPROT and awprot_requirement. When clear, writes are unfiltered. PROT does not identify the initiator. WARNING: please read back this register to ensure the filter was written correctly. If you do not do so the filter may not update before your next transaction, causing unexpected behavior.

2.1.6.7.12.4.2.3.4. CONTROL

Table 2222. gpio_wrap.CONTROL fields

Bits	Field	Access	Reset	Description
31:25	Reserved	-	-	Reserved
24	hw2_ovrd	RW	0x0	Setting this register will enable the secondary HW function to override the GPIO enable and data lines.
23:22	Reserved	-	-	Reserved
21	strap_value	R	0x0	This register holds the captured value that was applied to the pad when reset was de-asserted.
20	strap_valid	R	0x1	When set, this bit indicates that the strap value is valid. This field is not set if the GPIO is not an input by default
19:17	Reserved	-	-	Reserved
16	config_enable	RW	0x0	Setting this choosing the register values for PAD settings. This includes pull_enable, pull_select, and schmitt_select
15:11	Reserved	-	-	Reserved
10	schmitt_select	RW	0x0	Register-driven schmitt select.
9	pull_select	RW	0x0	Register-driven pull select - by default we pull down
8	pull_enable_n0_scan	RW	0x0	Register-driven pull enable. Default is disabled
7:3	Reserved	-	-	Reserved
2:0	drive_strength	RW	0x2	Register-driven drive-strength.

2.1.6.7.13. Telemetry Receiver

2.1.6.7.13.1. Overview

The receiver assembles an 8-bit ATB stream into probe-ID and counter messages. Software reads completed messages through a 32-bit AXI4-Lite register interface and explicitly pops each message. The core defaults to eight queued messages and four counters per message; these are elaboration parameters, not software settings. Threshold and missing-last-packet interrupts report service needs.

Reception does not stop when the message queue fills: a new message replaces the oldest one, including while software is reading it through several registers. The Telemetry Receiver section of the Programmer's Guide gives the buffer, flush and interrupt procedures. The receiver does not use `atid_i` to maintain separate source contexts; producers sharing a receiver must serialize complete messages.

2.1.6.7.13.1.1. Message Format

Eight little-endian ATB beats form a 64-bit packet. One or more packets form a message that ends when `last_packet` is set.

Table 2223 defines the fields carried in each telemetry packet.

Table 2223. Telemetry packet fields

Field	Width	Location
`last_packet`	1 bit	Bit 63 of each packet
`probe_id`	5 bits	Bits `[60:56]` of the first packet
block	9 bits	Seven per packet: 1-bit valid + 8-bit data
counter	32 bits	Four consecutive blocks, most-significant byte first

A counter is valid only when all four of its blocks are valid. The number of counters per message is parameterized (default 4); the field layout is fixed.

2.1.6.7.13.2. Architecture

The receiver has two stores: a byte assembly buffer for the incoming message and a queue of decoded messages for software. Neither is a second independently configurable telemetry channel.

2.1.6.7.13.2.1. Assembly and Decode

An accepted beat (`atvalid_i && atready_o`) writes one assembly byte. Eight beats form a packet, least-significant byte first. Bit 63 marks the last packet; the first packet carries the probe ID at bits `[60:56]`. Counter decoding starts at block 1 of the first packet, continues across packet boundaries, and assembles each counter most-significant byte first. All four block-valid bits must be set for a counter to be valid; otherwise its decoded value is zero.

The assembly capacity is derived from `MAX_NUM_COUNTERS_PER_MESSAGE`. Reaching that capacity without a last-packet marker raises `MISSING_LAST` and resets the write pointer. A last-packet marker also resets the pointer and queues the decoded message. The core accepts beats except during a receiver-flush pulse; message-queue fullness does not apply backpressure.

IMPORTANT

Every configured counter position is decoded, including positions beyond the last packet received. A short message following a longer one can therefore inherit trailing values and validity bits. Producers must overwrite the complete configured message footprint and mark unused counter blocks invalid. Receiver flush resets the pointer but leaves assembly bytes intact; only reset clears that storage.

2.1.6.7.13.2.2. Message Queue and Readout

The queue exposes its oldest message in `TELEMETRY_PROBE_ID`, `TELEMETRY_COUNTER_VLDS` and `TELEMETRY_COUNTER[0..31]`. Reads do not consume data; `CTRL.BUFFER_POP` advances the queue only when it is nonempty. Empty-queue reads return zero. Counter registers beyond the configured counter count also return zero and have cleared validity bits.

On arrival while full, hardware drops the oldest message and advances the read pointer. There is no snapshot across the separate software reads: overflow can change the visible message mid-read. Arrange sufficient buffering/service rate, or quiesce the producer, when a coherent software snapshot is required. `STATUS` reports empty/full, not a numeric occupancy count or an overflow interrupt.

2.1.6.7.13.2.3. Interrupts

`irq_o` is the OR of the two status sources masked by their corresponding `INTR_ENABLE` bits. Masking an interrupt does not acknowledge its source.

Table 2224. Telemetry interrupt conditions

Source	Condition and clearing
MISSING_LAST	Sticky status when assembly capacity is reached without the last-packet marker. It latches even while disabled. Write one to the status bit to clear it; INTR_TEST.MISSING_LAST supplies a test pulse.
BUFFER_THRESHOLD	Read-only live status while occupancy is strictly greater than the effective threshold, or INTR_TEST.BUFFER_THRESHOLD is set. Drain to at most the threshold, raise the threshold, or clear the test bit as appropriate. Writing the status bit does not clear this source.

2.1.6.7.13.2.4. Reset and Flush

Reset clears assembly bytes, queue pointers and control/interrupt registers. Queue payload storage is not reset, but empty-queue reads return zero. Supply rst_ni with asynchronous assertion and deassertion synchronized to clk_i.

CTRL.TELEMETRY_RX_FLUSH is a pulse that discards queued messages and resets the assembly pointer. It does not erase either payload store or purge the wrapper's upstream ATB crossing FIFO. Quiesce traffic when an empty receiver must remain empty after the pulse.

CTRL.TELEMETRY_TX_FLUSH requests a flush from the upstream transmitter through afvalid_o. Hardware clears the request after afvalid_o && afready_i. Completion depends on the producer's acknowledgement; this is separate from a local receiver flush.

2.1.6.7.13.3. Interface

The Telemetry Receiver component provides AXI4-Lite register access and Advanced Trace Bus (ATB) telemetry data reception interfaces.

2.1.6.7.13.3.1. Configuration Parameters

The parameters and ports of telemetry_receiver are listed in the HTML edition of this manual, under RTL Modules Reference.

The core has two elaboration parameters. BUFFER_DEPTH (default 8) sets the number of decoded messages the queue holds; it must be a power of two and at least 2. MAX_NUM_COUNTERS_PER_MESSAGE (default 4) sets the number of counters decoded from each message.

The ATB beat width (8 bits), packet width (64 bits), counter width (32 bits) and ATB ID width (7 bits) are package constants. The core register port has an 8-bit address and 32-bit data path.

2.1.6.7.13.3.2. Signal Interfaces

2.1.6.7.13.3.3. Global Interface

The global interface provides fundamental clock and reset signals required for basic operation.

2.1.6.7.13.3.4. Clock and Reset

clk_i is the core clock and rst_ni its asynchronous, active-low reset; telemetry_receiver_wrap adds clk_telemetry_i / rst_telemetry_ni for the ATB side. Clock frequency, jitter, reset duration and physical timing constraints must come from the integration timing specification.

2.1.6.7.13.3.5. ATB Telemetry Interface

The ATB (Advanced Trace Bus) interface receives telemetry data using standard ATB protocol.

2.1.6.7.13.3.6. ATB Protocol Specifications

- **Data Width**: 8 bits per beat
- **ID Width**: 7 bits; the receiver ignores `atid_i`
- **Flow Control**: Valid/ready handshaking for reliable data transfer
- **Flush Support**: Bidirectional flush signaling for stream management
- **Back-pressure**: Component can assert `atready_o` low to apply back-pressure
- **Latency**: Zero-cycle latency when ready, immediate acceptance when `atready_o` is high

2.1.6.7.13.3.7. Interrupt Interface

The interrupt interface provides a single interrupt output for event notification.

2.1.6.7.13.3.8. Interrupt Specifications

- **Polarity**: Active high (asserted when high)
- **Duration**: Level-sensitive, remains asserted until cleared
- **Sources**: Buffer threshold and error condition interrupts
- **Clearing**: `MISSING_LAST` is write-one-to-clear. The read-only `BUFFER_THRESHOLD` source remains asserted while occupancy exceeds the configured threshold or its test bit is set; it cannot be cleared by writing status.
- **Latency**: Interrupt assertion within 2 clock cycles of triggering condition

2.1.6.7.13.3.9. Subsystem Wrapper

`telemetry_receiver_wrap` defaults to three receivers. It configures their queue depth with `TELEMETRY_RECEIVER_BUFFER_DEPTH` (default 8) and counter counts with `TELEMETRY_RECEIVER_MAX_NUM_COUNTERS_PER_MESSAGE` (default 4 per receiver). Actual subsystem values and aperture assignments come from the integration.

The wrapper receives ATB traffic on `clk_telemetry_i` / `rst_telemetry_ni` and crosses it into `clk_i` / `rst_ni` through an eight-entry asynchronous FIFO per receiver. Its external ready signal reflects crossing-FIFO capacity. This does not turn the core's decoded-message queue into a lossless backpressured queue. The wrapper also contains flush-handshake synchronizers and returns a decode error for register addresses outside its configured receiver apertures.

2.1.6.7.13.4. Memory Map and Register Reference

2.1.6.7.13.4.1. Memory Map

Each core occupies 256 bytes with 32-bit registers at four-byte offsets. Control, status, interrupt and message-header registers occupy `0x00`–`0x18`; 32 counter registers occupy `0x80`–`0xFC`. The wrapper map places each receiver in its integration-defined aperture. Reset values and field access types are specified below; reset and flush storage behavior is described in Architecture.

2.1.6.7.13.4.2. Detailed Register Map

2.1.6.7.13.4.2.1. Telemetry Receiver Address Map

Configuration, status, and data-buffer registers for a single telemetry receiver channel.

NOTE

Register Arrays:

- **TELEMETRY_COUNTER[32]**: 32 registers, base 0x80, stride 0x4

Table 2225. Telemetry Receiver Address Map register list

Address	Name	Access	Description
0x0	CTRL	RW	Control Register
0x4	STATUS	R	Status Register
0x8	INTR_STATUS	RW	Interrupt Status Register
0xC	INTR_ENABLE	RW	Interrupt Enable Register
0x10	INTR_TEST	RW	Interrupt Test Register
0x14	TELEMETRY_PROBE_ID	R	Telemetry Probe ID Register
0x18	TELEMETRY_COUNTER_VLDS	R	Telemetry Counter Valid Bits Register
0x80 - 0xFC	TELEMETRY_COUNTER[32]	R	Telemetry Counter Register

2.1.6.7.13.4.2.1.1. CTRL

Table 2226. telemetry_receiver.CTRL fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved
23:12	BUFFER_THRESHOLD	RW	0x0	Telemetry Message Buffer Threshold. The Telemetry Buffer Threshold Interrupt is asserted when the number of entries in the buffer is greater than this value. Only the low log2(queue depth)+1 bits are compared, so values alias modulo twice the queue depth, and only values below the queue depth can assert the interrupt.
11:9	Reserved	-	-	Reserved
8	TELEMETRY_TX_FLUSH	RW	0x0	Telemetry Transmitter Flush. Writing 1 flushes all FIFOs in the telemetry transmitter. The flushing is done via the ATB AF interface. This bit clears itself after the flush completes.
7:5	Reserved	-	-	Reserved
4	TELEMETRY_RX_FLUSH	W 1P	0x0	Telemetry Receiver Flush. Writing 1 discards queued messages and resets the assembly write pointer. Stored payload bytes are not cleared. In particular, a later short message can retain trailing counter values and validity from an earlier message. This operation does not erase storage.
3:1	Reserved	-	-	Reserved
0	BUFFER_POP	W 1P	0x0	Telemetry Message Buffer Pop. Effective only if STATUS.BUFFER_EMPTY = 0. Writing 1 pops the buffer and thus updates the data in the TELEMETRY_PROBE_ID, TELEMETRY_COUNTER_VLDS, and TELEMETRY_COUNTER[32] registers.

2.1.6.7.13.4.2.1.2. STATUS

Table 2227. telemetry_receiver.STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_FULL	R	0x0	Telemetry Message Buffer Full.
3:1	Reserved	-	-	Reserved
0	BUFFER_EMPTY	R	0x1	Telemetry Message Buffer Empty.

2.1.6.7.13.4.2.1.3. INTR_STATUS

Table 2228. telemetry_receiver.INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_THRESHOLD	R	0x0	Telemetry Message Buffer Threshold Interrupt. Asserted when the number of telemetry messages in the Telemetry Message Buffer is greater than CTRL.BUFFER_THRESHOLD.
3:1	Reserved	-	-	Reserved
0	MISSING_LAST	RW1C	0x0	Last Packet Missing Interrupt. Asserted when the Telemetry Receiver has not received a Last Packet flag when the maximum number of packets a message can consist of has been received.

2.1.6.7.13.4.2.1.4. INTR_ENABLE

Table 2229. telemetry_receiver.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_THRESHOLD	RW	0x0	Telemetry Message Buffer Threshold Interrupt Enable.
3:1	Reserved	-	-	Reserved
0	MISSING_LAST	RW	0x0	Last Packet Missing Interrupt Enable.

2.1.6.7.13.4.2.1.5. INTR_TEST

Table 2230. telemetry_receiver.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_THRESHOLD	RW	0x0	Telemetry Message Buffer Threshold Interrupt Test. Writing 1 forces the interrupt and writing 0 releases it.
3:1	Reserved	-	-	Reserved
0	MISSING_LAST	W 1P	0x0	Last Packet Missing Interrupt Test. Writing 1 forces the interrupt.

2.1.6.7.13.4.2.1.6. TELEMETRY_PROBE_ID

Table 2231. telemetry_receiver.TELEMETRY_PROBE_ID fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	PROBE_ID	R	0x0	Probe ID. Contains the Probe ID field of the telemetry message at the bottom of the Telemetry Message Buffer.

2.1.6.7.13.4.2.1.7. TELEMETRY_COUNTER_VLDS

Table 2232. telemetry_receiver.TELEMETRY_COUNTER_VLDS fields

Bits	Field	Access	Reset	Description
31:0	COUNTER_VLDS	R	0x0	Counter Valid Bits. Indicates which of the counter values in the telemetry message at the bottom of the Telemetry Message Buffer are valid. Bit i is for the i-th counter.

2.1.6.7.13.4.2.1.8. TELEMETRY_COUNTER[32]

Table 2233. telemetry_receiver.TELEMETRY_COUNTER[32] fields

Bits	Field	Access	Reset	Description
31:0	COUNTER	R	0x0	Counter Value. Contains one of the 32 counter values in the telemetry message at the bottom of the Telemetry Message Buffer.

2.1.6.7.13.4.2.2. Telemetry Receiver Wrapper Address Map

Wrapper address map instantiating the telemetry receiver channels.

NOTE

Register Arrays:

- **telemetry_receiver[3].CTRL**: 3 registers, base 0x0, stride 0x100
- **telemetry_receiver[3].STATUS**: 3 registers, base 0x4, stride 0x100
- **telemetry_receiver[3].INTR_STATUS**: 3 registers, base 0x8, stride 0x100
- **telemetry_receiver[3].INTR_ENABLE**: 3 registers, base 0xC, stride 0x100
- **telemetry_receiver[3].INTR_TEST**: 3 registers, base 0x10, stride 0x100
- **telemetry_receiver[3].TELEMETRY_PROBE_ID**: 3 registers, base 0x14, stride 0x100
- **telemetry_receiver[3].TELEMETRY_COUNTER_VLDS**: 3 registers, base 0x18, stride 0x100
- **telemetry_receiver[3].TELEMETRY_COUNTER[32]**: 96 registers, base 0x80 (telemetry_receiver x3 stride 0x100, TELEMETRY_COUNTER x32 stride 0x4)

Table 2234. Telemetry Receiver Wrapper Address Map register list

Address	Name	Access	Description
0x0 - 0x200	telemetry_receiver[3].CTRL	RW	Control Register
0x4 - 0x204	telemetry_receiver[3].STATUS	R	Status Register
0x8 - 0x208	telemetry_receiver[3].INTR_STATUS	RW	Interrupt Status Register
0xC - 0x20C	telemetry_receiver[3].INTR_ENABLE	RW	Interrupt Enable Register
0x10 - 0x210	telemetry_receiver[3].INTR_TEST	RW	Interrupt Test Register
0x14 - 0x214	telemetry_receiver[3].TELEMETRY_PROBE_ID	R	Telemetry Probe ID Register
0x18 - 0x218	telemetry_receiver[3].TELEMETRY_COUNTER_VLDS	R	Telemetry Counter Valid Bits Register
0x80 - 0x2FC	telemetry_receiver[3].TELEMETRY_COUNTER[32]	R	Telemetry Counter Register

2.1.6.7.13.4.2.2.1. telemetry_receiver[3].CTRL

Table 2235. telemetry_receiver_wrap.telemetry_receiver[3].CTRL fields

Bits	Field	Access	Reset	Description
31:24	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
23:12	BUFFER_THRESHOLD	RW	0x0	Telemetry Message Buffer Threshold. The Telemetry Buffer Threshold Interrupt is asserted when the number of entries in the buffer is greater than this value. Only the low log2(queue depth)+1 bits are compared, so values alias modulo twice the queue depth, and only values below the queue depth can assert the interrupt.
11:9	Reserved	-	-	Reserved
8	TELEMETRY_TX_FLUSH	RW	0x0	Telemetry Transmitter Flush. Writing 1 flushes all FIFOs in the telemetry transmitter. The flushing is done via the ATB AF interface. This bit clears itself after the flush completes.
7:5	Reserved	-	-	Reserved
4	TELEMETRY_RX_FLUSH	W 1P	0x0	Telemetry Receiver Flush. Writing 1 discards queued messages and resets the assembly write pointer. Stored payload bytes are not cleared. In particular, a later short message can retain trailing counter values and validity from an earlier message. This operation does not erase storage.
3:1	Reserved	-	-	Reserved
0	BUFFER_POP	W 1P	0x0	Telemetry Message Buffer Pop. Effective only if STATUS.BUFFER_EMPTY = 0. Writing 1 pops the buffer and thus updates the data in the TELEMETRY_PROBE_ID, TELEMETRY_COUNTER_VLDS, and TELEMETRY_COUNTER[32] registers.

2.1.6.7.13.4.2.2.2. telemetry_receiver[3].STATUS

Table 2236. telemetry_receiver_wrap.telemetry_receiver[3].STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_FULL	R	0x0	Telemetry Message Buffer Full.
3:1	Reserved	-	-	Reserved
0	BUFFER_EMPTY	R	0x1	Telemetry Message Buffer Empty.

2.1.6.7.13.4.2.2.3. telemetry_receiver[3].INTR_STATUS

Table 2237. telemetry_receiver_wrap.telemetry_receiver[3].INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_THRESHOLD	R	0x0	Telemetry Message Buffer Threshold Interrupt. Asserted when the number of telemetry messages in the Telemetry Message Buffer is greater than CTRL.BUFFER_THRESHOLD.
3:1	Reserved	-	-	Reserved
0	MISSING_LAST	RW1C	0x0	Last Packet Missing Interrupt. Asserted when the Telemetry Receiver has not received a Last Packet flag when the maximum number of packets a message can consist of has been received.

2.1.6.7.13.4.2.2.4. telemetry_receiver[3].INTR_ENABLE

Table 2238. telemetry_receiver_wrap.telemetry_receiver[3].INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_THRESHOLD	RW	0x0	Telemetry Message Buffer Threshold Interrupt Enable.

Bits	Field	Access	Reset	Description
3:1	Reserved	-	-	Reserved
0	MISSING_LAST	RW	0x0	Last Packet Missing Interrupt Enable.

2.1.6.7.13.4.2.2.5. telemetry_receiver[3].INTR_TEST

Table 2239. telemetry_receiver_wrap.telemetry_receiver[3].INTR_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	BUFFER_THRESHOLD	RW	0x0	Telemetry Message Buffer Threshold Interrupt Test. Writing 1 forces the interrupt and writing 0 releases it.
3:1	Reserved	-	-	Reserved
0	MISSING_LAST	W 1P	0x0	Last Packet Missing Interrupt Test. Writing 1 forces the interrupt.

2.1.6.7.13.4.2.2.6. telemetry_receiver[3].TELEMETRY_PROBE_ID

Table 2240. telemetry_receiver_wrap.telemetry_receiver[3].TELEMETRY_PROBE_ID fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4:0	PROBE_ID	R	0x0	Probe ID. Contains the Probe ID field of the telemetry message at the bottom of the Telemetry Message Buffer.

2.1.6.7.13.4.2.2.7. telemetry_receiver[3].TELEMETRY_COUNTER_VLDS

Table 2241. telemetry_receiver_wrap.telemetry_receiver[3].TELEMETRY_COUNTER_VLDS fields

Bits	Field	Access	Reset	Description
31:0	COUNTER_VLDS	R	0x0	Counter Valid Bits. Indicates which of the counter values in the telemetry message at the bottom of the Telemetry Message Buffer are valid. Bit i is for the i-th counter.

2.1.6.7.13.4.2.2.8. telemetry_receiver[3].TELEMETRY_COUNTER[32]

Table 2242. telemetry_receiver_wrap.telemetry_receiver[3].TELEMETRY_COUNTER[32] fields

Bits	Field	Access	Reset	Description
31:0	COUNTER	R	0x0	Counter Value. Contains one of the 32 counter values in the telemetry message at the bottom of the Telemetry Message Buffer.

2.1.6.7.14. UART and Log Engine Wrapper Registers

The wrapper maps include the UART and log-engine control registers and their composed register banks. Offsets are relative to each wrapper's base address.

2.1.6.7.14.1. UART Wrapper Address Map

Wrapper address map instantiating the per-UART log-engine blocks.

NOTE	**Register Arrays:**

- **uart_log_engine_wrap[4].uart_log_engine_ctrl.CTRL**: 4 registers, base 0x0, stride 0x400
- **uart_log_engine_wrap[4].uart.RBR**: 4 registers, base 0x100, stride 0x400
- **uart_log_engine_wrap[4].uart.IER**: 4 registers, base 0x104, stride 0x400
- **uart_log_engine_wrap[4].uart.IIR**: 4 registers, base 0x108, stride 0x400
- **uart_log_engine_wrap[4].uart.LCR**: 4 registers, base 0x10C, stride 0x400
- **uart_log_engine_wrap[4].uart.MCR**: 4 registers, base 0x110, stride 0x400
- **uart_log_engine_wrap[4].uart.LSR**: 4 registers, base 0x114, stride 0x400
- **uart_log_engine_wrap[4].uart.MSR**: 4 registers, base 0x118, stride 0x400
- **uart_log_engine_wrap[4].uart.SCR**: 4 registers, base 0x11C, stride 0x400
- **uart_log_engine_wrap[4].uart.ECR**: 4 registers, base 0x120, stride 0x400
- **uart_log_engine_wrap[4].uart.ITR**: 4 registers, base 0x124, stride 0x400
- **uart_log_engine_wrap[4].log_engine.CTRL**: 4 registers, base 0x200, stride 0x400
- **uart_log_engine_wrap[4].log_engine.LOG_REGION_SIZE**: 4 registers, base 0x204, stride 0x400
- **uart_log_engine_wrap[4].log_engine.LOG_REGION_ADDR**: 4 registers, base 0x208, stride 0x400
- **uart_log_engine_wrap[4].log_engine.LOG_WRITE_ADDR**: 4 registers, base 0x210, stride 0x400
- **uart_log_engine_wrap[4].log_engine.INTR_STATUS**: 4 registers, base 0x214, stride 0x400
- **uart_log_engine_wrap[4].log_engine.INTR_ENABLE**: 4 registers, base 0x218, stride 0x400
- **uart_log_engine_wrap[4].log_engine.INTR_TEST**: 4 registers, base 0x21C, stride 0x400
- **uart_log_engine_wrap[4].log_engine.LOG_CTRL[16]**: 64 registers, base 0x240 (uart_log_engine_wrap x4 stride 0x400, LOG_CTRL x16 stride 0x4)

Table 2243. UART Wrapper Address Map register list

Address	Name	Access	Description
0x0 - 0xC00	uart_log_engine_wrap[4].uart_log_engine_ctrl.CTRL	RW	Control Register
0x100 - 0xD00	uart_log_engine_wrap[4].uart.RBR	R	Receiver Buffer Register
0x104 - 0xD04	uart_log_engine_wrap[4].uart.IER	RW	Interrupt Enable Register
0x108 - 0xD08	uart_log_engine_wrap[4].uart.IIR	R	Interrupt Identification Register
0x10C - 0xD0C	uart_log_engine_wrap[4].uart.LCR	RW	Line Control Register
0x110 - 0xD10	uart_log_engine_wrap[4].uart.MCR	RW	Modem Control Register
0x114 - 0xD14	uart_log_engine_wrap[4].uart.LSR	R	Line Status Register
0x118 - 0xD18	uart_log_engine_wrap[4].uart.MSR	R	Modem Status Register
0x11C - 0xD1C	uart_log_engine_wrap[4].uart.SCR	RW	Scratch Register
0x120 - 0xD20	uart_log_engine_wrap[4].uart.ECR	RW	Extended Control Register

Address	Name	Access	Description
0x124 - 0xD24	uart_log_engine_wrap[4].uart.ITR	RW	Interrupt Test Register
0x200 - 0xE00	uart_log_engine_wrap[4].log_engine.CTRL	RW	Control Register
0x204 - 0xE04	uart_log_engine_wrap[4].log_engine.LOG_REGION_SIZE	RW	Log Region Size Register
0x208 - 0xE08	uart_log_engine_wrap[4].log_engine.LOG_REGION_ADDR	RW	Log Region Address Register
0x210 - 0xE10	uart_log_engine_wrap[4].log_engine.LOG_WRITE_ADDR	RW	Log Write Address Register
0x214 - 0xE14	uart_log_engine_wrap[4].log_engine.INTR_STATUS	RW	Interrupt Status Register
0x218 - 0xE18	uart_log_engine_wrap[4].log_engine.INTR_ENABLE	RW	Interrupt Enable Register
0x21C - 0xE1C	uart_log_engine_wrap[4].log_engine.INTR_TEST	W	Interrupt Test Register
0x240 - 0xE7C	uart_log_engine_wrap[4].log_engine.LOG_CTRL[16]	RW	Log Control Register

2.1.6.7.14.1.1. uart_log_engine_wrap[4].uart_log_engine_ctrl.CTRL

Table 2244. uart_wrap.uart_log_engine_wrap[4].uart_log_engine_ctrl.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	UART_EN	RW	0x0	UART Enable. When set, the pad-mux downstream will be forced to accept UART traffic.

2.1.6.7.14.1.2. uart_log_engine_wrap[4].uart.RBR

Table 2245. uart_wrap.uart_log_engine_wrap[4].uart.RBR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R RMOD	0x0	Received Data. Contains a received character. If FIFOs are enabled, this field points to the bottom of the RX FIFO. Otherwise, this field points to a single- byte Receiver Buffer Register.

2.1.6.7.14.1.3. uart_log_engine_wrap[4].uart.IER

Table 2246. uart_wrap.uart_log_engine_wrap[4].uart.IER fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	EFEI	RW	0x0	Enable FIFO Error Interrupt.
3	EDSSI	RW	0x0	Enable (Delta Status of) Modem Status Interrupt.
2	ELSI	RW	0x0	Enable (Receiver) Line Status Interrupt.
1	ETBEI	RW	0x0	Enable Transmitter Buffer Empty (Transmitter Holding Register Empty) Interrupt.
0	ERBFI	RW	0x0	Enable Receiver Buffer Full (Received Data Ready) Interrupt.

2.1.6.7.14.1.4. uart_log_engine_wrap[4].uart.IIR

Table 2247. uart_wrap.uart_log_engine_wrap[4].uart.IIR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:6	FIFOS_ENABLED	R	0x0	FIFOs Enabled: * 0x0 - FIFOs are disabled * 0x3 - FIFOs are enabled
5:4	Reserved	-	-	Reserved
3:1	INTERRUPT_ID	R	0x0	Interrupt ID: * 0x7 - FIFO Error Interrupt (priority 0) * 0x3 - Receiver Line Status Interrupt (priority 1) * 0x6 - Reception Timeout Interrupt (priority 2) * 0x2 - Received Data Ready Interrupt (priority 3) * 0x1 - Transmitter Holding Register Empty Interrupt (priority 4) * 0x0 - Modem Status Interrupt (priority 5)
0	INTERRUPT_PENDING	R	0x1	Interrupt Pending. Active-low.

2.1.6.7.14.1.5. uart_log_engine_wrap[4].uart.LCR

Table 2248. uart_wrap.uart_log_engine_wrap[4].uart.LCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	DLAB	RW	0x0	Divisor Latch Access Bit. If set, allows access to the DLL and DLM registers when accessing addresses 0x0 and 0x4, respectively. If unset, allows access to the THR, RBR, and IIR registers.
6	SET_BREAK	RW	0x0	Set Break. If set, forces the tx_o output to 0 to cause a break condition on the receiving UART.
5	STICK_PARITY	RW	0x0	Stick Parity. If set, forces the transmit and received parity bits to be 0 if even parity is selected and 1 if odd parity is selected.
4	EPS	RW	0x0	Even Parity Select: * 1 - even parity * 0 - odd parity
3	PEN	RW	0x0	Parity Enable.
2	STB	RW	0x0	Stop Bits: * 0 - 1 stop bit. * 1 - 2 stop bits (or 1.5 stop bits if word length is set to 5 bits)
1:0	WLS	RW	0x0	Word Length Select: * 0x0 - 5 bits per character * 0x1 - 6 bits per character * 0x2 - 7 bits per character * 0x3 - 8 bits per character

2.1.6.7.14.1.6. uart_log_engine_wrap[4].uart.MCR

Table 2249. uart_wrap.uart_log_engine_wrap[4].uart.MCR fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	LINE_LOOPBACK	RW	0x0	Line Loopback. If set, the rx_i input is internally connected to the tx_o output.
4	LOOP	RW	0x0	System Loopback. If set, the transmitter is internally connected to the receiver. The tx_o output is set to 1.
3	OUT2	RW	0x0	User Output 2. Writing to this bit drives the out2_no in the opposite polarity.
2	OUT1	RW	0x0	User Output 1. Writing to this bit drives the out1_no in the opposite polarity.
1	RTS	RW	0x0	Request to Send. Writing to this bit drives the rts_no output in the opposite polarity.
0	DTR	RW	0x0	Data Terminal Ready. Writing to this bit drives the dtr_no output in the opposite polarity.

2.1.6.7.14.1.7. uart_log_engine_wrap[4].uart.LSR

Table 2250. uart_wrap.uart_log_engine_wrap[4].uart.LSR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ERROR_IN_RCVR_FIFO	R	0x0	Error in Receiver FIFO. When set, indicates that the receiver FIFO or (RBR in non-FIFO mode) has the parity, framing, or break error. In other words, at least one of the PE, FE, and BI bits is set.
6	TEMT	R	0x1	Transmitter Empty. When set, indicates that the transmitter shift register and the transmitter FIFO (or THR in non-FIFO mode) are empty.
5	THRE	R	0x1	Transmitter Holding Register Empty. When set, indicates that the TX FIFO (or THR in non-FIFO mode) is empty. Clearing the Transmitter Holding Register Empty Interrupt does NOT clear this bit.
4	BI	R RC	0x0	Break Interrupt. When set, indicates that the rx_i input is 0 for an entire frame's time (start + data + parity + stop bits). In FIFO mode, this bit set when the character reaches the top of the receiver FIFO. In non-FIFO mode, this bit is set when the character enters the RBR. This bit triggers the Receiver Line Status Interrupt.
3	FE	R RC	0x0	Framing Error. When set, indicates that the received character is missing a stop bit. In FIFO mode, this bit is set when the character reaches the top of the FIFO. In non-FIFO mode, this bit is set when the character enters the RBR. This bit triggers the Receiver Line Status Interrupt.
2	PE	R RC	0x0	Parity Error. When set, indicates that the character at the top of the receiver FIFO (or RBR in non-FIFO mode) has a parity error. This bit triggers the Receiver Line Status Interrupt.
1	OE	R RC	0x0	Overrun Error. When set, indicates that the RX FIFO (or Receiver Buffer Register in Non-FIFO Mode) is full when new character is received. In FIFO Mode, the new character is dropped. In non-FIFO mode, the existing character in the RBR is overwritten. This bit triggers the Receiver Line Status Interrupt.
0	DR	R	0x0	Data Ready. When set, indicates that the RX FIFO (or RBR in non-FIFO mode) contains data.

2.1.6.7.14.1.8. uart_log_engine_wrap[4].uart.MSR

Table 2251. uart_wrap.uart_log_engine_wrap[4].uart.MSR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	DCD	R	0x0	Data Carrier Detect. This bit reflects the dcd_ni input in the opposite polarity, so it reads 1 while a carrier is detected.
6	RI	R	0x0	Ring Indicator. This bit reflects the ri_ni input in the opposite polarity, so it reads 1 while the remote modem signals an incoming call.
5	DSR	R	0x0	Data Set Ready. This bit reflects the dsr_ni input in the opposite polarity, so it reads 1 while the remote modem is connected and ready.
4	CTS	R	0x0	Clear to Send. This bit reflects the cts_ni input in the opposite polarity, so it reads 1 while the remote device is ready to receive data.
3	DDCD	R RC	0x0	Delta Data Carrier Detect. When set, indicates that the DCD bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.
2	TERI	R RC	0x0	Trailing Edge Ring Indicator. When set, indicates that the RI bit has changed from a 1 to a 0. This bit triggers the Modem Status Interrupt.

Bits	Field	Access	Reset	Description
1	DDSR	R RC	0x0	Delta Data Set Ready. When set, indicates that the DSR bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.
0	DCTS	R RC	0x0	Delta Clear to Send. When set, indicates that the CTS bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.

2.1.6.7.14.1.9. uart_log_engine_wrap[4].uart.SCR

Table 2252. uart_wrap.uart_log_engine_wrap[4].uart.SCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	SCR	RW	0x0	Scratch. Holds user data.

2.1.6.7.14.1.10. uart_log_engine_wrap[4].uart.ECR

Table 2253. uart_wrap.uart_log_engine_wrap[4].uart.ECR fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1:0	RCVR_TRIGGER_MS2B	RW	0x0	Receiver FIFO Trigger Level Most Significant 2 Bits. To configure the least significant 2 bits, use the FCR.RCVR_TRIGGER register field. The configurations for the trigger levels are: * 0x0 - 1 character * 0x1 - 4 characters * 0x2 - 8 characters * 0x3 - 14 characters * 0x4 - 32 characters * 0x5 - 64 characters * 0x6 - 128 characters * 0x7 - 256 characters * 0x8 - 512 characters * 0x9 - 1024 characters * 0xA - 2048 characters * 0xB - 4096 characters

2.1.6.7.14.1.11. uart_log_engine_wrap[4].uart.ITR

Table 2254. uart_wrap.uart_log_engine_wrap[4].uart.ITR fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	TRTI	RW	0x0	Test Reception Timeout Interrupt. Writing a 1 forces the interrupt and writing 0 releases it.
4	TFEI	RW	0x0	Test FIFO Error Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
3	TDSSI	RW	0x0	Test (Delta Status of) Modem Status Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
2	TLSI	RW	0x0	Test (Receiver) Line Status Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
1	TTBEI	RW	0x0	Test Transmitter Buffer Empty (Transmitter Holding Register Empty) Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
0	TRBFI	RW	0x0	Test Receiver Buffer Full (Received Data Ready) Interrupt. Writing 1 forces the interrupt and writing 0 releases it.

2.1.6.7.14.1.12. uart_log_engine_wrap[4].log_engine.CTRL

Table 2255. uart_wrap.uart_log_engine_wrap[4].log_engine.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
0	EN	RW	0x0	Log Engine Enable. When set, enables the Log Engine. When cleared, the engine stops fetching and writing, discards buffered log data and resets transfer progress. Configuration and pending LOG_LEN values are retained, so a pending entry restarts from the start of its slot when the engine is enabled again. Clearing does not wait for outstanding bus responses.

2.1.6.7.14.1.13. uart_log_engine_wrap[4].log_engine.LOG_REGION_SIZE

Table 2256. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_REGION_SIZE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	LOG_REGION_SIZE	RW	0x0	Log region size in bytes. Supported values are at most 512 KiB and aligned to 128 bytes (16 slots times the 8-byte fetch beat). If software programs a larger value, RTL clamps the effective region to 512 KiB. For a value that is not 128-byte aligned, RTL divides the effective region among the 16 slots and rounds each slot's transferable capacity down to complete 8-byte fetch beats. A requested LOG_LEN above that capacity is clamped to the capacity.

2.1.6.7.14.1.14. uart_log_engine_wrap[4].log_engine.LOG_REGION_ADDR

Table 2257. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_REGION_ADDR fields

Bits	Field	Access	Reset	Description
63:56	RESERVED	R	0x0	Reserved. Reads as zero; writes are ignored.
55:32	LOG_REGION_ADDR_HI	RW	0x0	Log Region Start Address High. Contains fabric address bits [55:32].
31:0	LOG_REGION_ADDR_LO	RW	0x0	Log Region Start Address Low.

2.1.6.7.14.1.15. uart_log_engine_wrap[4].log_engine.LOG_WRITE_ADDR

Table 2258. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_WRITE_ADDR fields

Bits	Field	Access	Reset	Description
31:0	LOG_WRITE_ADDR	RW	0x0	Log Write Address. This is the address where the log data is written to.

2.1.6.7.14.1.16. uart_log_engine_wrap[4].log_engine.INTR_STATUS

Table 2259. uart_wrap.uart_log_engine_wrap[4].log_engine.INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	RW1C	0x0	Log Write Error Interrupt. Asserted when the bus for writing log data returns an error.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	RW1C	0x0	Log Fetch Error Interrupt. Asserted when the bus for fetching log data returns an error.

2.1.6.7.14.1.17. uart_log_engine_wrap[4].log_engine.INTR_ENABLE

Table 2260. uart_wrap.uart_log_engine_wrap[4].log_engine.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	RW	0x0	Log Write Error Interrupt Enable.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	RW	0x0	Log Fetch Error Interrupt Enable.

2.1.6.7.14.1.18. uart_log_engine_wrap[4].log_engine.INTR_TEST

Table 2261. uart_wrap.uart_log_engine_wrap[4].log_engine.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	W 1P	0x0	Log Write Error Interrupt Test. Writing 1 forces the interrupt.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	W 1P	0x0	Log Fetch Error Interrupt Test. Writing 1 forces the interrupt.

2.1.6.7.14.1.19. uart_log_engine_wrap[4].log_engine.LOG_CTRL[16]

Table 2262. uart_wrap.uart_log_engine_wrap[4].log_engine.LOG_CTRL[16] fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	LOG_LEN	RW	0x0	Log Length. Writing a nonzero value representing the log length in bytes to this field starts the log transfer process. The field holds the requested length until the transfer completes, when hardware clears it to zero; it is not a remaining-byte counter. There are 16 copies of this register, each representing a log entry. The log entries go through round robin arbitration.

2.1.6.7.14.2. UART Log Engine Control Address Map

Top-level enable register for the UART log-engine block.

Table 2263. UART Log Engine Control Address Map register list

Address	Name	Access	Description
0x0	CTRL	RW	Control Register

2.1.6.7.14.2.1. CTRL

Table 2264. uart_log_engine_ctrl.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	UART_EN	RW	0x0	UART Enable. When set, the pad-mux downstream will be forced to accept UART traffic.

2.1.6.7.14.3. UART Log Engine Wrapper Address Map

Composes the UART 16550 core, log engine, and their control registers for one UART instance.

NOTE **Register Arrays:**

- **LOG_CTRL[16]**: 16 registers, base 0x240, stride 0x4

Table 2265. UART Log Engine Wrapper Address Map register list

Address	Name	Access	Description
0x0	uart_log_engine_ctrl.CTRL	RW	Control Register
0x100	RBR	R	Receiver Buffer Register
0x104	IER	RW	Interrupt Enable Register
0x108	IIR	R	Interrupt Identification Register
0x10C	LCR	RW	Line Control Register
0x110	MCR	RW	Modem Control Register
0x114	LSR	R	Line Status Register
0x118	MSR	R	Modem Status Register
0x11C	SCR	RW	Scratch Register
0x120	ECR	RW	Extended Control Register
0x124	ITR	RW	Interrupt Test Register
0x200	log_engine.CTRL	RW	Control Register
0x204	LOG_REGION_SIZE	RW	Log Region Size Register
0x208	LOG_REGION_ADDR	RW	Log Region Address Register
0x210	LOG_WRITE_ADDR	RW	Log Write Address Register
0x214	INTR_STATUS	RW	Interrupt Status Register
0x218	INTR_ENABLE	RW	Interrupt Enable Register
0x21C	INTR_TEST	W	Interrupt Test Register
0x240 - 0x27C	LOG_CTRL[16]	RW	Log Control Register

2.1.6.7.14.3.1. uart_log_engine_ctrl.CTRL

Table 2266. uart_log_engine_wrap.uart_log_engine_ctrl.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	UART_EN	RW	0x0	UART Enable. When set, the pad-mux downstream will be forced to accept UART traffic.

2.1.6.7.14.3.2. RBR

Table 2267. uart_log_engine_wrap.RBR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	DATA	R RMOD	0x0	Received Data. Contains a received character. If FIFOs are enabled, this field points to the bottom of the RX FIFO. Otherwise, this field points to a single- byte Receiver Buffer Register.

2.1.6.7.14.3.3. IER

Table 2268. uart_log_engine_wrap.IER fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	EFEI	RW	0x0	Enable FIFO Error Interrupt.
3	EDSSI	RW	0x0	Enable (Delta Status of) Modem Status Interrupt.
2	ELSI	RW	0x0	Enable (Receiver) Line Status Interrupt.
1	ETBEI	RW	0x0	Enable Transmitter Buffer Empty (Transmitter Holding Register Empty) Interrupt.
0	ERBFI	RW	0x0	Enable Receiver Buffer Full (Received Data Ready) Interrupt.

2.1.6.7.14.3.4. IIR

Table 2269. uart_log_engine_wrap.IIR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:6	FIFOS_ENABLED	R	0x0	FIFOs Enabled: * 0x0 - FIFOs are disabled * 0x3 - FIFOs are enabled
5:4	Reserved	-	-	Reserved
3:1	INTERRUPT_ID	R	0x0	Interrupt ID: * 0x7 - FIFO Error Interrupt (priority 0) * 0x3 - Receiver Line Status Interrupt (priority 1) * 0x6 - Reception Timeout Interrupt (priority 2) * 0x2 - Received Data Ready Interrupt (priority 3) * 0x1 - Transmitter Holding Register Empty Interrupt (priority 4) * 0x0 - Modem Status Interrupt (priority 5)
0	INTERRUPT_PENDING	R	0x1	Interrupt Pending. Active-low.

2.1.6.7.14.3.5. LCR

Table 2270. uart_log_engine_wrap.LCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	DLAB	RW	0x0	Divisor Latch Access Bit. If set, allows access to the DLL and DLM registers when accessing addresses 0x0 and 0x4, respectively. If unset, allows access to the THR, RBR, and IIR registers.
6	SET_BREAK	RW	0x0	Set Break. If set, forces the tx_o output to 0 to cause a break condition on the receiving UART.
5	STICK_PARITY	RW	0x0	Stick Parity. If set, forces the transmit and received parity bits to be 0 if even parity is selected and 1 if odd parity is selected.
4	EPS	RW	0x0	Even Parity Select: * 1 - even parity * 0 - odd parity
3	PEN	RW	0x0	Parity Enable.
2	STB	RW	0x0	Stop Bits: * 0 - 1 stop bit. * 1 - 2 stop bits (or 1.5 stop bits if word length is set to 5 bits)
1:0	WLS	RW	0x0	Word Length Select: * 0x0 - 5 bits per character * 0x1 - 6 bits per character * 0x2 - 7 bits per character * 0x3 - 8 bits per character

2.1.6.7.14.3.6. MCR

Table 2271. uart_log_engine_wrap.MCR fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
5	LINE_LOOPBACK	RW	0x0	Line Loopback. If set, the rx_i input is internally connected to the tx_o output.
4	LOOP	RW	0x0	System Loopback. If set, the transmitter is internally connected to the receiver. The tx_o output is set to 1.
3	OUT2	RW	0x0	User Output 2. Writing to this bit drives the out2_no in the opposite polarity.
2	OUT1	RW	0x0	User Output 1. Writing to this bit drives the out1_no in the opposite polarity.
1	RTS	RW	0x0	Request to Send. Writing to this bit drives the rts_no output in the opposite polarity.
0	DTR	RW	0x0	Data Terminal Ready. Writing to this bit drives the dtr_no output in the opposite polarity.

2.1.6.7.14.3.7. LSR

Table 2272. uart_log_engine_wrap.LSR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ERROR_IN_RCVR_FIFO	R	0x0	Error in Receiver FIFO. When set, indicates that the receiver FIFO or (RBR in non-FIFO mode) has the parity, framing, or break error. In other words, at least one of the PE, FE, and BI bits is set.
6	TEMT	R	0x1	Transmitter Empty. When set, indicates that the transmitter shift register and the transmitter FIFO (or THR in non-FIFO mode) are empty.
5	THRE	R	0x1	Transmitter Holding Register Empty. When set, indicates that the TX FIFO (or THR in non-FIFO mode) is empty. Clearing the Transmitter Holding Register Empty Interrupt does NOT clear this bit.
4	BI	R RC	0x0	Break Interrupt. When set, indicates that the rx_i input is 0 for an entire frame's time (start + data + parity + stop bits). In FIFO mode, this bit set when the character reaches the top of the receiver FIFO. In non-FIFO mode, this bit is set when the character enters the RBR. This bit triggers the Receiver Line Status Interrupt.
3	FE	R RC	0x0	Framing Error. When set, indicates that the received character is missing a stop bit. In FIFO mode, this bit is set when the character reaches the top of the FIFO. In non-FIFO mode, this bit is set when the character enters the RBR. This bit triggers the Receiver Line Status Interrupt.
2	PE	R RC	0x0	Parity Error. When set, indicates that the character at the top of the receiver FIFO (or RBR in non-FIFO mode) has a parity error. This bit triggers the Receiver Line Status Interrupt.
1	OE	R RC	0x0	Overrun Error. When set, indicates that the RX FIFO (or Receiver Buffer Register in Non-FIFO Mode) is full when new character is received. In FIFO Mode, the new character is dropped. In non-FIFO mode, the existing character in the RBR is overwritten. This bit triggers the Receiver Line Status Interrupt.
0	DR	R	0x0	Data Ready. When set, indicates that the RX FIFO (or RBR in non-FIFO mode) contains data.

2.1.6.7.14.3.8. MSR

Table 2273. uart_log_engine_wrap.MSR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	DCD	R	0x0	Data Carrier Detect. This bit reflects the dcd_ni input in the opposite polarity, so it reads 1 while a carrier is detected.

Bits	Field	Access	Reset	Description
6	RI	R	0x0	Ring Indicator. This bit reflects the ri_ni input in the opposite polarity, so it reads 1 while the remote modem signals an incoming call.
5	DSR	R	0x0	Data Set Ready. This bit reflects the dsr_ni input in the opposite polarity, so it reads 1 while the remote modem is connected and ready.
4	CTS	R	0x0	Clear to Send. This bit reflects the cts_ni input in the opposite polarity, so it reads 1 while the remote device is ready to receive data.
3	DDCD	R RC	0x0	Delta Data Carrier Detect. When set, indicates that the DCD bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.
2	TERI	R RC	0x0	Trailing Edge Ring Indicator. When set, indicates that the RI bit has changed from a 1 to a 0. This bit triggers the Modem Status Interrupt.
1	DDSR	R RC	0x0	Delta Data Set Ready. When set, indicates that the DSR bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.
0	DCTS	R RC	0x0	Delta Clear to Send. When set, indicates that the CTS bit has changed since the last time this register was read. This bit triggers the Modem Status Interrupt.

2.1.6.7.14.3.9. SCR

Table 2274. uart_log_engine_wrap.SCR fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	SCR	RW	0x0	Scratch. Holds user data.

2.1.6.7.14.3.10. ECR

Table 2275. uart_log_engine_wrap.ECR fields

Bits	Field	Access	Reset	Description
31:2	Reserved	-	-	Reserved
1:0	RCVR_TRIGGER_MS2B	RW	0x0	Receiver FIFO Trigger Level Most Significant 2 Bits. To configure the least significant 2 bits, use the FCR.RCVR_TRIGGER register field. The configurations for the trigger levels are: * 0x0 - 1 character * 0x1 - 4 characters * 0x2 - 8 characters * 0x3 - 14 characters * 0x4 - 32 characters * 0x5 - 64 characters * 0x6 - 128 characters * 0x7 - 256 characters * 0x8 - 512 characters * 0x9 - 1024 characters * 0xA - 2048 characters * 0xB - 4096 characters

2.1.6.7.14.3.11. ITR

Table 2276. uart_log_engine_wrap.ITR fields

Bits	Field	Access	Reset	Description
31:6	Reserved	-	-	Reserved
5	TRTI	RW	0x0	Test Reception Timeout Interrupt. Writing a 1 forces the interrupt and writing 0 releases it.
4	TFEI	RW	0x0	Test FIFO Error Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
3	TDSSI	RW	0x0	Test (Delta Status of) Modem Status Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
2	TLSI	RW	0x0	Test (Receiver) Line Status Interrupt. Writing 1 forces the interrupt and writing 0 releases it.

Bits	Field	Access	Reset	Description
1	TTBEI	RW	0x0	Test Transmitter Buffer Empty (Transmitter Holding Register Empty) Interrupt. Writing 1 forces the interrupt and writing 0 releases it.
0	TRBFI	RW	0x0	Test Receiver Buffer Full (Received Data Ready) Interrupt. Writing 1 forces the interrupt and writing 0 releases it.

2.1.6.7.14.3.12. log_engine.CTRL

Table 2277. uart_log_engine_wrap.log_engine.CTRL fields

Bits	Field	Access	Reset	Description
31:1	Reserved	-	-	Reserved
0	EN	RW	0x0	Log Engine Enable. When set, enables the Log Engine. When cleared, the engine stops fetching and writing, discards buffered log data and resets transfer progress. Configuration and pending LOG_LEN values are retained, so a pending entry restarts from the start of its slot when the engine is enabled again. Clearing does not wait for outstanding bus responses.

2.1.6.7.14.3.13. LOG_REGION_SIZE

Table 2278. uart_log_engine_wrap.LOG_REGION_SIZE fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	LOG_REGION_SIZE	RW	0x0	Log region size in bytes. Supported values are at most 512 KiB and aligned to 128 bytes (16 slots times the 8-byte fetch beat). If software programs a larger value, RTL clamps the effective region to 512 KiB. For a value that is not 128-byte aligned, RTL divides the effective region among the 16 slots and rounds each slot's transferable capacity down to complete 8-byte fetch beats. A requested LOG_LEN above that capacity is clamped to the capacity.

2.1.6.7.14.3.14. LOG_REGION_ADDR

Table 2279. uart_log_engine_wrap.LOG_REGION_ADDR fields

Bits	Field	Access	Reset	Description
63:56	RESERVED	R	0x0	Reserved. Reads as zero; writes are ignored.
55:32	LOG_REGION_ADDR_HI	RW	0x0	Log Region Start Address High. Contains fabric address bits [55:32].
31:0	LOG_REGION_ADDR_LO	RW	0x0	Log Region Start Address Low.

2.1.6.7.14.3.15. LOG_WRITE_ADDR

Table 2280. uart_log_engine_wrap.LOG_WRITE_ADDR fields

Bits	Field	Access	Reset	Description
31:0	LOG_WRITE_ADDR	RW	0x0	Log Write Address. This is the address where the log data is written to.

2.1.6.7.14.3.16. INTR_STATUS

Table 2281. uart_log_engine_wrap.INTR_STATUS fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
4	LOG_WRITE_ERR	RW1C	0x0	Log Write Error Interrupt. Asserted when the bus for writing log data returns an error.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	RW1C	0x0	Log Fetch Error Interrupt. Asserted when the bus for fetching log data returns an error.

2.1.6.7.14.3.17. INTR_ENABLE

Table 2282. uart_log_engine_wrap.INTR_ENABLE fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	RW	0x0	Log Write Error Interrupt Enable.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	RW	0x0	Log Fetch Error Interrupt Enable.

2.1.6.7.14.3.18. INTR_TEST

Table 2283. uart_log_engine_wrap.INTR_TEST fields

Bits	Field	Access	Reset	Description
31:5	Reserved	-	-	Reserved
4	LOG_WRITE_ERR	W 1P	0x0	Log Write Error Interrupt Test. Writing 1 forces the interrupt.
3:1	Reserved	-	-	Reserved
0	LOG_FETCH_ERR	W 1P	0x0	Log Fetch Error Interrupt Test. Writing 1 forces the interrupt.

2.1.6.7.14.3.19. LOG_CTRL[16]

Table 2284. uart_log_engine_wrap.LOG_CTRL[16] fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	LOG_LEN	RW	0x0	Log Length. Writing a nonzero value representing the log length in bytes to this field starts the log transfer process. The field holds the requested length until the transfer completes, when hardware clears it to zero; it is not a remaining-byte counter. There are 16 copies of this register, each representing a log entry. The log entries go through round robin arbitration.

2.1.6.7.15. Peripheral Parameter Settings

The SMC sets peripheral parameters at instantiation from `smc_config_pkg`, `smc_pkg`, and the padring package; these are the authoritative sources. Most values match the IP defaults, but the following differ from the default documented in the IP's own section.

Table 2285 compares the SMC parameter overrides with each peripheral's default values.

Table 2285. SMC Peripheral Parameter Overrides

Peripheral	Parameter	IP default	SMC value
Mailbox	smc_pkg::NumMailboxes	2	32

Peripheral	Parameter	IP default	SMC value
Mailbox	`smc_pkg::MailboxDepth`	8	2
I2C	`smc_config_pkg::I2cTargetRxFifoDepth`	268	64
I3C	`smc_config_pkg::NumI3c`	2	6
GPIO	`MAX_TRANS` (threaded from the `smc` module parameter)	32	2
GPIO	`INPUT_BY_DEFAULT` (per instance, from `smc_padring_pkg::DefaultDirectionMap`)	input on all	input on 62 of 65 GPIOs, output on the remaining 3
UART 16550	`smc_config_pkg::UartTxFifoDepth`	16	32
UART 16550	`smc_config_pkg::UartRxFifoDepth`	16	32

The System Timer OCTS takes no parameters. The eFuse overrides only bus widths and interface types. The Log Engine, AVSBus Controller, and Telemetry Receiver are configured explicitly through `smc_config_pkg`, but at values equal to their IP defaults.

2.1.6.8. Design-for-Debug (DFD) and Core Logic Analyzer (CLA)

The SMC integrates a Design-for-Debug (DFD) subsystem that observes internal activity, triggers on programmable conditions, and captures trace, all on-chip and without external instrumentation. Its core is a Core Logic Analyzer (CLA) that watches a configurable debug bus, evaluates programmable events, and fires actions — an interrupt, a clock stop, a cross-trigger, or a trace capture — when those events occur. Trace storage uses the connected external sink-memory interface. Several capabilities of the generic DFD block are not connected in SMC, as detailed below.




Figure 77. SMC DFD block diagram

Figure 77 shows the DFD block as SMC instantiates it. `smc_dfd_wrap` contains the DFD IP `dfd_top_cla_dst_apb` (`u_dfd_top`),

configured with one CLA and one debug signal trace (DST) instance. Parts of the generic block that SMC does not build are drawn as dashed grey boxes. Inputs and outputs that SMC ties off or leaves unconnected are drawn as dashed lines. The instruction trace (N-Trace) is not built. The trace AXI master and the JTAG register port are tied off, and the timestamp inputs are tied to zero. The CLA and DST paths provide the observation functions described here.

The debug bus from `smc_base` has 64 lanes of 16 bits. Eight level-3 and four level-2 debug-bus muxes reduce it to the 16 lanes that enter the CLA, under the select register in the DFX CSRs. The CLA's own mux stage then selects the 64-bit debug bus that the CLA evaluates and passes to the DST. The wrapper gates `clk_smc_i` for the muxes and the IP under `dfd_cg_en`, and it counts `clk_ref_i` edges into the CLA time tick. The trace sink writes eight external trace RAMs of 256 × 64 bits, 16 KiB in total.

Software programs the mux tree one mux at a time through the single `DEBUG_BUS_MUX` register. The level-3 muxes have IDs 7 to 14 and each takes eight consecutive debug-bus lanes; the level-2 muxes have IDs 3 to 6 and each drives four consecutive CLA input lanes. A mux takes `Dbmmode` while `Dbmid` equals its ID, and its lane selects while `Dbmid` equals its ID and its mode is 1. Each lane select is a binary index: 0 passes input lane *n* to output lane *n*, and 1 to 4 select input lanes 4 to 7. The CLA's own stage, programmed through `CDbgMuxSelLo` with `DbmId` 0, decodes its selects the same way, so 1 to 12 select CLA input lanes 4 to 15. The capture set-up sequence is in the Programmer's Guide.

Bit 0 of `xtrig_clk_halt_mask` in the DFX CSRs masks the CLA cross-trigger and halt-clock outputs, with every cross-trigger lane masked together; bits 15:1 have no effect. The clocks-stopped output also requires `tdr_dbg_ctrl_clock_stop_en_i`, and it drives a CPU interrupt and a DTP clock-stop request. The debug interrupt drives a CPU interrupt. The sixteen custom actions leave the SMC, and the SMU wires five of them to the SEP CPU debug controls. The CLA debug marker returns to the SMC debug bus. The `debug_marker`, `chiplet_enable`, `gpio_en`, `dtb_ns_en` and `dtb_ew_en` fields of `DEBUG_CTRL` have no effect in SMC.

Key features include:

- A programmable debug bus that routes internal signals of interest to the analyzer under software control
- An event engine supporting signal-match, edge, transition, ones-count, any-change, and counter events
- Event-action pairing that binds detected events to system actions
- Per-trigger snapshot of the debug bus and status flags identifying which pair fired
- Cross-trigger exchange with the rest of the debug infrastructure
- Trace capture through the external sink-memory interface

2.1.6.8.1. Debug Bus

The analyzer operates on a debug bus: a fixed-width vector of internal signals sampled every cycle. A selection fabric chooses which internal signals are driven onto the bus, so a single analyzer can be pointed at different parts of the design without RTL changes. Software selects the observed signal set, then programs the event engine against the resulting bus value.

2.1.6.8.2. Core Logic Analyzer

The CLA is organized as a set of nodes, each holding several event-action pairs (EAPs). An EAP binds one or more events, computed from the debug bus, to one or more actions taken when those events occur. The event engine evaluates several event types in parallel (Table 2286).

Table 2286. SMC CLA event types

Event	Description
Signal match	Fires when the masked debug bus equals a programmed value (`debug_bus & mask == match`). Several independent match events are available.
Edge	Fires on a rising or falling edge of selected debug-bus signals.
Transition	Fires when a masked subset of the bus moves from a programmed value A to a programmed value B.
Ones count	Fires when the population count of a masked subset equals a programmed value.
Any change	Fires when any signal within a masked subset changes.
Time match	Unavailable in this integration. Its timestamp input is tied to zero. The comparator requires a nonzero match value, so the event cannot fire; it does not use the local CLA timestamp register.
Counter	Counts cycles following an event match and fires when the count is reached; a small pool of counters is available for measuring intervals or deferring an action.

When an EAP fires, a status flag records which pair triggered — for example, so an interrupt handler can identify the source — and a snapshot register latches the debug-bus value at the moment of the trigger for post-mortem inspection. EAPs are enabled together once programming is complete, so a partially programmed pairing never triggers.

2.1.6.8.3. Actions and Cross-Triggering

An EAP can drive one or more actions:

- **Debug interrupt** — raise a non-maskable interrupt to the CPU.
- **Clock stop** — halt clocks to freeze the design for inspection.
- **GPIO toggle** — the generic block provides this action, but SMC terminates it on an unused local signal; it does not drive a pad.
- **Cross-trigger out** — signal other debug blocks that a local event occurred.
- **Trace capture** — hand the event to the trace subsystem.
- **Custom actions** — reserved outputs for design-specific use.

Cross-trigger inputs let events elsewhere in the system arm or fire local actions, and cross-trigger outputs propagate local events outward, so debug conditions can be correlated across blocks rather than observed in isolation.

2.1.6.8.4. Trace

The configured trace sink uses external memory request/response ports. The optional trace AXI master has unconnected request outputs and tied-low response inputs, so it cannot stream trace over the SMC fabric.

SMC selects local CLA timestamp scheme 0, advanced by the wrapper's reference clock-derived `time_tick`. This local counter is distinct from the generic `i_timestamp`, reference timestamp, and OCTS timestamp inputs, all tied to zero. The integration does not provide the advertised global timestamp alignment through those inputs. In particular, the time-match event consumes the tied-off timestamp rather than the running CLA timestamp register.

Because of timestamp scheme 0 and the 64-bit CLA debug bus, several CLA registers have no effect in SMC. `TsCapture`, `CDbgTimestampCapture` and `CDbgClaTimestampOffset` serve only the reference-timestamp scheme. The Hi halves of the match, compare, transition, ones-count, change and snapshot registers serve only a 128-bit debug bus. `CDbgMuxSelHi`, and `Muxselseg4` to `Muxselseg7` of `CDbgMuxSelLo`, select lanes beyond the four that the CLA mux drives.

2.1.6.8.5. Interrupts

The SMC interrupt table lists the two CLA-driven sources. See [interrupts].

- **CLA clock stop** — asserted while the CLA has stopped clocks.
- **CLA debug interrupt** — the debug interrupt raised by a CLA action.

2.1.6.8.6. Memory Map and Register Reference

2.1.6.8.6.1. Memory Map

The CLA counter values and timestamp fields are software-writable. Software writes take priority over simultaneous hardware updates; later hardware updates can advance or clear them according to their configured controls. The sink's `trDstRamWPHigh` register likewise accepts software writes. These are live read/write state, not read-only status.

The generated `smc_cla` map is the programmer view of this aperture (see Section 2.1.6.10.1).

2.1.6.8.6.2. Detailed Register Map

2.1.6.8.6.2.1. SMC DFD MMR Aperture Address Map

Composite debug (DFD) MMR aperture mapping the DST sink, funnel, CLA, and DST blocks that smc_dfd_wrap instantiates.

Table 2287. SMC DFD MMR Aperture Address Map register list

Address	Name	Access	Description
0x0	Trdstramcontrol	RW	-
0x4	Trdstramimpl	RW	-
0x10	Trdstramstartlow	RW	-
0x14	Trdstramstarthigh	RW	-
0x18	Trdstramlimitlow	RW	-
0x1C	Trdstramlimithigh	RW	-
0x20	Trdstramwplow	RW	-
0x24	Trdstramwphigh	RW	-
0x28	Trdstramrplow	RW	-
0x2C	Trdstramrphigh	RW	-
0x40	Trdstramdata	R	-
0xFF8	dst_sink.ScratchLo	RW	Scratch register (low) for DV and potential ECO usage
0xFFC	dst_sink.ScratchHi	RW	Scratch register (high) for DV and potential ECO usage
0x1000	Trfunnelcontrol	RW	-
0x1004	Trfunnelimpl	R	-
0x1008	Trfunneldisinput	RW	-
0x1FF8	funnel.ScratchLo	RW	Scratch register (low) for DV and potential ECO usage
0x1FFC	funnel.ScratchHi	RW	Scratch register (high) for DV and potential ECO usage
0x2100	CDbgClaCounter0Cfg	RW	Configure CLA counter0. One of the 4 counters used for counting cycles after a event match, and trigger a action on match.
0x2108	CDbgClaCounter1Cfg	RW	Configure CLA counter1. One of the 4 counters used for counting cycles after a event match, and trigger a action on match.
0x2110	CDbgClaCounter2Cfg	RW	Configure CLA counter2. One of the 4 counters used for counting cycles after a event match, and trigger a action on match.

Address	Name	Access	Description
0x2118	CDbgClaCounter3Cfg	RW	Configure CLA counter3. One of the 4 counters used for counting cycles after a event match, and trigger a action on match.
0x2120	CDbgNode0Eap0	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2128	CDbgNode0Eap1	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2130	CDbgNode1Eap0	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2138	CDbgNode1Eap1	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2140	CDbgNode2Eap0	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2148	CDbgNode2Eap1	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2150	CDbgNode3Eap0	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2158	CDbgNode3Eap1	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2160	CDbgSignalMask0Lo	RW	Used to define debug bus match events. The positive match event (0x2) fires when debug_bus & mask = match; the negative match event (0x3) fires when debug_bus & mask != match.
0x2168	CDbgSignalMatch0Lo	RW	Used to define debug bus match events. The positive match event (0x2) fires when debug_bus & mask = match; the negative match event (0x3) fires when debug_bus & mask != match.
0x2170	CDbgSignalMask1Lo	RW	Used to define debug bus match events. The positive match event (0x4) fires when debug_bus & mask = match; the negative match event (0x5) fires when debug_bus & mask != match.
0x2178	CDbgSignalMatch1Lo	RW	Used to define debug bus match events. The positive match event (0x4) fires when debug_bus & mask = match; the negative match event (0x5) fires when debug_bus & mask != match.
0x2180	CDbgSignalEdgeDetectCfg	RW	Register to configure debug bus for edge triggers.
0x2188	CDbgEapStatus	RW	Register to indicate if an EAP was activated. There is one status bit per EAP in bits [15:0] (Node0Eap0..Node3Eap3, 4 EAPs per Node across 4 Nodes) and one write-to-clear bit per EAP in bits [47:32] (Node0Eap0W2C..Node3Eap3W2C); write the matching w2c bit to reset a status bit. The register is used by SW to know if an action was taken (ex: NMI ISR needs to know which of the EAP triggered the NMI)
0x2190	CDbgClaCtrlStatus	RW	Ctrl/Status register to Enable EAP after EAP programming is complete, and read the current node.
0x2198	CDbgMuxSelLo	RW	Mode, ID, fine-grain time enable and lane selects for the CLA debug-bus mux, which builds the four 16-bit lanes of the CLA's 64-bit debug bus from 16 input segments. The mux ID is 0: the mode is taken while DbmId is 0, and the lane selects while DbmId is 0 and DbmMode is 1.
0x21A0	CDbgRsvd1	RW	Reserved Register that can be changed.
0x21A8	CDbgRsvd2	RW	Reserved Register that can be changed.
0x21B0	CDbgTransitionMaskLo	RW	3 registers to configure "transition event". This register is to select the signals of interest using a mask.
0x21B8	CDbgTransitionFromValueLo	RW	3 registers to configure "transition event". The event is triggered on transition from Value A to Value B. This register specifies Value A.
0x21C0	CDbgTransitionToValueLo	RW	3 registers to configure "transition event". The event is triggered on transition from Value A to Value B. This register specifies Value B.

Address	Name	Access	Description
0x21C8	CDbgOnesCountMaskLo	RW	2 registers to configure "ones count" event. This register is to select the signals of interest using a mask.
0x21D0	CDbgOnesCountValue	RW	2 registers to configure "ones count" event. Event triggered when the sum of the signals match the value specified in this register.
0x21D8	CDbgAnyChangeLo	RW	Event triggered when a subset of debug signals change. The mask is used to select the subset of the debug signals.
0x21E0	CDbgSignalSnapshotNode0Eap0Lo	R	debug Bus Value when Node0 Eap0 Trigger is met.
0x21E8	CDbgSignalSnapshotNode0Eap1Lo	R	debug Bus Value when Node0 Eap1 Trigger is met.
0x21F0	CDbgSignalSnapshotNode1Eap0Lo	R	debug Bus Value when Node1 Eap0 Trigger is met.
0x21F8	CDbgSignalSnapshotNode1Eap1Lo	R	debug Bus Value when Node1 Eap1 Trigger is met.
0x2200	CDbgSignalSnapshotNode2Eap0Lo	R	debug Bus Value when Node2 Eap0 Trigger is met.
0x2208	CDbgSignalSnapshotNode2Eap1Lo	R	debug Bus Value when Node2 Eap1 Trigger is met.
0x2210	CDbgSignalSnapshotNode3Eap0Lo	R	debug Bus Value when Node3 Eap0 Trigger is met.
0x2218	CDbgSignalSnapshotNode3Eap1Lo	R	debug Bus Value when Node3 Eap1 Trigger is met.
0x2220	CDbgClaTimeMatch	RW	This value is compared (greater than or equal to the programmed value) against the internal time register value of the core, and is used to generate a time match event for CLA. Needs to be non zero for the time match event signal to trigger. The event will only trigger an action if the EAP programming is done. Requires writing 0 to this register to stop the match event.
0x2228	CDbgSignalMask2Lo	RW	Used to define debug bus match events. The positive match event (0x1C) fires when debug_bus & mask = match; the negative match event (0x1D) fires when debug_bus & mask != match.
0x2230	CDbgSignalMatch2Lo	RW	Used to define debug bus match events. The positive match event (0x1C) fires when debug_bus & mask = match; the negative match event (0x1D) fires when debug_bus & mask != match.
0x2238	CDbgSignalMask3Lo	RW	Used to define debug bus match events. The positive match event (0x1E) fires when debug_bus & mask = match; the negative match event (0x1F) fires when debug_bus & mask != match.
0x2240	CDbgSignalMatch3Lo	RW	Used to define debug bus match events. The positive match event (0x1E) fires when debug_bus & mask = match; the negative match event (0x1F) fires when debug_bus & mask != match.
0x2248	CDbgNode0Eap2	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2250	CDbgNode0Eap3	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2258	CDbgNode1Eap2	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2260	CDbgNode1Eap3	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2268	CDbgNode2Eap2	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2270	CDbgNode2Eap3	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2278	CDbgNode3Eap2	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2280	CDbgNode3Eap3	RW	CLA Action(s) are tied to events(s) using "event-action pairing" registers. One of the 16 EAPs (4 EAPs per Node, 4 Nodes).
0x2288	CDbgSignalSnapshotNode0Eap2Lo	R	debug Bus Value when Node0 Eap2 Trigger is met.
0x2290	CDbgSignalSnapshotNode0Eap3Lo	R	debug Bus Value when Node0 Eap3 Trigger is met.

Address	Name	Access	Description
0x2298	CDbgSignalSnapshotNode1Eap2Lo	R	debug Bus Value when Node1 Eap2 Trigger is met.
0x22A0	CDbgSignalSnapshotNode1Eap3Lo	R	debug Bus Value when Node1 Eap3 Trigger is met.
0x22A8	CDbgSignalSnapshotNode2Eap2Lo	R	debug Bus Value when Node2 Eap2 Trigger is met.
0x22B0	CDbgSignalSnapshotNode2Eap3Lo	R	debug Bus Value when Node2 Eap3 Trigger is met.
0x22B8	CDbgSignalSnapshotNode3Eap2Lo	R	debug Bus Value when Node3 Eap2 Trigger is met.
0x22C0	CDbgSignalSnapshotNode3Eap3Lo	R	debug Bus Value when Node3 Eap3 Trigger is met.
0x22C8	CDbgSignalDelayMuxSel	RW	-
0x22D8	CDbgClaXtriggerTimestretch	RW	This value determines the time stretched pulse duration for the cross trigger. 8 bits for each of the two triggers.
0x22F0	CDbgClaTimestamp	RW	64-bit timestamp counter. Increments on time_tick. Can be written directly or loaded from timestamp_sync on xtrigger when resync is enabled.
0x22F8	CDbgClaTimestampSync	RW	Timestamp sync value. This value is loaded into the timestamp register on xtrigger posedge when resync bit is enabled.
0x2300	CDbgClaTimestampConfig	RW	Timestamp configuration register. Controls resync behavior and debug marker.
0x2308	CDbgClaTimestampOffset	RW	Timestamp offset register. The Offset value is subtracted from the timestamp before comparing with incoming timestamp value. No effect in the SMC, where the CLA timestamp counts the local time tick (timestamp scheme 0).
0x2400	CDbgSignalMask0Hi	RW	Used to define debug bus match events. The positive match event (0x2) fires when debug_bus & mask = match; the negative match event (0x3) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2408	CDbgSignalMatch0Hi	RW	Used to define debug bus match events. The positive match event (0x2) fires when debug_bus & mask = match; the negative match event (0x3) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2410	CDbgSignalMask1Hi	RW	Used to define debug bus match events. The positive match event (0x4) fires when debug_bus & mask = match; the negative match event (0x5) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2418	CDbgSignalMatch1Hi	RW	Used to define debug bus match events. The positive match event (0x4) fires when debug_bus & mask = match; the negative match event (0x5) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2420	CDbgSignalMask2Hi	RW	Used to define debug bus match events. The positive match event (0x1C) fires when debug_bus & mask = match; the negative match event (0x1D) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2428	CDbgSignalMatch2Hi	RW	Used to define debug bus match events. The positive match event (0x1C) fires when debug_bus & mask = match; the negative match event (0x1D) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2430	CDbgSignalMask3Hi	RW	Used to define debug bus match events. The positive match event (0x1E) fires when debug_bus & mask = match; the negative match event (0x1F) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2438	CDbgSignalMatch3Hi	RW	Used to define debug bus match events. The positive match event (0x1E) fires when debug_bus & mask = match; the negative match event (0x1F) fires when debug_bus & mask != match. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.

Address	Name	Access	Description
0x2440	CDbgMuxSelHi	RW	No effect in the SMC. The CLA debug-bus mux has four output lanes and takes its mode, ID, fine-grain time enable and lane selects from CDbgMuxSelLo.
0x2448	CDbgTransitionMaskHi	RW	3 registers to configure "transition event". This register is to select the signals of interest using a mask. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2450	CDbgTransitionFromValueHi	RW	3 registers to configure "transition event". The event is triggered on transition from Value A to Value B. This register specifies Value A. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2458	CDbgTransitionToValueHi	RW	3 registers to configure "transition event". The event is triggered on transition from Value A to Value B. This register specifies Value B. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2460	CDbgOnesCountMaskHi	RW	2 registers to configure "ones count" event. This register is to select the signals of interest using a mask. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2468	CDbgAnyChangeHi	RW	Event triggered when a subset of debug signals change. The mask is used to select the subset of the debug signals. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2470	CDbgSignalSnapshotNode0Eap0Hi	R	debug Bus Value when Node0 Eap0 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x2478	CDbgSignalSnapshotNode0Eap1Hi	R	debug Bus Value when Node0 Eap1 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x2480	CDbgSignalSnapshotNode1Eap0Hi	R	debug Bus Value when Node1 Eap0 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x2488	CDbgSignalSnapshotNode1Eap1Hi	R	debug Bus Value when Node1 Eap1 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x2490	CDbgSignalSnapshotNode2Eap0Hi	R	debug Bus Value when Node2 Eap0 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x2498	CDbgSignalSnapshotNode2Eap1Hi	R	debug Bus Value when Node2 Eap1 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24A0	CDbgSignalSnapshotNode3Eap0Hi	R	debug Bus Value when Node3 Eap0 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24A8	CDbgSignalSnapshotNode3Eap1Hi	R	debug Bus Value when Node3 Eap1 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24B0	CDbgSignalSnapshotNode0Eap2Hi	R	debug Bus Value when Node0 Eap2 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24B8	CDbgSignalSnapshotNode0Eap3Hi	R	debug Bus Value when Node0 Eap3 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24C0	CDbgSignalSnapshotNode1Eap2Hi	R	debug Bus Value when Node1 Eap2 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24C8	CDbgSignalSnapshotNode1Eap3Hi	R	debug Bus Value when Node1 Eap3 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24D0	CDbgSignalSnapshotNode2Eap2Hi	R	debug Bus Value when Node2 Eap2 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24D8	CDbgSignalSnapshotNode2Eap3Hi	R	debug Bus Value when Node2 Eap3 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24E0	CDbgSignalSnapshotNode3Eap2Hi	R	debug Bus Value when Node3 Eap2 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.
0x24E8	CDbgSignalSnapshotNode3Eap3Hi	R	debug Bus Value when Node3 Eap3 Trigger is met. Never captured in the SMC, whose CLA evaluates a 64-bit debug bus.

Address	Name	Access	Description
0x24F0	CDbgLfsr	RW	LFSR value.
0x24F8	CDbgLfsrMask	RW	LFSR programming mask.
0x2500	CDbgTimestampCapture	R	Captured timestamp upper bits. When ts_capture is set in the timestamp config register, a cross trigger 0 event captures the timestamp upper bits into this register. Never captured in the SMC, where the CLA timestamp counts the local time tick (timestamp scheme 0).
0x2508	CDbgCompare0Lo	RW	Value for arithmetic comparison.
0x2510	CDbgCompare0MaskLo	RW	Value to mask the arithmetic comparison.
0x2518	CDbgCompare1Lo	RW	Value for arithmetic comparison.
0x2520	CDbgCompare1MaskLo	RW	Value to mask the arithmetic comparison.
0x2528	CDbgCompare2Lo	RW	Value for arithmetic comparison.
0x2530	CDbgCompare2MaskLo	RW	Value to mask the arithmetic comparison.
0x2538	CDbgCompare3Lo	RW	Value for arithmetic comparison.
0x2540	CDbgCompare3MaskLo	RW	Value to mask the arithmetic comparison.
0x2548	CDbgCompare0Hi	RW	Value for arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2550	CDbgCompare0MaskHi	RW	Value to mask the arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2558	CDbgCompare1Hi	RW	Value for arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2560	CDbgCompare1MaskHi	RW	Value to mask the arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2568	CDbgCompare2Hi	RW	Value for arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2570	CDbgCompare2MaskHi	RW	Value to mask the arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2578	CDbgCompare3Hi	RW	Value for arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2580	CDbgCompare3MaskHi	RW	Value to mask the arithmetic comparison. No effect in the SMC, whose CLA evaluates a 64-bit debug bus; only the Lo register is used.
0x2FF8	Scratch	RW	Additional scratch register for DV and potential ECO usage
0x3000	Trdstcontrol	RW	-
0x3004	Trdstimpl	RW	-
0x3008	Trdstinstfeatures	RW	-
0x31A0	CDbgDebugTraceCfg	RW	-
0x3FF8	dst.ScratchLo	RW	Scratch register (low) for DV and potential ECO usage
0x3FFC	dst.ScratchHi	RW	Scratch register (high) for DV and potential ECO usage

2.1.6.8.6.2.1.1. Trdstramcontrol

Table 2288. smc_cla.Trdstramcontrol fields

Bits	Field	Access	Reset	Description
31:9	Reserved	-	-	Reserved
8	Trdstramstoponwrap	RW	0x0	-
7:5	Reserved	-	-	Reserved
4	Trdstrammode	RW	0x0	-

Bits	Field	Access	Reset	Description
3	Trdstramempty	R	0x1	-
2	Reserved	-	-	Reserved
1	Trdstramenable	RW	0x0	-
0	Trdstramactive	RW	0x0	-

2.1.6.8.6.2.1.2. Trdstramimpl

Table 2289. smc_cla.Trdstramimpl fields

Bits	Field	Access	Reset	Description
31:28	Reserved	-	-	Reserved
27:24	Trdstramvendorframelength	RW	0x1	-
23:14	Reserved	-	-	Reserved
13	Trdstramhassmem	R	0x1	-
12	Trdstramhassram	R	0x1	-
11:8	Trdstramcomptype	R	0x9	-
7:4	Trdstramverminor	R	0x0	-
3:0	Trdstramvermajor	R	0x1	-

2.1.6.8.6.2.1.3. Trdstramstartlow

Table 2290. smc_cla.Trdstramstartlow fields

Bits	Field	Access	Reset	Description
31:2	Trdstramstartlow	RW	0x0	-
1:0	Rsvd10	R	0x0	-

2.1.6.8.6.2.1.4. Trdstramstarthigh

Table 2291. smc_cla.Trdstramstarthigh fields

Bits	Field	Access	Reset	Description
31:0	Trdstramstarthigh	RW	0x0	-

2.1.6.8.6.2.1.5. Trdstramlimitlow

Table 2292. smc_cla.Trdstramlimitlow fields

Bits	Field	Access	Reset	Description
31:2	Trdstramlimitlow	RW	0x0	-
1:0	Rsvd10	R	0x0	-

2.1.6.8.6.2.1.6. Trdstramlimithigh

Table 2293. smc_cla.Trdstramlimithigh fields

Bits	Field	Access	Reset	Description
31:0	Trdstramlimithigh	RW	0x0	-

2.1.6.8.6.2.1.7. Trdstramwplow

Table 2294. smc_cla.Trdstramwplow fields

Bits	Field	Access	Reset	Description
31:2	Trdstramwplow	RW	0x0	-
1	Reserved	-	-	Reserved
0	Trdstramwrap	R	0x0	-

2.1.6.8.6.2.1.8. Trdstramwphigh

Table 2295. smc_cla.Trdstramwphigh fields

Bits	Field	Access	Reset	Description
31:0	Trdstramwphigh	RW	0x0	-

2.1.6.8.6.2.1.9. Trdstramrplow

Table 2296. smc_cla.Trdstramrplow fields

Bits	Field	Access	Reset	Description
31:2	Trdstramrplow	RW	0x0	-
1:0	Rsvd10	R	0x0	-

2.1.6.8.6.2.1.10. Trdstramrphigh

Table 2297. smc_cla.Trdstramrphigh fields

Bits	Field	Access	Reset	Description
31:0	Trdstramrphigh	RW	0x0	-

2.1.6.8.6.2.1.11. Trdstramdata

Table 2298. smc_cla.Trdstramdata fields

Bits	Field	Access	Reset	Description
31:0	Trdstramdata	R	0x0	-

2.1.6.8.6.2.1.12. dst_sink.ScratchLo

Table 2299. smc_cla.dst_sink.ScratchLo fields

Bits	Field	Access	Reset	Description
31:0	Data	RW	0x0	-

2.1.6.8.6.2.1.13. dst_sink.ScratchHi

Table 2300. smc_cla.dst_sink.ScratchHi fields

Bits	Field	Access	Reset	Description
31:0	Data	RW	0x0	-

2.1.6.8.6.2.1.14. Trfunnelcontrol

Table 2301. smc_cla.Trfunnelcontrol fields

Bits	Field	Access	Reset	Description
31:4	Reserved	-	-	Reserved
3	Trfunnelempty	R	0x1	-
2	Reserved	-	-	Reserved
1	Trfunnelenable	RW	0x0	-
0	Trfunnelactive	RW	0x0	-

2.1.6.8.6.2.1.15. Trfunnelimpl

Table 2302. smc_cla.Trfunnelimpl fields

Bits	Field	Access	Reset	Description
31:12	Reserved	-	-	Reserved
11:8	Trfunnelcomptype	R	0x8	-
7:4	Trfunnelverminor	R	0x0	e
3:0	Trfunnelvermajor	R	0x1	-

2.1.6.8.6.2.1.16. Trfunneldisinput

Table 2303. smc_cla.Trfunneldisinput fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	Trfunneldisinput	RW	0x0	Bits 7:0 are reserved for N-trace srcs and 15:8 for Dst sources

2.1.6.8.6.2.1.17. funnel.ScratchLo

Table 2304. smc_cla.funnel.ScratchLo fields

Bits	Field	Access	Reset	Description
31:0	Data	RW	0x0	-

2.1.6.8.6.2.1.18. funnel.ScratchHi

Table 2305. smc_cla.funnel.ScratchHi fields

Bits	Field	Access	Reset	Description
31:0	Data	RW	0x0	-

2.1.6.8.6.2.1.19. CDbgClaCounter0Cfg

Table 2306. smc_cla.CDbgClaCounter0Cfg fields

Bits	Field	Access	Reset	Description
63	Rsvd	RW	0x0	-
62:48	UpperTarget	RW	0x0	-
47:33	UpperCounter	RW	0x0	-

Bits	Field	Access	Reset	Description
32	ResetOnTarget	RW	0x0	When Counter = {upper_target,target} reset to 0. With this bit set, counter will provide a periodic tick w/ frequency of (target +1) if the action is set to Auto Incr. The periodic tick will continue till Stop Auto Incr or Clear Counter action.
31:16	Target	RW	0x0	-
15:0	Counter	RW	0x0	-

2.1.6.8.6.2.1.20. CDbgClaCounter1Cfg

Table 2307. smc_cla.CDbgClaCounter1Cfg fields

Bits	Field	Access	Reset	Description
63	Rsvd	RW	0x0	-
62:48	UpperTarget	RW	0x0	-
47:33	UpperCounter	RW	0x0	-
32	ResetOnTarget	RW	0x0	When Counter = {upper_target,target}, reset to 0. With this bit set, counter will provide a periodic tick w/ frequency of (target +1) if the action is set to Auto Incr. The periodic tick will continue till Stop Auto Incr or Clear Counter action.
31:16	Target	RW	0x0	-
15:0	Counter	RW	0x0	-

2.1.6.8.6.2.1.21. CDbgClaCounter2Cfg

Table 2308. smc_cla.CDbgClaCounter2Cfg fields

Bits	Field	Access	Reset	Description
63	Rsvd	RW	0x0	-
62:48	UpperTarget	RW	0x0	-
47:33	UpperCounter	RW	0x0	-
32	ResetOnTarget	RW	0x0	When Counter = {upper_target,target}, reset to 0. With this bit set, counter will provide a periodic tick w/ frequency of (target +1) if the action is set to Auto Incr. The periodic tick will continue till Stop Auto Incr or Clear Counter action.
31:16	Target	RW	0x0	-
15:0	Counter	RW	0x0	-

2.1.6.8.6.2.1.22. CDbgClaCounter3Cfg

Table 2309. smc_cla.CDbgClaCounter3Cfg fields

Bits	Field	Access	Reset	Description
63	Rsvd	RW	0x0	-
62:48	UpperTarget	RW	0x0	-
47:33	UpperCounter	RW	0x0	-
32	ResetOnTarget	RW	0x0	When Counter = {upper_target,target}, reset to 0. With this bit set, counter will provide a periodic tick w/ frequency of (target +1) if the action is set to Auto Incr. The periodic tick will continue till Stop Auto Incr or Clear Counter action.
31:16	Target	RW	0x0	-

Bits	Field	Access	Reset	Description
15:0	Counter	RW	0x0	-

2.1.6.8.6.2.1.23. CDbgNode0Eap0

Table 2310. smc_cla.CDbgNode0Eap0 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.24. CDbgNode0Eap1

Table 2311. smc_cla.CDbgNode0Eap1 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action

Bits	Field	Access	Reset	Description
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.25. CDbgNode1Eap0

Table 2312. smc_cla.CDbgNode1Eap0 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.26. CDbgNode1Eap1

Table 2313. smc_cla.CDbgNode1Eap1 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions

Bits	Field	Access	Reset	Description
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.27. CDbgNode2Eap0

Table 2314. smc_cla.CDbgNode2Eap0 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.28. CDbgNode2Eap1

Table 2315. smc_cla.CDbgNode2Eap1 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event

Bits	Field	Access	Reset	Description
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.29. CDbgNode3Eap0

Table 2316. smc_cla.CDbgNode3Eap0 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.30. CDbgNode3Eap1

Table 2317. smc_cla.CDbgNode3Eap1 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event

Bits	Field	Access	Reset	Description
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.31. CDbgSignalMask0Lo

Table 2318. smc_cla.CDbgSignalMask0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.32. CDbgSignalMatch0Lo

Table 2319. smc_cla.CDbgSignalMatch0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.33. CDbgSignalMask1Lo

Table 2320. smc_cla.CDbgSignalMask1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.34. CDbgSignalMatch1Lo

Table 2321. smc_cla.CDbgSignalMatch1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.35. CDbgSignalEdgeDetectCfg

Table 2322. smc_cla.CDbgSignalEdgeDetectCfg fields

Bits	Field	Access	Reset	Description
63:16	Reserved	-	-	Reserved
15	PosEdgeSignal1	RW	0x0	Defines which edge to detect for singal from signal1_select. 1: Pos edge, 0: Neg Edge
14:8	Signal1Select	RW	0x0	Define which signal to select for edge detection.
7	PosEdgeSignal0	RW	0x0	Defines which edge to detect for singal from signal0_select. 1: Pos edge, 0: Neg Edge
6:0	Signal0Select	RW	0x0	Define which signal to select for edge detection.

2.1.6.8.6.2.1.36. CDbgEapStatus

Table 2323. smc_cla.CDbgEapStatus fields

Bits	Field	Access	Reset	Description
63:48	Reserved	-	-	Reserved
47	Node3Eap3W2C	RW	0x0	-
46	Node3Eap2W2C	RW	0x0	-
45	Node3Eap1W2C	RW	0x0	-
44	Node3Eap0W2C	RW	0x0	-
43	Node2Eap3W2C	RW	0x0	-
42	Node2Eap2W2C	RW	0x0	-
41	Node2Eap1W2C	RW	0x0	-
40	Node2Eap0W2C	RW	0x0	-
39	Node1Eap3W2C	RW	0x0	-
38	Node1Eap2W2C	RW	0x0	-
37	Node1Eap1W2C	RW	0x0	-
36	Node1Eap0W2C	RW	0x0	-
35	Node0Eap3W2C	RW	0x0	-
34	Node0Eap2W2C	RW	0x0	-
33	Node0Eap1W2C	RW	0x0	-
32	Node0Eap0W2C	RW	0x0	-
31:16	Rsvd3116	R	0x0	-
15	Node3Eap3	R	0x0	-
14	Node3Eap2	R	0x0	-
13	Node3Eap1	R	0x0	-
12	Node3Eap0	R	0x0	-
11	Node2Eap3	R	0x0	-
10	Node2Eap2	R	0x0	-
9	Node2Eap1	R	0x0	-
8	Node2Eap0	R	0x0	-
7	Node1Eap3	R	0x0	-
6	Node1Eap2	R	0x0	-
5	Node1Eap1	R	0x0	-
4	Node1Eap0	R	0x0	-
3	Node0Eap3	R	0x0	-
2	Node0Eap2	R	0x0	-
1	Node0Eap1	R	0x0	-
0	Node0Eap0	R	0x0	-

2.1.6.8.6.2.1.37. CDbgClaCtrlStatus

Table 2324. smc_cla.CDbgClaCtrlStatus fields

Bits	Field	Access	Reset	Description
63	ClaLock	RW	0x0	If this bit is set, then CLA is locked and the enable_cla is latched forever
62:16	Rsvd6216	RW	0x0	reserved fields
15	DisableLocalClockHalt	RW	0x0	If this bit is set, clock halt action is not applied to local clocks

Bits	Field	Access	Reset	Description
14	DisableGlobalClockHalt	RW	0x0	If this bit is set, clock halt action is not applied to global clocks
13:7	ClaChainLoopDelay	RW	0x36	Self-filter delay, in CLA clock cycles, for the CLA's own cross-triggers. When an EAP action drives cross-trigger output n, the CLA ignores incoming cross-trigger n for one cycle, ClaChainLoopDelay cycles later, so that its own trigger returning through the cross-trigger network does not retrigger it; with 0 it ignores the input in the same cycle. A further own trigger while the delay counts does not restart it. Incoming clock halt is not filtered.
6	EnableCla	RW	0x0	Set this bit to 1 to enable the CLA functional clock; clear it to 0 to gate that clock (save pwr). The CLA register block runs on a clock whose functional enable is tied high, so this bit can still be written while the functional clock is gated
5	EnableEap	RW	0x0	Set Enable EAP to 1 after EAP programming is complete
4:2	Reserved	-	-	Reserved
1:0	CurrentNode	R	0x0	Read the current node.

2.1.6.8.6.2.1.38. CDbgMuxSelLo

Table 2325. smc_cla.CDbgMuxSelLo fields

Bits	Field	Access	Reset	Description
63:58	Muxselseg7	RW	0x0	No effect in the SMC: the CLA debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
57:52	Muxselseg6	RW	0x0	No effect in the SMC: the CLA debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
51:46	Muxselseg5	RW	0x0	No effect in the SMC: the CLA debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
45:40	Muxselseg4	RW	0x0	No effect in the SMC: the CLA debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
39:34	Muxselseg3	RW	0x0	Binary segment select for lane 3 of the CLA debug bus, bits [63:48]. The input segments are 16 bits wide: Seg0 = input bits [15:0], Seg1 = [31:16], and so on to Seg15. 0 selects Seg3; a value k from 1 to 12 selects Seg(k+3), so 1 selects Seg4 and 4 selects Seg7; 13 to 63 drive zero. When FineGrainTime is set, the fine-grain time counter is inserted below Seg0: 0 selects Seg2, and k from 1 to 13 selects Seg(k+2).
33:28	Muxselseg2	RW	0x0	Binary segment select for lane 2 of the CLA debug bus, bits [47:32]. The input segments are 16 bits wide: Seg0 = input bits [15:0], Seg1 = [31:16], and so on to Seg15. 0 selects Seg2; a value k from 1 to 12 selects Seg(k+3), so 1 selects Seg4 and 4 selects Seg7; 13 to 63 drive zero. When FineGrainTime is set, the fine-grain time counter is inserted below Seg0: 0 selects Seg1, and k from 1 to 13 selects Seg(k+2).
27:22	Muxselseg1	RW	0x0	Binary segment select for lane 1 of the CLA debug bus, bits [31:16]. The input segments are 16 bits wide: Seg0 = input bits [15:0], Seg1 = [31:16], and so on to Seg15. 0 selects Seg1; a value k from 1 to 12 selects Seg(k+3), so 1 selects Seg4 and 4 selects Seg7; 13 to 63 drive zero. When FineGrainTime is set, the fine-grain time counter is inserted below Seg0: 0 selects Seg0, and k from 1 to 13 selects Seg(k+2).
21:16	Muxselseg0	RW	0x0	Binary segment select for lane 0 of the CLA debug bus, bits [15:0]. The input segments are 16 bits wide: Seg0 = input bits [15:0], Seg1 = [31:16], and so on to Seg15. 0 selects Seg0; a value k from 1 to 12 selects Seg(k+3), so 1 selects Seg4 and 4 selects Seg7; 13 to 63 drive zero. When FineGrainTime is set, the fine-grain time counter is inserted below Seg0: 0 selects the fine-grain time counter, and k from 1 to 13 selects Seg(k+2).
15:9	Rsvd159	RW	0x0	-
8	Finegraintime	RW	0x0	Fine Grain Time Enable. If this bit is set, the fine grain time is enabled.

Bits	Field	Access	Reset	Description
7:2	Dbmid	RW	0x0	Unique DBM ID of the DBM instance
1:0	Dbmmode	RW	0x0	Mode selection, 0: DBM off, 1: Normal debug mode, 2: DBM ID output mode, 3: Toggle Mode

2.1.6.8.6.2.1.39. CDbgRsvd1

Table 2326. smc_cla.CDbgRsvd1 fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value of reserved register.

2.1.6.8.6.2.1.40. CDbgRsvd2

Table 2327. smc_cla.CDbgRsvd2 fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value of reserved register.

2.1.6.8.6.2.1.41. CDbgTransitionMaskLo

Table 2328. smc_cla.CDbgTransitionMaskLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.42. CDbgTransitionFromValueLo

Table 2329. smc_cla.CDbgTransitionFromValueLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.43. CDbgTransitionToValueLo

Table 2330. smc_cla.CDbgTransitionToValueLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.44. CDbgOnesCountMaskLo

Table 2331. smc_cla.CDbgOnesCountMaskLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.45. CDbgOnesCountValue

Table 2332. smc_cla.CDbgOnesCountValue fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.46. CDbgAnyChangeLo

Table 2333. smc_cla.CDbgAnyChangeLo fields

Bits	Field	Access	Reset	Description
63:0	Mask	RW	0x0	-

2.1.6.8.6.2.1.47. CDbgSignalSnapshotNode0Eap0Lo

Table 2334. smc_cla.CDbgSignalSnapshotNode0Eap0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.48. CDbgSignalSnapshotNode0Eap1Lo

Table 2335. smc_cla.CDbgSignalSnapshotNode0Eap1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.49. CDbgSignalSnapshotNode1Eap0Lo

Table 2336. smc_cla.CDbgSignalSnapshotNode1Eap0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.50. CDbgSignalSnapshotNode1Eap1Lo

Table 2337. smc_cla.CDbgSignalSnapshotNode1Eap1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.51. CDbgSignalSnapshotNode2Eap0Lo

Table 2338. smc_cla.CDbgSignalSnapshotNode2Eap0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.52. CDbgSignalSnapshotNode2Eap1Lo

Table 2339. smc_cla.CDbgSignalSnapshotNode2Eap1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.53. CDbgSignalSnapshotNode3Eap0Lo

Table 2340. smc_cla.CDbgSignalSnapshotNode3Eap0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.54. CDbgSignalSnapshotNode3Eap1Lo

Table 2341. smc_cla.CDbgSignalSnapshotNode3Eap1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.55. CDbgClaTimeMatch

Table 2342. smc_cla.CDbgClaTimeMatch fields

Bits	Field	Access	Reset	Description
63:0	TimeMatchVal	RW	0x0	-

2.1.6.8.6.2.1.56. CDbgSignalMask2Lo

Table 2343. smc_cla.CDbgSignalMask2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.57. CDbgSignalMatch2Lo

Table 2344. smc_cla.CDbgSignalMatch2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.58. CDbgSignalMask3Lo

Table 2345. smc_cla.CDbgSignalMask3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.59. CDbgSignalMatch3Lo

Table 2346. smc_cla.CDbgSignalMatch3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.60. CDbgNode0Eap2

Table 2347. smc_cla.CDbgNode0Eap2 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action

Bits	Field	Access	Reset	Description
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.61. CDbgNode0Eap3

Table 2348. smc_cla.CDbgNode0Eap3 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.62. CDbgNode1Eap2

Table 2349. smc_cla.CDbgNode1Eap2 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action

Bits	Field	Access	Reset	Description
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.63. CDbgNode1Eap3

Table 2350. smc_cla.CDbgNode1Eap3 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.64. CDbgNode2Eap2

Table 2351. smc_cla.CDbgNode2Eap2 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.65. CDbgNode2Eap3

Table 2352. smc_cla.CDbgNode2Eap3 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.66. CDbgNode3Eap2

Table 2353. smc_cla.CDbgNode3Eap2 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.67. CDbgNode3Eap3

Table 2354. smc_cla.CDbgNode3Eap3 fields

Bits	Field	Access	Reset	Description
63:58	Action3	RW	0x0	Select an Action
57:52	Action2	RW	0x0	Select an Action
51:44	Udf	RW	0x0	User Defined Function with event type 0, 1, and 2 as arguments
43:38	EventType2	RW	0x0	Select a trigger event
37	CustomAction1Enable	RW	0x0	custom_action1 is valid only if custom_action1_enable is set
36	CustomAction0Enable	RW	0x0	custom_action0 is valid only if custom_action0_enable is set
35:32	CustomAction1	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
31:28	CustomAction0	RW	0x0	Select the bit position of custom action bus to be set when EAP trigger is met. External blocks can define and implement the specific action for a given bit.
27:22	EventType1	RW	0x0	Select a trigger event
21:16	EventType0	RW	0x0	Select a trigger event
15:14	LogicalOp	RW	0x0	Relation to be satisfied among events to activate the actions
13:8	Action1	RW	0x0	Select an Action
7:2	Action0	RW	0x0	Select an Action
1:0	DestNode	RW	0x0	Select Destination Node

2.1.6.8.6.2.1.68. CDbgSignalSnapshotNode0Eap2Lo

Table 2355. smc_cla.CDbgSignalSnapshotNode0Eap2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.69. CDbgSignalSnapshotNode0Eap3Lo

Table 2356. smc_cla.CDbgSignalSnapshotNode0Eap3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.70. CDbgSignalSnapshotNode1Eap2Lo

Table 2357. smc_cla.CDbgSignalSnapshotNode1Eap2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.71. CDbgSignalSnapshotNode1Eap3Lo

Table 2358. smc_cla.CDbgSignalSnapshotNode1Eap3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.72. CDbgSignalSnapshotNode2Eap2Lo

Table 2359. smc_cla.CDbgSignalSnapshotNode2Eap2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.73. CDbgSignalSnapshotNode2Eap3Lo

Table 2360. smc_cla.CDbgSignalSnapshotNode2Eap3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.74. CDbgSignalSnapshotNode3Eap2Lo

Table 2361. smc_cla.CDbgSignalSnapshotNode3Eap2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.75. CDbgSignalSnapshotNode3Eap3Lo

Table 2362. smc_cla.CDbgSignalSnapshotNode3Eap3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.76. CDbgSignalDelayMuxSel

Table 2363. smc_cla.CDbgSignalDelayMuxSel fields

Bits	Field	Access	Reset	Description
63:32	Rsvd	RW	0x0	-
31:30	Muxselseg15	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
29:28	Muxselseg14	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
27:26	Muxselseg13	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
25:24	Muxselseg12	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
23:22	Muxselseg11	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
21:20	Muxselseg10	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
19:18	Muxselseg9	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
17:16	Muxselseg8	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0
15:14	Muxselseg7	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 7
13:12	Muxselseg6	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 6
11:10	Muxselseg5	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 5
9:8	Muxselseg4	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 4
7:6	Muxselseg3	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 3
5:4	Muxselseg2	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 2
3:2	Muxselseg1	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 1
1:0	Muxselseg0	RW	0x0	Dbg Mux Shifted signals Select Bits for Lane 0

2.1.6.8.6.2.1.77. CDbgClaXtriggerTimestretch

Table 2364. smc_cla.CDbgClaXtriggerTimestretch fields

Bits	Field	Access	Reset	Description
63:16	Rsvd	RW	0x0	-
15:8	Xtrigger1Stretch	RW	0x0	-
7:0	Xtrigger0Stretch	RW	0x0	-

2.1.6.8.6.2.1.78. CDbgClaTimestamp

Table 2365. smc_cla.CDbgClaTimestamp fields

Bits	Field	Access	Reset	Description
63:8	TimestampUpper	RW	0x0	Current timestamp value (upper 56 bits)
7:0	TimestampLower	RW	0x0	Current timestamp value (lower 8 bits)

2.1.6.8.6.2.1.79. CDbgClaTimestampSync

Table 2366. smc_cla.CDbgClaTimestampSync fields

Bits	Field	Access	Reset	Description
63:0	TimestampSync	RW	0x0	Sync value to load into timestamp

2.1.6.8.6.2.1.80. CDbgClaTimestampConfig

Table 2367. smc_cla.CDbgClaTimestampConfig fields

Bits	Field	Access	Reset	Description
63:10	Rsvd1	RW	0x0	Reserved
9	TsCapture	RW	0x0	When this bit is set, a cross trigger 0 event will cause the value from Timestamp register to be written into the TimestampCapture register. No effect in the SMC, where the CLA timestamp counts the local time tick (timestamp scheme 0).
8:1	DebugMarker	RW	0x0	Debug marker output value
0	Resync	RW	0x0	When set, timestamp is loaded from timestamp_sync on xtrigger posedge. Auto-clears after load.

2.1.6.8.6.2.1.81. CDbgClaTimestampOffset

Table 2368. smc_cla.CDbgClaTimestampOffset fields

Bits	Field	Access	Reset	Description
63:56	Rsvd0	RW	0x0	Reserved
55:0	Offset	RW	0x0	Timestamp offset value. No effect in the SMC.

2.1.6.8.6.2.1.82. CDbgSignalMask0Hi

Table 2369. smc_cla.CDbgSignalMask0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.83. CDbgSignalMatch0Hi

Table 2370. smc_cla.CDbgSignalMatch0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.84. CDbgSignalMask1Hi

Table 2371. smc_cla.CDbgSignalMask1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.85. CDbgSignalMatch1Hi

Table 2372. smc_cla.CDbgSignalMatch1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.86. CDbgSignalMask2Hi

Table 2373. smc_cla.CDbgSignalMask2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.87. CDbgSignalMatch2Hi

Table 2374. smc_cla.CDbgSignalMatch2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.88. CDbgSignalMask3Hi

Table 2375. smc_cla.CDbgSignalMask3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Mask to be applied to debug bus before match

2.1.6.8.6.2.1.89. CDbgSignalMatch3Hi

Table 2376. smc_cla.CDbgSignalMatch3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value used for debug bus match.

2.1.6.8.6.2.1.90. CDbgMuxSelHi

Table 2377. smc_cla.CDbgMuxSelHi fields

Bits	Field	Access	Reset	Description
63:58	Muxselseg15	RW	0x0	No effect in the SMC.
57:52	Muxselseg14	RW	0x0	No effect in the SMC.
51:46	Muxselseg13	RW	0x0	No effect in the SMC.
45:40	Muxselseg12	RW	0x0	No effect in the SMC.
39:34	Muxselseg11	RW	0x0	No effect in the SMC.
33:28	Muxselseg10	RW	0x0	No effect in the SMC.
27:22	Muxselseg9	RW	0x0	No effect in the SMC.
21:16	Muxselseg8	RW	0x0	No effect in the SMC.
15:8	Rsvd158	RW	0x0	-
7:2	Dbmid	RW	0x0	No effect in the SMC.
1:0	Dbmmode	RW	0x0	No effect in the SMC.

2.1.6.8.6.2.1.91. CDbgTransitionMaskHi

Table 2378. smc_cla.CDbgTransitionMaskHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.92. CDbgTransitionFromValueHi

Table 2379. smc_cla.CDbgTransitionFromValueHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.93. CDbgTransitionToValueHi

Table 2380. smc_cla.CDbgTransitionToValueHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.94. CDbgOnesCountMaskHi

Table 2381. smc_cla.CDbgOnesCountMaskHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	-

2.1.6.8.6.2.1.95. CDbgAnyChangeHi

Table 2382. smc_cla.CDbgAnyChangeHi fields

Bits	Field	Access	Reset	Description
63:0	Mask	RW	0x0	-

2.1.6.8.6.2.1.96. CDbgSignalSnapshotNode0Eap0Hi

Table 2383. smc_cla.CDbgSignalSnapshotNode0Eap0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.97. CDbgSignalSnapshotNode0Eap1Hi

Table 2384. smc_cla.CDbgSignalSnapshotNode0Eap1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.98. CDbgSignalSnapshotNode1Eap0Hi

Table 2385. smc_cla.CDbgSignalSnapshotNode1Eap0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.99. CDbgSignalSnapshotNode1Eap1Hi

Table 2386. smc_cla.CDbgSignalSnapshotNode1Eap1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.100. CDbgSignalSnapshotNode2Eap0Hi

Table 2387. smc_cla.CDbgSignalSnapshotNode2Eap0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.101. CDbgSignalSnapshotNode2Eap1Hi

Table 2388. smc_cla.CDbgSignalSnapshotNode2Eap1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.102. CDbgSignalSnapshotNode3Eap0Hi

Table 2389. smc_cla.CDbgSignalSnapshotNode3Eap0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.103. CDbgSignalSnapshotNode3Eap1Hi

Table 2390. smc_cla.CDbgSignalSnapshotNode3Eap1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.104. CDbgSignalSnapshotNode0Eap2Hi

Table 2391. smc_cla.CDbgSignalSnapshotNode0Eap2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.105. CDbgSignalSnapshotNode0Eap3Hi

Table 2392. smc_cla.CDbgSignalSnapshotNode0Eap3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.106. CDbgSignalSnapshotNode1Eap2Hi

Table 2393. smc_cla.CDbgSignalSnapshotNode1Eap2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.107. CDbgSignalSnapshotNode1Eap3Hi

Table 2394. smc_cla.CDbgSignalSnapshotNode1Eap3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.108. CDbgSignalSnapshotNode2Eap2Hi

Table 2395. smc_cla.CDbgSignalSnapshotNode2Eap2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.109. CDbgSignalSnapshotNode2Eap3Hi

Table 2396. smc_cla.CDbgSignalSnapshotNode2Eap3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.110. CDbgSignalSnapshotNode3Eap2Hi

Table 2397. smc_cla.CDbgSignalSnapshotNode3Eap2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.111. CDbgSignalSnapshotNode3Eap3Hi

Table 2398. smc_cla.CDbgSignalSnapshotNode3Eap3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	R	0x0	-

2.1.6.8.6.2.1.112. CDbgLfsr

Table 2399. smc_cla.CDbgLfsr fields

Bits	Field	Access	Reset	Description
63:1	Lfsr	RW	0x0	Value of the LFSR register.
0	LfsrActive	RW	0x0	Enable the LFSR register.

2.1.6.8.6.2.1.113. CDbgLfsrMask

Table 2400. smc_cla.CDbgLfsrMask fields

Bits	Field	Access	Reset	Description
63:1	Mask	RW	0x0	Value to mask the LFSR register.
0	Rsvd0	RW	0x0	Reserved.

2.1.6.8.6.2.1.114. CDbgTimestampCapture

Table 2401. smc_cla.CDbgTimestampCapture fields

Bits	Field	Access	Reset	Description
63:0	Timestamp	R	0x0	Timestamp capture value.

2.1.6.8.6.2.1.115. CDbgCompare0Lo

Table 2402. smc_cla.CDbgCompare0Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.116. CDbgCompare0MaskLo

Table 2403. smc_cla.CDbgCompare0MaskLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.117. CDbgCompare1Lo

Table 2404. smc_cla.CDbgCompare1Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.118. CDbgCompare1MaskLo

Table 2405. smc_cla.CDbgCompare1MaskLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.119. CDbgCompare2Lo

Table 2406. smc_cla.CDbgCompare2Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.120. CDbgCompare2MaskLo

Table 2407. smc_cla.CDbgCompare2MaskLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.121. CDbgCompare3Lo

Table 2408. smc_cla.CDbgCompare3Lo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.122. CDbgCompare3MaskLo

Table 2409. smc_cla.CDbgCompare3MaskLo fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.123. CDbgCompare0Hi

Table 2410. smc_cla.CDbgCompare0Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.124. CDbgCompare0MaskHi

Table 2411. smc_cla.CDbgCompare0MaskHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.125. CDbgCompare1Hi

Table 2412. smc_cla.CDbgCompare1Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.126. CDbgCompare1MaskHi

Table 2413. smc_cla.CDbgCompare1MaskHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.127. CDbgCompare2Hi

Table 2414. smc_cla.CDbgCompare2Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.128. CDbgCompare2MaskHi

Table 2415. smc_cla.CDbgCompare2MaskHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.129. CDbgCompare3Hi

Table 2416. smc_cla.CDbgCompare3Hi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value for arithmetic comparison.

2.1.6.8.6.2.1.130. CDbgCompare3MaskHi

Table 2417. smc_cla.CDbgCompare3MaskHi fields

Bits	Field	Access	Reset	Description
63:0	Value	RW	0x0	Value to mask the arithmetic comparison.

2.1.6.8.6.2.1.131. Scratch

Table 2418. smc_cla.Scratch fields

Bits	Field	Access	Reset	Description
63:0	Data	RW	0x0	-

2.1.6.8.6.2.1.132. Trdstcontrol

Table 2419. smc_cla.Trdstcontrol fields

Bits	Field	Access	Reset	Description
31:27	Reserved	-	-	Reserved
26:24	Trdstformat	RW	0x3	bit[0]: XOR Enable, bit[1]: VLT Enable. Supported values : 2'b3 (XOR+VLT Compression), 2'b1 (XOR Compresion), 2'b0 (No Compression)
23:20	Trdstsyncmax	RW	0x0	When trDstSyncMode is set to 2'b10, timestamp will be sent for every 2^(trDstSyncMax + 4) Cluster clocks.
19:18	Reserved	-	-	Reserved
17:16	Trdstsyncmode	RW	0x0	When the field is set tp 2'b10, sent timestamp. All other vlaues not NA.
15	Trdstinhibitsrc	R	0x0	-
14	Reserved	-	-	Reserved
13	Trdstinststallena	R	0x0	-
12	Trdstinststalloroverflow	R	0x0	-
11	Trdstinsttriggerenable	RW	0x0	-
10	Reserved	-	-	Reserved
9	Trdstcontext	R	0x0	-
8:7	Reserved	-	-	Reserved
6:4	Trdstinstmode	R	0x6	-
3	Trdstempty	R	0x1	-
2	Trdstinsttracing	RW	0x0	-
1	Trdstenable	RW	0x0	-
0	Trdstactive	RW	0x0	-

2.1.6.8.6.2.1.133. Trdstimpl

Table 2420. smc_cla.Trdstimpl fields

Bits	Field	Access	Reset	Description
31	Trdsttimestampconfig	RW	0x0	DST timestamp configuration. 0: timestamp input form external source (CoreTime). 1: timestamp from CLA timesync.
30:28	Trdstvendorstreamlength	RW	0x4	Specify Stream length. A stream starts with "no compressed packet". Stream length specifies number of frames before a non-compressed packet is sent.Stream Length = 32* 2^(trDstVendorStreamLength + 1)
27:24	Trdstvendorframelength	RW	0x1	Specify frame length. Frame Length = trDstVendorFrameLength* 64 ; Frame Length should be a multiple of Bank Data Width.
23:20	Trdstprotocolminor	R	0x0	-
19:16	Trdstprotocolmajor	R	0x1	-
15:12	Reserved	-	-	Reserved
11:8	Trdstcomptype	R	0x1	-
7:4	Trdstverminor	R	0x0	-
3:0	Trdstvermajor	R	0x1	-

2.1.6.8.6.2.1.134. Trdstinstfeatures

Table 2421. smc_cla.Trdstinstfeatures fields

Bits	Field	Access	Reset	Description
31:28	Trdstsrcbits	RW	0x4	-
27:16	Trdstsrcid	RW	0x0	-
15:9	Reserved	-	-	Reserved
8	Trdstinstenrepeatedhistory	R	0x0	-
7:2	Reserved	-	-	Reserved
1	Trdstinstnotrapaddr	R	0x0	-
0	Trdstinstnoaddrdiff	R	0x0	-

2.1.6.8.6.2.1.135. CDbgDebugTraceCfg

Table 2422. smc_cla.CDbgDebugTraceCfg fields

Bits	Field	Access	Reset	Description
31:22	Reserved	-	-	Reserved
21	FrameClosureMode	RW	0x0	Closure Mode: 1: Close frame with a packet no larger than max packet size before any overflow (due to packets crossing frame boundary). 0: Close frame when packets cross boundary. Push back packet crossing frame boundary to packet generator.
20	FrameModeEnable	RW	0x1	Enable Frame Mode (Frame Mode: Always pack "frame length" number of bytes for trace transmission). If flush to memory is stalled (due to silicon bug), we can have incomplete packets in memory. Frame Mode will help SW decoder to avoid reading incomplete trasnmitted packets. In Frame Mode, SW will get a memory pointer that is aligned to Frame Length. HW will ensure there are no incomplete packets incluced in the region pointed by memory pointer.
19:16	Reserved	-	-	Reserved
15:12	FrameLenghtInBytes	RW	0x2	Use trDstImpl[trDstVendorFrameLength] for Frame Length programming. Register field ZBB-ed.

Bits	Field	Access	Reset	Description
11:4	TraceFrameFillByte	RW	0x81	Use "Filler Packet" to align a stream of trace packets within a frame boundary.
3:0	TraceSourceId	RW	0x0	Trace Source ID

2.1.6.8.6.2.1.136. dst.ScratchLo

Table 2423. smc_cla.dst.ScratchLo fields

Bits	Field	Access	Reset	Description
31:0	Data	RW	0x0	-

2.1.6.8.6.2.1.137. dst.ScratchHi

Table 2424. smc_cla.dst.ScratchHi fields

Bits	Field	Access	Reset	Description
31:0	Data	RW	0x0	-

2.1.6.9. eFuse Shadow Register Scan Protection

DFT scan test and debug scandump share the scan chain infrastructure. Any flop placed on a scan chain can be shifted out, and any flop on a dumpable chain can be observed by a debug user. The SMC eFuse shadow registers hold the LOCKS field, which is the sole enforcement point for read and write access control over the entire SMC fuse map. If those flops were scannable, an attacker could shift a cleared LOCKS value into the shadow array and defeat the access controls without touching the fuse macro itself. This section describes how the LOCKS shadow words are excluded from every scan chain.

The asset classes referenced here (Class 1 / Class 2 / Class 3) are defined authoritatively in the SEP Lifecycle Controller chapter, *Asset and Scan-Chain Protection*. This section records how they apply to the SMC eFuse controller.

2.1.6.9.1. SMC eFuse Asset Classification

Table 2425 relates the SMC fuse contents to their security class and scan policy.

Table 2425. SMC eFuse shadow register classification

Class	SMC content	Scan policy
Class 1a (confidentiality)	*none*	The SMC fuse map holds no device secrets — it carries identifiers (JTAG_PUBLIC_IDENTITY, I2C_I3C_ID), boot configuration (SMC_CONFIG, OCCP_TRANSPORT_TIMEOUT), and spare regions. There are no keys, no UIDs used as key material, and no token registers. Consequently no confidentiality masking is required.
Class 1b (integrity)	LOCKS	Excluded from every scan chain. Never scannable, never dumpable, for any LC state or debug grant.
Class 2 (secret-bearing)	*none*	The SMC eFuse controller instantiates no cryptographic engine and no key vault, so it contributes no Class 2 scan roots and needs no dedicated secret-bearing chain.
Class 3 (general)	All remaining fuse-map words	Normal scan and scandump handling, subject to the SMC debug policy.

Because SMC has no Class 1a asset, secure_tm is not used for secret disconnection in the SMC eFuse controller: secure_tm_i is tied to 1'b0 and SECRET_SHADOW_RANGES is left at '0. This differs from SEP, where secure_tm disconnects the UID / CLASS_KEY sources from their Class 2 consumers.

2.1.6.9.2. Implementation

efuse_shadow_regs keeps its shadow storage in two separately named arrays and reconstructs the public register view from both. The array holding Class 1 words is named with an _n0_scan suffix, which is the reserved naming handle the synthesis scan-insertion flow uses to identify the flops it must leave off all scan chains:

- shadow_efuse_values_n0_scan — Class 1 words, excluded from scan.
- shadow_efuse_values — Class 3 words, normal scan handling.

Which words land in the Class 1 array is set by the CLASS1_SHADOW_RANGES parameter. smc_efuse_wrapper drives it from smc_efuse_pkg::Class1ShadowRanges, which derives the range from the generated RDL metadata rather than hard-coding word indices, so the exclusion follows the register map if the map is regenerated:

```
localparam efuse_pkg::shadow_word_range_map_t Class1ShadowRanges = '{
    0: efuse_pkg::make_shadow_word_range(
        LOCKS_REG_OFFSET, $bits(smc_efuse_map_locks_reg_t), NumFuseWordWidth),
    default: '0
};
```

LOCKS sits at fuse-map offset 0x0 and is 64 bits wide, so this resolves to shadow words 0 and 1.

Table 2426 maps fuse fields to their shadow-register word ranges.

Table 2426. SMC shadow word allocation

Quantity	Value
Fuse map size	1 KB (8192 bits, 256 x 32-bit words)
Class 1 words (shadow_efuse_values_n0_scan)	2 (words 0-1, LOCKS)
Class 3 words (shadow_efuse_values)	254

Three ASSERT_INIT checks in efuse_shadow_regs verify at elaboration that the configured ranges are well formed, non-overlapping, and inside the shadow array, so a bad range map is a build failure rather than a silent loss of protection.

2.1.6.9.3. Downstream Lock Path

Excluding the LOCKS shadow flops is only sufficient if no scannable flop downstream of them re-derives the lock decision. In the SMC eFuse controller this holds by construction: efuse_shadow_reg_access_control, which compares the incoming APB address against the field map and produces the write_locked / read_locked decisions, is purely combinational. There is no intermediate state element between the Class 1 shadow words and the APB write-enable and read-data paths that they gate.

The one sequential consumer of that logic is locked_field_access_interrupt_o, which reports that a locked-field access was attempted. It carries an access-violation event, not lock state, so observing it does not reveal or alter the LOCKS value.

2.1.6.9.4. Notes for DFT

- The _n0_scan suffix is a Class 1 marker and takes precedence over any enclosing scan hierarchy. Do not rename it; the exclusion is carried entirely by the signal name, as there is no separate constraint list in this repository.
- efuse_shadow_regs also declares chiplet_state_change_completed_n0_scan and sop_state_change_completed_n0_scan. These serve the SEP RMA token / LC state transition path. In the SMC instance HAS_LC_STATE is 1'b0 and both are

driven to a constant 1'b1, so they hold no SMC state; they are expected to be constant-propagated away.

- Adding a secret or a new integrity-critical field to the SMC fuse map requires extending `Class1ShadowRanges` (and, for a confidentiality asset, `SECRET_SHADOW_RANGES` plus a real `secure_tm_i` source). Adding the register to the RDL alone does not confer scan protection.

2.1.6.9.5. Verification

`smc_efuse_shadow_lock_matrix_test` exercises reads and writes across the `LOCKS` matrix and therefore covers the relocated words functionally, confirming that moving `LOCKS` into the Class 1 array does not change access-control behaviour.

2.1.6.10. Memory Map and Register Reference

2.1.6.10.1. Memory Map

This section provides a comprehensive overview of the SMC memory map. The SMC address space is organized to provide access to various functional units including CPU control, peripheral interfaces, system management functions, and fabric control mechanisms.

All addresses below are expressed as `BASE + offset`, where `BASE` can be either the local alias (`LOCAL_BASE`, fixed read-only at `0xC000_0000`) or the global system address (`GLOBAL_BASE`, programmable by firmware). The fabric routes transactions to SMC resources identically regardless of which base is used, as long as the access falls inside the relevant local or global aperture. Both apertures are sized by the SMC `REGION_SIZE` CSR, which resets to 16 MiB and may be reprogrammed by firmware. Address ranges include both endpoints. Addresses are 32-bit aligned and follow standard AXI4-Lite addressing conventions. For details on how `LOCAL_BASE` and `GLOBAL_BASE` relate and how an adopter maps this aperture into the system address space, refer to the SMC Address Map Integration section of the Integration Guide.

2.1.6.10.1.1. Address Space Organization

The generated component map reports each allocated aperture separately from the extent occupied by registers.

Table 2427. SMC Functional Address-Space Organization

Address Range	Size	Unit	Description
BASE + 0x0 – BASE + 0xFFF	4 KiB	Watchdog Timers	Per-core watchdog timers.
BASE + 0x2000 – BASE + 0xBFFF	40 KiB	System and Peripheral Control	Reset, GPIO, serial peripherals, eFuse, telemetry, timer, DTP, and DFT status.
BASE + 0x10000 – BASE + 0x16FFF	28 KiB	Fabric Control	Base configuration, address remapping, and traffic filters.
BASE + 0x18000 – BASE + 0x37FFF	128 KiB	Mailbox	Thirty-two bidirectional mailbox pairs.
BASE + 0x38000 – BASE + 0x382FF	768 B	Data Processing	DMA controller and memory zeroer.
BASE + 0x39000 – BASE + 0x3FFFF	28 KiB	CPU and I/O Control	CPU-cluster control and OCA I3C controller.
BASE + 0x40000 – BASE + 0x15FFFF	1152 KiB	Local Memories	Scratchpad ROM and RAM.
BASE + 0x160000 – BASE + 0x163FFF	16 KiB	CLA	Core Logic Analyzer debug and trace.
BASE + 0x400000 – BASE + 0x406547	25928 B	Adopter External	Adopter-owned technology-specific and supplementary peripherals.
BASE + 0x1000000 – BASE + 0x1FFFFFF	16 MiB	Address Remapping	Machine-mode and hypervisor remapped regions.

Address Range	Size	Unit	Description
BASE + 0x4000000 – BASE + 0x7FFFFFF	64 MiB	PLIC	Platform-Level Interrupt Controller aperture.
BASE + 0x8000000 – BASE + 0x8013FFF	80 KiB	Core-Local Timer and Errors	Core-local timer and per-core bus-error units.

Table 2428. SMC Component Address Map

Address Range	Size	Decoded Extent	Unit	Instances	Stride	Description	Hole in Extent (R / W)	Past Extent (R / W)
BASE + 0x0 – BASE + 0x3FF	1 KiB	36 B	Watchdog Timer Address Map	1 instance	-	Core 0 watchdog timer.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0x400 – BASE + 0x7FF	1 KiB	36 B	Watchdog Timer Address Map	1 instance	-	Core 1 watchdog timer.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0x800 – BASE + 0xBFF	1 KiB	36 B	Watchdog Timer Address Map	1 instance	-	Core 2 watchdog timer.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0xC00 – BASE + 0xFFF	1 KiB	36 B	Watchdog Timer Address Map	1 instance	-	Core 3 watchdog timer.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0x1000 – BASE + 0x1867	2152 B	2152 B	Debug Module Hart Interface	1 instance	-	Memory region through which a hart in Debug Mode exchanges state with the Debug Module: handshake mailboxes, generated instructions, program buffer, data registers, per-hart flags and the debug ROM. Only the harts of the CPU cluster reach this region; SMC bus initiators outside the cluster do not. The debugger-facing Debug Module registers (dmcontrol, dmstatus, abstractcs, sbcs, …) are reached over the Debug Module Interface and do not appear in this map.	DECERR, 0xBADCAB1E / DECERR[1]	-

Address Range	Size	Decoded Extent	Unit	Instances	Stride	Description	Hole in Extent (R / W)	Past Extent (R / W)
BASE + 0x2000 – BASE + 0x27FF	2 KiB	204 B	Reset Unit Address Map	1 instance	-	System reset control.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x2800 – BASE + 0x2FFF	2 KiB	524 B	SMC Miscellaneous Wrapper Address Map	1 instance	-	Aggregates the SMC scratch, chip-configuration, and NDM-reset register blocks.	DECERR, 0xBADCAB1E / SLVERR	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x3000 – BASE + 0x3FFF	4 KiB	1040 B	GPIO Interface Address Map	65 instances	16 B	GPIO interface configuration: pad/core routing, receive and transmit enables, and interrupt control.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x4000 – BASE + 0x4FFF	4 KiB	92 B	AVSBus Controller Address Map	1 instance	-	Command, readback, status, and interrupt registers for the AVSBus (V1.3.1) controller.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x5000 – BASE + 0x5FFF	4 KiB	3596 B	I2C Wrapper Address Map	1 instance	-	I2C and SMBus controller.	DECERR, 0xBADCAB1E / SLVERR	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x6000 – BASE + 0x6FFF	4 KiB	4 KiB	UART Wrapper Address Map	1 instance	-	UART controller.	OKAY, 0x0 / OKAY; between sub-blocks: DECERR, 0xBADCAB1E / SLVERR	-
BASE + 0x7000 – BASE + 0x7FFF	4 KiB	1 KiB	Efuse address map of physical efuse macro	1 instance	-	Address map for efuse shadow registers providing access to various chip configuration and ID fields	-	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x8000 – BASE + 0x8FFF	4 KiB	28 B	eFuse Interface Control Address Map	1 instance	-	eFuse command and status registers.	-	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x9000 – BASE + 0x9FFF	4 KiB	768 B	Telemetry Receiver Wrapper Address Map	1 instance	-	Telemetry data receiver.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0xA000 – BASE + 0xAFFF	4 KiB	36 B	OCTS System Timer Address Map	1 instance	-	Open Chiplet Time Synchronization (OCTS) System Timer Registers	-	DECERR, 0xBADCAB1E / SLVERR

Address Range	Size	Decoded Extent	Unit	Instances	Stride	Description	Hole in Extent (R / W)	Past Extent (R / W)
BASE + 0xB000 – BASE + 0xB7FF	2 KiB	2 KiB	dtp_ctrl_reg	1 instance	-	512-entry DTP control block.	Forwarded	-
BASE + 0xB800 – BASE + 0xBFFF	2 KiB	24 B	DFX Control and Status Address Map	1 instance	-	DFT status exposed to boot firmware.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0x10000 – BASE + 0x11FFF	8 KiB	76 B	SMC Base Configuration Address Map	1 instance	-	SMC base-address and aperture configuration.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x12000 – BASE + 0x12FFF	4 KiB	256 B	AXI Alias Remap Address Map	8 instances	32 B	TLB Registers for address remapping and attribute tagging	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x13000 – BASE + 0x13FFF	4 KiB	64 B	Output Remap Address Map	8 instances	8 B	Address-translation registers that remap outbound transactions and tag their attributes.	-	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x14000 – BASE + 0x14FFF	4 KiB	64 B	Output Remap Address Map	8 instances	8 B	Address-translation registers that remap outbound transactions and tag their attributes.	-	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x15000 – BASE + 0x15FFF	4 KiB	512 B	AXI Filter Control Address Map	16 instances	32 B	Per-filter access-control registers defining permitted address ranges and transaction attributes.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x16000 – BASE + 0x16FFF	4 KiB	512 B	AXI Filter Control Address Map	16 instances	32 B	Per-filter access-control registers defining permitted address ranges and transaction attributes.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / SLVERR
BASE + 0x18000 – BASE + 0x37FFF	128 KiB	129104 B	SMC AXI-Lite Mailbox Wrapper Address Map	1 instance	-	Thirty-two bidirectional mailbox pairs.	SLVERR, 0x0 / SLVERR	DECERR, 0xBADCAB1E / DECERR
BASE + 0x38000 – BASE + 0x381FF	512 B	312 B	iDMA Controller Address Map	1 instance	-	Direct-memory-access controller.	OKAY, 0xFFFFFFFF / OKAY	DECERR, 0xBADCAB1E / DECERR

Address Range	Size	Decoded Extent	Unit	Instances	Stride	Description	Hole in Extent (R / W)	Past Extent (R / W)
BASE + 0x38200 – BASE + 0x382FF	256 B	24 B	Zeroer Control Address Map	1 instance	-	Control and status registers for the AXI memory-zeroing engine.	-	DECERR, 0xBADCAB1E / DECERR
BASE + 0x39000 – BASE + 0x39FFF	4 KiB	704 B	CPU Control Address Map	1 instance	-	SMC CPU-cluster control.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0x3A000 – BASE + 0x3FFFF	24 KiB	24 KiB	OCA I3C Controller Wrapper Address Map	1 instance	-	Wrapper address map instantiating the per-controller I3C CSR blocks.	OKAY, 0x0 / OKAY[2]	-
BASE + 0x40000 – BASE + 0x5FFFF	128 KiB	128 KiB	spm_rom_memory	1 instance	-	Scratchpad ROM memory, present only in non-CPL configurations.	-[3]	-
BASE + 0x60000 – BASE + 0x15FFFF	1 MiB	1 MiB	spm_memory	1 instance	-	Scratch RAM Memory - only present for non-CPL configurations	-	-
BASE + 0x160000 – BASE + 0x163FFF	16 KiB	16 KiB	SMC DFD MMR Aperture Address Map	1 instance	-	Core Logic Analyzer debug and trace aperture.	OKAY, 0x0 / OKAY	-
BASE + 0x400000 – BASE + 0x406547	25928 B	25928 B	SMC External Window Address Map	1 instance	-	Adopter-owned external peripheral aperture.	Adopter-defined	-
BASE + 0x1000000 – BASE + 0x17FFFFF	8 MiB	8 MiB	mmode_region	1 instance	-	Address region whose accesses an output remap redirects.	Forwarded	-
BASE + 0x1800000 – BASE + 0x1FFFFFF	8 MiB	8 MiB	xvisor_region	1 instance	-	Address region whose accesses an output remap redirects.	Forwarded	-
BASE + 0x4000000 – BASE + 0x7FFFFFF	64 MiB	2125832 B	PLIC Address Map	1 instance	-	Platform-Level Interrupt Controller.	OKAY, 0x0 / OKAY[4]	DECERR, 0xBADCAB1E / DECERR
BASE + 0x8000000 – BASE + 0x800FFFF	64 KiB	48 KiB	CLINT Address Map	1 instance	-	Core-Local Interruptor.	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
BASE + 0x8010000 – BASE + 0x8010FFF	4 KiB	48 B	Bus Error Unit Address Map	1 instance	-	Core 0 bus-error unit.	-	DECERR, 0xBADCAB1E / DECERR

Address Range	Size	Decoded Extent	Unit	Instances	Stride	Description	Hole in Extent (R / W)	Past Extent (R / W)
BASE + 0x8011000 – BASE + 0x8011FFF	4 KiB	48 B	Bus Error Unit Address Map	1 instance	-	Core 1 bus-error unit.	-	DECERR, 0xBADCAB1E / DECERR
BASE + 0x8012000 – BASE + 0x8012FFF	4 KiB	48 B	Bus Error Unit Address Map	1 instance	-	Core 2 bus-error unit.	-	DECERR, 0xBADCAB1E / DECERR
BASE + 0x8013000 – BASE + 0x8013FFF	4 KiB	48 B	Bus Error Unit Address Map	1 instance	-	Core 3 bus-error unit.	-	DECERR, 0xBADCAB1E / DECERR
BASE + 0x8014000 – BASE + 0x8014FFF	4 KiB	4 KiB	smc_cluster_error_device	1 instance	-	Error responder for unmapped cluster-bus accesses.	DECERR, 0xBADCAB1E / DECERR[1]	-

Notes

[1] Only the harts of the CPU cluster reach this unit. An access from outside the cluster answers the same at every address in its aperture.
[2] Each instance implements 16 DAT and 16 DCT entries: the DAT at 0x400-0x7FF repeats every 0x80 bytes, the DCT at 0x800-0xFFF repeats every 0x100 bytes, and DCT writes are dropped.
[3] A write answers SLVERR and leaves the ROM unchanged.
[4] 0x544, 0x102C and 0x202C are the upper halves of live 64-bit words, so a 64-bit read there returns live data.

The last two columns state how the SMC answers a 32-bit access that no register or memory backs, as seen at its inbound AXI port, and Decode Response Codes defines them and their codes.

An address between unit apertures reaches no unit. A read there answers `DECERR` with data `0xBADCAB1E`, and a write answers `DECERR`, except from `BASE + 0x001_7000` through `BASE + 0x001_7FFF`, where it answers `SLVERR`.

An address inside neither the local nor the global aperture answers `DECERR` to reads and writes. The M-mode and Xvisor remap regions forward accesses from SMC initiators only; an access to them from the inbound port answers `DECERR`.

The inbound port reaches a unit only while its whole aperture lies below `BASE + REGION_SIZE`. At the reset value the PLIC, CLINT and bus-error units lie beyond it and answer `DECERR`. The SMC harts reach the PLIC and CLINT inside the CPU cluster regardless of `REGION_SIZE`.

The I2C, UART, I3C, AVSBus and Telemetry Receiver windows answer `SLVERR`, with read data `0xBADCAB1E`, while the peripheral's `CLOCK_GATE_CONTROL` enable in SMC_BASE_CONFIG is set and its clock is stopped.

2.1.6.10.1.2. AXI-Lite External Window

The `smc_external` window at `BASE + 0x040_0000` is the adopter extension window. OCAH exposes this AXI-Lite bus so an adopter can attach their own technology- and vendor-specific implementations of memory-mapped blocks. The window is split into two regions (see `smc_external.rdl`). Apart from the eFuse SHIM control block described below, hardware treats both identically; the split is purely organizational:

- **Mandatory** (`BASE + 0x040_0000`): blocks every integration must implement. Their function is dictated by the OCAH specifications, but their implementation is inherently technology- and vendor-specific — the eFuse SHIM, the per-pad GPIO controls, the PLL wrapper and the strap registers at `BASE + 0x040_3000`.

- **Supplementary** (`BASE + 0x040_4000`): any additional memory-mapped devices the adopter wants to expose, such as peripheral controllers, extra pad controls and the PVT wrapper.

The generated SMC map reports this as one opaque adopter-owned aperture. Concrete placements inside it are integration-specific and are documented by the adopter. The strap registers are read-only values consumed by boot firmware; how the adopter captures them is implementation-defined. Both boot ROMs read them at `BASE + 0x040_3000`, so an integration places them there.

The eFuse SHIM control block is the exception. Its placement is fixed at the base of the window, `BASE + 0x040_0000`, and its size is the `EFUSE_SHIM_SIZE` parameter (`CFG.SMC_EFUSE_SHIM_SIZE` at the SMU). The peripheral crossbar routes that range to the eFuse controller, which forwards it unchanged on `efuse_bank_ctrl` to the adopter's SHIM. It never appears on the external port. The adopter defines the SHIM's control registers at offset `0x0` of its own `smc_external` map.

The supplementary (optional) region of the window is passed through to the SMU's `smc_external_req_o` / `smc_external_resp_i` ports for adopter integration. The adopter may implement any memory-mapped functions there, or may instead terminate the region with an error response. The reference integration (`hw/top/smc_ip_integration.sv`) terminates unclaimed accesses in this region with a DECERR response via the `prim_axi_lite_err_slv` helper; this is one integration choice, not a requirement.

2.1.6.10.1.3. Register Interface Standards

All SMC components use standard AMBA interfaces. We summarize the interfaces in Table 2429:

Table 2429. SMC Register Interface Standards

Interface	Address Width	Data Width	Description
AXI4-Lite	32-bit	64-bit	High-performance components
APB4	32-bit	32-bit	Peripheral components
Address Alignment: 32-bit registers on 4-byte boundaries, 64-bit on 8-byte boundaries			
Endianness: Little-endian byte ordering throughout			
Protection: AXI protection bits used for secure/non-secure access control			

2.1.6.10.1.4. Access Control and Security

Table 2430 summarises the SMC access-control mechanisms.

Table 2430. SMC Access Control Mechanisms

Mechanism	Description
Address Filtering	Configurable inbound and outbound address filters
Protection Levels	AXI protection attribute enforcement
Secure Regions	eFuse and security-critical registers require elevated privileges
Error Handling	Bus error units provide comprehensive error logging and reporting

2.1.6.10.2. Detailed Register Map

2.1.6.10.2.1. External Window Reference Maps

The PLL and PVT maps below describe placeholder memory footprints used by the open verification models. Their memory words do not specify the control registers of an adopter's clock or sensor implementation. The straps map describes captured GPIO values. Placement of these blocks within the external window is integration-specific.

2.1.6.10.2.1.1. PLL Wrapper Placeholder Address Map

Adopter clock-control placeholder reserving the PLL map slot; no CSRs are modeled.

NOTE

Register Arrays:

- **mem_array[954]**: 954 registers, base 0x0, stride 0x4

Table 2431. PLL Wrapper Placeholder Address Map register list

Address	Name	Access	Description
0x0 - 0xEE4	mem_array[954]	R	-

2.1.6.10.2.1.1.1. mem_array[954]

Table 2432. pll_wrap.mem_array[954] fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	-

2.1.6.10.2.1.2. PVT Wrapper Placeholder Address Map

Adopter PVT and monitor placeholder reserving the map slot; no CSRs are modeled.

NOTE

Register Arrays:

- **mem_array[594]**: 594 registers, base 0x0, stride 0x4

Table 2433. PVT Wrapper Placeholder Address Map register list

Address	Name	Access	Description
0x0 - 0x944	mem_array[594]	R	-

2.1.6.10.2.1.2.1. mem_array[594]

Table 2434. pvt_wrap.mem_array[594] fields

Bits	Field	Access	Reset	Description
31:0	data	R	-	-

2.1.6.10.2.1.3. Straps Address Map

Configuration strap values. How they are captured is adopter-defined.

Table 2435. Straps Address Map register list

Address	Name	Access	Description
0x0	STRAPS_LO	R	-
0x4	STRAPS_HI	R	-

2.1.6.10.2.1.3.1. STRAPS_LO

Table 2436. straps.STRAPS_LO fields

Bits	Field	Access	Reset	Description
31:0	straps	R	0x0	Configuration straps 0 - 31. Bits 0 - 10, 16, 17, 24 and 27 - 31 have no strap assigned; no strap function consumes them. Strap assignments in this range: * bit 11: CHIP_ID[3] - CHIP_ID is the I2C/I3C static address strap * bit 12: CHIP_ID[2] - CHIP_ID is the I2C/I3C static address strap * bit 13: BYPASS_SRAM_REPAIR - Bypass the memory repair process * bit 14: TEST_EN - Enable DFT test mode * bit 15: CHIP_ID[1] - CHIP_ID is the I2C/I3C static address strap * bit 18: BOOT_I2C - Default alternate boot channel is I3C0 and can be reconfigured to use I2C0 * bit 19: BOOT_RECOVERY - Use I3C0 for BL1 boot image loading instead of the SPI channel * bit 20: BL0_PLLCLK - Use the PLL generated clock by default in BL0, and override to use the reference clock when this strap is asserted * bit 21: STATUS_RPT_DISABLE - Disable BL0 status reporting. It is on by default * bit 22: SPI_USE_FUSED_CONFIG - Use the SPI configuration values stored in the fuse field * bit 23: CHIP_ID[0] - CHIP_ID is the I2C/I3C static address strap * bit 25: PRIMARY_CHIPLET - Identifies the primary chiplet, the boot master * bit 26: SRAM_AUTO_ZERO_DISABLE - Disable auto zero of the SMC SRAM when asserted

2.1.6.10.2.1.3.2. STRAPS_HI

Table 2437. straps.STRAPS_HI fields

Bits	Field	Access	Reset	Description
31:29	Reserved	-	-	Reserved
28:0	straps	R	0x0	Configuration straps 32 - 60. All bits other than those listed below have no strap assigned; no strap function consumes them. Strap assignments in this range: * bit 22: MBIST_BYPASS - Ignore results of Power-On MBIST for boot * bit 26: ROTATE_UPDATE - Swaps primary and backup image in SEP BL0 ROM

2.1.6.10.3. Spare SMC Register Blocks

The following shows the detailed register map of a set of programmer-visible spare SMC blocks. They are spare but essential: for example, the scratch block provides general-purpose registers, and the chip-config and NDM-reset blocks hold system-level configuration and reset control.

2.1.6.10.3.1. Chip Config, Scratch, NDM Reset, and Misc Wrap

2.1.6.10.3.1.1. Chip Configuration Address Map

Chip version, identification, and lifecycle-state registers.

Table 2438. Chip Configuration Address Map register list

Address	Name	Access	Description
0x0	VERSION_LO	R	-
0x4	VERSION_HI	R	-
0x8	CHIP_ID	R	-
0xC	LC_STATE	R	-

2.1.6.10.3.1.1.1. VERSION_LO

Table 2439. chip_config.VERSION_LO fields

Bits	Field	Access	Reset	Description
31:0	version_lo	R	0x100A0	SMC version, lower 32 bits

2.1.6.10.3.1.1.2. VERSION_HI

Table 2440. chip_config.VERSION_HI fields

Bits	Field	Access	Reset	Description
31:0	version_hi	R	0x0	SMC version, upper 32 bits

2.1.6.10.3.1.1.3. CHIP_ID

Table 2441. chip_config.CHIP_ID fields

Bits	Field	Access	Reset	Description
31:0	chip_id	R	0x0	Chip ID (e.g. 0 = Memory, 1 = CPU, 2 = AI Compute, 3 = Ethernet)

2.1.6.10.3.1.1.4. LC_STATE

Table 2442. chip_config.LC_STATE fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	lc_state	R	0xF	Lifecycle state value from SEP. Default to invalid state

2.1.6.10.3.1.2. Scratch Address Map

General-purpose scratch register bank.

NOTE

Register Arrays:

- **SCRATCH[8]**: 8 registers, base 0x0, stride 0x4

Table 2443. Scratch Address Map register list

Address	Name	Access	Description
0x0 - 0x1C	SCRATCH[8]	RW	-

2.1.6.10.3.1.2.1. SCRATCH[8]

Table 2444. scratch.SCRATCH[8] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	0x0	Scratch register

2.1.6.10.3.1.3. NDM Reset Control Address Map

Per-cluster NDM reset handshake with an external CPU cluster debug module

Table 2445. NDM Reset Control Address Map register list

Address	Name	Access	Description
0x0	NDMRESET_REQUEST	R	-
0x4	NDMRESET_PROCESS	RW	-
0x8	NDMRESET_CLUSTER_COUNT	R	-

2.1.6.10.3.1.3.1. NDMRESET_REQUEST

Table 2446. ndm_reset.NDMRESET_REQUEST fields

Bits	Field	Access	Reset	Description
31:0	ndmreset_request	R	0x0	Bit i is the NDM reset request from external CPU cluster i. Bits below ndmreset_cluster_count follow the request input. Bits at and above that count read as 0. The field holds up to 32 clusters.

2.1.6.10.3.1.3.2. NDMRESET_PROCESS

Table 2447. ndm_reset.NDMRESET_PROCESS fields

Bits	Field	Access	Reset	Description
31:0	ndmreset_process	RW	0x0	Bit i is the firmware response to the NDM reset request from external CPU cluster i. Bits below ndmreset_cluster_count are driven on the process output. Bits at and above that count are stored and are not driven. The field holds up to 32 clusters.

2.1.6.10.3.1.3.3. NDMRESET_CLUSTER_COUNT

Table 2448. ndm_reset.NDMRESET_CLUSTER_COUNT fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	ndmreset_cluster_count	R	0x0	Number of external CPU clusters connected on the low bits of NDMRESET_REQUEST and NDMRESET_PROCESS. Software masks those registers with this value. The maximum is 32.

2.1.6.10.3.1.4. SMC Miscellaneous Wrapper Address Map

Aggregates the SMC scratch, chip-configuration, and NDM-reset register blocks.

NOTE

Register Arrays:

- **scratch_cold.SCRATCH[8]**: 8 registers, base 0x0, stride 0x4
- **scratch_cold_warm.SCRATCH[8]**: 8 registers, base 0x80, stride 0x4

Table 2449. SMC Miscellaneous Wrapper Address Map register list

Address	Name	Access	Description
0x0 - 0x1C	scratch_cold.SCRATCH[8]	RW	-
0x80 - 0x9C	scratch_cold_warm.SCRATCH[8]	RW	-
0x100	VERSION_LO	R	-
0x104	VERSION_HI	R	-

Address	Name	Access	Description
0x108	CHIP_ID	R	-
0x10C	LC_STATE	R	-
0x200	NDMRESET_REQUEST	R	-
0x204	NDMRESET_PROCESS	RW	-
0x208	NDMRESET_CLUSTER_COUNT	R	-

2.1.6.10.3.1.4.1. scratch_cold.SCRATCH[8]

Table 2450. misc_wrap.scratch_cold.SCRATCH[8] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	0x0	Scratch register

2.1.6.10.3.1.4.2. scratch_cold_warm.SCRATCH[8]

Table 2451. misc_wrap.scratch_cold_warm.SCRATCH[8] fields

Bits	Field	Access	Reset	Description
31:0	data	RW	0x0	Scratch register

2.1.6.10.3.1.4.3. VERSION_LO

Table 2452. misc_wrap.VERSION_LO fields

Bits	Field	Access	Reset	Description
31:0	version_lo	R	0x100A0	SMC version, lower 32 bits

2.1.6.10.3.1.4.4. VERSION_HI

Table 2453. misc_wrap.VERSION_HI fields

Bits	Field	Access	Reset	Description
31:0	version_hi	R	0x0	SMC version, upper 32 bits

2.1.6.10.3.1.4.5. CHIP_ID

Table 2454. misc_wrap.CHIP_ID fields

Bits	Field	Access	Reset	Description
31:0	chip_id	R	0x0	Chip ID (e.g. 0 = Memory, 1 = CPU, 2 = AI Compute, 3 = Ethernet)

2.1.6.10.3.1.4.6. LC_STATE

Table 2455. misc_wrap.LC_STATE fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	lc_state	R	0xF	Lifecycle state value from SEP. Default to invalid state

2.1.6.10.3.1.4.7. NDMRESET_REQUEST

Table 2456. misc_wrap.NDMRESET_REQUEST fields

Bits	Field	Access	Reset	Description
31:0	ndmreset_request	R	0x0	Bit i is the NDM reset request from external CPU cluster i. Bits below ndmreset_cluster_count follow the request input. Bits at and above that count read as 0. The field holds up to 32 clusters.

2.1.6.10.3.1.4.8. NDMRESET_PROCESS

Table 2457. misc_wrap.NDMRESET_PROCESS fields

Bits	Field	Access	Reset	Description
31:0	ndmreset_process	RW	0x0	Bit i is the firmware response to the NDM reset request from external CPU cluster i. Bits below ndmreset_cluster_count are driven on the process output. Bits at and above that count are stored and are not driven. The field holds up to 32 clusters.

2.1.6.10.3.1.4.9. NDMRESET_CLUSTER_COUNT

Table 2458. misc_wrap.NDMRESET_CLUSTER_COUNT fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7:0	ndmreset_cluster_count	R	0x0	Number of external CPU clusters connected on the low bits of NDMRESET_REQUEST and NDMRESET_PROCESS. Software masks those registers with this value. The maximum is 32.

2.1.6.10.3.2. Base Config and DFX Status

2.1.6.10.3.2.1. SMC Base Configuration Address Map

Base-address, region-size, per-block clock-gating enable, and interrupt configuration registers.

Table 2459. SMC Base Configuration Address Map register list

Address	Name	Access	Description
0x0	GLOBAL_BASE	RW	-
0x8	LOCAL_BASE	R	-
0x10	REGION_SIZE	RW	-
0x18	CLOCK_GATE_CONTROL	RW	-
0x20	HANG_DET_SYS_AXI_CTRL	RW	AXI hang detector control and interrupt status.
0x28	HANG_DET_SYS_AXI_TIMEOUT_THRESHOLD	RW	Consecutive cycles with outstanding AXI transactions and no completion before a timeout fires.
0x30	HANG_DET_SEP_AXI_CTRL	RW	AXI hang detector control and interrupt status.
0x38	HANG_DET_SEP_AXI_TIMEOUT_THRESHOLD	RW	Consecutive cycles with outstanding AXI transactions and no completion before a timeout fires.
0x40	HANG_DET_DATA_ACCEL_CTRL	RW	AXI hang detector control and interrupt status.
0x48	HANG_DET_DATA_ACCEL_TIMEOUT_THRESHOLD	RW	Consecutive cycles with outstanding AXI transactions and no completion before a timeout fires.

2.1.6.10.3.2.1.1. GLOBAL_BASE

Table 2460. smc_base_config.GLOBAL_BASE fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	base	RW	0x40000000	Global base address for the CPU

2.1.6.10.3.2.1.2. LOCAL_BASE

Table 2461. smc_base_config.LOCAL_BASE fields

Bits	Field	Access	Reset	Description
63:56	Reserved	-	-	Reserved
55:0	base	R	0xC0000000	Local base address for the CPU

2.1.6.10.3.2.1.3. REGION_SIZE

Table 2462. smc_base_config.REGION_SIZE fields

Bits	Field	Access	Reset	Description
63:32	Reserved	-	-	Reserved
31:0	size	RW	0x1000000	Region size for SMC resources, sizing both the local alias window and the global aperture. Must be a non-zero power of two: the fabric derives its local-alias address mask as (size - 1), so any other value produces a discontiguous mask and misroutes accesses. Zero leaves no reachable local aperture. GLOBAL_BASE and LOCAL_BASE must be aligned to this size. Inbound accesses to a unit whose window extends past this size answer DECERR. Defaults to 16MB (0x100_0000); FW reprograms per chiplet spec.

2.1.6.10.3.2.1.4. CLOCK_GATE_CONTROL

Table 2463. smc_base_config.CLOCK_GATE_CONTROL fields

Bits	Field	Access	Reset	Description
63:30	Reserved	-	-	Reserved
29:24	cg_hysteresis	RW	0x1F	Clockgate cg_hysteresis
23:14	Reserved	-	-	Reserved
13	telemetry_cg_en	RW	0x0	Clock gate enable for telemetry. While set, the telemetry receiver clocks are stopped and every access to the SMC_TELEMETRY_RECEIVER_WRAP window answers SLVERR with read data 0xBADCAB1E.
12	uart_cg_en	RW	0x0	Clock gate enable for UART. While set, the UART peripheral clock is stopped and every access to the SMC_UART_WRAP window answers SLVERR with read data 0xBADCAB1E.
11	i2c_cg_en	RW	0x0	Clock gate enable for I2C. While set, the I2C peripheral clock is stopped and every access to the SMC_I2C_WRAP window answers SLVERR with read data 0xBADCAB1E.
10	avs_cg_en	RW	0x0	Clock gate enable for AVSBus. While set, the AVSBus controller clocks are stopped and every access to the SMC_AVSBUS_CONTROLLER window answers SLVERR with read data 0xBADCAB1E.
9	i3c_cg_en	RW	0x0	Clock gate enable for I3C. While set, the I3C peripheral clock is stopped and every access to the OCA_I3C_WRAP window answers SLVERR with read data 0xBADCAB1E.

Bits	Field	Access	Reset	Description
8	zeroer_cg_en	RW	0x0	Clock gate enable for axi zeroer
7	output_fabric_cg_en	RW	0x0	Clock gate enable for the output fabric remap demux and mux
6	addr_remap_cg_en	RW	0x0	Clock gate enable for address remapper register logic
5	filter_ib_reg_cg_en	RW	0x0	Clockgate enable for inbound filter registers
4	filter_ib_axi_cg_en	RW	0x0	Clockgate enable for the inbound filters
3	filter_ob_reg_cg_en	RW	0x0	Clockgate enable for outbound filter registers
2	filter_ob_axi_cg_en	RW	0x0	Clockgate enable for the outbound filters
1	mailbox_cg_en	RW	0x0	Clockgate enable for the mailbox
0	dma_cg_en	RW	0x0	Clockgate enable for the DMA

2.1.6.10.3.2.1.5. HANG_DET_SYS_AXI_CTRL

Table 2464. smc_base_config.HANG_DET_SYS_AXI_CTRL fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved
12	irq	R	0x0	Reads 1 while this detector's interrupt is asserted, from a timeout or from irq_test, and 0 while enable or irq_en is clear. A live level, not a latch: it clears when the interrupt drops. Writes are ignored.
11:9	Reserved	-	-	Reserved
8	irq_test	RW	0x0	Interrupt test. When 1, asserts irq_o without a bus stall, so firmware can exercise the interrupt path. Gated by enable and irq_en: it substitutes for the timeout, it does not override the interrupt enable.
7:5	Reserved	-	-	Reserved
4	irq_en	RW	0x0	Interrupt enable. When irq_en and enable are high, irq_o follows the detector; when 0, irq_o is held low. Gates a real timeout and irq_test alike.
3:1	Reserved	-	-	Reserved
0	enable	RW	0x0	When 1, the timeout counter runs. When 0, the counter reloads from the threshold and irq_o is forced low.

2.1.6.10.3.2.1.6. HANG_DET_SYS_AXI_TIMEOUT_THRESHOLD

Table 2465. smc_base_config.HANG_DET_SYS_AXI_TIMEOUT_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	value	RW	0x1000	Threshold in clock cycles. Default 0x1000. 20 bits ⇒ up to ~1M cycles (~1ms at 1GHz). 0 disables timeout detection: a stalled bus never asserts irq_o, though irq_test still asserts it. A threshold write takes effect when the stall count next restarts (on a completion, an idle bus, or enable cleared). So it does not change a stall already being timed.

2.1.6.10.3.2.1.7. HANG_DET_SEP_AXI_CTRL

Table 2466. smc_base_config.HANG_DET_SEP_AXI_CTRL fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved

Bits	Field	Access	Reset	Description
12	irq	R	0x0	Reads 1 while this detector's interrupt is asserted, from a timeout or from irq_test, and 0 while enable or irq_en is clear. A live level, not a latch: it clears when the interrupt drops. Writes are ignored.
11:9	Reserved	-	-	Reserved
8	irq_test	RW	0x0	Interrupt test. When 1, asserts irq_o without a bus stall, so firmware can exercise the interrupt path. Gated by enable and irq_en: it substitutes for the timeout, it does not override the interrupt enable.
7:5	Reserved	-	-	Reserved
4	irq_en	RW	0x0	Interrupt enable. When irq_en and enable are high, irq_o follows the detector; when 0, irq_o is held low. Gates a real timeout and irq_test alike.
3:1	Reserved	-	-	Reserved
0	enable	RW	0x0	When 1, the timeout counter runs. When 0, the counter reloads from the threshold and irq_o is forced low.

2.1.6.10.3.2.1.8. HANG_DET_SEP_AXI_TIMEOUT_THRESHOLD

Table 2467. smc_base_config.HANG_DET_SEP_AXI_TIMEOUT_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	value	RW	0x1000	Threshold in clock cycles. Default 0x1000. 20 bits ⇒ up to ~1M cycles (~1ms at 1GHz). 0 disables timeout detection: a stalled bus never asserts irq_o, though irq_test still asserts it. A threshold write takes effect when the stall count next restarts (on a completion, an idle bus, or enable cleared). So it does not change a stall already being timed.

2.1.6.10.3.2.1.9. HANG_DET_DATA_ACCEL_CTRL

Table 2468. smc_base_config.HANG_DET_DATA_ACCEL_CTRL fields

Bits	Field	Access	Reset	Description
31:13	Reserved	-	-	Reserved
12	irq	R	0x0	Reads 1 while this detector's interrupt is asserted, from a timeout or from irq_test, and 0 while enable or irq_en is clear. A live level, not a latch: it clears when the interrupt drops. Writes are ignored.
11:9	Reserved	-	-	Reserved
8	irq_test	RW	0x0	Interrupt test. When 1, asserts irq_o without a bus stall, so firmware can exercise the interrupt path. Gated by enable and irq_en: it substitutes for the timeout, it does not override the interrupt enable.
7:5	Reserved	-	-	Reserved
4	irq_en	RW	0x0	Interrupt enable. When irq_en and enable are high, irq_o follows the detector; when 0, irq_o is held low. Gates a real timeout and irq_test alike.
3:1	Reserved	-	-	Reserved
0	enable	RW	0x0	When 1, the timeout counter runs. When 0, the counter reloads from the threshold and irq_o is forced low.

2.1.6.10.3.2.1.10. HANG_DET_DATA_ACCEL_TIMEOUT_THRESHOLD

Table 2469. smc_base_config.HANG_DET_DATA_ACCEL_TIMEOUT_THRESHOLD fields

Bits	Field	Access	Reset	Description
31:20	Reserved	-	-	Reserved
19:0	value	RW	0x1000	Threshold in clock cycles. Default 0x1000. 20 bits ⇒ up to ~1M cycles (~1ms at 1GHz). 0 disables timeout detection: a stalled bus never asserts irq_o, though irq_test still asserts it. A threshold write takes effect when the stall count next restarts (on a completion, an idle bus, or enable cleared). So it does not change a stall already being timed.

2.1.6.10.3.2.2. DFX Control and Status Address Map

Memory-repair and MBIST status, debug clock and cross-trigger controls, and debug-mux selects.

Table 2470. DFX Control and Status Address Map register list

Address	Name	Access	Description
0x0	STATUS_SMU	R	-
0x8	DEBUG_CTRL	RW	-
0x10	DEBUG_BUS_MUX	RW	Mode, ID and lane selects for the twelve debug-bus muxes that reduce the SMC debug bus to the 16 CLA input lanes. Each mux takes its mode while Dbmid equals its ID, and its lane selects while Dbmid equals its ID and its mode is 1, so program one mux at a time.

2.1.6.10.3.2.2.1. STATUS_SMU

Table 2471. dfx_ctrl_status.STATUS_SMU fields

Bits	Field	Access	Reset	Description
63:13	Reserved	-	-	Reserved
12	mbist_abort	R	0x0	One bit indicator from DFT logic to say that MBIST has hit timeout and aborted This register is sticky 1 and will hold the value until reset
11:9	Reserved	-	-	Reserved
8	mbist_pass	R	0x0	One bit indicator from DFT logic to say when MBIST is successful This register is sticky 1 and will hold the value until reset
7:5	Reserved	-	-	Reserved
4	mbist_done	R	0x0	One bit indicator from DFT logic to say when MBIST is completed This register is sticky 1 and will hold the value until reset
3	Reserved	-	-	Reserved
2	mem_repair_abort	R	0x0	One bit indicator from DFT logic to say that mem repair has hit timeout and aborted This register is sticky 1 and will hold the value until reset
1	mem_repair_success	R	0x0	One bit indicator from DFT logic to say if mem repair was successful This register is sticky 1 and will hold the value until reset
0	mem_repair_done	R	0x0	One bit indicator from DFT logic to say when mem repair is completed. This register is sticky 1 and will hold the value until reset

2.1.6.10.3.2.2.2. DEBUG_CTRL

Table 2472. dfx_ctrl_status.DEBUG_CTRL fields

Bits	Field	Access	Reset	Description
31	Reserved	-	-	Reserved
30:23	debug_marker	RW	0x0	Holds the written value for software to read back. It has no effect in the SMC; the debug marker on the SMC debug bus comes from the core logic analyzer (CLA).

Bits	Field	Access	Reset	Description
22:7	xtrig_clk_halt_mask	RW	0x0	CLA cross-trigger and halt-clock enable. Bit 0 (register bit 7) enables every CLA cross-trigger output lane together with the CLA halt-clock request; 0 holds them all inactive. Bits 15:1 hold the written value for software to read back and have no effect.
6	dtb_ew_en	RW	0x0	Holds the written value for software to read back. It has no effect in the SMC.
5	dtb_ns_en	RW	0x0	Holds the written value for software to read back. It has no effect in the SMC.
4	force_clk_en	RW	0x0	Design-for-debug (DFD) clock force. 1 keeps the DFD clock running whatever the value of cg_en.
3	cg_en	RW	0x0	DFD clock stop. 1 stops the clock to the debug-bus muxes and the CLA unless force_clk_en is 1; 0 lets it run. The clock also runs while the SMC is in reset.
2	gpio_en	RW	0x0	Holds the written value for software to read back. It has no effect in the SMC.
1:0	chiplet_enable	RW	0x0	Holds the written value for software to read back. It has no effect in the SMC.

2.1.6.10.3.2.2.3. DEBUG_BUS_MUX

Table 2473. dfx_ctrl_status.DEBUG_BUS_MUX fields

Bits	Field	Access	Reset	Description
63:58	Muxselseg7	RW	0x0	No effect in the SMC: each debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
57:52	Muxselseg6	RW	0x0	No effect in the SMC: each debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
51:46	Muxselseg5	RW	0x0	No effect in the SMC: each debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
45:40	Muxselseg4	RW	0x0	No effect in the SMC: each debug-bus mux has four output lanes, selected by Muxselseg0 to Muxselseg3.
39:34	Muxselseg3	RW	0x0	Binary input-lane select for output lane 3 of the addressed debug-bus mux, which takes eight 16-bit input lanes and drives four. 0 selects input lane 3; a value k from 1 to 4 selects input lane k+3, so 4 selects lane 7; 5 to 63 drive zero.
33:28	Muxselseg2	RW	0x0	Binary input-lane select for output lane 2 of the addressed debug-bus mux, which takes eight 16-bit input lanes and drives four. 0 selects input lane 2; a value k from 1 to 4 selects input lane k+3, so 4 selects lane 7; 5 to 63 drive zero.
27:22	Muxselseg1	RW	0x0	Binary input-lane select for output lane 1 of the addressed debug-bus mux, which takes eight 16-bit input lanes and drives four. 0 selects input lane 1; a value k from 1 to 4 selects input lane k+3, so 4 selects lane 7; 5 to 63 drive zero.
21:16	Muxselseg0	RW	0x0	Binary input-lane select for output lane 0 of the addressed debug-bus mux, which takes eight 16-bit input lanes and drives four. 0 selects input lane 0; a value k from 1 to 4 selects input lane k+3, so 4 selects lane 7; 5 to 63 drive zero.
15:8	Rsvd158	RW	0x0	-
7:2	Dbmid	RW	0x0	ID of the debug-bus mux to program: 3 to 6 address the level-2 muxes and 7 to 14 the level-3 muxes.
1:0	Dbmmode	RW	0x0	Mode selection, 0: DBM off, 1: Normal debug mode, 2: DBM ID output mode, 3: Toggle Mode

2.1.6.10.3.3. Component Register References

For detailed register-level documentation of each SMC component, refer to the individual component documentation (Table 2474).

Table 2474. SMC Component Documentation

Category	Description	Reference
CPU and System Control	CPU Control, PLIC, CLINT, Watchdog Timers, and Bus Error Units	cpu
Interrupt Controller	Platform-Level Interrupt Controller (PLIC) details	interrupts
DMA Controller	DMA Controller detailed register interface	dma
Memory Zeroer	Memory Zeroer control registers	zeroer
Fabric Control	Address remapping, inbound/outbound filters, and fabric control registers	fabric
Peripherals and I/O	Mailbox, System Timer OCTS, eFuse, UART 16550, Log Engine, I2C, I3C, AVSBus, GPIO, and Telemetry Receiver	periphs
Reset Management	Reset unit and system control registers	clk_rst
Clock Generation	PLL wrapper and clock generation registers	pll
DFD / CLA	Design-for-debug wrap and Core Logic Analyzer register map	dfd

2.1.7. Debug & Test Ports (DTP)

The Debug & Test Ports (DTP) module provides debug and test infrastructure. It integrates the JTAG Interface Unit (JIU) and the Cross Trigger Network (CTN) into a single instantiable subsystem that exposes a standard external JTAG port, internal debug bridges, and a configurable cross-trigger fabric.

2.1.7.1. Capabilities

- **JTAG access** — IEEE 1149.1-2013 Primary TAP with configurable Secondary TAPs for hierarchical multi-chiplet debug connectivity per IEEE 1838-2019 (3DIC).
- **iJTAG chains** — IEEE 1687-2014 SIB-based chains for DFT secure, DFT non-secure, and DFD instrumentation, plus SMC and SEP OTP debug bridges.
- **JTAG2AXI bridges** — SMC fabric, SMC OTP and SEP OTP debug access without system software.
- **Cross-trigger fabric** — Configurable network (1–32 external CTPs, 0–32 internal cross triggers) supporting both wire-OR and point-to-point signalling per the Open Chiplet Cross Triggering (OCCT) specification.
- **Clock stop** — Unified halt path combining JTAG DEBUG_CONTROL and CLA clock-stop requests, with separate CLA-only readback for software observation.
- **Lifecycle feature control** — SEP-driven enable polarity gates eleven debug and test paths (five STAP/scan paths, three iJTAG chains and three JTAG2AXI bridges) independently.

2.1.7.2. Overview

The DTP contains two major functional blocks — the JTAG Interface Unit (JIU) and the Cross Trigger Network (CTN) — plus the DTP top-level wiring that connects them to each other, to the SMC and SEP, and to the external JTAG and cross-trigger pads.




Figure 78. DTP internal structure

Figure 78 draws each RTL instance under its instance name inside the `u_jtag_intf_unit` and `u_cross_trigger_network` hierarchy boundaries. Labels at the figure edges name what each DTP port connects to in the SMU. Blue lines carry JTAG and scan data, dark lines AXI4 and AXI-Lite, and grey lines other signals. Dashed blocks exist only when their enable parameter is set: the three JTAG2AXI bridges follow `JTAG_SMC_DBG_ENABLE` and `JTAG_SEP_DBG_ENABLE`, and the STAPs follow `JTAG_STAP_IO_ENABLE`, `JTAG_SMC_DBG_ENABLE`, `JTAG_SEP_DBG_ENABLE` and `JTAG_NUM_EXTRA_STAPS`. The grey fan-out from the debug-disable synchroniser reaches every STAP, SIB and bridge. The DTP JTAG scan chain figure gives the serial order of the scan paths.

The figure names each count by its `dtp` parameter. `XTRIG_NUM_CTP` external CTPs, `XTRIG_NUM_INT_CT` internal lanes and

XTRIG_NUM_CLK_STOP_REQ clock-stop requests default to the dtp_pkg values 16, 10 and 9. The CTM is N × N, where N is XTRIG_NUM_CTP + XTRIG_NUM_INT_CT (26 by default); its generated register geometry must equal that sum, which elaboration checks. u_axil_xbar has one manager port for the CTM and one for each external CTP, 17 by default. JTAG_NUM_EXTRA_STAPS sets the number of u_stap_extra instances, 1 by default. In the cross-trigger network, u_axil_xbar decodes the DTP CSR window, which the SMC peripheral crossbar rebases to 0, onto the CTM at offset 0x000 and one 16-byte window for each external CTP from 0x200. The internal cross-trigger lanes are u_int_ctp_core instances without CSRs, whose protocol XTRIG_INT_CT_MODE fixes. In the SMU the first two lanes connect to the SMC DFD CLA, one clock-stop request comes from the CLA, and the remaining lanes and requests leave the SMU.

2.1.7.2.1. JTAG Interface Unit

The JTAG Interface Unit (JIU) is the top-level JTAG control module. It contains:

- A Primary TAP (PTAP) — the main chiplet JTAG entry point, connected to the five external JTAG pins (TCK, TDI, TDO, TMS, TRST_n).
- A configurable set of Secondary TAPs (STAPs) — for I/O chiplet-to-chiplet JTAG, SMC CPU debug, SEP CPU debug, and optional extra TAPs.
- An iJTAG network selected by SELECT_IJTAG, with a serial cascade of secure DFT, non-secure DFT, and DFD SIBs. Each SIB inserts or bypasses its associated external scan segment.
- Independent instruction-selected PTAP TDRs for SMC fabric debug (JTAG2AXI), SMC OTP (JTAG2AXIL), and SEP OTP (JTAG2AXIL). These bridges are outside the iJTAG SIB cascade.

2.1.7.2.2. Cross Trigger Network

The Cross Trigger Network (CTN) routes cross-trigger pulses between on-chip sources and sinks and the external CTP pads. It consists of:

- **Cross Trigger Ports (CTPs)** — pad-facing modules, each connecting to four I/O pads (CT_Req_out, CT_Ack_in, CT_Req_in, CT_Ack_out) and supporting both wire-OR and point-to-point signalling.
- **Cross Trigger Matrix (CTM)** — an N × N AND-OR crossbar (26 × 26 by default) that statically routes trigger pulses under AXI-Lite CSR control.
- **Clock stop aggregation** — the CTN OR-reduces all xtrig_clk_stop_req_i inputs (CLA sources) and OR-combines the result with the JTAG jtag_clock_stop bit to produce the registered stop_clks_o output.

Per-path debug-disable inputs gate STAPs, iJTAG SIBs, and JTAG2AXI bridges.

2.1.7.2.3. Debug Access Paths

External debug access reaches the DTP subsystem through two routes:

JTAG path: An external debugger drives the five JTAG pins directly. The PTAP decodes the JTAG instruction, selects the appropriate TDR, and routes data through the scan chain. JTAG2AXI instructions allow the debugger to generate AXI transactions on the SMC fabric via the PTAP's built-in bridges, without involving the SMC CPU.

AXI path: The DTP cross-trigger configuration registers (CTM and CTP CSRs) are memory-mapped inside the SMC address space. The SMC exposes them on its axil_dtp_csr_req_o / axil_dtp_csr_resp_i interface, which the SMU wires directly to the DTP axil_xtrig_req_i / axil_xtrig_resp_o ports. Software running on the SMC reaches the CTN CSRs through its own register map (dtp_ctrl_reg in smc.rdl). An external debugger using the PTAP JTAG2AXI bridge reaches the same window through the SMC fabric AXI port. See the CTN Memory Map section for the CTN-internal address layout.

Firmware and an external debugger share this window. The Programmer's Guide gives the cross-trigger programming sequence.

2.1.7.3. Clocks and Resets

2.1.7.3.1. Clock Domains

The DTP operates in two clock domains (Table 2475).

Table 2475. DTP clock domains

Domain	Signal	Description
System clock	`clk_i`	Main clock for cross-trigger logic and AXI interfaces. All CTN and CSR logic runs in this domain.
JTAG clock	TCK	JTAG test clock for all TAP controller and scan logic. Clocks the PTAP, STAP state machines, and scan registers. Asynchronous to `clk_i`.

The combined JTAG and CLA clock-stop request crosses into `clk_i` through two synchronizer stages in `ctn_clock_stop_ctrl`, followed by an output register. The CLA clock-stop status also crosses into TCK through the DEBUG_CONTROL TDR's two-flop `u_cla_clock_stop_sync` synchronizer before bit 4 captures it. The CTP handshake crossings are described in the CTP interface.

2.1.7.3.2. Reset Architecture

Table 2476 identifies the reset inputs and the logic they reset.

Table 2476. DTP reset signals

Signal	Description
`rst_n_i`	Active-low asynchronous reset for cross-trigger logic and AXI interfaces. Resets all CTN and CSR state; clock-stop output resets to 0 (clocks running).
`pwr_on_rst_ni`	Active-low asynchronous power-on reset for JTAG logic. Combined internally with TRST_n; resets the PTAP to Test-Logic-Reset state and clears all TDRs.
TRST_n (JTAG pin)	Optional external active-low TAP reset. When asserted, drives the PTAP to Test-Logic-Reset regardless of the TCK or TMS state.

All registers reset to safe states. The JTAG TAP returns to Test-Logic-Reset on either TRST_n or power-on reset.

2.1.7.3.3. IC_RESET Overrides

The primary TAP exposes a reset-selection test data register (TDR) through `IC_RESET`. IEEE 1149.1-2013 defines the instruction in Clause 8.21 and the reset-selection register in Clause 17. The IEEE working-group summary of the 2013 changes identifies both clauses. In this implementation, per reset port it holds `reset_control`, the active-low reset value to drive, and `reset_enable`, which selects it. One `reset_hold` bit sits nearest TDO.

`reset_enable` is active low despite the name: it resets to 1, leaving the port's functional reset connected, and writing 0 hands the port over to `reset_control`. The overrides leave the DTP on `jtag_ic_reset_{smc,sep,ext}_o`, whose `.ovrd` member is active high and whose `.val` carries `reset_control`.

`reset_hold` also resets to 1, which lets Test-Logic-Reset clear the enable/control bits. Write 0 to keep an override asserted across TLR; only TRST clears `reset_hold` itself.

Consumers select between the two sources with a hazard-free multiplexer, which holds its output while the select alone

moves. Moving `reset_enable` and `reset_control` in one Update-DR changes the select and a data input together, which can pulse a reset on a port that neither source is resetting. The Programmer's Guide gives the override sequence.

At the SMU the TDR concatenates three slices from TDI to TDO: SMC, SEP, then the external slice, followed by `reset_hold`. The SMC and SEP port lists are OCAH-defined. The external slice is adopter-defined: its width and fields come from the SMU type parameter `ic_reset_ext_t`. The Integrator Guide records the SMU-composed port map.

2.1.7.3.4. Clock Stop

The DTP combines JTAG DEBUG_CONTROL and CLA clock-stop request sources into one functional chiplet halt path, while keeping the CLA-only status separate for debugger readback.

2.1.7.3.4.1. Halt Path Architecture

Figure 79 shows how JTAG and CLA requests contribute to the chiplet halt path, with the DTP as the SMU instantiates it. The DEBUG_CONTROL TDR is drawn as its five bits, with bit 0 nearest TDO. The grey box below the DTP is the part of the SMC DFD block (`smc_dfd_wrap`) that produces the SMC's clock-stop request and exchanges cross-triggers with the DTP. Gate and flop symbols draw the logic of the path, and CDC badges mark the two-flop synchronizers where a signal enters the TCK or `clk_i` domain.




Figure 79. DTP JTAG and CLA clock-stop aggregation

Three distinct signals participate in clock stop:

`jtag_clock_stop` (JTAG DEBUG_CONTROL bit 3)

Written through the DEBUG_CONTROL TDR (IR 0x18) in the primary TAP and routed to the CTN clock-stop controller. OR-combined with CLA requests to form the registered `stop_clks_o` output that connects to chiplet functional clock gating. The bit resets on TRST, on power-on reset and whenever the TAP enters Test-Logic-Reset.

`cla_clock_stop_en` (JTAG DEBUG_CONTROL bit 2)

Exported at the DTP top level as `cla_clock_stop_en_o`. It is not part of the `stop_clks_o` aggregation inside the CTN. In the SMU it drives the SMC DFD's `tdr_dbg_ctrl_clock_stop_en_i`, which gates the SMC CLA's clock-stop request on `xtrig_clk_stop_req_i[0]`, so it decides whether the SMC CLA can halt the chiplet.

CLA clock-stop indication

The CTN OR-reduces `xtrig_clk_stop_req_i` (CLA sources only, not `jtag_clock_stop`) to form the `cla_clock_stop` readback status. The OR is combinational, so the DEBUG_CONTROL TDR passes it through a two-flop TCK synchronizer before bit 4 captures it in Capture-DR. A debugger reads it there to observe whether any CLA clock-stop source is active.

2.1.7.3.4.2. Signal Flow

1. The JTAG Interface Unit captures DEBUG_CONTROL bits in the TCK domain. The `jtag_clock_stop` bit is routed to the CTN clock-stop controller; `cla_clock_stop_en` is exported at the DTP boundary.
2. The CTN OR-reduces `xtrig_clk_stop_req_i` to produce `cla_clock_stop` status, then OR-combines that aggregate with `jtag_clock_stop`. The result passes a two-flop `clk_i` synchronizer and an output flop to produce `stop_clks_o`, which follows the requests three `clk_i` cycles later and is low while `rst_n_i` is asserted.
3. The `cla_clock_stop` status is fed back into the DEBUG_CONTROL readback path so a debugger can observe CLA clock-stop source activity independently of its own direct-stop assertion.

This architecture keeps CLA observability distinct from the JTAG direct-stop path, while either source can assert the functional chiplet halt through `stop_clks_o`.

In the SMU, lane 0 of the `XTRIG_NUM_CLK_STOP_REQ` `xtrig_clk_stop_req_i` lanes carries the SMC DFD's clocks-stopped output. That output is the CLA halt-clock action, masked by bit 0 of `xtrig_clk_halt_mask` in the SMC DFX CSRs and ANDed with `cla_clock_stop_en_o`; it also raises an SMC CPU interrupt. The remaining lanes, `xtrig_clk_stop_req_i[XTRIG_NUM_CLK_STOP_REQ-1:1]`, come from the SMU's own `xtrig_clk_stop_req_i` ports. The same mask gates the CLA cross-trigger outputs, which reach the cross-trigger matrix through internal lanes 1 and 0 (`xtrig_ctm_dst_req_i[1:0]`); `xtrig_ctm_src_req_o[1:0]` returns to the CLA. The SMU runs both SMC lanes in pulse-synchronization mode and ties their acknowledges low, and exports internal lanes 9 to 2.

For the CTN clock-stop controller implementation and the `xtrig_clk_stop_req_i` input indexing, see Cross-Trigger Network.

2.1.7.3.5. Clock Distribution

Figure 80 shows which DTP blocks use the system clock and which use TCK. The DTP has two clocks and no clock gates. `clk_i`, the system clock (`clk_smu_i` in the SMU), clocks the whole cross-trigger network and the AXI side of the three JTAG2AXI bridges. TCK, from `jtag_ptap_client_tap_ctrl_i.tck`, clocks the rest of the JTAG interface unit. Each block is tinted by the clock that runs it, and each clock has one arrow into each hierarchy it reaches. CDC badges mark the blocks that synchronize a signal from another domain: the cross-trigger port input synchronizers, the clock-stop controller, the `dbg_disable_i` synchronizers, the DEBUG_CONTROL `cla_clock_stop` synchronizer and the JTAG2AXI bridges' `u_axi_cdc`. TCK leaves the DTP unchanged on the host TAP control of every STAP and on the host scan control of the boundary-scan, extended STAP, DFT and DFD ports.




Figure 80. DTP system-clock and JTAG-clock distribution

2.1.7.3.6. Reset Distribution

Figure 81 shows the reset distribution for DTP system logic and the JTAG scan paths. Each reset has its own colour, and the input names below the DTP ports are the SMU nets that drive them. Gate and flop symbols show where resets are combined, and a reset ends on the bottom edge of the flop it resets.

- `rst_n_i` (`rst_primary_smc_clk_no` in the SMU) resets the cross-trigger network and the AXI side of the JTAG2AXI bridges.
- `pwr_on_rst_ni` (`powergood_stable` in the SMU) sets the `dbg_disable_i` synchronizers to 1, disabling every debug path until the lifecycle value arrives. `u_trst_n_and` ANDs it with the TRST pin to form the combined TRST.

- The combined TRST resets the TAP controller, including its Test-Logic-Reset flop, the TMP controller and the TDO retiming flop. It also resets the hold flops of the 3DCR and IC_RESET TDRs, the 3DCR scan register and the STAPs, and leaves unchanged on the host TAP control of every STAP.
- The TAP controller derives the scan reset `rst_n`, which is low in Test-Logic-Reset, and the scan channel reset `chrst_n`, which the TMP persistence mode holds released through Test-Logic-Reset. `rst_n` resets the instruction register, most TDRs, the TCK side of the JTAG2AXI bridges, the STAPs and the SIBs. The 3DCR TDR takes it only while its hold bit is clear, and the IC_RESET TDR only while its `reset_hold` bit is set. `chrst_n` is not used inside the DTP; both leave on the host scan control of the boundary-scan, extended STAP, DFT and DFD ports.

The two-flop `cla_clock_stop` synchronizer in the DEBUG_CONTROL TDR has no reset. `test_en_i` drives the test mode of the cross-trigger network and the JTAG2AXI bridges. `scan_rst_ni` is not connected inside the DTP, which has no reset synchronizer, so `rst_n_i` must arrive scan-controlled. A STAP whose enable parameter is 0 drives its host TRST low.




Figure 81. DTP system and JTAG reset distribution

2.1.7.4. JTAG Operation

This page describes how the DTP integrates its JTAG components at the subsystem level: topology, scan chain ordering, lifecycle feature control. Clock domains and reset overrides are described in Clocks and Resets; IP Reference contains the individual JTAG components.

2.1.7.4.1. DTP JTAG Topology

The DTP instantiates a single JTAG Interface Unit (JIU) as the primary debug entry point for the chiplet. The JIU connects to:

- The five external JTAG pins (TCK, TDI, TDO, TMS, TRST_n).
- The Cross Trigger Network, for the `jtag_clock_stop` bit in the DEBUG_CONTROL instruction and for the `cla_clock_stop` readback status.
- The SMC AXI fabric via a JTAG2AXI bridge.
- The SMC and SEP OTP controllers via AXI4-Lite JTAG2AXI bridges.
- The SMC and SEP CPU debug TAPs via STAPs.

Figure 82 shows the PTAP, secondary scan path, and iJTAG instrument network.




Figure 82. DTP JTAG scan chain

Read Figure 82 along the arrows from TDI to TDO. TDI reaches every register and external chain at once; the IR and TDR

mux returns the instruction register in Shift-IR and, in Shift-DR, the register the current instruction selects. Italic labels beside a mux name the instructions or the select bit that choose its input, and 0 or 1 at a mux input is the select value that picks it. The PTAP output then enters the STAP chain, which is scanned only while the TAP_3DCR STAP-select bit is set: the bit gates the chain's scan strobes and selects its return onto TDO. Otherwise TDO takes the PTAP output directly. TDO is retimed on the falling edge of TCK except during a ZERO_LENGTH_BYPASS DR scan with the STAP-select bit clear, when the last mux takes the TDO mux output ahead of the retimer and TDI reaches TDO combinationally. While the bit is set, ZERO_LENGTH_BYPASS behaves exactly as BYPASS: the PTAP bypass register leads the STAP chain and the chain's return is retimed. The figure counts the extra STAPs by the jtag_intf_unit parameter NUM_EXTRA_STAPS, which dtp sets from JTAG_NUM_EXTRA_STAPS. Each STAP and SIB carries, in italics, the dbg_disable_i field that closes it. Dashed blocks exist only when their enable parameter is set, as the list below gives for the STAPs; the JTAG2AXI bridges follow JTAG_SMC_DBG_ENABLE and JTAG_SEP_DBG_ENABLE. Each STAP adds one SIB bit to the chain; opening the SIB inserts the STAP's 3-bit 3DCR, and setting the 3DCR STAP-select bit splices in its secondary TAP. Each iJTAG SIB inserts its external segment after its SIB bit while that bit is set.

2.1.7.4.2. STAP Secondary Scan Path

The PTAP secondary scan path connects the STAPs in this fixed order:

1. PTAP
2. I/O STAP — when JTAG_STAP_IO_ENABLE=1
3. SMC debug STAP — when JTAG_SMC_DBG_ENABLE=1
4. SEP debug STAP — when JTAG_SEP_DBG_ENABLE=1
5. Extra STAP instances [JTAG_NUM_EXTRA_STAPS-1:0]
6. Return to PTAP

When a STAP is disabled by parameter, the DTP bypasses it in the secondary scan chain and drives its host outputs low, apart from TCK, which still follows the PTAP.

2.1.7.4.3. JTAG2AXI Bridges

The PTAP contains three JTAG2AXI bridges, each selected by its own group of six instructions (Table 2477). The request and response type parameters of a bridge set its bus type, address width and data width. Its read and write pipeline-depth parameters set how many transactions it queues, where 0 allows a single outstanding transaction. The table lists the DTP defaults. Each bridge reports its configuration in its *_JTAG2AXI_CAPS register. Every output of a bridge's manager port depends only on the bridge's internal state, so no combinational path runs from the port's inputs to its outputs. A bridge accepts a response from the cycle after its request handshake completes.

Table 2477. DTP JTAG2AXI bridges

Bridge	Instructions	Bus	Address / data width (bits)	Type parameters	Pipeline-depth parameters (default 3)
SMC fabric	0x27–0x2C (SMC_*)	AXI4	56 / 64	smc_jtag_axi_req_t, smc_jtag_axi_resp_t	SMC_RD_PL_DEPTH, SMC_WR_PL_DEPTH
SMC OTP	0x1B–0x20 (SMC_OTP_*)	AXI4-Lite	32 / 32	smc_otp_axil_req_t, smc_otp_axil_resp_t	SMC_OTP_RD_PL_DEPTH, SMC_OTP_WR_PL_DEPTH
SEP OTP	0x21–0x26 (SEP_OTP_*)	AXI4-Lite	32 / 32	sep_otp_axil_req_t, sep_otp_axil_resp_t	SEP_OTP_RD_PL_DEPTH, SEP_OTP_WR_PL_DEPTH

2.1.7.4.4. Debug Disable

dbg_disable_i (sep_lifecycle_ctrl_pkg::dbg_disable_t) is a per-path debug/test disable vector. Each field is active-high (1

= path disabled). The JTAG interface unit synchronizes the vector into the TCK domain and applies each field to the named path.

Table 2478 maps each debug path to its active-high disable field.

Table 2478. DTP debug-disable paths

Path	Disable Field
I/O STAP host path	`dbg_disable_i.stap_io`
SMC debug STAP host path	`dbg_disable_i.stap_smc`
SEP debug STAP host path	`dbg_disable_i.stap_sep`
Extra STAP host paths	`dbg_disable_i.stap_extra`
External STAP return path	`dbg_disable_i.stap_host`
Secure external DFT iJTAG path	`dbg_disable_i.dft_secure`
Non-secure external DFT iJTAG path	`dbg_disable_i.dft_nonsecure`
DFD iJTAG path	`dbg_disable_i.dfd`
SMC fabric JTAG2AXI path	`dbg_disable_i.smc_jtag2axi`
SMC OTP JTAG2AXI path	`dbg_disable_i.smc_otp_jtag2axi`
SEP OTP JTAG2AXI path	`dbg_disable_i.sep_otp_jtag2axi`

A disabled path remains observable only where required for control and readback. For a JTAG2AXI bridge, disabling means TDR update registers are not latched. The disable gates the idle state: an active AXI transaction continues to completion, and buffered requests are flushed when idle is reached. For a STAP, the host-visible scan access is clamped so the disabled path cannot reach downstream secure logic.

The STAP and iJTAG fields are applied in `jtag_intf_unit`; the three JTAG2AXI fields are applied in `jtag_ptap`.

2.1.7.5. Cross-Trigger Operation

The Cross-Trigger Network (CTN) routes debug events between internal sources and external cross-trigger ports. Matrices select event destinations; ports provide wire-OR or point-to-point signaling at the chiplet boundary.

2.1.7.5.1. Event Routing

The CTN combines Cross-Trigger Matrices (CTMs) and Cross-Trigger Ports (CTPs). The port modes are configured before the matrix routes for an event path, and both before the participating debug sources are enabled.

2.1.7.5.2. Clock Stop

JTAG and CLA clock-stop requests feed the chiplet halt path. Clocks and Resets owns its aggregation, clock-domain crossing and reset behavior.

Clock-stop integration

2.1.7.5.3. Programming Reference

IP Reference groups the network, port and matrix descriptions. The CTN owns the unified register map; its component chapters describe routing and handshakes.

CTN Register Map

The Programmer's Guide gives the cross-trigger programming sequence for the port modes and matrix routes referenced above.

2.1.7.6. IP Reference

The JTAG family provides scan and debug access. The cross-trigger family routes events and coordinates debug actions between blocks and chiplets.

2.1.7.6.1. JTAG

2.1.7.6.1.1. JTAG Interface Unit

The JTAG Interface Unit (JIU) is the top-level JTAG control module for the DTP subsystem. It manages the primary JTAG port and all supporting instrument logic.

2.1.7.6.1.1.1. Overview

The JIU contains:

- A Primary TAP (PTAP) with chiplet IDCODE, boundary scan, BIST, reset control and JTAG2AXI bridges.
- A configurable number of Secondary TAPs (STAPs) for downstream chiplet JTAG, SMC CPU debug, SEP CPU debug, and optional additional TAPs.
- An iJTAG network with SIB-based chains for DFT (secure and non-secure), DFD, and JTAG2AXI bridges to the SMC fabric, SMC OTP and SEP OTP controllers.
- Per-path debug-disable inputs gate STAPs, iJTAG SIBs, and JTAG2AXI bridges.

The PTAP, STAP and all supporting logic conform to IEEE 1149.1-2013 (JTAG), IEEE 1687-2014 (iJTAG) and IEEE 1838-2019 (3DIC).

2.1.7.6.1.1.2. Configuration Parameters

The JIU is configured through the PTAP feature enables, the I/O, SMC debug and SEP debug STAP enables, the number of additional STAPs, the IDCODE and JTAG_CAPS values, and the JTAG2AXI pipeline depths.

The parameters of `jtag_intf_unit` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.1.1.3. Architecture

The JTAG Interface Unit integrates the PTAP, STAP chain and iJTAG network into a unified debug access point.

Figure 83 shows the PTAP, STAP chain, and iJTAG network at the debug access point. Follow the arrows from TDI to TDO: italic labels beside a mux name the instructions or select bit that choose its input, 0 or 1 at a mux input is the select value that picks it, and italic labels in the STAPs and SIBs name the `dbg_disable_i` field that closes each one. Dashed blocks exist only when their enable parameter is set; `NUM_EXTRA_STAPS` sets the number of `u_stap_extra` instances. TDO is retimed on the falling edge of TCK except during a `ZERO_LENGTH_BYPASS` DR scan with the `TAP_3DCR` STAP-select bit clear, when the last mux takes the TDO mux output ahead of the retimer and TDI reaches TDO combinationally. While the bit is set, `ZERO_LENGTH_BYPASS` behaves exactly as `BYPASS`: the PTAP bypass register leads the STAP chain and the chain's return is retimed, because the chain launches its last bit on the rising TCK edge.




Figure 83. JTAG Interface Unit scan chain

2.1.7.6.1.1.3.1. Scan Chain Topology

The PTAP is connected to the incoming JTAG interface for the chiplet. The scan chain is organized in three major segments: the Primary TAP processes all instructions, the Secondary TAP chain provides hierarchical TAP access, and the iJTAG network enables instrument-level access to debug blocks.

2.1.7.6.1.1.3.1.1. STAP Chain Hierarchy

The STAP chain implements a four-level hierarchy with configurable lockup latch insertion optimized for different physical routing distances.

Table 2479 relates each STAP level to its lockup-latch configuration and physical role.

Table 2479. JIU STAP chain hierarchy

Level	STAP Type	TDI_LOCKUP	SCAN_OUT_LOCKUP	Purpose
1	I/O STAP	1	0	Chiplet-to-chiplet connectivity (die boundary crossing)
2	SMC Debug STAP	0	0	On-chip connection to SMC CPU debugger TAP
3	SEP Debug STAP	0	0	On-chip connection to SEP CPU debugger TAP
4	Extra STAPs [N-1:0]	0	0	Local debug ports

The I/O STAP enables TDI lockup to handle the longer propagation delays across die boundaries. On-chip STAPs (SMC Debug, SEP Debug) disable TDI lockup since signal routing is local to the chiplet.

No STAP in the chain enables scan output lockup. The chain return reaches the PTAP's falling-edge TDO retimer, and a lockup ahead of that retimer would add one TCK of latency to every scan through the STAP chain. The last STAP's scan output also drives `stap_host_scan_out_o`, which launches on the rising edge of TCK like the host scan outputs of the iJTAG SIBs.

`stap_host_scan_out_o` carries the scan bit of the last STAP's SIB. That bit resets to 0 on TRST and in Test-Logic-Reset, so the port reads 0 from reset.

2.1.7.6.1.1.3.1.2. Debug Disable Synchronization

`dbg_disable_i` (`sep_lifecycle_ctrl_pkg::dbg_disable_t`) is in the system clock domain and must be synchronized to TCK before use. The interface unit synchronizes each bit through a 2-FF chain whose reset value is 1 (fail-closed). The synchronized fields gate STAP and SIB selection and are forwarded to the PTAP for the JTAG2AXI bridges.

Each field is active-high (1 = path disabled).

Table 2480 maps each debug access point to its synchronized disable field.

Table 2480. JIU debug-disable fields

Access Point	Disable Field
I/O STAP	`dbg_disable_i.stap_io`
SMC Debug STAP	`dbg_disable_i.stap_smc`
SEP Debug STAP	`dbg_disable_i.stap_sep`
Extra STAPs	`dbg_disable_i.stap_extra`
External STAP return path	`dbg_disable_i.stap_host`
DFT Secure SIB	`dbg_disable_i.dft_secure`
DFT Non-Secure SIB	`dbg_disable_i.dft_nonsecure`
DFD SIB	`dbg_disable_i.dfd`
SMC fabric JTAG2AXI	`dbg_disable_i.smc_jtag2axi`
SMC OTP JTAG2AXI	`dbg_disable_i.smc_otp_jtag2axi`
SEP OTP JTAG2AXI	`dbg_disable_i.sep_otp_jtag2axi`

2.1.7.6.1.1.3.2. iJTAG Network

The iJTAG network is organized into three cascaded Segment Insertion Bit (SIB) chains. Each SIB is gated by the corresponding synchronized debug-disable field. Each SIB's scan bit and control bit reset to 0 on TRST and in Test-Logic-Reset, so `dft_secure_host_scan_out_o`, `dft_host_scan_out_o` and `dfd_host_scan_out_o` read 0 from reset, whether or not the SIB is disabled.

The PTAP selects the iJTAG network as its DR under SELECT_IJTAG and, when `RUNBIST_ENABLE` is set, under RUNBIST. From TDI the scan path passes through the DFT Secure SIB, the DFT Non-Secure SIB and the DFD SIB, and the DFD SIB's output returns to the PTAP. Each SIB is one bit long. While a SIB is open, its segment is inserted on the TDO side of its bit: the SIB bit drives the segment's scan input, and the segment's return continues to the next SIB. With every SIB closed the iJTAG DR is three bits long, laid out as in Table 2481.

Table 2481. JIU iJTAG DR with every SIB closed

DR Bit	SIB	Segment Ports	Disable Field
0	DFD	dfd_host_scan_*	dbg_disable_i.dfd
1	DFT Non-Secure	dft_host_scan_*	dbg_disable_i.dft_nonsecure
2	DFT Secure	dft_secure_host_scan_*	dbg_disable_i.dft_secure

Bit 0 is nearest TDO and is the first bit shifted in. A SIB bit shifted in as 1 opens that SIB at Update-DR, and its segment is on the scan path from the next DR scan. Each SIB captures its own open state. A SIB whose disable field is set stays closed and remains a one-bit stage that captures 0, whatever is shifted into it.

With the DFT Non-Secure SIB open and an N-bit segment, the DR is N + 3 bits long: bit 0 is the DFD SIB, bits N to 1 are the segment with the bit nearest its scan output at bit 1, bit N + 1 is the DFT Non-Secure SIB and bit N + 2 is the DFT Secure SIB. The network attached to each segment's ports defines its contents and length. The Programmer's Guide gives the segment access sequence.

2.1.7.6.1.1.3.2.1. DFT Secure Chain

The DFT Secure chain is gated by dbg_disable_i.dft_secure. This port is for security-sensitive DFT control.

2.1.7.6.1.1.3.2.2. DFT Non-Secure Chain

The DFT Non-Secure chain is gated by dbg_disable_i.dft_nonsecure. General DFT control is attached to this port.

2.1.7.6.1.1.3.2.3. DFD Chain

The Design-for-Debug (DFD) chain is gated by dbg_disable_i.dfd. Integrator-defined debug instruments are attached to this port.

2.1.7.6.1.1.3.3. JTAG2AXI Interfaces

The interface unit instantiates multiple JTAG2AXI bridges. Each bridge is a set of PTAP TDRs selected by its own instructions and gated by its own dbg_disable_i field (Table 2480); no bridge is reached through the iJTAG network.

- **SMC JTAG2AXI TDRs**: This set of TDRs provide a mechanism to inject AXI transactions onto the SMC AXI local interconnect.
- **SMC Fuse JTAG2AXIL TDRs**: This set of TDRs provide a mechanism to interact directly with the SMC fuse controller. The JTAG2AXIL interface connects to the fuse controller CSRs through an AXI4-lite-to-APB bridge.
- **SEP Fuse JTAG2AXIL TDRs**: This set of TDRs provide a mechanism to interact directly with the SEP fuse controller. The JTAG2AXIL interface connects to the fuse controller CSRs through an AXI4-lite-to-APB bridge.

2.1.7.6.1.1.4. Interface

2.1.7.6.1.1.4.1. Instruction Encodings

The JTAG interface unit uses 6-bit instruction encodings (Table 2482).

Table 2482. JIU instruction encodings

Encoding	Name	Register Size	Security
0x00	BYPASS (IEEE 1149.1, Section 8.4)	1	
0x01	IDCODE (IEEE 1149.1, Section 8.13)	32	

Encoding	Name	Register Size	Security
0x02	RUNBIST (IEEE 1149.1, Section 8.10)	BIST	
0x03	SAMPLE_PRELOAD (IEEE 1149.1, Sections 8.6 and 8.7)	BSR	
0x04	EXTEST (IEEE 1149.1, Section 8.8)	BSR	
0x05	EXTEST_TRAIN	BSR	
0x06	EXTEST_PULSE	BSR	
0x07	CLAMP (IEEE 1149.1, Section 8.11)	1	
0x08	HIGHZ (IEEE 1149.1, Section 8.16)	1	
0x09	INTEST (IEEE 1149.1, Section 8.9)	BSR	
0x0A	CLAMP_HOLD (IEEE 1149.1, Section 8.20)	2	
0x0B	CLAMP_RELEASE (IEEE 1149.1, Section 8.20)	2	
0x0C	TMP_STATUS (IEEE 1149.1, Section 8.20)	2	
0x0D	IC_RESET (IEEE 1149.1, Section 8.21)	Variable	
0x0E	TAP_3DCR (IEEE 1838, Section 5.5.1)	2	
0x10-0x17	*Reserved for RISC-V*		
0x18	DEBUG_CONTROL	5	
0x19	JTAG_CAPS	60	
0x1A	SELECT_IJTAG	Variable	
0x1B	SMC_OTP_JTAG2AXI_CAPS	14	
0x1C	SMC_OTP_AXI_SINGLE_OP	Variable	
0x1D	SMC_OTP_AXI_SERIES_CTRL	Variable	
0x1E	SMC_OTP_AXI_SERIES_DATA_INCR	Variable	
0x1F	SMC_OTP_AXI_SERIES_DATA_NO_INCR	Variable	
0x20	SMC_OTP_AXI_SERIES_DATA_WITH_ERROR_STATUS	Variable	
0x21	SEP_OTP_JTAG2AXI_CAPS	14	
0x22	SEP_OTP_AXI_SINGLE_OP	Variable	
0x23	SEP_OTP_AXI_SERIES_CTRL	Variable	
0x24	SEP_OTP_AXI_SERIES_DATA_INCR	Variable	
0x25	SEP_OTP_AXI_SERIES_DATA_NO_INCR	Variable	
0x26	SEP_OTP_AXI_SERIES_DATA_WITH_ERROR_STATUS	Variable	
0x27	SMC_JTAG2AXI_CAPS	14	
0x28	SMC_AXI_SINGLE_OP	Variable	
0x29	SMC_AXI_SERIES_CTRL	Variable	
0x2A	SMC_AXI_SERIES_DATA_INCR	Variable	
0x2B	SMC_AXI_SERIES_DATA_NO_INCR	Variable	
0x2C	SMC_AXI_SERIES_DATA_WITH_ERROR_STATUS	Variable	

Encoding	Name	Register Size	Security
0x3D	ZERO_LENGTH_BYPASS	0; 1, as BYPASS, while the PTAP TAP_3DCR STAP-select bit is set	
0x3E	INV_BYPASS		
0x3F	BYPASS (IEEE 1149.1, Section 8.4)	1	

The length of each variable-length JTAG2AXI register follows from the bridge's address width, data width and pipeline depth, and for the series data registers from the size last written to `*_AXI_SERIES_CTRL`. The PTAP JTAG2AXI Support section defines each layout.

NOTE: All instruction encodings *not* explicitly defined in this table map to the BYPASS instruction.

2.1.7.6.1.1.4.2. Signal Interface

Packed control and bus types remain bundles at the `jtag_intf_unit` boundary; their members are not separate scalar ports.

The parameters and ports of `jtag_intf_unit` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.1.1.4.3. Dependencies

The JTAG Interface Unit depends on the following components:

- `hw/ip/jtag/jtag_ptap` - Primary TAP
- `hw/ip/jtag/jtag_stap` - Secondary TAP
- `hw/common/ocah_prim` - Primitive cells

2.1.7.6.1.2. JTAG PTAP

The Primary TAP (PTAP) is the main JTAG access point for the chiplet. It implements IEEE 1149.1-2013 with extensions for IEEE 1687-2014 (iJTAG) and IEEE 1838-2019 (3DIC).

2.1.7.6.1.2.1. Overview

The PTAP provides:

- Full IEEE 1149.1-2013 TAP controller with 16-state FSM and one-hot encoding.
- Test Data Registers (TDRs) for all defined JTAG instructions.
- Test Mode Persistence (TMP) support — gates JTAG clock stop and test assertion across a configurable list of reset conditions.
- Boundary scan with scan ports and control signals.
- BIST support via the RUNBIST instruction.
- 3DIC support (TAP_3DCR) for STAP selection over a JTAG scan chain.
- iJTAG SIB-based network access.
- JTAG2AXI debug bridges for SMC fabric, SMC OTP and SEP OTP.

2.1.7.6.1.2.2. Configuration Parameters

The PTAP is configured through feature enables for the optional instructions, TMP, IC_RESET slices and debug bridges, the IC_RESET slice types, the IDCODE and JTAG_CAPS values, and the JTAG2AXI pipeline depths.

The parameters of `jtag_ptap` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.1.2.3. Architecture

The PTAP is fully compliant with the IEEE JTAG specifications. It implements a modular design with a core TAP controller, dedicated register modules for each instruction type, and optional AXI bridge modules for debug access. The architecture supports Test Mode Persistence (TMP), boundary scan with dedicated scan ports and control signals, BIST functionality, and 3DIC support with STAP scan ports and control signals derived from internal TDRs.

Figure 84 shows the control, decode, and scan-data paths through the PTAP.




Figure 84. PTAP module architecture

Blue lines carry scan data and grey lines carry control. `client_tdi_i` feeds the instruction register and every register in the scan-register group, whose last column gives the IR opcodes, in hex, that select each register for a DR scan. The 6-bit instruction register captures `6'b000001`, resets to IDCODE and decodes its opcode one-hot onto `inst_decoded_o[63:0]`. An opcode with no register of its own, or one whose enable parameter is 0, selects BYPASS. Dashed registers and bridges are present only when their parameter enables them (Table 2483). The boundary-scan chain and the iJTAG network lie outside the PTAP: `client_tdi_i` is forwarded to them, and their returns enter the TDR multiplexer.

`tdr_mux` takes the output of every register in the group and the boundary-scan and iJTAG returns. It selects the instruction register while `ir_scan_ctrl.select` is set, and otherwise the register that `inst_decoded_o` selects. The numbers on the inputs of each 2:1 multiplexer are the select values that pass them. `u_zlb_tdr_mux` passes `client_tdi_i` instead of

tdr_mux during a ZERO_LENGTH_BYPASS DR scan, and its output also leaves on stap_host_scan_out_o toward the STAP chain. u_tdo_mux passes the chain return stap_host_scan_in_i while stap_select, the TAP_3DCR select bit, is set. The retimer registers the result on the falling TCK edge, and u_tdo_bypass_mux bypasses the retimer during a ZERO_LENGTH_BYPASS DR scan. Both ZERO_LENGTH_BYPASS multiplexers take their select from inst_decoded_o[3D] ANDed with dr_scan_select_reg, the DR scan select registered on the falling TCK edge, and with the inverse of stap_select. While stap_select is set, ZERO_LENGTH_BYPASS therefore behaves exactly as BYPASS (Section 2.1.7.6.1.2.3.4.1).

pwr_on_rst_ni is ANDed with the client TRST in u_trst_n_and. The result, jtag_trst_n, resets the TAP controller and the retimer, and the controller forwards it with TCK and TMS on host_tap_ctrl_o. The controller also drives the IR and DR scan controls, ORed together and gated by stap_select, on stap_host_scan_ctrl_o, so the STAP chain holds its state while the bit is clear. The TMP controller takes the decoded CLAMP_HOLD, CLAMP_RELEASE and BYPASS instructions and the TMP_STATUS bypass_escape_bit, and returns persistence_mode to the TAP controller. The AXI side of each JTAG2AXI bridge runs on clk_i and rst_n_i and takes the DFT test-mode enable test_en_i; the figure omits all three. Each bridge has its own *_security_disable_i input (Table 2498).

2.1.7.6.1.2.3.1. Module Hierarchy

Table 2483 identifies the PTAP submodules and the conditions under which they are instantiated.

Table 2483. PTAP module hierarchy

Module	Purpose	Conditional
jtag_tap_ctrlr	IEEE 1149.1 TAP controller FSM (16 states, one-hot encoded)	Always instantiated
jtag_inst_reg	6-bit instruction register with 64-wide one-hot decoded output	Always instantiated
jtag_byp_reg	1-bit bypass register (BYPASS instruction)	Always instantiated
jtag_inv_byp_reg	1-bit inverted bypass register (INV_BYPASS instruction)	Always instantiated
jtag_idcode_reg	32-bit IDCODE register	Always instantiated
jtag_3dcr_reg	2-bit 3D Control Register for STAP control	When STAP_IO_ENABLE || SEP_DBG_ENABLE || SMC_DBG_ENABLE || NUM_EXTRA_STAPS != 0
jtag_tmp	Test Mode Persistence controller	When TMP_ENABLE=1
jtag_tmp_status_reg	2-bit TMP status register	When TMP_ENABLE=1
jtag_ic_reset_reg	IC_RESET control register (2*(NumSmcIcReset+NumSepIcReset+NumExtIcReset)+1 bits)	When any of IC_RESET_SMC_ENABLE, IC_RESET_SEP_ENABLE, IC_RESET_EXT_ENABLE is 1
jtag_debug_ctrl_reg	5-bit debug control register	Always instantiated
jtag_caps_reg	60-bit capabilities readback register	Always instantiated
jtag2axi (SMC OTP)	JTAG-to-AXI-Lite bridge for SMC OTP controller	When SMC_DBG_ENABLE=1
jtag2axi (SEP OTP)	JTAG-to-AXI-Lite bridge for SEP OTP controller	When SEP_DBG_ENABLE=1
jtag2axi (SMC fabric)	JTAG-to-AXI bridge for SMC system fabric	When SMC_DBG_ENABLE=1

2.1.7.6.1.2.3.2. TAP Controller State Machine

The TAP controller implements the IEEE 1149.1 16-state finite state machine using one-hot encoding. Each state is assigned a unique bit position within a 16-bit vector, enabling direct state detection via single-bit comparisons.

Table 2484 lists the one-hot encodings and functions of the sixteen TAP-controller states.

Table 2484. PTAP state encodings

State	Encoding	Description
TEST_LOGIC_RESET	16'h0001	State 0: Reset state, instruction register loads IDCODE
RUN_TEST_IDLE	16'h0002	State 1: Idle state between operations
SELECT_DR_SCAN	16'h0004	State 2: Select data register scan path
CAPTURE_DR	16'h0008	State 3: Capture data into selected DR
SHIFT_DR	16'h0010	State 4: Shift data through selected DR
EXIT1_DR	16'h0020	State 5: Exit from shift to either pause or update
PAUSE_DR	16'h0040	State 6: Pause DR shift operation
EXIT2_DR	16'h0080	State 7: Exit from pause back to shift or update
UPDATE_DR	16'h0100	State 8: Update DR from shift register
SELECT_IR_SCAN	16'h0200	State 9: Select instruction register scan path
CAPTURE_IR	16'h0400	State 10: Capture data into IR (fixed pattern 6'b000001)
SHIFT_IR	16'h0800	State 11: Shift data through IR
EXIT1_IR	16'h1000	State 12: Exit from shift to either pause or update
PAUSE_IR	16'h2000	State 13: Pause IR shift operation
EXIT2_IR	16'h4000	State 14: Exit from pause back to shift or update
UPDATE_IR	16'h8000	State 15: Update IR, decode new instruction

Five consecutive TCK cycles with TMS high bring the state machine to TEST_LOGIC_RESET from any state, as the IEEE 1149.1 state graph defines. A state register value that is not one of the sixteen one-hot encodings also moves to TEST_LOGIC_RESET on the next rising edge of TCK.

Control signals are generated using a split approach. The update and run-test-idle signals are decoded combinationally from the current state as Moore machine outputs. The capture, shift, test-logic-reset and TDO output enable signals are decoded from the current state and registered on the falling edge of TCK, so they are stable before the next rising edge samples data.

2.1.7.6.1.2.3.3. Reset Hierarchy

The PTAP employs a three-level reset hierarchy to support power-on initialization, JTAG reset, and conditional register preservation.

Table 2485 identifies the source and scope of each PTAP reset.

Table 2485. PTAP reset hierarchy

Reset Signal	Source	Scope
`jtag_trst_n`	`pwr_on_rst_ni && client_tap_ctrl_i.trst_n`	Primary reset for all JTAG logic, combines power-on and external TRST
`test_logic_reset`	Derived from TAP FSM state (asserted when state == TEST_LOGIC_RESET)	Resets instruction and data registers
`chrst_n`	`TMP_ENABLE ? (!test_logic_reset || persistence_mode_i) : !test_logic_reset`	Channel reset for TMP-aware registers, preserves state when in persistence mode

The primary reset `jtag_trst_n` is formed by AND-gating the power-on reset input with the external TRST signal. This combined reset feeds all JTAG clock domain logic. The TAP controller derives `test_logic_reset` from the FSM state, which normally resets all registers. When Test Mode Persistence is enabled, the conditional reset `chrst_n` allows boundary scan and configuration registers to survive TEST_LOGIC_RESET state transitions while in persistence mode.

2.1.7.6.1.2.3.4. TDR Multiplexer

The PTAP implements an instruction-dependent data register multiplexer. During IR scan operations, the instruction register connects to the scan path. During DR scan operations, the appropriate data register is selected based on the currently decoded instruction. Each test data register has dedicated scan control logic that enables selection only when the corresponding instruction is active and the required feature is enabled.

The scan path supports zero-length bypass through explicit `prim_stdmux2` multiplexer cells rather than behavioral multiplexing. This implementation prevents glitches on scan path selectors during instruction transitions.

STAP selection is implemented as a second-level multiplexer. When the 3DCR register's select bit is asserted, the STAP chain input replaces the TDR multiplexer output. The STAP scan control signals are generated by OR-combining the instruction register and data register scan controls, enabling STAP operation during both IR and DR scan sequences as required by IEEE 1838. The select bit also gates the select, capture, shift and update strobes of the STAP scan interface, so they stay low while the bit is clear.

2.1.7.6.1.2.3.4.1. Zero-Length Bypass

While the TAP_3DCR STAP-select bit is clear, the ZERO_LENGTH_BYPASS instruction connects TDI directly to TDO without intermediate register stages, providing minimum scan latency for hierarchical JTAG chains. The DR scan adds no bit, and TDO follows TDI combinationally rather than through the retimer.

While the STAP-select bit is set, ZERO_LENGTH_BYPASS behaves exactly as BYPASS. The last stage of the STAP chain shifts on the rising TCK edge, so its return must reach TDO through the falling-edge retimer, and a path that skips the retimer cannot carry it. The bypass register is selected, captures 0 and leads the STAP chain, and TDO is retimed. A DR scan under ZERO_LENGTH_BYPASS is then one bit longer than the STAP chain and matches a DR scan under BYPASS bit for bit.

2.1.7.6.1.2.3.5. TDO Retiming

The TDO output is retimed on the falling edge of TCK as required by IEEE 1149.1 Section 4.5.2. The retiming register ensures that TDO transitions occur at the same clock edge that samples TDI at the receiving device, maintaining timing margins across board-level JTAG chains. For zero-length bypass operation with the TAP_3DCR STAP-select bit clear, the retimer is bypassed using an explicit `prim_stdmux2` cell to minimize scan latency. While the bit is set, TDO is retimed under every instruction, ZERO_LENGTH_BYPASS included.

2.1.7.6.1.2.3.6. ID Code

The IDCODE instruction accesses a TDR containing device identification information.

Table 2486 defines the identification fields shifted out by IDCODE.

Table 2486. PTAP IDCODE fields

Bits	Field	Access	Description
31:28	si_rev	R	Silicon revision
27:12	part_num	R	Chiplet model ID
11:1	mfr_id	R	JEDEC-assigned manufacturer ID, encoded into 11 bits
0	marker	R	Marker bit, always 1

Bits shifted into the IDCODE TDR are ignored. The Programmer's Guide gives the TDR access sequence for this register.

2.1.7.6.1.2.3.7. Debug Control

The DEBUG_CONTROL instruction accesses a TDR defining general control bits for debug and control of the design.

Table 2487 defines the clock-stop and debug-control fields of the DEBUG_CONTROL TDR.

Table 2487. PTAP DEBUG_CONTROL fields

Bits	Field	Access	Reset	Description
4	cla_clock_stop	R	0	When set, indicates that a CLA in the chiplet attempted to stop the clocks. Note that the clocks will actually have been stopped only when *cla_clock_stop_en* is set.
3	jtag_clock_stop	RW	0	When set, stops all clocks in the chiplet. This is wired to the functional clock gaters on all of the PLLs in the chiplet. This bit is active high.
2	cla_clock_stop_en	RW	0	When set, enables the CLAs to stop the clocks in the design. This bit indicates that an external debugger is connected and ready to do debug or scan dump operations after the CLA stops the clocks. This bit is intended to protect against unintentional CLA clock stops in the field due to incorrect CLA programming. This bit is active high.
1	boot_stall_ovrd	RW	0	When set, overrides the boot stall signal to the internals of the part to use the value from boot_stall in this TDR instead. This bit is active high.
0	boot_stall	RW	0	When boot_stall_override is set, the value in this bit is used for boot stall. This bit is active high: setting to 1 causes boot stall.

The DEBUG_CONTROL TDR captures bits shifted into its R/W fields and ignores those shifted into its RO fields. The Programmer's Guide gives the TDR access sequence for this register.

2.1.7.6.1.2.3.8. JTAG Capabilities

The JTAG_CAPS instruction accesses a read-only TDR reporting the DTP version number and general configuration parameters for the DTP.

Table 2488 defines the version and configuration fields reported by JTAG_CAPS.

Table 2488. PTAP JTAG_CAPS fields

Bits	Field	Access	Description
59:54	num_xtrig_int_ct	R	The number of internal cross trigger signals.
53:48	num_xtrig_ctp	R	The number of Cross Trigger Ports.
47:44	num_xtra_stap	R	The number of additional DTP STAP interfaces.
43	stap_io_en	R	The STAP interface for chiplet-to-chiplet connectivity is enabled.
42	sep_dbg_en	R	The SEP STAP interface enabled.
41	smc_dbg_en	R	The SMC JTAG2AXI interface is enabled.
40:33	num_smc_ic_rst	R	The number of SMC IC_RESET override ports.
32:25	num_sep_ic_rst	R	The number of SEP IC_RESET override ports.
24:17	num_ext_ic_rst	R	The number of external IC_RESET override ports.
16	ic_rst_inst_en	R	The IC_RESET instruction is enabled.
15	tmp_inst_en	R	The TMP controller functionality and instructions are enabled.
14	runbist_inst_en	R	The RUNBIST instruction is enabled.
13	highz_inst_en	R	The HIGHZ instruction is enabled.
12	clamp_inst_en	R	The CLAMP instruction is enabled.

Bits	Field	Access	Description
11	intest_inst_en	R	The INTEST instruction is enabled.
10	extest_pulse_en	R	The EXTEST_PULSE instruction is enabled.
9	extest_train_en	R	The EXTEST_TRAIN instruction is enabled.
8	bsr_inst_en	R	All mandatory boundary scan instructions are enabled.
7:0	och_ver	R	The MAJOR version number of the DTP IP.

Bits shifted into the JTAG_CAPS TDR are ignored. The Programmer's Guide gives the TDR access sequence for this register.

2.1.7.6.1.2.3.9. Boundary Scan Support

All boundary scan and BIST instructions defined in IEEE 1149.1 are optionally supported, but support is not enabled by default. RTL parameters are provided to selectively enable support for each instruction. Any disabled instruction has the same behavior as the BYPASS instruction.

Any boundary scan instruction that selects the BSRs shifts their contents out on TDO. The Programmer's Guide gives the TDR access sequence for these registers.

2.1.7.6.1.2.3.10. BIST Support

The RUNBIST instruction is optionally supported, but support is not enabled by default. An RTL parameter is provided to selectively enable support. Any disabled instruction has the same behavior as the BYPASS instruction.

When the RUNBIST instruction is selected, the iJTAG network is selected as the active scan chain. An iJTAG network control signal indicates that the RUNBIST instruction is active. A designer may also utilize the decoded INST_SELECT signal to trigger the BIST logic for any instructions that they have enabled.

The PTAP adds no Segment Insertion Bit (SIB) or other scan cell to the iJTAG path. TDI is forwarded unchanged to the iJTAG network, and the network's return is the RUNBIST TDR, so the length and contents of the RUNBIST DR are defined entirely by the iJTAG network attached to the PTAP.

The Programmer's Guide gives the BIST execution sequence.

In the JTAG Interface Unit, the iJTAG network begins with three SIBs; their bit map and the integrated scan sequence are given in iJTAG Network.

2.1.7.6.1.2.3.11. Test Mode Persistence (TMP) Support

There is optional support for TMP, but support for TMP is disabled by default. An RTL parameter enables support for TMP.

When TMP support is enabled, a TMP controller is included in the PTAP. The TMP controller manages the active-low *CH_RESET_N* signal. The *CH_RESET_N* signal is the reset signal for any registers that must retain their state across TLR soft resets, mainly the boundary scan cells. *CH_RESET_N* asserts whenever the TAP is in the TLR state *except* when the TMP controller is in the *PERSISTENCE_ON* state. When the TMP controller is in the *PERSISTENCE_ON* state, the only events that will assert *CH_RESET_N* are full power-on-reset (POR) or TRST signal assertion.

When TMP support is disabled, the *CLAMP_HOLD*, *CLAMP_RELEASE*, and *TMP_STATUS* instructions have the same behavior as the *BYPASS* instruction, and the *CH_RESET_N* signal always responds to every POR, TRST, or TLR event, i.e. it is an exact copy of the *RESET_N* signal.

Table 2489 defines the bypass-escape and persistence-status bits.

Table 2489. PTAP TMP_STATUS fields

Bit	Reset	Description
Bypass Escape (bit 0)	0	Whenever this bit is set, the TMP controller will transition to the *PERSISTENCE_OFF* state when the TAP controller enters the *UPDATE_IR* state after the *BYPASS* instruction has been selected.
TMP Status (bit 1)	0 on capture	Capture-DR samples whether the TMP controller is in the Persistence-On state. The update register resets to `2'b10`; its bit 1 is replaced by the controller state on capture and does not enable persistence.

2.1.7.6.1.2.3.12. 3DIC Support

There is optional support for STAP interfaces, and support is enabled by default. An RTL parameter selects the number of STAP interfaces, where a value of 0 disables STAP support.

In order to properly support the IEEE 1838 standard, a chain of STAP interfaces must be inserted at the end of each chiplet's scan chain. This is done after the *IR Select* MUX to ensure that both the instruction registers and TDRs from all enabled PTAPs in the scan chain are scannable. As a consequence, the STAPs require dedicated capture, shift, and update control signals that are triggered during both the IR and DR sequences.

The PTAP has a 2-bit *3DCR* register that is accessed with the *TAP_3DCR* instruction. This register provides an option to bypass all STAPs in the scan chain.

Table 2490 defines the configuration-hold and STAP-selection bits.

Table 2490. PTAP 3DCR fields

Bit	Reset	Description
Config Hold	0	When this bit is set, the PTAP TLR state does not reset this TDR, and it will hold its current state until TRST is asserted.
Select	0	When this bit is unset, the PTAP's top-level STAP scan interface is completely bypassed: TDO does not come from the STAP chain, and the select, capture, shift and update strobes of the STAP scan interface stay low, so the STAP chain holds its state through every IR and DR scan.

The select bit takes effect at Update-DR of the scan that writes it. A scan that sets it therefore covers only this register, and the STAP chain joins the scan path from the next IR or DR scan onwards. Software sets the select bit in a TAP_3DCR scan of its own before programming any STAP.

When STAP support is disabled, the TAP_3DCR instruction has the same behavior as the *BYPASS* instruction, and the STAP scan chain cannot be selected.

2.1.7.6.1.2.3.13. IC_RESET Support

The PTAP provides support for a configurable number of IEEE 1149.1-compliant reset controls. The IC_RESET TDR is composed of three independently-enabled slices:

- **SMC slice** (nearest TDI): driven by the `ic_reset_smc_t` struct type and gated by `IC_RESET_SMC_ENABLE`. Sized from `$bits(ic_reset_smc_t)`.
- **SEP slice**: driven by the `ic_reset_sep_t` struct type and gated by `IC_RESET_SEP_ENABLE`. Sized from `$bits(ic_reset_sep_t)`.
- **External slice** (nearest TDO): driven by the `ic_reset_ext_t` struct type and gated by `IC_RESET_EXT_ENABLE`. Sized from

`$bits(ic_reset_ext_t)`. The instantiator supplies this type; the PTAP does not name the external ports.

Each slice's struct must contain `.ovrd` and `.val` sub-structs of identical width (checked via an elaboration-time assertion in `jtag_ptap`). Within `jtag_ic_reset_reg`, the reset-enable and reset-control bits are interleaved in IEEE 1149.1 §17 order: in each port's pair, `reset_enable` is nearer TDO and `reset_control` nearer TDI, so port *n* occupies TDR bits `2*n+1` and `2*n+2` (Table 2491). `jtag_ptap` packs the three struct slices into that interleaved bus and unpacks the outputs back into structured form. The TDR carries the SMC slice closest to TDI, then SEP, then the external slice, followed by the single `reset_hold` bit.

The total length is `2 * (NumSmcIcReset + NumSepIcReset + NumExtIcReset) + 1` bits. Each `Num*IcReset` is half the width of its slice's struct type, `$bits(ic_reset_*_t) / 2`, when the matching `IC_RESET_*_ENABLE` parameter is set, and 0 otherwise.

Table 2491 defines the reset-control, reset-enable, and bypass fields in the IC_RESET TDR.

Table 2491. PTAP IC_RESET fields

Bits	Field	Access	Reset	Description
2*n+2	reset_control	RW	1	The controlled, active-low reset value driven while *reset_enable* is 0 (i.e. while JTAG override is active).
2*n+1	reset_enable	RW	1	Active-LOW per IEEE 1149.1 §17: 1 (default) ⇒ JTAG override DISABLED (upstream reset passes through); 0 ⇒ JTAG override ENABLED (the port is driven by *reset_control*). The "enable" in the IEEE name refers to "enabling the controlled reset state", not the override mechanism.
0	reset_hold	RW	1	When 0, TLR will **not** reset the *reset_enable* and *reset_control* bits. TRST/POR will always reset all bits.

IMPORTANT

Polarity convention — the TDR field names come from the IEEE 1149.1 §17 specification and use an active-low `reset_enable`. `jtag_ic_reset_reg` converts this into a conventional **active-high** override signal (`ic_reset_ovrd_o[i] = !reset_enable[i]`) before it leaves the register, so every downstream consumer sees `.ovrd == 1` meaning "JTAG is currently overriding this port". Do not re-invert this signal downstream.

For each of the resets defined in the TDR, the PTAP exposes two logical signals (grouped into the per-slice `jtag_*_reset_ctrl_t` structs):

- *ic_reset_ovrd* / `.ovrd` - **Active-high** JTAG-override flag (the bit-wise inversion of *reset_enable*). 1 ⇒ JTAG is driving this reset, 0 ⇒ upstream reset passes through.
- *ic_reset_ctrl_n* / `.val` - Active-low reset value driven when *ic_reset_ovrd* is asserted (identical to the *reset_control* TDR bit).

2.1.7.6.1.2.3.14. iJTAG Support

The PTAP provides a scan port for an IEEE 1687-2014-compliant hierarchical iJTAG network. The *SELECT_IJTAG* instruction is always decoded; no configuration parameter removes it. While it is the current instruction, a DR scan selects the iJTAG network and the network return drives TDO.

2.1.7.6.1.2.3.15. JTAG2AXI Support

2.1.7.6.1.2.3.15.1. *_JTAG2AXI_CAPS

This is a private instruction that accesses a read-only TDR reporting the configuration parameters for the given JTAG2AXI debugging instrument.

Table 2492 defines the configuration fields reported by each JTAG2AXI instrument.

Table 2492. PTAP JTAG2AXI capability fields

Bits	Field	Access	Description
13:12	rd_pl_depth	R	The depth of the transaction read queue where 0 indicates only a single outstanding transaction allowed at any given time.
11:10	wr_pl_depth	R	The depth of the transaction write queue where 0 indicates only a single outstanding transaction allowed at any given time.
9:7	data_size	R	The size of AxDATA in powers-of-2 bytes. 0: 1 byte (8 bits) 1: 2 bytes (16 bits) 2: 4 bytes (32 bits) 3: 8 bytes (64 bits) 4: 16 bytes (128 bits) 5: 32 bytes (256 bits) 6: 64 bytes (512 bits) 7: 128 bytes (1024 bits)
6:1	addr_size	R	The size of AxADDR in bits.
0	bus_type	R	The type of the AXI bus. 0: AXI4 1: AXI4-Lite

2.1.7.6.1.2.3.15.2. *_AXI_SINGLE_OP

This is a private instruction that generates a single AXI read or write transaction. It provides a mechanism for an external debugger to do sparse reads or writes to nearly any register in the design. Since the entire address must be shifted in for each transaction, this instruction is most useful for sparse accesses. This instruction uses semantics very similar to the RISC-V DTM DMI instruction.

Let `D` be the AXI data width in bits, `A` the address width, and `S` the scan size-field width: 1 bit for `D ⇐ 16`, 2 bits for `D ⇐ 64`, and 3 bits otherwise. The single-operation TDR has `2 + S + D/8 + D + A` bits. For `D=64` and `A=51`, it has 127 bits.

The size field requests a transfer of `2**size` bytes. The AXI protocol does not allow a transfer wider than the data bus, so the bridge uses the effective size `E = min(size, data_size)`, where `data_size = log2(D/8)` is the capability field of the same name. A size above `data_size` transfers one full `D`-bit beat: for `D=32`, the 2-bit size field admits 3, and the bridge transfers 4 bytes.

Figure 85 shows the single-operation TDR for a 64-bit data bus and a 51-bit address bus. In this and the following layout figures the most significant bit is on the left, nearest TDI, and bit 0 on the right shifts out to TDO first. The bit range of each field is above it and its width below it; field widths are not drawn to scale.




Figure 85. JTAG2AXI single-operation layout

Table 2493 defines the address, data, byte-enable, size, and operation fields.

Table 2493. JTAG2AXI single-operation fields

Bits	Field	Access	Reset	Description
(2+S+D/8+D) +: A	address	RW	0	Address used for AXI access. In Update-DR the AXI transaction is issued. On a Capture-DR, this field holds the previous value.
(2+S+D/8) +: D	data	RW	0	The data to write on an AXI write during Update-DR. On a Capture-DR, this field contains the data returned from an AXI read if the previous operation was a read, or holds the write data previously used if the previous operation was a write.

Bits	Field	Access	Reset	Description
(2+S) +: (D/8)	wstrb	RW	0	The byte strobes for a write transaction. This value is driven on WSTRB when the transaction is a write. On a Capture-DR, this field holds the previous value.
2 +: S	size	RW	0	The requested transfer size in powers-of-2 bytes. The effective size E, the smaller of this field and data_size, is used as AxSIZE for the transaction. 0: 1 byte (8 bits) 1: 2 bytes (16 bits) 2: 4 bytes (32 bits) 3: 8 bytes (64 bits) 4: 16 bytes (128 bits) 5: 32 bytes (256 bits) 6: 64 bytes (512 bits) 7: 128 bytes (1024 bits)
1:0	op	RW	0	When the debugger writes this field, it has the following meaning: 0: Ignore data and address (nop) Don't send anything over AXI during Update-DR. This operation should never result in a busy or error response. 1: Read from address (read) 2: Write data to address (write) 3: Reserved When the debugger reads this field, it means the following: 0: The previous operation completed successfully and returned an OKAY status 1: The previous operation completed but failed and returned a SLVERR status 2: The previous operation completed but failed and returned a DECERR or other error status, or a system reset discarded it (see Section 2.1.7.6.1.2.3.15.7). 3: The latest operation was attempted before the previous operation completed; the previous AXI request is still in progress. The operation attempted in this access will be ignored. If a debugger sees this status, it needs to give the target more TCK edges between Update-DR and Capture-DR. The simplest way to do that is to add extra transitions in Run-Test/Idle.

2.1.7.6.1.2.3.15.3. *_AXI_SERIES_CTRL

This is a private instruction that preloads the start address of a region that will be subsequently read or written using the AXI_SERIES_DATA instruction. It is used when an external debugger wants to either:

- Read or write a contiguous block of registers or memory.
- Repeatedly read or write the same location (e.g., polling)

Using the series instructions instead of the AXI_SINGLE_OP instruction is much more time efficient for these use cases.

The pipeline-depth field width P is 1 when FIFO_DEPTH=0, otherwise $clog2(FIFO_DEPTH+1). The control TDR has 2 + S + P + A + 1 bits. For D=64, A=51, and FIFO_DEPTH=3, the length is 58 bits.

Figure 86 shows the series-control TDR for 64-bit data, 51-bit addresses, and FIFO_DEPTH=3.




Figure 86. JTAG2AXI series-control layout

Table 2494 defines the control fields used to start and manage a series of AXI accesses.

Table 2494. JTAG2AXI series-control fields

Bits	Field	Access	Reset	Description
(2+S+P+A)	reset	RW	0	Reset the pending error flags reported in op.
(2+S+P) +: A	address	RW	0	Address used for AXI access. In Update-DR the AXI transaction is issued.

Bits	Field	Access	Reset	Description
(2+S) +: P	pl_depth	RW	0	pipeline_depth For write transactions, this sets the number of pending unissued write transactions that can be queued by this block to pl_depth + 1. Setting a non-zero value allows the debugger to queue additional write transactions before the previous ones have been issued. For read transactions, this field sets the number of read responses that this block will pipeline. This allows the debugger to queue multiple reads to targets with long or variable latency while getting read data responses in a deterministic fashion. The first pl_depth + 1 reads will return DEADBEEF marker data. This field can be set to a value between 0 and the (wr/rd)_pl_depth field read from the bridge's *_JTAG2AXI_CAPS register. When the debugger reads this field, an indication of whether there are any pending transactions will be returned: 2'b00: There are no pending transactions 2'b01: There is at least one pending transaction
2 +: S	size	RW	0	The requested transfer size in powers-of-2 bytes. The effective size E, the smaller of this field and data_size, is used as AxSIZE for the transaction. 0: 1 byte (8 bits) 1: 2 bytes (16 bits) 2: 4 bytes (32 bits) 3: 8 bytes (64 bits) 4: 16 bytes (128 bits) 5: 32 bytes (256 bits) 6: 64 bytes (512 bits) 7: 128 bytes (1024 bits)
1:0	op	RW	0	When the debugger writes this field, it has the following meaning: 0: Ignore data and address (nop). Don't do anything on Update-DR for AXI_SERIES_DATA. 1: Read from address (read). Update-DR for AXI_SERIES_DATA causes an AXI read to be performed. 2: Write data to address (write). Update-DR for AXI_SERIES_DATA causes an AXI write to be performed. 3: Reserved; treated as nop. When the debugger reads this field, it means the following: 0: All previous series operations completed successfully and returned an OKAY status. 1: At least one previous series operation completed but failed and returned a SLVERR status. This status is sticky until cleared by AXI_SERIES_CTRL.reset. 2: At least one previous series operation completed but failed and returned a DECERR or other error status, or a system reset discarded a series operation that was in progress or queued (see Section 2.1.7.6.1.2.3.15.7). This status is sticky until cleared by AXI_SERIES_CTRL.reset. Codes 1 and 2 report the first failed series operation since the last AXI_SERIES_CTRL.reset; a later failure does not replace it. The completion status of an AXI_SINGLE_OP operation is reported only through AXI_SINGLE_OP.op and does not change codes 0 to 2. 3: At least one operation was attempted before the previous operation completed. The operations attempted when there was a pending operation in progress were ignored. If a debugger sees this status, it needs to give the target more TCK edges between Update-DR and Capture-DR. The simplest way to do that is to add extra transitions in Run-Test/Idle. This status is sticky until cleared by AXI_SERIES_CTRL.reset.

2.1.7.6.1.2.3.15.4. *_AXI_SERIES_DATA_INCR

This is a private instruction that does the actual read/write to the address previously specified.

After the access is completed, an internal address register used for the series, which was previously loaded by AXI_SERIES_CTRL, is incremented as follows:

AXI_SERIES_CTRL.address += 2**E

This allows the debugger to load or dump contiguous regions of address space.

Note that this is a variable-length data register. The length is n bits where n = 8*(2**E).

The data field is the logical transfer payload. The bridge places that payload on the AXI byte lanes selected by the current address and the effective size E, and Capture-DR returns the payload from those lanes.

The data field is drawn as the payload bytes it holds, with bit 0 aligned across the four sizes. The incrementing payload

layouts for effective sizes E of 0, 1, 2, and 3 are shown in Figure 87, Figure 88, Figure 89, Figure 90, respectively. Effective size 3 needs a 64-bit data bus, which the last figure assumes.




Figure 87. JTAG2AXI incrementing data layout for effective size 0




Figure 88. JTAG2AXI incrementing data layout for effective size 1




Figure 89. JTAG2AXI incrementing data layout for effective size 2




Figure 90. JTAG2AXI incrementing data layout for effective size 3

Table 2495 defines the payload shifted through the incrementing data instruction.

Table 2495. JTAG2AXI incrementing data fields

Bits	Field	Access	Reset	Description
n-1:0	data	RW	0	Data value to read/write. The read data is from the previous read access.

2.1.7.6.1.2.3.15.5. *_AXI_SERIES_DATA_NO_INCR

This is a private instruction that does the actual read/write to the address previously specified.

Unlike AXI_SERIES_DATA_INCR, this instruction does not change the address in AXI_SERIES_CTRL. This instruction allows the debugger to continue to read or write this same address using additional AXI_SERIES_DATA_NO_INCR instructions. This is useful for repeated polling or triggering.

Note that this is a variable-length data register. The length is n bits where n = 8*(2**E).

The data field is the logical transfer payload. The bridge places that payload on the AXI byte lanes selected by the current address and the effective size E, and Capture-DR returns the payload from those lanes.

The non-incrementing data register has the same layout as the incrementing one, so the same figures apply. The non-incrementing payload layouts for effective sizes E of 0, 1, 2, and 3 are shown in Figure 91, Figure 92, Figure 93, Figure 94, respectively.




Figure 91. JTAG2AXI non-incrementing data layout for effective size 0




Figure 92. JTAG2AXI non-incrementing data layout for effective size 1




Figure 93. JTAG2AXI non-incrementing data layout for effective size 2




Figure 94. JTAG2AXI non-incrementing data layout for effective size 3

Table 2496 defines the payload shifted through the non-incrementing data instruction.

Table 2496. JTAG2AXI non-incrementing data fields

Bits	Field	Access	Reset	Description
n-1:0	data	RW	0	Data value to read/write. The read data is from the previous read access.

2.1.7.6.1.2.3.15.6. *_AXI_SERIES_DATA_WITH_ERROR_STATUS

This is a private instruction that does the actual read/write to the address previously specified.

Unlike AXI_SERIES_DATA_INCR and AXI_SERIES_DATA_NO_INCR, the increment is selectable per transaction and the error status from the previous status is returned. This instruction is used when granular error reporting is desired during a block operation.

Note that this is a variable-length data register. The length is n+1 bits where n = 8*(2**E).

The data field is the logical transfer payload. The bridge places that payload on the AXI byte lanes selected by the current address and the effective size E, and Capture-DR returns the payload from those lanes.

The error-status payload layouts for effective sizes E of 0, 1, 2, and 3 are shown in Figure 95, Figure 96, Figure 97, Figure 98, respectively. Effective size 3 needs a 64-bit data bus, which the last figure assumes.




Figure 95. JTAG2AXI error-status data layout for effective size 0




Figure 96. JTAG2AXI error-status data layout for effective size 1




Figure 97. JTAG2AXI error-status data layout for effective size 2




Figure 98. JTAG2AXI error-status data layout for effective size 3

Table 2497 defines the data payload and the shared increment-control and error-status bit.

Table 2497. JTAG2AXI data and error-status fields

Bits	Field	Access	Reset	Description
n	increment/status	RW	0	The value shifted into this bit indicates whether the address should be incremented after this transaction completes. The value shifted out of this bit indicates whether the previous transaction completed successfully (0 = succeeded, 1 = failed). An AXI result of SLVERR or DECERR, a system reset that discarded the transaction, as well as attempting a new transaction while the previous was still pending will cause the status to be returned as "failed".
n-1:0	data	RW	0	Data value to read/write. The read data is from the previous read access.

2.1.7.6.1.2.3.15.7. System Reset Recovery

A system reset resets the AXI side of each JTAG2AXI instrument while its JTAG side keeps running. The instrument recovers without a TAP reset. When the reset reaches its JTAG side, it discards every operation that is in flight or queued: the AXI transaction it was waiting on, series requests not yet issued, and series read data not yet shifted out. The target can still complete a transaction that was already on the AXI bus before the reset reached it, so the debugger must treat a discarded write as having an unknown effect.

After the discard:

- The SINGLE_OP op field reads 2 if a single operation or an error-status series operation was discarded, and its captured read-data field reads 0. Otherwise both keep their values.
- The SERIES_CTRL op field reads 2 if a series operation was discarded and it held no earlier series error. Otherwise it keeps its value, including a sticky status of 3. Only AXI_SERIES_CTRL.reset clears it.
- The SERIES_CTRL address, size, pl_depth and op settings keep their values, but the read pipeline restarts empty. Reprogram SERIES_CTRL before resuming a pipelined series read.

Recovery starts when the system reset asserts and completes within 52 periods of the slower of TCK and the AXI clock after the system reset deasserts. TCK periods count only while the debugger drives TCK, for example with transitions in Run-Test/Idle. An operation shifted in during that time is held and issued once recovery completes, and the SINGLE_OP op field reads 3 until the operation finishes.

2.1.7.6.1.2.3.16. Debug Disable

The PTAP has three per-bridge debug-disable inputs. The JTAG interface unit synchronizes those bits to TCK and presents them here as ready-to-gate signals. Each input is active-high: when it is 1, the corresponding `jtag2axi` instance blocks AXI transaction generation.

Table 2498 maps the three JTAG2AXI bridges to their active-high disable inputs.

Table 2498. PTAP debug-disable inputs

Debug Interface	Disable Input
SMC Fabric JTAG2AXI	`smc_jtag2axi_security_disable_i`
SMC OTP JTAG2AXIL	`smc_otp_jtag2axi_security_disable_i`
SEP OTP JTAG2AXIL	`sep_otp_jtag2axi_security_disable_i`

2.1.7.6.1.2.4. Interface

2.1.7.6.1.2.4.1. Instruction Encodings

The PTAP uses 6-bit instruction encodings. During the capture phase, the least significant bit (closest to TDO) of the

instruction register always presents a 1 to the scan chain, and the next least significant bit presents a 0 as specified by the 1149.1 standard, section 7.2.1. All other bits of the instruction register always return 0s.

Table 2499 lists the PTAP instruction encodings and associated register lengths.

Table 2499. PTAP instruction encodings

Encoding	Name	Register Size	Description
0x00	BYPASS	1	IEEE 1149.1, Section 8.4
0x01	IDCODE	32	IEEE 1149.1, Section 8.13
0x02	RUNBIST	BIST	IEEE 1149.1, Section 8.10
0x03	SAMPLE_PRELOAD	BSR	IEEE 1149.1, Sections 8.6 and 8.7
0x04	EXTEST	BSR	IEEE 1149.1, Section 8.8
0x05	EXTEST_TRAIN	BSR	
0x06	EXTEST_PULSE	BSR	
0x07	CLAMP	1	IEEE 1149.1, Section 8.11
0x08	HIGHZ	1	IEEE 1149.1, Section 8.16
0x09	INTEST	BSR	IEEE 1149.1, Section 8.9
0x0A	CLAMP_HOLD	2	IEEE 1149.1, Section 8.20
0x0B	CLAMP_RELEASE	2	IEEE 1149.1, Section 8.20
0x0C	TMP_STATUS	2	IEEE 1149.1, Section 8.20
0x0D	IC_RESET	Variable	IEEE 1149.1, Section 8.21
0x0E	TAP_3DCR	2	IEEE 1838, Section 5.5.1
0x18	DEBUG_CONTROL	5	Debug and clock stop control
0x19	JTAG_CAPS	60	Capabilities readback
0x1A	SELECT_IJTAG	Variable	iJTAG network selection
0x1B	SMC_OTP_JTAG2AXI_CAPS	14	SMC OTP bridge capabilities readback
0x1C	SMC_OTP_AXI_SINGLE_OP	Variable	SMC OTP bridge single transaction
0x1D	SMC_OTP_AXI_SERIES_CTRL	Variable	SMC OTP bridge series control
0x1E	SMC_OTP_AXI_SERIES_DATA_INCR	Variable	SMC OTP bridge series data, incrementing address
0x1F	SMC_OTP_AXI_SERIES_DATA_NO_INCR	Variable	SMC OTP bridge series data, fixed address
0x20	SMC_OTP_AXI_SERIES_DATA_WITH_ERROR_STATUS	Variable	SMC OTP bridge series data with error status
0x21	SEP_OTP_JTAG2AXI_CAPS	14	SEP OTP bridge capabilities readback
0x22	SEP_OTP_AXI_SINGLE_OP	Variable	SEP OTP bridge single transaction
0x23	SEP_OTP_AXI_SERIES_CTRL	Variable	SEP OTP bridge series control
0x24	SEP_OTP_AXI_SERIES_DATA_INCR	Variable	SEP OTP bridge series data, incrementing address
0x25	SEP_OTP_AXI_SERIES_DATA_NO_INCR	Variable	SEP OTP bridge series data, fixed address
0x26	SEP_OTP_AXI_SERIES_DATA_WITH_ERROR_STATUS	Variable	SEP OTP bridge series data with error status
0x27	SMC_JTAG2AXI_CAPS	14	SMC fabric bridge capabilities readback

Encoding	Name	Register Size	Description
0x28	SMC_AXI_SINGLE_OP	Variable	SMC fabric bridge single transaction
0x29	SMC_AXI_SERIES_CTRL	Variable	SMC fabric bridge series control
0x2A	SMC_AXI_SERIES_DATA_INCR	Variable	SMC fabric bridge series data, incrementing address
0x2B	SMC_AXI_SERIES_DATA_NO_INCR	Variable	SMC fabric bridge series data, fixed address
0x2C	SMC_AXI_SERIES_DATA_WITH_ERROR_STATUS	Variable	SMC fabric bridge series data with error status
0x3D	ZERO_LENGTH_BYPASS	0, or 1	TDI to TDO with no register; BYPASS, with its 1-bit register, while the TAP_3DCR STAP-select bit is set
0x3E	INV_BYPASS		
0x3F	BYPASS	1	IEEE 1149.1, Section 8.4

The length of each variable-length JTAG2AXI register follows from the bridge's address width, data width and pipeline depth, and for the series data registers from the size last written to `*_AXI_SERIES_CTRL`. Section 2.1.7.6.1.2.3.15 defines each layout.

NOTE: All instruction encodings *not* explicitly defined in this table map to the BYPASS instruction.

2.1.7.6.1.2.4.2. Signal Interface

Packed control and bus types remain bundles at the `jtag_ptap` boundary; their members are not separate scalar ports.

The parameters and ports of `jtag_ptap` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.1.2.4.3. Dependencies

The PTAP depends on the following components:

- `hw/common/ocah_prim` — Primitive cells (synchronizers, clock gating)
- `hw/ip/jtag/jtag_stap` — Secondary TAP (when 3DIC support enabled)

2.1.7.6.1.3. JTAG STAP

The Secondary TAP (STAP) enables hierarchical interconnection of TAP controllers across multiple chiplets as specified in IEEE 1838-2019 (3DIC). Each STAP interface extends the SiP's primary JTAG access across internal or external chiplets.

2.1.7.6.1.3.1. Overview

The DTP supports these STAP types:

- **I/O STAP** — extends JTAG to the next chiplet in the SiP.
- **SMC Debug STAP** — provides access to the SMC CPU core debugger TAP.
- **SEP Debug STAP** — provides access to the SEP CPU core debugger TAP.
- **Additional STAPs** — optional connections to additional on- or off-chip TAPs.
- **Extended STAP Scan Interface** — a port for adding STAPs external to the DTP.

Each STAP has an active-high disable input. When it is asserted, STAP selection, host TDO, and 3DCR updates are

blocked.

2.1.7.6.1.3.2. Configuration Parameters

Three timing parameters are available to optimise the STAP for different physical topologies, particularly die-boundary crossings.

The parameters of `jtag_stap` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.1.3.3. Architecture

IEEE 1838-2019 enables hierarchical interconnection of TAP controllers across multiple chiplets. Each STAP interface provides an extension of a SiP's primary JTAG interface across internal chiplets. When enabled, a STAP interface is part of the JTAG scan chain, otherwise the STAP interface is bypassed. In addition, STAPs can also support connection of other TAP interfaces included on the same chiplet as the PTAP.

2.1.7.6.1.3.3.1. Module Hierarchy

The STAP implementation consists of three main components integrated within a single module (Table 2500).

Table 2500. STAP module hierarchy

Module	Purpose	Conditional
`prim_jtag_sib_mux_pre`	Segment Insertion Bit multiplexer for TAP control signal routing	Always
`prim_jtag_scan_reg`	3-bit 3DCR control register (config_hold, stap_sel, tms_hold)	Always
Lockup latches	TDO lockup (always), TDI lockup (optional), scan output lockup (optional)	Per parameter

2.1.7.6.1.3.3.2. STAP Module

Each STAP has a 3-bit 3DCR TDR that defines the control interface for the STAP. Note that the STAP 3DCRs take a distributed segment approach to improve timing, as opposed to the single monolithic PTAP 3DCR approach detailed in the IEEE 1838 standard. This 3DCR is connected inline within each STAP's scan chain. A SIB is inserted at the end of the 3DCR to exclude it from the scan chain when not needed. The one-bit SIB is always in the scan chain, so a STAP adds one bit to the chain while its SIB is closed and four bits while it is open. While the STAP is selected, the downstream TAP's scan path is also in the chain, between the STAP's scan input and the SIB.

When not selected, the STAP interface TMS signal is tied to the constant value specified by the TMS-Hold bit of the 3DCR, otherwise it follows the PTAP TMS signal.

Figure 99 shows the scan path, the host TDO path and the gating logic of one STAP. Blue lines carry scan data and grey lines carry control. A small circle marks an inverted gate input, and a name at the tail of a short arrow (`stap_sel`, `security_disable_i` and `client_scan_ctrl_i.shift_en`) is the same signal drawn elsewhere in the figure. `stap_scan_in` feeds both the scan-in mux and the TDO lockup flop, whose output leaves on `host_tdo_o` toward the secondary TAP. While `stap_sel` is set, the scan-in mux passes the secondary TAP's return on `host_tdi_i`, which splices that TAP into the chain; otherwise it passes `stap_scan_in`. The SIB inserts the 3DCR into the client scan path or bypasses it, and its one-bit register drives `client_scan_out_o`. The dashed input stages are optional: SCAN_IN_PIPE on `client_scan_in_i` defaults to disabled for all DTP instances, and TDI_LOCKUP on `host_tdi_i` defaults to disabled but is enabled for the I/O STAP (`gen_stap_io`) to provide timing margin for the die boundary crossing.




Figure 99. STAP scan and control paths

`security_disable_i` gates three signals through AND gates with an inverted input: `stap_sel`, from the 3DCR `stap_sel_int` bit; the 3DCR update enable, from the SIB's `update_en`; and `host_tdo_o`. Because the TMS mux and the TDO output enable take the gated `stap_sel`, a disabled STAP also parks the host TMS at `tms_hold` and holds `host_tdo_oen_o` low. `host_tap_ctrl_o` carries TCK and TRST from `client_tap_ctrl_i` unchanged; only its TMS passes through the mux. Where the TCK and TRST line crosses the shift-enable input, the gap in the shift-enable line marks that the two do not connect. The SIB itself is not gated. The 3DCR reset combines the client TRST, `config_hold_sticky` and the scan reset as Table 2501 describes.

2.1.7.6.1.3.3.3. 3DCR Register

The 3-bit 3DCR control register is implemented using `prim_jtag_scan_reg` with a loopback configuration. The register outputs feed back to the data inputs, allowing the register to retain its configuration across scan operations while still being scannable for updates.

Table 2501 defines the three control bits retained in the STAP scan register.

Table 2501. STAP 3DCR fields

Bit	Field	Reset	Description
2	TMS-Hold	0	Defines the parked TMS value when the STAP is disabled. When `stap_sel=0`, the host TMS output is driven with this static value rather than following the client TMS input.
1	Select (stap_sel)	0	Enables the STAP scan interface. When `stap_sel=1`, the STAP routes scan data through the downstream TAP. When `stap_sel=0`, the downstream TAP is not in the scan path and its TMS is held at the TMS-Hold value. While `security_disable_i` is high, a capture of the 3DCR reads this bit as 0 whatever its stored value (Table 2503).
0	Config-Hold	0	Preserves the 3DCR configuration across Test-Logic-Reset. The active-low register reset is `client_tap_ctrl_i.trst_n AND (config_hold_sticky OR host_sib_scan_ctrl.rst_n)`, where `config_hold_sticky` samples `config_hold` on the falling edge of TCK and resets only on TRST. TRST assertion always resets the register regardless of this bit.

2.1.7.6.1.3.3.4. STAP Types

Table 2502 lists the STAPs allocated for the DTP JTAG interface. The STAPs are serially chained TDI → TDO according to their order in this table from top to bottom. In addition to the STAPs integrated into the DTP, the STAP scan chain is ported out of the DTP so that the chiplet integrator may add additional STAPs closer to their point of use.

Table 2502. DTP STAP allocation

Purpose	Description
STAP to Next Chiplet	This STAP forwards JTAG to the next chiplet in the SiP.
SMC Core Debug	Provides access to the internal SMC CPU core debugger TAP.
SEP Core Debug	Provides access to the internal SEP CPU core debugger TAP.
[N-1:0] Additional STAPs	Provides access to additional STAPs for on or off-chip TAP connectivity.
Extended STAP Scan Interface	Provides the ability to add STAPs external to the DTP closer to their point of use.

2.1.7.6.1.3.3.5. Debug Disable

The `security_disable_i` input is active-high (1 = STAP disabled). When it is asserted, three aspects of STAP operation are blocked (Table 2503).

Table 2503. STAP debug-disable behavior

Signal	Behavior when asserted
`stap_sel` (internal)	Forced to 0 regardless of the 3DCR Select bit, so scan data is not routed through the downstream TAP. The 3DCR captures this forced value, so a scan through the 3DCR reads Select as 0.
`host_tdo_o`	Forced to 0, so the downstream TAP cannot leak data on the host TDO even if it is accessed.
`client_reg_scan_ctrl.update_en`	Forced to 0, so the 3DCR cannot be updated while the STAP is disabled. The stored Select bit keeps its value: when `security_disable_i` clears, a STAP whose stored Select bit is 1 is selected again without a 3DCR write. The disable does not block the 3DCR reset, so TRST clears the stored bit, and so does the scan reset while Config-Hold is 0.

STAP selection, host TDO, and 3DCR updates are all blocked combinationally at the module output, so there is no timing-dependent bypass of the disable.

2.1.7.6.1.3.3.6. Lockup Latches

The STAP implements three types of lockup latches to manage timing across die boundaries and long scan chains. These latches are clocked on the falling edge of TCK to capture data during the second half of the clock cycle, providing setup time margin for the next rising edge.

2.1.7.6.1.3.3.6.1. TDO Lockup Latch

The TDO lockup latch is always present and cannot be disabled. On every falling edge of TCK it captures the client scan data entering the STAP and drives it on `host_tdo_o` to the downstream TAP's TDI. The downstream TAP samples TDI on the rising edge of TCK, so the latch gives that path half a TCK period of setup margin.

2.1.7.6.1.3.3.6.2. TDI Lockup Latch

The TDI lockup latch is optional and controlled by the `TDI_LOCKUP` parameter (default = 0). When enabled, this latch captures the host TDI input on the falling edge of TCK before routing it to the client TDI output. This adds one additional cycle of latency but provides timing margin for die boundary crossings where signal delays may be significant. In the DTP integration, TDI lockup is enabled only for the I/O STAP that crosses between chiplets.

2.1.7.6.1.3.3.6.3. Scan Output Lockup Latch

The scan output lockup latch is optional and controlled by the `SCAN_OUT_LOCKUP` parameter (default = 0). This latch is implemented within the `prim_jtag_sib_mux_pre` module and retimes the client scan output on the falling edge of TCK. Enable it where the client scan output feeds a rising-edge stage clocked by a later TCK branch. Leave it disabled where the output reaches a falling-edge stage, such as the PTAP TDO retimer: two falling-edge stages in series add one TCK of scan latency. The DTP integration leaves it disabled on every STAP.

2.1.7.6.1.3.4. Interface

2.1.7.6.1.3.4.1. Signal Interface

Packed control and bus types remain bundles at the `jtag_stap` boundary; their members are not separate scalar ports.

The parameters and ports of `jtag_stap` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.1.3.4.2. Timing Requirements

The STAP interface timing follows IEEE 1838-2019:

- TDI is sampled on the rising edge of TCK
- TDO is driven on the falling edge of TCK
- TMS is sampled on the rising edge of TCK
- The TDO lockup latch captures the client scan data on every falling edge of TCK

2.1.7.6.1.3.4.3. Dependencies

The STAP depends on the following components:

- `hw/common/ocah_prim` - Primitive cells (clock gating, synchronizers)

2.1.7.6.2. Cross-Trigger

2.1.7.6.2.1. Cross-Trigger Network

The Cross-Trigger Network (CTN) implements inter-chiplet and on-chip cross-trigger routing per the Open Chiplet Cross Triggering (OCCT) specification. It combines a configurable set of Cross Trigger Ports (CTPs) facing the I/O pads with a Cross Trigger Matrix (CTM) that routes trigger pulses between all sources and sinks under AXI-Lite CSR control.

2.1.7.6.2.1.1. Overview

The CTN serves four purposes:

1. **Die-to-die cross triggering** — trigger pulses propagate between chiplets in a multi-die SiP through the CTP GPIO pads.
2. **On-chip cross triggering** — internal CLAs and other logic exchange trigger pulses without leaving the chiplet.
3. **Unified management** — a single AXI-Lite interface configures all CTP and CTM settings through a contiguous address window.
4. **Clock stop coordination** — the CTN OR-reduces CLA `xtrig_clk_stop_req_i` inputs and combines the result with the JTAG `jtag_clock_stop` bit to produce the registered `stop_clks_o` output.

2.1.7.6.2.1.2. Configuration Parameters

The CTN is configured through its external and internal port counts, the number of clock-stop request inputs, and the protocol of each internal CTP.

The parameters of `cross_trigger_network` are listed in the HTML edition of this manual, under RTL Modules Reference.

The DTP passes these counts through as `XTRIG_NUM_CTP`, `XTRIG_NUM_INT_CT`, and `XTRIG_NUM_CLK_STOP_REQ`. The elaborated `NUM_CTP + NUM_INT_CT` must equal the generated Cross-Trigger Matrix `NUM_CT_SRC` and `NUM_CT_DST`; see Cross-Trigger Matrix.

2.1.7.6.2.1.3. Architecture

Figure 100 is an example of a SiP with a heterogeneous cross triggering scheme utilizing both wire-OR and point-to-point cross triggering interfaces:




Figure 100. SiP cross-trigger topology

The package carries a single cross trigger across six chiplets. Chiplets 0, 1 and 2 each have a CTP in wire-OR mode on one shared wire, and point-to-point CTP pairs link Chiplet 0 with Chiplets 3 and 4, and Chiplet 3 with Chiplet 5. Chiplet 0 is the bridge between the wire-OR group and the point-to-point chiplets. Each CTP lists its pads on the side that faces its partner, in the order that keeps every point-to-point wire straight. The wire-OR net also reaches a package pin, which makes the trigger visible outside the package and could accept an external trigger; a package pin is impractical for point-to-point signalling.

The Programmer's Guide lists the CTM routing that each chiplet programs for this topology.

No route leads from a CTP back to itself, but a CTP in wire-OR mode also receives the falling edge that it drives onto the shared wire. A trigger that Chiplet 0 forwards to its wire-OR CTP therefore comes back from that CTP one wire-OR round trip later, and Chiplet 0's wire-OR rule forwards it again. For a trigger from Chiplet 3, the echo reaches Chiplet 0's local CLAs and Chiplets 3 and 4 a second time, and Chiplet 3 passes it on to Chiplet 5. Triggers from Chiplet 4, Chiplet 5 and Chiplet 0's local CLAs echo in the same way; triggers that enter from Chiplets 1 and 2 do not. Any bridge between a wire-OR group and point-to-point links behaves like this, so a destination can see one trigger twice, the second copy one wire-OR round trip after the first.

2.1.7.6.2.1.3.1. Cross Trigger Port (CTP)

The CTN supports from 1 to 32 external CTPs, set by its `NUM_CTP` parameter, which defaults to 16. Each external CTP uses one GPIO pad in wire-OR mode and two or four in point-to-point mode. These ports support both point-to-point and wire-OR cross trigger signaling modes.

Each CTP connects to four separate I/O pads:

- **CT_Req_out** - The cross trigger request output signal. The CTP asserts this signal to transmit a cross trigger in both point-to-point and wire-OR modes. In point-to-point mode the request is held high until the receiver acknowledges the request. In wire-OR mode, this signal drives the output-enable port of the I/O pad for duration defined by a pulse stretching module, and the pad output is driven static-low. Also in wire-OR mode the I/O pad input connects to the CTP without inversion. The shared wire is an open-drain active-low signal, and the CTP receives a cross trigger on its falling (assertion) edge.
- **CT_Ack_in** - The cross trigger acknowledge input signal. Exclusive to point-to-point mode. The cross trigger receiver asserts this signal when it acknowledges the CTP's cross trigger request.
- **CT_Req_in** - The cross trigger request input signal. Exclusive to point-to-point mode. This is the external cross trigger request received by the CTP.
- **CT_Ack_out** - The cross trigger acknowledge output signal. Exclusive to point-to-point mode. The CTP asserts this signal after receiving a cross trigger request, and de-asserts this signal after the cross trigger request is released.

When a GPIO pad is configured for cross triggering, the I/O pad assumes the role of one of these four cross trigger signals, and the pad controls and I/O data signals are connected to the associated CTP.

The logical structure of a CTP module is shown in Figure 101 in the Cross-Trigger Port architecture.

Signal names, directions, and pad controls are listed in the CTP Signal Interface.

The register interface for each CTP module is described in the CTN Memory Map section below.

2.1.7.6.2.1.3.1.1. Wire-OR Mode

Wire-OR mode is a 1-wire cross trigger signaling scheme compatible with many existing cross triggering implementations. This scheme is very resource efficient, as it only requires a single pin per chiplet connected to the network. However, the performance of the network decreases as the number of connected chiplets increase. Also, the

duration of the cross trigger pulse must be pre-arranged across all connected chiplets.

Each chiplet has an open-drain I/O connected to a single shared wire. Any connected chiplet may pull this signal low to assert a cross trigger. Depending on the electrical requirements, one or more internal pad pull-ups or external keepers ensure the cross trigger request signal remains high when no cross trigger is asserted. To ensure no connected chiplet misses a cross trigger pulse, all chiplets transmitting a trigger pulse must stretch the pulse a mutually agreed upon length of time.

Note that in wire-OR mode the *CT_Req_out* signal is connected to an open-drain configured I/O pad. For I/O pads that do have explicit open-drain control, the request data signal should connect to the output-enable control pin of the I/O pad, and the output data signal of the I/O pin should be driven statically low.

The logical behavior of a CTP in wire-OR mode is shown in Figure 102 in the Cross-Trigger Port architecture, and any number of chiplets may have their *CT_Req_out* pads interconnected as shown in Figure 103 in the same architecture section.

2.1.7.6.2.1.3.1.2. Point-to-Point Mode

Point-to-point mode utilizes a four-phase handshaking scheme to synchronize a cross trigger quickly and reliably between two chiplets without pulse stretching. While this scheme is simple and fast, it requires a dedicated CTP for each chiplet-to-chiplet interconnection, and each CTP requires four I/O pads for bi-directional communication, or two pads for unidirectional communication. All output pads are configured for push-pull operation.

The logical behavior of a CTP in point-to-point mode is shown in Figure 104 in the Cross-Trigger Port architecture, and any two chiplets may have their four cross trigger pads cross-coupled as shown in Figure 105 in the same architecture section.

On the sender side, the receiver's *CT_Ack_out* is connected to the sender's *CT_Ack_in* pad. *CT_Req_out* asserts whenever *CT_Src* asserts. *CT_Req_out* will then remain asserted until *CT_Ack_in* asserts.

On the receiver side, the sender's *CT_Req_out* is connected to the receiver's *CT_Req_in* pad. On any positive edge of *CT_Req_in*, the receiver generates a pulse on *CT_Dst* and asserts *CT_Ack_out*. Deassertion proceeds in exactly the same sequence.

The timing of the request/acknowledge handshake is shown in Figure 106 in the Cross-Trigger Port architecture.

2.1.7.6.2.1.3.2. Cross Trigger Matrix (CTM)

The CTM is a crossbar that aggregates and statically routes cross trigger pulses between various sources and sinks. Typical connections to the CTM include Core Logic Analyzers (CLAs) and CTPs, including other miscellaneous devices. The CTM is compatible with CTPs operating in either of the two signaling modes, point-to-point or wire-OR. Typically, each device or logic module connected to the CTM will act as both a source and a sink for cross trigger pulses.

The source selection and destination routing performed by the CTM are shown in Figure 107 in the Cross-Trigger Matrix architecture.

The CTM is programmed at runtime via firmware or debug transactions. Proper configuration of the CTMs in each chiplet will minimize trigger latency and prevent loops in the SiP cross trigger network. Configuration is accomplished via CSRs. The CTM register interface is described in the CTN Memory Map section below, and the Programmer's Guide gives the order in which to program the CTPs and the CTM.

2.1.7.6.2.1.3.3. Address Map

The CTN provides a unified CSR address space accessed via a single AXI-Lite subordinate port. An internal AXI-Lite crossbar (`axi_lite_xbar`) routes transactions to the CTM and external CTPs based on address decoding. The crossbar registers all five channels at the subordinate port, so no combinational path runs from the port's inputs to its outputs, and each channel adds one cycle of latency. Each channel's register holds up to two beats and keeps its READY high while it holds fewer than two. The crossbar serves one CSR access at a time, so the port can accept a second request on a channel while the crossbar is still serving the first.

Table 2504 lists the CTM and external-CTP address ranges.

Table 2504. CTN address allocation

Component	Address Range	Size	Description
CTM	0x0000 - 0x01FF	512 bytes	Cross Trigger Matrix configuration registers (one 8-byte `CT_SRC[k].CONFIG_0` slot per CT_Src port, up to 64 ports)
CTP[0]	0x0200 - 0x020F	16 bytes	External CTP 0 configuration
CTP[1]	0x0210 - 0x021F	16 bytes	External CTP 1 configuration
…	…	…	…
CTP[15]	0x02F0 - 0x02FF	16 bytes	External CTP 15 configuration
Internal CTPs	No CSR address	N/A	Configured via build-time parameters only

The table shows the default 16 external CTPs. External CTP *n* occupies the 16 bytes from `0x200 + 0x10*n`.

The crossbar is configured with `MaxMstTrans=1` and `MaxSlvTrans=1`, serializing all CSR accesses. This simplification reduces arbitration logic at the cost of concurrent access capability.

2.1.7.6.2.1.3.4. Internal vs External CTP Architecture

The CTN instantiates `NUM_CTP` external CTPs, 16 by default, using the full `cross_trigger_port` module with CSR interface, and `NUM_INT_CT` internal CTPs, 10 by default, using only the `cross_trigger_port_core` module without registers.

Table 2505 compares the modules, configuration, and connections used for external and internal CTPs.

Table 2505. External and internal CTP comparison

Aspect	External CTP	Internal CTP
Module	`cross_trigger_port` (full)	`cross_trigger_port_core` (CSR-less)
CSR Interface	16-byte AXI-Lite address space	None (build-time parameters)
GPIO Interface	4-pad interface to die I/O	Logical signals to internal CLAs
Configuration	Runtime via CSRs (mode, invert, stretch_mult, reset)	Build-time via `INT_CT_MODE` parameter
Index Range	ctm_ct_src/dst[0:15]	ctm_ct_src/dst[16:25]
Signal Mapping	Standard GPIO pad controls	Repurposed GPIO signals (see Table 2506 and Table 2507)

2.1.7.6.2.1.3.4.1. Internal CTP Signal Remapping

Internal CTPs reuse the cross_trigger_port_core GPIO interface but connect to logical signals rather than physical pads. The `INT_CT_MODE` parameter bits are inverted before use: `ModeWireOr = ~INT_CT_MODE[i]`. This means `INT_CT_MODE[i]=0` selects Wire-OR mode, while `INT_CT_MODE[i]=1` selects Point-to-Point mode.

The internal wire-OR request from a CLA is active-high, while the CTP core receives a wire-OR cross trigger on the

falling edge of an idle-high wire. The network therefore inverts `ctm_dst_req_i[i]` before `ct_req_out_din`, so an internal CTP receives a cross trigger on the rising edge of the CLA request.

Wire-OR Mode (INT_CT_MODE[i]=0, internal ModeWireOr=1):

Table 2506 maps the CTP core signals to internal connections in wire-OR mode.

Table 2506. Internal CTP wire-OR connections

CTP Core Signal	Internal Connection
`ct_req_out_dout_en`	→ `ctm_src_req_o[i]` (stretched pulse to CLA)
`ct_req_out_din`	← `~ctm_dst_req_i[i]` (stretched pulse from CLA, inverted)
All other signals	Unused (tied to constants)

Point-to-Point Mode (INT_CT_MODE[i]=1, internal ModeWireOr=0):

Table 2507 maps the CTP core signals to internal connections in point-to-point mode.

Table 2507. Internal CTP point-to-point connections

CTP Core Signal	Internal Connection
`ct_req_out_dout`	→ `ctm_src_req_o[i]` (level-based request to CLA)
`ct_req_in_din`	← `ctm_dst_req_i[i]` (level-based request from CLA)
`ct_ack_in_din`	← `ctm_src_ack_i[i]` (acknowledge from CLA)
`ct_ack_out_dout`	→ `ctm_dst_ack_o[i]` (acknowledge to CLA)

This remapping allows internal CTPs to operate in either mode without physical GPIO pads, enabling on-chip cross-triggering between CLAs and the external cross-trigger network.

2.1.7.6.2.1.3.5. Signal Flow

External Cross Trigger Flow

1. **Outgoing Trigger**: CTM ct_src → CTP ct_src_i → GPIO pads
2. **Incoming Trigger**: GPIO pads → CTP ct_dst_o → CTM ct_dst_i

Internal Cross Trigger Flow

1. **To Internal Sink**: CTM ct_src → Internal CTP → ctm_src_req_o
2. **From Internal Source**: ctm_dst_req_i → Internal CTP → CTM ct_dst

2.1.7.6.2.1.3.6. Clock Stop Control

The `ctn_clock_stop_ctrl` module aggregates clock stop requests from multiple sources using a two-stage OR-tree architecture. The module separates CLA-only status from the combined functional halt signal to support independent JTAG visibility and chiplet clock gating control. The CTN sizes its request input with its own `NUM_CLK_STOP_REQ` parameter, which defaults to 9.

The parameters and ports of `ctn_clock_stop_ctrl` are listed in the HTML edition of this manual, under RTL Modules Reference.

The aggregation logic operates as follows:

1. **CLA OR-Tree**: All CLA request inputs are OR-reduced combinationally: `cla_clk_stop_req = |clk_stop_req_i`
2. **Combined Request**: JTAG and CLA requests are OR-combined: `clk_stop_req_combined = jtag_clock_stop_i | cla_clk_stop_req`
3. **Synchronization and Output Registration**: The combined request passes through a two-flop synchronizer into `clk_i` and then an output register, so `stop_clks_o` follows a change in either request after three `clk_i` cycles.

The synchronizer resolves the asynchronous JTAG and CLA requests into `clk_i`, and the output register keeps glitches out of the chiplet's functional clock gating logic. The combinatorial `cla_clock_stop_o` output provides immediate visibility of CLA activity to the JTAG interface, allowing debuggers to distinguish between JTAG-initiated and CLA-initiated clock stops.

2.1.7.6.2.1.3.7. Port Indexing

Table 2508 maps CTM port indices to external CTPs, internal CTPs, and clock-stop connections.

Table 2508. CTN matrix port indices

Port Index	Description
0 to N-1	External CTPs (NUM_CTP)
N to N+M-1	Internal CTPs (NUM_INT_CT)

Where N = NUM_CTP and M = NUM_INT_CT. This indexing is used for CTM ct_dst_i and ct_src_o port assignment and CTM routing configuration registers.

2.1.7.6.2.1.4. Interface

2.1.7.6.2.1.4.1. Cross Trigger Port (CTP)

For the module diagram and signalling modes, see CTN Architecture.

Each CTP is built on `cross_trigger_port_core`. Its operating mode resets to wire-OR: the CSR MODE field of an external CTP resets to 0, which selects wire-OR, and 1 selects peer-to-peer. `INT_CT_MODE` sets the mode of each internal CTP.

The parameters and ports of `cross_trigger_port_core` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.2.1.4.2. Cross Trigger Matrix (CTM)

The CTM has the following data ports and logical structure:

- **CT_Src[N-1:0]** - Cross trigger pulse output signals from the CTM to CLAs, CTPs, or other cross trigger sinking devices, where N is the number of these cross trigger sinks.
- **CT_Dst[M-1:0]** - Cross trigger pulse input signals to the CTM from CLAs, CTPs, or other cross trigger generating devices, where M is the number of these cross trigger sources.

2.1.7.6.2.1.4.3. Cross Trigger Network Module Interface

The parameters and ports of `cross_trigger_network` are listed in the HTML edition of this manual, under RTL Modules Reference.

2.1.7.6.2.1.4.4. Dependencies

The CTN depends on the following components:

- `hw/ip/cross_trigger/cross_trigger_port` - Cross Trigger Port IP
- `hw/ip/cross_trigger/cross_trigger_matrix` - Cross Trigger Matrix IP
- `vendor/pulp-platform/axi` - AXI infrastructure (`axi_lite_xbar`)

2.1.7.6.2.1.5. Programming

Cross-trigger configuration is static: every external CTP is configured once per boot before the CTM routes that use it are opened. The Programmer's Guide gives the cross-trigger programming sequence with reconfiguration and handshake deadlock recovery.

2.1.7.6.2.1.6. Memory Map

2.1.7.6.2.1.6.1. Memory Map

The Cross Trigger Network combines the Cross Trigger Matrix (CTM) and Cross Trigger Port (CTP) registers into a unified address space. Its generated map keeps the CTP instance count and stride with the allocated apertures:

Table 2509. Cross Trigger Network Address Map

Base Address	End Address	Size	Decoded Extent	Unit	Instances	Stride	Description	Hole in Extent (R / W)	Past Extent (R / W)
0x00000000	0x000001FF	512 B	208 B	Cross Trigger Matrix Address Map	1 instance	-	Configuration registers for the cross trigger matrix	OKAY, 0x0 / OKAY	DECERR, 0xBADCAB1E / DECERR
0x00000200	0x000002FF	256 B	252 B	Cross Trigger Port Address Map	16 instances	16 B	Configuration and status registers for the cross trigger port	OKAY, 0x0 / OKAY	OKAY, 0x0 / OKAY

The CTN adds no CTN-specific registers; it decodes the AXI-Lite CSR interface onto the CTM and CTP blocks it instantiates. The composite SystemRDL top is the common source for these addresses and for the generated RTL constants.

The last two columns state how the network answers a 32-bit access that no register backs, as seen at its AXI-Lite CSR port, and Decode Response Codes defines them and their codes. An address above `0x2FF` matches no block and answers `DECERR`, with read data `0xBADCAB1E`.

2.1.7.6.2.1.6.2. Detailed Register Map

2.1.7.6.2.1.6.2.1. Cross Trigger Matrix Registers

2.1.7.6.2.1.6.2.1.1. Cross Trigger Matrix Address Map

Configuration registers for the cross trigger matrix

NOTE **Register Arrays:**

- **CT_SRC[26].CONFIG_0**: 26 registers, base 0x0, stride 0x8

Table 2510. Cross Trigger Matrix Address Map register list

Address	Name	Access	Description
0x0 - 0xC8	CT_SRC[26].CONFIG_0	RW	Cross Trigger Source Configuration - CT_Dst select mask

2.1.7.6.2.1.6.2.1.1.1. CT_SRC[26].CONFIG_0

Table 2511. cross_trigger_matrix.CT_SRC[26].CONFIG_0 fields

Bits	Field	Access	Reset	Description
31:26	Reserved	-	-	Reserved
25:0	CT_DST_SELECT	RW	0x0	Selects the CT_Dst port(s) to forward on the CT_Src output at this array index. Each bit corresponds to one CT_Dst port, from CT_Dst[0] at bit 0 upwards. Multiple ports may be selected as a trigger source. All selected source ports are then OR'd together to produce the CT_Src output. Set this register to all-zero to disable that output.

2.1.7.6.2.1.6.2.2. Cross Trigger Port Registers

Each CTP window repeats the following register layout.

2.1.7.6.2.1.6.2.2.1. Cross Trigger Port Address Map

Configuration and status registers for the cross trigger port

Table 2512. Cross Trigger Port Address Map register list

Address	Name	Access	Description
0x0	CONFIG	RW	Cross Trigger Port Configuration
0x4	STATUS	R	Cross Trigger Port Status. Writes complete with an OKAY response and leave the register unchanged.
0x8	STRETCH_MULT	RW	Pulse Stretch Multiplier

2.1.7.6.2.1.6.2.2.1.1. CONFIG

Table 2513. cross_trigger_port.CONFIG fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	RESET	RW	0x0	While set, holds the outgoing point-to-point handshake idle with CT_Req_out deasserted and discards core-side cross trigger pulses for transmission. The incoming handshake keeps running. Set and then clear it to recover a handshake deadlock.
1	INVERT	RW	0x0	Inverts the sense of the incoming and outgoing GPIO signals. 0 - No inversion. Wire-OR mode uses active-low signaling with active or passive pull-ups. Point-to-point mode uses active-high signaling. 1 - All inputs and outputs of I/Os are inverted. Wire-OR mode uses active-high signaling with active or passive pull-downs. Point-to-point mode uses active-low signaling. Write it in the same access as MODE.

Bits	Field	Access	Reset	Description
0	MODE	RW	0x0	Selects the operating mode of the CTP. 0 - Wire-OR, 1 - Point-to-Point. Program it once, in the same write as INVERT, from the package's cross trigger topology, before any cross trigger matrix route selects or targets this port. While wire-OR is selected the point-to-point handshake is held idle with its request deasserted; after point-to-point is selected, the handshake ignores the CT_Req_in and CT_Ack_in pads until their synchronized levels are valid.

2.1.7.6.2.1.6.2.2.1.2. STATUS

Table 2514. cross_trigger_port.STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ACK_OUT	R	0x0	Readout of the current CT_Ack_out level with CONFIG.INVERT undone, so 1 means the acknowledge is asserted whatever the pad polarity. Reads 0 in wire-OR mode.
6	REQ_IN	R	0x0	Readout of the current synchronized CT_Req_in level with CONFIG.INVERT undone, so 1 means the request is asserted whatever the pad polarity.
5	ACK_IN	R	0x0	Readout of the current synchronized CT_Ack_in level with CONFIG.INVERT undone, so 1 means the acknowledge is asserted whatever the pad polarity.
4	REQ_OUT	R	0x0	Readout of the current CT_Req_out level with CONFIG.INVERT undone, so 1 means the request is asserted whatever the pad polarity. Reads 0 in wire-OR mode.
3:1	Reserved	-	-	Reserved
0	BUSY	R	0x0	Indicates whether a pulse assertion or handshake is currently in progress. 0 - Pulse or handshake is not in progress, 1 - Pulse or handshake is currently in progress

2.1.7.6.2.1.6.2.2.1.3. STRETCH_MULT

Table 2515. cross_trigger_port.STRETCH_MULT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	STRETCH_MULT	RW	0x0	The number of clock cycles a core-side cross trigger pulse is stretched on the GPIO pin when in wire-OR mode. Whenever a core-side pulse is received, the generated GPIO pulse has a width of (STRETCH_MULT+1) clock cycles.

2.1.7.6.2.1.6.2.3. Composite Network Registers

This map gives the CTM and CTP register offsets within the generated CTN composition. The individual block maps above give offsets within each block.

2.1.7.6.2.1.6.2.3.1. Cross Trigger Network Address Map

Cross trigger matrix and externally visible cross trigger ports

NOTE

Register Arrays:

- **CT_SRC[26].CONFIG_0**: 26 registers, base 0x0, stride 0x8
- **ctp[16].CONFIG**: 16 registers, base 0x200, stride 0x10

- **ctp[16].STATUS**: 16 registers, base 0x204, stride 0x10
- **ctp[16].STRETCH_MULT**: 16 registers, base 0x208, stride 0x10

Table 2516. Cross Trigger Network Address Map register list

Address	Name	Access	Description
0x0 - 0xC8	CT_SRC[26].CONFIG_0	RW	Cross Trigger Source Configuration - CT_Dst select mask
0x200 - 0x2F0	ctp[16].CONFIG	RW	Cross Trigger Port Configuration
0x204 - 0x2F4	ctp[16].STATUS	R	Cross Trigger Port Status. Writes complete with an OKAY response and leave the register unchanged.
0x208 - 0x2F8	ctp[16].STRETCH_MULT	RW	Pulse Stretch Multiplier

2.1.7.6.2.1.6.2.3.1.1. CT_SRC[26].CONFIG_0

Table 2517. cross_trigger_network.CT_SRC[26].CONFIG_0 fields

Bits	Field	Access	Reset	Description
31:26	Reserved	-	-	Reserved
25:0	CT_DST_SELECT	RW	0x0	Selects the CT_Dst port(s) to forward on the CT_Src output at this array index. Each bit corresponds to one CT_Dst port, from CT_Dst[0] at bit 0 upwards. Multiple ports may be selected as a trigger source. All selected source ports are then OR'd together to produce the CT_Src output. Set this register to all-zero to disable that output.

2.1.7.6.2.1.6.2.3.1.2. ctp[16].CONFIG

Table 2518. cross_trigger_network.ctp[16].CONFIG fields

Bits	Field	Access	Reset	Description
31:3	Reserved	-	-	Reserved
2	RESET	RW	0x0	While set, holds the outgoing point-to-point handshake idle with CT_Req_out deasserted and discards core-side cross trigger pulses for transmission. The incoming handshake keeps running. Set and then clear it to recover a handshake deadlock.
1	INVERT	RW	0x0	Inverts the sense of the incoming and outgoing GPIO signals. 0 - No inversion. Wire-OR mode uses active-low signaling with active or passive pull-ups. Point-to-point mode uses active-high signaling. 1 - All inputs and outputs of I/Os are inverted. Wire-OR mode uses active-high signaling with active or passive pull-downs. Point-to-point mode uses active-low signaling. Write it in the same access as MODE.
0	MODE	RW	0x0	Selects the operating mode of the CTP. 0 - Wire-OR, 1 - Point-to-Point. Program it once, in the same write as INVERT, from the package's cross trigger topology, before any cross trigger matrix route selects or targets this port. While wire-OR is selected the point-to-point handshake is held idle with its request deasserted; after point-to-point is selected, the handshake ignores the CT_Req_in and CT_Ack_in pads until their synchronized levels are valid.

2.1.7.6.2.1.6.2.3.1.3. ctp[16].STATUS

Table 2519. cross_trigger_network.ctp[16].STATUS fields

Bits	Field	Access	Reset	Description
31:8	Reserved	-	-	Reserved
7	ACK_OUT	R	0x0	Readout of the current CT_Ack_out level with CONFIG.INVERT undone, so 1 means the acknowledge is asserted whatever the pad polarity. Reads 0 in wire-OR mode.
6	REQ_IN	R	0x0	Readout of the current synchronized CT_Req_in level with CONFIG.INVERT undone, so 1 means the request is asserted whatever the pad polarity.
5	ACK_IN	R	0x0	Readout of the current synchronized CT_Ack_in level with CONFIG.INVERT undone, so 1 means the acknowledge is asserted whatever the pad polarity.
4	REQ_OUT	R	0x0	Readout of the current CT_Req_out level with CONFIG.INVERT undone, so 1 means the request is asserted whatever the pad polarity. Reads 0 in wire-OR mode.
3:1	Reserved	-	-	Reserved
0	BUSY	R	0x0	Indicates whether a pulse assertion or handshake is currently in progress. 0 - Pulse or handshake is not in progress, 1 - Pulse or handshake is currently in progress

2.1.7.6.2.1.6.2.3.1.4. ctp[16].STRETCH_MULT

Table 2520. cross_trigger_network.ctp[16].STRETCH_MULT fields

Bits	Field	Access	Reset	Description
31:16	Reserved	-	-	Reserved
15:0	STRETCH_MULT	RW	0x0	The number of clock cycles a core-side cross trigger pulse is stretched on the GPIO pin when in wire-OR mode. Whenever a core-side pulse is received, the generated GPIO pulse has a width of (STRETCH_MULT+1) clock cycles.

2.1.7.6.2.2. Cross-Trigger Port

The Cross Trigger Port (CTP) is the pad-facing signalling module for cross-trigger communication per the Open Chiplet Cross Triggering (OCCT) specification. Each CTP connects the chiplet core logic to four I/O pads and handles the timing and handshaking required for both wire-OR and point-to-point signalling schemes.

2.1.7.6.2.2.1. Overview

Each CTP connects to four I/O pads:

- **CT_Req_out** — cross-trigger request output.
- **CT_Ack_in** — acknowledge input (point-to-point only).
- **CT_Req_in** — cross-trigger request input (point-to-point only).
- **CT_Ack_out** — acknowledge output (point-to-point only).

Two inter-chiplet signalling schemes are supported:

- **Wire-OR** — supports a wide range of existing chiplet implementations and is resource efficient. Uses pulse stretching to ensure reliable detection across chiplet boundary delays.
- **Point-to-point** — faster, more reliable, and simpler to configure. Uses four-phase handshaking with CDC synchronisers at the die boundary.

2.1.7.6.2.2.2. Configuration

The CTP has no build-time parameters. All operational settings are programmed at runtime through the AXI-Lite CSR interface:

Table 2521 summarises the runtime controls exposed through the CTP CSR interface.

Table 2521. CTP configuration registers

Register	Description
`MODE`	Select wire-OR (0) or point-to-point (1) signalling.
`STRETCH_MULT`	16-bit pulse stretch multiplier for wire-OR mode.
`INVERT`	Signal polarity inversion for GPIO adaptation.
`RESET`	Handshake state machine reset.

See the CTN Memory Map for the full CTP register layout and field descriptions. The CTN decodes the AXI-Lite CSR window and presents each CTP's registers at a 16-byte stride starting at offset 0x0200.

`MODE` and `INVERT` are static configuration, set once per boot in a single write before any CTM route selects or targets the port. The Programmer's Guide gives the cross-trigger programming sequence with reconfiguration and deadlock recovery.

2.1.7.6.2.2.3. Architecture

The Cross Trigger Port architecture separates the register interface from core logic to enable reuse. The full `cross_trigger_port` module includes CSRs for runtime configuration, while the `cross_trigger_port_core` module provides the core functionality without registers, allowing instantiation for internal cross-trigger connections without AXI-Lite overhead.

Figure 101 shows the Cross Trigger Port logic and its pad interfaces.




Figure 101. CTP module structure

The figure is read from the core side on the left to the four GPIO pads on the right. Every 2:1 mux is selected by `mode_wire_or_i`, and the numbers inside it mark which input each select value takes. Input 1, drawn upper, passes in wire-OR mode, when `mode_wire_or_i` is high because `CONFIG.MODE` is 0; input 0, drawn lower, passes in point-to-point mode. Italic names are nets driven by `u_reg` from the named CSR fields. Every pad control and both core-side outputs, `ct_dst_o` and `busy_o`, leave the port through a register on `clk_i`. Each pad input passes through two synchroniser registers and an XOR with `invert_i` and, on the handshake inputs, an AND with `p2p_din_valid` before any logic uses it. The `STATUS` read-back from the core to `u_reg` is not drawn.

2.1.7.6.2.2.3.1. Submodule Hierarchy

The CTP core instantiates four specialized submodules for different aspects of cross-trigger operation:

Table 2522 identifies the submodules that implement synchronization and cross-trigger operation.

Table 2522. CTP submodules

Module	Purpose
`ctp_synchronizer`	Implements 2-FF synchronizers for asynchronous GPIO inputs (ct_req_out_din, ct_req_in_din, ct_ack_in_din) from remote chiplets
`ctp_pulse_stretcher`	Extends source pulse duration for Wire-OR mode transmission, with configurable stretch multiplier (0-65535 cycles)
`ctp_edge_detector`	Detects positive edges on the synchronized ct_req_in signal; its output is not connected, because the receiver state machine works on the ct_req_in level
`ctp_handshake_ctrl`	Implements sender and receiver state machines for Point-to-Point mode four-phase handshaking protocol

2.1.7.6.2.2.3.2. Wire-OR Mode

Wire-OR mode is a 1-wire cross trigger signaling scheme compatible with many existing cross triggering implementations. This scheme is very resource efficient, as it only requires a single pin per chiplet connected to the network. However, the performance of the network decreases as the number of connected chiplets increase. Also, the duration of the cross trigger pulse must be pre-arranged across all connected chiplets.

2.1.7.6.2.2.3.2.1. Pulse Stretcher Operation

The pulse stretcher extends single-cycle core-side pulses to multi-cycle GPIO assertions lasting `stretch_mult + 1` clock cycles. The module implements a 16-bit countdown counter that loads the stretch multiplier value when a new pulse arrives and decrements to zero. If a new pulse arrives before the counter reaches zero, the counter restarts from the stretch multiplier value, ensuring that rapid successive pulses merge into an extended assertion.

The output `stretched_pulse` remains asserted as long as the counter is non-zero. This stretched pulse drives the output enable control for the open-drain CT_Req_out GPIO pad, effectively pulling the shared wire low for the configured duration.

Each chiplet has an open-drain I/O connected to a single shared wire. Any connected chiplet may pull this signal low to assert a cross trigger. Depending on the electrical requirements, one or more internal pad pull-ups or external keepers ensure the cross trigger request signal remains high when no cross trigger is asserted. To ensure no connected chiplet misses a cross trigger pulse, all chiplets transmitting a trigger pulse must stretch the pulse a mutually agreed upon length of time.

Note that in wire-OR mode the *CT_Req_out* signal is connected to an open-drain configured I/O pad. For I/O pads that do have explicit open-drain control, the request data signal should connect to the output-enable control pin of the I/O pad, and the output data signal of the I/O pin should be driven statically low.

Figure 102 shows the open-drain request path and pulse-stretching logic used in wire-OR mode. It is Figure 101 with every mux resolved to its wire-OR input. The CT_Req_out pad drives the constant `invert_i`, so its output enable, the stretched pulse, decides when the pad pulls the wire. The CTP receives a cross trigger on the falling edge of the synchronised wire: the register marked *prev* holds the previous level and the AND gate fires when the previous level is high and the current one low. The CTP disables the buffers of the other three pads in this mode, so they are not drawn.




Figure 102. CTP wire-OR behavior

Any number of chiplets may have their *CT_Req_out* pads interconnected as shown in Figure 103. In each chiplet the CLAs reach the CTM through the internal CTPs of the Cross Trigger Network, and the CTM reaches the external CTP through its *CT_Src* and *CT_Dst* signals. The shared wire also reaches a package pin.




Figure 103. CTP wire-OR chiplet connections

2.1.7.6.2.2.3.3. Point-to-Point Mode

Point-to-point mode utilizes a four-phase handshaking scheme to synchronize a cross trigger quickly and reliably between two chiplets without pulse stretching. While this scheme is simple and fast, it requires a dedicated CTP for each

chiplet-to-chiplet interconnection, and each CTP requires four I/O pads for bi-directional communication, or two pads for unidirectional communication. All output pads are configured for push-pull operation.

Figure 104 shows the request and acknowledge paths used for point-to-point handshaking. It is Figure 101 with every mux resolved to its point-to-point input. The output enables of CT_Req_out and CT_Ack_out and the input enables of CT_Ack_in and CT_Req_in are registered 1s. The input enable of the CT_Req_out pad is 0 in this mode, so only its output buffer is drawn, and the pulse stretcher and falling-edge detector are unused.




Figure 104. CTP point-to-point behavior

Any two chiplets may have their four cross trigger pads cross-coupled as shown in Figure 105. Each CTP lists its pads on the side that faces its partner, in the order that keeps every wire straight, so each request output meets a request input and each acknowledge output an acknowledge input.




Figure 105. CTP point-to-point chiplet connections

On the sender side, the receiver's *CT_Ack_out* is connected to the sender's *CT_Ack_in* pad. *CT_Req_out* asserts whenever *CT_Src* asserts. *CT_Req_out* will then remain asserted until *CT_Ack_in* asserts.

On the receiver side, the sender's *CT_Req_out* is connected to the receiver's *CT_Req_in* pad. On any positive edge of *CT_Req_in*, the receiver generates a pulse on *CT_Dst* and asserts *CT_Ack_out*. Deassertion proceeds in exactly the same sequence.

The timing of the request/acknowledge handshake is shown in Figure 106. The timing is illustrative, and the delays are not to scale:




Figure 106. CTP request-acknowledge timing

2.1.7.6.2.2.3.3.1. Synchronization and CDC Handling

All GPIO input signals are asynchronous with respect to the CTP system clock and require synchronization to prevent metastability. The `ctp_synchronizer` module implements three independent 2-FF synchronizer chains using the `prim_flop_2sync` primitive:

Table 2523 identifies the incoming signals synchronized in each operating mode.

Table 2523. CTP signal synchronization

Signal	Used In Mode	Synchronization Purpose
`ct_req_out_din`	Wire-OR	Synchronizes open-drain wire state from remote chiplets before edge detection
`ct_req_in_din`	Point-to-Point	Synchronizes request signal from remote sender before receiver FSM

Signal	Used In Mode	Synchronization Purpose
ct_ack_in_din	Point-to-Point	Synchronizes acknowledge signal from remote receiver before sender FSM

After synchronization, an optional inversion is applied if the INVERT configuration bit is set. This allows adaptation to GPIO pads with different polarity requirements. Edge detection and state machine processing occur only on synchronized (and optionally inverted) signals, ensuring all CTP core logic operates on glitch-free inputs.

2.1.7.6.2.2.3.3.2. Handshake State Machines

Point-to-point mode implements two independent state machines within the ctp_handshake_ctrl module, enabling full-duplex cross-triggering. The sender state machine controls outgoing cross-trigger requests, while the receiver state machine handles incoming requests. Both state machines operate synchronously in the system clock domain on synchronized GPIO inputs.

The state machines run only in point-to-point mode. While wire-OR mode is selected, cross_trigger_port_core holds the sender in SENDER_IDLE with ct_req_out=0 and blocks ct_src_i from reaching it. The CT_Req_in and CT_Ack_in pad inputs are disabled in wire-OR mode, and after point-to-point mode is selected their synchronizers hold the disabled pad level for two cycles. The core presents both synchronized inputs to the state machines as deasserted until the delayed input enable shows the synchronizers carry pad data. Neither a trigger raised in wire-OR mode nor the level of a disabled pad reaches the point-to-point pads when the mode changes.

Sender State Machine:

Table 2524 lists the sender handshake states, transition conditions, and output actions.

Table 2524. CTP sender state transitions

Current State	Condition	Next State	Output Actions
SENDER_IDLE	ct_src_i asserted	SENDER_REQ_ASSERTED	Assert ct_req_out=1
SENDER_REQ_ASSERTED	ct_ack_in_sync asserted	SENDER_WAIT_ACK_DEASSERT	De-assert ct_req_out=0
SENDER_WAIT_ACK_DEASSERT	ct_ack_in_sync de-asserted	SENDER_IDLE	None (remain idle)
Any state	reset_i asserted	SENDER_IDLE	Force ct_req_out=0
Any state	Wire-OR mode selected	SENDER_IDLE	Force ct_req_out=0

Receiver State Machine:

Table 2525 lists the receiver handshake states, transition conditions, and output actions.

Table 2525. CTP receiver state transitions

Current State	Condition	Next State	Output Actions
RECEIVER_IDLE	ct_req_in_sync asserted	RECEIVER_ACK_ASSERTED	Assert ct_ack_out=1, generate ct_dst pulse
RECEIVER_ACK_ASSERTED	ct_req_in_sync de-asserted	RECEIVER_WAIT_REQ_DEASSERT	De-assert ct_ack_out=0, clear ct_dst
RECEIVER_WAIT_REQ_DEASSERT	ct_req_in_sync remains low	RECEIVER_IDLE	None
RECEIVER_WAIT_REQ_DEASSERT	ct_req_in_sync goes high	Remain in state	Continue waiting

The ct_dst output pulse is generated for a single clock cycle when the receiver state machine transitions from IDLE to ACK_ASSERTED. The busy signal indicates an active cross-trigger transfer: it reflects either state machine being outside its IDLE state. It is registered once in ctp_handshake_ctrl and again in cross_trigger_port_core, so busy_o and STATUS.BUSY rise two clk_i cycles after a state machine leaves IDLE and fall two clk_i cycles after both state machines return to

IDLE. Logic that samples busy_o within two cycles of a trigger on ct_src_i, or of the end of a handshake, sees the previous value.

2.1.7.6.2.2.4. Interface

2.1.7.6.2.2.4.1. Signal Interface

Packed control and bus types remain bundles at the cross_trigger_port module boundary; their members are not separate scalar ports.

The parameters and ports of cross_trigger_port are listed in the HTML edition of this manual, under RTL Modules Reference.

cross_trigger_port includes the CSR interface. The register-free cross_trigger_port_core instead takes mode_wire_or_i, invert_i, handshake_reset_i, and stretch_mult_i as configuration inputs. At that core interface, mode_wire_or_i = 1 selects wire-OR and 0 selects point-to-point; the CSR MODE field is inverted before reaching it.

2.1.7.6.2.2.4.2. Dependencies

The CTP depends on the following components:

- hw/common/ocah_prim - Primitive cells (synchronizers, pulse stretcher)

2.1.7.6.2.3. Cross-Trigger Matrix

The Cross Trigger Matrix (CTM) is an AND-OR crossbar that aggregates and statically routes cross-trigger pulses between all sources (CTPs, CLAs, internal devices) and sinks under AXI-Lite CSR control. The default DTP configuration uses 26 input ports and 26 output ports.

2.1.7.6.2.3.1. Overview

The CTM is compatible with both wire-OR and point-to-point CTPs. Typical connections include Core Logic Analyzers (CLAs) and Cross Trigger Ports (CTPs). Each device connected to the CTM acts as both a source and a sink.

The NUM_CT_SRC and NUM_CT_DST parameters in regs/cross_trigger_matrix.rdl define the matrix dimensions and default to 26 each. The RTL derives the following localparams from the generated register map:

Table 2526 lists the source and destination counts used by the CTM register map.

Table 2526. CTM configuration constants

Constant	Value	Description
NUM_CT_SRC	26	Number of CT_Src output ports (sized by the CT_SRC array in the register map).
NUM_CT_DST	26	Number of CT_Dst input ports (sized by the CT_DST_SELECT field width in the register map).

These values cannot be overridden at instantiation. Resizing the matrix requires regenerating the register map with PeakRDL addrmap overrides (OCAH_REG_RDL_PARAMS_cross_trigger_matrix) that match the elaborated Cross-Trigger Network total (NUM_CTP + NUM_INT_CT). The CTN fails elaboration if that total disagrees with the generated NUM_CT_SRC and NUM_CT_DST. The CTM takes the AXI-Lite request and response types as module parameters, which the CTN overrides to match its own crossbar.

The wrapper passes the register block only the address bits its register map spans, and the CTN ends the matrix's crossbar window at the end of that map. An access past the last CT_Src register completes with DECERR rather than

reaching a register. The 512-byte CTM aperture holds 64 source registers at the 8-byte stride, so a matrix of up to 64 ports needs only the regenerated CTM and CTN register maps.

Every CT_Src port occupies 8 bytes regardless of the port count. At or below 32 destinations, each register is a single 32-bit word with immediate write semantics. Above 32 destinations both words must be written before the mask takes effect, preventing half-programmed states.

The register map for the CTM and for each CTP is included once in the CTN Memory Map section. This page covers the crossbar architecture and signal interface only.

2.1.7.6.2.3.2. Architecture

The Cross Trigger Matrix has N source ports and N destination ports, one of each per CTM port of the Cross Trigger Network, so N = `XTRIG_NUM_CTP` + `XTRIG_NUM_INT_CT`. The `dtp_pkg` defaults of 16 external CTPs and 10 internal CTPs give N = 26. `cross_trigger_matrix_pkg` takes `NUM_CT_SRC` and `NUM_CT_DST` from the register map, and the CTN asserts at elaboration that both equal `NUM_CTP` + `NUM_INT_CT`, so resizing the matrix means regenerating `regs/cross_trigger_matrix.rdl` to match. The matrix implements a combinatorial AND-OR crossbar with registered outputs to route cross-trigger pulses between CTPs and internal cross-trigger sources.

Figure 107 shows how the CTM selects and combines sources for each registered destination.




Figure 107. CTM routing structure

The figure draws two of the N selectors, for ct_src_o[0] and ct_src_o[N-1], and in each the AND gates for inputs 0, 1 and N-1; the dots stand for the rest. The thick lines are buses whose taps carry the bit index: the ct_dst_i bus fans out to every selector, and each selector reads its own CT_SRC[j].CONFIG_0.CT_DST_SELECT field from u_reg, the matrix CSR block reached over AXI-Lite.

The CTM is programmed at runtime via firmware or debug transactions. Proper configuration of the CTMs in each chiplet will minimize trigger latency and prevent loops in the SiP cross trigger network.

2.1.7.6.2.3.2.1. Routing Logic

The CTM routing implements a two-stage combinatorial path followed by output registration. Each of the N CT_Src output ports is driven by a dedicated ctm_src_selector module that performs the following operation:

Table 2527 describes the selection, combination, and register stages of destination routing.

Table 2527. CTM routing stages

Stage	Operation
Selection (AND)	Each CT_Dst[i] input is AND-gated with its corresponding select bit: selected_pulses[i] = ct_dst_i[i] & select_mask[i]
Aggregation (OR)	All selected pulses are OR-reduced: ct_src_comb = |selected_pulses
Registration	The combinatorial result is registered on clk_i rising edge: ct_src_o ⇐ ct_src_comb

This architecture allows each CT_Src output to combine pulses from multiple CT_Dst inputs through OR-aggregation. Multiple CT_Src outputs can source from the same CT_Dst input, enabling broadcast distribution. The register stage prevents glitches on the output when configuration changes or when multiple input pulses arrive simultaneously.

2.1.7.6.2.3.2.2. Port Indexing

Table 2528 maps matrix indices to external CTPs, internal CTPs, and clock-stop connections.

Table 2528. CTM port indices

Port Index	Description
0 to NUM_CTP-1	External CTPs (NUM_CTP)
NUM_CTP to N-1	Internal CTPs (NUM_INT_CT)

NUM_CTP and NUM_INT_CT are the CTN parameters that XTRIG_NUM_CTP and XTRIG_NUM_INT_CT set. This indexing is used for CTM ct_dst_i and ct_src_o port assignment and CTM routing configuration registers.

2.1.7.6.2.3.3. Interface

2.1.7.6.2.3.3.1. Signal Interface

Packed control and bus types remain bundles at the cross_trigger_matrix module boundary; their members are not separate scalar ports.

The parameters and ports of cross_trigger_matrix are listed in the HTML edition of this manual, under RTL Modules Reference.

NUM_CT_SRC and NUM_CT_DST come from the generated register package. Routing masks are programmed through the AXI-Lite CSR port; there are no separate route-configuration or acknowledge ports.

2.1.7.6.2.3.3.2. Data Ports

The CTM has the following data ports:

- **CT_Src[N-1:0]** - Cross trigger pulse output signals from the CTM to CLAs, CTPs, or other cross trigger sinking devices, where N is the number of these cross trigger sinks.
- **CT_Dst[M-1:0]** - Cross trigger pulse input signals to the CTM from CLAs, CTPs, or other cross trigger generating devices, where M is the number of these cross trigger sources.

2.1.7.6.2.3.3.3. Dependencies

The CTM depends on the following components:

- `hw/common/ocah_prim` - Primitive cells

2.1.7.7. Configuration and Reference

This page provides the DTP top-level port table. Configuration parameters are defined on their owning IP pages; see the links in the section below. The generated CTM and CTP register maps appear in the CTN Memory Map section of the Cross-Trigger Network page.

2.1.7.7.1. Port Reference

Table 2529 lists all DTP top-level ports. The port table is shared with the Integrator Guide.

Legend: Where no Default entry is shown in Description / Default, the original port reference specifies N/A — those ports have no integrator-supplied default; connect as directed by Description.

Table 2529 lists the DTP boundary ports, their dimensions, and their connections.

Table 2529. DTP Port Declaration

Interface Name	Type	Dir	Width	Description / Default	Connection
`clk_i`	`logic`	In	1	System clock for cross trigger logic and JTAG2AXI bridges.	System clock
`rst_n_i`	`logic`	In	1	System reset (active low). Resets cross trigger and AXI logic; does not affect the TAP controller.	System reset
`pwr_on_rst_ni`	`logic`	In	1	Power-on reset for JTAG state machine (active low, asynchronous).	Power-on reset
`dbg_disable_i`	`sep_lifecycle_ctrl_pkg ::dbg_disable_t`	In	-	Per-path lifecycle controls for disabling debug and test interfaces. Active-high (1 = path disabled). DTP synchronizes each field into the JTAG TCK domain.	SEP lifecycle controller or adopter-equivalent policy source
`jtag_ptap_client_tap_ctrl_i`	`jtag_tap_ctrl_t`	In	-	Primary JTAG TAP control (TCK, TMS, TRST_N).	External JTAG pads
`jtag_ptap_client_tdi_i`	`logic`	In	1	Primary JTAG TDI.	External JTAG pads
`jtag_ptap_client_tdo_o`	`logic`	Out	1	Primary JTAG TDO.	External JTAG pads
`jtag_ptap_client_tdo_oen_o`	`logic`	Out	1	Primary JTAG TDO output enable.	External JTAG pads
`jtag_bsr_host_scan_ctrl_o`	`jtag_scan_ctrl_t`	Out	-	Boundary scan control. Tie scan_in to scan_out if BSR is disabled.	Boundary scan chain
`jtag_bsr_host_scan_in_i`	`logic`	In	1	Boundary scan data in.	Boundary scan chain

Interface Name	Type	Dir	Width	Description / Default	Connection
jtag_bsr_host_scan_out_o	logic	Out	1	Boundary scan data out.	Boundary scan chain
jtag_stap_io_host_tap_ctrl_o	jtag_tap_ctrl_t	Out	-	I/O STAP TAP control for chiplet-to-chiplet connectivity. If JTAG_STAP_IO_ENABLE=0, only .tck is driven; .tms is 0 and .trst_n is 0, so TRST is asserted and a TAP connected to the port is held in Test-Logic-Reset.	I/O STAP host
jtag_stap_io_host_tdi_i	logic	In	1	I/O STAP TDI. Default: Tie to '0 if unused.	I/O STAP host
jtag_stap_io_host_tdo_o	logic	Out	1	I/O STAP TDO.	I/O STAP host
jtag_stap_io_host_tdo_oen_o	logic	Out	1	I/O STAP TDO output enable.	I/O STAP host
jtag_stap_smc_host_tap_ctrl_o	jtag_tap_ctrl_t	Out	-	SMC debug STAP TAP control. If JTAG_SMC_DBG_ENABLE=0, only .tck is driven; .tms is 0 and .trst_n is 0, so TRST is asserted and a TAP connected to the port is held in Test-Logic-Reset.	SMC JTAG port
jtag_stap_smc_host_tdi_i	logic	In	1	SMC debug STAP TDI (from SMC TDO). Default: Tie to '0 if unused.	SMC JTAG port
jtag_stap_smc_host_tdo_o	logic	Out	1	SMC debug STAP TDO (to SMC TDI).	SMC JTAG port
jtag_stap_smc_host_tdo_oen_o	logic	Out	1	SMC debug STAP TDO output enable.	SMC JTAG port
jtag_stap_sep_host_tap_ctrl_o	jtag_tap_ctrl_t	Out	-	SEP debug STAP TAP control. If JTAG_SEP_DBG_ENABLE=0, only .tck is driven; .tms is 0 and .trst_n is 0, so TRST is asserted and a TAP connected to the port is held in Test-Logic-Reset.	SEP JTAG port
jtag_stap_sep_host_tdi_i	logic	In	1	SEP debug STAP TDI (from SEP TDO). Default: Tie to '0 if unused.	SEP JTAG port
jtag_stap_sep_host_tdo_o	logic	Out	1	SEP debug STAP TDO (to SEP TDI).	SEP JTAG port
jtag_stap_sep_host_tdo_oen_o	logic	Out	1	SEP debug STAP TDO output enable.	SEP JTAG port
jtag_stap_extra_host_tap_ctrl_o	jtag_tap_ctrl_t	Out	[JtagNumExtraStapPorts-1:0]	Extra STAP TAP control array. If JTAG_NUM_EXTRA_STAPS=0, the single padded element drives only .tck; its .tms is 0 and its .trst_n is 0, so TRST is asserted and a TAP connected to it is held in Test-Logic-Reset.	Extra STAP hosts
jtag_stap_extra_host_tdi_i	logic	In	[JtagNumExtraStapPorts-1:0]	Extra STAP TDI array. Default: Tie to '0 if unused.	Extra STAP hosts
jtag_stap_extra_host_tdo_o	logic	Out	[JtagNumExtraStapPorts-1:0]	Extra STAP TDO array.	Extra STAP hosts
jtag_stap_extra_host_tdo_oen_o	logic	Out	[JtagNumExtraStapPorts-1:0]	Extra STAP TDO output enable array.	Extra STAP hosts
jtag_stap_host_scan_ctrl_o	jtag_scan_ctrl_t	Out	-	Extended STAP scan control. Tie scan_in to scan_out if unused.	STAP scan chain
jtag_stap_host_scan_in_i	logic	In	1	Extended STAP scan data in.	STAP scan chain
jtag_stap_host_scan_out_o	logic	Out	1	Extended STAP scan data out.	STAP scan chain
jtag_dfd_host_scan_ctrl_o	jtag_scan_ctrl_t	Out	-	DFD iJTAG scan control. Tie scan_in to scan_out if unused.	DFD iJTAG chain
jtag_dfd_host_scan_in_i	logic	In	1	DFD iJTAG scan data in.	DFD iJTAG chain
jtag_dfd_host_scan_out_o	logic	Out	1	DFD iJTAG scan data out.	DFD iJTAG chain

Interface Name	Type	Dir	Width	Description / Default	Connection
jtag_dft_secure_host_scan_ctrl_o	jtag_scan_ctrl_t	Out	-	Secure DFT iJTAG scan control. Tie scan_in to scan_out if unused.	Secure DFT iJTAG chain
jtag_dft_secure_host_scan_in_i	logic	In	1	Secure DFT iJTAG scan data in.	Secure DFT iJTAG chain
jtag_dft_secure_host_scan_out_o	logic	Out	1	Secure DFT iJTAG scan data out.	Secure DFT iJTAG chain
jtag_dft_host_scan_ctrl_o	jtag_scan_ctrl_t	Out	-	Non-secure DFT iJTAG scan control. Tie scan_in to scan_out if unused.	Non-secure DFT iJTAG chain
jtag_dft_host_scan_in_i	logic	In	1	Non-secure DFT iJTAG scan data in.	Non-secure DFT iJTAG chain
jtag_dft_host_scan_out_o	logic	Out	1	Non-secure DFT iJTAG scan data out.	Non-secure DFT iJTAG chain
axi_smc_dbg_req_o	smc_jtag_axi_req_t	Out	-	SMC fabric debug AXI request. Active when JTAG_SMC_DBG_ENABLE=1. Default: tie to '0 if disabled.	SMC jtag_axi_in_req_i
axi_smc_dbg_resp_i	smc_jtag_axi_resp_t	In	-	SMC fabric debug AXI response. Default: tie to '0 if disabled.	SMC jtag_axi_in_resp_o
axil_smc_otp_jtag_req_o	smc_otp_axil_req_t	Out	-	SMC OTP debug AXI-Lite request. Default: tie to '0 if disabled.	SMC axil_smc_otp_jtag_req_i
axil_smc_otp_jtag_resp_i	smc_otp_axil_resp_t	In	-	SMC OTP debug AXI-Lite response. Default: tie to '0 if disabled.	SMC axil_smc_otp_jtag_resp_o
axil_sep_otp_jtag_req_o	sep_otp_axil_req_t	Out	-	SEP OTP debug AXI-Lite request. Default: tie to '0 if disabled.	SEP axil_sep_otp_jtag_req_i
axil_sep_otp_jtag_resp_i	sep_otp_axil_resp_t	In	-	SEP OTP debug AXI-Lite response. Default: tie to '0 if disabled.	SEP axil_sep_otp_jtag_resp_o
stop_clks_o	logic	Out	1	Clock stop output from JTAG DEBUG_CONTROL or CLA clock-stop requests via CTN.	PLL clock gates
cla_clock_stop_en_o	logic	Out	1	CLA clock stop enable from DEBUG_CONTROL register.	Clock control logic
jtag_boot_stall_ovrd_o	logic	Out	1	JTAG boot stall override enable.	Boot control
jtag_boot_stall_o	logic	Out	1	JTAG boot stall value when override is asserted.	Boot control
jtag_ic_reset_smc_o	ic_reset_smc_t	Out	$bits(ic_reset_smc_t)	SMC IC_RESET override slice. Struct contains .ovrd (override enables) and .val (active-low override values), each sized to match the corresponding SMC reset control struct. Tied to '0 when JTAG_IC_RESET_SMC_ENABLE=0.	SMC jtag_smc_reset_ctrl_i
jtag_ic_reset_sep_o	ic_reset_sep_t	Out	$bits(ic_reset_sep_t)	SEP IC_RESET override slice. Struct contains .ovrd (override enables) and .val (active-low override values), each sized to match the corresponding SEP reset control struct. Tied to '0 when JTAG_IC_RESET_SEP_ENABLE=0.	SEP jtag_sep_reset_ctrl_i
jtag_ic_reset_ext_o	ic_reset_ext_t	Out	$bits(ic_reset_ext_t)	External IC_RESET override slice. Struct contains .ovrd (override enables) and .val (active-low override values), each sized per integrator-defined type. Tied to '0 when JTAG_IC_RESET_EXT_ENABLE=0.	Integrator-defined reset overrides for logic outside the SMU
jtag_ptap_state_o	tap_state_e	Out	-	Current PTAP TAP state.	Debug infrastructure
jtag_ptap_inst_decoded_o	jtag_instruction_decoded_e	Out	-	Current decoded PTAP instruction.	Debug infrastructure

Interface Name	Type	Dir	Width	Description / Default	Connection
axil_xtrig_req_i	xtrig_axil_req_t	In	-	Cross trigger CSR AXI-Lite request from SMC.	SMC axil_dtp_csr_req_o
axil_xtrig_resp_o	xtrig_axil_resp_t	Out	-	Cross trigger CSR AXI-Lite response to SMC.	SMC axil_dtp_csr_resp_i
xtrig_ctm_src_req_o	logic	Out	[XTRIG_NUM_INT_CT-1:0]	Cross trigger source requests from CTM to destination sinks.	Cross trigger sinks
xtrig_ctm_src_ack_i	logic	In	[XTRIG_NUM_INT_CT-1:0]	Cross trigger source acknowledges. Unused in pulse-sync mode (mode bit = 0). Default: tie to '0 in pulse-sync mode.	Cross trigger sinks
xtrig_ctm_dst_req_i	logic	In	[XTRIG_NUM_INT_CT-1:0]	Cross trigger destination requests from source generators. Default: tie to '0 if unused.	Cross trigger sources
xtrig_ctm_dst_ack_o	logic	Out	[XTRIG_NUM_INT_CT-1:0]	Cross trigger destination acknowledges. Unused in pulse-sync mode (mode bit = 0).	Cross trigger sources
xtrig_clk_stop_req_i	logic	In	[XTRIG_NUM_CLK_STOP_REQ-1:0]	Clock stop requests from CLAs or other devices in the chiplet. Default: Tie to '0 if unused.	Clock stop requesters
xtrig_ctp_req_out_dout_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP request-out data output (to pad ring).	GPIO pad ring
xtrig_ctp_req_out_dout_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP request-out output enable.	GPIO pad ring
xtrig_ctp_req_out_din_i	logic	In	[XTRIG_NUM_CTP-1:0]	CTP request-out loopback input. Default: tie to '0 if unused.	GPIO pad ring
xtrig_ctp_req_out_din_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP request-out input enable.	GPIO pad ring
xtrig_ctp_req_in_dout_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP request-in data output.	GPIO pad ring
xtrig_ctp_req_in_dout_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP request-in output enable.	GPIO pad ring
xtrig_ctp_req_in_din_i	logic	In	[XTRIG_NUM_CTP-1:0]	CTP request-in data input. Default: tie to '0 if unused.	GPIO pad ring
xtrig_ctp_req_in_din_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP request-in input enable.	GPIO pad ring
xtrig_ctp_ack_in_dout_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP ack-in data output.	GPIO pad ring
xtrig_ctp_ack_in_dout_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP ack-in output enable.	GPIO pad ring
xtrig_ctp_ack_in_din_i	logic	In	[XTRIG_NUM_CTP-1:0]	CTP ack-in data input. Default: tie to '0 if unused.	GPIO pad ring
xtrig_ctp_ack_in_din_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP ack-in input enable.	GPIO pad ring
xtrig_ctp_ack_out_dout_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP ack-out data output.	GPIO pad ring
xtrig_ctp_ack_out_dout_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP ack-out output enable.	GPIO pad ring
xtrig_ctp_ack_out_din_i	logic	In	[XTRIG_NUM_CTP-1:0]	CTP ack-out data input. Default: tie to '0 if unused.	GPIO pad ring
xtrig_ctp_ack_out_din_en_o	logic	Out	[XTRIG_NUM_CTP-1:0]	CTP ack-out input enable.	GPIO pad ring
test_en_i	logic	In	1	DFT test-mode enable (active high) for the JTAG2AXI bridges and the cross trigger CSR crossbar. Default: 0 in functional mode.	DFT controller

Interface Name	Type	Dir	Width	Description / Default	Connection
`scan_rst_ni`	`logic`	In	1	DFT scan reset (active low). Unused: DTP has no reset synchronizer, so `rst_n_i` must arrive scan-controlled.	DFT controller, or tie high

2.1.7.7.2. Configuration Parameters

DTP instantiation parameters are defined on their owning IP pages:

- **JTAG Interface Unit** parameters (STAP count, I/O/SMC/SEP/extra STAP enables) — see the JTAG Interface Unit page.
- **PTAP** parameters (IC_RESET struct types, IDCODE fields, JTAG2AXI pipeline depths, feature-enable enables) — see the JTAG PTAP page.
- **Cross Trigger Network** parameters (CTP count, internal CT count, clock-stop request count, per-CTP operating mode) — see the Cross-Trigger Network page.

2.1.7.7.3. Address Map

CTN Register Map

2.2. System Management Network (SMN)

The System Management Network (SMN) is the system fabric outside the SMU. It carries transactions between the SMU and resources elsewhere in the chiplet. SEP, SMC and DTP belong to the SMU; the SMN is a separate platform component.

2.2.1. SMU Interface

The SMU exposes two AXI interfaces toward the SMN:

- `smu_axi_in_req_i` / `smu_axi_in_resp_o`: external requests entering the SMU and their responses.
- `smu_axi_out_req_o` / `smu_axi_out_resp_i`: requests leaving the SMU and responses from the external fabric.

The internal SMU crossbar connects SEP, SMC and these external interfaces. It routes incoming requests to the programmed SEP or SMC global aperture. SEP and SMC requests that match neither aperture leave through the external output. External requests cannot loop back to that output; an unmatched incoming address produces a decode error.

2.2.2. Addressing and Integration

SEP and SMC global base addresses and region sizes are software-programmed. The surrounding system must use the same address assignments when accessing those subsystems. Subsystem remapping and filtering are described in their Interconnect chapters, and the Programmer's Guide gives the aperture programming sequence.

This chapter describes the SMU boundary. Network topology, routing beyond that boundary and connections to other chiplets depend on the enclosing system.

See SMU AXI Crossbar, OCAH Memory Map, SEP Interconnect and SMC Interconnect.

2.3. AXI-over-UCIe Bridge (AoU)

The AXI-over-UCIe bridge transports AXI transactions between chiplets through the UCIe interface. These pages reproduce the AOU_CORE Microarchitecture Specification, originally authored by BOS Semiconductors, and follow the AXI over UCIe protocol specification.

2.3.1. Overview and Features

Apache License Release
AOU_CORE Microarchitecture specification
Version 1.00, Feb.27 2026
BOS Semiconductors

2.3.1.1. Introduction

This microarchitecture specification includes detailed functional description of AOU_CORE.

The contents of this document are given as follows. Section 1 is for overview. Section 2 is for features, implementation specific features, and assumptions. In Section 3, the architecture and operation of AoU IP are given. Section 4 covers interrupt sources. Section 5 covers error handling. Section 6 includes the integration guidelines such as clocks, resets, and I/O descriptions. Section 7 includes the software operation guide including the register map and activation flows. Section 8 includes performance, power, and area information.

2.3.1.1.1. Overview

The AOU_CORE is a bridge between AXI interface and the UCIe FDI interface, defined in AoU standard v0.7 spec. To achieve low latency, AOU_CORE directly handles signals related to the UCIe FDI interface data flow control and processes data in 32-byte, 64-byte, or 128-byte chunks (selected at integration time via the FDI_CONFIG parameter; see the Integrator guide) in a cut-through manner, without converting them to 256-byte flit data. It receives AXI messages from its own AXI subordinate interface, packs them into chunks of the configured FDI width, and transmits these chunks to the remote AoU device via UCIe. The remote AoU receives the chunks from the UCIe FDI interface, unpacks them into AXI messages, and delivers the data through its AXI manager interface. The one-way AoU latency, measured from the AXI input of the local device to the AXI output of the remote device over a back-to-back connection in a single clock domain, is 7 cycles for read requests, 8 cycles for read data, 9 cycles for write requests, 9 cycles for write data, and 6 cycles for write responses. For applications using UCIe, including those with some CDC domains, the round-trip time (RTT) latency from an AXI read request to the corresponding AXI read response through this AoU IP over UCIe is approximately 45 cycles, excluding the memory latency of the remote device.

To achieve high efficiency, all TX requests and data messages are packed in a compact format, ensuring that no AoU payload slots are wasted. The current payload is even updated when the UCIe stalls the current chunk and space remains available. As a result, the throughput matches the values defined in the AoU specification. In each cycle, the RX can process the maximum number of messages defined in the AoU standard: 4 read requests, 4 write requests, 2 read data, 2 write data, and 12 write responses, respectively.

It supports flow control for all exceptional cases defined in the UCIe standard. First, it handles the chunk valid/cancel signal, including the alternative implementation method described in the UCIe specification. Second, it handles the stall request signal received from the D2D Adapter while maintaining the Flit-aligned boundary. Interoperability is also supported when the remote device uses a different AXI data width.

AOU_CORE supports a configurable number of Resource Plane(RPs), with both the number of RPs and each RP's AXI data width fully parameterizable. A dedicated field in the SFR allows software to configure the target RP, enabling flexible RP

mapping. For each RP, the AW, W and AR channel support three arbitration modes: Round Robin, AXI QoS scheme, and Port QoS scheme. Additionally, a starvation-prevention mechanism is implemented to ensure fair arbitration across all RP channels.

The operating frequency of AOU_CORE targets 1 GHz and meets timing requirements without relying on multi-cycle paths. The TX buffer is configured with a minimal number of FIFO entries, while the RX Data buffer default depth is FDI-config aware: default 140 entries when FDI_CONFIG selects a 1024b (128B) FDI interface (FDI_CFG_SP_128B or FDI_CFG_TP_64B_128B), and default 88 entries otherwise. The entry size takes into account the round-trip latency for credit consumption and return, and matches the per-RP RP*_RX_W_FIFO_DEPTH / RP*_RX_R_FIFO_DEPTH parameter defaults documented in the Integrator guide.

2.3.1.2. Features

Figure 108 shows the AXI-to-UCIe bridge functions and their relationships.




Figure 108. Block Diagram of AOU_CORE and function description

2.3.1.2.1. Basic features

- Single APB subordinate interface
  - Configuration/control/status register access
- Multiple AXI subordinate & manager interface
  - Configurable RP port & RP remapping supported
  - Supports variable data widths and burst length requests. Configurable FIFO Depth
- UCIe 256B latency-optimized flit(Format 6) support only
- Message packing and unpacking are handled in a unit of 32, 64, or 128 bytes, corresponding to the configured FDI data width (32B@1 GHz, 64B@1 GHz, or 128B@1 GHz).
- Selectable Early response by setting SFR
- Selectable 32B / 64B / 128B single-PHY and 32B+64B / 64B+128B two-PHY FDI configurations, selected via the

FDI_CONFIG parameter (see the Integrator guide). Two-PHY variants additionally require the +define+TWO_PHY build flag so the second-PHY ports physically exist.

- Configurable number of Resource Plane and each RP's AXI data width
- RP Remapping
- QoS scheme between RP with AW, W, AR channel
- Interoperability with different data width remote die
- Handling of flit cancel and stall request as specified in the UCIe specification
- Selectable AXI Aggregator added for BUS efficiency
- According to the AoU specification, except for the AXI data width, the parameters AXI_ADDR_WD, AXI_ID_WD, and AXI_LEN_WD are fixed. Porting to match the width of the connected ports must be handled externally to AOU_CORE_TOP.
- Returning read data that exceeds the AXI data width of the remote die is treated as a violation.
- For a Read Request received from the remote die, if ARSIZE is 5 or less, it returns a Read Data message with DLEN = 2'b00; if ARSIZE is 6, it returns a Read Data message with DLEN = 2'b01; if ARSIZE is 7, it returns a Read Data message with DLEN = 2'b10; Accordingly, if the local die receives a read data message from the remote die whose size is smaller than its own AXI data width, it duplicates the data to match its own AXI data width.

2.3.2. Architecture

This section describes the block diagram of AOU_CORE.

2.3.2.1. Block diagram




Figure 109. Architecture of AOU_CORE

Figure 109 shows block diagram of current AOU_CORE. The AXI interface supports both Manager and Subordinate transactions for message transmission and reception. AOU_CORE may issue AR and AW requests to the remote die using the local bus width. Consequently, R-data from the remote die and W-data from the local die are constrained to the local bus width. However, since the remote die can transmit data with variable DLEN, AOU_CORE must support all possible data lengths. This functionality is managed by AXI4MUX_3X1_TOP, which receives variable DLEN data from RX_CORE, aligns it to the local bus width, and splits the burst length into segments matching the local bus burst size.

Inside AXI4MUX_3X1_TOP, AXI aggregator is added for improving bus utilization. AXI aggregator combines narrow read & write data and send it to BUS. This functionality may modify AXI Len & Size. For example, AXI AR with 256-bit size & 16 burst length may transfer into 1024-bit size & 4 burst length. This operation can be controlled via SFR setting.

AOU_CORE provides a parameterizable FDI interface; the data-path width is selected by FDI_CONFIG (FDI_CFG_SP_32B / FDI_CFG_SP_64B / FDI_CFG_SP_128B for single-PHY, FDI_CFG_TP_32B_64B / FDI_CFG_TP_64B_128B for two-PHY). See the Integrator Guide for the full table of FDI_CONFIG values and resulting per-PHY widths.

2.3.2.2. TX_CORE




Figure 110. Block Diagram of Single RP AOU_TX_CORE

Figure 110 shows the simplified block diagram of single RP AOU_TX_CORE. The module receives AXI messages for Remote Die. AOU_TX_AXI_BUFFER captures AXI messages from the system bus. When AOU_TX_CORE obtains sufficient credit from AOU_CRD_CTRL, it packs the AXI message into an AOU message and stores it in the ring buffer. Once there is enough space to hold all messages, messages are stored to the ring buffer in parallel. The ring buffer subsequently performs handshake operations with the FDI interface.

2.3.2.2.1. TX_CORE QoS Scheme

Figure 111 shows the arbitration path used to select among resource-plane requests.




Figure 111. TX_CORE QoS Scheme

When multiple RP requests are issued from the TX core, a QoS scheme is applied. The TX core supports three QoS schemes: **Round-Robin**, **Port QoS**, and **AXI QoS**. Each transaction supports three QoS level: **High, Normal, Low.**

Round-Robin (ARB_MODE = 2'b00) : Round-robin arbitration between valid RP. When a handshake occurs, the RP that will receive the next grant is determined.

Figure 112 illustrates grant rotation among valid resource-plane requests.




Figure 112. Round-Robin arbitration example

Port QoS (ARB_MODE = 2'b01): For each RP, the QoS level is configured by an SFR. Arbitration is performed based on the QoS value is the SFR. The AXI QoS field is not used for arbitration.

The port QoS is divided into three levels: High, Normal, and Low priority. Port QoS can be configured by setting PRIOR_RP_AXI.PRx_PRIOR. A 2-bit field is used for QoS and supports values from 1 to 3. If the field is set to 0, it is treated as 1.

By default, arbitration is performed in the order **High** → **Normal** → **Low**. If a timeout occurs while a request is at Normal or Low priority, the request is promoted and treated as High priority. Timeout value can be configured by setting PRIOR_TIMER.TIMER_THRESHOLD. The resolution used for timeout determination can be configured through PRIOR_TIMER.TIMER_RESOLUTION.

If multiple RPs have the same priority, arbitration among them is performed in a round-robin manner.

Figure 113 illustrates arbitration using the configured resource-plane priorities.




Figure 113. Port QoS arbitration example

AXI QoS (ARB_MODE = 2'b10): For each RP, the QoS level is determined by the value of the AXI QoS field. Arbitration is performed based on the AXI QoS value. For the 4-bit AXI QoS field, boundary of High priority and Normal Priority can be configured by SFR setting. The port QoS is divided into three levels: **High**, **Normal**, and **Low** priority. By default, arbitration is performed in the order **High** → **Normal** → **Low**. If a timeout occurs while a request is at Normal or Low priority, the request is promoted and treated as High priority. If multiple RPs have the same priority, arbitration among them is performed in a round-robin manner.

Figure 114 illustrates arbitration using the AXI QoS fields.




Figure 114. AXI QoS arbitration example

2.3.2.3. RX_CORE




Figure 115. Block Diagram of AOU_RX_CORE

Figure 115 shows the simplified block diagram of AOU_RX_CORE. AOU_RX_CORE is a submodule that interfaces directly with the D2D adapter, receiving I_FDI_PL_VALID, I_FDI_PL_DATA, and I_FDI_PL_FLIT_CANCEL signals to determine the validity of incoming chunks, and unpacking messages in accordance with the AOU specification. Within RX_CORE, there is a submodule called RX_FDI_IF, which is designed to handle flit cancel as defined in the UCIe specification. This module forwards only valid chunks to the Chunk Decoder.

To ensure that the local die can support AXI transfers regardless of the AXI data width of the remote die, AOU_RX_CORE integrates both Downsizer and Upsizer modules internally.

AOU_RX_CORE includes a splitter that can divide burst lengths so that AXI messages with any burst length from the remote die can be supported on the local bus. The AW, W, and AR messages received from the remote die are sent to the AXI Manager interface, while the B and R messages received from the remote die are directed to the AXI Subordinate

interface. The R data may be smaller than the local die AXI data width depending on the ARSIZE of the corresponding AR requests, but R 4M1S FIFO duplicate values so that it is delivered to the AXI Subordinate interface with the same width as the local die AXI data width. Furthermore, the B responses corresponding to the AW and W AXI transfers issued through the Manager interface are routed into the AXI_3X1_MUX before being sent to the AOU_TX_CORE.

As illustrated in the figure above, the granularity of data transmitted from the FIFO, whether directed to the bus or to the AXI_3X1_MUX, is conveyed to the AOU_CRD_CTRL.




Figure 116. Architecture of Chunk Decoder

Figure 116 shows the architecture of the Chunk Decoder which is central submodule of RX_CORE. It consists of shift

registers and multiple decoders that decode each message, based on the received valid chunk along with its associated msg_idx and msg_valid information. Since AXI messages differ in the number of granules, the time required for decoding also varies.

For example, a B message has a size of 1 granule and can therefore be decoded immediately once a valid chunk is received from RX_FDI_IF. In contrast, Rdata or Wdata, which have a data width of 1024 bits, require 27-30 granules, and thus cannot be decoded immediately. Instead, they are decoded after approximately three cycles. Because messages of 27-30 granules may span up to four flits during transmission.

2.3.2.4. Message FIFO

Figure 117 shows the data FIFO organization.




Figure 117. Data FIFO

Figure 118 shows the request and response FIFO organization.




Figure 118. Req / Resp FIFO

The Turn-Around-Time(TAT) of AOU_CORE, including the D2D adaptor, is approximately 40 ns (equivalent to 40 cycles at 1 GHz). Therefore, the depth of the AW, AR, and B FIFOs is set to 44 regarding the margin.

The width of the Req and Resp FIFOs is equal to the length of the corresponding message. Since 12 granules are currently being decoded at once, up to 4 AW/AR requests and up to 12 B responses can be written into the FIFO in a single cycle. Therefore, the AW/AR FIFO is implemented as a 4S1M FIFO and B FIFO is implemented as a 12S1M FIFO.

In contrast, for the Wdata and Rdata FIFOs, the FIFO width and depth is defined differently.

The width of a data message varies depending on the bus data width. Therefore, the width of the Data FIFO corresponds to the message width in the case of the minimum bus data width.

For example, the width of the RDATA FIFO is 279 bits, which consists of 256 bits for the minimum bus data width, 10 bits for RID, 2 bits for RRESP, 1 bit for RLAST, and additional sdlen 2 bits to identify message width.

In aspect of WDATA FIFO, the width is 290bit. It contains 256 bits for the minimum bus data widths, 32bits for the minimum strb data widths, and additional sdlen 2bits to identify message width.

If the data received from the remote die has sdlen of 0(256bit data), the message will be stored in a single entry of the DATA FIFO. If the data received from the remote die has sdlen of 1(512bit data), the message will be stored across two entries of the Data FIFO. Similarly, if the data received from the remote die has sdlen of 2(1024bit), the message will be stored across four entries of the Data FIFO.

In addition, the depth of the Data FIFO is not 44. The depth has been determined under the assumption that the current bus data width is 512 bits. When the bus data width is 512 bits, a W message occupies 15 granules. Since the decoder in RX_CORE can decode 12 granules per cycle, the maximum W message can reach the FIFO once every 1.25 cycles (15G ÷ 12G/cycle = 1.25 cycles). Furthermore, as mentioned above, when the bus data width is 512 bits, each message is stored across two FIFO entries. Therefore, if the maximum turnaround time (TAT) to be covered is 50 ns (50 cycles), the depth can be set to 80 (50 / 1.25 x 2 = 80). Regarding the margin, Data FIFO's depth is set to 88.

When FDI_CONFIG selects a 1024b (128B) FDI interface (FDI_CFG_SP_128B or FDI_CFG_TP_64B_128B), the per-chunk granule rate roughly doubles, so the per-RP RP*_RX_W_FIFO_DEPTH / RP*_RX_R_FIFO_DEPTH parameter defaults are bumped to 140 entries to keep the same effective TAT margin. See the Integrator Guide for the parameter defaults.

FIFOs are allocated for each RP, and the depth of the FIFOs for each RP is configurable.

2.3.2.5. Data width converter

2.3.2.5.1. Overview




Figure 119. AXI4MUX_3X1_TOP

According to the AoU specification, even if the data width differs between chips, they must be able to transmit AXI transfers to each other. Because the remote die may issue read or write transactions with data widths of 256, 512, or 1024 bits, the local die is responsible for converting the data to align with its own bus data width. The response must then be reformatted to match the original request size before being returned.

Within AOU_CORE_TOP, the AOU_AXI4MUX_3X1_TOP module performs this function. Figure 119 shows how the structure of the Bypass, AXI Downsizer, and AXI Upsizer varies depending on the AXI data width of the local die.

2.3.2.5.2. Width Adaptation Paths

Three slave channel slots correspond to three possible remote data widths: 256 bits, 512 bits, and 1024 bits. Which slot uses an upsizer, bypass, or downsizer depends on the local die's AXI_DATA_WD parameter. A dedicated variant of the width-adapter module is instantiated for each supported local width:

Table 2530 identifies the width-adapter variant and conversion path for each local and remote data width.

Table 2530. AoU width-adaptation paths

Local AXI_DATA_WD	Variant instantiated	CH0 (256b remote)	CH1 (512b remote)	CH2 (1024b remote)
256	AOU_AXI4MUX_3X1_256	Bypass	Downsizer	Downsizer
512	AOU_AXI4MUX_3X1_512	Upsizer	Bypass	Downsizer
1024	AOU_AXI4MUX_3X1_1024	Upsizer	Upsizer	Bypass

Write path routing: The DLEN field embedded in the Write Data message indicates the original data width.

AOU_AXI4MUX_3X1_TOP uses this field to steer write data and strobes to the correct channel slot (and therefore through the correct width adapter).

Read path routing: The ARSIZE field of the Read Request message determines which channel slot handles the read response. The 3:1 mux selects the active slave R channel based on a 2-bit selector derived from ARSIZE.

The upsizer (AOU_AXI_UP) packs multiple narrow beats into a single wider beat, recalculating AWLEN/ARLEN accordingly. The downsizer (AOU_AXI_DOWN) splits a single wide beat into multiple narrower beats. Both modules regenerate WLAST internally using a beat counter that compares the current W beat count against the recalculated burst length.

2.3.2.5.3. WLAST Regeneration

The AoU Write Data message does not carry a WLAST signal. The AOU_AXI_WLAST_GEN module regenerates WLAST by aligning the phases of WriteReq and Write Data messages. It operates upstream of the width adapters in the RX-to-AXI path within AOU_CORE_RP.

The module uses I_S_WDLENGTH (derived from the DLEN field) to determine the number of W beats expected for each AW transaction:

- When AWLEN == 0 (single-beat burst), WLAST is asserted immediately on the first AW/W handshake.
- For multi-beat bursts, WLAST is asserted when the internal remaining beat counter r_m_awch_remain_beat reaches 1.

In addition to AOU_AXI_WLAST_GEN, the upsizer and downsizer modules (AOU_AXI_UP and AOU_AXI_DOWN) each contain their own WLAST generation logic to account for the changed burst length after width conversion.

2.3.2.6. AXI Transaction Splitter

2.3.2.6.1. Overview

In the AoU specification, the AXI LEN field is fixed at 8 bits, allowing the remote die to issue burst transactions up to the maximum supported by an 8-bit AXI LEN. However, because the local die's bus may not support the full 8-bit burst length, inbound AXI transactions must be split into bursts that the local bus can handle and then reassembled to match the original request.

Even if the burst length increases as a result of data-width conversion, the AXI transactions are always split to ensure they do not exceed the maximum burst length supported by the local bus.

The splitter (AOU_AXI_SPLIT_TR) sits between the 3:1 arbitration mux and the AXI Aggregator inside AOU_AXI4MUX_3X1_TOP. One instance exists per RP, and the maximum burst length can be configured independently for each RP through the AOU_SPLIT_TR_RPn SFRs.

> **Note:** The AOU_CON0.AXI_SPLIT_TR_EN field exists in the SFR but is currently tied to 1'b0 in AOU_CORE_RP, making the splitter always active. The enable bit is reserved for future use.

2.3.2.6.2. Burst Splitting

The splitter uses internal address-generator submodules (aou_axi_split_addrgen_ar for reads, aou_axi_split_addrgen_aw for writes) to decompose a single long burst into multiple sub-bursts, each no longer than MAX_AxBURSTLEN + 1 beats.

Addresses for each sub-burst are computed from the original base address, burst type, and size.

The MAX_AxBURSTLEN value must be of the form 2^n - 1. Legal values are:

Table 2531 lists the supported maximum burst-length settings and resulting beat counts.

Table 2531. AoU burst-splitting limits

MAX_AxBURSTLEN	Max beats per sub-burst
0	1
1	2
3	4
7	8
15	16
31	32
63	64
127	128
255	256 (no split)

ID width: The splitter reserves 2 bits from the AXI ID for internal sub-burst tracking. Master-side IDs are therefore ID_WD - 2 bits wide. The 2 extra bits allow the splitter to correlate responses from up to 4 outstanding sub-bursts per original transaction.

2.3.2.6.3. Response Reassembly

Read path: The aou_split_tr_arch reorder buffer tracks the sub-burst sequence for each outstanding read. Slave-side RLAST is asserted only when the final beat of the last sub-burst is received, reconstructing the original burst boundary. Intermediate RLAST signals from the master side are consumed internally.

Write path: B responses from sub-bursts are merged. The splitter tracks outstanding write sub-bursts with r_wr_pending_cnt and returns a single B response to the slave side once all sub-bursts have completed. If any sub-burst returns an error (|I_M_BRESP_RS), the merged BRESP_ERR flag is set, propagating the error to the slave-side response.

ID mismatch detection: The splitter exports DEST_TABLE_RID_ERR and DEST_TABLE_BID_ERR signals that flag responses with IDs not matching any outstanding transaction. These feed the INT_MI0_ID_MISMATCH interrupt source via AOU_AXI4MUX_3X1_TOP.

2.3.2.6.4. SFR Configuration

Table 2532 identifies the SFR fields associated with burst splitting.

Table 2532. AoU burst-splitter SFR controls

SFR	Field	Description
AOU_CON0	AXI_SPLIT_TR_EN	Global enable (reserved, tied inactive in current RTL)
AOU_SPLIT_TR_RP0	MAX_AWBURSTLEN	Max write burst length for RP0 (must be 2^n - 1)
AOU_SPLIT_TR_RP0	MAX_ARBURSTLEN	Max read burst length for RP0 (must be 2^n - 1)
AOU_SPLIT_TR_RP1	MAX_AWBURSTLEN / MAX_ARBURSTLEN	Same for RP1
AOU_SPLIT_TR_RP2	MAX_AWBURSTLEN / MAX_ARBURSTLEN	Same for RP2

SFR	Field	Description
AOU_SPLIT_TR_RP3	MAX_AWBURSTLEN / MAX_ARBURSTLEN	Same for RP3

These SFRs must be configured before activation and must not be changed during normal operation.

2.3.2.7. Write Early Response Controller

2.3.2.7.1. Overview

The AOU_EARLY_BRESP_CTRL_AWCACHE module sits between the local AXI subordinate interface and the AOU TX datapath. One instance exists per RP and can be independently enabled or disabled via the per-RP WRITE_EARLY_RESPONSE_RPn.EARLY_BRESP_EN SFR.

When enabled, the module returns an early B response (BRESP = OKAY) to the local AXI manager as soon as both the write address (AW) and the last write data beat (W with WLAST) have been received at the AXI subordinate port -- before the write is packed into AoU messages, transmitted over FDI, and completed on the remote die. This reduces the write latency seen by the local requester at the cost of deferred error reporting.

Early response applies only to **bufferable** writes (AWCACHE[0] = 1). Non-bufferable writes (AWCACHE[0] = 0) pass through the module unchanged: the AW, W, and B channels are forwarded directly between the local AXI interface and the AOU TX datapath with no early response generated, and the actual BRESP from the remote die is returned to the local AXI manager as normal.

2.3.2.7.2. Transaction Flow -- Normal Case

Figure 120 shows the message flow for a bufferable write when the remote die returns a successful response.




Figure 120. AoU successful early write response

When the actual B response arrives from the remote die for a transaction that already received an early response, the controller consumes it internally: O_AXI_S_BVALID is held low (the local AXI manager sees no second response) while

O_AXI_M_BREADY is asserted high (the response is drained from the AOU RX path).

2.3.2.7.3. Transaction Flow -- Error Case

If the actual B response from the remote die carries an error (BRESP[1] = 1, indicating SLVERR or DECERR), the error cannot be reported via the AXI B channel because the early OKAY response was already returned to the local AXI manager. Instead, the error is reported via interrupt and SFR capture.

Figure 121 shows how a remote write error is consumed after the local manager has received an early response.




Figure 121. AoU error after an early write response

The interrupt fires when the consumed response has BRESP[1] = 1. SW must:

1. Read WRITE_EARLY_RESPONSE_RPn.WRITE_RESP_ERR_ID_INFO to identify the failing transaction's AXI ID.
2. Read WRITE_EARLY_RESPONSE_RPn.WRITE_RESP_ERR_TYPE_INFO to identify the error type (SLVERR or DECERR).
3. Write 1 to WRITE_EARLY_RESPONSE_RPn.WRITE_RESP_ERR (W1C) to clear the interrupt.

2.3.2.7.4. ID Ordering

The AOU_EARLY_TABLE inside the controller maintains a tracking table with WR_MO_CNT entries (matching the subordinate write outstanding count). Each entry records:

Table 2533 defines the fields tracked for each outstanding write.

Table 2533. AoU early-response tracking fields

Field	Purpose
id	AXI write ID (AWID)
bufferable	AWCACHE[0] flag
pending	Transaction is in flight (AW accepted, B not yet received from remote)

Field	Purpose
same_id_tr_cnt	Count of older pending transactions with the same AXI ID that have not yet been early-responded or actually responded
early_go	Set when same_id_tr_cnt reaches 0, indicating this entry is eligible for early response
wid_numbering	Per-ID sequence number for matching B responses to the correct table entry

The early_go flag ensures that for transactions sharing the same AXI ID, early responses are issued strictly in order. A later bufferable transaction with the same ID waits until all prior same-ID transactions have been responded to (either via early response or actual remote BRESP). This preserves AXI ID ordering even when bufferable and non-bufferable writes with the same ID are interleaved.

2.3.2.7.5. Write-Outstanding Queue Backpressure

The backpressure mechanism described in this section is only active when the early response feature is enabled (EARLY_BRESP_EN = 1). When disabled, the module is a transparent pass-through: all AW, W, and B signals are wired directly between the subordinate and manager interfaces with no outstanding-count gating, and write depth is bounded only by whatever the downstream AOU TX datapath can accept.

When enabled, the early table has WR_MO_CNT entries (default 32, set by the S_WR_MO_CNT parameter). Every write that enters the controller -- bufferable or non-bufferable -- occupies one table entry from the time WLAST is accepted until the **actual B response** arrives from the remote die and is consumed.

Issuing an early B does **not** free the table entry. The entry remains occupied (pending = 1, out = 1) until the real remote B is received. The table depth therefore limits the total number of writes in flight across the FDI link, not just the number awaiting early response.

When r_aw_cnt == WR_MO_CNT, AWREADY and WREADY are deasserted toward the local AXI manager, stalling both the AW and W channels. The AOU TX datapath and FDI link continue operating normally during this time -- only new write acceptance is blocked. As actual B responses arrive from the remote die and table entries are freed, AWREADY and WREADY reassert and the manager may resume issuing writes.

The O_PENDING_CNT_OVER signal (exposed via the interrupt controller) fires if a write handshake is attempted while the counter is already at the limit, serving as a diagnostic for system-hang detection.

Figure 122 shows the write queue filling, stalling, and draining as tracking entries become available.




Figure 122. AoU write-outstanding backpressure

2.3.2.7.6. Mixed Ordering -- Bufferable Before Non-Bufferable (Same ID)

When a bufferable write (TXN0) is followed by a non-bufferable write (TXN1) on the same AWID, the controller handles them as follows:

1. TXN0 enters the table with same_id_tr_cnt = 0 and early_go = 1. Its early B is eligible immediately and is returned to the manager.
2. After TXN0's early B is issued, out is set to 1. TXN1 enters the table with bufferable = 0. The same_id_tr_cnt

computation excludes entries with out = 1, so TXN1 sees same_id_tr_cnt = 0.

3. TXN1 is non-bufferable, so no early B is generated for it regardless of early_go. It waits for the actual remote B.
4. The wid_numbering field ensures actual B responses are matched in issue order: TXN0 has wid_numbering = 0, TXN1 has wid_numbering = 1.
5. When TXN0's actual B arrives, O_EarlyResponse_Consume = 1 (bufferable entry at the read pointer), so the response is consumed silently. TXN1's wid_numbering decrements to 0.
6. When TXN1's actual B arrives, O_EarlyResponse_Consume = 0 (non-bufferable), so the response is forwarded to the subordinate as a normal BVALID.

The local AXI manager sees: early B for TXN0 first, then actual B for TXN1 -- correct AXI ID ordering is preserved.

Figure 123 shows response ordering when a bufferable write precedes a non-bufferable write on the same AXI ID.




Figure 123. AoU bufferable then non-bufferable writes

2.3.2.7.7. Mixed Ordering -- Non-Bufferable Before Bufferable (Same ID)

When a non-bufferable write (TXN0) is followed by a bufferable write (TXN1) on the same AWID, the early response for TXN1 is **delayed** until TXN0's actual B has been received.

1. TXN0 enters the table with bufferable = 0, out = 0. No early B is generated (not bufferable).
2. TXN1 enters the table with bufferable = 1. Because TXN0 is still pending and ~out, TXN1 sees same_id_tr_cnt = 1 and early_go = 0. The early B for TXN1 is **blocked**.
3. When TXN0's actual B arrives from the remote die, it is forwarded to the subordinate (non-bufferable pass-through, O_EarlyResponse_Consume = 0). The table update loop decrements TXN1's same_id_tr_cnt from 1 to 0, setting early_go = 1.
4. On the following cycle, TXN1's early B becomes eligible and is issued to the manager.

This is the key latency impact of mixed-cacheability ordering: the bufferable write's early response is delayed until the preceding non-bufferable same-ID write fully completes its round trip through the remote die. The early-response latency benefit is lost for that transaction. Software or interconnect designers should be aware that interleaving non-bufferable writes ahead of bufferable writes on the same ID negates the early-response advantage for those bufferable transactions.

Figure 124 shows response ordering when a non-bufferable write precedes a bufferable write on the same AXI ID.




Figure 124. AoU non-bufferable then bufferable writes

2.3.2.7.8. Enable/Disable Procedure

The EARLY_BRESP_EN SFR may be written at any time, but the internal enable (r_early_bresp_en) only transitions when it is safe to do so:

1. Confirm WRITE_EARLY_RESPONSE_RPn.WRITE_RESP_DONE = 1 (no pending write transactions; r_aw_cnt == 0).
2. Set or clear EARLY_BRESP_EN via APB write.
3. The internal register transitions on the next clock edge where O_BRESP_DONE is asserted and no AW handshake is in progress. This guarantees that the mode change does not occur mid-transaction.

2.3.2.7.9. SFR Fields

The WRITE_EARLY_RESPONSE_RPn register (one per RP: RP0 at 0x0028, RP1 at 0x0040, RP2 at 0x0058, RP3 at 0x0070)

contains:

Table 2534 defines the per-resource-plane early-response controls.

Table 2534. AoU early-response SFR fields

Field	Bits	Access	Description
EARLY_BRESP_EN	[0]	RW	Enable early B response for bufferable writes on this RP.
WRITE_RESP_ERR_ID_INFO	[10:1]	RO	AXI ID of the transaction whose actual BRESP had an error.
WRITE_RESP_ERR_TYPE_INFO	[12:11]	RO	BRESP error type (2'b10 = SLVERR, 2'b11 = DECERR).
WRITE_RESP_ERR	[13]	W1C	Write 1 to clear the INT_EARLY_RESP_ERR interrupt.
WRITE_RESP_DONE	[14]	RO	1 when no write transactions are pending (r_aw_cnt == 0).

See the full register map for the complete SFR listing.

2.3.2.8. AXI Aggregator

2.3.2.8.1. Overview

The AXI Aggregator (AOU_AGGREGATOR) combines narrow read and write data into full-width bus beats to improve bus utilization. It sits downstream of the AXI Transaction Splitter and is the last processing stage before the AXI manager port inside AOU_AXI4MUX_3X1_TOP. One instance exists per RP.

When enabled, the aggregator promotes AWSIZE/ARSIZE to the full bus width and recalculates AWLEN/ARLEN accordingly. For example, an incoming AR with size 256 bits and burst length 16 is converted to size 1024 bits and burst length 4, then issued on the AXI manager interface. When R data returns, it is split to restore the original format. The same principle applies to writes.

When disabled via the per-RP AOU_CON0.RPn_AXI_AGGREGATOR_EN SFR, all master-side signals bypass the aggregator entirely and flow directly to the AXI manager port without modification.

2.3.2.8.2. Write Aggregation

Write aggregation is activated when **both** conditions are met:

1. AWSIZE is narrower than the full bus width (AXSIZE < $clog2(DATA_WD/8)).
2. AWLEN is non-zero (multi-beat burst).

When activated, the aggregator:

- Promotes AWSIZE to the full bus width.
- Recalculates AWLEN based on the ratio between original and promoted sizes.
- OR-merges WDATA and WSTRB across consecutive narrow beats until a full-width beat is assembled, then emits the merged beat on the master W channel.
- AWBURST is passed through unchanged.

A depth-16 synchronous FIFO decouples the AW and W channels. The AW is issued on the master side only after confirming that sufficient W FIFO space is available for the recalculated AWLEN, preventing deadlocks when the downstream bus back-pressures the W channel.

Figure 125 shows narrow write beats merging into a wider downstream transfer.




Figure 125. Write Aggregation -- Narrow-to-Wide Beat Merging

2.3.2.8.3. Read Aggregation

Read aggregation follows the same size-promotion logic as writes. ARSIZE and ARLEN are promoted to the full bus width, and ARBURST is passed through (the aggregator does not restrict burst type to INCR).

The AOU_AGGREGATOR_INFO submodule tracks outstanding AR transactions. For each issued AR, it records the original burst geometry (size, length) so that when wide R data returns from the manager side, the module can regenerate the correct slave-side RLAST at the original burst boundaries. Wide R beats are presented to the slave side multiple times (once per original narrow beat) with the appropriate byte-lane selection.

2.3.2.8.4. SFR Fields

Table 2535 identifies the resource-plane aggregation enables.

Table 2535. AoU aggregation SFR fields

SFR	Field	Bits	Description
AOU_CON0	RP0_AXI_AGGREGATOR_EN	[20]	Enable aggregator for RP0
AOU_CON0	RP1_AXI_AGGREGATOR_EN	[21]	Enable aggregator for RP1
AOU_CON0	RP2_AXI_AGGREGATOR_EN	[22]	Enable aggregator for RP2
AOU_CON0	RP3_AXI_AGGREGATOR_EN	[23]	Enable aggregator for RP3

These fields must be configured before activation and must not be changed during normal operation.

2.3.2.9. Credit Controller




Figure 126. Block Diagram of AOU_CRD_CTRL

Figure 126 shows the simplified block diagram of AOU_CRD_CTRL. The Credit Controller manages both the credits granted to the remote die and the credits received from the remote die. It considers the credit consumed when the TX CORE packs an AXI message into the ring buffer, and considers the credit returned when an AXI message is popped from the RX CORE FIFO. The credit controller always grants the maximum credits available and uses only one of the two

methods - either the Misc Credit Grant messages or the Message Credit field - to grant credits.**

Rx Credit**

The local die is responsible for tracking the credits advertised to the remote die and issuing new credits once they are returned. Rx Credit accounts for both advertised and returned credits and is managed by the AOU_RX_CRD_CTRL module inside AOU_CRD_CTRL.

More specifically, Rx Credit refers to the credit provided by the local die to the remote die. The remote die uses this credit to transmit messages, which are then received and unpacked by the local Rx Core. Because the processing and unpacking occur within the Rx Core, this credit is defined as Rx Credit. The maximum available Rx Credit is determined by the depth of the Rx FIFO.

To ensure that no data is lost under flow control, credits shall not be granted when sufficient buffer space is unavailable. Therefore, the amount of credit advertised shall be determined conservatively by considering the worst-case condition. Here, the worst case is defined as the condition in which the smallest amount of credit can be advertised. Consequently, the maximum available is specified as the minimum value among all possible cases when credits are fully advertised:

```
MAX AVAILABLE CREDIT = min(max advertised credit case1, max advertised credit case2, ...,
max advertised credit caseN)
```

Assuming all PROFEXTLEN values are set to 0, the maximum advertised credit is calculated as follows: **For WREQ, RREQ, WRESPCRED**, each FIFO entry is considered to be allocated according to the granule size of each message.

```
RX AW MAX CREDIT = RX AW FIFO DEPTH x WriteReq Granules
RX AR MAX CREDIT = RX AR FIFO DEPTH x ReadReq Granules
RX B  MAX CREDIT = RX B  FIFO DEPTH x WriteResp Granules
```

In the case of WDATA, data widths of 256, 512 or 1024 may be received. Separate FIFOs are provided for data and for strobe, each with the same FIFO depth. Each FIFO entry is 256 bits wide for DATA and 32 bits wide for STRB, ensuring efficient utilization of the FIFO. Accordingly, 512-bit width data occupies two entries, while 1024-bit width data occupies four entries. As illustrated in Figure 126, for non-Writefull message types, WDATA is stored in the DATA FIFO and WSTRB is stored in the STRB FIFO.

Figure 127 illustrates the separate storage of write data and write strobes.




Figure 127. Example of WDATA and WSTRB FIFO Operation

```
Occupying Data entry per message = WDATA Width / DATA FIFO Width
```

Table 2536. WriteData Credit Calculation

WDATA width	Granule size per message	Occupying Data entry per message	Granules per Data FIFO entry	Granules per Strb FIFO entry	Granules per FIFO entry
256b	8	1	8	-	8
512b	15	2	7.5	-	7.5
1024b	30	4	7.5	-	7.5

Table 2537. WriteDataFull Credit Calculation

WDATA width	Granule size per message	Occupying Data entry per message	Granules per Data FIFO entry	Granules per Strb FIFO entry	Granules per FIFO entry
256b	7	1	7	-	7
512b	14	2	7	-	7
1024b	27	4	6.75	-	6.75

Table 2536 and Table 2537 illustrates all possible writedata, writedatafull message types and the credit calculation when

messages consist solely of one type. The minimum advertised credit occurs when only 1024bit writedatafull messages are received. According the maximum available credit for WDATA is defined as follows:

```
RX W MAX CREDIT = (RX W FIFO DEPTH / 4) x WriteData Full1024bit Granules
```

In the case of RDATA, Receiving RDATA from the remote die implies that the local die has already issued a ReadReq message. The ARSIZE used when sending is determined by the AXI_DATA_WD of the local die. For example, if AXI_DATA_WD is 512, the AR will request RDATA of 512 bits or less, and the received RDATA will therefore be 512 or 256 bits wide.

Figure 128 illustrates read-data storage at different AXI data widths.




Figure 128. Example of RDATA FIFO Operation

Table 2538 relates read-data width to FIFO occupancy and granule credits.

Table 2538. ReadData Credit Calculation

RDATA Width	Granule size	Occupying entry (RDATA width / FIFO width)	Granules per FIFO entry (Granule size / Occupying entry)
256	8	1	8
512	14	2	7
1024	27	4	6.75

Similarly, for RDATA, credits must be advertised conservatively by considering the maximum data width associated with AXI_DATA_WD. As AXI_DATA_WD increases, the maximum credit that can be advertised decreases. Therefore, credit shall always be calculated based on AXI_DATA_WD. For example, if AXI_DATA_WD is 512, the possible RDATA widths are 256, 512, and credit must be determined under the conservative assumption that all RDATA widths are 512bits. Likewise, if AXI_DATA_WD is 1024, the possible RDATA widths are 256, 512, and 1024, and credits must be determined under the conservative assumption that all RDATA are 1024bits.

```
RX R MAX CREDIT = {RX R FIFO DEPTH / (AXI_DATA_WD / 256)} x AXI_DATA_WD RDATA Granule
Size
```

Tx Max Credit

- Tx Credit refers to the credit that the local die receives from the remote die. Based on this credit, the Tx Core is permitted to pack messages into flits and transmit them. For this reason, the term is defined as Tx Credit.
- Tx Credit is managed by the AOU_TX_CRD_CTRL in AOU_CRD_CTRL, which is responsible for counting the credits received from the remote die and tracking the credits consumed during message packing.
- It is recommended that Tx Max Credit parameter be set to the maximum credit value that the remote die is capable of granting.
    - If Tx Max Credit is configured to a value lower than the maximum credit issued by the remote die, credit accounting shall be limited to the Tx Max Credit value. In this case, flow control operates strictly within the range defined by Tx Max Credit, regardless of the remote die's capability.
    - If Tx Max Credit is configured to a value greater than or equal to the maximum grantable credit of the remote die, the local die can fully utilize all credits actually granted by the remote die.
    - This behavior implies that the Tx Max Credit setting is not dependent on the remote die's internal configuration. The local die shall simply make use of the credits that are actually granted to it.

Credit Advertisement Mechanism

Upon receipt of an ActivateReq from the remote die, AOU_CORE_TOP responds with an ActivateAck and, at the same time, advertises credit through a Misc CreditGrant Message. Only the initial credit advertisement is performed through this Misc message. Because only a single Resource Plane is implemented, after the initial advertisement, subsequent credit advertisements are carried by the Message Credit field within the protocol header. In multiple-RP configuration, credit advertisement is likewise delivered exclusively through the Message Credit field within the protocol header. Credits for multiple RPs are advertised in a round-robin manner. A grant is issued only when at least one of the credit fields - wreq, wdata, rreq, rdata, or wresp - contains a non-zero value to be advertised.

Definition of Tx Credit Consumption and Rx Credit Advertisement/Return Timing

- The Tx Credit is increased immediately upon receipt of a credit message from the Rx Core, within the updated value taking effect in the following cycle. Credit is decremented when the Tx Core packs a message and places it into the ring buffer. The consumption point is defined at the time of insertion into the per-RP Tx FIFO.
- The AOU_RX_CRD_CTRL exchanges credit messages (PLP protocol header MsgCredit field, dedicated Misc message) with the Tx core through valid/ready signaling. Tx core asserts CRDTGRANT_READY when the Tx core can pack a Misc Credit Message or asserts MSGCREDIT_CRED_READY when a protocol header is required to be transmitted. A credit is considered advertised at the point when the credit message handshake (valid and ready both asserted) occurs. At that instant, the advertised credits are treated as already reserved for the RX FIFO. Accordingly, a credit is not considered returned when a message leaves the RX Core, but only when data is actually dequeued from the RX FIFO, releasing the previously reserved credit.

2.3.2.10. RP Remapping

2.3.2.10.1. Configuration Rules

The Resource Plane (RP) operates based on the smaller RP count between the local and remote dies and follows a strict one-to-one mapping. RP assignments are configured through the **DEST_RP** SFR. The values of RP3_DEST, RP2_DEST, RP1_DEST, and RP0_DEST must be unique, and for any RP that is utilized, the configuration on the local and remote dies must be symmetrical.

This configuration must remain static and must be programmed before activation. It must not be altered during normal operation.

When the local and remote dies have different RP_COUNT values, the effective RP count is the smaller of the two.

Unused RP slots in the DEST_RP register are functionally don't-care but should be set to non-overlapping values for clean credit routing (see AOU Misconfiguration Behaviour).

Figure 129 shows how resource-plane identifiers are remapped across the link.




Figure 129. Resource Plane Remapping

2.3.2.10.2. Header Encoding

For AXI messages (WriteReq, WriteData, ReadReq), the TX path (AOU_TX_AXI_BUFFER) embeds the DEST_RP field from the SFR into the destination RP field of every outgoing message header. The remote die uses this field to route the received message to the correct RP for processing.

For credit grant messages, AOU_TX_CRD_CTRL encodes the *local* RP index (not the DEST_RP value) so that the remote die can route returned credits to the correct local RP's credit counter. This asymmetry -- destination RP in data messages, source RP in credit messages -- is fundamental to the RP remapping scheme.

2.3.2.10.3. Misconfiguration Behavior

No hardware duplicate-detection logic exists for the DEST_RP register. If DEST_RP values are configured with overlapping (duplicate) entries, the credit routing logic in AOU_TX_CRD_CTRL -- which uses a unique case statement on I_RP_DEST_RP[i] -- will fall through to the default case, mapping to the RP0 credit view. This results in silent credit accounting errors rather than a flagged interrupt or error condition.

Software is responsible for ensuring uniqueness and symmetry of the DEST_RP configuration on both link partners before initiating activation.

2.3.2.11. UCIe Flit cancel mechanism

AOU_CORE supports all UCIe flit cancel mechanisms. The three cases -- retransmit, flit partially valid, and full flit cancel -- are handled by the AOU_RX_FDI_IF submodule within RX_CORE.

Figure 130 illustrates the retransmit case of UCIe flit cancellation.

Figure 10-15. Example for pl_flit_cancel for Latency-Optimized Flits and CRC Error on First Flit Half



Figure 130. UCIe Flit Cancel - Retransmit case

Figure 131 illustrates the partially valid flit case.

Figure 10-16. Example for pl_flit_cancel for Latency-Optimized Flits and CRC Error on Second Flit Half




Figure 131. UCIe Flit Cancel - Flit Partially Valid case

Figure 132 illustrates the full flit-cancel case.

Figure 10-17. Example for pl_flit_cancel for Latency-Optimized Flits and CRC Error on Second Flit Half, Alternate Implementation Example



Figure 132. UCIe Flit Cancel - Full Flit Cancel case

2.3.2.11.1. Cancel Cases

The AOU_RX_FDI_IF module uses the FDI pl_valid and pl_flit_cancel signals to determine how to handle each incoming chunk. Three cases are distinguished:

Table 2539 maps the valid and cancel signals to the receive action.

Table 2539. AoU flit-cancel cases

pl_valid	pl_flit_cancel	Action
1	0	**Normal**: Phase counter increments. Chunk is stored in the staging buffer.
1	1	**Retransmit / Partial Valid**: Phase counter decrements by 1. The staging buffer is re-aligned with {zero_data, pl_data} and a valid pattern of {1'b0, 1'b1}, replacing the previously stored partial chunk with the corrected data.
0	1	**Full Flit Cancel**: Phase counter decrements by 2. Staging buffer entries are cleared. This is the strongest rollback, discarding the entire in-progress half-flit.

2.3.2.11.2. RX_FDI_IF Buffering

The AOU_RX_FDI_IF module maintains a staging buffer (r_data) that is HF_PHASE_CNT entries deep, where HF_PHASE_CNT = PHASE_CNT / 2. For the default 512-bit FDI data width, PHASE_CNT = 4 and HF_PHASE_CNT = 2, so the staging buffer holds 2 chunk entries -- one half-flit of data.

A parallel valid array (r_data_valid) tracks which staging buffer entries contain valid chunk data. The output to RX_CORE is gated:

```
rx_chunk_data_valid = r_data_valid[1] && !pl_flit_cancel
```

This ensures that chunk presentation is suppressed whenever pl_flit_cancel is asserted, even if valid data exists in the staging buffer. Downstream, AOU_RX_CORE advances its phase counter (r_aou_rx_phase) only when rx_chunk_data_valid is high, so cancel-suppressed cycles stall the RX phase progression without data loss.

2.3.2.11.3. Timing

Cancel handling is purely combinational on the same clock edge as the FDI input signals. No additional pipeline stages are introduced beyond the 2-entry staging buffer and the phase FSM. The latency from FDI input to valid chunk presentation at RX_CORE is therefore determined solely by the half-flit fill time under normal operation.

> **Note:** The flit_packing_state counter (a TX-side concept in AOU_TX_CORE) is unrelated to RX cancel handling. RX cancel operates entirely within AOU_RX_FDI_IF using the phase counter r_phase.

The figures below illustrate an example of how only valid chunk data is delivered to RX_CORE. Within the design, pl_data, pl_valid, and pl_flit_cancel are defined as part of the FDI interface. In contrast, rx_chunk_data and rx_chunk_data_valid represent the signals responsible for delivering valid chunks to RX_CORE.

Figure 133 shows the selection of valid chunks for RX_CORE.




Figure 133. Example of selecting valid chunks for RX_CORE

2.3.3. Interrupts and Errors

2.3.3.1. Interrupt

Table 2540 lists the interrupt names, access behavior, and triggering conditions.

Table 2540. Interrupt Sources

Interrupt Name	Access	Description
INT_ACTIVATE_START	W1C	Asserted when activation of the AoU Protocol layer is required.
INT_DEACTIVATE_START	W1C	Asserted when deactivation of the AOU Protocol layer is required.
INT_SI0_ID_MISMATCH	W1C	Asserted when AXI subordinate port received with an AXI ID response that does not match any transaction
INT_MI0_ID_MISMATCH	W1C	Asserted when AXI manager port received with an AXI ID response that does not match any transaction
INT_EARLY_RESP_ERR	W1C	Asserted when B response error occurs on early responded B response
INT_REQ_LINKRESET	W1C	Asserted when AOU_CORE encounters AOU SPEC protocol violation. Request link to go LinkReset.

- **INT_ACTIVATE_START**

An interrupt that occurs when activation of the AoU Protocol layer is required. The interrupt can be cleared by writing '1' to the AOU_CORE.AOU_INIT.INT_ACTIVATE_START SFR. For details, please refer to the Interrupt description in Activation & Deactivation Flow.

- **INT_DEACTIVATE_START**

An interrupt that occurs when deactivation of the AoU Protocol layer is required. The interrupt can be cleared by writing '1' to the AOU_CORE.AOU_INIT.INT_DEACTIVATE_START SFR. For details, please refer to the Interrupt description in Activation & Deactivation Flow.

- **INT_SI0_ID_MISMATCH**

An interrupt that occurs on the AXI Subordinate Interface when a B or R channel response is received with an ID that was not previously issued as a request. For details on ID mismatch detection, see Section 2.3.2.7.4.

Software can check the mismatched AXI ID by reading AOU_CORE.AXI_SLV_ID_MISMATCH_ERR SFR. The interrupt can be cleared by writing '1' to AOU_CORE.AXI_SLV_ID_MISMATCH_ERR.SLV_BRESP_ERR / SLV_RRESP_ERR.

- **INT_MI0_ID_MISMATCH**

An interrupt that occurs on the AXI Manager Interface when a B or R channel response is received with an ID that was not previously issued as a request. This is detected by the Section 2.3.2.6 destination table.

Software can check the mismatched AXI ID by reading AOU_CORE.ERROR_INFO SFR. The interrupt can be cleared by writing '1' to AOU_CORE.ERROR_INFO.SPLIT_BID_MISMATCH_ERR / SPLIT_RID_MISMATCH_ERR.

- **INT_EARLY_RESP_ERR**

An interrupt that occurs when, due to the Section 2.3.2.7 feature, a B response has already been sent through the AXI Subordinate Interface, and a subsequent actual B response arrives with an error. For details, see Section 2.3.2.7.3.

Software can check the ID and error type of the transaction in which the error occurred by reading AOU_CORE.WRITE_EARLY_RESPONSE SFR. The interrupt can be cleared by writing '1' to AOU_CORE.WRITE_EARLY_RESPONSE.WRITE_RESP_ERR.

- **INT_REQ_LINKRESET**

An interrupt that occurs when AOU_CORE receives an AoU protocol violation. Refer to LinkReset Error Reporting. When AOU_CORE receives a protocol violation, software must perform a software reset of AOU_CORE and re-enter the activation sequence.

2.3.3.2. Error

TBD

2.3.4. PPA and Appendices

2.3.4.1. PPA

2.3.4.1.1. Performance

Performance evaluation is conducted in both 512-bit local die and 512-bit remote die environments. The initial latency is measured from the AXI input of the local AOU_CORE to the AXI output of the remote AOU_CORE.

Table 2541 lists the measured latency of each AXI channel in a back-to-back connection.

Table 2541. AOU_CORE Initial Latency (Cycles)

AXI Channel	AoU Latency on B2B connection
Read Request (AR)	9
Read Data (R)	11
Write Request (AW)	12
Write Data (W)	12
Write Response (B)	10
Misc	9

The reason of two additional latency for AW and W CH is from WLAST signal generator, and data width converter.

Figure 134 shows the initial transfer latency when AOU_CORE is connected through UCIe.




Figure 134. Initial Latency of AOU_CORE with UCIe (Cycle)

Figure 135 shows how bandwidth efficiency varies with UCIe FDI latency.




Figure 135. AoU Bandwidth Efficiency with Respect to UCIe FDI Latency

The results of efficiency measurements for read and write operations with varying burst lengths are presented. For write operations, two cases were evaluated. Normal Write and Write Full, where no write strobe bits are transmitted. The measured values and the corresponding expected values are as follows.

Table 2542 compares measured and expected efficiency across burst lengths and write modes.

Table 2542. AOU_CORE Data Transfer Efficiency

Data transfer efficiency		Uni-direction transfer		Bi-direction transfer	
AXI burst length	Data type	Measured	AoU limit by spec	Measured	AoU limit by spec
16 burst	Read data	85.3%*	85.7%	85.3%	84.6%
	Write data	79.0%	79.0%	78.5%	78.7%
	WriteFull data**	84.2%	84.6%	84.2%	84.2%
1 Burst	Read data	85.3%	85.7%	71.9%	70.6%
	Write data	66.7%	66.7%	63.3%	63.1%
	WriteFull data	70.3%	70.6%	67.0%	66.7%

- 0.4% performance drop is not from IP, but just from transfer data size. If the transfer data size is the multiples of 6 burst such 132 beats, it shows the same performance number with the limit in AoU spec. Everything is the same case. Note that the efficiency is measured with 128/(cycle_from_1st_valid_to_last_valid + 1), where 1 is the hidden bubble right before the first valid. It is indispensable since AoU data message size can not covered in a single 64B chunk, unlike local AXI bus.

2.3.4.1.2. Power

TBD

2.3.4.1.3. Area

Figure 136 shows the area contribution of each submodule in a single-resource-plane AoU.




Figure 136. Area of 1 RP AOU

The area for each 1 RP AOU submodule is shown in the figure above.

Among them, the RX_W_FIFO and RX_R_FIFO, which store write data and read data respectively, occupy the largest portion of the AOU area. These FIFOs are currently implemented as register-based FIFOs.

FIFO Depths : TX = 2 entries / RX = 88 entries for R/W data, and 44 entries for AW/AR/B. The 88-entry default for R/W data applies when FDI_CONFIG selects a non-1024b interface; the 1024b configurations (FDI_CFG_SP_128B / FDI_CFG_TP_64B_128B) default to 140 entries, which proportionally increases the R/W FIFO area component. The Expected R/W data for 128GBs/s is 176 entries.

v0.4 AOU_CORE

With 2 RP, each AXI bandwidth is 512 bit and 256 bit, AOU_CORE area was 197k um^2.

The FIFO depth of the two RPs are identical.

Table 2543 compares the reported area across resource-plane configurations.

Table 2543. AOU_CORE Area (measured at an FDI_CFG_SP_64B-equivalent configuration; numbers will scale up for FDI_CFG_*_128B configurations due to the 88 -> 140 R/W FIFO depth bump.)

AoU Area (um^2)	64GB/s
1RP	(AXI : 512bit)
97K	2RP
(AXI : 256bit & 512bit)	197K

2.3.4.2. Appendix B. Referenced Documents

Table 2544 lists the documents cited by the imported AoU microarchitecture specification.

Table 2544. Referenced Documents

Document Name	Document Location and/or URL	Issuance Date
AXI-over-UCIe (AoU) Specification, Revision 0.7	https://openchipletatlas.org	2025

Register programming, activation and deactivation flows, and the debug features are in the AoU Programming Guide chapter of the Programmer's Guide.

For references from all TRM chapters, see Referenced Documents.

Chapter 3. IP Reference

This catalogue collects the reusable IP reference pages published in the TRM. The subsystem chapters describe how these blocks are integrated into OCAH.

3.1. Management and I/O

- AVSBus Controller
- AXI-Lite Mailbox Unit
- GPIO
- I2C
- I3C Controller
- Log Engine
- System Timer OCTS
- Telemetry Receiver
- UART 16550

3.2. Security

- Deterministic Random Bit Generator (DRBG)
- eFuse
- Entropy Source
- Key Manager
- Scrambler

3.3. Debug and cross-trigger

- JTAG Interface Unit
- JTAG PTAP
- JTAG STAP
- Cross-Trigger Network
- Cross-Trigger Port
- Cross-Trigger Matrix

3.4. Interconnect infrastructure

3.4.1. AXI Traffic Filter

The AXI traffic filter (`axi_filter_wrap`) is the common address and attribute filter used on the inbound and outbound

AXI paths of both SEP and SMC. This section describes the decode algorithm, which is identical in every instance; the subsystem chapters describe where each instance sits in their fabric and how firmware is expected to program it.

A filter holds a configurable number of independent entries. Each entry is one `filter_ctrl` register triple — `FILTER_CONFIG`, `START_ADDR`, `END_ADDR` — and every entry is evaluated against every transaction.

3.4.1.1. Instances

Table 2545 compares the filter dimensions, unmatched-traffic behavior, and bypass controls.

Table 2545. Traffic filter instances

Instance	Entries	Address	Data bus	Unmatched traffic	Bypass
SEP inbound	16	56-bit	64-bit	Blocked	While SEP-scope debug is enabled
SEP outbound	32	56-bit	64-bit	Blocked	None
SMC inbound	16	56-bit	64-bit	Blocked	None
SMC outbound	16	56-bit	64-bit	Permitted	None

NS and source ID matching are enabled on all four instances. Group ID matching is disabled at build time on all four, so the `group_id` field has no effect.

3.4.1.2. Match, Then Permit

Decode is two distinct steps, and the difference between them governs what happens when entries overlap.

First, every entry is evaluated in parallel to produce a **match**. An entry matches only when all of the following hold:

- `entry_enabled` is 1. A disabled entry never matches.
- The transaction address falls inside the entry's address range, after the granule widening described below.
- `prot[1]` equals `allow_ns`. This is an equality test, not a permission grant: an entry with `allow_ns = 0` matches secure transactions only, and an entry with `allow_ns = 1` matches non-secure transactions only.
- The transaction's source ID equals `src_id`, or `src_id` is 0, which is a wildcard matching any source ID.
- `allow_burst` is 1, or the transaction is a single beat (`AxLEN` = 0).

Second, the **lowest-numbered** matching entry wins, and only that entry's permission bit is consulted: `read_allowed` for AR, `write_allowed` for AW. If the bit is clear, the transaction is blocked. If no entry matches at all, the outcome is the instance's unmatched-traffic policy from the Table 2545.

The two steps therefore fail differently:

- A transaction that **fails a match condition** on an entry falls through to the remaining entries, and a higher-numbered entry can still admit it. A non-secure transaction, a burst, or a foreign source ID is not denied by an entry that rejects it; it simply does not select that entry.
- A transaction that **matches** the lowest-numbered entry but finds its permission bit clear is blocked outright. Higher-numbered entries are never examined, even if one of them would have permitted the access.

Entry index is thus a strict priority and the first match ends the search, so a specific policy takes effect only at a lower index than any broader policy that overlaps it.

Writes and reads are decoded independently: the AW channel and the AR channel each run the full decode against their own address, burst length, prot[1] and source ID, so a write and a read to the same address may select different entries.

3.4.1.3. Address Range Granule

Address comparison ignores the low address bits, so a filter range always covers a whole number of granules. allow_burst selects the granule:

- allow_burst = 1: the granule is 4 KB and address bits [11:0] are ignored.
- allow_burst = 0: the granule is the data bus width — 8 bytes on every instance in the Table 2545 — and address bits [2:0] are ignored.

START_ADDR consequently widens **down** to the base of its granule and END_ADDR widens **up** to the top of its granule, so a range is never narrower than one granule. Programming START_ADDR equal to END_ADDR, or any range shorter than the granule, still admits the whole granule, and a range that straddles a granule boundary admits both granules.

Table 2546 illustrates the address ranges admitted when burst filtering widens a programmed interval.

Table 2546. Granule widening examples

allow_burst	START_ADDR	END_ADDR	**Addresses admitted**
1	0x1001	0x1002	0x1000-0x1FFF, one 4 KB granule
1	0x0FFF	0x1000	0x0000-0x1FFF, two 4 KB granules
1	0x2000	0x2FFF	0x2000-0x2FFF, already granule-aligned
0	0x1001	0x1002	0x1000-0x1007, one 8-byte granule

Hardware writes the widened values back into START_ADDR and END_ADDR when both land in the same granule, so reading back the first example above returns 0x1000 and 0x1FFF. When the programmed range spans more than one granule the write-back does not fire and read-back returns the programmed values unchanged, even though address matching still widens them, so read-back is not the effective range.

Widening only ever enlarges a range, so a range programmed tighter than the granule opens more address space than the programmed numbers suggest. The Programmer's Guide gives the filter programming rules.

3.4.1.4. Blocked Transactions

A blocked transaction is not dropped. It is steered to an AXI error subordinate that terminates it with a DECERR response on BRESP or RRESP, so the initiator always receives a response.

3.4.1.5. Locking a Filter Entry

Setting FILTER_CONFIG.locked freezes a filter entry. The bit is write-once (woset): once set it cannot be cleared. While it is set, every write to that entry's FILTER_CONFIG, START_ADDR and END_ADDR registers is steered to the same AXI error subordinate as a blocked transaction and terminates with a DECERR response; reads still return the locked configuration. This holds for the SMC and SEP filter instances alike.

Appendix A: Register Field Access Notation

The register tables in this manual are generated from each block's SystemRDL description by the PeakRDL toolchain. Their **Access** column reports a field's software access together with any read or write side effect as one compact token, so a status bit that a write of 1 clears reads as `RW1C` rather than a bare `RW`. This appendix decodes that notation.

An Access cell is built in three parts:

1. a **base access** token, giving whether software can read the field, write it, or neither;
2. an optional **write side-effect suffix** joined directly to the base for an effect that an individual written bit triggers (`RW1C`, `W1S`, `RW0C`);
3. optional **space-separated flags** for whole-field write effects, read effects, and single-cycle pulses (`R RC`, `RW WS`, `W 1P`).

A field with no side effect keeps the bare base token. The same base tokens appear in the per-register summary tables, where they aggregate the access of the register's fields.

Table 2547. Register field access tokens

Token	Meaning	SystemRDL property
Base access		
`R`	Software can read the field.	`sw = r`
`W`	Software can write the field.	`sw = w`
`RW`	Software can read and write the field.	`sw = rw`
`-`	Reserved, or no software access.	`sw = na`, or a reserved gap
Write side-effect suffix — acts on the individual written bit		
`1C`	Writing 1 to a bit clears it; writing 0 leaves it.	`onwrite = woclr`
`1S`	Writing 1 to a bit sets it.	`onwrite = woset`
`1T`	Writing 1 to a bit toggles it.	`onwrite = wot`
`0C`	Writing 0 to a bit clears it.	`onwrite = wzc`
`0S`	Writing 0 to a bit sets it.	`onwrite = wzs`
`0T`	Writing 0 to a bit toggles it.	`onwrite = wzt`
Write flags — act on any write to the field		
`WC`	Any write clears the whole field.	`onwrite = wclr`
`WS`	Any write sets the whole field.	`onwrite = wset`
`WMOD`	A write invokes a block-specific hardware function.	`onwrite = wuser`
Read flags		
`RC`	Reading the field clears it.	`onread = rclr`
`RS`	Reading the field sets it.	`onread = rset`
`RMOD`	Reading the field invokes a block-specific hardware function.	`onread = ruser`
Pulse		
`1P`	The field self-clears the cycle after it is written, producing a one-cycle pulse.	`singlepulse`

A.1. References

Table 2547 follows the field-property semantics of the SystemRDL 2.0 register description language (Accellera), as

rendered by the PeakRDL toolchain.

- PeakRDL — the control and status register generator toolchain that produces these register tables.
- systemrdl-compiler field properties — the `onwrite`, `onread` and `singlepulse` properties and their `woclr` / `woset` / `rclr` / `rset` shorthand forms.

Appendix B: Referenced Documents

This appendix collects the companion guides, specifications and external design documentation referenced by the subsystem and IP chapters. Revisions below are those cited in this manual; an unspecified revision does not imply the latest edition.

B.1. OCAH Documentation

Table 2548 identifies the companion guides used for integration and programming details.

Table 2548. OCAH documentation references

Document	Referenced for
Open Chiplet Atlas Harness (OCAH) Integrator Guide	Subsystem integration and external interfaces, including the SEP external TRNG aperture's register decode and error-response requirements.

B.2. OCA Specifications

Table 2549 identifies the OCA specifications cited by this manual.

Table 2549. OCA specification references

Document	Referenced for
Open Chiplet Cross Triggering (OCCT) specification	DTP cross-trigger fabric, Cross-Trigger Network and Cross-Trigger Port. The cited revision and a document-specific URL are not specified in this manual.
Open Chiplet Atlas specification: Open Chiplet Time Synchronization (OCTS)	System Timer OCTS protocol and credit-based synchronization. The cited revision is not specified in this manual.
AXI-over-UCIe (AoU) specification	AoU bridge protocol. The imported AoU microarchitecture specification cites revision 0.7 (2025).

B.3. Interface and Security Standards

Table 2550 identifies the standards used by the interfaces and security functions.

Table 2550. Interface and security standard references

Document	Referenced for
Universal Chiplet Interconnect Express (UCIe) specification	AoU FDI interface, flit cancellation and stall handling. The cited revision is not specified in this manual.
IEEE 1149.1-2013	DTP JTAG TAPs, instruction registers and IC_RESET test data register.
IEEE 1838-2019	DTP hierarchical multi-chiplet test access and STAP 3D control register.
IEEE 1687-2014	DTP iJTAG instrumentation and segment insertion bits (SIBs).
I2C-bus specification, revisions 6 and 7.0	I2C controller. The feature overview cites revision 7.0; the architecture chapter cites revision 6 for electrical and timing requirements.
System Management Bus (SMBus) specification, revision 3.2	I2C controller SMBus operation.
Power Management Bus (PMBus) specification, revision 1.4	I2C controller PMBus operation.
AVSBus specification, version 1.3.1	AVSBus controller voltage-scaling frames and responses.
MIPI I3C Basic specification, versions 1.0 and 1.1.1	I3C core controller interface.

Document	Referenced for
MIPI I3C HCI (Host Controller Interface) specification, version 1.2	I3C core controller register map.
TCRI recovery specification, version 1.0	I3C core controller recovery interface.
NIST SP 800-90A, revision 1	DRBG and SEP random-number generation.
NIST SP 800-90B	Entropy Source and SEP TRNG entropy assessment and health tests.
FIPS 140-2	Entropy Source discussion of planned certification readiness.
FIPS 203	Adams Bridge ML-KEM-1024 operations.
FIPS 204	Adams Bridge ML-DSA-87 operations and SEP lifecycle signing policy.

B.4. External Design Documentation

Table 2551 identifies the upstream design documentation used by the subsystem chapters.

Table 2551. External design documentation references

Document or project	Referenced for
Rocket Core	SMC CPU and memory system.
VeeR EL2 Programmer's Reference Manual	SEP CPU architecture, CSRs and interrupt behavior.
iDMA	SMC DMA engine.
Caliptra Adams Bridge documentation	SEP post-quantum cryptographic accelerator.
OpenTitan HMAC documentation	SEP HMAC-SHA2 accelerator and programming model.
OpenTitan OTBN documentation	SEP public-key accelerator and programming model.
OpenTitan AES documentation	SEP AES cipher and programming model.
OpenTitan KMAC documentation	SEP KMAC-SHA3 accelerator and programming model.
OpenTitan Key Manager	Background on a comparable key manager design. The OCAH Key Manager firmware interface is defined by its own firmware chapter, not by this document.
OpenTitan CSRNG and EDN	DRBG core register semantics and application entropy delivery.
OpenTitan DMA Controller	SEP DMA and its programming model.
OpenTitan SPI Host documentation	SEP SPI host and programming model.
OpenTitan Always-On Timer documentation	SEP watchdog timer and programming model.
OpenTitan I2C Controller documentation	SMC I2C controller architecture and programming model. The I2C chapter also cites the upstream source.
OpenTitan I2C Device Interface Functions	I2C controller firmware interface.
OpenTitan Cryptolib API	SEP cryptographic software interface background.