


1. No connection to +12V flying lead.
2. Reset drawn incorrectly
3. LED #4 drawn connected to A instead of C