## LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
R2	DASHBOARD/LEFT REAR CONNECTION
R3	DASHBOARD/DRIVER'S DOOR CONNECTION
R4	DASHBOARD/PASSENGER'S DOOR CONNECTION
R13	LEFT REAR/LEFT-HAND REAR DOOR CONNECTION
R20	ENGINE/IGNITION
R24	ENGINE/INJECTION CONNECTION
R33	FRONT SIDE/BUMPER
R37	ENGINE/INJECTION CONNECTION
R67	FRONT OF ENGINE/ENGINE CONNECTION
R98	UNDER BODY WIRING / ENGINE WIRING HARNESS CONNECTION
R99	DASHBOARD/HEATING CONNECTION
R107	DASHBOARD/FRONT OF ENGINE CONNECTION
R187	PASSENGER COMPARTMENT/CENTRAL COURTESY LIGHT CONNECTION
R235	DASHBOARD/AUTOMATIC GEARBOX CONNECTION
R241	RAISED BRAKE LIGHT/LEFT-HAND REAR CONNECTION
R243	RIGHT-HAND REAR DOOR/REAR LEFT-HAND WIRING CONNECTION
R251	DASHBOARD/CAR PHONE CONNECTION
R301	DASHBOARD/COURTESY LIGHT CONNECTION
R319	REAR/REAR BUMPER CONNECTION
R323	SEAT / RIGHT-HAND SEAT ELECTRICAL FUNCTIONS
R324	SEAT / LEFT-HAND SEAT ELECTRICAL FUNCTIONS
R325	PASSENGER COMPARTMENT/AFTER-MARKET ALARM WIRING CONNECTION
R334	PASSENGER COMPARTMENT/PASSENGER FRONT SEAT CONNECTION
R339	ROOF / SUNROOF
R344	DASHBOARD / FRONT PASSENGER AIRBAG CONNECTION
R369	DASH BOARD / MULTIMEDIA CONNECTION
R372	REAR / FASCIA BAND CONNECTION
R374	REAR LEFT-HAND WIRING / FRONT WIRING HARNESS CONNECTION
R417	PASSENGER COMPARTMENT / PTC HEATING WIRING CONNECTION
R430	HANDS-FREE MICROPHONE/ROOF CONNECTION
R433	ENGINE HARNESS / SEQUENTIAL GEARBOX CONNECTION
R675	MULTIMEDIA / MICROPHONE CONNECTION