
PRIMARY USE: To reduce coarse sediment transport from construction sites. **ADDITIONAL USES**:

BRUSH BARRIER

What is it? The brush barrier provides a temporary physical barrier located downslope of disturbed areas by using stacked shrubs and related materials.

Purpose

Brush barriers reduce stormwater runoff velocities of sheet flow and impede sediment caused by erosion.



Limitations

This BMP is not intended for concentrated flows or substantial amounts of sheet flow. Application of brush barriers should be for small construction sites and slopes not exceeding 1.5:1 (H:V).

Materials

Brush; woody material not to exceed six inches (152 mm) in diameter; filter fabric as required by local conditions or regulations.

Installation

Filter fabric may be required to ensure a barrier's filtration ability. Where concentrated flow passes around or under the barrier, it should be expanded and increased in size accordingly and/or augmented by toed-in filter fabric. After installation, barrier dimensions must be maintained.

Source: Surface Water Design Manual; King County, Washington.