Chapter 3: Arithmetic for Computers

Ngo Lam Trung

[with materials from Computer Organization and Design, 4th Edition, Patterson & Hennessy, © 2008, MK and M.J. Irwin's presentation, PSU 2008]

Chapter 3.1 NLT, SoICT, 2020

Content

- Integer representation and arithmetic
- Floating point number representation and arithmetic

Chapter 3.2 NLT, SoICT, 2020

Addition and subtraction

- Addition
 - Similar to what you do to add two numbers manually
 - Digits are added bit by bit from right to left
 - Carries passed to the next digit to the left
- Subtraction
 - Negate the second operand then add to the first operand

$$ullet$$
 00000 00000 00000 00000 00000 00000 0111_{two} = 7_{ten} 00000 00000 00000 00000 0000 0000 0110_{two} = 6_{ten} 0000 0000 0000 0000 0000 0000 1101_{two} = 13_{ten}

Chapter 3.3 NLT, SoICT, 2020

□ All numbers are 8-bit signed integer

$$122 + 8 =$$

$$122 + 80 =$$

Chapter 3.4 NLT, SoICT, 2020

Dealing with Overflow


- Overflow occurs when the result of an operation cannot be represented in 32-bits, i.e., when the sign bit contains a value bit of the result and not the proper sign bit
 - When adding operands with different signs or when subtracting operands with the same sign, overflow can never occur

Operation	Operand A	Operand B	Result indicating overflow
A + B	≥ 0	≥ 0	< 0
A + B	< 0	< 0	≥ 0
A - B	≥ 0	< 0	< 0
A - B	< 0	≥ 0	≥ 0

Chapter 3.5 NLT, SoICT, 2020

Adder implementation

N-bit ripple-carry adder



Performance depends on data length

→ Performance is low

Chapter 3.6 NLT, SoICT, 2020

Making addition faster: infinite hardware

- Parallelize the adder with the cost of hardware
- Given the addition:

$$a_{n-1}a_{n-2} \dots a_1a_0 + bn_{-1}b_{n-2} \dots b_1b_0$$

 \Box Let c_i is the carry at bit i

$$c2 = (b1.c1) + (a1.c1) + (a1.b1)$$

 $c1 = (b0.c0) + (a0.c0) + (a0.b0)$

Find c2 from a0, b0, a1, b1?

Chapter 3.7 NLT, SoICT, 2020

Making addition faster: Carry Lookahead

- Approach
 - Make hardwired 4 bit adder → fast and simple enough
 - Develop a carry lookahead unit to calculate the carry bit before finishing the addition
- □ At bit i

$$ci + 1 = (bi \cdot ci) + (ai \cdot ci) + (ai \cdot bi)$$
$$= (ai \cdot bi) + (ai + bi) \cdot ci$$

Denote

$$gi = ai \cdot bi$$

 $pi = ai + bi$

Then

$$ci + 1 = gi + pi \cdot ci$$

Chapter 3.8 NLT, SoICT, 2020

Carry lookahead

With 4-bit adder

$$c1 = g0 + (p0 \cdot c0)$$

$$c2 = g1 + (p1 \cdot g0) + (p1 \cdot p0 \cdot c0)$$

$$c3 = g2 + (p2 \cdot g1) + (p2 \cdot p1 \cdot g0) + (p2 \cdot p1 \cdot p0 \cdot c0)$$

$$c4 = g3 + (p3 \cdot g2) + (p3 \cdot p2 \cdot g1) + (p3 \cdot p2 \cdot p1 \cdot g0)$$

$$+ (p3 \cdot p2 \cdot p1 \cdot p0 \cdot c0)$$


- → All carry bits can be calculated after 3 gate delay
- → All result bits can be calculated after maximum of 4 gate delay

→ How to implement bigger adder?

Chapter 3.9 NLT, SoICT, 2020

Carry lookahead

□ For 16-bit adder → fast C1, C2, C3, C4 is needed



Chapter 3.10 NLT, SoICT, 2020

Carry lookahead

Denote

$$P0 = p3 \cdot p2 \cdot p1 \cdot p0$$

$$G0 = g3 + (p3 \cdot g2) + (p3 \cdot p2 \cdot g1) + (p3 \cdot p2 \cdot p1 \cdot g0)$$

$$P1 = p7 \cdot p6 \cdot p5 \cdot p4$$

$$G1 = g7 + (p7 \cdot g6) + (p7 \cdot p6 \cdot g5) + (p7 \cdot p6 \cdot p5 \cdot g4)$$

$$P2 = p11 \cdot p10 \cdot p9 \cdot p8$$

$$G2 = g11 + (p11 \cdot g10) + (p11 \cdot p10 \cdot g9) + (p11 \cdot p10 \cdot p9 \cdot g8)$$

$$P3 = p15 \cdot p14 \cdot p13 \cdot p12$$

$$G3 = g15 + (p15 \cdot g14) + (p15 \cdot p14 \cdot g13) + (p15 \cdot p14 \cdot p13 \cdot g12)$$

Then big-carry bits can be calculated fast

$$C1 = G0 + (P0 \cdot c0)$$


$$C2 = G1 + (P1 \cdot G0) + (P1 \cdot P0 \cdot c0)$$

$$C3 = G2 + (P2 \cdot G1) + (P2 \cdot P1 \cdot G0) + (P2 \cdot P1 \cdot P0 \cdot c0)$$

$$C4 = G3 + (P3 \cdot G2) + (P3 \cdot P2 \cdot G1) + (P3 \cdot P2 \cdot P1 \cdot G0) + (P3 \cdot P2 \cdot P1 \cdot P0 \cdot c0)$$

Chapter 3.11 NLT, SoICT, 2020

16-bit Adder



Chapter 3.12 NLT, SoICT, 2020

□ Dertermine g_i , pi, G_i , Pi when adding the two 16-bit numbers

$$a = 0001 \ 1010 \ 0011 \ 0011$$

 $b = 1110 \ 0101 \ 1110 \ 1011$

 \Box Calculate c_{15}

Chapter 3.13 NLT, SoICT, 2020

$$\begin{array}{c} gi = ai \cdot bi \\ pi = ai + bi \end{array}$$

$$\begin{array}{c} p_3 = 1 \cdot 1 \cdot 1 \cdot 1 = 1 \\ p_3 = 1 \cdot 1 \cdot 1 \cdot 1 = 1 \\ p_4 = 1 \cdot 1 \cdot 1 \cdot 1 = 1 \\ p_5 = 1 \cdot 1 \cdot 1 \cdot 1 = 1 \\ p_7 = 1 \cdot 1 \cdot 1 \cdot 1 = 1 \\$$

$$G0 = g3 + (p3 \cdot g2) + (p3 \cdot p2 \cdot g1) + (p3 \cdot p2 \cdot p1 \cdot g0)$$

$$= 0 + (1 \cdot 0) + (1 \cdot 0 \cdot 1) + (1 \cdot 0 \cdot 1 \cdot 1) = 0 + 0 + 0 + 0 + 0 = 0$$

$$G1 = g7 + (p7 \cdot g6) + (p7 \cdot p6 \cdot g5) + (p7 \cdot p6 \cdot p5 \cdot g4)$$

$$= 0 + (1 \cdot 0) + (1 \cdot 1 \cdot 1) + (1 \cdot 1 \cdot 1 \cdot 0) = 0 + 0 + 1 + 0 = 1$$

$$G2 = g11 + (p11 \cdot g10) + (p11 \cdot p10 \cdot g9) + (p11 \cdot p10 \cdot p9 \cdot g8)$$

$$= 0 + (1 \cdot 0) + (1 \cdot 1 \cdot 0) + (1 \cdot 1 \cdot 1 \cdot 0) = 0 + 0 + 0 + 0 = 0$$

$$G3 = g15 + (p15 \cdot g14) + (p15 \cdot p14 \cdot g13) + (p15 \cdot p14 \cdot p13 \cdot g12)$$

$$= 0 + (1 \cdot 0) + (1 \cdot 1 \cdot 0) + (1 \cdot 1 \cdot 1 \cdot 0) = 0 + 0 + 0 + 0 = 0$$

Chapter 3.14 NLT, SoICT, 2020

 $ightharpoonup c_{15}$ is actually C_4

$$C4 = G3 + (P3 \cdot G2) + (P3 \cdot P2 \cdot G1) + (P3 \cdot P2 \cdot P1 \cdot G0) + (P3 \cdot P2 \cdot P1 \cdot P0 \cdot c0) = 0 + (1 \cdot 0) + (1 \cdot 1 \cdot 1) + (1 \cdot 1 \cdot 1 \cdot 0) + (1 \cdot 1 \cdot 1 \cdot 0 \cdot 0) = 0 + 0 + 1 + 0 + 0 = 1$$


Chapter 3.15 NLT, SoICT, 2020

Compare performance of 16-bit ripple carry and 16-bit carry lookahead adders, assuming delay of all logic gates are equal?

Chapter 3.16 NLT, SoICT, 2020

Multiply

Binary multiplication is just a bunch of right shifts and adds




n-bit multiplicand and multiplier → 2*n-bit product*

Chapter 3.17 NLT, SoICT, 2020

Multiplicand		1000_{ten}
Multiplier	Χ	1001_{ten}
		1000
		0000
		0000
		1000
Product		1001000 _{ten}

Chapter 3.18 NLT, SoICT, 2020

Add and Right Shift Multiplier Hardware



Chapter 3.20 NLT, SolCT, 2020

MIPS Multiply Instruction

Multiply (mult and multu) produces a double precision product (2 x 32 bit)

mult \$s0, \$s1 # hi||lo = \$s0 * \$s1

0 16 17 0 0 0x18


- Two additional registers: hi and lo
- Low-order word of the product is stored in processor register 10 and the high-order word is stored in register hi
- Instructions mfhi rd and mflo rd are provided to move the product to (user accessible) registers in the register file

Chapter 3.21 NLT, SoICT, 2020

Division


 Division is just a bunch of quotient digit guesses and left shifts and subtracts

dividend = quotient x divisor + remainder



Chapter 3.22 NLT, SoICT, 2020

Left Shift and Subtract Division Hardware



Chapter 3.24 NLT, SoICT, 2020

MIPS Divide Instruction

□ Divide (div and divu) generates the reminder in hi and the quotient in lo

- Instructions mfhi rd and mflo rd are provided to move the quotient and reminder to (user accessible) registers in the register file
- □ As with multiply, divide ignores overflow so software must determine if the quotient is too large. Software must also check the divisor to avoid division by 0.

Chapter 3.25 NLT, SoICT, 2020

Representing Big (and Small) Numbers

- Encoding non-integer value?
 - □ Earth mass: (5.9722±0.0006)×1024 (kg)

 - PI number

- Problem: how to represent the above numbers?
- → We need reals or floating-point numbers!
- → Floating point numbers in decimal:
 - **→** 1000
 - $\rightarrow 1 \times 10^3$
 - $\rightarrow 0.1 \times 10^4$

Chapter 3.26 NLT, SoICT, 2020

Floating point number

In decimal system

$$2013.1228 = 201.31228 * 10$$

$$= 20.131228 * 10^{2}$$

$$= 2.0131228 * 10^{3}$$

$$= 20131228 * 10^{-4}$$

■ What is the "standard" form?

$$2.0131228 * 10^3 = 2.0131228E + 03$$

mantissa

exponent

- □ In binary $X = \pm 1.xxxxx * 2^{yyyy}$
- Sign, mantissa, and exponent need to be represented

Chapter 3.27 NLT, SoICT, 2020

Floating point number

Floating point representation in binary

$$(-1)^{sign} \times 1.F \times 2^{E-bias}$$

- Still have to fit everything in 32 bits (single precision)
- □ Bias = 127 with single precision floating point number

S	E (exponent)	F (fraction)
1 sign b	it 8 bits	23 bits

- Defined by the IEEE 754-1985 standard
 - Single precision: 32 bit
 - Double precision: 64 bit
 - Correspond to float and double in C

Chapter 3.28 NLT, SoICT, 2020

Ex1: convert X into decimal value

 $X = 1100\ 0001\ 0101\ 0110\ 0000\ 0000\ 0000\ 0000$

```
sign = 1 \rightarrow X is negative

E = 1000 0010 = 130

F = 10101100...00

\rightarrow X = (-1)<sup>1</sup> x 1.101011000..00 x 2<sup>130-127</sup>

= -1.101011 x 2<sup>3</sup> = -1101.011

= -13.375
```

Chapter 3.29 NLT, SoICT, 2020

Ex2: find decimal value of X

 $X = 0011 \ 1111 \ 1000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000$

sign = 0
e = 0111 1111 = 127
m = 000...0000 (23 bit 0)
$$X = (-1)^0 \times 1.00...000 \times 2^{127-127} = 1.0$$

Chapter 3.30 NLT, SoICT, 2020

Ex3: find binary representation of X = 9.6875 in IEEE 754 single precision

Converting X to plain binary

$$9_{10} = 1001_2$$

 \rightarrow 9.6875₁₀ = 1001.1011₂

Chapter 3.31 NLT, SoICT, 2020

■ Ex3: find binary representation of X = 9.6875 in IEEE 754 single precision

$$X = 9.6875_{(10)} = 1001.1011_{(2)} = 1.0011011 \times 2^{3}$$

Then
$$S = 0$$

$$e = 127 + 3 = 130_{(10)} = 1000 \ 0010_{(2)}$$

$$m = 001101100...00 \ (23 \ bit)$$

Finally

 $X = 0100\ 0001\ 0001\ 1011\ 0000\ 0000\ 0000\ 0000$

Chapter 3.32 NLT, SoICT, 2020

- \square 1.0₂ x 2⁻¹ =
- □ 100.75₁₀ =

Chapter 3.33 NLT, SoICT, 2020


Some special values

- □ Largest+: 0 11111110 1.1111111111111111111111 = $(2-2^{-23}) \times 2^{254-127}$

Chapter 3.34 NLT, SoICT, 2020

Too large or too small values

- Overflow (floating point) happens when a positive exponent becomes too large to fit in the exponent field
- Underflow (floating point) happens when a negative exponent becomes too large to fit in the exponent field



- Reduce the chance of underflow or overflow is to offer another format that has a larger exponent field
 - Double precision takes two MIPS words

s E (exponent)		F (fraction)		
1 bit	11 bits	20 bits		
F (fraction continued)				

32 bits Chapter 3.35

Reduce underflow with the same bit length?

De-normalized number

Chapter 3.36 NLT, SoICT, 2020

IEEE 754 FP Standard Encoding

- Special encodings are used to represent unusual events
 - ± infinity for division by zero
 - NAN (not a number) for invalid operations such as 0/0
 - True zero is the bit string all zero

Single Precision		Double Precision		Object
E (8)	F (23)	E (11)	F (52)	Represented
0000 0000	0	0000 0000	0	true zero (0)
0000 0000	nonzero	0000 0000	nonzero	± denormalized number
0111 1111 to +127,-126	anything	01111111 to +1023,-1022	anything	± floating point number
1111 1111	+ 0	1111 1111	- 0	± infinity
1111 1111	nonzero	1111 1111	nonzero	not a number (NaN)

Chapter 3.37 NLT, SoICT, 2020

Floating Point Addition

Addition (and subtraction)

$$(\pm F1 \times 2^{E1}) + (\pm F2 \times 2^{E2}) = \pm F3 \times 2^{E3}$$

- Step 0: Restore the hidden bit in F1 and in F2
- Step 1: Align fractions by right shifting F2 by E1 E2 positions (assuming E1 ≥ E2) keeping track of (three of) the bits shifted out in G R and S
- Step 2: Add the resulting F2 to F1 to form F3
- □ Step 3: Normalize F3 (so it is in the form 1.XXXXX ...)
 - If F1 and F2 have the same sign → F3 ∈[1,4) → 1 bit right shift F3 and increment E3 (check for overflow)
 - If F1 and F2 have different signs → F3 may require many left shifts each time decrementing E3 (check for underflow)
- Step 4: Round F3 and possibly normalize F3 again
- Step 5: Rehide the most significant bit of F3 before storing the result

Chapter 3.38 NLT, SoICT, 2020

Floating Point Addition Example

- □ Add: 0.5 + (-0.4375) = ? $(0.5 = 1.0000 \times 2^{-1}) + (-0.4375 = -1.1100 \times 2^{-2})$
 - ☐ Step 0: Hidden bits restored in the representation above
 - Step 1: Shift significand with the smaller exponent (1.1100) right until its exponent matches the larger exponent (so once)
 - □ Step 2: Add significands 1.0000 + (-0.111) = 1.0000 - 0.111 = 0.001
 - Step 3: Normalize the sum, checking for exponent over/underflow $0.001 \times 2^{-1} = 0.010 \times 2^{-2} = .. = 1.000 \times 2^{-4}$
 - □ Step 4: The sum is already rounded, so we're done
 - Step 5: Rehide the hidden bit before storing

Chapter 3.40 NLT, SoICT, 2020

Floating Point Multiplication

Multiplication

$$(\pm F1 \times 2^{E1}) \times (\pm F2 \times 2^{E2}) = \pm F3 \times 2^{E3}$$

- Step 0: Restore the hidden bit in F1 and in F2
- Step 1: Add the two (biased) exponents and subtract the bias from the sum, so E1 + E2 127 = E3
 - also determine the sign of the product (which depends on the sign of the operands (most significant bits))
- Step 2: Multiply F1 by F2 to form a double precision F3
- □ Step 3: Normalize F3 (so it is in the form 1.XXXXX ...)
 - Since F1 and F2 come in normalized → F3 ∈[1,4) → 1 bit right shift
 F3 and increment E3
 - Check for overflow/underflow
- Step 4: Round F3 and possibly normalize F3 again
- Step 5: Rehide the most significant bit of F3 before storing the result

Chapter 3.41 NLT, SoICT, 2020

Floating Point Multiplication Example

Multiply

$$(0.5 = 1.0000 \times 2^{-1}) \times (-0.4375 = -1.1100 \times 2^{-2})$$

- Step 0: Hidden bits restored in the representation above
- Step 1: Add the exponents (not in bias would be -1 + (-2) = -3 and in bias would be (-1+127) + (-2+127) − 127 = (-1 -2) + (127+127-127) = -3 + 127 = 124
- Step 2: Multiply the significands
 1.0000 x 1.110 = 1.110000
- Step 3: Normalized the product, checking for exp over/underflow
 1.110000 x 2⁻³ is already normalized
- □ Step 4: The product is already rounded, so we're done
- Step 5: Rehide the hidden bit before storing

Chapter 3.43 NLT, SoICT, 2020

Support for Accurate Arithmetic


- □ IEEE 754 FP rounding modes
 - □ Always round up (toward +∞)
 - □ Always round down (toward -∞)
 - Truncate
 - Round to nearest even (when the Guard || Round || Sticky are 100) always creates a 0 in the least significant (kept) bit of F
- Rounding (except for truncation) requires the hardware to include extra F bits during calculations
 - Guard bit used to provide one F bit when shifting left to normalize a result (e.g., when normalizing F after division or subtraction)
 - Round bit used to improve rounding accuracy
 - Sticky bit used to support Round to nearest even; is set to a 1 whenever a 1 bit shifts (right) through it (e.g., when aligning F during addition/subtraction)

Chapter 3.44 NLT, SoICT, 2020

MIPS Arithmetic Logic Unit (ALU)

Must support the Arithmetic/Logic operations of the ISA

```
add, addi, addiu, addu sub, subu mult, multu, div, divu \frac{B}{32} and, andi, nor, or, ori, xor, xori beq, bne, slt, sltiu, sltu
```



- With special handling for
 - □ sign extend addi, addiu, slti, sltiu
 - □ zero extend andi, ori, xori
 - overflow detection add, addi, sub

Chapter 3.45 NLT, SoICT, 2020