https://www.facebook.com/luubenhga

BDQ-29 Surface x1
A01

Locker adjust line

Note: Adjust the place you need

A10 orienting line

A08 orienting line

A02 orienting line

BDQ-29 Back leather x1
A03

A08 orienting line

BDQ-29 Back leather x1
A02

BDQ-29 Locker mat leather x1
A10

BDQ-29 Locker mat leather x1
A10

Locker orienting line

A09 orienting line

BDQ-29 Flap x1
A04

A12 orienting line

Rivet

Rivet

A02 orienting line

Welting with 0.6mm leather

BDQ-29 Interlayer x1
A07

BDQ-29 Strap x2
A09

Allowance line

BDQ-29 Handle leather x1
A12

BDQ-29 Strap x4
A08

Allowance line

BDQ-29 Handle inner leather x1
A11

Rivet

Hollow

BDQ-29 Handle strengthen leather x1
A12

Note: Blue line is allowance line

BDQ-29 Gusset x2
A05

A06 orienting line

A05 orienting line

BDQ-29 Bottom x1
A06

The orange line is joint and sewing line

LZpattern
BDQ-29 briefcase
A0 print 1:1