
LEATHER TOP-HANDLE BAG PATTERN

Print setting: A4 “actual size”




1 cm

1 cm

LEATHER TOP-HANDLE BAG PATTERN


Print setting: A4 “actual size”







LEATHER TOP-HANDLE BAG PATTERN


Print setting: A4 “actual size”







LEATHER TOP-HANDLE BAG PATTERN
Print setting: A4 “actual size”



Side strip


Side strip


1 cm


1 cm


LEATHER TOP-HANDLE BAG PATTERN


Print setting: A4 “actual size”















LEATHER TOP-HANDLE BAG PATTERN

Print setting: A4 “actual size”




1 cm

1 cm

LEATHER TOP-HANDLE BAG PATTERN

Print setting: A4 “actual size”




Side

1 cm

1 cm

LEATHER TOP-HANDLE BAG PATTERN

Print setting: A4 “actual size”




Side

1 cm

1 cm

LEATHER TOP-HANDLE BAG PATTERN

Print setting: A4 “actual size”



1 cm

1 cm