PRINTING INSTRUCTION

1. File > Print
2. Click on fiPage Setupfl button make sure your paper size is set to the paper size that you will print and Scale at 100%
3. In fiPages Sizing & Handlingfl click on fiSizefl button and select fiActual sizefl



CraftsmanGus

CraftsmanGus

CraftsmanGus : Pattern

Standard : Simple Trucker Wallet
Wal T01 #4mm.
4th Deck
1.5 mm. REC

X 1

CraftsmanGus : Pattern

Standard : Simple Trucker Wallet
Wal T01 #4mm.
3rd & 5th Deck
1.5 mm. REC

X 2

CraftsmanGus : Pattern

Standard : Simple Trucker Wallet
Wal T01 #4mm.
2nd Deck
1.5 mm. REC

X 1

*Note: Use YKK zipper No.3, or RIRI No.04 (or similar)

1st Deck

CraftsmanGus







