Long Zipper Wallet

Printing Instruction

CraftsmanGus

1. File > Print
2. Click on fiPage Setupfl button make sure your paper size is set to A4 and Scale at 100%
3. In fiPages Sizing & Handlingfl click on fiSizefl button and select fiActual sizefl



CraftsmanGus

LOG/ZO1

19.8 cm x 7.3 cm

LOG/ZO2

19.8 cm x 4.9 cm

CraftsmanGus

LOG/ZO3

19.8 cm x 4.9 cm

LOG/ZO4

14 cm x 7.4 cm

CraftsmanGus

LOG/ZO5

17 cm x 16.9 cm

Long Zipper Wallet



LOG/ZO6

CraftsmanGus

19.8 cm x 20.5 cm

Long Zipper Wallet



LOG/ZO7

CraftsmanGus

19.8 cm x 21.2 cm

CraftsmanGus

18.8 cm x 7.9 cm

LOG/ZO8