

1. File > Print
2. Click on fiPage Setupfl button make sure your paper size is set to the paper size that you will print and Scale at 100%
3. In fiPages Sizing & Handlingfl click on fiSizefl button and select fiActual sizefl








Craftsm
Standard : S
Wal T01 #4
2nd Deck
1.5 mm. RE

*Note: Use YKK z

1st Deck

CraftsmanGus



CraftsmanGus

CraftsmanGus

