

INSTRUÇÕES MIPS - DECODIFICAÇÃO

INSTRUÇÃO	TIPO	OPCODE (decimal)	OPCODE (binário)	FUNCTION (decimal)	FUNCTION (binário)
add	R	0	000000	32	100000
addi	I	8	001000		
addiu	I	9	001001		
addu	R	0	000000	33	100001
and	R	0	000000	36	100100
andi	I	12	001100		
bgtz	I	7	000111		
beq	I	4	000100		
bltz	I	1	000001		
blez	I	6	000110		
bne	I	5	000101		
div	R	0	000000	26	011010
divu	R	0	000000	27	011011
j	J	2	000010		
jal	J	3	000011		
jr	R	0	000000	8	001000
lb	I	32	100000		
lbu	I	36	100100		
lui	I	15	001111		
lw	I	35	100011		
mfhi	R	0	000000	16	010000
mflo	R	0	000000	18	010010
mult	R	0	000000	24	011000
multu	R	0	000000	25	011001
nor	R	0	000000	39	100111
or	R	0	000000	37	100101
ori	I	13	001101		
sb	I	40	101000		
sll	R	0	000000	0	000000
sllv	R	0	000000	4	000100
slt	R	0	000000	42	101010
slti	I	10	001010		
sra	R	0	000000	3	000011
srav	R	0	000000	7	000111
srl	R	0	000000	2	000010
srlv	R	0	000000	6	000110
sub	R	0	000000	34	100010
subu	R	0	000000	35	100011
sw	I	43	101011		
syscall		0	000000	12	001100
xor	R	0	000000	38	100110
xori	I	14	001110		