
# ETSITS 136 443 V10.0.0 (2011-01)

Technical Specification

LTE; Evolved Universal Terrestrial Radio Access Network (E-UTRAN); M2 Application Protocol (M2AP) (3GPP TS 36.443 version 10.0.0 Release 10)



Reference
RTS/TSGR-0336443va00

Keywords
LTE

#### **ETSI**

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

Individual copies of the present document can be downloaded from: <a href="http://www.etsi.org">http://www.etsi.org</a>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<a href="http://portal.etsi.org/tb/status/status.asp">http://portal.etsi.org/tb/status/status.asp</a></a>

If you find errors in the present document, please send your comment to one of the following services: <u>http://portal.etsi.org/chaircor/ETSI\_support.asp</u>

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2011.
All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup>, **UMTS**<sup>TM</sup>, **TIPHON**<sup>TM</sup>, the TIPHON logo and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.

**3GPP**<sup>™</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners. **LTE**<sup>™</sup> is a Trade Mark of ETSI currently being registered

for the benefit of its Members and of the 3GPP Organizational Partners. **GSM**® and the GSM logo are Trade Marks registered and owned by the GSM Association.

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

#### **Foreword**

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <a href="http://webapp.etsi.org/key/queryform.asp">http://webapp.etsi.org/key/queryform.asp</a>.

## Contents

Intelle	ectual Property Rights	2
Forev	word	2
Forev	word	6
1	Scope	7
2	References	7
3	Definitions, symbols and abbreviations	Q
3.1	Definitions	
3.2	Abbreviations	
4	General	
4.1	Procedure Specification Principles	
4.2	Forwards and Backwards Compatibility	
4.3	Specification Notations	9
5	M2AP Services	11
5.1	M2AP procedure modules	
5.2	Parallel transactions	11
6	Services Expected from Signalling Transport	12
7	Functions of M2AP	
8	M2AP Procedures	14
8.1	List of M2AP Elementary procedures	
8.2	MBMS Session Start	
8.2.1	General	
8.2.2	Successful Operation	
8.2.3	Unsuccessful Operation	
8.2.4	Abnormal Conditions	
8.3	MBMS Session Stop	
8.3.1	General	
8.3.2	Successful Operation	
8.3.3	Abnormal Conditions	16
8.4	MBMS Scheduling Information	16
8.4.1	General	
8.4.2	Successful Operation	
8.4.3	Abnormal Conditions	
8.5	Reset	
8.5.1	General	
8.5.2	Successful Operation	
8.5.2.1		
8.5.2.2		
8.5.3 8.5.3.1	Abnormal Conditions	
8.5.3.2		
8.5.3.3		
8.6	M2 Setup	
8.6.1	General.	
8.6.2	Successful Operation	
8.6.3	Unsuccessful Operation	
8.6.4	Abnormal Conditions	
8.7	eNB Configuration Update	
8.7.1	General	
8.7.2	Successful Operation	
8.7.3	Unsuccessful Operation	22
8.7.4	Abnormal Conditions	22

8.8	MCE Configuration Update	
8.8.1	General	
8.8.2	Successful Operation	
8.8.3	Unsuccessful Operation	
8.8.4	Abnormal Conditions	
8.9	Error Indication	
8.9.1	General	
8.9.2	Successful Operation	
8.9.3	Abnormal Conditions	
8.10	MBMS Session Update	
8.10.1	General	
8.10.2	Successful Operation	
8.10.3	Unsuccessful Operation	
8.10.4	Abnormal Conditions	25
	lements for M2AP Communication	
9.1	Message Functional Definition and Content	
9.1.1	General	
9.1.1	Message Contents	
9.1.1.1	Presence	
9.1.1.2	Criticality	
9.1.1.3	Range	
9.1.1.4	Assigned Criticality	
9.1.2	MBMS SESSION START REQUEST	
9.1.3	MBMS SESSION START RESPONSE	
9.1.4	MBMS SESSION START FAILURE	
9.1.5	MBMS SESSION STOP REQUEST	
9.1.6 9.1.7	MBMS SESSION STOP RESPONSEMBMS SCHEDULING INFORMATION	
9.1.7 9.1.8	MBMS SCHEDULING INFORMATION RESPONSE	
9.1.8	RESET	
9.1.10	RESET ACKNOWLEDGE	
9.1.11	M2 SETUP REQUEST	
9.1.12	M2 SETUP RESPONSE	
9.1.13	M2 SETUP FAILURE	
9.1.14	ENB CONFIGURATION UPDATE	
9.1.15	ENB CONFIGURATION UPDATE ACKNOWLEDGE	
9.1.16	ENB CONFIGURATION UPDATE FAILURE	
9.1.17	MCE CONFIGURATION UPDATE	
9.1.18	MCE CONFIGURATION UPDATE ACKNOWLEDGE	
9.1.19	MCE CONFIGURATION UPDATE FAILURE	
9.1.20	ERROR INDICATION	34
9.1.21	MBMS SESSION UPDATE REQUEST	
9.1.22	MBMS SESSION UPDATE RESPONSE	
9.1.23	MBMS SESSION UPDATE FAILURE	35
9.2	Information Element Definitions	35
9.2.1	Radio Network Layer Related IEs	35
9.2.1.1	Message Type	35
9.2.1.2	Cause	35
9.2.1.3	Void	
9.2.1.4	Void	
9.2.1.5	Void	
9.2.1.6	Void	
9.2.1.7	Criticality Diagnostics	
9.2.1.8	PMCH Configuration	
9.2.1.9	MBMS Session List per PMCH	
9.2.1.10	Global eNB ID	
9.2.1.11	E-UTRAN CGI	
9.2.1.12	eNB MBMS Configuration data Item IEs	
9.2.1.13	MCCH related BCCH Configuration Item	
9.2.1.14	MBSFN Area Id	
9.2.1.15	Time to Wait	41

9.2.1.16	Global MCE ID	41
9.2.1.17	MBSFN Subframe Configuration	41
9.2.1.18	Common Subframe Allocation Period	41
9.2.1.19	MCCH Update Time	42
9.2.1.20	MBSFN Synchronisation Area Id	42
9.2.2	Transport Network Layer Related IEs	42
9.2.2.1	IP Address	42
9.2.2.2	GTP-TEID	42
9.2.3	NAS Related IEs	42
9.2.3.1	MCE MBMS M2AP ID	42
9.2.3.2	eNB MBMS M2AP ID	43
9.2.3.3	TMGI	43
9.2.3.4	MBMS Session Identity	43
9.2.3.5	Void	43
9.2.3.6	MBMS Service Area	43
9.2.3.7	PLMN Identity	43
9.3	Message and Information Element Abstract Syntax (with ASN.1)	45
9.3.1	General	
9.3.2	Usage of Private Message Mechanism for Non-standard Use	45
9.3.3	Elementary Procedure Definitions	45
9.3.4	PDU Definitions	50
9.3.5	Information Element definitions	
9.3.6	Common definitions	68
9.3.7	Constant definitions	69
9.3.8	Container definitions	71
9.4	Message Transfer Syntax	75
9.5	Timers	75
10 H	andling of Unknown, Unforeseen and Erroneous Protocol Data	7 <i>6</i>
Annex A	A (informative): Change history	77
	•	

## Foreword

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

#### where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

## 1 Scope

The present document specifies the E-UTRAN radio network layer signalling protocol for the M2 interface. The M2 Application Protocol (M2AP) supports the functions of M2 interface by signalling procedures defined in this document. M2AP is developed in accordance to the general principles stated in [2] and [3].

## 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.
- 3GPP TR 21.905: "Vocabulary for 3GPP Specifications". [1] [2] 3GPP TS 36.401: "E-UTRAN Architecture Description". 3GPP TS 36.300: "Evolved Universal Terrestrial Radio Access (E-UTRA) and Evolved Universal [3] Terrestrial Radio Access Network (E-UTRAN); Overall description; Stage 2". [4] 3GPP TS 36.413: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN); S1 Application Protocol (S1AP)". ITU-T Recommendation X.691 (07/2002): "Information technology - ASN.1 encoding rules -[5] Specification of Packed Encoding Rules (PER) ". [6] ITU-T Recommendation X.680 (07/2002): "Information technology - Abstract Syntax Notation One (ASN.1): Specification of basic notation". 3GPP TS 36.412: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN); S1 [7] signalling transport ".
- signalling transport ".

  [8] 3GPP TS 23.246: "Multimedia Broadcast/Multicast Service (MBMS); Architecture and functional
- description".

  [9] 3GPP TS 29.061 "Interworking between the Public Land Mobile Network (PLMN) supporting
- packet based services and Packet Data Networks (PDN)".
- [10] 3GPP TS 23.203: "Policy and charging control architecture".
- [11] 3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRAN); Radio Resource Control (RRC) Protocol Specification".
- [12] 3GPP TS 36.211: "Evolved Universal Terrestrial Radio Access (E-UTRAN); Physical Channels and Modulation".
- [13] 3GPP TS 36.445: "Evolved Universal Terrestrial Radio Access Network (E-UTRAN); M1 Data Transport".

## 3 Definitions, symbols and abbreviations

#### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

**Elementary Procedure:** M2AP consists of Elementary Procedures (EPs). An Elementary Procedure is a unit of interaction between eNBs and the MCE. These Elementary Procedures are defined separately and are intended to be used to build up complete sequences in a flexible manner. If the independence between some EPs is restricted, it is described under the relevant EP description. Unless otherwise stated by the restrictions, the EPs may be invoked independently of each other as stand alone procedures, which can be active in parallel. The usage of several M2AP EPs together or together with EPs from other interfaces is specified in stage 2 specifications (e.g. [3] and [8]).

An EP consists of an initiating message and possibly a response message. Two kinds of EPs are used:

- Class 1: Elementary Procedures with response (success and/or failure).
- Class 2: Elementary Procedures without response.

For Class 1 EPs, the types of responses can be as follows:

#### Successful:

- A signalling message explicitly indicates that the elementary procedure successfully completed with the receipt of the response.

#### Unsuccessful:

- A signalling message explicitly indicates that the EP failed.
- On time supervision expiry (i.e. absence of expected response).

#### Successful and Unsuccessful:

- One signalling message reports both successful and unsuccessful outcome for the different included requests. The response message used is the one defined for successful outcome.

Class 2 EPs are considered always successful.

**eNB MBMS M2AP ID:** Unique identity, referencing the MBMS-service-associated logical M2-connection within an eNB.

**MCE MBMS M2AP ID:** Unique identity, referencing the MBMS-service-associated logical M2-connection within an MCE.

**MBMS E-RAB:** denotes both, the data bearer established between the eNB and the UE(s) to transport MBMS data and the MBMS M1 data bearer.

**MBMS-service-associated signalling:** When M2AP messages associated to one MBMS service uses the MBMS-service-associated logical M2-connection for association of the message to the respective MBMS service in eNB and EPC.

**MBMS-service-associated logical M2-connection:** The MBMS-service-associated logical M2-connection uses the identities *eNB MBMS M2AP ID* and *MCE MBMS M2AP ID*. For a received M2AP message the MCE identifies the associated MBMS E-RAB based on the *MCE MBMS M2AP ID* IE and the eNB identifies the associated MBMS-RAB based on the *eNB MBMS M2AP ID* IE.

#### 3.2 Abbreviations

For the purposes of the present document, the abbreviations given in TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in TR 21.905 [1].

MCCH Multicast Control CHannel PMCH Physical Multicast CHannel

### 4 General

## 4.1 Procedure Specification Principles

The principle for specifying the procedure logic is to specify the functional behaviour of the terminating node exactly and completely. Any rule that specifies the behaviour of the originating node shall be possible to be verified with information that is visible within the system.

The following specification principles have been applied for the procedure text in clause 8:

- The procedure text discriminates between:
  - 1) Functionality which "shall" be executed

The procedure text indicates that the receiving node "shall" perform a certain function Y under a certain condition. If the receiving node supports procedure X but cannot perform functionality Y requested in the REQUEST message of a Class 1 EP, the receiving node shall respond with the message used to report unsuccessful outcome for this procedure, containing an appropriate cause value.

2) Functionality which "shall, if supported" be executed

The procedure text indicates that the receiving node "shall, if supported," perform a certain function Y under a certain condition. If the receiving node supports procedure X, but does not support functionality Y, the receiving node shall proceed with the execution of the EP, possibly informing the requesting node about the not supported functionality.

- Any required inclusion of an optional IE in a response message is explicitly indicated in the procedure text. If the procedure text does not explicitly indicate that an optional IE shall be included in a response message, the optional IE shall not be included. For requirements on including *Criticality Diagnostics* IE, see section 10 in [4].

## 4.2 Forwards and Backwards Compatibility

The forwards and backwards compatibility of the protocol is assured by mechanism where all current and future messages, and IEs or groups of related IEs, include ID and criticality fields that are coded in a standard format that will not be changed in the future. These parts can always be decoded regardless of the standard version.

## 4.3 Specification Notations

For the purposes of the present document, the following notations apply:

Procedure When referring to an elementary procedure in the specification the Procedure Name is written with

the first letters in each word in upper case characters followed by the word "procedure", e.g. E-

RAB procedure.

Message When referring to a message in the specification the MESSAGE NAME is written with all letters

in upper case characters followed by the word "message", e.g. MESSAGE NAME message.

IE When referring to an information element (IE) in the specification the *Information Element Name* 

is written with the first letters in each word in upper case characters and all letters in Italic font

followed by the abbreviation "IE", e.g. Information Element IE.

Value of an IE When referring to the value of an information element (IE) in the specification the "Value" is written as it is specified in subclause 9.2 enclosed by quotation marks, e.g. "Value".

## 5 M2AP Services

The present clause describes the services an eNB offers to its associated MCE.

## 5.1 M2AP procedure modules

The M2 interface M2AP procedures may be sub-divided as follows:

- 1. M2AP MBMS session control procedures;
- 2. M2AP global procedures;

The M2AP session control procedures are related to MBMS services.

The Global Procedures module contains procedures that are not related to a specific MBMS service.

## 5.2 Parallel transactions

Unless explicitly indicated in the procedure specification, at any instance in time one protocol peer shall have a maximum of one ongoing M2AP procedure related to a certain MBMS service.

## 6 Services Expected from Signalling Transport

The signalling connection shall provide in sequence delivery of M2AP messages. M2AP shall be notified if the signalling connection breaks.

## 7 Functions of M2AP

The M2AP protocol provides the following functions:

- MBMS Session Handling. This function supports start, stop and modify of an MBMS session, as well as configuration and modification of basic radio transmission parameters related to that service.
- MBMS Scheduling Information. This function provides MCCH related information to the eNB.
- Reporting of General Error Situations. This function allows reporting of general error situations, for which function specific error messages have not been defined.
- Resetting the M2. This function is used to reset the M2 interface.
- Setting up the M2. This function is used to exchange necessary data for the eNB for setup the M2 interface, provides basic configuration of radio parameters for transmission of MBMS data and implicitly perform an M2 Reset.
- eNB and MCE Configuration Update functions are to update configuration data exchanged during setup of M2.

The mapping between the above functions and M2 EPs is shown in the table below.

Table 1: Mapping between M2AP functions and M2AP EPs

Function	Elementary Procedure(s)
MBMS Session Handling	a) MBMS Session Start
	b) MBMS Session Stop
	c) MBMS Session Update
MBMS Scheduling Information	MBMS Scheduling Information
Reporting of General Error Situations	Error Indication
Resetting the M2	Reset
Setting up the M2	M2 Setup
Configuration Update	a) eNB Configuration Update
- 	b) MCE Configuration Update

## 8 M2AP Procedures

## 8.1 List of M2AP Elementary procedures

In the following tables, all EPs are divided into Class 1 and Class 2 EPs (see subclause 3.1 for explanation of the different classes):

Table 2: Class 1 procedures

Elementary	Initiating Message	Successful Outcome	Unsuccessful Outcome
Procedure		Response message	Response message
MBMS Session	MBMS SESSION	MBMS SESSION START	MBMS SESSION START
Start	START REQUEST	RESPONSE	FAILURE
MBMS Session	MBMS SESSION	MBMS SESSION STOP	
Stop	STOP REQUEST	RESPONSE	
MBMS Session	MBMS SESSION	MBMS SESSION	MBMS SESSION UPDATE
Update	UPDATE REQUEST	UPDATE RESPONSE	FAILURE
MBMS	MBMS SCHEDULING	MBMS SCHEDULING	
Scheduling	INFORMATION	INFORMATION	
Information		RESPONSE	
Reset	RESET	RESET	
		ACKNOWLEDGE	
M2 Setup	M2 SETUP REQUEST	M2 SETUP RESPONSE	M2 SETUP FAILURE
eNB	ENB	ENB CONFIGURATION	ENB CONFIGURATION
Configuration	CONFIGURATION	UPDATE	UPDATE FAILURE
Update	UPDATE	ACKNOWLEDGE	
MCE	MCE	MCE CONFIGURATION	MCE CONFIGURATION
Configuration	CONFIGURATION	UPDATE	UPDATE FAILURE
Update	UPDATE	ACKNOWLEDGE	

Table 3: Class 2 procedures

Elementary Procedure	Message
Error Indication	ERROR INDICATION

The following applies concerning interference between Elementary Procedures:

- The Reset procedure takes precedence over all other EPs.

## 8.2 MBMS Session Start

#### 8.2.1 General

The purpose of the MBMS Session Start procedure is to request the eNB to notify UEs about an upcoming MBMS Session of a given MBMS Bearer Service and to establish an MBMS E-RAB and an MBMS-service-associated logical M2-connection. The MBMS Session Start procedure is triggered by the MCE.

The procedure uses MBMS-Service-associated signalling.

#### 8.2.2 Successful Operation




Figure 8.2.2-1. MBMS Session Start procedure. Successful operation.

The MCE initiates the procedure by sending an MBMS SESSION START REQUEST message. If the eNB accepts the MBMS session start request, the eNB responds with the MBMS SESSION START RESPONSE message. The eNB shall join the transport network IP multicast address (including the IP address of the multicast source) as described by the *TNL Information* IE to enable the reception of MBMS data.

If the MBMS SESSION START REQUEST message contains the *MBMS Session Identity* IE, the eNB shall notify the UEs about the information for the MBMS session.

#### 8.2.3 Unsuccessful Operation




Figure 8.2.3-1. MBMS Session Start procedure. Unsuccessful operation.

If the eNB is not capable of correctly processing the request (e.g. the MBMS resources could not be established at all in any cell), the MCE shall be informed by the MBMS SESSION START FAILURE message.

#### 8.2.4 Abnormal Conditions

Void.

## 8.3 MBMS Session Stop

#### 8.3.1 General

The purpose of the MBMS Session Stop procedure is to request the eNB to notify UEs about the end of a given MBMS Session of a given MBMS Bearer Service and to release the corresponding MBMS E-RAB and the MBMS-service-associated logical M2-connection. The MBMS Session Stop procedure is triggered by the MCE.

The procedure uses MBMS-Service-associated signalling.

#### 8.3.2 Successful Operation




Figure 8.3.2-1. MBMS Session Stop procedure. Successful operation.

The MCE initiates the procedure by sending a MBMS SESSION STOP REQUEST message. Upon receipt of the MBMS SESSION STOP REQUEST message, the eNB shall respond with the MBMS SESSION STOP RESPONSE message. The eNB shall disable the reception from the IP backbone of the particular MBMS bearer service, release the affected resources and remove the MBMS bearer context.

#### 8.3.3 Abnormal Conditions

Void.

## 8.4 MBMS Scheduling Information

#### 8.4.1 General

 $The \ purpose \ of \ the \ MBMS \ Scheduling \ Information \ Procedure \ is \ to \ provide \ MCCH \ related \ information \ to \ the \ eNB$ 

The procedure uses non MBMS-Service-associated signalling.

## 8.4.2 Successful Operation




Figure 8.4.2-1. MBMS Scheduling Information procedure. Successful operation.

The MCE initiates the procedure by sending the MBMS SCHEDULING INFORMATION message to the eNB. If PMCH configuration information is contained in this message, the eNB shall do PMCH transmission according to the PMCH configuration information. If PMCH configuration information for an existing PMCH is not contained in this message, the eNB should stop PMCH transmission for the PMCH. The eNB shall store the *MBSFN Area Configuration Item* IE, and apply the MCCH update from the modification period defined in the *MCCH Update Time* IE. The eNB shall schedule the MBMS services appear in the MCCH according to the order defined in the *MBMS Session List per PMCH* IE.

#### 8.4.3 Abnormal Conditions

Void.

#### 8.5 Reset

#### 8.5.1 General

The purpose of the Reset procedure is to initialise or re-initialise the eNB M2AP MBMS-service-related contexts, in the event of a failure in the MCE or vice versa. This procedure doesn"t affect the application level configuration data exchanged during the M2 Setup procedure.

The procedure uses non MBMS-service-associated signalling.

#### 8.5.2 Successful Operation

#### 8.5.2.1 Reset Procedure Initiated from the MCE




Figure 8.5.2.1-1. Reset procedure initiated from the MCE. Successful operation.

In the event of a failure at the MCE, which has resulted in the loss of some or all transaction reference information, a RESET message shall be sent to the eNB.

At reception of RESET message the eNB shall release all allocated resources on M2 and M1/Uu related to MBMS-service association(s) and remove all MBMS-service contexts including MBMS M2AP IDs.

After the eNB has released all assigned M2 resources and MBMS-service contexts, the eNB shall respond with the RESET ACKNOWLEDGE message. The eNB does not need to wait for the release of radio resources to be completed before returning the RESET ACKNOWLEDGE message.

If the RESET message contains the MBMS-Service-associated logical M2-connection list IE, then:

- The eNB shall use the MCE MBMS M2AP ID IE and/or the eNB MBMS M2AP ID IE to explicitly identify the MBMS service association(s) to be reset.
- The eNB shall in the RESET ACKNOWLEDGE message include, for each MBMS service association to be reset, the *MBMS-Service-associated logical M2-connection Item* IE in the *MBMS-Service-associated logical M2-connection Item* IEs shall be in the same order as received in the RESET message and shall include also unknown MBMS-Service-associated logical M2-connections. Empty *MBMS-Service-associated logical M2-connection Item* IEs, received in the RESET message, may be omitted in the RESET ACKNOWLEDGE message.
- If the MCE MBMS M2AP ID IE is included in the MBMS-Service-associated logical M2-connection Item IE for an MBMS service association, the eNB shall include the MCE MBMS M2AP ID IE in the corresponding MBMS-Service-associated logical M2-connection Item IE in the RESET ACKNOWLEDGE message.

- If the *eNB MBMS M2AP ID* IE is included in an *MBMS-Service-associated logical M2-connection Item* IE for an MBMS service association, the eNB shall include the *eNB MBMS M2AP ID* IE in the corresponding *MBMS-Service-associated logical M2-connection Item* IE in the RESET ACKNOWLEDGE message.

#### **Interactions with other procedures:**

If the RESET message is received, any other ongoing procedure (except another Reset procedure) shall be aborted.

#### 8.5.2.2 Reset Procedure Initiated from the eNB




Figure 8.5.2.2-1. Reset procedure initiated from the eNB. Successful operation.

In the event of a failure at the eNB, which has resulted in the loss of some or all transaction reference information, a RESET message shall be sent to the MCE.

At reception of RESET message the MCE shall release all allocated resources and MBMS-service contexts on M2 for the eNB.

After the MCE has released all assigned M2 resources and MBMS-service contexts for the eNB, the MCE shall respond with the RESET ACKNOWLEDGE message.

If the RESET message contains the MBMS-Service-associated logical M2-connection list IE, then:

- The MCE shall use the MCE MBMS M2AP ID IE and/or the eNB MBMS M2AP ID IE to explicitly identify the MBMS service association(s) to be reset.
- The MCE shall in the RESET ACKNOWLEDGE message include, for each MBMS service association to be reset, the MBMS-Service-associated logical M2-connection Item IE in the MBMS-Service-associated logical M2-connection list IE. The MBMS-Service-associated logical M2-connection Item IEs shall be in the same order as received in the RESET message and shall include also unknown MBMS-Service-associated logical M2-connections. Empty MBMS-Service-associated logical M2-connection Item IEs, received in the RESET message, may be omitted in the RESET ACKNOWLEDGE message.
- If the MCE MBMS M2AP ID IE is included in the MBMS-Service-associated logical M2-connection Item IE for an MBMS service association, the MCE shall include the MCE MBMS M2AP ID IE in the corresponding MBMS-Service-associated logical M2-connection Item IE in the RESET ACKNOWLEDGE message.
- If the eNB MBMS M2AP ID IE is included in an MBMS-Service-associated logical M2-connection Item IE for an MBMS service association, the MCE shall include the eNB MBMS M2AP ID IE in the corresponding MBMS-Service-associated logical M2-connection Item IE in the RESET ACKNOWLEDGE message.

#### Interactions with other procedures:

If the RESET message is received, any other ongoing procedure (except another Reset procedure) shall be aborted.

#### 8.5.3 Abnormal Conditions

#### 8.5.3.1 Abnormal Condition at the MCE

If the RESET message includes the *MBMS-Service-associated logical M2-connection list* IE, but neither the *MCE MBMS M2AP ID* IE nor the *eNB MBMS M2AP ID* IE is present for a *MBMS-Service-associated logical M2-connection Item* IE, then the MCE shall ignore the *MBMS-Service-associated logical M2-connection Item* IE. The MCE may return the empty *MBMS-Service-associated logical M2-connection Item* IE in the *MBMS-Service-associated logical M2-connection list* IE in the RESET ACKNOWLEDGE message.

#### 8.5.3.2 Abnormal Condition at the eNB

If the RESET message includes the *MBMS-Service-associated logical M2-connection list* IE, but neither the *MCE MBMS M2AP ID* IE nor the *eNB MBMS M2AP ID* IE is present for a *MBMS-Service-associated logical M2-connection Item* IE, then the eNB shall ignore the *MBMS-Service-associated logical M2-connection Item* IE. The eNB may return the empty *MBMS-Service-associated logical M2-connection Item* IE in the *MBMS-Service-associated logical M2-connection list* IE in the RESET ACKNOWLEDGE message.

#### 8.5.3.3 Crossing of Reset Messages

If Reset procedure is ongoing in eNB and the eNB receives a RESET message from the peer entity on the same M2 interface related to one or several MBMS service associations previously requested to be reset, indicated explicitly or implicitly in the received RESET message, the eNB shall respond with RESET ACKNOWLEDGE message as described in 8.5.2.1.

If Reset procedure is ongoing in MCE and the MCE receives a RESET message from the peer entity on the same M2 interface related to one or several MBMS service associations previously requested to be reset, indicated explicitly or implicitly in the received RESET message, the MCE shall respond with RESET ACKNOWLEDGE message as described in 8.5.2.2.

## 8.6 M2 Setup

#### 8.6.1 General

The purpose of the M2 Setup procedure is to exchange application level data needed for the eNB and MCE to interoperate correctly on the M2 interface and to configure MCCH related content on the BCCH for each of the cells controlled by the eNB which is foreseen to participate in MBMS service data transmission. This procedure shall be the first M2AP procedure triggered after the TNL association has become operational. The procedure uses non MBMS-service-associated signalling.

This procedure erases any existing application level in the eNB and the MCE and MCCH related BCCH data in all cells served by the eNB. This procedure also re-initialises the E-UTRAN M2AP MBMS service related contexts (if any) and erases all related signalling connections in the two nodes like a Reset procedure would do.

#### 8.6.2 Successful Operation




Figure 8.6.2-1. M2 Setup procedure. Successful operation.

The eNB initiates the procedure by sending a M2 SETUP REQUEST message including the appropriate data to the MCE. The eNB shall include in the M2 SETUP REQUEST message the cell(s) which are foreseen to participate in MBMS service data transmission.

The MCE responds with M2 SETUP RESPONSE message including the appropriate data. The MCE shall provide MCCH related BCCH data for all cells indicated in the M2 SETUP REQUEST message.

The exchanged data shall be stored in the respective node, MCCH related BCCH data broadcasted as provided by the MCE in the respective cell(s), and used for the duration of the TNL association.

When this procedure is finished the M2 interface is operational, all affected cells are ready for MBMS service data transmission and other M2 messages can be exchanged.

If the M2 SETUP REQUEST message contains the *eNB Name* IE the MCE may use this IE as a human readable name of the eNB.

If the M2 SETUP RESPONSE message contains the *MCE Name* IE the eNB may use this IE as a human readable name of the MCE. If the M2 SETUP RESPONSE message contains the *Cell Information List* IE the eNB shall broadcast the MCCH related BCCH configuration in the cells indicated in the IE. If the M2 SETUP RESPONSE message does not contain the *Cell Information List* IE the eNB shall not broadcast the MCCH related BCCH configuration in any cell.

#### 8.6.3 Unsuccessful Operation




Figure 8.6.2-1. M2 Setup procedure. Unsuccessful operation.

If the MCE can not accept the setup it should respond with a M2 SETUP FAILURE message and appropriate cause value.

If the M2 SETUP FAILURE messages include the *Time To Wait* IE the eNB shall wait at least for the indicated time before reinitiating the M2 setup towards the same MCE.

#### 8.6.4 Abnormal Conditions

Void.

## 8.7 eNB Configuration Update

#### 8.7.1 General

The purpose of the eNB Configuration Update procedure is to update application level configuration data needed for the eNB and MCE to interoperate correctly on the M2 interface.

The procedure uses non MBMS-service-associated signalling.

#### 8.7.2 Successful Operation




Figure 8.7.2-1. eNB Configuration Update procedure. Successful operation.

The eNB initiates the procedure by sending an ENB CONFIGURATION UPDATE message to the MCE including an appropriate set of updated configuration data that it has just taken into operational use. The eNB CONFIGURATION UPDATE message may contain:

- the Global eNB ID IE,
- the eNB Name IE,
- the eNB MBMS Configuration data per cell IE.

The MCE responds with ENB CONFIGURATION UPDATE ACKNOWLEDGE message to acknowledge that it successfully updated the configuration data. If the ENB CONFIGURATION ACKNOWLEDGE message contains the *Cell Information List* IE the eNB shall broadcast the MCCH related BCCH configuration in the cells indicated in the IE. If the ENB CONFIGURATION ACKNOWLEDGE message does not contain the *Cell Information List* IE the eNB shall not broadcast the MCCH related BCCH configuration in any cell.

The eNB may update the configured MBMS Services Areas and the MBSFN Synchronisation Area per cell:

- If the eNB includes the *E-UTRAN CGI* IE for a cell within the ENB CONFIGURATION UPDATE message, the MCE shall assume that the eNB does neither broadcast MCCH related data in the BCCH nor any MBMS service data in that cell any more.
- If the eNB includes the *eNB MBMS Configuration data Item* IE for a cell within the ENB CONFIGURATION UPDATE message, the MCE may decide to include in the ENB CONFIGURATION UPDATE ACKNOWLEDGE message MCCH related BCCH data for that cell.

The exchanged data shall be stored in the respective node, MCCH related BCCH data broadcasted as provided by the MCE in the respective cell(s), and used for the duration of the TNL association.

When this procedure is finished all affected cells are ready for MBMS service data transmission and other M2 messages can be exchanged.

#### 8.7.3 Unsuccessful Operation




Figure 8.7.3-1. eNB Configuration Update procedure. Unsuccessful operation.

If the MCE can not accept the update it shall respond with an ENB CONFIGURATION UPDATE FAILURE message and appropriate cause value.

If the ENB CONFIGURATION UPDATE FAILURE message includes the *Time To Wait* IE the eNB shall wait at least for the indicated time before reinitiating the ENB Configuration Update procedure towards the MCE. Both nodes shall continue to operate the M2 interface with their respective configuration data.

#### 8.7.4 Abnormal Conditions

Void.

## 8.8 MCE Configuration Update

#### 8.8.1 General

The purpose of the MCE Configuration Update procedure is to update application level configuration data needed for the eNB and MCE to interoperate correctly on the M2 interface and to re-configure MCCH related content on the BCCH for each of the cells controlled by the eNB which is foreseen to participate in MBMS service data transmission. The procedure uses non MBMS-service-associated signalling.

#### 8.8.2 Successful Operation




Figure 8.8.2-1. MCE Configuration Update procedure. Successful operation.

The MCE initiates the procedure by sending an MCE CONFIGURATION UPDATE message to the eNB including an appropriate set of updated configuration data. The MCE CONFIGURATION UPDATE message may contain:

- the Global MCE ID IE,

- the MCE Name IE,
- the MCCH related BCCH Configuration data per cell IE.

The eNB responds with the MCE CONFIGURATION UPDATE ACKNOWLEDGE message to acknowledge that it successfully updated the configuration data.

If the MCE CONFIGURATION UPDATE message contains the *Cell Information List* IE the eNB shall broadcast the MCCH related BCCH configuration in the cells indicated in the IE. If the MCE CONFIGURATION UPDATE message does not contain the *Cell Information List* IE the eNB shall not broadcast the MCCH related BCCH configuration in any cell.

#### 8.8.3 Unsuccessful Operation




Figure 8.78.3-1. MCE Configuration Update procedure. Unsuccessful operation.

If the eNB can not accept the update it shall respond with an MCE CONFIGURATION UPDATE FAILURE message and appropriate cause value.

If the MCE CONFIGURATION UPDATE FAILURE message includes the *Time To Wait* IE the MCE shall wait at least for the indicated time before reinitiating the MCE Configuration Update procedure towards the eNB. Both nodes shall continue to operate the M2 interface with their respective configuration data.

#### 8.8.4 Abnormal Conditions

Void.

#### 8.9 Error Indication

#### 8.9.1 General

The Error Indication procedure is initiated by a node to report detected errors in one incoming message, provided they cannot be reported by an appropriate failure message.

If the error situation arises due to reception of a message utilising MBMS-service-associated signalling, then the Error Indication procedure uses MBMS-service-associated signalling. Otherwise the procedure uses non MBMS-service-associated signalling.

#### 8.9.2 Successful Operation




Figure 8.9.2-1. Error Indication procedure, MCE originated. Successful operation.




Figure 8.9.2.1-2. Error Indication procedure, eNB originated. Successful operation.

When the conditions defined in clause 10 are fulfilled, the Error Indication procedure is initiated by an ERROR INDICATION message sent from the receiving node.

The ERROR INDICATION message shall contain at least either the Cause IE or the Criticality Diagnostics IE.

In case the Error Indication procedure is triggered by utilising MBMS-service-associated signalling the *MCE MBMS M2AP ID* IE and the *eNB MBMS M2AP ID* IE shall be included in the ERROR INDICATION message. If one or both of *MCE MBMS M2AP ID* IE and the *eNB MBMS M2AP ID* IE are not correct, the cause shall be set to appropriate value e.g. "Unknown or already allocated MCE MBMS M2AP ID" or "Unknown or inconsistent pair of MBMS M2AP ID".

#### 8.9.3 Abnormal Conditions

Void.

## 8.10 MBMS Session Update

#### 8.10.1 General

The purpose of the MBMS Session Update procedure is to inform the eNB about changing characteristics of the MBMS session e.g. change in the service area.

The procedure uses MBMS-Service-associated signalling.

#### 8.10.2 Successful Operation




Figure 8.10.2-1. MBMS Session Update procedure. Successful operation.

The MCE initiates the procedure by sending a MBMS SESSION UPDATE REQUEST message.

If the *MBMS Service Area* IE is included in the MBMS SESSION UPDATE REQUEST message, the eNB shall check the involvement of its cells in the new service area, update correspondingly the MBMS context and resources, join or leave the IP multicast if needed and send the MBMS SESSION UPDATE RESPONSE message. The eNB shall use the *TNL Information* IE included in the MBMS SESSION UPDATE REQUEST message to join the IP multicast when needed. If the MBMS SESSION UPDATE REQUEST message contains the *MBMS Session Identity* IE for an MBMS service, the eNB shall use it for broadcast of the MBMS Session Identity on air interface.

#### 8.10.3 Unsuccessful Operation




Figure 8.10.3-1. MBMS Session Update procedure. Unsuccessful operation.

If the eNB fails to update the MBMS session, it shall return a MBMS SESSION UPDATE FAILURE message.

#### 8.10.4 Abnormal Conditions

Void.

## 9 Elements for M2AP Communication

## 9.1 Message Functional Definition and Content

#### 9.1.1 General

Sub clauses 9.1 and 9.2 describe the structure of the messages and information elements required for the M2AP protocol in tabular format. Sub clause 9.3 provides the corresponding ASN.1 definition.

The following attributes are used for the tabular description of the messages and information elements: Presence, Range Criticality and Assigned Criticality.

#### 9.1.1 Message Contents

#### 9.1.1.1 Presence

All information elements in the message descriptions below are marked mandatory, optional or conditional according to table 4.

Table 4. Meaning of abbreviations used in M2AP messages

Abbreviation	Meaning
M	IEs marked as Mandatory (M) shall always be included in the
	message.
0	IEs marked as Optional (O) may or may not be included in the
	message.
С	IEs marked as Conditional (C) shall be included in a message only if the condition is satisfied. Otherwise the IE shall not be included.

#### 9.1.1.2 Criticality

Each Information Element or Group of Information Elements may have criticality information applied to it. Following cases are possible:

Table 5. Meaning of content within "Criticality" column

Abbreviation	Meaning		
-	No criticality information is applied explicitly.		
YES	Criticality information is applied. This is usable only for non-		
	repeatable IEs		
GLOBAL	The IE and all its repetitions together have one common criticality		
	information. This is usable only for repeatable IEs.		
EACH Each repetition of the IE has its own criticality information.			
	allowed to assign different criticality values to the repetitions. This is		
	usable only for repeatable IEs.		

#### 9.1.1.3 Range

The Range column indicates the allowed number of copies of repetitive IEs/IE groups.

#### 9.1.1.4 Assigned Criticality

This column provides the actual criticality information as defined in subclause 10.3.2 in [4], if applicable.

#### 9.1.2 MBMS SESSION START REQUEST

This message is sent by the MCE to establish an MBMS-service-associated logical M2-connection.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	reject
TMGI	M		9.2.3.3		YES	reject
MBMS Session Identity	0		9.2.3.4		YES	ignore
MBMS Service Area	M		9.2.3.6		YES	reject
TNL Information		1			YES	reject
>IP Multicast Address	М		IP Address 9.2.2.1		-	
>IP Source Address	M		IP Address 9.2.2.1		-	
>GTP DL TEID	M		GTP-TEID 9.2.2.2		-	

#### 9.1.3 MBMS SESSION START RESPONSE

This message is sent by the eNB to report the successful outcome of the request from the MBMS SESSION START REQUEST message.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	ignore
eNB MBMS M2AP ID	М		9.2.3.2		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.4 MBMS SESSION START FAILURE

This message is sent by the eNB to report the unsuccessful outcome of the request from the MBMS SESSION START REQUEST message.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	ignore
Cause	M		9.2.1.2		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.5 MBMS SESSION STOP REQUEST

This message is sent by the MCE to release the corresponding MBMS E-RAB and the MBMS-service-associated logical M2-connection.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	reject
eNB MBMS M2AP ID	M		9.2.3.2		YES	reject

#### 9.1.6 MBMS SESSION STOP RESPONSE

This message is sent by the eNB to acknowledge the MBMS SESSION STOP message.

Direction:  $eNB \rightarrow MCE$ .

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	ignore
eNB MBMS M2AP ID	M		9.2.3.2		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

## 9.1.7 MBMS SCHEDULING INFORMATION

This message is sent by the MCE to provide MCCH related information to the eNB.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1	•	YES	reject
MCCH Update Time	M		9.2.1.19		YES	reject
MBSFN Area		1			YES	reject
Configuration List						
>MBSFN Area		1 to			EACH	reject
Configuration Item IEs		<maxnoofmbsf< td=""><td></td><td></td><td></td><td>_</td></maxnoofmbsf<>				_
		Nareas>				
>>PMCH		1			YES	reject
Configuration List						
>>>PMCH		0 to			EACH	reject
Configuration Item		<maxnoofpmch< td=""><td></td><td></td><td></td><td></td></maxnoofpmch<>				
IEs		sperMBSFNarea				
		>				
>>>>PMCH	M		9.2.1.8		-	
Configuration						
>>>MBMS	M		9.2.1.9		-	
Session List per						
PMCH						
>>Subframes		1			YES	reject
Configuration List						
>>>Subframes		1 to			EACH	reject
Configuration Item		<maxnoofmbsf< td=""><td></td><td></td><td></td><td></td></maxnoofmbsf<>				
IEs		Nallocations>				
>>>>MBSFN	M		9.2.1.17		-	
Subframe						
Configuration						
>>Common Subframe	M		9.2.1.18		YES	reject
Allocation Period						
>>MBSFN Area ID	M		9.2.1.14		YES	reject

Range bound	Explanation
maxnoofMBSFNareas	Maximum no. of MBSFN areas served by a single eNB. The value
	for maxnoofMBSFNareas is 256.
maxnoofPMCHsperMBSFNarea	Maximum no. of PMCHs possible per MBSFN .The value for maxnoofMCHsperMBSFNarea is 15.
maxnoofMBSFNallocations	Maximum no. of MBSFN frame allocations with different offset. The value for maxnoofMBSFNallocations is 8.

## 9.1.8 MBMS SCHEDULING INFORMATION RESPONSE

This message is sent by the eNB to acknowledge the MBMS SCHEDULING INFORMATION message.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.1.1		YES	reject
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.9 **RESET**

This message is either sent by the eNB or the MCE and is used to request the M2 interface to be reset.

Direction:  $eNB \rightarrow MCE$ ,  $MCE \rightarrow eNB$ 

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Cause	M		9.2.1.2		YES	ignore
CHOICE Reset Type	M				YES	reject
>M2 interface						
>>Reset All	М		ENUMERAT ED (Reset all,)		_	_
>Part of M2 interface						
>>MBMS-Service- associated logical M2- connection list		1			_	_
>>>MBMS-Service - associated logical M2-connection Item		1 to < maxnoofIndividu alM2Connection sToReset >			EACH	reject
>>>eNB MBMS M2AP ID	0		9.2.3.2		_	_
>>>MCE MBMS M2AP ID	0		9.2.3.1		_	_

Range bound	Explanation			
maxnoofIndividualM2ConnectionsToReset	Maximum no. of MBMS-Service-associated logical M2-connections			
	allowed to reset in one message. Value is 256.			

## 9.1.10 RESET ACKNOWLEDGE

This message is sent as a response to the RESET message.

Direction: MCE  $\rightarrow$  eNB, eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MBMS-Service- associated logical M2- connection list		01			YES	ignore
>MBMS-Service - associated logical M2- connection Item		1 to < maxnoofIndividu alM2Connection sToReset >			EACH	ignore
>>eNB MBMS M2AP ID	0		9.2.3.2		_	_
>>MCE MBMS M2AP ID	0		9.2.3.1		_	_
Criticality Diagnostics	0		9.2.1.7		YES	ignore

Range bound	Explanation			
maxnoofIndividualM2ConnectionsToReset	Maximum no. of MBMS-Service-associated logical M2-connections			
	allowed to reset in one message. Value is 256.			

## 9.1.11 M2 SETUP REQUEST

This message is sent by the eNB to initiate the M2 interface instance.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.1.1		YES	reject
Global eNB ID	М		9.2.1.10		YES	reject
eNB Name	0		Printable String (1150,)		YES	ignore
eNB MBMS Configuration data per cell		1	, ,		YES	reject
>eNB MBMS Configuration data Item IEs		1 to <maxnoofcells></maxnoofcells>			EACH	reject
>>eNB MBMS Configuration data Item	М		9.2.1.12		-	

Range bound	Explanation
maxnoofCells	Maximum no. of cells that may be served by an eNB. The value for
	maxnoofCells is 256.

## 9.1.12 M2 SETUP RESPONSE

This message is sent by the MCE to complete the initiation of an M2 interface instance, providing MCCH related BCCH information.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.1.1		YES	reject
Global MCE ID	M		9.2.1.16		YES	reject
MCE Name	0		Printable String (1150,)		YES	ignore
MCCH related BCCH Configuration data per MBSFN area		1			YES	reject
>MCCH related BCCH Configuration data Item IEs		1 to <maxnoofmbsf Nareas&gt;</maxnoofmbsf 			EACH	reject
>> MCCH related BCCH Configuration Item	M		9.2.1.13		-	

Range bound	Explanation
maxnoofMBSFNareas	Maximum no. of MBSFN areas served by a single eNB. The value
	for maxnoofMBSFNareas is 256.

## 9.1.13 M2 SETUP FAILURE

This message is sent by the MCE to indicate non acceptance of the M2 Setup Request.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Cause	M		9.2.1.2		YES	ignore
Time To Wait	0		9.2.1.15		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.14 ENB CONFIGURATION UPDATE

This message is sent by the eNB to indicate that application level configuration data has changed in the eNB.

Direction:  $eNB \rightarrow MCE$ .

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Global eNB ID	0		9.2.1.10		YES	reject
eNB Name	0		Printable String (1150,)		YES	ignore
eNB MBMS Configuration data per cell		01			YES	reject
>eNB MBMS Configuration data Item IEs		1 to <maxnoofcells></maxnoofcells>			EACH	reject
>>CHOICE eNB ID	M					
>>>eNB MBMS Configuration data Item			9.2.1.12			
>>>E-UTRAN CGI			9.2.1.11			

Range bound	Explanation
maxnoofCells	Maximum no. of cells that may be served by an eNB. The value for
	maxnoofCells is 256.

## 9.1.15 ENB CONFIGURATION UPDATE ACKNOWLEDGE

This message acknowledges the ENB CONFIGURATION UPDATE message.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCCH related BCCH		01			YES	reject
Configuration data per						
MBSFN area						
>MCCH related BCCH		1 to			EACH	reject
Configuration data Item		<maxnoofmbsf< td=""><td></td><td></td><td></td><td></td></maxnoofmbsf<>				
IEs		Nareas>				
>>MCCH related	M		9.2.1.13		-	
BCCH Configuration						
Item						
Criticality Diagnostics	0		9.2.1.7		YES	ignore

Range bound	Explanation
maxnoofMBSFNareas	Maximum no. of MBSFN areas served by a single eNB. The value
	for maxnoofMBSFNareas is 256.

## 9.1.16 ENB CONFIGURATION UPDATE FAILURE

This message is sent by the MCE to indicate non acceptance of the eNB Configuration Update.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Cause	M		9.2.1.2		YES	ignore
Time To Wait	0		9.2.1.15		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.17 MCE CONFIGURATION UPDATE

This message is sent by the MCE to indicate that application level configuration data has changed in the MCE.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Global MCE ID	0		9.2.1.16		YES	reject
MCE Name	0		Printable String (1150,)		YES	ignore
MCCH related BCCH Configuration data per MBSFN area		01			YES	reject
>MCCH related BCCH Configuration data Item IEs		1 to <maxnoofmbsf Nareas&gt;</maxnoofmbsf 			EACH	reject
>>MCCH related BCCH Configuration Item	M		9.2.1.13		-	

Range bound	Explanation
maxnoofMBSFNareas	Maximum no. of MBSFN areas served by a single eNB. The value
	for maxnoofMBSFNareas is 256.

#### 9.1.18 MCE CONFIGURATION UPDATE ACKNOWLEDGE

This message acknowledges the MCE CONFIGURATION UPDATE message.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.19 MCE CONFIGURATION UPDATE FAILURE

This message is sent by the eNB to indicate non acceptance of the MCE Configuration Update.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
Cause	M		9.2.1.2		YES	ignore
Time To Wait	0		9.2.1.15		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.20 ERROR INDICATION

This message is sent by both the MCE and the eNB and is used to indicate that some error has been detected in the node.

Direction: MCE  $\rightarrow$  eNB and eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	ignore
MCE MBMS M2AP ID	0		9.2.3.1		YES	ignore
eNB MBMS M2AP ID	0		9.2.3.2		YES	ignore
Cause	0		9.2.1.2		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

#### 9.1.21 MBMS SESSION UPDATE REQUEST

This message is sent by the MCE to the eNB in order to inform of the change of session characteristics e.g. service area of one MBMS service session.

Direction: MCE  $\rightarrow$  eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	reject
eNB MBMS M2AP ID	M		9.2.3.2		YES	reject
TMGI	M		9.2.3.3		YES	reject
MBMS Session Identity	0		9.2.3.4		YES	ignore
MBMS Service Area	0		9.2.3.6		YES	ignore
TNL Information	0				YES	reject
>IP Multicast Address	M		9.2.2.1		-	
>IP Source Address	M		IP Address		-	
			9.2.2.1			
>GTP DL TEID	M		GTP-TEID		-	
			9.2.2.2			

#### 9.1.22 MBMS SESSION UPDATE RESPONSE

This message is sent by the eNB to report the successful outcome of the request from the MBMS SESSION UPDATE REQUEST message.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	ignore
eNB MBMS M2AP ID	M		9.2.3.2		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

## 9.1.23 MBMS SESSION UPDATE FAILURE

This message is sent by the eNB to report the unsuccessful outcome of the request from the MBMS SESSION UPDATE REQUEST message.

Direction: eNB  $\rightarrow$  MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.1.1		YES	reject
MCE MBMS M2AP ID	M		9.2.3.1		YES	ignore
eNB MBMS M2AP ID	М		9.2.3.2		YES	ignore
Cause	М		9.2.1.2		YES	ignore
Criticality Diagnostics	0		9.2.1.7		YES	ignore

## 9.2 Information Element Definitions

## 9.2.1 Radio Network Layer Related IEs

#### 9.2.1.1 Message Type

The Message Type IE uniquely identifies the message being sent. It is mandatory for all messages.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Message Type				Assumed
				max no of
				messages is 256.
>Procedure Code	M		(Session Start, Session Stop, MBMS Scheduling Information, Reset, M2 Setup, eNB Configuration Update, MCE Configuration Update, Error Indication, Session Update,)	
>Type of Message	М		CHOICE (Initiating Message, Successful Outcome, Unsuccessful Outcome,)	

#### 9.2.1.2 Cause

The purpose of the *Cause IE* is to indicate the reason for a particular event for the M2AP protocol.

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	
CHOICE Cause Group	М			•	
>Radio					
Network Layer					
>>Radio Network Layer Cause	М		ENUMERATED (Unknown or already allocated MCE MBMS M2AP ID, Unknown or already allocated eNB MBMS M2AP ID, Unknown or inconsistent pair of MBMS M2AP IDs, Radio resources not available, Interaction with other procedure, Unspecified,)		
>Transport Layer			,		
>>Transport Layer Cause	М		ENUMERATED (Transport Resource Unavailable, Unspecified,)		
> NAS					
>> NAS Cause	М		ENUMERATED (Unspecified,)		
>Protocol					
>>Protocol Cause	M		ENUMERATED (Transfer Syntax Error, Abstract Syntax Error (Reject), Abstract Syntax Error (Ignore and Notify), Message not Compatible with Receiver State, Semantic Error, Abstract Syntax Error (Falsely Constructed Message), Unspecified,)		
>Misc					
>>Miscellan eous Cause	М		ENUMERATED (Control Processing Overload, Hardware Failure, O&M Intervention, Unspecified,)		

The meaning of the different cause values is described in the following table. In general, "not supported" cause values indicate that the related capability is missing. On the other hand, "not available" cause values indicate that the related capability is present, but insufficient resources were available to perform the requested action.

Radio Network Layer cause	Meaning		
Unknown or already allocated MCE MBMS M2AP ID	The action failed because the MCE MBMS M2AP ID is either unknown, or (for a first message received at the eNB) is known and already allocated to an existing MBMS service related context.		
Unknown or already allocated eNB MBMS M2AP ID	The action failed because the eNB MBMS M2AP ID is either unknown, or (for a first message received at the MCE) is known and already allocated to an existing context.		
Unknown or inconsistent pair of MBMS M2AP IDs	The action failed because both MBMS M2AP IDs are unknown, or are known but do not define a single MBMS context.		
Radio resources not available	No requested radio resources are available		
Interaction with other procedure	The action is due to an ongoing interaction with another procedure		
Unspecified	Sent for radio network layer cause when none of the specified cause values applies		

Transport Layer cause	Meaning		
Transport Resource Unavailable	The required transport resources are not available		
Unspecified	Sent for transport network layer cause when none of the		
	specified cause values applies.		

NAS cause	Meaning			
Unspecified	Sent for NAS cause when none of the specified cause values			
	applies.			

Protocol cause	Meaning		
Transfer Syntax Error	The received message included a transfer syntax error.		
Abstract Syntax Error (Reject)	The received message included an abstract syntax error and the concerning criticality indicated "reject".		
Abstract Syntax Error (Ignore And Notify)	The received message included an abstract syntax error and the concerning criticality indicated "ignore and notify".		
Message Not Compatible With Receiver State	The received message was not compatible with the receiver state.		
Semantic Error	The received message included a semantic error.		
Abstract Syntax Error (Falsely	The received message contained IEs or IE groups in wrong		
Constructed Message)	order or with too many occurrences.		
Unspecified	Sent for protocol cause when none of the specified cause values applies.		
Miscellaneous cause	Meaning		
Control Processing Overload	Control processing overload		
Hardware Failure	Action related to hardware failure		
O&M Intervention	The action is due to O&M intervention.		
Unspecified	Sent when none of the above cause values applies and the cause is not related to any of the categories Radio Network Layer, Transport Network Layer, NAS or Protocol.		

( )	.2.1	יי ו		'oid
ч		1 7		( )   ( )
·	. – .		v	OIG

9.2.1.4 Void

9.2.1.5 Void

9.2.1.6 Void

## 9.2.1.7 Criticality Diagnostics

The *Criticality Diagnostics* IE is sent by the eNB or the MCE when parts of a received message have not been comprehended or were missing, or if the message contained logical errors. When applicable, it contains information about which IEs were not comprehended or were missing.

For further details on how to use the *Criticality Diagnostics* IE, (see section 10 in [4]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Procedure Code	0		INTEGER (0255)	Procedure Code is to be used if Criticality Diagnostics is part of Error Indication procedure, and not within the response message of the same procedure that caused the error
Triggering Message	0		ENUMERATED( initiating message, successful outcome, unsuccessful outcome)	The Triggering Message is used only if the Criticality Diagnostics is part of Error Indication procedure.
Procedure Criticality	0		ENUMERATED( reject, ignore, notify)	This Procedure Criticality is used for reporting the Criticality of the Triggering message (Procedure).
Information Element Criticality Diagnostics		0 to <maxnoof errors&gt;</maxnoof 		
>IE Criticality	М		ENUMERATED( reject, ignore, notify)	The IE Criticality is used for reporting the criticality of the triggering IE. The value 'ignore' shall not be used.
>IE ID	М		INTEGER (065535)	The IE ID of the not understood or missing IE
>Type of Error	M		ENUMERATED( not understood, missing,)	

Range bound	Explanation			
maxnooferrors	Maximum no. of IE errors allowed to be reported with a single			
	message. The value for maxnooferrors is 256.			

# 9.2.1.8 PMCH Configuration

This information element provided PMCH configuration related content for MCCH.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Allocated Subframes End	М		INTEGER (01535)	Encoded as the sf-AllocEnd IE in[11]
Modulation and Coding Scheme	М		INTEGER (028)	Encoded as the dataMCS IE in[11]
MCH Scheduling Period	М		ENUMERAT ED (rf8, rf16, rf32, rf64, rf128, rf256, rf512, rf1024)	Encoded as the mch- SchedulingPeriod IE in [11]

# 9.2.1.9 MBMS Session List per PMCH

This information element provided PMCH configuration related content for MCCH.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MBMS Session List per PMCH Item IEs		1 to <maxnoofsession sPerPMCH&gt;</maxnoofsession 		
>MBMS Service Identity	M		TMGI 9.2.3.3	
>LCID	M		INTEGER (028)	Logical Channel Identity

Range bound	Explanation		
maxnoofSessionsPerPMCH	Maximum no. of Sessions per PMCH. The value for		
	maxnoofSessionsPerPMCH is 29.		

#### 9.2.1.10 Global eNB ID

This information element is used to globally identify an eNB (see [2]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.2.3.7	
CHOICE eNB ID	M			
>Macro eNB ID			BIT STRING (20)	Equal to the 20 leftmost bits of the <i>Cell Identity</i> IE contained in the <i>E-UTRAN CGI</i> IE (see section 9.2.1.11) of each cell served by the eNB

#### 9.2.1.11 E-UTRAN CGI

This information element is used to globally identify a cell (see [2]).

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.2.3.7	
Cell Identity	M		BIT STRING (28)	The 20 leftmost bits of the Cell Identity correspond to the eNB ID ( <i>Global eNB ID</i> IE defined in section 9.2.1.10).

## 9.2.1.12 eNB MBMS Configuration data Item IEs

This information element provides MBMS related configuration information from the eNB.

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
E-UTRAN CGI	M		9.2.1.11	
MBSFN Synchronisation	M		9.2.1.20	
Area Id				
MBMS Service Area List		1		
>MBMS Service Area		1 to		
Item		<maxnoofmbmss< td=""><td></td><td></td></maxnoofmbmss<>		
		erviceAreasPerCe		
		ll>		
>>MBMS Service Area	M		9.2.3.6	·

Range bound	Explanation
maxnoofMBMSServiceAreasPerCell	Maximum no. of Service Areas per cell. The value for
	maxnoofMBMSServiceAreasPerCell is 256.

## 9.2.1.13 MCCH related BCCH Configuration Item

This information element provides MCCH related BCCH configuration information to the eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MBSFN Area Id	M		9.2.1.14	
PDCCH Length	M		ENUMERAT	This IE is encoded along the
			ED (s1,	number of OFDM symbols for
			s2,)	PDCCH as of table 6.7-1. in [12].
Repetition Period	M		ENUMERAT	The same encoding as the
			ED (rf32,	mcch-RepetitionPeriod in
			rf64, rf128,	mcch-Config as specified in
			rf256)	[11]
Offset	M		INTEGER	The same encoding as the
			(010)	mcch-Offset in mcch-Config as specified in [11]
Modification Period	М		ENUMERAT	The same encoding as the
cacaci. i ciica			ED (rf512,	mcch-ModificationPeriod in
			rf1024)	mcch-Config as specified in
			,	[11]
Subframe Allocation Info	М		BIT STRING	The same encoding as the sf-
			(SIZE(6))	AllocInfo specified in [11]
Modulation and Coding	M		ENUMERAT	The same encoding as the
Scheme			ED (n2, n7,	signallingMCS specified in [11]
			n13, n19)	
Cell Information List		01		
>Cell Information		1 to		
		<maxnoofcells></maxnoofcells>		
>>E-UTRAN CGI	M		9.2.1.11	
>>Cell Reservation Info	M		ENUMERAT	
			ED	
			(reservedCel	
			_ I,	
			nonReserve	
			dCell,)	

Range bound	Explanation
maxnoofCells	Maximum no. of cells that may be served by an eNB. The value for maxnoofCells is 256.

#### 9.2.1.14 MBSFN Area Id

This IE defines the MBSFN Area Id.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MBSFN Area Id	M		INTEGER	The same encoding as the
			(0255)	mbsfn-Areald specified in [11].

#### 9.2.1.15 Time to Wait

This IE defines the minimum allowed waiting time.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Time to Wait	M		ENUMERAT	
			ED(1s, 2s,	
			5s, 10s, 20s,	
			60s,)	

#### 9.2.1.16 Global MCE ID

This IE is used to globally identify an MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN Identity	M		9.2.3.8	
MCE ID	M		OCTET	
			STRING(SIZ	
			E(2))	

#### 9.2.1.17 MBSFN Subframe Configuration

This IE indicates the MBSFN Subframe Configuration, as defined in [11].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Radio Frame Allocation Period	M		ENUMERAT ED (n1, n2, n4, n8, n16, n32)	Semantics along the IE definition in [11]
Radio Frame Allocation Offset	М		INTEGER (07)	Semantics along the IE definition in [11]
CHOICE Subframe Allocation	М			
>One Frame				
>>One Frame Item	М		BIT STRING (SIZE(6))	Semantics along the IE definition in [11]
>Four Frames				
>> Four Frame Item	М		BIT STRING (SIZE(24))	Semantics along the IE definition in [11]

#### 9.2.1.18 Common Subframe Allocation Period

This IE defines the period during which allocated subframes are divided between PMCHs configured for the MBSFN area, see [11].

IE/Group Name	Presence	Range	IE type and	Semantics description
			reference	
Common Subframe	М		ENUMERAT	The same encoding as the
Allocation Period			ED (rf4, rf8,	commonSF-AllocPeriod as
			rf6, rf32,	specified in [11]
			rf64, rf128,	
			rf256)	

#### 9.2.1.19 MCCH Update Time

This IE indicates the time at which the eNB shall apply the update of the MCCH as specified in [3].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MCCH Update Time	М		INTEGER (0255)	This IE indicates the modification period, as an absolute value, from when the MCCH update should be applied.  Note: The duration of the modification period is configured in eNB and MCE:

#### 9.2.1.20 MBSFN Synchronisation Area Id

This IE defines the MBSFN Synchronisation Area Identity as specified in [3].

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MBSFN Synchronisation	М		INTEGER	The MBSFN Synchronisation
Area Id			(065535)	Area is defined in [3]

#### 9.2.2 Transport Network Layer Related IEs

#### 9.2.2.1 IP Address

This information element is an IP address.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
IP Address	M		OCTET STRING (416)	The Radio Network Layer is not supposed to interpret the address information. It should pass it to the transport layer for interpretation. For details on the IP Address, see ref. [13].

#### 9.2.2.2 GTP-TEID

This information element is the GTP Tunnel Endpoint Identifier to be used for the user plane transport between eNB and the MBMS-GW.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
GTP TEID	M		OCTET STRING (4)	
			31KING (4)	

#### 9.2.3 NAS Related IEs

#### 9.2.3.1 MCE MBMS M2AP ID

The MCE MBMS M2AP ID uniquely identifies the MBMS Service association over the M2 interface within the MCE.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MCE MBMS M2AP ID	М		INTEGER (0 2 <sup>24</sup> -1)	

#### 9.2.3.2 eNB MBMS M2AP ID

The eNB MBMS M2AP ID uniquely identifies the MBMS Service association over the M2 interface within the eNB.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
eNB MBMS M2AP ID	M		INTEGER (0	
			65535)	

#### 9.2.3.3 TMGI

The TMGI uniquely identifies the MBMS Bearer Service.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
TMGI				
>PLMN identity	M		9.2.3.7	
>Service ID	М		OCTET	
			STRING	
			(SIZE (3))	

#### 9.2.3.4 MBMS Session Identity

The MBMS Session Identity identifies the session of an MBMS Bearer Service in E-UTRAN and is used by the UE to recognise repetitions of the session.

This IE is transparent to RAN.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MBMS Session Identity	М		OCTET STRING	Coded same way as the MBMS Session Identity IE as
			(SIZE (1))	defined in [9].

#### 9.2.3.5 Void

#### 9.2.3.6 MBMS Service Area

The MBMS Service Area IE consists of a list of one or several MBMS Service Area Identities where each MBMS Service Area Identity is frequency agnostic and can be mapped onto one or more cells.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
MBMS Service Area	M		OCTET STRING	Value part coded per MBMS Service Area AVP as defined in [9].

#### 9.2.3.7 PLMN Identity

This information element indicates the PLMN Identity.

IE/Group Name	Presence	Range	IE type and reference	Semantics description
PLMN identity	M		OCTET STRING (SIZE (3))	- digits 0 to 9, encoded 0000 to 1001, - 1111 used as filler digit, two digits per octet, - bits 4 to 1 of octet n encoding digit 2n-1 - bits 8 to 5 of octet n encoding digit 2n  -The Selected PLMN identity consists of 3 digits from MCC followed by either -a filler digit plus 2 digits from MNC (in case of 2 digit MNC) or -3 digits from MNC (in case of a 3 digit MNC).

# 9.3 Message and Information Element Abstract Syntax (with ASN.1)

#### 9.3.1 General

M2AP ASN.1 definition conforms with [5] and [6].

Sub clause 9.3 presents the Abstract Syntax of the M2AP protocol with ASN.1. In case there is contradiction between the ASN.1 definition in this sub clause and the tabular format in sub clause 9.1 and 9.2, the ASN.1 shall take precedence, except for the definition of conditions for the presence of conditional elements, in which the tabular format shall take precedence.

The ASN.1 definition specifies the structure and content of M2AP messages. M2AP messages can contain any IEs specified in the object set definitions for that message without the order or number of occurrence being restricted by ASN.1. However, for this version of the standard, a sending entity shall construct an M2AP message according to the PDU definitions module and with the following additional rules (Note that in the following IE means an IE in the object set with an explicit id. If one IE needed to appear more than once in one object set, then the different occurrences have different IE ids):

- IEs shall be ordered (in an IE container) in the order they appear in object set definitions.
- Object set definitions specify how many times IEs may appear. An IE shall appear exactly once if the presence field in an object has value "mandatory". An IE may appear at most once if the presence field in an object has value "optional" or "conditional". If in a tabular format there is multiplicity specified for an IE (i.e. an IE list) then in the corresponding ASN.1 definition the list definition is separated into two parts. The first part defines an IE container list in which the list elements reside. The second part defines list elements. The IE container list appears as an IE of its own. For this version of the standard an IE container list may contain only one kind of list elements.

If an M2AP message that is not constructed as defined above is received, this shall be considered as Abstract Syntax Error, and the message shall be handled as defined for Abstract Syntax Error in clause 10.


### 9.3.2 Usage of Private Message Mechanism for Non-standard Use

The private message mechanism for non-standard use may be used:

- for special operator (and/or vendor) specific features considered not to be part of the basic functionality, i.e. the functionality required for a complete and high-quality specification in order to guarantee multivendor inter-operability.
- by vendors for research purposes, e.g. to implement and evaluate new algorithms/features before such features are proposed for standardisation.

The private message mechanism shall not be used for basic functionality. Such functionality shall be standardised.

# 9.3.3 Elementary Procedure Definitions



```
M2AP-PDU-Descriptions {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
eps-Access (21) modules (3) m2ap (4) version1 (1) m2ap-PDU-Descriptions (0) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
__ ********************
-- IE parameter types from other modules.
__ *********************
IMPORTS
   Criticality,
   ProcedureCode
FROM M2AP-CommonDataTypes
   SessionStartRequest,
   SessionStartResponse,
   SessionStartFailure.
   SessionStopRequest,
   SessionStopResponse,
   SessionUpdateRequest,
   SessionUpdateResponse,
   SessionUpdateFailure,
   MbmsSchedulingInformation,
   MbmsSchedulingInformationResponse,
   ErrorIndication,
   Reset,
   ResetAcknowledge,
   M2SetupRequest,
   M2SetupResponse,
   M2SetupFailure,
   ENBConfigurationUpdate,
   ENBConfigurationUpdateAcknowledge,
   ENBConfigurationUpdateFailure,
   MCEConfigurationUpdate,
   MCEConfigurationUpdateAcknowledge,
   MCEConfigurationUpdateFailure,
   PrivateMessage
FROM M2AP-PDU-Contents
   id-sessionStart,
   id-sessionStop,
   id-sessionUpdate,
   id-mbmsSchedulingInformation,
   id-errorIndication,
   id-reset,
   id-m2Setup,
   id-eNBConfigurationUpdate,
```

```
id-mCEConfigurationUpdate,
   id-privateMessage
FROM M2AP-Constants:
  Interface Elementary Procedure Class
M2AP-ELEMENTARY-PROCEDURE ::= CLASS {
    &InitiatingMessage
    &SuccessfulOutcome
                                   OPTIONAL,
    &UnsuccessfulOutcome
                                      OPTIONAL,
    &procedureCode
                           ProcedureCode UNIQUE,
    &criticality
                                          DEFAULT ignore
                           Criticality
WITH SYNTAX {
                           &InitiatingMessage
   INITIATING MESSAGE
    [SUCCESSFUL OUTCOME
                           &SuccessfulOutcomel
                               &UnsuccessfulOutcome]
    [UNSUCCESSFUL OUTCOME
    PROCEDURE CODE
                           &procedureCode
    [CRITICALITY
                           &criticality]
-- Interface PDU Definition
M2AP-PDU ::= CHOICE {
   initiatingMessage
                      InitiatingMessage,
                       SuccessfulOutcome,
    successfulOutcome
   unsuccessfulOutcome UnsuccessfulOutcome,
InitiatingMessage ::= SEQUENCE
   procedureCode M2AP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}),
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}{@procedureCode}),
   criticality
                   M2AP-ELEMENTARY-PROCEDURE.&criticality
   value
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}{@procedureCode})
                   M2AP-ELEMENTARY-PROCEDURE.&InitiatingMessage
SuccessfulOutcome ::= SEQUENCE {
   procedureCode M2AP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}),
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}{@procedureCode}),
   criticality
                   M2AP-ELEMENTARY-PROCEDURE.&criticality
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}{@procedureCode})
   value
                   M2AP-ELEMENTARY-PROCEDURE. & Successful Outcome
UnsuccessfulOutcome ::= SEQUENCE {
   ({M2AP-ELEMENTARY-PROCEDURES}),
   criticality
                   M2AP-ELEMENTARY-PROCEDURE.&criticality
                                                                  ({M2AP-ELEMENTARY-PROCEDURES}{@procedureCode}),
```

```
M2AP-ELEMENTARY-PROCEDURE.&UnsuccessfulOutcome
                                                                ({M2AP-ELEMENTARY-PROCEDURES}{@procedureCode})
   value
     ****************
-- Interface Elementary Procedure List
M2AP-ELEMENTARY-PROCEDURES M2AP-ELEMENTARY-PROCEDURE ::= {
   M2AP-ELEMENTARY-PROCEDURES-CLASS-1
   M2AP-ELEMENTARY-PROCEDURES-CLASS-2
M2AP-ELEMENTARY-PROCEDURES-CLASS-1 M2AP-ELEMENTARY-PROCEDURE ::=
   sessionStart
   sessionStop
   sessionUpdate
   mbmsSchedulingInformation
   reset
   m2Setup
   eNBConfigurationUpdate
   mCEConfigurationUpdate
M2AP-ELEMENTARY-PROCEDURES-CLASS-2 M2AP-ELEMENTARY-PROCEDURE ::=
   errorIndication
   privateMessage
-- Interface Elementary Procedures
sessionStart M2AP-ELEMENTARY-PROCEDURE ::= {
                          SessionStartRequest
   INITIATING MESSAGE
   SUCCESSFUL OUTCOME
                          SessionStartResponse
   UNSUCCESSFUL OUTCOME SessionStartFailure
   PROCEDURE CODE
                          id-sessionStart
   CRITICALITY
                          reject
sessionStop M2AP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE
                          SessionStopRequest
   SUCCESSFUL OUTCOME
                          SessionStopResponse
   PROCEDURE CODE
                          id-sessionStop
```

```
CRITICALITY
                            reject
sessionUpdate M2AP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            SessionUpdateRequest
                            SessionUpdateResponse
    SUCCESSFUL OUTCOME
                            SessionUpdateFailure
    UNSUCCESSFUL OUTCOME
                            id-sessionUpdate
    PROCEDURE CODE
    CRITICALITY
                            reject
mbmsSchedulingInformation M2AP-ELEMENTARY-PROCEDURE ::= {
                            MbmsSchedulingInformation
    INITIATING MESSAGE
    SUCCESSFUL OUTCOME
                            MbmsSchedulingInformationResponse
    PROCEDURE CODE
                            id-mbmsSchedulingInformation
    CRITICALITY
                            reject
errorIndication M2AP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            ErrorIndication
    PROCEDURE CODE
                            id-errorIndication
    CRITICALITY
                            ignore
reset M2AP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            Reset
    SUCCESSFUL OUTCOME
                            ResetAcknowledge
    PROCEDURE CODE
                            id-reset
                            reject
    CRITICALITY
m2Setup M2AP-ELEMENTARY-PROCEDURE ::= {
    INITIATING MESSAGE
                            M2SetupRequest
    SUCCESSFUL OUTCOME
                            M2SetupResponse
                            M2SetupFailure
    UNSUCCESSFUL OUTCOME
                            id-m2Setup
    PROCEDURE CODE
    CRITICALITY
                            reject
eNBConfigurationUpdate
                            M2AP-ELEMENTARY-PROCEDURE ::= {
                            ENBConfigurationUpdate
    INITIATING MESSAGE
                            ENBConfigurationUpdateAcknowledge
    SUCCESSFUL OUTCOME
                            ENBConfigurationUpdateFailure
    UNSUCCESSFUL OUTCOME
                            id-eNBConfigurationUpdate
    PROCEDURE CODE
    CRITICALITY
                            reject
                            M2AP-ELEMENTARY-PROCEDURE ::= {
mCEConfigurationUpdate
    INITIATING MESSAGE
                            MCEConfigurationUpdate
                            MCEConfigurationUpdateAcknowledge
    SUCCESSFUL OUTCOME
                            MCEConfigurationUpdateFailure
    UNSUCCESSFUL OUTCOME
    PROCEDURE CODE
                            id-mCEConfigurationUpdate
    CRITICALITY
                            reject
```

#### 9.3.4 PDU Definitions

```
__ ********************
-- PDU definitions for M2AP.
__ *********************
M2AP-PDU-Contents {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
eps-Access (21) modules (3) m2ap (4) version1 (1) m2ap-PDU-Contents (1) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
     ****************
-- IE parameter types from other modules.
IMPORTS
   Cause,
   CriticalityDiagnostics,
   ENB-MBMS-Configuration-data-Item,
   ENB-MBMS-Configuration-data-ConfigUpdate-Item,
   ENB-MBMS-M2AP-ID,
   ENBname,
   GlobalENB-ID,
   GlobalMCE-ID,
   MBSFN-Area-ID,
   MBMS-Service-Area,
   MBMS-Session-ID,
   MBMSsessionListPerPMCH-Item,
   MBMS-Service-associatedLogicalM2-ConnectionItem,
   MBSFN-Subframe-Configuration,
   MCCH-Update-Time,
   MCCHrelatedBCCH-ConfigPerMBSFNArea-Item,
   MCE-MBMS-M2AP-ID,
   MCEname,
   PMCH-Configuration,
   Common-Subframe-Allocation-Period,
```

```
TimeToWait,
    TMGI.
   TNL-Information
FROM M2AP-IEs
    PrivateIE-Container{},
    ProtocolExtensionContainer{}.
    ProtocolIE-Container{},
    ProtocolIE-ContainerList{},
    ProtocolIE-ContainerPair(),
    ProtocolIE-ContainerPairList{},
    ProtocolIE-Single-Container{},
   M2AP-PRIVATE-IES,
   M2AP-PROTOCOL-EXTENSION,
    M2AP-PROTOCOL-IES,
    M2AP-PROTOCOL-IES-PAIR
FROM M2AP-Containers
    id-MCE-MBMS-M2AP-ID,
    id-ENB-MBMS-M2AP-ID,
    id-TMGI,
    id-MBMS-Session-ID,
    id-MBMS-Service-Area,
    id-TNL-Information,
    id-CriticalityDiagnostics,
    id-Cause,
    id-MBSFN-Area-Configuration-List,
    id-MBSFN-Subframe-Configuration-Item,
    id-MBSFN-Subframe-Configuration-List,
    id-MCCH-Update-Time,
    id-PMCH-Configuration-List,
    id-PMCH-Configuration-Item,
    id-Common-Subframe-Allocation-Period,
    id-GlobalENB-ID.
    id-ENBname,
    id-ENB-MBMS-Configuration-data-List,
    id-ENB-MBMS-Configuration-data-Item,
    id-GlobalMCE-ID,
    id-MCEname,
    id-MCCHrelatedBCCH-ConfigPerMBSFNArea,
    id-MCCHrelatedBCCH-ConfigPerMBSFNArea-Item,
    id-TimeToWait,
    id-ENB-MBMS-Configuration-data-List-ConfigUpdate,
    id-ENB-MBMS-Configuration-data-ConfigUpdate-Item,
    id-MBSFN-Area-ID,
    id-ResetType,
    id-MBMS-Service-associatedLogicalM2-ConnectionItem,
    id-MBMS-Service-associatedLogicalM2-ConnectionListResAck,
    maxnoofMBSFN-Allocations,
    maxnoofMBSFNareas,
    maxnoofPMCHsperMBSFNarea,
    maxnoofCells,
    maxnoofMBMSServiceAreasPerCell,
```

```
maxnoofSessionsPerPMCH,
   maxnooferrors.
   maxNrOfIndividualM2ConnectionsToReset
FROM M2AP-Constants:
-- SESSION START REQUEST
__ ********************
SessionStartRequest ::= SEQUENCE {
   protocolIEs
                                ProtocolIE-Container
                                                         {{SessionStartRequest-IEs}},
   . . .
SessionStartRequest-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                           CRITICALITY reject TYPE MCE-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory
     ID id-TMGI
                                           CRITICALITY reject TYPE TMGI
                                                                                             PRESENCE mandatory
     ID id-MBMS-Session-ID
                                           CRITICALITY ignore TYPE MBMS-Session-ID
                                                                                             PRESENCE optional
                                           CRITICALITY reject TYPE MBMS-Service-Area
     ID id-MBMS-Service-Area
                                                                                             PRESENCE mandatory
   { ID id-TNL-Information
                                           CRITICALITY reject TYPE TNL-Information
                                                                                             PRESENCE mandatory
__ *******************************
-- SESSION START RESPONSE
__ *********************
SessionStartResponse ::= SEQUENCE {
                                                         {{ SessionStartResponse-IEs}},
   protocolIEs
                                ProtocolIE-Container
   . . .
SessionStartResponse-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                           CRITICALITY ignore TYPE MCE-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory
     ID id-ENB-MBMS-M2AP-ID
                                           CRITICALITY ignore TYPE ENB-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory
    ID id-CriticalityDiagnostics
                                           CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                             PRESENCE optional },
-- SESSION START FAILURE
__ ********************
SessionStartFailure ::= SEQUENCE {
   protocolIEs
                                ProtocolIE-Container
                                                         {{ SessionStartFailure-IEs}},
   . . .
```

```
SessionStartFailure-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                           CRITICALITY ignore TYPE MCE-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory
     ID id-Cause
                                           CRITICALITY ignore TYPE Cause
                                                                                             PRESENCE mandatory
    ID id-CriticalityDiagnostics
                                                                                             PRESENCE optional },
                                           CRITICALITY ignore TYPE CriticalityDiagnostics
  *****************
-- SESSION STOP REQUEST
__ ***********************
SessionStopRequest ::= SEQUENCE {
                                ProtocolIE-Container
                                                         {{SessionStopRequest-IEs}},
   protocolIEs
   . . .
SessionStopRequest-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                           CRITICALITY reject TYPE MCE-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory }
     ID id-ENB-MBMS-M2AP-ID
                                           CRITICALITY reject TYPE ENB-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory } ,
-- SESSION STOP RESPONSE
__ ********************************
SessionStopResponse ::= SEQUENCE {
                                                         {{ SessionStopResponse-IEs}},
   protocolIEs
                                ProtocolIE-Container
   . . .
SessionStopResponse-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                           CRITICALITY ignore TYPE MCE-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory
     ID id-ENB-MBMS-M2AP-ID
                                           CRITICALITY ignore TYPE ENB-MBMS-M2AP-ID
                                                                                             PRESENCE mandatory
    { ID id-CriticalityDiagnostics
                                           CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                             PRESENCE optional } ,
   . . .
-- SESSION UPDATE REQUEST
__ *********************
SessionUpdateRequest ::= SEQUENCE {
   protocolIEs
                                ProtocolIE-Container
                                                         {{SessionUpdateRequest-IEs}},
   . . .
```

```
SessionUpdateRequest-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                          CRITICALITY reject TYPE MCE-MBMS-M2AP-ID
                                                                                            PRESENCE mandatory
     ID id-ENB-MBMS-M2AP-ID
                                          CRITICALITY reject TYPE ENB-MBMS-M2AP-ID
                                                                                            PRESENCE mandatory
     ID id-TMGI
                                          CRITICALITY reject TYPE TMGI
                                                                                            PRESENCE mandatory
     ID id-MBMS-Session-ID
                                          CRITICALITY ignore TYPE MBMS-Session-ID
                                                                                            PRESENCE optional
     ID id-MBMS-Service-Area
                                          CRITICALITY ignore TYPE MBMS-Service-Area
                                                                                            PRESENCE optional
   { ID id-TNL-Information
                                          CRITICALITY reject TYPE TNL-Information
                                                                                            PRESENCE optional } ,
  *****************
-- SESSION UPDATE RESPONSE
  ····
SessionUpdateResponse ::= SEQUENCE
                                                        {{ SessionUpdateResponse-IEs}},
   protocolIEs
                                ProtocolIE-Container
SessionUpdateResponse-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                          CRITICALITY ignore TYPE MCE-MBMS-M2AP-ID
                                                                                            PRESENCE mandatory }
     ID id-ENB-MBMS-M2AP-ID
                                          CRITICALITY ignore TYPE ENB-MBMS-M2AP-ID
                                                                                            PRESENCE mandatory }
    ID id-CriticalityDiagnostics
                                          CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                            PRESENCE optional },
-- SESSION UPDATE FAILURE
__ *******************************
SessionUpdateFailure ::= SEQUENCE {
   protocolIEs
                                ProtocolIE-Container
                                                        {{ SessionUpdateFailure-IEs}},
SessionUpdateFailure-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCE-MBMS-M2AP-ID
                                          CRITICALITY ignore TYPE MCE-MBMS-M2AP-ID
                                                                                            PRESENCE mandatory
     ID id-ENB-MBMS-M2AP-ID
                                          CRITICALITY ignore TYPE ENB-MBMS-M2AP-ID
                                                                                            PRESENCE mandatory
                                          CRITICALITY ignore TYPE Cause
     ID id-Cause
                                                                                            PRESENCE mandatory
     ID id-CriticalityDiagnostics
                                          CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                            PRESENCE optional },
-- MBMS SCHEDULING INFORMATION
  ******************
```

```
MbmsSchedulingInformation ::= SEQUENCE {
   protocolIEs
                                 ProtocolIE-Container
                                                          {{ MbmsSchedulingInformation-IEs}},
   . . .
MbmsSchedulingInformation-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCCH-Update-Time
                                           CRITICALITY reject TYPE MCCH-Update-Time
                                                                                                       PRESENCE mandatory }
    { ID id-MBSFN-Area-Configuration-List
                                           CRITICALITY reject TYPE MBSFN-Area-Configuration-List PRESENCE mandatory } ,
MBSFN-Area-Configuration-List ::= SEQUENCE (SIZE(1.. maxnoofMBSFNareas)) OF ProtocolIE-Container { { MBSFN-Area-Configuration-Item } }
MBSFN-Area-Configuration-Item M2AP-PROTOCOL-IES ::= {
     ID id-PMCH-Configuration-List
                                           CRITICALITY reject TYPE PMCH-Configuration-List
                                                                                                 PRESENCE mandatory }
     ID id-Common-Subframe-Allocation-Period CRITICALITY reject TYPE Common-Subframe-Allocation-Period PRESENCE mandatory
     ID id-MBSFN-Area-ID
                                            CRITICALITY reject TYPE MBSFN-Area-ID
                                                                                                 PRESENCE mandatory },
   . . .
PMCH-Configuration-List ::= SEQUENCE (SIZE(0.. maxnoofPMCHsperMBSFNarea)) OF ProtocolIE-Single-Container { { PMCH-Configuration-ItemIEs } }
PMCH-Configuration-ItemIEs M2AP-PROTOCOL-IES ::= {
   { ID id-PMCH-Configuration-Item CRITICALITY reject
                                                      TYPE PMCH-Configuration-Item PRESENCE mandatory },
   . . .
PMCH-Configuration-Item ::= SEQUENCE {
   pmch-Configuration
                                 PMCH-Configuration,
   mbms-Session-List
                                 MBMSsessionListPerPMCH-Item,
                                 ProtocolExtensionContainer { { PMCH-Configuration-ItemExtIEs} } OPTIONAL,
   iE-Extensions
   . . .
PMCH-Configuration-ItemExtIEs M2AP-PROTOCOL-EXTENSION ::= {
MBSFN-Subframe-ConfigurationList ::= SEOUENCE (SIZE(1.. maxnoofMBSFN-Allocations)) OF ProtocolIE-Single-Container { { MBSFN-Subframe-
ConfigurationItem } }
MBSFN-Subframe-ConfigurationItem M2AP-PROTOCOL-IES ::= {
   { ID id-MBSFN-Subframe-Configuration-Item
                                                CRITICALITY reject
                                                                     TYPE MBSFN-Subframe-Configuration
                                                                                                          PRESENCE mandatory },
    . . .
-- MBMS SCHEDULING INFORMATION RESPONSE
  ******************
```

```
MbmsSchedulingInformationResponse ::= SEQUENCE {
   protocolIEs
                                ProtocolIE-Container
                                                         {{ MbmsSchedulingInformationResponse-IEs}},
   . . .
MbmsSchedulingInformationResponse-IEs M2AP-PROTOCOL-IES ::= {
   { ID id-CriticalityDiagnostics
                                                  CRITICALITY ignore TYPE CriticalityDiagnostics PRESENCE optional },
   . . .
  *****************
-- M2 SETUP REQUEST
M2SetupRequest ::= SEQUENCE {
                                                         {{M2SetupRequest-IEs}},
   protocolIEs
                                ProtocolIE-Container
M2SetupRequest-IEs M2AP-PROTOCOL-IES ::= {
                                               CRITICALITY reject TYPE GlobalENB-ID
     ID id-GlobalENB-ID
                                                                                                     PRESENCE mandatory }
     ID id-ENBname
                                               CRITICALITY ignore TYPE ENBname
                                                                                                     PRESENCE optional }
   { ID id-ENB-MBMS-Configuration-data-List
                                               CRITICALITY reject TYPE ENB-MBMS-Configuration-data-List PRESENCE mandatory
ENB-MBMS-Configuration-data-List ::= SEQUENCE (SIZE(1.. maxnoofCells)) OF ProtocolIE-Single-Container { { ENB-MBMS-Configuration-data-ItemIEs } }
ENB-MBMS-Configuration-data-ItemIEs
                                    M2AP-PROTOCOL-IES ::= {
   { ID id-ENB-MBMS-Configuration-data-Item
                                            CRITICALITY reject
                                                                 TYPE ENB-MBMS-Configuration-data-Item PRESENCE mandatory },
   . . .
  -- M2 SETUP RESPONSE
  M2SetupResponse ::= SEQUENCE {
                                                         {{ M2SetupResponse-IEs}},
   protocolIEs
                                ProtocolIE-Container
M2SetupResponse-IEs M2AP-PROTOCOL-IES ::= {
     ID id-GlobalMCE-ID
                                                                                                     PRESENCE mandatory }
                                                  CRITICALITY reject TYPE GlobalMCE-ID
     ID id-MCEname
                                                                                                     PRESENCE optional
                                                  CRITICALITY ignore TYPE MCEname
     ID id-MCCHrelatedBCCH-ConfigPerMBSFNArea
                                                      CRITICALITY reject TYPE MCCHrelatedBCCH-ConfigPerMBSFNArea PRESENCE mandatory }
   { ID id-CriticalityDiagnostics
                                                  CRITICALITY ignore TYPE CriticalityDiagnostics PRESENCE optional } ,
```

```
MCCHrelatedBCCH-ConfigPerMBSFNArea ::= SEQUENCE (SIZE(1.. maxnoofMBSFNareas)) OF ProtocolIE-Single-Container { MCCHrelatedBCCH-
ConfigPerMBSFNArea-ItemIEs } }
MCCHrelatedBCCH-ConfigPerMBSFNArea-ItemIEs M2AP-PROTOCOL-IES ::= {
   TYPE MCCHrelatedBCCH-ConfiqPerMBSFNArea-Item PRESENCE mandatory },
   . . .
  ****************
-- M2 SETUP FAILURE
__ **********************
M2SetupFailure ::= SEQUENCE {
   protocolIEs
                                               {{ M2SetupFailure-IEs}},
                          ProtocolIE-Container
   . . .
M2SetupFailure-IEs M2AP-PROTOCOL-IES ::= {
    ID id-Cause
                             CRITICALITY ignore TYPE Cause
                                                                 PRESENCE mandatory }
    ID id-TimeToWait
                             CRITICALITY ignore TYPE TimeToWait
                                                                 PRESENCE optional }
    ID id-CriticalityDiagnostics
                             CRITICALITY ignore TYPE CriticalityDiagnostics PRESENCE optional },
   -- ENB CONFIGURATION UPDATE
__ ********************************
ENBConfigurationUpdate ::= SEQUENCE {
   protocolIEs
                          ProtocolIE-Container
                                               {{ENBConfigurationUpdate-IEs}},
ENBConfigurationUpdate-IEs M2AP-PROTOCOL-IES ::= {
    ID id-GlobalENB-ID
                                            CRITICALITY reject TYPE GlobalENB-ID
                                                                                          PRESENCE optional } |
    ID id-ENBname
                                            CRITICALITY ignore TYPE ENBname
                                                                                        PRESENCE optional }
   optional } ,
ENB-MBMS-Configuration-data-List-ConfigUpdate ::= SEQUENCE (SIZE(1.. maxnoofCells)) OF ProtocolIE-Single-Container { { ENB-MBMS-Configuration-data-
ConfigUpdate-ItemIEs } }
ENB-MBMS-Configuration-data-ConfigUpdate-ItemIEs M2AP-PROTOCOL-IES ::= {
   TYPE ENB-MBMS-Configuration-data-ConfigUpdate-Item PRESENCE
mandatory },
   . . .
```

```
-- ENB CONFIGURATION UPDATE ACKNOWLEDGE
ENBConfigurationUpdateAcknowledge ::= SEQUENCE {
                                                            {{ ENBConfigurationUpdateAcknowledge-IEs}},
   protocolIEs
                                ProtocolIE-Container
ENBConfigurationUpdateAcknowledge-IEs M2AP-PROTOCOL-IES ::= {
     ID id-MCCHrelatedBCCH-ConfigPerMBSFNArea
                                                         CRITICALITY reject TYPE MCCHrelatedBCCH-ConfigPerMBSFNArea PRESENCE optional }
    ID id-CriticalityDiagnostics
                                                         CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                                                   PRESENCE optional },
-- ENB CONFIGURATION UPDATE FAILURE
__ *********************
ENBConfigurationUpdateFailure ::= SEQUENCE {
   protocolIEs
                                 ProtocolIE-Container
                                                            {{ ENBConfigurationUpdateFailure-IEs}},
   . . .
ENBConfigurationUpdateFailure-IEs M2AP-PROTOCOL-IES ::= {
     ID id-Cause
                                     CRITICALITY ignore TYPE Cause
                                                                                   PRESENCE mandatory }
     ID id-TimeToWait
                                     CRITICALITY ignore TYPE TimeToWait
                                                                                   PRESENCE optional
     ID id-CriticalityDiagnostics
                                     CRITICALITY ignore TYPE CriticalityDiagnostics PRESENCE optional },
-- MCE CONFIGURATION UPDATE
MCEConfigurationUpdate ::= SEQUENCE
   protocolIEs
                                  ProtocolIE-Container
                                                            {{MCEConfigurationUpdate-IEs}},
MCEConfigurationUpdate-IEs M2AP-PROTOCOL-IES ::= {
     ID id-GlobalMCE-ID
                                                     CRITICALITY reject TYPE GlobalMCE-ID
                                                                                                          PRESENCE optional }
    ID id-MCEname
                                                                                                           PRESENCE optional }
                                                     CRITICALITY ignore TYPE MCEname
```

```
{ ID id-MCCHrelatedBCCH-ConfigPerMBSFNArea
                                                       CRITICALITY reject TYPE MCCHrelatedBCCH-ConfiqPerMBSFNArea PRESENCE optional } ,
-- MCE CONFIGURATION UPDATE ACKNOWLEDGE
MCEConfigurationUpdateAcknowledge ::= SEQUENCE {
                                                          {{ MCEConfigurationUpdateAcknowledge-IEs}},
   protocolIEs
                                 ProtocolIE-Container
   . . .
MCEConfigurationUpdateAcknowledge-IEs M2AP-PROTOCOL-IES ::= {
   { ID id-CriticalityDiagnostics
                                                   CRITICALITY ignore TYPE CriticalityDiagnostics PRESENCE optional },
  *****************
-- MCE CONFIGURATION UPDATE FAILURE
  *****************
MCEConfigurationUpdateFailure ::= SEQUENCE {
                                                          {{ MCEConfigurationUpdateFailure-IEs}},
   protocolIEs
                                 ProtocolIE-Container
MCEConfigurationUpdateFailure-IEs M2AP-PROTOCOL-IES ::= {
                                     CRITICALITY ignore TYPE Cause
     ID id-Cause
                                                                                 PRESENCE mandatory }
     ID id-TimeToWait
                                     CRITICALITY ignore TYPE TimeToWait
                                                                                 PRESENCE optional
    { ID id-CriticalityDiagnostics
                                     CRITICALITY ignore TYPE CriticalityDiagnostics PRESENCE optional },
-- ERROR INDICATION
ErrorIndication ::= SEQUENCE {
   protocolIEs
                                 ProtocolIE-Container
                                                          {{ErrorIndication-IEs}},
    . . .
ErrorIndication-IEs M2AP-PROTOCOL-IES ::= {
    { ID id-MCE-MBMS-M2AP-ID
                                                                                          PRESENCE optional } |
                                         CRITICALITY ignore TYPE MCE-MBMS-M2AP-ID
```

```
ID id-ENB-MBMS-M2AP-ID
                                       CRITICALITY ignore TYPE ENB-MBMS-M2AP-ID
                                                                                       PRESENCE optional }
     ID id-Cause
                                       CRITICALITY ignore TYPE Cause
                                                                                      PRESENCE optional
     ID id-CriticalityDiagnostics
                                       CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                                      PRESENCE optional
-- RESET
__ *********************
Reset ::= SEQUENCE {
   protocolIEs
                                ProtocolIE-Container
                                                        {{Reset-IEs}},
   . . .
Reset-IEs M2AP-PROTOCOL-IES ::= {
     ID id-Cause
                                CRITICALITY ignore TYPE Cause
                                                                       PRESENCE mandatory
   { ID id-ResetType
                                CRITICALITY reject TYPE ResetType
                                                                       PRESENCE mandatory
ResetType ::= CHOICE {
   m2-Interface
                        ResetAll,
   partOfM2-Interface
                        MBMS-Service-associatedLogicalM2-ConnectionListRes,
ResetAll ::= ENUMERATED {
   reset-all,
MBMS-Service-associatedLogicalM2-ConnectionListRes ::= SEQUENCE (SIZE(1.. maxNrOfIndividualM2ConnectionsToReset)) OF ProtocolIE-Single-Container {
{ MBMS-Service-associatedLogicalM2-ConnectionItemRes } }
MBMS-Service-associatedLogicalM2-ConnectionItemRes M2AP-PROTOCOL-IES ::= {
   TYPE MBMS-Service-associatedLogicalM2-ConnectionItem
                                                                                                                            PRESENCE
mandatory },
-- RESET ACKNOWLEDGE
__ ********************************
ResetAcknowledge ::= SEQUENCE {
                                                        {{ResetAcknowledge-IEs}},
   protocolIEs
                                ProtocolIE-Container
   . . .
```

```
ResetAcknowledge-IEs M2AP-PROTOCOL-IES ::= {
   { ID id-MBMS-Service-associatedLogicalM2-ConnectionListResAck
                                                             CRITICALITY ignore TYPE MBMS-Service-associatedLogicalM2-
ConnectionListResAck
                           PRESENCE optional }
   { ID id-CriticalityDiagnostics CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                              PRESENCE optional },
MBMS-Service-associatedLogicalM2-ConnectionListResAck ::= SEQUENCE (SIZE(1.. maxNrOfIndividualM2ConnectionsToReset)) OF ProtocolIE-Single-Container
MBMS-Service-associatedLoqicalM2-ConnectionItemResAck M2AP-PROTOCOL-IES ::= {
   { ID id-MBMS-Service-associatedLogicalM2-ConnectionItem CRITICALITY ignore
                                                                       TYPE MBMS-Service-associatedLogicalM2-ConnectionItem
mandatory },
     *****************
-- PRIVATE MESSAGE
__ **********************
PrivateMessage ::= SEOUENCE {
   privateIEs
              PrivateIE-Container {{PrivateMessage-IEs}},
   . . .
PrivateMessage-IEs M2AP-PRIVATE-IES ::= {
END
```

#### 9.3.5 Information Element definitions

```
maxnoofPMCHsperMBSFNarea,
    maxnoofCells,
    maxnoofMBMSServiceAreasPerCell,
    maxnoofSessionsPerPMCH,
    maxnooferrors
FROM M2AP-Constants
    Criticality,
    ProcedureCode,
    ProtocolIE-ID,
    TriggeringMessage
FROM M2AP-CommonDataTypes
    ProtocolExtensionContainer{},
    ProtocolIE-Single-Container{},
    M2AP-PROTOCOL-EXTENSION,
    M2AP-PROTOCOL-IES
FROM M2AP-Containers;
-- A
AllocatedSubframesEnd
                                 ::= INTEGER (0..1535)
-- B
-- C
Cause ::= CHOICE {
    radioNetwork
                        CauseRadioNetwork,
    transport
                        CauseTransport,
    nAS
                        CauseNAS,
                        CauseProtocol,
    protocol
                        CauseMisc,
    misc
CauseMisc ::= ENUMERATED {
    control-processing-overload,
    hardware-failure,
    om-intervention,
    unspecified,
    . . .
CauseNAS ::= ENUMERATED {
    unspecified,
    . . .
CauseProtocol ::= ENUMERATED {
    transfer-syntax-error,
```

```
abstract-syntax-error-reject,
    abstract-syntax-error-ignore-and-notify,
    message-not-compatible-with-receiver-state,
    semantic-error,
    abstract-syntax-error-falsely-constructed-message,
    unspecified,
CauseRadioNetwork ::= ENUMERATED {
    unknown-or-already-allocated-MCE-MBMS-M2AP-ID,
    unknown-or-already-allocated-eNB-MBMS-M2AP-ID,
    unknown-or-inconsistent-pair-of-MBMS-M2AP-IDs,
    radio-resources-not-available,
    interaction-with-other-procedure,
    unspecified,
    . . .
CauseTransport ::= ENUMERATED {
    transport-resource-unavailable,
    unspecified,
    . . .
Cell-Information
                    ::= SEQUENCE {
    eCGI
                                     ECGI,
    cellReservationInfo
                                    ENUMERATED {reservedCell, nonReservedCell, ...},
    iE-Extensions
                                    ProtocolExtensionContainer { { Cell-Information-ExtIEs} } OPTIONAL,
    . . .
Cell-Information-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
                      ::= SEOUENCE (SIZE(1..maxnoofCells)) OF Cell-Information
Cell-Information-List
CriticalityDiagnostics ::= SEQUENCE {
    procedureCode
                                    ProcedureCode
                                                                     OPTIONAL,
    triggeringMessage
                                    TriggeringMessage
                                                                     OPTIONAL,
    procedureCriticality
                                    Criticality
                                                                     OPTIONAL,
    iEsCriticalityDiagnostics
                                    CriticalityDiagnostics-IE-List OPTIONAL,
    iE-Extensions
                                    ProtocolExtensionContainer { (CriticalityDiagnostics-ExtIEs) }
CriticalityDiagnostics-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
CriticalityDiagnostics-IE-List ::= SEQUENCE (SIZE (1..maxnooferrors)) OF
```

```
SEQUENCE {
       iECriticality
                                Criticality,
                                ProtocolIE-ID,
       iE-ID
       typeOfError
                                TypeOfError,
                                ProtocolExtensionContainer { {CriticalityDiagnostics-IE-List-ExtIEs} } OPTIONAL,
       iE-Extensions
CriticalityDiagnostics-IE-List-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
-- E
ECGI ::= SEQUENCE {
                                PLMN-Identity,
   pLMN-Identity
    eUTRANcellIdentifier
                                EUTRANCellIdentifier,
                                ProtocolExtensionContainer { {ECGI-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
ECGI-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
ENB-ID ::= CHOICE {
   macro-eNB-ID
                   BIT STRING (SIZE (20)),
ENB-MBMS-Configuration-data-Item
                                   ::= SEQUENCE {
                                    ECGI,
   mbsfnSynchronisationArea
                                    MBSFN-SynchronisationArea-ID,
   mbmsServiceAreaList
                                    MBMS-Service-Area-ID-List,
   iE-Extensions
                                    ProtocolExtensionContainer { { ENB-MBMS-Configuration-data-Item-ExtIEs} } OPTIONAL,
ENB-MBMS-Configuration-data-Item-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
ENB-MBMS-Configuration-data-ConfigUpdate-Item ::= CHOICE {
   mBMSConfigData
                                    ENB-MBMS-Configuration-data-Item,
    eCGI
                                    ECGI,
    . . .
ENB-MBMS-M2AP-ID
                       ::= INTEGER (0..65535)
ENBname ::= PrintableString (SIZE (1..150,...))
```

```
EUTRANCellIdentifier ::= BIT STRING (SIZE (28))
-- F
-- G
GlobalENB-ID ::= SEQUENCE {
    pLMN-Identity
                           PLMN-Identity,
    eNB-ID
                           ENB-ID,
    iE-Extensions
                           ProtocolExtensionContainer { {GlobalENB-ID-ExtIEs} } OPTIONAL,
GlobalENB-ID-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
GlobalMCE-ID ::= SEQUENCE {
    pLMN-Identity
                           PLMN-Identity,
   mCE-ID
                           MCE-ID,
                           ProtocolExtensionContainer { {GlobalMCE-ID-ExtIEs} } OPTIONAL,
   iE-Extensions
GlobalMCE-ID-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
GTP-TEID
                          ::= OCTET STRING (SIZE (4))
-- H
-- I
IPAddress
                ::= OCTET STRING (SIZE(4..16))
-- J
-- K
-- L
LCID
       ::= INTEGER (0..28)
-- M
MBMS-Service-associatedLogicalM2-ConnectionItem ::= SEQUENCE {
                                   ENB-MBMS-M2AP-ID OPTIONAL,
    eNB-MBMS-M2AP-ID
    mCE-MBMS-M2AP-ID
                                   MCE-MBMS-M2AP-ID OPTIONAL,
    iE-Extensions
                                   ProtocolExtensionContainer { { MBMS-Service-associatedLogicalM2-ConnectionItemExtIEs} } OPTIONAL,
MBMS-Service-associatedLogicalM2-ConnectionItemExtIEs M2AP-PROTOCOL-EXTENSION ::= {
    . . .
```

66

```
MBMS-Service-Area
                           ::= OCTET STRING
MBMS-Service-Area-ID-List ::= SEOUENCE (SIZE(1..maxnoofMBMSServiceAreasPerCell)) OF MBMS-Service-Area
MBMS-Session-Duration ::= OCTET STRING (SIZE (3))
MBMS-Session-ID ::= OCTET STRING (SIZE (1))
MBMSsessionListPerPMCH-Item ::= SEQUENCE (SIZE(1..maxnoofSessionsPerPMCH)) OF SEQUENCE {
                                    TMGI,
    tmqi
   lcid
                                    LCID.
    iE-Extensions
                                    ProtocolExtensionContainer { MBMSsessionListPerPMCH-Item-ExtIEs} } OPTIONAL,
MBMSsessionListPerPMCH-Item-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
MBSFN-Area-ID
                   ::= INTEGER (0..255)
MBSFN-SynchronisationArea-ID ::= INTEGER (0..65535)
MBSFN-Subframe-Configuration ::= SEQUENCE {
    radioframeAllocationPeriod
                                   ENUMERATED {n1, n2, n4, n8, n16, n32},
    radioframeAllocationOffset
                                   INTEGER (0..7),
    subframeAllocation
                                    CHOICE {
       oneFrame
                                        BIT STRING (SIZE (6) ),
                                        BIT STRING (SIZE (24) ) },
       fourFrames
                                    ProtocolExtensionContainer { { MBSFN-Subframe-Configuration-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
MBSFN-Subframe-Configuration-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
MCCH-Update-Time
                  ::= INTEGER (0..255)
MCCHrelatedBCCH-ConfigPerMBSFNArea-Item ::= SEQUENCE {
    mbsfnArea
                                    MBSFN-Area-ID,
    pdcchLength
                                    ENUMERATED {s1, s2, ...},
    repetitionPeriod
                                    ENUMERATED {rf32, rf64, rf128, rf256},
    offset
                                    INTEGER (0..10),
    modificationPeriod
                                    ENUMERATED {rf512, rf1024},
    subframeAllocationInfo
                                    BIT STRING (SIZE(6)),
    modulationAndCodingScheme
                                    ENUMERATED {n2, n7, n13, n19},
    cellInformationList
                                    Cell-Information-List OPTIONAL,
                                    ProtocolExtensionContainer { MCCHrelatedBCCH-ConfigPerMBSFNArea-Item-ExtIEs} } OPTIONAL,
    iE-Extensions
    . . .
```

```
MCCHrelatedBCCH-ConfiqPerMBSFNArea-Item-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
MCE-ID
                      ::= OCTET STRING (SIZE(2))
MCE-MBMS-M2AP-ID
                           ::= INTEGER (0.. 16777215)
MCEname ::= PrintableString (SIZE (1..150,...))
MCH-Scheduling-Period
                                  ::= ENUMERATED {rf8, rf16, rf32, rf64, rf128, rf256, rf512, rf1024}
-- N
-- O
-- P
PLMN-Identity ::= OCTET STRING (SIZE(3))
PMCH-Configuration
                           ::= SEQUENCE
    allocatedSubframesEnd
                                       AllocatedSubframesEnd,
    dataMCS
                                   INTEGER (0..28),
    mchSchedulingPeriod
                                   MCH-Scheduling-Period,
    iE-Extensions
                                   ProtocolExtensionContainer { {PMCH-Configuration-ExtIEs} } OPTIONAL,
    . . .
PMCH-Configuration-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
Common-Subframe-Allocation-Period ::= ENUMERATED {rf4, rf8, rf6, rf32, rf64, rf128, rf256}
PriorityLevel
                         ::= INTEGER { spare (0), highest (1), lowest (14), no-priority (15) } (0..15)
-- O
-- R
-- S
TimeToWait ::= ENUMERATED {v1s, v2s, v5s, v10s, v20s, v60s, ...}
TMGI ::= SEQUENCE {
    pLMNidentity
                           PLMN-Identity,
    serviceID
                           OCTET STRING (SIZE (3)),
   iE-Extensions
                           ProtocolExtensionContainer { {TMGI-ExtIEs} } OPTIONAL,
TMGI-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
TNL-Information ::= SEQUENCE {
```

```
iPMCAddress
                                    IPAddress,
    i PSourceAddress
                                    IPAddress,
    qTP-TEID
                                    GTP-TEID.
                                    ProtocolExtensionContainer { {TNL-Information-ExtIEs} } OPTIONAL,
    iE-Extensions
TNL-Information-ExtIEs M2AP-PROTOCOL-EXTENSION ::= {
TypeOfError ::= ENUMERATED {
    not-understood,
   missing,
-- X
-- Y
-- Z
END
```

#### 9.3.6 Common definitions

```
-- Common definitions
__ ********************
M2AP-CommonDataTypes {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
eps-Access (21) modules (3) m2ap (4) version1 (1) m2ap-CommonDataTypes (3) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
  *****************
-- Extension constants
__ ********************
maxPrivateIEs
                                    INTEGER ::= 65535
maxProtocolExtensions
                                    INTEGER ::= 65535
maxProtocolIEs
                                    INTEGER ::= 65535
```

```
__ *********************
-- Common Data Types
__ *********************
Criticality
             ::= ENUMERATED { reject, ignore, notify }
Presence
             ::= ENUMERATED { optional, conditional, mandatory }
PrivateIE-ID ::= CHOICE {
   local
                   INTEGER (0.. maxPrivateIEs),
   qlobal
                   OBJECT IDENTIFIER
ProcedureCode
              ::= INTEGER (0..255)
ProtocolIE-ID
              ::= INTEGER (0..maxProtocolIEs)
TriggeringMessage ::= ENUMERATED { initiating-message, successful-outcome, unsuccessful-outcome}
END
```

#### 9.3.7 Constant definitions

```
ProcedureCode ::= 1
id-sessionStop
id-mbmsSchedulingInformation
                                                           ProcedureCode ··= 2
id-errorIndication
                                                           ProcedureCode ::= 3
                                                           ProcedureCode ::= 4
id-reset
id-m2Setup
                                                           ProcedureCode ::= 5
id-eNBConfigurationUpdate
                                                           ProcedureCode ::= 6
id-mCEConfigurationUpdate
                                                           ProcedureCode ::= 7
                                                           ProcedureCode ::= 8
id-privateMessage
id-sessionUpdate
                                                           ProcedureCode ::= 9
  *****************
-- Lists
__ **********************
maxnoofMBSFNareas
                                        INTEGER ::= 256
maxnoofMBSFN-Allocations
                                        INTEGER ::= 8
maxnoofPMCHsperMBSFNarea
                                        INTEGER ::= 15
maxnoofCells
                                        INTEGER ::= 256
maxnoofMBMSServiceAreasPerCell
                                        INTEGER ::= 256
maxnoofSessionsPerPMCH
                                        INTEGER ::= 29
maxnooferrors
                                        INTEGER ::= 256
maxNrOfIndividualM2ConnectionsToReset
                                        INTEGER ::= 256
__ *********************
-- IEs
__ *********************
id-MCE-MBMS-M2AP-ID
                                                                      ProtocolIE-ID ::= 0
id-ENB-MBMS-M2AP-ID
                                                                      ProtocolIE-ID ::= 1
id-TMGI
                                                                      ProtocolIE-ID ::= 2
id-MBMS-Session-ID
                                                                      ProtocolIE-ID ::= 3
id-MBMS-Service-Area
                                                                      ProtocolIE-ID ::= 6
id-TNL-Information
                                                                      ProtocolIE-ID ::= 7
id-CriticalityDiagnostics
                                                                      ProtocolIE-ID ::= 8
id-Cause
                                                                      ProtocolIE-ID ::= 9
id-MBSFN-Area-Configuration-List
                                                                      ProtocolIE-ID ::= 10
id-PMCH-Configuration-List
                                                                      ProtocolIE-ID ::= 11
id-PMCH-Configuration-Item
                                                                      ProtocolIE-ID ::= 12
id-GlobalENB-ID
                                                                      ProtocolIE-ID ::= 13
id-ENBname
                                                                      ProtocolIE-ID ::= 14
id-ENB-MBMS-Configuration-data-List
                                                                      ProtocolIE-ID ::= 15
id-ENB-MBMS-Configuration-data-Item
                                                                      ProtocolIE-ID ::= 16
id-GlobalMCE-ID
                                                                      ProtocolIE-ID ::= 17
id-MCEname
                                                                      ProtocolIE-ID ::= 18
                                                                      ProtocolIE-ID ::= 19
id-MCCHrelatedBCCH-ConfigPerMBSFNArea
id-MCCHrelatedBCCH-ConfigPerMBSFNArea-Item
                                                                      ProtocolIE-ID ::= 20
id-TimeToWait
                                                                      ProtocolIE-ID ::= 21
id-MBSFN-Subframe-Configuration-List
                                                                      ProtocolIE-ID ::= 22
id-MBSFN-Subframe-Configuration-Item
                                                                      ProtocolIE-ID ::= 23
```

```
id-Common-Subframe-Allocation-Period
                                                                             ProtocolIE-ID ::= 24
id-MCCH-Update-Time
                                                                             ProtocolIE-ID ::= 25
id-ENB-MBMS-Configuration-data-List-ConfigUpdate
                                                                             ProtocolIE-ID ::= 26
id-ENB-MBMS-Configuration-data-ConfigUpdate-Item
                                                                             ProtocolIE-ID ::= 27
id-MBMS-Service-associatedLogicalM2-ConnectionItem
                                                                             ProtocolIE-ID ::= 28
id-MBSFN-Area-ID
                                                                             ProtocolIE-ID ::= 29
id-ResetType
                                                                             ProtocolIE-ID ::= 30
id-MBMS-Service-associatedLoqicalM2-ConnectionListResAck
                                                                             ProtocolIE-ID ::= 31
```

END

#### 9.3.8 Container definitions

```
__ **********************
-- Container definitions
__ **********************
M2AP-Containers {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
eps-Access (21) modules (3) m2ap (4) version1 (1) m2ap-Containers (5) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
   ***************
-- IE parameter types from other modules.
__ ********************
IMPORTS
   maxPrivateIEs,
  maxProtocolExtensions,
  maxProtocolIEs,
   Criticality,
   Presence,
  PrivateIE-ID,
   ProtocolIE-ID
FROM M2AP-CommonDataTypes;
__ *******************
-- Class Definition for Protocol IEs
__ **********************
M2AP-PROTOCOL-IES ::= CLASS {
        ProtocolIE-ID
                               UNIQUE,
```

```
&criticality
                   Criticality,
    &Value,
    &presence
                   Presence
WITH SYNTAX {
                   &id
    ID
    CRITICALITY
                   &criticality
   TYPE
                   &Value
    PRESENCE
                   &presence
-- Class Definition for Protocol IEs
M2AP-PROTOCOL-IES-PAIR ::= CLASS {
                           ProtocolIE-ID
                                              UNIQUE,
    &firstCriticality
                           Criticality,
    &FirstValue,
    &secondCriticality
                           Criticality,
    &SecondValue,
    &presence
                           Presence
WITH SYNTAX {
    ID
                           &id
                           &firstCriticality
    FIRST CRITICALITY
                           &FirstValue
    FIRST TYPE
                           &secondCriticality
    SECOND CRITICALITY
    SECOND TYPE
                           &SecondValue
    PRESENCE
                           &presence
-- Class Definition for Protocol Extensions
M2AP-PROTOCOL-EXTENSION ::= CLASS {
    &id
                       ProtocolIE-ID
                                          UNIQUE,
    &criticality
                       Criticality,
    &Extension,
    &presence
                       Presence
WITH SYNTAX {
    ID
                       &id
    CRITICALITY
                       &criticality
    EXTENSION
                       &Extension
    PRESENCE
                       &presence
__ *********************
```

73

```
-- Class Definition for Private IEs
__ **********************
M2AP-PRIVATE-IES ::= CLASS {
   &id
                     PrivateIE-ID,
   &criticality
                     Criticality,
   &Value,
   &presence
                      Presence
WITH SYNTAX {
   ID
                      &id
   CRITICALITY
                      &criticality
   TYPE
                      &Value
   PRESENCE
                      &presence
    *******************
-- Container for Protocol IEs
ProtocolIE-Container {M2AP-PROTOCOL-IES : IEsSetParam} ::=
   SEQUENCE (SIZE (0..maxProtocolIEs)) OF
   ProtocolIE-Field {{IEsSetParam}}
ProtocolIE-Single-Container {M2AP-PROTOCOL-IES : IESSetParam} ::=
   ProtocolIE-Field {{IEsSetParam}}
ProtocolIE-Field {M2AP-PROTOCOL-IES : IESSetParam} ::= SEQUENCE {
                 M2AP-PROTOCOL-IES.&id
                                                       ({IEsSetParam}),
                  M2AP-PROTOCOL-IES.&criticality
                                                       ({IEsSetParam}{@id}),
   criticality
                                                       ({IEsSetParam}{@id})
   value
                 M2AP-PROTOCOL-IES.&Value
     ***************
  Container for Protocol IE Pairs
ProtocolIE-ContainerPair {M2AP-PROTOCOL-IES-PAIR : IEsSetParam} ::=
   SEOUENCE (SIZE (0..maxProtocolIEs)) OF
   ProtocolIE-FieldPair {{IEsSetParam}}
ProtocolIE-FieldPair {M2AP-PROTOCOL-IES-PAIR : IESSetParam} ::= SEQUENCE
                                                              ({IEsSetParam}),
   iд
                     M2AP-PROTOCOL-IES-PAIR.&id
   firstCriticality M2AP-PROTOCOL-IES-PAIR.&firstCriticality
                                                              ({IEsSetParam}{@id}),
   firstValue
                                                              ({IEsSetParam}{@id}),
                     M2AP-PROTOCOL-IES-PAIR.&FirstValue
                                                              ({IEsSetParam}{@id}),
   secondCriticality M2AP-PROTOCOL-IES-PAIR.&secondCriticality
   secondValue
                     M2AP-PROTOCOL-IES-PAIR.&SecondValue
                                                              ({IEsSetParam}{@id})
```

END

```
-- Container Lists for Protocol IE Containers
ProtocolIE-ContainerList {INTEGER : lowerBound, INTEGER : upperBound, M2AP-PROTOCOL-IES : IEsSetParam} ::=
   SEQUENCE (SIZE (lowerBound..upperBound)) OF
   ProtocolIE-Container {{IEsSetParam}}
ProtocolIE-ContainerPairList {INTEGER : lowerBound, INTEGER : upperBound, M2AP-PROTOCOL-IES-PAIR : IESSetParam} ::=
   SEQUENCE (SIZE (lowerBound..upperBound)) OF
   ProtocolIE-ContainerPair {{IEsSetParam}}
       *****************
-- Container for Protocol Extensions
__ **********************
ProtocolExtensionContainer {M2AP-PROTOCOL-EXTENSION : ExtensionSetParam} ::=
   SEQUENCE (SIZE (1..maxProtocolExtensions)) OF
   ProtocolExtensionField {{ExtensionSetParam}}
ProtocolExtensionField {M2AP-PROTOCOL-EXTENSION : ExtensionSetParam} ::= SEQUENCE
                                                         ({ExtensionSetParam}),
                    M2AP-PROTOCOL-EXTENSION.&id
   criticality
                    M2AP-PROTOCOL-EXTENSION.&criticality
                                                         ({ExtensionSetParam}{@id}),
                                                         ({ExtensionSetParam}{@id})
   extensionValue
                    M2AP-PROTOCOL-EXTENSION. &Extension
    ******************
-- Container for Private IEs
  *****************
PrivateIE-Container {M2AP-PRIVATE-IES : IEsSetParam} ::=
   SEQUENCE (SIZE (1..maxPrivateIEs)) OF
   PrivateIE-Field {{IEsSetParam}}
PrivateIE-Field {M2AP-PRIVATE-IES : IEsSetParam} ::= SEQUENCE {
               M2AP-PRIVATE-IES.&id
                                              ({IEsSetParam}),
   criticality M2AP-PRIVATE-IES.&criticality ({IEsSetParam}{@id}),
                 M2AP-PRIVATE-IES.&Value
                                              ({IEsSetParam}{@id})
   value
```

# 9.4 Message Transfer Syntax

M2AP shall use the ASN.1 Basic Packed Encoding Rules (BASIC-PER) Aligned Variant as transfer syntax as specified in ref. [5].

# 9.5 Timers

# Handling of Unknown, Unforeseen and Erroneous Protocol Data

Section 10 of [4] is applicable for the purposes of the present document.

# Annex A (informative): Change history

TSG#	TSG Doc.	CR	Rev	Subject/Comment	New
2008-02				First draft	0.0.0
2009-10				Second draft	0.0.1
2009-10				Draft with first content	0.0.2
2009-10				Including comments from RAN3#65bis	0.0.3
2009-10				Preparing RAN3#66	0.0.4
2009-10				Submission to RAN3#66, based on received comments	0.0.5
2009-11				Update following discussions at RAN3#66	0.0.6
2009-11				further revisions along RAN2 agreements, step to v100	1.0.0
2009-11				incorporating comments along email discussions before RAN#46	1.1.0
2009-12				stepping the version to 2.0.0 for approval at RAN#46	2.0.0
46	RP-091200			Approved at RAN#46	9.0.0
47	RP-100226	0001	1	Some minor description corrections for M2AP	9.1.0
47	RP-100226	0002	1	Removal of QoS information in MBMS Session Start message	9.1.0
47	RP-100226	0003		Clarification of MCCH Update Time	9.1.0
47	RP-100226	0004		Correct the descripton of Error Indication and misspelt of BIT STRING	9.1.0
47	RP-100227	0005	1	Some corrections to TS36.443	9.1.0
47	RP-100226	0006	1	MBSFN subframe configuration	9.1.0
47	RP-100227	8000	2	MBSFN Area Configuration	9.1.0
47	RP-100227	0009	1	Miscellaneous corrections to TS36.443	9.1.0
47	RP-100227	0010	2	Optional MBMS Session ID	9.1.0
47	RP-100227	0013	3	Remove the MBMS Session Duration IE from the MBMS Session Start Request	9.1.0
				message	
47	RP-100227	0015	3	Misc corrections	9.1.0
47	RP-100227	0016	2	Introduction of MBMS Session Update in M2AP	9.1.0
47	RP-100227	0019	3	Rapporteur"s update for M2AP protocol	9.1.0
49	RP-100906	0027		Alignment of tabulars to agreed notation for TS36.413 and TS36.423	9.2.0
2010-12				Created Rel-10 version based on v. 9.2.0	10.0.0

# History

	Document history				
V10.0.0	January 2011	Publication			