# ETSITS 100 607-4 V8.5.0 (2003-09)

Technical Specification

Digital cellular telecommunications system (Phase 2+);
Mobile Station (MS) conformance specification;
Part 4: Subscriber Interface Module (SIM)
application toolkit conformance specification
(3GPP TS 11.10-4 version 8.5.0 Release 1999)



# Reference RTS/TSGT-0311110-4v850 Keywords GSM

#### **ETSI**

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<a href="http://portal.etsi.org/tb/status/status.asp">http://portal.etsi.org/tb/status/status.asp</a></a>

If you find errors in the present document, send your comment to: <a href="mailto:editor@etsi.org">editor@etsi.org</a>

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2003.
All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup> and **UMTS**<sup>TM</sup> are Trade Marks of ETSI registered for the benefit of its Members. **TIPHON**<sup>TM</sup> and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members. **3GPP**<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

# Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

### **Foreword**

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under <a href="http://webapp.etsi.org/key/queryform.asp">http://webapp.etsi.org/key/queryform.asp</a>.

# Contents

Intelle	ectual Property Rights	2
Forew	vord	2
Forew	vord	8
1	Scope	9
2	References	9
3	Definitions and abbreviations	11
3.1	Mobile station definition and configurations	11
3.2.1	Applicability of the present document	11
3.2.3	Applicability to terminal equipment	11
3.2.4	Definitions	
3.2.4.1	Format of the table of optional features	11
3.2.4.2	11	
3.2.4.3	Status and notations	12
3.4	Applicability table	
3.5	Conventions for mathematical notations	
3.6	Conventions on electrical terms	
3.7	Terms on test conditions	27
4	Test equipment	27
5	Testing methodology in general	27
5.1	Testing of optional functions and procedures	
5.2	Test interfaces and facilities	
5.3	Different protocol layers	
5.4	Information to be provided by the apparatus supplier	
5.5	Definitions of transmit and receive times	
6	Reference test methods	28
7	Implicit testing	28
8	Measurement uncertainty	28
9	Format of tests	28
10	Generic call set up procedures.	30
11 - 2	6 Not used	
	Testing of the SIM/ME interface	
	27.21 Not used	
27.22	SIM Application Toolkit	
27.22.		
27.22.	11	31
27.22.	11 7 11	25
27.22	(Profile Download)	
27.22.		
27.22.	<u>*</u>	
27.22.	1 1	
27.22.		
27.22.		
27.22.		
27.22.		
27.22.		
27.22.		
27.22.		
27.22.	2.5 Test requirement	40

27.22.3	Servicing of proactive SIM commands	
27.22.3.1	Definition and applicability	41
27.22.3.2	Conformance requirement	41
27.22.3.3	Test purpose	41
27.22.3.4	Method of test	41
27.22.3.5	Test requirement	41
27.22.4	Proactive SIM commands	42
27.22.4.1	DISPLAY TEXT	42
27.22.4.1.1	DISPLAY TEXT (Normal)	42
27.22.4.1.2	DISPLAY TEXT (Support of "No response from user")	51
27.22.4.1.3	DISPLAY TEXT (Display of extension text)	52
27.22.4.1.4	DISPLAY TEXT (Sustained text)	54
27.22.4.1.5	DISPLAY TEXT (Display of icons)	59
27.22.4.1.6	DISPLAY TEXT (UCS2 display supported)	64
27.22.4.2	GET INKEY	
27.22.4.2.1	GET INKEY(normal)	66
27.22.4.2.2	GET INKEY (No response from User)	72
27.22.4.2.3	GET INKEY (UCS2 format display)	74
27.22.4.2.4	GET INKEY (UCS2 format of entry)	76
27.22.4.2.5	GET INKEY ("Yes/No" Response)	78
27.22.4.2.6	GET INKEY (display of Icon)	80
27.22.4.2.7	GET INKEY (Help Information)	
27.22.4.3.	GET INPUT	
27.22.4.3.1	GET INPUT (normal)	
27.22.4.3.2	GET INPUT (No response from User)	104
27.22.4.3.3	GET INPUT (UCS2 format display)	
27.22.4.3.4	GET INPUT (UCS2 format of entry)	
27.22.4.3.5	GET INPUT (default text)	
27.22.4.3.6	GET INPUT (display of Icon)	
27.22.4.3.6.5	Test Requirement	
27.22.4.3.7	GET INPUT (Help Information)	
27.22.4.4	MORE TIME	125
27.22.4.4.1	Definition and applicability	125
27.22.4.4.2	Conformance requirement	
27.22.4.4.3	Test purpose	125
27.22.4.4.4	Method of test	125
27.22.4.4.5	Test requirement	
27.22.4.5	PLAY TONE	126
27.22.4.5.1	Definition and applicability	126
27.22.4.5.2	Conformance requirement	
27.22.4.5.3	Test purpose	127
27.22.4.5.4	Method of test	127
27.22.4.6	POLL INTERVAL	139
27.22.4.6.1	Definition and applicability	139
27.22.4.6.2	Conformance requirement	
27.22.4.6.3	Test purpose	139
27.22.4.6.4	Method of test	
27.22.4.6.5	Test requirement	140
27.22.4.7	REFRESH	
27.22.4.7.1	REFRESH (normal)	140
27.22.4.7.2	REFRESH (IMSI changing procedure)	149
27.22.4.8	SET UP MENU and ENVELOPE MENU SELECTION	153
27.22.4.8.1	SET UP MENU (normal) and ENVELOPE MENU SELECTION	
27.22.4.8.2	SET UP MENU (help request support) and ENVELOPE MENU SELECTION	
27.22.4.8.3	SET UP MENU (next action support) and ENVELOPE MENU SELECTION	
27.22.4.8.4	SET UP MENU (display of icons) and ENVELOPE MENU SELECTION	
27.22.4.8.5	SET UP MENU (soft keys support) and ENVELOPE MENU SELECTION	
27.22.4.9	SELECT ITEM	
27.22.4.9.1	SELECT ITEM (mandatory features for ME supporting SELECT ITEM)	176
27.22.4.9.2	SELECT ITEM (next action support)	
27.22.4.9.3	SELECT ITEM (default item support)	
27.22.4.9.4	SELECT ITEM (help request support)	191

27.22.4.9.5	SELECT ITEM (icons support)	193
27.22.4.9.6	SELECT ITEM (presentation style)	197
27.22.4.9.7	SELECT ITEM (soft keys support)	
27.22.4.9.8	SELECT ITEM (Support of "No response from user")	
27.22.4.10	SEND SHORT MESSAGE	
27.22.4.10.1	SEND SHORT MESSAGE (normal)	
27.22.4.10.2	SEND SHORT MESSAGE (UCS2 support)	
27.22.4.10.3	SEND SHORT MESSAGE (icon support)	223
27.22.4.11	SEND SS	
27.22.4.11.1	SEND SS (normal)	
27.22.4.11.2	SEND SS (Icon support)	
27.22.4.11.3	SEND SS (UCS2 support)	
27.22.4.12	SEND USSD	
27.22.4.12.1	SEND USSD (normal)	
27.22.4.12.2	SEND USSD (Icon support)	
27.22.4.12.3	SEND USSD (UCS2 support)	
27.22.4.13	SET UP CALL	
27.22.4.13.1	SET UP CALL (normal)	
27.22.4.13.2	SET UP CALL (second alpha identifier)	
27.22.4.13.3	SET UP CALL (display of icons)	
27.22.4.14	POLLING OFF	
27.22.4.14.1	Definition and applicability	
27.22.4.14.2	Conformance requirement	
27.22.4.14.3	Test purpose	
27.22.4.14.4	Method of test	
27.22.4.14.5 27.22.4.15	Test requirementPROVIDE LOCAL INFORMATION	
27.22.4.15	Definition and applicability	
27.22.4.15.1	Conformance requirement	
27.22.4.15.3	Test purpose	
27.22.4.15.4	Method of tests	
27.22.4.15.5	Test requirement	
27.22.4.16	SET UP EVENT LIST	
27.22.4.16.1	SET UP EVENT LIST (normal)	295
27.22.4.17	PERFORM CARD APDU	303
27.22.4.17.1	PERFORM CARD APDU (normal)	
27.22.4.17.2	PERFORM CARD APDU (detachable card reader)	
27.22.4.18	POWER OFF CARD	
27.22.4.18.1	POWER OFF CARD (normal)	
27.22.4.18.2	POWER OFF CARD (detachable card reader)	
27.22.4.19	POWER ON CARD	
27.22.4.19.1	POWER ON CARD (normal)	
27.22.4.19.2	POWER ON CARD (detachable card reader)	
27.22.4.20	GET READER STATUS	
27.22.4.20.1 27.22.4.20.2	GET READER STATUS (normal)	
27.22.4.20.2	TIMER MANAGEMENT and ENVELOPE TIMER EXPIRATION	
27.22.4.21	TIMER MANAGEMENT (normal)	
27.22.4.21.1	ENVELOPE TIMER EXPIRATION (normal)	
27.22.4.21.2	SET UP IDLE MODE TEXT	
27.22.4.22.1	SET UP IDLE MODE TEXT (normal)	
27.22.4.22.2	SET UP IDLE MODE TEXT (Icon support)	
27.22.4.22.3	SET UP IDLE MODE TEXT (UCS2 support)	
27.22.4.23	RUN AT COMMAND	
27.22.4.23.1	RUN AT COMMAND (normal)	
27.22.4.23.2	RUN AT COMMAND (Icon support)	
27.22.4.24	SEND DTMF	
27.22.4.24.1	SEND DTMF (Normal)	401
27.22.4.24.2	SEND DTMF (Display of icons)	
27.22.4.24.3	SEND DTMF (UCS2 support)	
27.22.4.25	LANGUAGE NOTIFICATION	
27.22.4.25.1	Definition and applicability	413

27.22.4.25.2	Conformance Requirement	412
	*	
27.22.4.25.3	Test purpose	
27.22.4.25.4	Method of Test	
27.22.4.26	LAUNCH BROWSER	415
27.22.4.26.1	LAUNCH BROWSER (No session already launched)	415
27.22.4.26.2	LAUNCH BROWSER (Interaction with current session)	
27.22.4.26.3	LAUNCH BROWSER (UCS2 support)	
27.22.4.26.4	LAUNCH BROWSER (icons support)	
27.22.4.27	OPEN CHANNEL	
27.22.4.27.1	Definition and applicability	433
27.22.4.27.2	Conformance requirements	433
27.22.4.27.3	Test purpose	433
27.22.4.27.4	Method of test	
27.22.4.28	CLOSE CHANNEL	
27.22.4.28.1	Definition and applicability	
27.22.4.28.2	Conformance requirements	
27.22.4.28.3	Test purpose	
27.22.4.28.4	Method of Test	447
27.22.4.29	RECEIVE DATA	451
27.22.4.29.1	Definition and applicability	
27.22.4.29.2	Conformance requirements	
27.22.4.29.3	Test purpose	
27.22.4.29.4	Method of test	
27.22.4.30	SEND DATA	
27.22.4.30.1	Definition and applicability	457
27.22.4.30.2	Conformance requirements	457
27.22.4.30.3	Test purpose	
27.22.4.30.4	Method of test	
27.22.4.31	GET CHANNEL STATUS	
27.22.4.31.1	Definition and applicability	
27.22.4.31.2	Conformance requirements	
27.22.4.31.3	Test purpose	470
27.22.4.31.4	Method of test	471
27.22.5	Data Download to SIM	475
27.22.5.1	SMS-PP Data Download	
27.22.5.1.1	Definition and applicability	
	Conformance requirement	
27.22.5.1.2	•	
27.22.5.1.3	Test purpose	
27.22.5.1.4	Method of Test	
27.22.5.1.5	Test requirement	483
27.22.5.2	SMS-CB Data Download	483
27.22.5.2.1	Definition and applicability	
27.22.5.2.2	Conformance requirement	
27.22.5.2.3	<u> •</u>	
	Test purpose	
27.22.5.2.4	Method of Test	
27.22.5.2.5	Test requirement	486
27.22.6	CALL CONTROL BY SIM	486
27.22.6.1	Procedure for Mobile Originated calls	486
27.22.6.1.1	Definition and applicability	
27.22.6.1.2	Conformance requirement	
	<u> •</u>	
27.22.6.1.3	Test purpose	
27.22.6.1.4	Method of tests	
27.22.6.1.5	Test requirement	
27.22.6.2	Procedure for Supplementary (SS) Services	
27.22.6.2.1	Definition and applicability	499
27.22.6.2.2	Conformance requirement	
27.22.6.2.3	Test purpose	
27.22.6.2.4	Method of tests	
27.22.6.2.5	Test requirement	
27.22.6.3	Interaction with Fixed Dialling Number (FDN)	
27.22.6.3.1	Definition and applicability	
27 22 6 3 2	Conformance requirement	504

27.22.6.2.3		pose	
27.22.6.2.4		of tests	
27.22.6.3.5		uirement	
27.22.6.4		Barred Dialling Number (BDN) service	
27.22.6.4.1	Definition	on and applicability	508
27.22.6.4.2	Conform	nance requirement	508
27.22.6.2.3	Test pur	pose	508
27.22.6.2.4	Method	of tests	508
27.22.6.4.5	Test req	uirement	512
27.22.7	EVENT DOWN	NLOAD	512
27.22.7.1		ent	
27.22.7.1.1	MT Call	Event (normal)	512
27.22.7.2	Call Connec	cted Event	515
27.22.7.2.1		nnected Event (MT and MO call)	
27.22.7.2.2	Call Cor	nnected Event (ME supporting SET UP CALL)	517
27.22.7.3	Call Discon	nected Event	520
27.22.7.3.1	Call Dis	connected Event	520
27.22.7.4	Location Sta	atus Event	524
27.22.7.4.1	Location	Status Event (normal)	524
27.22.7.5	User Activit	ty Event	526
27.22.7.5.1		tivity Event (normal)	
27.22.7.6		available event	
27.22.7.6.1		een Available (normal)	
27.22.7.7		status event	
27.22.7.7.1	Card Re	ader Status (normal)	529
27.22.7.7.2		ader Status(detachable card reader)	
27.22.7.8		election event	
27.22.7.8.1		ge selection event (normal)	
27.22.7.9		mination event	
27.22.7.9.1		termination (normal)	
27.22.7.10		ole event	
27.22.7.10.1		on and applicability	
27.22.7.10.2		nance requirements	
27.22.7.10.3		pose	
27.22.7.10.4		of test	
27.22.7.11		itus event	
27.22.7.11.1		on and applicability	
27.22.7.11.2		nance requirements	
27.22.7.11.3		pose	
27.22.7.11.4	-	of test	
Annex A (n	ormative):	Void	545
Annex B (in	nformative):	Void	546
Annex C (v	oid):	Void	547
Annex D (n	•	Details of Test-SIM (TestSIM)	548
Annex E (n	ormative):	Details of terminal profile support	550
•	nformative):	Change history	
•	ŕ	g	

# Foreword

This Technical Specification has been produced by the 3<sup>rd</sup> Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

#### where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

# 1 Scope

The present document describes the technical characteristics and methods of test for testing the SIM Application Toolkit implemented in Mobile Stations (MS) for the Pan European digital cellular communications system and Personal Communication Systems (PCS) operating in the 450 MHz, 480 MHz, 700 MHz, 750 MHz, 850 MHz, 900 MHz, 1 800 MHz and 1 900 MHz frequency band (GSM 400, GSM 700, GSM 750, GSM 850, GSM 900, DCS 1 800 and PCS 1 900) within the European digital cellular telecommunications system, in compliance with the relevant requirements, and in accordance with the relevant guidance given in ISO/IEC 9646-7 [19] and ETS 300 406 [20].

The present document is valid for MS implemented according to GSM Phase2+ R96, or R97, or R98, or R99.

The present document covers the minimum characteristics considered necessary in order to provide sufficient performance for mobile equipment and to prevent interference to other services or to other users, and to the PLMNs.

It does not necessarily include all the characteristics which may be required by a user or subscriber, nor does it necessarily represent the optimum performance achievable.

The present document is part of the GSM-series of technical specifications. The present document neither replaces any of the other GSM technical specifications or GSM related ETSs or ENs, nor is it created to provide full understanding of (or parts of) the GSM 400, GSM 700, GSM 850, GSM 900, DCS1800 and PCS1900 systems . The present document lists the requirements, and provides the methods of test for testing the SIM Application Toolkit implemented in a MS for conformance to the GSM standard.

For a full description of the system, reference should be made to all the GSM technical specifications or GSM related ETSs or ENs. Clause 2 provides a complete list of the GSM technical specifications, GSM related ETSs, ENs, and ETRs, on which this conformance test specifications is based.

If there is a difference between this present conformance document, and any other GSM technical specification or GSM related ETS or EN, or 3GPP TS, then the other GSM technical specification or GSM related ETS or EN or 3GPP TS shall prevail.

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the relevant Release*.
  - For a GSM Phase 2+ Release 1999 MS, references to GSM documents are to version 8.x.y (for 01.-series to 12.-series) or (3.x.y for 21.-series to 35.-series), when available.
  - For a GSM Phase 2+ Release 1998 MS, references to GSM documents are to version 7.x.y, when available.
  - For a GSM Phase 2+ Release 1997 MS, references to GSM documents are to version 6.x.y, when available.
  - For a GSM Phase 2+ Release 1996 MS, references to GSM documents are to version 5.x.y,. when available.

NOTE: References to 3GPP Technical Specifications and Technical Reports throughout the present document shall be interpreted according to the Release shown in the formal reference in this clause, based upon the Release of the implementation under test.

EXAMPLE:	References for a R99 MS shall be interpreted as:
	[1] 3GPP TS 21.905 R99
	[2] 3GPP TS 22.001 R99
	etc.
[1]	3GPP TS 01.04 (R96 to R98): "Abbreviations and acronyms". 3GPP TR 21.905 (R99 onwards): "Vocabulary for 3GPP Specifications".
[2]	3GPP TS 02.01 (R96 to R98): "Principles of telecommunication services supported by a GSM Public Land Mobile Network (PLMN)". 3GPP TS 22.001 (R99 onwards): "Principles of circuit telecommunication services supported by a Public Land Mobile Network (PLMN)".
[3]	3GPP TS 02.03 (R96 to R98): "Teleservices supported by a GSM Public Land Mobile Network (PLMN)". 3GPP TS 22.003 (R99 onwards): "Circuit Teleservices supported by a Public Land Mobile Network (PLMN)".
[4]	3GPP TS 02.04 (R96 to R98): "General on supplementary services". 3GPP TS 22.004 (R99 onwards): "General on supplementary services".
[5]	3GPP TS 02.06 (R96 to R98): "Types of Mobile Stations (MS)".
[6]	3GPP TS 02.07 (R96 to R98): "Mobile Station (MS) features".
[7]	3GPP TS 03.38 (R96 to R98): "Alphabets and language-specific information". 3GPP TS 23.038 (R99 onwards): "Alphabets and language-specific information".
[8]	3GPP TS 03.40 (R96 to R98): "Technical realization of the Short Message Service (SMS); Point-to-Point (PP)". 3GPP TS 23.040 (R99 onwards): "Technical realization of the Short Message Service (SMS)".
[9]	3GPP TS 03.41 (R96 to R98): "Technical realization of Cell Broadcast Service (CBS)". 3GPP TS 23.041 (R99 onwards): "Technical realization of Cell Broadcast Service (CBS)".
[10]	3GPP TS 04.08 (R96 to R99): "Mobile radio interface; Layer 3 specification" (see note 1). 3GPP TS 24.008 (R99 onwards): "Mobile radio interface layer 3 specification; Core network protocols; Stage 3" (see note 1).
[11]	3GPP TS 04.11 (R96 to R98): "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".  3GPP TS 24.011 (R99 onwards): "Point-to-Point (PP) Short Message Service (SMS) Support on mobile radio interface".
[12]	3GPP TS 51.010-1 (Rel-5): "Mobile Station (MS) conformance specification; Part 1: Conformance specification".
[13]	3GPP TS 11.11 (R96 to R99): "Specification of the Subscriber Identity Module - Mobile Equipment (SIM-ME) interface".
[14]	3GPP TS 11.12 (R96): "Specification of the 3 Volt Subscriber Identity Module - Mobile Equipment (SIM-ME) interface".
[15]	3GPP TS 11.14 (R96 to R99): "Specification of the SIM application toolkit for the Subscriber Identity Module - Mobile Equipment (SIM - ME) interface".
[16]	Void.
[17a]	ISO/IEC 10646-1: "Information technology - Universal Multiple Octet Coded Character Set (UCS) - Part 1: Architecture and Basic Multilingual Plane".
[17b]	ISO/IEC 10646-2: "Information technology - Universal Multiple Octet Coded Character Set (UCS) - Part 2: Supplementary Planes".

[18]	3GPP TS 27 007	(R99 onwar	ds): "AT	command set for 30	7 User Equipment	(UE)"
1101	3011 15 27.007	(IC)) Oliwai	us). 111 '	communa set for se	J OSCI Equipincin	(01).

[19] ISO/IEC 9646-7 (1995): "Information technology - Open Systems Interconnection - Conformance

testing methodology and framework - Part 7: Implementation Conformance Statements".

[20] ETSI ETS 300 406 (1995): "Methods for Testing and Specification (MTS); Protocol and profile

conformance testing specifications; Standardization methodology".

## 3 Definitions and abbreviations

# 3.1 Mobile station definition and configurations

The mobile station definition and configurations specified in 3GPP TS 51.010-1 [12] clause 3.1 shall apply, unless otherwise specified in the present clause.

# Applicability

## 3.2.1 Applicability of the present document

The present specification applies to a terminal equipment that supports the SIM Application Toolkit optional feature.

# Applicability of the individual tests

Table B.1 lists the optional features for which the supplier of the implementation states the support.

## 3.2.3 Applicability to terminal equipment

The applicability to terminal equipment specified in 3GPP TS 51.010-1 [12] clause 3.2.3 shall apply, unless otherwise specified in the present clause.

See table A.1.

#### 3.2.4 Definitions

For the purposes of the present document, the terms and definitions given in 3GPP TS 51.010-1 [12], clause 3.3, apply.

#### 3.2.4.1 Format of the table of optional features

#### Option

The optional feature supported or not by the implementation.

#### Support Answer notation

The support columns shall be filled in by the supplier of the implementation. The following common notations, defined in ISO/IEC 9646-7 [19], are used for the support column in the tables below.

Y or y supported by the implementation

N or n not supported by the implementation

N/A, n/a or - no answer required (allowed only if the status is N/A, directly or after evaluation of a conditional

status)

Mnemonic column

The Mnemonic column contains mnemonic identifiers for each item.

#### 3.2.4.2 Format of the applicability table

The applicability of every test in table B.1 is formally expressed by the use of Boolean expression defined in the following clause.

The columns in table B.1 have the following meaning:

- In the "Item" column a local entry number for the requirement in the table is given.
- In the "Description" column a short non-exhaustive description of the requirement is found.
- The "Release" column gives the Release applicable and onwards, for the item in the "Description" column
- The "Test Sequence(s)" column gives a reference to the test sequence number(s) detailed in the present document and required to validate the implementation of the corresponding item in the "Description" column.
- For a given Release, the corresponding "Rel 9x ME" column lists the tests required for a Mobile Station to be declared compliant to this Release.
- The "Support" column is blank in the proforma, and shall be completed by the manufacturer in respect of each particular requirement to indicate the choices, which have been made in the implementation.
- The "Terminal Profile" column gives a reference to the corresponding bit that needs to be present in the Terminal Profile.

#### 3.2.4.3 Status and notations

The "Release 9x ME" columns shows the status of the entries as follows:

The following notations, defined in ISO/IEC 9646-7 [19], are used for the status column:

M	mandatory - the capability is required to be supported.
O	optional - the capability may be supported or not.
N/A	not applicable - in the given context, it is impossible to use the capability.
X	prohibited (excluded) - there is a requirement not to use this capability in the given context.
O.i	qualified optional - for mutually exclusive or selectable options from a set. "i" is an integer which identifies an unique group of related optional items and the logic of their selection which is defined immediately following the table.

Ci conditional - the requirement on the capability ("M", "O", "X" or "N/A") depends on the support of other optional or conditional items. "i" is an integer identifying an unique conditional status expression which is defined immediately following the table. For nested conditional expressions, the syntax "IF ... THEN (IF ... THEN ... ELSE ... ELSE ... shall be used to avoid ambiguities.

#### References to items

For each possible item answer (answer in the support column) there exists a unique reference, used, for example, in the conditional expressions. It is defined as the table identifier, followed by a solidus character "/", followed by the item number in the table. If there is more than one support column in a table, the columns shall be discriminated by letters (a, b, etc.), respectively.

EXAMPLE: A.1/4 is the reference to the answer of item 4 in table A.1.

# Table of optional features

Support of SIM Application Toolkit is optional for Mobile Equipment. However, if an ME states conformance with a specific GSM release, it is mandatory for the ME to support all functions of that release, as stated in table A.1.

The support of letter classes, which specify mainly ME hardware dependent features, is optional for the ME and may supplement the SIM Application Toolkit functionality described in the present document. If an ME states conformance to a letter class, it is mandatory to support all functions within the respective letter class.

The supplier of the implementation shall state the support of possible options in table A.1.

**Table A.1: Options** 

Item	Option	Status	Support	Mnemonic
1	Capability Configuration parameter	0		O_Cap_Conf
2	Sustained text	0		O_sust_text
3	UCS2 coding scheme for Entry	0		O_Ucs2_Entry
4	Extended Text String	0		O_Ext_Str
5	Help information	0		O_Help
6	Icons	0		O_lcons
7	Class A: Dual Slot	0		O_Dual_Slot
8	Detachable reader	0		O_Detach_Rdr
9	Class B: RUN AT	0		O_Run_At
10	Class C: LAUNCH BROWSER	0		O_LB
11	Class D: Soft keys	0		O_Soft_key
12	Class E: B.I.P	0		O_BIP
13	Screen sizing parameters	0		O_Scr_Siz
14	Screen Resizing	0		O_Scr_Resiz
15	UCS2 coding scheme for Display	0		O_Ucs2_Disp
16	Mobile supporting GPRS	0		O_GPRS
17	Mobile supporting UDP	0		O_UDP
18	Mobile supporting TCP	0		O_TCP
19	Redial in Set Up Call	0		O_Redial
20	Mobile decision to respond with	0		O_D_NoResp
	"No response from user" in finite			
	time			

# 3.4 Applicability table

Table B.1: Applicability of tests

m	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	PROFILE DOWNLOAD 27.22.1	R96	1	M	M	М	М	E.1/1	
	Contents of the TERMINAL PROFILE command 27.22.2	R96		М	М	М	M	E.1/1	
,	Servicing of Proactive SIM Commands 27.22.3	R96		М	М	M	M		
	DISPLAY TEXT 27.22.4.1								
	Unpacked	R96	1.1	М	М	М	М	E.1/17	
	Screen busy	R96	1.2	М	М	М	M	E.1/17	
	high priority	R96	1.3	М	М	M	M	E.1/17	
	Packed	R96	1.4	М	М	M	M	E.1/17	
	clear after delay	R96	1.5	М	М	M	M	E.1/17	
	clear after user confirmation	R96	1.1	М	М	M	M	E.1/17	
	long text up to 160 bytes	R96	1.6	М	М	M	M	E.1/17	
	Backwards move in SIM session	R96	1.7	М	М	M	M	E.1/17	
	Session terminated by user	R96	1.8	М	М	M	M	E.1/17	
	Command not understood by ME	R96	1.9	М	М	M	M	E.1/17	
	no response from user	R96	2.1	М	М	M	M	E.1/17	
	Extension Text	R98	3.1			C106	C106	E.1/17 AND E.1/16	
	sustained text	R98	4.1, 4.2, 4.3, 4.4			C104	C104	E.1/17 AND E.1/65	
	Icons	R98	5.1, 5.2, 5.3			C108	C108	E.1/17	
	UCS2 display	R97	6.1		C118	C118	C118	E.1/17 AND E.1/15	

1	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	GET INKEY 27.22.4.2		, ,						
	prompt unpacked	R96	1.1	М	М	М	М	E.1/18	
Ī	prompt packed	R96	1.2	М	M	M	M	E.1/18	
Ī	digits only	R96	1.1	М	M	M	M	E.1/18	
	Backwards move in SIM session	R96	1.3	М	М	M	M	E.1/18	
Ī	Session terminated by user	R96	1.4	М	M	M	M	E.1/18	
	SMS alphabet	R96	1.5	М	М	M	M	E.1/18	
	Long text up to 160 bytes	R96	1.6	М	М	M	M	E.1/18	
	no response from user	R96	2.1	М	М	М	М	E.1/18	
	UCS2 display	R97	3.1		C118	C118	C118	E.1/18	
	, ,							AND	
								E.1/15	
Ī	UCS2 display, Long text up to 70 chars	R97	3.2		C118	C118	C118	E.1/18	
								AND	
								E.1/15	
Ī	UCS2 format of entry	R97	4.1		C105	C105	C105	E.1/18	
								AND	
								E.1/14	
Ī	"Yes/No" response	R98	5.1			M	M	E.1/18	
								AND	
								E.1/60	
Ī	Icons	R98	6.1, 6.2,			C108	C108	E.1/18	
			6.3, 6.4						
	Help information	R97	7.1		C107	C107	C107	E.1/18	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
6	GET INPUT 27.22.4.3								
	input unpacked	R96	1.1	М	M	М	М	E.1/19	
	input packed	R96	1.2	М	M	М	М	E.1/19	
	digits only	R96	1.1	М	M	М	М	E.1/19	
	SMS alphabet	R96	1.3	М	M	М	М	E.1/19	
	hidden input	R96	1.4	М	M	М	М	E.1/19	
	min / max acceptable length	R96	1.5, 1.9	М	М	М	М	E.1/19	
	Backwards move in SIM session	R96	1.6	М	M	М	М	E.1/19	
	Session terminated by user	R96	1.7	М	M	М	М	E.1/19	
	Prompt text up to 160 bytes	R96	1.8	М	M	М	М	E.1/19	
	SMS default alphabet, ME to echo text, packing not required	R96	1.9	М	М	М	М	E.1/19	
	Null length for the text string	R96	1.10	М	M	М	М	E.1/19	
	no response from user	R96	2.1	М	М	М	М	E.1/19	
	UCS2 display	R97	3.1, 3.2		C118	C118	C118	E.1/19	
								AND	
								E.1/15	
	UCS2 entry	R97	4.1, 4.2		C105	C105	C105	E.1/19	
	·							AND	
								E.1/14	
	default text for the input	R97	5.1, 5.2		M	М	М	E.1/19	
	icons	R98	6.1, 6.2, 6.3, 6.4			C108	C108	E.1/19	
	help information	R97	7.1		C107	C107	C107	E.1/19	
7	MORE TIME 27.22.4.4	R96	1.1	М	M	М	М	E.1/20	
8	PLAY TONE 27.22.4.5								
	play all tones	R96	1.1	М	M	М	М	E.1/21	
	display alpha	R96	1.1	М	M	М	М	E.1/21	
	user termination	R96	1.1	М	M	М	М	E.1/21	
	superimpose	R96	1.1	М	M	М	М	E.1/21	
	UCS2 display	R97	TBD					E.1/21	
								AND	
								E.1/15	
	icons	R98	TBD					E.1/21	
9	POLL INTERVAL 27.22.4.6								
	duration	R96	1.1	М	M	М	М	E.1/22	
10	REFRESH 27.22.4.7								
	SIM initialization, enabling FDN mode	R96	1.1	М	М	М	М	E.1/24	
	file change notification of FDN file	R96	1.2	М	М	М	М	E.1/24	
	SIM initialization and file change notification of PLMN	R96	1.3	М	М	М	М	E.1/24	
	SIM initialization and full file change notification, enabling FDN mode	R96	1.4	M	M	M	M	E.1/24	
	SIM reset	R96	1.5	М	М	М	M	E.1/24	1
	SIM Initialization after SMS-PP data download	R96	1.6	M	M	M	M	E.1/24	
	Siivi iiiittalizatioii aitei Sivis-FP data dowiiload	K90	0.1	IVI	IVI	IVI	íVí	□.1/24	1

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	IMSI Changing procedure	R98	2.1			М	М	E.1/24	
11	SET UP MENU 27.22.4.8								
	Set up, menu selection, replace and remove menu	R96	1.1	М	М	М	М	E.1/30	
								AND E.1/4	
	Large menu	R96	1.2	М	M	М	M	E.1/30	
								AND E.1/4	
	help information	R97	2.1		C107	C107	C107	E.1/30	
								AND E.1/4	
	next action indicator	R97	3.1		M	М	М	E.1/30	
	icons	R98	4.1, 4.2			C108	C108	E.1/30	
	soft key access	R99	5.1				C112	E.1/30	
								AND	
								E.1/74	
12	SELECT ITEM 27.22.4.9								
	Mandatory features	R96	1.1	М	M	М	M	E.1/25	
	Large menu	R96	1.2, 1.3,	М	M	М	M	E.1/25	
			1.5,1.6						
	Backwards move	R96	1.4	М	M	М	M	E.1/25	
	user termination	R96	1.5	М	M	М	М	E.1/25	
	no response from user	R96	8.1	C120	C120	C120	C120	E.1/25	
	next action indicator	R97	2.1		M	М	M	E.1/25	
	default selected item	R97	3.1		M	М	М	E.1/25	
	help information	R97	4.1		C107	C107	C107		
	icons	R98	5.1, 5.2			C108	C108	E.1/25	
	Presentation style	R98	6.1, 6.2			М	М	E.1/25	
	Soft keys	R99	7.1				C112	E.1/25	
								AND	
								E.1/73	
13	SEND SMS 27.22.4.10								
	Packing not required	R96	1.1, 1.3 1.5	М	M	M	M	E.1/26	
	Packing required	R96	1.2, 1.4	М	М	М	М	E.1/26	
	8 bit data	R96	1.1, 1.2	М	М	М	М	E.1/26	
	SMS default alphabet	R96	1.3, 1.4, 1.5	М	M	М	М	E.1/26	
	160 bytes length	R96	1.4, 1.5	М	M	М	М	E.1/26	
	Alpha identifier	R96	1.6, 1.7, 1.8	М	М	M	М	E.1/26	
	UCS2 SMS	R97	2.1		C118	C118	C118	E.1/26 AND E.1/15	
	icons	R98	3.1, 3.2		1	C108	C108	E.1/26	
14	SEND SS 27.22.4.11	1100	0.1, 0.2			0.00	0.00	2.1/20	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	call forward unconditional, all bearers, successful	R96	1.1	M	М	М	М	E.1/27	
	call forward unconditional, all bearers, Return Error	R96	1.2	M	M	M	М	E.1/27	
	call forward unconditional, all bearers, Reject	R96	1.3	M	М	M	М	E.1/27	
	call forward unconditional, all bearers, successful, SS request size limit	R96	1.4	М	М	M	М	E.1/27	
	interrogate CLIR status, successful, alpha identifier limits	R96	1.5	M	М	М	М	E.1/27	
	call forward unconditional, all bearers, successful, null data alpha identifier	R96	1.6	М	М	М	М	E.1/27	
	call forward unconditional, all bearers, successful, icon support	R98	2.1, 2.2, 2.3, 2.4			C108	C108	E.1/27	
	UCS2 display	R97	3.1		C118	C118	C118	E.1/27 AND E.1/15	
15	SEND USSD 27.22.4.12								
	7-bit data, successful	R96	1.1	M	M	M	M	E.1/28	
	8-bit data, successful	R96	1.2	M	M	М	М	E.1/28	
	UCS2 data, successful	R96	1.3	M	M	M	М	E.1/28	
	7-bit data, unsuccessful	R96	1.4	M	M	M	М	E.1/28	
	7-bit data, unsuccessful	R96	1.5	М	M	М	М	E.1/28	
	256 octets, 7-bit data, successful, long alpha identifier	R96	1.6	М	M	М	М	E.1/28	
	7-bit data, successful, no alpha identifier	R96	1.7	M	M	М	М	E.1/28	
	7-bit data, successful, null length alpha identifier	R96	1.8	M	M	М	М	E.1/28	
	icons	R98	2.1, 2.2, 2.3, 2.4			C108	C108	E.1/28	
	UCS2	R97	3.1		C118	C118	C118	E.1/28 AND E.1/15	
16	SET UP CALL 27.22.4.13								
	Call confirmed by the user and connected	R96	1.1	М	М	М	М	E.1/29	
	call rejected by the user	R96	1.2	M	M	M	М	E.1/29	
	redial	R96	1.3	C119	C119	C119	C119	E.1/29	
	putting all other calls on hold, ME busy	R96	1.4	M	M	М	М	E.1/29	
	disconnecting all other calls, ME busy	R96	1.5	M	M	М	M	E.1/29	
	only if not currently busy on another call, ME busy	R96	1.6	M	M	М	М	E.1/29	
	putting all other calls on hold, call hold is not allowed	R96	1.7	М	М	М	М	E.1/29	
	Capability configuration	R96	1.8	C101	C101	C101	C101	E.1/29	
	long dialling number string	R96	1.9	М	M	М	М	E.1/29	
	long first alpha identifier	R96	1.10	М	M	М	М	E.1/29	
	Called party subaddress	R96	1.11	М	M	М	М	E.1/29	
	maximum duration for the redial mechanism	R96	1.12	C119	C119	C119	C119	E.1/29	
	second alpha identifier	R98	2.1			M	М	E.1/29 AND E.1/63	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	UCS2 Display	R97	TBD					E.1/29 AND E.1/15	
	icons	R98	3.1,3.2, 3.3, 3.4			C108	C108	E.1/29	
17	POLLING OFF 27.22.4.14	R96	1.1	М	М	М	М	E.1/23	
18	PROVIDE LOCAL INFO 27.22.4.15								
	location information	R96	1.1	М	M	М	М	E.1/31	
	IMEI	R96	1.2	М	M	M	М	E.1/31	
	network measurement results and BCCH channel list	R98	1.3			М	М	E.1/32 AND E.1/67	
	Date, time and time zone	R98	1.4			М	М	E.1/59	
	language setting	R99	1.5				М	E.1/68	
	Timing advance	R99	1.6				M	E.1/69	
19	SET UP EVENT LIST 27.22.4.16	1100							
	Set up call connected event	R97	1.1		М	М	М	E.1/33 AND E.1/35	
	Replace by new event list	R97	1.2		М	М	М	E.1/33 AND E.1/35 AND E.1/36	
	Remove event	R97	1.3		М	М	М	E.1/33 AND E.1/35	
	Remove Event on ME Power Cycle	R97	1.4		М	М	М	E.1/33 AND E.1/35	
20	PERFORM CARD APDU 27.22.4.17								
	Additional card inserted, Select MF and Get Response	R98	1.1			C109	C109	E.1/51	
	Additional card inserted, Select DF GSM, Select EF PLMN , Update Binary, Read Binary on EF PLMN	R98	1.2			C109	C109	E.1/51	
	Additional card inserted, card powered off	R98	1.3			C109	C109	E.1/51	
	No card inserted, card powered off	R98	1.4			C109	C109	E.1/51	
	Invalid card reader identifier	R98	1.5			C109	C109	E.1/51	
	Detachable reader	R98	2.1			C116	C116	E.1/51	
21	POWER OFF CARD 27.22.4.18								
_	Additional card inserted	R98	1.1			C109	C109	E.1/50	
	No card inserted	R98	1.2			C109	C109	E.1/50	
	Detachable reader	R98	2.1			C116	C116	E.1/50	
22	POWER ON CARD 27.22.4.19								1

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	Additional card inserted	R98	1.1			C109	C109	E.1/49	
	No ATR	R98	1.2			C109	C109	E.1/49	
	No card inserted	R98	1.3			C109	C109	E.1/49	
	Detachable reader	R98	2.1			C116	C116	E.1/49	
23	GET READER STATUS 27.22.4.20								
	Additional card inserted, card powered	R98	1.1			C109	C109	E.1/52	
	Additional card inserted, card not powered	R98	1.2			C109	C109	E.1/52	
	Additional card inserted, card not present	R98	1.3			C109	C109	E.1/52	
	Detachable reader	R98	2.1			C116	C116	E.1/52	
24	TIMER MANAGEMENT 27.22.4.21.1						9.10		
	Start timer 1 several times, get the current value of the timer and deactivate the timer successfully	R98	1.1			М	М	E.1/57 AND E.1/58	
	Start timer 2 several times, get the current value of the timer and deactivate the timer successfully	R98	1.2			М	М	E.1/57 AND E.1/58	
	Start timer 8 several times, get the current value of the timer and deactivate the timer successfully	R98	1.3			M	М	E.1/57 AND E.1/58	
	Try to get the current value of a timer which is not started: action in contradiction with the current timer state	R98	1.4			М	М	E.1/57 AND E.1/58	
	Try to deactivate a timer which is not started: action in contradiction with the current timer state	R98	1.5			M	М	E.1/57 AND E.1/58	
	Start 8 timers successfully	R98	1.6			М	М	E.1/57 AND E.1/58	
25	ENVELOPE TIMER EXPIRATION 27.22.4.21.2								
	Pending proactive SIM command	R98	2.1			М	М	E.1/6 AND E.1/57	
	SIM application toolkit busy	R98	2.2			M	M	E.1/6 AND E.1/57 AND E.1/20	
26	SET UP IDLE MODE TEXT 27.22.4.22		1				1	220	
	Display idle mode text	R98	1.1			М	М	E.1/61 AND E.1/33 AND E.1/39	
	Replace idle mode text	R98	1.2			М	М	E.1/61 AND	

١	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
								E.1/33 AND E.1/39	
-	Remove idle mode test	R98	1.3			M	М	E.1/61 AND E.1/33 AND E.1/39	
•	Competing information on ME display	R98	1.4			M	М	E.1/61 AND E.1/33 AND E.1/39	
	ME powered cycled	R98	1.5			M	М	E.1/61 AND E.1/33 AND E.1/39	
	Refresh with SIM initialization	R98	1.6			M	M	E.1/61 AND E.124 AND E.1/33 AND E.1/39	
	Large text string	R98	1.7			M	М	E.1/61 AND E.1/33 AND E.1/39	
	Followed by a Display Text	R98	1.8			M	M	E.1/61 AND E.1/33 AND E.1/39 AND E.1/17	
=	Followed by a Play Tone	R98	1.9			M	М	E.1/61 AND E.1/33 AND E.1/39 AND E.1/21	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
	icons	R98	2.1, 2.2, 2.3, 2.4			C108	C108	E.1/61 AND E.1/39	
	UCS2 display	R98	3.1			C118	C118	E.1/61 AND E.1/15 AND E.1/39	
27	RUN AT COMMAND 27.22.4.23							211700	
	No alpha Identifier	R98	1.1			C110	C110	E.1/62	
	null data alpha identifier presented	R98	1.2			C110	C110	E.1/62	
	alpha identifier presented	R98	1.3			C110	C110	E.1/62	
	icons	R98	2.1, 2.2, 2.3, 2.4, 2.5			C114	C114	E.1/62	
	SEND DTMF 27.22.4.24								
	A call has been successfully established before the beginning of the test	R98	1.1			M	М	E.1/66	
	alpha identifier	R98	1.2, 1.3			М	М	E.1/66	
	Mobile is not in a speech call	R98	1.4			М	М	E.1/66	
	Icons	R98	2.1, 2.2, 2.3			C108	C108	E.1/66	
	UCS2 display	R98	3.1			C118	C118	E.1/66 AND E.1/15	
	LANGUAGE NOTIFICATION 27.22.4.25								
	Specific language notification	R99	1.1				М	E.1/70	
	Non specific language notification	R99	1.2				М	E.1/70	
	LAUNCH BROWSER 27.22.4.26								
	No session already launched: Connect to the default URL	R99	1.1				C111	E.1/71	
	connect to the specified URL, alpha identifier length=0	R99	1.2				C111	E.1/71	
	Browser identity, no alpha identifier	R99	1.3				C111	E.1/71	
	one bearer specified and gateway/proxy identity	R99	1.4				C111	E.1/71	
	several bearers specified, gateway/proxy id specified	R99	1.5	]			C111	E.1/71	
	Interaction with current session	R99	2.1, 2.2, 2.3				C111	E.1/71	
	UCS2 display	R99	3.1				C117	E.1/71 AND E.1/15	
	icons	R99	4.1, 4.2				C115	E.1/71	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
31	OPEN CHANNEL 27.22.4.27								
	Immediate link establishment, CSD, 9600 bps	R99	1.1, 1.2, 1.3, 1.4, 1.5, 1.6				C113	E.1/89 AND E.1/97	
	immediate link establishment, CSD, 9600 bps, performed with modification	R99	1.7				C113	E.1/89 AND E.1/97	
	immediate link establishment, CSD, Network currently unable to process command	R99	1.8				C113	E.1/89 AND E.1/97	
	immediate link establishment, CSD, No channel available	R99	1.9				C113	E.1/89 AND E.1/97	
	ME busy	R99	1.10				M	E.1/89 AND E.1/97 AND E.1/29	
32	CLOSE CHANNEL 27.22.4.28								
	successful	R99	1.1				C113	E.1/89 AND E.1/90	
	with an invalid channel identifier	R99	1.2				C113	E.1/89 AND E.1/90	
	on an already closed channel	R99	1.3				C113	E.1/90	
33	RECEIVE DATA 27.22.4.29								
	already opened channel	R99	1.1				C113	E.1/89 AND E.1/91	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
34	SEND DATA 27.22.4.30								
	immediate mode	R99	1.1				C113	E.1/89 AND E.1/92	
	Store mode	R99	1.2				C113	E.1/89 AND E.1/92	
	Store mode, Tx buffer fully used	R99	1.3				C113	E.1/89 AND E.1/92	
	2 consecutive SEND DATA Store mode	R99	1.4				C113	E.1/89 AND E.1/92	
	immediate mode with a bad channel identifier	R99	1.5				C113	E.1/89 AND E.1/92	
	immediate mode, Proactive SIM session terminated by the user	R99	1.6				C113	E.1/89 AND E.1/92	
35	GET CHANNEL STATUS 27.22.4.31								
	without any BIP channel opened	R99	1.1				C113	E.1/93	
	with a BIP channel currently opened	R99	1.2				C113	E.1/89 AND E.1/93	
	after a link dropped	R99	1.3				C113	E.1/89 AND E.1/93	
36	DATA DOWNLOAD TO SIM 27.22.5								
37	SMS-PP DATA DOWNLOAD 27.22.5.1								
	General data coding, SIM responds with '90 00'	R96	1.1	М	M	М	М	E.1/2	
	SIM responds with '91 XX'	R96	1.2	М	M	М	М	E.1/2	
	More time	R96	1.3	М	M	М	М	E.1/2	
	8 bit alphabet	R96	1.4	М	M	М	M	E.1/2	
	Data coding / message class	R96	1.5, 1.6	M	M	М	M	E.1/2	
38	SMS-CB DATA DOWNLOAD 27.22.5.2								
	ME does not display message	R96	1.1	М	М	М	M	E.1/3	
	More time	R96	1.2	М	М	M	M	E.1/3 AND E.1/20	
	ME displays message	R96	1.3	M	M	M	M	E.1/3	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
39	CALL CONTROL BY SIM 27.22.6		<u> </u>						
	Procedure for MO calls (Cell identity in envelope call control)	R97	1.1 to 1.14		М	M	M	E.1/10 AND E.1/11 AND E.1/13 AND E.1/29	
	Procedure for SS (Cell identity in envelope call control)	R97	2.1, 2.2, 2.3, 2.4		M	M	M	E.1/10 AND E.1/11	
	Interaction with FDN (Cell identity in envelope call control)	R97	3.1, 3.2, 3.3, 3.5		М	М	М	E.1/10	
	Support of BDN service (Cell identity in envelope call control)	R97	4.1, 4.2, 4.3, 4.4		М	M	M	E.1/10	
	MO SMS control by SIM	R97	TBD					E.1/12	
40	EVENT DOWNLOAD 27.22.7								
	27.22.7.1: MT call event	R97	1.1		M	M	M	E.1/34 AND E.1/33	
	27.22.7.2.1: call connected event	R97	1.1		М	M	M	E.1/35 AND E.1/33	
	27.22.7.2.2: ME supporting SET UP CALL	R97	2.1		М	М	M	E.1/35 AND E.1/29 AND E.1/33	
	27.22.7.3: call disconnected event	R97	1.1		M	M	M	E.1/36 AND E.1/33	
	27.22.7.4: location status event	R97	1.1		М	M	M	E.1/37 AND E.1/33	
	27.22.7.5: user activity event	R97	1.1		М	М	М	E.1/38 AND E.1/33	
	27.22.7.6: idle screen available event	R97	1.1		М	M	M	E.1/39 AND E.1/33	
	27.22.7.7.1: Card reader status normal	R98	1.1			C109	C109	E.1/40 AND E.1/33	
	27.22.7.7.2: Detachable card reader	R98	2.1			C116	C116	E.1/40	

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Terminal Profile	Support
								AND	
	27 22 7 0. language calcution areas	R99	1.1				M	E.1/33 E.1/41	
	27.22.7.8: language selection event	K99	1.1				IVI	AND	
								E.1/33	
	27.22.7.9: Browser termination event	R99	1.1				C111	E.1/42	
		1.00						AND	
								E.1/33	
	27.22.7.10: Data available event	R99	1.1				C113	E.1/43	
								AND	
								E.1/89	
	27.22.7.11: Channel status event	R99	1.1				C113	E.1/44	
								AND	
0404		0.00==0==4						E.1/89	
C101 C102	IF A.1/1 THEN M ELSE N/A void	O_Cap_Conf							
C102	void								
C104	IF A.1/2 THEN M ELSE N/A	O_Sust_text							
C105	IF A.1/3 THEN M ELSE N/A	O_Ucs2_Entry							
C106	IF A.1/4 THEN M ELSE N/A	O Ext Str							
C107	IF A.1/5 THEN M ELSE N/A	O_Help							
C108	IF A.1/6 THEN (O.1 OR O.2) ELSE N/A	O_Icons							
C109	IF A.1/7 THEN M ELSE N/A	O_Dual_Slot							
C110	IF A.1/9 THEN M ELSE N/A	O_Run_At							
C111	IF A.1/10 THEN M ELSE N/A	O_LB							
C112	IF A.1/11 THEN M ELSE N/A	O_Soft_key							
C113 C114	IF A.1/12 THEN M ELSE N/A IF C110 AND C108 THEN M ELSE N/A	O_BIP O_Run_At AND O_Io	ono						
C114 C115	IF C110 AND C108 THEN M ELSE N/A IF C111 AND C108 THEN M ELSE N/A	O_KUII_ALAND O_IC	OUS						
C116	IF C111 AND C108 THEN M ELSE N/A	O_LB AND O_ICONS	Detach Rdr						
C117	IF C111 AND C105 THEN M ELSE N/A	O_LB AND O_Ucs2	_Detach_Rui						
C118	IF A.1/14 THEN M ELSE N/A	O_Ucs2_Disp							
$\circ$									
C119	IF A.1/19 THEN M ELSE N/A	O_Redial							
	IF A.1/19 THEN M ELSE N/A IF A.1/20 THEN M ELSE N/A	O_Redial O_D_NoResp							
C119		O_D_NoResp rd 1 of EF <sub>(IMG)</sub> , tests x.1A I							

### 3.5 Conventions for mathematical notations

The conventions for mathematical notations specified in 3GPP TS 51.010-1 [12] clause 3.4 shall apply, unless otherwise specified in the present clause.

### 3.6 Conventions on electrical terms

The conventions on electrical terms specified in 3GPP TS 51.010-1 [12] clause 3.5 shall apply, unless otherwise specified in the present clause.

### 3.7 Terms on test conditions

The terms on test conditions specified in 3GPP TS 51.010-1 [12] clause 3.6 shall apply, unless otherwise specified in the present clause.

# 4 Test equipment

The test equipment is specified in 3GPP TS 51.010-1 [12] clause 4.

# 5 Testing methodology in general

# 5.1 Testing of optional functions and procedures

Any function or procedure which is optional, as indicated in the present document, may be subject to a conformance test if it is implemented in the ME.

### 5.2 Test interfaces and facilities

The test interfaces and facilities specified in 3GPP TS 51.010-1 [12] clause 5.2 shall apply, unless otherwise specified in the present clause.

The SIM interface provides the main test interface for the purpose of performing conformance tests.

# 5.3 Different protocol layers

The different protocol layers specified in 3GPP TS 51.010-1 [12] clause 5.3 shall apply, unless otherwise specified in the present clause.

# 5.4 Information to be provided by the apparatus supplier

The information to be provided by the apparatus supplier specified in 3GPP TS 51.010-1 [12] clause 5.4 shall apply, unless otherwise specified in the present clause.

In addition, the apparatus supplier shall provide the information with respect the Supported Option table A.1.

### 5.5 Definitions of transmit and receive times

The definitions of transmit and receive times specified in 3GPP TS 51.010-1 [12] clause 5.5 shall apply, unless otherwise specified in the present clause.

# 6 Reference test methods

The reference test methods specified in 3GPP TS 51.010-1 [12] clause 6 shall apply, unless otherwise specified.

# 7 Implicit testing

For some GSM features conformance is not verified explicitly in the present document. This does not imply that correct functioning of these features is not essential, but that these are implicitly tested to a sufficient degree in other tests.

It should be noted that for these features some aspects have to be and are explicitly tested, e.g. the ability to switch between 3v and 5v operation.

Some SIM features will be explicitly tested as result of other tests. These should be identified for the following reason:

- To identify the areas of overlap and thus provide a more efficient testing.

# 8 Measurement uncertainty

The measured value relating to the corresponding limit shall be used to determine whether or not a terminal equipment meets the requirement. (ETR 028, annex B).

This process is often referred to as "shared risk".

# 9 Format of tests

In general the following basic format for tests is used:

#### 27.22.X.X. Tested command

27.22.X.X.1 Command tested in «environment #1" (NORMAL, ICONS, UCS2 ...)

#### 27.22.X.X.1.1 Definition and applicability

This clause refers back to clause 3.2.2.

#### 27.22.X.X.1.2 Conformance requirement

Only if required, this clause details the necessary core specification references.

#### 27.22.X.X.1.3 Test purpose

This clause details the purpose of the test.

#### **27.22.X.X.1.4** Method of test

#### 27.22.X.X.1.4.1 Initial conditions

If present this clause defines the initial conditions to be established before running each test sequence.

#### 27.22.X.X.1.4.2 Procedure

This clause details the test procedure. Each test sequence shall be carried out independently unless otherwise stated.

• Sequence 1.1 (further initial conditions, added here)

Command 1.1.1
TERMINAL RESPONSE1.1.1A or 1.1.1B
Command 1.1.2
TERMINAL RESPONSE1.1.2

PROACTIVE COMMAND 1.1.1

**TERMINAL RESPONSE 1.1.1A** 

TERMINAL RESPONSE 1.1.1B

PROACTIVE COMMAND 1.1.2

**TERMINAL RESPONSE 1.1.2** 

• Sequence 1.2

Command 1.2.1
TERMINAL RESPONSE 1.2.1
Command 1.2.2
TERMINAL RESPONSE1.2.2 (same as TERMINAL RESPONSE 1.2.1)
Command 1.2.3
TERMINAL RESPONSE 1.2.3

PROACTIVE COMMAND 1.2.1

PROACTIVE COMMAND 1.2.2

PROACTIVE COMMAND 1.2.3

TERMINAL RESPONSE 1.2.1

TERMINAL RESPONSE 1.2.2

**TERMINAL RESPONSE 1.2.3** 

• Sequence 1.3

Command 1.3.1 TERMINAL RESPONSE1.3.1

PROACTIVE COMMAND 1.3.1

**TERMINAL RESPONSE 1.3.1** 

### 27.22.X.X.1.5 Test requirement

This clause details the conditions to be met for successful completion of the test.

#### 27.22.X.X.2 Command tested in "environment #2" (NORMAL, ICONS, UCS2 ...)

27.22.X.X. 2.1 Definition and applicability

27.22.X.X. 2.2 Conformance requirement

**27.22.X.X. 2.3** Test purpose

#### 27.22.X.X. 2.4 Method of test

27.22.X.X. 2.4.1.1 Initial conditions

#### 27.22.X.X. 2.4.1.2 Procedure

• Sequence 2.1

Command 2.1.1

TERMINAL RESPONSE2.1.1A or 2.1.1B

Command 2.1.2

TERMINAL RESPONSE2.1.2

PROACTIVE COMMAND 2.1.1

**TERMINAL RESPONSE 2.1.1A** 

**TERMINAL RESPONSE 2.1.1B** 

PROACTIVE COMMAND 2.1.2

**TERMINAL RESPONSE 2.1.2** 

• Sequence 2.2

Command 2.2.1

TERMINAL RESPONSE 2.2.1

Command 2.2.2

TERMINAL RESPONSE 2.2.2 (same as TERMINAL RESPONSE 2.2.1)

Command 2.2.3

TERMINAL RESPONSE 2.2.3

PROACTIVE COMMAND 2.2.1

PROACTIVE COMMAND 2.2.2

PROACTIVE COMMAND 2.2.3

Coding TERMINAL RESPONSE 2.2.1

Coding TERMINAL RESPONSE 2.2.2

Coding TERMINAL RESPONSE 2.2.3

27.22.X.X.2.5 Test requirement

# 10 Generic call set up procedures

The generic call set up procedure specified in 3GPP TS 51.010-1 [12] clause 10 shall apply, unless otherwise specified in the present clause.

# 11 - 26 Not used

# 27 Testing of the SIM/ME interface

This clause is an addition to 3GPP TS 51.010-1 [12] clause 27 to confirm the correct interpretation of the SIM Application Toolkit commands and the correct operation of the Toolkit facilities.

The definitions, declarations and default values specified in 3GPP TS 51.010-1 [12] clause 27 shall apply, unless otherwise specified in the present clause.

A SIM Simulator with the appropriate SIM Application Toolkit functionality will be required. The SIM data defined below shall be used for all test cases unless otherwise specified within the test case.

The comprehension required flags in SIMPLE-TLV objects that are included in a TERMINAL RESPONSE or an ENVELOPE shall be set as described in TS 11.14 [15]. This means that in cases where it is up to the ME to decide if this flag is used or not, the corresponding Tag coding in the TERMINAL RESPONSEs and ENVELOPEs in this document represents only one of the two valid possibilities.

### 27.1 - 27.21 Not used

# 27.22 SIM Application Toolkit

### 27.22.1 General Test purpose

Testing of functional conformance to SIM Application Toolkit commands, including pro-active SIM commands.

All facilities given by the TERMINAL PROFILE as supported, for which tests exist in the present document, shall be tested.

Many of the proactive SIM commands include an alpha identifier data object. This is intended to be a short one or two word identifier for the ME to optionally display on the screen along with any other indications, at the same time as the ME performs the SIM command.

NOTE: The sequence of SIM Application Toolkit commands are specific to the Toolkit Application being executed within the SIM, hence sequential testing of commands is not possible. The testing will therefore have to be performed on a command by command basis.

# 27.22.2 Definition of default values for SIM Application Toolkit testing

A SIM containing the following default values is used for all tests of this clause unless otherwise stated.

For each item, the logical default values and the coding within the Elementary Files (EF) of the SIM follow, as defined in:

• 3GPP TS 11.10-1, clause 27 [12].

NOTE 1: Bx represents byte x of the coding.

NOTE 2: Unless otherwise defined, the coding values in binary.

#### EFSST (SIM Service Table)

#### Logically:

Abbreviated Dialling Numbers allocated and activated
Fixed Dialling Numbers allocated and activated
Extension 1 allocated and activated
Extension 2 allocated and activated
SMS Parameters allocated and activated
Cell Broadcast Message Identifier allocated and activated
Data download via SMS-CB allocated and activated
Data download via SMS-PP allocated and activated
Menu selection allocated and activated
Call control allocated and not activated
Proactive SIM allocated and activated
Cell Broadcast Message Identifier Ranges allocated and activated
Barred Dialling Numbers allocated and not activated

(Service 32) Extension4 allocated and activated

(Service 37) Mobile Originated Short Message control by SIM allocated and not activated

(Service 39) Image (IMG) allocated and activated

(Service 41) USSD string data object supported in Call Control allocated and activated

(Service 42) RUN AT COMMAND command allocated and activated

(Service 48) Extended Capability Configuration Parameters allocated and activated

	B4	B3	B2	B1	Coding:
lxx	xxxx11xx	1111111xx	XXXXXXX	xx1111xx	
	xxxx1	1111111xx	XXXXXXX	xx1111xx	

B5	B6	B7	B8
XXXXXXX	XXXXXXX	01111111	11011111

B9	B10	B11	B12
xxxxxxx	xx11xx01	xxxx1111	11xxxxxx

EF<sub>Phase</sub> (SIM Phase Identification)

Logically: Phase 2+

Coding: '03'

EF<sub>IMSI</sub> (International Mobile Subscriber Identity)

Logically:

Length: 8 bytes

IMSI: 001 01 0123456789

Coding: '08 09 10 10 10 32 54 76 98'

EF<sub>CBMI</sub> (Cell Broadcast Message Identifier)

Logically:

Cell Broadcast Message Identifier 1: '0C 0C'

Coding: OC OC FF .. FF

EF<sub>CBMID</sub> (Cell Broadcast Message Identifier for Data Download)

Logically:

Cell Broadcast Message Identifier 1: '10 01'

Coding: 10 01 FF .. FF

EF<sub>FDN</sub> (Fixed Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "ABC"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 123

CCI: None Ext2: None

Coding:	B1	B2	В3	B4	 B32	B33	B34	B35	B36	B37	 B46
Record 1:	41	42	43	FF	 FF	03	81	21	F3	FF	 FF

Record 2:

Length of alpha identifier: 32 characters
Alpha identifier: "DEF"
Length of BCD number: "04"

TON and NPI: Telephony and Unknown

Dialled number: 9876 CCI: None Ext2: None

Coding:	B1	B2	В3	B4	 B32	B33	B34	B35	B36	B37	 B46
Record 1:	44	45	46	FF	 FF	03	81	89	67	FF	 FF

#### EF<sub>BDN</sub> (Barred Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "CBA"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 321
CCI: None
Ext4: None
Comparison Method Info: None

Coding:	B1	B2	B3	B4	 B32	B33	B34	B35	B36	B37	 B46
Record 1:	43	42	41	FF	FF	03	81	23	F1		FF

NOTE: EF<sub>BDN</sub> shall be invalidated unless otherwise stated, i.e. by indicating that Barred Dialling Numbers

service is enabled.

#### EF<sub>ECC</sub> (Emergency Call Codes)

Logically:

Emergency Call Code 1: '1020'

Coding:     01   02   FF
--------------------------

Emergency Call Code 2: '112'

Coding:	11	F2	FF		

#### EF<sub>SMSP</sub> (Short message service parameters)

Logically:

Record 1:

Record length: 28 bytes

Parameter Indicators:

TP-Destination Address: Parameter absent
TS-Service Centre Address: Parameter present
TP-Protocol Identifier: Parameter absent
TP-Data Coding Scheme: Parameter absent
TP-Validity Period: Parameter absent

TS-Service Centre Address:

TON: International Number

NPI: "ISDN / telephone numbering plan"

Dialled number string: "112233445566778"

Coding:	B1	B2	В3	 B13	B14	B15	B16	B17	B18	B19	B20	B21	B22	B23
Record 1:	FD	FF	FF	 FF	09	91	11	22	33	44	55	66	77	F8

B24	B25	B26	B27	B28
FF	FF	FF	FF	FF

#### For the display of icon:

- Under the DF Telecom: creation of DF Graphics (5F50);
- Under the DF 5F50: creation of EF<sub>Img</sub> (4F20, linear fixed file) and EF<sub>Instance</sub> (4FXX, transparent file).

#### EF<sub>Img</sub> (Image, 4F20)

#### Record 1:

#### Logically:

Number of Actual Images Instances: 01 Image Instance Width: 08 Image Instance Height: 08

Image Coding Scheme: 11 (basic image)
Image Instance File Identifier: 4F 04 (EF<sub>Instance</sub>)

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 0A

#### Coding:

BER-TLV:	01	08	08	11	4F	04	00	00	00	0A	FF	FF
	FF											

#### Record 2:

#### Logically:

Number of Actual Images Instances: 01 Image Instance Width: 08 Image Instance Height: 08

 $\begin{array}{ll} \text{Image Coding Scheme:} & 21 \text{ (colour image)} \\ \text{Image Instance File Identifier:} & 4F 02 \text{(EF}_{\text{Instance}}) \\ \end{array}$ 

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 1F

#### Coding:

BER-TLV:	01	2E	28	21	4F	02	00	00	00	1F	FF	FF
	FF											

#### Record 3:

#### Logically:

Number of Actual Images Instances: 01 Image Instance Width: 18 Image Instance Height: 10

Image Coding Scheme:11 (basic image)Image Instance File Identifier:4F 03 (EFInstance)

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 32

#### Coding:

BER-TLV:	01	18	10	11	4F	03	00	00	00	32	FF	FF
	FF											

#### Record 4:

#### Logically:

Number of Actual Images Instances: 01 Image Instance Width: 2E Image Instance Height: 28

Image Coding Scheme: 11 (basic image)
Image Instance File Identifier: 4F 01 (EF<sub>Instance</sub>)

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 E8

#### Coding:

BER-TLV:	01	2E	28	11	4F	01	00	00	00	E8	FF	FF
	FF											

#### Record 5:

#### Logically:

Number of Actual Images Instances: 01 Image Instance Width: 05 Image Instance Height: 05

Image Coding Scheme: 11 (basic image)
Image Instance File Identifier: 4F 05 (EF<sub>Instance</sub>)

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 08

#### Coding:

BER-TLV:	01	05	05	11	4F	05	00	00	00	08	FF	FF
·	FF	FF	FF	FF	FF	FF						

#### EF<sub>Instance</sub> (4F01)

#### Logically:

Image Instance Data: see below

#### Coding:

BER-TLV:	2E	28	00	00	00	00	00	00	00	01	FF	80
	00	00	00	0F	FF	00	00	00	00	77	FE	00
	00	00	01	BF	F8	00	00	00	06	FF	E0	00
	00	00	1A	03	80	00	00	00	6B	F6	ВС	00
	00	01	AF	D8	38	00	00	06	BF	60	20	00
	00	1A	FD	80	40	00	00	6B	F6	00	80	00
	01	A0	1F	02	00	00	06	FF	E4	04	00	00
	1B	FF	90	10	00	00	6D	EE	40	40	00	01
	BF	F9	01	00	00	6F	FF	E4	04	00	00	1B
	FF	90	10	00	00	6F	FE	40	40	00	01	BF
	F9	01	00	00	06	F	E6	04	00	00	1B	FF
	88	10	00	00	6F	FE	20	40	00	01	BF	F8
	66	00	00	06	FF	E0	F0	00	00	1B	FF	80
	80	00	00	7F	FE	00	00	00	03	00	0C	00
	00	00	1F	FF	F8	00	00	00	00	00	00	00
	00	00	00	00	00	00	00	00	00	00	00	00
	1C	21	80	44	EE	00	48	C4	31	92	20	01
	25	11	45	50	80	07	14	45	15	43	80	12
	71	1C	4D	80	00	4A	24	89	32	20	01	C8
	9E	24	4E	E0								

## EF<sub>Instance</sub> (4F02)

Logically:

Image Instance Data:

Image width:08Image length:08Bits per raster image point:02Number of CLUT entries:03Location of CLUT:00 16Image body:see below

Coding:

BER-TLV:	80	80	02	03	00	16	AA	AA	80	02	85	42
	81	42	81	42	81	52	80	02	AA	AA	FF	00
	00	00	FF	00	00	00	FF					

## EF<sub>Instance</sub> (4F03)

Logically:

Image Instance Data: see below

Coding:

BER-TLV:	18	10	FF	FF	FF	80	00	01	80	00	01	80
	00	01	8F	3C	F1	89	20	81	89	20	81	89
	20	F1	89	20	11	89	20	11	89	20	11	8F
	3C	F1	80	00	01	80	00	01	80	00	01	FF
	FF	FF										

## EF<sub>Instance</sub> (4F04)

Logically:

Image Instance Data: see below

### BER-TLV: 08 08 FF 03 A5 99 99 A5 C3 FF

## EF<sub>Instance</sub> (4F05)

Logically:

Image Instance Data: see below

Coding:

BER-TLV:	05	05	FE	EB	BF	FF	FF	FF

# 27.22.1 Initialization of SIM Application Toolkit Enabled SIM by SIM Application Toolkit Enabled ME (Profile Download)

## 27.22.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.1.2 Conformance requirement

The ME shall support the PROFILE DOWNLOAD command as defined in:

• 3GPP TS 11.14 [15] clause 5.2.

## 27.22.1.3 Test purpose

To verify that the ME sends a TERMINAL PROFILE command in accordance with the above requirements.

#### 27.22.1.4 Method of test

### 27.22.1.4.1 Initial conditions

The ME is connected to the SIM Simulator. All elementary files are coded as the default Toolkit personalization, with the CHV1 enabled.

#### 27.22.1.4.2 Procedure

## **Expected Sequence 1 (PROFILE DOWNLOAD)**

Step	Direction	Message / Action	Comments
1	$USER \to ME$	Power on ME	
		DIN.	
2	ME → USER	PIN entry request	
3	$USER \to ME$	Enter "1111"	
4	MF  o SIM	VERIFY CHV1 1.1A	[CHV1 code: "1111"]
5	SIM → ME	VERIFY CHV ATTEMPT	[Crivi code. 1111]
3	SIIVI → IVIE	UNSUCCESSFUL 1.1A	
		UNSUCCESSFUL 1.1A	
6	ME → USER	PIN entry request	
7	USER → ME	Enter "1234"	
	OOLIK / MIL		
8	$ME \to SIM$	VERIFY CHV1 1.1B	[CHV1 code: "1234"]
9	$SIM \to ME$	NORMAL ENDING OF	
		COMMAND 1.1A	
10	$ME \rightarrow SIM$	SELECT EF PHASE 1.2	
11	$ME \rightarrow SIM$	READ BINARY (EF PHASE) 1.3	Expected PHASE = 03 returned by SIM
12	$ME \rightarrow SIM$	TERMINAL PROFILE 1.4	PROFILE DOWNLOAD
13	$SIM \rightarrow ME$	NORMAL ENDING OF	
		COMMAND 1.1A	
<b> </b>			
14	$ME \rightarrow SIM$	SELECT EF IMSI 1.5	
		or	
		SELECT EF LOCI 1.6	

**VERIFY CHV1: 1.1A** 

Logically:

Coding:

APD	U:	CLA=A0	INS=2	20 P1:	=00 F	2=01	P3=08	
DATA IN:	31	31	31	31	FF	FF	FF	FF

## **VERIFY CHV1 ATTEMPT UNSUCCESSFUL: 1.1A**

Logically:

Coding:

SW1=98 SW2=04

**VERIFY CHV1: 1.1B** 

Logically:

APD	U:	CLA=A0	INS=2	20 P1=	=00 F	P2=01	P3=08	
DATA IN:	31	32	33	34	FF	FF	FF	FF

1	<b>NC</b>	١R	M	Δ	ı	FI	MГ	'n	N	G	C	۱	F	C	0	N	ΠN	И	Δ	N	IΓ	١-	1	1	L	Δ
	v	ıη	· IV	_	_	_	N.	"	14	u	•	,		u	u	w	ш	٧ı	_	u v		,.			.,	٦.

Logically:

Coding:

SW1=90 SW2=00

**SELECT EF PHASE: 1.2** 

Logically:

Coding:

CLA=A0   INS=A4   P1=00   P2=00   P3=02	J: CLA=A0

DATA IN: 6F AE

Response:

SW1=9F SW2=0F

**READ BINARY (EF PHASE): 1.3** 

Logically:

Coding:

APDU: CLA=A0	INS=B0	P1=00	P2=00	P3=01	ĺ
--------------	--------	-------	-------	-------	---

Response:

DATA OUT: 03

SW1=90 SW2=00

**TERMINAL PROFILE: 1.4** 

Logically:

Coding:

APDU:	CLA=A0	INS=10	P1=00	P2=01	P3=XX
	•	•	•	•	•
	DATA IN:	YY	77		

With XX representing the length of the following DATA IN depending on the SIM Toolkit commands supported by the ME, and with YY, ZZ, ... representing here the bytes of the TERMINAL PROFILE data, as specified in 3GPP TS 11.14 [15], clause 5.2.

**SELECT EF IMSI: 1.5** 

Logically:

APDU:	CLA=A0	INS=A4	P1=	=00	P2=00	P3=02
	DATA IN	l: (	3F	07		

#### **SELECT EF LOCI: 1.6**

Logically:

Coding:

APDU:	CLA=A0	INS:	=A4	P1=00		P2=00	P3=02
	DATA II	DATA IN:			7E		

## 27.22.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.

### 27.22.2 Contents of the TERMINAL PROFILE command

## 27.22.2.1 Definition and applicability

See table E.1.

## 27.22.2.2 Conformance requirement

The ME shall support the PROFILE DOWNLOAD command as defined in:

• 3GPP TS 11.14 [15] clause 5.2.

## 27.22.2.3 Test purpose

- 1. Verify that the TERMINAL PROFILE indicates that Profile Download facility is supported.
- 2. Record which SIM Application Toolkit facilities are supported by the ME, to determine which subsequent tests are required.

#### 27.22.2.4 Method of test

#### 27.22.2.4.1 Initial conditions

The ME is connected to the SIM Simulator. All elementary files are coded as the default SIM Application Toolkit personalization.

#### 27.22.1.4.2 Procedure

- a) The ME is powered on.
- b) After the ME sends the TERMINAL PROFILE command to the SIM Simulator, the SIM Simulator shall record the content of the TERMINAL PROFILE.
- c) The SIM Simulator shall return SW1 / SW2 of '90 00'.
- d) The contents of the TERMINAL PROFILE is recorded and compared to the corresponding table E.1 "status" column.

The test is terminated upon the ME sending the TERMINAL PROFILE command to the SIM Simulator.

## 27.22.2.5 Test requirement

1) After step a) the ME shall send the TERMINAL PROFILE command to the SIM Simulator with bit 1 of the first byte set to 1 (facility supported by ME).

2) In table E.1 for the corresponding ME Sim Toolkit Release and Options, The TERMINAL PROFILE information "support" recorded must be in accordance with the "Status" column.

## 27.22.3 Servicing of proactive SIM commands

## 27.22.3.1 Definition and applicability

See clause 3.2.2.

## 27.22.3.2 Conformance requirement

On detection of a pending SIM Application Toolkit command from the SIM the ME shall perform the FETCH command to retrieve the proactive SIM command. The result of the executed command shall be transmitted from the ME to the SIM within a TERMINAL RESPONSE command.

The MORE TIME proactive command is used in this test. The ME shall have knowledge of this command, but may not support this SIM Application Toolkit facility.

• 3GPP TS 11.14 [15] clause 6.3.

### 27.22.3.3 Test purpose

To verify that the ME uses the FETCH command to obtain the proactive SIM command, after detection of a pending proactive SIM command. The pending proactive SIM command is indicated by the response parameters '91 xx' from the SIM.

To verify that the ME transmits the result of execution of the proactive SIM command to the SIM in the TERMINAL RESPONSE command.

#### 27.22.3.4 Method of test

#### 27.22.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as the SIM Application Toolkit default.

The SIM Simulator is configured to indicate that a proactive SIM command is pending.

The SIM Simulator is configured to monitor the SIM - ME interface.

#### 27.22.3.4.2 Procedure

- a) The ME is powered on.
- b) After the ME has performed the PROFILE DOWNLOAD procedure, the SIM Simulator indicates that a Proactive SIM Command is pending with SW1 / SW2 of '91 0B'.
- c) After the ME sends the FETCH command to the SIM Simulator, the SIM Simulator returns Proactive SIM Command 2.1: MORE TIME.

#### 27.22.3.5 Test requirement

- 1) After step b) the ME shall send the FETCH command to the SIM.
- 2) After step c) the ME shall send the TERMINAL REPONSE command with command number "01", type of command "02" and command qualifier "00".

#### 27.22.4 Proactive SIM commands

#### 27.22.4.1 DISPLAY TEXT

#### 27.22.4.1.1 DISPLAY TEXT (Normal)

#### 27.22.4.1.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.1.1.2 Conformance requirements

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15], clause 5.2, clause 6.4.1, clause 6.5.4, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

#### 27.22.4.1.1.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.1.1.4 Method of test

#### 27.22.4.1.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.1.1.4.2 Procedure

## Expected Sequence 1.1 (DISPLAY TEXT normal priority, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
		DISPLAY TEXT 1.1.1	message, unpacked, 8 bit data]
4	$ME \to USER$	Display "Toolkit Test 1"	
5	$USER \to ME$	Clear Message	
6	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 1.1.1	
7	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

#### PROACTIVE COMMAND: DISPLAY TEXT 1.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Coding:

BER-TLV:	D0	1A	81	03	01	21	80	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	31								

TERMINAL RESPONSE: DISPLAY TEXT 1.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 0
---

## Expected Sequence 1.2 (DISPLAY TEXT normal priority, Unpacked 8 bit data for Text String, screen busy)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to ME$	Set the ME screen to a display	The ME will be set to a mode so that normal
		mode other than the normal	priority text commands shall be rejected.
		stand-by display	
2	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.2.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority]
		DISPLAY TEXT 1.2.1	
5	$ME \rightarrow USER$	No change of the currently being	
		used display.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[ME currently unable to process command -
		DISPLAY TEXT 1.2.1	screen busy]
7	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 1.2.1: same as 1.1.1

TERMINAL RESPONSE: DISPLAY TEXT 1.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional information: Screen is busy

Coding:

BER-TLV:	81	03	01	21	80	82	02	82	81	83	02	20
	01											

## Expected Sequence 1.3 (DISPLAY TEXT, high priority, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	The ME screen is in a mode other than the
		PENDING: DISPLAY TEXT 1.3.1	normal stand by display.
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[High priority]
		DISPLAY TEXT 1.3.1	
4	$ME \to USER$	Display "Toolkit Test 2"	
5	$USER \to ME$	Clear Message	
6	$ME \to SIM$	TERMINAL RESPONSE:	
		DISPLAY TEXT 1.3.1	
7	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
8	$USER \to ME$	Set the ME screen back to normal	
		stand-by display	

#### PROACTIVE COMMAND: DISPLAY TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: high priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 2"

Coding:

BER-TLV:	D0	1A	81	03	01	21	81	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	32								

#### TERMINAL RESPONSE: DISPLAY TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: high priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TL\	/: 81	03	01	21	81	82	02	82	81	83	01	00	l
---------	-------	----	----	----	----	----	----	----	----	----	----	----	---

## Expected Sequence 1.4 (DISPLAY TEXT, Packed, SMS default alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Packed, SMS default alphabet]
		DISPLAY TEXT 1.4.1	
4	$ME \to USER$	Display "Toolkit Test 3"	
5	$USER \to ME$	Clear Message	
6	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 1.4.1	

PROACTIVE COMMAND: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM Destination device: Display

Text string

packed, SMS default alphabet "Toolkit Test 3" Data coding scheme:

Text:

Coding:

BER-TLV:	D0	19	81	03	01	21	80	82	02	81	02	8D
	0E	00	D4	F7	9B	BD	4E	D3	41	D4	F2	9C
	0E	9A	01									

TERMINAL RESPONSE: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number:

**DISPLAY TEXT** Command type:

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

#### Expected Sequence 1.5 (DISPLAY TEXT, Clear message after delay, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Clear message after a delay]
		DISPLAY TEXT 1.5.1	
4	ME  o	Display "Toolkit Test 4" and clear	
		this message after a short delay	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 1.5.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
1		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 1.5.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data Text: "Toolkit Test 4"

Coding:

BER-TLV:	D0	1A	81	03	01	21	00	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	34								

TERMINAL RESPONSE: DISPLAY TEXT 1.5.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	01	21	00	82	02	82	81	83	01	00	l
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

#### Expected Sequence 1.6 (DISPLAY TEXT, Text string with 160 bytes, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Text string with 160 bytes - maximum for non
		DISPLAY TEXT 1.6.1	extension text]
4	$ME \rightarrow USER$	Display " This command instructs	
		the ME to display a text message.	
		It allows the SIM to define the	
		priority of that message, and the	
		text string format. Two types of	
		prio"	
5	$USER \to ME$	Clear Message	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	Command performed successfully
		DISPLAY TEXT 1.6.1	

PROACTIVE COMMAND: DISPLAY TEXT 1.6.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data

Text: "This command instructs the ME to display a text message. It allows the SIM to

define the priority of that message, and the text string format. Two types of prio"

## Coding:

BER-TLV:	D0	81	AD	81	03	01	21	80	82	02	81	02
	8D	81	A1	04	54	68	69	73	20	63	6F	6D
	6D	61	6E	64	20	69	6E	73	74	72	75	63
	74	73	20	74	68	65	20	4D	45	20	74	6F
	20	64	69	73	70	6C	61	79	20	61	20	74
	65	78	74	20	6D	65	73	73	61	67	65	2E
	20	49	74	20	61	6C	6C	6F	77	73	20	74
	68	65	20	53	49	4D	20	74	6F	20	64	65
	66	69	6E	65	20	74	68	65	20	70	72	69
	6F	72	69	74	79	20	6F	66	20	74	68	61
	74	20	6D	65	73	73	61	67	65	2C	20	61
	6E	64	20	74	68	65	20	74	65	78	74	20
	73	74	72	69	6E	67	20	66	6F	72	6D	61
	74	2E	20	54	77	6F	20	74	79	70	65	73
	20	6F	66	20	70	72	69	6F				

TERMINAL RESPONSE: DISPLAY TEXT 1.6.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01	21	80 82	02	82 81	83	01	00
-------------------	----	-------	----	-------	----	----	----

## Expected Sequence 1.7 (DISPLAY TEXT, Backward move in SIM session, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		DISPLAY TEXT 1.7.1	
4	$ME \rightarrow USER$	Display " <go-backwards"< td=""><td></td></go-backwards"<>	
5	$USER \to ME$	Indicate the need to go backwards	
		in the proactive SIM application	
		session	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Backward move in the proactive SIM session
		DISPLAY TEXT 1.7.1	requested by the user]

PROACTIVE COMMAND: DISPLAY TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

Coding:

BER-TLV:	D0	1A	81	03	01	21	80	82	02	81	02	8D
	0F	04	3C	47	4F	2D	42	41	43	4B	57	41
	52	44	53	3E								

**TERMINAL RESPONSE: DISPLAY TEXT 1.7.1** 

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Backward move in the proactive SIM session requested by the user

BER-TLV:	01	03	01	21	80	92	02	92	01	02	Λ1	11
DEK-ILV.	01	03	UI	Z	00	02	02	02	01	೦೦	UI	11

#### Expected Sequence 1.8 (DISPLAY TEXT, session terminated by user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		DISPLAY TEXT 1.8.1	
4	$ME \rightarrow USER$	Display " <abort>"</abort>	
5	$USER \to ME$	Indicate the need to end the	
		proactive SIM application session	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Proactive SIM session terminated by the
		DISPLAY TEXT 1.8.1	user]
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data Text: "<ABORT>"

Coding:

BER-TLV:	D0	13	81	03	01	21	80	82	02	81	02	8D
	08	04	3C	41	42	4F	52	54	3E			

TERMINAL RESPONSE: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

										~~		
	101	<b>Λ</b> 2	I 01	21	1 0/1	റ	$\alpha$	റ	101	1 02	I 01	1 10
DEK-IIV					וחט			0/				

## Expected Sequence 1.9 (DISPLAY TEXT, icon and text to be displayed, no text string given, not understood by ME)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
_		PENDING: DISPLAY TEXT 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	Including icon identifier, icon shall be
			displayed together with the alpha text string, but no text string given
4	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command data not understood by ME
		DISPLAY TEXT 1.9.1	(clause 6.5.4)]
5	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	, , , ,
		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 1.9.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Contents: null data object

Icon Identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon Identifier:} & \mbox{record 1 in } \mbox{EF}_{(IMG)} \\ \end{array}$ 

Coding:

BER-TLV:	D0	0F	81	03	01	21	80	82	02	81	02	8D
	00	9E	02	00	01							

TERMINAL RESPONSE: DISPLAY TEXT 1.9.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV:	81	03	01	21	80	82	02	82	81	83	01	32

27.22.4.1.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.9.

#### 27.22.4.1.2 DISPLAY TEXT (Support of "No response from user")

#### 27.22.4.1.2.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.1.2.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

#### 27.22.4.1.2.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.1.2.4 Method of test

#### 27.22.4.1.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

#### 27.22.4.1.2.4.1 Procedure

## Expected Sequence 2.1 (DISPLAY TEXT, no response from user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
		DISPLAY TEXT 2.1.1	message, unpacked, 8 bit data]
4	$ME \rightarrow USER$	Display " <time-out>"</time-out>	
6	$ME \to SIM$	TERMINAL RESPONSE:	[No response from user] within 5 s after the
		DISPLAY TEXT 2.1.1	end of that defined period of time
7	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

## PROACTIVE COMMAND: DISPLAY TEXT 2.1.1

#### Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data Text: "<TIME-OUT>"

Coding:

BER-TLV:	D0	16	81	03	01	21	80	82	02	81	02	8D
	0B	04	3C	54	49	4D	45	2D	4F	55	54	3E

#### TERMINAL RESPONSE: DISPLAY TEXT 2.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: No response from user

Coding:

BER-TLV:	81	03	01	21	80	82	02	82	81	83	01	12

#### 27.22.4.1.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

## 27.22.4.1.3 DISPLAY TEXT (Display of extension text)

#### 27.22.4.1.3.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.1.3.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

#### 27.22.4.1.3.3 Test purpose

To verify that the ME displays the extension text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.1.3.4 Method of test

#### 27.22.4.1.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.1.3.4.2 Procedure

## **Expected Sequence 3.1 (DISPLAY TEXT, display of the extension text)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Text string with the maximum of 240 bytes]
		DISPLAY TEXT 3.1.1	
4	$ME \rightarrow USER$	Display "This command instructs	
		the ME to display a text message,	
		and/or an icon (see clause 6.5.4).	
		It allows the SIM to define the	
		priority of that message, and the	
		text string format. Two types of	
		priority are defined:- display	
		normal priority text and/"	
5		Clear Message	
6	$ME \rightarrow SIM$		[Command performed successfully]
		DISPLAY TEXT 3.1.1	
7	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

#### PROACTIVE COMMAND: DISPLAY TEXT 3.1.1

### Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data

Text: "This command instructs the ME to display a text message and/or an icon (see

clause 6.5.4). It allows the SIM to define the priority of that message, and the text string format. Two types of priority are defined:- display normal priority text and/"

BER-TLV:	D0	81	FD	81	03	01	21	80	82	02	81	02
	8D	81	F1	04	54	68	69	73	20	63	6F	6D
	6D	61	6E	64	20	69	6E	73	74	72	75	63
	74	73	20	74	68	65	20	4D	45	20	74	6F
	20	64	69	73	70	6C	61	79	20	61	20	74
	65	78	74	20	6D	65	73	73	61	67	65	2C
	20	61	6E	64	2F	6F	72	20	61	6E	20	69
	63	6F	6E	20	28	73	65	65	20	36	2E	35
	2E	34	29	2E	20	49	74	20	61	6C	6C	6F
	77	73	20	74	68	65	20	53	49	4D	20	74
	6F	20	64	65	66	69	6E	65	20	74	68	65
	20	70	72	69	6f	72	69	74	79	20	6F	66
	20	74	68	61	74	20	6D	65	73	73	61	67
	65	2C	20	61	6E	64	20	74	68	65	20	74
	65	78	74	20	73	74	72	69	6E	67	20	66
	6F	72	6D	61	74	2E	20	54	77	6F	20	74
	79	70	65	73	20	6F	66	20	70	72	69	6F
	72	69	74	79	20	61	72	65	20	64	65	66
	69	6E	65	64	3A	2D	20	64	69	73	70	6C
	61	79	20	6E	6F	72	6D	61	6C	20	70	72
	69	6F	72	69	74	79	20	74	65	78	74	20

61	6F	64	2F				l
<u> </u>	~-	<b>.</b>					

TERMINAL RESPONSE: DISPLAY TEXT 3.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	21	80	82	02	82	81	83	01	00
	01	00	01	'	00	02	02	02	01	00	01	00

#### 27.22.4.1.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

#### 27.22.4.1.4 DISPLAY TEXT (Sustained text)

#### 27.22.4.1.4.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.1.4.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.43.

### 27.22.4.1.4.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, returns a successful result in the TERMINAL RESPONSE command send to the SIM and sustain the display beyond sending the TERMINAL response.

27.22.4.1.4.4 Method of test

27.22.4.1.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.1.4.4.2 Procedure

## Expected Sequence 4.1 (DISPLAY TEXT, sustained text, unpacked data 8 bits, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
		DISPLAY TEXT 4.1.1	message, unpacked, 8 bit data]
4	$ME \rightarrow USER$	Display "Toolkit Test 1"	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 4.1.1	
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
8	$ME \rightarrow USER$	Display of "Toolkit Test 1" shall	Text shall sustain until - a subsequent
		sustain	proactive command is received containing
			display data.

## PROACTIVE COMMAND: DISPLAY TEXT 4.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data Text: "Toolkit Test 1"

Immediate Response

## Coding:

BER-TLV:	D0	1C	81	03	01	21	80	82	02	81	02	8D
'	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	31	AB	00						

### TERMINAL RESPONSE: DISPLAY TEXT 4.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

						00		00				
BER-TLV:	1 01	1 02	1 01	1 71	1 00	ເວລ	$ \sim$ $\sim$	ເວລ	101	02	1 01	- $        -$
IDEK-ILV.	1 0 1	I U.S			เดย	0/	1 0/	1 0/		1 0.0		1 ()()

#### Expected Sequence 4.2 (DISPLAY TEXT, sustained text, clear message after delay, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Clear message after a delay]
		DISPLAY TEXT 4.2.1	
4	$ME \rightarrow USER$	Display "Toolkit Test 2"	
5	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 4.2.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$ME \rightarrow USER$	Display "Toolkit Test 2"	Text shall sustain until - the expiration of a
1			short delay.

PROACTIVE COMMAND: DISPLAY TEXT 4.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 2"

Immediate Response

Coding:

BER-TLV:	D0	1C	81	03	01	21	00	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	32	AB	00						

TERMINAL RESPONSE: DISPLAY TEXT 4.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	01	03	Ω1	21	00	92	02	92	01	02	Ω1	00
DEK-ILV.	01	03	UI	_ Z I	UU	02	02	02	01	೦೦	UI	UU

#### Expected Sequence 4.3 (DISPLAY TEXT, sustained text, wait for user MMI to clear, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[wait for user to clear message]
		DISPLAY TEXT 4.3.1	
4	$ME \to USER$	Display "Toolkit Test 3"	
5	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 4.3.1	
6	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$ME \rightarrow USER$	Display of "Toolkit Test 3"	Text shall sustain until - a user MMI action.
8	$USER \to ME$	Clear message	

PROACTIVE COMMAND: DISPLAY TEXT 4.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 3"

Immediate Response

Coding:

BER-TLV:	D0	1C	81	03	01	21	80	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	33	AB	00						

TERMINAL RESPONSE: DISPLAY TEXT 4.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TI V	Ω1	Λ3	Ω1	21	80	82	02	82	Ω1	83	Λ1	00

## Expected Sequence 4.4 (DISPLAY TEXT, sustained text, wait for high priority event to clear, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[wait for user to clear message]
		DISPLAY TEXT 4.4.1	
4	$ME \rightarrow USER$	Display "Toolkit Test 4"	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 4.4.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$ME \rightarrow USER$	Display of "Toolkit Test 4"	Text shall sustain until - a higher priority event
			occurs.
8	$SS \to ME$	INCOMING MOBILE	
		TERMINATED CALL	

PROACTIVE COMMAND: DISPLAY TEXT 4.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 4"

Immediate Response

Coding:

BER-TLV:	D0	1C	81	03	01	21	80	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	34	AB	00						

TERMINAL RESPONSE: DISPLAY TEXT 4.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-T	.V:	81	03	01	21	80	82	02	82	81	83	01	00	
-------	-----	----	----	----	----	----	----	----	----	----	----	----	----	--

#### 27.22.4.1.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1 to 4.4.

## 27.22.4.1.5 DISPLAY TEXT (Display of icons)

#### 27.22.4.1.5.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.1.5.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.5.4, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

#### 27.22.4.1.5.3 Test purpose

To verify that the ME displays the icons which are referred to in the contents of the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.1.5.4 Method of test

#### 27.22.4.1.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.1.5.4.2 Procedure

#### Expected Sequence 5.1A (DISPLAY TEXT, display of basic icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[BASIC-ICON, self-explanatory]
		DISPLAY TEXT 5.1.1	
4	$ME \rightarrow USER$	Display the BASIC-ICON	
5	$USER \to ME$	Clear Message	
6	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 5.1.1A	

#### PROACTIVE COMMAND: DISPLAY TEXT 5.1.1

## Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Basic Icon"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	1A	81	03	01	21	80	82	02	81	02	8D
_	0B	04	42	61	73	69	63	20	49	63	6F	6E
	9E	02	00	01								

TERMINAL RESPONSE: DISPLAY TEXT 5.1.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

## Expected Sequence 5.1B (DISPLAY TEXT, display of basic icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[BASIC-ICON, self-explanatory]
		DISPLAY TEXT 5.1.1	
4	$ME \rightarrow USER$	Display "Basic Icon" without icon	
5	$USER \to ME$	Clear Message	
6	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully, but
		DISPLAY TEXT 5.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: DISPLAY TEXT 5.1.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 04

#### Expected Sequence 5.2A (DISPLAY TEXT, display of colour icon, successful)

Step	Direction	MESSAGE / Action	Comments
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND:	[COLOUR-ICON]
		DISPLAY TEXT 5.2.1	
10	$ME \rightarrow USER$	Display the COLOUR-ICON	
11	$USER \to ME$	Clear Message	
12	$ME \to SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 5.2.1A	

PROACTIVE COMMAND: DISPLAY TEXT 5.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Colour Icon"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 2 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	1B	81	03	01	21	80	82	02	81	02	8D
	0C	04	43	6F	6C	6F	75	72	20	49	63	6F
	6E	9E	02	00	02							

TERMINAL RESPONSE: DISPLAY TEXT 5.2.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

## Expected Sequence 5.2B (DISPLAY TEXT, display of colour icon, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND:	[COLOUR-ICON]
		DISPLAY TEXT 5.2.1	
10	$ME \rightarrow USER$	Display "Colour Icon" without the	
		icon	
11	$USER \to ME$	Clear Message	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully, but
		DISPLAY TEXT 5.2.1B	requested icon could not be displayed]

TERMINAL RESPONSE: DISPLAY TEXT 5.2.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

BER-TLV:	81	03	01	21	80	82	02	82	81	83	01	04	
----------	----	----	----	----	----	----	----	----	----	----	----	----	--

## Expected Sequence 5.3A (DISPLAY TEXT, display of basic icon, not self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.3.1	
14	$ME \rightarrow SIM$	FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[BASIC-ICON, not self-explanatory]
		DISPLAY TEXT 5.3.1	
16	$ME \rightarrow USER$	Display the BASIC-ICON	
		And	
		Display "Basic Icon"	
17	$USER \to ME$	Clear Message	
18	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		DISPLAY TEXT 5.3.1A	
19	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 5.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Basic Icon"

Icon Identifier:

Icon qualifier: icon is not self-explanatory

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	1A	81	03	01	21	80	82	02	81	02	8D
	0B	04	42	61	73	69	63	20	49	63	6F	6E
	9E	02	01	01								

TERMINAL RESPONSE: DISPLAY TEXT 5.3.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

	BEK-ILV:	81	03	01	21	80	82	02	82	81	83	01	00
--	----------	----	----	----	----	----	----	----	----	----	----	----	----

## Expected Sequence 5.3B (DISPLAY TEXT, display of basic icon, not self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.3.1	
14	$ME \rightarrow SIM$	FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[BASIC-ICON, not self-explanatory]
		DISPLAY TEXT 5.3.1	
16	$ME \rightarrow USER$	Display "Basic Icon" without the	
		icon	
17	$USER \to ME$	Clear Message	
18	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully, but
		DISPLAY TEXT 5.3.1B	requested icon could not be displayed]
19	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

TERMINAL RESPONSE: DISPLAY TEXT 5.3.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

	BER-TLV:	81	03	01	21	80	82	02	82	81	83	01	04
--	----------	----	----	----	----	----	----	----	----	----	----	----	----

#### 27.22.4.1.5.5 Test requirement

The ME shall operate in the manner defined in expected sequences 5.1A to 5.3B.

#### 27.22.4.1.6 DISPLAY TEXT (UCS2 display supported)

#### 27.22.4.1.6.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.1.6.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.1, clause 6.5.4, clause 6.6.1, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

The ME shall support the UCS2 alphabet for the coding of the Cyrillic alphabet, as defined in the following technical specification: ISO/IEC 10646 [17].

### 27.22.4.1.6.3 Test purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.6.4 Method of test

27.22.4.1.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.1.6.4.2 Procedure

#### **Expected Sequence 6.1 (DISPLAY TEXT, UCS2 coded)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
		DISPLAY TEXT 6.1.1	message, UCS2 coded]
4	$ME \to USER$		["Hello" in Russian]
		Display " ЗДРАВСТВУЙТЕ "	
5	$USER \to ME$	Clear message	
6	$ME \to SIM$	TERMINAL RESPONSE:	
		DISPLAY TEXT 6.1.1	

#### PROACTIVE COMMAND: DISPLAY TEXT 6.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV:	D0	24	81	03	01	21	80	82	02	81	02	8D
-	19	08	04	17	04	14	04	20	04	10	04	12
	04	21	04	22	04	12	04	23	04	19	04	22
	04	15										

#### TERMINAL RESPONSE: DISPLAY TEXT 6.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-T	LV:	81	03	01	21	80	82	02	82	81	83	01	00
-------	-----	----	----	----	----	----	----	----	----	----	----	----	----

### 27.22.4.1.6.5 Test requirement

The ME shall operate in the manner defined in expected sequence 6.1.

#### 27.22.4.2 GET INKEY

#### 27.22.4.2.1 GET INKEY(normal)

#### 27.22.4.2.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.2.1.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

#### 27.22.4.2.1.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the single character entered in the TERMINAL RESPONSE command sent to the SIM.

#### 27.22.4.2.1.4 Method of test

#### 27.22.4.2.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be set to a display other than the idle display.

#### 27.22.4.2.1.4.2 Procedure

## Expected Sequence 1.1 (GET INKEY, digits only for character, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[digits only, no help info available]
		INKEY 1.1.1	
4	$ME \rightarrow USER$	Display "Enter "+""	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INKEY 1.1.1	

#### PROACTIVE COMMAND: GET INKEY 1.1.1

#### Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data Text: "Enter "+" "

Coding:

BER-TLV:	D0	15	81	03	01	22	00	82	02	81	82	8D
	0A	04	45	6E	74	65	72	20	22	2B	22	

#### **TERMINAL RESPONSE: GET INKEY 1.1.1**

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

	BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
-		8D	02	04	2B								

## Expected Sequence 1.2 (GET INKEY, digits only for character set, SMS default Alphabet for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, no help info available]
		INKEY 1.2.1	
4	$ME \rightarrow USER$	Display "Enter "0""	
			Text string coding in packed format
5	$USER \to ME$	Enter the input "0" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[command performed successfully]
		GET INKEY 1.2.1	

#### PROACTIVE COMMAND: GET INKEY 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: SMS default alphabet

Text: "Enter "0""

#### Coding:

BER-TLV:	D0	14	81	03	01	22	00	82	02	81	82	8D
	09	00	45	37	BD	2C	07	89	60	22		

TERMINAL RESPONSE: GET INKEY 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "0"

Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
_	8D	02	04	30								

### **Expected Sequence 1.3 (GET INKEY, backward move)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, no help information available]
		INKEY 1.3.1	
4	$ME \rightarrow USER$	Display " <go-backwards>"</go-backwards>	
			Text string coding in unpacked format
5	$USER \to ME$	Backwards move MMI action	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[backward move in the proactive SIM session
		INKEY 1.3.1	requested by the user]

#### PROACTIVE COMMAND: GET INKEY 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

BER-TLV:	D0	1A	81	03	01	22	00	82	02	81	82	8D
_	0F	04	3C	47	4F	2D	42	41	43	4B	57	41
	52	44	53	3E								

TERMINAL RESPONSE: GET INKEY 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

	BE	R-TLV:	81	03	01	22	00	82	02	82	81	83	01	11
--	----	--------	----	----	----	----	----	----	----	----	----	----	----	----

#### **Expected Sequence 1.4 (GET INKEY, abort)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, no help information available]
		INKEY 1.4.1	
4	$ME \rightarrow USER$	Display " <abort>"</abort>	Text string coding in unpacked format
5	$USER \to ME$	Terminate the Proactive SIM	
		session MMI action	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Proactive SIM session terminated by the
		INKEY 1.4.1	user]

#### PROACTIVE COMMAND: GET INKEY 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<ABORT>"

Coding:

BER-TLV:	D0	13	81	03	01	22	00	82	02	81	82	8D
	80	04	3C	41	42	4F	52	54	3E			

TERMINAL RESPONSE: GET INKEY 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	10
DLIX-ILV.	01	03	Οī	~~	00	02	02	02	01	03	Οī	10

## Expected Sequence 1.5 (GET INKEY, SMS default alphabet for character set, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[characters from SMS default alphabet, no
		INKEY 1.5.1	help info available]
4	$ME \rightarrow USER$	Display "Enter "q""	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "q" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INKEY 1.5.1	

#### PROACTIVE COMMAND: GET INKEY 1.5.1

#### Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "Enter "q""

Coding:

BER-TLV:	D0	15	81	03	01	22	01	82	02	81	82	8D
	0A	04	45	6E	74	65	72	20	22	71	22	

#### **TERMINAL RESPONSE: GET INKEY 1.5.1**

#### Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "q"

Coding:

BER-TLV:	81	03	01	22	01	82	02	82	81	83	01	00
	8D	02	04	71								

#### Expected Sequence 1.6 (GET INKEY, Max length for the Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, no help info available]
		INKEY 1.6.1	
4	$ME \rightarrow USER$	Display "Enter "x". This	
		command instructs the ME to	160 characters Text string coding in
		display text, and to expect the	unpacked format
		user to enter a single character.	
		Any response entered by the	
		user shall be passed t "	
5	$USER \to ME$	Enter the input "x" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INKEY 1.6.1	

PROACTIVE COMMAND: GET INKEY 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter "x". This command instructs the ME to display text, and to expect the user to

enter a single character. Any response entered by the user shall be passed t"

BER-TLV:	D0	81	AD	81	03	01	22	01	82	02	81	82
	8D	81	A1	04	45	6E	74	65	72	20	22	78
	22	2E	20	54	68	69	73	20	63	6F	6D	6D
	61	6E	64	20	69	6E	73	74	72	75	63	74
	73	20	74	68	65	20	4D	45	20	74	6F	20
	64	69	73	70	6C	61	79	20	74	65	78	74
	2C	20	61	6E	64	20	74	6F	20	65	78	70
	65	63	74	20	74	68	65	20	75	73	65	72
	20	74	6F	20	65	6E	74	65	72	20	61	20
	73	69	6E	67	6C	65	20	63	68	61	72	61
	63	74	65	72	2E	20	41	6E	79	20	72	65
	73	70	6F	6E	73	65	20	65	6E	74	65	72
	65	64	20	62	79	20	74	68	65	20	75	73
	65	72	20	73	68	61	6C	6C	20	62	65	20
	70	61	73	73	65	64	20	74				

TERMINAL RESPONSE: GET INKEY 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "x"

Coding:

BER-TLV:	81	03	01	22	01	82	02	82	81	83	01	00
	8D	02	04	78								

## 27.22.4.2.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

#### 27.22.4.2.2 GET INKEY (No response from User)

## 27.22.4.2.2.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.2.2.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

# 27.22.4.2.2.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

## 27.22.4.2.2.4 Method of test

#### 27.22.4.2.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

## 27.22.4.2.2.4.2 Procedure

# **Expected Sequence 2.1 (GET INKEY, no response from the user)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, no help information available]
		INKEY 2.1.1	
4	$ME \rightarrow USER$	Display " <time-out>"</time-out>	
			Text string coding in unpacked format
5	USER	Waiting and no completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[No response from user] within 5 s after the
		INKEY 2.1.1	end of that defined period of time
7	USER	Check the delay of TERMINAL	
		RESPONSE is reasonable or not	

PROACTIVE COMMAND: GET INKEY 2.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "<TIME-OUT>"

Coding:

BER-TLV:	D0	16	81	03	01	22	00	82	02	81	82	8D
	0B	04	3C	54	49	4D	45	2D	4F	55	54	3E

TERMINAL RESPONSE: GET INKEY 2.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: No response from user

Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	12

27.22.4.2.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

# 27.22.4.2.3 GET INKEY (UCS2 format display)

## 27.22.4.2.3.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.2.3.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

#### 27.22.4.2.3.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

## 27.22.4.2.3.4 Method of test

#### 27.22.4.2.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.2.3.4.2 Procedure

## Expected Sequence 3.1 (GET INKEY, Text String coding in UCS2 Alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[Digits only, no help information available]
		INKEY 3.1.1	
4	$ME \rightarrow USER$	Display " ЗДРАВСТВУЙТЕ "	Text string "Hello" in Russian coding in 16 bits
			UCS2 alphabet format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INKEY 3.1.1	

# PROACTIVE COMMAND: GET INKEY 3.1.1

### Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: 16 bit data UCS2 alphabet format

Техt: "ЗДРАВСТВУЙТЕ "

Coding:

BER-TLV:	D0	24	81	03	01	22	00	82	02	81	82	8D
	19	80	04	17	04	14	04	20	04	10	04	12
	04	21	04	22	04	12	04	23	04	19	04	22
	04	15										

TERMINAL RESPONSE: GET INKEY 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 3.2 (GET INKEY, max length for the Text String coding in UCS2 Alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[digits only, no help information available]
		INKEY 3.2.1	
4	$ME \rightarrow USER$	Display	
		"ЗДРАВСТВУЙТЕЗДРАВСТВУ	Text string length 70 characters, coding in 16
			bits UCS2 alphabet format
		ВУЙТЕЗДРАВСТВУЙТЕЗДРАВ	
		СТВУЙ"	
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INKEY 3.2.1	

PROACTIVE COMMAND: GET INKEY 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM

Destination device: ME

**Text String** 

Data coding scheme:16 bit data UCS2 alphabet formatText:"ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ

ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ"

Coding:

BER-TLV:	D0	81	99	81	03	01	22	00	82	02	81	82
	8D	81	8D	08	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19

TERMINAL RESPONSE: GET INKEY 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
	8D	02	04	2B								

27.22.4.2.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1 to 3.2.

27.22.4.2.4 GET INKEY (UCS2 format of entry)

27.22.4.2.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.4.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

## 27.22.4.2.4.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.4.4 Method of test

27.22.4.2.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.2.4.4.2 Procedure

## Expected Sequence 4.1 (GET INKEY, characters from UCS2 alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[characters from UCS2 alphabet, no help
		INKEY 4.1.1	information available]
4	$ME \rightarrow USER$	Display "Enter"	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "Д"	Russian character, coding in UCS2 format
		and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INKEY 4.1.1	

## PROACTIVE COMMAND: GET INKEY 4.1.1

#### Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: characters from UCS2 alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter"

BER-TLV:	D0	11	81	03	01	22	03	82	02	81	82	8D
	06	04	45	6E	74	65	72					

TERMINAL RESPONSE: GET INKEY 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: characters from UCS2 alphabet, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: 16 bit data UCS2 alphabet format

Text: "Д'

Coding:

BER-TLV:	81	03	01	22	03	82	02	82	81	83	01	00
_	8D	03	08	04	14							

## 27.22.4.2.4.5 Test requirement

The ME shall operate in the manner defined in expected sequence 4.1.

# 27.22.4.2.5 GET INKEY ("Yes/No" Response)

## 27.22.4.2.5.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.2.5.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2 and clause 12.15.3.

# 27.22.4.2.5.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

## 27.22.4.2.5.4 Method of test

#### 27.22.4.2.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.2.5.4.2 Procedure

# Expected Sequence 5.1(GET INKEY, "Yes/No" Response for the input, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: GET INKEY 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INKEY 5.1.1	["Yes/No" Response, no help information available]
4	$ME \rightarrow USER$	Display "Enter"	Text string coding in unpacked format
5	$USER \to ME$	Choice "Yes" and Completion	
6	ME → SIM	TERMINAL RESPONSE: GET INKEY 5.1.1	[command performed successfully] Check if it is in accordance with the user choice (value '01' in the Text String data object)
7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INKEY 5.1.2	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INKEY 5.1.2	["Yes/No" Response, no help information available]
10	$ME \rightarrow USER$	Display "Enter Yes/No:"	Text string coding in unpacked format
11	$USER \to ME$	Choice "No" and Completion	
12	ME → SIM	TERMINAL RESPONSE: GET INKEY 5.1.2	[command performed successfully] Check if it is in accordance with the user choice (value '00' in the Text String data object)

## PROACTIVE COMMAND: GET INKEY 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data

Text: "Enter"

Coding:

BER-TLV:	D0	11	81	03	01	22	04	82	02	81	82	8D
	06	04	45	6E	74	65	72					

## TERMINAL RESPONSE: GET INKEY 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: 01 (hex)

Coding:

BER-TLV:	81	03	01	22	04	82	02	82	81	83	01	00
	8D	02	04	01								

PROACTIVE COMMAND: GET INKEY 5.1.2: same as 5.1.1

**TERMINAL RESPONSE: GET INKEY 5.1.2** 

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: 00 (hex)

Coding:

BER-TLV:	81	03	01	22	04	82	02	82	81	83	01	00
	8D	02	04	00								

27.22.4.2.5.5 Test requirement

The ME shall operate in the manner defined in expected sequence 5.1.

27.22.4.2.6 GET INKEY (display of Icon)

27.22.4.2.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.2.6.2 Conformance requirement

The ME shall support the GET INKEY command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.5.4, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

27.22.4.2.6.3 Test purpose

To verify that the ME displays the Icon contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.6.4 Method of test

27.22.4.2.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

27.22.4.2.6.4.2 Procedure

# Expected Sequence 6.1A (GET INKEY, Basic icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[BASIC-ICON self-explanatory for the Text
		INKEY 6.1.1	string]
4	$ME \rightarrow USER$	Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
5		Enter "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	Command performed successfully]
		INKEY 6.1.1A	

## PROACTIVE COMMAND: GET INKEY 6.1.1

# Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "<NO-ICON>"

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 1 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	19	81	03	01	22	00	82	02	81	82	8D
	0A	04	3C	4E	4F	2D	49	43	4F	4E	3E	1E
	02	00	01									

## TERMINAL RESPONSE: GET INKEY 6.1.1A

# Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

**Text String** 

Data coding scheme: unpacked, 8 bit data

Γext: "+"

Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
·	8D	02	04	2B								

# Expected Sequence 6.1B (GET INKEY, Basic icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET INKEY 6.1.1	[BASIC-ICON self-explanatory for the Text string]
4		Display " <no-icon>" for the prompt without the icon</no-icon>	
			Text string coding in unpacked format
5	$USER \to ME$	Enter "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INKEY 6.1.1B	[Command performed successfully, but requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.1.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	04
	8D	02	04	2B								

# Expected Sequence 6.2A (GET INKEY, Basic icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[BASIC-ICON non self-explanatory for the
		INKEY 6.2.1	Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" and</basic-icon>	
		Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
_			
5	$USER \to ME$	Enter the input "+" and	
		completion	10 1 ( 1 )
6	$ME \rightarrow SIM$		[Command performed successfully]
		INKEY 6.2.1A	

#### PROACTIVE COMMAND: GET INKEY 6.2.1

## Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<BASIC-ICON>"

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 1 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	1C	81	03	01	22	00	82	02	81	82	8D	l
	0D	04	3C	42	41	53	49	43	2D	49	43	4F	l
	4E	3E	1E	02	01	01							l

# TERMINAL RESPONSE: GET INKEY 6.2.1A

## Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 6.2B (GET INKEY, Basic icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[BASIC-ICON non self-explanatory for the
		INKEY 6.2.1	Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" for the</basic-icon>	
		prompt without the icon	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Command performed successfully, but
		INKEY 6.2.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.2.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	04
	ЯD	02	04	2B								

# Expected Sequence 6.3A (GET INKEY, Colour icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
_		PENDING: GET INKEY 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[COLOUR-ICON self-explanatory for the Text
		INKEY 6.3.1	string]
4	$ME \rightarrow USER$	Display the COLOUR-ICON for	
		the prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Command performed successfully]
		INKEY 6.3.1A	

PROACTIVE COMMAND: GET INKEY 6.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<NO-ICON>"

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 2 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	1D	81	03	01	22	00	82	02	81	82	8D	
	0A	04	3C	4E	4F	2D	49	43	4F	4E	3E	1E	
	02	00	02										

TERMINAL RESPONSE: GET INKEY 6.3.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 6.3B (GET INKEY, Colour icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[COLOUR-ICON self-explanatory for the Text
		INKEY 6.3.1	string]
4	$ME \rightarrow USER$	Display " <no-icon>"for the</no-icon>	
		prompt without the icon	
			Text string coding in unpacked format
_			
5	$USER \to ME$	Enter the input "+" and	
6	ME CIM	completion TERMINAL RESPONSE: GET	[Command parformed augacosfully but
0	$ME \rightarrow SIM$	INKEY 6.3.1B	[Command performed successfully, but requested icon could not be displayed]
		INNET U.S. ID	requested icon could not be displayed]
	I		I I

TERMINAL RESPONSE: GET INKEY 6.3.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	04
	βD	02	04	2B								

# Expected Sequence 6.4A (GET INKEY, Colour icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[COLOUR-ICON non self-explanatory for the
		INKEY 6.4.1	Text string]
4	$ME \rightarrow USER$	Display " <colour-icon>" and</colour-icon>	
		Display the COLOUR-ICON for	
		the prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Command performed successfully]
		INKEY 6.4.1A	

## PROACTIVE COMMAND: GET INKEY 6.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<COLOUR-ICON>"

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 2 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	1D	81	03	01	22	00	82	02	81	82	8D
	0E	04	3C	43	4F	4C	4F	55	52	2D	49	43
	4F	4F	3F	1F	02	01	02					

## TERMINAL RESPONSE: GET INKEY 6.4.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

8D	02	04	2B				

# Expected Sequence 6.4B (GET INKEY, Colour icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[COLOUR-ICON non self-explanatory for the
		INKEY 6.4.1	Text string]
4	$ME \rightarrow USER$	Display " <colour-icon>" for</colour-icon>	
		the prompt without the icon	
			Total states a souling in common along the manual
_		Fatouth a innert Well and	Text string coding in unpacked format
5	USER → ME	Enter the input "+" and	
	NAT 0114	completion	ro
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Command performed successfully, but
		INKEY 6.4.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.4.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

## Coding:

BER-TLV:	81	03	01	22	00	82	02	82	81	83	01	04
	8D	02	04	2B								

# 27.22.4.2.6.5 Test requirement

The ME shall operate in the manner defined in expected sequence 6.1A to 6.4B.

# 27.22.4.2.7 GET INKEY (Help Information)

# 27.22.4.2.7.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.2.7.2 Conformance requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.2, clause 6.5.4, clause 6.6.2, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.31.

# 27.22.4.2.7.3 Test purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

#### 27.22.4.2.7.4 Method of test

#### 27.22.4.2.7.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.2.7.4.2 Procedure

# **Expected Sequence 7.1 (GET INKEY, help information available)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 7.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INKEY 7.1.1	[digits only, help information available]
4	$ME \rightarrow USER$	Display "Enter "+""	
			Text string coding in unpacked format
5	$USER \to ME$	Press "help" key	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INKEY 7.1.1	[help info required]
7	$SIM \to ME$	PROACTIVE COMMAND PENDING: DISPLAY TEXT 7.1.1	
8	$ME \to SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND: DISPLAY TEXT (help info)	
10	$ME \rightarrow USER$	Display "Help information"	Text string coded in unpacked format
11	$USER \rightarrow ME$	Clear Message	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: DISPLAY TEXT (help info)	
13	$SIM \to ME$	PROACTIVE COMMAND PENDING: GET INKEY 7.1.2	
14	$ME \rightarrow SIM$	FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[digits only, help information available]
15	SIIVI → IVIL	INKEY 7.1.2	[digits only, nelp information available]
16	$ME \to USER$	Display "Enter "+""	
47		Fatantha immut II. II and	Repetition of get inkey
17	$USER \to ME$	Enter the input "+" and	
18	$ME \rightarrow SIM$	completion TERMINAL RESPONSE: GET INKEY 7.1.2	[Command performed successfully]

# PROACTIVE COMMAND: GET INKEY 7.1.1

#### Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, help information available

Device identities

Source device: SIM Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "Enter "+""

Coding:

BER-TLV:	D0	15	81	03	01	22	80	82	02	81	82	8D
	0A	04	45	6E	74	65	72	20	22	2B	22	

TERMINAL RESPONSE: GET INKEY 7.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Help information required by the user

Coding:

BER-TLV: 81 03 01 22 80 82 02 82 81 83 01 13

PROACTIVE COMMAND: DISPLAY TEXT 7.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Help information"

Coding:

BER-TLV: D0 1C 81 03 01 21 80 82 02 81 02 8D 11 48 65 6C 70 20 69 6E 66 72 6D 61 74 69 6F 6E

**TERMINAL RESPONSE: DISPLAY TEXT 7.1.1** 

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TL	/: 81	03	01	21	80	82	02	82	81	83	01	00	1
--------	-------	----	----	----	----	----	----	----	----	----	----	----	---

## PROACTIVE COMMAND: GET INKEY 7.1.2

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "Enter "+""

Coding:

BER-TLV:	D0	15	81	03	01	22	80	82	02	81	82	8D
	0A	04	45	6E	74	65	72	20	22	2B	22	

#### **TERMINAL RESPONSE: GET INKEY 7.1.2**

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, \*, # and +) only, help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String:

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV:	81	03	01	22	80	82	02	82	81	83	01	04
•	8D	02	04	2B								

## 27.22.4.2.7.5 Test requirement

The ME shall operate in the manner defined in expected sequence 7.1.

# 27.22.4.3. GET INPUT

# 27.22.4.3.1 GET INPUT (normal)

# 27.22.4.3.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.3.1.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

#### 27.22.4.3.1.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

#### 27.22.4.3.1.4 Method of test

#### 27.22.4.3.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.3.1.4.2 Procedure

# Expected Sequence 1.1 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	INPUT 1.1.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help info available]
4	$ME \rightarrow USER$	Display "Enter 12345"	Range of expected length is 5-5 Text string coding in unpacked format
5	$USER \to ME$	Enter the input "12345" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 1.1.1	[command performed successfully]

# PROACTIVE COMMAND: GET INPUT 1.1.1

#### Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

BER-TLV:	D0	1B	81	03	01	23	00	82	02	81	82	8D
	0C	04	45	6E	74	65	72	20	31	32	33	34
	35	91	02	05	05							

TERMINAL RESPONSE: GET INPUT 1.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

1

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

BER-TLV:	81	03	01	23	80	82	02	82	81	83	01	00
	8D	06	04	31	32	33	34	35				

# Expected Sequence 1.2 (GET INPUT, digits only, SMS default alphabet, ME to echo text, packing SMS Point-to-point required by ME)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 1.2.1	text, packing required, no help information
1			available]
4	$ME \rightarrow USER$	Display " Enter 67*#+"	Range of expected length is 5-5
			Text string coding in packed format
5	$USER \to ME$	Enter the input "67*#+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 1.2.1	

PROACTIVE COMMAND: GET INPUT 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in packed SMS format, ME

to echo text, no help information available

Device identities

Source device: SIM Destination device: ME

**Text String** 

Data coding scheme: SMS default alphabet Text: "Enter 67\*#+"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV:	D0	1A	81	03	01	23	08	82	02	81	82	8D
	0B	00	45	37	BD	2C	07	D9	6E	AA	D1	0A
	91	02	05	05								

TERMINAL RESPONSE: GET INPUT 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in packed SMS format, ME

to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: packed SMS format

Text: "67\*#+"

Coding:

BER-TLV:	81	03	01	23	80	82	02	82	81	83	01	00
	8D	06	00	B6	9B	6A	B4	02				

# Expected Sequence 1.3 (GET INPUT, character set, SMS Default Alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INPUT 1.3.1	[character set, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display "Enter AbCdE"	Range of expected length is 5-5 Text string coding in unpacked format
5	$USER \to ME$	Enter the input "AbCdE" and completion	
6	ME	Echo " AbCdE"	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 1.3.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: Character set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: SIM

Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data Text: "Enter AbCdE"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV:	D0	1B	81	03	01	23	01	82	02	81	82	8D
	0C	04	45	6E	74	65	72	20	41	62	43	64
	45	91	02	05	05							

**TERMINAL RESPONSE: GET INPUT 1.3.1** 

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: Character set, SMS default alphabet, input in unpacked format, ME to echo text, no

help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "AbCdE"

Coding:

BER-TLV:	81	03	01	23	01	82	02	82	81	83	01	00
•	8D	06	04	41	62	43	64	45				

# Expected Sequence 1.4 (GET INPUT, digits only, SMS default alphabet, ME to hide text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to hide
		INPUT 1.4.1	text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display	Range of expected length is 4-8
		"Password 1 <send>2345678"</send>	Text string coding in unpacked format
5	$USER \rightarrow ME$	Enter the input "2345678" and	
		completion	
6	ME	input not displayed	optionally indication of key entries such as by
			displaying "*"
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 1.4.1	

PROACTIVE COMMAND: GET INPUT 1.4.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

hide text, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "Password 1<SEND>2345678"

Response length

Minimum length: 4 Maximum length: 8

## Coding:

BER-TLV:	D0	27	81	03	01	23	04	82	02	81	82	8D
_	18	04	50	61	73	73	77	6F	72	64	20	31
	3C	53	45	4E	44	3E	32	33	34	35	36	37
	38	91	02	04	08							

#### **TERMINAL RESPONSE: GET INPUT 1.4.1**

# Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

hide text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "2345678"

BER-TLV:	81	03	01	23	04	82	02	82	81	83	01	00
	8D	08	04	32	33	34	35	36	37	38		

# Expected Sequence 1.5 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.5.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
			text, packing not required, no help information available]
4	$ME \to USER$	Display "Enter 19,09,0(1)"	Range of expected length is 1-20 Text string coding in unpacked format
5	$USER \to ME$	Completion without input	
6	MMI →USER	Display "invalid length"	
7	USER →ME	Enter	
		"12345678901234567890" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 1.5.1	[command performed successfully]

#### PROACTIVE COMMAND: GET INPUT 1.5.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Enter 1..9,0..9,0(1)"

Response length

Minimum length: 1 Maximum length: 20

# Coding:

BER-TLV:	D0	24	81	03	01	23	00	82	02	81	82	8D
•	15	04	45	6E	74	65	72	20	31	2E	2E	39
	2C	30	2E	2E	39	2C	30	28	31	29	91	02
	01	14										

## **TERMINAL RESPONSE: GET INPUT 1.5.1**

# Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data
Text: "12345678901234567890"

## Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	15	04	31	32	33	34	35	36	37	38	39
	30	31	32	33	34	35	36	37	38	39	30	

# Expected Sequence 1.6 (GET INPUT, backwards move)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 1.6.1	text, packing not required, no help information
			available]
4	$ME \rightarrow USER$	Display " <go-backwards>"</go-backwards>	Range of expected length is 0-8
			Text string coding in unpacked format
5	$USER \rightarrow ME$	Backwards move MMI action	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[backward move in the proactive SIM session
		INPUT 1.6.1	requested by the user]

## PROACTIVE COMMAND: GET INPUT 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

Response length

Minimum length: 0 Maximum length: 8

# Coding:

BER-TLV:	D0	1E	81	03	01	23	00	82	02	81	82	8D
	0F	04	3C	47	4F	2D	42	41	43	4B	57	41
	52	44	53	3E	91	02	00	80				

## **TERMINAL RESPONSE: GET INPUT 1.6.1**

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 11

# **Expected Sequence 1.7 (GET INPUT, abort)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 1.7.1	text, packing not required, no help information
			available]
4	$ME \rightarrow USER$	Display " <abort>"</abort>	Range if expected length is 0-8
			Text string coding in unpacked format
5	$USER \to ME$	Terminate the Proactive SIM	
		session MMI action	
6			[Proactive SIM session terminated by the
		INPUT 1.7.1	user]

## PROACTIVE COMMAND: GET INPUT 1.7.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<ABORT>"

Response length

Minimum length: 0 Maximum length: 8

Coding:

BER-TLV:	D0	17	81	03	01	23	00	82	02	81	82	8D
	08	04	3C	41	42	4F	52	54	3E	91	02	00
	08											

#### **TERMINAL RESPONSE: GET INPUT 1.7.1**

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	10	l
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

# Expected Sequence 1.8 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INPUT 1.8.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display	Range of length expected is 160-160
		"***111111111###***2222222	Text string coding in unpacked format
		222###***333333333###***44	
		4444444###***555555555##	
		#***6666666666###***7777777	
		777###***888888888###***99	
		9999999###***000000000##	
		#"	
5	$USER \to ME$	Enter the input	
		"***111111111###***2222222	
		222###***333333333###***44	
		4444444###***555555555	
		#***6666666666###***7777777	
		777###***888888888###***99	
		9999999###***000000000##  #"	
		and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 1.8.1	[command performed successfully]

# PROACTIVE COMMAND: GET INPUT 1.8.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME

to echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "\*\*\*111111111###\*\*\*222222222###\*\*\*333333333###\*\*\*44444444###\*\*\*

555555555###\*\*\*666666666###\*\*\*77777777###\*\*\*888888888###\*\*\*9999

99999###\*\*\*000000000###"

Response length

Minimum length: 160 Maximum length: 160

BER-TLV:	D0	81	B1	81	03	01	23	00	82	02	81	82
	8D	81	A1	04	2A	2A	2A	31	31	31	31	31
	31	31	31	31	31	23	23	23	2A	2A	2A	32
	32	32	32	32	32	32	32	32	32	23	23	23
	2A	2A	2A	33	33	33	33	33	33	33	33	33
	33	23	23	23	2A	2A	2A	34	34	34	34	34
	34	34	34	34	34	23	23	23	2A	2A	2A	35
	35	35	35	35	35	35	35	35	35	23	23	23
	2A	2A	2A	36	36	36	36	36	36	36	36	36
	36	23	23	23	2A	2A	2A	37	37	37	37	37
	37	37	37	37	37	23	23	23	2A	2A	2A	38
	38	38	38	38	38	38	38	38	38	23	23	23
	2A	2A	2A	39	39	39	39	39	39	39	39	39
	39	23	23	23	2A	2A	2A	30	30	30	30	30
	30	30	30	30	30	23	23	23	91	02	A0	A0

**TERMINAL RESPONSE: GET INPUT 1.8.1** 

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "\*\*\*111111111###\*\*\*222222222###\*\*\*

33333333###\*\*\*4444444### \*\*\*5555555555###\*\*\*666666666### \*\*\*77777777###\*\*\*88888888### \*\*\*999999999###\*\*\*0000000000###"

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	81	A1	04	2A	2A	2A	31	31	31	31	31
	31	31	31	31	31	23	23	23	2A	2A	2A	32
	32	32	32	32	32	32	32	32	32	23	23	23
	2A	2A	2A	33	33	33	33	33	33	33	33	33
	33	23	23	23	2A	2A	2A	34	34	34	34	34
	34	34	34	34	34	23	23	23	2A	2A	2A	35
	35	35	35	35	35	35	35	35	35	23	23	23
	2A	2A	2A	36	36	36	36	36	36	36	36	36
	36	23	23	23	2A	2A	2A	37	37	37	37	37
	37	37	37	37	37	23	23	23	2A	2A	2A	38
	38	38	38	38	38	38	38	38	38	23	23	23
	2A	2A	2A	39	39	39	39	39	39	39	39	39
	39	23	23	23	2A	2A	2A	30	30	30	30	30
	30	30	30	30	30	23	23	23				

# Expected Sequence 1.9 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 1.9.1	text, packing not required, no help information
			available]
4	$ME \rightarrow USER$	Display " <send>"</send>	Range of expected length is 0-1
			Text string coding in unpacked format
5	$USER \to ME$	Completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 1.9.1	

## PROACTIVE COMMAND: GET INPUT 1.9.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "<SEND>"

Response length

Minimum length: 0 Maximum length: 1

#### Coding:

BER-TLV:	D0	16	81	03	01	23	00	82	02	81	82	8D
	07	04	3C	53	45	4E	44	3E	91	02	00	01

## TERMINAL RESPONSE: GET INPUT 1.9.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: empty string

## Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	01	04									

## Expected Sequence 1.10 (GET INPUT, null length for the text string, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.10.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 1.10.1	text, packing not required, no help info
			available]
4	$ME \rightarrow USER$	Request for input	Range of expected length is 0-5
			Null Text string
5	$USER \to ME$	Enter the input "12345" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 1.10.1	

# PROACTIVE COMMAND: GET INPUT 1.10.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text string

Text: length null (00).

Response length

Minimum length: 1 Maximum length: 5

Coding:

BER-TLV:	D0	0F	81	03	01	23	00	82	02	81	82	8D
	00	91	02	01	05							

## TERMINAL RESPONSE: GET INPUT 1.10.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

BER-TLV:	81	03	01	23	80	82	02	82	81	83	01	00
	8D	06	04	31	32	33	34	35				

## 27.22.4.3.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.10.

## 27.22.4.3.2 GET INPUT (No response from User)

# 27.22.4.3.2.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.3.2.2 Conformance requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

# 27.22.4.3.2.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.3.2.4 Method of test

## 27.22.4.3.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

# 27.22.4.3.2.4.2 Procedure

## **Expected Sequence 2.1 (GET INPUT, no response from the user)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet
			ME to echo text, packing not required, no help
			information available]
4	$ME \rightarrow USER$	Display " <time-out>"</time-out>	Range of expected length is 0-10
			Text string coding in unpacked format
5	USER	Waiting and no completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[No response from user] within 5 s after the
		INPUT 2.1.1	end of that defined period of time

#### PROACTIVE COMMAND: GET INPUT 2.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: unpacked, 8 bit data
Text: "<TIME-OUT>"

Response length

Minimum length: 0 Maximum length: 10

#### Coding:

BER-TLV:	D0	1A	81	03	01	23	00	82	02	81	82	8D
	0B	04	3C	54	49	4D	45	2D	4F	55	54	3E
	91	02	00	0A								

#### **TERMINAL RESPONSE: GET INPUT 2.1.1**

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: No response from user

Coding:

	Е	BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	12
--	---	----------	----	----	----	----	----	----	----	----	----	----	----	----

## 27.22.4.3.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

# 27.22.4.3.3 GET INPUT (UCS2 format display)

## 27.22.4.3.3.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.3.3.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

#### 27.22.4.3.3.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.3.4 Method of test

27.22.4.3.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.3.3.4.2 Procedure

## Expected Sequence 3.1 (GET INPUT, text string coding in UCS2, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET INPUT 3.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	$ME \to USER$	Display " ЗДРАВСТВУЙТЕ "	Range of expected length is 5-5 Text string "Hello" in Russian coding in 16 bits UCS2 alphabet format
5	$USER \to ME$	Enter the input "HELLO" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 3.1.1	[command performed successfully]

#### PROACTIVE COMMAND: GET INPUT 3.1.1

#### Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME

to echo text, no help information available

Device identities

Source device: SIM Destination device: ME

Text String

Data coding scheme: 16 bit data UCS2 alphabet format

Техt: "ЗДРАВСТВУЙТЕ "

Response length

Minimum length: 5 Maximum length: 5

BER-TLV:	D0	28	81	03	01	23	00	82	02	81	82	8D
	19	08	04	17	04	14	04	20	04	10	04	12

04	21	04	22	04	12	04	23	04	19	04	22
04	15	91	02	05	05						

**TERMINAL RESPONSE: GET INPUT 3.1.1** 

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "HELLO"

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	06	04	48	45	4C	4C	4F				

# Expected Sequence 3.2 (GET INPUT, max length for the text string coding in UCS2, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INPUT 3.2.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display	Range of expected length is 5-5
		"ЗДРАВСТВУЙТЕЗДРАВСТВ УЙТЕ	Text string length 70 characters, coding in 16 bits UCS2 alphabet format
		ЗДРАВСТВУЙТЕЗДРАВСТВ	
		УЙТЕ	
		ЗДРАВСТВУЙТЕЗДРАВСТВУЙ "	
5	$USER \to ME$	Enter the input "Hello" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 3.2.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME

to echo text, no help information available

Device identities

Source device: SIM Destination device: ME

**Text String** 

Data coding scheme: 16 bit data UCS2 alphabet format

Text: "ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ

ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV:	D0	81	9D	81	03	01	23	00	82	02	81	82
	8D	81	8D	80	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	91	02	05	05								

**TERMINAL RESPONSE: GET INPUT 3.2.1** 

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "HELLO"

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	06	04	48	45	4C	4C	4F				

27.22.4.3.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1 to 3.2.

27.22.4.3.4 GET INPUT (UCS2 format of entry)

27.22.4.3.4.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.3.4.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in ISO/IEC 10646 [17].

## 27.22.4.3.4.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

## 27.22.4.3.4.4 Method of test

## 27.22.4.3.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.3.4.4.2 Procedure

# Expected Sequence 4.1 (GET INPUT, character set from UCS2 alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 4.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[character set, UCS2 alphabet, ME to echo
		INPUT 4.1.1	text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display "enter Hello"	Range of expected length is 5-5 Text string coding in unpacked format
5	$USER \to ME$	Enter the input "ЗДРАВСТВУЙТЕ "	"Hello" in Russian, coding in UCS2 format
6	$ME \rightarrow SIM$	and completion TERMINAL RESPONSE: GET INPUT 4.1.1	[command performed successfully]

## PROACTIVE COMMAND: GET INPUT 4.1.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data Text: "Enter Hello"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV:	D0	1B	81	03	01	23	03	82	02	81	82	8D
	0C	04	45	6E	74	65	72	20	48	65	6C	6C
	6F	91	02	05	05							

TERMINAL RESPONSE: GET INPUT 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: UCS2

Text: "ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV:	81	03	01	23	03	82	02	82	81	83	01	00
	8D	19	80	04	17	04	14	04	20	04	10	04
	12	04	21	04	22	04	12	04	23	04	19	04
	22	04	15									

# Expected Sequence 4.2 (GET INPUT, character set from UCS2 alphabet, Max length for the input, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[character set, UCS2 alphabet, ME to echo
		INPUT 4.2.1	text, packing not required, no help information
			available]
4	$ME \rightarrow USER$	Display	Range of expected length is no limit
		"Enter Hello:"	Text string coding in unpacked format
5	$USER \to ME$	Enter the input	Input length 70 characters, coding in UCS2
		ogi mbe ibi milesgi mbe ib	format
		УИТЕ	
		ЗДРАВСТВУЙТЕЗДРАВСТВ	
		УЙТЕ	
		ЗДРАВСТВУЙТЕЗДРАВСТВУЙ	
		and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 4.2.1	

PROACTIVE COMMAND: GET INPUT 4.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: SIM Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Enter Hello"

Response length

Minimum length: 5

Maximum length: No maximum length requirement

## Coding:

BER-TLV:	D0	1B	81	03	01	23	03	82	02	81	82	8D
	0C	04	45	6E	74	65	72	20	48	65	6C	6C
	6F	91	02	05	FF							

## TERMINAL RESPONSE: GET INPUT 4.2.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text, no help

information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Data coding scheme: UCS2

Text: "ЗДРАВСТВУЙТЕ...ЗДРАВСТВУЙ" (70 chars)

## Coding:

BER-TLV:	81	03	01	23	03	82	02	82	81	83	01	00
	8D	81	8D	80	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19

## 27.22.4.3.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1 to 4.2.

# 27.22.4.3.5 GET INPUT (default text)

## 27.22.4.3.5.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.3.5.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

## 27.22.4.3.5.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.5.4 Method of test

27.22.4.3.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.3.5.4.2 Procedure

## Expected Sequence 5.1(GET INPUT, default text for the input, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 5.1.1	text, packing not required, no help
			information available]
4	$ME \rightarrow USER$	Display "Enter 12345"	Range of expected length is 5-5
		Display "12345"	Text string coding in unpacked format
			Default text coding in unpacked format
5	$USER \to ME$	Completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 5.1.1	

## PROACTIVE COMMAND: GET INPUT 5.1.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

Default Text

Data coding scheme: unpacked, 8 bit data

Text: "12345"

# Coding:

BER-TLV:	D0	23	81	03	01	23	00	82	02	81	82	8D
	0C	04	45	6E	74	65	72	20	31	32	33	34
	35	91	02	05	05	17	06	04	31	32	33	34
	35											

# **TERMINAL RESPONSE: GET INPUT 5.1.1**

# Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

## Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
·	8D	06	04	31	32	33	34	35				

# Expected Sequence 5.2 (GET INPUT, default text for the input with max length, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 5.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 5.2.1	text, packing not required, no help
			information available]
4	$ME \rightarrow USER$	Display "Enter:"	Range of expected length is 5-5
		Display default text input:	Text string coding in unpacked format
		"***111111111###***22222222	Default text length 160 bytes coding in
		22###***33333333###***4444	unpacked format
		444444###***555555555###***	
		666666666###***777777777	
		##***888888888###***999999	
		999###***000000000###"	
5	$USER \to ME$	Completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed successfully]
		INPUT 5.2.1	

## PROACTIVE COMMAND: GET INPUT 5.2.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: SIM Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data

Text: "Enter:"

Response length

Minimum length: 160 Maximum length: 160

Default Text

Data coding scheme: unpacked, 8 bit data

Text: "\*\*\*111111111###\*\*\*22222222###\*\*\*33333333###\*\*\*444444444###\*\*\*

555555555###\*\*\*666666666###\*\*\*77777777###\*\*\*888888888###\*\*\*9999

99999###\*\*\*000000000###"

## Coding:

BER-TLV:	D0	81	BA	81	03	01	23	00	82	02	81	82
	8D	07	04	45	6E	74	65	72	3A	91	02	A0
	A0	17	81	A1	04	2A	2A	2A	31	31	31	31
	31	31	31	31	31	23	23	23	2A	2A	2A	32
	32	32	32	32	32	32	32	32	32	32	23	23
	23	2A	2A	2A	33	33	33	33	33	33	33	33
	33	33	23	23	23	2A	2A	2A	34	34	34	34
	34	34	34	34	34	34	23	23	23	2A	2A	2A
	35	35	35	35	35	35	35	35	35	35	23	23
	23	2A	2A	2A	36	36	36	36	36	36	36	36
	36	36	23	23	23	2A	2A	2A	37	37	37	37
	37	37	37	37	37	37	23	23	23	2A	2A	2A
	38	38	38	38	38	38	38	38	38	38	23	23
	23	2A	2A	2A	39	39	39	39	39	39	39	39
	39	39	23	23	23	2A	2A	2A	30	30	30	30
	30	30	30	30	30	30	23	23	23			

## TERMINAL RESPONSE: GET INPUT 5.2.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: unpacked, 8 bit data

Text: "\*\*\*111111111###\*\*\*222222222###\*\*\*33333333###\*\*\*44444444###\*\*\*

55555555###\*\*\*666666666###\*\*\*77777777###\*\*\*888888888###\*\*\*9999

999999###\*\*\*0000000000###"

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	81	A1	04	2A	2A	2A	31	31	31	31	31
	31	31	31	31	31	23	23	23	2A	2A	2A	32
	32	32	32	32	32	32	32	32	32	23	23	23
	2A	2A	2A	33	33	33	33	33	33	33	33	33
	33	23	23	23	2A	2A	2A	34	34	34	34	34
	34	34	34	34	34	23	23	23	2A	2A	2A	35
	35	35	35	35	35	35	35	35	35	23	23	23
	2A	2A	2A	36	36	36	36	36	36	36	36	36
	36	23	23	23	2A	2A	2A	37	37	37	37	37
	37	37	37	37	37	23	23	23	2A	2A	2A	38
	38	38	38	38	38	38	38	38	38	23	23	23
	2A	2A	2A	39	39	39	39	39	39	39	39	39
	39	23	23	23	2A	2A	2A	30	30	30	30	30
	30	30	30	30	30	23	23	23				

## 27.22.4.3.5.5 Test requirement

The ME shall operate in the manner defined in expected sequences 5.1 to 5.2.

# 27.22.4.3.6 GET INPUT (display of Icon)

27.22.4.3.6.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.3.6.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.5.4, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3, clause 12.13 and clause 12.31.

# 27.22.4.3.6.3 Test purpose

To verify that the ME displays the Icon contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

## 27.22.4.3.6.4 Method of test

## 27.22.4.3.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

## 27.22.4.3.6.4.2 Procedure

# Expected Sequence 6.1A (GET INPUT, Basic icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[BASIC-ICON self-explanatory for the Text
		INPUT 6.1.1	string]
4	$ME \rightarrow USER$	Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	Command performed successfully]
		INPUT 6.1.1A	

## PROACTIVE COMMAND: GET INPUT 6.1.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 1 (number of record in  $EF_{Img}$ )

## Coding:

BER-TLV:	D0	1D	81	03	01	23	00	82	02	81	82	8D
_	0A	04	3C	4E	4F	2D	49	43	4F	4E	3E	91
	02	00	0A	1E	02	00	01					

## TERMINAL RESPONSE: GET INPUT 6.1.1A

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	23	04	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 6.1B (GET INPUT, Basic icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[BASIC-ICON self-explanatory for the Text
		INPUT 6.1.1	string]
4	$ME \to USER$	Display " <no-icon>" for the</no-icon>	
		prompt without the icon	
			Text string coding in unpacked format
5	$USER \to ME$	Enter "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Command performed successfully, but
		INPUT 6.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INPUT 6.1.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	04
	8D	02	04	2B								

# Expected Sequence 6.2A (GET INPUT, Basic icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[BASIC-ICON non self-explanatory for the
		INPUT 6.2.1	Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" and</basic-icon>	
		Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
_			
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$		[Command performed successfully]
		INPUT 6.2.1A	

## PROACTIVE COMMAND: GET INPUT 6.2.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "<BASIC-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 1 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	20	81	03	01	23	00	82	02	81	82	8D
	0D	04	3C	42	41	53	49	43	2D	49	43	4F
	4E	3E	91	02	00	0A	1E	02	01	01		

## TERMINAL RESPONSE: GET INPUT 6.2.1A

# Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 6.2B (GET INPUT, Basic icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INPUT 6.2.1	[BASIC-ICON non self-explanatory for the Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" for the prompt without the icon</basic-icon>	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and completion	
6	ME → SIM	TERMINAL RESPONSE: GET INPUT 6.2.1B	[Command performed successfully, but requested icon could not be displayed]

TERMINAL RESPONSE: GET INPUT 6.2.1B

Logically:

Command details

Command number:

Command type: **GET INPUT** 

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

Command performed successfully but requested icon could not be displayed General Result:

Text string

unpacked, 8 bit data Text: "+" Data coding scheme:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	04
	δD	02	04	2B								

# Expected Sequence 6.3A (GET INPUT, Colour icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[COLOUR-ICON self-explanatory for the Text
		INPUT 6.3.1	string]
4	$ME \rightarrow USER$	Display the COLOUR-ICON for	
		the prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[Command performed successfully]
		INPUT 6.3.1A	

## PROACTIVE COMMAND: GET INPUT 6.3.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "<NO-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 2 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	1D	81	03	01	23	00	82	02	81	82	8D
	0A	04	3C	4E	4F	2D	49	43	4F	4E	3E	91
	02	00	0A	1E	02	00	02					

## TERMINAL RESPONSE: GET INPUT 6.3.1A

# Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 6.3B (GET INPUT, Colour icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET INPUT 6.3.1	[COLOUR-ICON self-explanatory for the Text string]
4	$ME \rightarrow USER$	Display the COLOUR-ICON for	
		the prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET INPUT 6.3.1B	[Command performed successfully, but requested icon could not be displayed]

TERMINAL RESPONSE: GET INPUT 6.3.1B

Logically:

Command details

Command number:

Command type: **GET INPUT** 

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

Command performed successfully but requested icon could not be displayed General Result:

Text string

unpacked, 8 bit data "+" Data coding scheme:

Text:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	04
•	8D	02	04	2B								

# Expected Sequence 6.4A (GET INPUT, Colour icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	[COLOUR-ICON non self-explanatory for the
		INPUT 6.4.1	Text string]
4	$ME \rightarrow USER$	Display " <colour-icon>" and</colour-icon>	
		Display the COLOUR-ICON for	
		the prompt	
			Tout string and in a in turn poly of forms at
_			Text string coding in unpacked format
5	USER → ME	Enter the input "+" and	
		completion	10 1 1 1 1 1
6	$ME \rightarrow SIM$		[Command performed successfully]
		INPUT 6.4.1A	

## PROACTIVE COMMAND: GET INPUT 6.4.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "<COLOUR-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 2 (number of record in  $EF_{Img}$ )

Coding:

BER-TLV:	D0	1D	81	03	01	23	00	82	02	81	82	8D
	0A	04	3C	4E	4F	2D	49	43	4F	4E	3E	91
	02	00	0A	1E	02	01	02					

## TERMINAL RESPONSE: GET INPUT 6.4.1A

# Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	02	04	2B								

# Expected Sequence 6.4B (GET INPUT, Colour icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
2	ME SOM	PENDING: GET INPUT 6.4.1	
	$ME \rightarrow SIM$	. = . •	
3	$SIM \to ME$	PROACTIVE COMMAND: GET INPUT 6.4.1	[COLOUR-ICON non self-explanatory for the Text string]
4	ME → USER	Display " <colour-icon>" for the prompt without the icon</colour-icon>	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
6	$ME \rightarrow SIM$	completion TERMINAL RESPONSE: GET INPUT 6.4.1B	[Command performed successfully, but requested icon could not be displayed]

TERMINAL RESPONSE: GET INPUT 6.4.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, no help information available

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	04
	8D	02	04	2B								

# 27.22.4.3.6.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 6.1A to 6.4B.

# 27.22.4.3.7 GET INPUT (Help Information)

27.22.4.3.7.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.3.7.2 Conformance requirement

The ME shall support the GET INPUT command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.3, clause 6.6.3, clause 6.8, clause 6.11, clause 12.6, clause 12.15, clause 12.15.1, clause 12.15.2, clause 12.15.3 and clause 12.13.

#### 27.22.4.3.7.3 Test purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns a 'help information required by the user' result value in the TERMINAL RESPONSE command sent to the SIM if the user has indicated the need to get help information.

27.22.4.3.7.4 Method of test

27.22.4.3.7.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.3.7.4.2 Procedure

# Expected Sequence 7.1 (GET INPUT, digits only, ME to echo text, ME supporting 8 bit data Message, help information available)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 7.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET	[digits only, SMS default alphabet, ME to echo
		INPUT 7.1.1	text, packing not required, help information
			available]
4	$ME \rightarrow USER$	Display "Enter 12345"	Range of expected length is 5-5
			Text string coding in unpacked format
5	$USER \to ME$	Press "help"	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET	[command performed, help information
		INPUT 7.1.1	required by user]

## PROACTIVE COMMAND: GET INPUT 7.1.1

## Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, help information available

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data Text: "Enter 12345"

Response length

Minimum length: 5
Maximum length: 5

BER-TLV:	D0	1B	81	03	01	23	80	82	02	81	82	8D
	0C	04	45	6E	74	65	72	20	31	32	33	34
	35	91	02	05	05							

TERMINAL RESPONSE: GET INPUT 7.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

1

Command qualifier: digits (0-9, \*, # and +) only, SMS default alphabet, input in unpacked format, ME to

echo text, help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Help information required by the user

Coding:

BER-TLV: 81 03 01	23 80 82	02 82 8	1 83 01 13
-------------------	----------	---------	------------

## 27.22.4.3.7.5 Test requirement

The ME shall operate in the manner defined in expected sequence 7.1.

## 27.22.4.4 MORE TIME

# 27.22.4.4.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.4.2 Conformance requirement

The ME shall support the MORE TIME command as defined in:

• 3GPP TS 11.14 [15] clause 6.4.4, clause 6.6.4, clause 5.2, clause 12.6 and clause 12.7.

# 27.22.4.4.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the MORE TIME proactive SIM command.

# 27.22.4.4.4 Method of test

## 27.22.4.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.4.4.2 Procedure

# **Expected Sequence 1.1 (MORE TIME)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: MORE TIME 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: MORE	
		TIME 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: MORE	[Command performed successfully]
		TIME 1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: MORE TIME 1.1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	02	00	82	02	81	82

TERMINAL RESPONSE: MORE TIME 1.1.1

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	02	00	82	02	82	81	83	01	00
D = 1 \ 1 = \ 1 .	, o.	00	0.		00	_ <del>_</del>	~ <u>~</u>		<b>.</b>		<b>.</b>	

# 27.22.4.4.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

# 27.22.4.5 PLAY TONE

# 27.22.4.5.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.5.2 Conformance requirement

The ME shall support the PLAY TONE command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.5, clause 6.6.5, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.16 and clause 12.8.

# 27.22.4.5.3 Test purpose

To verify that the ME plays an audio tone of a type and duration contained in the PLAY TONE proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME plays the requested audio tone through the external ringer whilst not in call and shall superimpose the tone on top of the downlink audio whilst in call.

To verify that the ME displays the text contained in the PLAY TONE proactive SIM command.

## 27.22.4.5.4 Method of test

## 27.22.4.5.4.1 Initial conditions

The ME is connected to the SIM Simulator and to the System Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.5.4.2 Procedure

# **Expected Sequence 1.1 (PLAY TONE)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: PLAY	
		TONE 1.1.1	
4	$ME \rightarrow USER$	Display "Dial Tone"	
		Play a standard supervisory dial	
		tone through the external ringer for	
		a duration of 5 s	
5	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
	/	TONE 1.1.1	,,,
6	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.2	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND: PLAY	
10	ME  o USER	TONE 1.1.2	
10	IVIE → USER	Display "Sub. Busy"	
		Play a standard supervisory called	
		subscriber busy tone for a duration	
		of 5 s	
11	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
		TONE 1.1.2	
12	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.3	

Step	Direction	MESSAGE / Action	Comments
14	$ME \rightarrow SIM$	FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND: PLAY TONE 1.1.3	
16	$ME \to USER$	Display "Congestion"	
		Play a standard supervisory	
		congestion tone for a duration of 5 s	
17	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
18	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
19	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4	
20 21	$ME \rightarrow SIM$	FETCH PROACTIVE COMMAND: PLAY	
21	$SIM \rightarrow ME$	TONE 1.1.4	
22	$ME \to USER$	Display "RP Ack"	
		Play a standard supervisory radio	
23	ME  o SIM	path acknowledgement tone TERMINAL RESPONSE: PLAY	[Command performed successfully]
		TONE 1.1.4	[,
24	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
25	$SIM \to ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5	
26	$ME \rightarrow SIM$	FETCH	
27	$SIM \to ME$	PROACTIVE COMMAND: PLAY TONE 1.1.5	
28	$ME \to USER$	Display "No RP"	
		Play a standard supervisory radio	
		path not available / call dropped tone for a duration of 5 s	
29	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
30	$SIM \to ME$	TONE 1.1.5 PROACTIVE SIM SESSION	
		ENDED	
31	$SIM \to ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.6	
32	$ME \rightarrow SIM$	FETCH	
33	$SIM \rightarrow ME$	PROACTIVE COMMAND: PLAY TONE 1.1.6	
34	$ME \rightarrow USER$	Display "Spec Info"	
		Play a standard supervisory error /	
		special information tone for a duration of 5 s	
35	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
36	$SIM \to ME$	TONE 1.1.6 PROACTIVE SIM SESSION	
37	SIM  o ME	ENDED PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.7	
38 39	$ME \to SIM$ $SIM \to ME$	FETCH PROACTIVE COMMAND: PLAY	
		TONE 1.1.7	
40	$ME \rightarrow USER$	Display "Call Wait"	
		Play a standard supervisory call waiting tone for a duration of 5 s	
41	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
42	$SIM \to ME$	TONE 1.1.7 PROACTIVE SIM SESSION	
72	Olivi IVIE	ENDED	

Step	Direction	MESSAGE / Action	Comments
43	$SIM \rightarrow ME$	PROACTIVE COMMAND	
4.4	ME OIM	PENDING: PLAY TONE 1.1.8	
44 45	ME  o SIM $SIM  o ME$	FETCH PROACTIVE COMMAND: PLAY	
45	SIIVI → IVI⊑	TONE 1.1.8	
46	$ME \to USER$	Display "Ring Tone"	
	, , , , ,		
		Play a standard supervisory	
47		ringing tone for duration of 5 s	
47	$ME \rightarrow SIM$	TERMINAL RESPONSE: PLAY TONE 1.1.8	[Command performed successfully]
48	$SIM \to ME$	PROACTIVE SIM SESSION	
	OIW / WIL	ENDED	
49	$USER \to ME$	Set up a voice call	User dials 123456789 to connect to the
			network manually]
50		Establish voice call	[Voice call is established]
51	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.9	
52	ME  o SIM	FETCH	
53	$SIM \rightarrow ME$	PROACTIVE COMMAND: PLAY	
	J / IVIL	TONE 1.1.9	
54	$ME \to USER$	Display "Dial Tone"	
		Superimpose the standard supervisory dial tone on the audio	
		downlink for the duration of 5 s	
55	$ME \rightarrow SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
	, , , , , , , , , , , , , , , , , , , ,	TONE 1.1.9	, , , , , , , , , , , , , , , , , , , ,
56	$SIM \to ME$	PROACTIVE SIM SESSION	
<b>5</b> 7	0114 145	ENDED	
57	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.10	
58	$ME \to SIM$	FETCH	
59	SIM → ME	PROACTIVE COMMAND: PLAY	
	· · · · · · · · · · · · · · · · · · ·	TONE 1.1.10	
60	$ME \to USER$	Display "This command instructs	
		the ME to play an audio tone.	
		Upon receiving this command, the ME shall check if it is currently in,	
		or in the process of setting up	
		(SET-UP message sent to the	
		network, see GSM"04.08"(8)), a	
		speech call If the ME I"	
		Play a gaparal base	
61	ME  o SIM	Play a general beep ITERMINAL RESPONSE: PLAY	[Command performed successfully]
	1VIL / O11VI	TONE 1.1.10a	[2 5and ponomina adoptioning]
		or	or
		TERMINAL RESPONSE: PLAY	[Command beyond ME's capabilities]
60		TONE 1.1.10b	
62	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
63	$SIM \to ME$	PROACTIVE COMMAND	
	J /	PENDING: PLAY TONE 1.1.11	
64	$ME \to SIM$	FETCH	
65	$SIM \to ME$	PROACTIVE COMMAND: PLAY	
66	ME LICER	TONE 1.1.11	
66	$ME \rightarrow USER$	Display "Beep"	
		Play a ME proprietary general	
		beep	
67	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
		TONE 1.1.11a	
		Or TERMINAL RESPONSE: PLAY	or [Command beyond ME's capabilities]
		TONE 1.1.11b	[Command Deyond IVIE's Capabilities]
L	<u> </u>		<u> </u>

Step	Direction	MESSAGE / Action	Comments
68	$SIM \to ME$	PROACTIVE SIM SESSION	
69	$SIM \to ME$	PROACTIVE COMMAND	
70	$ME \to SIM$	PENDING: PLAY TONE 1.1.12 FETCH	
71	SIM → ME	PROACTIVE COMMAND: PLAY	
72	$ME \to USER$	TONE 1.1.12 Display "Positive"	
73	$ME \to SIM$	Play a ME proprietary positive acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.12a or	[Command performed successfully] or
74	SIM  o ME	TERMINAL RESPONSE: PLAY TONE 1.1.12b PROACTIVE SIM SESSION	[Command beyond ME's capabilities]
75	$SIM \to ME$	ENDED PROACTIVE COMMAND	
76	ME  o SIM	PENDING: PLAY TONE 1.1.13 FETCH	
77	SIM → ME	PROACTIVE COMMAND: PLAY TONE 1.1.13	
78	$ME \to USER$	Display "Negative"	
79	$ME \to SIM$	Play a ME proprietary negative acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.13a or	[Command performed successfully]
80	$SIM \to ME$	TERMINAL RESPONSE: PLAY TONE 1.1.13b PROACTIVE SIM SESSION ENDED	[Command beyond ME's capabilities]
81	$SIM \to ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.14	
82 83	$\begin{array}{c} ME \to SIM \\ SIM \to ME \end{array}$	FETCH PROACTIVE COMMAND: PLAY	
84	$ME \to USER$	TONE 1.1.14 Display "Quick"	
85	$ME \to SIM$	Play a ME proprietary general beep TERMINAL RESPONSE: PLAY TONE 1.1.14a	[Command performed successfully]
		or TERMINAL RESPONSE: PLAY	or [Command beyond ME's capabilities]
86	$SIM \to ME$	TONE 1.1.14b PROACTIVE SIM SESSION	
87	$SIM \to ME$	PROACTIVE COMMAND	
88	ME  o SIM	PENDING: PLAY TONE 1.1.15 FETCH	
89	$SIM \rightarrow ME$	PROACTIVE COMMAND: PLAY TONE 1.1.15	
90	$ME \to USER$	Display " <abort>"</abort>	
		Play a ME Error / Special information tone for 1 minute until user aborts this command	
91	$ME \to SIM$	TERMINAL RESPONSE: PLAY TONE 1.1.15	[Proactive SIM session terminated by the user]
92	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
93	$SIM \to ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.16	
94	$ME \to SIM$	FETCH	

Step	Direction	MESSAGE / Action	Comments
95	$SIM \to ME$	PROACTIVE COMMAND: PLAY	[No alpha identifier, no tone tag, no duration
		TONE 1.1.16	tag]
96	$ME \to User$	ME plays general beep, or if not	[ME uses default duration defined by
		supported any (defined by ME- manufacturer) other supported tone	ME-manufacturer]
97	$ME \to SIM$	TERMINAL RESPONSE: PLAY TONE 1.1.16	[Command performed successfully], [ME uses general beep, or if not supported any (defined by ME-manufacturer) other supported tone, uses default duration defined by ME-manufacturer]
98	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

## PROACTIVE COMMAND: PLAY TONE 1.1.1

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
	09	44	69	61	6C	20	54	6F	6E	65	8E	01
	01	84	02	01	05							

# PROACTIVE COMMAND: PLAY TONE 1.1.2

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Sub. Busy"

Tone: Standard supervisory tones: called subscriber busy

Duration

Time unit: Seconds
Time interval: 5

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
	09	53	75	62	2E	20	42	75	73	79	8E	01
	02	84	02	01	05							

## PROACTIVE COMMAND: PLAY TONE 1.1.3

## Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Congestion"

Tone: Standard supervisory tones: congestion

Duration

Time unit: Seconds
Time interval: 5

## Coding:

BER-TLV:	D0	1C	81	03	01	20	00	82	02	81	03	85
	0A	43	6F	6E	67	65	73	74	69	6F	6E	8E
	01	03	84	02	01	05						

## PROACTIVE COMMAND: PLAY TONE 1.1.4

# Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece
Alpha identifier: "RP Ack"

Tone: Standard supervisory tones: radio path acknowledge

Duration

Time unit: Seconds
Time interval: 5

## Coding:

BER-TLV:	D0	18	81	03	01	20	00	82	02	81	03	85
-	06	52	50	20	41	63	6B	8E	01	04	84	02
	01	05										

## PROACTIVE COMMAND: PLAY TONE 1.1.5

# Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "No RP"

Tone: Standard supervisory tones: radio path not available

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV:	D0	17	81	03	01	20	00	82	02	81	03	85
	05	4E	6F	20	52	50	8E	01	05	84	02	01
	05											

# PROACTIVE COMMAND: PLAY TONE 1.1.6

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece

Alpha identifier: "Spec Info"

Tone: Standard supervisory tones: Error/ special information

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
	09	53	70	65	63	20	49	6E	66	6F	8E	01
	06	84	02	01	05							

# PROACTIVE COMMAND: PLAY TONE 1.1.7

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece

Alpha identifier: "Call Wait"

Tone: Standard supervisory tones: call waiting tone

Duration

Time unit: Seconds
Time interval: 5

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
•	09	43	61	6C	6C	20	57	61	69	74	8E	01
	07	84	02	01	05							

## PROACTIVE COMMAND: PLAY TONE 1.1.8

## Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Ring Tone"

Tone: Standard supervisory tones: ringing tone

Duration

Time unit: Seconds
Time interval: 5

## Coding:

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
	09	52	69	6E	67	20	54	6F	6E	65	8E	01
	08	84	02	01	05							

## PROACTIVE COMMAND: PLAY TONE 1.1.9

## Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Earpiece

Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

## Coding:

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
_	09	44	69	61	6C	20	54	6F	6E	65	8E	01
	01	84	02	01	05							

## PROACTIVE COMMAND: PLAY TONE 1.1.10

# Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece

Alpha identifier: "This command instructs the ME to play an audio tone. Upon receiving this

command, the ME shall check if it is currently in, or in the process of setting up (SET-UP message sent to the network, see GSM"04.08"(8)), a speech call. - If the

ME I"

BER-TLV:	D0	81	FD	81	03	01	20	00	82	02	81	03
DEK-ILV.										_		
	85	81	F1	54	68	69	73	20	63	6F	6D	6D
	61	6E	64	20	69	6E	73	74	72	75	63	74
	73	20	74	68	65	20	4D	45	20	74	6F	20
	70	6C	61	79	20	61	6E	20	61	75	64	69
	6F	20	74	6F	6E	65	2E	20	55	70	6F	6E
	20	72	65	63	65	69	76	69	6E	67	20	74
	68	69	73	20	63	6F	6D	6D	61	6E	64	2C
	20	74	68	65	20	4D	45	20	73	68	61	6C
	6C	20	63	68	65	63	6B	20	69	66	20	69
	74	20	69	73	20	63	75	72	72	65	6E	74
	6C	79	20	69	6E	2C	20	6F	72	20	69	6E
	20	74	68	65	20	70	72	6F	63	65	73	73
	20	6F	66	20	73	65	74	74	69	6E	67	20
	75	70	20	28	53	45	54	2D	55	50	20	6D
	65	73	73	61	67	65	20	73	65	6E	74	20
	74	6F	20	74	68	65	20	6E	65	74	77	6F
	72	6B	2C	20	73	65	65	20	47	53	4D	22
	30	34	2E	30	38	22	28	38	29	29	2C	20
	61	20	73	70	65	65	63	68	20	63	61	6C
	6C	2E	20	2D	20	49	66	20	74	68	65	20
	4D	45	20	49								

## PROACTIVE COMMAND: PLAY TONE 1.1.11

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Beep"

Tone: ME proprietary tones: general beep

Duration

Time unit: Seconds
Time interval: 1

Coding:

BER-TLV:	D0	16	81	03	01	20	00	82	02	81	03	85
	04	42	65	65	70	8E	01	10	84	02	01	01

# PROACTIVE COMMAND: PLAY TONE 1.1.12

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Positive"

Tone: ME proprietary tones: positive acknowledgement tone

Duration

Time unit: Seconds
Time interval: 1

Coding:

BER-TLV:	D0	1A	81	03	01	20	00	82	02	81	03	85
	08	50	6F	73	69	74	69	76	65	8E	01	11
	84	02	01	01								

# PROACTIVE COMMAND: PLAY TONE 1.1.13

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Negative"

Tone: ME proprietary tones: negative acknowledgement tone

Duration

Time unit: Seconds
Time interval: 1

Coding:

BER-TLV:	D0	1A	81	03	01	20	00	82	02	81	03	85
·	80	4E	65	67	61	74	69	76	65	8E	01	12
	84	02	01	01								

# PROACTIVE COMMAND: PLAY TONE 1.1.14

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Quick"

Tone: ME proprietary tones: general beep

Duration

Time unit: Tenths of seconds

Time interval: 2

BER-TLV:	D0	17	81	03	01	20	00	82	02	81	03	85
•	05	51	75	69	63	6B	8E	01	10	84	02	02
	02											

PROACTIVE COMMAND: PLAY TONE 1.1.15

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "<ABORT>"

Tone: Standard supervisory tones: Error / Special information

Duration

Time unit: Minutes
Time interval: 1

Coding:

BER-TLV:	D0	19	81	03	01	20	00	82	02	81	03	85
	07	3C	41	42	4F	52	54	3E	8E	01	06	84
	02	00	01									

PROACTIVE COMMAND: PLAY TONE 1.1.16

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece

Coding:

BER-TLV:	D0	09	81	03	01	20	00	82	02	81	03	
·												

TERMINAL RESPONSE: PLAY TONE 1.1.1 ... 1.1.9, 1.1.16

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

							00					
BER-TLV:	l 81	03	l 01	20	00	82	02	82	l 81	l 83	l 01	00

TERMINAL RESPONSE: PLAY TONE 1.1.10a ... 1.1.14a

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: PLAY TONE 1.1.10b ..1.1.14b

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command beyond ME's capabilities

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 30

**TERMINAL RESPONSE: PLAY TONE 1.1.15** 

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by user

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 10

27.22.4.5.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

# 27.22.4.6 POLL INTERVAL

# 27.22.4.6.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.6.2 Conformance requirement

The ME shall support the POLL INTERVAL command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.6, clause 6.6.6, clause 5.2, clause 12.6, clause 12.7 and clause 12.8.

## 27.22.4.6.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the POLL INTERVAL proactive SIM command.

To verify that the ME gives a valid response to the polling interval requested by the SIM.

To verify that the ME sends STATUS commands to the SIM at an interval no longer than the interval negotiated by the SIM.

## 27.22.4.6.4 Method of test

## 27.22.4.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.6.4.2 Procedure

## **Expected Sequence 1.1 (POLL INTERVAL, Seconds)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POLL INTERVAL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: POLL	[Duration: 20 seconds]
		INTERVAL 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: POLL	[Command performed successfully]
		INTERVAL 1.1.1	
5	ME	ME polls in intervals of 20 seconds	

## PROACTIVE COMMAND: POLL INTERVAL 1.1.1

## Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Duration

Time unit: Seconds
Time interval: 20

BER-TLV:	D0	0D	81	03	01	03	00	82	02	81	82	84
	02	01	14									

TERMINAL RESPONSE: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Seconds
Time interval: 20

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	84	02	01	14								

## 27.22.4.6.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

## 27.22.4.7 REFRESH

# 27.22.4.7.1 REFRESH (normal)

## 27.22.4.7.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.7.1.2 Conformance requirement

The ME shall support the REFRESH command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.7, clause 6.6.13, clause 5.2, clause 12.6, clause 12.7 and clause 12.18.

## 27.22.4.7.1.3 Test purpose

To verify that the ME performs the SIM initialization and / or re-reads the contents and structure of the EFs on the SIM that have been changed and / or restarts the card session by resetting the ME, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

## 27.22.4.7.1.4 Method of test

#### 27.22.4.7.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files for the second SIM Simulator are coded as SIM Application Toolkit default with the following exceptions.

# EF<sub>FDN</sub> (Fixed Dialling Numbers)

## Logically:

## At least 10 records

Record 1:

Length of alpha identifier: 32 characters Alpha identifier: "ABC" Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 123
CCI: None
Ext2: None

Coding:	B1	B2	В3	B4	 B32	B33	B34	B35	B36	B37	 B46	l
Record 1:	41	42	43	FF	 FF	03	81	21	F3	FF	 FF	

Record 2:

Length of alpha identifier: 32 characters Alpha identifier: "DEF" Length of BCD number: "04"

TON and NPI: Telephony and Unknown

Dialled number: 9876 CCI: None Ext2: None

Coding:	B1	B2	B3	B4	 B32	B33	B34	B35	B36	B37	 B46
Record 1:	44	45	46	FF	 FF	03	81	89	67	FF	 FF

## 27.22.4.7.1.4.2 Procedure

# **Expected Sequence 1.1 (REFRESH, SIM Initialization)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
_		PENDING: REFRESH 1.1.1	
2	/	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: REFRESH 1.1.1	
4	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
5	$ME \rightarrow SIM$	SIM Initialization	[ME performs SIM initialization]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE:	
		Or	
		TERMINAL RESPONSE: REFRESH 1.1.1B	[additional EFs read]
7	$SIM \to ME$	PROACTIVE SIM SESSION	
8	USER → ME		
9		Call set up not allowed	
10	$USER \to ME$	Call setup to "123"	
11	$ME \to SS$	Setup	Called party BCD number shall be "123"
			·

PROACTIVE COMMAND: REFRESH 1.1.1

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 01 03 82 02 81 82

TERMINAL RESPONSE: REFRESH 1.1.1A

Logically:

Command details

Command number:

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 00

TERMINAL RESPONSE: REFRESH 1.1.1B

Logically:

Command details

Command number:

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 03

# **Expected Sequence 1.2 (REFRESH, File Change Notification)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: REFRESH 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: REFRESH 1.2.1	
4	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
5	SIM	Update EF FDN RECORD 1	[EF FDN record 1 updated to contain the dialling string "0123456789"]
6	$ME \rightarrow SIM$	READ RECORD: EF FDN	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 1.2.1A Or	[normal ending]
		TERMINAL RESPONSE: REFRESH 1.2.1B	[additional EFs read]
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	$USER \to ME$	Call setup to "123"	
10	$ME \rightarrow USER$	Call set up not allowed	
11	$USER \to ME$	Call setup to "0123456789"	
12	$ME \rightarrow SS$	Setup	Called party BCD number shall be "0123456789"

# PROACTIVE COMMAND: REFRESH 1.2.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: SIM
Destination device: ME
File List: EF FDN

Coding:

BER-TLV:	D0	12	81	03	01	01	01	82	02	81	82	92
	07	01	3F	00	7F	10	6F	3B				

TERMINAL RESPONSE: REFRESH 1.2.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	01	01	82	02	82	81	83	01	00
DEIX IEV.	0.	00		0.		02	02	02		00		00

TERMINAL RESPONSE: REFRESH 1.2.1B

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 01 82 02 82 81 83 01 03

## **Expected Sequence 1.3 (REFRESH, SIM Initialization and File Change Notification)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: REFRESH 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		REFRESH 1.3.1	
4	SIM	Update EF PLMN	[EF PLMN to contain the PLMN code "98798" as the first PLMN code]
5	$ME \to SIM$	READ BINARY: EF PLMN	
6	$ME \to SIM$	TERMINAL RESPONSE: REFRESH 1.3.1A Or	[normal ending]
7	$SIM \to ME$	TERMINAL RESPONSE: REFRESH 1.3.1B PROACTIVE SIM SESSION ENDED	[additional EFs read]

PROACTIVE COMMAND: REFRESH 1.3.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: SIM
Destination device: ME
File List: EF PLMN

## Coding:

BER-TLV:	D0	12	81	03	01	01	02	82	02	81	82	92
	07	01	3F	00	7F	20	6F	30				

TERMINAL RESPONSE: REFRESH 1.3.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:
----------

TERMINAL RESPONSE: REFRESH 1.3.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

BER-TLV:	81	03	01	01	02	82	02	82	81	83	01	03

## **Expected Sequence 1.4 (REFRESH, SIM Initialization and Full File Change Notification)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: REFRESH 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		REFRESH 1.4.1	
4	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
5	SIM	Update EF FDN	[EF FDN record 1 updated to contain the dialling string "0123456789"]
6	$ME \to SIM$	SIM Initialization	[ME performs SIM initialization]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 1.4.1A Or	
		TERMINAL RESPONSE: REFRESH 1.4.1B	[additional EFs read]
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
9	$USER \to ME$	Call setup to "321"	
10	$ME \rightarrow USER$	Call set up not allowed	
11	$USER \to ME$	Call setup to "0123456789"	
12	$ME \rightarrow SS$	Setup	Called party BCD number shall be "0123456789"

## PROACTIVE COMMAND: REFRESH 1.4.1A

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialization and Full File Change Notification

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	01	00	82	02	81	82	
----------	----	----	----	----	----	----	----	----	----	----	----	--

## TERMINAL RESPONSE: REFRESH 1.4.1A

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	01	03	01	01	00	02	02	0.2	01	02	Λ1	00
DEK-ILV.	01	US	UI	UI	UU	02	02	02	01	ೲ	UI	UU

TERMINAL RESPONSE: REFRESH 1.4.1B

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME
Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV:	81	03	01	01	00	82	02	82	81	83	01	03
DEIX-IEV.	01	03	01	O I	00	02	02	02	01	00	01	03

## **Expected Sequence 1.5 (REFRESH, SIM Reset)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: REFRESH 1.5.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		REFRESH 1.5.1	
4	$ME \to SIM$	GSM Termination Procedure	
5	$ME \to SIM$	GSM Activation Procedure	[At same voltage]
6	$ME \to SIM$	SIM Initialization	
7	$ME \to SIM$		[NO TERMINAL RESPONSE]

PROACTIVE COMMAND: REFRESH 1.5.1

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Reset

Device identities

Source device: SIM Destination device: ME

RFR-TI V·	DO	09	81	03	01	01	04	82	02	81	82	

## Expected Sequence 1.6 (REFRESH, SIM Initialization after SMS-PP data download)

Step	Direction	MESSAGE / Action	Comments
1	ME	The ME shall be in its normal idle mode	[Start a sequence to verify that the ME returns the RP-ACK message back to the system Simulator, if the SIM responds with '90 00']
2	$SS \to ME$	SMS-PP Data Download Message 1.6.1	
3	$ME \to USER$	The ME shall not display the message or alert the user of a short message waiting	
4	$ME \to SIM$	ENVELOPE: SMS-PP DOWNLOAD 1.6.1	
5	$SIM \to ME$	PROACTIVE COMMAND PENDING: REFRESH 1.1.1	
6	$ME \to SS$	RP-ACK	
7	$ME \to SIM$	FETCH	
8	$SIM \to ME$	PROACTIVE COMMAND: REFRESH 1.1.1	
9	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
10	$ME \to SIM$	SIM Initialization	[ME performs SIM initialization]
11	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 1.1.1A Or	
		TERMINAL RESPONSE:	[additional EFs read]
12	$SIM \to ME$	REFRESH 1.1.1B PROACTIVE SIM SESSION ENDED	
13	$USER \to ME$	Call setup to "321"	
14	$ME \to USER$	Call set up not allowed	
15	$USER \to ME$	Call setup to "123"	
16	$ME \to SS$	Setup	Called party BCD number shall be "123"

#### SMS-PP (Data Download) Message 1.6.1

#### Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

BER-TLV	04	03	91	21	43	7F	12	89	10	10	00	00
	00	00	0D	53	F4	5B	4E	07	35	CB	F3	79
	F8	5C	06									

#### **ENVELOPE: SMS-PP DOWNLOAD 1.6.1**

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

**SMS TPDU** 

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group
Compression
Message Class
General Data Coding
Text is uncompressed
Class 2 SIM Specific Message

Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

#### Coding:

BER-TLV:	D1	2C	82	02	83	81	06	09	91	11	22	33
	44	55	66	77	F8	8B	1B	04	04	91	21	43
	7F	12	89	10	10	00	00	00	00	0D	53	F4
	5B	4E	07	35	CB	F3	79	F8	5C	06		

## 27.22.4.7.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

## 27.22.4.7.2 REFRESH (IMSI changing procedure)

#### 27.22.4.7.2.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.7.2.2 Conformance requirement

The ME shall support the REFRESH command as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.7, clause 6.6.13, clause 5.2, clause 12.6, clause 12.7 and clause 12.18.

Additionally the ME shall support the SIM Initialization procedure as defined in:

• 3GPP TS 11.11 [13] clause 12.2.1.

#### 27.22.4.7.2.3 Test purpose

To verify that the ME performs the SIM initialization and / or re-reads the contents and structure of the EFs on the SIM that have been changed and / or restarts the card session by resetting the ME, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.7.2.4 Method of test

27.22.4.7.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files for the second SIM Simulator are coded as SIM Application Toolkit default with the following exceptions.

#### 27.22.4.7.2.4.2 Procedure

#### Expected Sequence 2.1 (REFRESH, SIM Initialization and File Change Notification)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: REFRESH 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: REFRESH 2.1.1	
4	SIM	Update EF IMSI, EF LOCI and EF KC	[Update the contents of EF IMSI to "001010123456788", EF LOCI to not updated and EF KC to not valid]
5	ME	Invoke MM Restart Procedure	
6	$ME \rightarrow SIM$	SIM INITIALIZATION	[ME performs SIM initialization; including reading EF IMSI, EF LOCI and EF KC]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 2.1.1A Or	[normal]
		TERMINAL RESPONSE: REFRESH 2.1.1B	[additional EFs read]
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
9	$ME \to SS$	Location updating request (type "normal location updating")	[Send IMSI of "001010123456788" to System Simulator]

### PROACTIVE COMMAND: REFRESH 2.1.1

#### Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: SIM Destination device: ME

File List

File 1: EF IMSI File 2: EF LOCI File 3: EF KC

Coding:

BER-TLV:	D0	1E	81	03	01	01	02	82	02	81	82	92
_	13	03	3F	00	7F	20	6F	07	3F	00	7F	20
	6F	7E	3F	00	7F	20	6F	20				

TERMINAL RESPONSE: REFRESH 2.1.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 02 82 02 82 81 83 01 00

TERMINAL RESPONSE: REFRESH 2.1.1B

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

	E	BER-TLV:	81	03	01	01	02	82	02	82	81	83	01	03
--	---	----------	----	----	----	----	----	----	----	----	----	----	----	----

## **Expected Sequence 2.2 (REFRESH, SIM Initialization and Full File Change Notification)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: REFRESH 2.2.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: REFRESH 2.2.1	
4	SIM	Update EF IMSI	[Update the contents of EF IMSI to "001010123456787", -]
5	ME	Invoke MM Restart Procedure	_
6	$ME \rightarrow SIM$	SIM INITIALIZATION	[ME performs SIM initialization; including reading EF IMSI, EF LOCI and EF KC]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 2.2.1A Or	[normal]
		TERMINAL RESPONSE: REFRESH 2.2.1B	[additional EFs read]
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	$ME \rightarrow SS$	IMSI ATTACH	[Send IMSI of "001010123456787" to System Simulator]

PROACTIVE COMMAND: REFRESH 2.2.1

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialization and Full File Change Notification

Device identities

Source device: SIM
Destination device: ME

Coding:

DED TIVE	DO	00	0.4	00	04	04	00	0.0	00	0.4	00
BER-TLV:	D0	l 09	1 81	03	01	01	00	82	1 02	181	82

TERMINAL RESPONSE: REFRESH 2.2.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	01	00	82	02	82	81	83	01	00

TERMINAL RESPONSE: REFRESH 2.2.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialization and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV:	81	03	01	01	00	82	02	82	81	83	01	03	1
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

## **Expected Sequence 2.3 (REFRESH, SIM Reset)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: REFRESH 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		REFRESH 2.3.1	
4	SIM	Update EF IMSI	[Update the contents of EF IMSI to
			"001010123456786
5	$ME \rightarrow SIM$	GSM Termination Procedure	
6	$ME \rightarrow SIM$	GSM Activation Procedure	[At same voltage]
7	$ME \rightarrow SIM$	SIM Initialization	[ME performs SIM initialization; including
			reading EF IMSI, EF LOCI and EF KC]
8	$ME \to SS$	IMSI ATTACH	[Send IMSI of "001010123456786" to System
			Simulator]

## PROACTIVE COMMAND: REFRESH 2.3.1

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Reset

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	01	04	82	02	81	82
----------	----	----	----	----	----	----	----	----	----	----	----

## 27.22.4.7.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.3.

## 27.22.4.8 SET UP MENU and ENVELOPE MENU SELECTION

## 27.22.4.8.1 SET UP MENU (normal) and ENVELOPE MENU SELECTION

## 27.22.4.8.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.8.1.2 Conformance requirement

The ME shall support the SET UP MENU command as defined in:

• 3GPP TS 11.14 clause 5, clause 6.4.8, clause 6.6.7, clause 6.8, clause 6.11, clause 12.6, clause 12.9 and clause 13.4.

The ME shall support MENU SELECTION as defined in:

• 3GPP TS 11.14 [15] clause 4.4, clause 5.2, clause 6.4.8, clause 6.9, clause 8, clause 12.7 and clause 12.10.

#### 27.22.4.8.1.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME replaces the current list of menu items with the list of menu items contained in the SET UP MENU command.

To verify that the ME removes the current list of menu items following receipt of a SET UP MENU command with no items.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

To verify that when the help is available for the command and the user gas indicated the need to get help information on one of the items, the ME informs properly the SIM about an HELP REQUEST, using the MENU SELECTION mechanism.

#### 27.22.4.8.1.4 Method of test

#### 27.22.4.8.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.8.1.4.2 Procedure

# Expected Sequence 1.1 (SET UP MENU and MENU SELECTION, without Help Request, Replace and Remove a Toolkit Menu)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND SET UP	
		MENU 1.1.1	
4	$ME \rightarrow USER$	Integrate the menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items	
		of "Item 1", "Item 2", "Item 3" and "Item 4" under this header.	
5	ME  o SIM	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
	IVIE -> SIIVI	MENU 1.1.1	[Continuation enormed odecessiony]
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
	0 / <u></u>	ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit	
/		Menu"	
8	$ME \rightarrow USER$	Display "Item 1", "Item 2", "Item 3",	
		"Item 4"	
9	$USER \to ME$	Select the "Item 2" Menu entry	
4.0	$ME \rightarrow SIM$	Send the ENVELOPE 1.1.1:	
10		MENU SELECTION	
11	CIM . ME	(Identifier of item: 2) PROACTIVE COMMAND	[Second Set Up Menu, REPLACE Old Menu]
11	$SIM \rightarrow ME$	PENDING: SET UP MENU 1.1.2	[Second Set of Mend, KEFLACE Old Mend]
12	$ME \to SIM$	FETCH	
13	SIM → ME	PROACTIVE COMMAND SET UP	
	0 / <u></u>	MENU 1.1.2	
14	$ME \to USER$	Integrate the new menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items	
		of "One" and "Two" under this	
4.5	145 0114	header.	[Oarrana and Danfarrana d Oarrana and dhal
15	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 1.1.2	[Command Performed Successfully]
16	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
10	SIIVI -> IVIE	ENDED	
	$USER \to ME$	Select the Toolkit Menu "Toolkit	
17	OOLIK 7 IIIL	Menu"	
18	$ME \to USER$	Display "One", "Two"	
19	$USER \to ME$	Select the "Two" menu entry	
	$ME \rightarrow SIM$	Send the ENVELOPE 1.1.2:	
20		MENU SELECTION	
6.4		(Identifier of item: 12)	THE LOCAL MAN DELICATE THE STATE OF
21	$SIM \rightarrow ME$	PROACTIVE COMMAND	[Third Set Up Menu, REMOVE Toolkit Menu]
		PENDING: SET UP MENU 1.1.3 with SW1 / SW2 of '91 0F'.	
22	ME  o SIM	FETCH	
23	$SIM \rightarrow SIM$	PROACTIVE COMMAND SET UP	
	Olivi — IVIL	MENU 1.1.3	
24	$ME \rightarrow USER$	Remove the menu "Toolkit Menu"	
		from its menu system.	
25	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
		MENU 1.1.3	
26	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
07		ENDED	
27	$USER \to ME$	Has to unsuccessfully find the	
		Toolkit Menu	

#### PROACTIVE COMMAND: SET UP MENU 1.1.1

#### Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

#### Coding:

BER-TLV:	D0	3B	81	03	01	25	00	82	02	81	82	85
'-	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	8F	07	04	49	74	65	6D	20
	34											_

## PROACTIVE COMMAND: SET UP MENU 1.1.2

## Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: "11"
Text string of item: "One"

Item

Identifier of item: "12" Text string of item: "Two"

BER-TLV:	D0	23	81	03	01	25	00	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	04	11	4F	6E	65	8F	04	12	54	77
	6F											

PROACTIVE COMMAND: SET UP MENU 1.1.3

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME
Item: Empty

Coding:

BER-TLV:	D0	0D	81	03	01	25	00	82	02	81	82	85
·	00	8F	00									

#### TERMINAL RESPONSE: SET UP MENU 1.1.1, 1.1.2 and 1.1.3

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	25	00	82	02	82	81	83	01	00

## **ENVELOPE 1.1.1: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 02

Coding:

BER-TLV:	D3	07	82	02	01	81	90	01	02	I
----------	----	----	----	----	----	----	----	----	----	---

## **ENVELOPE 1.1.2: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 12 Coding:

BER-TLV:	D3	07	82	02	01	81	90	01	12

# Expected Sequence 1.2 (SET UP MENU, Large Menu with many items or with large items or with Large Alpha Identifier)

Step	Direction	MESSAGE / Action	Comments					
1	$SIM \to ME$	PROACTIVE COMMAND	[First Large Menu with many items, Fetch of					
	NAT 01NA	PENDING: SET UP MENU 1.2.1	FF bytes]					
2 3	ME  o SIM $SIM  o ME$	FETCH PROACTIVE COMMAND SET UP						
3	SIIVI → IVIE	MENU 1.2.1						
4	$ME \to USER$	Integrate the new menu header of						
		"LargeMenu1" into its menu						
		system and have the menu items						
		of "Zero", "One", "Two", Three", "Four", "Five", "Six", "Seven",						
		"Eight", "Nine", "Alpha", "Bravo",						
		"Charlie", "Delta", "Echo", "Fox-						
		trot", "Black", "Brown", "Red",						
		"Orange", "Yellow", "Green",						
		"Blue", "Violet", "Grey", "White", "milli", "micro", "nano" and "pico"						
		under this header.						
5	$ME \to SIM$	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]					
		MENU 1.2.1						
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED						
7	$USER \to ME$	Select the Toolkit "LargeMenu1"						
8	ME → USER	Display "Zero", "One", "Two"						
	/ 00	"pico"						
9	$USER \to ME$	Select the "Orange" menu entry						
10	$ME \to SIM$	Send the ENVELOPE 1.2.1:						
		MENU SELECTION (Identifier of item: 0x3D)						
11	$SIM \to ME$	PROACTIVE COMMAND	[Second Large Menu with large items, Fetch					
	OIIVI 7 IVIL	PENDING: SET UP MENU 1.2.2	of F6 bytes]					
12	$ME \to SIM$	FETCH						
13	$SIM \to ME$	PROACTIVE COMMAND SET UP						
14	$ME \to USER$	MENU 1.2.2 Integrate the new menu header of						
''	WE 7 OOLK	"LargeMenu2" into its menu						
		system and have the menu items						
		of "1 Call Forward Unconditional",						
		"2 Call Forward On User Busy", "3 Call Forward On No Reply", "4 Call						
		Forward On User Not Reachable",						
		"5 Barring Of All Outgoing Calls",						
		"6 Barring Of All Outgoing Int						
		Calls" and "7 CLI Presentation"						
15	$ME \rightarrow SIM$	under this header. TERMINAL RESPONSE: SET UP	[Command Performed Successfully]					
	IVIL / OIIVI	MENU 1.2.2	La community of the com					
16	$SIM \to ME$	PROACTIVE SIM SESSION						
47	LICED ME	ENDED						
17	$USER \to ME$	Select the Toolkit Menu "LargeMenu2"						
18	$ME \to USER$	Display "1 Call Forward						
	/ 552.1	Unconditional", "2 Call Forward On						
		User Busy", "3 Call Forward On No						
		Reply", "4 Call Forward On User						
		Not Reachable", "5 Barring Of All Outgoing Calls", "6 Barring Of All						
		Outgoing Calls, 6 Barring Of All Outgoing Int Calls", "7 CLI						
		Presentation"						

Step	Direction	MESSAGE / Action	Comments
19	$USER \to ME$	Select the "5 Barring Of All	
		Outgoing Calls" menu entry	
20	$ME \rightarrow SIM$	Send the ENVELOPE 1.2.2:	
		MENU SELECTION	
0.4		(Identifier of item: 0xFB)	FT1: 11 A4 ::1 A 1 1
21	$SIM \to ME$	PROACTIVE COMMAND	[Third Large Menu with a Large Alpha
		PENDING: SET UP MENU 1.2.3	Identifier and only one Short Item, Fetch of FF
22	ME CIM	FETCH	bytes]
23	ME  o SIM $SIM  o ME$	PROACTIVE COMMAND SET UP	
23	SIIVI → IVIE	MENU 1.2.3	
24	$ME \to USER$	Integrate the new menu header of	
	WIL → USLIX	" The SIM shall supply a set of	
		menu items, which shall be	
		integrated with the menu system	
		(or other MMI facility) in order to	
		give the user the opportunity to	
		choose one of these menu items at	
		his own discretion. Each item	
		comprises a sh" into it's menu	
		system and have a menu item of	
0.5		"Y" under this header.	10 10 ( 10
25	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 1.2.3	[Command Performed Successfully]
26	$SIM \to ME$	PROACTIVE SIM SESSION	
	OIM / MIL	ENDED	
27	$USER \to ME$	Select the Toolkit Menu "The SIM	
		shall supply a set of menu items,	
		which shall be integrated with the	
		menu system (or other MMI	
		facility) in order to give the user the	
		opportunity to choose one of these	
		menu items at his own discretion.	
28	ME LICED	Each item comprises a sh".	
28	ME → USER	Display "Y"	
30	USER → ME	Select the item "Y" Send the ENVELOPE 1.1.6:	
30	$ME \rightarrow SIM$	MENU SELECTION	
		(Identifier of item: 1)	
		Ridentinei oi item. 1)	

## PROACTIVE COMMAND: SET UP MENU 1.2.1

## Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "LargeMenu1"

Item

Identifier of item: "50" Text string of item: "Zero"

Item

Identifier of item: "4F"
Text string of item: "One"

Item

Identifier of item: "4E" Text string of item: "Two"

Item		
100111	Identifier of item:	"4D"
	Text string of item:	"Three"
Item	10.11 04.1119 01 1101111	111100
100111	Identifier of item:	"4C"
	Text string of item:	"Four"
Item	Text string of item.	1 our
110111	Identifier of item:	"4B"
	Text string of item:	"Five"
Item	Text string of items	1110
rtem	Identifier of item:	"4A"
	Text string of item:	"Six"
Item	Text string of item.	DIA
Item	Identifier of item:	"49"
	Text string of item:	"Seven"
Item	Text string of item.	Seven
пеш	Identifier of item:	"48"
Itam	Text string of item:	"Eight"
Item	T.1	" 47"
	Identifier of item:	"47"
<b>.</b>	Text string of item:	"Nine"
Item	7.4 1.71 0.1	
	Identifier of item:	"46"
	Text string of item:	"Alpha"
Item		
	Identifier of item:	"45"
	Text string of item:	"Bravo"
Item		
	Identifier of item:	"44"
	Text string of item:	"Charlie"
Item		
	Identifier of item:	"43"
	Text string of item:	"Delta"
Item	•	
	Identifier of item:	"42"
	Text string of item:	"Echo"
Item	C	
	Identifier of item:	"41"
	Text string of item:	"Fox-trot"
Item		3.2 3.00
	Identifier of item:	"40"
	Text string of item:	"Black"
Item	- July Stating Of Holli.	
100111	Identifier of item:	"3F"
	Text string of item:	"Brown"
Item	Text builty of Itelli.	DIOMII
пеш	Identifier of item:	"3E"
		"Red"
Item	Text string of item:	Neu
пеш	Identifier of item:	"2D"
		"3D"
τ.	Text string of item:	"Orange"
Item	T.1 (10) C.1.	"20"
	Identifier of item:	"3C"
<b>T</b> .	Text string of item:	"Yellow"
Item	Text string of item:	"Yellow"
Item	Text string of item:  Identifier of item:	"Yellow" "3B"
	Text string of item:	"Yellow"
Item Item	Text string of item:  Identifier of item:	"Yellow" "3B"

Text string of item:

"Blue"

Item

"39" Identifier of item:

"Violet" Text string of item:

Item

"38" Identifier of item:

Text string of item: "Grey"

Item

Identifier of item: "37"

"White" Text string of item:

Item

Identifier of item: "36" Text string of item: "milli"

Item

"35" Identifier of item:

Text string of item: "micro"

Item

"34" Identifier of item:

Text string of item: "nano"

Item

"33" Identifier of item: "pico" Text string of item:

## Coding:

BER-TLV:	D0	81	FC	81	03	01	25	00	82	02	81	82
	85	0A	4C	61	72	67	65	4D	65	6E	75	31
	8F	05	50	5A	65	72	6F	8F	04	4F	4F	6E
	65	8F	04	4E	54	77	6F	8F	06	4D	54	68
	72	65	65	8F	05	4C	46	6F	75	72	8F	05
	4B	46	69	76	65	8F	04	4A	53	69	78	8F
	06	49	53	65	76	65	6E	8F	06	48	45	69
	67	68	74	8F	05	47	4E	69	6E	65	8F	06
	46	41	6C	70	68	61	8F	06	45	42	72	61
	76	6F	8F	08	44	43	68	61	72	6C	69	65
	8F	06	43	44	65	6C	74	61	8F	05	42	45
	63	68	6F	8F	09	41	46	6F	78	2D	74	72
	6F	74	8F	06	40	42	6C	61	63	6B	8F	06
	3F	42	72	6F	77	6E	8F	04	3E	52	65	64
	8F	07	3D	4F	72	61	6E	67	65	8F	07	3C
	59	65	6C	6C	6F	77	8F	06	3B	47	72	65
	65	6E	8F	05	3A	42	6C	75	65	8F	07	39
	56	69	6F	6C	65	74	8F	05	38	47	72	65
	79	8F	06	37	57	68	69	74	65	8F	06	36
	6D	69	6C	6C	69	8F	06	35	6D	69	63	72
	6F	8F	05	34	6E	61	6E	6F	8F	05	33	70
	69	63	6F									

PROACTIVE COMMAND: SET UP MENU 1.2.2

Logically:

Command details

Command number:

SET UP MENU Command type:

Command qualifier: "00"

Device identities

SIM Source device: Destination device: ME

Alpha Identifier: "LargeMenu2"

Item

Identifier of item:

Text string of item: "1 Call Forward Unconditional" Item

Identifier of item: "FE"

Text string of item: "2 Call Forward On User Busy"

Item

Identifier of item: "FD"

Text string of item: "3 Call Forward On No Reply"

Item

Identifier of item: "FC"

Text string of item: "4 Call Forward On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "5 Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "6 Barring Of All Outgoing Int Calls"

Item

Identifier of item: "F9"

Text string of item: "7 CLI Presentation"

#### Coding:

DED TIVE	Ι ΒΛ	0.4	ГΩ	0.4	00	04	25	00	00	00	0.4	00
BER-TLV:	D0	81	F3	81	03	01	25	00	82	02	81	82
	85	0A	4C	61	72	67	65	4D	65	6E	75	32
	8F	1D	FF	31	20	43	61	6C	6C	20	46	6F
	72	77	61	72	64	20	55	6E	63	6F	6E	64
	69	74	69	6F	6E	61	6C	8F	1C	FE	32	20
	43	61	6C	6C	20	46	6F	72	77	61	72	64
	20	4F	6E	20	55	73	65	72	20	42	75	73
	79	8F	1B	FD	33	20	43	61	6C	6C	20	46
	6F	72	77	61	72	64	20	4F	6E	20	4E	6F
	20	52	65	70	6C	79	8F	25	FC	34	20	43
	61	6C	6C	20	46	6F	72	77	61	72	64	20
	4F	6E	20	55	73	65	72	20	4E	6F	74	20
	52	65	61	63	68	61	62	6C	65	8F	20	FB
	35	20	42	61	72	72	69	6E	67	20	4F	66
	20	41	6C	6C	20	4F	75	74	67	6F	69	6E
	67	20	43	61	6C	6C	73	8F	24	FA	36	20
	42	61	72	72	69	6E	67	20	4F	66	20	41
	6C	6C	20	4F	75	74	67	6F	69	6E	67	20
	49	6E	74	20	43	61	6C	6C	73	8F	13	F9
	37	20	43	4C	49	20	50	72	65	73	65	6E
	74	61	74	69	6F	6E						

## PROACTIVE COMMAND: SET UP MENU 1.2.3

#### Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha Identifier: "The SIM shall supply a set of menu items, which shall be integrated with the menu

system (or other MMI facility) in order to give the user the opportunity to choose

one of these menu items at his own discretion. Each item comprises a sh"

Item

Identifier of item: "01" Text string of item: "Y"

## Coding:

	1											
BER-TLV:	D0	81	FC	81	03	01	25	00	82	02	81	82
	85	81	EC	54	68	65	20	53	49	4D	20	73
	68	61	6C	6C	20	73	75	70	70	6C	79	20
	61	20	73	65	74	20	6F	66	20	6D	65	6E
	75	20	69	74	65	6D	73	2C	20	77	68	69
	63	68	20	73	68	61	6C	6C	20	62	65	20
	69	6E	74	65	67	72	61	74	65	64	20	77
	69	74	68	20	74	68	65	20	6D	65	6E	75
	20	73	79	73	74	65	6D	20	28	6F	72	20
	6F	74	68	65	72	20	4D	4D	49	20	66	61
	63	69	6C	69	74	79	29	20	69	6E	20	6F
	72	64	65	72	20	74	6F	20	67	69	76	65
	20	74	68	65	20	75	73	65	72	20	74	68
	65	20	6F	70	70	6F	72	74	75	6E	69	74
	79	20	74	6F	20	63	68	6F	6F	73	65	20
	6F	6E	65	20	6F	66	20	74	68	65	73	65
	20	6D	65	6E	75	20	69	74	65	6D	73	20
	61	74	20	68	69	73	20	6F	77	6E	20	64
	69	73	63	72	65	74	69	6F	6E	2E	20	45
	61	63	68	20	69	74	65	6D	20	63	6F	6D
	70	72	69	73	65	73	20	61	20	73	68	8F
	02	01	59									
				1	1	1	1	·	1	·	1	

TERMINAL RESPONSE: SET UP MENU 1.2.1, 1.2.2 and 1.2.3

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	25	00	82	02	82	81	83	01	00
----------	----	----	----	----	----	----	----	----	----	----	----	----

## **ENVELOPE 1.2.1: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 3D

BFR-TLV:	D3	07	92	02	Ω1	81	90	01	ЗD
IDENTILV.	1.70		1 02	I UZ			90		เอย

#### **ENVELOPE 1.2.2: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier FB

Coding:

BER-TLV:	D3	07	82	02	01	81	90	01	FB

#### **ENVELOPE 1.2.3: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 01

Coding:

BER-TLV:	D3	07	82	02	01	81	90	01	01

The following table details the test requirements with relation to the tested features:

	Proactive S	IM Command	Facilities
Proactive SIM Command Number	Alpha Identifier Length	Number of items	Maximum length of item
1.1.1	12	4	6
1.1.2	12	2	3
1.1.3	10	0	-
1.2.1	10	30	8
1.2.2	10	7	37
1.2.3	235	1	1

#### 27.22.4.8.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1 and in expected sequence 2.

## 27.22.4.8.2 SET UP MENU (help request support) and ENVELOPE MENU SELECTION

27.22.4.8.2.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.8.2.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1, with an additional one:

• 3GPP TS 11.14 [15] clause 12.21.

#### 27.22.4.8.2.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that when the help is available for the command and the user has indicated the need to get help information on one of the items, the ME informs properly the SIM about an HELP REQUEST, using the MENU SELECTION mechanism.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.2.4 Method of test

27.22.4.8.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.8.2.4.2 Procedure

## Expected Sequence 2.1 (SET UP MENU and MENU SELECTION, with Help Request, Replace and Remove a Toolkit Menu)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP	
		MENU 2.1.1	
4	$ME \rightarrow USER$	Integrate the menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items of "Item 1", "Item 2", "Item 3" and	
		"Item 4" under this header.	
5	$ME \rightarrow SIM$		[Command Performed Successfully]
	INIE 7 OIIVI	MENU 2.1.1	[Command Command Cacceconally]
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit	
		Menu"	
8	$ME \rightarrow USER$	, , , , , , , , , , , , , , , , , , , ,	
		"Item 4"	
9	$USER \to ME$	Select the Help Request on	
10	ME SIM	"Item 2" Menu entry Send the ENVELOPE 2.1.1:	
10	$ME \rightarrow SIM$	MENU SELECTION	
		(Identifier of item: 2)	

#### PROACTIVE COMMAND: SET UP MENU 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "80"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item:4

Text string of item: "Item 4"

## Coding:

BER-TLV:	D0	3B	81	03	01	25	80	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	8F	07	04	49	74	65	6D	20
	34											

## TERMINAL RESPONSE: SET UP MENU 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03	01 25	80 82	02 82	81	83	01	00
----------------	-------	-------	-------	----	----	----	----

## **ENVELOPE 2.1.1: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad Destination device: SIM Item identifier 02

Help request tag

Coding:

BER-TLV: D3 09 82	02 01	81 90	01	02	15	00
-------------------	-------	-------	----	----	----	----

## 27.22.4.8.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

## 27.22.4.8.3 SET UP MENU (next action support) and ENVELOPE MENU SELECTION

#### 27.22.4.8.3.1 Definition and applicability

See clause 3.2.2.

If the SIM provides an Items Next Action Indicator data object, the comprehension required flag shall be set to '0'.

#### 27.22.4.8.3.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1, with an additional one:

• 3GPP TS 11.14 [15] clause 12.24.

#### 27.22.4.8.3.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the next action indicator is supported.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

#### 27.22.4.8.3.4 Method of test

#### 27.22.4.8.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.8.3.4.2 Procedure

## Expected Sequence 3.1 (SET UP MENU, next action indicator "Send SM", "Set Up Call", "Launch Browser", "Provide Local Information", successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 3.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND SET UP MENU 3.1.1	
4	$ME \to USER$	Integrate the menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items	
		of "Item 1", "Item 2", "Item 3" and	
_		"Item 4" under this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
	0114 145	MENU 3.1.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit	
'	USER → IVIE	Menu"	
8	$ME \rightarrow USER$	Display "Item 1", "Item 2", "Item 3",	The ME may indicate to the user the
	WIE 7 OOEK	"Item 4"	consequences of performing the selection of
			an item.
9	$USER \to ME$	Navigate in the items, then select	The ME may indicate to the user the
		"Item 2".	consequences of performing the selection of
			an item.
10	$ME \to SIM$	Send the ENVELOPE 3.1.1:	
		MENU SELECTION	
		(Identifier of item: 2)	

## **ENVELOPE 3.1.1: MENU SELECTION**

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 02

Coding:

BER-TLV:	D3	07	82	02	01	81	90	01	02	

## PROACTIVE COMMAND: SET UP MENU 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Items next action indicator list

List: "Send SM", "Set Up Call", "Launch Browser", "Provide Local Information"

#### Coding:

BER-TLV:	D0	41	81	03	01	25	00	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	8F	07	04	49	74	65	6D	20
	34	18	04	13	10	15	26					

TERMINAL RESPONSE: SET UP MENU 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	25	00	82	02	82	81	83	01	00

#### 27.22.4.8.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

## 27.22.4.8.4 SET UP MENU (display of icons) and ENVELOPE MENU SELECTION

27.22.4.8.4.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.8.4.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1, with an additional one:

• GSM 11.14 clause 6.5.4, 12.31 and 12.32.

#### 27.22.4.8.4.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that icons are displayed with the command Set Up Menu in the Alpha Identifier and Items Data Objects. To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.4.4 Method of test

27.22.4.8.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.8.4.4.2 Procedure

## Expected Sequence 4.1A (SET UP MENU, BASIC ICON NOT SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP	
		MENU 4.1.1	
4	$ME \rightarrow USER$	Integrate the menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items	
		of "Item 1", "Item 2", "Item 3" under this header.	
5	$ME \to SIM$	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
	IVIL 7 OIIVI	MENU 4.1.1A	[command remained educationally]
6	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit	Verify the icon is displayed with alpha id.
_		Menu"	
8	$ME \rightarrow USER$	Display "Item 1", "Item 2", "Item 3".	
9	$USER \to ME$	Navigate in the items, then select	Verify icons are displayed for each item.
4.0		"Item 2".	
10	$ME \rightarrow SIM$	Send the ENVELOPE 3.1.1:	
		MENU SELECTION	
		(Identifier of item: 2)	

## PROACTIVE COMMAND: SET UP MENU 4.1.1

#### Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3
Text string of item: "Item 3"

Icon identifier

Icon qualifier: icon is not self explanatory

Icon identifier: record 1 EF (IMG)

Item icon identifier list

Icon qualifier: icon is not self explanatory

Icon identifier list: record 5 EF (IMG), record 5 EF (IMG), record 5 EF (IMG)

Coding:

BER-TLV:	D0	3C	81	03	01	25	00	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	9E	02	01	01	9F	04	01	05
	05	05										

TERMINAL RESPONSE: SET UP MENU 4.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

DED TI \/.	01	03	Λ1	25	00	82	02	0.0	81	02	01	00
DEN-ILV.	01	03	UI	23	00	02	02	02	01	03	UI	00

## Expected Sequence 4.1B (SET UP MENU, BASIC ICON NOT SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP MENU 4.1.1	[First Set Up Menu]
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND SET UP MENU 4.1.1	
4	$ME \to USER$	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 4.1.1B	[Command performed successfully, but requested icon could not be displayed]
6	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit Menu"	No icon is displayed with alpha id.
8	$ME \to USER$	Display "Item 1", "Item 2", "Item 3".	
9	$USER \to ME$	Navigate in the items, then select "Item 2".	no icon is displayed for each item.
10	$ME \rightarrow SIM$	Send the ENVELOPE 3.1.1: MENU SELECTION (Identifier of item: 2)	

TERMINAL RESPONSE: SET UP MENU 4.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 25 00 82 02 82 81 83 01 04

## Expected Sequence 4.2A (SET UP MENU, BASIC ICON SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND SET UP	
		MENU 4.2.1	
4	$ME \rightarrow USER$	Integrate the menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items of "Item 1", "Item 2", "Item 3" under	
		this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
	IVIL 7 OIIVI	MENU 4.2.1A	[command romanned edecectary]
		_	
6	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit	Verify the icon is displayed in alpha id.
		Menu"	
8		Display "Item 1", "Item 2", "Item 3".	
9	$USER \to ME$	Navigate in the items, then select	Verify icons are displayed for each item.
40	145 0114	"Item 2".	
10	$ME \rightarrow SIM$	Send the ENVELOPE 3.1.1:	
		MENU SELECTION (Identifier of item: 2)	
		(lucillilei oi ileili. 2)	

PROACTIVE COMMAND: SET UP MENU 4.2.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier:

"Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3
Text string of item: "Item 3"

Icon identifier

Icon qualifier: icon is self explanatory Icon identifier: record 1 EF (IMG)

Item icon identifier list

Icon qualifier: icon is self explanatory

Icon identifier list: record 5 EF (IMG), record 5 EF (IMG), record 5 EF (IMG)

## Coding:

BER-TLV:	D0	3C	81	03	01	25	00	82	02	81	82	85
•	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	9E	02	00	01	9F	04	00	05
	05	05										

## TERMINAL RESPONSE: SET UP MENU 4.2.1A

## Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

#### Coding:

BER-TLV:	81	03	Λ1	25	00	82	02	82	81	83	Λ1	00
DENTILV.	01	03	UI	20	UU	02	UZ	02	01	ಂ	UI	UU

# Expected Sequence 4.2B (SET UP MENU, BASIC ICON SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP MENU 4.2.1	
4	$ME \rightarrow USER$	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under	
5	$ME \rightarrow SIM$	this header. TERMINAL RESPONSE: SET UP MENU 4.2.1B	[Command Performed Successfully]
6	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit Menu"	No icon is displayed in alpha id.
8	$ME \rightarrow USER$	Display "Item 1", "Item 2", "Item 3".	

9	$USER \to ME$	Navigate in the items, then select	no icon is displayed for each item.	
		"Item 2".		
10	$ME \rightarrow SIM$	Send the ENVELOPE 3.1.1:		
		MENU SELECTION		
		(Identifier of item: 2)		

#### TERMINAL RESPONSE: SET UP MENU 4.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV:	81	03	01	25	00	82	02	82	81	83	01	04
DEIX IEV.	0.	00	0.	20	00	02	02	02		00	0.	0.

#### 27.22.4.8.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1A to 4.2B.

## 27.22.4.8.5 SET UP MENU (soft keys support) and ENVELOPE MENU SELECTION

27.22.4.8.5.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.8.5.2 Conformance requirement

Requirements are the same as in clause 27.22.4.8.1.1.

#### 27.22.4.8.5.3 Test purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that if soft key preferred is indicated in the command details and soft key for SET UP MENU is supported by the ME and the number of icon items does not exceed the number of soft keys available, then the ME displays those icons as soft key.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

27.22.4.8.5.4 Method of test

27.22.4.8.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.4.8.5.4.2 Procedure

## Expected Sequence 5.1 (SET UP MENU, SOFT KEY PREFERRED, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP	
		MENU 5.1.1	
4	$ME \rightarrow USER$	Integrate the menu header of	
		"Toolkit Menu" into its menu	
		system and have the menu items	
		of "Item 1", "Item 2" under this	
		header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
		MENU 5.1.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$USER \to ME$	Select the Toolkit Menu "Toolkit	
		Menu"	
8	$ME \rightarrow USER$	Display "Item 1", "Item 2"	
9	$USER \to ME$	Navigate in the items, then select	Verify we can select items through soft keys
		"Item 2".	
10	$ME \rightarrow SIM$	Send the ENVELOPE 3.1.1:	
		MENU SELECTION	
		(Identifier of item: 2)	

## PROACTIVE COMMAND: SET UP MENU 5.1.1

#### Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "01" (selection using soft key preferred)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2
Text string of item: "Item 2"

#### Coding:

BER-TLV:	D0	29	81	03	01	25	01	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32					

### TERMINAL RESPONSE: SET UP MENU 5.1.1

## Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	25	00	82	02	82	81	83	01	00

#### 27.22.4.8.5.5 Test requirement

The ME shall operate in the manner defined in expected sequence 5.1.

#### 27.22.4.9 SELECT ITEM

#### 27.22.4.9.1 SELECT ITEM (mandatory features for ME supporting SELECT ITEM)

#### 27.22.4.9.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.9.1.2 Conformance requirement

The ME shall support the Proactive SIM: Select Item facility as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5, clause 6.4.9, clause 6.6.8, clause 6.8, clause 12.6, clause 13.4 and clause 14.

#### 27.22.4.9.1.3 Test purpose

To verify that the ME correctly presents the set of items contained in the SELECT ITEM proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM with the identifier of the item chosen.

To verify that the ME allows a SELECT ITEM proactive SIM command within the maximum 255 byte BER-TLV boundary.

To verify that the ME returns a TERMINAL RESPONSE with "Proactive SIM application session terminated by the user", if the user has indicated the need to end the proactive SIM session.

To verify that the ME returns a TERMINAL RESPONSE with "Backwards move in the proactive SIM application session requested by the user", if the user has indicated the need to go backwards in the proactive SIM application session.

#### 27.22.4.9.1.4 Method of test

#### 27.22.4.9.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.9.1.4.2 Procedure

## **Expected Sequence 1.1 (SELECT ITEM, mandatory features, successful)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2",	
		"Item 3" and "Item 4" under the	
		header of "Toolkit Select".	
5	$USER \to ME$	Select "Item 2".	
6	$ME \to SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 1.1.1	·

#### PROACTIVE COMMAND: SELECT ITEM 1.1.1

## Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 1
Text string of item: "It

"Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

### Coding:

BER-TLV:	D0	3D	81	03	01	24	00	82	02	81	82	85
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33	8F	07	04	49	74	65
	6D	20	34									

#### TERMINAL RESPONSE: SELECT ITEM 1.1.1

## Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 02

Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	02									

## Expected Sequence 1.2 (SELECT ITEM, large menu, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.2.1	
4	$ME \rightarrow USER$	Present the items of "Zero", "One",	
		"Two", Three", "Four", "Five", "Six",	
		"Seven", "Eight", "Nine", "Alpha",	
		"Bravo", "Charlie", "Delta", "Echo",	
		"Fox-trot", "Black", "Brown", "Red",	
		"Orange", "Yellow", "Green",	
		"Blue", "Violet", "Grey", "White",	
		"milli", "micro", "nano" and "pico"	
_		under the header of "LargeMenu1"	
5		Select item "Orange".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 1.2.1	

#### PROACTIVE COMMAND: SELECT ITEM 1.2.1

## Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "LargeMenu1"

Item

Identifier of item: "50" Text string of item: "Zero"

Item

Identifier of item: "4F"
Text string of item: "One"

Item

Identifier of item: "4E"
Text string of item: "Two"

Item

Identifier of item: "4D"
Text string of item: "Three"

Item

Identifier of item: "4C"
Text string of item: "Four"

Item

Identifier of item: "4B" Text string of item: "Five"

Item	Identifier of item:	"4A"
Item	Text string of item:	"Six"
	Identifier of item: Text string of item:	"49" "Seven"
Item	Identifier of item:	"48"
Item	Text string of item:  Identifier of item:	"Eight" "47"
Item	Text string of item:	"Nine"
Itam	Identifier of item: Text string of item:	"46" "Alpha"
Item	Identifier of item: Text string of item:	"45" "Bravo"
Item	Identifier of item:	"44"
Item	Text string of item:  Identifier of item:	"Charlie" "43"
Item	Text string of item:	"Delta"
	Identifier of item: Text string of item:	"42" "Echo"
Item	Identifier of item: Text string of item:	"41" "Fox-trot"
Item	Identifier of item:	"40"
Item	Text string of item:  Identifier of item:	"Black" "3F"
Item	Text string of item:	"Brown"
Item	Identifier of item: Text string of item:	"3E" "Red"
пеш	Identifier of item: Text string of item:	"3D" "Orange"
Item	Identifier of item:	"3C"
Item	Text string of item:  Identifier of item:	"Yellow" "3B"
Item	Text string of item:	"Green"
Item	Identifier of item: Text string of item:	"3A" "Blue"
Item	Identifier of item: Text string of item:	"39" "Violet"
Item	Identifier of item: Text string of item:	"38" "Grey"
Item	Identifier of item:	"37"
Item	Text string of item:	"White"
	Identifier of item:	"36"

Text string of item: "milli"

Item

Identifier of item: "35"
Text string of item: "micro"

Item

Identifier of item: "34"

Text string of item: "nano"

Item

Identifier of item: "33" Text string of item: "pico"

## Coding:

BER-TLV:	D0	81	FC	81	03	01	24	00	82	02	81	82
	85	0A	4C	61	72	67	65	4D	65	6E	75	31
	8F	05	50	5A	65	72	6F	8F	04	4F	4F	6E
	65	8F	04	4E	54	77	6F	8F	06	4D	54	68
	72	65	65	8F	05	4C	46	6F	75	72	8F	05
	4B	46	69	76	65	8F	04	4A	53	69	78	8F
	06	49	53	65	76	65	6E	8F	06	48	45	69
	67	68	74	8F	05	47	4E	69	6E	65	8F	06
	46	41	6C	70	68	61	8F	06	45	42	72	61
	76	6F	8F	80	44	43	68	61	72	6C	69	65
	8F	06	43	44	65	6C	74	61	8F	05	42	45
	63	68	6F	8F	09	41	46	6F	78	2D	74	72
	6F	74	8F	06	40	42	6C	61	63	6B	8F	06
	3F	42	72	6F	77	6E	8F	04	3E	52	65	64
	8F	07	3D	4F	72	61	6E	67	65	8F	07	3C
	59	65	6C	6C	6F	77	8F	06	3B	47	72	65
	65	6E	8F	05	3A	42	6C	75	65	8F	07	39
	56	69	6F	6C	65	74	8F	05	38	47	72	65
	79	8F	06	37	57	68	69	74	65	8F	06	36
	6D	69	6C	6C	69	8F	06	35	6D	69	63	72
	6F	8F	05	34	6E	61	6E	6F	8F	05	33	70
	69	63	6F									

TERMINAL RESPONSE: SELECT ITEM 1.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 3D

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	3D									

## Expected Sequence 1.3 (SELECT ITEM, call options, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SELECT ITEM 1.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SELECT ITEM 1.3.1	
4	ME → USER	Present the items of " Call Forwarding Unconditional", "Call Forward On User Busy", "Call Forward On No Reply", "Call Forward On User Not Reachable", "Barring Of All Outgoing Calls", "Barring Of All Outgoing International Calls" and "CLI Presentation" under the header of " LargeMenu2	
5	$USER \to ME$	Select item "Barring Of All Outgoing Calls".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT ITEM 1.3.1	Command performed successfully
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

#### PROACTIVE COMMAND: SELECT ITEM 1.3.1

## Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00'

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "LargeMenu2"

Item

Identifier of item: "FF"

Text string of item: "Call Forwarding Unconditional"

Item

Identifier of item: "FE"

Text string of item: "Call Forwarding On User Busy"

Item

Identifier of item: "FD"

Text string of item: "Call Forwarding On No Reply"

Item

Identifier of item: "FC"

Text string of item: "Call Forwarding On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "Barring Of All Outgoing International Calls"

Item

Identifier of item: "F9"

Text string of item: "CLI Presentation"

## Coding:

BER-TLV:	D0	81	FB	81	03	01	24	00	82	02	81	82
	85	0A	4C	61	72	67	65	4D	65	6E	75	32
	8F	1E	FF	43	61	6C	6C	20	46	6F	72	77
	61	72	64	69	6E	67	20	55	6E	63	6F	6E
	64	69	74	69	6F	6E	61	6C	8F	1D	FE	43
	61	6C	6C	20	46	6F	72	77	61	72	64	69
	6E	67	20	4F	6E	20	55	73	65	72	20	42
	75	73	79	8F	1C	FD	43	61	6C	6C	20	46
	6F	72	77	61	72	64	69	6E	67	20	4F	6E
	20	4E	6F	20	52	65	70	6C	79	8F	26	FC
	43	61	6C	6C	20	46	6F	72	77	61	72	64
	69	6E	67	20	4F	6E	20	55	73	65	72	20
	4E	6F	74	20	52	65	61	63	68	61	62	6C
	65	8F	1E	FB	42	61	72	72	69	6E	67	20
	4F	66	20	41	6C	6C	20	4F	75	74	67	6F
	69	6E	67	20	43	61	6C	6C	73	8F	2C	FA
	42	61	72	72	69	6E	67	20	4F	66	20	41
	6C	6C	20	4F	75	74	67	6F	69	6E	67	20
	49	6E	74	65	72	6E	61	74	69	6F	6E	61
	6C	20	43	61	6C	6C	73	8F	11	F9	43	4C
	49	20	50	72	65	73	65	6E	74	61	74	69
	6F	6E										

TERMINAL RESPONSE: SELECT ITEM 1.3.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: FB

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
·	90	01	FB									

# Expected Sequence 1.4 (SELECT ITEM, backward move by user, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.4.1	
4	$ME \rightarrow USER$	Present the items of "One" and	
		"Two" under the header of "Select	
		Item".	
5	$USER \to ME$	Indicate to go backwards in the	
		proactive SIM application session.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Backward move in the proactive SIM
_	0114 145	ITEM 1.4.1	application session requested by user
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
	NAT CINA	PENDING: SELECT ITEM 1.4.2	
8	$ME \rightarrow SIM$		
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: ISELECT ITEM 1.4.2	
10	ME LICED	Present the items of "One" and	
10	IVIE → USER	"Two" under the header of "Select	
		Item".	
11	USER → ME	Indicate to end the proactive SIM	
''	OOLK -> IVIL	application and return the ME to	
		normal operation.	
12	$ME \rightarrow SIM$		Proactive SIM application terminated by the
	, <u> </u>	ITEM 1.4.2	user
13	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SELECT ITEM 1.4.1 and 1.4.2

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Select Item"

Item

Identifier of item: "11"
Text string of item: "One"

Item

Identifier of item: "12" Text string of item: "Two"

BER-TLV:	D0	22	81	03	01	24	00	82	02	81	82	85
	0B	53	65	6C	65	63	74	20	49	74	65	6D
	8F	04	11	4F	6E	65	8F	04	12	54	77	6F

TERMINAL RESPONSE: SELECT ITEM 1.4.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 11

TERMINAL RESPONSE: SELECT ITEM 1.4.2

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 10

## Expected Sequence 1.5 (SELECT ITEM, "Y", successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.5.1	
4	$ME \rightarrow USER$	Present the items of "Y" under the	
		header of "The SIM shall supply a	
		set of items from which the user	
		may choose one. Each item	
		comprises a short identifier (used	
		to indicate the selection) and a text	
		string. Optionally the SIM may	
		include an alpha identifier. The	
_	LIGED ME	alpha identifier i".	
5		Select item "Y"	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 1.5.1	
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

#### PROACTIVE COMMAND: SELECT ITEM 1.5.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "The SIM shall supply a set of items from which the user may choose one. Each

item comprises a short identifier (used to indicate the selection) and a text string.

Optionally the SIM may include an alpha identifier. The alpha identifier i"

Item

Identifier of item: "01" Text string of item: "Y"

Coding:

: · ·												
BER-TLV:	D0	81	FD	81	03	01	24	00	82	02	81	82
	85	81	ED	54	68	65	20	53	49	4D	20	73
	68	61	6C	6C	20	73	75	70	70	6C	79	20
	61	20	73	65	74	20	6F	66	20	69	74	65
	6D	73	20	66	72	6F	6D	20	77	68	69	63
	68	20	74	68	65	20	75	73	65	72	20	6D
	61	79	20	63	68	6F	6F	73	65	20	6F	6E
	65	2E	20	45	61	63	68	20	69	74	65	6D
	20	63	6F	6D	70	72	69	73	65	73	20	61
	20	73	68	6F	72	74	20	69	64	65	6E	74
	69	66	69	65	72	20	28	75	73	65	64	20
	74	6F	20	69	6E	64	69	63	61	74	65	20
	74	68	65	20	73	65	6C	65	63	74	69	6F
	6E	29	20	61	6E	64	20	61	20	74	65	78
	74	20	73	74	72	69	6E	67	2E	20	4F	70
	74	69	6F	6E	61	6C	6C	79	20	74	68	65
	20	53	49	4D	20	6D	61	79	20	69	6E	63
	6C	75	64	65	20	61	6E	20	61	6C	70	68
	61	20	69	64	65	6E	74	69	66	69	65	72
	2E	20	54	68	65	20	61	6C	70	68	61	20
	69	64	65	6E	74	69	66	69	65	72	20	
	69	8F	02	01	59							

TERMINAL RESPONSE: SELECT ITEM 1.5.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

#### Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	01									

#### Expected Sequence 1.6 (SELECT ITEM, Large menu, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.6.1	
4	$ME \rightarrow USER$	Present the items of "1 Call	
		Forward Unconditional", "2 Call	
		Forward On User Busy", "3 Call	
		Forward On No Reply", "4 Call	
		Forward On User Not Reachable",	
		"5 Barring Of All Outgoing Calls",	
		"6 Barring Of All Outgoing Int	
		Calls" and "7 CLI Presentation"	
		under the header of	
_		"OLargeMenu".	
5	USER → ME	Select item "5 Barring Of All	
		Outgoing Calls".	Company of montoness of access of all a
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 1.6.1	

PROACTIVE COMMAND: SELECT ITEM 1.6.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "0LargeMenu"

Item

Identifier of item: "FF"

Text string of item:

"1 Call Forward Unconditional"

Item

Identifier of item: "FE"

Text string of item: "2 Call Forward On User Busy"

Item

Identifier of item: "FD"

Text string of item: "3 Call Forward On No Reply"

Item

Identifier of item: "FC"

Text string of item: "4 Call Forward On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "5 Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "6 Barring Of All Outgoing Int Calls"

Item

Identifier of item: "F9"

Text string of item: "7 CLI Presentation"

## Coding:

BER-TLV:	D0	81	F3	81	03	01	24	00	82	02	81	82
	85	0A	30	4C	61	72	67	65	4D	65	6E	75
	8F	1D	FF	31	20	43	61	6C	6C	20	46	6F
	72	77	61	72	64	20	55	6E	63	6F	6E	64
	69	74	69	6F	6E	61	6C	8F	1C	FE	32	20
	43	61	6C	6C	20	46	6F	72	77	61	72	64
	20	4F	6E	20	55	73	65	72	20	42	75	73
	79	8F	1B	FD	33	20	43	61	6C	6C	20	46
	6F	72	77	61	72	64	20	4F	6E	20	4E	6F
	20	52	65	70	6C	79	8F	25	FC	34	20	43
	61	6C	6C	20	46	6F	72	77	61	72	64	20
	4F	6E	20	55	73	65	72	20	4E	6F	74	20
	52	65	61	63	68	61	62	6C	65	8F	20	FB
	35	20	42	61	72	72	69	6E	67	20	4F	66
	20	41	6C	6C	20	4F	75	74	67	6F	69	6E
	67	20	43	61	6C	6C	73	8F	24	FA	36	20
	42	61	72	72	69	6E	67	20	4F	66	20	41
	6C	6C	20	4F	75	74	67	6F	69	6E	67	20
	49	6E	74	20	43	61	6C	6C	73	8F	13	F9
	37	20	43	4C	49	20	50	72	65	73	65	6E
	74	61	74	69	6F	6E						

TERMINAL RESPONSE: SELECT ITEM 1.5

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: FB

Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	FB									

The following table details the test commands with relation to the tested features:

	Proactive SIM Command Facilities									
Proactive SIM Command SELECT ITEM Number	Alpha Identifier Length	Number of items	Maximum length of item							
1.1	14	4	6							
1.2	10	30	8							
1.3	10	7	43							
1.4	11	2	3							
1.5	236	1	1							
1.6	10	7	37							

## 27.22.4.9.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1, 1.2, 1.3, 1.4, 1.5 and 1.6 (SELECT ITEM, mandatory features).

27.22.4.9.2 SELECT ITEM (next action support)

27.22.4.9.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.2.2 Conformance Requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.2.3 Test purpose

To verify that the mobile supports next action indicator mode.

27.22.4.9.2.4 Method of test

27.22.4.9.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.9.2.4.2 Procedure

#### Expected Sequence 2.1 (SELECT ITEM, next action indicator, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 2.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 2.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	
		and "Item 3" under the header of	
		"Toolkit Select".	
		It presents also the following next	
		action indicators: Send SM, Set Up	
		Call, Provide Local Info.	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 2". Check that next action	
		indicators appear.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
1		ITEM 2.1.1	

#### PROACTIVE COMMAND: SELECT ITEM 2.1.1

## Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Items next action indicator

Items list "Send SM", "Set Up Call", "Provide Local Info."

Coding:

BER-TLV:	D0	39	81	03	01	24	00	82	02	81	82	85
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33	18	03	13	10	26	

TERMINAL RESPONSE: SELECT ITEM 2.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 02

Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	02									

27.22.4.9.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1

27.22.4.9.3 SELECT ITEM (default item support)

27.22.4.9.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.3.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.3.3 Test purpose

To verify that the mobile supports "default item" mode.

27.22.4.9.3.4 Method of test

27.22.4.9.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.9.3.4.2 Procedure

## Expected Sequence 3.1 (SELECT ITEM, default item, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 3.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	Check that "Item 2" is selected by default.
		and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 3".	
6	$ME \to SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 3.1.1	

#### PROACTIVE COMMAND: SELECT ITEM 3.1.1

### Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Item identifier

Identifier of item chosen 02

BER-TLV:	D0	27	81	03	01	24	00	82	02	81	82	85
DER-ILV.	טט	31	01	03	UI	24	UU	02	02	01	02	00
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33	90	01	02			

**TERMINAL RESPONSE: SELECT ITEM 3.1.1** 

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 03

Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	03									

191

27.22.4.9.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1

27.22.4.9.4 SELECT ITEM (help request support)

27.22.4.9.4.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.4.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.4.3 Test purpose

To verify that the mobile supports "help request" for the command Select Item.

27.22.4.9.4.4 Method of test

27.22.4.9.4.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

# 27.22.4.9.4.4.2 Procedure

## Expected Sequence 4.1 (SELECT ITEM, help request, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Help information available]
		SELECT ITEM 4.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	
		and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items until "Item 1".	
6	$USER \to ME$	Select the Help Request on "Item	
		1" Menu entry	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[Help information required by the user]
		ITEM 4.1.1	

## PROACTIVE COMMAND: SELECT ITEM 4.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "80" help information available

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Coding:

BER-TLV:	D0	34	81	03	01	24	80	82	02	81	82	85
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33						

## TERMINAL RESPONSE: SELECT ITEM 4.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "80"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Help information required by the user

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV:	81	03	01	24	80	82	02	82	81	83	01	13
_	90	01	01									

27.22.4.9.4.5 Test requirement

The ME shall operate in the manner defined in expected sequence 4.1

27.22.4.9.5 SELECT ITEM (icons support)

27.22.4.9.5.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.5.2 Conformance requirement

Same as clause 27.22.4.9.1.2 and 3GPP TS 11.14 [15] clause 12.31 and clause 12.32.

27.22.4.9.5.3 Test purpose

To verify that the mobile displays icons with the command Select Item.

27.22.4.9.5.4 Method of test

27.22.4.9.5.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.5.4.2 Procedure

## Expected Sequence 5.1A (SELECT ITEM, BASIC ICON NOT SELF EXPLANATORY, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	Verify icons are displayed in the alpha
		and "Item 3" under the header of	identifier and in the 3 items.
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 5.1.1 A	

PROACTIVE COMMAND: SELECT ITEM 5.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Icon Identifier:

Icon qualifier: "01" (icon is not self-explanatory)

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

Item icon identifier list:

Icon qualifier: "01" (icon is not self-explanatory)

Icon Identifier: record 5 in  $EF_{(IMG)}$ , record 5 in  $EF_{(IMG)}$ , record 5 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	3E	81	03	01	24	00	82	02	81	82	85
'-	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33	9E	02	01	01	9F	04
	01	05	05	05								

### TERMINAL RESPONSE: SELECT ITEM 5.1.1A

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
'	90	01	01									

# Expected Sequence 5.1B (SELECT ITEM, BASIC ICON NOT SELF EXPLANATORY, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	no icon is displayed in the alpha identifier nor
		and "Item 3" under the header of	in the 3 items.
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 1".	
6	$ME \to SIM$		[Command performed successfully, but
		ITEM 5.1.1 B	requested icon could not be displayed]

TERMINAL RESPONSE: SELECT ITEM 5.1.1B

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	04
'	90	01	01									

## Expected Sequence 5.2A (SELECT ITEM, BASIC ICON SELF EXPLANATORY, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.2.1	
4	$ME \to USER$	Display items of "Item 1", "Item 2"	Verify icons are displayed without text as
		and "Item 3" under the header of	alpha id and for the all 3 items.
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 5.2.1 A	

PROACTIVE COMMAND: SELECT ITEM 5.2.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01

Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Icon Identifier:

Icon qualifier: "00" (icon is self-explanatory)

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

Item icon identifier list:

Icon qualifier: "00" (icon is self-explanatory)

Icon Identifier: record 5 in  $EF_{(IMG)}$ , record 5 in  $EF_{(IMG)}$ , record 5 in  $EF_{(IMG)}$ 

#### Coding:

BER-TLV:	D0	3E	81	03	01	24	00	82	02	81	82	85
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33	9E	02	00	01	9F	04
	00	05	05	05								

## TERMINAL RESPONSE: SELECT ITEM 5.2.1A

#### Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	00
	90	01	01									

# Expected Sequence 5.2B (SELECT ITEM, BASIC ICON SELF EXPLANATORY, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.2.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	no icon is displayed with text as alpha id nor
		and "Item 3" under the header of	for the all 3 items.
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully but
		ITEM 5.2.1B	requested icon could not be displayed]

TERMINAL RESPONSE: SELECT ITEM 5.2.1B

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV:	81	03	01	24	00	82	02	82	81	83	01	04
	90	01	01									

27.22.4.9.5.5 Test requirement

The ME shall operate in the manner defined in expected sequences 5.1A to 5.2B.

27.22.4.9.6 SELECT ITEM (presentation style)

27.22.4.9.6.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.6.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.6.3 Test purpose

To verify that the mobile supports the "presentation style" with the command Select Item.

27.22.4.9.6.4 Method of test

27.22.4.9.6.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.9.6.4.2 Procedure

# Expected Sequence 6.1 (SELECT ITEM, PRESENTATION AS A CHOICE OF NAVIGATION OPTIONS, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 6.1.1	
4	$ME \to USER$	Display items of "Item 1", "Item 2"	Verify if presentation style appears.
		and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \to ME$	Navigate in the items, then select	
		"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 6.1.1	

#### PROACTIVE COMMAND: SELECT ITEM 6.1.1

#### Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "03" (presentation as a choice of navigation options)

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

BER-TLV:	D0	34	81	03	01	24	03	82	02	81	82	85
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33						

TERMINAL RESPONSE: SELECT ITEM 6.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "03" (presentation as a choice of navigation options)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV:	81	03	01	24	03	82	02	82	81	83	01	00
	90	01	01									

# Expected Sequence 6.2 (SELECT ITEM, PRESENTATION AS A CHOICE OF DATA VALUES, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 6.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 6.2.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	Verify if presentation style appears
		and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \rightarrow ME$	Navigate in the items, then select	
		"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 6.2.1	

PROACTIVE COMMAND: SELECT ITEM 6.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "01" (presentation as a choice of data values)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

BER-TLV:	D0	34	81	03	01	24	01	82	02	81	82	85
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33						

TERMINAL RESPONSE: SELECT ITEM 6.2.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "01"(presentation as a choice of data values)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV:	81	03	01	24	01	82	02	82	81	83	01	00
	90	01	01									

27.22.4.9.6.5 Test requirement

The ME shall operate in the manner defined in expected sequences 6.1 and 6.2.

27.22.4.9.7 SELECT ITEM (soft keys support)

27.22.4.9.7.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.7.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

27.22.4.9.7.3 Test purpose

To verify that the mobile supports the "soft keys" with the command Select Item.

27.22.4.9.7.4 Method of test

27.22.4.9.7.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.9.7.4.2 Procedure

# Expected Sequence 7.1 (SELECT ITEM, SELECTING USING SOFT KEYS PREFERRED, successful, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 7.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 7.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	
		under the header of "Toolkit	
		Select".	
5	$USER \to ME$	Navigate in the items, then select	Verify that we can choose an item through
		"Item 1".	soft keys
6	$ME \to SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 7.1.1	

# PROACTIVE COMMAND: SELECT ITEM 7.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "04" (selection using soft keys preferred)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Coding:

BER-TLV:	D0	2B	81	03	01	24	04	82	02	81	82	85
-	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32			

## TERMINAL RESPONSE: SELECT ITEM 7.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "04" (selection using soft keys preferred)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

BER-TLV:	81	03	01	24	04	82	02	82	81	83	01	00
	90	01	01									

## 27.22.4.9.7.5 Test requirement

The ME shall operate in the manner defined in expected sequence 7.1.

# 27.22.4.9.8 SELECT ITEM (Support of "No response from user")

27.22.4.9.8.1 Definition and applicability

See clause 3.2.2.

27.22.4.9.8.2 Conformance requirement

Same as clause 27.22.4.9.1.2.

#### 27.22.4.9.8.3 Test purpose

To verify that after a period of user inactivity the ME returns a "No response from user" result value in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.9.8.4 Method of test

27.22.4.9.8.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME Manufacturer shall have defined the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

## 27.22.4.9.8.4.2 Procedure

## **Expected Sequence 8.1 (SELECT ITEM, no response from user)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 8.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 8.1.1	
4	$ME \rightarrow USER$	Display items of "Item 1", "Item 2"	
		and "Item 3" under the header of	
		" <time-out>".</time-out>	
5	USER	Waiting and no completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[No response from user] within 5 s after the
		ITEM 8.1.1	end of that defined period of time
7	USER	Check if the delay of TERMINAL	
		RESPONSE is reasonable or not	

PROACTIVE COMMAND: SELECT ITEM 8.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha identifier: "<TIME-OUT>"

Item

Identifier of item: 01

Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Coding:

BER-TLV:	D0	30	81	03	01	24	00	82	02	81	82	85
	0A	3C	54	49	4D	45	2D	4F	55	54	3E	8F
	07	01	49	74	65	6D	20	31	8F	07	02	49
	74	65	6D	20	32	8F	07	03	49	74	65	6D
	20	33										Į.

**TERMINAL RESPONSE: SELECT ITEM 8.1.1** 

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: No response from user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 12

27.22.4.9.8.5 Test requirement

The ME shall operate in the manner defined in expected sequence 8.1.

27.22.4.10 SEND SHORT MESSAGE

27.22.4.10.1 SEND SHORT MESSAGE (normal)

27.22.4.10.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.10.1.2 Conformance requirement

The ME shall support the Proactive SIM: SEND SHORT MESSAGE facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.10, clause 6.6.9, clause 12.6, clause 12.7, clause 12.2, clause 12.1, clause 12.13, clause 12.31 and clause 5.2.

#### 27.22.4.10.1.3 Test purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

#### 27.22.4.10.1.4 Method of test

#### 27.22.4.10.1.4.1 Initial conditions

The ME is connected to the system Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.10.1.4.2 Procedure

### Expected Sequence 1.1(SEND SHORT MESSAGE, packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 1.1.1	
4	$ME \rightarrow USER$	Display "Send SM"	[Alpha Identifier]
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 1.1	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.1.1	

## PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1

## Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

#### Coding:

BER-TLV:	D0	37	81	03	01	13	00	82	02	81	83	85
	07	53	65	6E	64	20	53	4D	86	09	91	11
	22	33	44	55	66	77	F8	8B	18	01	00	09
	91	10	32	54	76	F8	40	F4	0C	54	65	73
	74	20	4D	65	73	73	61	67	65			

## SMS-PP (SEND SHORT MESSAGE) Message 1.1

#### Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

#### Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F4	0C
	54	65	73	74	20	4D	65	73	73	61	67	65

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 1.1.1

## Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TL	V: 81	1 03	01	13	00	82	02	82	81	83	01	00	l
--------	-------	------	----	----	----	----	----	----	----	----	----	----	---

#### Expected Sequence 1.2 (SEND SHORT MESSAGE, packing required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing required, 8-bit data]
		SHORT MESSAGE 1.2.1	
4	$ME \rightarrow USER$	Display "Send SM"	[Alpha Identifier]
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 1.2	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.2.1	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 1.2.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

**SMS TPDU** 

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 7

TP-UD "Send SM"

BER-TLV:	D0	32	81	03	01	13	01	82	02	81	83	85
	07	53	65	6E	64	20	53	4D	86	09	91	11
	22	33	44	55	66	77	F8	8B	13	01	00	09
	91	10	32	54	76	F8	40	F4	07	53	65	6E
	64	20	53	4D								

## SMS-PP (SEND SHORT MESSAGE) Message 1.2

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

**TP-DCS** 

Message coding SMS default alphabet

Message class 0 TP-UDL 7

TP-UD "Send SM"

Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F0	07
	D3	B2	9B	0C	9A	36	01					

# TERMINAL RESPONSE: SEND SHORT MESSAGE 1.2.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	01	13	01	82	02	82	81	83	01	00

# Expected Sequence 1.3 (SEND SHORT MESSAGE, packing not required, SMS default alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, SMS default alphabet]
		SHORT MESSAGE 1.3.1	
4	$ME \rightarrow USER$	Display "Short Message"	[Alpha Identifier]
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 1.3	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.3.1	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 1.3.1

#### Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Short Message"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

**TP-DCS** 

Message coding SMS default alphabet

Message class 0
TP-UDL 13

TP-UD "Short Message"

BER-TLV:	D0	3D	81	03	01	13	00	82	02	81	83	85
	0D	53	68	6F	72	74	20	4D	65	73	73	61
	67	65	86	09	91	11	22	33	44	55	66	77
	F8	8B	18	01	00	09	91	10	32	54	76	F8
	40	F0	0D	53	F4	5B	4E	07	35	CB	F3	79
	F8	5C	06									

## SMS-PP (SEND SHORT MESSAGE) Message 1.3

#### Logically:

**SMS TPDU** 

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 13

TP-UD "Short Message"

## Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F0	0D
	53	F4	5B	4E	07	35	CB	F3	79	F8	5C	06

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 1.3.1

## Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	01	03	01	12	00	92	02	92	01	92	01	00
DEK-ILV.	01	03	01	13	UU	02	02	82	01	೦೦	UI	1 00

# Expected Sequence 1.4 (SEND SHORT MESSAGE, packing required, 8 bit data, message of 160 characters user data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.4. 1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing required, 8 bit data]
		SHORT MESSAGE 1.4.1	
4	$ME \to USER$	Display " The address data object	[Alpha Identifier]
		holds the RP_Destination_Address	
		"	
5	$ME \to SS$	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	[message of 140 bytes user data]
		MESSAGE) Message 1.4	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.4.1	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 1.4.1

### Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "The address data object holds the RP\_Destination\_Address"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8 bit data Message class class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transp"

## Coding:

	1											
BER-TLV:	D0	81	FD	81	03	01	13	01	82	02	81	83
	85	38	54	68	65	20	61	64	64	72	65	73
	73	20	64	61	74	61	20	6F	62	6A	65	63
	74	20	68	6F	6C	64	73	20	74	68	65	20
	52	50	11	44	65	73	74	69	6E	61	74	69
	6F	6E	11	41	64	64	72	65	73	73	86	09
	91	11	22	33	44	55	66	77	F8	8B	81	AC
	01	00	09	91	10	32	54	76	F8	40	F4	A0
	54	77	6F	20	74	79	70	65	73	20	61	72
	65	20	64	65	66	69	6E	65	64	3A	20	2D
	20	41	20	73	68	6F	72	74	20	6D	65	73
	73	61	67	65	20	74	6F	20	62	65	20	73
	65	6E	74	20	74	6F	20	74	68	65	20	6E
	65	74	77	6F	72	6B	20	69	6E	20	61	6E
	20	53	4D	53	2D	53	55	42	4D	49	54	20
	6D	65	73	73	61	67	65	2C	20	6F	72	20
	61	6E	20	53	4D	53	2D	43	4F	4D	4D	41
	4E	44	20	6D	65	73	73	61	67	65	2C	20
	77	68	65	72	65	20	74	68	65	20	75	73
	65	72	20	64	61	74	61	20	63	61	6E	20
	62	65	20	70	61	73	73	65	64	20	74	72
	61	6E	73	70								

## SMS-PP (SEND SHORT MESSAGE) Message 1.4

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

**TP-DCS** 

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transp"

## Coding:

BER-TLV:		01	00	09	91	10	32	54	76	F8	40	F0
	A0	D4	FB	1B	44	CF	C3	СВ	73	50	58	5E
	06	91	CB	E6	B4	BB	4C	D6	81	5A	A0	20
	68	8E	7E	СВ	E9	A0	76	79	3E	0F	9F	CB
	20	FA	1B	24	2E	83	E6	65	37	1D	44	7F
	83	E8	E8	32	C8	5D	A6	DF	DF	F2	35	28
	ED	06	85	DD	A0	69	73	DA	9A	56	85	CD
	24	15	D4	2E	CF	E7	E1	73	99	05	7A	CB
	41	61	37	68	DA	9C	B6	86	CF	66	33	E8
	24	82	DA	E5	F9	3C	7C	2E	В3	40	77	74
	59	5E	06	D1	D1	65	50	7D	5E	96	83	C8
	61	7A	18	34	0E	BB	41	E2	32	08	1E	9E
	CF	СВ	64	10	5D	1E	76	CF	E1			

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

# Expected Sequence 1.5 (SEND SHORT MESSAGE, packing not required, SMS default alphabet, message of 160 characters user data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.5.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, SMS default alphabet]
		SHORT MESSAGE 1.5.1	
4	$ME \rightarrow USER$	Display " The address data object	[Alpha Identifier]
		holds the RP_Destination_Address	
		"	
5	$ME \to SS$	Send SMS-PP (SEND SHORT	[message of 140 bytes user data]
		MESSAGE) Message 1.5	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.5.1	

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "The address data object holds the RP Destination Address"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

**SMS TPDU** 

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

**TP-DCS** 

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transp"

#### Coding:

BER-TLV:	D0	81	E9	81	03	01	13	00	82	02	81	83
	85	38	54	68	65	20	61	64	64	72	65	73
	73	20	64	61	74	61	20	6F	62	6A	65	63
	74	20	68	6F	6C	64	73	20	74	68	65	20
	52	50	20	44	65	73	74	69	6E	61	74	69
	6F	6E	20	41	64	64	72	65	73	73	86	09
	91	11	22	33	44	55	66	77	F8	8B	81	98
	01	00	09	91	10	32	54	76	F8	40	F0	A0
	D4	FB	1B	44	CF	C3	CB	73	50	58	5E	06
	91	СВ	E6	B4	BB	4C	D6	81	5A	A0	20	68
	8E	7E	СВ	E9	A0	76	79	3E	0F	9F	СВ	20
	FA	1B	24	2E	83	E6	65	37	1D	44	7F	83
	E8	E8	32	C8	5D	A6	DF	DF	F2	35	28	ED
	06	85	DD	A0	69	73	DA	9A	56	85	CD	24
	15	D4	2E	CF	E7	E1	73	99	05	7A	CB	41
	61	37	68	DA	9C	B6	86	CF	66	33	E8	24
	82	DA	E5	F9	3C	7C	2E	В3	40	77	74	59
	5E	06	D1	D1	65	50	7D	5E	96	83	C8	61
	7A	18	34	0E	BB	41	E2	32	08	1E	9E	CF
	СВ	64	10	5D	1E	76	CF	E1				

## SMS-PP (SEND SHORT MESSAGE) Message 1.5

### Logically:

**SMS TPDU** 

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00'

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an SMS-

SUBMIT message, or an SMS-COMMAND message, where the user data can be

passed transp"

#### Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F0	A0
_	D4	FB	1B	44	CF	C3	CB	73	50	58	5E	06
	91	CB	E6	B4	BB	4C	D6	81	5A	A0	20	68
	8E	7E	CB	E9	A0	76	79	3E	0F	9F	CB	20
	FA	1B	24	2E	83	E6	65	37	1D	44	7F	83
	E8	E8	32	C8	5D	A6	DF	DF	F2	35	28	ED
	06	85	DD	A0	69	73	DA	9A	56	85	CD	24
	15	D4	2E	CF	E7	E1	73	99	05	7A	CB	41
	61	37	68	DA	9C	B6	86	CF	66	33	E8	24
	82	DA	E5	F9	3C	7C	2E	В3	40	77	74	59
	5E	06	D1	D1	65	50	7D	5E	96	83	C8	61
	7A	18	34	0E	BB	41	E2	32	80	1E	9E	CF
	СВ	64	10	5D	1E	76	CF	E1				

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00												
	BER-TLV:	81		13	00	82	02	82	81	83	01	00

# Expected Sequence 1.6 (SEND SHORT MESSAGE, alpha identifier 160 bytes long, SMS default alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$		[packing not required, SMS default alphabet]
		SHORT MESSAGE 1.6.1	
4	$ME \rightarrow USER$	Display "Two types are defined: - A	[Alpha Identifier of 160 bytes]
		short message to be sent to the	
		network in an SMS-SUBMIT	
		message, or an SMS-COMMAND	
		message, where the user data can	
		be passed transparently; - A short	
		message to be sent to the network	
		in an SMS-SUBMIT "	
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 1.6	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.6.1	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 1.6.1

### Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can

be passed transparently; - A short message to be sent to the network in an

SMS-SUBMIT"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "01"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class Class 0
TP-UDL 1
TP-UD " "

D0	81	FD	81	03	01	13	00	82	02	81	83
85	81	E6	54	77	6F	20	74	79	70	65	73
20	61	72	65	20	64	65	66	69	6E	65	64
3A	20	2D	20	41	20	73	68	6F	72	74	20
6D	65	73	73	61	67	65	20	74	6F	20	62
65	20	73	65	6E	74	20	74	6F	20	74	68
65	20	6E	65	74	77	6F	72	6B	20	69	6E
20	61	6E	20	53	4D	53	2D	53	55	42	4D
49	54	20	6D	65	73	73	61	67	65	2C	20
6F	72	20	61	6E	20	53	4D	53	2D	43	4F
4D	4D	41	4E	44	20	6D	65	73	73	61	67
65	2C	20	77	68	65	72	65	20	74	68	65
20	75	73	65	72	20	64	61	74	61	20	63
61	6E	20	62	65	20	70	61	73	73	65	64
20	74	72	61	6E	73	70	61	72	65	6E	74
6C	79	3B	20	2D	20	41	20	73	68	6F	72
74	20	6D	65	73	73	61	67	65	20	74	6F
20	62	65	20	73	65	6E	74	20	74	6F	20
74	68	65	20	6E	65	74	77	6F	72	6B	20
69	6E	20	61	6E	20	53	4D	53	2D	53	55
42	4D	49	54	20	8B	09	01	00	02	91	10
40	F0	01	20		_		_			_	
	85 20 3A 6D 65 65 20 49 6F 4D 65 20 61 20 67 74 20 74 69 42	85 81 20 61 3A 20 6D 65 65 20 65 20 20 61 49 54 6F 72 4D 4D 65 2C 20 75 61 6E 20 74 6C 79 74 20 20 62 74 68 69 6E 42 4D	85 81 E6 20 61 72 3A 20 2D 6D 65 73 65 20 6E 20 61 6E 20 61 6E 49 54 20 6F 72 20 4D 4D 41 65 2C 20 20 75 73 61 6E 20 20 74 72 6C 79 3B 74 20 6D 20 62 65 74 68 65 69 6E 20 42 4D 49	85 81 E6 54 20 61 72 65 3A 20 2D 20 6D 65 73 73 65 20 73 65 65 20 6E 65 20 61 6E 20 49 54 20 6D 6F 72 20 61 4D 4D 41 4E 65 2C 20 77 20 75 73 65 61 6E 20 62 20 74 72 61 6C 79 3B 20 74 20 6D 65 20 62 65 20 74 68 65 20 69 6E 20 61 42 4D 49 54	85         81         E6         54         77           20         61         72         65         20           3A         20         2D         20         41           6D         65         73         73         61           65         20         6E         65         74           20         61         6E         20         53           49         54         20         6D         65           6F         72         20         61         6E           4D         4D         41         4E         44           65         2C         20         77         68           20         75         73         65         72           61         6E         20         62         65           20         74         72         61         6E           6C         79         3B         20         2D           74         20         6D         65         73           20         62         65         20         73           74         68         65         20         73	85         81         E6         54         77         6F           20         61         72         65         20         64           3A         20         2D         20         41         20           6D         65         73         73         61         67           65         20         73         65         6E         74           65         20         6E         65         74         77           20         61         6E         20         53         4D           49         54         20         6D         65         73           6F         72         20         61         6E         20           4D         4D         41         4E         44         20           65         2C         20         77         68         65           20         75         73         65         72         20           61         6E         20         62         65         20           20         74         72         61         6E         73           6C         79         3B         20         <	85         81         E6         54         77         6F         20           20         61         72         65         20         64         65           3A         20         2D         20         41         20         73           6D         65         73         73         61         67         65           65         20         73         65         6E         74         20           65         20         6E         65         74         77         6F           20         61         6E         20         53         4D         53           49         54         20         6D         65         73         73           6F         72         20         61         6E         20         53           4D         4D         41         4E         44         20         6D           65         2C         20         77         68         65         72           20         75         73         65         72         20         64           61         6E         20         62         65         20	85         81         E6         54         77         6F         20         74           20         61         72         65         20         64         65         66           3A         20         2D         20         41         20         73         68           6D         65         73         73         61         67         65         20           65         20         73         65         6E         74         20         74           65         20         6E         65         74         77         6F         72           20         61         6E         20         53         4D         53         2D           49         54         20         6D         65         73         73         61           6F         72         20         61         6E         20         53         4D           4D         4D         41         4E         44         20         6D         65           65         2C         20         77         68         65         72         65           20         75         73	85         81         E6         54         77         6F         20         74         79           20         61         72         65         20         64         65         66         69           3A         20         2D         20         41         20         73         68         6F           6D         65         73         73         61         67         65         20         74           65         20         73         65         6E         74         20         74         6F           65         20         6E         65         74         77         6F         72         6B           20         61         6E         20         53         4D         53         2D         53           49         54         20         6D         65         73         73         61         67           6F         72         20         61         6E         20         53         4D         53           4D         4D         41         4E         44         20         6D         65         73           65         2C	85         81         E6         54         77         6F         20         74         79         70           20         61         72         65         20         64         65         66         69         6E           3A         20         2D         20         41         20         73         68         6F         72           6D         65         73         73         61         67         65         20         74         6F           65         20         73         65         6E         74         20         74         6F         20           65         20         6E         65         74         77         6F         72         6B         20           20         61         6E         20         53         4D         53         2D         53         55           49         54         20         6D         65         73         73         61         67         65           6F         72         20         61         6E         20         53         4D         53         2D           4D         4D         41	85         81         E6         54         77         6F         20         74         79         70         65           20         61         72         65         20         64         65         66         69         6E         65           3A         20         2D         20         41         20         73         68         6F         72         74           6D         65         73         73         61         67         65         20         74         6F         20           65         20         73         65         6E         74         20         74         6F         20         74           65         20         6E         65         74         77         6F         72         6B         20         69           20         61         6E         20         53         4D         53         2D         53         55         42           49         54         20         6D         65         73         73         61         67         65         2C           6F         72         20         61         6E         20

## SMS-PP (SEND SHORT MESSAGE) Message 1.6

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "01"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0
TP-UDL 1
TP-UD " "

Coding:

	BER-TLV:	01	00	02	91	10	40	F0	01	20
--	----------	----	----	----	----	----	----	----	----	----

## TERMINAL RESPONSE: SEND SHORT MESSAGE 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE Command qualifier: packing not required Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

# Expected Sequence 1.7(SEND SHORT MESSAGE, alpha identifier length '00', packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 1.7.1	
4	ME	No information to user	[Alpha identifier length '00']
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 1.7	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.7.1	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 1.7.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier:

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

BER-TLV:	D0	37	81	03	01	13	00	82	02	81	83	85
	00	86	09	91	11	22	33	44	55	66	77	F8
	8B	18	01	00	09	91	10	32	54	76	F8	40
	F4	0C	54	65	73	74	20	4D	65	73	73	61
	67	65										

#### SMS-PP (SEND SHORT MESSAGE) Message 1.7

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

BER-	ΓLV:	01	00	09	91	10	32	54	76	F8	40	F4	0C
		54	65	73	74	20	4D	65	73	73	61	67	65

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 1.7.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

# Expected Sequence 1.8 (SEND SHORT MESSAGE, packing not required, 8-bit data, no alpha identifier, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 1.8.1	
4	$ME \rightarrow USER$	May give information to user	[No Alpha Identifier]
		concerning what is happening	
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 1.8	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 1.8.1	- · · ·

# PROACTIVE COMMAND: SEND SHORT MESSAGE 1.8.1

#### Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

**TP-DCS** 

Message coding Message class Class 0
TP-UDL 12

TP-UD "Test Message"

BER-TLV:	D0	2E	81	03	01	13	00	82	02	81	83	86	l
	09	91	11	22	33	44	55	66	77	F8	8B	18	l
	01	00	09	91	10	32	54	76	F8	40	F4	0C	l
	54	65	73	74	20	4D	65	73	73	61	67	65	ı

## SMS-PP (SEND SHORT MESSAGE) Message 1.8

#### Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

#### Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F4	0C
	54	65	73	74	20	4D	65	73	73	61	67	65

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 1.8.1

## Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

#### 27.22.4.10.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1 to 8.

# 27.22.4.10.2 SEND SHORT MESSAGE (UCS2 support)

# 27.22.4.10.2.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.10.2.2 Conformance requirement

The ME shall support the Proactive SIM: SEND SHORT MESSAGE facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.10, clause 6.6.9, clause 12.6, clause 12.7, clause 12.2, clause 12.1, clause 12.13, clause 12.31 and clause 5.2.

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17].

#### 27.22.4.10.2.3 Test purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.2.4 Method of test

27.22.4.10.2.4.1 Initial conditions

The ME is connected to the system Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.10.2.4.2 Procedure

#### Expected Sequence 2.1 (SEND SHORT MESSAGE, packing not required, UCS2 (16-bit data))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, 16-bit data]
		SHORT MESSAGE 2.1.1	
4	$ME \to USER$	Display "Send SM"	[Alpha Identifier]
5	$ME \to SS$	Send SMS-PP (SEND SHORT	["ЗДРАВСТВУЙТЕ" = "Hello" in Russian]
		MESSAGE) Message 2.1	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 2.1.1	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE: 2.1.1

## Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 16-bit data Message class class 0 TP-UDL 24

ТР-UD "ЗДРАВСТВУЙТЕ"

## Coding:

BER-TLV:	D0	43	81	03	01	13	00	82	02	81	83	85
	07	53	65	6E	64	20	53	4D	86	09	91	11
	22	33	44	55	66	77	F8	8B	18	01	00	09
	91	10	32	54	76	F8	40	08	18	04	17	04
	14	04	20	04	10	04	12	04	21	04	22	04
	12	04	23	04	19	04	22	04	15			

#### SMS-PP (SEND SHORT MESSAGE) Message 2.1

#### Logically:

**SMS TPDU** 

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding UCS2 (16-bit data)

Message class 0 TP-UDL 24

TP-UD "ЗДРАВСТВУЙТЕ"

#### Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	80	18
·	04	17	04	14	04	20	04	10	04	12	04	21
	04	22	04	12	04	23	04	19	04	22	04	15

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 2.2.1

#### Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

	BER-TLV:	81	03	01	13	00	82	02	82	81	83	01	00
--	----------	----	----	----	----	----	----	----	----	----	----	----	----

#### 27.22.4.10.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

#### 27.22.4.10.3 SEND SHORT MESSAGE (icon support)

27.22.4.10.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.10.3.2 Conformance requirement

27.22.4.10.3.3 Test purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.3.4 Method of test

27.22.4.10.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME screen shall be in its normal stand-by display.

27.22.4.10.3.4.2 Procedure

# Expected Sequence 3.1A (SEND SHORT MESSAGE, basic icon self-explanatory, packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 3.1.1	
4	$ME \rightarrow USER$	Displays the icon and not the	[basic icon self-explanatory]
		alpha identifier	
5	$ME \rightarrow SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 3.1	
6	$SS \rightarrow ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 3.1.1A	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 3.1.1

#### Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "NO ICON"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8bit-data Message class 0 TP-UDL 12

TP-UD "Test Message"

Icon Identifier

Icon Qualifier self-explanatory

Icon Identifier 1 (number of record in EF IMG)

#### Coding:

BER-TLV:	D0	3B	81	03	01	13	00	82	02	81	83	85
	07	4E	4F	20	49	43	4F	4E	86	09	91	11
	22	33	44	55	66	77	F8	8B	18	01	00	09
	91	10	32	54	76	F4	40	F4	0C	54	65	73
	74	20	4D	65	73	73	61	67	65	9E	02	00
	01											

# SMS-PP (SEND SHORT MESSAGE) Message 3.1

#### Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 12

TP-UD "Test Message"

Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F4	0C
	54	65	73	74	20	4D	65	73	73	61	67	65

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 3.1.1A

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BEK-ILV:	81	03	01	13	00	82	02	82	81	83	01	00
'												

# Expected Sequence 3.1B (SEND SHORT MESSAGE, basic icon self-explanatory, packing not required, 8-bit data, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data, basic icon
		SHORT MESSAGE 3.1.1	self-explanatory]]
4	$ME \rightarrow USER$	Displays the alpha identifier	·
		without the icon	
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 3.1	
6	$SS \rightarrow ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully, but
		SHORT MESSAGE 3.1.1B	requested icon could not be displayed]

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 3.1.1B

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

BER-TLV:	81	03	01	13	00	82	02	82	81	83	01	04	1
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

# Expected Sequence 3.2A (SEND SHORT MESSAGE, basic icon non-self-explanatory, packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 3.2.1	
4	$ME \rightarrow USER$	display the icon and "Send SM"	[basic icon non-self-explanatory]
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 3.2	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SHORT MESSAGE 3.2.1A	

#### PROACTIVE COMMAND: SEND SHORT MESSAGE 3.2.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha Identifier "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8bit-data Message class 0 TP-UDL 12

TP-UD "Test Message"

Icon Identifier

Icon Qualifier non-self-explanatory

Icon Identifier 1 (number of record in EF IMG)

BER-TLV:	D0	3B	81	03	01	13	00	82	02	81	83	85
	07	53	65	6E	64	20	53	4D	86	09	91	11
	22	33	44	55	66	77	F8	8B	18	01	00	09
	91	10	32	54	76	F8	40	F4	0C	54	65	73
	74	20	4D	65	73	73	61	67	65	1E	02	01
	01											

## SMS-PP (SEND SHORT MESSAGE) Message 3.2

#### Logically:

**SMS TPDU** 

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

#### Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F4	0C
	54	65	73	74	20	4D	65	73	73	61	67	65

# TERMINAL RESPONSE: SEND SHORT MESSAGE 3.2.1A

#### Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	01	13	00	82	02	82	81	83	01	00

# Expected Sequence 3.2B (SEND SHORT MESSAGE, basic icon non-self-explanatory, packing not required, 8-bit data, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	[packing not required, 8-bit data, basic icon
		SHORT MESSAGE 3.2.1	non-self-explanatory ]
4	$ME \rightarrow USER$	display "Send SM" without the icon	
5	$ME \to SS$	Send SMS-PP (SEND SHORT	
		MESSAGE) Message 3.2	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully, but
		SHORT MESSAGE 3.2.1B	requested icon could not be displayed]

#### TERMINAL RESPONSE: SEND SHORT MESSAGE 3.2.1B

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed;

Coding:

BER-TL\	': 81	03	01	13	00	82	02	82	81	83	01	04	l
---------	-------	----	----	----	----	----	----	----	----	----	----	----	---

## 27.22.4.10.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1A to 3.2B.

#### 27.22.4.11 SEND SS

## 27.22.4.11.1 SEND SS (normal)

#### 27.22.4.11.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.11.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send SS facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.11, clause 6.6.10, clause 12.12.1, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.14, clause 12.31 and clause 6.5.4.

## 27.22.4.11.1.3 Test purpose

To verify that the ME correctly translates and sends the supplementary service request indicated in the SEND SS proactive SIM command to the system Simulator.

To verify that the ME returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the SS and any contents of the SS result as additional data.

27.22.4.11.1.4 Method of test

27.22.4.11.1.4.1 Initial conditions

The ME is connected to the System Simulator and the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

#### 27.22.4.11.1.4.2 Procedure

#### Expected Sequence 1.1 (SEND SS, call forward unconditional, all bearers, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		SS 1.1.1	
4	$ME \rightarrow USER$	Display "Call Forward"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	
		SS 1.1.1	

#### PROACTIVE COMMAND: SEND SS 1.1.1

## Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Call Forward"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

#### Coding:

BER-TLV:	D0	27	81	03	01	11	00	82	02	81	83	85
	0C	43	61	6C	6C	20	46	6F	72	77	61	72
	64	89	0E	91	AA	12	0A	21	43	65	87	09
	21	43	65	87	B9							

#### **REGISTER 1.1**

Logically (only SS argument):

#### REGISTER SS ARGUMENT

SS-Code:

- Call Forwarding Unconditional

TeleserviceCode

- All Tele Services

ForwardedToNumber

- nature of address ind.: international

- numbering plan ind.: ISDN/Telephony (E.164)

- TBCD String: 01234567890123456789

#### Coding:

BER-TLV	30	13	04	01	21	83	01	00	84	0B	91	10
-	32	54	76	98	10	32	54	76	98			

#### RELEASE COMPLETE (SS RETURN RESULT) 1.1

Logically (only from operation code):

# REGISTER SS RETURN RESULT

ForwardingInfo

SS-Code

- Call Forwarding Unconditional

Forward Feature List

ForwardingFeature

TeleserviceCode

- All Tele Services

#### SS-Status

- state ind.: operative

- provision ind.: provisioned

- registration ind.: registered

- activation ind.: active

#### ForwardedToNumber

- nature of address ind.: international

- numbering plan ind.: ISDN/Telephony (E.164)

- TBCD String: 01234567890123456789

# Coding:

BER-TLV	0A	A0	1A	04	01	21	30	15	30	13	83	01
	00	84	01	07	84	0B	91	10	32	54	76	98
	10	32	54	76	98							

#### TERMINAL RESPONSE: SEND SS 1.1.1

#### Logically:

Command details

Command number: 1

Command type: SEND SS

Command qualifier: "00"

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

BER-TLV:	81	03	01	11	00	82	02	82	81	03	1E
-	00	0A	A0	1A	04	01	21	30	15	30	13
	83	01	00	84	01	07	85	0B	91	10	32
	54	76	98	10	32	54	76	98			

## Expected Sequence 1.2 (SEND SS, call forward unconditional, all bearers, Return Error)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND SS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND SS 1.1.1	
4	$ME \rightarrow USER$	Display "Call Forward"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN ERROR) 1.1	[Return Error]
7	$ME \to SIM$	TERMINAL RESPONSE: SEND SS 1.2.1	

## RELEASE COMPLETE (SS RETURN ERROR) 1.1

Logically (only from error code):

Error Code: Facility not supported

Coding:

BER-TLV 02 11 15

TERMINAL RESPONSE: SEND SS 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: SS Return Error Additional information: Error Code

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	02
_	34	15									

## Expected Sequence 1.3 (SEND SS, call forward unconditional, all bearers, Reject)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND SS 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND SS 1.1.1	
4	$ME \rightarrow USER$	Display "Call Forward"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS REJECT) 1.1.	[Reject]
7	$ME \to SIM$	TERMINAL RESPONSE: SEND SS 1.3.1	

# RELEASE COMPLETE (SS REJECT) 1.1

Logically (only from problem code):

Problem Code:

- General problem
- Unrecognized component

|--|

**TERMINAL RESPONSE: SEND SS 1.3.1** 

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: SS Return Error

Additional information: No specific cause can be given

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	02
	34	00									

# Expected Sequence 1.4 (SEND SS, call forward unconditional, all bearers, successful, SS request size limit)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND SS 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND SS 1.4.1	
4	$ME \rightarrow USER$	Display "Call Forward"	
5	$ME \to SS$	REGISTER 1.2	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN RESULT) 1.2	[Successful]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND SS 1.4.1	

PROACTIVE COMMAND: SEND SS 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Call Forward"

SS String

TON: International

NPI: "ISDN / telephone numbering plan"

SS string: "\*\*21\*+01234567890123456789012345678901234567\*11#"

BER-TLV:	D0	32	81	03	01	11	00	82	02	81	83	85
	0C	43	61	6C	6C	20	46	6F	72	77	61	72
	64	89	19	91	AA	12	0A	21	43	65	87	09
	21	43	65	87	09	21	43	65	87	09	21	43
	65	A7	11	FB								

## **REGISTER 1.2**

Logically (only SS argument):

#### REGISTER SS ARGUMENT

Register SSArg

SS-Code

Call Forwarding Unconditional

TeleserviceCode

Telephony

Forwarded To Number

nature of address ind.: international

numbering plan ind.: ISDN/Telephony (E.164)

TBCD String: 0123456789012345678901234567

#### Coding:

BER-TLV	30	1C	04	01	21	83	01	11	84	14	91	10
-	32	54	76	98	10	32	54	76	98	10	32	54
	76	98	10	32	54	76						

## RELEASE COMPLETE (SS RETURN RESULT) 1.2

Logically (only from operation code):

# REGISTER SS RETURN RESULT

Forwarding Info

SS-Code

- Call Forwarding Unconditional

ForwardFeatureList

ForwardingFeature

TeleserviceCode

- Telephony

SS-Status

- state ind .: operative

- provision ind.: provisioned

- registration ind.: registered

- activation ind.: active

ForwardedToNumber

- nature of address ind.: international

- numbering plan ind.: ISDN/Telephony (E.164)

- TBCD String: 0123456789012345678901234567

BER-TLV	0A	A0	23	04	01	21	30	1E	30	1C	83	01
	11	84	01	07	84	14	91	10	32	54	76	98
	10	32	54	76	98	10	32	54	76	98	10	32
	54	76										

TERMINAL RESPONSE: SEND SS 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	27
	00	0A	A0	23	04	01	21	30	1E	30	1C
	83	01	11	84	01	07	84	14	91	10	32
	54	76	98	10	32	54	76	98	10	32	54
	76	98	10	32	54	76					

## Expected Sequence 1.5 (SEND SS, interrogate CLIR status, successful, alpha identifier limits)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND SS 1.5.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND SS 1.5.1	
4	$ME \to USER$	Display "Even if the Fixed Dialling Number service is	
		enabled, the supplementary service control string	
		included in the SEND SS proactive command shall not	
		be checked against those of the FDN list. Upon	
		receiving this command, the ME shall deci"	
5	/ 00	REGISTER 1.3	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN RESULT) 1.3	[Successful]
7	$ME \to SIM$	TERMINAL RESPONSE: SEND SS 1.5.1	

PROACTIVE COMMAND: SEND SS 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Even if the Fixed Dialling Number service is enabled, the supplementary service

control string included in the SEND SS proactive command shall not be checked against those of the FDN list. Upon receiving this command, the ME shall deci"

SS String

TON: Undefined NPI: Undefined SS string: "\*#31#"

BER-TLV:	D0	81	FD	81	03	01	11	00	82	02	81	83
	85	81	EB	45	76	65	6E	20	69	66	20	74
	68	65	20	46	69	78	65	64	20	44	69	61
	6C	6C	69	6E	67	20	4E	75	6D	62	65	72
	20	73	65	72	76	69	63	65	20	69	73	20
	65	6E	61	62	6C	65	64	2C	20	74	68	65
	20	73	75	70	70	6C	65	6D	65	6E	74	61
	72	79	20	73	65	72	76	69	63	65	20	63
	6F	6E	74	72	6F	6C	20	73	74	72	69	6E
	67	20	69	6E	63	6C	75	64	65	64	20	69
	6E	20	74	68	65	20	53	45	4E	44	20	53
	53	20	70	72	6F	61	63	74	69	76	65	20
	63	6F	6D	6D	61	6E	64	20	73	68	61	6C
	6C	20	6E	6F	74	20	62	65	20	63	68	65
	63	6B	65	64	20	61	67	61	69	6E	73	74
	20	74	68	6F	73	65	20	6F	66	20	74	68
	65	20	46	44	4E	20	6C	69	73	74	2E	20
	55	70	6F	6E	20	72	65	63	65	69	76	69
	6E	67	20	74	68	69	73	20	63	6F	6D	6D
	61	6E	64	2C	20	74	68	65	20	4D	45	20
	73	68	61	6C	6C	20	64	65	63	69	89	04
	FF	BA	13	FB								

#### **REGISTER 1.3**

Logically (only SS argument):

## INTERROGATE SS ARGUMENT

SS-Code

- Calling Line Id Restriction

Coding:

BER-TLV	30	0.3	04	01	12
D = 1 \ 1 = V		00	<b>.</b>	<b>.</b>	

# RELEASE COMPLETE (SS RETURN RESULT) 1.3

Logically (only from operation code):

## INTERROGATE SS RESULT

CliRestrictionInfo

SS-Status

- state ind.: operative

provision ind.: provisionedregistration ind.: registeredactivation ind.: not active

CliRestrictionOption

- Temporary Def Allowed

BER-TLV	0E	A4	06	04	01	06	0A	01	02

**TERMINAL RESPONSE: SEND SS 1.5.1** 

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Additional information

Operation Code: SS Code

Parameters: SS Return Result

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	0A
	00	0E	A4	06	04	01	06	0A	01	02	

# Expected Sequence 1.6 (SEND SS, call forward unconditional, all bearers, successful, null data alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND SS 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND SS 1.6.1	
4		Should not give any information to the user on the fact that the ME is sending an SS request	
5		REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN RESULT) 1.1	[Successful]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND SS 1.1.1	

PROACTIVE COMMAND: SEND SS 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: null data object

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

BER-TLV:	D0	1B	81	03	01	11	00	82	02	81	83	85
	00	89	0E	91	AA	12	0A	21	43	65	87	09
	21	43	65	87	B9							

#### 27.22.4.11.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1 to 1.6.

## 27.22.4.11.2 SEND SS (Icon support)

27.22.4.11.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.11.2.2 Conformance requirement

27.22.4.11.2.3 Test purpose

To verify that the ME displays the text contained in the SEND SS proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

#### 27.22.4.11.2.4 Method of test

#### 27.22.4.11.2.4.1 Initial conditions

The ME is connected to the System Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

The elementary files are coded as Toolkit default.

#### 27.22.4.11.2.4.2 Procedure

# Expected Sequence 2.1A (SEND SS, call forward unconditional, all bearers, successful, basic icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND	
		SS 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND SS 2.1.1	[BASIC-ICON, self-explanatory]
4	$ME \rightarrow USER$	Display the icon without the alpha identifier	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN	[Successful]
		RESULT) 1.1	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND SS 2.1.1A	[Command performed successfully]

#### PROACTIVE COMMAND: SEND SS 2.1.1

#### Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Basic Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

Icon Identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon Identifier:} & \mbox{record 1 in } \mbox{EF}_{(IMG)} \end{array}$ 

## Coding:

BER-TLV:	D0	29	81	03	01	11	00	82	02	81	83	85
-	0A	42	61	73	69	63	20	49	63	6F	6E	89
	0E	91	AA	12	0A	21	43	65	87	09	21	43
	65	87	B9	9E	02	00	01					

TERMINAL RESPONSE: SEND SS 2.1.1A

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

# Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	1E
	00	0A	A0	1A	04	01	21	30	15	30	13
	83	01	00	84	01	07	85	0B	91	10	32
	54	76	98	10	32	54	76	98			

# Expected Sequence 2.1B (SEND SS, call forward unconditional, all bearers, successful, basic icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, self-explanatory]
		SS 2.1.1	
4	$ME \rightarrow USER$	Display "Basic Icon" without the	
		icon	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully, but
		SS 2.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: SEND SS 2.1.1B

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:

81	03	01	11	00	82	02	82	81	03	1E
04	0A	A0	1A	04	01	21	30	15	30	13
83	01	00	84	01	07	85	0B	91	10	32
54	76	98	10	32	54	76	98			

# Expected Sequence 2.2A (SEND SS, call forward unconditional, all bearers, successful, colour icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[COLOUR-ICON, self-explanatory]
		SS 2.2.1	
4	$ME \rightarrow USER$	Display the icon	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SS 2.1.1A	

PROACTIVE COMMAND: SEND SS 2.2.1

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Colour Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

Icon Identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon Identifier:} & \mbox{record 2 in } EF_{(IMG)} \end{array}$ 

BER-TLV:	D0	2A	81	03	01	11	00	82	02	81	83	85
	0B	43	6F	6C	6F	75	72	20	49	63	6F	6E
	89	0E	91	AA	12	0A	21	43	65	87	09	21
	43	65	87	B9	9E	02	00	02				

# Expected Sequence 2.2B (SEND SS, call forward unconditional, all bearers, successful, colour icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[COLOUR-ICON, self-explanatory]
		SS 2.2.1	
4	$ME \rightarrow USER$	Display "Colour Icon" without the	
		icon	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed but requested icon
		SS 2.1.1B	could not be displayed]

# Expected Sequence 2.3A (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, non self-explanatory]
		SS 2.3.1	
4	$ME \rightarrow USER$	Display "Basic Icon" and the icon	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SS 2.1.1A	

#### PROACTIVE COMMAND: SEND SS 2.3.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Text: "Basic Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

BER-TLV:	D0	29	81	03	01	11	00	82	02	81	83	85
	0A	42	61	73	69	63	20	49	63	6F	6E	89
	0E	91	AA	12	0A	21	43	65	87	09	21	43
	65	87	B9	9E	02	01	01					

# Expected Sequence 2.3B (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, non self-explanatory]
		SS 2.3.1	
4	$ME \rightarrow USER$	Display "Basic Icon" without the	
		icon	
5	/ 00	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed but requested icon
		SS 2.1.1B	could not be displayed]

# Expected Sequence 2.4 (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory, no alpha identifier presented)

	Step	Direction	MESSAGE / Action	Comments
	1	$SIM \to ME$	PROACTIVE COMMAND PENDING:	
			SEND SS 2.4.1	
	2	$ME \to SIM$	FETCH	
	3	$SIM \to ME$	PROACTIVE COMMAND: SEND SS 2.4.1	[BASIC-ICON, non self-explanatory]
L	4	$ME \to SIM$	TERMINAL RESPONSE: SEND SS 2.4.1	[Command data not understood by ME]

#### PROACTIVE COMMAND: SEND SS 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

BER-TLV:	D0	1D	81	03	01	11	00	82	02	81	83	89
_	0E	91	AA	12	0A	21	43	65	87	09	21	43
	65	87	B9	9E	02	01	01					

TERMINAL RESPONSE: SEND SS 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	83	01	32
DEIX IEV.	0.	00	0.		00	02	02	02		00	0.	02

#### 27.22.4.11.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1A to 2.4.

#### 27.22.4.11.3 SEND SS (UCS2 support)

27.22.4.11.3.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.11.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in: ISO/IEC 10646 [17].

#### 27.22.4.11.3.3 Test purpose

To verify that the ME displays the UCS2 text contained in the SEND SS proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.11.3.4 Method of test

27.22.4.11.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

#### 27.22.4.11.3.4.2 Procedure

# Expected Sequence 3.1 (SEND SS, call forward unconditional, all bearers, successful, UCS2 text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		SS 3.1.1	
4	$ME \rightarrow USER$	Display "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \to SIM$	TERMINAL RESPÓNSE: SEND	[Command performed successfully]
		SS 1.1.1	

#### PROACTIVE COMMAND: SEND SS 3.1.1

## Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "\*\*21\*+01234567890123456789#"

#### Coding:

BER-TLV:	D0	34	81	03	01	11	00	82	02	81	83	85
	19	80	04	17	04	14	04	20	04	10	04	12
	04	21	04	22	04	12	04	23	04	19	04	22
	04	15	89	0E	91	AA	12	0A	21	43	65	87
	09	21	43	65	87	B9						

# 27.22.4.11.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

## 27.22.4.12 SEND USSD

## 27.22.4.12.1 SEND USSD (normal)

## 27.22.4.12.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.12.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send USSD facility as defined in:

- 3GPP TS 11.14 [15] clause 6.1, clause 6.4.12, clause 6.6.11, clause 12.12.7, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.17, clause 12.31 and clause 6.5.4.
- 3GPP TS 03.38 [7] clause 5.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in: ISO/IEC 10646 [17].

#### 27.22.4.12.1.3 Test purpose

To verify that the ME correctly translates and sends the unstructured supplementary service request indicated in the SEND USSD proactive SIM command to the system Simulator.

To verify that the ME returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the USSD request and including a USSD result as a text string in the TERMINAL RESPONSE.

#### 27.22.4.12.1.4 Method of test

#### 27.22.4.12.1.4.1 Initial conditions

The ME is connected to the System Simulator and the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

#### 27.22.4.12.1.4.2 Procedure

#### Expected Sequence 1.1 (SEND USSD, 7-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		USSD 1.1.1	
4	$ME \rightarrow USER$	Display "7-bit USSD"	
5	ME  o SS	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.1	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	
		USSD 1.1.1	

## PROACTIVE COMMAND: SEND USSD 1.1.1

#### Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "7-bit USSD"

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

BER-TLV:	D0	50	81	03	01	12	00	82	02	81	83	85
	0A	37	2D	62	69	74	20	55	53	53	44	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	В3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60		

#### **REGISTER 1.1**

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

## Coding:

BER-TLV	30	3D	04	01	F0	04	38	41	E1	90	58	34
	1E	91	49	E5	92	D9	74	3E	A1	51	E9	94
	5A	B5	5E	B1	59	6D	2B	2C	1E	93	СВ	E6
	33	3A	AD	5E	В3	DB	EE	37	3C	2E	9F	D3
	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD	76
	C3	E5	60									

## RELEASE COMPLETE (SS RETURN RESULT) 1.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

## Coding:

BER-TLV	30	1E	04	01	F0	04	19	D5	E9	94	08	9A
_	D3	E5	69	F7	19	24	2F	8F	CB	69	7B	99
	0C	32	CB	DF	6D	D0	74	0A				

## TERMINAL RESPONSE: SEND USSD 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

**Text String** 

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01
	00	8D	1A	00	D5	E9	94	80	9A	D3	E5
	69	F7	19	24	2F	8F	СВ	69	7B	99	0C
	32	CB	DF	6D	D0	74	0A				

## Expected Sequence 1.2 (SEND USSD, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		USSD 1.2.1	
4	$ME \rightarrow USER$	Display "8-bit USSD"	
5	$ME \to SS$	REGISTER 1.2	
6	$SS \to ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.2	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND	
		SS 1.2.1	

## PROACTIVE COMMAND: SEND USSD 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "8-bit USSD"

**USSD String** 

Data coding scheme: Uncompressed, no message class meaning, 8-bit data

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

# Coding:

BER-TLV:	D0	58	81	03	01	12	00	82	02	81	83	85
\ <u>-</u>	0A	38	2D	62	69	74	20	55	53	53	44	8A
	41	44	41	42	43	44	45	46	47	48	49	4A
	4B	4C	4D	4E	4F	50	51	52	53	54	55	56
	57	58	59	5A	2D	61	62	63	64	65	66	67
	68	69	6A	6B	6C	6D	6E	6F	70	71	72	73
	74	75	76	77	78	79	7A	2D	31	32	33	34
	35	36	37	38	39	30						

## **REGISTER 1.2**

Logically (only USSD argument):

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, 8-bit data

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

BER-TLV	30	45	04	01	44	04	40	41	42	43	44	45
	46	47	48	49	4A	4B	4C	4D	4E	4F	50	51
	52	53	54	55	56	57	58	59	5A	2D	61	62
	63	64	65	66	67	68	69	6A	6B	6C	6D	6E
	6F	70	71	72	73	74	75	76	77	78	79	7A
	2D	31	32	33	34	35	36	37	38	39	30	

# RELEASE COMPLETE (SS RETURN RESULT) 1.2

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, 8-bit data

USSD string:

- "USSD string received from SS"

#### Coding:

BER-TLV	30	21	04	01	44	04	1C	55	53	53	44	20
	73	74	72	69	6E	67	20	72	65	63	65	69
	76	65	64	20	66	72	6F	6D	20	53	53	

TERMINAL RESPONSE: SEND USSD 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: Uncompressed, no message class meaning, 8-bit data

String: "USSD string received from SS"

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01
	00	8D	1D	04	55	53	53	44	20	73	74
	72	69	6E	67	20	72	65	63	65	69	76
	65	64	20	66	72	6F	6D	20	53	53	

## Expected Sequence 1.3 (SEND USSD, UCS2 data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
		USSD 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND USSD 1.3.1	
4	$ME \rightarrow USER$	Display "UCS2 USSD"	
5	$ME \to SS$	REGISTER 1.3	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN RESULT)	["USSD string received from SS"]
		1.3	-
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND SS 1.3.1	

PROACTIVE COMMAND: SEND USSD 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "UCS2 USSD"

**USSD String** 

Data coding scheme: Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string: "ЗДРАВСТВУЙТЕ" ("Hello" in Russian)

Coding:

BER-TLV:	D0	2F	81	03	01	12	00	82	02	81	83	85
_	09	55	43	53	32	20	55	53	53	44	8A	19
	48	04	17	04	14	04	20	04	10	04	12	04
	21	04	22	04	12	04	23	04	19	04	22	04
	15											

#### **REGISTER 1.3**

Logically (only USSD argument):

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string:

- "ЗДРАВСТВУЙТЕ" ("Hello" in Russian)

Coding:

BER-TLV	30	1D	04	01	48	04	18	04	17	04	14	04
	20	04	10	04	12	04	21	04	22	04	12	04
	23	04	19	04	22	04	15					

## RELEASE COMPLETE (SS RETURN RESULT) 1.3

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string:

- "USSD string received from SS"

#### Coding:

BER-TLV	30	3D	04	01	48	04	38	00	55	00	53	00
	53	00	44	00	20	00	73	00	74	00	72	00
	69	00	6E	00	67	00	20	00	72	00	65	00
	63	00	65	00	69	00	76	00	65	00	64	00
	20	00	66	00	72	00	6F	00	6D	00	20	00
	53	00	53									

TERMINAL RESPONSE: SEND USSD 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: Uncompressed, no message class meaning, UCS2 (16 bit)

String: "USSD string received from SS"

Coding:

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01
	00	8D	39	08	00	55	00	53	00	53	00
	44	00	20	00	73	00	74	00	72	00	69
	00	6E	00	67	00	20	00	72	00	65	00
	63	00	65	00	69	00	76	00	65	00	64
	00	20	00	66	00	72	00	6F	00	6D	00
	20	00	53	00	53						

## Expected Sequence 1.4 (SEND USSD, 7-bit data, unsuccessful (Return Error))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND USSD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND USSD 1.1.1	
4	$ME \rightarrow USER$	Display "7-bit USSD"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN ERROR) 1.1	Return Error
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND USSD 1.4.1	

## RELEASE COMPLETE (SS RETURN ERROR) 1.1

Logically (only from Return Error code):

ProcessUnstructuredSS-Request RETURN ERROR

Return Error code:

- Unknown alphabet

TERMINAL RESPONSE: SEND USSD 1.4.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier:

Device identities

Source device: ME Destination device: SIM

Result

General Result: USSD Return Error Additional information: "Unknown alphabet"

"00"

Coding:

BER-TLV:	81	03	01	12	00	82	02	82	81	83	02
	37	47									

## Expected Sequence 1.5 (SEND USSD, 7-bit data, unsuccessful (Reject))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND USSD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND USSD 1.1.1	
4	$ME \rightarrow USER$	Display "7-bit USSD"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS REJECT) 1.1	Reject
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND USSD 1.5.1	

## RELEASE COMPLETE (SS REJECT) 1.1

Logically (only from Problem code):

ProcessUnstructuredSS-Request REJECT

Invoke Problem code:

- Mistyped parameter

Coding:

BER-TLV	81	01	02
---------	----	----	----

TERMINAL RESPONSE: SEND <u>U</u>SSD 1.5.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: USSD Return Error

Additional information: "No specific cause can be given"

Coding:

BER-TLV:	81	03	01	12	00	82	02	82	81	83	02
	37	00									

# Expected Sequence 1.6 (SEND USSD, 256 octets, 7-bit data, successful, long alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND	
		USSD 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND USSD 1.6.1	
4	$ME \rightarrow USER$	Display "once a RELEASE COMPLETE	
		message containing the USSD Return Result	
		message not containing an error has been	
		received from the network, the ME shall	
		inform the SIM that the command has"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN	["USSD string received from SS"]
		RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "once a RELEASE COMPLETE message containing the USSD Return Result

message not containing an error has been received from the network, the ME shall

inform the SIM that the command has"

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

## Coding:

BER-TLV:	D0	81	FD	81	03	01	12	00	82	02	81	83
	85	81	В6	6F	6E	63	65	20	61	20	52	45
	4C	45	41	53	45	20	43	4F	4D	50	4C	45
	54	45	20	6D	65	73	73	61	67	65	20	63
	6F	6E	74	61	69	6E	69	6E	67	20	74	68
	65	20	55	53	53	44	20	52	65	74	75	72
	6E	20	52	65	73	75	6C	74	20	6D	65	73
	73	61	67	65	20	6E	6F	74	20	63	6F	6E
	74	61	69	6E	69	6E	67	20	61	6E	20	65
	72	72	6F	72	20	68	61	73	20	62	65	65
	6E	20	72	65	63	65	69	76	65	64	20	66
	72	6F	6D	20	74	68	65	20	6E	65	74	77
	6F	72	6B	2C	20	74	68	65	20	4D	45	20
	73	68	61	6C	6C	20	69	6E	66	6F	72	6D
	20	74	68	65	20	53	49	4D	20	74	68	61
	74	20	74	68	65	20	63	6F	6D	6D	61	6E
	64	20	68	61	73	8A	39	F0	41	E1	90	58
	34	1E	91	49	E5	92	D9	74	3E	A1	51	E9
	94	5A	B5	5E	B1	59	6D	2B	2C	1E	93	CB
	E6	33	3A	AD	5E	В3	DB	EE	37	3C	2E	9F
	D3	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD
	76	C3	E5	60								

## Expected Sequence 1.7 (SEND USSD, 7-bit data, successful, no alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND	
		USSD 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND USSD 1.7.1	
4	$ME \to USER$	Optionally display an informative message	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN RESULT)	["USSD string received from SS"]
		1.1	
7	$ME \to SIM$	TERMINAL RESPONSE: SEND USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.7.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

## Coding:

BER-TLV:	D0	44	81	03	01	12	00	82	02	81	83	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	B3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60		

## Expected Sequence 1.8 (SEND USSD, 7-bit data, successful, null length alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND	
		USSD 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND USSD 1.8.1	
4	$ME \rightarrow USER$	the ME should not give any information to the	
		user on the fact that the ME is sending a USSD	
		request	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN RESULT)	["USSD string received from SS"]
		1.1	-
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.8.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: ""

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

#### Coding:

BER-TLV:	D0	46	81	03	01	12	00	82	02	81	83	85
	00	8A	39	F0	41	E1	90	58	34	1E	91	49
	E5	92	D9	74	3E	A1	51	E9	94	5A	B5	5E
	B1	59	6D	2B	2C	1E	93	CB	E6	33	3A	AD
	5E	В3	DB	EE	37	3C	2E	9F	D3	EB	F6	3B
	3E	AF	6F	C5	64	33	5A	CD	76	C3	E5	60

## 27.22.4.12.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 - 1.8.

## 27.22.4.12.2 SEND USSD (Icon support)

27.22.4.12.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.12.2.2 Conformance requirement

27.22.4.12.2.3 Test purpose

To verify that the ME displays the text contained in the SEND USSD proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.12.2.4 Method of test

27.22.4.12.2.4.1 Initial conditions

The ME is connected to the System Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator

The elementary files are coded as Toolkit default.

#### 27.22.4.12.2.4.2 Procedure

# Expected Sequence 2.1A (SEND USSD, 7-bit data, successful, basic icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND	
		USSD 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND USSD 2.1.1	[BASIC-ICON, self-explanatory]
4	$ME \rightarrow USER$	Display BASIC ICON	
5	$ME \to SS$	REGISTER 2.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN	["USSD string received from SS"]
		RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND USSD 2.1.1A	[Command performed successfully]

#### PROACTIVE COMMAND: SEND USSD 2.1.1

### Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Basic Icon"

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in  $EF_{(IMG)}$ 

## Coding:

BER-TLV:	D0	54	81	03	01	12	00	82	02	81	83	85
	0A	42	61	73	69	63	20	49	63	6F	6E	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	В3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60	9E	02
	00	01										

#### **REGISTER 2.1**

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

## Coding:

BER-TLV	30	3D	04	01	F0	04	38	41	E1	90	58	34
	1E	91	49	E5	92	D9	74	3E	A1	51	E9	94
	5A	B5	5E	B1	59	6D	2B	2C	1E	93	CB	E6
	33	3A	AD	5E	В3	DB	EE	37	3C	2E	9F	D3
	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD	76
	C3	E5	60									

## RELEASE COMPLETE (SS RETURN RESULT) 2.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

### Coding:

BER-TLV	30	1E	04	01	F0	04	19	D5	E9	94	08	9A
	D3	E5	69	F7	19	24	2F	8F	CB	69	7B	99
	0C	32	CB	DF	6D	D0	74	0A				_

TERMINAL RESPONSE: SEND USSD 2.1.1A

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

**Text String** 

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01
	00	8D	1A	00	D5	E9	94	80	9A	D3	E5
	69	F7	19	24	2F	8F	CB	69	7B	99	0C
	32	CB	DF	6D	D0	74	0A				

# Expected Sequence 2.1B (SEND USSD, 7-bit data, successful, basic icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, self-explanatory]
		USSD 2.1.1	
4	$ME \rightarrow USER$	Display "Basic Icon" without the	
		icon	
5	$ME \to SS$	REGISTER 2.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed but requested icon
		USSD 2.1.1B	could not be displayed]

TERMINAL RESPONSE: SEND USSD 2.1.1B

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

**Text String** 

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01
	04	8D	1A	00	D5	E9	94	80	9A	D3	E5
	69	F7	19	24	2F	8F	CB	69	7B	99	0C
	32	СВ	DF	6D	D0	74	0A				

## Expected Sequence 2.2 (SEND USSD, 7-bit data, successful, colour icon self explanatory)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[COLOUR-ICON, self-explanatory]
		USSD 2.2.1	
4	$ME \rightarrow USER$	Display COLOUR-ICON	
		or	
		May give information to user	
		concerning what is happening	
5	/ 00	REGISTER 2.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$		[Command performed successfully]
		USSD 2.1.1A	or
			[Command performed but requested icon
		TERMINAL RESPONSE: SEND	could not be displayed]
		USSD 2.1.1B	

PROACTIVE COMMAND: SEND USSD 2.2.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Color Icon"

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 2 in  $EF_{(IMG)}$ 

BER-TLV:	D0	54	81	03	01	12	00	82	02	81	83	85
	0A	43	6F	6C	6F	72	20	49	63	6F	6E	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	В3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60	9E	02
	00	02										

# Expected Sequence 2.3A (SEND USSD, 7-bit data, successful, basic icon non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, non self-explanatory]
		USSD 2.3.1	
4	$ME \rightarrow USER$	Display "Basic Icon" and BASIC-	
		ICON	
_		DECICTED 6.4	
5	/ 00	REGISTER 2.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		USSD 2.1.1A	

PROACTIVE COMMAND: SEND USSD 2.3.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Basic Icon"

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

BER-TLV:	D0	54	81	03	01	12	00	82	02	81	83	85
'-	0A	42	61	73	69	63	20	49	63	6F	6E	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	В3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60	9E	02
	01	01										

# Expected Sequence 2.3B (SEND USSD, 7-bit data, successful, basic icon non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, non self-explanatory]
		USSD 2.3.1	
4	ME  o	Display "Basic Icon" without the	
	USER	icon	
5	$ME \rightarrow SS$	REGISTER 2.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed but requested icon
		USSD 2.1.1B	could not be displayed]

# Expected Sequence 2.4 (SEND USSD, 7-bit data, basic icon non self-explanatory, no alpha identifier presented)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, non self-explanatory]
		USSD 2.4.1	·
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command data not understood by ME]
		USSD 2.4.1	

PROACTIVE COMMAND: SEND USSD 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in  $EF_{(IMG)}$ 

BER-TLV:	D0	48	81	03	01	12	00	82	02	81	83	8A	l
	39	F0	41	E1	90	58	34	1E	91	49	E5	92	
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59	l
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	B3	l
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF	l
	6F	C5	64	33	5A	CD	76	C3	E5	60	9E	02	l
	01	01											

TERMINAL RESPONSE: SEND USSD 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01	32

#### 27.22.4.12.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 - 2.4.

### 27.22.4.12.3 SEND USSD (UCS2 support)

27.22.4.12.3.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.12.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646 [17].

#### 27.22.4.12.3.3 Test purpose

To verify that the ME displays the UCS2 text contained in the SEND USSD proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.12.3.4 Method of test

27.22.4.12.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

#### 27.22.4.12.3.4.2 Procedure

## Expected Sequence 3.1 (SEND USSD, 7-bit data, successful, UCS2 text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
		USSD 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND USSD 3.1.1	
4	$ME \rightarrow USER$	Display "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
5	$ME \to SS$	REGISTER 3.1	
6	$SS \to ME$	RELEASE COMPLETE (SS RETURN	[Successful]
		RESULT) 3.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND USSD 3.1.1	[Command performed successfully]

#### PROACTIVE COMMAND: SEND USSD 3.1.1

## Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

**USSD String** 

Data coding scheme: 7-bit default, no message class

USSD String: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

### Coding:

BER-TLV:	D0	5F	81	03	01	12	00	82	02	81	83	85
	19	80	04	17	04	14	04	20	04	10	04	12
	04	21	04	22	04	12	04	23	04	19	04	22
	04	15	8A	39	F0	41	E1	90	58	34	1E	91
	49	E5	92	D9	74	3E	A1	51	E9	94	5A	B5
	5E	B1	59	6D	2B	2C	1E	93	CB	E6	33	3A
	AD	5E	В3	DB	EE	37	3C	2E	9F	D3	EB	F6
	3B	3E	AF	6F	C5	64	33	5A	CD	76	C3	E5
	60											

### **REGISTER 3.1**

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD String:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

## Coding:

BER-TLV	30	3D	04	01	F0	04	38	41	E1	90	58	34
	1E	91	49	E5	92	D9	74	3E	A1	51	E9	94
	5A	B5	5E	B1	59	6D	2B	2C	1E	93	CB	E6
	33	3A	AD	5E	В3	DB	EE	37	3C	2E	9F	D3
	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD	76
	C3	E5	60									

## RELEASE COMPLETE (SS RETURN RESULT) 3.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD String:

- "USSD string received from SS"

#### Coding:

BER-TLV	30	1E	04	01	F0	04	19	D5	E9	94	08	9A
	D3	E5	69	F7	19	24	2F	8F	CB	69	7B	99
	0C	32	CB	DF	6D	D0	74	0A				

## TERMINAL RESPONSE: SEND USSD 3.1.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

## Coding:

BER-TLV:	81	03	01	12	00	82	02	82	81	83	01
	00	8D	1A	00	D5	E9	94	80	9A	D3	E5
	69	F7	19	24	2F	8F	CB	69	7B	99	0C
	32	CB	DF	6D	D0	74	0A				

# 27.22.4.12.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

## 27.22.4.13 SET UP CALL

#### 27.22.4.13.1 SET UP CALL (normal)

#### 27.22.4.13.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.13.1.2 Conformance requirement

The ME shall support the Proactive SIM: Set Up Call facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.13, clause 6.6.12, clause 12.6, clause 12.7, clause 12.12, clause 12.12.3 and clause 5.2.

### 27.22.4.13.1.3 Test purpose

To verify that the ME accepts the Proactive Command - Set Up Call, displays the alpha identifier to the user, attempts to set up a call to the address and returns the result in the TERMINAL RESPONSE.

#### 27.22.4.13.1.4 Method of test

#### 27.22.4.13.1.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the system simulator.

### 27.22.4.13.1.4.2 Procedure

#### Expected Sequence 1.1 (SET UP CALL, call confirmed by the user and connected)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET	
		UP CALL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP CALL	
		1.1.1	
4	$ME \rightarrow USER$	ME displays "Not busy" during user	
		confirmation phase.	
5	$USER \to ME$	The user confirms the call set up	[user confirmation]
6	$ME \to SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT message	
		from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.1.1	[Command performed successfully]
		The ME shall not update EF LND with the	
		called party address.	
9	$USER \to ME$	The user ends the call after 5 s.	
		The ME returns to idle mode.	

### PROACTIVE COMMAND: SET UP CALL 1.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Not busy"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

#### Coding:

BER-TLV:	D0	1E	81	03	01	10	00	82	02	81	83	85
	80	4E	6F	74	20	62	75	73	79	86	09	91
	10	32	04	21	43	65	1C	2C				

#### TERMINAL RESPONSE: SET UP CALL 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00	l
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

## Expected Sequence 1.2 (SET UP CALL, call rejected by the user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		CALL 1.1.1	
4	$ME \to USER$	ME displays "Not busy" during the	
		user confirmation phase	
5	$USER \to ME$	The user rejects the set up call	[user rejects the call]
6	$ME \to SIM$	TERMINAL RESPONSE 1.2.1	[User did not accept call set-up request]
7	$ME \rightarrow USER$	The ME returns in idle mode.	

# TERMINAL RESPONSE: SET UP CALL 1.2.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: User did not accept the proactive command

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	22
		00			00	02	02	02	0.	00	0.	

## **Expected Sequence 1.3 (SET UP CALL, redial)**

The system simulator shall be configured such that call set up requests will be rejected with cause "User Busy".

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[only if not currently busy on another call with
		CALL 1.3.1	redial]
4	$ME \to USER$	ME displays "Not busy with redial"	
		during the user confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirms the call]
6	$ME \to SS$	ME attempts to set up a call to	[redial mechanism]
		"+012340123456p1p2" at least	
		twice	
7	$ME \to SIM$	TERMINAL RESPONSE 1.3.1	[network currently unable to process
			command]
8	$ME \rightarrow USER$	The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Not busy with redial"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV:	D0	2A	81	03	01	10	01	82	02	81	83	85
	14	4E	6F	74	20	62	75	73	79	20	77	69
	74	68	20	72	65	64	69	61	6C	86	09	91
	10	32	04	21	43	65	1C	2C				

TERMINAL RESPONSE: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME Destination device: SIM Result

General Result: network currently unable to process command

Additional Information: User Busy

Coding:

BER-TLV:	81	03	01	10	01	82	02	82	81	83	02	21
_	91											

## Expected Sequence 1.4 (SET UP CALL, putting all other calls on hold, ME busy)

ME is busy on a call

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET	
		UP CALL 1.4.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$		[putting all other calls on hold]
		1.4.1	
4	$ME \to USER$	ME displays "On hold" during the user	
		confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirms the call]
6	$ME \to SS$	The active call is put on hold	
7	$ME \rightarrow SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
8	$SS \to ME$	The ME receives the CONNECT message	
_		from the system simulator.	
9	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.4.1	[Command performed successfully]
40			
10	USER $\rightarrow$ ME	The user ends the call after 5 s.	
		The ME retrieves the previous call	

### PROACTIVE COMMAND: SET UP CALL 1.4.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "On hold"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV:	D0	1D	81	03	01	10	02	82	02	81	83	85
	07	4F	6E	20	68	6F	6C	64	86	09	91	10
	32	04	21	43	65	1C	2C					

TERMINAL RESPONSE: SET UP CALL 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	02	82	02	82	81	83	01	00
DEIX IEV.	01	03	01	10	02	02	02	02	01	00	01	00

## Expected Sequence 1.5 (SET UP CALL, disconnecting all other calls, ME busy)

ME is busy on a call

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET	
		UP CALL 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP CALL	[disconnecting all other calls]
		1.5.1	
4	$ME \rightarrow USER$	ME displays "Disconnect" during the user	
		confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirms the call]
6	$ME \to SS$	The ME disconnects the active call	
7	$ME \rightarrow SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
8	$SS \to ME$	The ME receives the CONNECT message	
		from the system simulator.	
9	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.5.1	[Command performed successfully]
10	$USER \to ME$	The user ends the call after 5 s.	

#### PROACTIVE COMMAND: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: disconnecting all other calls

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Disconnect"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV:	D0	20	81	03	01	10	04	82	02	81	83	85
	0A	44	69	73	63	6F	6E	6E	65	63	74	86
	09	91	10	32	04	21	43	65	1C	2C		

TERMINAL RESPONSE: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01	10 04	182 102 18	32 81 83	01 00	1
-------------------	-------	------------	----------	-------	---

## Expected Sequence 1.6 (SET UP CALL, only if not currently busy on another call, ME busy)

ME is busy on a call

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[only if not currently busy on another call]
		CALL 1.1.1	
4	$ME \to SIM$	TERMINAL RESPONSE 1.6.1	[ME currently unable to process command]

#### TERMINAL RESPONSE: SET UP CALL 1.6.1

## Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional Information: ME currently busy on call

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	02	20
	02											

## Expected Sequence 1.7 (SET UP CALL, putting all other calls on hold, call hold is not allowed)

ME is busy on a call. The system simulator shall be configured to not allow Call Hold.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.4.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[putting all other calls on hold]
		CALL 1.4.1	
4	$ME \to USER$	ME displays "On hold" during the	
		user confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirms the call]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.7.1	[Network currently unable to process command]

TERMINAL RESPONSE: SET UP CALL 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME Destination device: SIM

Result

General Result: Network currently unable to process command

Additional Information: No specific cause can be given

Coding:

BER-TLV:	81	03	01	10	02	82	02	82	81	83	02	21
_	00											

## **Expected Sequence 1.8 (SET UP CALL, Capability configuration)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.8.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[Capability configuration parameters: full rate
		CALL 1.8.1	support]
4	$ME \to USER$	ME displays "Capability config"	
		during the user confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \to SS$	The ME attempts to set up a call to	
		"+012340123456p1p2" using the	
		capability configuration parameters	
_		supplied by SIM	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	10 1 1 1 1 1
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.8.1	[Command performed successfully]
9	LICED . ME	The user ands the call	
9	$USER \to ME$	The user ends the call	
		The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.8.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Capability config"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Capability configuration parameters

Information transfer cap: full rate support only MS

BER-TLV:	D0	2B	81	03	01	10	00	82	02	81	83	85
	11	43	61	70	61	62	69	6C	69	74	79	20
	63	6F	6E	66	69	67	86	09	91	10	32	04
	21	43	65	1C	2C	87	02	01	20			

TERMINAL RESPONSE: SET UP CALL 1.8.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00
D	<b>.</b>	-	<b>.</b>		00		~_					

#### Expected Sequence 1.9 (SET UP CALL, max dialling number string, no alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE SET UP CALL 1.9.1	[dialling number string, no alpha identifier]
4	$USER \to ME$	The user confirms the set up call	[user confirmation]
5	$ME \rightarrow SS$	The ME attempts to set up a call to	
		"012345678901234567890123456	
		789*#*#*#*#0123456789012345	
		67890123456789*#*#*#*#"	
6	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.9.1	[Command performed successfully]
8	USER $\rightarrow$ ME	The user ends the call	
		The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.9.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Address

TON: International

NPI: ISDN / telephone numbering plan

789\*#\*#\*#\*#\*# "

## Coding:

BER-TLV:	D0		34	81	03	01	10	01	82	02	81	83
	86		29	91	10	32	54	76	98	10	32	54
	76	98	10	32	54	76	98	BA	BA	BA	BA	BA
	10	32	54	76	98	10	32	45	67	89	01	32
	54	76	98	BA	BA	BA	BA	BA				

TERMINAL RESPONSE: SET UP CALL 1.9.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	01	82	02	82	81	83	01	00
DEIX IEV.	01	00	01	10	01	02	02	02	01	00	01	00

## Expected Sequence 1.10 (SET UP CALL,256 octets length, long first alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP	
		CALL 1.10.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP CALL	[ alpha identifier]
		1.10.1	
4	$ME \to USER$	ME displays "Three types are defined: - set up	
		a call, but only if not currently busy on another	
		call; - set up a call, putting all other calls (if any)	
		on hold; - set up a call, disconnecting all other	
		calls (if any) first. For each of these types, "	
_		during the user confirmation phase.	
5		The user confirms the set up call	[user confirmation]
6	ME→SS	The ME attempts to set up a call to "+01"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from	
_		the system simulator.	
8	,	TERMINAL RESPONSE 1.10.1	[Command performed successfully]
9	USER $\rightarrow$ ME	The user ends the call	
		The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Three types are defined: - set up a call, but only if not currently busy on another

call; - set up a call, putting all other calls (if any) on hold; - set up a call, disconnecting all other calls (if any) first. For each of these types, "

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "01"

Coding:

BER-TLV:	D0	81	FD	81	03	01	10	01	82	02	81	83
	85	81	ED	54	68	72	65	65	20	74	79	70
	65	73	20	61	72	65	20	64	65	66	69	6E
	65	64	3A	20	2D	20	73	65	74	20	75	70
	20	61	20	63	61	6C	6C	2C	20	62	75	74
	20	6F	6E	6C	79	20	69	66	20	6E	6F	74
	20	63	75	72	72	65	6E	74	6C	79	20	62
	75	73	79	20	6F	6E	20	61	6E	6F	74	68
	65	72	20	63	61	6C	6C	3B	20	2D	20	73
	65	74	20	75	70	20	61	20	63	61	6C	6C
	2C	20	70	75	74	74	69	6E	67	20	61	6C
	6C	20	6F	74	68	65	72	20	63	61	6C	6C
	73	20	28	69	66	20	61	6E	79	29	20	6F
	6E	20	68	6F	6C	64	3B	20	2D	20	73	65
	74	20	75	70	20	61	20	63	61	6C	6C	2C
	20	64	69	73	63	6F	6E	6E	65	63	74	69
	6E	67	20	61	6C	6C	20	6F	74	68	65	72
	20	63	61	6C	6C	73	20	28	69	66	20	61
	6E	79	29	20	66	69	72	73	74	2E	20	46
	6F	72	20	65	61	63	68	20	6F	66	20	74
	68	65	73	65	20	74	79	70	65	73	2C	20
	86	02	91	10								

TERMINAL RESPONSE: SET UP CALL 1.10.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

DED TIVE	0.4	00	Ω1	40	04	0.0	00	0.0	0.4	0.0	Λ4	00
BER-TLV:	1 81	03	0.1	l 10	01	82	02	82	1 81	83	0.1	- 00

# Expected Sequence 1.11A (SET UP CALL, Called party subaddress, command performed successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.11.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[set up a call with called party subaddress]
		CALL 1.11.1	
4	$ME \rightarrow USER$	ME displays "Called party" during	
		the user confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	ME→SS	The ME attempts to set up a call to	
		"+012340123456p1p2" with the	
		called party subaddress	
		information	
7	$SS \rightarrow ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.11.1A	[Command performed successfully]
9	USER $\rightarrow$ ME	The user ends the call	
		The ME returns in idle mode.	

# Expected Sequence 1.11B (SET UP CALL, Called party subaddress, ME not supporting the called party subaddress)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.11.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[set up a call with called party subaddress]
		CALL 1.11.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.11.1B	[beyond ME's capabilities]

PROACTIVE COMMAND: SET UP CALL 1.11.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Called party"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012340123456p1p2"

Called party subaddress

Type of subaddress: NSAP (X.213 / ISO 8348 AD2) Odd / even indicator: even number of address signals Subaddress information: AFI, 95, 95, 95, 95, 95

BER-TLV:	D0	2B	81	03	01	10	00	82	02	81	83	85
	0C	43	61	6C	6C	65	64	20	70	61	72	74
	79	86	09	91	10	32	04	21	43	65	1C	2C
	88	07	80	50	95	95	95	95	95			

TERMINAL RESPONSE: SET UP CALL 1.11.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00

#### TERMINAL RESPONSE: SET UP CALL 1.11.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Beyond ME's capabilities

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	30

## Expected Sequence 1.12 (SET UP CALL, maximum duration for the redial mechanism)

The system simulator shall be configured such that call set up requests will be rejected with cause "User Busy".

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.12.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[only if not currently busy on another call with
		CALL 1.12.1	redial]
4	$ME \to USER$	ME displays "Duration" during the	
		user confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirms the call]
6	$ME \to SS$		[redial mechanism with maximum duration of
		"+012340123456p1p2" . It stops its	10 seconds]]
		attempts after 10 seconds.	
7	$ME \to SIM$	TERMINAL RESPONSE 1.12.1	[network currently unable to process
			command]
8	$ME \to USER$	The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.12.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Duration"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012340123456p1p2"

Duration

Unit: Seconds Interval: 10

Coding:

BER-TLV:	D0	22	81	03	01	10	01	82	02	81	83	85
	80	44	75	72	61	74	69	6F	6E	86	09	91
	10	32	04	21	43	65	1C	2C	84	02	01	0A

#### TERMINAL RESPONSE: SET UP CALL 1.12.1

#### Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME Destination device: SIM

Result

General Result: network currently unable to process command

Additional Information: User Busy

Coding:

BER-TLV:	81	03	01	10	01	82	02	82	81	83	02	21
	91											

#### 27.22.4.13.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.12.

## 27.22.4.13.2 SET UP CALL (second alpha identifier)

27.22.4.13.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.13.2.2 Conformance requirement

Same as clause 27.22.4.13.2.1.

#### 27.22.4.13.2.3 Test purpose

To verify that the ME accepts a Proactive Command - Set Up Call, displays the alpha identifiers to the user, attempts to set up a call to the address and returns the result in the TERMINAL RESPONSE.

27.22.4.13.2.4 Method of test

27.22.4.13.2.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and is in updated idle mode on the system simulator.

#### 27.22.4.13.1.4.2 Procedure

## **Expected Sequence 2.1 (SET UP CALL, two alpha identifiers)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP CALL 2.1.1	
2	ME  o SIM	FETCH	
3	/ 0	PROACTIVE COMMAND: SET UP	
	SIIVI → IVIE	CALL 2.1.1	
4	$ME \to USER$	ME displays "CONFIRMATION" during	
		the user confirmation phase	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \to SS$	The ME attempts to set up a call to	[second alpha identifier]
		"+012340123456p1p2".	
		The ME displays "CALL" if the ME	
		supports 2 <sup>nd</sup> alpha identifier or otherwise	
		"CONFIRMATION"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 2.1.1	[Command performed successfully]
		The ME shall not update EF LND with	
		the called party address.	
9	USER $\rightarrow$ ME	The user ends the call after 5 s.	
		The ME returns in idle mode.	

#### PROACTIVE COMMAND: SET UP CALL 2.1.1

## Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "CONFIRMATION"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Alpha Identifier (call set up phase): "CALL"

BER-TLV:	D0	28	81	03	01	10	00	82	02	81	83	85
	0C	43	4F	4E	46	49	52	4D	41	54	49	4F
	4E	86	09	91	10	32	04	21	43	65	1C	2C
	85	04	43	41	4C	4C						

TERMINAL RESPONSE: SET UP CALL 2.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00

#### 27.22.4.13.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

### 27.22.4.13.3 SET UP CALL (display of icons)

27.22.4.13.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.13.3.2 Conformance requirement

27.22.4.13.3.3 Test purpose

To verify that the ME accepts a Proactive Set Up Call , displays the message or icon to the user ,attempts to set up a call to the address, returns the result in the TERMINAL response.

27.22.4.13.3.4 Method of test

27.22.4.13.3.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and is in updated idle mode on the system simulator.

#### 27.22.4.13.3.4.2 Procedure

# Expected Sequence 3.1A (SET UP CALL, display of basic icon during confirmation phase, not self-explanatory, successful)

Direction	MESSAGE / Action	Comments
$SIM \to ME$	PROACTIVE COMMAND	
	PENDING: SET UP CALL 3.1.1	
$ME \to SIM$	FETCH	
$SIM \to ME$	PROACTIVE COMMAND: SET UP	Including icon identifier, icon shall be
		displayed in addition of the first alpha
		identifier
$ME \rightarrow USER$		
	•	
	· ·	[user confirmation]
ME→SS		
$SS \rightarrow ME$		
$ME \rightarrow SIM$	TERMINAL RESPONSE 3.1.1A	[Command performed successfully]
USER → ME	The user ends the call after 5 s	
OOLIN - IVIL		
	$\begin{array}{c} \text{SIM} \rightarrow \text{ME} \\ \text{ME} \rightarrow \text{SIM} \\ \text{SIM} \rightarrow \text{ME} \\ \\ \text{ME} \rightarrow \text{USER} \\ \\ \text{USER} \rightarrow \text{ME} \\ \text{ME} \rightarrow \text{SS} \\ \\ \text{SS} \rightarrow \text{ME} \\ \\ \\ \text{ME} \rightarrow \text{SIM} \\ \\ \end{array}$	$\begin{array}{cccccccccccccccccccccccccccccccccccc$

#### PROACTIVE COMMAND: SET UP CALL 3.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.1.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

### Coding:

BER-TLV:	D0	30	81	03	01	10	00	82	02	81	83	85
	16	53	65	74	20	75	70	20	63	61	6C	6C
	20	49	63	6F	6E	20	33	2E	31	2E	31	86
	09	91	10	32	04	21	43	65	1C	2C	9E	02
	01	01										

TERMINAL RESPONSE: SET UP CALL 3.1.1A

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 0
--

# Expected Sequence 3.1B (SET UP CALL, display of basic icon during confirmation phase, not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	Including icon identifier, icon shall be
		CALL 3.1.1	displayed in addition of the first alpha
			identifier
4	$ME \rightarrow USER$	ME displays "Set up call Icon	
		3.1.1" without the basic icon during	
		a user confirmation phase.	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \rightarrow SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.1.1B	[Command performed successfully, but
			requested icon could not be displayed].
9	USER $\rightarrow$ ME	The user ends the call after 5 s.	
		The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

BER-TLV:	81	03	01	10	00	82	02	83	81	83	01	04	
----------	----	----	----	----	----	----	----	----	----	----	----	----	--

# Expected Sequence 3.2A (SET UP CALL, display of basic icon during confirmation phase, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	Including icon identifier, icon shall be
		CALL 3.2.1	displayed instead of the first alpha identifier
4	$ME \to USER$	ME displays the basic icon during	
		a user confirmation phase.	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \to SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	/ 0	TERMINAL RESPONSE 3.2.1A	[Command performed successfully]
9	$USER \to ME$	The user ends the call after 5 s.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 3.2.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.2.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV:	D0	30	81	03	01	10	00	82	02	81	83	85
	16	53	65	74	20	75	70	20	63	61	6C	6C
	20	49	63	6F	6E	20	33	2E	32	2E	31	86
	09	91	10	32	04	21	43	65	1C	2C	9E	02
	00	01										

TERMINAL RESPONSE: SET UP CALL 3.2.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00

# Expected Sequence 3.2B (SET UP CALL, display of basic icon during confirmation phase, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$		Including icon identifier, icon shall be
		CALL 3.2.1	displayed instead of the first alpha identifier
4	$ME \to USER$	ME display " Set up call Icon 3.2.1"	
		without the icon	
5	$USER \to ME$		[user confirmation]
6	$ME { ightarrow} SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.2.1B	[Command performed successfully, but
			requested icon could not be displayed].
_			
9	USER $\rightarrow$ ME	The user ends the call after 5 s.	
		The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

DED #11/	0.4	00	~ 4	4.0	9	0	00	20	•	0	04	~ 4
IBFR-TI V·	I 81	1 ():3	01	10	1 00	1 82	1 ()2	I 83	I 81	I 83	()1	()4

# Expected Sequence 3.3A (SET UP CALL, display of colour icon during confirmation phase, not self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	Including icon identifier, icon shall be displayed in
		CALL 3.3.1	addition of the first alpha identifier
4	$ME \to USER$	ME displays "Set up call Icon 3.3"	
		and the colour icon during a user	
		confirmation phase.	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \rightarrow SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \to SIM$	TERMINAL RESPONSE 3.3.1A	[Command performed successfully]
9	USER $\rightarrow$ ME	The user ends the call after 5 s.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 3.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.3.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 2 in EF IMG>

## Coding:

BER-TLV:	D0	30	81	03	01	10	00	82	02	81	83	85
	16	53	65	74	20	75	70	20	63	61	6C	6C
	20	49	63	6F	6E	20	33	2E	33	2E	31	86
	09	91	10	32	04	21	43	65	1C	2C	9E	02
	01	02										

TERMINAL RESPONSE: SET UP CALL 3.3.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

Coding:

BER-TLV: 8	81 03	01 10	00	82	02	82	81	83	01	00	
------------	-------	-------	----	----	----	----	----	----	----	----	--

# Expected Sequence 3.3B (SET UP CALL, display of colour icon during confirmation phase, not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	Including icon identifier, icon shall be
		CALL 3.3.1	displayed in addition of the first alpha
			identifier
4	$ME \rightarrow USER$	ME only display alpha string: " Set	
		up call Icon 3.3.1"	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \to SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \to SIM$	TERMINAL RESPONSE 3.3.1B	[Command performed successfully, but
			requested icon could not be displayed].
9	$USER \to ME$	The user ends the call after 5 s.	
		The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.3.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

BER-TLV:
----------

# Expected Sequence 3.4A (SET UP CALL, display of self explanatory basic icon during set up call, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.4.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	Including a second alpha identifier and two
		CALL 3.4.1	icons
4	$ME \to USER$	ME displays the basic icon during	
		a user confirmation phase.	
5	$USER \to ME$	The user confirms the set up call	[user confirmation]
6	$ME \rightarrow SS$	The ME attempts to set up a call to	
		"+012340123456p1p2". The ME	
		displays the basic icon during the	
		set up call. If the ME cannot	
		display the icon, it displays " Set	
		up call Icon 3.4.1"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.4.1A	[Command performed successfully]
	LIGED ME	The warm and the call ofter 5 -	
9	USER → ME	The user ends the call after 5 s.	
		The ME returns in idle mode.	

## PROACTIVE COMMAND: SET UP CALL 3.4.1

## Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.4.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"
Alpha identifier: "Set up call Icon 3.4.2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

BER-TLV:	D0	48	81	03	01	10	00	82	02	81	83	85
	16	53	65	74	20	75	70	20	63	61	6C	6C
	20	49	63	6F	6E	20	33	2E	34	2E	31	86
	09	91	10	32	04	21	43	65	1C	2C	85	16
	53	65	74	20	75	70	20	63	61	6C	6C	20
	49	63	6F	6 <sup>E</sup>	20	33	2E	34	2E	32	9E	02
	00	01										

TERMINAL RESPONSE: SET UP CALL 3.4.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00
DLIX ILV.	0 1	00	01	10	00	02	02	02	0 1	00	0 1	00

# Expected Sequence 3.4B (SET UP CALL, display of self explanatory basic icon during set up call, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 3.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$		Including a second alpha identifier and two
		CALL 3.4.1	icons
4	$ME \rightarrow USER$	ME display "Set up call Icon 3.4.1"	
_		without the icon	
5		<u>'</u>	[user confirmation]
6	$ME \to SS$	The ME attempts to set up a call to	
		"+012340123456p1p2". The ME	
		displays the basic icon during the	
		set up call. If the ME cannot	
		display the icon, it displays " Set up call Icon 3.4.1"	
7	$SS \rightarrow ME$	The ME receives the CONNECT	
	33 → IVIL	message from the system	
		simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.4.1B	[Command performed successfully, but
	, , , , , , , , , , , , , , , , , , ,		requested icon could not be displayed].
			requested for foodid flot be displayed].
9	$USER \to ME$	The user ends the call after 5 s.	
		The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.4.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	04

#### 27.22.4.13.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1A to 3.4B.

## 27.22.4.14 POLLING OFF

## 27.22.4.14.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.14.2 Conformance requirement

The ME shall support the POLLING OFF as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.14, clause 6.6.14, clause 6.8, clause 6.11, clause 12.6 and clause 12.7.

## 27.22.4.14.3 Test purpose

To verify that the ME cancels the effect of any previous POLL INTERVAL commands and does not effect SIM presence detection.

## 27.22.4.14.4 Method of test

#### 27.22.4.14.4.1 Initial conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.14.4.2 Procedure

## **Expected Sequence 1.1 (POLLING OFF)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POLLING	
		INTERVAL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$		Interval = 1 min
		POLL INTERVAL 1.1.1	
4	$ME \rightarrow SIM$		[command performed successfully]
		INTERVAL 1.1.1 A or	
		TERMINAL RESPONSE:	
_		POLL INTERVAL 1.1.1B	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: POLLING OFF	
	145 0114	1.1.2 FETCH	
6 7	$ME \rightarrow SIM$	. = . •	
/	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
8	ME CIM	POLLING OFF 1.1.2	[and the second of the second
0	$ME \rightarrow SIM$	TERMINAL RESPONSE: POLLING OFF 1.1.2	[command performed successfully]
9	USER → SIM		
10		STATUS	CIM processes detection
11	ME → SIM		SIM presence detection
''	ME	Time interval shall not exceed 30 seconds	
12	ME CIM	STATUS	SIM presence detection
12	$ME \rightarrow SIM$	STATUS	Silvi presence detection

#### PROACTIVE COMMAND: POLL INTERVAL 1.1.1

Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Duration

Time unit: Minutes
Time interval: 1

Coding:

BER-TLV:	D0	0D	81	03	01	03	00	82	02	81	82	84	
	02	00	01										

## TERMINAL RESPONSE: POLL INTERVAL 1.1.1A

Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Minutes
Time interval: 1

Coding:

BER-TLV:	81	03	01	03	00	82	02	82	81	83	01	00
	84	02	00	01								

TERMINAL RESPONSE: POLL INTERVAL 1.1.1B

Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Seconds
Time interval: 60

Coding:

BER-TLV:	81	03	01	03	00	82	02	82	81	83	01	00
	84	02	01	3C								

PROACTIVE COMMAND: POLLING OFF 1.1.2

Logically:

Command details

Command number: 1

Command type: POLLING OFF

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 04 00 82 02 81 82

TERMINAL RESPONSE: POLLING OFF 1.1.2

Logically:

Command details

Command number: 1

Command type: POLLING OFF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

		00										
BER-TLV:	l 81	03	01	04	00	82	02	82	l 81	83	01	00

## 27.22.4.14.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

# 27.22.4.15 PROVIDE LOCAL INFORMATION

# 27.22.4.15.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.15.2 Conformance requirement

The ME shall support the PROVIDE LOCAL INFORMATION facility as defined in:

• 3GPP TS 11.14 [15] clause 6.4.15.

#### 27.22.4.15.3 Test purpose

To verify that the ME returns the following requested local information within a TERMINAL RESPONSE:

- location information:
  - Mobile Country Code (MCC);
  - Mobile Network Code (MNC);
  - Location Area Code (LAC); and
  - cell ID of the current serving cell;
- the IMEI of the ME;
- the Network Measurement Results and the BCCH channel list;
- the current date, time and time zone;
- the current ME language setting;
- the Timing Advance;

if the local information is stored in the ME; otherwise, sends the correct error code to the SIM in the TERMINAL RESPONSE.

#### 27.22.4.15.4 Method of tests

#### 27.22.4.15.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME is connected to the System Simulator and has performed the location update procedure.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 1;
- Mobile Network Code (MNC) = 1;
- Location Area Code (LAC) = 1;

- Cell Identity value = 1;
- Timing advance = 0;
- Frequency parameters: DCS 1800, neighbour allocations = 561, 565, 568, 569, 573, 575, 577, 581, 582 and 585.

The elementary files are coded as the SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.15.4.2 Procedure

## Expected Sequence 1.1 (PROVIDE LOCAL INFORMATION, Local Info (MCC, MNC, LAC & Cell ID))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: PROVIDE	
		LOCAL INFORMATION 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: PROVIDE	[Command performed successfully, MCC MNC LAC
		LOCAL INFORMATION 1.1.1	and Cell Identity as system simulator

#### PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.1.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "00" Location information (MCC MNC LAC and Cell Identity)

Device identities

Source device: SIM
Destination device: ME

Coding:

DED TILL	Б.		- 4	02	- 4				00	~ 4	0.0
BER-TLV:	D0	09	81	03	01	26	00	82	02	81	82

# TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.1.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "00" Location information (MCC MNC LAC and Cell Identity)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

**Location Information** 

MCC & MNC: MCC = 1, MNC = 1

Location Area Code: 1 Cell Identity Value: 1

BER-TLV:	81	03	01	26	00	82	02	82	81	83	01	00
	93	07	00	F1	10	00	01	00	01			

# **Expected Sequence 1.2 (PROVIDE LOCAL INFORMATION, IMEI of the ME)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: PROVIDE	
		LOCAL INFORMATION 1.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: PROVIDE	[Command performed successfully, IMEI
		LOCAL INFORMATION 1.2.1	as system simulator]

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.2.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "01" IMEI of the ME

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81	03 01	26 01	82 02	81	82	l
-------------------	-------	-------	-------	----	----	---

## TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.2.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "01" IMEI of the ME

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

**IMEI** 

IMEI of the ME: The IMEI of the ME

The result coding depends on the Mobile IMEI value.

Coding:

BER-TLV:	81	03	01	26	01	82	02	82	81	83	01	00
	94	08	XX									

# **Expected Sequence 1.3 (PROVIDE LOCAL INFORMATION, Network Measurement Results (NMR))**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: PROVIDE	
		LOCAL INFORMATION 1.3.1	

4 ME → SIM TERMINAL RESPONSE: PROVIDE [Command performed successfully, LOCAL INFORMATION 1.3.1 NMR as system simulator]

## PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.3.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "02" Network Measurement Results

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	26	02	82	02	81	82

#### TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.3.1

The actual values of the measurements are not tested.

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "02" Network Measurement Results

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Network Measurement Results RXLEV-FULL-SERVING-CELL=52, BA not used, DTX not used, as

an example in the BER-TLV)

BCCH channel list 561, 565, 568, 569, 573, 575, 577, 581, 582 and 585

Coding:

BER-TLV:	81	03	01	26	02	82	02	82	81	83	01	00
	96	10	34	34	00	00	00	00	00	00	00	00
	00	00	00	00	00	00	9D	0E	8C	63	58	E2
	39	8F	63	F9	06	45	91	A4	90	00		

# Expected Sequence 1.4 (PROVIDE LOCAL INFORMATION, Date, Time, Time Zone)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: PROVIDE	
		LOCAL INFORMATION 1.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: PROVIDE	[Command performed successfully]
		LOCAL INFORMATION 1.4.1	

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.4.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "03" Date Time and Time Zone

Device identities

Source device: SIM Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 03 82 02 81 82

## TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.4.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: "03" Date Time and Time Zone

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Date-Time and Time Zone date an time set by the user: 7<sup>th</sup> May 2002, 14h 08mn 17s, no time zone

information, as an example in TLV

Coding:

BER-TLV:	81	03	01	26	03	82	02	82	81	83	01	00
	A6	07	20	50	70	41	80	71	FF			

# **Expected Sequence 1.5 (PROVIDE LOCAL INFORMATION, Language setting)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: PROVIDE	
		LOCAL INFORMATION 1.5.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: PROVIDE	[Command performed successfully]
1		LOCAL INFORMATION 1.5.1	-  -

#### PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.5.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "04" Language setting

Device identities

Source device: SIM Destination device: ME

BER-TLV:   D0   09   81   03   01	26	26 0	04 82	02	81	82
-----------------------------------	----	------	-------	----	----	----

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.5.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "04" Language setting

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Language English ("en") as an example for TLV

Coding:

BER-TLV:	81	03	01	26	04	82	02	82	81	83	01	00
	AD	02	65	6E								

## **Expected Sequence 1.6 (PROVIDE LOCAL INFORMATION, Timing advance)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: PROVIDE	
		LOCAL INFORMATION 1.6.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: PROVIDE	[Command performed successfully]
		LOCAL INFORMATION 1.6.1	

# PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.6.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "05" Timing Advance

Device identities

Source device: SIM
Destination device: ME

Coding:

DED TIV.	_										
BER-TLV:	D0	09	Ω1	0.3	I 01	1 26	05	92	02	1 01	92
IDENTILV.	1 00	เบฮ		l US	ı vı	1 20	เบอ	1 02	1 02		02

#### TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.6.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: "05" Timing Advance

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timing Advance 2 bytes

ME status: "00" ME is in idle state Idle State

Timing Advance:

Coding:

BER-TLV:	81	03	01	26	05	82	02	82	81	83	01	00
	AE	02	00	00								

## 27.22.4.15.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

### 27.22.4.16 SET UP EVENT LIST

## 27.22.4.16.1 SET UP EVENT LIST (normal)

27.22.4.16.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.16.1.2 Conformance requirement

The ME shall support the Proactive SIM: Set Up Event List facility as defined in:

• 3GPP TS 11.14 [15] clause 6.4.16 and clause 6.6.16.

Additionally the ME shall support the Event Download: Call Connect and the Event Download: Call Disconnected mechanism as defined in:

• 3GPP TS 11.14 [15] clause 11.2, clause 11.2.1, clause 11.2.2, clause 11.3, clause 11.3.1 and clause 11.3.2.

#### 27.22.4.16.1.3 Test purpose

To verify that the ME accepts a list of events that it shall monitor the current list of events supplied by the SIM, is able to have this current list of events replaced and is able to have the list of events removed.

To verify that when the ME has successfully accepted or removed the list of events, it shall send TERMINAL RESPONSE (OK) to the SIM and when the ME is not able to successfully accept or remove the list of events, it shall send TERMINAL RESPONSE (Command beyond ME's capabilities).

#### 27.22.4.16.1.4 Method of test

#### 27.22.4.16.1.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files for the second SIM Simulator are coded as SIM Application Toolkit default.

## 27.22.4.16.1.4.2 Procedure

# **Expected Sequence 1.1 (SET UP EVENT LIST, Set Up Call Connect Event)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP	
		EVENT LIST 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP EVENT	
		LIST 1.1.1	
4	$ME \to SIM$	TERMINAL RESPONSE: SET UP EVENT	
		LIST 1.1.1	
5	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
6	$SS \to ME$	SETUP 1.1.1	[Incoming call alert]
7	$USER \to ME$	User shall accept the incoming call	
8	$ME \to SS$	CONNECT 1.1.1	
9	$ME \to SIM$	ENVELOPE: EVENT DOWNLOAD CALL	[Call Connected Event]
		CONNECTED 1.1.1	-
10	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	01										

## TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

# **SET UP 1.1.1**

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

## CONNECT 1.1.1

Logically:

Transaction identifier

Value: XX XX

# ENVELOPE: EVENT DOWNLOAD CALL CONNECTED 1.1A.1Logically

Event list

Event 1: Call Connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier

Value: XXXX

Coding:

BER-TLV:	D6	XX	99	01	01	82	02	83	81	9C	XX		1
----------	----	----	----	----	----	----	----	----	----	----	----	--	---

# **Expected Sequence 1.2 (SET UP EVENT LIST, Replace Event)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
_		1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP EVENT LIST 1.2.1	[Call Connected and Call Disconnected Events]
	$ME \to SIM$	TERMINAL RESPONSE: SET UP	_
		EVENT LIST 1.2.1	
4	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
_		1.2.2	
5	/	FETCH	
6	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[Call Disconnected Event]
_		EVENT LIST 1.2.2	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
0	CINA . NAT	EVENT LIST 1.2.2	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
10	$SS \rightarrow ME$	SETUP 1.2.2	[Incoming call alert]
11		User shall accept the incoming call	[mooning can along
12	ME → SS	CONNECT 1.2.2	
13	SS → ME	DISCONNECT 1.2.2	
10	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD	[Call Disconnect Event]
	IVIL -7 SIIVI	CALL DISCONNECT 1.2.2	[Odii Disconiicot Event]
14	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
	O / IVIE	ENDED	

PROACTIVE COMMAND: SET UP EVENT LIST 1.2.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected
Event 2: Call Disconnected

Coding:

BER-TLV:	D0	0D	81	03	01	05	00	82	02	81	82	99
·	02	01	02									

### TERMINAL RESPONSE: SET UP EVENT LIST 1.2.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TI	V: 8	1 03	01	05	00	82	02	82	81	83	01	00	l
--------	------	------	----	----	----	----	----	----	----	----	----	----	---

# PROACTIVE COMMAND: SET UP EVENT LIST 1.2.2

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Disconnected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99	1
	01	02											1

# TERMINAL RESPONSE: SET UP EVENT LIST 1.2.2

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00
	• .		• .	~ ~		~-	~-	~-	• .		• .	

## **SET UP 1.2.2**

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

CONNECT 1.2.2

Logically:

Transaction identifier

Value: XX XX

**DISCONNECT 1.2.2** 

Logically:

Transaction identifier

Value: XX XX

Cause

Value: XX XX

ENVELOPE: EVENT DOWNLOAD CALL DISCONNECTED 1.2.2

Logically:

Event list

Event 1: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier

Value: XX XX

Cause

Value: XX XX

BER-TLV:	D6	XX	99	01	02	82	02	83	81	9C	XX	
·	9A	XX										

# **Expected Sequence 1.3 (SET UP EVENT LIST, Remove Event)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
		1.3.1	
2	/	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[Call Connected Event]
		EVENT LIST 1.3.1	
	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		EVENT LIST 1.3.1	
4	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
		1.3.1	
5	$ME \rightarrow SIM$	FETCH	
6	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[Remove Event]
		EVENT LIST 1.3.2	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		EVENT LIST 1.3.2	
8	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
10	$SS \to ME$	SETUP 1.3.2	[Incoming call alert]
11	$USER \to ME$	User shall accept the incoming call	
12	$ME \to SS$	CONNECT 1.3.2	
13	$SS \to ME$	DISCONNECT 1.3.2	

PROACTIVE COMMAND: SET UP EVENT LIST 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
•	01	01										

TERMINAL RESPONSE: SET UP EVENT LIST 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	0.4	02	01	ΩE	00	0.2	02	0.0	0.4	0.2	01	00
DEK-ILV.	01	03	UI	05	UU	02	02	02	01	೦೦	UI	00

PROACTIVE COMMAND: SET UP EVENT LIST 1.3.2

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME
Event list: Empty

Coding:

BER-TLV:	D0	0B	81	03	01	05	00	82	02	81	82	99
	00											

TERMINAL RESPONSE: SET UP EVENT LIST 1.3.2

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

DED TIV			- 4	0.5		0.0	00	00	~ 4	0.2	~ 4	
BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

**SET UP 1.3.2** 

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

CONNECT 1.3.2

Logically:

Transaction identifier

Value: XX XX

**DISCONNECT 1.3.2** 

Logically:

Transaction identifier

Value: XX XX

Cause

Value: XX XX

# Expected Sequence 1.4 (SET UP EVENT LIST, Remove Event on ME Power Cycle)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
		1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[Call Connected Event]
		EVENT LIST 1.4.1	
	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		EVENT LIST 1.4.1	
4	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
5		Power off ME	
6	$User \to ME$	Power on ME	
7	$SS \to ME$	SETUP 1.4A	[Incoming call alert]
8	$USER \to ME$	User shall accept the incoming call	
9	$ME \to SS$	CONNECT 1.4.1	
10	$SS \to ME$	DISCONNECT 1.4.1	

PROACTIVE COMMAND: SET UP EVENT LIST 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	01										

TERMINAL RESPONSE: SET UP EVENT LIST 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

**SET UP 1.4.1** 

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

#### CONNECT 1.4.1

Logically:

Transaction identifier

Value: XX XX

#### **DISCONNECT 1.4.1**

Logically:

Transaction identifier

Value: XX XX

Cause

Value: XX XX

#### 27.22.4.16.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.4.

#### 27.22.4.17 PERFORM CARD APDU

## 27.22.4.17.1 PERFORM CARD APDU (normal)

# 27.22.4.17.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.4.17.1.2 Conformance requirement

The ME shall support the Proactive SIM: Perform Card APDU facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 5.2, clause 6.4.17, clause 6.6.17, clause 6.8, clause 12.6, clause 12.7, clause 12.35, clause 12.36 and clause 12.12.9.

Additionally the ME shall support multiple card operation as defined in:

• 3GPP TS 11.14 [15] clause 6.4.19, clause 6.6.19, clause 6.4.18 and clause 6.6.18.

# 27.22.4.17.1.3 Test purpose

To verify that the ME sends an APDU command to the additional card identified in the PERFORM CARD APDU proactive SIM command, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

In this particular case a special Test-SIM (TestSIM) with T=0 protocol is chosen as additional card for the additional ME card reader (for coding of the TestSIM see annex D).

27.22.4.17.1.4 Method of test

27.22.4.17.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The TestSIM is inserted in the additional ME card reader.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

The elementary files of the TestSIM are coded as defined in annex D.

#### 27.22.4.17.1.4.2 Procedure

# Expected Sequence 1.1 (PERFORM CARD APDU, card reader 1, additional card inserted, Select MF and Get Response)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 1.1.1	
4	/ 0	RESET CARD	[Perform electrical initialization]
5		ANSWER TO RESET 1.1	[ATR]
6	$ME \to SIM$	TERMINAL RESPONSE: POWER	[ATR]
_		ON CARD 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PERFORM CARD	
0	ME CIM	APDU 1.1.1 FETCH	
8	$ME \rightarrow SIM$	PROACTIVE COMMAND:	[Calaat Mastarfila]
9	$SIM \rightarrow ME$	PERFORM CARD APDU 1.1.1	[Select Masterfile]
10	ME \ SIM2	C-APDU: SELECT 1.1	[Select Masterfile]
11		R-APDU: SELECT 1.1	[Command performed successfully - length
''	SIIVIZ -> IVIL	IN-AI DO. GELEGI I.I	'1B' of response data]
12	$ME \rightarrow SIM$	TERMINAL RESPONSE:	TB of response dataj
	WE / OW	PERFORM CARD APDU 1.1.1	
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PERFORM CARD	
		APDU 1.1.2	
14	$ME \rightarrow SIM$	FETCH	
15	$SIM \to ME$	PROACTIVE COMMAND:	[Get Response with length '1B']
		PERFORM CARD APDU 1.1.2	
16		C-APDU: GET RESPONSE 1.1	[Get Response with length '1B']
17		R-APDU: GET RESPONSE 1.1	[Response data with length '1B']
18	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Response data with length '1B']
		PERFORM CARD APDU 1.1.2	

# PROACTIVE COMMAND POWER ON CARD 1.1.1

# Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

## Coding:

BER-TLV:	D0	09	81	03	01	31	00	82	02	81	11

#### **ANSWER TO RESET 1.1**

## Logically:

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

T1: 91
T2: 99
T3: 00
T4: 12
T5: C1
T6: 00

#### Coding:

BER-TLV:	3B	86	00	91	99	00	12	C1	00
----------	----	----	----	----	----	----	----	----	----

## TERMINAL RESPONSE: POWER ON CARD 1.1.1

#### Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

T1: 91
T2: 99
T3: 00
T4: 12
T5: C1
T6: 00

## Coding:

BER-TLV:	81	03	01	31	00	82	02	82	81	83	01	00	l
	A1	09	3B	86	00	91	99	00	12	C1	00		l

#### PROACTIVE COMMAND PERFORM CARD APDU 1.1.1

# Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: Master File

Coding:

BER-TLV:	D0	12	81	03	01	30	00	82	02	81	11	A2
	07	A0	A4	00	00	02	3F	00				

C-APDU: SELECT 1.1

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

Coding:

BER-TLV: A0 A4 00 00 02 3F 00

R-APDU: SELECT 1.1

Logically:

Status Words

SW1 / SW2: Command performed successfully - length '1B' of response data

Coding:

BER-TLV: 9F 1B

TERMINAL RESPONSE: PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully - length '1B' of response data

BER-TLV:	81	03	01	30	00	82	02	11	81	83	01	00
	A3	02	9F	1B								

# PROACTIVE COMMAND PERFORM CARD APDU 1.1.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: '00'

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: GET RESPONSE

P1 parameter: '00' P2 parameter: '00' Le: '1B'

Coding:

BER-TLV:	D0	10	81	03	01	30	00	82	02	81	11	A2
	05	A0	C0	00	00	1B						

## C-APDU: GET RESPONSE 1.1

Logically:

C-APDU

Class: 'A0'

Instruction: GET RESPONSE

P1 parameter: '00' P2 parameter: '00' Le: '1B'

Coding:

BER-TLV: A0 C0 00 00 1B

# R-APDU: GET RESPONSE 1.1

Logically:

R-APDU data

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File

Type of file: MF

RFU: 00 00 22 FF 01' Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz

Technology identification: 3V Technology SIM

CHV1: disabled DFs in current directory: 2

EFs in current directory: 2
EFs in current directory: 8
Number of CHV and admin. Codes: 3

RFU byte 18: 00

CHV1 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV1 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV2 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized
RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Status Words

SW1 / SW2: Normal ending of command

#### Coding:

В	ER-TLV:	00	00	02	8D	3F	00	01	00	00	22	FF	01	
		0E	9B	02	08	03	00	83	8A	83	8A	00	00	
		83	00	FF	90	00								l

#### TERMINAL RESPONSE: PERFORM CARD APDU 1.1.2

## Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU data

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File

Type of file: MF

RFU: 00 00 22 FF 01' Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz

Technology identification: 3V Technology SIM

CHV1: disabled DFs in current directory: 2

EFs in current directory:

Number of CHV and admin. Codes: 3 RFU byte 18: 00

CHV1 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV1 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV2 status:

False representations remaining: 10
RFU-bits 7-5: 0000
Secret code: Initialized
RFU bytes 23: 00
Reserved for admin. management: 00 83 00 FF

Statu Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV:	81	03	01	30	00	82	02	11	81	83	01	00
-	A3	0F	00	00	02	8D	3F	00	01	00	00	22
	FF	01	0E	90	00							

# Expected Sequence 1.2 (PERFORM CARD APDU, card reader 1, additional card inserted, Select DF GSM, Select EF PLMN, Update Binary, Read Binary on EF PLMN)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD 1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Power on card reader 1]
	NAT 01140	POWER ON CARD 1.1	ID-of-on-ological initialization
4		RESET CARD	[Perform electrical initialization]
5		ANSWER TO RESET 1.1	[ATR]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER ON CARD 1.1	[ATR]
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: PERFORM CARD	
		APDU 1.2.1	
8	,	FETCH	10 1 10011
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: PERFORM CARD APDU 1.2.1	[Select GSM]
10	ME SIMO	C-APDU: SELECT 1.2a	[Select GSM]
11		R-APDU: SELECT 1.2a	[Delect Colvi]
12		TERMINAL RESPONSE:	
12	IVIL -> OIIVI	PERFORM CARD APDU 1.2.1	
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PERFORM CARD	
		APDU 1.2.2	
14		FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Select PLMN]
10	ME OIMO	PERFORM CARD APDU 1.2.2	[Coloct DI MAN]
16 17		C-APDU: SELECT 1.2b R-APDU: SELECT 1.2b	[Select PLMN]
18		TERMINAL RESPONSE:	
10	$ME \to SIM$	PERFORM CARD APDU 1.2.2	
19	$SIM \rightarrow ME$	PROACTIVE COMMAND	
	Olivi 7 IVIL	PENDING: PERFORM CARD	
		APDU 1.2.3	
20	$ME \rightarrow SIM$	FETCH	
21	$SIM \to ME$	PROACTIVE COMMAND:	[Update Binary]
		PERFORM CARD APDU 1.2.3	
22		C-APDU: UPDATE BINARY 1.2	[Update Binary]
23	$ SIM2 \rightarrow ME $	R-APDU: UPDATE BINARY 1.2	

Step	Direction	MESSAGE / Action	Comments
24	$ME \rightarrow SIM$	TERMINAL RESPONSE:	
		PERFORM CARD APDU 1.2.3	
25	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PERFORM CARD	
		APDU 1.2.4	
26	$ME \rightarrow SIM$	FETCH	
27	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Read Binary]
		PERFORM CARD APDU 1.2.4	
28	$ME \rightarrow SIM2$	C-APDU: READ BINARY 1.2	[Read Binary]
29	$SIM2 \rightarrow ME$	R-APDU: READ BINARY 1.2	
30	$ME \rightarrow SIM$	TERMINAL RESPONSE:	
		PERFORM CARD APDU 1.2.4	
31	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Update Binary]
		PERFORM CARD APDU 1.2.5	
32	$ME \rightarrow SIM2$	C-APDU: UPDATE BINARY 1.2a	[Update Binary]
33	$SIM2 \rightarrow ME$	R-APDU: UPDATE BINARY 1.2	
34	$ME \rightarrow SIM$	TERMINAL RESPONSE:	
		PERFORM CARD APDU 1.2.3	

## PROACTIVE COMMAND PERFORM CARD APDU 1.2.1

# Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: DF GSM

# Coding:

BER-TLV:	D0	12	81	03	01	30	00	82	02	81	11	A2
	07	A0	A4	00	00	02	7F	20				

## PROACTIVE COMMAND: PERFORM CARD APDU 1.2.2

# Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: EF PLMN

# Coding:

BER-TLV:	D0	12	81	03	01	30	00	82	02	81	11	A2
	07	A0	A4	00	00	02	6F	30				

## PROACTIVE COMMAND: PERFORM CARD APDU 1.2.3

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Coding:

BER-TLV:	D0	28	81	03	01	30	00	82	02	81	11	A2
_	1D	A0	D6	00	00	18	00	01	02	03	04	05
	06	07	08	09	0A	0B	0C	0D	0E	0F	10	11
	12	13	14	15	16	17						

## PROACTIVE COMMAND: PERFORM CARD APDU 1.2.4

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: READ BINARY

P1 parameter: '00' P2 parameter: '00' Le: '18'

BER-TLV:	D0	10	81	03	01	30	00	82	02	81	11	A2
	05	Α0	B0	00	00	18						

## PROACTIVE COMMAND: PERFORM CARD APDU 1.2.5

# Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

# Coding:

BER-TLV:	D0	28	81	03	01	30	00	82	02	81	11	A2
	1D	A0	D6	00	00	18	FF	FF	FF	FF	FF	FF
	FF											
	FF	FF	FF	FF	FF	FF						

## C-APDU: SELECT 1.2a

# Logically:

## C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: DF GSM

# Coding:

# C-APDU: SELECT 1.2b

# Logically:

# C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: EF PLMN

BER-TLV: A0	A4	00	00	02	6F	30
-------------	----	----	----	----	----	----

C-APDU: UPDATE BINARY 1.2

Logically:

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Coding:

BER-TLV:	A0	D6	00	00	18	00	01	02	03	04	05	06
	07	80	09	0A	0B	0C	0D	0E	0F	10	11	12
	13	14	15	16	17							

C-APDU: READ BINARY 1.2

Logically:

C-APDU

Class: 'A0'

Instruction: READ BINARY

P1 parameter: '00' P2 parameter: '00' Le: '18'

Coding:

BER-TLV: A0 B0 00 00 18

C-APDU: UPDATE BINARY 1.2a

Logically:

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Coding:

BER-TLV:	A0	D6	00	00	18	FF						
	FF											
	FF	FF	FF	FF	FF							

R-APDU: SELECT 1.2a

Logically:

Status Words

SW1 / SW2: Normal ending of command - length '1B' of response data

Coding:

BER-TLV: 9F 1B

R-APDU: SELECT 1.2b

Logically:

Status Words

SW1 / SW2: Normal ending of command - length '0F' of response data

Coding:

BER-TLV: 9F 0F

R-APDU: UPDATE BINARY 1.2

Logically:

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 90 00

R-APDU: READ BINARY 1.2

Logically:

R-APDU data

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV:	00	01	02	03	04	05	06	07	80	09	0A	0B
	0C	0D	0E	0F	10	11	12	13	14	15	16	17
	90	00										

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully - length 1B of response data

## Coding:

BER-TLV:	81	03	01	30	00	82	02	11	81	83	01	00
·	A3	02	9F	1B								

## TERMINAL RESPONSE: PERFORM CARD APDU 1.2.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully - length 0F of response data

Coding:

BER-TLV:	81	03	01	30	00	82	02	11	81	83	01	00
	А3	02	9F	0F								

## TERMINAL RESPONSE: PERFORM CARD APDU 1.2.3

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV:	81	03	01	30	00	82	02	11	81	83	01	00
	А3	02	90	00								

## TERMINAL RESPONSE: PERFORM CARD APDU 1.2.4

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

R-APDU

R-APDU data

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F 10 11 12 13 14 15 16 17'

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV:	81	03	01	30	00	82	02	11	81	83	01	00
_	A2	81	EF	A0	D6	00	00	EC	00	01	02	03
	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
	10	11	12	13	14	15	16	17	90	00		

# Expected Sequence 1.3 (PERFORM CARD APDU, card reader 1, card inserted, card powered off)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER OFF CARD	
		1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Power off card reader 1]
		POWER OFF CARD 1.3.1	
4	$ME \rightarrow SIM2$	POWER OFF CARD	[Power off card reader 1]
5	$ME \to SIM$	TERMINAL RESPONSE: POWER	[Successful]
		OFF CARD 1.3.1	
6	ME	SIM2 is powered off from ME card	
		reader	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PEFORM CARD APDU	
_		1.1.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.1.1	
10	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Card powered off]
		PERFORM CARD APDU 1.3.1	

PROACTIVE COMMAND: POWER OFF CARD 1.3.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 32 00 82 02 81 11

TERMINAL RESPONSE: POWER OFF CARD 1.3.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	01
	00										

# TERMINAL RESPONSE: PERFORM CARD APDU 1.3.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error

Additional Information: Card powered off

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	02
_	38	04									

# Expected Sequence 1.4 (PERFORM CARD APDU, card reader 1, no card inserted)

Step	Direction	MESSAGE / Action	Comments
1	ME	SIM2 is removed from ME card	
		reader	
2	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PEFORM CARD APDU	
		1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \to ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[No card inserted]
		PERFORM CARD APDU 1.4.1	-

## TERMINAL RESPONSE: PERFORM CARD APDU 1.4.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card removed or not present

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	02
·	38	02									

# Expected Sequence 1.5 (PERFORM CARD APDU, card reader 7 (which is not the valid card reader identifier of the additional ME card reader))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[invalid card reader ID]
		PENDING: PEFORM CARD APDU	
		1.5.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.5.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Specified reader not valid]
		PERFORM CARD APDU 1.5.1	_

## PROACTIVE COMMAND: PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 7

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: Master File

Coding:

BER-TLV:	D0	12	81	03	01	30	00	82	02	81	17	A2
	07	A0	A4	00	00	02	3F	00				

C-APDU: SELECT 1.1

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

BER-TLV:	A0	A4	00	00	02	3F	00
----------	----	----	----	----	----	----	----

TERMINAL RESPONSE: PERFORM CARD APDU 1.5.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Specified reader not valid

#### Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	02
	38	09									

## 27.22.4.17.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.5.

## 27.22.4.17.2 PERFORM CARD APDU (detachable card reader)

27.22.4.17.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.17.2.2 Conformance requirement

27.22.4.17.2.3 Test purpose

To verify that the ME sends an APDU command to the additional card identified in the PERFORM CARD APDU proactive SIM command, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.17.2.4 Method of test

27.22.4.17.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The card reader shall be detached from the ME.

## 27.22.4.17.2.4.2 Procedure

# Expected Sequence 2.1 (PERFORM CARD APDU, card reader 1, card reader detached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: PEFORM CARD APDU	
		2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.1.1	-
4	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Card reader detached]
		PERFORM CARD APDU 2.1.1	-

# PROACTIVE COMMAND: PERFORM CARD APDU 2.1.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: Master File

Coding:

BER-TLV:	D0	12	81	03	01	30	00	82	02	81	11	A2
	07	A0	A4	00	00	02	3F	00				

# TERMINAL RESPONSE: PERFORM CARD APDU 2.1.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card reader removed or not present

BER-TLV:	81	03	01	30	00	82	02	82	81	83	02
	38	01									

## 27.22.4.17.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

# 27.22.4.18 POWER OFF CARD

# 27.22.4.18.1 POWER OFF CARD (normal)

# 27.22.4.18.1.1 Definition and applicability

See clause 3.2.2.

#### 27.22.4.18.1.2 Conformance requirement

The ME shall support the Proactive SIM: Power Off Card facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.18, clause 6.6.18, clause 12.6, clause 12.7, clause 12.12, clause 12.12.9, clause 5.2 and annex H.

## 27.22.4.18.1.3 Test purpose

To verify that the ME closes a session with the additional card identified in the POWER OFF CARD proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

## 27.22.4.18.1.4 Method of test

## 27.22.4.18.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

# 27.22.4.18.1.4.2 Procedure

## Expected Sequence 1.1 (POWER OFF CARD, card reader 1)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING:	
		POWER OFF CARD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: POWER OFF	[Power off card reader 1]
		CARD 1.1.1	
4	$ME \rightarrow SIM2$	POWER OFF CARD	[Power off card reader 1]
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER OFF	[Successful]
		CARD 1.1.1	

PROACTIVE COMMAND: POWER OFF CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV:	D0	09	81	03	01	32	00	82	02	81	11
D-1 \ 1 - V .			<b>.</b>		<b>.</b>	- U	00			<b>.</b>	

# TERMINAL RESPONSE: POWER OFF CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	01
	00										

# Expected Sequence 1.2 (POWER OFF CARD, card reader 1, no card inserted)

Step	Direction	MESSAGE / Action	Comments
1	SIM2	SIM2 is removed from ME card reader	
2	$SIM \to ME$	PROACTIVE COMMAND PENDING: POWER	
		OFF CARD 1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \to ME$	PROACTIVE COMMAND: POWER OFF CARD	[Power off card reader 1]
		1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER OFF CARD	[No card inserted]
		1.2.1	_

# TERMINAL RESPONSE: POWER OFF CARD 1.2.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card removed or not present

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	02
	38	02									

## 27.22.4.18.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.2.

## 27.22.4.18.2 POWER OFF CARD (detachable card reader)

27.22.4.18.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.18.2.2 Conformance requirement

Void.

27.22.4.18.2.3 Test purpose

To verify that the ME closes a session with the additional card identified in the POWER OFF CARD proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.18.2.4 Method of test

27.22.4.18.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

The card reader shall be detached from the ME.

27.22.4.18.2.4.2 Procedure

# Expected Sequence 2.1 (POWER OFF CARD, card reader 1, no card reader attached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: POWER OFF CARD 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND: POWER OFF CARD 2.1.1	[Power off card reader 1]
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER ON CARD 2.1.1	[Card reader removed or not present]

PROACTIVE COMMAND: POWER OFF CARD 2.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV:	D0	09	81	03	01	32	00	82	02	81	11

TERMINAL RESPONSE: POWER OFF CARD 2.1.1

Logically:

Command details

Command number: 1

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card reader removed or not present

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	02
	38	01									

#### 27.22.4.18.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

#### 27.22.4.19 POWER ON CARD

## 27.22.4.19.1 POWER ON CARD (normal)

## 27.22.4.19.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.19.1.2 Conformance requirement

The ME shall support the Proactive SIM: Power On Card facility as defined in:

- 3GPP TS 11.14 [15] clause 6.1, clause 6.4.19, clause 6.6.19, clause 12.6, clause 12.7, clause 12.12, clause 12.12.9, clause 12.34, clause 5.2 and annex H.
- ISO /IEC 7816-3 [21].

## 27.22.4.19.1.3 Test purpose

To verify that the ME starts a session with the additional card identified in the POWER ON CARD proactive SIM command, and successfully returns the Answer To Reset within the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.4.19.1.4 Method of test

27.22.4.19.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

## 27.22.4.19.1.4.2 Procedure

## **Expected Sequence 1.1 (POWER ON CARD, card reader 1)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING:	
		POWER ON CARD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: POWER ON	[Power on card reader 1]
		CARD 1.1.1	
4	$ME \rightarrow SIM2$	RESET CARD	[Perform electrical initialization]
5	$SIM2 \rightarrow ME$	ANSWER TO RESET 1.1.1	[ATR]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER ON	[ATR]
		CARD 1.1.1	

## PROACTIVE COMMAND: POWER ON CARD 1.1.1

## Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

## Coding:

BER-TLV:	D0	09	81	03	01	31	00	82	02	81	11

## **ANSWER TO RESET 1.1.1**

## Logically:

'3B'
0F
'P'
'o'
'w'
'e'
'r'
'O'
'n'
'C'
'a'
'r'
'd'
'T'

T13 (Historical character): 'e'
T14 (Historical character): 's'
T15 (Historical character): 't'

Coding:

BER-TLV:	3B	0F	50	6F	77	65	72	4F	6E	43	61	72
	64	54	65	74	75							

## TERMINAL RESPONSE: POWER ON CARD 1.1.1

#### Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B' T0 (Format character): 0F T1 (Historical character): 'P' 'o' T2 (Historical character): T3 (Historical character): 'w' T4 (Historical character): 'e' 'r' T5 (Historical character): T6 (Historical character): 'O' T7 (Historical character): 'n' 'C' T8 (Historical character): T9 (Historical character): 'a' T10 (Historical character): 'r' T11 (Historical character): 'd' T12 (Historical character): 'T' T13 (Historical character): 'e' T14 (Historical character): 's' 't' T15 (Historical character):

## Coding:

BER-TLV:	81	03	01	31	00	82	02	82	81	83	01	00
	A1	11	3B	0F	50	6F	77	65	72	4F	6E	43
	61	72	64	54	65	74	75					

## Expected Sequence 1.2 (POWER ON CARD, card reader 1, no ATR)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 1.1.1	
4	$ME \rightarrow SIM2$	RESET CARD	[Perform electrical initialization]
5	$SIM2 \rightarrow ME$	NO ATR	[No ATR]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER	[No ATR]
		ON CARD 1.2.1	

TERMINAL RESPONSE: POWER ON CARD 1.2.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error

Additional Information: Card mute

Coding:

BER-TLV:	81	03	01	31	00	82	02	82	81	83	02	38
_	06											

## Expected Sequence 1.3 (POWER ON CARD, card reader 1, no card inserted)

Step	Direction	MESSAGE / Action	Comments
1	SIM2	SIM2 is removed from ME card	
		reader	
2	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \to ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER	[Card removed or not present]
		ON CARD 1.3.1	

#### TERMINAL RESPONSE: POWER ON CARD 1.3.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: Card reader 0

Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card removed or not present

Coding:

BER-TLV:	81	03	01	31	00	82	02	82	81	83	02	38
	02											

## 27.22.4.19.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

27.22.4.19.2 POWER ON CARD (detachable card reader)

27.22.4.19.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.19.2.2 Conformance requirement

27.22.4.19.2.3 Test purpose

To verify that the ME starts a session with the additional card identified in the POWER ON CARD proactive SIM command, and successfully returns the Answer To Reset within the TERMINAL RESPONSE command send to the SIM.

27.22.4.19.2.4 Method of test

27.22.4.19.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The card reader shall be detached from the ME.

27.22.4.19.2.4.2 Procedure

## Expected Sequence 2.1 (POWER ON CARD, card reader 1, no card reader attached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 2.1.1	-
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER	[Card reader removed or not present]
		ON CARD 2.1.1	

PROACTIVE COMMAND: POWER ON CARD 2.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

BER-TI V·	DΩ	nα	81	03	01	31	00	82	02	81	11

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: Card reader 0

Destination device: SIM

Result

General Result: MultipleCard commands error Additional Information: Card reader removed or not present

#### Coding:

BER-TLV:	81	03	01	31	00	82	02	82	81	83	02	38
	01											

## 27.22.4.19.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

#### 27.22.4.20 GET READER STATUS

## 27.22.4.20.1 GET READER STATUS (normal)

27.22.4.20.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.20.1.2 Conformance requirement

The ME shall support the Proactive SIM: Get Card Reader Status facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 5.2, clause 6.4.20, clause 6.6.20, clause 6.8, clause 12.6, clause 12.7, clause 12.33, clause 12.57 and annex H.

Additionally the ME shall support multiple card operation as defined in:

• 3GPP TS 11.14 [15] clause 6.4.19, clause 6.6.19, clause 6.4.18 and clause 6.6.18.

## 27.22.4.20.1.3 Test purpose

To verify that the ME sends starts a session with the additional card identified in the GET CARD READER STATUS proactive SIM command, and successfully returns information about all interfaces to additional card reader(s) in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

In this test case the second SIM-Simulator (SIM2) shall response with the ATR "3B 00".

27.22.4.20.1.4 Method of test

27.22.4.20.1.4.1 Initial conditions

The ME shall support the Proactive SIM: Get Card Reader Status (Card Reader Status) facility. The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

#### 27.22.4.20.1.4.2 Procedure

## Expected Sequence 1.1 (GET CARD READER STATUS, card reader 1, card inserted, card powered)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: POWER ON CARD 1.1.1	
2	$\text{ME} \to \text{SIM}$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND PENDING: POWER ON CARD 1.1.1	[Power on card reader 1]
4	$ME \to SIM2$	RESET CARD	[Perform electrical initialization]
5	$SIM2 \to ME$	ANSWER TO RESET 1.1.1	[ATR]
6	$ME \to SIM$	TERMINAL RESPONSE: POWER ON CARD 1.1.1	[ATR]
7	$SIM \to ME$	PROACTIVE COMMAND PENDING: GET CARD READER STATUS 1.1.1	
8	$ME \to SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1	[Get Card Reader Status]
10	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1a Or	[Successful]
		TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1b	[Successful]
		TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1c	[Successful]
		TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1d	[Successful]

## PROACTIVE COMMAND: POWER ON CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

BER-TLV:	D0	09	81	0.3	01	31	00	82	02	81	11

#### **ANSWER TO RESET 1.1.1**

Logically:

TS (Initial character): '3B' TO (Format character): '00'

Coding:

BER-TLV: A1 02 3B 00

#### TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number: 1

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B' T0 (Format character): '00'

Coding:

BER-TLV:	81	03	01	31	00	82	02	82	81	83	01	00
	A1	02	3B	00								

## PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	l 81	03	l 01	33	00	82	l 02	81	82
DLIX ILV.		00	01		01	33	00	02	02	0 1	02

## TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1a

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: Yes

## Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	F1							

## TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1b

## Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: Yes

## Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
·	00	A0	01	D1							

## TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1c

## Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: Yes

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	F9							

#### TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1d

## Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: Yes

## Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	D9							

# Expected Sequence 1.2 (GET CARD READER STATUS, card reader 1, card inserted, card not powered)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: POWER OFF CARD 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: POWER OFF CARD 1.2.1	[Power off card reader 1]
4	$ME \rightarrow SIM2$	POWER OFF CARD	[Power off card reader 1]
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER OFF CARD 1.2.1	[Successful]
6	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET CARD READER STATUS 1.1.1	
7	$ME \rightarrow SIM$	FETCH	
8	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1	[Get Card Reader Status]
9	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1a Or	[Successful]
		TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1b or	[Successful]
		TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1c Or	[Successful]
		TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1d	[Successful]

PROACTIVE COMMAND: POWER OFF CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV:	D0	09	81	03	01	32	00	82	02	81	11
DEIX-IEV.		0.0	01	00	O I	32	00	02	02	01	1.1

# TERMINAL RESPONSE: POWER OFF CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	32	00	82	02	82	81	83	01
	00										

## TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1a

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: No

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	71							

## TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1b

#### Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: No

## Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	51							

#### TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1c

#### Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: No

## Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	79							

## TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1d

#### Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
•	00	A0	01	59							

## Expected Sequence 1.3 (GET CARD READER STATUS, card reader 1, card not present)

Step	Direction	MESSAGE / Action	Comments
1	SIM2	SIM2 is removed from ME card reader	
2	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
		GET CARD READER STATUS 1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET CARD	[Get Card Reader Status]
		READER STATUS 1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET CARD	[Successful]
		READER STATUS 1.3.1a	
		or	
		TERMINAL RESPONSE: GET CARD	[Successful]
		READER STATUS 1.3.1b	
		or	
		TERMINAL RESPONSE: GET CARD	[Successful]
		READER STATUS 1.3.1c	
		or	
		TERMINAL RESPONSE: GET CARD	
		READER STATUS 1.3.1d	[Successful]

## TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1a

## Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: No
Card powered: No

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	31							

#### TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1b

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: No
Card powered: No

Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	11							

#### TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1c

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: No
Card powered: No

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	39							

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: No
Card powered: No

Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	19							

#### 27.22.4.20.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

## 27.22.4.20.2 GET CARD READER STATUS (detachable card reader)

27.22.4.20.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.20.2.2 Conformance requirement

Void.

27.22.4.20.2.3 Test purpose

To verify that the ME closes a session with the additional card identified in the GET CARD READER STATUS proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.20.2.4 Method of test

27.22.4.20.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

The card reader shall be detached from the ME.

## 27.22.4.20.2.4.2 Procedure

# Expected Sequence 2.1 (GET CARD READER STATUS, no card reader attached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: GET CARD	
		READER STATUS 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: GET CARD READER	[Get Card Reader Status]
		STATUS 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: GET CARD READER	[Successful]
		STATUS 2.1.1a	
		or	
		TERMINAL RESPONSE: GET CARD READER	[Successful]
		STATUS 2.1.1b	

#### PROACTIVE COMMAND: GET CARD READER STATUS 2.1.1

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card Reader Status

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: DO	09	81	03	01	33	00	82	02	81	82	1
-------------	----	----	----	----	----	----	----	----	----	----	---

#### TERMINAL RESPONSE: GET CARD READER STATUS 2.1.1a

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	A0	01	29							

TERMINAL RESPONSE: GET CARD READER STATUS 2.1.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

## Coding:

BER-TLV:	81	03	01	33	00	82	02	82	81	83	01
	00	Α0	01	09							

#### 27.22.4.20.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 2.1.

## 27.22.4.21 TIMER MANAGEMENT and ENVELOPE TIMER EXPIRATION

## 27.22.4.21.1 TIMER MANAGEMENT (normal)

27.22.4.21.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.21.1.2 Conformance Requirement

The ME shall support the TIMER MANAGEMENT as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.21, clause 6.8, clause 12.6, clause 12.7, clause 12.37 and clause 12.38.

#### 27.22.4.21.1.3 Test purpose

To verify that the ME manages correctly its internal timers, start a timer, deactivate a timer or return the current value of a timer according to the Timer Identifier defined in the TIMER MANAGEMENT proactive SIM command.

## 27.22.4.21.1.4 Method of Test

## 27.22.4.21.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

## 27.22.4.21.1.4.2 Procedure

# Expected Sequence 1.1 (TIMER MANAGEMENT, start timer 1 several times, get the current value of the timer and deactivate the timer successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND:	[start timer 1]
		TIMER MANAGEMENT 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 1 minute following reception of Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.1.2	
6	$ME \rightarrow SIM$	FETCH	
7		PROACTIVE COMMAND:	[ask value of timer 1]
	NAT 0184	TIMER MANAGEMENT 1.1.2	[someoned manformers of supposed with 1]
8	ME → SIM	TERMINAL RESPONSE: TIMER	[command performed successfully]
9	$SIM \rightarrow ME$	MANAGEMENT 1.1.2 PROACTIVE COMMAND	Before timer expires!
9	SIIVI → IVIE	PENDING: TIMER	before timer expires:
		MANAGEMENT 1.1.3	
10	$ME \rightarrow SIM$	FETCH	
11	IVIL 7 OIIVI	PROACTIVE COMMAND:	[reinitialize timer 1]
1		TIMER MANAGEMENT 1.1.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
	, vii – , oiivi	MANAGEMENT 1.1.3	[,]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 30 s following reception of the Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.1.4	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 1]
		TIMER MANAGEMENT 1.1.4	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.1.4	

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 5 min

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	01	A5	03	00	50	00					

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	01										

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 1min 30s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	01	A5	03	00	10	03			,		

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 1

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	01										

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.1 and 1.1.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding::

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	01									

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: value < to the timer value of command 1.1.1

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	00
	A4	01	01	A5	03	XX	XX	XX				

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: value < to the timer value of command 1.1.3

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	00
	A4	01	01	A5	03	XX	XX	XX				

# Expected Sequence 1.2 (TIMER MANAGEMENT, start timer 2 several times, get the current value of the timer and deactivate the timer successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND:	[start timer 2]
		TIMER MANAGEMENT 1.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.2.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 1 minute following reception of Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.2.2	
6	$ME \rightarrow SIM$	FETCH	
7		PROACTIVE COMMAND:	[ask value of timer 2]
8	NAT 0184	TIMER MANAGEMENT 1.2.2	[someoned manformers of supposed with 1]
8	ME → SIM	TERMINAL RESPONSE: TIMER	[command performed successfully]
9	$SIM \rightarrow ME$	MANAGEMENT 1.2.2 PROACTIVE COMMAND	Before timer expires!
9	SIIVI → IVIE	PENDING: TIMER	before timer expires:
		MANAGEMENT 1.2.3	
10	ME → SIM	FETCH	
11	IVIL -> OIIVI	PROACTIVE COMMAND:	[reinitialize timer 2]
''		TIMER MANAGEMENT 1.2.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
	, , , , , , , , , , , , , , , , , , , ,	MANAGEMENT 1.2.3	[,]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 10 seconds following reception of
		PENDING: TIMER	Terminal Response
		MANAGEMENT 1.2.4	·
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 2]
		TIMER MANAGEMENT 1.2.4	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.2.4	

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: 23 h 59 min 59 s

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	02	A5	03	32	95	95					

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	02										

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.3

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: 40 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	02	A5	03	00	00	04					

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 2

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	02										

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.1 and 1.2.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	02									

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: value < to the timer value of command 1.2.1

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	00
	A4	01	02	A5	03	XX	XX	XX				

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: value < to the timer value of command 1.2.3

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	00
	A4	01	02	A5	03	XX	XX	XX				

# Expected Sequence 1.3 (TIMER MANAGEMENT, start timer 8 several times, get the current value of the timer and deactivate the timer successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND:	[start timer 8]
		TIMER MANAGEMENT 1.3.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
_		MANAGEMENT 1.3.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 1 minute following reception of Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.3.2	
6	$ME \rightarrow SIM$	FETCH	
7		PROACTIVE COMMAND:	[ask value of timer 8]
8	NAT OINA	TIMER MANAGEMENT 1.3.2	[command parformed augeografully]
0	IME → SIM	TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.2	[command performed successfully]
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	Before timer expires!
3	SIIVI - IVIE	PENDING: TIMER	Delote titlet expires:
		MANAGEMENT 1.3.3	
10	$ME \rightarrow SIM$	FETCH	
11	IVIL 7 OIIVI	PROACTIVE COMMAND:	[reinitialize timer 8]
1		TIMER MANAGEMENT 1.3.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
	, , , , , , , , , , , , , , , , , , , ,	MANAGEMENT 1.3.3	[,]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 30 seconds following reception of
		PENDING: TIMER	Terminal Response
		MANAGEMENT 1.3.4	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 8]
		TIMER MANAGEMENT 1.3.4	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.3.4	

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: 20min

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
-	01	08	A5	03	00	02	00					

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	08										

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: 01 h 00 min 00 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	08	A5	03	10	00	00					

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4	
	01	08											

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.1 and 1.3.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 8

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	80									

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: value < to the timer value of command 1.3.1

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	00
	A4	01	80	A5	03	XX	XX	XX				

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: value < to the timer value of command 1.3.3

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	00
	A4	01	08	A5	03	XX	XX	XX				

# Expected Sequence1.4 (TIMER MANAGEMENT, try to get the current value of a timer which is not started: action in contradiction with the current timer state)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND:	[get current value from timer 1]
		TIMER MANAGEMENT 1.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
_		MANAGEMENT 1.4.1	state]
5	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.4.2	
6	$ME \rightarrow SIM$	FETCH	
7	IVIL -> SIIVI	PROACTIVE COMMAND:	[get current value from timer 2]
<b>'</b>		TIMER MANAGEMENT 1.4.2	[get current value from timer 2]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
	INIE 7 OIIVI	MANAGEMENT 1.4.2	state]
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	,
		PENDING: TIMER	
		MANAGEMENT 1.4.3	
10	$ME \rightarrow SIM$	FETCH	
11		PROACTIVE COMMAND:	[get current value from timer 3]
4.0		TIMER MANAGEMENT 1.4.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
12	OIM ME	MANAGEMENT 1.4.3 PROACTIVE COMMAND	state]
13	$SIM \rightarrow ME$	PENDING: TIMER	
		MANAGEMENT 1.4.4	
14	$ME \rightarrow SIM$	FETCH	
15	IVIL 7 OIIVI	PROACTIVE COMMAND:	[get current value from timer 4]
		TIMER MANAGEMENT 1.4.4	[got ourself value from times 1]
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.4.4	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.4.5	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[get current value from timer 5]
16	$ME \rightarrow SIM$	TIMER MANAGEMENT 1.4.5 TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
10		MANAGEMENT 1.4.5	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	State
'	OIIVI 7 IVIL	PENDING: TIMER	
		MANAGEMENT 1.4.6	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[get current value from timer 6]
		TIMER MANAGEMENT 1.4.6	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
4.5		MANAGEMENT 1.4.6	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
14	$ME \rightarrow SIM$	MANAGEMENT 1.4.7 FETCH	
15		PROACTIVE COMMAND:	[get current value from timer 7]
13		TIMER MANAGEMENT 1.4.7	[get current value nom timer /]
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
	/ 31171	MANAGEMENT 1.4.7	state]
	1	1	

Step	Direction	MESSAGE / Action	Comments
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.4.8	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[get current value from timer 8]
		TIMER MANAGEMENT 1.4.8	-
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.4.8	state]

#### PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	01										

## TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	01							,		

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	02										

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	02									

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 3

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	03										

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 3

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	03									

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 4

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4	
-	01	04											

## TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 4

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	04									

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 5

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	05										

#### TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 5

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	05									

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 6

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	06										

## TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 6

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	06									

#### PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.7

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 7

Coding:

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
•	01	07										

#### TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 7

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	07									

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

BER-TLV:	D0	0C	81	03	01	27	10	82	02	81	82	A4
	01	08										

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 8

Coding:

BER-TLV:	81	03	01	27	10	82	02	82	81	83	01	24
	A4	01	08									

# Expected Sequence1.5 (TIMER MANAGEMENT, try to deactivate a timer which is not started: action in contradiction with the current timer state)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.5.1	
2	$ME \to SIM$	FETCH	
3		PROACTIVE COMMAND:	[deactivate timer 1]
		TIMER MANAGEMENT 1.5.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
_		MANAGEMENT 1.5.1	state]
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER IMANAGEMENT 1.5.2	
6	$ME \rightarrow SIM$	FETCH	
6 7	IVIE -> SIIVI	PROACTIVE COMMAND:	[deactivate timer 2]
<b>'</b>		TIMER MANAGEMENT 1.5.2	[ueactivate timer 2]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	faction in contradiction with the current timer
	IVIL / OIIVI	MANAGEMENT 1.5.2	state]
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	otato]
		PENDING: TIMER	
		MANAGEMENT 1.5.3	
10	$ME \to SIM$	FETCH	
11		PROACTIVE COMMAND:	[deactivate timer 3]
		TIMER MANAGEMENT 1.5.3	
12	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.3	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
1 44		MANAGEMENT 1.5.4	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 4]
16	NAT CINA	TIMER MANAGEMENT 1.5.4 TERMINAL RESPONSE: TIMER	Loction in contradiction with the current times
10	$ME \rightarrow SIM$	MANAGEMENT 1.5.4	[action in contradiction with the current timer state]
		INAMAGENIENT 1.5.4	วเลเซ

Step	Direction	MESSAGE / Action	Comments
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.5.5	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 5]
		TIMER MANAGEMENT 1.5.5	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.5	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.5.6	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 6]
		TIMER MANAGEMENT 1.5.6	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
40		MANAGEMENT 1.5.6	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
14	NAT CINA	MANAGEMENT 1.5.7 FETCH	
	$ME \rightarrow SIM$	PROACTIVE COMMAND:	[docativate times 7]
15		TIMER MANAGEMENT 1.5.7	[deactivate timer 7]
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
10	IVIE -> SIIVI	MANAGEMENT 1.5.7	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	State
'0	Olivi -> IVIL	PENDING: TIMER	
		MANAGEMENT 1.5.8	
14	$ME \rightarrow SIM$	FETCH	
15	, , , , , , , , , , , , , , , , , , , ,	PROACTIVE COMMAND:	[deactivate timer 8]
		TIMER MANAGEMENT 1.5.8	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.8	state]

# PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
·	01	01										

## TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
	A4	01	01									

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	02										

## TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
_	A4	01	02									

## PROACTIVE COMMAND3: TIMER MANAGEMENT 1.5.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 3

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
_	01	03										

## TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 3

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
	A4	01	03									

## PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 4

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	04										

# TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 4

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
	A4	01	04									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 5

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	05										

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 5

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24	
	A4	01	05										

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 6

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	06										

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 6

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
	A4	01	06									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 7

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	07										

# TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 7

Coding:

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
	A4	01	07									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Coding:

BER-TLV:	D0	0C	81	03	01	27	01	82	02	81	82	A4
	01	08										

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier

Identifier of timer: 8

BER-TLV:	81	03	01	27	01	82	02	82	81	83	01	24
	Α4	01	08									

# **Expected Sequence 1.6 (TIMER MANAGEMENT, start 8 timers successfully)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER MANAGEMENT 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	.vic / Oiivi	PROACTIVE COMMAND:	[timer 1]
		TIMER MANAGEMENT 1.6.1	
4	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
5	$SIM \to ME$	MANAGEMENT 1.6.1 PROACTIVE COMMAND	
5	SIIVI → IVIE	PENDING: TIMER	
		MANAGEMENT 1.6.2	
6	$ME \to SIM$	FETCH	
7		PROACTIVE COMMAND:	[timer 2]
8	$ME \rightarrow SIM$	TIMER MANAGEMENT 1.6.2 TERMINAL RESPONSE: TIMER	[command performed successfully]
	IVIL -> OIIVI	MANAGEMENT 1.6.2	[seminaria perfermed edecectrally]
9	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
10	$ME \rightarrow SIM$	MANAGEMENT 1.6.3 FETCH	
11	IVIE -> SIIVI	PROACTIVE COMMAND:	[timer 3]
		TIMER MANAGEMENT 1.6.3	[
12	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
40	CINA NAT	MANAGEMENT 1.6.3	
13	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.6.4	
14	$ME \to SIM$	FETCH	
15		PROACTIVE COMMAND:	[timer 4]
16	ME CIM	TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER	[command performed successfully]
10	$ME \rightarrow SIM$	MANAGEMENT 1.6.4	[command performed successfully]
17	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
10		MANAGEMENT 1.6.5	
18 19	$ME \rightarrow SIM$	FETCH PROACTIVE COMMAND:	[timer 5]
		TIMER MANAGEMENT 1.6.5	
20	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
	0114	MANAGEMENT 1.6.5	
21	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.6.6	
22	$ME \to SIM$	FETCH	
23		PROACTIVE COMMAND:	[timer 6]
24		TIMER MANAGEMENT 1.6.6	[command performed augmentally]
24	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6	[command performed successfully]
25	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
00	ME 011:	MANAGEMENT 1.6.7	
26 27	$ME \rightarrow SIM$	FETCH PROACTIVE COMMAND:	[timer 7]
21		TIMER MANAGEMENT 1.6.6	
28	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.6.7	
29	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER MANAGEMENT 1.6.8	
30	$ME \to SIM$	FETCH	
31		PROACTIVE COMMAND:	[timer 8]
		TIMER MANAGEMENT 1.6.8	
32	$ME \to SIM$		[command performed successfully]
		MANAGEMENT 1.6.8	

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	01	A5	03	00	00	50					

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	01									

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 2

Timer value

Value of timer: 5 s

### Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	02	A5	03	00	00	50					

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 2

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	02									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 3

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	03	A5	03	00	00	50					

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 3

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	03									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 4

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	04	A5	03	00	00	50					

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 4

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	04									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM Destination device: ME

Timer identifier

Identifier of timer: 5

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	05	A5	03	00	00	50					

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 5

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	05									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 6

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	06	A5	03	00	00	50					

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 6

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	06									

### PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 7

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4	
	01	07	A5	03	00	00	50						

### TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 7

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	Α4	01	07									

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 8

Timer value

Value of timer: 5 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	80	A5	03	00	00	50					

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 8

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	08									

27.22.4.21.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

27.22.4.21.2 ENVELOPE TIMER EXPIRATION (normal)

27.22.4.21.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.21.2.2 Conformance requirement

The ME shall support the ENVELOPE (TIMER EXPIRATION) command as defined in the following technical specifications:

• 3GPP TS 11.14 clause 4.10, clause 10.1 and clause 10.2.

The ME shall support the TIMER MANAGEMENT as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.21, clause 6.8, clause 12.6, clause 12.7, clause 12.37 and clause 12.38.

### 27.22.4.21.2.3 Test purpose

To verify that the ME shall pass the identifier of the timer that has expired and its value using the ENVELOPE (TIMER EXPIRATION) command, when a timer previously started in a TIMER MANAGEMENT proactive command expires.

27.22.4.21.2.4 Method of test

27.22.4.21.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The timer 1 is not started.

When the SIM is busy when the envelope TIMER EXPIRATION is sent, either the ME retries periodically to send the envelope, either it waits for a TERMINAL RESPONSE processed by the SIM with status '90 00'.

If the ME waits for a TR with status '90 00', the ME manufacturer shall specify how many TERMINAL RESPONSES with status '90 00' are expected before sending the TIMER EXPIRATION envelope.

#### 27.22.4.21.2.4.2 Procedure

### Expected Sequence 2.1 (TIMER EXPIRATION, pending proactive SIM command)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND: TIMER	[timer 1]
		MANAGEMENT 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 2.1.1	
5	$ME \rightarrow SIM$	ENVELOPE: TIMER EXPIRATION	
		2.1.1	
6	$SIM \to ME$	PROACTIVE COMMAND	[response to envelope is "91 xx"]
		PENDING: MORE TIME X.1(or an	
		other SAT command tested before	
		to ensure it is properly supported	
		by the mobile).	
7	$ME \to SIM$	FETCH	

### PROACTIVE COMMAND: TIMER MANAGEMENT 2.1.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 0 h 0 min 10 s

Coding:

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	01	A5	03	00	00	01					

### TERMINAL RESPONSE: TIMER MANAGEMENT 2.1.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
·	A4	01	01									

# **ENVELOPE: TIMER EXPIRATION 2.1.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier Timer 1

Timer value

Hour: '00' Minute: '00' Second: '10'  $\pm$  1 s

BER-TLV:	D7	0C	82	02	82	81	A4	01	01	A5	03	00
·	00	XX										

# **Expected Sequence 2.2A (TIMER EXPIRATION, SIM application toolkit busy)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND: TIMER	[timer 1]
		MANAGEMENT 2.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 2.2.1	
5	$ME \rightarrow SIM$	ENVELOPE: TIMER EXPIRATION	
		2.2.1A	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION BUSY	[SIM is busy; response to the envelope = "93 00"]
			[SIM is busy during 10 seconds, the ME retries the sending of the envelope until it is accepted]
7		ENVELOPE: TIMER EXPIRATION 2.2.1B	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION BUSY	[SIM is busy, response to the envelope = "93 00"]
9		ENVELOPE: TIMER EXPIRATION 2.2.1C	-
10	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	[SIM is not busy]

Or:

# **Expected Sequence 2.2B (TIMER EXPIRATION, SIM application toolkit busy)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 2.2.1	
2	$ME \rightarrow SIM$		Itima and 41
3		PROACTIVE COMMAND: TIMER MANAGEMENT 2.2.1	[timer 1]
4		TERMINAL RESPONSE: TIMER MANAGEMENT 2.2.1	[command performed successfully]
5	$ME \rightarrow SIM$	ENVELOPE: TIMER EXPIRATION 2.2.1A	
6	$SIM \to ME$	RESPONSE TO THE ENVELOPE	[SIM is busy; response to the envelope = "93 00"]
			[SIM is busy during 10 sec, the ME may retry to send the envelope. After one (or several) answer(s) 93 00, the ME waits for a TERMINAL RESPONSE processed by the SIM with status "90 00"]
7	$ME \rightarrow SIM$	STATUS	[SIM is not busy]
8	$SIM \rightarrow ME$	Response to the STATUS	[SW1/SW2=91 xx]
		command	
9	$ME \rightarrow SIM$	PROACTIVE COMMAND PENDING	
10	$SIM \rightarrow ME$	FETCH	
		PROACTIVE COMMAND: e.g. MORE TIME 2.2.2	
11	$ME \rightarrow SIM$	TERMINAL RESPONSE: e.g. TIMER MANAGEMENT 2.2.2	[command performed successfully]
12	$SIM \rightarrow ME$		[SW1/SW2 = 90 00]
			Steps 7→12 shall be repeated (X-1) times if the ME manufacturers specifies that the ME waits for X TERMINAL RESPONSES with status 90 00 to send the TIMER EXPIRATION envelope.
13	$ME \rightarrow SIM$	ENVELOPE: TIMER EXPIRATION 2.2.1B	
14		PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: TIMER MANAGEMENT 2.2.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier

Identifier of timer: 1

Timer value

Value of timer: 0 h 0 min 30 s

BER-TLV:	D0	11	81	03	01	27	00	82	02	81	82	A4
	01	01	A5	03	00	00	03					

TERMINAL RESPONSE: TIMER MANAGEMENT 2.2.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier

Identifier of timer: 1

Coding:

BER-TLV:	81	03	01	27	00	82	02	82	81	83	01	00
	A4	01	01									

**ENVELOPE: TIMER EXPIRATION 2.2.1A** 

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier

Timer 1

Timer value

Hour: '00'Minute: '00'Second:  $'30' \pm 1 \text{ s}$ 

Coding:

BER-TLV:	D7	0C	82	02	82	81	A4	01	01	A5	03	00
	00	XX										

**ENVELOPE: TIMER EXPIRATION 2.2.1B** 

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier
Timer 1

Timer value

Hour: '00' Minute: '00'

Second:  $\geq$  timer in clause 2.2.1A

BER-TLV:	D7	0C	82	02	82	81	A4	01	01	A5	03	00
	00	XX										

**ENVELOPE: TIMER EXPIRATION 2.2.1C** 

Logically:

Device identities

Source device: ME Destination device: SIM

Timer identifier Timer 1 Timer value

> Hour: '00' Minute: '00'

Second:  $\geq$  timer in 2.2.1B

Coding:

BER-TLV:	D7	0C	82	02	82	81	A4	01	01	A5	03	00
	00	XX										

PROACTIVE COMMAND: MORE TIME 2.2.2

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

	BEI	R-TLV:	D0	09	81	03	01	02	00	82	02	81	82
--	-----	--------	----	----	----	----	----	----	----	----	----	----	----

TERMINAL RESPONSE: MORE TIME 2.2.2

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

				0	-		0	S				
BER-TLV:	Ι Ω1	<b>∩</b> 3	Ι Λ1	1 02	00	22		1 27	Ω1	ΩQ	Λ1	00
	1 01	1 03		1 02	1 00	02	1 02	02	101	1 00		1 00

27.22.4.21.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.2B.

### 27.22.4.22 SET UP IDLE MODE TEXT

### 27.22.4.22.1 SET UP IDLE MODE TEXT (normal)

### 27.22.4.22.1.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.22.1.2 Conformance requirement

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.22, clause 6.6.22, clause 6.4.16, clause 6.6.16, clause 11.6, clause 6.8, clause 11, clause 11.1, clause 12.25, clause 6.4.7 and clause 6.6.13.

Additionally the ME shall support the REFRESH proactive SIM facility as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.1, clause 6.4.7, clause 6.6.13, clause 6.11, clause 12.6, clause 12.12, clause 13.4 and clause 14.

### 27.22.4.22.1.3 Test purpose

To verify that the text passed to the ME is displayed as idle mode text.

#### 27.22.4.22.1.4 Method of test

### 27.22.4.22.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

### 27.22.4.22.1.4.2 Procedure

# Expected Sequence 1.1 (SET UP IDLE MODE TEXT, display idle mode text)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Idle Mode Text]
		PENDING: SET UP IDLE MODE	
		TEXT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 1.1.2	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command performed successfully]
		IDLE MODE TEXT 1.1.1	
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
6			Only if idle screen not already available
7	$ME \to USER$	Display "Idle Mode Text"	

### PROACTIVE COMMAND: SET UP IDLE MODE TEXT 1.1.1

### Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Idle Mode Text"

Coding:

BER-TLV:	D0	1A	81	03	01	28	00	82	02	81	82	8D
	0F	04	49	64	6C	65	20	4D	6F	64	65	20
	54	65	78	74								

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	00
DEIX IEV.	0.	00	0.		00	02	02	02	0.	00	0.	00

# Expected Sequence 1.2 (SET UP IDLE MODE TEXT, replace idle mode text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP IDLE MODE	
		TEXT 1.1.2	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[Idle Mode Text]
		IDLE MODE TEXT 1.1.2	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		IDLE MODE TEXT 1.1.2	
5	$USER \to ME$	Select idle screen	Only if idle screen not already available
6	$ME \rightarrow USER$	Display "Idle Mode Text"	
7	$SIM \to ME$	PROACTIVE COMMAND	[Idle Mode Text]
		PENDING: SET UP IDLE MODE	
		TEXT 1.2.1	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		IDLE MODE TEXT 1.2.1	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
10			Only if idle screen not already available
11	$ME \rightarrow USER$	Display "Toolkit Test"	

PROACTIVE COMMAND: SETUP IDLE MODE TEXT 1.2.1

Logically:

Command details

Command number: 1

Command type: SETUP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM

Destination device: Display

**Text String** 

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test"

Coding:

BER-TLV:	D0	18	81	03	01	28	00	82	02	81	82	8D
	0D	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74										

### TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.2.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	00
	0.	00		20	00	02	02	02	0.	00	0.	00

### Expected Sequence 1.3 (SET UP IDLE MODE TEXT, remove idle mode text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
		SET UP IDLE MODE TEXT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$		["Idle Mode Text"]
		IDLE MODE TEXT 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
_		IDLE MODE TEXT 1.1.1	
5		Select idle screen	Only if idle screen not already available
6	$ME \rightarrow USER$	Display "Idle Mode Text"	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
		SET UP IDLE MODE TEXT 1.3.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[Remove idle mode text]
		IDLE MODE TEXT 1.3.1	
10	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		IDLE MODE TEXT 1.3.1	
11	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
12	$USER \to ME$	Select idle screen	Only if idle screen not already available
13	$ME \rightarrow USER$	Display idle screen / "Idle Mode Text"	
		not to be displayed	

### PROACTIVE COMMAND: SETUP IDLE MODE TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: SETUP IDLE MODE TEXT

Command qualifier: RFU

Source device: SIM Destination device: ME

Text String: zero length TLV

Coding:

BER-TLV:	D0	0B	81	03	01	28	00	82	02	81	82	8D
	00											

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	00

# **Expected Sequence 1.4 (SET UP IDLE MODE TEXT, competing information on ME display)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP IDLE MODE	
		TEXT 1.1/2	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	["Idle Mode Text"]
		IDLE MODE TEXT 1.1.2	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command performed successfully]
_		IDLE MODE TEXT 1.12	
5	$USER \to ME$	Select idle screen	Only if idle screen not already available
6	$ME \rightarrow USER$	Display "Idle Mode Text"	
7	$SS \to ME$	SMS PP 1.4.1	[Display immediate SMS]
8	$ME \to USER$	Display "Short Message"	
9	$USER \to ME$	Clear display and select idle	
		screen	
10	$ME \rightarrow USER$	Display "Idle Mode Text"	
11	$SIM \to ME$	PROACTIVE COMMAND	
40		PENDING: DISPLAY TEXT 1.4.1	
12	$ME \rightarrow SIM$	FETCH	
13	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
14	ME LICED	DISPLAY TEXT 1.4.1	message, unpacked, 8 bit data]
	ME → USER	Display " Toolkit Test 1"	
15	USER → ME	Clear Message	[Command parformed augeopatully]
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: DISPLAY TEXT 1.4.1	[Command performed successfully]
17	ME LICED	Display "Idle Mode Text"	
18	$SIM \rightarrow ME$	PROACTIVE COMMAND	
10	SIIVI → IVI⊑	PENDING: PLAY TONE 1.4.1	
19	$ME \rightarrow SIM$	FETCH	
20	$SIM \rightarrow ME$	PROACTIVE COMMAND: PLAY	
	OIIVI / IVIL	TONE 1.4.1	
21	$ME \rightarrow USER$	Display "Dial Tone"	
		Play a standard supervisory dial	
		tone through the external ringer for	
		a duration of 5 s	
22	$ME \to SIM$	TERMINAL RESPONSE: PLAY	[Command performed successfully]
		TONE 1.4.1	
23	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
0.4		ENDED	
24	$ME \rightarrow USER$	Display "Idle Mode Text"	

# SMS-PP 1.4.1

Logically:

SMS TPDU	
TP-MTI	SMS-SUBMIT
TP-RD	Instruct the SC to accept an SMS-SUBMIT for a SM
TP-VPF	TP-VP field not present
TP-RP	TP-Reply-Path is not set in this SMS-SUBMIT
TP-UDHI	The TP-UD field contains only the short message
TP-SRR	A status report is not requested
TP-MR	"00"
TP-DA	
TON	International number
NPI	"ISDN / telephone numbering plan"
Address value	"012345678"
TP-PID	Short message type 0
TP-DCS	
Message coding	8-bit data
Message class	class 0

TP-UDL 12

TP-UD "Test Message"

Coding:

BER-TLV:	01	00	09	91	10	32	54	76	F8	40	F4	0C
	54	65	73	74	20	4D	65	73	73	61	67	65

### PROACTIVE COMMAND: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Coding:

BER-TLV:	D0	1A	81	03	01	21	80	82	02	81	02	8D
	0F	04	54	6F	6F	6C	6B	69	74	20	54	65
	73	74	20	31								

### TERMINAL RESPONSE: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

### PROACTIVE COMMAND: PLAY TONE 1.4.1

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

TONe: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV:	D0	1B	81	03	01	20	00	82	02	81	03	85
	09	44	69	61	6C	20	54	6F	6E	65	8E	01
	01	84	02	01	05							

TERMINAL RESPONSE: PLAY TONE 1.4.1

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	20	00	82	02	82	81	83	01	00
DLIX-ILV.	01	00	01	20	00	02	02	02	01	00	01	00

# **Expected Sequence 1.5 (SET UP IDLE MODE TEXT, ME power cycled)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP IDLE MODE	
		TEXT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	["Idle Mode Text"]
		IDLE MODE TEXT 1.1.2	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[command performed successfully]
		IDLE MODE TEXT 1.1.2	
5	$USER \to ME$	Select idle screen	Only if idle screen not already available
6	$ME \rightarrow USER$	Display "Idle Mode Text"	
7	$USER \rightarrow ME$	Power off ME	
8	$ME \Leftrightarrow SIM$	GSM TERMINATION	
		PROCEDURE	
9	$USER \rightarrow ME$	Power on ME	
10	$ME \Leftrightarrow SIM$	GSM ACTIVATION PROCEDURE	
11	$ME \Leftrightarrow SIM$	SIM INITIALIZATION	
12	$USER \to ME$	Select idle screen	Only if idle screen not already available
13	$ME \rightarrow USER$	Display idle screen / "Idle Mode	
		Text" not to be displayed	

# Expected Sequence 1.6 (SET UP IDLE MODE TEXT, REFRESH with SIM Initialization)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[Idle Mode Text]
		PENDING: SET UP IDLE MODE	
		TEXT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 1.1.2	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		IDLE MODE TEXT 1.1.2	
5		Select idle screen	Only if idle screen not already available
6	$ME \rightarrow USER$	Display "Idle Mode Text"	
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: REFRESH 1.6.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND:	[SIM Initialization]
		REFRESH 1.6.1	
10	$ME \Leftrightarrow SIM$	SIM INITIALIZATION	
11	$USER \to ME$	Select idle screen	Only if idle screen not already available
12	$ME \rightarrow USER$	Display idle screen / "Idle Mode	
		Text" not to be displayed	
13	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		REFRESH 1.6.1A	
		or	
		TERMINAL RESPONSE:	[Command performed successfully with
		REFRESH 1.6.1B	additional files read]
14	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: REFRESH 1.6.1

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	01	03	82	02	81	82
			• .		<b>.</b>	• .		~-	~-	• .	

TERMINAL RESPONSE: REFRESH 1.6.1A

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	01	01	03	82	02	82	81	83	01	00

TERMINAL RESPONSE: REFRESH 1.6.1B

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialization

Device identities

Source device: ME Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 03

# **Expected Sequence 1.7 (SET UP IDLE MODE TEXT, large text string)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[large text string]
		PENDING: SET UP IDLE MODE	
		TEXT 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 1.7.1	
4	$ME \rightarrow SIM$		[command performed successfully]
		IDLE MODE TEXT 1.7.1	
5	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
6	$USER \to ME$	Select idle screen	Only if idle screen not already available
7	$ME \rightarrow USER$	' '	[274 characters]
		text string, which shall be	
		displayed by the ME as an idle	
		mode text if the ME is able to do it.	
		The presentation style is left as an	
		implementation decision to the ME	
		manufacturer. The idle mode text	
		shall be displayed in a manner that	
		ensures that ne"	

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text String

Data coding scheme: packed, SMS default alphabet

Text: "The SIM shall supply a text string, which shall be displayed by the ME as an idle

mode text if the ME is able to do it. The presentation style is left as an implementation decision to the ME manufacturer. The idle mode text shall be

displayed in a manner that ensures that ne"

Coding:

	_											
BER-TLV:	D0	81	FD	81	03	01	28	00	82	02	81	82
	8D	81	F1	00	54	74	19	34	4D	36	41	73
	74	98	CD	06	CD	EB	70	38	3B	0F	0A	83
	E8	65	3C	1D	34	A7	СВ	D3	EE	33	0B	74
	47	A7	C7	68	D0	1C	1D	66	В3	41	E2	32
	88	9C	9E	C3	D9	E1	7C	99	0C	12	E7	41
	74	74	19	D4	2C	82	C2	73	50	D8	0D	4A
	93	D9	65	50	FB	4D	2E	83	E8	65	3C	1D
	94	36	83	E8	E8	32	A8	59	04	A5	E7	A0
	B0	98	5D	06	D1	DF	20	F2	1B	94	A6	BB
	A8	E8	32	08	2E	2F	CF	СВ	6E	7A	98	9E
	7E	BB	41	73	7A	9E	5D	06	A5	E7	20	76
	D9	4C	07	85	E7	A0	B0	1B	94	6E	C3	D9
	E5	76	D9	4D	0F	D3	D3	6F	37	88	5C	1E
	A7	E7	E9	B7	1B	44	7F	83	E8	E8	32	A8
	59	04	B5	C3	EE	BA	39	3C	A6	D7	E5	65
	B9	0B	44	45	97	41	69	32	BB	0C	6A	BF
	C9	65	10	BD	8C	A7	83	E6	E8	30	9B	0D
	12	97	41	E4	F4	1C	CE	0E	E7	СВ	64	50
	DA	0D	0A	83	DA	61	B7	BB	2C	07	D1	D1
	61	3A	A8	EC	9E	D7	E5	E5	39	88	8E	0E
	D3	41	EE	32								

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.7.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

27.22.4.22.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.7.

27.22.4.22.2 SET UP IDLE MODE TEXT (Icon support)

27.22.4.22.2.1 Definition and applicability

See clause 3.2.2.

27.22.4.22.2.2 Conformance requirement

27.22.4.22.2.3 Test purpose

To verify that the ME text and / or icon passed to the ME is displayed by the ME as an idle mode text.

To verify that the icon identifier provided with the text string can replace the text string or accompany it.

To verify that if both an alpha identifier or text string, and an icon are provided with a proactive command, and both are requested to be displayed, but the ME is not able to display both together on the screen, then the alpha identifier or text string takes precedence over the icon.

To verify that if the SIM provides an icon identifier with a proactive command, then the ME shall inform the SIM if the icon could not be displayed by sending the general result "Command performed successfully, but requested icon could not be displayed".

To verify that if the ME receives an icon qualifier with bit 1 set to 0, meaning "an alpha identifier or text string related to the icon may be displayed together with the icon by the ME", and no alpha identifier / text string is given by the SIM, than the ME shall reject the command with general result "Command data not understood by ME".

27.22.4.22.2.4 Method of test

27.22.4.22.2.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

### 27.22.4.22.2.4.2 Procedure

### Expected Sequence 2.1A (SET UP IDLE MODE TEXT, Icon is self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Icon is self-explanatory]
		PENDING: SET UP IDLE MODE	·
		TEXT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 2.1.1	
4	$ME \to SIM$	TERMINAL RESPONSE: SET UP	[command performed successfully]
		IDLE MODE TEXT 2.1.1A	
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
6		Select idle screen	Only if idle screen not already available
7	$ME \to USER$	Display the icon	

### PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM Destination device: ME

Text String: "Idle text"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV:	D0	19	81	03	01	28	00	82	02	81	82	8D
	0A	04	49	64	6C	65	20	74	65	78	74	9E
	02	00	01									

### TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	00
DLIX-ILV.	01	03	01	20	00	02	02	02	01	00	01	00

# Expected Sequence 2.1B (SET UP IDLE MODE TEXT, Icon is self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Icon is self-explanatory]
		PENDING: SET UP IDLE MODE	
		TEXT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Command performed successfully, but
		IDLE MODE TEXT 2.1.1B	requested icon could not be displayed]
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
6			Only if idle screen not already available
7	$ME \to USER$	Display "Idle text" without the icon	

### TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	04

# Expected Sequence 2.2A (SET UP IDLE MODE TEXT, Icon is not self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Icon is not self-explanatory]
		PENDING: SET UP IDLE MODE	
		TEXT 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 2.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[command performed successfully]
		IDLE MODE TEXT 2.2.1A	
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
6	$USER \to ME$	Select idle screen	Only if idle screen not already available
7	$ME \rightarrow USER$	Display icon #1 and "Idle text"	

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.2.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text String: "Idle text"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV:	D0	19	81	03	01	28	00	82	02	81	82	8D
	0A	04	49	64	6C	65	20	74	65	78	74	9E
	02	01	01									

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.2.1A

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	Λ1	28	00	82	02	82	81	83	Λ1	00
DER-ILV.	01	US	I U I		UU	02	UZ	02	01	ೲ	UI	UU

### Expected Sequence 2.2B (SET UP IDLE MODE TEXT, Icon is not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Icon is not self-explanatory]
		PENDING: SET UP IDLE MODE	
		TEXT 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 2.2.1	
4	,		[Command performed successfully, but
		IDLE MODE TEXT 2.2.1B	requested icon could not be displayed]
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
6	$USER \to ME$	Select idle screen	Only if idle screen not already available
7	$ME \rightarrow USER$	Display "Idle text" without the icon	

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT RFU

Command qualifier:

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

	BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	04
--	----------	----	----	----	----	----	----	----	----	----	----	----	----

### Expected Sequence 2.3 (SET UP IDLE MODE TEXT, Icon is self-explanatory, colour icon)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Icon is self-explanatory]
		PENDING: SET UP IDLE MODE	·
		TEXT 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 2.3.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[command performed successfully]
		IDLE MODE TEXT 2.3.1	
			[requested icon could not be displayed]
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
6	$USER \to ME$	Select idle screen	Only if idle screen not already available
7	ME USER	Display "Idle text"	

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.3.1

Logically:

Command details

Command number:

SET UP IDLE MODE TEXT Command type:

Command qualifier: **RFU** 

Device identities

SIM Source device:

Destination device: ME
Text String: "Idle text"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 2 in EF IMG>

Coding:

BER-TLV:	D0	19	81	03	01	28	00	82	02	81	82	8D
	0A	04	49	64	6C	65	20	74	65	78	74	9E
	02	00	02									

### TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.3.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	00
	0.	00			00	02	02	02	0.	00		00

### TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.3.2

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

	E	BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	04
--	---	----------	----	----	----	----	----	----	----	----	----	----	----	----

### Expected Sequence 2.4 (SET UP IDLE MODE TEXT, Icon is not self-explanatory, no text string)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Icon is not self-explanatory, no text string]
		PENDING: SET UP IDLE MODE	
		TEXT 2.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 2.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		IDLE MODE TEXT 2.4.1	
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.4.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM Destination device: ME

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

E	BER-TLV:	D0	0D	81	03	01	28	00	82	02	81	82	9E	1
		02	01	01										

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 2.4.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

27.22.4.22.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1A to 2.4.

### 27.22.4.22.3 SET UP IDLE MODE TEXT (UCS2 support)

27.22.4.22.3.1 Definition and applicability

See clause 3.2.2.

27.22.4.22.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646 [17].

27.22.4.22.3.3 Test purpose

To verify that the UCS2 coded text string is displayed by the ME as an idle mode text.

27.22.4.22.3.4 Method of test

27.22.4.22.3.4.1 Initial conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.22.3.4.2 Procedure

### Expected Sequence 3.1 (SET UP IDLE MODE TEXT, UCS2 alphabet text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	["Hello" in Russian]
		PENDING: SET UP IDLE MODE	
		TEXT 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	
		IDLE MODE TEXT 3.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		IDLE MODE TEXT 3.1.1	
5	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
6		Select idle screen	Only if idle screen not already available
7	$ME \rightarrow USER$	Display " ЗДРАВСТВУЙТЕ"	["Hello" in Russian]

### PROACTIVE COMMAND: SET UP IDLE MODE TEXT 3.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

**Text String** 

Data coding scheme: UCS2 (16bit)
Text: "ЗДРАВСТВУЙТЕ"

-	BER-TLV:	D0	2/	Ω1	Λ3	Ω1	28	00	82	02	Ω1	82	βD
- 11	3E D = 1 L V .	1 120	1 /4		(),)		1 /0	1 ()()	0/	1 0/		0/	עסו

19	80	04	17	04	14	04	20	04	10	04	12
04	21	04	22	04	12	04	23	04	19	04	22
04	15										

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier:

RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	28	00	82	02	82	81	83	01	00

### 27.22.4.22.3.5 Test requirement

The ME shall operate in the manner defined in expected sequence 3.1.

### 27.22.4.23 RUN AT COMMAND

### 27.22.4.23.1 RUN AT COMMAND (normal)

### 27.22.4.23.1.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.23.1.2 Conformance requirement

The ME shall support the Proactive SIM: RUN AT COMMAND facility as defined in:

- 3GPP TS 11.14 [15] clause 6.4.23, clause 6.6.23, clause 5.2, clause 6.8, clause 12.6, clause 12.7, clause 12.2, clause 12.40, clause 12.31 and clause 12.41.
- 3GPP TS 27.007 [18].

### 27.22.4.23.1.3 Test purpose

To verify that the ME responds to an AT Command contained within a RUN AT COMMAND as though it were initiated by an attached TE, and returns an AT Response within a TERMINAL RESPONSE to the SIM.

### 27.22.4.23.1.4 Method of test

### 27.22.4.23.1.4.1 Initial conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the test the ME shall be connected to the TE.

The TA-TE interface is set to 8-bit operation.

### 27.22.4.23.1.4.2 Procedure

# Expected Sequence 1.1(RUN AT COMMAND, no alpha identifier presented, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[no alpha identifier, request IMSI]
		AT COMMAND 1.1.1	
4	ME ( $\rightarrow$ User)	The ME may give information to	
		the user concerning what is	
		happening	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 1.1.1	Response containing IMSI]

### PROACTIVE SIM COMMAND: RUN AT COMMAND 1.1.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Coding:

BER-TLV:	D0	12	81	03	01	34	00	82	02	81	82	A8
	07	41	54	2B	43	49	4D	43				

### TERMINAL RESPONSE: RUN AT COMMAND 1.1.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

AT Response

AT Response string: IMSI

BER-TLV:	81	03	01	34	00	82	02	82	81	83	01	00
	Α9	08	08	09	10	10	32	54	76	98		

### Expected Sequence 1.2 (RUN AT COMMAND, null data alpha identifier presented, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[null data alpha identifier, request IMSI]
		AT COMMAND 1.2.1	
4	ME	The ME should not give any	
		information to user on the fact that	
		the ME is performing an AT	
		command	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 1.1.1	Response containing IMSI]

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.2.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier null data object

AT Command

AT Command string: "AT+CIMI"

Coding:

BER-TLV:	D0	14	81	03	01	34	00	82	02	81	82	85
_	00	A8	07	41	54	2B	43	49	4D	49		

# Expected Sequence 1.3 (RUN AT COMMAND, alpha identifier presented, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		1.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[alpha identifier, request IMSI]
		AT COMMAND 1.3.1	
4	$ME \to USER$	Display "Run AT Command"	
7	$ME \to SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 1.1.1	Response containing IMSI]

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.3.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha Identifier "Run AT Command"

AT Command

AT Command string: "AT+CIMI"

Coding:

BER-TLV:	D0	22	81	03	01	34	00	82	02	81	82	85
_	0E	52	75	6E	20	41	54	20	43	6F	6D	6D
	61	6E	64	A8	07	41	54	2B	43	49	4D	49

#### 27.22.4.23.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

## 27.22.4.23.2 RUN AT COMMAND (Icon support)

27.22.4.23.2.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.23.2.2 Conformance requirement

The ME shall support the Proactive SIM: RUN AT COMMAND facility as defined in:

- 3GPP TS 11.14 [15] clause 6.4.23, clause 6.6.23, clause 5.2, clause 6.8, clause 12.6, clause 12.7, clause 12.2, clause 12.40, clause 12.31 and clause 12.41.
- 3GPP TS 27.007 [18].

## 27.22.4.23.2.3 Test purpose

To verify that the ME responds to an AT Command contained within a RUN AT COMMAND as though it were initiated by an attached TE, and returns an AT Response within a TERMINAL RESPONSE to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.23.2.4 Method of test

#### 27.22.4.23.2.4.1 Initial conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the test the ME shall be connected to the TE.

The TA-TE interface is set to 8-bit operation.

The ME screen shall be in its normal stand-by display.

### 27.22.4.23.2.4.2 Procedure

# Expected Sequence 2.1 (RUN AT COMMAND, basic icon self explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[BASIC-ICON, self-explanatory, request IMSI]
		AT COMMAND 2.1.1	
4	$ME \rightarrow USER$	Display BASIC ICON	
		Or	
		May give information to user	
		concerning what is happening	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
			containing IMSI]

### PROACTIVE COMMAND: RUN AT COMMAND 2.1.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon identifier:} & \mbox{record 1 in } \mbox{EF}_{(IMG)} \\ \end{array}$ 

Coding:

BER-TLV:	D0	16	81	03	01	34	00	82	02	81	82	A8
·	07	41	54	2B	43	49	4D	43	9E	02	00	01

## TERMINAL RESPONSE: RUN AT COMMAND 2.1.1A

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

AT Response

AT Response string: IMSI

BER-TLV:	81	03	01	34	00	82	02	82	81	83	01	00
	A9	80	08	09	10	10	32	54	76	98		

TERMINAL RESPONSE: RUN AT COMMAND 2.1.1B

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

AT Response

AT Response string: IMSI

Coding:

BER-TLV:	81	03	01	34	00	82	02	82	81	83	01	04
	A9	08	08	09	10	10	32	54	76	98		

## Expected Sequence 2.2 (RUN AT COMMAND, colour icon self explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[COLOUR-ICON, self-explanatory, request
		AT COMMAND 2.2.1	IMSI]
4	$ME \rightarrow USER$	Display COLOUR-ICON	
		Or	
		May give information to user	
		concerning what is happening	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
1			containing IMSI]

PROACTIVE COMMAND: RUN AT COMMAND 2.2.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon identifier:} & \mbox{record 2 in } EF_{(IMG)} \\ \end{array}$ 

# Coding:

BER-TLV:	D0	6	81	03	01	34	00	82	02	81	82	A8
	07	41	54	2B	43	49	4D	43	9E	02	00	02

# Expected Sequence 2.3 (RUN AT COMAND, basic icon non self-explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[BASIC-ICON, non self-explanatory, request
		AT COMMAND 2.3.1	IMSI]
4	$ME \to USER$	Display "Basic Icon" and BASIC-	
		ICON	
		Or	
		Display "Basic Icon"	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
			containing IMSI]

# PROACTIVE COMMAND: RUN AT COMMAND 2.3.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Alpha Identifier

Alpha identifier: "Basic Icon"

AT Command

AT Command string: "AT+CIMI"

Icon identifier

Icon qualifier: icon is non self-explanatory

Icon identifier: record 1 in  $EF_{(IMG)}$ 

BER-TLV:	D0	22	81	03	01	34	00	82	02	81	82	85
	0A	42	61	73	69	63	20	49	63	6F	6D	A8
	07	41	54	2B	43	49	4D	43	9F	02	01	01

## Expected Sequence 2.4 (RUN AT COMMAND, colour icon non self-explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[COLOUR-ICON, non self-explanatory,
		AT COMMAND 2.4.1	request IMSI]
4	$ME \to USER$	Display "Colour Icon" and	
		COLOUR-ICON	
		Or	
		Display "Colour Icon"	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
			[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
			containing IMSI]

PROACTIVE COMMAND: RUN AT COMMAND 2.4.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha identifier: "Colour Icon"

AT Command

AT Command string: "AT+CIMI"

Icon identifier:

Icon qualifier: icon is self-explanatory Icon identifier: record 2 in  $EF_{(IMG)}$ 

### Coding:

BER-TLV:	D0	23	81	03	01	34	00	82	02	81	82	85
_	0B	43	6F	6C	6F	75	72	20	49	63	6F	6D
	A8	07	41	54	2B	43	49	4D	43	9E	02	01
	02											

# Expected Sequence 2.5 (RUN AT COMMAND, basic icon non self-explanatory, no alpha identifier presented)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		SS 2.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[BASIC-ICON, non self-explanatory]
		AT COMMAND 2.5.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command data not understood by ME]
		COMMAND 2.5.1	

PROACTIVE COMMAND: RUN AT COMMAND 2.5.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon identifier

Icon qualifier: icon is non self-explanatory

Icon identifier: record 1 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	16	81	03	01	34	00	82	02	81	82	A8
	07	41	54	2B	43	49	4D	43	9E	02	01	01

### TERMINAL RESPONSE: RUN AT COMMAND 2.5.1

#### Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Result

General Result: Command data not understood by ME

Coding:

BER-TLV:	81	03	01	34	00	82	02	82	81	83	01	32	l
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

### 27.22.4.23.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.5.

### 27.22.4.24 SEND DTMF

## 27.22.4.24.1 SEND DTMF (Normal)

## 27.22.4.24.1.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.24.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.24, clause 6.6.24, clause 12.12.2, clause 5.2, clause 12.6, clause 12.7, clause 12.2 and clause 12.44.

#### 27.22.4.24.1.3 Test purpose

To verify that after a call has been successfully established the ME sends the DTMF string contained in the SEND DTMF proactive SIM command to the network, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME does not locally generate audible DTMF tones and play them to the user.

To verify that if the ME is in idle mode it informs the SIM using TERMINAL RESPONSE '20' with the additional information "Not in speech call".

To verify that the ME displays the text contained in the SEND DTMF proactive SIM command.

To verify that if an alpha identifier is provided by the SIM and is a null data object the ME does not give any information to the user on the fact that the ME is performing a SEND DTMF command.

#### 27.22.4.24.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

#### 27.22.4.24.1.4. 2 Procedure

# Expected Sequence 1.1 (SEND DTMF, A call has been successfully established before the beginning of the test)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DTMF 1.1.1	
4	$ME \rightarrow USER$	May give information to the user concerning what is happening.	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
9	$SIM \rightarrow ME$	DTMF 1.1.1 PROACTIVE SIM SESSION ENDED	

### PROACTIVE COMMAND: SEND DTMF 1.1.1

## Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
DTMF String: "1" pause "2"

BER-TLV:	D0	0D	81	03	01	14	00	82	02	81	83	AC
	02	C1	F2									

Start DTMF 1.1

Logically:

DTMF String: "1"

Start DTMF 1.2

Logically:

DTMF String: "2"

TERMINAL RESPONSE: SEND DTMF 1.1.1

Logically:

Command details

Command number: 1

Communa number.

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:   81   03   01	14 00 82	02   82   81	83   01   00
-------------------------	----------	--------------	--------------

# Expected Sequence 1.2 (SEND DTMF, containing alpha identifier, a call has been successfully established before the beginning of the test)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DTMF 1.2.1	
4	$ME \rightarrow USER$		Alpha identifier
		Do not locally generate audible	
		DTMF tones and play them to the	
_	NAT 00	user.	[[[4]]]
5	$ME \rightarrow SS$	Start DTMF 1.1	["1"]
6	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
7	$ME \rightarrow SS$	Start DTMF 1.3	["3"]
8	$ME \rightarrow SS$	Start DTMF 1.4	["4"]
9	$ME \to SS$	Start DTMF 1.5	["5"]
10	$ME \to SS$	Start DTMF 1.6	["6"]
11	$ME \to SS$	Start DTMF 1.7	["7"]
12	$ME \to SS$	Start DTMF 1.8	["8"]
13	$ME \to SS$	Start DTMF 1.9	["9"]
14	$ME \to SS$	Start DTMF 1.10	["0"]
15	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
16	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: SEND DTMF 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Send DTMF"

DTMF String: "1234567890"

Coding:

BER-TLV:	D0	1B	81	03	01	14	00	82	02	81	83	85
	09	53	65	6E	64	20	44	54	4D	46	AC	05
	21	43	65	87	09							_

Start DTMF 1.3

Logically:

DTMF String: "3"

Start DTMF 1.4

Logically:

DTMF String: "4"

Start DTMF 1.5

Logically:

DTMF String: "5"

Start DTMF 1.6

Logically:

DTMF String: "6"

Start DTMF 1.7

Logically:

DTMF String: "7"

Start DTMF 1.8

Logically:

DTMF String: "8"

Start DTMF 1.9

Logically:

DTMF String: "9"

Start DTMF 1.10

Logically:

DTMF String: "0"

# Expected Sequence 1.3 (SEND DTMF, containing alpha identifier with null data object, a call has been successfully established before the beginning of the test)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	Alpha identifier with null data object
		DTMF 1.3.1	
4	$ME \rightarrow USER$	Do not give any information to the user on the fact that the ME is	
		performing a SEND DTMF	
		command.	
		Do not locally generate audible	
		DTMF tones and play them to the	
		user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 30 seconds ±20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		DTMF 1.1.1	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

## PROACTIVE COMMAND: SEND DTMF 1.3.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "" (null data object)

DTMF String: "1" pause "2"

BER-TLV:	D0	13	81	03	01	14	00	82	02	81	83	85
	00	AC	06	C1	CC	CC	CC	CC	2C			

## Expected Sequence 1.4 (SEND DTMF, mobile is not in a speech call)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		DTMF 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[ME currently unable to process command,
			not in speech call]
5	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

TERMINAL RESPONSE: SEND DTMF 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: ME currently unable to process command

Additional information: Not in speech call

Coding:

BER-TLV:	81	03	01	14	00	82	02	82	81	83	02	20
	07											

## 27.22.4.24.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences.

## 27.22.4.24.2 SEND DTMF (Display of icons)

27.22.4.24.2.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.24.2.2 Conformance requirement

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.24, clause 6.6.24, clause 12.12.2, clause 5.2, clause 12.6, clause 12.7, clause 12.2, clause 12.44, clause 12.31 and clause 6.5.4.

#### 27.22.4.24.2.3 Test purpose

To verify that after a call has been successfully established the ME send the DTMF string contained in the SEND DTMF proactive SIM command to the network, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME do not locally generate audible DTMF tones and play them to the user.

To verify that the ME displays the text contained in the SEND DTMF proactive SIM command.

To verify that the ME displays the icons which are referred to in the contents of the SEND DTMF proactive SIM command.

27.22.4.24.2.4 Method of test

27.22.4.24.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

The elementary files are coded as Toolkit default.

### 27.22.4.24.2.4.2 Procedure

## Expected Sequence 2.1 (SEND DTMF, BASIC ICON self explanatory, successful)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	[BASIC-ICON, self-explanatory]
		DTMF 2.1.1	
4	$ME \rightarrow USER$	Display the BASIC-ICON	
		Do not locally generate audible	
		DTMF tones and play them to the	
		user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		DTMF 2.1.1A	
9	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

#### PROACTIVE COMMAND: SEND DTMF 2.1.1

### Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Basic Icon"
DTMF String: "1" pause "2"

Icon identifier

Icon qualifier: icon is self-explanatory Icon identifier: record 1 in  $EF_{(IMG)}$ 

BER-TLV:	D0	1D	81	03	01	14	00	82	02	81	83	85
·	0A	42	61	73	69	63	20	49	63	6F	6E	AC
	02	C1	F2	9E	02	00	01					

DTMF Request 2.1.1

Logically:

DTMF String: \$DTMF\_2.1\$ = "C1 F2" (given as example)

TERMINAL RESPONSE: SEND DTMF 2.1.1A

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

RED_TI \/·	01	0.3	01	1/	00	92	02	92	01	93	01	00
IDEK-ILV.	1 01	1 03	1 01	1 1 <del>4</del>	I UU	1 02	I UZ	02		00	1 01	1 00

# Expected Sequence 2.1B (SEND DTMF, BASIC ICON self explanatory, requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DTMF 2.1.1	[BASIC-ICON, self-explanatory]
4	$ME \rightarrow USER$	Display "Basic Icon" without the	
		icon	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20 %
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully, but
		DTMF 2.1.1B	requested icon could not be displayed]
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

TERMINAL RESPONSE: SEND DTMF 2.1.1B

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed

Coding:

BER-TLV:	l 81	03	l 01	14	00	82	02	82	81	83	01	04
D		,					V-	U_				

## Expected Sequence 2.2 (SEND DTMF, COLOUR-ICON self explanatory, successful)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[COLOUR-ICON]
		DTMF 2.2.1	
4	$ME \rightarrow USER$	Display the COLOUR-ICON	
		Do not locally generate audible	
		DTMF tones and play them to the	
		user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		DTMF 2.1.1A	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

# PROACTIVE COMMAND: SEND DTMF 2.2.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Colour Icon"

DTMF String: "1" pause "2"

Icon identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon identifier:} & \text{record 2 in } EF_{\text{(IMG)}} \\ \end{array}$ 

Coding:

BER-TLV:	D0	1E	81	03	01	14	00	82	02	81	83	85
_	0B	43	6F	6C	6F	75	72	20	49	63	6F	6E
	AC	02	C1	F2	9E	02	00	02				

# Expected Sequence 2.2B (SEND DTMF, COLOUR-ICON self explanatory, requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND DTMF 2.2.1	[COLOUR-ICON]
4	$ME \to USER$	Display "Colour Icon" without the icon	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully, but
		DTMF 2.1.1B	requested icon could not be displayed]
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

# Expected Sequence 2.3A (SEND DTMF, Alpha identifier & BASIC-ICON, not self-explanatory, successful)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
2	$ME \rightarrow SIM$	PENDING: SEND DTMF 2.3.1 FETCH	
3		. = . •	[Alaba identifier 9 DACIC ICON] and colf
3	$SIM \to ME$	PROACTIVE COMMAND: SEND DTMF 2.3.1	[Alpha identifier & BASIC-ICON, not self- explanatory]
4	$ME \rightarrow USER$	Display the BASIC-ICON	
5 6 7 8	$\begin{array}{c} ME \to SS \\ ME \\ ME \to SS \\ ME \to SIM \end{array}$	Do not locally generate audible DTMF tones and play them to the user. Start DTMF 1.1 Start DTMF 1.2 TERMINAL RESPONSE: SEND DTMF 2.1.1A	["1"] No DTMF sending for 3 seconds ±20 % ["2"] [Command performed successfully]
9	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

## PROACTIVE COMMAND: SEND DTMF 2.3.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Send DTMF"

DTMF String: "1" pause "2"

Icon identifier:

Icon qualifier: icon is not self-explanatory

Icon identifier: record 1 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	1C	81	03	01	14	00	82	02	81	83	85
	09	53	65	6E	64	20	44	54	4D	46	AC	02
	C1	F2	9E	02	01	01						

# Expected Sequence 2.3B (SEND DTMF, Alpha identifier & BASIC-ICON, not self-explanatory, requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	[Alpha identifier & BASIC-ICON, not self-
		DTMF 2.3.1	explanatory]
4	$ME \rightarrow USER$	Display "Send DTMF" without the	
		icon	
		Do not locally generate audible	
		Do not locally generate audible DTMF tones and play them to the	
		user.	
5	$ME \rightarrow SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20%
7	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
8	$ME \to SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully, but
		DTMF 2.1.1B	requested icon could not be displayed]
9	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

## 27.22.4.24.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences.

# 27.22.4.24.3 SEND DTMF (UCS2 support)

### 27.22.4.24.3.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.24.3.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in:

• 3GPP TS 11.14 [15] clause 6.1, clause 6.4.24, clause 6.6.24, clause 12.12.2, clause 5.2, clause 12.6, clause 12.7, clause 12.2 and clause 12.44.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646. [17].

## 27.22.4.24.3.3 Test purpose

To verify that the ME displays the UCS2 text contained in the SEND DTMF proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.24.3.4 Method of test

27.22.4.24.3.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.24.3.4.2 Procedure

## Expected Sequence 3.1 (SEND DTMF, successful, UCS2 text)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		DTMF 3.1.1	
4	$ME \rightarrow USER$	Display "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds ±20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		DTMF 3.1.1	
9	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

#### PROACTIVE COMMAND: SEND DTMF 3.1.1

## Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)
Text: "ЗДРАВСТВУЙТЕ"
DTMF String: "1" pause "2"

### Coding:

BER-TLV:	D0	28	81	03	01	14	00	82	02	81	83	8D
	19	80	04	17	04	14	04	20	04	10	04	12
	04	21	04	22	04	12	04	23	04	19	04	22
	04	15	AC	02	C1	F2						

#### TERMINAL RESPONSE: SEND DTMF 3.1.1

## Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successful

Coding:

BER-TLV:	81	03	01	14	00	82	02	82	81	83	01	00

### 27.22.4.12.2.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.

### 27.22.4.25 LANGUAGE NOTIFICATION

## 27.22.4.25.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.25.2 Conformance Requirement

The ME shall conclude the command by sending TERMINAL RESPONSE (OK) to the SIM, as soon as possible after receiving the LANGUAGE NOTIFICATION proactive SIM command.

• 3GPP TS 11.14 clause 6.4.25 and clause 6.6.25.

## 27.22.4.25.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the LANGUAGE NOTIFICATION proactive SIM command.

## 27.22.4.25.4 Method of Test

#### 27.22.4.25.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.25.4.2 Procedure

## **Expected Sequence 1.1 (LANGUAGE NOTIFICATION)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LANGUAGE	
		NOTIFICATION 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$		Language specified in the command is
		LANGUAGE NOTIFICATION 1.1.1	different from the one set on the mobile.
4	$ME \rightarrow SIM$		[Command performed successfully]
		LANGUAGE NOTIFICATION 1.1.1	
5	$SIM \rightarrow ME$		Check that language of ME has been
			replaced by the one specified in LANGUAGE
			NOTIFICATION 1.1.1

### PROACTIVE COMMAND: LANGUAGE NOTIFICATION 1.1.1

### Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION Command qualifier: "01" (specific language notification)

Device identities

Source device: SIM Destination device: ME

Language

Language 'se'(Spanish)  $\rightarrow$  73 65

or 'de' → 64 65 (German) for instance: choose a language different from the one initially set on the ME to check the proper execution

of the command

## Coding:

BER-TLV:	D0	0D	81	03	01	35	01	82	02	81	82	AD
	02	73	65									

### TERMINAL RESPONSE: LANGUAGE NOTIFICATION 1.1.1

# Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "01"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

# Coding:

BER-TLV:	81	03	01	35	01	82	02	82	81	83	01	00
----------	----	----	----	----	----	----	----	----	----	----	----	----

## **Expected Sequence 1.2 (LANGUAGE NOTIFICATION)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LANGUAGE	
		NOTIFICATION 1.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	Language specified in the command is
		LANGUAGE NOTIFICATION 1.1.1	different from the one set on the mobile.
4	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		LANGUAGE NOTIFICATION 1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LANGUAGE	
		NOTIFICATION 1.2.1	
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		LANGUAGE NOTIFICATION 1.2.1	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Command performed successfully]
		LANGUAGE NOTIFICATION 1.2.1	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	Check that initial language is set again.
		ENDED	

PROACTIVE COMMAND: LANGUAGE NOTIFICATION 1.2.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "00" (non specific language notification)

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	35	00	82	02	81	82

#### TERMINAL RESPONSE: LANGUAGE NOTIFICATION 1.2.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	35	00	82	02	82	81	83	01	00

#### 27.22.4.25.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 and 1.2.

## 27.22.4.26 LAUNCH BROWSER

## 27.22.4.26.1 LAUNCH BROWSER (No session already launched)

27.22.4.26.1.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.26.1.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, clause 12.49, clause 12.50, clause 12.15 and clause 12.31.

### 27.22.4.26.1.3 Test purpose

To verify that when the ME is in idle state, it launches properly the Wap session required in LAUNCH BROWSER, and returns a successful result in the TERMINAL RESPONSE command.

27.22.4.26.1.4 Method of test

27.22.4.26.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

• the default Wap parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway")

With that default gateway we shall be able to access to an URL different from the default one.

• another gateway with an IP address different from the one defined in default Wap parameters.

The mobile is in idle mode.

#### 27.22.4.26.1.4.2 Procedure

## Expected Sequence 1.1 (LAUNCH BROWSER, connect to the default URL)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.1.1	if not already launched", no null alpha id.]
4	$ME \to USER$	ME displays the alpha identifier	
5	$USER \to ME$	The user may have to confirm the	[option: user confirmation]
		launch browser.	
6	$ME \to SIM$	TERMINAL RESPONSE: LAUNCH	[Command performed successfully]
		BROWSER 1.1.1	
7	ME→SS	The ME attempts to launch the	
		session with the default Wap	
		parameters and the default URL.	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
9	$USER \to ME$	The user verifies that the default	
		Wap session is properly	
		established.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

### PROACTIVE COMMAND: LAUNCH BROWSER 1.1.1

#### Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
URL empty
Alpha Identifier "Default URL"

BER-TLV:	D0	18	81	03	01	15	00	82	02	81	82	31
	00	05	0B	44	65	66	61	75	6C	74	20	55
	52	4C										

TERMINAL RESPONSE: LAUNCH BROWSER 1.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	15	00	82	02	82	81	83	01	00

# Expected Sequence 1.2 (LAUNCH BROWSER, connect to the specified URL, alpha identifier length=0)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.2.1	
2	/	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[connect to defined URL, "launch browser, if
		LAUNCH BROWSER 1.2.1	not already launched, alpha identifier
			length=0]
4	$ME \rightarrow USER$	No information should be	
_		displayed.	
5	$USER \to ME$	,	[option: user confirmation]
		launch browser.	[O
6	$ME \rightarrow SIM$		[Command performed successfully]
7	ME OO	BROWSER 1.2.1	
/	ME→SS	The ME attempts to connect the	
		URL specified in the LAUNCH BROWSER command.	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
	SIIVI → IVIE	ENDED	
9	USER → ME	The user verifies that the URL is	
	OOLIN IVIL	properly connected.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM Destination device: ME

URL <a href="http://xxx.yyy.zzz">http://xxx.yyy.zzz</a> (note: this URL shall be different from the default URL, but it can

be reached from the gateway defined by default in the Wap parameters of the

mobile)

Alpha Identifier empty

Coding:

BER-TLV:	D0	1F	81	03	01	15	00	82	02	81	82	31
	12	68	74	74	70	3A	2F	2F	78	78	78	2E
	79	79	79	2E	7A	7A	7A	05	00			

# TERMINAL RESPONSE: LAUNCH BROWSER 1.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier:

launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	15	00	82	02	82	81	83	01	00
D = 1 \ 1 = \ 1 .	, o.	00	, o.		00	- C	~ <u> </u>		, o.		<b>.</b>	00

## Expected Sequence 1.3 (LAUNCH BROWSER, Browser identity, no alpha identifier)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.3.1	if not already launched, browser identity]
4	$ME \to USER$	ME may display a default message	
		of its own.	
5	$USER \to ME$	The user may confirm the launch	[option: user confirmation]
		browser.	
6	$ME \to SIM$	TERMINAL RESPONSE: LAUNCH	[Command performed successfully]
		BROWSER 1.3.1	
7	$ME { ightarrow} SS$	The ME attempts to connect the	
		default URL.	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
_		ENDED	
9	$USER \to ME$	The user verifies that the default	
		Wap session is properly	
		established.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
Browser Identity default
URL empty

Coding::

BER-TLV:	D0	0E	81	03	01	15	00	82	02	81	82	30
	01	00	31	00								

## TERMINAL RESPONSE: LAUNCH BROWSER 1.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-T	LV: 8′	1 03	01	15	00	82	02	82	81	83	01	00	
-------	--------	------	----	----	----	----	----	----	----	----	----	----	--

# Expected Sequence 1.4 (LAUNCH BROWSER, one bearer specified and gateway/proxy identity)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.4.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.4.1	if not already launched, 1 bearer specified, gateway/proxy id specified]
4	$ME \to USER$	ME may display a default message	
5	$USER \to ME$	The user may confirm the launch	[option: user confirmation]
		browser.	
6	$ME \to SIM$	TERMINAL RESPONSE: LAUNCH	[Command performed successfully]
		BROWSER 1.4.1 A	
		Or	
			[Launch browser generic error code - bearer
		BROWSER 1.4.1 B	not available]
		Or TERMINAL RESPONSE: LAUNCH	[Command performed with pertial
		BROWSER 1.4.1 C	comprehension
7	ME→SS	The ME attempts to connect the	Comprehension
'	WL→SS	default URL using the requested	
		bearer and proxy identity	
8	$SIM \to ME$	PROACTIVE SIM SESSION	
	O 7	ENDED	
9	$USER \to ME$	If performed successfully:	
		the user verifies that the Wap	
		session is properly established	
		with the required bearer. Then	
		he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.4.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
URL empty
Bearer GPRS

Gateway/Proxy id

DCSunpacked, 8 bits data

Text string abc.def.ghi (different from the default IP address)

Coding::

BER-TLV:	D0	1C	81	03	01	15	00	82	02	81	82	31
	00	32	01	03	0D	0C	04	61	62	63	2E	64
	65	66	2E	67	68	69						

### TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1 A

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Launch browser generic error code

Additional information Bearer not available

BER-TLV:	81	03	01	15	00	82	02	82	81	83	02	26
	01											

TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1 C

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully, with partial comprehension

Coding:

BER-TLV: 81 03 01 15 00 82 02 82	81	81 83	33 01	01	I
----------------------------------	----	-------	-------	----	---

# Expected Sequence 1.5 (LAUNCH BROWSER, several bearers specified, gateway/proxy id specified)

Step	Direction	MESSAGE / Action	Comments
0			[ME is in idle mode]
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.5.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.5.1	if not already launched, several bearers, gateway/proxy id specified]
4	$ME \to USER$	ME may display a default message	
5	$USER \to ME$	The user may confirm the launch browser.	[option: user confirmation]
6	$ME \to SIM$	TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 A	[Command performed successfully]
		Or	
		TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 B	[Launch browser generic error code - bearer not available]
		Or	
		TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 C	[Command performed with partial comprehension]
7	$ME \rightarrow SS$	The ME attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
9	$USER \to ME$	If performed successfully:	
		the user verifies that the Wap	
		session is properly established	
		with one of the required bearers.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.5.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM

Destination device: ME URL empty

Bearer GPRS, USSD, SMS

Gateway/Proxy id

DCS 7 bits default alphabet

Text string abc.def.ghi (different from the default IP address)

Coding::

BER-TLV:	D0	1D	81	03	01	15	00	82	02	81	82	31
	00	32	03	03	02	00	0D	0B	00	61	F1	D8
	45	2E	9B	5D	67	74	1A					

## TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 A

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

## TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Launch browser generic error code

Additional information Bearer not available

Coding:

BER-TLV:	81	03	01	15	00	82	02	82	81	83	02	26
	01											

### TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 C

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully, with partial comprehension

Coding:

BER-TLV:	81	വദ	01	15	00	82	02	82	81	ี่ 83	Λ1	Λ1
DEIX IEV.	01	00	01	10	00	02	02	02	01	03	01	01

#### 27.22.4.26.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.5

## 27.22.4.26.2 LAUNCH BROWSER (Interaction with current session)

27.22.4.26.2.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.26.2.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, optional clause 12.49, optional clause 12.50, clause 12.15 and clause 12.31.

#### 27.22.4.26.2.3 Test purpose

To verify that when the ME is already busy in a Wap session, it launches properly the Wap session required in LAUNCH BROWSER, and returns a successful result in the TERMINAL RESPONSE.

#### 27.22.4.26.2.4 Method of test

### 27.22.4.26.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to a Wap gateway is required. The default Wap parameters (IP address, gateway/proxy identity, called number...) of the tested mobile shall be properly filled to access that gateway.

The mobile is busy in a Wap session, the user navigates in pages different from the URL defined by default in Wap parameters.

## 27.22.4.26.2.4.2 Procedure

## Expected Sequence 2.1 (LAUNCH BROWSER, use the existing browser, connect to the default URL)

Step	Direction	MESSAGE / Action	Comments
0	ME	The user is navigating in a Wap	[Browser is in use, the current session is not
		session (not default URL).	secured]
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		2.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[connect to the default URL, "use the existing
		LAUNCH BROWSER 2.1.1	browser", no null alpha id.]
4	$ME \rightarrow USER$	ME displays the alpha identifier	

5	$USER \to ME$	The user confirms the launch	[user confirmation]
6		browser. TERMINAL RESPONSE: LAUNCH	[Command performed successfully]
U		BROWSER 2.1.1	[Command performed successfully]
7	$ME \rightarrow SS$	The ME does not close the existing	
		session and attempts to connect	
		the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
9	$USER \to ME$	The user verifies that the default	
		URL is connected; and the	
		previous URL can be retrieved.	
		Then he/she ends the navigation	
		with the default URL.	

### PROACTIVE COMMAND: LAUNCH BROWSER 2.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Default URL"

Coding:

BER-TLV:	D0	18	81	03	01	15	02	82	02	81	82	31
	00	05	0B	44	65	66	61	75	6C	74	20	55
	52	4C										

## TERMINAL RESPONSE: LAUNCH BROWSER 2.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	15	02	82	02	82	81	83	01	00
----------	----	----	----	----	----	----	----	----	----	----	----	----

# Expected Sequence 2.2 (LAUNCH BROWSER, close the existing browser session and launch new browser session, connect to the default URL)

	Step	Direction	MESSAGE / Action	Comments
Ī	0	ME	The user is navigating in a Wap	[Browser is in use, the current session is not
			session (not default URL)	secured]

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: LAUNCH BROWSER 2.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: LAUNCH BROWSER 2.2.1	[connect to the default URL, "close the existing browser session and launch new browser session", no null alpha id.]
4	$ME \to USER$	ME displays the alpha identifier	
5	$USER \to ME$	The user confirms the launch browser.	[user confirmation]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: LAUNCH BROWSER 2.2.1	[Command performed successfully]
7	ME→SS	The ME closes the existing session and attempts to launch the session with the default Wap parameters and the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	The user verifies that the default URL is connected; and the previous URL cannot be retrieved (to verify the previous session has been closed).  Then he/she does not end the navigation.	

PROACTIVE COMMAND: LAUNCH BROWSER 2.2.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: close the existing browser session and launch new browser sessionDevice identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Default URL"

Coding:

BER-TLV:	D0	18	81	03	01	15	03	82	02	81	82	31
	00	05	0B	44	65	66	61	75	6C	74	20	55
	52	4C										

TERMINAL RESPONSE: LAUNCH BROWSER 2.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: close the existing browser session and launch new browser session

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BER-TLV:	81	03	01	15	03	82	02	82	81	83	01	00	I
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

## Expected Sequence 2.3 (LAUNCH BROWSER, if not already launched)

Step	Direction	MESSAGE / Action	Comments
0	ME	The user is navigating in a Wap	[Browser is in use, the current session is not
1	SIM  o ME	session (not default URL) PROACTIVE COMMAND PENDING: LAUNCH BROWSER	secured]
2	ME  o SIM	2.3.1  FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: LAUNCH BROWSER 2.3.1	[connect to the default URL, "launch browser, if not already launched]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: LAUNCH BROWSER 2.3.1	[ME unable to process command - browser unavailable]
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
10	USER → ME	The user verifies that the default URL has not been connected. Then he/she ends the navigation. The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 2.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: SIM
Destination device: ME
URL empty

Coding:

BER-TLV:	D0	0B	81	03	01	15	00	82	02	81	82	31
	00											

TERMINAL RESPONSE: LAUNCH BROWSER 2.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already launched

Device identities

Source device: ME Destination device: SIM

Result

General Result: Launch browser generic error code

Additional data Browser unavailable

BER-TLV:	81	03	01	15	00	82	02	82	81	83	02	26
	02											

### 27.22.4.26.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.3.

## 27.22.4.26.3 LAUNCH BROWSER (UCS2 support)

#### 27.22.4.26.3.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.26.3.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, optional clause 12.49, optional clause 12.50, clause 12.15 and clause 12.31.

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in:

• ISO/IEC 10646 [17].

#### 27.22.4.26.2.3 Test purpose

To verify that the ME performs a proper user confirmation with an USC2 alpha identifier, launches the Wap session required in LAUNCH BROWSER and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.26.3.4 Method of test

### 27.22.4.26.3.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

• the default Wap parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway").

With that default gateway we shall be able to access to an URL different from the default one.

• another gateway with an IP address different from the one defined in default Wap parameters.

The mobile is busy in a Wap session, the user navigates in pages different from the URL defined by default in Wap parameters.

#### 27.22.4.26.3.4.2 Procedure

### Expected Sequence 3.1 (LAUNCH BROWSER, use the existing browser, connect to the default URL)

Step	Direction	MESSAGE / Action	Comments
0	ME	The user is navigating in a Wap	[Browser is in use, the current session is not
		session (not default URL)	secured]]
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[connect to the default URL, "use the existing
		LAUNCH BROWSER 3.1.1	browser", alpha id. In UCS2]

4	$ME \to USER$	ME displays the alpha identifier "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
5		The user confirms the launch browser.	[user confirmation]
6		TERMINAL RESPONSE: LAUNCH BROWSER 3.1.1	[Command performed successfully]
7		The ME does not close the existing session and attempts to connect the default URL.	
8	• · · · · · · · · · · · · · · · · · · ·	PROACTIVE SIM SESSION ENDED	
9		The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL.	

### PROACTIVE COMMAND: LAUNCH BROWSER 3.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier

Data coding scheme: UCS2 (16 bits)
Text: "ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV:	D0	26	81	03	01	15	02	82	02	81	82	31
	00	05	19	80	04	17	04	14	04	20	04	10
	04	12	04	21	04	22	04	12	04	23	04	19
	04	22	04	15								

### TERMINAL RESPONSE: LAUNCH BROWSER 3.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

	82 81 83 01 00
--	----------------

# 27.22.4.26.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 3.1.

## 27.22.4.26.4 LAUNCH BROWSER (icons support)

### 27.22.4.26.4.1 Definition and applicability

See clause 3.2.2.

### 27.22.4.26.4.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clauses 6.4.26 and 6.6.26, clause 12.6, clause 12.7, clause 12.48, clause 13.2, clause 12.2, clause 12.47, optional clause 12.49, optional clause 12.50, clause 12.15 and clause 12.31.

### 27.22.4.26.4.3 Test purpose

To verify that the ME performs a proper user confirmation with an icon identifier, launches the Wap session required in LAUNCH BROWSER and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

#### 27.22.4.26.4.4 Method of test

#### 27.22.4.26.4.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

• the default Wap parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway").

With that default gateway we shall be able to access to an URL different from the default one.

• another gateway with an IP address different from the one defined in default Wap parameters.

The mobile is busy in a Wap session, the user navigates in pages different from the URL defined by default in Wap parameters.

#### 27.22.4.26.4.4.2 Procedure

# Expected Sequence 4.1A (LAUNCH BROWSER, use the existing browser, icon not self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not
		PENDING: LAUNCH BROWSER	secured]]
		4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "use the existing
			browser", no null alpha id.]
4	$ME \to USER$	ME displays the alpha identifier	["Not self explan."]
		and the icon	
5	$USER \to ME$	The user confirms the launch	[user confirmation]
		browser.	

6	$ME \rightarrow SIM$	TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 A	[Command performed successfully]
7	ME→SS	The ME does not close the existing session and attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL.	

#### PROACTIVE COMMAND: LAUNCH BROWSER 4.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Not self explan."

Icon identifier:

Icon qualifier: not self-explanatory Icon identifier: record 1 in  $EF_{(IMG)}$ 

Coding:

BER-TLV:	D0	21	81	03	01	15	02	82	02	81	82	31
	00	05	10	4E	6F	74	20	73	65	6C	66	20
	65	78	70	6C	61	6E	2E	1E	02	01	01	

## TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 A

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

	- 4	9	•	1	02	S	0	S	•	0	•	
BER-TLV:	I 81	I กว	I ()1	15	(1)2				I 81	83	I ()1	00
		1 03			02	02	1 02	1 02				

Expected Sequence 4.1B (LAUNCH BROWSER, use the existing browser, icon not self explanatory, requested icon could not be displayed)

	Step	Direction	MESSAGE / Action	Comments	İ
--	------	-----------	------------------	----------	---

1	$SIM \to ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not
		PENDING: LAUNCH BROWSER	secured]]
		4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "use the existing
		LAUNCH BROWSER 4.1.1	browser", no null alpha id.]
4	$ME \rightarrow USER$	ME displays the alpha identifier	["Not self explan."]
		Without the icon	
5	$USER \to ME$	The user confirms the launch	[user confirmation]
		browser.	
6	$ME \rightarrow SIM$		[Command performed successfully but
		BROWSER 4.1.1 B	requested icon could not be displayed]
7	ME→SS	The ME does not close the existing	
		session and attempts to connect	
		the default URL.	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
9	$USER \to ME$	The user verifies that the default	
		URL is connected; and the	
		previous URL can be retrieved.	
		Then he/she ends the navigation	
		with the default URL.	

TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

	BER-TLV:	81	03	01	15	02	82	02	82	81	83	01	04
--	----------	----	----	----	----	----	----	----	----	----	----	----	----

# Expected Sequence 4.2A (LAUNCH BROWSER, use the existing browser, icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not
		PENDING: LAUNCH BROWSER	secured]]
		4.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "use the existing
		LAUNCH BROWSER 4.2.1	browser", alpha id. In UCS2]
4	$ME \to USER$	ME displays only the icon	["Self explan."]
5	$USER \to ME$	The user confirms the launch	[user confirmation]
		browser.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: LAUNCH	[Command performed successfully]
		BROWSER 4.2.1 A	
7	$ME { ightarrow} SS$	The ME does not close the existing	
		session and attempts to connect	
_		the default URL.	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

9	$USER \to ME$	The user verifies that the default	
		URL is connected; and the	
		previous URL can be retrieved.	
		Then he/she ends the navigation	
		with the default URL.	

# PROACTIVE COMMAND: LAUNCH BROWSER 4.2.1

#### Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Self explan."

Icon identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{self-explanatory} \\ \text{Icon identifier:} & \text{record 1 in EF}_{\text{(IMG)}} \\ \end{array}$ 

#### Coding:

BER-TLV:	D0	1D	81	03	01	15	02	82	02	81	82	31
	00	05	0C	73	65	6C	66	20	65	78	70	6C
	61	6F	2F	1F	02	00	01					

## TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 A

## Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	15	02	82	02	82	81	83	01	00
----------	----	----	----	----	----	----	----	----	----	----	----	----

# Expected Sequence 4.2B (LAUNCH BROWSER, use the existing browser, icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments	
1	$SIM \to ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not	
		PENDING: LAUNCH BROWSER	secured]]	
		4.2.1		
2	$ME \to SIM$	FETCH		
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "use the existing	
		LAUNCH BROWSER 4.2.1	browser", alpha id. In UCS2]	
4	$ME \to USER$	ME displays only the alpha	["Self explan."]	
		identifier		
5	$USER \to ME$	The user confirms the launch	[user confirmation]	
		browser.		

(	ô	$ME \to SIM$	TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 B	[Command performed successfully]
				[Command performed successfully but requested icon could not be displayed]
7	7	$ME { ightarrow} SS$	The ME does not close the existing	
			session and attempts to connect	
			the default URL.	
8	3	$SIM \to ME$	PROACTIVE SIM SESSION	
			ENDED	
Ç	9	$USER \to ME$	The user verifies that the default	
			URL is connected; and the	
			previous URL can be retrieved.	
			Then he/she ends the navigation	
			with the default URL.	

### TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV:	81	03	01	15	02	82	02	82	81	83	01	04

#### 27.22.4.26.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 4.1A to 4.2B.

### 27.22.4.27 OPEN CHANNEL

# 27.22.4.27.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.27.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

## 27.22.4.27.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (OK); or
- $\bullet \quad TERMINAL\ RESPONSE\ (Command\ performed\ with\ modification);\ or$
- TERMINAL RESPONSE (Network currently unable to process command);

to the SIM after the ME receives the OPEN CHANNEL proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

#### 27.22.4.27.4 Method of test

#### 27.22.4.27.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.27.4.2 Procedure

## Expected Sequence 1.1 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.32)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.1.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	. ,

#### PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

#### Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	01	B9	02	00	2A				

#### TERMINAL RESPONSE: OPEN CHANNEL 1.1.1

## Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	00	01	B9	02
	00	2A										

## Expected Sequence 1.2 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.34)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.2.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.2.1	

#### PROACTIVE COMMAND: OPEN CHANNEL 1.2.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.34

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	0C	00	01	B9	02	00	2A				

TERMINAL RESPONSE: OPEN CHANNEL 1.2.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.34

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV:

81	03	01	40	01	82	02	82	81	83	01	00
B8	02	81	01	B5	04	01	0C	00	01	B9	02
00	2A										

## Expected Sequence 1.3 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.120)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.3.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.3.1	

#### PROACTIVE COMMAND: OPEN CHANNEL 1.3.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.120

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	27	00	01	B9	02	00	2A				

TERMINAL RESPONSE: OPEN CHANNEL 1.3.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.120

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	27	00	01	B9	02
	00	2A										

# Expected Sequence 1.4 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.110 or X.31 flag stuffing, bearer asynchronous UDI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.4.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.4.1	

PROACTIVE COMMAND: OPEN CHANNEL 1.4.1

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.110 or X.31 flag stuffing Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
_	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	47	00	01	В9	02	00	2A				

#### TERMINAL RESPONSE: OPEN CHANNEL 1.4.1

#### Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Bearer Description

Bearer Parameter

Data rate: 9600bps V.110 or X.31 flag stuffing Bearer Service: data circuit asynchronous UDI

Connection Element: non-transparent

## Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	47	00	01	B9	02
	00	2Α										

# Expected Sequence 1.5 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.32, bearer asynchronous RDI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.5.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.5.1	

#### PROACTIVE COMMAND: OPEN CHANNEL 1.5.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous RDI

Connection element: non-transparent

Buffer size 42

## Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
_	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	04	01	B9	02	00	2A				

#### TERMINAL RESPONSE: OPEN CHANNEL 1.5.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Bearer Description

Bearer Parameter

Data rate: 9600bps V.32

Bearer Service: data circuit asynchronous RDI

Connection Element: non-transparent

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	04	01	B9	02
	00	2A										

# Expected Sequence 1.6 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.32, bearer asynchronous)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.6.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.6.1	, , , , , , , , , , , , , , , , , , , ,

PROACTIVE COMMAND: OPEN CHANNEL 1.6.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous Connection element: both, transparent preferred

Buffer size 42

Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
-	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	02	B9	02	00	2A				

TERMINAL RESPONSE: OPEN CHANNEL 1.6.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Bearer Description Bearer Parameter

Data rate: 9600bps V.32

Bearer Service: data circuit asynchronous Connection Element: both, transparent preferred

## Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	00	02	B9	02
	00	2A										

# Expected Sequence 1.7(OPEN CHANNEL, immediate link establishment, CSD, 9600 bps, performed with modification)

The system simulator shall be configured such that open channel requests will be accepted with modification

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.7.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed with modification]
		CHANNEL (immediate) 1.7.1	

#### PROACTIVE COMMAND: OPEN CHANNEL 1.7.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 64000bps X.31

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

## Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	54	00	01	B9	02	00	2A				

## TERMINAL RESPONSE: OPEN CHANNEL 1.7.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed with modification
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	07
	B8	02	81	01	B5	04	01	07	00	01	B9	02
	00	2A										

# Expected Sequence 1.8 (OPEN CHANNEL, immediate link establishment, CSD, Network currently unable to process command)

The system simulator shall be configured such that open channel requests will be rejected with "No specific cause can be given".

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.8.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Network currently unable to process
		CHANNEL (immediate) 1.8.1	command]

#### PROACTIVE COMMAND: OPEN CHANNEL 1.8.1

## Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 64000bps X.31

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
•	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	54	00	01	B9	02	00	2A				

TERMINAL RESPONSE: OPEN CHANNEL 1.8.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Network currently unable to process command

Additional info: No

Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	02	21
	00											

#### Expected Sequence 1.9 (OPEN CHANNEL, immediate link establishment, CSD, No channel available)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.9.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully ]
		CHANNEL (immediate) 1.9.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.9.2	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Bearer independent protocol error]
		CHANNEL (immediate) 1.9.2	

PROACTIVE COMMAND: OPEN CHANNEL 1.9.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 56000bps V.120

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	33	00	01	B9	02	00	2A				

TERMINAL RESPONSE: OPEN CHANNEL 1.9.1

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 56000bps V.120

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	33	00	01	B9	02
	00	2A										

### PROACTIVE COMMAND: OPEN CHANNEL 1.9.2

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 56000bps V.120

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

# Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	33	00	01	B9	02	00	2A				

TERMINAL RESPONSE: OPEN CHANNEL 1.9.2

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Bearer Independent Protocol error

Additional info: No channel available

Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	02	3A
	01											

# Expected Sequence 1.10 (OPEN CHANNEL, ME is busy on another call related to CSD)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.10.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		CALL 1.10.1	
4	$ME \rightarrow USER$	ME displays "Not busy" and	
		prompts the user to set up a call to "+012340123456p1p2"	
5	$USER \to ME$	The user confirms the call set up	[user confirmation]
6	$ME { ightarrow} SS$	The ME attempts to set up a call to	
		"+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \to SIM$	TERMINAL RESPONSE: SET UP	[Command performed successfully]
		CALL 1.10.1	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	
10	ME OIM	PENDING: OPEN CHANNEL 1.1.1	
10	L / O	FETCH	
11	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	
40		CHANNEL (immediate) 1.1.1	IN ACT and a second sec
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[ME currently unable to process command]
		CHANNEL (immediate) 1.10.1	

PROACTIVE COMMAND: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Not busy"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV:	D0	1E	81	03	01	10	00	82	02	81	83	85
	08	4E	6F	74	20	62	75	73	79	86	09	91
	10	32	04	21	43	65	1C	2C				

#### TERMINAL RESPONSE: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00
DLIX-ILV.	01	03	01	10	00	02	02	02	01	00	O I	00

## TERMINAL RESPONSE: OPEN CHANNEL 1.10.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional info: ME currently busy on call

Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	02	20
	02											

### 27.22.4.27.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.10.

## 27.22.4.28 CLOSE CHANNEL

## 27.22.4.28.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.28.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

## 27.22.4.28.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (Command Performed Successfully); or
- TERMINAL RESPONSE (Bearer Independent Protocol Error);

to the SIM after the ME receives the CLOSE CHANNEL proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

#### 27.22.4.28.4 Method of Test

#### 27.22.4.28.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.28.4.2 Procedure

#### **Expected sequence 1.1 (CLOSE CHANNEL, successful)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD, 9600bps
		CHANNEL (immediate) 1.1.1	V.32]
4	/ 00	SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: CLOSE CHANNEL	
		1.1.1	
8	$ME \rightarrow SIM$	_	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: CLOSE	
		CHANNEL 1.1.1	
10	$ME \to SS$	DISCONNECT	[MO DISCONNECT]
11	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE	[Command performed successfully]
		CHANNEL 1.1.1	

### PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM Destination device: ME

Address

TON: International number

NIPNPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	01	B9	02	00	2A				

#### TERMINAL RESPONSE: OPEN CHANNEL 1.1.1

#### Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	00	01	B9	02
	00	2A										

#### PROACTIVE COMMAND: CLOSE CHANNEL 1.1.1

## Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Coding:

BER-TLV: D0 09 81 03 01 41 00 82 02 81 21

TERMINAL RESPONSE: CLOSE CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 41 00 82 02 82 81 83 01 00

## Expected sequence 1.2 (CLOSE CHANNEL, with an invalid channel identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD, 9600bps
		CHANNEL (immediate) 1.1.1	V.32]
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: CLOSE CHANNEL	
		1.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: CLOSE	
		CHANNEL 1.2.1	
10	$ME \rightarrow SIM$		[Invalid channel number]
		CHANNEL 1.2.1	

PROACTIVE COMMAND: CLOSE CHANNEL 1.2.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 2

BER-TLV:	D0	09	81	03	01	41	00	82	02	81	22

TERMINAL RESPONSE: CLOSE CHANNEL 1.2.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Bearer Independent Protocol error Additional Result: Channel identifier not valid

Coding:

BER-TLV:	81	03	01	41	00	82	02	82	81	83	02	3A
	03											

## Expected sequence 1.3 (CLOSE CHANNEL, on an already closed channel)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
		OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD,
		CHANNEL (immediate) 1.1.1	9600bps V.32]
4		SETUP CALL	
5		CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
ļ	i	CHANNEL (immediate) 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
		CLOSE CHANNEL 1.1.1	
8	$ME \rightarrow SIM$		
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: CLOSE	
ļ		CHANNEL 1.1.1	
10	l .	DISCONNECT	[MO DISCONNECT]
11	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE	[Command performed successfully]
		CHANNEL 1.1.1	
12	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
4.0		CLOSE CHANNEL 1.3.1	
13	$ME \rightarrow SIM$	I -	
14	$SIM \rightarrow ME$	PROACTIVE COMMAND: CLOSE	
4.5		CHANNEL 1.3.1	[Ob a mark along all]
15	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE	[Channel closed]
		CHANNEL 1.3.1	

PROACTIVE COMMAND: CLOSE CHANNEL 1.3.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM

Destination device: Channel 1

Coding:

DED TIVE	DΛ	00	0.4	00	04	11	00	0.2	00	0.4	24
BER-TLV:	D0	09	81	03	01	41	00	82	02	81	Z1

#### TERMINAL RESPONSE: CLOSE CHANNEL 1.3.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Bearer Independent Protocol error

Additional Result: Channel closed

Coding:

BER-TLV:	81	03	01	41	00	82	02	82	81	83	02	3A
_	02											

#### 27.22.4.28.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

#### 27.22.4.29 RECEIVE DATA

## 27.22.4.29.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.29.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

## 27.22.4.29.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (Command Performed Successfully); or
- TERMINAL RESPONSE (ME currently unable to process command); or
- TERMINAL RESPONSE (Bearer Independent Protocol Error);

to the SIM after the ME receives the RECEIVE DATA proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

#### 27.22.4.29.4 Method of test

#### 27.22.4.29.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

## 27.22.4.29.4.2 Procedure

# Expected sequence 1.1 (RECEIVE DATA, already opened channel)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP EVENT LIST	
		1.1.1 PENDING	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP EVENT LIST	
		1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP EVENT LIST	
_		1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.1.1	
6	$ME \rightarrow SIM$		
7	INIE -> SIINI	PROACTIVE COMMAND: OPEN CHANNEL	[Immediate link establishment, CSD,
,	SIIVI → IVIE	(immediate) 1.1.1	9600bps V.32]
8	$ME \rightarrow SS$	SETUP CALL	00000p3 v.02j
9		CONNECTED	
10		TERMINAL RESPONSE: OPEN CHANNEL	[Command performed successfully]
	"""	(immediate) 1.1.1	[
11	$SS \rightarrow ME$	Transfer of 1kB data to the ME through channel 1	
12	$ME \rightarrow SIM$	ENVELOPE (Data Available)	(1 kB of data in the ME buffer)
13	$SIM \to ME$	PROACTIVE COMMAND PENDING: RECEIVE	
		DATA 1.1.1	
14	$ME \rightarrow SIM$		
15			200 Bytes
16		TERMINAL RESPONSE: RECEIVE DATA 1.1.1	
17	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: RECEIVE	
4.0		DATA 1.1.2	
18	$ME \rightarrow SIM$		
19			200 Bytes
20		TERMINAL RESPONSE: RECEIVE DATA 1.1.2	
21	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: RECEIVE	
22	$ME \rightarrow SIM$	DATA 1.1.3	
23			200 Bytes
24		TERMINAL RESPONSE: RECEIVE DATA 1.1.3	200 Bytes
25		PROACTIVE COMMAND PENDING: RECEIVE	
20	OIIVI -> IVIL	DATA 1.1.4	
26	$ME \rightarrow SIM$		
27			200 Bytes
28		TERMINAL RESPONSE: RECEIVE DATA 1.1.4	_
29		PROACTIVE COMMAND PENDING: RECEIVE	
		DATA 1.1.5	
30	$ME \rightarrow SIM$		
31		PROACTIVE COMMAND: RECEIVE DATA 1.1.5	200 Bytes
32	$ME \rightarrow SIM$	TERMINAL RESPONSE: RECEIVE DATA 1.1.5	

## PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

# Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: SIM Destination device: ME

Event list Data available

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	09										

#### TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-T	_V: 81		01	05	00	82	02	82	81	83	01	00	1
-------	--------	--	----	----	----	----	----	----	----	----	----	----	---

#### PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 1000

Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	01	B9	02	0.3	F8				

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 1000

#### Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
-	B8	02	81	01	B5	04	01	07	00	01	B9	02
	03	E8										

#### PROACTIVE COMMAND: RECEIVE DATA 1.1.1

#### Logically:

Command details

Command number:

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

# Coding:

BER-TLV:	D0	0C	81	03	01	42	00	82	02	81	21	B7
·	01	C8										

#### PROACTIVE COMMAND: RECEIVE DATA 1.1.2

# Logically:

Command details

Command number: 2

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

BER-TLV:	D0	0C	81	03	02	42	00	82	02	81	21	B7
	01	C8										

PROACTIVE COMMAND: RECEIVE DATA 1.1.3

Logically:

Command details

Command number: 3

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV:	D0	0C	81	03	03	42	00	82	02	81	21	В7
	01	C8										

## PROACTIVE COMMAND: RECEIVE DATA 1.1.4

Logically:

Command details

Command number: 4

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV:	D0	0C	81	03	04	42	00	82	02	81	21	B7
	01	C8										

# PROACTIVE COMMAND: RECEIVE DATA 1.1.5

Logically:

Command details

Command number: 5

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV:	D0	0C	81	03	05	42	00	82	02	81	21	B7
	01	C8										

TERMINAL RESPONSE: RECEIVE DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: FF

#### Coding:

BER-TLV:	81	03	01	42	00	82	02	82	81	83	01	00
-	B6	C8	XX	XX	XX							
	B7	01	FF									

#### TERMINAL RESPONSE: RECEIVE DATA 1.1.2

#### Logically:

Command details

Command number: 2

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: FF

## Coding:

BER-TLV:	81	03	02	42	00	82	02	82	81	83	01	00
	B6	C8	XX	XX	XX							
	B7	01	FF									

## TERMINAL RESPONSE: RECEIVE DATA 1.1.3

## Logically:

Command details

Command number: 3

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: FF

BER-TLV:	81	03	03	42	00	82	02	82	81	83	01	00
	B6	C8	XX	XX	XX							
	B7	01	FF									

TERMINAL RESPONSE: RECEIVE DATA 1.1.4

Logically:

Command details

Command number: 4

Command type: RECEIVE DATA
Command qualifier: RFUDevice identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: C8

Coding:

BER-TLV:	81	03	04	42	00	82	02	82	81	83	01	00
	B6	C8	XX	XX	XX							
	B7	01	C8									

TERMINAL RESPONSE: RECEIVE DATA 1.1.5

Logically:

Command details

Command number: 5

Command type: RECEIVE DATA
Command qualifier: RFUDevice identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: 00

Coding:

BER-TLV:	81	03	01	42	00	82	02	82	81	83	01	00
-	B6	C8	XX	XX	XX							
	B7	01	00									

27.22.4.29.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.4.30 SEND DATA

27.22.4.30.1 Definition and applicability

See clause 3.2.2.

27.22.4.30.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

27.22.4.30.3 Test purpose

To verify that the ME shall send a:

- TERMINAL RESPONSE (Command Performed Successfully); or
- TERMINAL RESPONSE (ME currently unable to process command); or
- TERMINAL RESPONSE (Bearer Independent Protocol Error);

to the SIM after the ME receives the SEND DATA proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

#### 27.22.4.30.4 Method of test

#### 27.22.4.30.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.4.30.4.2 Procedure

# Expected sequence 1.1 (SEND DATA, immediate mode)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD, 9600bps
		CHANNEL (immediate) 1.1.1	V.32, 1KB buffer]
4		SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DATA 1.1.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		DATA (immediate) 1.1.1	
10	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		DATA (immediate) 1.1.1	

# PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

#### Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 1000

Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	01	B9	02	03	E8				

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 1000

Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	00	01	B9	02
	03	F8										

PROACTIVE COMMAND: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 8 Bytes of data

Coding:

BER-TLV:	D0	13	81	03	01	43	01	82	02	81	21	B6
·	80	XX										

TERMINAL RESPONSE: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: 8 Bytes

Coding:

BER-TLV:	81	03	01	43	01	82	02	82	81	83	01	00
	B7	01	80									

# **Expected sequence 1.2 (SEND DATA, Store mode)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING:	
		OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD,
		CHANNEL (immediate) 1.1.1	9600bps V.32, 1KB buffer]
4		SETUP CALL	
5		CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
		SEND DATA 1.2.1	
8	$ME \to SIM$		
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	Send 500 Bytes of data (200 + 200 + 100)
40		DATA (store mode) 1.2.1	
10	ME → SIM	TERMINAL RESPONSE: SEND	[Command performed successfully]
11	$SIM \rightarrow ME$	DATA (store mode) 1.2.1 PROACTIVE COMMAND PENDING:	
11	SIIVI → IVIE	ISEND DATA 1.2.2	
12	$ME \rightarrow SIM$		
13		PROACTIVE COMMAND: SEND	
13	SIIVI -> IVIE	DATA (store mode) 1.2.2	
14	ME → SIM	TERMINAL RESPONSE: SEND	[Command performed successfully]
'-	IVIL -> OIIVI	DATA (store mode) 1.2.2	[command performed successiony]
15	$SIM \rightarrow MF$	PROACTIVE COMMAND PENDING:	
	Olivi 7 IVIL	SEND DATA 1.2.3	
16	$ME \rightarrow SIM$		
17		PROACTIVE COMMAND: SEND	
	· ··· <del>-</del>	DATA (Immediate mode) 1.2.3	
18	$ME \rightarrow SIM$	TERMINAL RESPONSÉ: SEND	[Command performed successfully]
		DATA (Immediate mode) 1.2.3	

## PROACTIVE COMMAND: SEND DATA 1.2.1

# Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV:	D0	81	D4	81	03	01	43	00	82	02	81	21
	B6	81	C8	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV:	81	03	01	43	00	82	02	82	81	83	01	00
	B7	01	FF									

PROACTIVE COMMAND: SEND DATA 1.2.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV:	D0	81	D4	81	03	01	43	00	82	02	81	21
	B6	81	C8	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.2.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

## Coding:

BER-TLV:	81	03	01	43	00	82	02	82	81	83	01	00
	B7	01	FF									

PROACTIVE COMMAND: SEND DATA 1.2.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Immediate mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 100 Bytes of data

Coding:

BER-TLV:	D0	6F	81	03	01	43	01	82	02	81	21	B6
_	64	XX	XX	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.2.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Immediate mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

				,					,		,	
BER-TLV:	81	03	01	43	01	82	02	82	81	83	01	00
	R7	01	FF									

Expected sequence 1.3 (SEND DATA, Store mode, Tx buffer fully used)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: OPEN	
		CHANNEL 1.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN CHANNEL	[Immediate link establishment, CSD, 9600bps
		(immediate) 1.1.1	V.32, 1KB buffer]
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN CHANNEL	[Command performed successfully]
7	CINA NAT	(immediate) 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND DATA 1.3.1	
8	$ME \rightarrow SIM$		
9		PROACTIVE COMMAND: SEND DATA (store	Send 1kByte of data by packet of 200 Bytes
9	SIIVI → IVIE	mode) 1.3.1	Send Tribyte of data by packet of 200 bytes
10	$ME \rightarrow SIM$	,	[Command performed successfully]
	WIE / OIIW	mode) 1.3.1	[command performed edeedeerdmy]
11	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
		DATA 1.3.2	
12	$ME \rightarrow SIM$	FETCH	
13	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DATA (store	[200 Bytes]
		mode) 1.3.2	
14	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (store	[Command performed successfully]
		mode) 1.3.2	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
16	NAT OIM	DATA 1.3.3	
16 17	$ME \rightarrow SIM$		[200 Duton]
17	SIIVI → IVIE	PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3	[200 Bytes]
18	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (store	[Command performed successfully]
10	IVIL -> SIIVI	mode) 1.3.3	[Command performed successfully]
19	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
		DATA 1.3.4	
20	$ME \rightarrow SIM$	FETCH	
21	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DATA (store	[200 Bytes]
		mode) 1.3.4	
22	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (store	[Command performed successfully]
		mode) 1.3.4	
23	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
24	NAT OLNA	DATA 1.3.5	
24	$ME \rightarrow SIM$	PROACTIVE COMMAND: SEND DATA	[200 Pytoo]
25	$SIM \rightarrow ME$	(immediate) 1.3.5	[200 Bytes]
26	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA	[Command performed successfully]
20	IVIL -7 SIIVI	(immediate) 1.3.5	[Command performed Successfully]
	1	Millinediate) 1.0.0	

# PROACTIVE COMMAND: SEND DATA 1.3.1

# Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data : 200 Bytes of data

BER-TLV:	D0	81	D4	81	03	01	43	00	82	02	81	21
	B6	81	C8	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV:	81	03	01	43	00	82	02	82	81	83	01	00
	B7	01	FF									

PROACTIVE COMMAND: SEND DATA 1.3.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV:	D0	81	D4	81	03	01	43	00	82	02	81	21
	B6	81	C8	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.3.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

BER-TLV:	81	03	01	43	00	82	02	21	82	83	01	00
	B7	01	FF									

PROACTIVE COMMAND: SEND DATA 1.3.3

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV:	D0	81	D4	81	03	01	43	00	82	02	81	21
	B6	81	C8	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.3.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV:	81	03	01	43	00	82	02	82	81	83	01	00
	B7	01	FF									

PROACTIVE COMMAND: SEND DATA 1.3.4

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV:	D0	81	D4	81	03	01	43	00	82	02	81	21
	B6	81	C8	XX	XX							

TERMINAL RESPONSE: SEND DATA 1.3.4

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: 200 bytes of space available in the Tx buffer

#### Coding:

BER-TLV:	81	03	01	43	00	82	02	82	81	83	01	00
	B7	01	C8									

#### PROACTIVE COMMAND: SEND DATA 1.3.5

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

## Coding:

BER-TLV:	D0	81	D4	81	03	01	43	01	82	02	81	21
	B6	81	C8	XX	XX							

## TERMINAL RESPONSE: SEND DATA 1.3.5

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Channel data length: No space available in the Tx buffer

Coding:

BER-TLV:	81	03	01	43	01	82	02	82	81	83	01	00
	B7	01	00									

# Expected sequence 1.4 (SEND DATA, 2 consecutive SEND DATA Store mode)

SIM → ME   PROACTIVE COMMAND PENDING: OPEN CHANNEL   Commendiate   1.1.1	Step	Direction	MESSAGE / Action	Comments
SIM → ME			CHANNEL 1.1.1	
4				
4 ME → SS SETUP CALL 5 SS ME CONNECTED 6 ME → SIM TERMINAL RESPONSE: OPEN CHANNEL (immediate) 1.1.1 7 SIM → ME DATA 1.3.1 8 ME → SIM FETCH 9 SIM → ME PROACTIVE COMMAND SEND DATA (store mode) 1.3.1 10 ME → SIM TERMINAL RESPONSE: SEND DATA (store mode) 1.3.1 11 SIM → PROACTIVE COMMAND SEND DATA (store mode) 1.3.2 12 ME → SIM TERMINAL RESPONSE: SEND DATA (store mode) 1.3.2 13 SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.2 14 ME → SIM TERMINAL RESPONSE: SEND DATA (store mode) 1.3.2 15 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.3 16 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.3 17 SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3 18 ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3 19 SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3 19 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 19 ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4 19 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 19 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 19 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 19 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 10 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 11 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 12 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 12 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 12 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.5 13 ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 14 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.5 15 ME → SIM → SIM → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 16 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4 17 ME → SIM	3	$SIM \rightarrow ME$		
SS → ME   CONNECTED	4	ME		V.32, 1KB buffer]
FEMINAL RESPONSE: OPEN CHANNEL				
7				[Command performed successfully]
7		IVIL -> OIIVI		[Command performed successfully]
9	7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
9	8	$ME \rightarrow SIM$	FETCH	
10 ME → SIM (store mode) 1.3.1  11 SIM → ME  ME → SIM → FETCH  13 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.2  14 ME → SIM → FETCH  15 SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.2  16 ME → SIM → RETCH  17 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.3  18 ME → SIM → RETCH  17 SIM → RETCH  18 ME → SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.3  18 ME → SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.3  19 SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.4  19 SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.4  FETCH  20 ME → SIM → FETCH  21 SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.4  FETCH  22 ME → SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.4  FETCH  23 SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.4  FETCH  24 SIM → REMINAL RESPONSE: SEND DATA (store mode) 1.3.5  25 ME → SIM → REMINAL RESPONSE: SEND DATA (mimediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  27 ME → SIM → REMINAL RESPONSE: SEND DATA (mimediate) 1.3.5  28 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  28 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  29 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  20 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  21 ME → SIM → SIM FETCH  22 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  28 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  29 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  20 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  21 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  21 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  22 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  23 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  24 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  25 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (mimediate) 1.3.5  26 SIM → ME PROACTIVE COMM	9	$SIM \to ME$		Send 1kByte of data by packet of 200 Bytes
11	10	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA	[Command performed successfully]
SEND DATA 1.3.2    12	11		1,	
SIM →   PROACTIVE COMMAND: SEND DATA (store mode) 1.3.2   [Command performed successfully]		ME	SEND DATA 1.3.2	
ME	12		FETCH	
ME	13	$ exttt{SIM}  ightarrow$	PROACTIVE COMMAND: SEND DATA	[200 Rutos]
SIM (store mode) 1.3.2  15 SIM → ME → SIM → FETCH  17 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.3  18 ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3  19 SIM → ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4  20 ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4  21 SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4  22 ME → SIM → RESPONSE: SEND DATA (store mode) 1.3.4  23 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4  24 SIM → ME → SIM → PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  25 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  27 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  28 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  29 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  21 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  22 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  23 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  24 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  25 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  27 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5		ME		[200 Dytes]
SIM → (store mode) 1.3.2  15 SIM → ME → SIM → FETCH  17 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.3  18 ME → SIM → ROACTIVE COMMAND: SEND DATA (store mode) 1.3.3  19 SIM → ME → SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4  20 ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4  21 SIM → ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4  22 ME → SIM → RESPONSE: SEND DATA (store mode) 1.3.4  23 SIM → PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4  24 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  25 ME → SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  27 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  28 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  29 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  29 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  20 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  29 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  20 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  20 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  21 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  22 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  23 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  24 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  25 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  27 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5	14	ME $\rightarrow$	TEDMINAL DESDONSE: SEND DATA	[Command parformed successfully]
ME		SIM		[Command performed successfully]
ME	15	$SIM \rightarrow$	DDG AGTIVE GOMMAND DENDING	
16				
SIM			SEND DATA 1.3.3	
ME	16		FETCH	
ME	17	$SIM \rightarrow$	DDG ACTIVE COMMAND OFNE DATA	[000 Bata al
18       ME → SIM       TERMINAL RESPONSE: SEND DATA (store mode) 1.3.3       [Command performed successfully]         19       SIM → ME       PROACTIVE COMMAND PENDING: SEND DATA (store mode) 1.3.4       [200 Bytes]         21       SIM → ME       PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4       [200 Bytes]         22       ME → SIM       TERMINAL RESPONSE: SEND DATA (store mode) 1.3.4       [Command performed successfully]         23       SIM → ME       PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5          24       SIM → ME       PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5       [Command performed successfully]         25       ME → SIM       PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5       [Command performed successfully]         26       SIM → ME       PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5       [Command performed successfully]         26       SIM → ME       PROACTIVE COMMAND PENDING: SEND DATA       [Command performed successfully]         27       ME → SIM       FETCH       Send 1kByte of data by packet of 200 Bytes				[200 Bytes]
SIM			(store mode) 1.3.3	
SIM → ME   SIM → PROACTIVE COMMAND PENDING: SEND DATA	18	ME $\rightarrow$	TEDMINAL DESDONSE: SEND DATA	[Command parformed successfully]
SIM →   PROACTIVE COMMAND PENDING:   SEND DATA 1.3.4		SIM		[Command performed successiony]
ME			(Store mode) 1.3.3	
SEND DATA 1.3.4  20 ME → SIM → FETCH  21 SIM → ME → CACTIVE COMMAND: SEND DATA (Store mode) 1.3.4  22 ME → SIM → TERMINAL RESPONSE: SEND DATA (Store mode) 1.3.4  23 SIM → PROACTIVE COMMAND PENDING: SEND DATA 1.3.5  24 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  25 ME → SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  27 ME → SIM → ME PROACTIVE COMMAND PENDING: SEND DATA 1.3.1  27 ME → SIM → ME PROACTIVE COMMAND: SEND DATA  28 SIM → ME PROACTIVE COMMAND: SEND DATA  29 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (Store mode) 1.3.4  20 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA (Store mode) 1.3.4  SEND DATA 1.3.1  SEND DATA 1.3.4  SEND DATA (Store mode) 1.	19	$ exttt{SIM}  ightarrow$	PROACTIVE COMMAND BENDING:	
20 ME → SIM → PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4  22 ME → SIM → TERMINAL RESPONSE: SEND DATA (store mode) 1.3.4  23 SIM → PROACTIVE COMMAND PENDING: SEND DATA 1.3.5  24 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  25 ME → SIM → SIM PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  27 ME → SIM FETCH  28 SIM → ME PROACTIVE COMMAND: SEND DATA  Send 1kByte of data by packet of 200 Bytes		ME		
SIM   SIM   PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4   [200 Bytes]			OLIND DATA 1.3.4	
21	20		FETCH	
ME (store mode) 1.3.4  22 ME → SIM TERMINAL RESPONSE: SEND DATA (store mode) 1.3.4  23 SIM → PROACTIVE COMMAND PENDING: SEND DATA (smmediate) 1.3.5  24 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  25 ME → SIM (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  27 ME → SIM FETCH  28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes	21	$SIM \rightarrow$	DD 4.0711/F 6.0111/11/F 6.0111/11	F
TERMINAL RESPONSE: SEND DATA (store mode) 1.3.4   Command performed successfully]				[200 Bytes]
SIM   SIM   SIM   PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5   SIM $\rightarrow$ ME   PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5   TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5   TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5   PROACTIVE COMMAND PENDING: SEND DATA 1.3.1   PROACTIVE COMMAND PENDING: SEND DATA 1.3.1   FETCH   PROACTIVE COMMAND: SEND DATA   Send 1kByte of data by packet of 200 Bytes			(store mode) 1.3.4	
SIM   SIM   SIM   PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5   SIM $\rightarrow$ ME   PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5   TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5   TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5   PROACTIVE COMMAND PENDING: SEND DATA 1.3.1   PROACTIVE COMMAND PENDING: SEND DATA 1.3.1   FETCH   PROACTIVE COMMAND: SEND DATA   Send 1kByte of data by packet of 200 Bytes	22	ME $\rightarrow$	TERMINAL DECRONCE CENT DATE	[Command nonformed successfull 1
$\begin{array}{cccccccccccccccccccccccccccccccccccc$				[Command performed successfully]
ME  PROACTIVE COMMAND PENDING: SEND DATA 1.3.5  24 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5  PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  PROACTIVE COMMAND PENDING: SEND DATA  SEND DATA  [Command performed successfully]  ME → SIM → ME PROACTIVE COMMAND: SEND DATA  Send 1kByte of data by packet of 200 Bytes			(store mode) 1.3.4	
ME  PROACTIVE COMMAND PENDING: SEND DATA 1.3.5  24 SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5  TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5  PROACTIVE COMMAND PENDING: SEND DATA (immediate) 1.3.5  PROACTIVE COMMAND PENDING: SEND DATA  SEND DATA  [Command performed successfully]  ME → SIM → ME PROACTIVE COMMAND: SEND DATA  Send 1kByte of data by packet of 200 Bytes	23	$ ext{SIM}  ightarrow$	DDOACTIVE COMMAND DENDING.	
24 SIM → ME (immediate) 1.3.5 25 ME → SIM TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5 26 SIM → ME DATA 1.3.1 27 ME → SIM SIM → ME SIM SIM → ME PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5 28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes		ME		
(immediate) 1.3.5  ZERMINAL RESPONSE: SEND DATA (command performed successfully)			SLIND DATA 1.3.3	
25 ME → SIM TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5  26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA 1.3.1  27 ME → SIM FETCH  28 SIM → ME PROACTIVE COMMAND: SEND DATA  Send 1kByte of data by packet of 200 Bytes	24	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DATA	
26 SIM → ME (immediate) 1.3.5 PROACTIVE COMMAND PENDING: SEND DATA 1.3.1 FETCH 28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes	_			
26 SIM → ME PROACTIVE COMMAND PENDING: SEND DATA 1.3.1  27 ME → SIM FETCH 28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes	25	$ME \rightarrow SIM$		[Command performed successfully]
DATA 1.3.1  27 ME → SIM FETCH  28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes	26	SIM VME		
27 ME → SIM FETCH 28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes	20	OIIVI → IVIE		
28 SIM → ME PROACTIVE COMMAND: SEND DATA Send 1kByte of data by packet of 200 Bytes	27	$ME \rightarrow SIM$		
			PROACTIVE COMMAND: SEND DATA	Send 1kByte of data by packet of 200 Bytes
			(store mode) 1.3.1	

29	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (store mode) 1.3.1	[Command performed successfully]
30	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND DATA 1.3.2	
31	$ME \rightarrow SIM$		
32	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DATA (store mode) 1.3.2	[200 Bytes]
33	$ME \rightarrow SIM$	,	[Command performed successfully]
34	$SIM \rightarrow ME$	PROACTIVÉ COMMAND PENDING: SEND DATA 1.3.3	
35	$ME \rightarrow SIM$	FETCH	
36	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DATA (store mode) 1.3.3	[200 Bytes]
37	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (store mode) 1.3.3	[Command performed successfully]
38	$SIM \rightarrow ME$	PROACTIVÉ COMMAND PENDING: SEND DATA 1.3.4	
39	$ME \rightarrow SIM$	FETCH	
40	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND DATA (store mode) 1.3.4	[200 Bytes]
41	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (store mode) 1.3.4	[Command performed successfully]
42	$SIM \rightarrow ME$	PROACTIVÉ COMMAND PENDING: SEND DATA 1.3.5	
43	$SIM \to ME$	PROACTIVE COMMAND: SEND DATA (immediate) 1.3.5	
44	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND DATA (immediate) 1.3.5	[Command performed successfully]

# Expected sequence 1.5 (SEND DATA, immediate mode with a bad channel identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD, 9600bps
		CHANNEL (immediate) 1.1.1	V.32, 1KB buffer]
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DATA 1.5.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	
		DATA (immediate) 1.5.1	
10	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Invalide channel number]
		DATA (immediate) 1.1.1	

## PROACTIVE COMMAND: SEND DATA 1.5.1

## Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 2

Channel Data

Channel Data: 8 Bytes of data

Coding:

BER-TLV:	D0	13	81	03	01	43	01	82	02	81	22	B6
	08	XX										

TERMINAL RESPONSE: SEND DATA 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME Destination device: SIM

Result

General Result: Bearer Independent Protocol error (3A)
Additional Result: Channel identifier not valid (03)

Coding:

BER-TLV:	81	03	01	43	01	82	02	82	81	83	02	3A
	03											

# Expected sequence 1.6 (SEND DATA, immediate mode, Proactive SIM session terminated by the user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD, 9600bps
		CHANNEL (immediate) 1.1.1	V.32, 1KB buffer]
4		SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING; SEND DATA 1.6.1	
8	$ME \rightarrow SIM$		
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: SEND	
		DATA (immediate) 1.6.1	
10	ME  o	ME displays "Send data"	
	USER		
11	USER →	Abort proactive session	
	ME		
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Proactive SIM session terminated by the
		DATA (immediate) 1.1.1	[user]

PROACTIVE COMMAND: SEND DATA 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: SIM
Destination device: Channel 1
Alpha Identifier: Send data

Channel Data

Channel Data: 8 Bytes of data

Coding:

BER-TLV:	D0	1E	81	03	01	43	01	82	02	81	21	85
_	09	53	65	6E	64	20	64	61	74	61	B6	80
	XX											

## TERMINAL RESPONSE: SEND DATA 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Send Immediately

Device identities

Source device: ME Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV:	81	03	01	43	01	82	02	82	81	83	01	10
DLIX ILV.	0.	00	0.	70	0 1	02	02	02	0.	00	0 1	10

### 27.22.4.30.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

## 27.22.4.31 GET CHANNEL STATUS

## 27.22.4.31.1 Definition and applicability

See clause 3.2.2.

## 27.22.4.31.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

## 27.22.4.31.3 Test purpose

To verify that the ME shall send a TERMINAL RESPONSE (Command Performed Successfully) to the SIM after the ME receives the GET STATUS proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

## 27.22.4.31.4 Method of test

27.22.4.31.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.31.4.2 Procedure

## Expected sequence 1.1 (GET STATUS, without any BIP channel opened)

For that test, no channel has been opened.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET CHANNEL	
		STATUS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	
		STATUS 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL GET STATUS 1.1.1	[Command performed successfully]

#### PROACTIVE COMMAND: GET STATUS 1.1.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	44	00	82	02	81	82	l
----------	----	----	----	----	----	----	----	----	----	----	----	---

#### TERMINAL RESPONSE: GET STATUS 1.1.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: No Channel, link not established

BER-TLV:	81	03	01	44	00	82	02	82	81	83	01	00
	B8	02	00	00								

## Expected sequence 1.2 (GET STATUS, with a BIP channel currently opened)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL	
		1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN	[Immediate link establishment, CSD, 9600bps
		CHANNEL (immediate) 1.2.1	V.32]
4		SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.2.1	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET CHANNEL	
		STATUS 1.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET	
		STATUS 1.2.1	
10	$ME \rightarrow SIM$	TERMINAL GET STATUS 1.2.1	[Command performed successfully]

#### PROACTIVE COMMAND: OPEN CHANNEL 1.2.1

## Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

## Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	01	B9	02	00	2A				

## TERMINAL RESPONSE: OPEN CHANNEL 1.2.1

## Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	00	01	B9	02
	00	2A										

#### PROACTIVE COMMAND: GET STATUS 1.2.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	44	00	82	02	81	82	l
----------	----	----	----	----	----	----	----	----	----	----	----	---

#### TERMINAL RESPONSE: GET STATUS 1.2.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: Channel 1 open, link established

Coding:

BER-TLV:	81	03	01	44	00	82	02	82	81	83	01	00
	B8	02	81	00								

## **Expected sequence 1.3 (GET STATUS, after a link dropped)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: OPEN	
		CHANNEL 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: OPEN CHANNEL	[Immediate link establishment, CSD,
		(immediate) 1.2.1	9600bps V.32]
4	$ME \to SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: OPEN CHANNEL	[Command performed successfully]
		(immediate) 1.2.1	
7	$SS \rightarrow ME$	DROP LINK	
8	$ME \rightarrow SIM$	ENVELOPE EVENT DOWNLOAD: CHANNEL	[Link dropped]
		STATUS 1.3.1	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET	
		STATUS 1.3.1	
10	$ME \rightarrow SIM$		
11	$SIM \rightarrow ME$	PROACTIVE COMMAND: GET STATUS 1.3.1	
12	$ME \rightarrow SIM$	TERMINAL GET STATUS 1.3.1	[Command performed successfully]

## **ENVELOPE EVENT DOWNLOAD: CHANNEL STATUS 1.3.1**

Logically:

Event list

Event list: Channel Status

Device identities

Source device: ME Destination device: SIM

Channel status

Channel status: Channel 1, link dropped

Coding:

BER-TLV:	D6	0B	99	01	0A	82	02	82	81	B8	02	01
	05											

## PROACTIVE COMMAND: GET STATUS 1.3.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	44	00	82	02	81	82	I
----------	----	----	----	----	----	----	----	----	----	----	----	---

**TERMINAL RESPONSE: GET STATUS 1.3.1** 

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: Channel 1, link dropped

Coding:

BER-TLV:	81	03	01	44	00	82	02	82	81	83	01	00
	B8	02	01	05								

#### 27.22.4.31.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

## 27.22.5 Data Download to SIM

## 27.22.5.1 SMS-PP Data Download

## 27.22.5.1.1 Definition and applicability

See clause 3.2.2.

## 27.22.5.1.2 Conformance requirement

The ME shall support the Proactive SIM: SMS-PP Data Download facility as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 4.3, clause 5, clause 7.1, clause 12.1, clause 12.7 and clause 12.13.

## 27.22.5.1.3 Test purpose

To verify that the ME transparently passes the "data download via SMS Point-to-point" messages to the SIM.

To verify that the ME returns the RP-ACK message back to the system Simulator, if the SIM responds with '90 00' or '91 XX'.

To verify that the ME returns the response data from the SIM back to the system Simulator in the TP-User-Data element of the RP-ACK message, if the SIM responds with '9F XX'.

#### 27.22.5.1.4 Method of Test

#### 27.22.5.1.4.1 Initial conditions

The ME is connected to the system Simulator and the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.5.1.4.2 Procedure

#### Expected Sequence 1.1 (SMS-PP Data Download, General Data Coding, Default Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	ME	The ME shall be in its normal idle	[Start a sequence to verify that the ME returns
		mode	the RP-ACK message back to the system
			Simulator, if the SIM responds with '90 00']
2	$SS \to ME$	SMS-PP Data Download Message	
		1.1.1	
3	$ME \rightarrow USER$	The ME shall not display the	
		message or alert the user of a	
		short message waiting	
4	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
		DOWNLOAD 1.1.2	
5	$SIM \to ME$	SW1 / SW2 of '90 00'	
6	$ME \to SS$	RP-ACK.	

#### SMS-PP (Data Download) Message 1.1.1

Logically:

**SMS TPDU** 

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

#### Coding:

BER-TLV	04	03	91	21	43	7F	12	89	10	10	00	00
	00	00	0D	53	F4	5B	4E	07	35	СВ	F3	79
	F8	5C	06									

## **ENVELOPE: SMS-PP DOWNLOAD 1.1.2**

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

**SMS TPDU** 

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC TP-RP TP-Reply-Path is not set in this SMS-DELIVER TP-UDHI TP-UD field contains only the short message TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group
Compression
Message Class
General Data Coding
Text is uncompressed
Class 2 SIM Specific Message

Alphabet Default Alphabet

TP-SCTS: 01/01/98 00:00:00 +0 TP-UDL 13

TP-UD "Short Message"

## Coding:

BER-TLV:	D1	2C	82	02	83	81	06	09	91	11	22	33
_	44	55	66	77	F8	8B	1B	04	04	91	21	43
	7F	12	89	10	10	00	00	00	00	0D	53	F4
	5B	4E	07	35	CB	F3	79	F8	5C	06		

# Expected Sequence 1.2 (SMS-PP Data Download, General Data Coding, Default Alphabet, GET RESPONSE, Acknowledgement)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-PP Data Download Message	
		1.2.1	
2	$ME \rightarrow USER$	The ME shall not display the	
		message or alert the user of a	
		short message waiting.	
3	$ME \rightarrow SIM$	  ENVELOPE: SMS-PP	
3	IVIE -> SIIVI	DOWNLOAD 1.2.2	
4	$SIM \rightarrow ME$		[SW1 / SW2 of '9F 0B']
5	$ME \rightarrow SIM$	GET RESPONSE	
_			
6	$SIM \rightarrow ME$	SMS-PP Data Download SIM	
		Acknowledgement 1.2.3	
7	$ME \to SS$	SMS-PP Data Download SIM	
		Acknowledgement 1.2.4 in the TP-	
		User-Data element of the RP-ACK	
		message. The values of protocol	
		identifier and data coding scheme	
		in RP-ACK shall be as in the	
		original message.	

# Expected Sequence 1.3 (SMS-PP Data Download, General Data Coding, Default Alphabet, FETCH, MORE TIME)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-PP Data Download Message	
2	$ME \to USER$	1.3.1 The ME shall not display the	
		message or alert the user of a	
		short message waiting	
3	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
4	$SIM \rightarrow ME$	DOWNLOAD 1.3.2 PROACTIVE COMMAND	[SW1 / SW2 of '91 0B']
7	SIIVI → IVIE	PENDING: MORE TIME 1.3.3	[300173002 01 91 00]
5	ME  o SS	RP-ACK	
6	$ME \to SIM$	FETCH	
7	$SIM \to ME$	PROACTIVE COMMAND: MORE	
		TIME 1.3.4	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: MORE	
	0114 145	TIME 1.3.5	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: MORE TIME 1.3.4

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM Destination device: ME

Coding:

BER-TLV:	D0	09	81	03	01	02	00	82	02	81	82

**TERMINAL RESPONSE: MORE TIME 1.3.5** 

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

BFR-TI V·	81	03	01	02	00	82	02	82	81	83	01	00

## Expected Sequence 1.4 (SMS-PP Data Download, General Data Coding, 8 Bit Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	SMS-PP Data Download Message	
		1.4.1	
2	ME	The ME shall not display the	
		message or alert the user of a	
		short message waiting	
3	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
		DOWNLOAD 1.4.2	
4	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
5	$ME \rightarrow SS$	RP-ACK	

#### SMS-PP (Data Download) Message 1.2.1 / 1.3.1 / 1.4.1

Logically:

**SMS TPDU** 

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group
Compression

Classification
General Data Coding
Text is uncompressed

Classification
Classification

Message Class Class 2 SIM Specific Message

Alphabet 8 bit

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV:	04	03	91	21	43	7F	16	89	10	10	00	00	
	00	00	0D	53	68	6F	72	74	20	4D	65	73	]
	73	61	67	65									l

#### ENVELOPE: SMS-PP DOWNLOAD 1.2.2 / 1.3.2 / 1.4.2,

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding
Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet 8 bit

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

#### Coding:

BER-TLV:	D1	2D	82	02	83	81	06	09	91	11	22	33
-	44	55	66	77	F8	8B	1C	04	04	91	21	43
	7F	16	89	10	10	00	00	00	00	0D	53	68
	6F	72	74	20	4D	65	73	73	61	67	65	

## Expected Sequence 1.5 (SMS-PP Data Download, Data Coding / Message Class, Default Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	ME	The ME shall be in its normal idle mode.	
2	$SS \rightarrow ME$	SMS-PP Data Download Message 1.5.1.	
3	ME	The ME shall not display the message or alert	
		the user of a short message waiting	
4	$ME \rightarrow SIM$	ENVELOPE: SMS-PP DOWNLOAD 1.5.2.	
5	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
6	$ME \to SS$	RP-ACK	

#### SMS-PP (Data Download) Message 1.5.1

#### Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding Default Alphabet

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

BER-TLV:	04	03	91	21	43	7F	F2	89	10	10	00	00
	00	00	0D	53	F4	5B	4E	07	35	CB	F3	79
	F8	5C	06									

**ENVELOPE: SMS-PP DOWNLOAD 1.5.2** 

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding Default Alphabet

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV:	D1	2C	82	02	83	81	06	09	91	11	22	33
	44	55	66	77	F8	8B	1B	04	04	91	21	43
	7F	F2	89	10	10	00	00	00	00	0D	53	F4
	5B	4E	07	35	CB	F3	79	F8	5C	06		

#### Expected Sequence 1.6 (SMS-PP Data Download, with Data Coding / Message Class, 8 Bit Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	SMS-PP Data Download Message	
		1.6.1	
2	ME	The ME shall not display the	
		message or alert the user of a	
		short message waiting	
3	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
		DOWNLOAD 1.6.2	
4	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
5	$ME \rightarrow SS$	RP-ACK	

SMS-PP (Data Download) Message 1.6.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding 8 bit

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

#### Coding:

BER-TLV:	04	03	91	21	43	7F	F6	89	10	10	00	00
	00	00	0D	53	68	6F	72	74	20	4D	65	73
	73	61	67	65								

#### **ENVELOPE: SMS-PP DOWNLOAD 1.6.2**

#### Logically:

#### SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

**SMS TPDU** 

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding 8 bit

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

#### Coding:

BER-TLV:	D1	2D	82	02	83	81	06	09	91	11	22	33
-	44	55	66	77	F8	8B	1C	04	04	91	21	43
	7F	F6	89	10	10	00	00	00	00	0D	53	68
	6F	72	74	20	4D	65	73	73	61	67	65	

#### SMS-PP Data Download SIM Acknowledgement 1.2.4

BER-TLV:	50	68	69	6C	20	48	6F	6F	6B	65	72

#### 27.22.5.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.6.

#### 27.22.5.2 SMS-CB Data Download

## 27.22.5.2.1 Definition and applicability

See clause 3.2.2.

## 27.22.5.2.2 Conformance requirement

The ME shall support the Proactive SIM: SMS-CB Data Download facility as defined in:

• 3GPP TS 11.14 [15] clause 4.3, clause 5, clause 7.2, clause 12.5 and clause 12.7.

## 27.22.5.2.3 Test purpose

To verify that the ME transparently passes the "data download via SMS Cell Broadcast" messages to the SIM, which contain a message identifier found in  $EF_{CBMID}$ .

#### 27.22.5.2.4 Method of Test

#### 27.22.5.2.4.1 Initial conditions

The ME is connected to the system Simulator and the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.5.2.4.2 Procedure

# Expected Sequence 1.1 (SMS-CB (Data Download), ENVELOPE(SMS-CB DOWNLOAD), ME does not display message)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-CB (DATA DOWNLOAD)	Message identifier '10 01'
		1.1	
2	$ME \rightarrow SIM$	ENVELOPE (SMS-CB	
		DOWNLOAD) 1.1	
3	$SIM \to ME$	SW1, SW2 '90 00'	

### SMS-CB (Data Download) Message 1.1

#### Logically:

#### Message Content

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "1001"

Data coding Scheme

Message Coding: 8 bit data

Message class: No message class

Page Parameter

Total number of pages: 1 Page number: 1

Content of message: "Cell Broadcast "...

#### Coding:

BER-TLV:	C0	11	10	01	F4	11	43	65	6C	6C	20	42
_	72	6F	61	64	63	61	73	74	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20								

## **ENVELOPE: SMS-CB DOWNLOAD 1.1**

Logically:

Cell Broadcast Download

Device identities

Source device: Network Destination device: SIM

Cell Broadcast page

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1 Update number: 1 Message Identifier: "1001"

Data coding Scheme

Message Coding: 8 bit data

Message class: No message class

Page Parameter
Number of pages: 1
Page number: 1

Content of message: "Cell Broadcast " ...

BER-TLV:	D2	5E	82	02	83	81	8C	58	C0	11	10	01
	F4	11	43	65	6C	6C	20	42	72	6F	61	64
	63	61	73	74	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20

# Expected Sequence 1.2 (SMS-CB(DATA DOWNLOAD), ENVELOPE(SMS-CB DATA DOWNLOAD), FETCH, MORE TIME, ME does not display message)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-CB (DATA DOWNLOAD)	Message identifier '10 01'
		1.1	-
2	$ME \rightarrow SIM$	ENVELOPE (SMS-CB	
		DOWNLOAD) 1.1	
3	$SIM \to ME$		SW1/SW2 '91 0B'
4	$ME \to SIM$	FETCH 1.1	
5	$SIM \to ME$	PROACTIVE COMMAND:MORE	
		TIME 1.1	
6	$ME \to SIM$	TERMINAL RESPONSE	
7	$SIM \to ME$	SW1/SW2 '90 00'	SIM session ended

PROACTIVE COMMAND: MORE TIME 1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

TERMINAL RESPONSE: MORE TIME 1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME Command qualifier: "00"

Comman Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	02	00	82	02	82	81	83	01	00

## Expected Sequence 1.3 (SMS-CB (DATA DOWNLOAD), ME displays message)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	SMS-CB (DATA DOWNLOAD) 1.2	Message identifier '0C 0C'
2	ME → USER	ME displays message	

SMS-CB (Data Download) Message 1.2

Logically:

Message Content

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "0C0C"

Message Identifier:
Data coding Scheme

Message Coding:

8 bit data

Message class: No message class

Page Parameter

Total number of pages: 1 Page number: 1

Content of message: "Cell Broadcast".

#### Coding:

BER-TLV:	C0	11	0C	0C	F4	11	43	65	6C	6C	20	42
	72	6F	61	64	63	61	73	74	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20								

### 27.22.5.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.3.

## 27.22.6 CALL CONTROL BY SIM

## 27.22.6.1 Procedure for Mobile Originated calls

## 27.22.6.1.1 Definition and applicability

See clause 3.2.2.

### 27.22.6.1.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.1.1.

## 27.22.6.1.3 Test purpose

To verify that for all call set-up attempts, even those resulting from a SET UP CALL proactive SIM command, the ME shall first pass the call set-up details (dialled digits and associated parameters) to the SIM, using the ENVELOPE (CALL CONTROL).

To verify that if the SIM responds with '90 00', the ME shall set up the call with the dialled digits and other parameters as sent to the SIM.

To verify that if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to set up the call as proposed, not set up the call, set up a call using the data supplied by the SIM.

To verify that, in the case where the initial call set-up request results from a proactive SET UP CALL, if the call control result is "not allowed" or "allowed with modifications", the ME shall inform the SIM using TERMINAL RESPONSE "interaction with call control by SIM or MO short message control by SIM, action not allowed".

To verify that it is possible for the SIM to request the ME to set up an emergency call by supplying the number "112" as the response data.

## 27.22.6.1.4 Method of tests

#### 27.22.6.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and System Simulator and has performed the location update procedure.

The GSM parameters of the system simulator are:

- Mobile Country Code (MCC) = 1;
- Mobile Network Code (MNC) = 1;
- Location Area Code (LAC) = 1;
- Cell Identity value = 1.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

#### 27.22.6.1.4.2 Procedure

# Expected Sequence 1.1 (CALL CONTROL BY SIM , set up call attempt by user, the SIM responds with $^{190}$ 00')

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
		"+01234567890123456789"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		1.1.1	
3	$SIM \rightarrow ME$	90 00	
4	$ME \to SS$	The ME sets up the call without	[Set up call to "+01234567890123456789"
		modification	

#### **ENVELOPE CALL CONTROL 1.1.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

BER-TLV:	D4	1A	82	02	82	81	86	0B	91	10	32	54
_	76	98	10	32	54	76	98	13	07	00	F1	10
	00	01	00	01								

# Expected Sequence 1.2 (CALL CONTROL BY SIM , set up call attempt by user, allowed without modification)

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
		"+01234567890123456789"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		1.2.1	
3	$SIM \to ME$	9F 02	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \rightarrow ME$	CALL CONTROL RESULT 1.2.1	[Call control result: "Allowed, no
			modification"]
6	$ME \to SS$	The ME sets up the call without	[Set up call to "+01234567890123456789"
		modification	

## **ENVELOPE CALL CONTROL 1.2.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	1A	82	02	82	81	86	0B	91	10	32	54
	76	98	10	32	54	76	98	13	07	00	F1	10
	00	01	00	01								

## **CALL CONTROL RESULT 1.2.1**

Logically:

Call control result : '00' = Allowed, no modification

Coding:

BER-TLV: 00 00

# Expected Sequence 1.3 (CALL CONTROL BY SIM, set up call attempt resulting from a set up call proactive command, allowed without modification)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND: SET	
		UP CALL 1.3.1 PENDING	
2	ME→SIM	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP CALL 1.3.1	[Set up call to "+012340123456"]
4	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		1.3.1	
5	$SIM \to ME$	9F 02	
6	$ME \rightarrow SIM$	GET RESPONSE	
7	$SIM \to ME$		[Call control result: "Allowed, no modification"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP CALL 1.3.1	[command performed successfully]
9	$ME \to SS$	The ME sets up the call without modification	[Set up call to "+012340123456"]

PROACTIVE COMMAND: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding:

BER-TLV:	D0	21	81	03	01	10	00	82	02	81	83
	05	0D	2B	30	31	32	33	34	30	31	32
	33	34	35	36	86	07	91	10	32	04	21
	43	65									

# **ENVELOPE CALL CONTROL 1.3.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

BER-TLV:	D4	16	02	02	82	81	06	07	91	10	32
-	04	21	43	65	13	07	00	F1	10	00	01
	00	01									

## **CALL CONTROL RESULT 1.3.1**

Logically:

Call control result : '00' = Allowed, no modification

Coding:

BER-TLV: 00 00

TERMINAL RESPONSE: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV	81	03	01	10	00	82	02	82	81	83	01	00	l
---------	----	----	----	----	----	----	----	----	----	----	----	----	---

## Expected Sequence 1.4 (CALL CONTROL BY SIM, set up call attempt by user, not allowed)

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
		"+01234567890123456789"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		1.4.1	
3	$SIM \to ME$	9F 02	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \rightarrow ME$	CALL CONTROL RESULT 1.4.1	[Call control result: "not Allowed"]
6	$ME \rightarrow SS$	The ME does not set up the call	

## **ENVELOPE CALL CONTROL 1.4.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+01234567890123456789"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)

Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	1A	82	02	82	81	86	0B	91	10	32	54
_	76	98	10	32	54	76	98	13	07	00	F1	10
	00	01	00	01								

#### **CALL CONTROL RESULT 1.4.1**

Logically:

Call control result: '01' = not Allowed

Coding:

BER-TLV: 01 00

# Expected Sequence 1.5 (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, not allowed)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND: SET	
		UP CALL 1.5.1 PENDING	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET	[Set up call to "+012340123456"
		UP CALL 1.5.1	
4	$ME \to SIM$	ENVELOPE CALL CONTROL	
		1.5.1	
5	$SIM \to ME$	9F 02	
6	$ME \to SIM$	GET RESPONSE	
7	$SIM \to ME$	CALL CONTROL RESULT 1.5.1	[Call control result: "Not Allowed"]
8	$ME \to SIM$	TERMINAL RESPONSE: SET UP	Permanent Problem - Interaction with
		CALL 1.5.1	Call Control by SIM]
9	$ME \to SS$	The ME does not set up the call	

PROACTIVE COMMAND: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

BER-TLV:	D0	21	81	03	01	10	00	82	02	81	83
	05	0D	2B	30	31	32	33	34	30	31	32
	33	34	35	36	86	07	91	10	32	04	21
	//3	65									

#### **ENVELOPE CALL CONTROL 1.5.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	16	02	02	82	81	06	07	91	10	32
	04	21	43	65	13	07	00	F1	10	00	01
	00	01									

## **CALL CONTROL RESULT 1.5.1**

Logically:

Call control result: '01' = not Allowed

Coding:

BER-TLV: 01 00

TERMINAL RESPONSE: SET UP CALL 1.5.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Interaction with call control by SIM or MO short message control by SIM,

permanent problem

Additional information: Action not allowed

BER-TLV:	81	03	01	10	00	82	02	82	81	83	02	39
	01											

# Expected Sequence 1.6 (CALL CONTROL BY SIM , set up call attempt by user, allowed with modifications)

Step	Direction	Message / Action	Comments
1	$User \rightarrow ME$	Set up a call to	
		"+01234567890123456789"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		1.6.1	
3	$SIM \rightarrow ME$	9F 07	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 1.6.1	[Call control result: "Allowed with modifications", ]
6	$ME \rightarrow SS$	The ME sets up the call to "+010203"	

## **ENVELOPE CALL CONTROL 1.6.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	1A	82	02	82	81	86	0B	91	10	32	54
	76	98	10	32	54	76	98	13	07	00	F1	10
	00	01	00	01								

## **CALL CONTROL RESULT 1.6.1**

Logically:

Call control result: '02' = Allowed with modifications

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "010203"

BER-TLV:	02	06	86	04	91	10	20	30
----------	----	----	----	----	----	----	----	----

# Expected Sequence 1.7 (CALL CONTROL BY SIM, set up call attempt resulting from a set up call proactive command, allowed with modifications)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND: SET	
		UP CALL 1.7.1 PENDING	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP CALL 1.7.1	[Set up call to "+012340123456"]
4	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
5	$SIM \to ME$	9F 0B	
6	$ME \rightarrow SIM$	GET RESPONSE	
7	$SIM \to ME$	CALL CONTROL RESULT 1.7.1	[Call control result: "Allowed with modifications"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP CALL 1.7.1	[command performed successfully]
9	$ME \to SS$	The ME sets up the call to "+011111111111"	

PROACTIVE COMMAND: SET UP CALL 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: National

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Coding:

BER-TLV:	D0	21	81	03	01	10	00	82	02	81	83
	05	0D	2B	30	31	32	33	34	30	31	32
	33	34	35	36	86	07	91	10	32	04	21

#### **ENVELOPE CALL CONTROL 1.7.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

BER-TLV:	D4	16	02	02	82	81	06	07	91	10	32
-	04	21	43	65	13	07	00	F1	10	00	01
	00	01									

## **CALL CONTROL RESULT 1.7.1**

Logically:

Call control result: '02' = Allowed with modifications

Address

TON: National

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+01111111111"

Coding:

BER-TLV:	02	0A	86	06	07	91	10	11	11	11	11
·	11										

## TERMINAL RESPONSE: SET UP CALL 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	10	00	82	02	82	81	83	01	00	1
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

# Expected Sequence 1.8 (CALL CONTROL BY SIM, set up call attempt by user, allowed with modifications: emergency call)

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
		"+01234567890123456789"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL 1.8.1	
3	$SIM \rightarrow ME$	9F 06	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \rightarrow ME$	CALL CONTROL RESULT 1.8.1	[Call control result: "Allowed with
			modifications"]
6	$ME \rightarrow SS$	The ME sets up an emergency call;	

#### **ENVELOPE CALL CONTROL 1.8.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	1A	82	02	82	81	86	0B	91	10	32	54
	76	98	10	32	54	76	98	13	07	00	F1	10
	00	01	00	01								

## **CALL CONTROL RESULT 1.8.1**

Logically:

Call control result Allowed, with modification

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "112"

Coding:

BER-TLV: 02 05 86 03 81 11 F2

# Expected Sequence 1.9 (CALL CONTROL BY SIM , set up call attempt by user, allowed with modifications: number in $\mathsf{EF}_{\mathsf{ECC}}$ )

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
		"+01234567890123456789"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL 1.9.1	
3	$SIM \rightarrow ME$	9F 06	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \rightarrow ME$	CALL CONTROL RESULT 1.9.1	[Call control result: "Allowed with modifications"]
6	$ME \rightarrow SS$	The ME sets up call with the dialled digits "1020". The ME does not set up an emergency call, but stes up a normal call	

#### **ENVELOPE CALL CONTROL 1.9.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

BER-TLV:	D4	1A	82	02	82	81	86	0B	91	10	32	54
	76	98	10	32	54	76	98	13	07	00	F1	10
	00	01	00	01								

#### **CALL CONTROL RESULT 1.9.1**

Logically:

Call control result Allowed, with modification

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "1020"

Coding:

BER-TLV:	02	05	86	03	81	01	02

# Expected Sequence 1.10 (CALL CONTROL BY SIM, set up call attempt by user to an emergency call)

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to "112"	
2	$ME \rightarrow SIM$	The ME does not send any ENVELOPE CALL CONTROL	
3	$ME \rightarrow SS$	The ME sets up an emergency call	

# Expected Sequence 1.11 (CALL CONTROL BY SIM , set up call through call register, the SIM responds with '90 00')

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers allowed by call control in its register.

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
2	$ME \to SIM$	"+01234567890123456789" ENVELOPE CALL CONTROL 1.1.1	
3	$SIM \to ME$	90 00	
4	$ME \to SS$	The ME sets up the call without	[Set up call to "+01234567890123456789"]
5	LICED . ME	modification End Call.	
3	$USER \to ME$	Elia Call.	
6	$USER \to ME$	Recall the last dialled number	
7	$ME \to SIM$	ENVELOPE CALL CONTROL	
		1.1.1	
8	$SIM \to ME$	90 00	
9	$ME \to SS$	The ME sets up the call without	[Set up call to "+01234567890123456789"]
		modification	
10	$USER \to ME$	End Call.	

# Expected Sequence 1.12 (CALL CONTROL BY SIM, set up call through call register, allowed without modification)

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers allowed by call control in its register.

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to "+0123456789"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
3	$SIM \to ME$	9F 02	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 1.2.1	[Call control result: "Allowed, no modification"]
6	$ME \to SS$	The ME sets up the call without modification	[Set up call to "+0123456789"]
7	$User \to ME$	End the call then call the last dialled number	
8	$ME \to SIM$	ENVELOPE CALL CONTROL 1.2.1	
9	$SIM \to ME$	9F 02	[Call control result: "Allowed, no modification"]
10	$ME \to SIM$	GET RESPONSE	[Set up call to "+01234567890123456789"]
11	$SIM \to ME$	CALL CONTROL RESULT 1.2.1	-

## Expected Sequence 1.13 (CALL CONTROL BY SIM, set up call through call register, not allowed)

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers not allowed by call control in its register.

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to "+0123456789"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL 1.4.1	
3	$SIM \to ME$	9F 02	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 1.4.1	[Call control result: "not Allowed"]
6	$ME \to SS$	The ME does not set up the call	
7	$User \to ME$	The user calls the last dialled number	
8	$ME \to SIM$	ENVELOPE CALL CONTROL 1.4.1	
9	$SIM \to ME$	9F 02	
10	$ME \to SIM$	GET RESPONSE	
11	$SIM \to ME$	CALL CONTROL RESULT 1.4.1	[Call control result: "not Allowed"]
12	$ME \to SS$	The ME does not set up the call	

# Expected Sequence 1.14 (CALL CONTROL BY SIM , set up call through call register, allowed with modifications)

Pre-condition: the ME has a mean to register the last dialled number(s), and the ME will store dialled numbers allowed with modification in its register.

Step	Direction	Message / Action	Comments
1	$User \to ME$	Set up a call to	
2	$ME \rightarrow SIM$	"+01234567890123456789" ENVELOPE CALL CONTROL 1.6.1	
3	$SIM \to ME$	9F 07	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \rightarrow ME$	CALL CONTROL RESULT 1.6.1	[Call control result: "Allowed with modifications"]
6	$ME \to SS$	The ME sets up the call to "+010203"	,
7	$User \to ME$	Set up a call to	
8	ME  o SIM	"+01234567890123456789" ENVELOPE CALL CONTROL	
O	IVIL -> OIIVI	1.6.1	
9	$SIM \to ME$	9F 07	
10	$ME \to SIM$	GET RESPONSE	
11	$SIM \rightarrow ME$	CALL CONTROL RESULT 1.6.1	[Call control result: "Allowed with modifications"]
12	$ME \to SS$	The ME sets up the call to "+010203"	_

## 27.22.6.1.5 Test requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.14.

## 27.22.6.2 Procedure for Supplementary (SS) Services

# 27.22.6.2.1 Definition and applicability

See clause 3.2.2.

## 27.22.6.2.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in the following technical specifications:

• 3GPP TS 11.14 [15] clause 9.1.2.

## 27.22.6.2.3 Test purpose

To verify that the ME first pass the supplementary service control string corresponding to the supplementary service operation to the SIM, using the ENVELOPE (CALL CONTROL) command.

To verify that, if the SIM responds with '90 00', the ME shall send the supplementary service operation with the information as sent to the SIM.

To verify that, if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to send the supplementary service operation as proposed, not send the SS operation, or instead send the SS operation using the data supplied by the SIM.

## 27.22.6.2.4 Method of tests

#### 27.22.6.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

#### 27.22.6.2.4.2 Procedure

## Expected Sequence 2.1 (CALL CONTROL BY SIM, send SS, the SIM responds with '90 00')

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user selects the facility of the	
		ME which requires an	
		unconditional call forward	
		supplementary service operation	
		to be sent to the network (System	
		Simulator).	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		2.1.1	
3	$SIM \to ME$	90 00	
4	ME  o SS	REGISTER 2.1	[The ME sends the supplementary
			service operation with the information as
			sent to the SIM]
5	$SS \to ME$	RELEASE COMPLETE (SS	
		RETURN RESULT) 2.1	

## **ENVELOPE CALL CONTROL 2.1.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON/NPI: "FF" Dialling number string "\*21#"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	89	03	FF	2A	B1	13
	07	00	F1	10	00	01	00	01				

#### **REGISTER 2.1**

Logically (only SS argument):

ACTIVATE SS ARGUMENT

SS-Code:

- Call Forwarding Unconditional

TeleserviceCode

- All Tele Services

Coding:

BER-TLV	30	06	04	01	21	83	01	00		

## RELEASE COMPLETE (SS RETURN RESULT) 2.1

Logically (only from operation code):

#### ACTIVATE SS RETURN RESULT

Forwarding Info

SS-Code

- Call Forwarding Unconditional

Forward Feature List

ForwardingFeature TeleserviceCode

- All Tele Services

SS-Status

state ind.: operativeprovision ind.: provisionedregistration ind.: registeredactivation ind.: active

#### Coding:

BER-TLV	0C	A0	0D	04	01	21	30	80	30	06	83	01
-	00	84	01	07								

## Expected Sequence 2.2 (CALL CONTROL BY SIM, send SS, allowed without modifications)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user selects the facility of the	
		ME which requires an	
		unconditional call forward	
		supplementary service operation	
		to be sent to the network (System Simulator).	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		2.2.1	
3	$SIM \to ME$	9F 02	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 2.2.1	[Call control result: "Allowed without modifications"]
6	ME	The ME sends the supplementary	
	1V1L	service operation with the	
		information as sent to the SIM	

## **ENVELOPE CALL CONTROL 2.2.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: Unknown

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "\*21\*#"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

BER-TLV:	D4	13	82	02	82	81	89	04	81	2A	A1	FB
	13	07	00	F1	10	00	01	00	01			

## **CALL CONTROL RESPONSE 2.2.1**

Logically:

Call control result Allowed, no modifications

Coding:

BER-TLV: 00 00

## Expected Sequence 2.3 (CALL CONTROL BY SIM, send SS, not allowed)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user selects the facility of the	
		ME which requires an	
		unconditional call forward	
		supplementary service operation	
		to be sent to the network (System	
		Simulator).	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		2.3.1	
3	$SIM \to ME$	9F 02	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 2.3.1	[Call control result: "Not Allowed"]
6	$ME \to SS$	The ME does not send the	
		supplementary service operation	

## **ENVELOPE CALL CONTROL 2.3.1**

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: Unknown Dialling number string "\*21#"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	89	03	FF	2A	B1	13
_	07	00	F1	10	00	01	00	01				

#### **CALL CONTROL RESPONSE 2.3.1**

Logically:

Call control result Not Allowed

BER-TLV:	01	00
----------	----	----

## Expected Sequence 2.4 (CALL CONTROL BY SIM, send SS, allowed with modifications)

Step	Direction Message / Action		Comments				
1	$User \to ME$	The user selects the facility of the					
		ME which requires an					
		unconditional call forward					
		supplementary service operation					
		to be sent to the network (System					
		Simulator).					
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL					
		2.4.1					
3	• · · · · · · · · · · · · · · · · · · ·	9F 07					
4	$ME \rightarrow SIM$	GET RESPONSE					
_							
5	$SIM \to ME$	CALL CONTROL RESULT 2.4.1	[Call control result: "Allowed with modifications"]				
6	$ME \to SS$	REGISTER 2.4	[The ME sends the supplementary				
			service operation with the information as sent by the SIM]				
7	$SS \to ME$	RELEASE COMPLETE (SS					
		RETURN RESULT) 2.4					

## **ENVELOPE CALL CONTROL 2.4.1**

Logically:

Device identities

Source device: ME Destination device: SIM

SS String

TON/NPI: Unknown Dialling number string "\*21#"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	89	03	FF	2A	B1	13
	07	00	F1	10	00	01	00	01				

## **CALL CONTROL RESPONSE 2.4.1**

Logically:

Call control result Allowed, with modifications

SS String

TON/NPI "FF" SS String "\*#21#"

Coding:

BER-TLV:	02	06	89	04	FF	BA	12	FB
----------	----	----	----	----	----	----	----	----

#### **REGISTER 2.4**

Logically (only SS argument):

INTERROGATE SS ARGUMENT

SS-Code

- Call Forwarding Unconditional

Coding:

DED TIV	20	02	0.4	Ω1	24
BER-TLV	30	03	04	01	21

#### RELEASE COMPLETE (SS RETURN RESULT) 2.4

Logically (only from operation code):

#### INTERROGATE SS RESULT

Call Forwarding Unconditional

SS-Status

- state ind .: operative

provision ind.: provisionedregistration ind.: registeredactivation ind.: not active

Coding:

BER-TLV	80	01	06			

# 27.22.6.2.5 Test requirement

The ME shall operate in the manner defined in expected sequences 2.1 to 2.4.

# 27.22.6.3 Interaction with Fixed Dialling Number (FDN)

# 27.22.6.3.1 Definition and applicability

See clause 3.2.2.

# 27.22.6.3.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.1.4.

# 27.22.6.2.3 Test purpose

To verify that the ME checks that the number entered through the MMI is on the FDN list.

To verify that, if the MMI input does not pass the FDN check, the call shall not be set up.

To verify that, if the MMI input does pass the FDN check, the ME shall pass the dialled digits and other parameters to the SIM, using the ENVELOPE (CALL CONTROL) command.

To verify that, if the SIM responds with "allowed, no modification", the ME shall set up the call as proposed.

To verify that, if the SIM responds with "not allowed", the ME shall not set up the call.

To verify that, if the SIM responds with "allowed with modifications", the ME shall set up the call in accordance with the response from the SIM. If the modifications involve changing the dialled digits, the ME shall not re-check this modified number against the FDN list.

# 27.22.6.2.4 Method of tests

27.22.6.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

Fixed Dialling Number service is enabled.

#### 27.22.6.2.4.2 Procedure

# Expected Sequence 3.1 (CALL CONTROL BY SIM, set up a call not in EF<sub>FDN</sub>)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "4321"	
2	$ME \rightarrow SIM$	The ME does not send the ENVELOPE (CALL CONTROL) command to the SIM.	
3	$ME \to SS$	The ME does not set up the call.	

# Expected Sequence 3.2 (CALL CONTROL BY SIM , set up a call in $\mathsf{EF}_\mathsf{FDN}$ , the SIM responds with '90 00')

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "123"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		3.2.1	
3	$SIM \rightarrow ME$	90 00	
4	$ME \to SS$	The ME sets up the call without	[Set up call to "123"]
		modification	

# **ENVELOPE CALL CONTROL 3.2.1**

# Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "123"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

# Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	23	F1	13
	07	00	F1	10	00	01	00	01				

# Expected Sequence 3.3 (CALL CONTROL BY SIM , set up a call in $\mathsf{EF}_\mathsf{FDN}$ , Allowed without modifications)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "9876"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		3.3.1	
3	$SIM \rightarrow ME$	9F 02	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \to ME$		[Call control result: "Allowed without modifications"]
6	$ME \to SS$		[Set up call to "9876"]

# **ENVELOPE CALL CONTROL 3.3.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	89	67	13
	07	00	F1	10	00	01	00	01				

# **CALL CONTROL RESPONSE 3.3.1**

Logically:

Call control result Allowed, no modifications

Coding:

BER-TLV: 00 00

# Expected Sequence 3.4 (CALL CONTROL BY SIM, set up a call in EF<sub>FDN</sub>, Not Allowed)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "9876"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		3.4.1	
3	$SIM \to ME$	9F 02	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 3.4.1	[Call control result: "Not Allowed"]
6	$MF \rightarrow SS$	The MF does not set up the call	

# **ENVELOPE CALL CONTROL 3.4.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	89	67	13
	07	00	F1	10	00	01	00	01				

# **CALL CONTROL RESPONSE 3.4.1**

Logically:

Call control result Not Allowed

Coding:

BER-TLV: 01 00

# Expected Sequence 3.5 (CALL CONTROL BY SIM, set up a call in EF<sub>FDN</sub>, Allowed with modifications)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "9876"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		3.5.1	
3	$SIM \to ME$	9F 07	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 3.5.1	[Call control result: "Allowed with
			modifications"]
6	$ME \to SS$	The ME sets up the call with data	[Set up call to "3333"]
		sent by the SIM	

# **ENVELOPE CALL CONTROL 3.5.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	89	67	13
	07	00	F1	10	00	01	00	01				

#### **CALL CONTROL RESPONSE 3.5.1**

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "3333"

Coding:

BER-TLV:	02	05	86	03	81	33	33
DEIX IEV.	02	00	00	00	0.	00	00

# 27.22.6.3.5 Test requirement

The ME shall operate in the manner defined in expected sequences 3.1 to 3.5.

# 27.22.6.4 Support of Barred Dialling Number (BDN) service

# 27.22.6.4.1 Definition and applicability

See clause 3.2.2.

# 27.22.6.4.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in:

• 3GPP TS 11.14 [15] clause 9.1.5.

# 27.22.6.2.3 Test purpose

To verify that, if Barred Dialling Number service is enabled, the ME checks the number entered through the MMI against  $EF_{BDN}$ .

To verify that, if the SIM responds with "not allowed", the ME does not set up the call.

To verify that, if the SIM responds with "allowed, no modification", the ME shall set up the call (or the supplementary service operation) as proposed.

To verify that, if the SIM responds with "allowed with modifications", the ME sets up the call in accordance with the response from the SIM. If the modifications involve changing the dialled number the ME does not re-check this modified number against the FDN list when FDN is enabled.

#### 27.22.6.2.4 Method of tests

#### 27.22.6.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the Systems Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

Barred Dialling Number service is enabled.

Prior to the execution of expected sequence 4.4 the FDN service shall be enabled.

# 27.22.6.2.4.2 Procedure

# Expected Sequence 4.1 (CALL CONTROL BY SIM, set up a call in EF<sub>BDN</sub>)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "321"	
2	$ME \rightarrow SIM$	ENVELOPE CALL CONTROL	
		4.1.1	
3	$SIM \to ME$	9F 02	
4	$ME \rightarrow SIM$	GET RESPONSE	
5	$SIM \rightarrow ME$	CALL CONTROL RESULT 4.1.1	[Call control result: "Not Allowed"]
6	$ME \rightarrow SS$	The ME does not set up the call	

# **ENVELOPE CALL CONTROL 4.1.1**

Logically:

Device identities

Source device: ME Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "321"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	23	F1	13	
	07	00	F1	10	00	01	00	01					1

# **CALL CONTROL RESPONSE 4.1.1**

Logically:

Call control result Not Allowed

Coding:

BER-TLV: 01 00

# Expected Sequence 4.2 (CALL CONTROL BY SIM , set up a call not in $\mathsf{EF}_{\mathsf{BDN}}$ , Allowed without modifications)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "1234"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		4.2.1	
3	$SIM \rightarrow ME$	9F 02	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 4.2.1	[Call control result: "Allowed without
			modifications"]
6	$ME \to SS$	The ME sets up the call without	[Set up call to "1234"]
		modification	

# **ENVELOPE CALL CONTROL 4.2.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "1234"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	21	43	13
	07	00	F1	10	00	01	00	01				

# **CALL CONTROL RESPONSE 4.2.1**

Logically:

Call control result Allowed, no modifications

Coding:

BER-TLV: 00 00

# Expected Sequence 4.3 (CALL CONTROL BY SIM , set up a call not in $\mathsf{EF}_{\mathsf{BDN}}$ , Allowed with modifications)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "1111"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		4.3.1	
3	$SIM \to ME$	9F 07	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 4.3.1	[Call control result: "Allowed with
			modifications"]
6	$ME \to SS$	The ME sets up the call with data	[Set up call to "2222"]
		sent by the SIM	

# **ENVELOPE CALL CONTROL 4.3.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

**Location Information** 

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

# Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	11	11	13
	07	00	F1	10	00	01	00	01				

#### **CALL CONTROL RESPONSE 4.3.1**

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "2222"

Coding:

BER-TLV: 02 05 86 03 81 22 22

# Expected Sequence 4.4 (CALL CONTROL BY SIM , FDN and BDN enabled, set up a call in ${\sf EF}_{\sf FDN}$ , Allowed with modifications)

Step	Direction	Message / Action	Comments
1	$User \to ME$	The user sets up a call to "123"	
2	$ME \to SIM$	ENVELOPE CALL CONTROL	
		4.4.1	
3	$SIM \rightarrow ME$	9F 0A	
4	$ME \to SIM$	GET RESPONSE	
5	$SIM \to ME$	CALL CONTROL RESULT 4.4.1	[Call control result: "Allowed with
			modifications"]
6	$ME \to SS$	The ME sets up the call with data	[Set up call to "987654321"the ME does
		sent by the SIM	not re-check this modified number
			against the FDN list]

# **ENVELOPE CALL CONTROL 4.4.1**

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D4	12	82	02	82	81	86	03	81	89	67	13
	07	00	F1	10	00	01	00	01				

# **CALL CONTROL RESPONSE 4.4.1**

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "987654321"

Coding:

BER-TLV: 02 08 86 06 81 89 67 45 23 F1

# 27.22.6.4.5 Test requirement

The ME shall operate in the manner defined in expected sequences 4.1 to 4.4.

# 27.22.7 EVENT DOWNLOAD

# 27.22.7.1 MT Call Event

27.22.7.1.1 MT Call Event (normal)

27.22.7.1.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.1.1.2 Conformance requirement

The ME shall support the EVENT: MT Call event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.1 and clause 12.25.

#### 27.22.7.1.1.3 Test purpose

To verify that the ME informs the SIM the an Event: MT Call has occurred using the ENVELOPE (EVENT DOWNLOAD - MT Call) command.

27.22.7.1.1.4 Method of test

# 27.22.7.1.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

# 27.22.7.1.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD -MT Call event)**

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		EVENT LIST 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		EVENT LIST 1.1.1	
5	$SS \to ME$	CALL SET UP without CLI	[MT Call Set Up Without CLI]
6	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD	
		- MT Call 1.1.1	
7	$SS \to ME$	CALL DISCONNECT	
8	$SS \to ME$	CALL SET UP with CLI	[MT Call Set Up With CLI]
9	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD	
		- MT Call 1.1.2	
10	$SS \to ME$	CALL DISCONNECT	
11	$SS \to ME$	CALL SET UP with CLI and sub-	[MT Call Set Up with CLI and sub-address]
		address	
12	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD	
		- MT Call 1.1.3	
13	$SS \to ME$	CALL DISCONNECT	

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: MT call

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01 00

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

DED TI \/·	0.4	00	04	0.5	00	0.2	00	0.2	0.1	0.0	04	00
BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

# **EVENT DOWNLOAD - MT CALL 1.1.1**

Logically:

Event list: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Coding:

BER-TLV:	D6	0A	19	01	00	82	02	83	81	1C	01	00
D		0, 1		<b>.</b>		<u> </u>		00			· ·	- 00

#### **EVENT DOWNLOAD - MT CALL 1.1.2**

Logically:

Event list: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Address:

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Coding:

BER-TLV:	D6	0F	19	01	00	82	02	83	81	1C	01	00
	86	03	90	89	67							

# **EVENT DOWNLOAD - MT CALL 1.1.3**

Logically:

Event list: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Address:

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Called party subaddress

Type of subaddress: NSAP (X.213 / ISO 8348 AD2) Odd / even indicator: even number of address signals

Subaddress information: AFI, 95, 95, 95, 95, 95

Coding:

BER-TLV:	D6	18	19	01	00	82	02	83	81	1C	01	00
	86	03	91	89	67	88	07	80	50	95	95	95
	95	95										

# 27.22.7.1.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

# 27.22.7.2 Call Connected Event

# 27.22.7.2.1 Call Connected Event (MT and MO call)

# 27.22.7.2.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.2.1.2 Conformance requirement

The ME shall support the EVENT: Call Connected event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.2 and clause 12.25.

# 27.22.7.2.1.3 Test purpose

To verify that the ME informs the SIM the an Event: Call Connected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Connected) command.

### 27.22.7.2.1.4 Method of test

# 27.22.7.2.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

# 27.22.7.2.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD -CALL CONNECTED)**

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1	[EVENT: Call Connected active]
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1	
5	$SS \to ME$	SETUP	[MT Call] Ti = 0
6	$\begin{array}{c} USER \to \\ ME \end{array}$	Accept Call Set Up	
7		CONNECT	
8	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD - Call Connected 1.1.1	
9	$SS \rightarrow ME$	DISCONNECT	
10	$\begin{array}{c} USER \to \\ ME \end{array}$	Initiate Call to "123"	
11	$ME \rightarrow SS$	SETUP	[MO Call] Ti = 0
12		CONNECT	
13	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD	
		- Call Connected 1.1.1	
14	$\begin{array}{c} USER \to \\ ME \end{array}$	End Call	
15	$ME \rightarrow SS$	DISCONNECT	

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	01										

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00
D = 1 \ 1 = \ 1 .	<b>.</b>	00	<b>.</b>	00	00	_ <del>_</del>	~ <u> </u>	- C	, o.		, o.	

#### **EVENT DOWNLOAD - CALL CONNECTED 1.1.1**

Logically:

Event list: Call connected

Device identities

Source device: ME
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

Coding:

BER-TL	V: D6	6 0A	19	01	01	82	02	82	81	1C	01	80	
--------	-------	------	----	----	----	----	----	----	----	----	----	----	--

# **EVENT DOWNLOAD - CALL CONNECTED 1.1.2**

Logically:

Event list: Call connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 1 (bit 8)

Coding:

BER-TLV:	D6	0A	10	Ω1	01	82	02	83	Ω1	10	Ω1	80
DENTILV.	טט ו	UA	19	UI	01	02	UZ	03	01	10	UI	00

# 27.22.7.2.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

# 27.22.7.2.2 Call Connected Event (ME supporting SET UP CALL)

27.22.7.2.2.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.2.2.2 Conformance requirement

Additionally the ME shall support the SET UP CALL Proactive SIM Command as defined in:

• 3GPP TS 11.14 [15] clause 11.2.2, clause 6.4.13 and clause 6.6.12.

# 27.22.7.2.2.3 Test purpose

To verify that the ME informs the SIM the an Event: Call Connected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Connected) command.

27.22.7.2.2.4 Method of test

27.22.7.2.2.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.2.4.2 Procedure

# **Expected Sequence 2.1 (EVENT DOWNLOAD -CALL CONNECTED, ME supporting SET UP CALL)**

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[EVENT: Call Connected active]
		EVENT LIST 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
5	0114 145	EVENT LIST 2.1.1	
5	SIM → ME	PROACTIVE COMMAND PENDING	
6	$ME \rightarrow SIM$		
7		PROACTIVE COMMAND: SET UP	ISAT Call
'	SIIVI -> IVIL	CALL 2.1.1	
8	ME		ME BEHAVIOUR: SET UP CALL
	$\rightarrow$ USER	during the user confirmation	
		phase.	
9	$USER \to$	Confirm call set up	
	ME		
10	$ME \rightarrow SS$	SETUP	Ti=0
11		CONNECT	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
		CALL 2.1.1	
13	$ME \rightarrow SIM$	ENVELOPE: CALL CONNECTED	
		2.1.1	

# PROACTIVE COMMAND: SET UP EVENT LIST 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	01										

# TERMINAL RESPONSE: SET UP EVENT LIST 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

# PROACTIVE COMMAND: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "+012340123456"

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding:

BER-TLV:	D0	21	81	03	01	10	00	82	02	81	83
	05	0D	2B	30	31	32	33	34	30	31	32
	33	34	35	36	86	07	91	10	32	04	21
	43	65									

# TERMINAL RESPONSE: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BEF	R-TLV:	81	03	01	10	00	82	02	82	81	83	01	00
-----	--------	----	----	----	----	----	----	----	----	----	----	----	----

# **EVENT DOWNLOAD - CALL CONNECTED 2.1.1**

Logically:

Event list: Call connected

Device identities

Source device: Network

Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 1 (bit 8)

Coding:

BER-TLV:	D6	0A	19	01	01	82	02	83	81	1C	01	80

# 27.22.7.2.2.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

# 27.22.7.3 Call Disconnected Event

#### 27.22.7.3.1 Call Disconnected Event

# 27.22.7.3.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.3.1.2 Conformance requirement

The ME shall support the EVENT: Call Disconnected event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.3 and clause 12.25.

# 27.22.7.3.1.3 Test purpose

To verify that the ME informs the SIM the an Event: Call Disconnected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Disconnected) command.

# 27.22.7.3.1.4 Method of test

#### 27.22.7.3.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

#### 27.22.7.3.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD -CALL DISCONNECTED)**

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING	
2	$ME \to SIM$		
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	[EVENT: Call Disconnected active]
		EVENT LIST 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
_	00 ME	EVENT LIST 1.1.1	Lincoming coll 1 Ti O
5	$SS \rightarrow ME$	SETUP	[ incoming call ] Ti=0
6		Accept Call Set Up	
7	$ME$ $SS \rightarrow ME$	DISCONNECT	[MT DISCONNECT]
8		ENVELOPE: CALL	[INT DISCONNECT]
0	IVIE→ SIIVI	DISCONNECTED 1.1.1	
9	$SS \rightarrow ME$	SETUP	[ incoming call ] Ti=0
10		Accept Call Set Up	[ mooning oan ] 11=0
	ME	/ isospi ca coi op	
11		RELEASE	[MT RELEASE]
12		ENVELOPE: CALL	,
		DISCONNECTED 1.1.1	
13	$SS \to ME$	SETUP	[ incoming call ] Ti=0
14	$USER \to$	Accept Call Set Up	
	ME		
15		RELEASE COMPLETE	[MT RELEASE COMPLETE]
16	$ME \rightarrow SIM$	ENVELOPE: CALL	
		DISCONNECTED 1.1.1	
17		SETUP	[ incoming call ] Ti=0
18	USER →	Accept Call Set Up	
40	ME	End Call	
19	USER →	End Call	
20	ME . CC	DISCONNECT	[MO DISCONNECT]
20		ENVELOPE: CALL	[INO DISCONNECT]
21	IVIE -> SIIVI	DISCONNECTED 1.1.2	
22	$SS \to ME$	SETUP	[ incoming call ] Ti=0
23		Accept Call Set Up	[ mooning odin ] ri=0
	ME		
24	SS → ME	DISCONNECT	[MT DISCONNECT + CAUSE: normal call
			clearing ]
25	$ME \rightarrow SIM$	ENVELOPE: CALL	
		DISCONNECTED 1.1.3	
26	$SS \to ME$	SETUP	Ti=0
27	$USER \to$	Accept Call Set Up	
	ME		
28	SS	TX POWER to XX	[RADIO LINK FAILURE]
29	$ME \rightarrow SIM$	ENVELOPE: CALL	
		DISCONNECTED 1.1.4A or 1.1.4B	

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

# Logically:

Command details

Command number: 1

SET UP EVENT LIST

Command type: Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Call Disconnected

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	02										

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

# **EVENT DOWNLOAD - CALL DISCONNECTED 1.1.1**

Logically:

Event list: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)

Cause:

Coding:

BER-TLV:	D6	0A	10	Ω1	02	82	02	83	Ω1	10	01	00
DER-ILV.	סט ו	UA	19	UI	02	02	02	၀၁	01		UI	00

# **EVENT DOWNLOAD - CALL DISCONNECTED 1.1.2**

Logically:

Event list: Call Disconnected

Device identities

Source device: ME Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 1 (bit 8)

Coding:

E	BER-TLV:	D6	0A	19	01	01	82	02	82	81	1C	01	80	
---	----------	----	----	----	----	----	----	----	----	----	----	----	----	--

# **EVENT DOWNLOAD - CALL DISCONNECTED 1.1.3**

Logically:

Event list: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7) Ti flag: 0 (bit 8)

Cause: normal call clearing

Coding:

BER-TLV:	D6	0E	19	01	01	82	02	83	81	1C	01	00
_	9A	02	60	90								

# **EVENT DOWNLOAD - CALL DISCONNECTED 1.1.4A**

Logically:

Event list: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 1 (bit 8)

Cause: radio link failure

Coding:

BER-TLV:	D6	0C	19	01	01	82	02	83	81	1C	01	80
	9A	00										

# **EVENT DOWNLOAD - CALL DISCONNECTED 1.1.4B**

Logically:

Event list: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value: 0 (bit 5-7)
Ti flag: 0 (bit 8)
Cause: radio link failure

Coding:

BER-TLV:	D6	0C	19	01	01	82	02	83	81	1C	01	00
·	9A	00										

# 27.22.7.3.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

# 27.22.7.4 Location Status Event

# 27.22.7.4.1 Location Status Event (normal)

# 27.22.7.4.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.4.1.2 Conformance requirement

The ME shall support the EVENT: Location Status event as defined in:

• 3GPP TS 11.14 [15] clause 11.4 and clause 6.4.16.

# 27.22.7.4.1.3 Test purpose

To verify that the ME informs the SIM that an Event: MM\_IDLE state has occurred using the ENVELOPE (EVENT DOWNLOAD - Location Status) command.

#### 27.22.7.4.1.4 Method of test

# 27.22.7.4.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

Two cells are defined. Cell 1 has location area code 1 and cell 2 has location area code 2.

MS is in service on Cell 1.

#### 27.22.7.4.4.2 Procedure

# **Expected Sequence 1.1(EVENT DOWNLOAD -LOCATION STATUS)**

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SET UP	
		EVENT LIST 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	
_		EVENT LIST 1.1.1	
5	SS	Cell 2 is switched on and cell 1 is	
		switched off	
6	ME	ME performs cell reselection to cell	
7	NAT 00	Leasting Undeting Degrees	
7	$ME \rightarrow SS$	Location Updating Request	
8		Location updating accept	
9	$ME \rightarrow SIM$		[NOTE: The inclusion of the location
		- Location Status 1.1.1	information is optional: (If location status
			indicates normal status)

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Location status

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	03										

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00	l
----------	----	----	----	----	----	----	----	----	----	----	----	----	---

# **EVENT DOWNLOAD - LOCATION STATUS 1.1.1**

Logically:

Event list: Location status

Device identities

Source device: ME Destination device: SIM

Location status: normal service

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Area Code (2) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV:	D6	13	19	01	02	82	02	82	81	1B	01	00
·	13	07	00	F1	10	00	02	00	01			

# 27.22.7.4.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

# 27.22.7.5 User Activity Event

# 27.22.7.5.1 User Activity Event (normal)

# 27.22.7.5.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.5.1.2 Conformance Requirement

The ME shall support the EVENT DOWNLOAD -USER ACTIVITY as defined in:

• 3GPP TS 11.14 [15] clause 5.2, clause 6.4.16, clause 6.8, clause 6.6.16, clause 6.11, clause 11, clause 11.5, clause 12.6 and clause 12.25.

# 27.22.7.5.1.3 Test purpose

To verify that the ME performed correctly the procedure of USER ACTIVITY EVENT.

#### 27.22.7.5.1.4 Method of Test

# 27.22.7.5.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

#### 27.22.7.5.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD -USER ACTIVITY)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[set up event list: event User Activity]
		PENDING: SET UP EVENT LIST	·
		1.1.1	
2	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET	[command performed successfully]
		UP EVENT LIST 1.1.1	
3	$USER \rightarrow ME$	press any key	
4	$ME \rightarrow SIM$	ENVELOPE EVENT	
		DOWNLOAD -USER ACTIVITY	
		1.1.1	
5	$USER \rightarrow ME$	press any key	check if no envelope Event Download-User
			activity sending to the SIM (this event is
			reported once)

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

# Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Event list User Activity

# Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	04										

#### TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: RFU

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

#### **EVENT DOWNLOAD -USER ACTIVITY 1.1.1**

Logically:

Event list User Activity

Device identities

Source device: ME Destination device: SIM

Coding:

BER-TLV: D6 07	19 01	04 82	02	82	81
----------------	-------	-------	----	----	----

# 27.22.7.5.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

# 27.22.7.6 Idle screen available event

27.22.7.6.1 Idle Screen Available (normal)

27.22.7.6.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.6.1.2 Conformance requirement

The ME shall support the EVENT: IDLE SCREEN AVAILABLE event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.1 and clause 12.25.

# 27.22.7.6.1.3 Test purpose

To verify that the ME informs the SIM the an Event: Idle Screen Available has occurred using the ENVELOPE (EVENT DOWNLOAD - IDLE SCREEN AVAILABLE) command.

27.22.7.6.1.4 Method of test

27.22.7.6.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.7.6.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD - IDLE SCREEN AVAILABLE)**

Step	Direction	MESSAGE / Action	Comments
1	$USER \to ME$	Select screen other than the ME	
2	$SIM \to ME$	idle screen PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.1.1	[set up event list: idle screen available]
3	$ME \to SIM$		[command performed successfully]
4	$USER \to ME$	Select ME idle screen	
5	$ME \to SIM$	ENVELOPE: IDLE SCREEN	
		AVAILABLE 1.1.1	
6	$USER \to ME$	Select ME idle screen	check if no envelope Event Download- idle screen sending to the SIM ( this event is reported once)

#### PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

# Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: idle screen available

# Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	05										

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

# Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00
D	<b>.</b>		<b>.</b>		00		V-	U_	<b>.</b>		<b>.</b>	

#### **EVENT DOWNLOAD - IDLE SCREEN AVAILABLE 1.1.1**

Logically:

Event list Idle screen available

Device identities

Source device: ME
Destination device: SIM

Coding:

BER-TLV:	D6	07	19	01	05	82	02	82	81

# 27.22.7.6.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

### 27.22.7.7 Card reader status event

# 27.22.7.7.1 Card Reader Status (normal)

# 27.22.7.7.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.7.1.2 Conformance requirement

The ME shall support the EVENT: Call Card Reader Status event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 4.9, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.7, clause 12.25, clause 12.33, annex G, annex H, clause 12.25 and clause 12.7.

# 27.22.7.7.1.3 Test purpose

To verify that the ME informs the SIM the an Event: Card Reader Status has changed using the ENVELOPE (EVENT DOWNLOAD - Card Reader Status) command.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

# 27.22.7.7.1.4 Method of test

#### 27.22.7.7.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

# 27.22.7.7.1.4.2 Procedure

# Expected Sequence 1.1 (EVENT DOWNLOAD, Card reader status, Card reader 1, card reader attached, no card inserted)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND 1.1.1	
		PENDING	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[EVENT: Card Reader Status]
4	$ME \rightarrow SIM$	EVENT LIST 1.1.1 TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1	[Successfully]
5	$User \to ME$	Insert a card in Reader	
6	$ME \rightarrow SIM$	ENVELOPE: CARD READER	
		STATUS 1.1.1a	
7 8		or ENVELOPE: CARD READER STATUS 1.1.1b Or ENVELOPE: CARD READER STATUS 1.1.1c Or ENVELOPE: CARD READER STATUS 1.1.1d Remove the card from Reader ENVELOPE: CARD READER STATUS 1.1.2a Or ENVELOPE: CARD READER STATUS 1.1.2b Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2d	

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Card Reader Status

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82
	99	01	06								

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

# ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 79

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 59

**ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1c** 

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV:	D6	0A	99	Λ1	06	82	02	82	81	A0	01	71
DLIX-ILV.	00	$\cup \cap$	99	Οī	00	02	02	02	01	$\Delta U$	Οī	/ 1

#### ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1d

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: Yes
Card powered: No

Coding:

# ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

E	BER-TLV:	D6	0A	99	01	06	82	02	82	81	A0	01	39	
---	----------	----	----	----	----	----	----	----	----	----	----	----	----	--

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV:	D6	0A	99	01	06	82	02	82	81	A0	01	19
DLIX-ILV.	00	UA	33	O I	00	02	02	02	01	70	O I	13

# ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2c

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV:	D6	0A	99	01	06	82	02	82	81	Α0	01	31

# ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2d

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-T	_V:	D6	0A	99	01	06	82	02	82	81	Α0	01	11	
-------	-----	----	----	----	----	----	----	----	----	----	----	----	----	--

# 27.22.7.7.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

# 27.22.7.7.2 Card Reader Status(detachable card reader)

# 27.22.7.7.2.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.7.2.2 Conformance requirement

The ME shall support the EVENT: Call Card Reader Status event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 4.9, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.7, clause 12.25, clause 12.33, annex G, annex H, clause 12.25 and clause 12.7.

# 27.22.7.7.2.3 Test purpose

To verify that the ME informs the SIM the an Event: Card Reader Status has changed using the ENVELOPE (EVENT DOWNLOAD - Card Reader Status) command.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen as an example.

#### 27.22.7.7.2.4 Method of test

# 27.22.7.7.2.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

# 27.22.7.7.2.4.2 Procedure

# Expected Sequence 2.1 (EVENT DOWNLOAD, Detachable reader, Card reader 1, detachable card reader not attached, no card inserted)

Step	Direction	Message / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		1.1.1PENDING	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[SET UP EVENT: Card Reader Status]
		EVENT LIST 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Successfully]
		EVENT LIST 1.1.1	
5	User $\rightarrow$ ME	Attach the Card Reader to ME	
6	$ME \rightarrow SIM$	ENVELOPE: CARD READER	
		STATUS 2.1.1a	
		Or	
		ENVELOPE: CARD READER	
		STATUS 2.1.1b	
7		Detach the Card Reader from ME	
8	$ME \rightarrow SIM$	ENVELOPE: CARD READER	
		STATUS 2.1.2a	
		Or	
		ENVELOPE: CARD READER	
		STATUS 2.1.2b	

#### **ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.1a**

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 39

# ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.1b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 19

# ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.2a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV:	D6	0A	99	01	06	82	02	82	81	A0	01	29

#### ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.2b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV:	D6	0A	99	01	06	82	02	82	81	A0	01	09
DEIX IEV.		0, 1	00	0.	00	02	02	02	0.	, , ,	0.	00

# 27.22.7.7.1.5 Test requirement

The behaviour of the test is as defined in 'Expected Sequence 2.1'.

# 27.22.7.8 Language selection event

# 27.22.7.8.1 Language selection event (normal)

# 27.22.7.8.1.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.8.1.2 Conformance requirement

The ME shall support the EVENT: LANGUAGE SELECTION event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.8 and clause 12.25.

# 27.22.7.8.1.3 Test purpose

To verify that the ME informs the SIM the an Event: Language selection has occurred using the ENVELOPE (EVENT DOWNLOAD - LANGUAGE SELECTION ) command.

# 27.22.7.8.1.4 Method of test

#### 27.22.7.8.1.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The current language shall have been set to English. Another language has to be supported, German is an example.

# 27.22.7.8.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD - LANGUAGE SELECTION)**

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[set up event list: language selection]
		PENDING: SET UP EVENT LIST	
		1.1.1	
2	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[command performed successfully]
		EVENT LIST 1.1.1	
3	$USER \to ME$	Change the language to German.	
4	$ME \rightarrow SIM$	ENVELOPE: LANGUAGE	
		SELECTION 1.1.1	
5	$USER \to ME$	Change the language to English	
6	$ME \rightarrow SIM$	ENVELOPE: LANGUAGE	check if an envelope Event Download-
		SELECTION 1.1.2	language selection is sending again to the
			SIM (this event is continuously reported)

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: language selection

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82	99
	01	07										

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

# **EVENT DOWNLOAD - LANGUAGE SELECTION 1.1.1**

Logically:

Event list Language selection

Device identities

Source device: ME
Destination device: SIM

Language

Language 'de'→64 65 (German)

Coding:

BER-TLV:	D6	0B	19	01	07	82	02	82	81	2D	02	64
	65											

# **EVENT DOWNLOAD - LANGUAGE SELECTION 1.1.2**

Logically:

Event list Language selection

Device identities

Source device: ME
Destination device: SIM

Language

Language 'en'→65 6E (English)

Coding:

BER-TLV:	D6	0B	19	01	07	82	02	82	81	2D	02	65
	6E											

# 27.22.7.8.1.5 Test requirement

The ME shall operate in the manner defined in expected sequence 1.1.

# 27.22.7.9 Browser termination event

# 27.22.7.9.1 Browser termination (normal)

# 27.22.7.9.1.1 Definition and applicability

This test is only applicable to ME's that support the EVENT: browser termination event driven information.

# 27.22.7.9.1.2 Conformance requirement

The ME shall support the EVENT: Browser termination event as defined in:

• 3GPP TS 11.14 [15] clause 4.7, clause 5.2, clause 6.4.16, clause 6.8, clause 11, clause 11.9, clause 12.25, clause 12.51, annex G and clause 12.7.

# 27.22.7.9.1.3 Test purpose

To verify that the ME informs the SIM of an Event: Browser termination using the ENVELOPE (EVENT DOWNLOAD - Browser Termination) command.

This test applies for MEs which have a browser.

#### 27.22.7.9.1.4 Method of test

#### 27.22.7.9.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

# 27.22.7.9.1.4.2 Procedure

# **Expected Sequence 1.1 (EVENT DOWNLOAD - Browser termination)**

Step	Direction	Message / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	
		EVENT LIST 1.1.1 PENDING	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP	[EVENT: Browser termination Status]
		EVENT LIST 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[Successfully]
		EVENT LIST 1.1.1	
5	User→ME	Launch the browser, go to an	
		URL, then stop the session and	
		the browser.	
6	$ME \rightarrow SIM$	ENVELOPE: BROWSER	
		TERMINATION 1.1.1	

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Browser termination

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82
·	99	01	80								

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

# **ENVELOPE: EVENT DOWNLOAD BROWSER TERMINATION 1.1.1**

Logically:

Event list

Event 1: Browser termination

Device identities

Source device: ME
Destination device: SIM

Browser termination cause: User termination

Coding:

BER-TLV:	D6	0A	99	01	08	82	02	82	81	B4	01	00

# 27.22.7.10 Data available event

# 27.22.7.10.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.10.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

Additionally the ME shall support ENVELOPE (EVENT DOWNLOAD - Data available).

# 27.22.7.10.3 Test purpose

To verify that the ME shall send an ENVELOPE (EVENT DOWNLOAD - Data available) to the SIM after the ME receives a packet of data from the server by the BIP channel previously opened.

#### 27.22.7.10.4 Method of test

#### 27.22.7.10.4.1 Initial conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure. The SIM must have sent the SET UP EVENT LIST to the ME to supply a set of events (event Data available).

#### 27.22.7.10.4.2 Procedure

#### Expected sequence 1.1 (EVENT DOWNLOAD - Data available)

For that test, it is assumed that an OPEN CHANNEL proactive command has been successfully executed (with a consistent SIM buffer size).

Step	Direction	MESSAGE / Action	Comments
1	$SERVER \to ME$	Data sent through the BIP channel	
2	$ME \to SIM$	ENVELOPE 1.1.1 (Event-Data	
		Available)	

# ENVELOPE: EVENT DOWNLOAD - Data available 1.1.1

Logically:

Event list

Event: Data available

Device identities

Source device: ME
Destination device: SIM

Channel status

Channel status: Channel 1 open, link established

Channel Data Length

Channel data length: 8 Bytes available in Rx buffer

Coding:

BER-TLV:	D6	0E	99	01	09	82	02	82	81	B8	02	81
	00	B7	01	80								

#### 27.22.7.11 Channel Status event

# 27.22.7.11.1 Definition and applicability

See clause 3.2.2.

# 27.22.7.11.2 Conformance requirements

The ME shall support the class "e" commands as defined in:

• 3GPP TS 11.14 [15].

Additionally the ME shall support ENVELOPE (EVENT DOWNLOAD - Channel Status).

# 27.22.7.11.3 Test purpose

To verify that the ME shall send an ENVELOPE (EVENT DOWNLOAD - Channel Status) to the SIM after the link dropped between the NETWORK and the ME.

#### 27.22.7.11.4 Method of test

# 27.22.7.11.4.1 Initial conditions

The ME is connected to the SIM Simulator and the System Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

#### 27.22.7.11.4.2 Procedure

#### Expected sequence 1.1 (EVENT DOWNLOAD - Channel Status on a link dropped)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING:	
		SET UP EVENT LIST 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$		[EVENT: channel status]
		EVENT LIST 1.1.1	
4	$ME \to SIM$		[command performed successfully]
		EVENT LIST 1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
_		OPEN CHANNEL 1.1.1	
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \to ME$	PROACTIVE COMMAND: OPEN	
		CHANNEL (immediate) 1.1.1	
8	$ME \to SS$	SETUP CALL	
9	$SS \to ME$	CONNECTED	
10	$ME \to SIM$	TERMINAL RESPONSE: OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
11	$NETWORK \to ME$	Link dropped	
12	$ME \to SIM$	ENVELOPE 1.1.1 (Event-Channel	
		Status)	

# PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Channel Status

Coding:

BER-TLV:	D0	0C	81	03	01	05	00	82	02	81	82
	99	01	0A								

# TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV:	81	03	01	05	00	82	02	82	81	83	01	00

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

#### Coding:

BER-TLV:	D0	1E	81	03	01	40	01	82	02	81	82	86
	09	91	11	22	33	44	55	66	77	F8	B5	04
	01	07	00	01	B9	02	00	2A				

# TERMINAL RESPONSE: OPEN CHANNEL 1.1.1

#### Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

# Coding:

BER-TLV:	81	03	01	40	01	82	02	82	81	83	01	00
	B8	02	81	01	B5	04	01	07	00	01	B9	02
	00	2A										

#### ENVELOPE: EVENT DOWNLOAD - Channel Status 1.1.1

Logically:

Event list

Event: Channel Status

Device identities

Source device: ME

Destination device: SIM

Channel status

Channel status: Channel 1, link dropped

Coding:

BER-TLV:	D6	0B	99	01	09	82	02	82	81	B8	02	01
	05											

Annex A (normative): Void

Annex B (informative): Void

Annex C (void): Void

# Annex D (normative): Details of Test-SIM (TestSIM)

The TestSIM shall be able to present the following data:

#### ANSWER TO RESET

#### Logically:

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

T1: 91
T2: 99
T3: 00
T4: 12
T5: C1
T6: 00

Coding:

BER-TLV:	3B	86	00	91	99	00	12	C1	00

- 1. For a successful outcome of the command "Select MasterFile" the TestSIM shall send SW1/SW2 "9F 1B".
- 2. For a successful outcome of the command "Get Response with Length 1B" on the MasterFile the TestSIM shall respond:

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File

Type of file: MF

RFU: 00 00 22 FF 01' Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz

Technology identification: 3V Technology SIM

CHV1: disabled DFs in current directory: 2

EFs in current directory: 8
Number of CHV and admin. Codes: 3
RFU byte 18: 00

CHV1 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV1 status:

False representations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialized

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialized

Unlock CHV2 status:

False representations remaining: 10
RFU-bits 7-5: 0000
Secret code: Initialized

RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Status Words

SW1 / SW2: Normal ending of command

#### Coding:

BER-TLV:	00	00	02	8D	3F	00	01	00	00	22	FF	01
	0E	9B	02	08	03	00	83	8A	83	8A	00	00
	83	00	FF	90	00							

1. For a successful outcome of the command "Select GSM" the TestSIM shall send SW1/SW2 "9F 1B".

2. For a successful outcome of the command "Select PLMN" the TestSIM shall send SW1/SW2 "9F 0F".

3. EF<sub>PLMN</sub> Information:

RFU-Bytes 1-2: 00 00 File size: 102 bytes File ID: 6F30

Type of File: Elementary file

Byte 8

RFU: 00

Access Condition:

UPDATE: CHV1
READ/SEEK: CHV1
RFU-bits 4-1: 1111
INCREASE: NEVER
INVALIDATE: NEVER
REHABILITATE: NEVER

File Status:

Invalidation status: File not invalidated

Readable/updateable: Not readable/updatable when invalidated

RFU-bits 8-4, 2: 0000 0
Length of following data: 2 bytes
Structure: Transparent

Length of record: 00

The initial coding of the  $EF_{PLMN}$  shall be FF FF ... FF (logically: Empty).

# Annex E (normative): Details of terminal profile support

**Table E.1: TERMINAL PROFILE support** 

Item	Terminal Profile	Ref.	Release	Status	Support	Mnemonic
1	Profile Download	3GPP TS 11.14, 5	R96	М		PD_Pro_Dvnl
2	SMS-PP data download	3GPP TS 11.14, 5	R96	C201		PD_SMS_PP
3	Cell Broadcast data	3GPP TS 11.14, 5	R96	C202		PD_CB
	download	·				
4	Menu selection	3GPP TS 11.14, 5	R96	М		PD_Menu_sel
5	'9EXX' response code for	3GPP TS 11.14, 5	R97	М		PD_9EXX
	SIM data download error					
6	Timer expiration	3GPP TS 11.14, 5	R98	М		PD_TExpir
7	USSD string data object	3GPP TS 11.14, 5	R98	М		PD_CC_USSD_Str
	supported in Call Control					
8	Envelope Call Control	3GPP TS 11.14, 5	R99	М		PD_CC_Auto_Redial
	always sent to the SIM					
	during automatic redial					
	mode					
9	Command result	3GPP TS 11.14, 5	R96	M		PD_Cmd_Res
10	Call Control by SIM	3GPP TS 11.14, 5	R96	M		PD_CC
11	Cell identity included in Call	3GPP TS 11.14, 5	R97	М		PD_CC_Cell_Id
40	Control by SIM	00DD T0 44 44 5	Doo			DD 140 0140 00
12	MO short message control	3GPP TS 11.14, 5	R98	М		PD_MO_SMS_CC
13	by SIM Handling of the alpha	3GPP TS 11.14, 5	R97	М		PD_Alpha _Id
13	identifier	3GFF 13 11.14, 5	K91	IVI		PD_Aipha _iu
14	UCS2 Entry supported	3GPP TS 11.14, 5	R97	C203		PD_UCS2_entry
15	UCS2 Display supported	3GPP TS 11.14, 5	R97	C203		PD_UCS2_Display
16	Display of the extension text		R98	C205		PD_Disp_Ext_Text
17	DISPLAY TEXT	3GPP TS 11.14, 5	R96	M		PD_Display_Text
18	GET INKEY	3GPP TS 11.14, 5	R96	M		PD_Get_Inkey
19	GET INPUT	3GPP TS 11.14, 5	R96	M		PD_Get_Input
20	MORE TIME	3GPP TS 11.14, 5	R96	M		PD_More_Time
21	PLAY TONE	3GPP TS 11.14, 5	R96	M		PD_Play_Tone
22	POLL INTERVAL	3GPP TS 11.14, 5	R96	M		PD_Poll_interval
23	POLLING OFF	3GPP TS 11.14, 5	R96	M		PD_Polling_Off
24	REFRESH	3GPP TS 11.14, 5	R96	M		PD_Refresh
25	SELECT ITEM	3GPP TS 11.14, 5	R96	M		PD_Select_Item
26	SEND SHORT MESSAGE	3GPP TS 11.14, 5	R96	M		PD_Send_SMS
27	SEND SS	3GPP TS 11.14, 5	R96	M		PD_Send_SS
28	SEND USSD	3GPP TS 11.14, 5	R98	M		PD_Send_USSD
29	SET UP CALL	3GPP TS 11.14, 5	R96	M		PD_SetUp_Call
30	SET UP MENU	3GPP TS 11.14, 5	R96	M		PD_SetUp_Menu
31	PROVIDE LOCAL	3GPP TS 11.14, 5	R96	M		PD_Provide_Local
•	INFORMATION (LOCI &					
	IMEI)					

Separation   Sep	Item	Terminal Profile	Ref.	Release	Status	Support	Mnemonic	
INFORMATION (NMR)   Supering						опроп		
33 SET UP EVENT LIST   30P TS 11.14, 5			.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
34   Event: MT call   3GPP TS 11.14, 5   R98   M   PD_Call_Conn	33		3GPP TS 11.14, 5	R98	М		PD Setup Evt List	
36   Event: Call connected   GSPP TS 11.1.1.4, 5   R98					М			
36   Event: Call disconnected   3GPP TS 11.14, 5   R98		Event: Call connected			М			
37   Event: Location status								
38   Event: User activity   SGPP TS 11.14, 5   R98								
39   Event: Idle screen available   3GPP TS 11.14, 5   R98					М			
40   Event: Card reader status   3GPP TS 11.14, 5   R99								
141   Event: Language selection   3GPP TS 11.14, 5   R99								
42   Event: Browser Termination   3GPP TS 11.14, 5   R99   C207   PD_Data_Avail     43   Event: Channel status   3GPP TS 11.14, 5   R99   C207   PD_Data_Avail     44   Event: Channel status   3GPP TS 11.14, 5   R99   C207   PD_Evt_Ch_Status     45   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_46     46   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_46     47   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_46     48   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_47     49   POWER ON CARD   3GPP TS 11.14, 5   R96   X   PD_RFU_48     49   POWER ON CARD   3GPP TS 11.14, 5   R98   C206   PD_C On     50   POWER OF CARD   3GPP TS 11.14, 5   R98   C206   PD_C Of     51   PERFORM CARD APDU   3GPP TS 11.14, 5   R98   C206   PD_C Of     52   GET READER STATUS   (Card reader identifier)     53   GET READER STATUS   (Card reader identifier)   3GPP TS 11.14, 5   R98   C206   PD_Get_Rdr_Status     54   RFU   3GPP TS 11.14, 5   R98   C206   PD_RET_U_56     55   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_56     56   RFU   3GPP TS 11.14, 5   R98   M   PD_RFU_56     57   TIMER MANAGEMENT   3GPP TS 11.14, 5   R98   M   PD_Timer_Val     58   TIMER MANAGEMENT   3GPP TS 11.14, 5   R98   M   PD_Timer_Val     59   PROVIDE LOCAL   3GPP TS 11.14, 5   R98   M   PD_Timer_Val     60   Sinary choice in GET   3GPP TS 11.14, 5   R98   M   PD_Evolde_Local_D_Time     61   SET UP IDLE MODE TEXT   3GPP TS 11.14, 5   R98   M   PD_SetUp_LolMod_T     62   RUN AT COMMAND (i.e.   3GPP TS 11.14, 5   R98   M   PD_SetUp_LolMod_T     63   2nd alpha identifier in SET   UP CALL   SEC_Alpha_Id     64   2nd capability configuration   3GPP TS 11.14, 5   R98   M   PD_SetUp_LolMod_T     65   Sustained Display arameter   Sustained_Display TS 11.14, 5   R99   M   PD_Provide_Local_T     64	41							
44   Event: Data available   3GPP TS 11.14, 5   R99   C207   PD_Data_Avail     44   Event: Channel status   3GPP TS 11.14, 5   R99   C207   PD_EVt_Ch_Status     55   RPU   3GPP TS 11.14, 5   R96   X   PD_RPU_46     46   RPU   3GPP TS 11.14, 5   R96   X   PD_RPU_46     47   RPU   3GPP TS 11.14, 5   R96   X   PD_RPU_47     48   RPU   3GPP TS 11.14, 5   R96   X   PD_RPU_47     49   POWER ON CARD   3GPP TS 11.14, 5   R96   X   PD_RPU_48     49   POWER ON CARD   3GPP TS 11.14, 5   R98   C206   PD_C_On     51   PERFORM CARD APDU   3GPP TS 11.14, 5   R98   C206   PD_C_Off     52   GET READER STATUS   GPP TS 11.14, 5   R98   C206   PD_C_APDU     52   GET READER STATUS   3GPP TS 11.14, 5   R98   C206   PD_G_ER_dr_Status     53   GET READER STATUS   3GPP TS 11.14, 5   R98   C206   PD_G_ER_dr_Status     54   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_54     55   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_55     56   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_55     57   TIMER MANAGEMENT   3GPP TS 11.14, 5   R96   X   PD_RFU_55     58   TIMER MANAGEMENT   3GPP TS 11.14, 5   R98   M   PD_TIMER_MSTATUS     59   PROVIDE LOCAL   INFORMATION (date, time and time zone)     60   Binary choice in GET   3GPP TS 11.14, 5   R98   M   PD_Finer_Val     61   SET UP IDLE MODE TEXT   3GPP TS 11.14, 5   R98   M   PD_Bin_Get_Inkey     62   RUN AT COMMAND (i.e. class "b" is supported")   C200   PD_CADEL_DCAL     64   2nd capability configuration   2GPP TS 11.14, 5   R98   M   PD_Setup_Call_Sec_Alpha_Id     65   SEND DTMF command   3GPP TS 11.14, 5   R98   M   PD_Setup_Call_Sec_Alpha_Id     66   SEND DTMF command   3GPP TS 11.14, 5   R98   M   PD_Provide_Local_DTAT     67   PROVIDE LOCAL   SGPP TS 11.14, 5   R98   M   PD_Provide_Local_DTAT     68   SEND DTMF command   3GPP TS 11.14, 5   R98   M   PD_Provide_Local_DTAT     69   PROVIDE LOCAL   SGPP TS 11.14, 5   R98   M   PD_Provide_Local_DTAT     60   SEND DTMF command   3GPP TS 11.14, 5   R98   M   PD_Provide_Local_DTAT     61   SEND DTMF command   3GPP TS 11.14, 5   R99   M   PD_Provide_Loca								
445   Event: Channel status   3GPP TS 11.14, 5   R99   C207   PD_Evt_Ch_Status     45   RFU								
45   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_46	44		-					
46         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_46           47         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_47           48         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_48           49         POWER ON CARD         3GPP TS 11.14, 5         R98         C206         PD_C_On           50         POWER OFF CARD         3GPP TS 11.14, 5         R98         C206         PD_C_Off           51         PERFORM CARD APDU         3GPP TS 11.14, 5         R98         C206         PD_C_C_APDU           52         GET READER STATUS         (Card reader identifier)         3GPP TS 11.14, 5         R98         C208         PD_GEt_Rdr_Status           54         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_54           55         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_55           56         RFU         3GPP TS 11.14, 5         R98         M         PD_TIME_MS_5           57         TIMER MANAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val           59         PROVIDE LOCAL (stature)         3GPP TS 11.14, 5         R98								
AFFU								
AB   RFU								
49   POWER ON CARD   3GPP TS 11.14, 5   R98   C.206   P.D. C. On								
DOUBRE OFF CARD   3GPP TS 11.14, 5   R98   C.206   P.D. C. Off		POWER ON CARD						
Detection   Dete								
52         GET READER STATUS (Card reader status)         3GPP TS 11.14, 5         R98         C206         PD_Get_Rdr_Status (Card reader status)           53         GET READER STATUS (Card reader identifier)         3GPP TS 11.14, 5         R99         C208         PD_Get_Rdr_Id           54         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_54           55         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           56         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           57         TIMER MANAGEMENT (SECTION (SECTION STATE) (SE								
Card reader status    Siger READER STATUS   GET READER STATUS								
SET READER STATUS   GEPT READER STATUS   GAPP TS 11.14, 5   R99   C208   PD_Get_Rdr_Id	0_				5255		2_001_1101_010100	
Card reader identifier)	53		3GPP TS 11.14, 5	R99	C208		PD_Get_Rdr_Id	
54         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_54           55         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           56         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           57         TIMER MANAGEMENT (start, stop)         3GPP TS 11.14, 5         R98         M         PD_Timer_Mgt_Start (start, stop)           58         TIMER MANAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val           59         PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_D-Time           60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Run_AT           62         RUN AT COMMAND (i.e. class 'b' is supported)         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_lad           63         2nd alpha identifier in SET         3GPP TS 11.14, 5         R98         M			, , ,					
55         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           56         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           57         TIMER MANAGEMENT (start, stop)         3GPP TS 11.14, 5         R98         M         PD_Timer_Mgt_Start Stop           58         TIMER MANAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val           59         PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_D.Time           60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           42         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         SEND DTMF command         3GPP TS 11.14	54		3GPP TS 11.14, 5	R96	Х		PD_RFU_54	
56         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_56           57         TIMER MANAGEMENT (start, stop)         3GPP TS 11.14, 5         R98         M         PD_Timer_Mgt_Start stop           58         TIMER MANAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val           59         PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_D_Time           60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61         SET UP IDLE MODE TEXT SGPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           66         SEND DTMF command         3	55							
57         TIMER MANAGEMENT (start, stop)         3GPP TS 11.14, 5         R98         M         PD_Timer_Mgt_Start _Stop           58         TIMER MANAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val _Stop           59         PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_ D_Time           60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T _xt           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T _xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T _xt           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m_2 m_2           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         M         PD_Sustained_Displ_Tx           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF	56	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_56	
(start, stop)         Stop           58 TIMER MANAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val           59 PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_D_Time           60 Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61 SET UP IDLE MODE TEXT (INKEY)         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62 RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           63 2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64 2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para mm and           65 Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           66 SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67 PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_E CCH_List           68 PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99 <td>57</td> <td>TIMER MANAGEMENT</td> <td></td> <td>R98</td> <td>М</td> <td></td> <td></td>	57	TIMER MANAGEMENT		R98	М			
58         TIMER MÁNAGEMENT (get current value)         3GPP TS 11.14, 5         R98         M         PD_Timer_Val (get current value)           59         PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_D_Time           60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         M         PD_Run_AT           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Posend_DTMF           67         PROVIDE LOCAL INFORMATION (Ining Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           69			,					
59         PROVIDE LOCAL INFORMATION (date, time and time zone)         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_D_Time           60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         C209         PD_Run_AT           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         C211         PD_Sustained_Displ_Txt           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_L CH_List           68         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A A A PD_Lang_Notif <tr< td=""><td>58</td><td></td><td>3GPP TS 11.14, 5</td><td>R98</td><td>М</td><td></td><td>PD_Timer_Val</td></tr<>	58		3GPP TS 11.14, 5	R98	М		PD_Timer_Val	
INFORMATION (date, time and time zone)		(get current value)						
and time zone   Binary choice in GET   3GPP TS 11.14, 5   R98   M   PD_Bin_Get_Inkey	59		3GPP TS 11.14, 5	R98	М		PD_Provide_Local_	
60         Binary choice in GET INKEY         3GPP TS 11.14, 5         R98         M         PD_Bin_Get_Inkey           61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         C209         PD_Run_AT           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         C211         PD_Sustained_Displ_Txt           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (Ianguage)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LANGLAGE							D_Time	
INKEY								
61         SET UP IDLE MODE TEXT         3GPP TS 11.14, 5         R98         M         PD_Stup_Id_Mod_T xt           62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         C209         PD_Run_AT           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         C211         PD_Sustained_Displ_Txt           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L SCH_A Advance)           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Launch_Brws           72         RFU	60		3GPP TS 11.14, 5	R98	M		PD_Bin_Get_Inkey	
Xt								
62         RUN AT COMMAND (i.e. class "b" is supported)         3GPP TS 11.14, 5         R98         C209         PD_Run_AT           63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT	61	SET UP IDLE MODE TEXT	3GPP TS 11.14, 5	R98	M		•	
class "b" is supported)         3         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para mD_Cap_Conf_Para mD_Cap_Conf_Para mD_Cap_Conf_Para mD_Cap_Cap_Conf_Para mD_Cap_Cap_Conf_Para mD_Cap_Cap_Cap_Cap_Cap_Cap_Cap_Cap_Cap_Cap								
63         2nd alpha identifier in SET UP CALL         3GPP TS 11.14, 5         R98         M         PD_SetUp_Call_Sec_Alpha_Id           64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         C211         PD_Sustained_Displ_Txt           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L SCH_LOCAL_LIST           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T ACH_LOCAL_LIST           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support fo	62		3GPP TS 11.14, 5	R98	C209		PD_Run_AT	
UP CALL			0000 70 44 44 5	D00			DD 0 (II 0 II 0	
64         2nd capability configuration parameter         3GPP TS 11.14, 5         R98         C210         PD_Cap_Conf_Para m           65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         C211         PD_Sustained_Displ_Txt           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L S           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu	63		3GPP 15 11.14, 5	K98	M			
parameter	0.4		2CDD TO 44.44.5	DOC	0040			
65         Sustained DISPLAY TEXT         3GPP TS 11.14, 5         R98         C211         PD_Sustained_Displ_Txt           66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L SCH_A PD_Provide_Local_T ALL_A PD_PROVIDE_LOCAL_TALL_A PD_PROVIDE_LOCAL_A PD_PROV	64		36PP 15 11.14, 5	Kag	C210		· ·	
	65		2CDD TQ 11 14 F	DOO	C211			
66         SEND DTMF command         3GPP TS 11.14, 5         R98         M         PD_Send_DTMF           67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L S           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu	ဝ၁	Sustained DISPLAY TEXT	JOSEF 10 11.14, 5	Kaa	0211			
67         PROVIDE LOCAL INFORMATION - BCCH         3GPP TS 11.14, 5         R98         M         PD_Provide_Local_B CCH_List           68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L S           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu	66	SEND DIME command	3CDD TC 11 11 F	DU6	N/I		_	
INFORMATION - BCCH	_							
68         PROVIDE LOCAL INFORMATION (language)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_L S           69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu	07		10   11.14, 5	1790	IVI			
INFORMATION (language)   S   S	68		3GPP TS 11 14 5	Raa	М			
69         PROVIDE LOCAL INFORMATION (Timing Advance)         3GPP TS 11.14, 5         R99         M         PD_Provide_Local_T A           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu	30			1133	141			
INFORMATION (Timing Advance)	69		3GPP TS 11 14 5	R99	М			
Advance)         Advance           70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu								
70         LANGUAGE NOTIFICATION         3GPP TS 11.14, 5         R99         M         PD_Lang_Notif           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu								
NOTIFICATION         Substitution         C212         PD_Launch_Brws           71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp_Menu	70		3GPP TS 11.14, 5	R99	М		PD_Lang_Notif	
71         LAUNCH BROWSER         3GPP TS 11.14, 5         R99         C212         PD_Launch_Brws           72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp Menu			, , ,				_ 5	
72         RFU         3GPP TS 11.14, 5         R96         X         PD_RFU_72           73         Soft keys support for SELECT ITEM         3GPP TS 11.14, 5         R99         C213         PD_Softkey_Select_I tem           74         Soft Keys support for SET UP MENU         3GPP TS 11.14, 5         R99         C213         PD_Softkey_SetUp _Menu	71		3GPP TS 11.14, 5	R99	C212		PD_Launch_Brws	
73 Soft keys support for SELECT ITEM  74 Soft Keys support for SET UP MENU  3GPP TS 11.14, 5 R99 C213 PD_Softkey_Select_I tem  R99 C213 PD_Softkey_SetUp Menu								
SELECT ITEM tem  74 Soft Keys support for SET 3GPP TS 11.14, 5 R99 C213 PD_Softkey_SetUp _Menu								
74 Soft Keys support for SET 3GPP TS 11.14, 5 R99 C213 PD_Softkey_SetUp _Menu			, , ,				•	
UP MENUMenu	74		3GPP TS 11.14, 5	R99	C213		PD_Softkey_SetUp	
75   RFU   3GPP TS 11.14, 5   R96   X   PD_RFU_75								
	75	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_75	

Item				Support			
76	RFU	3GPP TS 11.14, 5 R96 X			PD_RFU_76		
77	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_77	
78	RFU	3GPP TS 11.14, 5	R96	Χ		PD_RFU_78	
79	RFU	3GPP TS 11.14, 5	R96	Χ		PD_RFU_79	
80	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_80	
81	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
82	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
83	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
84	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
85	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
86	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
87	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C214		PD_Max_SoftKey	
88	Maximum number of soft keys available ('FF' = RFU)	3GPP TS 11.14, 5	R99	C124		PD_Max_SoftKey	
89	OPEN CHANNEL	3GPP TS 11.14, 5	R99	C207		PD_Open_Ch	
90	CLOSE CHANNEL	3GPP TS 11.14, 5	R99	C207		PD_Close_Ch	
91	RECEIVE DATA	3GPP TS 11.14, 5	R99	C207		PD_Rx_Data	
92	SEND DATA	3GPP TS 11.14, 5	R99	C207		PD_Send_Data	
93	GET CHANNEL STATUS	3GPP TS 11.14, 5	R99	C207		PD_Get_Ch_Status	
94	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_94	
95	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_95	
96	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_96	
97	CSD supported by ME	3GPP TS 11.14, 5	R99	C207		PD_CSD	
98	GPRS supported by ME	3GPP TS 11.14, 5	R99	C215		PD_GPRS	
99	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_99	
100	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_100	
101	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_101	
102	Number of channels supported by ME	3GPP TS 11.14, 5	R99	C207		PD_Nb_Channel	
103	Number of channels supported by ME	3GPP TS 11.14, 5	R99	C207		PD_Nb_Channel	
104	Number of channels supported by ME	3GPP TS 11.14, 5	R99	C207		PD_Nb_Channel	
105	Number of characters supported down the ME	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char	
106	Number of characters supported down the ME	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char	
107	Number of characters supported down the ME	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char	
108	Number of characters supported down the ME	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char	
109	Number of characters supported down the ME	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char	
110	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_110	
111	RFU	3GPP TS 11.14, 5		R96 X		PD_RFU_111	
112	Screen Sizing Parameters	3GPP TS 11.14, 5	R99	C216		PD_Screen_Siz	
113	Number of characters supported across the ME display	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp	
114	Number of characters supported across the ME display	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp	
115	Number of characters supported across the ME display	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp	

Item	Terminal Profile	Ref.	Release	Status	Support	Mnemonic
116	Number of characters	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp
	supported across the ME					
	display					
117	Number of characters	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp
	supported across the ME					
440	display  Number of characters	2CDD TC 44 44 5	DOO	0047		DD NIb Char Dian
118	supported across the ME	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp
	display					
119	Number of characters	3GPP TS 11.14, 5	R99	C217		PD_Nb_Char_Disp
110	supported across the ME		1100	0211		1 D_110_01101_D10p
	display					
120	Variable size fonts	3GPP TS 11.14, 5	R99	C217		PD_Var_Font
	Supported					
121	Display can be resized	3GPP TS 11.14, 5	R99	C218		PD_Disp_Resiz
122	Text Wrapping supported	3GPP TS 11.14, 5	R99	C218		PD_Txt_Wrap
123	Text Scrolling supported	3GPP TS 11.14, 5	R99	C218		PD_Txt_Scroll
124	RFU	3GPP TS 11.14, 5	R96	Χ		PD_RFU_124
125	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_125
126	Width reduction when in a	3GPP TS 11.14, 5	R99	C217		PD_Width_Reduc
	menu					
127	Width reduction when in a	3GPP TS 11.14, 5	R99	C217		PD_Width_Reduc
	menu					
128	Width reduction when in a	3GPP TS 11.14, 5	R99	C217		PD_Width_Reduc
400	menu	00DD T0 44 44 5	Doo	0000		DD TOD
129	TCP	3GPP TS 11.14, 5	R99	C220		PD_TCP
130	UDP RFU	3GPP TS 11.14, 5	R99	C221		PD_UDP
131 132	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_131
133	RFU	3GPP TS 11.14, 5 3GPP TS 11.14, 5	R96 R96	X		PD_RFU_132 PD_RFU_133
134	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_134
135	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_135
136	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_136
137	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_137
138	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_138
139	RFU	3GPP TS 11.14, 5	R96	X		PD RFU 139
140	RFU	3GPP TS 11.14, 5	R96	X		PD RFU 140
141	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_141
142	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_142
	RFU	3GPP TS 11.14, 5	R96	X		PD RFU 143
	RFU	3GPP TS 11.14, 5	R96	X		PD RFU 144
	Protocol Version	3GPP TS 11.14, 5	R99	TBD		· = •
146	Protocol Version	3GPP TS 11.14, 5	R99	TBD		
147	Protocol Version	3GPP TS 11.14, 5	R99	TBD		
148	Protocol Version	3GPP TS 11.14, 5	R99	TBD		
149	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_149
150	RFU	3GPP TS 11.14, 5	R96	X		PD_RFU_150
151	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_151
152	RFU	3GPP TS 11.14, 5	R96	Х		PD_RFU_152
C201	IF E.1/3 THEN O		•		D_CB	•
C202	IF E.1/2 THEN O I				_ SMS_PP	

C205	Item	Terminal Profile	Ref.	Release	Status	Support	Mnemonic
C205	C203	IF A.1/3 THEN M			O_	Ucs2_Entry	/
C206	C204	IF A.1/14 THEN M			O_	_Ucs2_Disp	
C207	C205	IF A.1/4 THEN M			O_	_Ext_Str	
C208	C206	IF A.1/7 THEN M			O_	_Dual_Slot	
C209	C207	IF A.1/12 THEN M			O_	_BIP	
C210	C208	IF (A.1/7 AND A.1/8	3) THEN M		O_	_Dual_Slot A	AND O_Detach_Rdr
C211	C209	IF A.1/9 THEN M			O_	_Run_At	
C212	C210	IF A.1/1 THEN M			O_	_Cap_Conf	
C213	C211	IF A.1/2 THEN M			O_	_sust_text	
C214       IF C213 THEN bit values "0" / "1" allowed       O_Softkey (parameters)         C215       IF C207 AND A.1/16       O_BIP AND O_GPRS         C216       IF A.1/13 THEN M       O_Scr_Siz         C217       IF C217 THEN bit values "0" / "1" allowed       O_Scr_Siz (parameters)         C218       IF A.1/14 THEN M       O_Scr_Resiz         C219       IF C218 THEN bit values "0" / "1" allowed       O_Scr_Resiz (parameters)	C212	IF A.1/10 THEN M			O_	_LB	
C215	C213	IF A.1/11 THEN M			O_	_Softkey	
C216       IF A.1/13 THEN M       O_Scr_Siz         C217       IF C217 THEN bit values "0" / "1" allowed       O_Scr_Siz (parameters)         C218       IF A.1/14 THEN M       O_Scr_Resiz         C219       IF C218 THEN bit values "0" / "1" allowed       O_Scr_Resiz (parameters)	C214	IF C213 THEN bit v	alues "0" / "1" allow	ed	O_	_Softkey (pa	arameters)
C217 IF C217 THEN bit values "0" / "1" allowed O_Scr_Siz (parameters) C218 IF A.1/14 THEN M O_Scr_Resiz C219 IF C218 THEN bit values "0" / "1" allowed O_Scr_Resiz (parameters)	C215	IF C207 AND A.1/1	6		O_	BIP AND C	_GPRS
C218 IF A.1/14 THEN M O_Scr_Resiz C219 IF C218 THEN bit values "0" / "1" allowed O_Scr_Resiz (parameters)	C216	IF A.1/13 THEN M			O_	_Scr_Siz	
C219 IF C218 THEN bit values "0" / "1" allowed O_Scr_Resiz (parameters)	C217	IF C217 THEN bit v	alues "0" / "1" allow	ed	O_	_Scr_Siz (pa	arameters)
	C218	IF A.1/14 THEN M			O_	_Scr_Resiz	
C220 IF C207 AND A.1/18 O BIP AND O TCP	C219	IF C218 THEN bit v	alues "0" / "1" allow	ed	O_	_Scr_Resiz	(parameters)
,	C220	IF C207 AND A.1/1	8		O_	BIP AND C	_TCP
C221 IF C207 AND A.1/17 O_BIP AND O_UDP	C221	IF C207 AND A.1/1	7		O_	BIP AND C	_UDP

Comments:
This static requirement for the TERMINAL PROFILE is specifying the bit coding of this command. In the support column a "Yes" (or "Y" or "y") means bit coding "1" and a "No" (or "N" or "n") and "X" means bit coding "0" in the command.

# Annex F (informative): Change history

CR	REV	PHASE	VERS	SUBJECT	CAT	NEW_VERS
-		96	-	Approved as release 1996 at SMG#30	-	5.0.0
A001		96	5.0.0	Corrections to SIM Application Toolkit Test Specification	F	5.1.0
7.001		- 00	5.1.0	Version update to 5.1.1 for Publication	-	5.1.1
A002		96	5.1.0	Editorial and coding corrections		5.2.0
A003		96	5.2.0	Correction of wrong coding for SIM Application Toolkit test 27.22.4.2		5.3.0
A004		96	5.2.0	Corrections for Test Case 27.22.5.1 (SMS-PP Data Download)		5.3.0
A005		96	5.3.0	Correction of wrong coding for SIM Application Toolkit 27.22	F	5.4.0
A006		96	5.4.0	Corrections for Test Case 27.22.4.7 (REFRESH)	F	5.5.0
A007		96	5.4.0	Corrections for Test Case 27.22.5.2 (SMS-CB Data Download)	F	5.5.0
A008		99	5.5.0	Upgrade of the MS SAT test specification to Release 99	F	8.1.0
A010r1		99	8.1.0	Addition of Terminal Profile information, suppression of PLAY TONE	F	8.2.0
				Test sequence 1.2		
A011		99	8.2.0	References to 11.10-1 replaced. Reference to 11.10-2 removed.	F	8.3.0
A012		R99	8.3.0	Corrections to Send Short Message, Sequence 1.4	F	8.4.0
A013		R99	8.3.0	Redial in Set Up Call	F	8.4.0
A014		R99	8.3.0	Correction to Terminal Response: Set Up Call 1.7.1	F	8.4.0
A015		R99	8.3.0	Select Item: Support of "No response from user"	F	8.4.0
A016		R99	8.3.0	Correction of Emergency Call test cases	F	8.4.0
A017				Essential corrections to default values for SIM Application Toolkit		
1010		Doo	0.4.0	testing	_	0.5.0
A018	-	R99	8.4.0	Clarification on comprehension required flag usage	F	8.5.0
A019				Essential corrections to Display text test cases		
A020				Essential corrections to Get Inkey test cases		
A021	-	R99	8.4.0	Essential corrections to Get Input test cases	F	8.5.0
A022				Essential corrections to Set Up Menu test cases		
A023				Essential corrections to Play Tone test cases		
A024				Essential corrections to Poll Intervall test case		
A025	-	R99	8.4.0	Essential corrections to Polling off test case	F	8.5.0
A026	-	R99	8.4.0	Essential corrections to Provide Local Information test cases	F	8.5.0
A027	-	R99	8.4.0	Essential corrections to Send Short message test cases		8.5.0
A028	-	R99	8.4.0	Essential corrections to Language Notification test cases	F	8.5.0
A029				Essential corrections to Send SS test cases		
A030	-	R99	8.4.0	Essential corrections to Set Up Call test cases	F	8.5.0
A031				Essential corrections to Send USSD test cases		
A032	-	R99	8.4.0	Essential correction to Set Up Idle Mode Text test cases	F	8.5.0
A033				Essential corrections to Power Off Card test case		
A034				Essential corrections to Perform Card APDU test cases		
A035				Essential correction to Get Reader Status test cases		
A036				Essential corrections to Send DTMF test cases		
A037	-	R99	8.4.0	Essential corrections to CALL CONTROL BY SIM test cases	F	8.5.0
A038	-	R99	8.4.0	Essential corrections to CALL CONTROL BY SIM (Interaction with	F	8.5.0
				FDN/ BDN) test cases		
A039				Essential corrections to Select Item test cases		
A040				Essential corrections to card reader status event download test cases		
A041	-	R99	8.4.0	Essential corrections to language selection and browser termination	F	8.5.0
				event download test cases		
A042	-	R99	8.4.0	Essential corrections to Close Channel test cases	F	8.5.0
A043	-	R99	8.4.0	Essential corrections to Launch Browser test cases	F	8.5.0
A044				Essential corrections to Open Channel test cases		
A045				Essential corrections to Receive Data test cases		
A046				Essential corrections to Send Data test cases		
A047				Essential corrections to channel status event download test case		
A048				Essential corrections to Get Channel Status test cases		
A049				Essential corrections to CB data download test cases		
A050	-	R99	8.4.0	Essential corrections to location status, user activity and idle screen	F	8.5.0
A051	-	R99	8.4.0	available event download test cases  Corrections in the REFRESH test sequences (with inclusion of T3-	F	8.5.0
				030535's contents)		
A052	-	R99	8.4.0	Essential corrections to test requirement references	F	8.5.0
A053				Essential corrections to CALL CONTROL BY SIM (supplementary services) test case		
A054	-	R99	8.4.0	Essential corrections to MT Call, Call connected and Call	F	8.5.0
			-: ···•	disconnected event download test cases		2.5.0

# History

	Document history						
V8.1.0	December 2002	Publication					
V8.2.0	February 2003	Publication					
V8.3.0	April 2003	Publication					
V8.4.0	June 2003	Publication					
V8.5.0	September 2003	Publication					