ETSITS 100 607-4 V8.1.0 (2002-12)

Technical Specification

Digital cellular telecommunications system (Phase 2+); Mobile Station (MS) Conformance Specification; Part 4: SIM Application Toolkit conformance specification (3GPP TS 11.10-4 version 8.1.0 Release 1999)



Reference RTS/TSGG-051110-4v810 Keywords GSM

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

http://portal.etsi.org/tb/status/status.asp

If you find errors in the present document, send your comment to: editor@etsi.org

Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2002. All rights reserved.

DECTTM, **PLUGTESTS**TM and **UMTS**TM are Trade Marks of ETSI registered for the benefit of its Members. **TIPHON**TM and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members. **3GPP**TM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

All published ETSI deliverables shall include information which directs the reader to the above source of information.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under www.etsi.org/key.

Contents

Intelle	ectual Property Rights	2
Forew	/ord	2
Forew	vord	17
1	Scope	18
2	References	18
3	Definitions, symbols and abbreviations	20
3.1	Mobile station definition and configurations.	
3.2	Applicability	
3.2.1	Applicability of this specification	
3.2.2	Applicability of the individual tests	
3.2.3	Applicability to terminal equipment	
3.2.4	Definitions	
3.2.4.1	Format of the Table of Optional Features	20
3.2.4.2	Format of the Applicability Table	21
3.2.4.3	Status and Notations	21
3.3	Table of Optional Features	
3.4	Applicability table	
3.5	Conventions for mathematical notations	
3.6	Conventions on electrical terms	
3.7	Terms on test conditions	38
4	Test Equipment	38
5	Testing methodology in general	20
5		
5.1 5.2	Testing of optional functions and procedures Test interfaces and facilities	
5.2	Different protocol layers	
5.3 5.4	Information to be provided by the apparatus supplier	
5. 4 5.5	Definitions of transmit and receive times	
6	Reference test methods.	
7	Implicit testing.	
8	Measurement uncertainty	
9	Format of tests	39
10	Generic call set up procedures.	42
11	- 26 Not used	42
27	Testing of the SIM/ME interface	43
	27.21 Not used	
27.22	SIM Application Toolkit	
27.22.	**	т
27.22.	(Profile Download)	46
27.22.		
27.22.		
27.22.	•	
27.22.	1	
27.22.		
27.22.	1	
27.22.		
27.22.		
27.22.	2.3 Test Purpose	49
27.22.	2.4 Method of Test	50

27.22.2.5	Test Requirement	
27.22.3 Se	ervicing of Proactive SIM Commands	
27.22.3.1	Definition and applicability	
27.22.3.2	Conformance requirement	50
27.22.3.3	Test Purpose	50
27.22.3.4	Method of test	50
27.22.3.5	Test Requirement	
	oactive SIM Commands	
27.22.4.1	DISPLAY TEXT.	
27.22.4.1.1	DISPLAY TEXT (Normal)	
27.22.4.1.1	Definition and applicability	
27.22.4.1.1.2		
	Conformance requirements	
27.22.4.1.1.3	Test Purpose	
27.22.4.1.1.4	Method of test	
27.22.4.1.1.4.1	Initial Conditions	
27.22.4.1.1.4.2	Procedure	
27.22.4.1.1.5	Test Requirement	60
27.22.4.1.2	DISPLAY TEXT (Support of "No response from user")	60
27.22.4.1.2.1	Definition and applicability	60
27.22.4.1.2.2	Conformance requirement	61
27.22.4.1.2.3	Test Purpose	
27.22.4.1.2.4	Method of test	
27.22.4.1.2.4.1	Initial Conditions	
27.22.4.1.2.4.1	Procedure	
27.22.4.1.2.5	Test Requirement	
27.22.4.1.3	DISPLAY TEXT (Display of extension text)	
	· · · · · · · · · · · · · · · · · · ·	
27.22.4.1.3.1	Definition and applicability	
27.22.4.1.3.2	Conformance requirement	
27.22.4.1.3.3	Test Purpose	
27.22.4.1.3.4	Method of test	
27.22.4.1.3.4.1	Initial Conditions	
27.22.4.1.3.4.2	Procedure	63
27.22.4.1.3.5	Test Requirement	64
27.22.4.1.4	DISPLAY TEXT (Sustained text)	64
27.22.4.1.4.1	Definition and applicability	64
27.22.4.1.4.2	Conformance requirement	65
27.22.4.1.4.3	Test Purpose	
27.22.4.1.4.4	Method of test	
27.22.4.1.4.4.1	Initial Conditions	
27.22.4.1.4.4.2	Procedure	
27.22.4.1.4.5	Test Requirement	
27.22.4.1.5		
	DISPLAY TEXT (Display of icons)	
27.22.4.1.5.1	Definition and applicability	
27.22.4.1.5.2	Conformance requirement	
27.22.4.1.5.3	Test Purpose	
27.22.4.1.5.4	Method of test	
27.22.4.1.5.4.1	Initial Conditions	
27.22.4.1.5.4.2	Procedure	
27.22.4.1.5.5	Test Requirement	
27.22.4.1.6	DISPLAY TEXT (UCS2 display supported)	75
27.22.4.1.6.1	Definition and applicability	
27.22.4.1.6.2	Conformance requirement	
27.22.4.1.6.3	Test Purpose	
27.22.4.1.6.4	Method of test	
27.22.4.1.6.4.1	Initial Conditions	
27.22.4.1.6.4.2	Procedure	
27.22.4.1.6.5	Test Requirement	
	<u> </u>	
27.22.4.2	GET INKEY	
27.22.4.2.1	GET INKEY(normal)	
27.22.4.2.1.1	Definition and applicability	
27.22.4.2.1.2	Conformance Requirement	
27 22 4 2 1 3	Test Purpose	78

27.22.4.2.1.4	Method of Test	
27.22.4.2.1.4.1	Initial conditions	
27.22.4.2.1.4.2	Procedure	
27.22.4.2.1.5	Test Requirement	
27.22.4.2.2	GET INKEY (No response from User)	
27.22.4.2.2.1	Definition and applicability	
27.22.4.2.2.2	Conformance Requirement	
27.22.4.2.2.3	Test Purpose	
27.22.4.2.2.4	Method of Test	
27.22.4.2.2.4.1	Initial Conditions	
27.22.4.2.2.4.2	Procedure	
27.22.4.2.2.5	Test Requirement	
27.22.4.2.3	GET INKEY (UCS2 format display)	
27.22.4.2.3.1	Definition and applicability	
27.22.4.2.3.2	Conformance Requirement	
27.22.4.2.3.3	Test Purpose	
27.22.4.2.3.4	Method of Test	
27.22.4.2.3.4.1	Initial Conditions	
27.22.4.2.3.4.2	Procedure	
27.22.4.2.3.5	Test Requirement	
27.22.4.2.4	GET INKEY (UCS2 format of entry)	
27.22.4.2.4.1	Definition and applicability	
27.22.4.2.4.2	Conformance Requirement	
27.22.4.2.4.3	Test Purpose	
27.22.4.2.4.4	Method of Test	
27.22.4.2.4.4.1	Initial Conditions	
27.22.4.2.4.4.2	Procedure	
27.22.4.2.4.5	Test Requirement	
27.22.4.2.5	GET INKEY ("Yes/No" Response)	
27.22.4.2.5.1	Definition and applicability	
27.22.4.2.5.2	Conformance Requirement	
27.22.4.2.5.3	Test Purpose	
27.22.4.2.5.4	Method of Test	
27.22.4.2.5.4.1	Initial Conditions	
27.22.4.2.5.4.2 27.22.4.2.5.5	Procedure	
27.22.4.2.6	Test Requirement	
27.22.4.2.6.1	Definition and applicability	
27.22.4.2.6.2	Conformance Requirement	
27.22.4.2.6.3	Test Purpose	
27.22.4.2.6.4	Method of Test.	
27.22.4.2.6.4.1	Initial Conditions	
27.22.4.2.6.4.2	Procedure	
27.22.4.2.6.5	Test Requirement	
27.22.4.2.7	GET INKEY (Help Information)	
27.22.4.2.7.1	Definition and applicability	
27.22.4.2.7.2	Conformance Requirement	
27.22.4.2.7.3	Test Purpose	
27.22.4.2.7.4	Method of Test.	
27.22.4.2.7.4.1	Initial Conditions	
27.22.4.2.7.4.2	Procedure	
27.22.4.2.7.5	Test Requirement	
27.22.4.3.	GET INPUT	
27.22.4.3.1	GET INPUT (normal)	
27.22.4.3.1.1	Definition and applicability	
27.22.4.3.1.2	Conformance Requirement	
27.22.4.3.1.3	Test Purpose	
27.22.4.3.1.4	Method of Test	
27.22.4.3.1.4.1	Initial Conditions	105
27.22.4.3.1.4.2	Procedure	106
27.22.4.3.1.5	Test Requirement	121
27.22.4.3.2	GET INPUT (No response from User)	121

27.22.4.3.2.1	Definition and applicability	121
27.22.4.3.2.2	Conformance Requirement	
27.22.4.3.2.3	Test Purpose	
27.22.4.3.2.4	Method of Test	
27.22.4.3.2.4.1	Initial Conditions	
27.22.4.3.2.4.2	Procedure	
27.22.4.3.2.5	Test Requirement	
27.22.4.3.3	GET INPUT (UCS2 format display)	
27.22.4.3.3.1	Definition and applicability	
27.22.4.3.3.1	Conformance Requirement	
27.22.4.3.3.3	Test Purpose	
27.22.4.3.3.4	Method of Test	
27.22.4.3.3.4.1	Initial Conditions	
27.22.4.3.3.4.2	Procedure	
27.22.4.3.3.5	Test Requirement	
27.22.4.3.4	GET INPUT (UCS2 format of entry)	
27.22.4.3.4.1	Definition and applicability	
27.22.4.3.4.2	Conformance Requirement	
27.22.4.3.4.3	Test Purpose	
27.22.4.3.4.4	Method of Test	
27.22.4.3.4.4.1	Initial Conditions	
27.22.4.3.4.4.2	Procedure	128
27.22.4.3.4.5	Test Requirement	131
27.22.4.3.5	GET INPUT (default text)	131
27.22.4.3.5.1	Definition and applicability	131
27.22.4.3.5.2	Conformance Requirement	131
27.22.4.3.5.3	Test Purpose	131
27.22.4.3.5.4	Method of Test	
27.22.4.3.5.4.1	Initial Conditions	
27.22.4.3.5.4.2	Procedure	
27.22.4.3.5.5	Test Requirement	
27.22.4.3.6	GET INPUT (display of Icon)	
27.22.4.3.6.1	Definition and applicability	
27.22.4.3.6.2	Conformance Requirement	
27.22.4.3.6.3	Test Purpose	
27.22.4.3.6.4	Method of Test	
27.22.4.3.6.4.1	Initial Conditions	
27.22.4.3.6.4.3	Procedure	
27.22.4.3.7	GET INPUT (Help Information)	
27.22.4.3.7.1	Definition and applicability	
27.22.4.3.7.1	** '	
	Conformance Requirement	
27.22.4.3.7.3	Test Purpose	
27.22.4.3.7.4	Method of Test	
27.22.4.3.7.4.1	Initial Conditions	
27.22.4.3.7.4.2	Procedure	
27.22.4.3.7.5	Test Requirement	
27.22.4.4	MORE TIME	
27.22.4.4.1	Definition and applicability	
27.22.4.4.2	Conformance Requirement	
27.22.4.4.3	Test Purpose	146
27.22.4.4.4	Method of Test	
27.22.4.4.5	Test Requirement	147
27.22.4.5	PLAY TONE.	148
27.22.4.5.1	Definition and applicability	148
27.22.4.5.2	Conformance Requirement	148
27.22.4.5.3	Test Purpose	
27.22.4.5.4	Method of Test	
27.22.4.5.5	Test Requirement	
27.22.4.6	POLL INTERVAL	
27.22.4.6.1	Definition and applicability	
27.22.4.6.2	Conformance Requirement	
27.22.1.6.2	Test Purnose	163

27.22.4.6.4	Method of Test	
27.22.4.6.5	Test Dequirement	
27.22.4.7	Test Requirement	
27.22.4.7		
	REFRESH (normal)	
27.22.4.7.1.1	Definition and applicability	
27.22.4.7.1.2	Conformance requirement	
27.22.4.7.1.3	Test Purpose	
27.22.4.7.1.4	Method of test	
27.22.4.7.1.4.1	Initial Conditions	
27.22.4.7.1.4.2 27.22.4.7.1.5	Procedure	
27.22.4.7.1	Test Requirement	
27.22.4.7.2.1	Definition and applicability	
27.22.4.7.2.1	Conformance requirement	
27.22.4.7.2.3	Test Purpose	
27.22.4.7.2.4	Method of test	
27.22.4.7.2.4.1	Initial Conditions	
27.22.4.7.2.4.1	Procedure	
27.22.4.7.2.5	Test Requirement	
27.22.4.8	SET UP MENU and ENVELOPE MENU SELECTION	
27.22.4.8.1	SET UP MENU and ENVELOPE MENU SELECTION (normal)	
27.22.4.8.1.1	Definition and applicability	
27.22.4.8.1.2	Conformance Requirement	
27.22.4.8.1.3	Test Purpose	
27.22.4.8.1.4	Method of Test	
27.22.4.8.1.4.1	Initial Conditions	
27.22.4.8.1.4.2	Procedure	
27.22.4.8.1.5	Test Requirement	
27.22.4.8.2	SET UP MENU (help request support)	
27.22.4.8.2.1	Definition and applicability	
27.22.4.8.2.2	Conformance Requirement	
27.22.4.8.2.3	Test Purpose	
27.22.4.8.2.4	Method of Test	
27.22.4.8.2.4.1	Initial Conditions	
27.22.4.8.2.4.2	Procedure	194
27.22.4.8.3	SET UP MENU (next action support)	
27.22.4.8.3.1	Definition and applicability	195
27.22.4.8.3.2	Conformance Requirement	195
27.22.4.8.3.3	Test Purpose	196
27.22.4.8.3.4	Method of Test	196
27.22.4.8.3.4.1	Initial Conditions	
27.22.4.8.3.4.2	Procedure	
27.22.4.8.4	SET UP MENU (display of icons)	
27.22.4.8.4.1	Definition and applicability	
27.22.4.8.4.2	Conformance Requirement	
27.22.4.8.4.3	Test Purpose	
27.22.4.8.4.4	Method of Test	
27.22.4.8.4.4.1	Initial Conditions	
27.22.4.8.4.4.2	Procedure	
27.22.4.8.5	SET UP MENU (soft keys support)	
27.22.4.8.5.1	Definition and applicability	
27.22.4.8.5.2 27.22.4.8.5.3	Conformance Requirement	
27.22.4.8.5.3	Test Purpose	
27.22.4.8.5.4.1	Method of Test Initial Conditions	
27.22.4.8.5.4.1	Procedure	
27.22.4.9	SELECT ITEM	
27.22.4.9.1	SELECT ITEM (mandatory features for ME supporting SELECT ITEM)	
27.22.4.9.1.1	Definition and applicability	
27.22.4.9.1.2	Conformance Requirement	
27.22.4.9.1.3	Test Purpose	
	Г	

27 22 4 0 1 4	M. 41 1 . CT 4	200
27.22.4.9.1.4		
27.22.4.9.1.4.1		
27.22.4.9.1.4.2		
27.22.4.9.1.5		222
27.22.4.9.2		rt)222
27.22.4.9.2.1	Definition and applicability	222
27.22.4.9.2.2	Conformance Requirement	223
27.22.4.9.2.3	Test Purpose	223
27.22.4.9.2.4		
27.22.4.9.2.4.1		223
27.22.4.9.2.4.2		
27.22.4.9.3		ort)
27.22.4.9.3.1		
27.22.4.9.3.1		
27.22.4.9.3.3	-	
27.22.4.9.3.4		
27.22.4.9.3.4.1		225
27.22.4.9.3.4.2		225
27.22.4.9.4		ort)227
27.22.4.9.4.1	Definition and applicability	227
27.22.4.9.4.2	Conformance Requirement	227
27.22.4.9.4.3	Test Purpose	227
27.22.4.9.4.4	Method of Test	227
27.22.4.9.4.4.1	Initial Conditions	227
27.22.4.9.4.4.2		227
27.22.4.9.5		229
27.22.4.9.5.1		
27.22.4.9.5.2		
27.22.4.9.5.3		
27.22.4.9.5.4	-	
27.22.4.9.5.4.1		
27.22.4.9.5.4.2		230
27.22.4.9.6)235
27.22.4.9.6.1		235
27.22.4.9.6.2		235
27.22.4.9.6.3		235
27.22.4.9.6.4		235
27.22.4.9.6.4.1		235
27.22.4.9.6.4.2	Procedure	
27.22.4.9.7	SELECT ITEM (soft keys support	
27.22.4.9.7.1	Definition and applicability	239
27.22.4.9.7.2	Conformance Requirement	239
27.22.4.9.7.3		239
27.22.4.9.7.4		
27.22.4.9.7.4.1		
27.22.4.9.7.4.2		
27.22.4.10		
27.22.4.10.1		ıl)241
27.22.4.10.1		
27.22.4.10.1.2		241
27.22.4.10.1.4		
27.22.4.10.1.4.1		241
27.22.4.10.1.4.2		242
27.22.4.10.1.5		
27.22.4.10.2	SEND SHORT MESSAGE (UCS2	support)
27.22.4.10.2.1	Definition and applicability	262
27.22.4.10.2.2	Conformance requirement	262
27.22.4.10.2.3	<u> </u>	262
27.22.4.10.2.4	*	262
27.22.4.10.2.4.1		
27.22.4.10.2.4.2		
27.22.1.10.2.1.2	Test Requirement	26/

27.22.4.10.3	CEND CHODT MECCACE (son summer)	264
	SEND SHORT MESSAGE (icon support)	
27.22.4.10.3.1	Definition and applicability	
27.22.4.10.3.2	Conformance requirement	
27.22.4.10.3.3	Test Purpose	
27.22.4.10.3.4	Method of test	
27.22.4.10.3.4.1	Initial Conditions	265
27.22.4.10.3.4.2	Procedure	265
27.22.4.10.3.5	Test Requirement	271
27.22.4.11	SEND SS	271
27.22.4.11.1	SEND SS (normal)	271
27.22.4.11.1.1	Definition and applicability	
27.22.4.11.1.2	Conformance requirement	
27.22.4.11.1.3	Test Purpose	
27.22.4.11.1.4	Method of test	
27.22.4.11.1.4.1	Initial Conditions	
27.22.4.11.1.4.2	Procedure	
27.22.4.11.1.5		
27.22.4.11.1.3	Test Requirement	
	SEND SS (Icon support)	
27.22.4.11.2.1	Definition and applicability	
27.22.4.11.2.2	Conformance requirement	
27.22.4.11.2.3	Test Purpose	
27.22.4.11.2.4	Method of test	
27.22.4.11.2.4.1	Initial Conditions	
.27.22.4.11.2.4.2		
27.22.4.11.2.5	Test Requirement	287
27.22.4.11.2	SEND SS (UCS2 support)	287
27.22.4.11.2.1	Definition and applicability	287
27.22.4.11.2.2	Conformance requirement	
27.22.4.11.2.3	Test Purpose	
27.22.4.11.2.4	Method of test	
27.22.4.11.2.4.1	Initial Conditions	
27.22.4.11.2.4.2	Procedure	
27.22.4.11.2.5	Test Requirement	
27.22.4.12	SEND USSD	
27.22.4.12.1	SEND USSD (normal)	
27.22.4.12.1.1	Definition and applicability	
27.22.4.12.1.1	Conformance requirement	
	<u>*</u>	
27.22.4.12.1.3	Test Purpose	
27.22.4.12.1.4	Method of test	
27.22.4.12.1.4.1	Initial Conditions	
27.22.4.12.1.4.2	Procedure	
27.22.4.12.1.5	Test Requirement	
27.22.4.12.2	SEND USSD (Icon support)	
27.22.4.12.2.1	Definition and applicability	
27.22.4.12.2.2	Conformance requirement	300
27.22.4.12.2.3	Test Purpose	300
27.22.4.12.2.4	Method of test	300
27.22.4.12.2.4.1	Initial Conditions	300
27.22.4.12.2.4.2	Procedure	
27.22.4.12.2.5	Test Requirement	
27.22.4.12.3	SEND USSD (UCS2 support)	
27.22.4.12.3.1	Definition and applicability	
27.22.4.12.3.2	Conformance requirement	
27.22.4.12.3.2	Test Purpose	
27.22.4.12.3.4	Method of test	
27.22.4.12.3.4.1	Initial Conditions	
27.22.4.12.3.4.2	Procedure	
27.22.4.12.3.5	Test Requirement	
27.22.4.13	SET UP CALL	
27.22.4.13.1	SET UP CALL (normal)	
27.22.4.13.1.1	Definition and applicability	
27 22 4 13 1 2	Conformance requirement	310

27.22.4.13.1.3	Test Purnose	310
27.22.4.13.1.4		
27.22.4.13.1.4.1		
27.22.4.13.1.4.2		
		311
27.22.4.13.2		326
27.22.4.13.2.1		
27.22.4.13.2.2	•	327
27.22.4.13.2.3	Test Purpose	327
27.22.4.13.2.4	Method of test	327
27.22.4.13.2.4.1	Initial Conditions	327
27.22.4.13.1.4.2	Procedure	327
27.22.4.13.3.5	Test Requirement	328
27.22.4.13.3		328
27.22.4.13.3.1		328
27.22.4.13.3.2		
27.22.4.13.3.3		
27.22.4.13.3.4	•	
27.22.4.13.3.4.1		
27.22.4.13.3.4.2		330
27.22.4.13.3.5		
27.22.4.14		340
27.22.4.14.1		340
27.22.4.14.2		340
27.22.4.14.3		340
27.22.4.14.4		340
27.22.4.14.4.1	Initial Conditions	340
27.22.4.14.4.2	Procedure	340
27.22.4.14.5	Test Requirement	342
27.22.4.15	PROVIDE LOCAL INFORMATION	342
27.22.4.15.1		342
27.22.4.15.2		342
27.22.4.15.3	•	342
27.22.4.15.4		
27.22.4.15.4.1		
27.22.4.15.4.2		
27.22.4.16		
27.22.4.16		
27.22.4.16.1.1		
27.22.4.16.1.2		
27.22.4.16.1.3	*	
27.22.4.16.1.4		
27.22.4.16.1.4.1		348
27.22.4.16.1.4.2		349
27.22.4.16.1.5		358
27.22.4.17		358
27.22.4.17.1	PERFORM CARD APDU (normal)	358
27.22.4.17.1.1	Definition and applicability	358
27.22.4.17.1.2		358
27.22.4.17.1.3		359
27.22.4.17.1.4		359
27.22.4.17.1.4.1		
27.22.4.17.1.4.2		
27.22.4.17.2		eader)
27.22.4.17.2.1		
27.22.4.17.2.1		
27.22.4.17.2.2	<u> •</u>	
		377
27.22.4.17.2.4		377
27.22.4.17.2.4.1		
27.22.4.18		
27.22.4.18.1	· · · · · · · · · · · · · · · · · · ·	
27.22.4.18.1.1		
27 22 4 18 1 2	Conformance requirement	370

27.22.4.18.1.3	Test Purpose	
27.22.4.18.1.4	Method of test	
27.22.4.18.1.4.1	Initial Conditions	
27.22.4.18.1.4.2	Procedure	
27.22.4.18.2	POWER OFF CARD (detachable card reader)	
27.22.4.18.2.1	Definition and applicability	
27.22.4.18.2.2	Conformance requirement	
27.22.4.18.2.3	Test Purpose	
27.22.4.18.2.4	Method of test	
27.22.4.18.2.4.1	Initial Conditions	
27.22.4.18.2.4.2	Procedure	
27.22.4.19	POWER ON CARD	
27.22.4.19.1	POWER ON CARD (normal)	
27.22.4.19.1.1	Definition and applicability	
27.22.4.19.1.2	Conformance requirement	
27.22.4.19.1.3	Test Purpose	
27.22.4.19.1.4 27.22.4.19.1.4.1	Method of test	
27.22.4.19.1.4.2	Procedure	
27.22.4.19.1.4.2	POWER ON CARD (detachable card reader)	
27.22.4.19.2.1	Definition and applicability	
27.22.4.19.2.1	Conformance requirement	387
27.22.4.19.2.3	Test Purpose	
27.22.4.19.2.4	Method of test	
27.22.4.19.2.4.1	Initial Conditions	
27.22.4.19.2.4.2	Procedure	
27.22.4.20	GET READER STATUS	
27.22.4.20.1	GET READER STATUS (normal)	
27.22.4.20.1.1	Definition and applicability	388
27.22.4.20.1.2	Conformance requirement	388
27.22.4.20.1.4	Method of test	
27.22.4.20.1.4.1	Initial Conditions	
27.22.4.20.1.4.2	Procedure	
27.22.4.20.2	GET CARD READER STATUS (detachable card reader)	
27.22.4.20.2.1	Definition and applicability	
27.22.4.20.2.2	Conformance requirement	
27.22.4.20.2.3 27.22.4.20.2.4	Test Purpose	
27.22.4.20.2.4.1	Initial Conditions	
27.22.4.20.2.4.1	TIMER MANAGEMENT and ENVELOPE TIMER EXPIRATION	
27.22.4.21.1	TIMER MANAGEMENT (normal)	
27.22.4.21.1.1	Definition and applicability	
27.22.4.21.1.2	Conformance Requirement	
27.22.4.21.1.3	Test Purpose	
27.22.4.21.1.4	Method of Test	
27.22.4.21.1.4.1	Initial Conditions	402
27.22.4.21.1.4.2	Procedure	402
27.22.4.21.2	ENVELOPE TIMER EXPIRATION (normal)	
27.22.4.21.2.1	Definition and applicability	
27.22.4.21.2.2	Conformance requirement	
27.22.4.21.2.3	Test Purpose	
27.22.4.21.2.4	Method of test	
27.22.4.21.2.4.1	Initial Conditions	
27.22.4.21.2.4.2 27.22.4.21.2.5	Procedure	
27.22.4.21	SET UP IDLE MODE TEXT	
27.22.4.22	SET UP IDLE MODE TEXT (normal)	
27.22.4.22.1.1	Definition and applicability	
27.22.4.22.1.2	Conformance requirement	
27.22.4.22.1.3	Test Purpose	
27.22.4.22.1.4	Method of test	
27.22.4.22.1.4.1	Initial Conditions	

27.22.4.22.1.4.2	Procedure	
27.22.4.22.3.5	Test Requirement	
27.22.4.22.2	SET UP IDLE MODE TEXT (Icon support)	
27.22.4.22.2.1	Definition and applicability	
27.22.4.22.2.2	Conformance requirement	460
27.22.4.22.2.3	Test Purpose	460
27.22.4.22.2.4	Method of test	461
27.22.4.22.2.4.1	Initial Conditions	461
27.22.4.22.2.4.2	Procedure	462
27.22.4.22.2.5	Test Requirement	468
27.22.4.22.3	SET UP IDLE MODE TEXT (UCS2 support)	469
27.22.4.22.3.1	Definition and applicability	
27.22.4.22.3.2	Conformance requirement	
27.22.4.22.3.3	Test Purpose	
27.22.4.22.3.4	Method of test	
27.22.4.22.3.4.1	Initial Conditions	
27.22.4.22.3.4.2	Procedure	
27.22.4.22.3.5	Test Requirement	
27.22.4.23	RUN AT COMMAND	
27.22.4.23.1	RUN AT COMMAND (normal)	
27.22.4.23.1.1	Definition and applicability	
27.22.4.23.1.2	Conformance requirement	
27.22.4.23.1.4	Method of test	
27.22.4.23.1.4.1	Initial Conditions	
27.22.4.23.1.4.2	Procedure	
27.22.4.23.1.5	Test Requirement	
27.22.4.23.1.3	RUN AT COMMAND (Icon support)	
27.22.4.23.2.1	Definition and applicability	
27.22.4.23.2.1	Conformance requirement	
27.22.4.23.2.3	Test Purpose	
27.22.4.23.2.4.1	Initial Conditions	
27.22.4.23.2.4.1		
	Procedure	
27.22.4.23.2.5	Test Requirement	
27.22.4.24	SEND DTMF	
27.22.4.24.1	SEND DTMF (Normal)	
27.22.4.24.1.1	Definition and applicability	
27.22.4.24.1.2	Conformance requirement	
27.22.4.24.1.3	Test Purpose	
27.22.4.24.1.4.1	Initial Conditions	
27.22.4.24.1.4. 2		
27.22.4.24.1.5	Test Requirement	
27.22.4.24.2	SEND DTMF (Display of icons)	
27.22.4.24.2.1	Definition and applicability	
27.22.4.24.2.2	Conformance requirement	
27.22.4.24.2.3	Test Purpose	
27.22.4.24.2.4.1	Initial Conditions	
27.22.4.24.2.4.2	Procedure	
27.22.4.24.2.5	Test Requirement	
27.22.4.24.3	SEND DTMF (UCS2 support)	
27.22.4.24.3.1	Definition and applicability	
27.22.4.24.3.2	Conformance requirement	
27.22.4.24.3.3	Test Purpose	491
27.22.4.24.3.4	Method of test	491
27.22.4.24.3.4.1	Initial Conditions	491
27.22.4.24.3.4.2	Procedure	491
27.22.4.12.2.5	Test Requirement	
27.22.4.25	LANGUAGE NOTIFICATION	
27.22.4.25.1	Definition and applicability	
27.22.4.25.2	Conformance Requirement	
27.22.4.25.3	Test Purpose	
27.22.4.25.4	Method of Test	
27.22.1.25.1	Test Requirement	/105

27.22.4.26	LAUNCH BROWSER	495
27.22.4.26.1	LAUNCH BROWSER (No session already launched)	
27.22.4.26.1.1	Definition and applicability	495
27.22.4.26.1.2	Conformance requirements	
27.22.4.26.1.3	Test Purpose	
27.22.4.26.1.4	Method of test	
27.22.4.26.1.4.1	Initial Conditions	
27.22.4.26.1.4.2	Procedure	
27.22.4.26.2	LAUNCH BROWSER (Interaction with current session)	
27.22.4.26.2.1	Definition and applicability	
27.22.4.26.2.2	Conformance requirements	
27.22.4.26.2.3	Test Purpose	
27.22.4.26.2.4	Method of test	
27.22.4.26.2.4.1	Initial Conditions	
27.22.4.26.2.4.2	Procedure	
27.22.4.26.3	LAUNCH BROWSER (UCS2 support)	
27.22.4.26.3.1	Definition and applicability	
27.22.4.26.3.2	Conformance requirements	
27.22.4.26.2.3	Test Purpose	
27.22.4.26.3.4	Method of test	
27.22.4.26.3.4.1	Initial Conditions	
27.22.4.26.3.4.2	Procedure	
27.22.4.26.4	LAUNCH BROWSER (icons support)	
27.22.4.26.4.1	Definition and applicability	
27.22.4.26.4.2	Conformance requirements	
27.22.4.26.4.3	Test Purpose	
27.22.4.26.4.4	Method of test	
27.22.4.26.4.4.1	Initial Conditions	
27.22.4.26.4.4.2	Procedure	
27.22.4.27	OPEN CHANNEL	
27.22.4.27	Definition and applicability	
27.22.4.27.2	Conformance requirements	
27.22.4.27.3	Test Purpose	
27.22.4.27.4	Method of test	
27.22.4.27.4.1	Initial Conditions	
27.22.4.27.4.1	Procedure	
27.22.4.28	CLOSE CHANNEL	
27.22.4.28	Definition and applicability	
27.22.4.28.2	Conformance requirements.	
27.22.4.28.3	Test Purpose	
27.22.4.28.4	Method of Test	
27.22.4.28.4.1	Initial Conditions	
27.22.4.28.4.1	Procedure	
27.22.4.29	RECEIVE DATA	
27.22.4.29	Definition and applicability	
27.22.4.29.1	÷÷ · · · ·	
27.22.4.29.3	Conformance requirements Test Purpose	
27.22.4.29.4	•	
27.22.4.29.4.1	Method of test	
	Procedure	
27.22.4.29.4.2 27.22.4.30	SEND DATA	
27.22.4.30		
27.22.4.30.1	Definition and applicability	
27.22.4.30.2	Conformance requirements	
	Test Purpose	
27.22.4.30.4	Method of test	
27.22.4.30.4.1	Initial Conditions	
27.22.4.30.4.2	Procedure	
27.22.4.31	GET CHANNEL STATUS	
27.22.4.31.1	Definition and applicability	
27.22.4.31.2	Conformance requirements	
27.22.4.31.3	Test Purpose	560 560

27.22.4.31.4.		
27.22.4.31.4.		
27.22.5	DATA DOWNLOAD TO SIM	564
27.22.5	Data Download to SIM	564
27.22.5.1	SMS-PP Data Download	564
27.22.5.1.1	Definition and applicability	564
27.22.5.1.2	Conformance requirement	564
27.22.5.1.3	Test Purpose	564
27.22.5.1.4	Method of Test	
27.22.5.1.5	Test Requirement	
27.22.5.2	SMS-CB Data Download	574
27.22.5.2.1	Definition and applicability	574
27.22.5.2.2	Conformance requirement	
27.22.5.2.3	Test Purpose	
27.22.5.2.4	Method of Test	
27.22.5.2.5	Test Requirement	
27.22.6	CALL CONTROL BY SIM	
27.22.6.1	Procedure for Mobile Originated calls	
27.22.6.1.1	Definition and applicability	
27.22.6.1.2	Conformance requirement	
27.22.6.1.3	Test Purpose	
27.22.6.1.4	method of tests	
27.22.6.1.4.1		
27.22.6.1.4.2		
27.22.6.2	Procedure for Supplementary (SS) Services	
27.22.6.2.1	Definition and applicability	
27.22.6.2.2	Conformance requirement	
27.22.6.2.3	Test Purpose	
27.22.6.2.4	method of tests	
27.22.6.2.4.1		
27.22.6.2.4.2		
27.22.6.3	Interaction with Fixed Dialling Number (FDN)	
27.22.6.3.1	Definition and applicability	
27.22.6.3.2	Conformance requirement	
27.22.6.2.3	Test Purpose	
27.22.6.2.4	method of tests	
27.22.6.2.4.1		
27.22.6.2.4.2		
27.22.6.4	Support of Barred Dialling Number (BDN) service	
27.22.6.4.1	Definition and applicability	
27.22.6.4.2	Conformance requirement	
27.22.6.2.3	Test Purpose	
27.22.6.2.4	method of tests.	
27.22.6.2.4.1		
27.22.6.2.4.2		
27.22.7	EVENT DOWNLOAD.	
27.22.7.1	MT Call Event	
27.22.7.1	MT Call Event (normal)	
27.22.7.1.1		
27.22.7.1.1.2		
27.22.7.1.1.3	<u> </u>	
27.22.7.1.1.3	1	
27.22.7.1.1.4		
27.22.7.1.1.4		
27.22.7.1.1.5		
27.22.7.1	Call Connected Event.	
27.22.7.2	Call Connected Event (MT and MO call)	
27.22.7.2.1	Definition and applicability	
27.22.7.2.1.1		
27.22.7.2.1.2	•	
27.22.7.2.1.3		
27.22.7.2.1.4		
-,,		

27.22.7.2.1.4.2	Procedure	
27.22.7.2.1.5	Test Requirement	
27.22.7.2.2	Call Connected Event (ME supporting SET UP CALL)	
27.22.7.2.2.1	Definition and applicability	
27.22.7.2.2.2	Conformance requirement	
27.22.7.2.2.3	Test Purpose	
27.22.7.2.2.4	Method of test	
27.22.7.2.2.4.1	Initial Conditions	
27.22.7.2.2.4.2	Procedure	612
27.22.7.2.2.5	Test Requirement	614
27.22.7.3	Call Disconnected Event	
27.22.7.3.1	Call Disconnected Event	
27.22.7.3.1.1	Definition and applicability	614
27.22.7.3.1.2	Conformance requirement	614
27.22.7.3.1.3	Test Purpose	614
27.22.7.3.1.4	Method of test	615
27.22.7.3.1.4.1	Initial Conditions	
27.22.7.3.1.4.2	Procedure	
27.22.7.3.1.5	Test Requirement	620
27.22.7.4	Location Status Event	
27.22.7.4.1	Location Status Event (normal)	
27.22.7.4.1.1	Definition and applicability	620
27.22.7.4.1.2	Conformance requirement	
27.22.7.4.1.3	Test Purpose	621
27.22.7.4.1.4	Method of test	621
27.22.7.4.1.4.1	Initial Conditions	
27.22.7.4.4.2	Procedure	621
27.22.7.4.1.5	Test Requirement	622
27.22.7.5	User Activity Event	
27.22.7.5.1	User Activity Event (normal)	622
27.22.7.5.1.1	Definition and applicability	622
27.22.7.5.1.2	Conformance Requirement	
27.22.7.5.1.3	Test Purpose	
27.22.7.5.1.4	Method of Test	
27.22.7.5.1.4.1	Initial Conditions	623
27.22.7.5.1.4.2	Procedure	
27.22.7.5.1.5	Test Requirement	
27.22.7.6	Idle screen available event	
27.22.7.6.1	Idle Screen Available (normal)	
27.22.7.6.1.1	Definition and applicability	
27.22.7.6.1.2	Conformance requirement	
27.22.7.6.1.3	Test Purpose	
27.22.7.6.1.4	Method of test	
27.22.7.6.1.4.1	Initial Conditions	
27.22.7.6.1.4.2	Procedure	
27.22.7.6.1.5	Test Requirement	
27.22.7.7	Card reader status event	
27.22.7.7.1	Card Reader Status (normal)	
27.22.7.7.1.1	Definition and applicability	
27.22.7.7.1.2	Conformance requirement	
27.22.7.7.1.3	Test Purpose	
27.22.7.7.1.4	Method of test	
27.22.7.7.1.4.1	Initial Conditions	
27.22.7.7.1.4.2	Procedure	
27.22.7.7.1.5	Test Requirement	
27.22.7.7.2	Card Reader Status(detachable card reader)	
27.22.7.7.2.1	Definition and applicability	
27.22.7.7.2.2	Conformance requirement	
27.22.7.7.2.3	Test Purpose	
27.22.7.7.2.4	Method of test	
27.22.7.7.2.4.1	Initial Conditions	
27.22.7.7.2.4.2	Procedure	633

27.22.7.7.1.5	Test l	Requirement	635
27.22.7.8		lection event	
27.22.7.8.1	Languag	e selection event (normal)	635
27.22.7.8.1.1	Defin	ition and applicability	635
27.22.7.8.1.2	Confe	ormance requirement	635
27.22.7.8.1.3	Test l	Purpose	635
27.22.7.8.1.4	Meth	od of test	635
27.22.7.8.1.4.1	In	itial Conditions	635
27.22.7.8.1.4.2	P	rocedure	635
27.22.7.8.1.5	Test l	Requirement	637
27.22.7.9	Browser terr	nination event	637
27.22.7.9.1		termination (normal)	
27.22.7.9.1.1	Defin	ition and applicability	637
27.22.7.9.1.2	Confe	ormance requirement	637
27.22.7.9.1.3	Test l	Purpose	637
27.22.7.9.1.4	Meth	od of test	638
27.22.7.9.1.4.1	In	itial Conditions	638
27.22.7.9.1.4.2	P	rocedure	638
27.22.7.10		le event	
27.22.7.10.1		n and applicability	
27.22.7.10.2		ance requirements	
27.22.7.10.3		pose	
27.22.7.10.4		of test	
27.22.7.10.4.1		l Conditions	
27.22.7.10.4.2		edure	
27.22.7.11		tus event	
27.22.7.11.1		n and applicability	
27.22.7.11.2		ance requirements	
27.22.7.11.3		pose	
27.22.7.11.4		of test	
27.22.7.11.4.1		l Conditions	
27.22.7.11.4.2	Proce	edure	642
Annex A (noi	rmative):	Void	643
Annex B (info	ormative):	void	644
Annex C (noi	rmative):	Initial Conditions for Icon Management	645
Annex D (noi	rmative):	Details of Test-SIM (TestSIM)	649
Annex C (infe	ormative):	Change History	652
History			653

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document describes the technical characteristics and methods of test for testing the SIM Application Toolkit implemented in Mobile Stations (MS) for the Pan European digital cellular communications system and Personal Communication Systems (PCS) operating in the 450 MHz, 480 MHz, 700 MHz, 750 MHz, 850 MHz, 900 MHz, 1 800 MHz and 1 900 MHz frequency band (GSM 400, GSM 700, GSM 750, GSM 850, GSM 900, DCS 1 800 and PCS 1 900) within the European digital cellular telecommunications system, in compliance with the relevant requirements, and in accordance with the relevant guidance given in ISO/IEC 9646-7 [19] and ETS 300 406 [20].

The present document is valid for MS implemented according to GSM Phase2+ R96, or R97, or R98, or R99.

The present document covers the minimum characteristics considered necessary in order to provide sufficient performance for mobile equipment and to prevent interference to other services or to other users, and to the PLMNs.

It does not necessarily include all the characteristics which may be required by a user or subscriber, nor does it necessarily represent the optimum performance achievable.

The present document is part of the GSM-series of technical specifications. The present document neither replaces any of the other GSM technical specifications or GSM related ETSs or ENs, nor is it created to provide full understanding of (or parts of) the GSM 400, GSM 700, GSM 850, GSM 900, DCS1800 and PCS1900 systems . The present document lists the requirements, and provides the methods of test for testing the SIM Application Toolkit implemented in a MS for conformance to the GSM standard.

For a full description of the system, reference should be made to all the GSM technical specifications or GSM related ETSs or ENs. Clause 2 provides a complete list of the GSM technical specifications, GSM related ETSs, ENs, and ETRs, on which this conformance test specifications is based.

If there is a difference between this present conformance document, and any other GSM technical specification or GSM related ETS or EN, or 3GPP TS, then the other GSM technical specification or GSM related ETS or EN or 3GPP TS shall prevail.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the relevant Release*.
 - For a GSM Phase 2+ Release 1999 MS, references to GSM documents are to version 8.x.y (for 01.-series to 12.-series) or (3.x.y for 21.-series to 35.-series), when available.
 - For a GSM Phase 2+ Release 1998 MS, references to GSM documents are to version 7.x.y, when available.
 - For a GSM Phase 2+ Release 1997 MS, references to GSM documents are to version 6.x.y, when available.
 - For a GSM Phase 2+ Release 1996 MS, references to GSM documents are to version 5.x.y,. when available.

NOTE: References to 3GPP Technical Specifications and Technical Reports throughout the present document shall be interpreted according to the Release shown in the formal reference in this clause, based upon the Release of the implementation under test.

EXAMPLE: References for a R99 MS shall be interpreted as:

[1	1 3GPP	TS	21	.905	R99

[2] 3GPP TS 22.001 R99

etc.

- [1] 3GPP TS 01.04 (R96 to R98): "Abbreviations and acronyms". 3GPP TR 21.905 (R99 onwards): "Vocabulary for 3GPP Specifications".
- [2] 3GPP TS 02.01 (R96 to R98): "Principles of telecommunication services supported by a GSM Public Land Mobile Network (PLMN)".

3GPP TS 22.001 (R99 onwards): "Principles of circuit telecommunication services supported by a Public Land Mobile Network (PLMN)".

- [3] 3GPP TS 02.03 (R96 to R98): "Teleservices supported by a GSM Public Land Mobile Network (PLMN)".
 3GPP TS 22.003 (R99 onwards): "Circuit Teleservices supported by a Public Land Mobile Network (PLMN)".
- [4] 3GPP TS 02.04 (R96 to R98): "General on supplementary services". 3GPP TS 22.004 (R99 onwards): "General on supplementary services".
- [5] 3GPP TS 02.06 (R96 to R98): "Types of Mobile Stations (MS)".
- [6] 3GPP TS 02.07 (R96 to R98): "Mobile Station (MS) features".
- [7] 3GPP TS 03.38 (R96 to R98): "Alphabets and language-specific information". 3GPP TS 23.038 (R99 onwards): "Alphabets and language-specific information".
- [8] 3GPP TS 03.40 (R96 to R98): "Technical realization of the Short Message Service (SMS);
 Point-to-Point (PP)".
 3GPP TS 23.040 (R99 onwards): "Technical realization of the Short Message Service (SMS)".
- [9] 3GPP TS 03.41 (R96 to R98): "Technical realization of Cell Broadcast Service (CBS)".3GPP TS 23.041 (R99 onwards): "Technical realization of Cell Broadcast Service (CBS)".
- [10] 3GPP TS 04.08 (R96 to R99): "Mobile radio interface layer 3 specification" (see note 1).3GPP TS 24.008 (R99 onwards): "Mobile radio interface layer 3 specification; Core network protocols; Stage 3" (see note 1).
- [11] 3GPP TS 04.11 (R96 to R98): "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".

 3GPP TS 24.011 (R99 onwards): "Point-to-Point (PP) Short Message Service (SMS) Support on mobile radio interface".
- [12] 3GPP TS 11.10-1 (Ph2+ to R99): " Digital cellular telecommunications system Mobile Station (MS) conformance specification Part 1: Conformance specification ".
- [13] 3GPP TS 11.11 (R96 to R99): "Specification of the Subscriber Identity Module Mobile Equipment (SIM-ME) interface".
- [14] 3GPP TS 11.12 (R96): "Specification of the 3 Volt Subscriber Identity Module Mobile Equipment (SIM-ME) interface".
- [15] 3GPP TS 11.14 (R96 to R99): "Specification of the SIM application toolkit for the Subscriber Identity Module Mobile Equipment (SIM ME) interface".
- [16] 3GPP TS 11.10-2 (Ph2+ to R99): " Digital cellular telecommunications system Mobile Station (MS) conformance specification Part 2: Protocol Implementation Conformance Statement (PICS) Proforma Specification".
- [17] ISO/IEC 10646-1 "Universal Multiple Octet Coded Character Set (UCS) Part 1: Architecture and Basic Multilingual Plane"

	ISO/IEC 10646-2 "Universal Multiple Octet Coded Character Set (UCS) Part 2: Supplementary Planes "
[18]	3GPP TS 27.007 (R99 onwards): "AT Command Set for User Equipment (UE)".
[19]	ISO/IEC 9646-7 (1995): "Information technology – Open Systems Interconnection – Conformance testing methodology and framework – Part 7: Implementation Conformance Statements".
[20]	ETS 300 406 (January 1995): "Methods for Testing and Specification (MTS); Protocol and profile conformance testing specifications; Standardization methodology".

3 Definitions, symbols and abbreviations

3.1 Mobile station definition and configurations

The mobile station definition and configurations specified in 3GPP TSM 11.10-1 [12] clause 3.1 shall apply, unless otherwise specified in the present clause.

3.2 Applicability

3.2.1 Applicability of this specification

The applicability specified in 3GPP TS 11.10-1 [12] clause 3.2.1 shall apply, unless otherwise specified in the present clause.

3.2.2 Applicability of the individual tests

The table B.1 lists the optional features for which the supplier of the implementation states the support.

3.2.3 Applicability to terminal equipment

The applicability to terminal equipment specified in 3GPP TS 11.10-1 [12] clause 3.2.3 shall apply, unless otherwise specified in the present clause.

See table A.1.

3.2.4 Definitions

The definitions specified in 3GPP TS 11.10-1 [12] clause 3.3 shall apply, unless otherwise specified in the present clause.

3.2.4.1 Format of the Table of Optional Features

Option

The optional feature supported or not by the implementation

Support Answer notation

The support columns shall be filled in by the supplier of the implementation. The following common notations, defined in ISO/IEC 9646-7 [19], are used for the support column in the tables below.

Y or y supported by the implementation

N or n not supported by the implementation

N/A, n/a or - no answer required (allowed only if the status is N/A, directly or after evaluation of a conditional status)

Mnemonic column

The Mnemonic column contains mnemonic identifiers for each item.

3.2.4.2 Format of the Applicability Table

The applicability of every test in table B.1 is formally expressed by the use of Boolean expression defined in the following section.

The columns in Table B.1 have the following meaning:

- In the "Item" column a local entry number for the requirement in the table is given.
- In the "Description" column a short non-exhaustive description of the requirement is found.
- The "Release" column gives the Release applicable and onwards, for the item in the "Description" column
- The "Test Sequence(s)" column gives a reference to the test sequence number(s) detailed in this document and required to validate the implementation of the corresponding item in the "Description" column.
- For a given Release, the corresponding "Rel 9x ME" column lists the tests required for a Mobile Station to be declared compliant to this Release.
- The "Support" column is blank in the proforma, and shall be completed by the manufacturer in respect of each particular requirement to indicate the choices, which have been made in the implementation.

3.2.4.3 Status and Notations

The "Release 9x ME" columns shows the status of the entries as follows:

The following notations, defined in ISO/IEC 9646-7 [19], are used for the status column:

M	mandatory – the capability is required to be supported.
O	optional – the capability may be supported or not.
N/A	not applicable – in the given context, it is impossible to use the capability.
X	prohibited (excluded) – there is a requirement not to use this capability in the given context.
O.i	qualified optional – for mutually exclusive or selectable options from a set. "i" is an integer which identifies an unique group of related optional items and the logic of their selection which is defined immediately following the table.
Ci	conditional – the requirement on the capability ("M", "O", "X" or "N/A") depends on the support of other optional or conditional items. "i" is an integer identifying an unique conditional status expression which is defined immediately following the table. For nested conditional expressions,

the syntax "IF ... THEN (IF ... THEN ... ELSE ... ELSE ... shall be used to avoid ambiguities.

References to items

For each possible item answer (answer in the support column) there exists a unique reference, used, for example, in the conditional expressions. It is defined as the table identifier, followed by a solidus character "/", followed by the item number in the table. If there is more than one support column in a table, the columns shall be discriminated by letters (a, b, etc.), respectively.

EXAMPLE 1: A.1/4 is the reference to the answer of item 4 in table A.1.

3.3 Table of Optional Features

Support of SIM Application Toolkit is optional for Mobile Equipment. However, if an ME states conformance with a specific GSM release, it is mandatory for the ME to support all functions of that release, as stated in the table, below.

The support of letter classes, which specify mainly ME hardware dependent features, is optional for the ME and may supplement the SIM Application Toolkit functionality described in this document. If an ME states conformancy to a letter class, it is mandatory to support all functions within the respective letter class.

The supplier of the implementation shall state the support of possible options in the table A.1 below.

Item Option Status support Mnemonic Capability Configuration parameter 0 O_Cap_Conf 2 Sustained text 0 O_sust_text 3 UCS2 coding scheme 0 O_Ucs2 4 **Extended Text String** 0 O_Ext_Str 5 Help information 0 O_Help 6 Icons 0 O_lcons Class A: Dual Slot O_Dual_Slot 0 Detachable reader 0 8 O_Detach_Rdr 0 Class B: RUN AT O_Run_At q Class C: LAUNCH BROWSER 10 0 O_LB O 11 Class D: Soft keys O_Soft_key 12 Class E: B.I.P 0 O_BIP

Table A.1: Options

3.4 Applicability table

Table B.1: Applicability of tests

Item	Description	Release	Test sequence (s)	Rel 96 ME	Rel 97 ME	Rel 98 ME	Rel 99 ME	Support
1	PROFILE DOWNLOAD 27.22.1	R96	1	М	M	M	M	
2	Contents of the TERMINAL PROFILE command 27.22.2	R96		М	М	М	М	
3	Servicing of Proactive SIM Commands 27.22.3	R96		М	М	М	М	

4	DISPLAY TEXT 27.22.4.1							
	Unpacked	R96	1.1	М	М	М	М	
	Screen busy	R96	1.2	М	М	М	М	
	high priority	R96	1.3	М	М	М	М	
	packed	R96	1.4	М	М	М	M	
	clear after delay	R96	1.5	М	М	М	М	
	clear after user confirmation	R96	1.1	М	М	М	M	
	long text up to 160 bytes	R96	1.6	М	М	М	M	
	Backwards move in SIM session	R96	1.7	М	М	М	М	
	Session terminated by user	R96	1.8	М	М	М	M	
	Command not understood by ME	R96	1.9	М	M	M	M	
	no response from user	R96	2.1	M	М	М	М	
	Extension Text	R98	3.1			C106	C106	
	sustained text	R98	4.1, 4.2, 4.3, 4.4			C104	C104	
	icons	R98	5.1, 5.2, 5.3			C108	C108	
	UCS2 display	R97	6.1		C105	C105	C105	
5	GET INKEY 27.22.4.2							
	prompt unpacked	R96	1.1	М	М	М	М	
	prompt packed	R96	1.2	М	М	М	М	
	digits only	R96	1.1	М	М	М	M	
	Backwards move in SIM session	R96	1.3	M	М	М	М	
	Session terminated by user	R96	1.4	М	М	М	M	
	SMS alphabet	R96	1.5	М	М	М	М	
	Long text up to 160 bytes	R96	1.6	M	М	М	М	

	no response from user	R96	2.1	М	М	М	M	
	UCS2 display	R97	3.1		C105	C105	C105	
	UCS2 display, Long text up to 70 chars	R97	3.2		C105	C105	C105	
	UCS2 format of entry	R97	4.1		C105	C105	C105	
	"Yes/No" response	R98	5.1			М	М	
	Icons	R98	6.1, 6.2, 6.3, 6.4			C108	C108	
	Help information	R97	7.1		C107	C107	C107	
6	GET INPUT							
	27.22.4.3							
	input unpacked	R96	1.1	М	М	М	M	
	input packed	R96	1.2	М	М	М	М	
	digits only	R96	1.1	М	М	М	М	
	SMS alphabet	R96	1.3	М	М	М	М	
	hidden input	R96	1.4	М	М	М	M	
	min / max acceptable length	R96	1.5, 1.9	М	М	М	М	
	Backwards move in SIM session	R96	1.6	М	М	М	М	
	Session terminated by user	R96	1.7	М	М	М	M	
	Prompt text up to 160 bytes	R96	1.8	М	М	М	М	
	SMS default alphabet, ME to echo text, packing not required	R96	1.9	М	М	М	M	
	Null length for the text string	R96	1.10	M	М	М	М	
	no response from user	R96	2.1	М	М	М	М	
	UCS2 display	R97	3.1, 3.2		C105	C105	C105	
	UCS2 entry	R97	4.1, 4.2		C105	C105	C105	
	default text for the input	R97	5.1, 5.2		М	М	М	

	icons	R98	6.1,			C108	C108	1
	icons	1130	6.2, 6.3, 6.4			0100	0100	
	help information	R97	7.1		C107	C107	C107	
7	MORE TIME 27.22.4.4	R96	1.1	М	М	М	М	
8	PLAY TONE 27.22.4.5							
	play all tones	R96	1.1	M	M	M	M	
	display alpha	R96	1.1	M	M	M	M	
	user termination	R96	1.1	M	M	M	M	
	superimpose	R96	1.1	M	M	M	M	
	backwards move	R96	1.2	M	M	M	M	
	key not interacting with play tone	K90	1.2	IVI	IVI	IVI	IVI	
	UCS2 display	R97	TBD					
	icons	R98	TBD					
9	POLL INTERVAL 27.22.4.6							
	duration	R96	1.1	М	М	М	М	
10	REFRESH 27.22.4.7							
	SIM initialisation, enabling FDN mode	R96	1.1	М	М	М	М	
	file change notification of FDN file	R96	1.2	М	М	М	M	
	SIM initialisation and file change notification of PLMN	R96	1.3	М	М	M	М	
	SIM initialisation and full file change notification, enabling FDN mode	R96	1.4	M	M	M	M	
	SIM reset	R96	1.5	М	М	М	M	
	SIM Initialisation after SMS-PP	R96	1.6	М	М	M	M	

	data download							
	IMSI Changing procedure	R98	2.1			М	M	
11	SET UP MENU 27.22.4.8							
	Set up, menu selection, replace and remove menu	R96	1.1	М	М	M	M	
	Large menu	R96	1.2	М	М	M	M	
	help information	R97	2.1		C107	C107	C107	
	next action indicator	R97	3.1		М	М	М	
	icons	R98	4.1, 4.2			C108	C108	
	soft key access	R99	5.1				C112	
12	SELECT ITEM 27.22.4.9							
	Mandatory features	R96	1.1	М	М	М	М	
	Large menu	R96	1.2, 1.3, 1.5,1. 6	М	М	M	M	
	Backwards move	R96	1.4	М	М	M	M	
	user termination	R96	1.5	М	М	М	M	
	next action indicator	R97	2.1		М	М	М	
	default selected item	R97	3.1		М	М	М	
	help information	R97	4.1		C107	C107	C107	
	icons	R98	5.1, 5.2			C108	C108	
	Presentation style	R98	6.1, 6.2			М	М	
	Soft keys	R99	7.1				C112	
13	SEND SMS 27.22.4.10							
	Packing not required	R96	1.1, 1.3 1.5	М	М	M	М	
	Packing required	R96	1.2, 1.4	M	М	М	М	

	8 bit data	R96	1.1,	М	М	М	M	
	o bit data	K90	1.2	IVI	IVI	IVI	IVI	
	SMS default alphabet	R96	1.3, 1.4, 1.5	М	М	М	М	
	160 bytes length	R96	1.4, 1.5	М	М	М	М	
	Alpha identifier	R96	1.6, 1.7, 1.8	М	М	М	М	
	UCS2 SMS	R97	2.1		C105	C105	C105	
	icons	R98	3.1, 3.2			C108	C108	
14	SEND SS 27.22.4.11							
	call forward unconditional, all bearers, successful	R96	1.1	М	M	M	M	
	call forward unconditional, all bearers, Return Error	R96	1.2	М	M	M	M	
	call forward unconditional, all bearers, Reject	R96	1.3	М	М	М	M	
	call forward unconditional, all bearers, successful, SS request size limit	R96	1.4	М	М	М	М	
	interrogate CLIR status, successful, alpha identifier limits	R96	1.5	М	M	M	M	
	call forward unconditional, all bearers, successful, null data alpha identifier	R96	1.6	М	М	М	М	
	call forward unconditional, all bearers, successful, icon support	R98	2.1, 2.2, 2.3, 2.4			C108	C108	
	UCS2 display	R97	3.1		C105	C105	C105	
15	SEND USSD 27.22.4.12							
	7-bit data,	R96	1.1	М	M	М	M	

	successful							
	8-bit data, successful	R96	1.2	М	М	М	М	
	UCS2 data, successful	R96	1.3	М	М	М	М	
	7-bit data, unsuccessful	R96	1.4	М	М	М	М	
	7-bit data, unsuccessful	R96	1.5	М	М	М	М	
	256 octets, 7-bit data, successful, long alpha identifier	R96	1.6	М	М	М	М	
	7-bit data, successful, no alpha identifier	R96	1.7	М	М	М	M	
	7-bit data, successful, null length alpha identifier	R96	1.8	М	М	М	M	
	icons	R98	2.1, 2.2, 2.3, 2.4			C108	C108	
	UCS2	R97	3.1		C105	C105	C105	
16	SET UP CALL 27.22.4.13							
	Call confirmed by the user and connected	R96	1.1	М	M	М	M	
	call rejected by the user	R96	1.2	М	М	М	М	
	redial	R96	1.3	М	М	М	М	
	putting all other calls on hold, ME busy	R96	1.4	М	М	М	M	
	disconnecting all other calls, ME busy	R96	1.5	М	М	М	M	
	only if not currently busy on another call, ME busy	R96	1.6	М	M	M	M	
	putting all other calls on hold, call hold is not allowed	R96	1.7	М	М	М	М	
	Capability configuration	R96	1.8	C1 01	C101	C101	C101	

	long dialing number string	R96	1.9	М	М	М	М	
	long first alpha identifier	R96	1.10	М	М	М	М	
	Called party subaddress	R96	1.11	М	М	M	М	
	maximum duration for the redial mechanism	R96	1.12	M	М	М	M	
	second alpha identifier	R98	2.1			M	М	
	UCS2 Display	R97	TBD					
	icons	R98	3.1,3. 2, 3.3, 3.4			C108	C108	
17	POLLING OFF 27.22.4.14	R96	1.1	М	М	M	М	
18	PROVIDE LOCAL INFO 27.22.4.15							
	location information	R96	1.1	М	М	M	М	
	IMEI	R96	1.2	М	М	М	М	
	network measurement results and BCCH channel list	R98	1.3			М	М	
	Date, time and time zone	R98	1.4			М	М	
	language setting	R99	1.5				М	
	Timing advance	R99	1.6				М	
19	SET UP EVENT LIST							
	27.22.4.16							
	Set up call connected event	R97	1.1		M	М	М	
	Replace by new event list	R97	1.2		М	M	М	
	Remove event	R97	1.3		М	М	М	
	Remove Event on ME Power Cycle	R97	1.4		M	M	М	
			1		1	i		<u> </u>

20	PERFORM CARD APDU					
	27.22.4.17					
	Additional card inserted, Select MF and Get Response	R98	1.1	C109	C109	
	Additional card inserted, Select DF GSM, Select EF PLMN, Update Binary, Read Binary on EF PLMN	R98	1.2	C109	C109	
	Additional card inserted, card powered off	R98	1.3	C109	C109	
	No card inserted, card powered off	R98	1.4	C109	C109	
	Invalid card reader identifier	R98	1.5	C109	C109	
	Detachable reader	R98	2.1	C116	C116	
24	DOWED OF					
21	POWER OFF CARD					
	27.22.4.18					
	Additional card inserted	R98	1.1	C109	C109	
	No card inserted	R98	1.2	C109	C109	
	Detachable reader	R98	2.1	C116	C116	
22	POWER ON CARD 27.22.4.19					
	Additional card inserted	R98	1.1	C109	C109	
	No ATR	R98	1.2	C109	C109	
	No card inserted	R98	1.3	C109	C109	
	Detachable reader	R98	2.1	C116	C116	
23	GET READER STATUS					

	27.22.4.20					
	Additional card inserted, card powered	R98	1.1	C109	C109	
	Additional card inserted, card not powered	R98	1.2	C109	C109	
	Additional card inserted, card not present	R98	1.3	C109	C109	
	Detachable reader	R98	2.1	C116	C116	
24	TIMER MANAGEMENT 27.22.4.21.1					
	Start timer 1 several times, get the current value of the timer and deactivate the timer successfully	R98	1.1	M	M	
	Start timer 2 several times, get the current value of the timer and deactivate the timer successfully	R98	1.2	М	M	
	Start timer 8 several times, get the current value of the timer and deactivate the timer successfully	R98	1.3	M	M	
	Try to get the current value of a timer which is not started: action in contradiction with the current timer state	R98	1.4	М	M	
	Try to deactivate a timer which is not started: action in contradiction with the current timer state	R98	1.5	M	M	
	Start 8 timers successfully	R98	1.6	M	М	
25	ENVELOPPE TIMER EXPIRATION					

	27.22.4.21.2					1
			2.4			
	Pending proactive SIM command	R98	2.1	M	М	
	SIM application toolkit busy	R98	2.2	M	М	
26	SET UP IDLE MODE TEXT					
	27.22.4.22					
	Display idle mode text	R98	1.1	M	М	
	Replace idle mode text	R98	1.2	M	М	
	Remove idle mode test	R98	1.3	М	М	
	Competing information on ME display	R98	1.4	М	М	
	ME powered cycled	R98	1.5	M	М	
	Refresh with SIM initialisation	R98	1.6	M	М	
	Large text string	R98	1.7	М	М	
	Followed by a Display Text	R98	1.8	M	М	
	Followed by a Play Tone	R98	1.9	M	М	
	icons	R98	2.1, 2.2, 2.3, 2.4	C108	C108	
	UCS2 display	R98	3.1	C105	C105	
27	RUN AT COMMAND					
	27.22.4.23					
	No alpha Identifier	R98	1.1	C110	C110	
	null data alpha identifier presented	R98	1.2	C110	C110	
	alpha identifier presented	R98	1.3	C110	C110	
	icons	R98	2.1, 2.2, 2.3, 2.4, 2.5	C114	C114	
						1

28	SEND DTMF 27.22.4.24					
	A call has been successfully established before the beginning of the test	R98	1.1	М	M	
	alpha identifier	R98	1.2, 1.3	М	М	
	Mobile is not in a speech call	R98	1.4	M	М	
	Icons	R98	2.1, 2.2, 2.3	C108	C108	
	UCS2 display	R98	3.1	C105	C105	
29	LANGUAGE NOTIFICATION 27.22.4.25					
	Specific language notification	R99	1.1		M	
	Non specific language notification	R99	1.2		М	
30	LAUNCH BROWSER 27.22.4.26					
	No session already launched : Connect to the default URL	R99	1.1		C111	
	connect to the specified URL, alpha identifier length=0	R99	1.2		C111	
	Browser identity, no alpha identifier	R99	1.3		C111	
	one bearer specified and gateway/proxy identity	R99	1.4		C111	
	several bearers specified, gateway/proxy id specified	R99	1.5		C111	
	Interaction with	R99	2.1,		C111	

	current session		2.3		1	<u> </u>	
		R99	3.1			C117	
	UCS2 display	K99	3.1			C117	
	icons	R99	4.1, 4.2			C115	
31	OPEN CHANNEL						
	27.22.4.27						
	Immediate link establishment, CSD, 9600 bps	R99	1.1, 1.2, 1.3, 1.4, 1.5, 1.6			C113	
	immediate link establishment, CSD, 9600 bps, performed with modification	R99	1.7			C113	
	immediate link establishment, CSD, Network currently unable to process command	R99	1.8			C113	
	immediate link establishment, CSD, No channel available	R99	1.9			C113	
	ME busy	R99	1.10			М	
32	CLOSE CHANNEL 27.22.4.28						
	successful	R99	1.1			C113	
	with an invalid channel identifier	R99	1.2			C113	
	on an already closed channel	R99	1.3			C113	
33	RECEIVE DATA 27.22.4.29						
	already opened channel	R99	1.1			C113	
34	SEND DATA						
	27.22.4.30						

	immediate mode	R99	1.1				C113	
	Store mode	R99	1.2				C113	
	Store mode, Tx buffer fully used	R99	1.3				C113	
	2 consecutive SEND DATA Store mode	R99	1.4				C113	
	immediate mode with a bad channel identifier	R99	1.5				C113	
	immediate mode, Proactive SIM session terminated by the user	R99	1.6				C113	
35	GET CHANNEL STATUS							
	27.22.4.31							
	without any BIP channel opened	R99	1.1				C113	
	with a BIP channel currently opened	R99	1.2				C113	
	after a link dropped	R99	1.3				C113	
36	DATA DOWNLOAD TO SIM 27.22.5							
37	SMS-PP DATA DOWNLOAD 27.22.5.1							
	General data coding, SIM responds with '90 00'	R96	1.1	M	М	M	M	
	SIM responds with '91 XX'	R96	1.2	М	М	М	М	
	More time	R96	1.3	M	M	M	M	
	8 bit alphabet	R96	1.4	M	M	M	M	
	Data coding / message class	R96	1.5, 1.6	M	М	М	М	
38	SMS-CB DATA DOWNLOAD							
	27.22.5.2							
			•	•	•	•	•	

	1				•			
	ME does not display message	R96	1.1	M	M	M	M	
	More time	R96	1.2	М	М	М	М	
	ME displays message	R96	1.3	М	М	M	M	
39	CALL CONTROL BY SIM							
	27.22.6							
	Procedure for MO calls (Cell identity in envelope call control)	R97	1.1 to 1.14		M	M	M	
	Prodedure for SS (Cell identity in envelope call control)	R97	2.1, 2.2, 2.3, 2.4		M	М	М	
	Interaction with FDN (Cell identity in envelope call control)	R97	3.1, 3.2, 3.3, 3.5		M	M	M	
	Support of BDN service (Cell identity in envelope call control)	R97	4.1, 4.2, 4.3, 4.4		М	М	М	
	MO SMS control by SIM	R97	TBD					
40	EVENT DOWNLOAD							
	27.22.7							
	27.22.7.1 : MT call event	R97	1.1		М	М	М	
	27.22.7.2.1 : call connected event	R97	1.1		М	М	М	
	27.22.7.2.2 : ME supporting SET UP CALL	R97	2.1		М	М	М	
	27.22.7.3 : call disconnected event	R97	1.1		M	М	M	
	27.22.7.4 : location status event	R97	1.1		M	M	М	
	27.22.7.5 : user activity event	R97	1.1		М	М	М	
	27.22.7.6 : idle screen available	R97	1.1		M	М	М	

event

0.1

0.2

27.22.7.7.1 : Card reader status normal	R98	1.1			C109	C109	
27.22.7.7.2 : Detachable card reader	R98	2.1			C116	C116	
27.22.7.8 : language selection event	R99	1.1				М	
27.22.7.9 : Browser termination event	R99	1.1				C111	
27.22.7.10 : Data available event	R99	1.1				C113	
27.22.7.11 : Channel status event	R99	1.1				C113	
C101	IF A.1/1 THEN M ELSE N/A			O_Cap_Cor	nf	_	
C102, C103	void						
C104	IF A.1/2 T	HEN M EL	SE N/A		O_Sust_text	t	
C105	IF A.1/3 T	HEN M EL	SE N/A		O_Ucs2		
C106	IF A.1/4 T	HEN M EL	SE N/A		O_Ext_Str		
C107	IF A.1/5 T	HEN M EL	SE N/A		O_Help		
C108	IF A.1/6 T	HEN (O.1 0	OR O.2) ELSE	E N/A	O_Icons		
C109	IF A.1/7 T	HEN M EL	SE N/A		O_Dual_Slot		
C110	IF A.1/9 T	HEN M EL	SE N/A		O_Run_At		
C111	IF A.1/10	THEN M E	LSE N/A		O_LB		
C112	IF A.1/11	THEN M E	LSE N/A		O_Soft_key		
C113	IF A.1/12	THEN M E	LSE N/A		O_BIP		
C114	IF C110 A	ND C108 T	THEN M ELSI	E N/A	O_Run_At	AND O_Icon	ıs
C115	IF C111 A	ND C108 T	THEN M ELSI	E N/A	A O_LB AND O_Icons		
C116	IF C105 A	ND A.1/8 T	THEN M ELS	E N/A	O_Dual_Slo	ot AND O_D	etach_Rdr
C117	IF C111 A	ND C105 T	THEN M ELSI	E N/A	O_LB AND	O_Ucs2	

3.5 Conventions for mathematical notations

The conventions for mathematical notations specified in 3GPP TS 11.10-1 [12] clause 3.4 shall apply, unless otherwise specified in the present clause.

M (where x is the expected sequence number value)

x.1B M (where x is the expected sequence number value)

IF (the ME supports icons as defined in record 1 of EF(IMG), tests x.1A M ELSE tests

IF the ME supports icons as defined in record 2 of EF_(IMG), tests x.2A M ELSE x.2B

3.6 Conventions on electrical terms

The conventions on electrical terms specified in 3GPP TS 11.10-1 [12] clause 3.5 shall apply, unless otherwise specified in the present clause.

3.7 Terms on test conditions

The terms on test conditions specified in 3GPP TS 11.10-1 [12] clause 3.6 shall apply, unless otherwise specified in the present clause.

4 Test Equipment

The test equipment is specified in 3GPP TS 11.10-1 [12] clause 4.

5 Testing methodology in general

5.1 Testing of optional functions and procedures

Any function or procedure which is optional, as indicated in the present document, may be subject to a conformance test if it is implemented in the ME.

5.2 Test interfaces and facilities

The test interfaces and facilities specified in 3GPP TS 11.10-1 [12] clause 5.2 shall apply, unless otherwise specified in the present clause.

The SIM interface provides the main test interface for the purpose of performing conformance tests.

5.3 Different protocol layers

The different protocol layers specified in 3GPP TS 11.10-1 [12] clause 5.3 shall apply, unless otherwise specified in the present clause.

5.4 Information to be provided by the apparatus supplier

The information to be provided by the apparatus supplier specified in 3GPP TS 11.10-1 [12] clause 5.4 shall apply, unless otherwise specified in the present clause.

In addition, the apparatus supplier shall provide the information with respect the Supported Option Table A.1.

5.5 Definitions of transmit and receive times

The definitions of transmit and receive times specified in 3GPP TS 11.10-1 [12] clause 5.5 shall apply, unless otherwise specified in the present clause.

6 Reference test methods

The reference test methods specified in 3GPP TS 11.10-1 [12] clause 6 shall apply, unless otherwise specified.

7 Implicit testing

For some GSM features conformance is not verified explicitly in this document. This does not imply that correct functioning of these features is not essential, but that these are implicitly tested to a sufficient degree in other tests.

It should be noted that for these features some aspects have to be and are explicitly tested, e.g. the ability to switch between 3v and 5v operation.

Some SIM features will be explicitly tested as result of other tests. These should be identified for the following reason:

- To identify the areas of overlap and thus provide a more efficient testing.

8 Measurement uncertainty

The measured value relating to the corresponding limit shall be used to determine whether or not a terminal equipment meets the requirement. (ETR 028 annex B).

This process is often referred to as "shared risk".

9 Format of tests

In general the following basic format for tests is used:

27.22.X.X. Tested command

27.22.X.X.1. Command tested in «environment #1 » (NORMAL, ICONS, UCS2 ...)

27.22.X.X. 1.1 Definition and applicability

This section refers back to Section 3.2.2..

27.22.X.X. 1.2 Conformance requirement

Only if required, this section details the necessary core specification references.

27.22.X.X. 1.3 Test Purpose

This section details the purpose of the test.

27.22.X.X. 1.4 Method of test

27.22.X.X. 1.4.1. Initial Conditions

If present this section defines the initial conditions to be established before running each test sequence.

27.22.X.X. 1.4.2 Procedure

This section details the test procedure. Each test sequence shall be carried out independently unless otherwise stated.

• Sequence 1.1 (further initial conditions, added here)

Command 1.1.1
TERMINAL RESPONSE1.1.1A or 1.1.1B
Command 1.1.2

TERMINAL RESPONSE1.1.2

PROACTIVE COMMAND 1.1.1

TERMINAL RESPONSE 1.1.1A

TERMINAL RESPONSE 1.1.1B

PROACTIVE COMMAND 1.1.2

TERMINAL RESPONSE 1.1.2

• Sequence 1.2

Command 1. 2.1

TERMINAL RESPONSE1.2.1

Command 1.2.2

TERMINAL RESPONSE1.2.2 (same as TERMINAL

RESPONSE1.2.1)

Command 1.2.3

TERMINAL RESPONSE1.2.3

PROACTIVE COMMAND 1.2.1

PROACTIVE COMMAND 1.2.2

PROACTIVE COMMAND 1.2.3

TERMINAL RESPONSE 1.2.1, TERMINAL RESPONSE 1.2.2

TERMINAL RESPONSE 1.2.3

• Sequence 1.3

Command 1.3.1

TERMINAL RESPONSE1.3.1

PROACTIVE COMMAND1.3.1

TERMINAL RESPONSE1.3.1

27.22.X.X.1.5 Test Requirement

This section details the conditions to be met for successful completion of the test.

27.22.X.X.2. Command tested in « environment #2 » (NORMAL, ICONS, UCS2 ...)

27.22.X.X. 2.1 Definition and applicability

27.22.X.X. 2.2 Conformance requirement

27.22.X.X. 2.3 Test Purpose

27.22.X.X. 2.4 Method of test

27.22.X.X. 2.4.1.1 Initial Conditions

27.22.X.X. 2.4.1.2 Procedure

• Sequence 2.1

Command 2.1.1
TERMINAL RESPONSE2.1.1A or 2.1.1B
Command 2.1.2
TERMINAL RESPONSE2.1.2

PROACTIVE COMMAND 2.1. 1

TERMINAL RESPONSE 2.1.1A

TERMINAL RESPONSE 2.1.1B

PROACTIVE COMMAND 2.1.2

TERMINAL RESPONSE 2.1.2

• Sequence 2.2

Command 2.2.1
TERMINAL RESPONSE2.2.1
Command 2.2 .2
TERMINAL RESPONSE2.2.2
(same as TERMINAL
RESPONSE2.2.1)
Command 2.2.3
TERMINAL RESPONSE2.2.3

PROACTIVE COMMAND2.2.1

PROACTIVE COMMAND2.2.2

PROACTIVE COMMAND2.2 .3

Coding TERMINAL RESPONSE2.2.1, TERMINAL RESPONSE2.2.2

Coding TERMINAL RESPONSE2.2.3

27.22.X.X.2.5 Test Requirement

10 Generic call set up procedures

The generic call set up procedure specified in 3GPP TS 11.10-1 [12] clause 10 shall apply, unless otherwise specified in the present clause.

11 - 26 Not used

27 Testing of the SIM/ME interface

This clause is an addition to 3GPP TS 11.10- [12] clause 27 to confirm the correct interpretation of the SIM Application Toolkit commands and the correct operation of the Toolkit facilities.

The definitions, declarations and default values specified in 3GPP TS 11.10-1 [12] clause 27 shall apply, unless otherwise specified in the present clause.

A SIM Simulator with the appropriate SIM Application Toolkit functionality will be required. The SIM data defined below shall be used for all test cases unless otherwise specified within the test case.

27.1 - 27.21 Not used

27.22 SIM Application Toolkit

General Test Purpose

Testing of functional conformance to SIM Application Toolkit commands, including pro-active SIM commands.

All facilities given by the TERMINAL PROFILE as supported, for which tests exist in this specification, shall be tested.

Many of the proactive SIM commands include an alpha identifier data object. This is intended to be a short one or two word identifier for the ME to optionally display on the screen along with any other indications, at the same time as the ME performs the SIM command.

NOTE: The sequence of SIM Application Toolkit commands are specific to the Toolkit Application being executed within the SIM, hence sequential testing of commands is not possible. The testing will therefore have to be performed on a command by command basis.

Definition of default values for SIM Application Toolkit testing

A SIM containing the following default values is used for all tests of this section unless otherwise stated.

For each item, the logical default values and the coding within the elementary files (EF) of the SIM follow.

NOTE1: Bx represents byte x of the coding

NOTE2: Unless otherwise defined, the coding values are hexadecimal.

The FDN, BDN and SMS-MO Control features are disabled.

EFSST (SIM Service Table)

Logically: Abbreviated Dialling Numbers allocated and activated

Extension 1 allocated and activated

Fixed Dialling Numbers allocated and activated

Extension 2 allocated and activated

Cell Broadcast Message Identifier allocated and activated Data download via SMS-CB allocated and activated Data download via SMS-PP allocated and activated

Menu selection allocated and activated Call control allocated and activated Proactive SIM allocated and activated

Cell Broadcast Message Identifier Ranges allocated and activated

Barred Dialling Numbers allocated and activated

Extension4 allocated and activated

Coding: B1 B2 B3 B4

xx1111xx xxxxxxx xx1111xx xxxx11xx (binary)

B5 B6 B7 B8

B9

xxxxxxxx (binary)

EF_{Phase} (SIM Phase Identification)

Logically: Phase 2+

Coding: '03'

EF_{IMSI} (International Mobile Subscriber Identity)

Logically:

Length: 8 bytes

IMSI: 001 01 0123456789

Coding: '08 09 10 10 10 32 54 76 98'

EF_{CBMI} (Cell Broadcast Message Identifier)

Logically:

Cell Broadcast Message Identifier 1: '0C 0C'

Coding: 0C 0C FF .. FF

EF_{CBMID} (Cell Broadcast Message Identifier for Data Download)

Logically:

Cell Broadcast Message Identifier 1: '10 01'

Coding: 10 01 FF .. FF

EF_{FDN} (Fixed Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "ABC"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 123
CCI: None
Ext2: None

Coding: В1 B2 В3 B4 **B32 B33 B34 B35 B36 B37 B46** Record 1: FF FF 41 42 43 FF FF 03 81 21 F3

Record 2:

Length of alpha identifier: 32 characters
Alpha identifier: "DEF"
Length of BCD number: "04"

TON and NPI: Telephony and Unknown

Dialled number: 9876 CCI: None Ext2: None

Codina: В1 B2 В3 B4 B32 B33 B34 **B35** B36 **B37** B46 Record 1: 44 45 46 FF FF 03 81 89 67 FF FF ...

EF_{BDN} (Barred Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "CBA"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 321
CCI: None
Ext4: None
Comparison Method Info: None

Coding: В1 B2 В3 B4 B32 B33 B34 B35 B36 **B37** B46 Record 1: 43 42 FF FF 03 23 F1 FF 81 ...

EF_{ECC} (Emergency Call Codes)

Logically:

Emergency Call Code 1: '1020'

Coding: 01 02 FF

EF_{SMSP} (Short message service parameters)

Logically:

Record 1:

Record length: 28 bytes

Parameter Indicators:

TP-Destination Address:
TS-Service Centre Address:
TP-Protocol Identifier:
TP-Data Coding Scheme:
TP-Validity Period:
Parameter absent
Parameter absent
Parameter absent
Parameter absent

TS-Service Centre Address:

TON: International Number

NPI: "ISDN / telephone numbering plan"

Dialled number string: "112233445566778"

Coding: В3 B13 B14 B15 B16 B17 B18 B19 B20 B21 B22 **B23** Record 1: FF FF FF F8 FD 09 91 11 22 33 44 55 66 77

B24 B25 B26 B27 B28 FF FF FF FF

27.22.1 Initialisation of SIM Application Toolkit Enabled SIM by SIM Application Toolkit Enabled ME (Profile Download)

27.22.1.1 Definition and applicability

See Section 3.2.2.

27.22.1.2 Conformance requirement

The ME shall support the PROFILE DOWNLOAD command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile).

27.22.1.3 Test Purpose

To verify that the ME sends a TERMINAL PROFILE command in accordance with the above requirements.

27.22.1.4 Method of test

27.22.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator. All elementary files are coded as the default Toolkit personalisation, with the CHV1 enabled.

27.22.1.4.2 Procedure

Expected Sequence 1 (PROFILE DOWNLOAD)

Step	Direction	Message / Action	Comments
1	USER → ME	Power on ME	
2	$\begin{array}{c} ME \ \rightarrow \\ USER \end{array}$	PIN entry request	
3	$\begin{array}{c} USER \ \rightarrow \\ ME \end{array}$	Enter "1111"	
4	$MF \rightarrow SIM$	VERIFY CHV1 1.1A	[CHV1 code: "1111"]
5		VERIFY CHV ATTEMPT UNSUCCESSFUL 1.1A	
6	$\begin{array}{c} ME \ \rightarrow \\ USER \end{array}$	PIN entry request	
7	$\begin{array}{c} USER \ \to \\ ME \end{array}$	Enter "1234"	
8	$ME \rightarrow SIM$	VERIFY CHV1 1.1B	[CHV1 code: "1234"]
9	$SIM \to ME$	NORMAL ENDING OF COMMAND 1.1A	
10		SELECT EF PHASE 1.2	
11		READ BINARY (EF PHASE) 1.3	Expected PHASE = 03 returned by SIM
12		TERMINAL PROFILE 1.4	PROFILE DOWNLOAD
13	SIM → ME	NORMAL ENDING OF COMMAND 1.1A	
14	$ME \to SIM$	SELECT EF IMSI 1.5	
		or SELECT EF LOCI 1.6	

VERIFY CHV1: 1.1A

Logically:

Coding:

APDU: CLA=A0 INS=20 P1=00 P2=01 P3=08

DATA IN: 31 31 31 FF FF FF FF

VERIFY CHV1 ATTEMPT UNSUCCESSFUL: 1.1A

Logically:

Coding:

SW1=98 SW2=04

VERIFY CHV1: 1.1B

Logically:

Coding:

APDU: CLA=A0 INS=20 P1=00 P2=01 P3=08

DATA IN: 31 32 33 34 FF FF FF

NORMAL ENDING OF COMMAND: 1.1A

Logically:

Coding:

SW1=90 SW2=00

SELECT EF PHASE: 1.2

Logically:

Coding:

APDU: CLA=A0 INS=A4 P1=00 P2=00 P3=02

DATA IN: 6F AE

Response

SW1=9F SW2=0F

SW1= 9F , SW2= 0F

READ BINARY (EF PHASE): 1.3

Logically:

Coding:

APDU: CLA=A0 INS=B0 P1=00 P2=00 P3=01

Response

DATA OUT: 03

SW1=90 SW2=00

TERMINAL PROFILE: 1.4

Logically:

Coding:

APDU: CLA=A0 INS=10 P1=00 P2=01 P3=XX

DATA IN: YY ZZ ...

With XX representing the length of the following DATA IN depending on the SIM Toolkit commands supported by the ME, and with YY, ZZ, ... representing here the bytes of the TERMINAL PROFILE data, as specified in the 11.14 [15], clause 5.2

SELECT EF IMSI: 1.5

Logically:

Coding:

APDU: CLA=A0 INS=A4 P1=00 P2=00 P3=02

DATA IN: 6F 07

SELECT EF LOCI: 1.6

Logically:

Coding:

APDU: CLA=A0 INS=A4 P1=00 P2=00 P3=02

DATA IN: 6F 7E

27.22.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.2 Contents of the TERMINAL PROFILE command

27.22.2.1 Definition and applicability

See Section 3.2.2.

27.22.2.2 Conformance requirement

The ME shall support the PROFILE DOWNLOAD command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile).

27.22.2.3 Test Purpose

- 1. Verify that the TERMINAL PROFILE indicates that Profile Download facility is supported.
- 2. Record which SIM Application Toolkit facilities are supported by the ME, to determine which subsequent tests are required.

27.22.2.4 Method of Test

27.22.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator. All elementary files are coded as the default SIM Application Toolkit personalisation.

27.22.1.4.2 Procedure

- a) The ME is powered on.
- b) After the ME sends the TERMINAL PROFILE command to the SIM Simulator, the SIM Simulator shall record the content of the TERMINAL PROFILE.
- c) The SIM Simulator shall return SW1 / SW2 of '90 00'.

The test is terminated upon the ME sending the TERMINAL PROFILE command to the SIM Simulator.

27.22.2.5 Test Requirement

1) After step a) the ME shall send the TERMINAL PROFILE command to the SIM Simulator with bit 1 of the first byte set to 1 (facility supported by ME).

27.22.3 Servicing of Proactive SIM Commands

27.22.3.1 Definition and applicability

See Section 3.2.2.

27.22.3.2 Conformance requirement

On detection of a pending SIM Application Toolkit command from the SIM the ME shall perform the FETCH command to retrieve the proactive SIM command. The result of the executed command shall be transmitted from the ME to the SIM within a TERMINAL RESPONSE command.

The MORE TIME proactive command is used in this test. The ME shall have knowledge of this command, but may not support this SIM Application Toolkit facility.

3GPP TS 11.14 [15] clause 6.3.

27.22.3.3 Test Purpose

To verify that the ME uses the FETCH command to obtain the proactive SIM command, after detection of a pending proactive SIM command. The pending proactive SIM command is indicated by the response parameters '91 xx' from the SIM.

To verify that the ME transmits the result of execution of the proactive SIM command to the SIM in the TERMINAL RESPONSE command.

27.22.3.4 Method of test

27.22.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as the SIM Application Toolkit default.

The SIM Simulator is configured to indicate that a proactive SIM command is pending.

The SIM Simulator is configured to monitor the SIM - ME interface.

27.22.3.4.2 Procedure

- a) The ME is powered on.
- b) After the ME has performed the PROFILE DOWNLOAD procedure, the SIM Simulator indicates that a Proactive SIM Command is pending with SW1 / SW2 of '91 0B'.
- c) After the ME sends the FETCH command to the SIM Simulator, the SIM Simulator returns Proactive SIM Command 2.1: MORE TIME.

27.22.3.5 Test Requirement

- 1) After step b) the ME shall send the FETCH command to the SIM.
- 2) After step c) the ME shall send the TERMINAL REPONSE command with command number "01", type of command "02" and command qualifier "00".

27.22.4 Proactive SIM Commands

27.22.4.1 DISPLAY TEXT

27.22.4.1.1 DISPLAY TEXT (Normal)

27.22.4.1.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.1.1.2 Conformance requirements

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.1 (Display Text), clause 6.5.4 (Icon Identifier), clause 6.6.1 (Display Text), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.31 (Icon identifier).

27.22.4.1.1.3 Test Purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.1.4 Method of test

27.22.4.1.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.1.4.2 Procedure

Expected Sequence 1.1 (DISPLAY TEXT normal priority, Unpacked 8 bit data for Text String, successful)

5	Step	Direction	MESSAGE / Action	Comments	1
---	------	-----------	------------------	----------	---

1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: DISPLAY TEXT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : DISPLAY TEXT 1.1.1	[Normal priority, wait for user to clear message, unpacked, 8 bit data]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Toolkit Test 1"	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	Clear Message	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : DISPLAY TEXT 1.1.1	[Command performed successfully]
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 1.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Coding:

BER-TLV: D0 1A 81 03 01 21 80 82 02 81 02 8D 6F 74 0F 04 54 6F 6C 6B 69 20 54 65 73 20 31

TERMINAL RESPONSE: DISPLAY TEXT 1.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 1.2 (DISPLAY TEXT normal priority, Unpacked 8 bit data for Text String, screen busy)

Step	Direction	MESSAGE / Action	Comments

1	$USER \to$	Set the ME screen to a display	The ME will be set to a mode so that normal	ì
	ME	mode other than the normal stand-	priority text commands shall be rejected.	ı
		by display		i
2	$SIM \to ME$	PROACTIVE COMMAND		i
		PENDING: DISPLAY TEXT 1.2.1		i
3	$\text{ME} \to \text{SIM}$	FETCH		ı
4	$SIM \to ME$	PROACTIVE COMMAND:	[Normal priority]	ı
		DISPLAY TEXT 1.2.1	·	i
5	ME o	No change of the currently being		ı
	USER	used display.		ı
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[ME currently unable to process command -	i
		DISPLAY TEXT 1.2.1	screen busy]	i
7	$SIM \to ME$	PROACTIVE SIM SESSION		i
		ENDED		1

PROACTIVE COMMAND: DISPLAY TEXT 1.2.1: same as 1.1.1

TERMINAL RESPONSE: DISPLAY TEXT 1.2.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional information: Screen is busy

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 02 20 01

Expected Sequence 1.3 (DISPLAY TEXT, high priority, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	The ME screen is in a mode other than the
		PENDING: DISPLAY TEXT 1.3.1	normal stand by display.
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	[High priority]
		DISPLAY TEXT 1.3.1	
4	ME o	Display "Toolkit Test 2"	
	USER		
5	$USER \to$	Clear Message	
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	
		DISPLAY TEXT 1.3.1	
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
8	$USER \to$	Set the ME screen back to normal	
	ME	stand-by display	

PROACTIVE COMMAND: DISPLAY TEXT 1.3.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: high priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 2"

Coding:

BER-TLV: D0 1A 81 03 01 21 82 02 81 02 8D 81 0F 04 54 6F 6F 6C 6B 69 74 20 54 65

73 74 20 32

TERMINAL RESPONSE: DISPLAY TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: high priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 81 82 02 82 81 83 01 00

Expected Sequence 1.4 (DISPLAY TEXT, Packed, SMS default alphabet, successful)

	Step	Direction	MESSAGE / Action	Comments
Ī	1	$SIM \to ME$	PROACTIVE COMMAND	
			PENDING: DISPLAY TEXT 1.4.1	
	2	$ME \to SIM$	FETCH	
	3	$SIM \to ME$	PROACTIVE COMMAND:	[Packed, SMS default alphabet]
			DISPLAY TEXT 1.4.1	
	4	ME o	Display "Toolkit Test 3"	
		USER		
	5	$USER \to$	Clear Message	
		ME		
	6	$ME \to SIM$	TERMINAL RESPONSE :	[Command performed successfully]
			DISPLAY TEXT 1.4.1	

PROACTIVE COMMAND: DISPLAY TEXT 1.4.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: packed, SMS default alphabet

Text: "Toolkit Test 3"

Coding:

BER-TLV: D0 19 81 03 01 21 80 82 02 81 02 8D

0E 00 D4 F7 9B BD 4E D3 41 D4 F2 9C

0E 9A 01

TERMINAL RESPONSE: DISPLAY TEXT 1.4.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 1.5 (DISPLAY TEXT, Clear message after delay, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	[Clear message after a delay]
		DISPLAY TEXT 1.5.1	
4	ME o	Display "Toolkit Test 4" and clear	
	USER	this message after a short delay	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 1.5.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 1.5.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 4"

Coding:

BER-TLV: D0 1A 81 03 01 21 00 82 02 81 02 8D

0F 04 54 6F 6F 6C 6B 69 74 20 54 65 73 74 20 34

TERMINAL RESPONSE: DISPLAY TEXT 1.5.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 00 82 02 82 81 83 01 00

Expected Sequence 1.6 (DISPLAY TEXT, Text string with 160 bytes, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Text string with 160 bytes – maximum for
		DISPLAY TEXT 1.6.1	non extension text]
4	ME o	Display "This command instructs	
	USER	the ME to display a text message.	
		It allows the SIM to define the	
		priority of that message, and the	
		text string format. Two types of	
		prio"	
5	$USER \to$	Clear Message	
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	Command performed successfully
		DISPLAY TEXT 1.6.1	

PROACTIVE COMMAND: DISPLAY TEXT 1.6.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data

Text: "This command instructs the ME to display a text message. It allows the

SIM to define the priority of that message, and the text string format. Two

types of prio"

Coding:

BER-TLV:	D0	81	AD	81	03	01	21	80	82	02	81	02
	8D	81	A1	04	54	68	69	73	20	63	6F	6D
	6D	61	6E	64	20	69	6E	73	74	72	75	63
	74	73	20	74	68	65	20	4D	45	20	74	6F
	20	64	69	73	70	6C	61	79	20	61	20	74
	65	78	74	20	6D	65	73	73	61	67	65	2E
	20	49	74	20	61	6C	6C	6F	77	73	20	74
	68	65	20	53	49	4D	20	74	6F	20	64	65
	66	69	6E	65	20	74	68	65	20	70	72	69
	6F	72	69	74	79	20	6F	66	20	74	68	61
	74	20	6D	65	73	73	61	67	65	2C	20	61
	6E	64	20	74	68	65	20	74	65	78	74	20
	73	74	72	69	6E	67	20	66	6F	72	6D	61
	74	2E	20	54	77	6F	20	74	79	70	65	73
	20	6F	66	20	70	72	69	6F				

TERMINAL RESPONSE: DISPLAY TEXT 1.6.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 1.7 (DISPLAY TEXT, Backward move in SIM session, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		DISPLAY TEXT 1.7.1	
4	ME o	Display " <go-backwards"< th=""><th></th></go-backwards"<>	
	USER	·	

5	$USER \to$	Indicate the need to go backwards		l
	ME	in the proactive SIM application		l
		session		l
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Backward move in the proactive SIM session	l
		DISPLAY TEXT 1.7.1	requested by the user]	l

PROACTIVE COMMAND: DISPLAY TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

Coding:

03 BER-TLV: D0 1A 81 01 21 02 02 8D 82 81 0F 04 3C 47 4F 2D 42 41 43 4B 57 41

52 44 53 3E

TERMINAL RESPONSE: DISPLAY TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 11

Expected Sequence 1.8 (DISPLAY TEXT, session terminated by user)

	Step	Direction	MESSAGE / Action	Comments
ĺ	1	$SIM \to ME$	PROACTIVE COMMAND	
			PENDING: DISPLAY TEXT 1.8.1	
	2	$ME \to SIM$	FETCH	
	3	$SIM \to ME$	PROACTIVE COMMAND:	
			DISPLAY TEXT 1.8.1	
	4	ME o	Display " <abort>"</abort>	
		USER		

5	$USER \to$	Indicate the need to end the		
	ME	proactive SIM application session		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Proactive SIM session terminated by the	
		DISPLAY TEXT 1.8.1	user]	
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION		
		ENDED		

PROACTIVE COMMAND: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data Text: "<ABORT>"

Coding:

BER-TLV: D0 13 81 03 01 21 80 82 02 81 02 8D 08 04 3C 41 42 4F 52 54 3E

TERMINAL RESPONSE: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 10

Expected Sequence 1.9 (DISPLAY TEXT, icon and text to be displayed, no text string given, not understood by ME)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	Including icon identifier, icon shall be
		DISPLAY TEXT 1.9.1	displayed together with the alpha text string,
			but no text string given

4	,	TERMINAL RESPONSE :	[Command data not understood by ME (clause 6.5.4)]	1
5		PROACTIVE SIM SESSION ENDED	(314435 515.17)]	1

PROACTIVE COMMAND: DISPLAY TEXT 1.9.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Contents: null data object

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 1 in EF}_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV: D0 0F 81 03 01 21 80 82 02 81 02 8D 00 9E 02 01 01

TERMINAL RESPONSE: DISPLAY TEXT 1.9.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 32

27.22.4.1.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 to 8.

27.22.4.1.2 DISPLAY TEXT (Support of "No response from user")

27.22.4.1.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.1.2.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.1 (Display Text), clause 6.6.1 (Display Text), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme)

27.22.4.1.2.3 Test Purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.2.4 Method of test

27.22.4.1.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.1.2.4.1 Procedure

Expected Sequence 2.1 (DISPLAY TEXT, no response from user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
		DISPLAY TEXT 2.1.1	message, unpacked, 8 bit data]
4	ME o	Display " <time-out>"</time-out>	
	USER		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[No response from user] within 5 seconds
		DISPLAY TEXT 2.1.1	after the end of that defined period of time
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 2.1.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<TIME-OUT>"

Coding:

BER-TLV: 03 02 02 8D D0 16 81 01 21 80 82 81 0B 54 49 2D 4F 55 54 3E 04 3C 4D 45

TERMINAL RESPONSE: DISPLAY TEXT 2.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: No response from user

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 12

27.22.4.1.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.1.3 DISPLAY TEXT (Display of extension text)

27.22.4.1.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.1.3.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.1 (Display Text), clause 6.6.1 (Display Text), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme).

27.22.4.1.3.3 Test Purpose

To verify that the ME displays the extension text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.3.4 Method of test

27.22.4.1.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.3.4.2 Procedure

Expected Sequence 3.1 (DISPLAY TEXT, display of the extension text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : DISPLAY TEXT 3.1.1	[Text string with the maximum of 240 bytes]
4	ME → USER	Display "This command instructs the ME to display a text message, and/or an icon (see 6.5.4). It allows the SIM to define the priority of that message, and the text string format. Two types of priority are defined:- display normal priority text and/"	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	Clear Message	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : DISPLAY TEXT 3.1.1	[Command performed successfully]
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 3.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data

Text: "This command instructs the ME to display a text

message and/or an icon (see 6.5.4). It allows the SIM to define the priority of that message, and the text string format. Two types of priority are defined:- display normal priority text and/"

\sim	٠.			
Cod	1	n	α	٠
CUU	ч	ш	≍	٠

BER-TLV:	D0	81	FD	81	03	01	21	80	82	02	81	02
	8D	81	F1	04	54	68	69	73	20	63	6F	6D
	6D	61	6E	64	20	69	6E	73	74	72	75	63
	74	73	20	74	68	65	20	4D	45	20	74	6F
	20	64	69	73	70	6C	61	79	20	61	20	74
	65	78	74	20	6D	65	73	73	61	67	65	2C
	20	61	6E	64	2F	6F	72	20	61	6E	20	69
	63	6F	6E	20	28	73	65	65	20	36	2E	35
	2E	34	29	2E	20	49	74	20	61	6C	6C	6F
	77	73	20	74	68	65	20	53	49	4D	20	74
	6F	20	64	64	66	69	6E	65	20	74	68	65
	20	70	72	69	6f	72	69	74	79	20	6F	66
	20	74	68	61	74	20	6D	65	73	73	61	67
	65	2C	20	61	6E	64	20	74	68	65	20	74
	65	78	74	20	73	74	72	69	6E	67	20	66
	6F	72	6D	61	74	2E	20	54	77	6F	20	74
	79	70	65	73	20	6F	66	20	70	72	69	6F
	72	69	74	79	20	61	72	65	20	64	65	66
	69	6E	65	64	3A	2D	20	64	69	73	70	6C
	61	79	20	6E	6F	72	6D	61	6C	20	70	72
	69	6F	72	69	74	79	20	74	65	78	74	20
	61	6E		2F	14	19	20	14	03	70	14	20
	ΟI	OΕ	64	∠┌								

TERMINAL RESPONSE: DISPLAY TEXT 3.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

27.22.4.1.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.1.4 DISPLAY TEXT (Sustained text)

27.22.4.1.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.1.4.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.1 (Display Text), clause 6.6.1 (Display Text), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme) and clause 12.43 (immediate response).

27.22.4.1.4.3 Test Purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, returns a successful result in the TERMINAL RESPONSE command send to the SIM and sustain the display beyond sending the TERMINAL response.

27.22.4.1.4.4 Method of test

27.22.4.1.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.4.4.2 Procedure

Expected Sequence 4.1 (DISPLAY TEXT, sustained text, unpacked data 8 bits, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Normal priority, wait for user to clear
		DISPLAY TEXT 4.1.1	message, unpacked, 8 bit data]
4	ME o	Display "Toolkit Test 1"	
	USER		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 4.1.1	
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
8	ME o	Display of "Toolkit Test 1" shall	Text shall sustain until - a subsequent
	USER	sustain	proactive command is received containing
			display data.

PROACTIVE COMMAND: DISPLAY TEXT 4.1.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 1"

Immediate Response

Coding:

BER-TLV: D0 1C 81 03 01 21 80 82 02 81 02 8D 0F 04 54 6F 6F 6C 6B 69 74 20 54 65

73 74 20 31 AB 00

TERMINAL RESPONSE: DISPLAY TEXT 4.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 4.2 (DISPLAY TEXT, sustained text, clear message after delay, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Clear message after a delay]
		DISPLAY TEXT 4.2.1	
4	ME o	Display "Toolkit Test 2"	
	USER		
5	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 4.2.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	ME o	Display "Toolkit Test 2"	Text shall sustain until – the expiration of a
	USER		short delay.

PROACTIVE COMMAND: DISPLAY TEXT 4.2.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 2"

Immediate Response

Coding:

BER-TLV: D0 1C 81 03 01 21 00 82 02 81 02 8D 0F 04 54 6F 6F 6C 6B 69 74 20 54 65

73 74 20 32 AB 00

TERMINAL RESPONSE: DISPLAY TEXT 4.2.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, clear message after a delay

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 00 82 02 82 81 83 01 00

Expected Sequence 4.3 (DISPLAY TEXT, sustained text, wait for user MMI to clear, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 4.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[wait for user to clear message]
		DISPLAY TEXT 4.3.1	
4	ME o	Display "Toolkit Test 3"	
	USER		
5	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 4.3.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	$ME \to$	Display of "Toolkit Test 3"	Text shall sustain until – a user MMI action.
	USER		
8	$USER \to$	Clear message	
	ME		

PROACTIVE COMMAND: DISPLAY TEXT 4.3.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 3"

Immediate Response

Coding:

BER-TLV: D0 1C 03 81 01 21 80 82 02 81 02 8D 0F 04 54 6F 6F 6C 6B 69 74 20 54 65

73 74 20 33 AB 00

TERMINAL RESPONSE: DISPLAY TEXT 4.3.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 4.4 (DISPLAY TEXT, sustained text, wait for high priority event to clear, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: DISPLAY TEXT 4.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : DISPLAY TEXT 4.4.1	[wait for user to clear message]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Toolkit Test 4"	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE : DISPLAY TEXT 4.4.1	[Command performed successfully]
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
7	$\begin{array}{c} ME \to \\ USER \end{array}$	Display of "Toolkit Test 4"	Text shall sustain until – a higher priority event occurs.
8	$SS \to ME$	INCOMING MOBILE TERMINATED CALL	

PROACTIVE COMMAND: DISPLAY TEXT 4.4.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test 4"

Immediate Response

Coding:

BER-TLV: D0 1C 81 03 01 21 80 82 02 81 02 8D

OF 04 54 6F 6F 6C 6B 69 74 20 54 65

TERMINAL RESPONSE: DISPLAY TEXT 4.4.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

27.22.4.1.4.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 to 4.

27.22.4.1.5 DISPLAY TEXT (Display of icons)

27.22.4.1.5.1 Definition and applicability

See section 3.2.2

27.22.4.1.5.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.1 (Display Text), clause 6.5.4 (Icon Identifier), clause 6.6.1 (Display Text), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.31 (Icon identifier).

27.22.4.1.5.3 Test Purpose

To verify that the ME displays the icons which are referred to in the contents of the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.5.4 Method of test

27.22.4.1.5.4.1 Initial Conditions

See Annex C

27.22.4.1.5.4.2 Procedure

Expected Sequence 5.1A (DISPLAY TEXT, display of basic icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[BASIC-ICON, self-explanatory]
		DISPLAY TEXT 5.1.1	
4	ME o	Display the BASIC-ICON	
	USER		
5	$USER \to$	Clear Message	
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 5.1.1A	

PROACTIVE COMMAND: DISPLAY TEXT 5.1.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data Text: "Basic Icon"

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 1 in EF}_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV: D0 03 01 02 02 8D 1A 81 21 80 82 81 0B 04 42 61 73 69 20 49 63 6F 6E 9E 02 00 01

TERMINAL RESPONSE: DISPLAY TEXT 5.1.1A

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 5.1B (DISPLAY TEXT, display of basic icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[BASIC-ICON, self-explanatory]
		DISPLAY TEXT 5.1.1	
4	ME o	Display "Basic Icon" without icon	
	USER		
5	$USER \to$	Clear Message	
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully, but
		DISPLAY TEXT 5.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: DISPLAY TEXT 5.1.1B

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 04

Expected Sequence 5.2A (DISPLAY TEXT, display of colour icon, successful)

Step	Direction	MESSAGE / Action	Comments
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND:	[COLOUR-ICON]
		DISPLAY TEXT 5.2.1	
10	ME o	Display the COLOUR-ICON	
	USER		
11	$USER \to$	Clear Message	
	ME		
12	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 5.2.1A	

PROACTIVE COMMAND: DISPLAY TEXT 5.2.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data Text: "Colour Icon"

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 2 in } EF_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV: D0 1B 81 03 01 21 80 82 02 81 02 8D 0C 04 43 6F 6C 75 72 20 49 63 6F 6E 9E 02 00 02

TERMINAL RESPONSE: DISPLAY TEXT 5.2.1A

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 5.2B (DISPLAY TEXT, display of colour icon, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
7	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[COLOUR-ICON]
		DISPLAY TEXT 5.2.1	
10	ME o	Display "Colour Icon" without the	
	USER	icon	
11	$USER \to$	Clear Message	
	ME		
12	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully, but
		DISPLAY TEXT 5.2.1B	requested icon could not be displayed]

TERMINAL RESPONSE: DISPLAY TEXT 5.2.1B

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 04

Expected Sequence 5.3A (DISPLAY TEXT, display of basic icon, not self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.3.1	

14	$ME \rightarrow SIM$	FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND : DISPLAY TEXT 5.3.1	[BASIC-ICON, not self-explanatory]
16	$\begin{array}{c} ME \to \\ USER \end{array}$	Display the BASIC-ICON And Display "Basic Icon"	
17	$\begin{array}{c} USER \to \\ ME \end{array}$	Clear Message	
18	$ME \rightarrow SIM$	TERMINAL RESPONSE : DISPLAY TEXT 5.3.1A	[Command performed successfully]
19	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: DISPLAY TEXT 5.3.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data Text: "Basic Icon"

Icon Identifier:

Icon qualifier: icon is not self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 03 1A 81 01 21 80 82 02 81 02 8D 0B 04 42 61 73 20 49 63 6F 6E

9E 02 01 01

TERMINAL RESPONSE: DISPLAY TEXT 5.3.1A

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 5.3B (DISPLAY TEXT, display of basic icon, not self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: DISPLAY TEXT 5.3.1	
14	$ME \rightarrow SIM$	FETCH	
15	$SIM \rightarrow ME$	PROACTIVE COMMAND : DISPLAY TEXT 5.3.1	[BASIC-ICON, not self-explanatory]
16	ME o	Display "Basic Icon" without the	
	USER	icon	
17	$USER \to$	Clear Message	
	ME		
18	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully, but
		DISPLAY TEXT 5.3.1B	requested icon could not be displayed]
4.0		DD 0 4 0 T 1) /F 0 14 0 F 0 0 10 1	
19	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
1	I		

TERMINAL RESPONSE: DISPLAY TEXT 5.3.1B

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 04

27.22.4.1.5.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.1.6 DISPLAY TEXT (UCS2 display supported)

27.22.4.1.6.1 Definition and applicability

See Section 3.2.2.

27.22.4.1.6.2 Conformance requirement

The ME shall support the DISPLAY TEXT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.1 (Display Text), clause 6.5.4 (Icon Identifier), clause 6.6.1 (Display Text), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.31 (Icon identifier).

The ME shall support the UCS2 alphabet for the coding of the Cyrillic alphabet, as defined in the following technical specification: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.1.6.3 Test Purpose

To verify that the ME displays the text contained in the DISPLAY TEXT proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.1.6.4 Method of test

27.22.4.1.6.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.1.6.4.2 Procedure

Expected Sequence 6.1 (DISPLAY TEXT, UCS2 coded)

	Step	Direction	MESSAGE / Action	Comments
ſ	1	$SIM \to ME$	PROACTIVE COMMAND	
			PENDING: DISPLAY TEXT 6.1.1	
	2	$ME \rightarrow SIM$	FETCH	
	3	$SIM \to ME$	PROACTIVE COMMAND :	[Normal priority, wait for user to clear
			DISPLAY TEXT 6.1.1	message, UCS2 coded]
	4	ME o		["Hello" in russian]
		USER	Display " ЗДРАВСТВУЙТЕ "	
	5	$USER \to$	Clear message	
		ME		
	6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	
			DISPLAY TEXT 6.1.1	

PROACTIVE COMMAND: DISPLAY TEXT 6.1.1

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: UCS2 (16bit)

Техт: "ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV: D0 24 81 03 01 21 80 82 02 81 02 8D

19 80 04 17 04 14 04 20 04 10 04 12 04 21 04 22 04 12 04 19 04 22

04 15

TERMINAL RESPONSE: DISPLAY TEXT 6.1.1

Logically:

Command details

Command number: 1

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

27.22.4.1.6.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.2 GET INKEY

27.22.4.2.1 GET INKEY(normal)

27.22.4.2.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.2.1.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme).

27.22.4.2.1.3 Test Purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the single character entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.1.4 Method of Test

27.22.4.2.1.4.1 Initial conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be set to a display other than the idle display.

27.22.4.2.1.4.2 Procedure

Expected Sequence 1.1 (GET INKEY, digits only for character, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[digits only, no help info available]
		INKEY 1.1.1	
4	$ME \rightarrow USER$	Display "Enter "+""	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[command performed successfully]
		GET INKEY 1.1.1	

PROACTIVE COMMAND: GET INKEY 1.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

1

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter"+""

Coding:

BER-TLV: 03 02 82 8D D0 15 81 01 22 00 82 81 0Α 04 45 6E 74 65 20 22 2B 22

Terminal Response: GET INKEY 1.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String "+"

Coding:

BER-TLV: 81 03 01 22 80 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 1.2 (GET INKEY, digits only for character set, SMS default Alphabet for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[digits only, no help info available]
		INKEY 1.2.1	
4	$ME \to USER$	Display "Enter "0""	
			Text string coding in packed format
5	$USER \to ME$	Enter the input "0" and	
		completion	
6	$ME \to SIM$	TERMINAL RESPONSE :	[command performed successfully]
		GET INKEY 1.2.1	

PROACTIVE COMMAND: GET INKEY 1.2.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: SMS default alphabet

Text: "Enter "0""

Coding:

BER-TLV: D0 14 81 03 01 22 00 82 02 81 82 8D

09 00 45 37 BD 2C 07 89 60 22

TERMINAL RESPONSE: GET INKEY 1.2.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String "0"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 00

8D 02 04 00

Expected Sequence 1.3 (GET INKEY, backward move)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[digits only, no help information available]
		INKEY 1.3.1	
4	$ME \rightarrow USER$	Display " <go-backwards>"</go-backwards>	
			Text string coding in unpacked format
5	$USER \to ME$	Backwards move MMI action	
6	$ME \to SIM$	TERMINAL RESPONSE : GET	[backward move in the proactive SIM session
		INKEY 1.3.1	requested by the user]
]

PROACTIVE COMMAND: GET INKEY 1.3.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<GO-BACKWARDS>"

Coding:

01 BER-TLV: D0 1A 03 22 82 02 82 8D 81 00 81 47 4F 43 4B 0F 04 3C 2D 42 41 57 41

52 44 53 3E

TERMINAL RESPONSE: GET INKEY 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 11

Expected Sequence 1.4 (GET INKEY, abort)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only,, no help information available]
		INKEY 1.4.1	
4	ME o	Display " <abort>"</abort>	Text string coding in unpacked format
	USER		
5	$USER \to$	Terminate the Proactive SIM	
	ME	session MMI action	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Proactive SIM session terminated by the
		INKEY 1.4.1	user]

PROACTIVE COMMAND: GET INKEY 1.4.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<ABORT>"

Coding:

BER-TLV: D0 13 81 03 01 22 00 82 02 81 82 8D

TERMINAL RESPONSE: GET INKEY 1.4.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 22 80 82 02 82 81 83 01 10

Expected Sequence 1.5 (GET INKEY, SMS default alphabet for character set, Unpacked 8 bit data for Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.5.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[characters from SMS default alphabet, no
		INKEY 1.5.1	help info available]
4	$ME \to USER$	Display "Enter "q""	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "q" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INKEY 1.5.1	

PROACTIVE COMMAND: GET INKEY 1.5.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter "q""

Coding:

BER-TLV: D0 15 81 03 01 22 01 82 02 81 82 8D

0A 04 45 6E 74 65 72 20 22 71 22

TERMINAL RESPONSE: GET INKEY 1.5.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String "q"

Coding:

BER-TLV: 81 03 01 22 01 82 02 82 81 83 01 00

8D 02 04 71

Expected Sequence 1.6 (GET INKEY, Max length for the Text String, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only, no help info available]
		INKEY 1.6.1	
4	$ME \rightarrow USER$		
		command instructs the ME to	160 characters Text string coding in
		display text, and to expect the	unpacked format
		user to enter a single character.	
		Any response entered by the	
_		user shall be passed t "	
5	$USER \to ME$	•	
_	ME CIM	completion	For any and an automorphism of a company of the com
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 1.6.1	[command performed successfully]
		INNET I.O.I	

PROACTIVE COMMAND: GET INKEY 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter "x". This command instructs the ME to display text, and to expect

the user to enter a single character. Any response entered by the user shall

be passed t"

Coding:

BER-TLV:	D0	81	AC	81	03	01	22	01	82	02	81	82
	8D	81	A1	04	45	6E	74	65	72	20	22	78
	22	2E	20	54	68	69	73	20	63	6F	6D	6D
	61	6E	64	20	69	5E	73	74	72	75	63	74
	73	20	74	68	65	20	4D	45	20	74	6F	20
	64	69	73	70	6C	61	79	20	74	65	78	74
	2C	20	61	6E	64	20	74	6F	20	65	78	70
	65	63	74	20	74	68	65	20	75	73	65	72
	20	74	6F	20	65	6E	74	65	72	20	61	20
	73	69	6E	67	6C	65	20	53	68	61	72	61
	63	74	65	72	2E	20	41	6E	79	20	72	65
	73	70	6F	6E	73	65	20	65	6E	74	65	72
	65	64	20	62	79	20	74	68	65	20	75	73
	65	72	20	73	68	61	6C	6C	20	62	65	20
	70	61	73	73	65	64	20	74				

TERMINAL RESPONSE: GET INKEY 1.6.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: SMS default alphabet, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String "x"

Coding:

BER-TLV: 81 03 01 22 01 82 02 82 81 83 01 00

8D 02 04 78

27.22.4.2.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 to 6.

27.22.4.2.2 GET INKEY (No response from User)

27.22.4.2.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.2.2.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme).

27.22.4.2.2.3 Test Purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

27.22.4.2.2.4 Method of Test

27.22.4.2.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.2.2.4.2 Procedure

Expected Sequence 2.1 (GET INKEY, no response from the user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[digits only, no help information available]
		INKEY 2.1.1	
4	$ME \rightarrow USER$	Display " <time-out>"</time-out>	
			Text string coding in unpacked format
5	USER	Waiting and no completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[No response from user] within 5 seconds
		INKEY 2.1.1	after the end of that defined period of time
7	USER	Check the delay of TERMINAL	
		RESPONSEis reasonable or not	

PROACTIVE COMMAND: GET INKEY 2.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<TIME-OUT>"

Response length

Minimum length: 0
Maximum length: 10

Coding:

BER-TLV: D0 16 81 03 01 22 00 82 02 81 82 8D 55 0B 04 3C 54 49 4D 45 2D 4F 54 3E

TERMINAL RESPONSE: GET INKEY 2.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: No response from user

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 12

27.22.4.2.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.2.3 GET INKEY (UCS2 format display)

27.22.4.2.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.2.3.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme).

Additionnally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.2.3.3 Test Purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.3.4 Method of Test

27.22.4.2.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.2.3.4.2 Procedure

Expected Sequence 3.1 (GET INKEY, Text String coding in UCS2 Alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[Digits only, no help information available]
		INKEY 3.1.1	
4	$ME \rightarrow USER$	Display " ЗДРАВСТВУЙТЕ "	Text string "Hello" in Russian coding in 16 bits
			UCS2 alphabet format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INKEY 3.1.1	

PROACTIVE COMMAND: GET INKEY 3.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: 16 bit data UCS2 alphabet format

Text: "ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV: D0 24 81 03 01 22 00 82 02 81 82 8D 19 80 04 17 04 14 20 04 04 12 04 10 04 21 04 22 04 12 04 23 04 19 04 22 04 15

Logically:

Command details

Command number: 1

TERMINAL RESPONSE: GET INKEY 3.1.1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 3.2 (GET INKEY, max length for the Text String coding in UCS2 Alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only, no help information available]
		INKEY 3.2.1	
4	$ME \rightarrow USER$		
		"ЗДРАВСТВУЙТЕЗДРАВСТВУ	Text string length 70 characters, coding in 16
		ЙТЕЗДРАВСТВУЙТЕЗДРАВСТ	bits UCS2 alphabet format
		ВУЙТЕЗДРАВСТВУЙТЕЗДРАВ	
		СТВУЙ"	
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INKEY 3.2.1	

PROACTIVE COMMAND: GET INKEY 3.2.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme:16 bit data UCS2 alphabet formatText:"ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ

ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ"

Coding:

BER-TLV: D0 8D 8D

TERMINAL RESPONSE: GET INKEY 3.2.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "+'

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 00

8D 02 04 2B

27.22.4.2.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 to 2.

27.22.4.2.4 GET INKEY (UCS2 format of entry)

27.22.4.2.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.2.4.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme).

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.2.4.3 Test Purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.4.4 Method of Test

27.22.4.2.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.2.4.4.2 Procedure

Expected Sequence 4.1 (GET INKEY, characters from UCS2 alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[characters from UCS2 alphabet, no help
		INKEY 4.1.1	information available]
4	$ME \rightarrow USER$	Display "Enter"	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "Д"	Russian character, coding in UCS2 format
		and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INKEY 4.1.1	

PROACTIVE COMMAND: GET INKEY 4.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: characters from UCS2 alphabet, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter"

Coding:

BER-TLV: D0 03 01 22 82 02 81 82 8D 11 81 03 45 6E 74 65 06 04

TERMINAL RESPONSE: GET INKEY 4.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: characters from UCS2 alphabet, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "Д"

Coding:

BER-TLV: 81 03 01 22 03 82 02 82 81 83 01 00

8D 03 08 04 14

27.22.4.2.4.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.2.5 GET INKEY ("Yes/No" Response)

27.22.4.2.5.1 Definition and applicability

See Section 3.2.2.

27.22.4.2.5.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme).

27.22.4.2.5.3 Test Purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.5.4 Method of Test

27.22.4.2.5.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.2.5.4.2 Procedure

Expected Sequence 5.1(GET INKEY, "Yes/No" Response for the input, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INKEY 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INKEY 5.1.1	["Yes/No" Response, no help information available]
4	$ME \rightarrow USER$	Display "Enter"	Text string coding in unpacked format
5	$USER \to ME$	Choice "Yes" and Completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 5.1.1	[command performed successfully] Check if it is in accordance with the user choice (value '01' in the Text String data object)
7	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INKEY 5.1.2	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INKEY 5.1.2	["Yes/No" Response, no help information available]
10	$ME \rightarrow USER$	Display "Enter Yes/No:"	Text string coding in unpacked format
11	$USER \to ME$	Choice "No" and Completion	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 5.1.2	[command performed successfully] Check if it is in accordance with the user choice (value '00' in the Text String data object)

PROACTIVE COMMAND: GET INKEY 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter"

Coding:

BER-TLV: D0 11 81 03 01 22 04 82 02 81 82 8D

TERMINAL RESPONSE: GET INKEY 5.1.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "1"

Coding:

BER-TLV: 81 03 01 22 04 82 02 82 81 83 01 00

8D 02 04 01

PROACTIVE COMMAND: GET INKEY 5.1.2: same as 5.1.1

TERMINAL RESPONSE: GET INKEY 5.1.2

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: "Yes/No" Response, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "0"

Coding:

BER-TLV: 81 03 01 22 04 82 02 82 81 83 01 00

8D 02 04 00

27.22.4.2.5.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.2.6 GET INKEY (display of Icon)

27.22.4.2.6.1 Definition and applicability

See section 3.2.2.

27.22.4.2.6.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.5.4 (Icon Identifier), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.31 (Icon identifier).

27.22.4.2.6.3 Test Purpose

To verify that the ME displays the Icon contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.6.4 Method of Test

27.22.4.2.6.4.1 Initial Conditions

See Annex C

27.22.4.2.6.4.2 Procedure

Expected Sequence 6.1A (GET INKEY, Basic icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[BASIC-ICON self-explanatory for the Text
		INKEY 6.1.1	string]
4	$ME \rightarrow USER$	Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter "+" and completion	
6	$ME \to SIM$	TERMINAL RESPONSE : GET	Command performed successfully]
		INKEY 6.1.1A	

PROACTIVE COMMAND: GET INKEY 6.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

Coding:

BER-TLV: D0 19 81 03 01 22 00 82 02 81 82 8D 0A 04 3C 4E 4F 2D 49 43 4F 4E 3E 1E

02 00 01

TERMINAL RESPONSE: GET INKEY 6.1.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String "+'

Coding:

BER-TLV: 81 03 01 22 04 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.1B (GET INKEY, Basic icon, self-explanatory, requested icon could not be displayed

)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[BASIC-ICON self-explanatory for the Text
		INKEY 6.1.1	string]
4	$ME \to USER$	Display " <no-icon>" for the</no-icon>	
		prompt without the icon	
			Text string coding in unpacked format
5	$USER \to ME$	Enter "+" and completion	
6	$ME \to SIM$	TERMINAL RESPONSE : GET	[Command performed successfully, but
		INKEY 6.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.1.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 04

8D 02 04 2B

Expected Sequence 6.2A (GET INKEY, Basic icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[BASIC-ICON non self-explanatory for the
		INKEY 6.2.1	Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" and</basic-icon>	
		Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
_		F	
5	USER → ME	Enter the input "+" and	
6	ME SIM	completion	[Command parformed successfully]
0	IVIE → SIIVI		
		INNET 0.2.TA	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 6.2.1A	[Command performed successfully]

PROACTIVE COMMAND: GET INKEY 6.2.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<BASIC-ICON>"

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

Coding:

1C 03 01 22 BER-TLV: D0 81 00 82 02 81 82 8D 0D 04 3C 42 41 53 43 2D 49 43 4F 49 4E 3E 1E 02 01 01

TERMINAL RESPONSE: GET INKEY 6.2.1A

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "+'

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.2B (GET INKEY, Basic icon, non self-explanatory, requested icon could not be displayed

)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
	ME CIM	PENDING: GET INKEY 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET INKEY 6.2.1	[BASIC-ICON non self-explanatory for the Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" for the prompt without the icon</basic-icon>	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 6.2.1B	[Command performed successfully, but requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.2.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 04

8D 02 04 2B

Expected Sequence 6.3A (GET INKEY, Colour icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON self-explanatory for the Text
		INKEY 6.3.1	string]
4	$ME \rightarrow USER$	Display the COLOUR-ICON for	
		the prompt	
			Text string coding in unpacked format
			rext string coding in dispacked format
5	USER → ME	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully]
		INKEY 6.3.1A	

PROACTIVE COMMAND: GET INKEY 6.3.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

D0 81 BER-TLV: 1D 03 02 81 82 8D 01 22 00 82 0A 04 3C 4E 4F 2D 49 4F 4E 3E 1E 02 00 02

TERMINAL RESPONSE: GET INKEY 6.3.1A

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.3B (GET INKEY, Colour icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON self-explanatory for the Text
		INKEY 6.3.1	string]
4	$ME \rightarrow USER$	Display " <no-icon>"for the</no-icon>	
		prompt without the icon	
			Text string coding in unpacked format
5	LICED ME	Enter the input "+" and	
3	USER → IVIE	completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully, but
	IVIL 7 OIIVI	INKEY 6.3.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.3.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 04

8D 02 04 2B

Expected Sequence 6.4A (GET INKEY, Colour icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: GET INKEY 6.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INKEY 6.4.1	[COLOUR-ICON non self-explanatory for the Text string]
4	ME → USER	Display " <colour-icon>" and Display the COLOUR-ICON for the prompt</colour-icon>	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 6.4.1A	[Command performed successfully]

PROACTIVE COMMAND: GET INKEY 6.4.1

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<COLOUR-ICON>"

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

BER-TLV: D0 1D 81 03 01 22 00 82 02 81 82 8D 0F 04 3C 43 4F 4C 4F 55 52 2D 43 4F 4E 3E 1E 02 01 02

TERMINAL RESPONSE: GET INKEY 6.4.1A

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 00 8D 02 04 2B

Expected Sequence 6.4B (GET INKEY, Colour icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INKEY 6.4.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON non self-explanatory for the
		INKEY 6.4.1	Text string]
4	$ME \rightarrow USER$	Display " <colour-icon>" for</colour-icon>	
		the prompt without the icon	
_			Text string coding in unpacked format
5	USER \rightarrow ME	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully, but
		INKEY 6.4.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INKEY 6.4.1B

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 04

8D 02 04 2B

27.22.4.2.6.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 to 4.

27.22.4.2.7 GET INKEY (Help Information)

27.22.4.2.7.1 Definition and applicability

See Section 3.2.2.

27.22.4.2.7.2 Conformance Requirement

The ME shall support the GET INKEY command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.2 (Get Inkey), clause 6.5.4 (Icon Identifier), clause 6.6.2 (Get Inkey), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.31 (Icon identifier).

27.22.4.2.7.3 Test Purpose

To verify that the ME displays the text contained in the GET INKEY proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.2.7.4 Method of Test

27.22.4.2.7.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.2.7.4.2 Procedure

Expected Sequence 7.1 (GET INKEY, help information available)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INKEY 7.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INKEY 7.1.1	[digits only, help information available]
4	$ME \rightarrow USER$	Display "Enter "+""	
			Text string coding in unpacked format
5	$USER \to ME$, ,	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 7.1.1	[help info required]
7	$ME \rightarrow SIM$	FETCH	
8	$SIM \rightarrow ME$	PROACTIVE COMMAND : DISPLAY TEXT (help info)	
9	$ME \rightarrow SIM$	TERMINAL RESPONSE : DISPLAY TEXT (help info)	
10	$ME \rightarrow SIM$	FETCH	
11	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INKEY 7.1.2	[digits only, help information available]
12	$ME \rightarrow USER$	Display "Enter "+""	
40	LIGER ME	Faton the count "." and	Repetition of get inkey
13	USER → ME	Enter the input "+" and completion	
14	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INKEY 7.1.2	[Command performed successfully]

PROACTIVE COMMAND: GET INKEY 7.1.1

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter "+""

Coding:

BER-TLV: D0 15 81 03 01 22 80 82 02 81 82 8D

OA 04 45 6E 74 65 72 20 22 2B 22

TERMINAL RESPONSE: GET INKEY 7.1.1

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Help information required by the user

Coding:

BER-TLV: 81 03 01 22 80 82 02 82 81 83 01 00

PROACTIVE COMMAND: GET INKEY 7.1.2

Logically:

Command details

Command number: 1

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter "+""

Coding:

BER-TLV: D0 15 81 03 01 22 80 82 02 81 82 8D

0A 04 45 6E 74 65 72 20 22 2B 22

TERMINAL RESPONSE: GET INKEY 7.1.2

Logically:

Command details

Command number:

Command type: GET INKEY

Command qualifier: digits (0-9, *, # and +) only, help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text String: "+"

Coding:

BER-TLV: 81 03 01 22 00 82 02 82 81 83 01 04

8D 02 04 2B

27.22.4.2.7.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.3. GET INPUT

27.22.4.3.1 GET INPUT (normal)

27.22.4.3.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.1.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications :

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text).

27.22.4.3.1.3 Test Purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.1.4 Method of Test

27.22.4.3.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.3.1.4.2 Procedure

Expected Sequence 1.1 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only, SMS default alphabet, ME to
		INPUT 1.1.1	echo text, packing not required, no help info
			available]
4	$ME \rightarrow USER$	Display "Enter 12345"	Range of expected length is 5-5
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "12345" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INPUT 1.1.1	

PROACTIVE COMMAND: GET INPUT 1.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV: D0 1B 81 03 01 23 00 82 02 81 82 8D 0C 04 45 6E 74 31 32 34 35 91 02 05 05

TERMINAL RESPONSE : GET INPUT 1.1.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

BER-TLV: 03 01 23 80 82 02 82 81 83 01 00 32 8D 06 04 31 33 34 35

Expected Sequence 1.2 (GET INPUT, digits only, SMS default alphabet, ME to echo text, packing SMS Point-to-point required by ME)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only, SMS default alphabet, ME to
		INPUT 1.2.1	echo text, packing required, no help
			information available]
4	$ME \rightarrow USER$	Display " Enter 67*#+""	Range of expected length is 5-5
			Text string coding in packed format
5	$USER \to ME$	Enter the input "67*#+"" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INPUT 1.2.1	

PROACTIVE COMMAND: GET INPUT 1.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in packed SMS

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: SMS default alphabet

Text: "Enter 67*#+"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV: D0 1A 81 03 01 23 80 82 02 81 82 8D 0B 00 45 37 BD 2C D9 6E 0A 07 AAD1 91 02 05 05

TERMINAL RESPONSE: GET INPUT 1.2.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in packed SMS

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

1

Text string

Data coding scheme: packed SMS format Text: "67*#+""

Coding:

BER-TLV: 81 03 01 23 80 82 02 82 81 83 01 00 8D 80 00 36 37 2A 23 2B 22

Expected Sequence 1.3 (GET INPUT, character set, SMS Default Alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[character set, SMS default alphabet, ME to
		INPUT 1.3.1	echo text, packing not required, no help
			information available]
4	$ME \rightarrow USER$	Display "Enter AbCdE"	Range of expected length is 5-5
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "AbCdE" and	
		completion	
6	ME	Echo " AbCdE"	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INPUT 1.3.1	

PROACTIVE COMMAND: GET INPUT 1.3.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: Character set, SMS default alphabet, input in unpacked format, ME to echo

text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Enter AbCdE"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV: D0 1B 81 03 01 23 01 82 02 81 82 8D 0C 6E 74 41 62 64 04 45 65 72 20 43

45 91 02 05 05

TERMINAL RESPONSE: GET INPUT 1.3.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: Character set, SMS default alphabet, input in unpacked format, ME to echo

text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "AbCdE"

Coding:

BER-TLV: 81 03 01 23 01 82 02 82 81 83 01 00

8D 06 04 41 62 43 64 45

Expected Sequence 1.4 (GET INPUT, digits only, SMS default alphabet, ME to hide text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only, SMS default alphabet, ME to hide
		INPUT 1.4.1	text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display	Range of expected length is 4-8
		"Password 1 <send>2345678"</send>	Text string coding in unpacked format
5	$USER \to ME$	Enter the input "2345678" and completion	
6	ME	input not displayed	optionally indication of key entries such as by
			displaying "*"
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 1.4.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 1.4.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to hide text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Password 1<SEND>2345678"

Response length

Minimum length: 4
Maximum length: 8

Coding:

BER-TLV: 03 8D D0 27 81 01 23 04 82 02 81 82 18 04 50 61 73 73 77 6F 72 64 20 31 3C 53 45 4E 44 3E 32 34 35 36 37 80 38 91 02 04

TERMINAL RESPONSE: GET INPUT 1.4.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to hide text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data Text: "2345678"

Coding:

BER-TLV: 03 01 23 04 82 02 82 81 83 01 00 80 04 32 33 34 35 36 37 38 8D

Expected Sequence 1.5 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[digits only, SMS default alphabet, ME to
		GET INPUT 1.5.1	echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display "Enter 19,09,0(1)"	Range of expected length is 1-20 Text string coding in unpacked format
5	$USER \to ME$	Completion without input	3
6	MMI ->USER	Display "invalid length"	
7	USER ->ME	Enter	
		"12345678901234567890" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 1.5.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 1.5.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "Enter 1..9,0..9,0(1)"

Response length

Minimum length: 1 Maximum length: 20

Coding:

BER-TLV: D0 24 81 03 01 23 00 82 02 81 82 8D 6E 20 2E 2E 39 15 04 45 74 65 72 31 2C 30 2E 2E 39 2C 30 28 31 29 91 02 01 14

TERMINAL RESPONSE: GET INPUT 1.5.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345678901234567890"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00 8D 15 04 31 32 33 34 35 36 37 38 39 34 39 30 32 33 35 36 37 38 30 31

Expected Sequence 1.6 (GET INPUT, backwards move,)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INPUT 1.6.1	

Ī	2	$\text{ME} \to \text{SIM}$	FETCH			
	3	$SIM \to ME$	PROACTIVE COMMAND : GET INPUT 1.6.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]		
	4	ME → USER	Display " <go- BACKWARDS>"</go- 	Range of expected length is 0-8 Text string coding in unpacked format		
	5	$\begin{array}{c} \text{USER} \rightarrow \\ \text{ME} \end{array}$	Backwards move MMI action			
	6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 1.6.1	[backward move in the proactive SIM session requested by the user]		

PROACTIVE COMMAND: GET INPUT 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: SIM

Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "<GO-BACKWARDS>"

Response length

Minimum length:0

Maximum length: 8

Coding:

BER-TLV: D0 1E 82 81 03 01 23 00 02 81 82 8D 0F 04 3C 47 43 4B 57 4F 2D 42 41 41 52 44 53 3E 91 02 00 08

TERMINAL RESPONSE: GET INPUT 1.6.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: ME

Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 11

Expected Sequence 1.7 (GET INPUT, abort)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: GET INPUT 1.7.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	SIM → ME	PROACTIVE COMMAND : GET INPUT 1.7.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	ME → USER	Display " <abort>"</abort>	Range if expected length is 0-8 Text string coding in unpacked format
5	USER → ME	Terminate the Proactive SIM session MMI action	
6	ME → SIM	TERMINAL RESPONSE : GET INPUT 1.7.1	[Proactive SIM session terminated by the user]

PROACTIVE COMMAND: GET INPUT 1.7.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: SIM

Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "<ABORT>"

Response length

Minimum length:0

Maximum length: 8

Coding:

BER-TLV: D0 17 81 03 01 23 00 82 02 81 82 8D

08

TERMINAL RESPONSE: GET INPUT 1.7.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo

text, no help information available

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 10

Expected Sequence 1.8 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1		PROACTIVE COMMAND PENDING: GET INPUT 1.8.1	
2	$ME \rightarrow SIM$	FETCH	

3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INPUT 1.8.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display "***111111111###***2222 22222###***333333333### ***444444444###***5555 55555###***666666666### ***77777777###***8888 88888###***99999999### ***00000000000###"	Range of length expected is 160-160 Text string coding in unpacked format
5	$USER \to ME$	Enter the input "***111111111###***2222 22222###***333333333### ***4444444444###***5555 55555###***666666666### ***77777777###***8888 8888###***99999999### ***00000000000###" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 1.8.1	[command performed successfully]

PROACTIVE COMMAND : GET INPUT 1.8.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: SIM

Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text:

Response length

Minimum length: 160

Maximum length: 160

Coding:

BER-TLV: D0 81 B1 81 03 01 23 00 82 02 81 82

8D	81	A1	04	2A	2A	2A	31	31	31	31	31
31	31	31	31	31	23	23	23	2A	2A	2A	32
32	32	32	32	32	32	32	32	32	23	23	23
2A	2A	2A	33	33	33	33	33	33	33	33	33
33	23	23	23	2A	2A	2A	34	34	34	34	34
34	34	34	34	34	23	23	23	2A	2A	2A	35
35	35	35	35	35	35	35	35	35	23	23	23
2A	2A	2A	36	36	36	36	36	36	36	36	36
36	23	23	23	2A	2A	2A	37	37	37	37	37
37	37	37	37	37	23	23	23	2A	2A	2A	38
38	38	38	38	38	38	38	38	38	23	23	23
2A	2A	2A	39	39	39	39	39	39	39	39	39
39	23	23	23	2A	2A	2A	30	30	30	30	30
30	30	30	30	30	23	23	23	91	02	A0	A0

TERMINAL RESPONSE: GET INPUT 1.8.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "***111111111###***222222222###***

333333333###***444444444###

55555555555###6666666666###

77777777###888888888###

99999999###0000000000###"

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	8D	81	A1	04	2A	2A	2A	31	31	31	31	31
	31	31	31	31	31	23	23	23	2A	2A	2A	32
	32	32	32	32	32	32	32	32	32	23	23	23
	2A	2A	2A	33	33	33	33	33	33	33	33	33
	33	23	23	23	2A	2A	2A	34	34	34	34	34
	34	34	34	34	34	23	23	23	2A	2A	2A	35
	35	35	35	35	35	35	35	35	35	23	23	23
	2A	2A	2A	36	36	36	36	36	36	36	36	36
	36	23	23	23	2A	2A	2A	37	37	37	37	37
	37	37	37	37	37	23	23	23	2A	2A	2A	38
	38	38	38	38	38	38	38	38	38	23	23	23
	2A	2A	2A	39	39	39	39	39	39	39	39	39
	39	23	23	23	2A	2A	2A	30	30	30	30	30
	30	30	30	30	30	23	23	23				

Expected Sequence 1.9 (GET INPUT, digits only, SMS default alphabet, ME to echo text, ME supporting 8 bit data Message)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INPUT 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INPUT 1.9.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	ME → USER	Display " <send>"</send>	Range of expected length is 0-1
			Text string coding in unpacked format
5	USER → ME	Completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 1.9.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 1.9.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: SIM

Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "<SEND>"

Response length

Minimum length:0

Maximum length: 1

Coding:

BER-TLV: D0 16 81 03 01 23 00 82 02 81 82 8D

07 04 3C 53 45 4E 44 3E 91 02 00 01

TERMINAL RESPONSE: GET INPUT 1.9.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: empty string

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00 8D 01 04

Expected Sequence 1.10 (GET INPUT, null length for the text string, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET INPUT 1.1.10	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET INPUT 1.1.10	[digits only, SMS default alphabet, ME to echo text, packing not required, no help info available]
4	ME → USER	Request for input	Range of expected length is 0-5 Null Text string
5	$\begin{array}{c} \text{USER} \rightarrow \\ \text{ME} \end{array}$	Enter the input "12345" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 1.1.10	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 1.1.10

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: SIM

Destination device: ME

Text string

Text: length null (00).

Response length

Minimum length: 1

Maximum length: 5

Coding:

03 00 82 81 BER-TLV: D0 0F 81 01 23 02 82 8D 00 91 02 01 05

TERMINAL RESPONSE: GET INPUT 1.1.10

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked format, ME to echo text, no help information available

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

BER-TLV: 81 83 01 00 81 03 01 23 80 82 02 82 8D 31 06 04 32 33 34 35

27.22.4.3.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 9.

27.22.4.3.2 GET INPUT (No response from User)

27.22.4.3.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.2.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text).

27.22.4.3.2.3 Test Purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns a "No response from user" result value in the TERMINAL RESPONSE command send to the SIM.

27.22.4.3.2.4 Method of Test

27.22.4.3.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

ME Manufacturers shall set the "no response from user" period of time.

The SIM simulator shall be set to that period of time.

27.22.4.3.2.4.2 Procedure

Expected Sequence 2.1 (GET INPUT, no response from the user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[digits only, SMS default alphabet
		INPUT 2.1	ME to echo text, packing not required, no
			help information available]
4	$ME \rightarrow USER$	Display " <time-out>"</time-out>	Range of expected length is 0-10
			Text string coding in unpacked format
5	USER	Waiting and no completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[No response from user] within 5 seconds
		INPUT 2.1.1	after the end of that defined period of time

PROACTIVE COMMAND: GET INPUT 2.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<TIME-OUT>"

Response length

Minimum length: 0
Maximum length: 10

Coding:

BER-TLV: 81 03 01 23 00 81 82 8D D0 1A 82 02 0B 04 3C 54 49 4D 45 2D 4F 55 54 3E 91 02 00 0A

TERMINAL RESPONSE: GET INPUT 2.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: No response from user

1

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 12

27.22.4.3.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.3.3 GET INPUT (UCS2 format display)

27.22.4.3.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.3.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text).

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.3.3.3 Test Purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.3.4 Method of Test

27.22.4.3.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.3.3.4.2 Procedure

Expected Sequence 3.1 (GET INPUT, text string coding in UCS2, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INPUT 3.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display " ЗДРАВСТВУЙТЕ "	Range of expected length is 5-5 Text string "Hello" in Russian coding in 16 bits UCS2 alphabet format
5	$USER \to ME$	Enter the input "HELLO" and completion	·
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 3.1.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: 16 bit data UCS2 alphabet format

Text: "ЗДРАВСТВУЙТЕ"

Response length

Minimum length: 5
Maximum length: 5

Coding:

BER-TLV: D0 28 81 03 01 23 00 82 02 81 82 8D 14 19 80 04 17 04 20 04 10 04 12 04 04 21 04 22 04 12 04 91 02 15 05 05

TERMINAL RESPONSE: GET INPUT 3.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "HELLO"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00

8D 06 04 48 45 4C 4C 4F

Expected Sequence 3.2 (GET INPUT, max length for the text string coding in UCS2, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: GET INPUT 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INPUT 3.2.1	[digits only, SMS default alphabet, ME to echo text, packing not required, no help information available]
4	ME → USER	Display "ЗДРАВСТВУЙТЕЗДРАВСТ ВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВ УЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ	Range of expected length is 5-5 Text string length 70 characters, coding in 16 bits UCS2 alphabet format
5	$USER \to ME$	Enter the input "Hello" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 3.2.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 3.2.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: 16 bit data UCS2 alphabet format

Text:

"ЗДРАВСТВУЙТЕЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕ ЗДРАВСТВУЙТЕЗДРАВСТВУЙ"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV: D0 8D 8D

TERMINAL RESPONSE: GET INPUT 3.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "HELLO"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00

8D 06 04 48 45 4C 4C 4F

27.22.4.3.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 to 2.

27.22.4.3.4 GET INPUT (UCS2 format of entry)

27.22.4.3.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.4.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text).

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications:

ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.3.4.3 Test Purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.4.4 Method of Test

27.22.4.3.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.3.4.4.2 Procedure

Expected Sequence 4.1 (GET INPUT, character set from UCS2 alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[character set, UCS2 alphabet, ME to echo
		INPUT 4.1.1	text, packing not required, no help information
4	ME LIGER	Diapley "enter Helle"	available]
4	ME → USER	Display "enter Hello"	Range of expected length is 5-5 Text string coding in unpacked format
5	$USER \to ME$	Enter the input	"Hello" in Russian, coding in UCS2 format
		"ЗДРАВСТВУЙТЕ "	
		and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INPUT 4.1.1	

PROACTIVE COMMAND: GET INPUT 4.1.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text,

no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Enter Hello"

Response length

Minimum length: 5
Maximum length: 5

Coding:

BER-TLV: D0 1B 81 03 01 23 03 82 02 81 82 8D 0C 04 45 6E 74 65 72 20 48 65 6C 6C 6F 02 05 91 05

TERMINAL RESPONSE: GET INPUT 4.1.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text,

no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: UCS2

Техт: "ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV: 8D

Expected Sequence 4.2 (GET INPUT, character set from UCS2 alphabet, Max length for the input, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[character set, UCS2 alphabet, ME to echo
		INPUT 4.2.1	text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display	Range of expected length is no limit
		"Enter Hello:"	Text string coding in unpacked format
5	$USER \to ME$	Enter the input	Input length 70 characters, coding in UCS2
		"ЗДРАВСТВУЙТЕЗДРАВСТ	format
		ВУЙТЕ	
		ЗДРАВСТВУЙТЕЗДРАВСТВ	
		УЙТЕ	
		ЗДРАВСТВУЙТЕЗДРАВСТВУЙ	
		and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 4.2.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 4.2.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text,

no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Enter Hello"

Response length

Minimum length: 5 Maximum length: 5

Coding:

BER-TLV: D0 1B 8D 0C 6E 6C 6C

6F 91 02 05 05

TERMINAL RESPONSE: GET INPUT 4.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: character set, UCS2 alphabet, input in unpacked format, ME to echo text,

no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Data coding scheme: UCS2

Text: "ЗДРАВСТВУЙТЕ...ЗДРАВСТВУЙ" (70 chars)

Coding:

BER-TLV: 8D 8D

27.22.4.3.4.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 to 2.

27.22.4.3.5 GET INPUT (default text)

27.22.4.3.5.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.5.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text).

27.22.4.3.5.3 Test Purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.5.4 Method of Test

27.22.4.3.5.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.3.5.4.2 Procedure

Expected Sequence 5.1(GET INPUT, default text for the input, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 5.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[digits only, SMS default alphabet, ME to
		INPUT 5.1.1	echo text, packing not required, no help
			information available]
4	$ME \rightarrow USER$	Display "Enter 12345"	Range of expected length is 5-5
		Display "12345"	Text string coding in unpacked format
			Default text coding in unpacked format
5	$USER \to ME$		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[command performed successfully]
		INPUT 5.1.1	

PROACTIVE COMMAND: GET INPUT 5.1.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Enter 12345"

Response length

Minimum length: 5 Maximum length: 5

Default Text

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

BER-TLV: 8D D0 23 81 03 01 23 00 82 02 81 82 0C 04 45 6E 74 65 72 20 31 32 33 34 35 32 34 91 02 05 05 17 05 04 31 33 35

TERMINAL RESPONSE: GET INPUT 5.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "12345"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00 8D 06 04 31 32 33 34 35

Expected Sequence 5.2 (GET INPUT, default text for the input with max length, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 5.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[digits only, SMS default alphabet, ME to
		INPUT 5.2.1	echo text, packing not required, no help information available]
4	$ME \rightarrow USER$	Display "Enter:"	Range of expected length is 5-5
		Display default text input:	Text string coding in unpacked format
		"***111111111###***22222222	Default text length 160 bytes coding in
		22###***33333333###***4444	unpacked format
		44444###***55555555###***	
		666666666###***777777777	
		##***888888888###***999999	
		999###***000000000###"	
5	$USER \to ME$	Completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 5.2.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 5.2.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data

Text: "Enter:"

Response length

Minimum length: 160 Maximum length: 160

Default Text

Data coding scheme: unpacked, 8 bit data

Text:

"***111111111##***222222222###***33333333###***44444444 4###***55555555###***666666666###***7777777###***88888

888###***99999999###***0000000000###"

Coding:

BER-TLV: D0 1B 8D 6E A0 A0 A0 2A

TERMINAL RESPONSE: GET INPUT 5.2.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Data coding scheme: unpacked, 8 bit data

Text:

"***11111111###***22222222###***33333333###***44444444 4###***555555555###***666666666###***77777777###***88888

8888###***999999999###***0000000000###"

Coding:

BER-TLV:	81	03	01	23	00	82	02	82	81	83	01	00
	17	81	A0	04	2A	2A	2A	31	31	31	31	31
	31	31	31	31	31	23	23	23	2A	2A	2A	32
	32	32	32	32	32	32	32	32	32	23	23	23
	2A	2A	2A	33	33	33	33	33	33	33	33	33
	33	23	23	23	2A	2A	2A	34	34	34	34	34
	34	34	34	34	34	23	23	23	2A	2A	2A	35
	35	35	35	35	35	35	35	35	35	23	23	23
	2A	2A	2A	36	36	36	36	36	36	36	36	36
	36	23	23	23	2A	2A	2A	37	37	37	37	37
	37	37	37	37	37	23	23	23	2A	2A	2A	38
	38	38	38	38	38	38	38	38	38	23	23	23
	2A	2A	2A	39	39	39	39	39	39	39	39	39
	39	23	23	23	2A	2A	2A	30	30	30	30	30
	D0	1D	81	03	01	23	00	82	02	81	82	8D
	0A	04	3C	4E	4F	2D	49	43	4F	4E	3E	91
	02	00	0A	1E	02	00	01	30	30	30	30	30
	23	23	23		02	00	01	50	50	00	50	50
	20	20	20									

27.22.4.3.5.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 to 2.

27.22.4.3.6 GET INPUT (display of Icon)

27.22.4.3.6.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.6.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.5.4 (Icon Identifier), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text), clause 12.31 (Icon identifier).

27.22.4.3.6.3 Test Purpose

To verify that the ME displays the Icon contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.6.4 Method of Test

27.22.4.3.6.4.1 Initial Conditions

27.22.4.3.6.4.2 See Annex C

27.22.4.3.6.4.3 Procedure

Expected Sequence 6.1A (GET INPUT, Basic icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[BASIC-ICON self-explanatory for the Text
		INPUT 6.1.1	string]
4	$ME \rightarrow USER$	Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
5		Enter "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	Command performed successfully]
		INPUT 6.1.1A	

PROACTIVE COMMAND: GET INPUT 6.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "<NO-ICON>"

Response length

Minimum length: 0

Maximum length: 10Icon Identifier Icon qualifier: self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

Coding:

BER-TLV: D0 1D 81 03 01 23 00 82 02 81 82 8D 0Α 04 3C 4E 4F 2D 49 43 4F 4E 3E 91 02 00 0A 02 00 1E 01

TERMINAL RESPONSE: GET INPUT 6.1.1A

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV: 81 03 01 23 04 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.1B (GET INPUT, Basic icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[BASIC-ICON self-explanatory for the Text
		INPUT 6.1.1	string]
4	$ME \rightarrow USER$	Display " <no-icon>" for the</no-icon>	
		prompt without the icon	
			Text string coding in unpacked format
5	$USER \to ME$	Enter "+" and completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully, but
		INPUT 6.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: GET INPUT 6.1.1B

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+'

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 04

8D 02 04 2B

Expected Sequence 6.2A (GET INPUT, Basic icon, non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[BASIC-ICON non self-explanatory for the
		INPUT 6.2.1	Text string]
4	$ME \to USER$	Display " <basic-icon>" and</basic-icon>	
		Display the BASIC-ICON for the	
		prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully]
		INPUT 6.2.1A	

PROACTIVE COMMAND:: GET INPUT 6.2.1

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<BASIC-ICON>"

Response length

Minimum length: 0
Maximum length: 10

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 1 (number of record in EF_{Img})

Coding:BE 1C D0 81 03 01 23 00 82 02 81 82 8D R-TLV: 8D 0D 04 3C 42 41 53 49 43 2D 49 43 4F 4E 3E 91 02 00 0Α 1E 02 01 01

TERMINAL RESPONSE: GET INPUT 6.2.1A

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.2B (GET INPUT, Basic icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[BASIC-ICON non self-explanatory for the
		INPUT 6.2.1	Text string]
4	$ME \rightarrow USER$	Display " <basic-icon>" for the</basic-icon>	
		prompt without the icon	
			Text string coding in unpacked format
5	LICED ME	Enter the input "1" and	
3	USEK → ME	Enter the input "+" and completion	
6	ME → SIM	TERMINAL RESPONSE : GET	[Command performed successfully, but
	IVIL -7 SIIVI	INPUT 6.2.1B	requested icon could not be displayed]
		1111 01 0.2.15	requested reen edula her be displayed]

TERMINAL RESPONSE: GET INPUT 6.2.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 04

8D 02 04 2B

Expected Sequence 6.3A (GET INPUT, Colour icon, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON self-explanatory for the Text
		INPUT 6.3.1	string]
4	$ME \rightarrow USER$	Display the COLOUR-ICON for	
		the prompt	
			Text string coding in unpacked format
5	$USER \to ME$	Enter the input "+" and	
		completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully]
		INPUT 6.3.1A	

PROACTIVE COMMAND: GET INPUT 6.3.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<NO-ICON>"

Response length

Minimum length: 0
Maximum length: 10

Icon Identifier

Icon qualifier: self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

03 01 23 BER-TLV: D0 1D 81 00 82 02 81 82 8D 4F 4E 0Α 04 3C 4E 4F 2D 49 43 3E 91 02 00 0Α 1E 02 02 00

TERMINAL RESPONSE: GET INPUT 6.3.1A

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.3B (GET INPUT, Colour icon, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON self-explanatory for the Text
		INPUT 6.3.1	string]
4	$ME \rightarrow USER$	Display the COLOUR-ICON for	
		the prompt	
			Total atalogue and discussion common also all forms of
			Text string coding in unpacked format
5	LICED ME	Enter the input "+" and	
3	USEK → IVIE	completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully, but
	IVIL -> OIIVI	INPUT 6.3.1B	requested icon could not be displayed]
		0. 0.02	requested issuit seals not be displayed]

TERMINAL RESPONSE: GET INPUT 6.3.1B

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 04

8D 02 04 2B

Expected Sequence 6.4A (GET INPUT, Colour icon, non self-explanatory, successful)

Ste	p Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 6.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON non self-explanatory for the
		INPUT 6.4.1	Text string]
4	$ME \rightarrow USER$	Display " <colour-icon>" and</colour-icon>	
		Display the COLOUR-ICON for	
		the prompt	
			Total state as an alternative constraint of the second
5	HOED ME	Enter the input "," and	Text string coding in unpacked format
)	USER → ME	Enter the input "+" and	
6	$ME \rightarrow SIM$	completion TERMINAL RESPONSE : GET	[Command performed successfully]
	IVIE → SIIVI	INPUT 6.4.1A	
		101 0.4.17	

PROACTIVE COMMAND: GET INPUT 6.4.1

Logically:

Command details

Command number:

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data
Text: "<COLOUR-ICON>"

Response length

Minimum length: 0 Maximum length: 10

Icon Identifier

Icon qualifier: not self-explanatory

Icon identifier: 2 (number of record in EF_{Img})

Coding:

BER-TLV: D0 1D 03 8D 81 01 23 00 82 02 81 82 0Α 04 3C 4E 4F 2D 49 43 4F 4E 3E 91 02 02 00 0A 1E 01 02

TERMINAL RESPONSE: GET INPUT 6.4.1A

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+"

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 00

8D 02 04 2B

Expected Sequence 6.4B (GET INPUT, Colour icon, non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
_		PENDING: GET INPUT 6.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[COLOUR-ICON non self-explanatory for the
		INPUT 6.4.1	Text string]
4	$ME \rightarrow USER$	Display " <colour-icon>" for</colour-icon>	
		the prompt without the icon	
			Toyt string adding in uppeaked format
5	LIGED ME	Enter the input "+" and	Text string coding in unpacked format
3	USER → IVIE	completion	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Command performed successfully, but
	IVIL / OIIVI	INPUT 6.4.1B	requested icon could not be displayed
		1111 01 0.1.12	requested icon could not be displayed]

TERMINAL RESPONSE: GET INPUT 6.4.1B

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, no help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Text string

Data coding scheme: unpacked, 8 bit data

Text: "+'

Coding:

BER-TLV: 81 03 01 23 00 82 02 82 81 83 01 04

8D 02 04 2B

27.22.4.3.7 GET INPUT (Help Information)

27.22.4.3.7.1 Definition and applicability

See Section 3.2.2.

27.22.4.3.7.2 Conformance Requirement

The ME shall support the GET INPUT command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.3 (Get Input), clause 6.6.3 (Get Input), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.15 (Text String), clause 12.15.1/2/3 (Data Coding Scheme), clause 12.13 (Default text).

27.22.4.3.7.3 Test Purpose

To verify that the ME displays the text contained in the GET INPUT proactive SIM command, and returns the text string entered in the TERMINAL RESPONSE command sent to the SIM.

27.22.4.3.7.4 Method of Test

27.22.4.3.7.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.3.7.4.2 Procedure

Expected Sequence 7.1 (GET INPUT, digits only, ME to echo text, ME supporting 8 bit data Message, help information available)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET INPUT 7.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET INPUT 7.1.1	[digits only, SMS default alphabet, ME to echo text, packing not required, help information available]
4	$ME \rightarrow USER$	Display "Enter 12345"	Range of expected length is 5-5 Text string coding in unpacked format
5	$USER \to ME$	Press "help"	
6	ME->USER	Display Help information	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET INPUT 7.1.1	[command performed successfully]

PROACTIVE COMMAND: GET INPUT 7.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, help information available

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Enter 12345"

Response length

Minimum length: 5
Maximum length: 5

Coding:

BER-TLV: D0 03 1B 81 01 23 80 82 02 81 82 8D 0C 74 31 04 45 6E 65 72 20 32 33 34 35 91 02 05 05

TERMINAL RESPONSE: GET INPUT 7.1.1

Logically:

Command details

Command number: 1

Command type: GET INPUT

Command qualifier: digits (0-9, *, # and +) only, SMS default alphabet, input in unpacked

format, ME to echo text, help information available

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Help information required by the user

Coding:

BER-TLV: 81 03 01 23 80 82 02 82 81 83 13 00

27.22.4.3.7.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.4 MORE TIME

27.22.4.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.4.2 Conformance Requirement

The ME shall support the MORE TIME command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.4.4 (More time), clause 6.6.4. (More time), clause 5.2 (Terminal profile), clause 12.6 (Command details), clause 12.7 (Device identities)

27.22.4.4.3 Test Purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the MORE TIME proactive SIM command.

27.22.4.4.4 Method of Test

27.22.4.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.4.4.2 Procedure

Expected Sequence 1.1 (MORE TIME)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: MORE TIME 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : MORE	
		TIME 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : MORE	[Command performed successfully]
		TIME 1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: MORE TIME 1.1.1

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 02 00 82 02 81 82

TERMINAL RESPONSE: MORE TIME 1.1.1

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

1

Coding:

BER-TLV: 81 03 01 02 00 82 02 82 81 83 01 00

27.22.4.4.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.5 PLAY TONE

27.22.4.5.1 Definition and applicability

See Section 3.2.2.

27.22.4.5.2 Conformance Requirement

The ME shall support the PLAY TONE command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.5 (Play Tone), clause 6.6.5. (Play Tone), clause 5.2 (Terminal Profile), clause 12.6 (Command details), clause 12.7 (Device identities), clause 12.2 (Alpha identifier), clause 12.16 (Tone), clause 12.8 (Duration)

27.22.4.5.3 Test Purpose

To verify that the ME plays an audio tone of a type and duration contained in the PLAY TONE proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME plays the requested audio tone through the external ringer whilst not in call and shall superimpose the tone on top of the downlink audio whilst in call.

To verify that the ME displays the text contained in the PLAY TONE proactive SIM command.

27.22.4.5.4 Method of Test

27.22.4.5.4.1 Initial Conditions

The ME is connected to the SIM Simulator and to the System Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.5.4.2 Procedure

Expected Sequence 1.1 (PLAY TONE)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : PLAY	
		TONE 1.1.1	
4	ME o	Display "Dial Tone"	
	USER		
		Play a standard supervisory dial	
		tone through the external ringer for	
		a duration of 5 seconds	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully]
		TONE 1.1.1	
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

SIM → ME	ſ	I	1	1
9 SIM → ME 10 ME → USER VISER VISER VISER Play a standard supervisory called subscriber busy tone for a duration of 5 seconds 11 ME → SIM → ME 12 SIM → ME 13 SIM → ME 15 SIM → ME 16 ME → Display "Congestion" VISER VISE	7	$SIM \rightarrow ME$		
TONE 1.1.2 Display "Sub. Busy" USER Play a standard supervisory called subscriber busy tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.2 SIM → ME SIM → ME PROACTIVE SIM SESSION ENDED PROBLED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 FETCH SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.3 PROACTIVE SIM SESSION ENDED 17 ME → SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND PLAY TONE 1.1.4 FETCH ME → SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.4 ME → SIM → ME PROACTIVE SIM SESSION ENDED 23 ME → SIM → ME PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE SIM SESSION ENDED 26 ME → SIM SESSION ENDED 27 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 PROACTIVE COMMAND : PLAY TONE 1.1.5 PROACTIVE COMMAND : PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 PROACTIVE SIM SESSION : PLAY TONE 1.1.5 PROACTIVE COMMAND : PLAY TONE 1.1.5 PROACTIVE COMMAND : PLAY TONE 1.1.5 PROACTIVE COMMAND : PLAY TONE 1.1	8	$ME \to SIM$	FETCH	
Display "Sub. Busy" Play a standard supervisory called subscriber busy tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.2 PROACTIVE COMMAND PROBLEM PROACTIVE SIM SESSION Play a standard supervisory called subscriber busy tone for a duration of 5 seconds PROACTIVE SIM SESSION PROBLEM PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 FETCH SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.3 Display "Congestion" USER Play a standard supervisory congestion tone for a duration of 5 seconds PROACTIVE SIM SESSION PROACTIVE COMMAND : PLAY TONE 1.1.4 PROACTIVE SIM SESSION PROACTIVE COMMAND : PLAY TONE 1.1.5 PROACTIVE SIM SESSION PROACTIVE SIM SESSION PROACTIVE SIM SESSION PROACTIVE	9	$SIM \rightarrow ME$		
Play a standard supervisory called subscriber busy tone for a duration of 5 seconds of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.2 PROACTIVE SIM SESSION ENDED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 FETCH SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds SIM → ME PROACTIVE SIM SESSION ENDED 17 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.3 PROACTIVE SIM SESSION ENDED 18 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 20 ME → SIM PREMINAL RESPONSE: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 21 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 22 ME → SIM PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 PROACTIVE COMMAND: PLAY TONE 1.1.5 PLAY TONE 1.1.5 PROACTIVE SIM SESSION PLAY TONE 1.1.5 PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION PLAY TONE 1.1.5 FETCH PROACTIVE SIM SESSION PLAY TONE 1.1.5 FETC	10			
of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.2 PROACTIVE SIM SESSION ENDED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 FETCH SIM → ME OSIM ME → SIM ME		OOLIK	Play a standard supervisory called	
11 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.2 12 SIM → ME PROACTIVE SIM SESSION ENDED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 14 ME → SIM PROACTIVE COMMAND : PLAY TONE 1.1.3 16 ME → SIM Display "Congestion" 17 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.3 18 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.3 19 SIM → ME PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.4 19 FROACTIVE COMMAND : PLAY TONE 1.1.4 10 ME → SIM PROACTIVE COMMAND : PLAY TONE 1.1.4 11 Display "RP Ack" 12 ME → USER 13 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.4 14 Display "RP Ack" 15 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.4 16 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.4 17 DISPLAY TONE 1.1.5 18 SIM → ME PROACTIVE SIM SESSION ENDED 20 SIM → ME PROACTIVE SIM SESSION ENDED 21 SIM → ME PROACTIVE SIM SESSION ENDED 22 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 23 ME → SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 24 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 25 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 26 ME → SIM TETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 27 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 28 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 20 SIM → ME PROACTIVE SIM SESSION ENDED 21 SIM → ME PROACTIVE SIM SESSION ENDED 22 SIM → ME PROACTIVE SIM SESSION ENDED (Command performed successfully) TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 29 SIM → ME PROACTIVE SIM SESSION (Command performed successfully) TONE 1.1.5 20 SIM → ME PROACTIVE SIM SESSION (Command performed successfully) TONE 1.1.5 20 SIM → ME PROACTIVE SIM SESSION (Command performed successfully) TONE 1.1.5 20 SIM → ME PROACTIVE SIM SESSION (Command performed successfully) TONE 1.1.5 21 SIM → ME PROACTIVE SIM SESSION (Command performed successfully) TONE 1.1.5				
TONE 1.1.2 PROACTIVE SIM SESSION ENDED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 FETCH 15 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.3 Display "Congestion" USER 16 ME → SIM INSUME → BROACTIVE COMMAND: PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds 17 ME → SIM SIM → ME PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PETCH PROACTIVE COMMAND: PLAY TONE 1.1.4 Display "RP Ack" USER 20 ME → SIM PROACTIVE SIM SESSION ENDED 21 SIM → ME PROACTIVE SIM SESSION ENDED 22 ME → SIM PROACTIVE SIM SESSION ENDED 23 ME → SIM PROACTIVE SIM SESSION ENDED 24 SIM → ME PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 PETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 DISPLAY TONE 1.1.5 DISPL				
12 SIM → ME PROACTIVE SIM SESSION ENDED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 FETCH 15 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds 17 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.3 TERMINAL RESPONSE : PLAY TONE 1.1.3 18 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.4 Display "RP Ack" 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.4 Display "RP Ack" 20 ME → SIM PROACTIVE COMMAND : PLAY TONE 1.1.4 PROACTIVE COMMAND : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 21 SIM → ME PROACTIVE SIM SESSION ENDED 22 ME → SIM PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path and available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 DISPLAY T	11	$ME \rightarrow SIM$		[Command performed successfully]
ENDED 13 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.3 PETCH SIM → ME Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds 17 ME → SIM TONE 1.1.3 PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PETCH Display "RP Ack" USER 19 ME → SIM PROACTIVE COMMAND PLAY TONE 1.1.4 PETCH PROACTIVE COMMAND: PLAY TONE 1.1.4 PETCH Display "RP Ack" USER 19 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.4 PROACTIVE COMMAND: PLAY TONE 1.1.4 PROACTIVE COMMAND PLAY TONE 1.1.4 PROACTIVE COMMAND PLAY TONE 1.1.4 PROACTIVE COMMAND PLAY TONE 1.1.5 PLAY TONE 1.1.5 Display "RP Ack" 10 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 PETCH PETC	12	$SIM \rightarrow MF$		
PENDING: PLAY TONE 1.1.3 ME → SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.3 SIM → ME PROACTIVE SIM SESSION ENDED PROACTIVE SIM SESSION ENDED PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND: PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 SIM → ME PROACTIVE SIM SESSION ENDED Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 SIM → ME PROACTIVE SIM SESSION ENDED PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 PROACTIVE COMMAND PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 PROACTIVE SIM SESSION				
PENDING: PLAY TONE 1.1.3 ME → SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.3 Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.3 SIM → ME PROACTIVE SIM SESSION ENDED PROACTIVE SIM SESSION ENDED PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND: PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 SIM → ME PROACTIVE SIM SESSION ENDED Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 SIM → ME PROACTIVE SIM SESSION ENDED PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 PROACTIVE COMMAND PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 PROACTIVE SIM SESSION	40	0114 145	DDC A OTIVE COMMAND	
14 ME → SIM FETCH SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.3 16 ME → USER Play a standard supervisory congestion tone for a duration of 5 seconds 17 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.3 18 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 20 ME → SIM FETCH 21 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 22 ME → SIM FETCH 23 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.4 24 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.4 25 Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 24 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 26 ME → SIM FETCH 27 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 28 ME → Display "No RP" 29 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION	13	SIM → ME		
15 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.3 Display "Congestion" 16 ME → USER 17 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.3 18 SIM → ME PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND PROBLEM PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 Display "RP Ack" 122 ME → USER 18 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH Display "RP Ack" 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH Display "RP Ack" 10 SIM → ME PROACTIVE SIM SESSION ENDED 23 ME → SIM → ME PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE SIM SESSION ENDED 26 ME → SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" 27 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 Display "No RP" 28 ME → SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM → ME PROACTIVE SIM SESSION 20 SIM → ME PROACTIVE SIM SESSION 21 Command performed successfully ICOMMAND PENDING: PLAY TONE 1.1.5 Display "No RP" 22 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 PROACTIVE SIM SESSION 23 SIM → ME PROACTIVE SIM SESSION	14	$ME \rightarrow SIM$		
Display "Congestion" Play a standard supervisory congestion tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.3 SIM → ME SIM → ME PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.4 PROACTIVE COMMAND : PLAY TONE 1.1.4 PROACTIVE COMMAND : PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 SIM → ME SIM → ME SIM → ME PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE SIM SESSION ENDED Command performed successfully] TONE 1.1.4 PROACTIVE COMMAND : PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 FIGURE : Command performed successfully] TONE 1.1.5 Display "No RP" Command performed successfully] TONE 1.1.5 PROACTIVE SIM SESSION [Command performed successfully] TONE 1.1.5 PROACTIVE SIM SESSION [Command performed successfully] TONE 1.1.5 PROACTIVE SIM SESSION [Command performed successfully]	15			
USER Play a standard supervisory congestion tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.3 PROACTIVE SIM SESSION ENDED SIM → ME SIM → ME SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 SIM → ME ABOUND SIM → ME SIM → ME SIM → ME SIM → ME ABOUND SIM → ME TONE 1.1.4 PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH SIM → ME ABOUND SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 PROACTIVE SIM SESSION COMMAND PROACTIVE COMMAND: PLAY TONE 1.1.5 PROACTIVE SIM SESSION COMMAND PROBLEM SECOND PROACTIVE SIM SESSION	4.0			
Play a standard supervisory congestion tone for a duration of 5 seconds 17 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.3 18 SIM → ME PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 20 ME → SIM SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.4 21 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.4 22 ME → USER 23 ME → SIM Display "RP Ack" 24 SIM → ME PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE SIM SESSION ENDED 26 ME → SIM SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 27 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 28 ME → SIM SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 29 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 15 TERMINAL RESPONSE: PLAY TONE 1.1.5 16 TERMINAL RESPONSE: PLAY TONE 1.1.5 17 SIM → ME PROACTIVE COMMAND PLAY TONE 1.1.5 18 SIM → ME PROACTIVE COMMAND PLAY TONE 1.1.5 19 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 10 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 10 SIM → ME PROACTIVE SIM SESSION 10 SIM → ME PROACTIVE SIM SESSION 11 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 12 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 13 SIM → ME PROACTIVE SIM SESSION 14 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 15 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 16 SIM → ME PROACTIVE SIM SESSION	16		Display "Congestion"	
congestion tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.3 PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 PROACTIVE COMMAND : PLAY TONE 1.1.4 PROACTIVE COMMAND : PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED SIM → ME SIM → ME SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 FETCH PROACTIVE SIM SESSION [Command performed successfully] TONE 1.1.5 PROACTIVE SIM SESSION		USLIX	Play a standard supervisory	
17 ME → SIM 18 SIM → ME 19 SIM → ME 20 ME → SIM 21 SIM → ME 22 ME → SIM 22 ME → SIM 23 ME → SIM 24 SIM → ME 25 SIM → ME 26 ME → SIM 27 SIM → ME 28 ME → SIM 29 PROACTIVE COMMAND : PLAY TONE 1.1.4 29 PROACTIVE COMMAND : PLAY TONE 1.1.4 20 ME → SIM PROACTIVE COMMAND : PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 26 SIM → ME 27 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 PROACTIVE SIM SESSION [Command performed successfully] TONE 1.1.5 PROACTIVE SIM SESSION				
TONE 1.1.3 PROACTIVE SIM SESSION ENDED 19 SIM → ME 20 ME → SIM 21 SIM → ME 21 SIM → ME 22 ME → USER Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 23 ME → SIM 24 SIM → ME 25 SIM → ME 26 ME → SIM 27 SIM → ME 28 ME → USER PROACTIVE COMMAND PROACTIVE SIM SESSION ENDED 26 ME → SIM 27 SIM → ME 28 ME → USER PROACTIVE COMMAND TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 TOME 1.1.5 Display "No RP" [Command performed successfully] TOME 1.1.5 TOME 1.1.4 TOME 1.1.	47	N45 01N4		[One or
18 SIM → ME PROACTIVE SIM SESSION ENDED 19 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.4 20 ME → SIM FETCH PROACTIVE COMMAND: PLAY TONE 1.1.4 21 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.4 22 ME → USER Play a standard supervisory radio path acknowledgement tone 23 ME → SIM PROACTIVE SIM SESSION ENDED 24 SIM → ME PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 26 ME → SIM PROACTIVE COMMAND: PLAY TONE 1.1.5 27 SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION [Command performed successfully]	17	ME → SIM		[Command performed successfully]
ENDED	18	$SIM \rightarrow ME$		
PENDING: PLAY TONE 1.1.4 PENDING: PLAY TONE 1.1.4 PETCH PROACTIVE COMMAND: PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 ME → SIM ME → SIM Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION [Command performed successfully]			ENDED	
PENDING: PLAY TONE 1.1.4 PENDING: PLAY TONE 1.1.4 PETCH PROACTIVE COMMAND: PLAY TONE 1.1.4 Display "RP Ack" Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 ME → SIM ME → SIM Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION [Command performed successfully]	40	OIM ME	DDC A CTIVE COMMAND	
20 ME → SIM SIM → ME 21 SIM → ME 22 ME → USER 23 ME → SIM Play a standard supervisory radio path acknowledgement tone 23 ME → SIM TONE 1.1.4 24 SIM → ME 25 SIM → ME 26 ME → SIM PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 26 ME → SIM → ME 27 SIM → ME 28 ME → USER 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 20 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 20 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 20 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 21 Command performed successfully] 22 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 23 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 24 Display "No RP" 25 Command performed successfully] 26 Command performed successfully] 27 SIM → ME 28 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 29 PROACTIVE SIM SESSION	19	SIM → ME		
21 SIM → ME	20	$ME \rightarrow SIM$		
22 ME → USER Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 26 ME → SIM PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 Display "No RP" 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TOME 1.1.5 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION [Command performed successfully]	21		PROACTIVE COMMAND : PLAY	
USER Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE: PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 SIM → ME SIM → SIM SIM → ME PROACTIVE SIM SESSION [Command performed successfully]	00			
Play a standard supervisory radio path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 PROACTIVE SIM SESSION [Command performed successfully]	22		Display "RP Ack"	
23 ME → SIM path acknowledgement tone TERMINAL RESPONSE : PLAY TONE 1.1.4 PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 PROACTIVE SIM SESSION [Command performed successfully] [Command performed successfully]		USLIX	Play a standard supervisory radio	
TONE 1.1.4 PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 Display "No RP" 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE: PLAY TONE 1.1.5 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 FROACTIVE SIM SESSION [Command performed successfully]			path acknowledgement tone	
24 SIM → ME PROACTIVE SIM SESSION ENDED 25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 26 ME → SIM FETCH PROACTIVE COMMAND: PLAY TONE 1.1.5 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION [Command performed successfully]	23	$ME \rightarrow SIM$		[Command performed successfully]
25 SIM → ME PROACTIVE COMMAND PENDING: PLAY TONE 1.1.5 26 ME → SIM SIM → ME PROACTIVE COMMAND: PLAY TONE 1.1.5 28 ME → USER 29 ME → SIM Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE: PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION [Command performed successfully]	24	SIM → ME	_	
26 ME → SIM PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION		OIW / IVIL		
26 ME → SIM PENDING: PLAY TONE 1.1.5 FETCH PROACTIVE COMMAND : PLAY TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 SIM → ME PROACTIVE SIM SESSION				
26 ME → SIM FETCH 27 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION	25	$SIM \rightarrow ME$		
27 SIM → ME PROACTIVE COMMAND : PLAY TONE 1.1.5 28 ME → USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION	26	MF → SIM		
TONE 1.1.5 Display "No RP" Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds TERMINAL RESPONSE : PLAY TONE 1.1.5 SIM → ME TONE 1.1.5 PROACTIVE SIM SESSION				
USER Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION			TONE 1.1.5	
Play a standard supervisory radio path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION	28		Display "No RP"	
path not available / call dropped tone for a duration of 5 seconds 29 ME → SIM TERMINAL RESPONSE : PLAY TONE 1.1.5 30 SIM → ME PROACTIVE SIM SESSION		USEK	Play a standard supervisory radio	
tone for a duration of 5 seconds $ME \rightarrow SIM TERMINAL \ RESPONSE : PLAY [Command performed successfully] TONE 1.1.5$ $SIM \rightarrow ME PROACTIVE \ SIM \ SESSION$			path not available / call dropped	
TONE 1.1.5 $SIM \rightarrow ME PROACTIVE SIM SESSION$				
30 SIM \rightarrow ME PROACTIVE SIM SESSION	29	$ME \rightarrow SIM$		[Command performed successfully]
	30	$SIM \rightarrow MF$		
		JIIVI / IVIL	ENDED	

I		I	I
31	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.6	
32	$ME \rightarrow SIM$	FETCH	
33	$SIM \rightarrow ME$	PROACTIVE COMMAND : PLAY TONE 1.1.6	
34	ME → USER	Display "Spec Info"	
	002.1	Play a standard supervisory error /	
		special information tone for a duration of 5 seconds	
35	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully]
00	0114 145	TONE 1.1.6	
36	SIM → ME	PROACTIVE SIM SESSION ENDED	
37	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.7	
38	$ME \rightarrow SIM$		
39	$SIM \to ME$	PROACTIVE COMMAND : PLAY	
40	ME o	TONE 1.1.7 Display "Call Wait"	
10	USER	Biopiay Gail Wait	
		Play a standard supervisory call waiting tone for a duration of 5	
		seconds	
41	$ME \to SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully]
42	SIM ME	TONE 1.1.7 PROACTIVE SIM SESSION	
	OIIVI 7 IVIL	ENDED	
43	SIM \ ME	PROACTIVE COMMAND	
	SIIVI -> IVIL	PENDING: PLAY TONE 1.1.8	
44	$ME \rightarrow SIM$		
45	$SIM \rightarrow ME$	PROACTIVE COMMAND : PLAY TONE 1.1.8	
46	ME o	Display "Ring Tone"	
	USER	Play a standard supervisory	
		ringing tone for duration of 5	
47	ME CIM	seconds	[Company of the state of the st
47	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY TONE 1.1.8	[Command performed successfully]
48	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
49	$USER \to$	Set up a voice call	[User dials 123456789 to connect to the
50	ME ME →	Establish voice call	network manually] [Voice call is established]
30	Network	LSIADIISII VUICE CAII	[voice can is established]
51		PROACTIVE COMMAND	
52	$ME \rightarrow SIM$	PENDING: PLAY TONE 1.1.9	
53	$SIM \rightarrow ME$	PROACTIVE COMMAND : PLAY	
E A	NAT.	TONE 1.1.9	
54	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Dial Tone"	
		Superimpose the standard	
		supervisory dial tone on the audio downlink for the duration of 5	
		seconds	
55	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY TONE 1.1.9	[Command performed successfully]
56	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

•	i		
57	$SIM \rightarrow ME$	PROACTIVE COMMAND	
58	$ME \rightarrow SIM$	PENDING: PLAY TONE 1.1.10	
59		PROACTIVE COMMAND : PLAY	
	0	TONE 1.1.10	
60	ME o	Display "This command instructs	
	USER	the ME to play an audio tone.	
		Upon receiving this command, the ME shall check if it is currently in,	
		or in the process of setting up	
		(SET-UP message sent to the	
		network, see GSM"04.08"(8)), a	
		speech call If the ME I"	
		Play a general beep	
61	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully]
		TONE 1.1.10a	0.5
		or TERMINAL RESPONSE : PLAY	or [Command beyond ME's capabilities]
		TONE 1.1.10b	
62	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
63	SIM ME	ENDED PROACTIVE COMMAND	
03	SIIVI -> IVIE	PENDING: PLAY TONE 1.1.11	
64	$ME \rightarrow SIM$		
65	$SIM \rightarrow ME$	PROACTIVE COMMAND : PLAY	
66	ME o	TONE 1.1.11 Display "Beep"	
	USER	Display Deep	
		Play a ME proprietary general	
67	ME CIM	beep TERMINAL RESPONSE : PLAY	[Command parformed guagagefully]
07	$ME \rightarrow SIM$	TONE 1.1.11a	[Command performed successfully]
		Or	or
		TERMINAL RESPONSE : PLAY	[Command beyond ME's capabilities]
68	SIM ME	TONE 1.1.11b PROACTIVE SIM SESSION	
	SIIVI -> IVIL	ENDED	
69	$SIM \rightarrow ME$	PROACTIVE COMMAND	
70	ME CIM	PENDING: PLAY TONE 1.1.12	
70 71	$ME \rightarrow SIM$	PROACTIVE COMMAND : PLAY	
''	Olivi — IVIL	TONE 1.1.12	
72	ME o	Display "Positive"	
	USER	Play a ME proprietory positive	
		Play a ME proprietary positive acknowledgement tone	
73	$ME \rightarrow SIM$		[Command performed successfully]
		TONE 1.1.12a	
		or TERMINAL RESPONSE : PLAY	or [Command beyond ME's capabilities]
		TONE 1.1.12b	
74	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

75	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.13	
76	$ME \rightarrow SIM$		
77	$SIM \rightarrow ME$	PROACTIVE COMMAND : PLAY	
78	ME o	TONE 1.1.13 Display "Negative"	
10	USER	Display Negative	
	USEK	Play a ME proprietary negative	
		acknowledgement tone	
79	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully]
		TONE 1.1.13a	
		or	or
		TERMINAL RESPONSE : PLAY	[Command beyond ME's capabilities]
		TONE 1.1.13b	
80	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
81	CIM . ME	ENDED PROACTIVE COMMAND	
01	SIIVI → IVIE	PENDING: PLAY TONE 1.1.14	
82	$ME \rightarrow SIM$		
83		PROACTIVE COMMAND : PLAY	
	J	TONE 1.1.14	
84	ME o	Display "Quick"	
	USER		
		Play a ME proprietary general	
85	ME CIM	beep TERMINAL RESPONSE : PLAY	[Command performed augeocafully]
65	IVIE → SIIVI	TONE 1.1.14a	[Command performed successfully]
		or	or
		TERMINAL RESPONSE : PLAY	[Command beyond ME's capabilities]
		TONE 1.1.14b	
86	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
87	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: PLAY TONE 1.1.15	
88	$ME \rightarrow SIM$		
89		PROACTIVE COMMAND : PLAY	
	J	TONE 1.1.15	
90	ME o	Display " <abort>"</abort>	
	USER		
		Play a ME Error / Special	
		information tone for 1 minute until	
91	ME _ \ SIM	user aborts this command TERMINAL RESPONSE : PLAY	[Proactive SIM session terminated by the
	IVIL -> SIIVI	TONE 1.1.15	user]
92	$SIM \rightarrow ME$		•
		ENDED	
93	$SIM \to ME$		
		PENDING: PLAY TONE 1.1.16	
94	$ME \rightarrow SIM$		
95	$ SIM \rightarrow ME$	PROACTIVE COMMAND : PLAY TONE 1.1.16	[No alpha identifier, no tone tag, no duration
96	$ME \rightarrow$	ME plays general beep, or if not	tag] [ME uses default duration defined by ME-
	User	supported any (defined by ME-	manufacturer]
	333.	manufacturer) other supported	
		tone	
97	$ME \rightarrow SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully], [ME
		TONE 1.1.16	uses general beep, or if not supported any
			(defined by ME-manufacturer) other
			supported tone, uses default duration defined by ME-manufacturer]
98	SIM ME	PROACTIVE SIM SESSION	by ME-IIIaliulaciuleij
30	JIIVI → IVIE	ENDED	
		1	

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV: D0 1B 81 03 01 20 00 82 02 81 03 85 09 44 69 61 6C 20 54 6F 6E 65 8E 01

01 84 02 01 05

PROACTIVE COMMAND: PLAY TONE 1.1.2

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Sub. Busy"

Tone: Standard supervisory tones: called subscriber busy

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV: D0 03 20 02 03 1B 81 01 00 82 81 85 09 75 62 2E 20 42 75 73 79 8E 01 53

02 84 02 01 05

Logically:

Command details

Command number: 1

PLAY TONE Command type:

Command qualifier: "00"

Device identities

Source device: SIM Destination device: Earpiece Alpha identifier: "Congestion"

Tone: Standard supervisory tones: congestion

Duration

Time unit: Seconds Time interval:

Coding:

BER-TLV: D0 1C 81 03 01 20 00 82 02 81 03 85

0Α 43 6F 6E 67 65 73 74 69 6F 6E 8E

05 01 03 84 02 01

1

PROACTIVE COMMAND: PLAY TONE 1.1.4

Logically:

Command details

Command number:

PLAY TONE Command type:

Command qualifier: "00"

Device identities

Source device: SIM Destination device: Earpiece Alpha identifier: "RP Ack"

Tone: Standard supervisory tones: radio path acknowledge

Duration

Seconds Time unit: Time interval: 5

Coding:

BER-TLV: D0 03 01 20 03 18 81 00 82 02 81 85 84 02

06 52 50 20 41 63 6B 8E 01 04

Logically:

Command details

Command number: 1

PLAY TONE Command type:

Command qualifier: "00"

Device identities

Source device: SIM Destination device: Earpiece "No RP" Alpha identifier:

Tone: Standard supervisory tones: radio path not available

Duration

Time unit: Seconds Time interval:

Coding:

17 BER-TLV: D0 81 03 01 20 82 02 81 03 85 00

05 4E 6F 20 52 50 8E 01 05 84 02 01

05

PROACTIVE COMMAND: PLAY TONE 1.1.6

Logically:

Command details

Command number:

PLAY TONE Command type:

1

Command qualifier: "00"

Device identities

Source device: SIM Destination device: Earpiece Alpha identifier: "Spec Info"

Tone: Standard supervisory tones: Error/ special information

Duration

Time unit: Seconds Time interval:

Coding:

BER-TLV: D0 1B 03 01 20 81 00 82 02 81 03 85 6F 6E 8E

20

49

66

01

01

PROACTIVE COMMAND: PLAY TONE 1.1.7

Logically:

Command details

Command number: 1

PLAY TONE Command type:

Command qualifier: "00"

Device identities

Source device: SIM Earpiece Destination device: "Call Wait" Alpha identifier:

Tone: Standard supervisory tones: call waiting tone

Duration

Time unit: Seconds Time interval:

Coding:

81 BER-TLV: D0 1B 03 01 20 00 82 02 81 03 85 01

09 43 61 6C 6C 20 57 71 69 74 8E 07 05 84 02 01

PROACTIVE COMMAND: PLAY TONE 1.1.8

Logically:

Command details

Command number:

PLAY TONE Command type:

Command qualifier: "00"

Device identities

Source device: SIM Destination device: Earpiece Alpha identifier: "Ring Tone"

Tone: Standard supervisory tones: ringing tone

1

Duration

Time unit: Seconds Time interval:

Coding:

BER-TLV: D0 1B 03 01 20 03 81 00 82 02 81 85 6F 6E 65 8E

09 52 69 6E 67 20 54

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV: D0 1B 6C 6F 6E 8E

01 84 02 01 05

PROACTIVE COMMAND: PLAY TONE 1.1.10

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

4D

Device identities

Source device: SIM
Destination device: Earpiece

Alpha identifier: "This command instructs the ME to play an audio tone. Upon receiving this

command, the ME shall check if it is currently in, or in the process of setting up (SET-UP message sent to the network, see GSM"04.08"(8)), a

speech call. - If the ME I"

Coding:

BER-TLV: D0 FD F1 6F 6D 6D 6E 6E 4D 6F 6E 6C 6F 6F 6F 6E 2E 6E 6E 6F 6D 6D 6E 2C 4D 6C 6C 6B 6E 6C 6E 2C 6F 6E 6F 6F 6E 2D 6D 6E 6F 6E 6F 6B 2C 4D 2E 2C 6C 6C 2E 2D

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Beep"

Tone: ME proprietary tones: general beep

1

Duration

Time unit: Seconds
Time interval: 1

Coding:

BER-TLV: D0 03 01 20 00 82 02 81 03 85 16 81 04 42 65 65 70 8E 01 10 84 02 01 01

PROACTIVE COMMAND: PLAY TONE 1.1.12

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Positive"

Tone: ME proprietary tones: positive acknowledgement tone

Duration

Time unit: Seconds
Time interval: 1

Coding:

BER-TLV: 81 03 01 20 02 03 D0 1A 00 82 81 85 80 50 6F 73 69 74 69 76 65 8E 01 11

84 02 01 01

PROACTIVE COMMAND: PLAY TONE 1.1.13

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Negative"

Tone: ME proprietary tones: negative acknowledgement tone

Duration

Time unit: Seconds
Time interval: 1

Coding:

BER-TLV: D0 1A 81 03 01 20 00 82 02 81 03 85

08 4E 65 67 61 74 69 76 65 8E 01 12

84 02 01 01

PROACTIVE COMMAND: PLAY TONE 1.1.14

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Quick"

Tone: ME proprietary tones: general beep

Duration

Time unit: Tenths of seconds

Time interval: 2

Coding:

BER-TLV: D0 17 81 03 01 20 00 82 02 81 03 85

05 51 75 69 63 6B 8E 01 10 84 02 02

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "<ABORT>"

Tone: Standard supervisory tones: Error / Special information

Duration

Time unit: Minutes
Time interval: 1

Coding:

BER-TLV: D0 19 81 03 01 20 00 02 81 03 85 82 07 3B 41 42 4F 52 3E 8E 01 06 84

02 00 01

PROACTIVE COMMAND: PLAY TONE 1.1.16

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece

Coding:

BER-TLV: D0 09 81 03 01 20 00 82 02 81 03

Expected Sequence 1.2 (PLAY TONE, backwards move key not interacting with play tone)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: PLAY TONE 1.1.17	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		PLAY TONE 1.1.17	
4	$ME \rightarrow USER$	Display " <go-backwards>"</go-backwards>	
5	USER → ME	The user presses the key which	
		normally corresponds to	
		Backwards move MMI action	
6	$ME \to SIM$	TERMINAL RESPONSE : PLAY	[Command performed successfully]
		TONE 1.1.17	
7	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Device identities

Source device: SIM
Destination device: Earpiece

Alpha identifier: "<GO-BACKWARDS>"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV: D0 20 81 03 01 20 00 82 02 81 03 85 2D 42 4B 52 0E 3C 47 4F 41 43 57 41

44 53 3E 8E 01 01 84 02 01 05

TERMINAL RESPONSE: PLAY TONE 1.1.17

Logically:

Command details

Command number:

Command type: PLAY TONE

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: PLAY TONE 1.1.1 ... 1.1.9, 1.1.16

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: PLAY TONE 1.1.10a ... 1.1.14a

Logically:

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: PLAY TONE 1.1.10b ..1.1.10b

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command beyond ME's capabilities

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 30

TERMINAL RESPONSE: PLAY TONE 1.1.15

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Proactive SIM session terminated by user

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 10

27.22.4.5.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.6 POLL INTERVAL

27.22.4.6.1 Definition and applicability

See Section 3.2.2.

27.22.4.6.2 Conformance Requirement

The ME shall support the POLL INTERVAL command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.6 (Poll interval), 6.6.6. (Poll interval), clause 5.2 (Terminal profile), clause 12.6 (Command details), clause 12.7 (Device identities), clause 12.8 (Duration)

27.22.4.6.3 Test Purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the POLL INTERVAL proactive SIM command.

To verify that the ME gives a valid response to the polling interval requested by the SIM.

To verify that the ME sends STATUS commands to the SIM at an interval no longer than the interval negotiated by the SIM.

27.22.4.6.4 Method of Test

27.22.4.6.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.6.4.2 Procedure

Expected Sequence 1.1 (POLL INTERVAL, Seconds)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POLL INTERVAL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : POLL	[Duration: 20 seconds]
		INTERVAL 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : POLL	[Command performed successfully]
		INTERVAL 1.1.1	
5	ME	ME polls in intervalls of 20	
		seconds	

PROACTIVE COMMAND: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Duration

Time unit: Seconds
Time interval: 20

Coding:

BER-TLV: D0 0D 81 03 01 03 00 82 02 81 82 84 02 01 14

TERMINAL RESPONSE: POLL INTERVAL 1.1.1

Logically:

Command details

Command number: 1

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Duration

Time unit: Seconds
Time interval: 20

Coding:

BER-TLV: 81 03 01 02 00 82 02 82 81 83 01 00 14 82 02 01

27.22.4.6.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.7 REFRESH

27.22.4.7.1 REFRESH (normal)

27.22.4.7.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.7.1.2 Conformance requirement

The ME shall support the REFRESH command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.7 (Refresh), 6.6.13.(Refresh), clause 5.2 (Terminal profile), clause 12.6 (Command details), clause 12.7 (Device identities), clause 12.18 (File list)

27.22.4.7.1.3 Test Purpose

To verify that the ME performs the SIM initialisation and / or re-reads the contents and structure of the EFs on the SIM that have been changed and / or restarts the card session by resetting the ME, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.7.1.4 Method of test

27.22.4.7.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files for the second SIM Simulator are coded as SIM Application Toolkit default with the following exceptions.

EF_{FDN} (Fixed Dialling Numbers)

Logically:

At least 10 records

Record 1:

Length of alpha identifier: 32 characters
Alpha identifier: "ABC"
Length of BCD number: "03"

TON and NPI: Telephony and Unknown

Dialled number: 123
CCI: None
Ext2: None

B32 **B**3 B4 B33 B34 B36 **B37 B46** Coding: B1 B2 **B**35 Record 1: 41 42 43 FF FF 03 81 21 F3 FF FF

Record 2:

Length of alpha identifier: 32 characters
Alpha identifier: "DEF"
Length of BCD number: "04"

TON and NPI: Telephony and Unknown

Dialled number: 9876
CCI: None
Ext2: None

Coding: B2 В3 B4 **B32 B33 B34 B35 B36 B37 B46** Record 1: 44 45 46 FF FF 03 81 89 67 FF FF ...

27.22.4.7.1.4.2 Procedure

Expected Sequence 1.1 (REFRESH, SIM Initialisation)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: REFRESH 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: REFRESH 1.1.1	
4	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
5	$ME \rightarrow SIM$	SIM Initialisation	[ME performs SIM initialisation]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 1.1.1A Or TERMINAL RESPONSE: REFRESH 1.1.1B	
7	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
8	$\begin{array}{c} USER \to \\ ME \end{array}$	Call setup to "321"	
9	$\begin{array}{c} ME \to \\ USER \end{array}$	Call set up not allowed	
10	$\begin{array}{c} USER \to \\ ME \end{array}$	Call setup to "123"	
11	$ME \rightarrow SS$	Setup	Called party BCD number shall be "123"

PROACTIVE COMMAND: REFRESH 1.1.1

Logically:

Command details

Command number:

Command type: REFRESH
Command qualifier: SIM Initialisation

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 01 03 82 02 81 82

TERMINAL RESPONSE: REFRESH 1.1.1A

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialisation

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 03 82 02 81 82 83 01 00

TERMINAL RESPONSE: REFRESH 1.1.1B

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialisation

Device identities

Source device: ME
Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 03 82 02 81 82 83 01 03

Expected Sequence 1.2 (REFRESH, File Change Notification)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: REFRESH 1.2.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: REFRESH 1.2.1	
4	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
5	SIM	Update EF FDN RECORD 1	[EF FDN record 1 updated to contain the dialling string "0123456789"]
6	$ME \rightarrow SIM$	READ RECORD: EF FDN	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 1.2.1A Or	[normal ending]
		TERMINAL RESPONSE: REFRESH 1.2.1B	[additional EFs read]
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
9	$\begin{array}{c} USER \to \\ ME \end{array}$	Call setup to "123"	
10	$\begin{array}{c} ME \to \\ USER \end{array}$	Call set up not allowed	
11	USER → ME	Call setup to "0123456789"	
12	$ME \rightarrow SS$	Setup	Called party BCD number shall be "0123456789"

PROACTIVE COMMAND: REFRESH 1.2.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: SIM
Destination device: ME
File List: EF FDN

Coding:

BER-TLV: D0 12 81 03 01 01 01 82 02 81 82 92

TERMINAL RESPONSE: REFRESH 1.2.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 01 82 02 81 82 83 01 00

TERMINAL RESPONSE: REFRESH 1.2.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 01 82 02 81 82 83 01 03

Expected Sequence .13 (REFRESH, SIM Initialisation and File Change Notification)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: REFRESH 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: REFRESH 1.3.1	
4	SIM	Update EF PLMN	[EF PLMN to contain the PLMN code "98798" as the first PLMN code]
5	$ME \to SIM$	READ BINARY: EF PLMN	
6	$ME \to SIM$	TERMINAL RESPONSE: REFRESH 1.3.1A Or	[normal ending]
7	$SIM \to ME$	TERMINAL RESPONSE: REFRESH 1.3.1B PROACTIVE SIM SESSION ENDED	[additional EFs read]

PROACTIVE COMMAND: REFRESH 1.3.1

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

1

Device identities

Source device: SIM
Destination device: ME
File List: EF PLMN

Coding:

BER-TLV: D0 12 81 03 01 01 02 82 02 81 82 92 7F 07 01 3F 00 20 6F 30

TERMINAL RESPONSE: REFRESH 1.3.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 02 82 02 81 82 83 01 00

TERMINAL RESPONSE: REFRESH 1.3.1B

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 02 82 02 81 82 83 01 03

Expected Sequence 1.4 (REFRESH, SIM Initialisation and Full File Change Notification)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: REFRESH 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: REFRESH 1.4.1	
4	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
5	SIM	Update EF FDN	[EF FDN record 1 updated to contain the dialling string "0123456789"]
6	$ME \rightarrow SIM$	SIM Initialisation	[ME performs SIM initialisation]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 1.4.1A	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
9	$\begin{array}{c} USER \to \\ ME \end{array}$	Call setup to "321"	
10	$\begin{array}{c} ME \to \\ USER \end{array}$	Call set up not allowed	
11	$\begin{array}{c} USER \to \\ ME \end{array}$	Call setup to "0123456789"	
12	$ME \rightarrow SS$	Setup	Called party BCD number shall be "0123456789"

PROACTIVE COMMAND: REFRESH 1.4.1A

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialisation and Full File Change Notification

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 01 00 82 02 81 82

TERMINAL RESPONSE: REFRESH 1.4.1A

Logically:

Command details

Command number: 1

Command type: REFRESH Command qualifier: SIM Initialisation

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 01 02 82 02 81 82 83 01 00 81 03 01

Expected Sequence 1.5 (REFRESH, SIM Reset)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: REFRESH 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
4	ME OIM	REFRESH 1.5.1	
4	IME → SIM	GSM Termination Procedure	
5	$ME \to SIM$	GSM Activation Procedure	[At same voltage]
6	$ME \rightarrow SIM$	SIM Initialisation	
_			ING TERMINAL REGRONGE
7	$ME \rightarrow SIM$		[NO TERMINAL RESPONSE]
	/ 0		

PROACTIVE COMMAND: REFRESH 1.5.1

Logically:

Command details

Command number:

Command type: REFRESH Command qualifier: SIM Reset

Device identities

Source device: SIM ME

Destination device:

Coding:

BER-TLV: D0 09 81 03 01 01 04 82 02 81 82

Expected Sequence 1.6 (REFRESH, SIM Initialisation after SMS-PP data download)

Step	Direction	MESSAGE / Action	Comments
1	ME	The ME shall be in its normal idle	Start a sequence to verify that the ME
		mode	returns the RP-ACK message back to the
			system Simulator, if the SIM responds with
			90 00']
2	$SS \to ME$	SMS-PP Data Download Message	-
		1.6.1	
3	ME o	The ME shall not display the	
	USER	message or alert the user of a	
		short message waiting	
4	$ME \rightarrow SIM$		
_		DOWNLOAD 1.6.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	
	NAT 00	PENDING: REFRESH 1.1.1	
6	ME -> SS	_	
7	$ME \rightarrow SIM$		
8	$SIM \rightarrow ME$		
	CIM	REFRESH 1.1.1	[Destricted distliner facture is an ablad]
9	SIM	Invalidate EF IMSI, EF LOCI and EF ADN	[Restricted dialling feature is enabled]
10	ME CIM	SIM Initialisation	[ME performs SIM initialisation]
11		TERMINAL RESPONSE:	[INE PEROTITIS STATEMENT
''	INE -> SIIN	REFRESH 1.1.1A	
		Or	
		TERMINAL RESPONSE:	
		REFRESH 1.1.1B	
12	$SIM \rightarrow ME$		
12	Olivi -> IVIL	ENDED	
13	USER →	Call setup to "321"	
	ME		
14	ME →	Call set up not allowed	
	USER	r	
15	USER →	Call setup to "123"	
	ME	'	
16	$ME \to SS$	Setup	Called party BCD number shall be "123"

SMS-PP (Data Download) Message 1.6.1

Logically:

SMS TPDU TP-MTI **SMS-DELIVER** No more messages waiting for the MS in this SC TP-MMS TP-Reply-Path is not set in this SMS-DELIVER TP-RP TP-UDHI TP-UD field contains only the short message TP-SRI A status report will not be returned to the SME TP-OA TON International number NPI "ISDN / telephone numbering plan" Address value "1234" TP-PID SIM Data download TP-DCS Coding Group General Data Coding Text is uncompressed Compression Class 2 SIM Specific Message Message Class Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0 TP-UDL 13 TP-UD "Short Message"

Coding:

BER-TLV	04	03	91	21	43	7F	12	89	10	10	00	00
	00	00	0D	53	F4	5B	4E	07	35	CB	F3	79
	Гο	FC	O.C									

ENVELOPE: SMS-PP DOWNLOAD 1.6.1

Logically:

SMS-PP Download Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV: 2C 02 D1 82 83 81 06 09 91 11 22 33 44 55 66 77 F8 8B 1B 04 04 91 21 43 7F 12 89 10 10 00 00 00 00 0D 53 F4 5B 07 35 CB F3 79 F8 5C 06

27.22.4.7.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1, 2, 3, 4 and 5.

27.22.4.7.2 REFRESH (IMSI changing procedure)

27.22.4.7.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.7.2.2 Conformance requirement

The ME shall support the REFRESH command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.7 (Refresh), 6.6.13.(Refresh), clause 5.2 (Terminal profile), clause 12.6 (Command details), clause 12.7 (Device identities), clause 12.18 (File list)

Additionally the ME shall support the SIM Initialisation procedure as defined in the following technical specifications:

3GPP TS 11.11 [13] clause 12.2.1

27.22.4.7.2.3 Test Purpose

To verify that the ME performs the SIM initialisation and / or re-reads the contents and structure of the EFs on the SIM that have been changed and / or restarts the card session by resetting the ME, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.7.2.4 Method of test

27.22.4.7.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files for the second SIM Simulator are coded as SIM Application Toolkit default with the following exceptions.

27.22.4.7.2.4.2 Procedure

Expected Sequence 2.1 (REFRESH, SIM Initialisation and File Change Notification)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: REFRESH 2.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: REFRESH 2.1.1	
4	SIM	Update EF IMSI, EF LOCI and EF KC	[Update the contents of EF IMSI to "001010123456788", EF LOCI to not updated and EF KC to not valid]
5	ME	Invoke MM Restart Procedure	
6	$ME \to SIM$	SIM INITIALISATION	[ME performs SIM initialisation; including reading EF IMSI, EF LOCI and EF KC]
7	$ME \to SIM$	TERMINAL RESPONSE: REFRESH 2.1.1A Or	[normal]
		TERMINAL RESPONSE: REFRESH 2.1.1B	[additional EFs read]
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	$ME \to SS$	Location updating request (type "normal location updating")	[Send IMSI of "001010123456788" to System Simulator]

PROACTIVE COMMAND: REFRESH 2.1.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

Device identities

Source device: SIM
Destination device: ME

File List

File 1: EF IMSI File 2: EF LOCI File 3: EF KC

Coding:

BER-TLV: D0 20 81 03 01 01 02 82 02 81 82 92 13 03 3F 00 7F 20 6F 07 3F 00 7F 20

6F 7E 3F 00 7F 20 6F 20

TERMINAL RESPONSE: REFRESH 2.1.1A

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

1

Coding:

BER-TLV: 81 03 01 01 02 82 02 81 82 83 01 00

TERMINAL RESPONSE: REFRESH 2.1.1B

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

Device identities

Source device: ME
Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 02 82 02 81 82 83 01 03

Expected Sequence 2.2 (REFRESH, SIM Initialisation and Full File Change Notification)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: REFRESH 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: REFRESH 2.2.1	
4	SIM	Update EF IMSI	[Update the contents of EF IMSI to "001010123456787", -]
5	ME	Invoke MM Restart Procedure	
6	$ME \rightarrow SIM$	SIM INITIALISATION	[ME performs SIM initialisation; including reading EF IMSI, EF LOCI and EF KC]
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: REFRESH 2.2.1	[normal]
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
9	$ME \rightarrow SS$	IMSI ATTATCH	[Send IMSI of "001010123456787" to System Simulator]

PROACTIVE COMMAND: REFRESH 2.2.1

Logically:

Command details

Command number:

Command type: REFRESH

Command qualifier: SIM Initialisation and Full File Change Notification

Device identities

Source device: SIM ME

Destination device:

Coding:

BER-TLV: 09 81 03 01 01 00 82 02 81 82 D0

TERMINAL RESPONSE: REFRESH 2.2.1

Logically:

Command details

Command number: 1

Command type: REFRESH

Command qualifier: SIM Initialisation and File Change Notification

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 00 82 02 81 82 83 01 00 Expected Sequence 2.3 (REFRESH, SIM Reset)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: REFRESH 2.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: REFRESH 2.3.1	
4	SIM	Update EF IMSI	[Update the contents of EF IMSI to "001010123456786
5	$ME \to SIM$	GSM Termination Procedure	
6	$ME \to SIM$	GSM Activation Procedure	[At same voltage]
7	$ME \to SIM$	SIM Initialisation	[ME performs SIM initialisation; including reading EF IMSI, EF LOCI and EF KC]
8	$ME \to SS$	IMSI ATTATCH	[Send IMSI of "001010123456786" to System Simulator]

PROACTIVE COMMAND: REFRESH 2.3.1

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Reset

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 01 04 82 02 81 82

27.22.4.7.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1, 2 and 3.

27.22.4.8 SET UP MENU and ENVELOPE MENU SELECTION

27.22.4.8.1 SET UP MENU and ENVELOPE MENU SELECTION (normal)

27.22.4.8.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.8.1.2 Conformance Requirement

The ME shall support the SET UP MENU command as defined in the following technical specifications:

3GPP TS 11.14 clause 5 (Profile download), 6.4.8 (SET UP MENU), 6.6.7 (SET UP MENU), 6.8 (Structure of TERMINAL RESPONSE), 6.11 (Proactive commands versus possible Terminal response), 12.6 (Command details), 12.9 (Item), 13.4 (Type of Command and Next Action Indicator).

The ME shall support MENU SELECTION as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.4 (Menu Selection mechanism), 5.2 (Terminal Profile), clause 6.4.8 (Set Up Menu), clause 6.9, clause 8 (Menu Selection), clause 12.7 (Device Identities), clause 12.10 (Item Identifier).

27.22.4.8.1.3 Test Purpose

To verify that the ME correctly integrates the menu items contained in the SET UP MENU proactive SIM command, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME replaces the current list of menu items with the list of menu items contained in the SET UP MENU command.

To verify that the ME removes the current list of menu items following receipt of a SET UP MENU command with no items.

To verify that the ME correctly passes the identifier of the selected menu item to the SIM using the ENVELOPE (MENU SELECTION) command.

To verify that when the help is available for the command and the user gas indicated the need to get help information on one of the items, the ME informs properly the SIM about an HELP REQUEST, using the MENU SELECTION mechanism.

27.22.4.8.1.4 Method of Test

27.22.4.8.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display

27.22.4.8.1.4.2 Procedure

Expected Sequence 1.1 (SET UP MENU and MENU SELECTION, without Help Request, Replace and Remove a Toolkit Menu)

1	-:-		Comments
	$SS \to ME$	PROACTIVE COMMAND PENDING: SET UP MENU 1.1.1	[First Set Up Menu]
2	$ME \to SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP MENU 1.1.1	
4	$\begin{array}{c} ME \to \\ USER \end{array}$	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items	
		of "Item 1", "Item 2", "Item 3" and "Item 4" under this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 1.1.1	[Command Performed Successfully]
6	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
7	$\begin{array}{c} USER \to \\ ME \end{array}$	Select the Toolkit Menu "Toolkit Menu"	
8	$\begin{array}{c} \text{ME} \rightarrow \\ \text{USER} \end{array}$	Display "Item 1", "Item 2", "Item 3", "Item 4"	
9	$\begin{array}{c} \text{USER} \rightarrow \\ \text{ME} \end{array}$	Select the "Item 2" Menu entry	
10	$ME \rightarrow SIM$	Send the ENVELOPE 1.1.1 : MENU SELECTION (Identifier of item: 2)	
11	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP MENU 1.1.2	[Second Set Up Menu, REPLACE Old Menu]
	$ME \rightarrow SIM$ $SIM \rightarrow ME$		
14	ME →	MENU 1.1.2 Integrate the new menu header of	
	USER	"Toolkit Menu" into its menu system and have the menu items of "One" and "Two" under this header.	
15	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 1.1.2	[Command Performed Successfully]
16	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
17	USER → ME	Select the Toolkit Menu "Toolkit Menu"	
18	ME → USER	Display "One", "Two"	
19	USER → ME	Select the "Two" menu entry Send the ENVELOPE 1.1.2:	
20	$ME \rightarrow SIM$	MENU SELECTION (Identifier of item: 12)	
21	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP MENU 1.1.3 with SW1 / SW2 of '91 0F'.	[Third Set Up Menu, REMOVE Toolkit Menu]
	$\begin{array}{c} ME \to SIM \\ SIM \to ME \end{array}$	FETCH	
24	$\begin{array}{c} ME \to \\ USER \end{array}$	Remove the menu "Toolkit Menu" from its menu system.	
25		•	[Command Performed Successfully]
26	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

27	USER -	→ Has to unsuccessfully find the	
21	ME	Toolkit Menu	

PROACTIVE COMMAND: SET UP MENU 1.1.1

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Coding:

BER-TLV: D0 3B 03 00 82 02 81 82 85 81 01 25 0C 54 6F 6F 6C 6B 69 74 20 4D 65 6E 75 8F 07 01 49 74 65 6D 20 31 8F 07 02 8F 74 49 74 65 6D 20 32 07 03 49 65 6D 20 33 8F 07 04 49 74 65 6D 20 34

PROACTIVE COMMAND: SET UP MENU 1.1.2

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: "11"
Text string of item: "One"

Item

Identifier of item: "12"
Text string of item: "Two"

Coding:

BER-TLV: D0 23 81 03 01 25 00 82 02 81 82 85

0C 54 6F 6F 6C 6B 69 74 20 4D 65 6E 8F 4F 8F 75 04 11 6E 65 04 12 54 77

6F

PROACTIVE COMMAND: SET UP MENU 1.1.3

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME
Item: Empty

Coding:

BER-TLV: D0 0D 81 03 01 25 00 82 02 81 82 85

00 8F 00

TERMINAL RESPONSE: SET UP MENU 1.1.1, 1.1.2 and 1.1.3

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 25 00 82 02 82 81 83 01 00

ENVELOPE 1.1.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 02

Coding:

BER-TLV: D3 07 81 02 01 81 90 01 02

ENVELOPE 1.2: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 12

Coding:

BER-TLV: D3 07 81 02 01 81 90 01 12

Expected Sequence 1.2 (SET UP MENU, Large Menu with many items or with large items or with Large Alpha Identifier)

			I
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP MENU 1.2.1	[First Large Menu with many items, Fetch of FF bytes]
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND SET UP MENU 1.2.1	
4	$ME \rightarrow$	Integrate the new menu header of	
	USER	"LargeMenu1" into its menu system and have the menu items	
		of "Zero", "One", "Two", Three",	
		"Four", "Five", "Six", "Seven",	
		"Eight", "Nine", "Alpha", "Bravo",	
		"Charlie", "Delta", "Echo", "Fox- trot", "Black", "Brown", "Red",	
		"Orange", "Yellow", "Green",	
		"Blue", "Violet", "Grey", "White",	
		"milli", "micro", "nano" and "pico"	
5	ME ZIM	under this header. TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
	IVIL -> OIIVI	MENU 1.2.1	[Command 1 chomica decectionity]
6	$SIM \to ME$		
		ENDED	
7	USER \rightarrow	Select the Toolkit	
7	ME	"LargeMenu1"	
8		Display "Zero", "One", "Two"	
	USER	"pico"	
9	$\begin{array}{cc} \text{USER} & \rightarrow \\ \text{ME} \end{array}$	Select the "Orange" menu entry	
		Send the ENVELOPE 1.2.1 :	
10	SIM	MENU SELECTION	
4.4	0114 145	(Identifier of item: 0x3D)	N
11	SIM → ME	PROACTIVE COMMAND PENDING: SET UP MENU 1.2.2	[Second Large Menu with large items, Fetch of F6 bytes]
12	$ME \to SIM$		[6 2,186]
13	$SIM \to ME$	PROACTIVE COMMAND SET UP	
14	ME o	MENU 1.2.2 Integrate the new menu header of	
	USER	"LargeMenu2" into its menu	
		system and have the menu items	
		of "1 Call Forward Unconditional", "2 Call Forward On User Busy", "3	
		Call Forward On No Reply", "4	
		Call Forward On User Not	
		Reachable", "5 Barring Of All Outgoing Calls", "6 Barring Of All	
		Outgoing Calls, 6 Barring Of All	
4.5		Presentation" under this header.	Command Barta 10 (11)
15	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 1.2.2	[Command Performed Successfully]
16	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
	USER →	Select the Toolkit Menu	
17	ME	"LargeMenu2"	
		Display "1 Call Forward	
	USER	Unconditional", "2 Call Forward	
		On User Busy", "3 Call	
18		Forward On No Reply", "4 Call Forward On User Not	
10		Reachable", "5 Barring Of All	
		Outgoing Calls", "6 Barring Of	
		All Outgoing Int Calls", "7 CLI	
		Presentation"	

19	ME	Select the "5 Barring Of All Outgoing Calls" menu entry	
20	$\begin{array}{cc} \text{ME} & \rightarrow \\ \text{SIM} \end{array}$	Send the ENVELOPE 1.2.2 : MENU SELECTION (Identifier of item: 0xFB)	
21	$SIM \rightarrow ME$,	[Third Large Menu with a Large Alpha Identifier and only one Short Item, Fetch of FF bytes]
22 23	$\begin{array}{c} ME \to SIM \\ SIM \to ME \end{array}$		
24	ME → USER	Integrate the new menu header of "The SIM shall supply a set of menu items, which shall be integrated with the menu system (or other MMI facility) in order to give the user the opportunity to choose one of these menu items at his own discretion. Each item comprises a sh" into it's menu system and have a menu item of "Y" under this header.	
25	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 1.2.3	[Command Performed Successfully]
26	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
5	USER → ME	Select the Toolkit Menu "The SIM shall supply a set of menu items, which shall be integrated with the menu system (or other MMI facility) in order to give the user the opportunity to choose one of these menu items at his own discretion. Each item comprises a sh".	
6	$\begin{array}{c} \text{ME} \rightarrow \\ \text{USER} \end{array}$	Display "Y"	
7	$\begin{array}{c} \text{USER} \\ \rightarrow \text{ME} \end{array}$	Select the item "Y"	
8	ME → SI M	Send the ENVELOPE 1.1.6 : MENU SELECTION (Identifier of item: 1)	

PROACTIVE COMMAND: SET UP MENU 1.2.1

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "LargeMenu1"

Item

Identifier of item: "50" Text string of item: "Zero"

Item

Identifier of item: "4F"
Text string of item: "One"

Item

Identifier of item: "4E"
Text string of item: "Two"

Item

Identifier of item: "4D"
Text string of item: "Three"

Item

Identifier of item: "4C"
Text string of item: "Four"

Item

Identifier of item: "4B"
Text string of item: "Five"

Item

Identifier of item: "4A" Text string of item: "Six"

Item

Identifier of item: "49"
Text string of item: "Seven"

Item

Identifier of item: "48"
Text string of item: "Eight"

[tem

Identifier of item: "47"
Text string of item: "Nine"

Item

Identifier of item: "46"
Text string of item: "Alpha"

Item

Identifier of item: "45"
Text string of item: "Bravo"

Item

Identifier of item: "44"
Text string of item: "Charlie"

Item

Identifier of item: "43"
Text string of item: "Delta"

Item

Identifier of item: "42"
Text string of item: "Echo"

Item

Identifier of item: "41"
Text string of item: "Fox-trot"

Item

Identifier of item: "40"
Text string of item: "Black"

Item

Identifier of item: "3F"
Text string of item: "Brown"

Item

Identifier of item: "3E"
Text string of item: "Red"

Item

Identifier of item: "3D"
Text string of item: "Orange"

Item

Identifier of item: "3C"
Text string of item: "Yellow"

Item

Identifier of item: "3B"
Text string of item: "Green"

Item

Identifier of item: "3A"
Text string of item: "Blue"

Item

Identifier of item: "39"
Text string of item: "Violet"

Item

Identifier of item: "38"
Text string of item: "Grey"

Item

Identifier of item: "37"
Text string of item: "White"

Item

Identifier of item: "36"
Text string of item: "milli"

Item

Identifier of item: "35"
Text string of item: "micro"

Item

Identifier of item: "34"
Text string of item: "nano"

Item

Identifier of item: "33"
Text string of item: "pico"

Coding:

BER-TLV:	D0	81	FC	81	03	01	25	00	82	02	81	82
	85	0A	4C	61	72	67	65	4D	65	6E	75	31
	8F	05	50	5A	65	72	6F	8F	04	4F	4F	6E
	65	8F	04	4E	54	77	6F	8F	06	4D	54	68
	72	65	65	8F	05	4C	46	6F	75	72	8F	05
	4B	46	69	76	65	8F	04	4A	53	69	78	8F
	06	49	53	65	76	65	6E	8F	06	48	45	69
	67	68	74	8F	05	47	4E	69	6E	65	8F	06
	46	41	6C	70	68	61	8F	06	45	42	72	61
	76	6F	8F	80	44	43	68	61	72	6C	69	65
	8F	06	43	44	65	6C	74	61	8F	05	42	45
	63	68	6F	8F	09	41	46	6F	78	2D	74	72
	6F	74	8F	06	40	42	6C	61	63	6B	8F	06
	3F	42	72	6F	77	6E	8F	04	3E	52	65	64
	8F	07	3D	4F	72	61	6E	67	65	8F	07	3C
	59	65	6C	6C	6F	77	8F	06	3B	47	72	65
	65	6E	8F	05	3A	42	6C	75	65	8F	07	39
	56	69	6F	6C	65	74	8F	05	38	47	72	65
	79	8F	06	37	57	68	69	74	65	8F	06	36
	6D	69	6C	6C	69	8F	06	35	6D	69	63	72
	6F	8F	05	34	6E	61	6E	6F	8F	05	33	70
	69	63	6F									

PROACTIVE COMMAND: SET UP MENU 1.2.2

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "LargeMenu2"

Item

Identifier of item: "FF"

Text string of item: "1 Call Forward Unconditional"

Item

Identifier of item: "FE

Text string of item: "2 Call Forward On User Busy"

Item

Identifier of item: "FD'

Text string of item: "3 Call Forward On No Reply"

Item

Identifier of item: "FC"

Text string of item: "4 Call Forward On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "5 Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "6 Barring Of All Outgoing Int Calls"

Item

Identifier of item: "F9"

Text string of item: "7 CLI Presentation"

Coding:

BER-TLV: D0 F3 4C 4D 6E 0A 8F 1D FF 6C 6C 6F 6E 6F 6E 6F 6E 6C 8F 1C FΕ 6C 6F 6C 4F 6E 8F 6C 1B FD 6C 6F 4F 6E 4E 6F 6C FC 8F 6C 6C 6F 4F 6E 4E 6F 6C 8F FΒ 6E 4F 6C 6C 4F 6F 6E 6C 6C 8F FΑ 6E 4F 6C 6C 4F 6F 6E 6C F9 6E 6C 8F 4C 6E 6F 6E

PROACTIVE COMMAND: SET UP MENU 1.2.3

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "The SIM shall supply a set of menu items, which shall be integrated with

the menu system (or other MMI facility) in order to give the user the opportunity to choose one of these menu items at his own discretion. Each

item comprises a sh"

Item

Identifier of item: "01"
Text string of item: "Y"

Coding:

BER-TLV: D0 81 FC 81 03 01 25 00 82 02 81 82 85 81 FC 54 68 65 20 53 49 4D 20 73

EC 4D 6C 6C 6C 6D 6F 6E 6D 2C 6C 6C 6E 6D 6E 6D 6F 6F 4D 4D 6C 6E 6F 6F 6F 6F 6E 6F 6F 6F 6F 6F 6E 6D 6D 6E 6F 6E 6F 6E 2E 6D 6F 6D 8F

TERMINAL RESPONSE: SET UP MENU 1.2.1, 1.2.2 and 1.2.3

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "no help information available"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 25 00 82 02 82 81 83 01 00

ENVELOPE 1.2.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 3D

Coding:

BER-TLV: D3 07 81 02 01 81 90 01 3D

ENVELOPE 1.2.2: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier FB

Coding:

BER-TLV: D3 07 81 02 01 81 90 01 FB

ENVELOPE 1.2.3: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad
Destination device: SIM
Item identifier 01

Coding:

BER-TLV: D3 07 81 02 01 81 90 01 01

The following table details the test requirements with relation to the tested features:

	Proactive SIM Command Facilities					
Proactive SIM Command Number	Alpha Identifier Length	Number of items	Maximum length of item			
1.1.1	12	4	6			
1.1.2	12	2	3			
1.1.3	10	0	-			
1.2.1	10	30	8			
1.2.2	10	7	37			
1.2.3	235	1	1			

27.22.4.8.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 and in expected sequence 2.

27.22.4.8.2 SET UP MENU (help request support)

27.22.4.8.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.8.2.2 Conformance Requirement

Requirements are the same as in 27.22.4.8.1.1, with an additional one: GSM 11.14 clause 12.21 (Help Request).

27.22.4.8.2.3 Test Purpose

To verify that when the help is available for the command and the user gas indicated the need to get help information on one of the items, the ME informs properly the SIM about an HELP REQUEST, using the MENU SELECTION mechanism.

27.22.4.8.2.4 Method of Test

27.22.4.8.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display

27.22.4.8.2.4.2 Procedure

Expected Sequence 2.1 (SET UP MENU and MENU SELECTION, with Help Request, Replace and Remove a Toolkit Menu)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	PROACTIVE COMMAND PENDING: SET UP MENU 2.1.1	[First Set Up Menu]
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP MENU 2.1.1	
4	ME → USER	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" and "Item 4" under this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 2.1.1	[Command Performed Successfully]
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
7	USER → ME	Select the Toolkit Menu "Toolkit Menu"	
8	$\begin{array}{cc} \text{ME} & \rightarrow \\ \text{USER} & \end{array}$	Display "Item 1", "Item 2", "Item 3", "Item 4"	
9	USER → ME	"Item 2" Menu entry	
10	ME → SIM	Send the ENVELOPE 2.1.1 : MENU SELECTION (Identifier of item: 2)	

PROACTIVE COMMAND: SET UP MENU 2.1.1

Lo	gica	llv:
LO	Sicu	ш.

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "80"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2
Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Coding:

BER-TLV:	D0	3B	81	03	01	25	80	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	8F	07	04	49	74	65	6D	20
	34											

TERMINAL RESPONSE: SET UP MENU 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « help information available »

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER- 81 03 01 25 80 82 02 82 81 83 01 00

TLV:

ENVELOPE 2.1.1: MENU SELECTION

Logically:

Menu selection

Device identities

Source device: Keypad

Destination device: SIM

Item identifier 02

Help request tag

Coding:

BER- D3 09 81 02 01 81 90 01 02 15 00

TLV:

27.22.4.8.3 SET UP MENU (next action support)

27.22.4.8.3.1 Definition and applicability

See Section 3.2.2.

If the SIM provides an Items Next Action Indicator data object, the comprehension required flag shall be set to '0'.

27.22.4.8.3.2 Conformance Requirement

Requirements are the same as in 27.22.4.8.1.1, with an additional one: GSM 11.14 clause 12.24 (Items Next Action Indicator).

27.22.4.8.3.3 Test Purpose

To verify that when the next action indicator is supported.

27.22.4.8.3.4 Method of Test

27.22.4.8.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display

27.22.4.8.3.4.2 Procedure

Expected Sequence 3.1 (SET UP MENU, next action indicator "Send SM", "Set Up Call", "Launch Browser", "Provide Local Information", successful)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 3.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP	
		MENU 3.1.1	
4	ME →	Integrate the menu header of	
	USER	"Toolkit Menu" into its menu	
		system and have the menu items of "Item 1", "Item 2", "Item 3" and	
		"Item 4" under this header.	
5	ME → SIM	TERMINAL RESPONSE: SET UP	[Command Performed Successfully]
	IVIE 7 OIIVI	MENU 3.1.1	[Command Command Comma
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
7	USER \rightarrow	Select the Toolkit Menu	
/	ME	"Toolkit Menu"	
0	$ME \rightarrow$	Display "Item 1", "Item 2", "Item	
8	USER	3", "Item 4"	
	USER \rightarrow	Navigate in the items, then	Check that next action indicators should
9	ME	select "Item 2".	appear.

PROACTIVE COMMAND: SET UP MENU 3.1.1

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item:

Text string of item: "Item 4"

Items next action indicator list

List: "Send SM", "Set Up Call", "Launch Browser", "Provide Local

Information"

Coding:

BER-TLV: D0 81 03 01 25 00 82 02 81 82 85 41 0C 6F 6F 6C 6B 74 20 4D 65 6E 54 69 75 8F 07 01 49 74 65 6D 20 31 8F 07 02 49 74 65 6D 20 32 8F 03 49 74 07 20 8F 04 49 74 65 20 65 6D 33 07 10 13 15 26

TERMINAL RESPONSE: SET UP MENU 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « no help information available »

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER- 81 03 01 25 00 82 02 82 81 83 01 00

TLV:

27.22.4.8.4 SET UP MENU (display of icons)

27.22.4.8.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.8.4.2 Conformance Requirement

Requirements are the same as in 27.22.4.8.1.1, with an additional one: GSM 11.14 clause 6.5.4, 12.31 and 12.32.

27.22.4.8.4.3 Test Purpose

To verify that icons are displayed with the command Set Up Menu in the Alpha Identifier and Items Data Objects.

27.22.4.8.4.4 Method of Test

27.22.4.8.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display

27.22.4.8.4.4.2 Procedure

Expected Sequence 4.1A (SET UP MENU, BASIC ICON NOT SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP MENU 4.1.1	
4	ME → USER	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 4.1.1A	[Command Performed Successfully]
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
7	USER → ME	Select the Toolkit Menu "Toolkit Menu"	Verify the icon is displayed with alpha id.
8	$\begin{array}{cc} \text{ME} & \rightarrow \\ \text{USER} & \end{array}$	Display "Item 1", "Item 2", "Item 3".	
9	USER → ME	Navigate in the items, then select "Item 2".	Verify icons are displayed for each item.

PROACTIVE COMMAND: SET UP MENU 4.1.1

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Icon identifier

Icon qualifier: icon is not self explanatory

Icon identifier: record 1 EF (IMG)

Item icon identifier list

Icon qualifier: icon is not self explanatory

Icon identifier list: record 5 EF (IMG), record 5 EF (IMG), record 5 EF (IMG)

Coding:

BER-TLV: D0 3C 81 03 01 25 00 82 02 81 82 85 0C 54 6F 6F 6C 6B 69 74 20 4D 65 6E 75 8F 49 74 65 6D 20 31 8F 07 07 01 6D 20 8F 74 02 49 74 65 32 07 03 49 9F 65 6D 20 33 9E 02 01 04 05 05 05

TERMINAL RESPONSE: SET UP MENU 4.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « no help information available »

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER- 81 03 01 25 00 82 02 82 81 83 01 00

TLV:

Expected Sequence 4.1B (SET UP MENU, BASIC ICON NOT SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP MENU 4.1.1	[First Set Up Menu]
2	$ME \rightarrow SIM$	FETCH	
3	SIM → ME	PROACTIVE COMMAND SET UP MENU 4.1.1	
4	ME → USER	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header.	
5	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE: SET UP MENU 4.1.1B	[Command performed successfully, but requested icon could not be displayed]
6	SIM → ME	PROACTIVE SIM SESSION ENDED	
7	USER → ME	Select the Toolkit Menu "Toolkit Menu"	No icon is displayed with alpha id.
8	ME → USER	Display "Item 1", "Item 2", "Item 3".	

0	$USER \rightarrow$	Navigate in the items, then select	no icon is displayed for each item.	
9	ME	"Item 2".		

TERMINAL RESPONSE: SET UP MENU 4.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « no help information available »

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Coding:

BER- 81 03 01 25 00 82 02 82 81 83 01 04 TLV:

Expected Sequence 4.2A (SET UP MENU, BASIC ICON SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP MENU 4.2.1	[First Set Up Menu]
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND SET UP MENU 4.2.1	
4	ME → USER	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header.	
5	ME → SIM	TERMINAL RESPONSE: SET UP MENU 4.2.1A	[Command Performed Successfully]

6	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE SIM SESSION ENDED	
7	USER → ME	Select the Toolkit Menu "Toolkit Menu"	Verify the icon is displayed in alpha id.
8	ME → USER	Display "Item 1", "Item 2", "Item 3".	
9	USER → ME	Navigate in the items, then select "Item 2".	Verify icons are displayed for each item.

PROACTIVE COMMAND: SET UP MENU 4.2.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item: 1

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Icon identifier

Icon qualifier: icon is self explanatory

Icon identifier: record 1 EF (IMG)

Item icon identifier list

Icon qualifier: icon is self explanatory

Icon identifier list: record 5 EF (IMG), record 5 EF (IMG), record 5 EF (IMG)

Coding:

BER-TLV:	D0	3C	81	03	01	25	00	82	02	81	82	85
	0C	54	6F	6F	6C	6B	69	74	20	4D	65	6E
	75	8F	07	01	49	74	65	6D	20	31	8F	07
	02	49	74	65	6D	20	32	8F	07	03	49	74
	65	6D	20	33	9E	02	00	01	9F	04	00	05
	05	05										

TERMINAL RESPONSE: SET UP MENU 4.2.1A

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « no help information available »

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER- 81 03 01 25 00 82 02 82 81 83 01 00 TLV:

Expected Sequence 4.2B (SET UP MENU, BASIC ICON SELF EXPLANATORY in ALPHA ID and ITEMS DATA OBJECTS, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP MENU 4.2.1	[First Set Up Menu]
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	SIM → ME	PROACTIVE COMMAND SET UP MENU 4.2.1	
4	ME → USER	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2", "Item 3" under this header.	

5	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE: SET UP MENU 4.2.1B	[Command Performed Successfully]
6	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE SIM SESSION ENDED	
7	$\begin{array}{c} \text{USER} \rightarrow \\ \text{ME} \end{array}$	Select the Toolkit Menu "Toolkit Menu"	No icon is displayed in alpha id.
8	$\begin{array}{c} \text{ME} \rightarrow \\ \text{USER} \end{array}$	Display "Item 1", "Item 2", "Item 3".	
9	$\begin{array}{c} \text{USER} \rightarrow \\ \text{ME} \end{array}$	Navigate in the items, then select "Item 2".	no icon is displayed for each item.

TERMINAL RESPONSE: SET UP MENU 4.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « no help information available »

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Coding:

BER- 81 03 01 25 00 82 02 82 81 83 01 04 TLV:

27.22.4.8.5 SET UP MENU (soft keys support)

27.22.4.8.5.1 Definition and applicability

See Section 3.2.2.

27.22.4.8.5.2 Conformance Requirement

Requirements are the same as in 27.22.4.8.1.1.

27.22.4.8.5.3 Test Purpose

To verify that if soft key preferred is indicated in the command details and soft key for SET UP MENU is supported by the ME and the number of icon items does not exceed the number of soft keys available, then the ME displays those icons as soft key.

27.22.4.8.5.4 Method of Test

27.22.4.8.5.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

The ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display

27.22.4.8.5.4.2 Procedure

Expected Sequence 5.1 (SET UP MENU, SOFT KEY PREFERRED, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	PROACTIVE COMMAND	[First Set Up Menu]
		PENDING: SET UP MENU 5.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND SET UP MENU 5.1.1	
4	ME → USER	Integrate the menu header of "Toolkit Menu" into its menu system and have the menu items of "Item 1", "Item 2" under this header.	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP MENU 5.1.1	[Command Performed Successfully]
6	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
7	USER → ME	Select the Toolkit Menu "Toolkit Menu"	
8	$\begin{array}{cc} \text{ME} & \rightarrow \\ \text{USER} & \end{array}$	Display "Item 1", "Item 2"	
9	USER → ME	Navigate in the items, then select "Item 2".	Verify we can select items through soft keys

PROACTIVE COMMAND: SET UP MENU 5.1.1

Logically:

Command details

Command number:

Command type: SET UP MENU

Command qualifier: "01" (selection using soft key preferred)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Menu"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Coding:

BER-TLV: D0 29 81 03 01 25 01 82 02 82 85 81 0C 54 6F 6F 6C 6B 69 74 20 4D 65 6E 75 8F 07 01 49 74 65 6D 20 31 8F 07 02 49 74 65 6D 20 32

TERMINAL RESPONSE: SET UP MENU 5.1.1

Logically:

Command details

Command number: 1

Command type: SET UP MENU

Command qualifier: « no help information available »

Device identities

Source device: ME

208

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER- 81 03 01 25 00 82 02 82 81 83 01 00 TLV:

27.22.4.9 SELECT ITEM

27.22.4.9.1 SELECT ITEM (mandatory features for ME supporting SELECT ITEM)

27.22.4.9.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.1.2 Conformance Requirement

The ME shall support the Proactive SIM: Select Item facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5 (Profile Download), 6.4.9 (Proactive SIM commands and procedures, SELECT ITEM), 6.6.8 (Structure of proactive SIM commands, SELECT ITEM), 6.8 (Structure of TERMINAL RESPONSE), 12.6 (Command details), 13.4 (Type of Command and Next Action Indicator), 14 (Allowed Type of command and Device identity combinations).

27.22.4.9.1.3 Test Purpose

To verify that the ME correctly presents the set of items contained in the SELECT ITEM proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM with the identifier of the item chosen.

To verify that the ME allows a SELECT ITEM proactive SIM command within the maximum 255 byte BER-TLV boundary.

To verify that the ME returns a TERMINAL RESPONSE with "Proactive SIM application session terminated by the user", if the user has indicated the need to end the proactive SIM session.

To verify that the ME returns a TERMINAL RESPONSE with "Backwards move in the proactive SIM application session requested by the user", if the user has indicated the need to go backwards in the proactive SIM application session.

The ability of the ME to send the TERMINAL RESPONSE with "No response from user" result value cannot be tested as the length of time to wait is undefined in GSM 11.14 [15].

27.22.4.9.1.4 Method of Test

27.22.4.9.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.1.4.2 Procedure

Expected Sequence 1.1 (SELECT ITEM, mandatory features, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.1.1	
4	ME o	Display items of "Item 1", "Item 2",	
	USER	"Item 3" and "Item 4" under the	
		header of "Toolkit Select".	
5	$USER \to$	Select "Item 2".	
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 1.1.1	

PROACTIVE COMMAND: SELECT ITEM 1.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item: 3

Text string of item: "Item 3"

Item

Identifier of item: 4

Text string of item: "Item 4"

Coding:

BER-TLV: D0 3D 81 03 01 24 00 82 02 81 82 85 0E 54 6F 6F 6C 6B 69 74 20 53 65 6C 65 63 74 8F 07 01 49 74 65 6D 20 31 8F 02 8F 07 49 74 65 6D 20 32 07 03 74 49 65 6D 20 33 8F 07 04 49 74 65 6D 20 34

TERMINAL RESPONSE: SELECT ITEM 1.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 02

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 00 90 01 02

Expected Sequence 1.2 (SELECT ITEM, large menu, successful)

Step	Direction	MESSAGE / Action	Comments
7	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.2.1	
8	$ME \rightarrow SIM$	FETCH	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.2.1	
10	ME o	Present the items of "Zero", "One",	
	USER	"Two", Three", "Four", "Five",	
		"Six", "Seven", "Eight", "Nine",	
		"Alpha", "Bravo", "Charlie",	
		"Delta", "Echo", "Fox-trot", "Black",	
		"Brown", "Red", "Orange",	
		"Yellow", "Green", "Blue", "Violet",	
		"Grey", "White", "milli", "micro",	
		"nano" and "pico" under the	
44	HOED	header of "LargeMenu1"	
11	USER →	Select item "Orange".	
40	ME	TERMINAL DESPONSE SELECT	
12	$ME \rightarrow SIM$		Command performed successfully
		ITEM 1.2.1	

PROACTIVE COMMAND: SELECT ITEM 1.2.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "LargeMenu1"

Item

Identifier of item: "50"
Text string of item: "Zero"

Item

Identifier of item: "4F"
Text string of item: "One"

Item

Identifier of item: "4E"
Text string of item: "Two"

Item

Identifier of item: "4D"
Text string of item: "Three"

Item

Identifier of item: "4C"
Text string of item: "Four"

Item

Identifier of item: "4B"
Text string of item: "Five"

Item

Identifier of item: "4A"
Text string of item: "Six"

Item

Identifier of item: "49"
Text string of item: "Seven"

Item

Identifier of item: "48"
Text string of item: "Eight"

Item

Identifier of item: "47"
Text string of item: "Nine"

Item

Identifier of item: "46"

Text string of item: "Alpha"

Item

Identifier of item: "45"
Text string of item: "Bravo"

Item

Identifier of item: "44"
Text string of item: "Charlie"

Item

Identifier of item: "43"
Text string of item: "Delta"

Item

Identifier of item: "42"
Text string of item: "Echo"

Item

Identifier of item: "41"
Text string of item: "Fox-trot"

Item

Identifier of item: "40"
Text string of item: "Black"

Item

Identifier of item: "3F"
Text string of item: "Brown"

Item

Identifier of item: "3E"
Text string of item: "Red"

Item

Identifier of item: "3D"
Text string of item: "Orange"

Item

Identifier of item: "3C"
Text string of item: "Yellow"

Item

Identifier of item: "3B"
Text string of item: "Green"

Item

Identifier of item: "3A"
Text string of item: "Blue"

Item

Identifier of item: "39"
Text string of item: "Violet"

Item

Identifier of item: "38"
Text string of item: "Grey"

Item

Identifier of item: "37"
Text string of item: "White"

Item

Identifier of item: "36"
Text string of item: "milli"

Item

Identifier of item: "35"
Text string of item: "micro"

Item

Identifier of item: "34"
Text string of item: "nano"

Item

Identifier of item: "33"
Text string of item: "pico"

Coding:

BER-TLV: FC D0 0A 4C 4D 6E 8F 5A 6F 8F 4F 4F 6E 8F 4E 6F 8F 4D 8F 4C 6F 8F 4B 8F 4A 8F 8F 6E 8F 4E 6E 8F 6C 8F 6C 6F 8F 6C 8F 8F 6F 8F 6F 2D 6F 8F 6C 6B 8F 3F 6F 6E 8F 3E 8F 3D 4F 6E 8F 3C 6C 6C 6F 8F 3B 6C 6E 8F ЗА 8F 6F 6C 8F 8F 8F 6C 6D 6C 8F 6D 6F 8F 6E 6E 6F 8F 6F

TERMINAL RESPONSE: SELECT ITEM 1.2.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 3D

Coding:

BER-TLV: 3D

Expected Sequence 1.3 (SELECT ITEM, call options, successful)

Direction	MESSAGE / Action	Comments
$SIM \rightarrow ME$		
$ME \rightarrow SIM$	FETCH	
$SIM \rightarrow ME$		
	SELECT ITEM 1.3.1	
ME o	Present the items of " Call	
USER	,	
	I	
	1 7 1	
	,	
	3 3	
LICED		
1		Command performed successfully
IVIE → SIIVI		
SIM ME		
Olivi → IVIE		
	$\begin{array}{c} \text{SIM} \rightarrow \text{ME} \\ \text{ME} \rightarrow \text{SIM} \\ \text{SIM} \rightarrow \text{ME} \\ \\ \text{ME} \rightarrow \\ \text{USER} \\ \\ \\ \text{USER} \rightarrow \\ \\ \text{ME} \rightarrow \\ \\ \text{ME} \rightarrow \\ \\ \text{SIM} \end{array}$	SIM → ME PROACTIVE COMMAND PENDING: SELECT ITEM 1.3.1 FETCH PROACTIVE COMMAND: SELECT ITEM 1.3.1 PROACTIVE COMMAND: SELECT ITEM 1.3.1 Present the items of " Call Forwarding Unconditional", "Call Forward On User Busy", "Call Forward On User Not Reachable", "Barring Of All Outgoing Calls", "Barring Of All Outgoing International Calls" and "CLI Presentation" under the header of " LargeMenu2 Select item "Barring Of All

PROACTIVE COMMAND: SELECT ITEM 1.3.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "LargeMenu2"

Item

Identifier of item: "FF"

Text string of item: "Call Forwarding Unconditional"

Item

Identifier of item: "FE"

Text string of item: "Call Forwarding On User Busy"

Item

Identifier of item: "FD"

Text string of item: "Call Forwarding On No Reply"

Item

Identifier of item: "FC"

Text string of item: "Call Forwarding On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "Barring Of All Outgoing International Calls"

Item

Identifier of item: "F9"

Text string of item: "CLI Presentation"

Coding:

BER-TLV: D0 FΒ 81 03 01 00 82 02 81 82 81 24 4C 4D 32 85 0A 61 72 65 65 6E 75 67 8F 1E FF 43 61 6C 6C 20 46 6F 72 77 6E 61 72 64 6E 67 20 63 69 55 6E 6F 74 6F 6C 1D FΕ 43 64 69 69 6E 61 8F 6C 6F 61 6C 20 46 72 77 61 72 64 69 6E 67 20 4F 6E 20 55 73 65 72 20 42 79 6C 20 46 75 73 8F 1C FD 43 6C 61 6F 72 77 61 72 64 69 6E 67 20 4F 6E 20 52 4E 6F 20 65 70 6C 79 8F 26 FC 20 43 61 6C 6C 46 6F 72 77 61 72 64 4F 20 73 69 6E 67 20 6E 55 65 72 20 4E 6F 74 20 52 65 61 63 68 61 62 6C 8F 65 1E FΒ 42 72 69 6E 20 61 72 67 6C 4F 66 20 41 6C 20 4F 75 74 67 6F 69 6E 67 20 43 61 6C 6C 73 8F 2C FΑ 42 69 4F 66 61 72 72 6E 67 20 20 41 6C 6C 20 4F 75 74 67 6F 69 6E 67 20 49 74 72 74 69 6F 6E 6E 65 6E 61 61 6C 20 43 61 6C 6C 73 8F 11 F9 43 4C 74 49 20 50 65 73 65 6E 74 61 69 72 6F 6E

TERMINAL RESPONSE: SELECT ITEM 1.3.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: FB

Coding:

BER-TLV: 01 00 03 24 00 82 02 82 81 83 01 81 90 01 FΒ

Expected Sequence 1.4 (SELECT ITEM, backward move by user, successful)

Step	Direction	MESSAGE / Action	Comments
20	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.4.1	
21	$ME \rightarrow SIM$	FETCH	
22	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.4.1	
23	ME o	Present the items of "One" and	
	USER	"Two" under the header of "Select	
		Item".	
24	$USER \to$	Indicate to go backwards in the	
	ME	proactive SIM application session.	
25	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Backward move in the proactive SIM
		ITEM 1.4.1	application session requested by user
26	$SIM \rightarrow ME$		
		PENDING: SELECT ITEM 1.4.2	
27	$ME \rightarrow SIM$	FETCH	
28	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.4.2	
29	····— /	Present the items of "One" and	
	USER	"Two" under the header of "Select	
		Item".	
30	$USER \to$	Indicate to end the proactive SIM	
	ME	application and return the ME to	
		normal operation.	
31	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Proactive SIM application terminated by the
		ITEM 1.4.2	user
32	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SELECT ITEM 1.4.1 and 1.4.2

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Select Item"

Item

Identifier of item: "11"
Text string of item: "One"

Item

Identifier of item: "12"
Text string of item: "Two"

Coding:

BER-TLV: D0 22 81 03 01 24 00 82 02 81 82 85 0B 6D 53 65 6C 65 63 74 20 49 74 65 8F 6F 8F 65 12 54 04 11 4F 6E 04 77

TERMINAL RESPONSE: SELECT ITEM 1.4.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: backward move in the proactive SIM session requested by the user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 11

TERMINAL RESPONSE: SELECT ITEM 1.4.2

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 10

Expected Sequence 1.5 (SELECT ITEM, "Y", successful)

Step	Direction	MESSAGE / Action	Comments
33	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.5.1	
34	$ME \rightarrow SIM$	FETCH	
35	$SIM \rightarrow ME$		
		SELECT ITEM 1.5.1	
36	ME o	Present the items of "Y" under the	
	USER	header of "The SIM shall supply a	
		set of items from which the user	
		may choose one. Each item	
		comprises a short identifier (used	
		to indicate the selection) and a text string. Optionally the SIM may	
		include an alpha identifier. The	
		alpha identifier i".	
37	USER →	Select item "Y"	
	ME		
38		TERMINAL RESPONSE: SELECT	Command performed successfully
	/	ITEM 1.5.1	
39	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SELECT ITEM 1.5.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "The SIM shall supply a set of items from which the user may choose one.

Each item comprises a short identifier (used to indicate the selection) and a text string. Optionally the SIM may include an alpha identifier. The alpha

identifier i"

Item

Identifier of item: "01"
Text string of item: "Y"

Coding:

BER-TLV: D0 FD ED 4D 6C 6C 6C 6F 6D 6F 6D 6D 6F 6F 6F 6E 2E 6D 6F 6D 6F 6E 6F 6E 6C 6F 6E 6E 2E 6E 4F 6C 6C 6F 6E 4D 6D 6E 6C 6E 6C 6E 2E 6C 6E 8F

TERMINAL RESPONSE: SELECT ITEM 1.5.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 00 90 01 01

Expected Sequence 1.6 (SELECT ITEM, Large menu, successful)

Step	Direction	MESSAGE / Action	Comments
40	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 1.6.1	
41	$ME \rightarrow SIM$	FETCH	
42	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 1.6.1	
43	ME o	Present the items of "1 Call	
	USER	Forward Unconditional", "2 Call	
		Forward On User Busy", "3 Call	
		Forward On No Reply", "4 Call	
		Forward On User Not Reachable",	
		"5 Barring Of All Outgoing Calls",	
		"6 Barring Of All Outgoing Int	
		Calls" and "7 CLI Presentation"	
		under the header of	
		"0LargeMenu".	
44	$USER \to$	Select item "5 Barring Of All	
	ME	Outgoing Calls".	
45	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 1.6.1	

PROACTIVE COMMAND: SELECT ITEM 1.6.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier: "0LargeMenu"

Item

Identifier of item: "FF"

Text string of item: "1 Call Forward Unconditional"

Item

Identifier of item: "FE"

Text string of item: "2 Call Forward On User Busy"

Item

Identifier of item: "FD"

Text string of item: "3 Call Forward On No Reply"

Item

Identifier of item: "FC"

Text string of item: "4 Call Forward On User Not Reachable"

Item

Identifier of item: "FB"

Text string of item: "5 Barring Of All Outgoing Calls"

Item

Identifier of item: "FA"

Text string of item: "6 Barring Of All Outgoing Int Calls"

Item

Identifier of item: "F9"

Text string of item: "7 CLI Presentation"

Coding:

BER-TLV: D0 81 F3 81 03 01 24 00 82 02 81 82 4C 4D 85 0A 30 61 65 65 6E 75 72 67 8F 1D FF 31 20 43 61 6C 6C 20 46 6F 72 6E 77 61 72 64 20 55 63 6F 6E 64 6E 6C 1C FΕ 20 69 74 6F 8F 32 69 61 6C 43 61 6C 20 46 6F 72 77 61 72 64 20 4F 6E 20 55 73 65 72 20 42 75 73 33 6C 79 8F 20 43 6C 20 46 1B FD 61 6F 72 77 61 72 64 20 4F 6E 20 4E 6F 6C 20 52 65 70 79 8F 25 FC 34 20 43 61 6C 6C 20 46 6F 72 77 61 72 64 20 4F 6E 20 55 73 65 72 20 4E 6F 74 20 52 65 61 63 68 61 62 6C 65 8F 20 FΒ 35 20 72 20 42 61 72 69 6E 67 4F 66 20 41 6C 6C 20 4F 75 74 67 6F 69 6E 67 20 43 6C 6C 73 8F 24 FΑ 36 61 20 42 6E 66 61 72 72 69 67 20 4F 20 41 6C 6C 20 4F 75 74 69 6E 20 67 6F 67 6C 49 6E 74 20 43 61 6C 73 8F 13 F9 37 20 43 4C 49 20 50 72 65 73 65 6E 74 74 69 6F 6E 61

TERMINAL RESPONSE: SELECT ITEM 1.5

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: FB

Coding:

01 BER-TLV: 81 03 24 00 82 02 82 81 83 01 00 01 FΒ 90

The following table details the test commands with relation to the tested features:

	Proactive SIM Command Facilities					
Proactive SIM Command SELECT ITEM Number	Alpha Identifier Length	Number of items	Maximum length of item			
1.1	14	4	6			
1.2	10	30	8			
1.3	10	7	43			
1.4	11	2	3			
1.5	236	1	1			
1.6	10	7	37			

27.22.4.9.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1.1, 1.2, 1.3, 1.4, 1.5 and 1.6 (SELECT ITEM, mandatory features).

27.22.4.9.2 SELECT ITEM (next action support)

27.22.4.9.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.2.2 Conformance Requirement

Same as 27.22.4.9.1.2

27.22.4.9.2.3 Test Purpose

To verify that the mobile supports next action indicator mode.

27.22.4.9.2.4 Method of Test

27.22.4.9.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.2.4.2 Procedure

Expected Sequence 2.1 (SELECT ITEM, next action indicator, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 2.1.1	
4	ME o	Display items of "Item 1", "Item 2"	
	USER	and "Item 3" under the header of	
		"Toolkit Select".	
		It presents also the following next	
		action indicators: Send SM, Set	
		Up Call, Provide Local Info.	
5	USER →	Navigate in the items, then select	
	ME	"Item 2". Check that next action	
		indicators appear.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 2.1.1	

PROACTIVE COMMAND: SELECT ITEM 2.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item:

Text string of item: "Item 1"

Item

Identifier of item: 2

Text string of item: "Item 2"

Item

Identifier of item:

Text string of item: "Item 3"

Items next action indicator

Items list "Send SM", "Set Up Call", "Provide Local Info."

Coding:

BER-TLV: D0 39 81 03 01 24 00 82 02 81 82 85 0E 54 6F 6F 6C 6B 69 74 20 53 65 6C 74 6D 65 63 74 8F 49 65 20 07 01 31 8F 49 74 6D 20 8F 03 07 02 65 32 07 49 74 65 6D 20 33 18 03 13 10 26

TERMINAL RESPONSE: SELECT ITEM 2.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 02

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 00 90 01 02

27.22.4.9.3 SELECT ITEM (default item support)

27.22.4.9.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.3.2 Conformance Requirement

Same as 27.22.4.9.1.2

27.22.4.9.3.3 Test Purpose

To verify that the mobile supports "default item" mode.

27.22.4.9.3.4 Method of Test

27.22.4.9.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.3.4.2 Procedure

Expected Sequence 3.1 (SELECT ITEM, default item, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 3.1.1	
4	ME o	Display items of "Item 1", "Item 2"	Check that "Item 2" is selected by default.
	USER	and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \to$	Navigate in the items, then select	
	ME	"Item 3".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	Command performed successfully
		ITEM 3.1.1	

PROACTIVE COMMAND: SELECT ITEM 3.1.1

Logically:

Command details

Command number:

SELECT ITEM Command type:

Command qualifier: "00"

Device identities

SIM Source device: Destination device: ME

"Toolkit Select" Alpha identifier:

Item

Identifier of item: 01 Text string of item: "Item 1"

Item

02 Identifier of item: "Item 2" Text string of item:

Identifier of item: 03 Text string of item: "Item 3"

Item identifier

Identifier of item chosen 02

Coding:

BER-TLV:	D0	37	-	03	_			82	-	81	-	
	0E	54	6F	6F	6C	6B	69	74	20	53	65	6C
	65	63	74	8F	07	01	49	74	65	6D	20	31
	8F	07	02	49	74	65	6D	20	32	8F	07	03
	49	74	65	6D	20	33	90	01	02			

TERMINAL RESPONSE: SELECT ITEM 3.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 03

Coding:

BER-TLV: 00 81 03 01 24 00 82 02 82 81 83 01 90 01 03

27.22.4.9.4 SELECT ITEM (help request support)

27.22.4.9.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.4.2 Conformance Requirement

Same as 27.22.4.9.1.2

27.22.4.9.4.3 Test Purpose

To verify that the mobile supports "help request" for the command Select Item.

27.22.4.9.4.4 Method of Test

27.22.4.9.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.4.4.2 Procedure

Expected Sequence 4.1 (SELECT ITEM, help request, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 4.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Help information available]
		SELECT ITEM 4.1.1	
4	ME o	Display items of "Item 1", "Item 2"	
	USER	and "Item 3" under the header of	
		"Toolkit Select".	
5	USER →	Navigate in the items until "Item	
	ME	1".	
6	$USER \to$	Select the Help Request on "Item	
	ME	1" Menu entry	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[Help information required by the user]
		ITEM 4.1.1	

PROACTIVE COMMAND: SELECT ITEM 4.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "80" help information available

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Coding:

BER-TLV: D0 81 03 24 82 02 85 34 01 80 81 82 6C 0E 54 6F 6F 6C 6B 69 74 20 53 65 8F 65 63 74 07 01 49 74 65 6D 20 31 8F 02 49 74 6D 20 32 8F 07 03 07 65 49 65 6D 20 74 33

TERMINAL RESPONSE: SELECT ITEM 4.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "80"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Help information required by the user

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 03 01 24 80 82 02 82 81 83 01 13 81 90 01 01

27.22.4.9.5 SELECT ITEM (icons support)

27.22.4.9.5.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.5.2 Conformance Requirement

Same as 27.22.4.9.1.2, and GSM 11.14 clause 12.31, and clause 12.32.

27.22.4.9.5.3 Test Purpose

To verify that the mobile displays icons with the command Select Item.

27.22.4.9.5.4 Method of Test

27.22.4.9.5.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.5.4.2 Procedure

Expected Sequence 5.1A (SELECT ITEM, BASIC ICON NOT SELF EXPLANATORY, successful)

	Step	Direction	MESSAGE / Action	Comments
Ī	1	$SIM \to ME$	PROACTIVE COMMAND	
			PENDING: SELECT ITEM 5.1.1	
	2	$ME \to SIM$	FETCH	
	3	$SIM \to ME$	PROACTIVE COMMAND:	
			SELECT ITEM 5.1.1	
	4	ME o	Display items of "Item 1", "Item 2"	Verify icons are displayed in the alpha
		USER	and "Item 3" under the header of	identifier and in the 3 items.
			"Toolkit Select".	
	5	$USER \to$	Navigate in the items, then select	
		ME	"Item 1".	
	6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
			ITEM 5.1.1 A	

PROACTIVE COMMAND: SELECT ITEM 5.1.1

Logically:

Command details

Command number:

Command type: SELECT ITEM

1

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Icon Identifier:

Icon qualifier: "01" (icon is not self-explanatory)

Icon Identifier: record 1 in $EF_{(IMG)}$

Item icon identifier list:

Icon qualifier: "01" (icon is not self-explanatory)

Icon Identifier: record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 3E 81 03 01 24 00 82 02 81 82 85 6F 6C 0E 54 6F 6C 6B 69 74 20 53 65 65 74 8F 74 6D 63 07 49 65 20 31 01 8F 07 02 49 74 65 6D 20 32 8F 07 03 9F 49 74 65 6D 20 33 9E 02 01 01 04 01 05 05 05

TERMINAL RESPONSE: SELECT ITEM 5.1.1A

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 03 01 24 00 82 02 82 83 01 00 81 81 90 01 01

Expected Sequence 5.1B (SELECT ITEM, BASIC ICON NOT SELF EXPLANATORY, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.1.1	
4	ME o	Display items of "Item 1", "Item 2"	no icon is displayed in the alpha identifier nor
	USER	and "Item 3" under the header of	in the 3 items.
		"Toolkit Select".	
5	$USER \to$	Navigate in the items, then select	
	ME	"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[Command performed successfully, but
		ITEM 5.1.1 B	requested icon could not be displayed]
1			

TERMINAL RESPONSE: SELECT ITEM 5.1.1B

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 04

90 01 01

Expected Sequence 5.2A (SELECT ITEM, BASIC ICON SELF EXPLANATORY, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.2.1	
4	ME o	Display items of "Item 1", "Item 2"	Verify icons are displayed without text as
	USER	and "Item 3" under the header of	alpha id and for the all 3 items.
		"Toolkit Select".	
5	$USER \to$	Navigate in the items, then select	
	ME	"Item 1".	
6	$ME \to SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 5.2.1 A	

PROACTIVE COMMAND: SELECT ITEM 5.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Icon Identifier:

Icon qualifier: "00" (icon is self-explanatory)

Icon Identifier: record 1 in $EF_{(IMG)}$

Item icon identifier list:

Icon qualifier: "00" (icon is self-explanatory)

Icon Identifier: record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$, record 5 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 3E 81 03 01 24 00 82 02 81 82 85 0E 54 6F 6F 6C 6B 69 74 20 53 65 6C 65 63 74 8F 07 01 49 74 65 6D 20 31 8F 02 49 74 8F 07 65 6D 20 32 07 03 49 74 65 6D 20 9E 02 00 01 9F 33 04 00 05 05 05

TERMINAL RESPONSE: SELECT ITEM 5.2.1A

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 03 01 24 00 82 02 82 81 83 01 00 81 90 01 01

Expected Sequence 5.2B (SELECT ITEM, BASIC ICON SELF EXPLANATORY, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 5.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 5.2.1	
4	ME o	Display items of "Item 1", "Item 2"	no icon is displayed with text as alpha id nor
	USER	and "Item 3" under the header of	for the all 3 items.
		"Toolkit Select".	
5	$USER \to$	Navigate in the items, then select	
	ME	"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully but
1		ITEM 5.2.1B	requested icon could not be displayed]

TERMINAL RESPONSE: SELECT ITEM 5.2.1B

Logically:

Command details

Command number:

Command type: SELECT ITEM

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be

displayed

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 81 03 01 24 00 82 02 82 81 83 01 04 90 01 01

27.22.4.9.6 SELECT ITEM (presentation style)

27.22.4.9.6.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.6.2 Conformance Requirement

Same as 27.22.4.9.1.2.

27.22.4.9.6.3 Test Purpose

To verify that the mobile supports the "presentation style" with the command Select Item.

27.22.4.9.6.4 Method of Test

27.22.4.9.6.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.6.4.2 Procedure

Expected Sequence 6.1 (SELECT ITEM, PRESENTATION AS A CHOICE OF NAVIGATION OPTIONS, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 6.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 6.1.1	
4	ME o	Display items of "Item 1", "Item 2"	Verify if presentation style appears.
	USER	and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \to$	Navigate in the items, then select	
	ME	"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 6.1.1	

PROACTIVE COMMAND: SELECT ITEM 6.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "03" (presentation as a choice of navigation options)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Item

Identifier of item: 03
Text string of item: "Item 3"

Coding:

BER-TLV: D0 34 81 03 01 24 03 82 02 81 82 85 6F 6C 0E 54 6F 6C 6B 69 74 20 53 65 8F 74 65 63 74 07 01 49 65 6D 20 31 8F 07 02 49 74 65 20 32 8F 07 03 49 74 65 6D 20 33

TERMINAL RESPONSE: SELECT ITEM 6.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "03" (presentation as a choice of navigation options)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 81 03 01 24 03 82 02 82 81 83 01 00

90 01 01

Expected Sequence 6.2 (SELECT ITEM, PRESENTATION AS A CHOICE OF DATA VALUES, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 6.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 6.2.1	
4	ME o	Display items of "Item 1", "Item 2"	Verify if presentation style appears
	USER	and "Item 3" under the header of	
		"Toolkit Select".	
5	$USER \to$	Navigate in the items, then select	
	ME	"Item 1".	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 6.2.1	

PROACTIVE COMMAND: SELECT ITEM 6.2.1

Logically:

Command details

1 Command number:

SELECT ITEM Command type:

Command qualifier: "01" (presentation as a choice of data values)

Device identities

SIM Source device: Destination device: ME

"Toolkit Select" Alpha identifier:

Item

Identifier of item: 01 Text string of item: "Item 1"

Item

02 Identifier of item: Text string of item: "Item 2"

Item

Identifier of item: 03

"Item 3" Text string of item:

Coding:

BER-TLV: D0 81 03 01 24 01 82 02 81 82 85 34 0E 54 6F 6F 6C 6B 69 74 20 53 65 6C 74 8F 74 65 63 07 01 49 65 6D 20 31 8F 74 32 03 07 02 49 65 6D 20 8F 07 49 74 65 6D 20 33

TERMINAL RESPONSE: SELECT ITEM 6.2.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "01"(presentation as a choice of data values)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 81 03 01 24 01 82 02 82 81 83 01 00

90 01 01

27.22.4.9.7 SELECT ITEM (soft keys support)

27.22.4.9.7.1 Definition and applicability

See Section 3.2.2.

27.22.4.9.7.2 Conformance Requirement

Same as 27.22.4.9.1.2.

27.22.4.9.7.3 Test Purpose

To verify that the mobile supports the "soft keys" with the command Select Item.

27.22.4.9.7.4 Method of Test

27.22.4.9.7.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.9.7.4.2 Procedure

Expected Sequence 7.1 (SELECT ITEM, SELECTING USING SOFT KEYS PREFERRED, successful, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SELECT ITEM 7.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		SELECT ITEM 7.1.1	
4	ME o	Display items of "Item 1", "Item 2"	
	USER	under the header of "Toolkit	
		Select".	
5	$USER \to$	Navigate in the items, then select	Verify that we can choose an item through
	ME	"Item 1".	soft keys
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: SELECT	[command performed successfully]
		ITEM 7.1.1	

PROACTIVE COMMAND: SELECT ITEM 7.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "04" (selection using soft keys preferred)

Device identities

Source device: SIM
Destination device: ME

Alpha identifier: "Toolkit Select"

Item

Identifier of item: 01
Text string of item: "Item 1"

Item

Identifier of item: 02
Text string of item: "Item 2"

Coding:

BER-TLV: D0 2B 81 03 01 24 04 82 02 81 82 85 6F 74 20 6C 0E 54 6F 6C 6B 69 53 65 8F 65 63 74 07 01 49 74 65 6D 20 31 8F 02 49 74 6D 20 32 07 65

TERMINAL RESPONSE: SELECT ITEM 7.1.1

Logically:

Command details

Command number: 1

Command type: SELECT ITEM

Command qualifier: "04" (selection using soft keys preferred)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Item identifier

Identifier of item chosen: 01

Coding:

BER-TLV: 81 03 01 24 04 82 02 82 81 83 01 00 90 01 01

27.22.4.10 SEND SHORT MESSAGE

27.22.4.10.1 SEND SHORT MESSAGE (normal)

27.22.4.10.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.10.1.2 Conformance requirement

The ME shall support the Proactive SIM: SEND SHORT MESSAGE facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.10 (Send Short Message), clause 6.6.9 (Send Short Message), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpha Identifier), clause 12.1 (Address), clause 12.13 (SMS-TPDU), clause 12.31 (Icon Identifier), clause 5.2 (Terminal Profile)27.22.4.10.1.3 Test Purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.1.4 Method of test

27.22.4.10.1.4.1 Initial Conditions

The ME is connected to the system Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.10.1.4.2 Procedure

Expected Sequence 1.1(SEND SHORT MESSAGE, packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 1.1.1	
4	ME o	Display "Send SM"	[Alpha Identifier]
	USER		
5	$ME \to SS$	Send SMS-PP "Test Message"	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.1.1	

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.1.1

Logically:

Command details
Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

BER-TLV: D0 37 81 03 01 13 00 82 02 81 83 85 65 6E 64 20 4D 86 09 91 07 53 53 11 22 33 44 55 66 77 F8 8B 18 01 00 09 91 10 32 54 76 F8 40 F4 0C 54 65 73 74 20 4D 65 73 73 67 65 61

SMS-PP (SEND SHORT MESSAGE) Message 1.1

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 12

TP-UD "Test Message"

F4 0C Coding: 01 00 09 91 10 32 54 76 F8 40 54 65 73 74 20 4D 65 73 73 61 67 65

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.1.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 1.2 (SEND SHORT MESSAGE, packing required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[packing required, 8-bit data]
		SHORT MESSAGE 1.2.1	
4	ME o	Display "Send SM"	[Alpha Identifier]
	USER		
5	$ME \to SS$	Send SMS-PP "Send SM"	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.2.1	-

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.2.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 7

TP-UD "Send SM"

Coding:

BER-TLV: D0 32 81 03 01 13 01 82 02 81 83 85 07 53 65 6E 64 20 53 4D 86 09 91 11 44 22 33 55 66 77 F8 8B 13 01 00 09 91 10 32 54 76 F8 40 F4 07 53 65 6E 64 20 53 4D

SMS-PP (SEND SHORT MESSAGE) Message 1.2

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-Reply-Path is not set in this SMS-SUBMIT

TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 7

TP-UD "Send SM"

Coding: 01 00 09 91 10 32 54 76 F8 40 F4 07

D3 B2 9B 0C 9A 36 01

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.2.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 01 82 02 82 81 83 01 00

Expected Sequence 1.3 (SEND SHORT MESSAGE, packing not required, SMS default alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.3.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[packing not required, SMS default alphabet]
		SHORT MESSAGE 1.3.1	
4	ME o	Display "Short Message"	[Alpha Identifier]
	USER		
5	$ME \to SS$	Send SMS-PP "Short Message"	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.3.1	. ,,

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.3.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Short Message"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV: D0 3D 81 03 01 13 00 82 02 81 83 85 0D 68 6F 72 74 20 4D 65 73 73 61 53 86 09 33 44 55 67 65 91 11 22 66 77 F8 8B 18 01 00 09 91 10 32 54 76 F8 40 0D F4 5B 35 CB F3 79 F0 53 4F 07 F8 5C 06

SMS-PP (SEND SHORT MESSAGE) Message 1.3

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 13

TP-UD "Short Message"

Coding: 01 09 76 F8 40 F0 0D 00 91 10 32 54 53 F4 5B 4E 07 35 CB F3 79 F8 5C 06

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.3.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 1.4 (SEND SHORT MESSAGE, packing required, SMS default alphabet, message of 160 bytes, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.4. 1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$		[packing required, SMS default alphabet]
		SHORT MESSAGE 1.4.1	
4	ME o	Display "The address data object	[Alpha Identifier]
	USER	holds the	
		RP_Destination_Address "	
5	$ME \rightarrow SS$	Send SMS-PP "Two types are	[message of 160 bytes]
		defined: - A short message to be	
		sent to the network in an SMS-	
		SUBMIT message, or an SMS-	
		COMMAND message, where the	
		user data can be passed transp"	
6	$SS \rightarrow ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.4.1	

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.4.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE

Command qualifier: packing required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "The address data object holds the RP_Destination_Address"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user

data can be passed transp"

Coding:

BER-TLV: D0 81 FD 81 03 01 13 00 82 02 81 83 85 38 54 68 65 20 64 72 65 73

73	20	64	61	74	61	20	6F	62	6A	65	63
74	20	68	6F	6C	64	73	20	74	68	65	20
52	50	11	44	65	73	74	69	6E	61	74	69
6F	6E	11	41	64	64	72	65	73	73	86	09
91	11	22	33	44	55	66	77	F8	8B	81	AC
01	00	09	91	10	32	54	76	F8	40	F4	A0
54	77	6F	20	74	79	70	65	73	20	61	72
65	20	64	65	66	69	6E	65	64	3A	20	2D
20	41	20	73	68	6F	72	74	20	6D	65	73
73	61	67	65	20	74	6F	20	62	65	20	73
65	6E	74	20	74	6F	20	74	68	65	20	6E
65	74	77	6F	72	6B	20	69	6E	20	61	6E
20	53	4D	53	2D	53	55	42	4D	49	54	20
6D	65	73	73	61	67	65	2C	20	6F	72	20
61	6E	20	53	4D	53	2D	43	4F	4D	4D	41
4E	44	20	6D	65	73	73	61	67	65	2C	20
77	68	65	72	65	20	74	68	65	20	75	73
65	72	20	64	61	74	61	20	63	61	6E	20
62	65	20	70	61	73	73	65	64	20	74	72
61	6E	73	70								

SMS-PP (SEND SHORT MESSAGE) Message 1.4

•		11	
	ogic	ดไป	17
ட	Ogic	an	у.

SMS TPDU TP-MTI **SMS-SUBMIT** TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM TP-VPF TP-VP field not present TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message TP-SRR A status report is not requested TP-MR "00" TP-DA TON International number NPI "ISDN / telephone numbering plan" Address value "012345678" TP-PID Short message type 0 TP-DCS SMS default alphabet Message coding Message class class 0 160 TP-UDL TP-UD

"Two types are defined: - A short message to be sent to the network in an SMS-SUBMIT message, or an SMS-COMMAND message, where the user

data can be passed transp"

Coding:

BER-TLV: 98 01 00 09 91 10 76 F8 40 F0 32 54 A0 D4 FΒ 1B 44 CF C3 CB 73 50 58 5E CB В4 BB 4C Α0 20 06 91 E6 D6 81 5A 68 8E 7E CB E9 A0 76 79 3E 0F 9F CB 7F 20 FΑ 1B 24 2E 83 E6 65 37 1D 44 83 32 C8 DF F2 35 28 E8 E8 5D A6 DF ED DD A0 73 9A CD 06 85 69 DA 56 85 24 15 D4 2E CF E7 E1 73 99 05 7A CB 41 37 DA 9C 66 E8 61 68 B6 86 CF 33 DA E5 F9 40 24 82 3C 7C 2E **B**3 77 74 59 5E 06 D1 D1 65 50 7D 5E 96 83 C8 1E 7A 18 34 0E BB 41 E2 32 80 9E 61 CF СВ 64 10 5D 1E 76 CF E1

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.4.1

Logically: Command details

Command number: 1

SEND SHORT MESSAGE Command type: Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 00 81 03 01 13 82 02 82 81 83 01 00

Expected Sequence 1.5 (SEND SHORT MESSAGE, packing not required, SMS default alphabet, message of 160 bytes, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[packing not required, SMS default alphabet]
		SHORT MESSAGE 1.5.1	
4	ME o	Display "The address data object	[Alpha Identifier]
	USER	holds the	
		RP_Destination_Address "	
5	$ME \rightarrow SS$	Send SMS-PP "Two types are	[message of 160 bytes]
		defined: - A short message to be	
		sent to the network in an SMS-	
		SUBMIT message, or an SMS-	
		COMMAND message, where the	
		user data can be passed transp"	
6	$SS \rightarrow ME$		
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.5.1	

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE
Command qualifier: packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "The address data object holds the RP Destination Address"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RDInstruct the SC to accept an SMS-SUBMIT for a SM TP-VPF TP-VP field not present TP-RP TP-Reply-Path is not set in this SMS-SUBMIT

TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0
TP-UDL 160

TP-UD

"Two types are defined: - A short message to be sent to the network in an SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can be passed transp"

Coding:

BER-TLV:	D0 85 73 74 52 6F 91 01 D4 91 8E FA	81 38 20 20 50 6E 11 00 FB CB 7E 1B	E9 54 64 68 20 20 22 09 1B E6 CB 24	81 68 61 6F 44 41 33 91 44 B4 E9 2E	03 65 74 6C 65 64 44 10 CF BB A0 83	01 20 61 64 73 64 55 32 C3 4C 76 E6	13 61 20 73 74 72 66 54 CB D6 79 65	00 64 6F 20 69 65 77 76 73 81 3E 37	82 64 62 74 6E 73 F8 F8 50 5A 0F 1D	02 72 6A 68 61 73 8B 40 58 A0 9F 44	81 65 65 65 74 86 81 F0 5E 20 CB 7F	83 73 63 20 69 09 98 A0 06 68 20 83
	-											
	_								_			
	D4	FB	1B	44	CF	C3	СВ	73	50	58	5E	06
	91	CB	E6	B4	BB	4C	D6	81	5A	A0	20	68
	8E	7E	CB	E9	A0	76	79	3E	0F	9F	CB	20
	FA	1B	24	2E	83	E6	65	37	1D	44	7F	83
	E8	E8	32	C8	5D	A6	DF	DF	F2	35	28	ED
	06	85	DD	A0	69	73	DA	9A	56	85	CD	24
	15	D4	2E	CF	E7	E1	73	99	05	7A	CB	41
	61	37	68	DA	9C	B6	86	CF	66	33	E8	24
	82	DA	E5	F9	3C	7C	2E	B3	40	77	74	59
	5E	06	D1	D1	65	50	7D	5E	96	83	C8	61
	7A	18	34	0E	BB	41	E2	32	80	1E	9E	CF
	CB	64	10	5D	1E	76	CF	E1				

SMS-PP (SEND SHORT MESSAGE) Message 1.5

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RDInstruct the SC to accept an SMS-SUBMIT for a SM
TP-VPF
TP-VP field not present
TP-RPTP-Reply-Path is not set in this SMS-SUBMIT

TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

Message class 0 TP-UDL 160

TP-UD "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user

data can be passed transp"

Coding:	01	00	09	91	10	32	54	76	F8	40	F0	A0
	D4	FB	1B	44	CF	C3	CB	73	50	58	5E	06
	91	CB	E6	B4	BB	4C	D6	81	5A	A0	20	68
	8E	7E	CB	E9	A0	76	79	3E	0F	9F	CB	20
	FA	1B	24	2E	83	E6	65	37	1D	44	7F	83
	E8	E8	32	C8	5D	A6	DF	DF	F2	35	28	ED
	06	85	DD	A0	69	73	DA	9A	56	85	CD	24
	15	D4	2E	CF	E7	E1	73	99	05	7A	CB	41
	61	37	68	DA	9C	B6	86	CF	66	33	E8	24
	82	DA	E5	F9	3C	7C	2E	B3	40	77	74	59
	5E	06	D1	D1	65	50	7D	5E	96	83	C8	61
	7A	18	34	0E	BB	41	E2	32	80	1E	9E	CF
	CB	64	10	5D	1E	76	CF	E1				

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.5.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 1.6 (SEND SHORT MESSAGE, alpha identifier 160 bytes long, SMS default alphabet, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[packing not required, SMS default alphabet]
		SHORT MESSAGE 1.6.1	
4	ME o	Display "Two types are defined: -	[Alpha Identifier of 160 bytes]
	USER	A short message to be sent to the	
		network in an SMS-SUBMIT	
		message, or an SMS-COMMAND	
		message, where the user data can	
		be passed transparently; - A short	
		message to be sent to the network	
		in an SMS-SUBMIT "	
5		Send SMS-PP " "	[space]
6		SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.6.1	

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.6.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Two types are defined: - A short message to be sent to the network in an

SMS-SUBMIT message, or an SMS-COMMAND message, where the user data can be passed transparently; - A short message to be sent to the

network in an SMS-SUBMIT "

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "01"

TP-PID Short message type 0

TP-DCS

Message coding SMS default alphabet

 $\begin{array}{ccc} \text{Message class} & \text{class 0} \\ \text{TP-UDL} & 1 \\ \text{TP-UD} & " \, " \end{array}$

Coding:

FD BER-TLV: D0 81 81 03 01 00 82 02 81 83 13 85 81 E6 54 77 6F 20 74 79 70 65 73 20 65 20 64 69 6E

ЗА	20	2D	20	41	20	73	68	6F	72	74	20
6D	65	73	73	61	67	65	20	74	6F	20	62
65	20	73	65	6E	74	20	74	6F	20	74	68
65	20	6E	65	74	77	6F	72	6B	20	69	6E
20	61	6E	20	53	4D	53	2D	53	55	42	4D
49	54	20	6D	65	73	73	61	67	65	2C	20
6F	72	20	61	6E	20	53	4D	53	2D	43	4F
4D	4D	41	4E	44	20	6D	65	73	73	61	67
65	2C	20	77	68	65	72	65	20	74	68	65
20	75	73	65	72	20	64	61	74	61	20	63
61	6E	20	62	65	20	70	61	73	73	65	64
20	74	72	61	6E	73	70	61	72	65	6E	74
6C	79	3B	20	2D	20	41	20	73	68	6F	72
74	20	6D	65	73	73	61	67	65	20	74	6F
20	62	65	20	73	65	6E	74	20	74	6F	20
74	68	65	20	6E	65	74	77	6F	72	6B	20
69	6E	20	61	6E	20	53	4D	53	2D	53	55
42	4D	49	54	20	8B	09	01	00	09	91	10
40	F0	01	20								

SMS-PP (SEND SHORT MESSAGE) Message 1.6

Logically:

SMS TPDU TP-MTI **SMS-SUBMIT** Instruct the SC to accept an SMS-SUBMIT for a SM TP-RD TP-VPF TP-VP field not present TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message A status report is not requested TP-SRR "00" TP-MR TP-DA TON International number NPI "ISDN / telephone numbering plan" Address value "01" TP-PID Short message type 0 TP-DCS Message coding SMS default alphabet Message class class 0 TP-UDL 1 TP-UD Coding: 01 00 09 91 10 40 F0 01 20

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE
Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 1.7(SEND SHORT MESSAGE, alpha identifier length '00', packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 1.7.1	
4	ME	No information to user	[Alpha identifier length '00']
5	$ME \to SS$	Send SMS-PP "Test Message"	-
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 1.7.1	-

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.7.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network

Alpha identifier:

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Coding:

BER-TLV: D0 37 81 03 01 13 00 82 02 81 83 85 00 09 91 22 33 44 55 66 F8 86 11 77 8B 18 01 00 09 91 10 32 54 76 F8 40 F4 0C 54 65 73 74 20 4D 65 73 73 61 67 65

SMS-PP (SEND SHORT MESSAGE) Message 1.7

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-Reply-Path is not set in this SMS-SUBMIT
TP-UDHI
The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00'

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data Message class class 0 TP-UDL 12

TP-UD "Test Message"

91 10 F8 40 F4 0C Coding: 01 00 09 32 54 76 74 4D 65 73 73 61 67 65 54 65 73 20

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.7.1

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 1.8 (SEND SHORT MESSAGE, packing not required, 8-bit data, no alpha identifier, successful)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: SEND SHORT MESSAGE 1.8.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	SIM → ME	PROACTIVE COMMAND : SEND SHORT MESSAGE 1.8.1	[packing not required, 8-bit data]
4	$\begin{array}{c} \text{ME} \rightarrow \\ \text{USER} \end{array}$	May give information to user concerning what is happening	[No Alpha Identifier]
5	$ME \rightarrow SS$	Send SMS-PP "Test Message"	
6	$SS \rightarrow ME$	SMS RP-ACK	
7	ME → SIM	TERMINAL RESPONSE : SEND SHORT MESSAGE 1.8.1	[Command performed successfully]

PROACTIVE COMMAND: SEND SHORT MESSAGE 1.8.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: SIM

Destination device: Network

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT

TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data

Message class 0

TP-UDL 12

TP-UD "Test Message"

Coding:

01 BER-TLV: D0 2E 81 03 13 00 82 02 81 83 86 09 91 11 22 33 44 55 77 F8 8B 18 66 01 00 09 91 10 32 54 76 F8 40 F4 0C74 54 65 73 20 4D 65 73 73 61 67 65

SMS-PP (SEND SHORT MESSAGE) Message 1.8

Logically:

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT

TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data

Message class 0

TP-UDL 12

TP-UD "Test Message"

Coding: 91 76 F8 F4 0C01 00 09 10 32 54 40 54 65 73 74 20 4D 65 73 73 61 67 65

TERMINAL RESPONSE: SEND SHORT MESSAGE 1.8.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE

Command qualifier: packing not required

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

27.22.4.10.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 to 8.

27.22.4.10.2 SEND SHORT MESSAGE (UCS2 support)

27.22.4.10.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.10.2.2 Conformance requirement

The ME shall support the Proactive SIM: SEND SHORT MESSAGE facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.10 (Send Short Message), clause 6.6.9 (Send Short Message), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpha Identifier), clause 12.1 (Address), clause 12.13 (SMS-TPDU), clause 12.31 (Icon Identifier), clause 5.2 (Terminal Profile)

Additionally, the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.10.2.3 Test Purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.2.4 Method of test

27.22.4.10.2.4.1 Initial Conditions

The ME is connected to the system Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.10.2.4.2 Procedure

Expected Sequence 2.1 (SEND SHORT MESSAGE, packing not required, UCS2 (16-bit data))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[packing not required, 16-bit data]
		SHORT MESSAGE 2.1.1	
4	ME o	Display "Send SM"	[Alpha Identifier]
	USER		
5	$ME \to SS$	Send SMS-PP "ЗДРАВСТВУЙТЕ"	["Hello" in russian]
6	OO /	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 2.1.1	

PROACTIVE COMMAND: SEND SHORT MESSAGE: 2.1.1

Logically:

Command details

Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RDInstruct the SC to accept an SMS-SUBMIT for a SM TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 16-bit data Message class class 0 TP-UDL 24

TP-UD ЗДРАВСТВУЙТЕ "

Coding:

BER-TLV: D0 4D 03 01 02 81 13 00 82 81 83 85 07 53 65 6E 64 20 53 4D 86 09 91 11 22 33 44 55 66 77 F8 8B 18 01 00 09 91 32 54 10 76 F8 40 80 18 04 17 04 14 04 20 04 10 04 04 21 04 22 04 12 04 19 15

SMS-PP (SEND SHORT MESSAGE) Message 2.1

Logically:

SMS TPDU

TP-MTI **SMS-SUBMIT**

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

A status report is not requested TP-SRR

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

"012345678" Address value

TP-PID Short message type 0

TP-DCS

Message coding UCS2 (16-bit data)

Message class class 0 TP-UDL

TP-UD " ЗДРАВСТВУЙТЕ

01 00 09 91 10 76 F8 40 08 18 Coding: 32 54 04 17 04 14 04 20 04 10 04 12 04 21

04 22 04 22 04 12 04 23 04 19 04 15

TERMINAL RESPONSE: SEND SHORT MESSAGE 2.2.1

Logically:

Command details

Command number: 1

SEND SHORT MESSAGE Command type: Command qualifier: packing not required

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 00 82 02 82 81 83 01 00 13

27.22.4.10.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1.

27.22.4.10.3 SEND SHORT MESSAGE (icon support)

27.22.4.10.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.10.3.2 Conformance requirement

27.22.4.10.3.3 Test Purpose

To verify that the ME correctly formats and sends a short message to the network (System Simulator) as indicated in the SEND SHORT MESSAGE proactive SIM command, and returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the Short Message.

27.22.4.10.3.4 Method of test

27.22.4.10.3.4.1 Initial Conditions

See Annex C

27.22.4.10.3.4.2 Procedure

Expected Sequence 3.1A (SEND SHORT MESSAGE, basic icon self-explanatory, packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 3.1.1	
4	ME o	Displays the icon and not the	[basic icon self-explanatory]
	USER	alpha identifier	
5	$ME \rightarrow SS$	Send SMS-PP "Test Message"	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 3.1.1A	

PROACTIVE COMMAND: SEND SHORT MESSAGE 3.1.1

Logically:

Command details
Command number: 1

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "NO ICON"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8bit-data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Icon Identifier

Icon Qualifier self-explanatory

Icon Identifier 1 (number of record in EF IMG)

Coding:

BER-TLV: D0 3B 81 03 01 13 00 02 81 83 85 82 20 49 07 4E 4F 43 4F 4E 86 09 91 11 22 44 55 66 F8 8B 01 00 09 33 77 18 91 10 32 54 76 F4 40 F4 0C 54 65 73 74 20 4D 65 73 73 61 67 65 9F 02 00 01

SMS-PP (SEND SHORT MESSAGE) Message 3.1

Logically:

SMS TPDU
TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

91 76 F4 0C Coding: 01 00 09 10 32 F8 40 54 65 73 74 4D 65 73 73 61 67 65 20

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.1.1A

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE
Command qualifier: packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 3.1B (SEND SHORT MESSAGE, basic icon self-explanatory, packing not required, 8-bit data, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[packing not required, 8-bit data, basic icon
		SHORT MESSAGE 3.1.1	self-explanatory]]
4	ME o	Displays the alpha identifier	
	USER	without the icon	
5	$ME \rightarrow SS$	Send SMS-PP "Test Message"	
6	$SS \rightarrow ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully, but
		SHORT MESSAGE 3.1.1B	requested icon could not be displayed]

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.1.1B

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 04

Expected Sequence 3.2A (SEND SHORT MESSAGE, basic icon non-self-explanatory, packing not required, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[packing not required, 8-bit data]
		SHORT MESSAGE 3.2.1	
4	ME o	display the icon and "Send SM"	[basic icon non-self-explanatory]
	USER		
5	$ME \to SS$	Send SMS-PP "Test Message"	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SHORT MESSAGE 3.2.1A	

PROACTIVE COMMAND: SEND SHORT MESSAGE 3.2.1

Logically:

Command details
Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: SIM
Destination device: Network
Alpha Identifier "Send SM"

Address

TON: International number

NPI: "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8bit-data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

Icon Identifier

Icon Qualifier non-self-explanatory

Icon Identifier 1 (number of record in EF IMG)

Coding:

BER-TLV: D0 3B 81 03 01 13 00 02 81 83 85 82 6E 07 53 65 64 20 53 4D 86 09 91 11 22 44 66 8B 01 00 09 33 55 77 F8 18 91 10 32 54 76 F8 40 F4 0C 54 65 73 74 20 4D 65 73 73 61 67 65 1E 02 01 01

SMS-PP (SEND SHORT MESSAGE) Message 3.2

Logically:

SMS TPDU
TP-MTI SMS-SUBMIT

TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM

TP-VPF TP-VP field not present

TP-RP TP-Reply-Path is not set in this SMS-SUBMIT TP-UDHI The TP-UD field contains only the short message

TP-SRR A status report is not requested

TP-MR "00"

TP-DA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "012345678"

TP-PID Short message type 0

TP-DCS

Message coding 8-bit data
Message class class 0
TP-UDL 12

TP-UD "Test Message"

F4 0C Coding: 01 00 09 91 10 32 76 F8 40 73 4D 73 73 61 67 65 54 65 74 20 65

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.2.1A

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 00

Expected Sequence 3.2B (SEND SHORT MESSAGE, basic icon non-self-explanatory, packing not required, 8-bit data, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SHORT	
		MESSAGE 3.2.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[packing not required, 8-bit data, basic icon
		SHORT MESSAGE 3.2.1	non-self-explanatory]
4	ME o	display "Send SM" without the icon	
	USER		
5	$ME \to SS$	Send SMS-PP "Test Message"	
6	$SS \to ME$	SMS RP-ACK	
7	$ME \to SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully, but
		SHORT MESSAGE 3.2.1B	requested icon could not be displayed]

TERMINAL RESPONSE: SEND SHORT MESSAGE 3.2.1B

Logically:

Command details

Command number:

Command type: SEND SHORT MESSAGE packing not required

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be displayed;

Coding:

BER-TLV: 81 03 01 13 00 82 02 82 81 83 01 04

27.22.4.10.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.11 SEND SS

Continuous length error in T.R. Result field.

27.22.4.11.1 SEND SS (normal)

27.22.4.11.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.11.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send SS facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.11 (Send SS), 6.6.10 (Send SS), clause 12.12.1 (Additional information for Send SS), clause 5.2 (Terminal Profile), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpa identifier), clause 12.14 (SS String), clause 12.31 (Icon identifier), clause 6.5.4 (Icon identifiers).

27.22.4.11.1.3 Test Purpose

To verify that the ME correctly translates and sends the supplementary service request indicated in the SEND SS proactive SIM command to the system Simulator.

To verify that the ME returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the SS and any contents of the SS result as additional data.

27.22.4.11.1.4 Method of test

27.22.4.11.1.4.1 Initial Conditions

The ME is connected to the System Simulator and the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator

27.22.4.11.1.4.2 Procedure

Expected Sequence 1.1 (SEND SS, call forward unconditional, all bearers, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		SS 1.1.1	
4	ME o	Display "Call Forward"	
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.1.1	

PROACTIVE COMMAND: SEND SS 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Call Forward"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*+01234567890123456789#"

Coding:

82 81 03 BER-TLV: D0 01 00 02 83 85 27 11 81 0C 43 61 6C 6C 20 46 6F 72 61 72 77 64 89 0E 91 AA12 0A 21 43 65 87 09 21 43 65 87 B9

REGISTER 1.1

Logically (only SS argument):

REGISTER SS ARGUMENT

SS-Code:

- Call Forwarding Unconditional

TeleserviceCode

- All Tele Services

Forwarded To Number

- nature of address ind. : international

- numbering plan ind. : ISDN/Telephony (E.164)

- TBCD String: 01234567890123456789

Coding:

BER-TLV 0B 10 30 13 04 01 21 83 01 00 84 91 32 54 76 98 10 32 54 76 98

RELEASE COMPLETE (SS RETURN RESULT) 1.1

Logically (only from operation code):

REGISTER SS RETURN RESULT

Forwarding Info

SS-Code

- Call Forwarding Unconditional

Forward Feature List

ForwardingFeature

TeleserviceCode

- All Tele Services

SS-Status

- state ind. : operative

- provision ind. : provisioned

- registration ind. : registered

- activation ind. : active

Forwarded To Number

- nature of address ind. : international

- numbering plan ind. : ISDN/Telephony (E.164)

- TBCD String: 01234567890123456789

Coding:

BER-TLV	0A	Α0	1A	04	01	21	30	15	30	13	83	01
	00	84	01	07	84	0B	91	10	32	54	76	98
	10	32	54	76	98							

TERMINAL RESPONSE: SEND SS 1.1.1

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	1E
	00	0A	A0	1A	04	01	21	30	15	30	13
	83	01	00	84	01	07	85	0B	91	10	32
	54	76	98	10	32	54	76	98			

Expected Sequence 1.2 (SEND SS, call forward unconditional, all bearers, Return Error)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		SS 1.1.1	
4	ME o	Display "Call Forward"	
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Return Error]
		RETURN ERROR) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.2.1	

RELEASE COMPLETE (SS RETURN ERROR) 1.1

Logically (only from error code):

Error Code: Facility not supported

Coding:

BER-TLV 02 11 15

TERMINAL RESPONSE: SEND SS 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: SS Return Error Additional information: Error Code

Coding:

BER-TLV: 81 03 01 11 00 82 02 82 81 03 02

34 15

Expected Sequence 1.3 (SEND SS, call forward unconditional, all bearers, Reject)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		SS 1.1.1	
4	ME o	Display "Call Forward"	
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Reject]
		REJECT) 1.1.	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.3.1	

RELEASE COMPLETE (SS REJECT) 1.1

Logically (only from problem code):

Problem Code:

- General problem
- Unrecognized component

Coding:

BER-TLV

80 01 00

TERMINAL RESPONSE: SEND SS 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: SS Return Error

Additional information: No specific cause can be given

Coding:

BER-TLV: 81 03 01 11 00 82 02 82 81 03 02

34 00

Expected Sequence 1.4 (SEND SS, call forward unconditional, all bearers, successful, SS request size limit)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		SS 1.4.1	
4	ME o	Display "Call Forward"	
	USER		
5	$ME \to SS$	REGISTER 1.2	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.2	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.4.1	

PROACTIVE COMMAND: SEND SS 1.4.1

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Call Forward"

SS String

TON: International

NPI: "ISDN / telephone numbering plan"

SS string: "**21*+01234567890123456789012345678901234567*11#"

Coding:

BER-TLV: D0 0C 6C 6C 6F 1A AA0A Α7 FΒ

REGISTER 1.2

Logically (only SS argument):

REGISTER SS ARGUMENT

RegisterSSArg

SS-Code

- Call Forwarding Unconditional

TeleserviceCode

- Telephony

ForwardedToNumber

- nature of address ind. : international

- numbering plan ind. : ISDN/Telephony (E.164)

- TBCD String: 0123456789012345678901234567

Coding:

BER-TLV 1C

RELEASE COMPLETE (SS RETURN RESULT) 1.2

Logically (only from operation code):

REGISTER SS RETURN RESULT

Forwarding Info

SS-Code

- Call Forwarding Unconditional

ForwardFeatureList

ForwardingFeature

TeleserviceCode

- Telephony

SS-Status

- state ind. : operative

- provision ind. : provisioned

- registration ind. : registered

- activation ind. : active

Forwarded To Number

- nature of address ind. : international

- numbering plan ind. : ISDN/Telephony (E.164)

- TBCD String: 0123456789012345678901234567

Coding:

BER-TLV	0A	Α0	23	04	01	21	30	1E	30	1C	83	01
	11	84	01	07	84	14	91	10	32	54	76	98
	10	32	54	76	98	10	32	54	76	98	10	32
	51	76										

TERMINAL RESPONSE: SEND SS 1.4.1

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	27
	00	0A	A0	23	04	01	21	30	1E	30	1C
	83	01	11	84	01	07	84	14	91	10	32
	54	76	98	10	32	54	76	98	10	32	54
	76	98	10	32	5/1	76					

Expected Sequence 1.5 (SEND SS, interrogate CLIR status, successful, alpha identifier limits)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		SS 1.5.1	
4	ME o	Display "Even if the Fixed Dialling	
	USER	Number service is enabled, the	
		supplementary service control	
		string included in the SEND SS	
		proactive command shall not be	
		checked against those of the FDN	
		list. Upon receiving this command,	
_		the ME shall deci"	
5		REGISTER 1.3	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.3	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.5.1	

PROACTIVE COMMAND: SEND SS 1.5.1

Logically:

Command details

Command number:

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Even if the Fixed Dialling Number service is enabled, the supplementary

service control string included in the SEND SS proactive command shall not be checked against those of the FDN list. Upon receiving this command,

the ME shall deci"

SS String

TON: Undefined NPI: Undefined SS string: "*#31#"

Coding:

BER-TLV: D0 FD EΒ 6E

6E 6C 6C 4E 6D 6E 2C 6C 6C 6D 6E 6C 6F 6E 6F 6E 6C 6E 6E 4E 6F 6F 6D 6D 6E 6C 6C 6E 6F 6B 6E 6F 6F 4E 6C 2E 6F 6E 6E 6F 6D 6D 2C 4D 6E 6C 6C

REGISTER 1.3

Logically (only SS argument):

INTERROGATE SS ARGUMENT

FF

BA

FΒ

SS-Code

- Calling Line Id Restriction

Coding:

BER-TLV 30 03 04 01 12

RELEASE COMPLETE (SS RETURN RESULT) 1.3

Logically (only from operation code):

INTERROGATE SS RESULT

CliRestrictionInfo

SS-Status

- state ind. : operative

provision ind. : provisionedregistration ind. : registeredactivation ind. : not active

CliRestrictionOption

- Temporary Def Allowed

Coding:

BER-TLV 0E A4 06 04 01 06 0A 01 02

TERMINAL RESPONSE: SEND SS 1.5.1

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Additional information

Operation Code: SS Code

Parameters: SS Return Result

Coding:

BER-TLV: 01 81 03 01 11 00 82 02 82 81 03 04 00 0E A4 06 01 06 0A01 02

Expected Sequence 1.6 (SEND SS, call forward unconditional, all bearers, successful, null data alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 1.6.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		SS 1.6.1	
4	ME	Should not give any information to	
		the user on the fact that the ME is	
		sending an SS request	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \to SIM$	TERMINAL RESPONSE : SEND	
		SS 1.1.1	

PROACTIVE COMMAND: SEND SS 1.6.1

Logically:

Command details

Command number:

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: null data object

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*+01234567890123456789#"

Coding:

BER-TLV: D0 1B 81 03 11 02 81 83 85 01 00 82 00 89 0E 91 AA12 0Α 21 43 65 87 09 21 43 65 87 B9

27.22.4.11.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1, 2, 3, 4, 5 and 6.

27.22.4.11.2 SEND SS (Icon support)

27.22.4.11.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.11.2.2 Conformance requirement

27.22.4.11.2.3 Test Purpose

To verify that the ME displays the text contained in the SEND SS proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.11.2.4 Method of test

27.22.4.11.2.4.1 Initial Conditions

The ME is connected to the System Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator

See Annex C for coding of the elementary files on SIM

.27.22.4.11.2.4.2 Procedure

Expected Sequence 2.1A (SEND SS, call forward unconditional, all bearers, successful, basic icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, self-explanatory]
		SS 2.1.1	
4	ME o	Display the icon without the alpha	
	USER	identifier	
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SS 2.1.1A	

PROACTIVE COMMAND: SEND SS 2.1.1

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier: "Basic Icon" SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*+01234567890123456789#"

Icon Identifier:

 $\begin{tabular}{ll} Icon qualifier: & icon is self-explanatory \\ Icon Identifier: & record 1 in EF_{(IMG)} \\ \end{tabular}$

Coding:

BER-TLV: D0 2A 81 03 01 11 00 82 02 81 83 85 0B 04 42 61 73 69 63 20 49 63 6F 6E 89 0E 91 12 21 43 65 87 09 AA0A 21 43 87 В9 9E 02 01 65

TERMINAL RESPONSE: SEND SS 2.1.1A

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	1E
	00	0A	A0	1A	04	01	21	30	15	30	13
	83	01	00	84	01	07	85	0B	91	10	32
	54	76	98	10	32	54	76	98			

Expected Sequence 2.1B (SEND SS, call forward unconditional, all bearers, successful, basic icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, self-explanatory]
		SS 2.1.1	
4	ME o	Display "Basic Icon" without the	
	USER	icon	
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully, but
		SS 2.1.1B	requested icon could not be displayed]
			. , .

TERMINAL RESPONSE: SEND SS 2.1.1B

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Additional information: Operation Code and SS Parameters

Coding:

BER-TLV:	81	03	01	11	00	82	02	82	81	03	1E
	04	0A	A0	1A	04	01	21	30	15	30	13
	83	01	00	84	01	07	85	0B	91	10	32
	54	76	90	10	32	54	76	08			

Expected Sequence 2.2A (SEND SS, call forward unconditional, all bearers, successful, colour icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[COLOUR-ICON, self-explanatory]
		SS 2.2.1	
4	ME o	Display the icon	
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		SS 2.1.1A	

PROACTIVE COMMAND: SEND SS 2.2.1

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: « Colour Icon »

SS String

TON: International

NPI: "ISDN / telephone numbering plan"
SS string: "**21*+01234567890123456789#"

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 2 in } EF_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV:	D0		81	03	01	11	00	82	02	81	83	85
		43	6F	6C	6F	75	72	20	49	63	6F	6E
	89	0E	91	AA	12	0A	21	43	65	87	09	21
	13	65	87	Ra	QΕ	02	$\Omega\Omega$	02				

Expected Sequence 2.2B (SEND SS, call forward unconditional, all bearers, successful, colour icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[COLOUR-ICON, self-explanatory]
		SS 2.2.1	
4	ME o	Display "Colour Icon" without the	
	USER	icon	
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed but requested icon
		SS 2.1.1B	could not be displayed]

Expected Sequence 2.3A (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, non self-explanatory]
		SS 2.3.1	
4	ME o	Display "Basic Icon" and the icon	
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	-
7	$ME \rightarrow SIM$	TERMINAL RESPÓNSE : SEND	[Command performed successfully]
		SS 2.1.1A	

PROACTIVE COMMAND: SEND SS 2.3.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: unpacked, 8 bit data Text: "Basic Icon"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*+01234567890123456789#"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV:	D0	2A	81	03	01	11	00	82	02	81	83	85
	0B	04	42	61	73	69	63	20	49	63	6F	6E
	89	0E	91	AA	12	0A	21	43	65	87	09	21
	43	65	87	R9	٩F	02	01	01				

Expected Sequence 2.3B (SEND SS, call forward unconditional, all bearers, successful, basic icon non self-explanatory)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, non self-explanatory]
		SS 2.3.1	
4	ME o	Display "Basic Icon" without the	
	USER	icon	
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed but requested icon
		SS 2.1.1B	could not be displayed]

Expected Sequence 2.4 (SEND SS, call forward unconditional, all bearers, successful, basic icon non selfexplanatory, no alpha identifier presented)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 2.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, non self-explanatory]
		SS 2.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command data not understood by ME]
		SS 2.4.1	

PROACTIVE COMMAND: SEND SS 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS
Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*+01234567890123456789#"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV: 1D 03 01 02 83 D0 81 11 00 82 81 89 0E 91 AA12 0A 21 43 65 87 09 21 43 В9 9E 02 65 87 01 01

TERMINAL RESPONSE: SEND SS 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV: 81 03 01 11 00 82 02 82 81 83 01 32

27.22.4.11.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences .

27.22.4.11.2 SEND SS (UCS2 support)

27.22.4.11.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.11.2.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.11.2.3 Test Purpose

To verify that the ME displays the UCS2 text contained in the SEND SS proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.11.2.4 Method of test

27.22.4.11.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.11.2.4.2 Procedure

Expected Sequence 3.1 (SEND SS, call forward unconditional, all bearers, successful, UCS2 text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND SS 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		SS 3.1.1	
4	ME o	Display "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 1.1	-
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		SS 1.1.1	

PROACTIVE COMMAND: SEND SS 3.1.1

Logically:

Command details

Command number:

Command type: SEND SS Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)

Техt: "ЗДРАВСТВУЙТЕ"

SS String

TON: International

NPI: "ISDN / telephone numbering plan" SS string: "**21*+01234567890123456789#"

Coding:

BER-TLV: D0 0E AA0Α B9

27.22.4.11.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.12 SEND USSD

27.22.4.12.1 SEND USSD (normal)

27.22.4.12.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.12.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send USSD facility as defined in the following technical specifications:

TS GSM 11.14 [15] clause 6.1, clause 6.4.12 (Send USSD), 6.6.11 (Send USSD), clause 12.12.7 (Additional information for USSD problem), clause 5.2 (Terminal Profile), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpa identifier), clause 12.17 (USSD String), clause 12.31 (Icon identifier), clause 6.5.4 (Icon identifiers).

TS GSM 03.38 [7] clause 5 (Cell broadcast data coding scheme)

Additionnally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.12.1.3 Test Purpose

To verify that the ME correctly translates and sends the unstructured supplementary service request indicated in the SEND USSD proactive SIM command to the system Simulator.

To verify that the ME returns a TERMINAL RESPONSE command to the SIM indicating the status of the transmission of the USSD request and including a USSD result as a text string in the TERMINAL RESPONSE.

27.22.4.12.1.4 Method of test

27.22.4.12.1.4.1 Initial Conditions

The ME is connected to the System Simulator and the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator

27.22.4.12.1.4.2 Procedure

Expected Sequence 1.1 (SEND USSD, 7-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		USSD 1.1.1	
4	ME o	Display "7-bit USSD"	
	USER		
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "7-bit USSD"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

BER-TLV:	D0	50	81	03	01	12	00	82	02	81	83	85
	0A	37	2D	62	69	74	20	55	53	53	44	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	B3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60		

REGISTER 1.1

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

BER-TLV	30	3D	04	01	F0	04	38	41	E1	90	58	34
	1E	91	49	E5	92	D9	74	3E	A1	51	E9	94
	5A	B5	5E	B1	59	6D	2B	2C	1E	93	CB	E6
	33	3A	AD	5E	B3	DB	EE	37	3C	2E	9F	D3
	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD	76
	C3	E5	60									

RELEASE COMPLETE (SS RETURN RESULT) 1.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

Coding:

BER-TLV	30	1E	04	01	F0	04	19	D5	E9	94	80	9A
	D3	E5	69	F7	19	24	2F	8F	CB	69	7B	99
	OC.	32	CB	DF	6D	DΩ	74	ΛA				

TERMINAL RESPONSE : SEND <u>U</u>SSD 1.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

BER-TLV: 81 03 01 12 00 82 02 82 81 83 01 00 8D 1A F0 D5 E9 94 80 9A D3 E5 0C CB 69 7B 99 69 F7 19 24 2F 8F СВ D0 74 32 DF 6D 0Α

Expected Sequence 1.2 (SEND USSD, 8-bit data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		USSD 1.2.1	
4	ME o	Display "8-bit USSD"	
	USER		
5	$ME \rightarrow SS$	REGISTER 1.2	
6	$SS \to ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.2	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.2.1	

PROACTIVE COMMAND: SEND USSD 1.2.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "8-bit USSD"

USSD String

Data coding scheme: Uncompressed, no message class meaning, 8-bit data

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

BER-TLV:	D0	58	81	03	01	12	00	82	02	81	83	85
	0A	38	2D	62	69	74	20	55	53	53	44	A8
	41	44	41	42	43	44	45	46	47	48	49	4A
	4B	4C	4D	4E	4F	50	51	52	53	54	55	56
	57	58	59	5A	2D	61	62	63	64	65	66	67
	68	69	6A	6B	6C	6D	6E	6F	70	71	72	73
	74	75	76	77	78	79	7A	2D	31	32	33	34
	35	36	37	38	30	30						

REGISTER 1.2

Logically (only USSD argument):

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, 8-bit data

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

BER-TLV	30	45	04	01	44	04	40	41	42	43	44	45
	46	47	48	49	4A	4B	4C	4D	4E	4F	50	51
	52	53	54	55	56	57	58	59	5A	2D	61	62
	63	64	65	66	67	68	69	6A	6B	6C	6D	6E
	6F	70	71	72	73	74	75	76	77	78	79	7A
	2D	31	32	33	34	35	36	37	38	39	30	

RELEASE COMPLETE (SS RETURN RESULT) 1.2

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, 8-bit data

USSD string:

- "USSD string received from SS"

Coding:

BER-TLV	30	21	04	01	44	04	1C	55	53	53	44	20
	73	74	72	69	6E	67	20	72	65	63	65	69
	76	65	64	20	66	72	6F	6D	20	53	53	

TERMINAL RESPONSE : SEND <u>U</u>SSD 1.2.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: Uncompressed, no message class meaning, 8-bit data

String: "USSD string received from SS"

Coding:

BER-TLV: 8D 1D 6E 6F 6D

Expected Sequence 1.3 (SEND USSD, UCS2 data, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		USSD 1.3.1	
4	ME o	Display "UCS2 USSD"	
	USER		
5	$ME \rightarrow SS$	REGISTER 1.3	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.3	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		SS 1.3.1	

PROACTIVE COMMAND: SEND USSD 1.3.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "UCS2 USSD"

USSD String

Data coding scheme: Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string: "ЗДРАВСТВУЙТЕ" ("Hello" in Russian)

Coding:

BER-TLV:	D0	2F	81	03	01	12	00	82	02	81	83	85
	09	55	43	53	32	20	55	53	53	44	8A	19
	48	04	17	04	14	04	20	04	10	04	12	04
	21	04	22	04	12	04	23	04	19	04	22	04
	15											

REGISTER 1.3

Logically (only USSD argument):

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string:

- "ЗДРАВСТВУЙТЕ" ("Hello" in Russian)

Coding:

BER-TLV	30	1D	04	01	48	04	18	04	17	04	14	04
	20	04	10	04	12	04	21	04	22	04	12	04
	23	04	19	04	22	04	15					

RELEASE COMPLETE (SS RETURN RESULT) 1.3

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- Uncompressed, no message class meaning, UCS2 (16 bit)

USSD string:

- "USSD string received from SS"

Coding:

BER-TLV	30	3D	04	01	48	04	38	00	55	00	53	00
	53	00	44	00	20	00	73	00	74	00	72	00
	69	00	6E	00	67	00	20	00	72	00	65	00
	63	00	65	00	69	00	76	00	65	00	64	00
	20	00	66	00	72	00	6F	00	6D	00	20	00
	53	00	53									

TERMINAL RESPONSE: SEND USSD 1.3.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: Uncompressed, no message class meaning, UCS2 (16 bit)

String: "USSD string received from SS"

Coding:

BER-TLV: 8D 6E 6F 6D

Expected Sequence 1.4 (SEND USSD, 7-bit data, unsuccessful (Return Error))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		USSD 1.1.1	
4	ME o	Display "7-bit USSD"	
	USER		
5	$ME \to SS$	REGISTER 1.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	Return Error
		RETURN ERROR) 1.1	
7	$ME \to SIM$	TERMINAL RESPONSE : SEND	
		USSD 1.4.1	

RELEASE COMPLETE (SS RETURN ERROR) 1.1

Logically (only from Return Error code):

ProcessUnstructuredSS-Request RETURN ERROR Return Error code:

- Unknown alphabet

Coding:

BER-TLV 02 01 47

TERMINAL RESPONSE : SEND <u>U</u>SSD 1.4.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: USSD Return Error Additional information: "Unknown alphabet"

Coding:

BER-TLV: 81 03 01 12 00 82 02 82 81 83 02 37 46

Expected Sequence 1.5 (SEND USSD, 7-bit data, unsuccessful (Reject))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		USSD 1.1.1	
4	ME o	Display "7-bit USSD"	
	USER		
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	Reject
		REJECT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		USSD 1.5.1	

RELEASE COMPLETE (SS REJECT) 1.1

Logically (only from Problem code):

ProcessUnstructuredSS-Request REJECT Invoke Problem code: - Mistyped parameter

Coding:

BER-TLV 81 01 02

TERMINAL RESPONSE : SEND <u>U</u>SSD 1.5.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: USSD Return Error

Additional information: "No specific cause can be given"

Coding:

BER-TLV: 81 03 01 12 00 82 02 82 81 83 02 37 00

Expected Sequence 1.6 (SEND USSD, 256 octets, 7-bit data, successful, long alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		USSD 1.6.1	
4	ME o	Display "once a RELEASE	
	USER	COMPLETE message containing	
		the USSD Return Result message	
		not containing an error has been	
		received from the network, the ME	
		shall inform the SIM that the	
		command has"	
5	$ME \to SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.1	-
7	$ME \rightarrow SIM$	TERMINAL RESPÓNSE : SEND	
		USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.6.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "once a RELEASE COMPLETE message containing the USSD Return

Result message not containing an error has been received from the network,

the ME shall inform the SIM that the command has"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

64 20 68 61 73 8A 39 F0 41 E1 90 58 34 1E 91 49 E5 92 D9 74 3E A1 51 E9 94 5A B5 5E B1 59 6D 2B 2C 1E 93 CE E6 33 3A AD 5E B3 DB EE 37 3C 2E 9F D3 EB F6 3B 3E AF 6F C5 64 33 5A CE 76 C3 E5 60	6E 20 72 6F 6F 72 73 68 20 74 74 20 64 20
---	---

Expected Sequence 1.7 (SEND USSD, 7-bit data, successful, no alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.7.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		USSD 1.7.1	
4	ME o	Optionally display an informative	
	USER	message	
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.7.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

BER-TLV:	D0	44	81	03	01	12	00	82	02	81	83	A8
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	В3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60		

Expected Sequence 1.8 (SEND USSD, 7-bit data, successful, null length alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		USSD 1.8.1	
4	ME o	the ME should not give any	
	USER	information to the user on the fact	
		that the ME is sending a USSD	
		request	
5	$ME \rightarrow SS$	REGISTER 1.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 1.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	
		USSD 1.1.1	

PROACTIVE COMMAND: SEND USSD 1.8.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha identifier : USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Coding:

BER-TLV:	D0	46	81	03	01	12	00	82	02	81	83	85
	00	8A	39	F0	41	E1	90	58	34	1E	91	49
	E5	92	D9	74	3E	A1	51	E9	94	5A	B5	5E
	B1	59	6D	2B	2C	1E	93	CB	E6	33	3A	AD
	5E	B3	DB	EE	37	3C	2E	9F	D3	EB	F6	3B
	3F	AF	6F	C5	64	33	5A	CD	76	C3	F5	60

27.22.4.12.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1.1 - 1.8.

27.22.4.12.2 SEND USSD (Icon support)

27.22.4.12.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.12.2.2 Conformance requirement

27.22.4.12.2.3 Test Purpose

To verify that the ME displays the text contained in the SEND USSD proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.12.2.4 Method of test

27.22.4.12.2.4.1 Initial Conditions

The ME is connected to the System Simulator and the SIM Simulator.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator

See Annex C for coding of the elementary files on SIM.

27.22.4.12.2.4.2 Procedure

Expected Sequence 2.1A (SEND USSD, 7-bit data, successful, basic icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, self-explanatory]
		USSD 2.1.1	
4	ME o	Display BASIC ICON	
	USER		
5	$ME \to SS$	REGISTER 2.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPÓNSE : SEND	[Command performed successfully]
		USSD 2.1.1A	

PROACTIVE COMMAND: SEND USSD 2.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Basic Icon"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier:

 $\begin{array}{ll} \mbox{Icon qualifier:} & \mbox{icon is self-explanatory} \\ \mbox{Icon Identifier:} & \mbox{record 1 in } EF_{(IMG)} \\ \end{array}$

Coding:

BER-TLV:	D0	55	81	03	01	12	00	82	02	81	83	85
	0B	04	42	61	73	69	63	20	49	63	6F	6E
	8A	39	F0	41	E1	90	58	34	1E	91	49	E5
	92	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1
	59	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E
	В3	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E
	AF	6F	C5	64	33	5A	CD	76	C3	E5	60	9E
	02	00	01									

REGISTER 2.1

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

BER-TLV	30	3D	04	01	EΛ	04	20	11	E1	90	58	34
DEK-ILV	30	30	04	υı	ΓU	04	30	41		90	50	34
	1E	91	49	E5	92	D9	74	3E	A1	51	E9	94
	5A	B5	5E	B1	59	6D	2B	2C	1E	93	CB	E6
	33	3A	AD	5E	В3	DB	EE	37	3C	2E	9F	D3
	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD	76
	C2	E5	60									

RELEASE COMPLETE (SS RETURN RESULT) 2.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

Coding:

BER-TLV	30	1E	04	01	F0	04	19	D5	E9	94	80	9A
	D3	E5	69	F7	19	24	2F	8F	CB	69	7B	99
	OC.	32	CB	DF	6D	DΩ	74	OΑ				

TERMINAL RESPONSE: SEND USSD 2.1.1A

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

BER-TLV: 03 01 00 82 81 12 82 02 81 83 01 F0 D5 D3 00 8D 1A E9 94 08 9A E5 69 F7 19 24 2F 8F CB 69 7B 99 0C 32 CB DF 6D D0 74 0A

Expected Sequence 2.1B (SEND USSD, 7-bit data, successful, basic icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, self-explanatory]
		USSD 2.1.1	
4	ME o	Display "Basic Icon" without the	
	USER	icon	
5	$ME \to SS$	REGISTER 2.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed but requested icon
		USSD 2.1.1B	could not be displayed]

TERMINAL RESPONSE : SEND <u>U</u>SSD 2.1.1B

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

G

displayed

Text string

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

BER-TLV: 81 03 01 12 00 82 02 82 81 83 01 04 8D 1A F0 D5 E9 94 80 9A D3 E5 69 19 2F CB 69 7B 99 0C F7 24 8F 32 CB DF 6D D0 74 0Α

Expected Sequence 2.2 (SEND USSD, 7-bit data, successful, colour icon self explanatory)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[COLOUR-ICON, self-explanatory]
		USSD 2.2.1	
4	ME o	Display COLOUR-ICON	
	USER	or	
		May give information to user	
		concerning what is happening	
5	$ME \rightarrow SS$	REGISTER 2.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		USSD 2.1.1A	or
		or	[Command performed but requested icon
		TERMINAL RESPONSE : SEND	could not be displayed]
1		USSD 2.1.1B	

PROACTIVE COMMAND: SEND USSD 2.2.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: « Color Icon »

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 2 in } EF_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV:	D0	55	81	03	01	12	00	82	02	81	83	85
	0B	04	43	6F	6C	6F	72	20	49	63	6F	6E
	8A	39	F0	41	E1	90	58	34	1E	91	49	E5
	92	D9	74	3E	A1	51	E9	94	5A	B5	5E	В1
	59	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E
	В3	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E
	AF	6F	C5	64	33	5A	CD	76	C3	E5	60	9E
	02	00	02									

Expected Sequence 2.3A (SEND USSD, 7-bit data, successful, basic icon non self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$		
		PENDING: SEND USSD 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	1	[BASIC-ICON, non self-explanatory]
		USSD 2.3.1	
4	ME o	Display "Basic Icon" and BASIC-	
	USER	ICON	
_	ME	DECICTED 2.4	
5	$ME \rightarrow SS$		
6	$SS \rightarrow ME$		["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		USSD 2.1.1A	
1			

PROACTIVE COMMAND: SEND USSD 2.3.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha Identifier: "Basic Icon"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

1234567890"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 81 03 01 12 00 82 02 81 83 85 55 0B 04 42 61 73 69 63 20 49 63 6F 6E F0 E1 49 E5 8A 39 41 90 58 34 1E 91 92 D9 74 3E E9 94 5A B5 5E В1 Α1 51 59 6D 2B 2C 1E CB E6 33 ЗА AD 5E 93 В3 DB ΕE 37 3C 2E 9F D3 EΒ F6 3B 3E 33 60 AF 6F C5 64 5A CD 76 E5 9E C3 02 01 01

Expected Sequence 2.3B (SEND USSD, 7-bit data, successful, basic icon non self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, non self-explanatory]
		USSD 2.3.1	
4	ME o	Display "Basic Icon" without the	
	USER	icon	
5	$ME \rightarrow SS$	REGISTER 2.1	
6	$SS \rightarrow ME$	RELEASE COMPLETE (SS	["USSD string received from SS"]
		RETURN RESULT) 2.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed but requested icon
		USSD 2.1.1B	could not be displayed]

Expected Sequence 2.4 (SEND USSD, 7-bit data, basic icon non self-explanatory, no alpha identifier presented)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 2.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, non self-explanatory]
		USSD 2.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command data not understood by ME]
		USSD 2.4.1	

PROACTIVE COMMAND: SEND USSD 2.4.1

Logically:

Command details

Command number: 1

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV:	D0	48	81	03	01	12	00	82	02	81	83	8A
	39	F0	41	E1	90	58	34	1E	91	49	E5	92
	D9	74	3E	A1	51	E9	94	5A	B5	5E	B1	59
	6D	2B	2C	1E	93	CB	E6	33	3A	AD	5E	B3
	DB	EE	37	3C	2E	9F	D3	EB	F6	3B	3E	AF
	6F	C5	64	33	5A	CD	76	C3	E5	60	9E	02
	01	01										

TERMINAL RESPONSE: SEND USSD 2.4.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV: 81 03 01 12 00 82 02 82 81 83 01 32

27.22.4.12.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 2.1 - 2.4.

27.22.4.12.3 SEND USSD (UCS2 support)

27.22.4.12.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.12.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications:

ISO/IEC 10646 [17].

27.22.4.12.3.3 Test Purpose

To verify that the ME displays the UCS2 text contained in the SEND USSD proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.12.3.4 Method of test

27.22.4.12.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default. Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.12.3.4.2 Procedure

Expected Sequence 3.1 (SEND USSD, 7-bit data, successful, UCS2 text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND USSD 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: SEND	
		USSD 3.1.1	
4	ME o	Display "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
	USER		
5	$ME \to SS$	REGISTER 3.1	
6	$SS \to ME$	RELEASE COMPLETE (SS	[Successful]
		RETURN RESULT) 3.1	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: SEND	[Command performed successfully]
		USSD 3.1.1	

PROACTIVE COMMAND: SEND USSD 3.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)

Техт: "ЗДРАВСТВУЙТЕ"

USSD String

Data coding scheme: 7-bit default, no message class

USSD string: "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-

Coding:

BER-TLV: D0 5F 81 03 01 12 00 82 02 81 83 85 04 19 80 04 17 04 14 04 20 10 04 12 04 04 04 04 21 22 04 12 04 23 19 22 04 15 8A 39 F0 41 E1 90 58 34 1E 91 49 92 D9 74 94 В5 E5 3E Α1 51 E9 5A 5E B1 59 6D 2B 2C 1E 93 СВ E6 33 ЗА AD 5E B3 DB EE 37 3C 2E 9F D3 EΒ F6 CD ΑF 3В 3E 6F C5 64 33 5A 76 C3 E5 60

REGISTER 3.1

Logically (only USSD argument)

ProcessUnstructuredSS-Request ARGUMENT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "ABCDEFGHIJKLMNOPQRSTUVWXYZ-abcdefghijklmnopqrstuvwxyz-1234567890"

Coding:

BER-TLV	30	3D	04	01	F0	04	38	41	E1	90	58	34
	1E	91	49	E5	92	D9	74	3E	A1	51	E9	94
	5A	B5	5E	B1	59	6D	2B	2C	1E	93	CB	E6
	33	ЗА	AD	5E	В3	DB	EE	37	3C	2E	9F	D3
	EB	F6	3B	3E	AF	6F	C5	64	33	5A	CD	76
	C3	F5	60									

RELEASE COMPLETE (SS RETURN RESULT) 3.1

Logically (only from USSD result):

ProcessUnstructuredSS-Request RETURN RESULT

USSD-DataCodingScheme:

- 7-bit default, no message class

USSD string:

- "USSD string received from SS"

Coding:

BER-TLV	30	1E	04	01	F0	04	19	D5	E9	94	80	9A
	D3	E5	69	F7	19	24	2F	8F	CB	69	7B	99
	OC.	32	CB	DF	6D	DΩ	74	OΑ				

TERMINAL RESPONSE: SEND USSD 3.1.1

Logically:

Command details

Command number:

Command type: SEND USSD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Text string

Data coding scheme: 7-bit default, no message class String: "USSD string received from SS"

Coding:

BER-TLV: 81 03 01 12 00 82 02 82 83 01 81 D5 D3 00 8D 1A F0 E9 94 80 9A E5 69 F7 19 24 2F 8F CB 69 7B 99 0C 32 CB D0 DF 6D 74 0A

27.22.4.12.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 3.1

27.22.4.13 SET UP CALL

27.22.4.13.1 SET UP CALL (normal)

27.22.4.13.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.13.1.2 Conformance requirement

The ME shall support the Proactive SIM: Set Up Call facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.13 (Set Up Call), clause 6.6.12 (Set Up Call), clause 12.6 (Command details), clause 12.7 (Device Identities), clause 12.12 (Result), clause 12.12.3 (Additional information for network problem), clause 5.2 (Terminal Profile)

27.22.4.13.1.3 Test Purpose

To verify that the ME accepts the Proactive Command – Set Up Call, displays the alpha identifier to the user, attempts to set up a call to the address and returns the result in the TERMINAL RESPONSE.

27.22.4.13.1.4 Method of test

27.22.4.13.1.4.1 Initial Conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the system simulator.

27.22.4.13.1.4.2 Procedure

Expected Sequence 1.1 (SET UP CALL, call confirmed by the user and connected)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP CALL 1.1.1	
4	ME o	ME displays "Not busy" during	
	USER	user confirmation phase.	
5	$USER \to$	The user confirms the call set up	[user confirmation]
	ME		
6	ME->SS	The ME attempts to set up a call	
		to "+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.1.1	[Command performed successfully]
		The ME shall not update EF LND	
		with the called party address.	
9	USER →	The user ends the call after 5	
	ME	seconds.	
		The ME returns to idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Not busy"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV: D0 1E 81 03 01 10 00 82 02 81 83 85 80 4E 6F 74 20 62 75 73 79 86 09 91 04 10 32 21 43 65 1C 2C

TERMINAL RESPONSE: SET UP CALL 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 1.2 (SET UP CALL, call rejected by the user)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP CALL 1.1.1	
4	ME o	ME displays "Not busy" durig the	
	USER	user confirmation phase	
5	$USER \to$	The user rejects the set up call	[user rejects the call]
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.2.1	[User did not accept call set-up request]
7	ME ->	The ME returns in idle mode.	
	USER		

TERMINAL RESPONSE: SET UP CALL 1.2.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: User did not accept call set-up request

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 22

Expected Sequence 1.3 (SET UP CALL, redial)

The system simulator shall be configured such that call set up requests will be rejected with cause "User Busy".

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$		[only if not currently busy on another call with
		UP CALL 1.2.1	redial]
4	ME o	ME displays "Not busy with redial"	
	USER	during the user confirmation phase	
5	$USER \to$	The user confirms the set up call	[user confirms the call]
	ME		
6	ME -> SS	ME attempts to set up a call to	[redial mechanism]
		"+012340123456p1p2" at least	
		twice	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.3.1	[network currently unable to process
			command]
8	ME ->	The ME returns in idle mode.	
	USER		

PROACTIVE COMMAND: SET UP CALL 1.2.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Not busy with redial"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

03 02 BER-TLV: D0 2A 81 01 10 01 82 81 83 85 4E 6F 74 20 73 79 20 14 62 75 77 69 74 68 20 72 65 64 69 61 6C 86 09 91 32 43 65 1C 2C 10 04 21

TERMINAL RESPONSE: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME
Destination device: SIM

Result

General Result: network currently unable to process command

Additional Information: User Busy

Coding:

BER-TLV: 81 03 01 10 01 82 02 82 81 83 02 21

91

Expected Sequence 1.4 (SET UP CALL, putting all other calls on hold, ME busy)

ME is busy on a call

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	[putting all other calls on hold]
		UP CALL 1.3.1	
4	ME o	ME displays "On hold" during the	
	USER	user confirmation phase	
5	$USER \to$	The user confirms the set up call	[user confirms the call]
	ME		
6		The active call is put on hold	
7	ME->SS	The ME attempts to set up a call	
		to "+012340123456p1p2"	
8	$SS \rightarrow ME$	The ME receives the CONNECT	
		message from the system	
	NAT CINA	simulator.	
9	ME → SIM	TERMINAL RESPONSE 1.4.1	[Command performed successfully]
10	IIQED \	The user ends the call after 5	
10	ME ME	seconds.	
	IVIL	The ME retrieves the previous call	

PROACTIVE COMMAND: SET UP CALL 1.3.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "On hold"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV: 1D 03 01 10 02 82 02 83 85 D0 81 81 07 4F 6E 20 68 6F 6C 86 09 91 10 32 1C 04 21 43 65 2C

TERMINAL RESPONSE: SET UP CALL 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 02 82 02 82 81 83 01 00

Expected Sequence 1.5 (SET UP CALL, disconnecting all other calls, ME busy)

ME is busy on a call

MAND CALL 1.4.1 MAND : SET [disconnecting all other calls]
MAND : SET [disconnecting all other calls]
MAND : SET [disconnecting all other calls]
nnect" during
n phase
ne set up call [user confirms the call]
s the active call
set up a call
p1p2"
e CONNECT
ystem
NICE 4 5 4
NSE 1.5.1 [Command performed successfully]
all after 5

PROACTIVE COMMAND: SET UP CALL 1.4.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: disconnecting all other calls

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Disconnect"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV: D0 20 81 03 01 10 04 82 02 81 83 85 0A 44 69 73 63 6F 6E 6E 65 63 74 86 09 10 04 65 1C 2C 91 32 21 43

TERMINAL RESPONSE: SET UP CALL 1.5.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 04 82 02 82 81 83 01 00

Expected Sequence 1.6 (SET UP CALL, only if not currently busy on another call, ME busy)

ME is busy on a call

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SET	[only if not currently busy on another call]
		UP CALL 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.6.1	[ME currently unable to process command]

TERMINAL RESPONSE: SET UP CALL 1.6.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional Information: ME currently busy on call

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 02 20 02

Expected Sequence 1.7 (SET UP CALL, putting all other calls on hold, call hold is not allowed)

ME is busy on a call.

The system simulator shall be configured to not allow Call Hold.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	[putting all other calls on hold]
		UP CALL 1.4.1	
4	ME o	ME displays "On hold" during the	
	USER	user confirmation phase	
5	$USER \to$	The user confirms the set up call	[user confirms the call]
	ME		
6	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.7.1	[Network currently unable to process
			command]

TERMINAL RESPONSE: SET UP CALL 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: putting all other calls on hold

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME currently unable to process command

Additional Information: No specific cause can be given

Coding:

BER-TLV: 81 03 01 10 02 82 02 82 81 83 02 21 00

Expected Sequence 1.8 (SET UP CALL, Capability configuration)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.8.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET	[Capability configuration parameters: full rate
		UP CALL 1.8.1	support]
4	ME o	ME displays "Capability config"	
	USER	during the user confirmation phase	
5	$USER \to$	The user confirms the set up call	[user confirmation]
	ME		
6	ME->SS	The ME attempts to set up a call	
		to "+012340123456p1p2" using	
		the capability configuration	
_		parameters supplied by SIM	
7	$SS \rightarrow ME$	The ME receives the CONNECT	
		message from the system	
		simulator.	[O
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.8.1	[Command performed successfully]
9	USER →	The user ends the call	
9	MF MF	The user ends the call The ME returns in idle mode.	
1	IVI⊏	THE ME TELUMS IN IGIE MOGE.	

PROACTIVE COMMAND: SET UP CALL 1.8.1

Logically:

Command details

Command number:

SET UP CALL Command type:

Command qualifier: if not busy on another call

Device identities

Source device: SIM Destination device: Network

Alpha identifier: "Capability config"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Capability configuration parameters

Information transfer cap: full rate support only MS

Coding:

BER-TLV: D0 2B 81 03 01 10 00 82 02 81 83 85 11 43 61 70 61 62 69 6C 69 74 79 20 09 10 63 6F 6E 66 69 67 86 91 32 04 2C 21 43 65 1C 87 02 01 20

TERMINAL RESPONSE: SET UP CALL 1.8.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 1.9 (SET UP CALL, max dialing number string, no alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.9.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE SET UP CALL 1.9.1	[dialing number string, no alpha identifier]
4	ME o	ME displays "Capability" during	
	USER	the user confirmation phase	
5	$USER \to$	The user confirms the set up call	[user confirmation]
	ME		
6	ME->SS	The ME attempts to set up a call	
		to	
		"012345678901234567890123456	
		789*#*#*#*#0123456789012345	
_		67890123456789*#*#*#*#"	
7	$SS \rightarrow ME$	The ME receives the CONNECT	
		message from the system	
8	ME CIM	simulator.	[Command parformed suggestfully]
0	IVIE → SIIVI	TERMINAL RESPONSE 1.9.1	[Command performed successfully]
9	USER →	The user ends the call	
	ME →	The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.9.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012345678901234567890123456789*#*#*#*#01234567890123456789

0123456789*#*#*#*#*# "

Coding:

BER-TLV: D0 34 81 03 01 10 01 82 02 81 83 86 29 91 10 32 54 76 98 10 32 54 76 98 10 32 54 76 98 BA BA BA BA BA 10 32 54 76 98 10 32 45 67 89 01 32 54 76 98 BA BA BA BA BA

TERMINAL RESPONSE: SET UP CALL 1.9.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 01 82 02 82 81 83 01 00

Expected Sequence 1.10 (SET UP CALL,256 octets length, long first alpha identifier)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 1.10.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: SET UP CALL 1.10.1	[alpha identifier]
4	ME → USER	ME displays "Three types are defined: - set up a call, but only if not currently busy on another call; - set up a call, putting all other calls (if any) on hold; - set up a call, disconnecting all other calls (if any) first. For each of these types, " during the user confirmation phase.	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+01"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.10.1	[Command performed successfully]
9	$\begin{array}{c} USER \ \to \\ ME \end{array}$	The user ends the call The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Three types are defined: - set up a call, but only if not currently busy on

another call; - set up a call, putting all other calls (if any) on hold; - set up a call, disconnecting all other calls (if any) first. For each of these types, "

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "01"

Coding:

BER-TLV: D0 FD ED 6E 2D ЗА 6C 6C 2C 6E 6C 6E 6F 6F 6E 6C 6F 6E 6F 6E 2D 6C 6C 3B 6C 6C 2C 6E 6C 6C 6C 6F 6C 6F 6E 6E 6F 6C 3B 2D 6C 6C 2C 6F 6E 6E 6C 6E 6C 6F 6C 6C 6E 2E 6F 6F

TERMINAL RESPONSE: SET UP CALL 1.10.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 01 82 02 82 81 83 01 00

Expected Sequence 1.11A (SET UP CALL, Called party subaddress, command performed successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.11.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 1.11.1	[set up a call with called party subaddress]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays "Called party" during the user confirmation phase	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2" with the called party subaddress information	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \to SIM$	TERMINAL RESPONSE 1.11.1A	[Command performed successfully]
9	$\begin{array}{c} USER \ \to \\ ME \end{array}$	The user ends the call The ME returns in idle mode.	

Expected Sequence 1.11B (SET UP CALL, Called party subaddress, ME not supporting the called party subaddress)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.11.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 1.11.1	[set up a call with called party subaddress]
4	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.11.1B	[beyond ME's capabilities]

PROACTIVE COMMAND: SET UP CALL 1.11.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Called party"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012340123456p1p2"

Called party subaddress

Type of subaddress: NSAP (X.213 / ISO 8348 AD2) Odd / even indicator: even number of address signals

Subaddress information: AFI, 95, 95, 95, 95

Coding:

BER-TLV: D0 2B 81 03 01 10 00 82 02 81 83 85 0C 6C 70 74 43 61 6C 65 64 20 61 72 79 86 09 91 10 32 04 21 43 65 1C 2C 95 88 80 50 95 95 95 95 07

TERMINAL RESPONSE: SET UP CALL 1.11.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: SET UP CALL 1.11.1B

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: if not busy on another call

Device identities

Source device: ME Destination device: SIM

Result

General Result: Beyond ME's capabilities

Coding:

BER-TLV: 81 03 01 10 00 82 02 83 81 83 01 30

Expected Sequence 1.12 (SET UP CALL, maximum duration for the redial mechanism)

The system simulator shall be configured such that call set up requests will be rejected with cause "User Busy"..

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP CALL 1.12.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SET	[only if not currently busy on another call with
		UP CALL 1.12.1	redial]
4	ME o	ME displays "Duration" during the	
	USER	user confirmation phase	
5	$USER \to$	The user confirms the set up call	[user confirms the call]
	ME		
6	ME -> SS	ME attempts to set up a call to	[redial mechanism with maximum duration of
		"+012340123456p1p2" . It stops	10 seconds]]
		its attempts after 10 seconds.	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE 1.12.1	[network currently unable to process
			command]
8	ME ->	The ME returns in idle mode.	
	USER		

PROACTIVE COMMAND: SET UP CALL 1.12.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Duration"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string: "012340123456p1p2"

Duration

Unit: Seconds Interval: 10

Coding:

BER-TLV: D0 22 81 03 01 10 01 82 02 81 83 85 80 44 75 61 74 69 6F 6E 86 09 91 72 10 32 04 21 43 65 1C 2C 84 02 01 0A

TERMINAL RESPONSE: SET UP CALL 1.12.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call with redial

Device identities

Source device: ME
Destination device: SIM

Result

General Result: network currently unable to process command

Additional Information: User Busy

Coding:

BER-TLV: 81 03 01 10 01 82 02 82 81 83 01 21 91

27.22.4.13.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1.1 to 1.12

27.22.4.13.2 SET UP CALL (second alpha identifier)

27.22.4.13.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.13.2.2 Conformance requirement

Same as 27.22.4.13.2.1.

27.22.4.13.2.3 Test Purpose

To verify that the ME accepts a Proactive Command – Set Up Call , displays the alpha identifiers to the user, attempts to set up a call to the address and returns the result in the TERMINAL RESPONSE.

27.22.4.13.2.4 Method of test

27.22.4.13.2.4.1 Initial Conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and is in updated idle mode on the system simulator

27.22.4.13.1.4.2 Procedure

Expected Sequence 2.1 (SET UP CALL, two alpha identifiers)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 2.1.1	
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays "CONFIRMATION" during the user confirmation phase	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2". The ME displays "CALL" if the ME supports 2 nd alpha identifier or otherwise "CONFIRMATION"	[second alpha identifier]
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 2.1.1 The ME shall not update EF LND with the called party address.	[Command performed successfully]
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "CONFIRMATION"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Alpha identifier (call set up phase): "CALL"

Coding:

BER-TLV: D0 28 81 03 01 10 00 82 02 81 83 85 4F 0C 43 4F 4E 46 49 52 4D 41 54 49 4E 86 09 91 10 32 21 43 65 1C 2C 4C 85 04 43 41 4C

TERMINAL RESPONSE: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

27.22.4.13.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 2.1

27.22.4.13.3 SET UP CALL (display of icons)

27.22.4.13.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.13.3.2 Conformance requirement

27.22.4.13.3.3 Test Purpose

To verify that the ME accepts a Proactive Set Up Call , displays the message or icon to the user ,attempts to set up a call to the address, returns the result in the TERMINAL response.

27.22.4.13.3.4 Method of test

27.22.4.13.3.4.1 Initial Conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and is in updated idle mode on the system simulator.

Initial Conditions for Icon Management according to Annex C are valid.

27.22.4.13.3.4.2 Procedure

Expected Sequence 3.1A (SET UP CALL, display of basic icon during confirmation phase, not selfexplanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 3.1.1	Including icon identifier, icon shall be displayed in addition of the first alpha identifier
4	ME → USER	ME displays "Set up call Icon 3.1.1" and the basic icon during a user confirmation phase.	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.1.1A	[Command performed successfully]
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 3.1.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.1.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV:	D0	38	81	03	01	10	00	82	02	81	83	85
	16	53	65	74	20	75	70	20	63	61	6C	6C
	20	49	63	6F	6E	20	33	2E	31	2E	31	86
	09	91	10	32	04	21	43	65	1C	2C	9E	02
	01	01										

TERMINAL RESPONSE: SET UP CALL 3.1.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 3.1B (SET UP CALL, display of basic icon during confirmation phase, not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 3.1.1	Including icon identifier, icon shall be displayed in addition of the first alpha identifier
4	ME → USER	ME displays "Set up call Icon 3.1.1" without the basic icon during a user confirmation phase.	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	SS → ME	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.1.1B	[Command performed successfully, but requested icon could not be displayed].
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 10 00 82 02 83 81 83 01 04

Expected Sequence 3.2A (SET UP CALL, display of basic icon during confirmation phase, self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 3.2.1	Including icon identifier, icon shall be displayed instead of the first alpha identifier
4	$ME \rightarrow USER$	ME displays the basic icon during a user confirmation phase.	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.2.1A	[Command performed successfully]
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 3.2.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.2.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV: D0 38 81 03 01 10 00 82 02 81 83 85 74 20 63 6C 16 53 65 20 75 70 61 6C 20 49 63 6F 6E 20 33 2E 32 2E 31 86 02 09 32 04 43 65 1C 2C 9E 91 10 21 00 01

TERMINAL RESPONSE: SET UP CALL 3.2.1A

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 3.2B (SET UP CALL, display of basic icon during confirmation phase, self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SET UP CALL 3.2.1	Including icon identifier, icon shall be displayed instead of the first alpha identifier
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME display " Set up call Icon 3.2.1" without the icon	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	$SS \to ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \to SIM$	TERMINAL RESPONSE 3.2.1B	[Command performed successfully, but requested icon could not be displayed].
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.2.1B

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 10 00 82 02 83 81 83 01 04

Expected Sequence 3.3A (SET UP CALL, display of coulour icon during confirmation phase, not self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 3.3.1	Including icon identifier, icon shall be displayed in addition of the first alpha identifier
4	ME → USER	ME displays "Set up call Icon 3.3" and the colour icon during a user confirmation phase.	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.3.1A	[Command performed successfully]]
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 3.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.3.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 2 in EF IMG>

Coding:

BER-TLV:	D0	38	81	03	01	10	00	82	02	81	83	85
	16	53	65	74	20	75	70	20	63	61	6C	6C
	20	49	63	6F	6E	20	33	2E	33	2E	31	86
	09	91	10	32	04	21	43	65	1C	2C	9E	02
	01	02										

TERMINAL RESPONSE: SET UP CALL 3.3.1A

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 3.3B (SET UP CALL, display of coulour icon during confirmation phase, not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 3.3.1	Including icon identifier, icon shall be displayed in addition of the first alpha identifier
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME only display alpha string: " Set up call Icon 3.3.1"	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.3.1B	[Command performed successfully, but requested icon could not be displayed].
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.3.1B

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 10 00 82 02 83 81 83 01 04

Expected Sequence 3.4A (SET UP CALL, display of self explanatory basic icon during set up call, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP CALL 3.4.1	Including a second alpha identifier and two icons
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays the basic icon during a user confirmation phase.	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2". The ME displays the basic icon during the set up call. If the ME cannot display the icon, it displays " Set up call Icon 3.4.1"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE 3.4.1A	[Command performed successfully]
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

PROACTIVE COMMAND: SET UP CALL 3.4.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: "Set up call Icon 3.4.1"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"
Alpha identifier: "Set up call Icon 3.4.2"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV: 03 D0 48 81 01 10 00 82 02 81 83 85 16 53 65 74 20 75 70 20 63 61 6C 6C 20 49 63 6F 6E 20 2E 34 2E 31 86 33 09 91 10 32 04 21 43 65 1C 2C 85 16 53 65 74 75 70 20 63 6C 6C 20 20 61 6^E 6F 34 32 9E 49 63 20 33 2E 2E 02 00 01

TERMINAL RESPONSE: SET UP CALL 3.4.1A

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 3.4B (SET UP CALL, display of self explanatory basic icon during set up call, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP CALL 3.4.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SET UP CALL 3.4.1	Including a second alpha identifier and two icons
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME display " Set up call Icon 3.4.1" without the icon	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the set up call	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2". The ME displays the basic icon during the set up call. If the ME cannot display the icon, it displays " Set up call Icon 3.4.1"	
7	$SS \to ME$	The ME receives the CONNECT message from the system simulator.	
8	$ME \to SIM$	TERMINAL RESPONSE 3.4.1B	[Command performed successfully, but requested icon could not be displayed].
9	USER → ME	The user ends the call after 5 seconds. The ME returns in idle mode.	

TERMINAL RESPONSE: SET UP CALL 3.4.1B

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 10 00 82 02 83 81 83 01 04

27.22.4.13.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 3.1 to 3.4.

27.22.4.14 POLLING OFF

27.22.4.14.1 Definition and applicability

See Section 3.2.2.

27.22.4.14.2 Conformance Requirement

The ME shall support the POLLING OFF as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.14 (Polling Off), clause 6.6.14 (Polling Off), clause 6.8 (Terminal Response), clause 6.11, clause 12.6 (Commands details), clause 12.7 (Device identities).

27.22.4.14.3 Test Purpose

To verify that the ME cancels the effect of any previous POLL INTERVAL commands and does not effect SIM presence detection.

27.22.4.14.4 Method of Test

27.22.4.14.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.14.4.2 Procedure

Expected Sequence 1.1 (POLLING OFF)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POLLING	
		INTERVAL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	Interval = 1 min
		POLL INTERVAL 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[command performed successfully]
		POLL INTERVAL 1.1.1	
5	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POLLING OFF	
		1.1.2	
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \to ME$	PROACTIVE COMMAND:	
		POLLING OFF 1.1.2	
8	$ME \to SIM$	TERMINAL RESPONSE:	[command performed successfully]
		POLLING OFF 1.1.2	
9	USER -> SIM	Call to be set up	
10	ME -> SIM	STATUS	SIM presence detection
11	ME	Time interval shall not exceed	
		30 seconds	
12	ME -> SIM	STATUS	SIM presence detection

PROACTIVE COMMAND: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Duration

Time unit: Minutes

Time interval: 1

Coding:

BER-TLV: D0 0D 81 03 01 03 00 82 02 81 82 84

02 00 01

TERMINAL RESPONSE: POLL INTERVAL 1.1.1

Logically:

Command details

Command number:

Command type: POLL INTERVAL

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 03 00 82 02 82 81 83 01 00

PROACTIVE COMMAND: POLLING OFF 1.1.2

Logically:

Command details

Command number:

Command type: POLLING OFF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 04 00 82 02 81 82

TERMINAL RESPONSE: POLLING OFF 1.1.2

Logically:

Command details

Command number: 1

Command type: POLLING OFF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 04 00 82 02 82 81 83 01 00

27.22.4.14.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.15 PROVIDE LOCAL INFORMATION

27.22.4.15.1 Definition and applicability

See Section 3.2.2.

27.22.4.15.2 Conformance requirement

The ME shall support the PROVIDE LOCAL INFORMATION facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.4.15

27.22.4.15.3 Test Purpose

To verify that the ME returns the following requested local information within a TERMINAL RESPONSE:

- location information: the mobile country code (MCC), mobile network code (MNC), location area code (LAC) and cell ID of the current serving cell;
- the IMEI of the ME;
- the Network Measurement Results and the BCCH channel list;
- the current date, time and time zone;
- the current ME language setting;
- the Timing Advance,

if the local information is stored in the ME; otherwise, sends the correct error code to the SIM in the TERMINAL RESPONSE.

27.22.4.15.4 Method of tests

27.22.4.15.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME is connected to the System Simulator and has performed the location update procedure.

The GSM parameters of the system simulator are:

Mobile country Code (MCC) = 1,

Mobile network code (MNC) = 1,

Location Area code (LAC) = 1,

Cell Identity value = 1,

Timing advance = 0,

Frequency parameters: DCS 1800, neighbour allocations = 561, 565, 568, 569, 573, 575, 577, 581, 582 and

585.

The elementary files are coded as the SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.15.4.2 Procedure

Expected Sequence 1.1 (PROVIDE LOCAL INFORMATION, Local Info (MCC, MNC, LAC & Cell ID)).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : PROVIDE	
		LOCAL INFORMATION 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : PROVIDE	[Command performed successfully, MCC MNC LAC
		LOCAL INFORMATION 1.1.1	and Cell Identity as system simulator

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.1.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: «00» Location information (MCC MNC LAC and Cell

Identity)

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 00 82 02 81 82

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.1.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: « 00 » Location information (MCC MNC LAC and Cell Identity)

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Location Information

MCC & MNC: MCC = 1, MNC = 1

Location Area Code: 1 Cell Identity Value: 1 Coding:

BER-TLV: 81 03 01 26 00 82 02 82 81 83 01 00 00 F1 10 01 00 01

Expected Sequence 1.2 (PROVIDE LOCAL INFORMATION, IMEI of the ME)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : PROVIDE	
		LOCAL INFORMATION 1.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : PROVIDE	[Command performed successfully, IMEI as system
		LOCAL INFORMATION 1.2.1	simulator]

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.2.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: « 01 » IMEI of the ME

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 01 82 02 81 82

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.2.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: « 01 » IMEI of the ME

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

IMEI

IMEI of the ME: The IMEI of the ME

The result coding depends on the Mobile IMEI value

Coding:

BER-TLV: 03 01 00 81 01 26 01 82 02 82 81 83 94 80 XXXX XXXXXXXXXXXX

Expected Sequence 1.3 (PROVIDE LOCAL INFORMATION, Network measurement results (NMR))

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.3.1	
2	$ME \rightarrow SIM$	FETCH	

-	3	$SIM \rightarrow ME$	PROACTIVE COMMAND : PROVIDE	
			LOCAL INFORMATION 1.3.1	
	4	$ME \rightarrow SIM$	TERMINAL RESPONSE : PROVIDE	[Command performed successfully, NMR as system
			LOCAL INFORMATION 1.3.1	simulator 1

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.3.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION

Qualifier: « 02 » Network Measurement Results

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 02 82 02 81 82

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.3.1

The actual values of the measurements are not tested.

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: « 02 » Network Measurement Results

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Network Measurement Results RXLEV-FULL-SERVING-CELL=52, BA not used, DTX not used, as an

example in the BER-TLV)

BCCH channel list 561, 565, 568, 569, 573, 575, 577, 581, 582 and 585

Coding:

BER-TLV: 81 03 01 26 02 82 02 82 81 83 01 00 00 00 96 10 34 34 00 00 00 00 00 00 9D 0E 8C 63 58 E2 00 00 00 00 00 00 39 8F 63 F9 06 45 91 A4 90 00

Expected Sequence 1.4 (PROVIDE LOCAL INFORMATION, Date, Time, Time Zone)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : PROVIDE	
		LOCAL INFORMATION 1.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : PROVIDE	[Command performed successfully]
		LOCAL INFORMATION 1.4.1	

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.4.1

1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION
Qualifier: « 03 » Date Time and Time Zone

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 03 82 02 81 82

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.4.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: « 03 » Date Time and Time Zone

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Date-Time and Time Zone date an time set by the user: 7th may 2002, 14h 08mn 17s, no time zone

information, as an example in TLV

Coding:

BER-TLV: 81 03 01 26 03 82 02 82 81 83 01 00

A6 07 20 50 70 41 80 71 FF

Expected Sequence 1.5 (PROVIDE LOCAL INFORMATION, Language setting)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : PROVIDE	
		LOCAL INFORMATION 1.5.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : PROVIDE	[Command performed successfully]
		LOCAL INFORMATION 1.5.1	·

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.5.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: « 04 » Language setting

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 04 82 02 81 82

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.5.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: « 04 » Language setting

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Language english (« en ») as an example for TLV

Coding:

BER-TLV: 81 03 01 26 04 82 02 82 81 83 01 00

AD 02 65 6E

Expected Sequence 1.6 (PROVIDE LOCAL INFORMATION, Timing advance)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PROVIDE	
		LOCAL INFORMATION 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : PROVIDE	
		LOCAL INFORMATION 1.6.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : PROVIDE	[Command performed successfully]
		LOCAL INFORMATION 1.6.1	

PROACTIVE COMMAND: PROVIDE LOCAL INFORMATION 1.6.1

Logically:

Command details

Command number: 1

Command type: PROVIDE LOCAL INFORMATION
Qualifier: « 05 » Timing Advance

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 26 05 82 02 81 82

TERMINAL RESPONSE: PROVIDE LOCAL INFORMATION 1.6.1

Logically:

Command details

Command number:

Command type: PROVIDE LOCAL INFORMATION

Qualifier: « 05 » Timing Advance

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timing Advance 2 bytes

ME status : « 00 » ME is in idle state Idle State

Timing Advance: 0

Coding:

BER-TLV: 81 03 01 26 05 82 02 82 81 83 01 00

AE 02 00 00

27.22.4.16 SET UP EVENT LIST

27.22.4.16.1 SET UP EVENT LIST (normal)

27.22.4.16.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.16.1.2 Conformance requirement

The ME shall support the Proactive SIM: Set Up Event List facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.4.16, 6.6.16

Additionally the ME shall support the Event Download: Call Connect and the Event Download: Call Disconnected mechanism as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 11.2, 11.2.1, 11.2.2, 11.3, 11.3.1 and 11.3.2.

27.22.4.16.1.3 Test Purpose

To verify that the ME accepts a list of events that it shall monitor the current list of events supplied by the SIM, is able to have this current list of events replaced and is able to have the list of events removed.

To verify that when the ME has successfully accepted or removed the list of events, it shall send TERMINAL RESPONSE (OK) to the SIM and when the ME is not able to successfully accept or remove the list of events, it shall send TERMINAL RESPONSE (Command beyond ME's capabilities).

27.22.4.16.1.4 Method of test

27.22.4.16.1.4.1 Initial Conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The elementary files for the second SIM Simulator are coded as SIM Application Toolkit default.

27.22.4.16.1.4.2 Procedure

Expected Sequence 1.1 (SET UP EVENT LIST, Set Up Call Connect Event)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$		
		PENDING: SET UP EVENT LIST	
		1.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP EVENT LIST 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.1.1	
5	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
6	$SS \to ME$	SETUP 1.1.1	[Incoming call alert]
7	$\begin{array}{c} USER \to \\ ME \end{array}$	User shall accept the incoming call	
8	$ME \to SS$	CONNECT 1.1.1	
9	$ME \rightarrow SIM$	ENVELOPE: EVENT DOWNLOAD CALL CONNECTED 1.1.1	[Call Connected Event]
10	$SIM \rightarrow ME$		

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01 01

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

SET UP 1.1.1

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

CONNECT 1.1.1

Logically:

Transaction identifier

Value: XX XX

ENVELOPE: EVENT DOWNLOAD CALL CONNECTED 1.1A.1Logically:

Event list

Event 1: Call Connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier

Value: XXXX

Coding:

BER-TLV: D6 xx 99 01 01 82 02 83 81 9C xx ...

Expected Sequence 1.2 (SET UP EVENT LIST, Replace Event)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SET UP EVENT LIST	
		1.2.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	[Call Connected and Call Disconnected
		UP EVENT LIST 1.2.1	Events]
	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	
4	CINA . NAT	EVENT LIST 1.2.1 PROACTIVE COMMAND	
4	SIIVI → IVIE	PENDING: SET UP EVENT LIST	
		1.2.2	
5	$ME \rightarrow SIM$	· ·	
6		PROACTIVE COMMAND : SET	[Call Disconnected Event]
		UP EVENT LIST 1.2.2	,
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	
		EVENT LIST 1.2.2	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
10	$SS \rightarrow ME$	SETUP 1.2.2	[Incoming call alert]
11	USER →	User shall accept the incoming call	[meening can alon]
	ME →	Coor Grain accopt the incoming can	
12	$ME \rightarrow SS$	CONNECT 1.2.2	
13	$SS \to ME$	DISCONNECT 1.2.2	
	$ME \rightarrow SIM$	ENVELOPE: EVENT	[Call Disconnect Event]
		DOWNLOAD CALL	
		DISCONNECT 1.2.2	
14	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SET UP EVENT LIST 1.2.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected Event 2: Call Disconnected

Coding:

BER-TLV: D0 0D 81 03 01 05 00 82 02 81 82 99 02 01 02

TERMINAL RESPONSE: SET UP EVENT LIST 1.2.1

Logically:

Command details

Command number:

SET UP EVENT LIST Command type:

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 03 01 05 00 82 02 82 81 83 01 00

PROACTIVE COMMAND: SET UP EVENT LIST 1.2.2

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM ME Destination device:

Event list

Call Disconnected Event 1:

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99

02 01

TERMINAL RESPONSE: SET UP EVENT LIST 1.2.2

Logically:

Command details

Command number:

SET UP EVENT LIST Command type:

Command qualifier: '00'

Device identities

Source device: ME Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

SET UP 1.2.2

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

CONNECT 1.2.2

Logically:

Transaction identifier

Value: XX XX

DISCONNECT 1.2.2

Logically:

Transaction identifier

Value: XX XX

Cause

Value: XX XX

ENVELOPE: EVENT DOWNLOAD CALL DISCONNECTED 1.2.2

Logically:

Event list

Event 1: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier

Value: XX XX

Cause

Value: XX XX

Coding:

BER-TLV: D6 xx 99 01 02 82 02 83 81 9C xx ...

9A xx ...

Expected Sequence 1.3 (SET UP EVENT LIST, Remove Event)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.3.1	
2	$ME \rightarrow SIM$		
3		PROACTIVE COMMAND : SET UP EVENT LIST 1.3.1	[Call Connected Event]
		TERMINAL RESPONSE : SET UP EVENT LIST 1.3.1	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.3.1	
5	$ME \rightarrow SIM$	FETCH	
6	$SIM \to ME$	PROACTIVE COMMAND : SET UP EVENT LIST 1.3.2	[Remove Event]
7	$ME \to SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.3.2	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
10	$SS \rightarrow ME$	SETUP 1.3.2	[Incoming call alert]
11	$\begin{array}{c} USER \to \\ ME \end{array}$	User shall accept the incoming call	
12	$ME \to SS$	CONNECT 1.3.2	
13	$SS \to ME$	DISCONNECT 1.3.2	

PROACTIVE COMMAND: SET UP EVENT LIST 1.3.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01

01

TERMINAL RESPONSE: SET UP EVENT LIST 1.3.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

PROACTIVE COMMAND: SET UP EVENT LIST 1.3.2

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list: Empty

Coding:

BER-TLV: D0 0B 81 03 01 05 00 82 02 81 82 99

00

TERMINAL RESPONSE: SET UP EVENT LIST 1.3.2

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

SET UP 1.3.2

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

CONNECT 1.3.2

Logically:

Transaction identifier

Value: XX XX

DISCONNECT 1.3.2

Logically:

Transaction identifier

Value: XX XX

Cause

Value: XX XX

Expected Sequence 1.4 (SET UP EVENT LIST, Remove Event on ME Power Cycle)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP EVENT LIST 1.4.1	[Call Connected Event]
	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.4.1	
4	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
5	User → ME	Power off ME	
6	User → ME	Power on ME	
7	$SS \rightarrow MF$	SETUP 1.4A	[Incoming call alert]
8	USER → ME	User shall accept the incoming call	
9	$ME \rightarrow SS$	CONNECT 1.4.1	
10	$SS \to ME$	DISCONNECT 1.4.1	

PROACTIVE COMMAND: SET UP EVENT LIST 1.4.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Call Connected

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99

01 01

TERMINAL RESPONSE: SET UP EVENT LIST 1.4.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

SET UP 1.4.1

Logically:

Transaction identifier

Value: XX XX

Address

Value: XX XX

Called party subaddress

Value: XX XX

CONNECT 1.4.1

Logically:

Transaction identifier

Value: XX XX

DISCONNECT 1.4.1

Logically:

Transaction identifier

Value: XX XX

Cause

Value: XX XX

27.22.4.16.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1, 2, 3 and 4.

27.22.4.17 PERFORM CARD APDU

27.22.4.17.1 PERFORM CARD APDU (normal)

27.22.4.17.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.17.1.2 Conformance requirement

The ME shall support the Proactive SIM: Perform Card APDU facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 5.2 (Terminal Profile), clause 6.4.17 (Perform Card APDU), clause 6.6.17 (Perform Card APDU), clause 6.8 (Structure of Terminal Response), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.35 (C-APDU), clause 12.36 (R-APDU), clause 12.12.9 (Additional information for MultipleCard Commands)

Additionally the ME shall support multiple card operation as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.4.19 (Power On Card), clause 6.6.19 (Power On Card), clause 6.4.18 (Power Off Card), clause 6.6.18 (Power Off Card)

27.22.4.17.1.3 Test Purpose

To verify that the ME sends an APDU command to the additional card identified in the PERFORM CARD APDU proactive SIM command, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

In this particular case a special Test-SIM (TestSIM) with T=0 protocol is chosen as additional card for the additional ME card reader (for coding of the TestSIM see Annex D).

27.22.4.17.1.4 Method of test

27.22.4.17.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The TestSIM is inserted in the additional ME card reader.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

The elementary files of the TestSIM are coded as defined in Annex D.

27.22.4.17.1.4.2 Procedure

Expected Sequence 1.1 (PERFORM CARD APDU, card reader 1, additional card inserted, Select MF and Get Response)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: POWER ON CARD 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: POWER ON CARD 1.1.1	[Power on card reader 1]
4	$ME \rightarrow SIM2$	RESET CARD	[Perform electrical initialisation]
5	$\begin{array}{c} \text{SIM2} \rightarrow \\ \text{ME} \end{array}$	ANSWER TO RESET 1.1	[ATR]
6	$ME \to SIM$	TERMINAL RESPONSE: POWER ON CARD 1.1.1	[ATR]
7	$SIM \to ME$	PROACTIVE COMMAND PENDING: PERFORM CARD APDU 1.1.1	
8	$ME \to SIM$	FETCH	
9	$SIM \to ME$	PROACTIVE COMMAND: PERFORM CARD APDU 1.1.1	[Select Masterfile]
10	$ME \rightarrow SIM2$	C-APDU: SELECT 1.1	[Select Masterfile]
11	$\begin{array}{c} \text{SIM2} \rightarrow \\ \text{ME} \end{array}$	R-APDU: SELECT 1.1	[Command performed successfully – length '1B' of response data]
12	$ME \to SIM$	TERMINAL RESPONSE: PERFORM CARD APDU 1.1.1	
13	$SIM \to ME$	PROACTIVE COMMAND PENDING: PERFORM CARD APDU 1.1.2	
14	$ME \to SIM$		
15	$SIM \rightarrow ME$	PROACTIVE COMMAND: PERFORM CARD APDU 1.1.2	[Get Response with length '1B']
16	$ ext{ME} ightarrow ext{SIM2}$	C-APDU: GET RESPONSE 1.1	[Get Response with length '1B']
17	$\begin{array}{c} \text{SIM2} \rightarrow \\ \text{ME} \end{array}$	R-APDU: GET RESPONSE 1.1	[Response data with length '1B']
18	$ME \to SIM$	TERMINAL RESPONSE: PERFORM CARD APDU 1.1.2	[Response data with length '1B']

PROACTIVE COMMAND POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 31 00 82 02 81 11

ANSWER TO RESET 1.1

Logically: '3B' TS (Initial character): T0 (Format character): '86' (Following interface characters: TD(1), number of historical characters: 6) TD1: '00' (Following interface characters: none, Transfer protocol: T=0) T1: 99 T2: T3: 00 T4: 12 T5: C1

Coding:

T6:

BER-TLV: 3B 86 00 91 99 00 12 C1 00

00

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B'

T0 (Format character): '86' (Following interface characters: TD(1), number of historical

characters: 6)

TD1: '00' (Following interface characters: none, Transfer protocol: T=0)

 T1:
 91

 T2:
 99

 T3:
 00

 T4:
 12

 T5:
 C1

 T6:
 00

Coding:

BER-TLV: 03 00 82 83 01 00 81 01 31 02 82 81 Α1 3B 86 00 91 00 C1 00

PROACTIVE COMMAND PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

Coding:

BER-TLV: D0 12 81 03 01 30 00 82 02 81 11 A2

07 A0 A4 00 00 02 3F 00

C-APDU: SELECT 1.1

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: Master File

Coding:

BER-TLV: A0 A4 00 00 02 3F 00

R-APDU: SELECT 1.1

Logically:

Status Words SW1 / SW2: Command performed successfully – length '1B' of response data

Coding:

BER-TLV: 9F 1B

TERMINAL RESPONSE: PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully – length '1B' of response data

Coding:

BER-TLV: 81 03 01 30 00 82 02 11 81 83 01 00

A3 02 9F 1B

PROACTIVE COMMAND PERFORM CARD APDU 1.1.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: '00'

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: GET RESPONSE

P1 parameter: '00' P2 parameter: '00' Le: '1B'

Coding:

BER-TLV: D0 10 81 03 01 30 00 82 02 81 11 A2

05 A0 C0 00 00 1B

C-APDU: GET RESPONSE 1.1

364 Logically: C-APDU 'A0' Class: **GET RESPONSE** Instruction: P1 parameter: '00' P2 parameter: '00' '1B' Coding: BER-TLV: C₀ 00 00 1B A0 R-APDU: GET RESPONSE 1.1 Logically: R-APDU data RFU: '00 00' '653 bytes' Not allocated memory: File ID: Master File Type of file: MF RFU: 00 00 22 FF 01' Length of following data: 14 bytes' File characteristics: Clock Stop: Not allowed Min. frequence for GSM algorithm: 13/8 MHz Technology identification: 3V Technology SIM CHV1: disabled DFs in current directory: 2 EFs in current directory: Number of CHV and admin. Codes: 3 RFU byte 18: CHV1 status: False representations remaining: 3 RFU-bits 7-5: 000 Secret code: Initialised Unlock CHV1 status: False represantations remaining: 10 RFU-bits 7-5: 000 Initialised Secret code: CHV2 status: False representations remaining: 3 RFU-bits 7-5: 000 Secret code: Initialised Unlock CHV2 status: False represantations remaining: 10 RFU-bits 7-5: 000 Initialised Secret code: RFU bytes 23: Reserved for admin. management: 00 83 00 FF Status Words SW1 / SW2: Normal ending of command Coding:

0E 9B 02 80 03 00 83 00 FF 90

02

8D

00

BER-TLV:

00

3F

00

01

00

A8

00

83

22

FF

00

01

00

TERMINAL RESPONSE: PERFORM CARD APDU 1.1.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU data

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File
Type of file: MF

RFU: 00 00 22 FF 01'

Length of following data: 14 bytes'

File characteristics:

Clock Stop: Not allowed
Min. frequence for GSM algorithm: 13/8 MHz
Technology identification: 3V Technology SIM

CHV1: disabled DFs in current directory: 2

EFs in current directory: 8 Number of CHV and admin. Codes: 3 RFU byte 18: 00

CHV1 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialised

Unlock CHV1 status:

False representations remaining: 10 RFU-bits 7-5: 000 Secret code: Initialised

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialised

Unlock CHV2 status:

False represantations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialised
RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 81 03 01 30 00 82 02 81 83 01 00 11 00 0F 00 02 8D 3F 00 01 00 00 22 A3

FF 01 0E 90 00

Expected Sequence 1.2 (PERFORM CARD APDU, card reader 1, additional card inserted, Select DF GSM, Select EF PLMN, Update Binary, Read Binary on EF PLMN)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$		
		PENDING: POWER ON CARD	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: POWER ON CARD 1.1	[Power on card reader 1]
4	$ME \rightarrow SIM2$	RESET CARD	[Perform electrical initialisation]
5	SIM2 → ME	ANSWER TO RESET 1.1	[ATR]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER ON CARD 1.1	[ATR]
7	$SIM \to ME$		
8	$ME \rightarrow SIM$	_	
9	$SIM \rightarrow ME$		[Select GSM]
10	$ME \rightarrow SIM2$	C-APDU: SELECT 1.2a	[Select GSM]
11	SIM2 → ME	R-APDU: SELECT 1.2a	
12		TERMINAL RESPONSE: PERFORM CARD APDU 1.2.1	
13	$SIM \to ME$		
14	$ME \to SIM$		
15	$SIM \to ME$	PROACTIVE COMMAND: PERFORM CARD APDU 1.2.2	[Select PLMN]
16	$ME \rightarrow SIM2$	C-APDU: SELECT 1.2b	[Select PLMN]
17	$\begin{array}{c} \text{SIM2} \rightarrow \\ \text{ME} \end{array}$	R-APDU: SELECT 1.2b	
18	$\text{ME} \to \text{SIM}$	TERMINAL RESPONSE:	
19	$SIM \to ME$	PERFORM CARD APDU 1.2.2 PROACTIVE COMMAND PENDING: PERFORM CARD APDU 1.2.3	
20	$ME \to SIM$		
21		PROACTIVE COMMAND: PERFORM CARD APDU 1.2.3	[Update Binary]
22	$ME \rightarrow SIM2$	C-APDU: UPDATE BINARY 1.2	[Update Binary]
23	SIM2 → ME	R-APDU: UPDATE BINARY 1.2	
24	$ME \to SIM$	TERMINAL RESPONSE: PERFORM CARD APDU 1.2.3	
25	$SIM \to ME$	PROACTIVE COMMAND PENDING: PERFORM CARD APDU 1.2.4	
26	$\text{ME} \to \text{SIM}$		
27	$SIM \to ME$	PERFORM CARD APDU 1.2.4	[Read Binary]
28	$ME \rightarrow SIM2$	C-APDU: READ BINARY 1.2	[Read Binary]
29	$\begin{array}{c} \text{SIM2} \rightarrow \\ \text{ME} \end{array}$	R-APDU: READ BINARY 1.2	
30	$ME \to SIM$	TERMINAL RESPONSE: PERFORM CARD APDU 1.2.4	
31	$SIM \to ME$	PROACTIVE COMMAND: PERFORM CARD APDU 1.2.5	[Update Binary]

32	'''= '	C-APDU: UPDATE BINARY 1.2a	[Update Binary]
	SIM2		
33	$SIM2 \rightarrow$	R-APDU: UPDATE BINARY 1.2	
	ME		
34	$ME \rightarrow SIM$	TERMINAL RESPONSE:	
		PERFORM CARD APDU 1.2.3	

PROACTIVE COMMAND PERFORM CARD APDU 1.2.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: DF GSM

Coding:

BER-TLV: 02 D0 12 81 03 01 30 00 82 81 11 A2 07 A0 A4 00 00 02 7F 20

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.2

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: EF PLMN

Coding:

BER-TLV: D0 03 01 82 02 12 81 30 00 81 Α2 11 07 A0 A4 00 00 02 6F 30

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.3

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F

10 11 12 13 14 15 16 17'

Coding:

BER-TLV: D0 28 81 03 01 30 00 82 02 81 11 A2

1D A0 D6 00 00 18 01 02 03 04 05 00 06 07 80 09 0A 0B 0C 0D 0E 0F 10 11 14 12 13 15 16 17

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.4

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

1

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: READ BINARY

P1 parameter: '00' P2 parameter: '00' Le: '18'

Coding:

BER-TLV: D0 10 81 03 01 30 00 82 02 81 11 A2

05 A0 B0 00 00 18

PROACTIVE COMMAND: PERFORM CARD APDU 1.2.5

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

FF FF FF FF FF FF FF'

Coding:

BER-TLV: D0 28 81 03 01 30 00 82 02 81 11 A2

1D A0 D6 00 00 18 FF FF

FF FF FF FF FF

C-APDU: SELECT 1.2a

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: DF GSM

Coding:

BER-TLV: A0 A4 00 00 02 7F 20

C-APDU: SELECT 1.2b

Logically:

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'
Data: EF PLMN

Coding:

BER-TLV: A0 A4 00 00 02 6F 30

C-APDU: UPDATE BINARY 1.2

Logically:

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F

10 11 12 13 14 15 16 17

Coding:

BER-TLV: A0 D6 00 00 18 00 01 02 03 04 05 06 07 80 09 0A 0B 0C 0D 0E 0F 10 12 11

13 14 15 16 17

C-APDU: READ BINARY 1.2

Logically:

C-APDU

Class: 'A0'

Instruction: READ BINARY

P1 parameter: '00' P2 parameter: '00' Le: '18'

Coding:

BER-TLV: A0 B0 00 00 18

C-APDU: UPDATE BINARY 1.2a

Logically:

C-APDU

Class: 'A0'

Instruction: UPDATE BINARY

P1 parameter: '00' P2 parameter: '00' Lc: '18'

FF FF FF FF FF FF FF'

Coding:

BER-TLV: A0 D6 00 00 18 FF FF FF FF FF FF

FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

R-APDU: SELECT 1.2a

Logically:

Status Words

SW1 / SW2: Normal ending of command – length '1B' of response data

Coding:

BER-TLV: 9F 1B

R-APDU: SELECT 1.2b

Logically:

Status Words

SW1 / SW2: Normal ending of command - length '0F' of response data

Coding:

BER-TLV: 9F 0F

R-APDU: UPDATE BINARY 1.2

Logically:

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 90 00

R-APDU: READ BINARY 1.2

Logically:

R-APDU data

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F

10 11 12 13 14 15 16 17 '

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 00 01 02 03 04 05 06 07 08 09 0A 0B

OC OD OE OF 10 11 12 13 14 15 16 17

90 00

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully – length 1B of response data

Coding:

BER-TLV: 81 03 01 30 00 82 02 11 81 83 01 00

A3 02 9F 1B

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.2

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Command performed successfully – length 0F of response data

Coding:

BER-TLV: 81 03 01 30 00 82 02 11 81 83 01 00

A3 02 9F 0F

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.3

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

R-APDU

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 81 03 01 30 00 82 02 11 81 83 01 00

A3 02 90 00

TERMINAL RESPONSE: PERFORM CARD APDU 1.2.4

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result:

Command performed successfully

R-APDU

R-APDU data

Data: '00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0B 0E 0F

10 11 12 13 14 15 16 17 '

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 03 30 00 82 83 01 00 81 01 02 11 81 Α2 81 EF A0 D6 00 00 EC 00 01 02 03 04 05 06 07 80 09 0Α 0B 0C 0D 0E 0F 10 12 13 14 15 16 17 90 00 11

Expected Sequence 1.3 (PERFORM CARD APDU, card reader 1, card inserted, card powered off)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER OFF CARD	
		1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$		[Power off card reader 1]
		POWER OFF CARD 1.3.1	
4	ME o	POWER OFF CARD	[Power off card reader 1]
	SIM2		
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: POWER	[Successful]
		OFF CARD 1.3.1	
6	ME	SIM2 is powered off from ME card	
		reader	
7	$SIM \rightarrow ME$		
		PENDING: PEFORM CARD	
		APDU 1.1.1	
8	$ME \rightarrow SIM$	_	
9	$SIM \to ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.1.1	
10	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Card powered off]
		PERFORM CARD APDU 1.3.1	

PROACTIVE COMMAND: POWER OFF CARD 1.3.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 32 00 82 02 81 11

TERMINAL RESPONSE: POWER OFF CARD 1.3.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 01 00

TERMINAL RESPONSE: PERFORM CARD APDU 1.3.1

Logically:

Command details

Command number: 1

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error

Additional information: Card powered off

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 02 38

04

Expected Sequence 1.4 (PERFORM CARD APDU, card reader 1, no card inserted)

Step	Direction	MESSAGE / Action	Comments
1	ME	SIM2 is removed from ME card	
		reader	
2	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PEFORM CARD	
		APDU 1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[No card inserted]
	, , , , , , , , , , , , , , , , , , , ,	PERFORM CARD APDU 1.4.1	

TERMINAL RESPONSE: PERFORM CARD APDU 1.4.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error Additional information: Card removed or not present

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 02 38

02

Expected Sequence 1.5 (PERFORM CARD APDU, card reader 7 (which is not the valid card reader identifier of the additional ME card reader))

Direction	MESSAGE / Action	Comments
$SIM \to ME$	PENDING: PEFORM CARD	[invalid card reader ID]
$ME \rightarrow SIM$	=	
$SIM \to ME$		[Select Master File]
$ME \to SIM$		[Specified reader not valid]
	$SIM \rightarrow ME$ $ME \rightarrow SIM$ $SIM \rightarrow ME$	$\begin{array}{c} \text{SIM} \rightarrow \text{ME} & \text{PROACTIVE COMMAND} \\ \text{PENDING: PEFORM CARD} \\ \text{APDU 1.5.1} \\ \text{ME} \rightarrow \text{SIM} & \text{FETCH} \\ \text{SIM} \rightarrow \text{ME} & \text{PROACTIVE COMMAND:} \\ \text{PERFORM CARD APDU 1.5.1} \\ \text{ME} \rightarrow \text{SIM} & \text{TERMINAL RESPONSE:} \end{array}$

PROACTIVE COMMAND:: PERFORM CARD APDU 1.1.1

Logically:

Command details

Command number: 1

PERFORM CARD APDU Command type:

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 7

C-APDU

Class: 'A0' Instruction: **SELECT** '00' P1 parameter: '00' P2 parameter: '02' Lc: Master File

Data:

Coding:

BER-TLV: 81 03 01 02 81 D0 12 30 00 82 17 Α2

07 A0 A4 00 00 02 3F 00

C-APDU: SELECT 1.1

Logically:

C-APDU

'A0' Class: Instruction: **SELECT** P1 parameter: '00' '00' P2 parameter: **'**02' Lc: Data: Master File

Coding:

BER-TLV: 00 00 02 3F 00 A0 Α4

TERMINAL RESPONSE: PERFORM CARD APDU 1.5.1

Logically:

Command details

Command number: 1

PERFORM CARD APDU Command type:

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error Additional information: Specified reader not valid

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 02 38

09

27.22.4.17.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.17.2 PERFORM CARD APDU (detachable card reader)

27.22.4.17.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.17.2.2 Conformance requirement

27.22.4.17.2.3 Test Purpose

To verify that the ME sends an APDU command to the additional card identified in the PERFORM CARD APDU proactive SIM command, and successfully returns the result of the execution of the command in the TERMINAL RESPONSE command send to the SIM.

27.22.4.17.2.4 Method of test

27.22.4.17.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The card reader shall be detached from the ME.

27.22.4.17.2.4.2 Procedure

Expected Sequence 2.1 (PERFORM CARD APDU, card reader 1, card reader detached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: PEFORM CARD	
		APDU 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Select Master File]
		PERFORM CARD APDU 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE:	[Card reader detached]
		PERFORM CARD APDU 2.1.1	

PROACTIVE COMMAND: PERFORM CARD APDU 2.1.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card Reader 1

C-APDU

Class: 'A0'
Instruction: SELECT
P1 parameter: '00'
P2 parameter: '00'
Lc: '02'

Data: Master File

Coding:

BER-TLV: D0 12 81 03 01 30 00 82 02 81 11 A2 00 07 A0 A4 00 02 3F 00

TERMINAL RESPONSE: PERFORM CARD APDU 2.1.1

Logically:

Command details

Command number:

Command type: PERFORM CARD APDU

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error
Additional information: Card reader removed or not present

Coding:

BER-TLV: 81 03 01 30 00 82 02 82 81 83 02 38 01

27.22.4.17.2.5 Test RequirementThe ME shall operate in the manner defined in expected sequence.

27.22.4.18 POWER OFF CARD

27.22.4.18.1 POWER OFF CARD (normal)

27.22.4.18.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.18.1.2 Conformance requirement

The ME shall support the Proactive SIM: Power Off Card facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.18 (Power Off Card), clause 6.6.18 (Power Off Card), clause 12.6 (Command details), clause 12.7 (Device Identities), clause 12.12 (Result), clause 12.12.9 (Additional information for MultipleCard commands), clause 5.2 (Terminal Profile), Annex H(Support of Multiple Card Operation),

:

27.22.4.18.1.3 Test Purpose

To verify that the ME closes a session with the additional card identified in the POWER OFF CARD proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.4.18.1.4 Method of test

27.22.4.18.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

27.22.4.18.1.4.2 Procedure

Expected Sequence 1.1 (POWER OFF CARD, card reader 1)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER OFF CARD	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	[Power off card reader 1]
		POWER OFF CARD 1.1.1	
4	ME o	POWER OFF CARD	[Power off card reader 1]
	SIM2		
5	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Successful]
		POWER OFF CARD 1.1.1	

PROACTIVE COMMAND: POWER OFF CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 32 00 82 02 81 11

TERMINAL RESPONSE: POWER OFF CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 01 00

Expected Sequence 1.2 (POWER OFF CARD, card reader 1, no card inserted)

Step	Direction	MESSAGE / Action	Comments
1	SIM2	SIM2 is removed from ME card	
2	$SIM \rightarrow ME$	reader PROACTIVE COMMAND PENDING: POWER OFF CARD	
		1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[Power off card reader 1]
		POWER OFF CARD 1.1.1	_
5	$ME \rightarrow SIM$	TERMINAL RESPONSE : POWER OFF CARD 1.2.1	[No card inserted]

TERMINAL RESPONSE: POWER OFF CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error Additional information: Card removed or not present

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 02 38

02

27.22.4.18.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.18.2 POWER OFF CARD (detachable card reader)

27.22.4.18.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.18.2.2 Conformance requirement

27.22.4.18.2.3 Test Purpose

To verify that the ME closes a session with the additional card identified in the POWER OFF CARD proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.18.2.4 Method of test

27.22.4.18.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

The card reader shall be detached from the ME.

27.22.4.18.2.4.2 Procedure

Expected Sequence 2.1 (POWER OFF CARD, card reader 1, no card reader attached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER OFF CARD	
		2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	[Power off card reader 1]
		POWER OFF CARD 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Card reader removed or not present]
		POWER ON CARD 2.1.1	

PROACTIVE COMMAND: POWER OFF CARD 2.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 32 00 82 02 81 11

TERMINAL RESPONSE: POWER OFF CARD 2.1.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME Destination device: SIM

Result

General Result: MultipleCard commands error
Additional information: Card reader removed or not present

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 02 38

01

27.22.4.18.2.5 Test RequirementThe ME shall operate in the manner defined in expected sequences

27.22.4.19 POWER ON CARD

27.22.4.19.1 POWER ON CARD (normal)

27.22.4.19.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.19.1.2 Conformance requirement

The ME shall support the Proactive SIM: Power On Card facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.19 (Power On Card), clause 6.6.19 (Power On Card),), clause 12.6 (Command details), clause 12.7 (Device Identities), clause 12.12 (Result), clause 12.12.9 (Additional information for MultipleCard commands), clause 12.34 (Card ATR), clause 5.2 (Terminal Profile), 3GPP TS 11.14 [15] Annex H(Support of Multiple Card Operation), ISO /IEC 7816-3

27.22.4.19.1.3 Test Purpose

To verify that the ME starts a session with the additional card identified in the POWER ON CARD proactive SIM command, and successfully returns the Answer To Reset within the TERMINAL RESPONSE command send to the SIM

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.4.19.1.4 Method of test

27.22.4.19.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

27.22.4.19.1.4.2 Procedure

Expected Sequence 1.1 (POWER ON CARD, card reader 1)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 1.1.1	
4	ME o	RESET CARD	[Perform electrical initialisation]
	SIM2		
5	$SIM2 \rightarrow$	ANSWER TO RESET 1.1.1	[ATR]
	ME		
6	$ME \to SIM$	TERMINAL RESPONSE :	[ATR]
		POWER ON CARD 1.1.1	

PROACTIVE COMMAND: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

POWER ON CARD Command type:

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

09 BER-TLV: D0 81 03 01 31 00 82 02 81 11

ANSWER TO RESET 1.1.1

Logically:

'3B' TS (Initial character): T0 (Format character): 0F

·Ρ' T1 (Historical character): T2 (Historical character): o'

w' T3 (Historical character):

T4 (Historical character): 'e'

T5 (Historical character): ʻr'

T6 (Historical character): O'

T7 (Historical character): 'n,

T8 (Historical character): 'C'

T9 (Historical character): ʻa'

ʻr' T10 (Historical character):

T11 (Historical character): ʻd'

'T' T12 (Historical character):

'e' T13 (Historical character):

's' T14 (Historical character): 't'

T15 (Historical character):

Coding:

BER-TLV: Α1 3B 0F 50 6F 77 65 72 4F 6E 43 11 74 61 72 64 54 65 75

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B' T0 (Format character): 0F

·Ρ' T1 (Historical character): T2 (Historical character): 'o' T3 (Historical character): w' T4 (Historical character): 'e' T5 (Historical character): ʻr' T6 (Historical character): O, T7 (Historical character): 'n, T8 (Historical character): 'C' T9 (Historical character): ʻa' ʻr' T10 (Historical character): ʻd' T11 (Historical character): 'T' T12 (Historical character): T13 (Historical character): 'e' T14 (Historical character): 's' T15 (Historical character): 't'

Coding:

BER-TLV: 01 81 03 31 00 82 02 82 81 83 01 00 0F 50 77 72 4F 6E 43 Α1 3B 6F 65 11 61 72 64 54 65 74 75

Expected Sequence 1.2 (POWER ON CARD, card reader 1, no ATR)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	[Power on card reader 1]
		POWER ON CARD 1.1.1	
4	ME o	RESET CARD	[Perform electrical initialisation]
	SIM2		
5	$SIM2 \rightarrow$	NO ATR	[No ATR]
	ME		
6	$ME \to SIM$	TERMINAL RESPONSE :	[No ATR]
		POWER ON CARD 1.2.1	

TERMINAL RESPONSE: POWER ON CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: MultipleCard commands error

Additional information: Card mute

Coding:

BER-TLV: 81 03 01 31 00 82 02 82 81 83 02 38

06

Expected Sequence 1.3 (POWER ON CARD, card reader 1, no card inserted)

Step	Direction	MESSAGE / Action	Comments
1	SIM2	SIM2 is removed from ME card	
2	$SIM \rightarrow ME$	reader PROACTIVE COMMAND PENDING: POWER ON CARD	
		1.1.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Card removed or not present]
		POWER ON CARD 1.3.1	

TERMINAL RESPONSE: POWER ON CARD 1.3.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: Card reader 0

Destination device: SIM

Result

General Result: MultipleCard commands error Additional information: Card removed or not present

Coding:

BER-TLV: 81 03 01 31 00 82 02 82 81 83 02 38 02

27.22.4.19.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.19.2 POWER ON CARD (detachable card reader)

27.22.4.19.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.19.2.2 Conformance requirement

27.22.4.19.2.3 Test Purpose

To verify that the ME starts a session with the additional card identified in the POWER ON CARD proactive SIM command, and successfully returns the Answer To Reset within the TERMINAL RESPONSE command send to the SIM.

27.22.4.19.2.4 Method of test

27.22.4.19.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The card reader shall be detached from the ME.

27.22.4.19.2.4.2 Procedure

Expected Sequence 2.1 (POWER ON CARD, card reader 1, no card reader attached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: POWER ON CARD	
		2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[Power on card reader 1]
		POWER ON CARD 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Card reader removed or not present]
		POWER ON CARD 2.1.1	

PROACTIVE COMMAND: POWER ON CARD 2.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 31 00 82 02 81 11

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: Card reader 0

Destination device: SIM

Result

General Result: MultipleCard commands error
Additional information: Card reader removed or not present

Coding:

BER-TLV: 81 03 01 31 00 82 02 82 81 83 02 38

27.22.4.19.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.20 GET READER STATUS

27.22.4.20.1 GET READER STATUS (normal)

27.22.4.20.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.20.1.2 Conformance requirement

The ME shall support the Proactive SIM: Get Card Reader Status facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1(Introduction), clause 5.2 (Terminal Profile), clause 6.4.20 (Get Reader Status), clause 6.6.20 (Get Reader Status), clause 6.8 (Terminal Response), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.33 (Card Reader Status), clause 12.57 (Card Reader Identifier), Annex H (Support of Multiple Card Operation)Additionally the ME shall support multiple card operation as defined in the following technical specifications:

3GPP TS 11.14 [] clause 6.4.19 (Power On Card), clause 6.6.19 (Power On Card), clause 6.4.18 (Power Off Card), 6.6.18 (Power Off Card)

27.22.4.20.1.3 Test Purpose

To verify that the ME sends starts a session with the additional card identified in the GET CARD READER STATUS proactive SIM command, and successfully returns information about all interfaces to additional card reader(s) in the TERMINAL RESPONSE command send to the SIM.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

In this test case the second SIM-Simulator (SIM2) shall response with the ATR "3B 00".

27.22.4.20.1.4 Method of test

27.22.4.20.1.4.1 Initial Conditions

The ME shall support the Proactive SIM: Get Card Reader Status (Card Reader Status) facility. The ME is connected to the SIM Simulator.

The ME card reader is connected to the second SIM Simulator (SIM2).

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

If the ME supports a detachable card reader, the card reader shall be attached to the ME.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

27.22.4.20.1.4.2 Procedure

Expected Sequence 1.1 (GET CARD READER STATUS, card reader 1, card inserted, card powered)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: POWER ON CARD 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: POWER ON CARD 1.1.1	[Power on card reader 1]
4	ME → SIM2	RESET CARD	[Perform electrical initialisation]
5	SIM2 → ME	ANSWER TO RESET 1.1.1	[ATR]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : POWER ON CARD 1.1.1	[ATR]
7		PROACTIVE COMMAND PENDING: GET CARD READER STATUS 1.1.1	
8	$ME \rightarrow SIM$		
9		PROACTIVE COMMAND : GET CARD READER STATUS 1.1.1	[Get Card Reader Status]
10	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET CARD READER STATUS 1.1.1a Or	[Successful]
		TERMINAL RESPONSE : GET CARD READER STATUS 1.1.1b or	[Successful]
		TERMINAL RESPONSE : GET CARD READER STATUS 1.1.1c or	[Successful]
		TERMINAL RESPONSE : GET CARD READER STATUS 1.1.1d	[Successful]

PROACTIVE COMMAND: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 31 00 82 02 81 11

ANSWER TO RESET 1.1.1

Logically:

TS (Initial character): '3B' T0 (Format character): '00'

Coding:

BER-TLV: A1 02 3B 00

TERMINAL RESPONSE: POWER ON CARD 1.1.1

Logically:

Command details

Command number:

Command type: POWER ON CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card ATR

TS (Initial character): '3B' TO (Format character): '00'

Coding:

BER-TLV: 81 03 01 31 00 82 02 82 81 83 01 00

A1 02 3B 00

PROACTIVE COMMAND: GET CARD READER STATUS 1.1.1

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 33 00 82 02 81 82

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1a

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: Yes

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 F1

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: Yes

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 D1

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1c

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: Yes

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 F9

TERMINAL RESPONSE: GET CARD READER STATUS 1.1.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: Yes

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 D9

Expected Sequence 1.2 (GET CARD READER STATUS, card reader 1, card inserted, card not powered)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: POWER OFF CARD	
2	$ME \rightarrow SIM$	1.2.1	
	IVIE → SIIVI	FEIGH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	[Power off card reader 1]
		POWER OFF CARD 1.2.1	
4	$ME \to$	POWER OFF CARD	[Power off card reader 1]
_	SIM2	TERMINAL RESPONSE	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE : POWER OFF CARD 1.2.1	[Successful]
6	SIM → ME	PROACTIVE COMMAND	
	Olivi 7 IVIL	PENDING: GET CARD READER	
		STATUS 1.1.1	
7	$ME \rightarrow SIM$		
8	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET	[Get Card Reader Status]
9	ME SIM	CARD READER STATUS 1.1.1 TERMINAL RESPONSE : GET	[Successful]
9	IVIE -> SIIVI	CARD READER STATUS 1.2.1a	[Successiui]
		Or	
		TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 1.2.1b	
		or TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 1.2.1c	[Successiul]
		Or	
		TERMINAL RESPONSE : GET	
		CARD READER STATUS 1.2.1d	[Successful]

PROACTIVE COMMAND: POWER OFF CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Card reader 1

Coding:

BER-TLV: D0 09 81 03 01 32 00 82 02 81 11

TERMINAL RESPONSE: POWER OFF CARD 1.2.1

Logically:

Command details

Command number:

Command type: POWER OFF CARD

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 32 00 82 02 82 81 01 00

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1a

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 71

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 51

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1c

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'Yes'
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 79

TERMINAL RESPONSE: GET CARD READER STATUS 1.2.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '01'
Card reader removable: 'Yes'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

Expected Sequence 1.3 (GET CARD READER STATUS, card reader 1, card not present)

Step	Direction	MESSAGE / Action	Comments
1	SIM2	SIM2 is removed from ME card	
		reader	
2	$SIM \rightarrow ME$		
		PENDING: GET CARD READER	
		STATUS 1.1.1	
3	$ME \rightarrow SIM$		
4	$SIM \rightarrow ME$		[Get Card Reader Status]
_		CARD READER STATUS 1.1.1	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 1.3.1a	
		Or TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 1.3.1b	[Successiui]
		or	
		TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 1.3.1c	[Eucoccoiui]
		or	
		TERMINAL RESPONSE : GET	
		CARD READER STATUS 1.3.1d	[Successful]

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1a

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader:

Card reader removable:

Card reader present:

Card reader ID-1 size:

Card present in reader:

Card powered:

No

No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: '1'
Card reader removable: 'No'
Card reader present: Yes
Card reader ID-1 size: 'No'
Card present in reader: No
Card powered: No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 11

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1c

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader:

Card reader removable:

Card reader present:

Card reader ID-1 size:

Card present in reader:

Card powered:

No

No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

TERMINAL RESPONSE: GET CARD READER STATUS 1.3.1d

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader:

Card reader removable:

Card reader present:

Card reader ID-1 size:

Card present in reader:

No

Card powered:

No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

00 A0 01 19

27.22.4.20.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.20.2 GET CARD READER STATUS (detachable card reader)

27.22.4.20.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.20.2.2 Conformance requirement

27.22.4.20.2.3 Test Purpose

To verify that the ME closes a session with the additional card identified in the GET CARD READER STATUS proactive SIM command, and successfully returns result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.20.2.4 Method of test

27.22.4.20.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to this test the ME shall have powered on the second SIM Simulator (SIM2).

The card reader shall be detached from the ME.

27.22.4.20.2.4.2 Procedure

Expected Sequence 2.1 (GET CARD READER STATUS, no card reader attached)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET CARD READER	
		STATUS 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	[Get Card Reader Status]
		CARD READER STATUS 2.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 2.1.1a	
		or	
		TERMINAL RESPONSE : GET	[Successful]
		CARD READER STATUS 2.1.1b	

PROACTIVE COMMAND: GET CARD READER STATUS 2.1.1

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card Reader Status

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 33 00 82 02 81 82

TERMINAL RESPONSE: GET CARD READER STATUS 2.1.1a

Logically:

Command details

Command number:

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader:01Card reader removable:YesCard reader present:NoCard reader ID-1 size:YesCard present in reader:NoCard powered:No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01

TERMINAL RESPONSE: GET CARD READER STATUS 2.1.1b

Logically:

Command details

Command number: 1

Command type: GET CARD READER STATUS

Command qualifier: Card reader status

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: 81 03 01 33 00 82 02 82 81 83 01 00 A0 01 09

27.22.4.20.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.21TIMER MANAGEMENT and ENVELOPE TIMER EXPIRATION

27.22.4.21.1 TIMER MANAGEMENT (normal)

27.22.4.21.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.21.1.2 Conformance Requirement

The ME shall support the TIMER MANAGEMENT as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.21 (Timer Management), clause 6.8 (Terminal Response), clause 12.6 (Commands details), clause 12.7 (Device Identities), clause 12.37 (Timer Identifier), clause 12.38 (Timer Value).

27.22.4.21.1.3 Test Purpose

To verify that the ME manages correctly its internal timers, start a timer, deactivate a timer or return the current value of a timer according to the Timer Identifier defined in the TIMER MANAGEMENT proactive SIM command.

27.22.4.21.1.4 Method of Test

27.22.4.21.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.4.21.1.4.2 Procedure

Expected Sequence 1.1 (TIMER MANAGEMENT, start timer 1 several times, get the current value of the timer and deactivate the timer successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.1.1	
2	$ME \to SIM$	FETCH	
3		PROACTIVE COMMAND:	[start timer 1]
		TIMER MANAGEMENT 1.1.1	
4	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.1.1	
5	$SIM \to ME$	PROACTIVE COMMAND	After 1 minute following reception of Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.1.2	
6	$ME \to SIM$	FETCH	
7		PROACTIVE COMMAND:	[ask value of timer 1]
		TIMER MANAGEMENT 1.1.2	
8	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.1.2	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	Before timer expires!
		PENDING: TIMER	
		MANAGEMENT 1.1.3	
10	$ME \rightarrow SIM$	FETCH	
11		PROACTIVE COMMAND:	[reinitialise timer 1]
		TIMER MANAGEMENT 1.1.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
4.0		MANAGEMENT 1.1.3	46 00 14 11 1 11
13	$SIM \to ME$	PROACTIVE COMMAND	After 30 seconds following reception of the
		PENDING: TIMER	Terminal Response
4.4		MANAGEMENT 1.1.4	
14	$ME \rightarrow SIM$	FETCH	Education to the sold
15		PROACTIVE COMMAND:	[deactivate timer 1]
10	ME OLA	TIMER MANAGEMENT 1.1.4	[
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.1.4	

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.1

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Timer value:

Value of timer: 5 min

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 01

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

1

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer:

Timer value:

Value of timer: 1min 30sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

PROACTIVE COMMAND: TIMER MANAGEMENT 1.1.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4 01 01

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.1 and 1.1.3

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 01

TERMINAL RESPONSE: TIMER MANAGEMENT 1.1.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 1

Timer value:

value of timer: value < to the timer value of command 1.1.1

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 00

A4 01 01 A5 03 xx xx xx

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer:

Timer value:

value of timer: value < to the timer value of command 1.1.3

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 00

A4 01 01 A5 03 xx xx xx

Expected Sequence 1.2 (TIMER MANAGEMENT, start timer 2 several times, get the current value of the timer and deactivate the timer successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
	· · · · · · · · · · · · · · · · · · ·	PENDING: TIMER	
		MANAGEMENT 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND:	[start timer 2]
		TIMER MANAGEMENT 1.2.1	
4	$\text{ME} \rightarrow \text{SIM}$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.2.1	
5	$SIM \to ME$	PROACTIVE COMMAND	After 1 minute following reception of Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.2.2	
6	$ME \to SIM$	FETCH	
7		PROACTIVE COMMAND:	[ask value of timer 2]
		TIMER MANAGEMENT 1.2.2	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.2.2	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	Before timer expires!
		PENDING: TIMER	
4.0		MANAGEMENT 1.2.3	
10	$ME \rightarrow SIM$	FETCH	
11		PROACTIVE COMMAND:	[reinitialise timer 2]
40		TIMER MANAGEMENT 1.2.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
40	0114 145	MANAGEMENT 1.2.3	After 40 consideration of
13	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	After 10 seconds following reception of
		MANAGEMENT 1.2.4	Terminal Response
14	$ME \rightarrow SIM$	FETCH	
15	IVIE -> SIIVI	PROACTIVE COMMAND:	[deactivate timer 2]
15		TIMER MANAGEMENT 1.2.4	[ucactivate tiller 2]
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
10	IVIL -> SIIVI	MANAGEMENT 1.2.4	[command performed successfully]

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.1

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Timer value:

Value of timer: 23h 59min 59sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 02 A5 03 32 95 95

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 02

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Timer value:

Value of timer: 40 sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 02 A5 03 00 00 04

PROACTIVE COMMAND: TIMER MANAGEMENT 1.2.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 02

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.1 and 1.2.3

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 02

TERMINAL RESPONSE: TIMER MANAGEMENT 1.2.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 2

Timer value:

value of timer: value < to the timer value of command 1.2.1

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 00

A4 01 02 A5 03 xx xx xx

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer:

Timer value:

value of timer: value < to the timer value of command 1.2.3

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 00

A4 01 02 A5 03 xx xx xx

Expected Sequence 1.3 (TIMER MANAGEMENT, start timer 8 several times, get the current value of the timer and deactivate the timer successfully)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 1.3.1	
2	$ME \to SIM$	FETCH	
3		PROACTIVE COMMAND:	[start timer 8]
		TIMER MANAGEMENT 1.3.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.3.1	
5	$SIM \to ME$	PROACTIVE COMMAND	After 1 minute following reception of Terminal
		PENDING: TIMER	Response
		MANAGEMENT 1.3.2	
6	$ME \rightarrow SIM$	FETCH	
7		PROACTIVE COMMAND:	[ask value of timer 8]
		TIMER MANAGEMENT 1.3.2	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
	0114 145	MANAGEMENT 1.3.2	Defens times a sumined
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	Before timer expires!
		PENDING: TIMER MANAGEMENT 1.3.3	
10	$ME \rightarrow SIM$	FETCH	
11	IVIE -> SIIVI	PROACTIVE COMMAND:	[reinitialise timer 8]
''		TIMER MANAGEMENT 1.3.3	[reminalise timer of
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
12	IVIL -> SIIVI	MANAGEMENT 1.3.3	[continand performed successfully]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	After 30 seconds following reception of
10	OIIVI 7 IVIL	PENDING: TIMER	Terminal Response
		MANAGEMENT 1.3.4	Tommia. Hoopenso
14	$ME \rightarrow SIM$	FETCH	
15	, , , , , , , , , , , , , , , , , , , ,	PROACTIVE COMMAND:	[deactivate timer 8]
		TIMER MANAGEMENT 1.3.4	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 1.3.4	-

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.1

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 8

Timer value:

Value of timer: 20min

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 08 A5 03 00 02 00

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 08

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

8

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer:

Timer value:

Value of timer: 01h 00min 00sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 08 A5 03 10 00 00

PROACTIVE COMMAND: TIMER MANAGEMENT 1.3.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 08

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.1 and 1.3.3

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 08

TERMINAL RESPONSE: TIMER MANAGEMENT 1.3.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 8

Timer value:

value of timer: value < to the timer value of command 1.3.1

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 00

A4 01 08 A5 03 xx xx xx

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 8

Timer value:

value of timer: value < to the timer value of command 1.3.3

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 00

A4 01 08 A5 03 xx xx xx

Expected Sequence1.4 (TIMER MANAGEMENT, try to get the current value of a timer which is not started: action in contradiction with the current timer state)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER MANAGEMENT 1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3		PROACTIVE COMMAND:	[get current value from timer 1]
		TIMER MANAGEMENT 1.4.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.1	[action in contradiction with the current timer state]
5	$SIM \rightarrow ME$	PROACTIVE COMMAND	State
	· · · · · · · · · · · · · · · · · · ·	PENDING: TIMER	
		MANAGEMENT 1.4.2	
6 7	$ME \rightarrow SIM$	FETCH PROACTIVE COMMAND:	[get current value from timer 2]
'		TIMER MANAGEMENT 1.4.2	[get current value from timer 2]
8	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
	0114 145	MANAGEMENT 1.4.2	state]
9	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.4.3	
10	$ME \to SIM$	FETCH	
11		PROACTIVE COMMAND:	[get current value from timer 3]
12	$ME \rightarrow SIM$	TIMER MANAGEMENT 1.4.3 TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
12	IVIL → SIIVI	MANAGEMENT 1.4.3	state]
13	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
14	$ME \rightarrow SIM$	MANAGEMENT 1.4.4 FETCH	
15	IVIL 7 OIIVI	PROACTIVE COMMAND:	[get current value from timer 4]
		TIMER MANAGEMENT 1.4.4	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
13	$SIM \to ME$	MANAGEMENT 1.4.4 PROACTIVE COMMAND	state]
	OIM / ME	PENDING: TIMER	
		MANAGEMENT 1.4.5	
14 15	$ME \rightarrow SIM$	FETCH PROACTIVE COMMAND:	[get current value from timer 5]
13		TIMER MANAGEMENT 1.4.5	[get current value from timer 5]
16	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
12	CINA . NAT	MANAGEMENT 1.4.5	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.4.6	
14	$ME \to SIM$	FETCH	
15		PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.6	[get current value from timer 6]
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.4.6	state]
13	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER MANAGEMENT 1.4.7	
14	$ME \to SIM$	FETCH	
15		PROACTIVE COMMAND:	[get current value from timer 7]
46	ME OIM	TIMER MANAGEMENT 1.4.7	Loction in controdiction with the surrent times
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.7	[action in contradiction with the current timer state]
13	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
14	ME CIM	MANAGEMENT 1.4.8 FETCH	
15	$ME \rightarrow SIM$	PROACTIVE COMMAND:	[get current value from timer 8]
		TIMER MANAGEMENT 1.4.8	[3-1 38.13.11 18.13 11011 18.1101 0]
16	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.4.8	state]

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 01

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 01

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 02

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 02

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.3

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 3

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 03

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.3

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 3

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 03

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.4

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 4

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 04

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 4

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 04

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.5

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 5

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 05

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 5

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 05

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.6

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 6

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 06

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 6

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 06

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.7

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 7

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 07

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 7

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 07

PROACTIVE COMMAND: TIMER MANAGEMENT 1.4.8

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT
Command qualifier: get the current value of the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: D0 0C 81 03 01 27 10 82 02 81 82 A4

01 08

TERMINAL RESPONSE: TIMER MANAGEMENT 1.4.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: get current value from the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: 81 03 01 27 10 82 02 82 81 83 01 24

A4 01 08

.

Expected Sequence1.5 (TIMER MANAGEMENT, try to deactivate a timer which is not started: action in contradiction with the current timer state)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
2	ME CIM	MANAGEMENT 1.5.1 FETCH	
2 3	$ME \rightarrow SIM$	PROACTIVE COMMAND:	[deactivate timer 1]
3		TIMER MANAGEMENT 1.5.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.1	state]
5	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
6	ME o SIM	MANAGEMENT 1.5.2 FETCH	
6 7	IVIL -> SIIVI	PROACTIVE COMMAND:	[deactivate timer 2]
		TIMER MANAGEMENT 1.5.2	[[4040417410 4111101 2]
8	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.2	state]
9	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER MANAGEMENT 1.5.3	
10	$ME \to SIM$	FETCH	
11	, , , , , , , , , , , , , , , , , , , ,	PROACTIVE COMMAND:	[deactivate timer 3]
		TIMER MANAGEMENT 1.5.3	-
12	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
40	OINA NAT	MANAGEMENT 1.5.3	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.5.4	
14	$ME \to SIM$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 4]
		TIMER MANAGEMENT 1.5.4	
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.4	[action in contradiction with the current timer state]
13	$SIM \to ME$	PROACTIVE COMMAND	State
		PENDING: TIMER	
		MANAGEMENT 1.5.5	
14	$ME \rightarrow SIM$	FETCH	
15		PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.5	[deactivate timer 5]
16	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
	IVIL 7 OIIVI	MANAGEMENT 1.5.5	state]
13	$SIM \to ME$	PROACTIVE COMMAND	-
		PENDING: TIMER	
1.4	NAT OINA	MANAGEMENT 1.5.6 FETCH	
14 15	$ME \rightarrow SIM$	PROACTIVE COMMAND:	[deactivate timer 6]
10		TIMER MANAGEMENT 1.5.6	
16	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.6	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: TIMER MANAGEMENT 1.5.7	
14	$ME \rightarrow SIM$	FETCH	
15	/ 51111	PROACTIVE COMMAND:	[deactivate timer 7]
		TIMER MANAGEMENT 1.5.7	-
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
13	CINA . NAT	MANAGEMENT 1.5.7	state]
13	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: TIMER	
		MANAGEMENT 1.5.8	
14	$\text{ME} \to \text{SIM}$	FETCH	
15		PROACTIVE COMMAND:	[deactivate timer 8]
40	NAT 0	TIMER MANAGEMENT 1.5.8	Faction in another distinct with the con-
16	$ME \rightarrow SIM$	TERMINAL RESPONSE: TIMER	[action in contradiction with the current timer
		MANAGEMENT 1.5.8	state]

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 01

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.1

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 01

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.2

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT
Command qualifier: deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 02

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 02

PROACTIVE COMMAND3: TIMER MANAGEMENT 1.5.3

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 3

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 03

427

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 3

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 03

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.4

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 4

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 04

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 4

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 04

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.5

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 5

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 05

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.5

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

1

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 5

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 05

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.6

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 6

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 06

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.6

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 6

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 06

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 7

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 07

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.7

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 7

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 07

PROACTIVE COMMAND: TIMER MANAGEMENT 1.5.8

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT Command qualifier: deactivate the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: D0 0C 81 03 01 27 01 82 02 81 82 A4

01 08

TERMINAL RESPONSE: TIMER MANAGEMENT 1.5.8

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: Deactivate Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Action in contradiction with the current timer state

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: 81 03 01 27 01 82 02 82 81 83 01 24

A4 01 08

Expected Sequence 1.6 (TIMER MANAGEMENT, start 8 timers successfully)

SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.1 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.1 Eimer 1] Eimer 2] Eimer 3] Eimer 3] Eimer 4] Eimer 4] Eimer 4] Eimer 4] Eimer 4] Eimer 5] Eimer 6] Eimer 6] Eimer 7] Eimer 7] Eimer 6] Eimer 7] Eimer 7] Eimer 7] Eimer 7] Eimer 8] Eimer 8] Eimer 8] Eimer 9] Eimer 8] Eimer 9]	Step	Direction	MESSAGE / Action	Comments
MANAGEMENT 1.6.1 ME → SIM	1	$SIM \to ME$		
ME → SIM				
PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.1 Immer 1]	2	ME → SIM		
TIMER MANAGEMENT 1.6.1 ME → SIM → ME RANAGEMENT 1.6.1 SIM → ME SIM → ME ME → SIM ME → SIM		IVIL → SIIVI	_	[timer 1]
MANAGEMENT 1.6.1 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.2 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.2 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT				[
SIM → ME SIM FENDING: TIMER MANAGEMENT 1.6.2 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 FETCH MANAGEMENT 1.6.2 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.3 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RES	4	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
PENDING: TIMER MANAGEMENT 1.6.2 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.3 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 ITERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.3 ITERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.3 ITERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.4 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 ITERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.4 ITERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.4 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 ITERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.5 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 TERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERRIMAL RESPONSE: TIMER MANAGEMENT 1.6.				
MB → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 ME → SIM ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.2 ME → SIM ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 ME → SIM ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 ME → SIM PROACTIVE COMMAND PROACTI	5	$SIM \rightarrow ME$		
FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 TETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER M			_	
PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.2 TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINA	6	$MF \rightarrow SIM$		
TIMER MANAGEMENT 1.6.2 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8		WE / 01W		[timer 2]
SIM → ME			TIMER MANAGEMENT 1.6.2	
SIM → ME	8	$ME \to SIM$		[command performed successfully]
PENDING: TIMER MANAGEMENT 1.6.3 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 PENDING: TIMER MANAGEMENT 1.6.4 PETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.4 PETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 PETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 IB ME → SIM PETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TEMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TEMETOH TIMER MANAGEMENT 1		0114 145		
MANAGEMENT 1.6.3 FETCH FROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERCH ME → SIM ME	9	$SIM \rightarrow ME$		
10 ME → SIM PETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 TETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 TETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.8 TE			1	
TIMER MANAGEMENT 1.6.3 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8	10	$ME \to SIM$		
12	11			[timer 3]
MANAGEMENT 1.6.3 MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE				
13 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RE	12	$ME \rightarrow SIM$		[command performed successfully]
PENDING: TIMER MANAGEMENT 1.6.4 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE:	13	SIM ME		
14				
15			MANAGEMENT 1.6.4	
TIMER MANAGEMENT 1.6.4 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.7 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL		$ME \to SIM$		
16 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4 17 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 18 ME → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 20 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 21 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 22 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 23 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 24 ME → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 25 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 26 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7 27 TIMER MANAGEMENT 1.6.7 28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 29 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 29 SIM → ME → SIM FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 31 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 33 ME → SIM TERMINAL RESPONSE: TIMER [timer 8]	15			[timer 4]
MANAGEMENT 1.6.4 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 18 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 20 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 21 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 22 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 24 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 25 SIM → ME PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 26 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 27 TIMER MANAGEMENT 1.6.6 28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 10 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND TIMER MANAGEMENT 1.6.6 11 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 12 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER TIMER MANAGEMENT 1.6.8	16	ME SIM	_	[command portormed successfully]
17 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.5 18 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 20 ME → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 21 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 22 ME → SIM PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 23 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 24 ME → SIM PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 25 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 26 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 28 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 29 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 31 ME → SIM TIMER MANAGEMENT 1.6.8 32 ME → SIM TIMER MANAGEMENT 1.6.8 33 ME → SIM TIMER MANAGEMENT 1.6.8 34 ME → SIM TIMER MANAGEMENT 1.6.8 35 ME → SIM TIMER MANAGEMENT 1.6.8 36 ME → SIM TIMER MANAGEMENT 1.6.8 37 ME → SIM TIMER MANAGEMENT 1.6.8 38 ME → SIM TIMER MANAGEMENT 1.6.8 39 ME → SIM TIMER MANAGEMENT 1.6.8 30 ME → SIM TIMER MANAGEMENT 1.6.8 31 ME → SIM TIMER MANAGEMENT 1.6.8 32 ME → SIM TIMER MANAGEMENT 1.6.8 33 ME → SIM TIMER MANAGEMENT 1.6.8 34 ME → SIM TIMER MANAGEMENT 1.6.8 35 ME → SIM TIMER MANAGEMENT 1.6.8 36 ME → SIM TIMER MANAGEMENT 1.6.8 37 ME → SIM TIMER MANAGEMENT 1.6.8 38 ME → SIM TIMER MANAGEMENT 1.6.8 39 ME → SIM TIMER MANAGEMENT 1.6.8	10	IVIE -> SIIVI		[confinant performed successibility]
18 ME → SIM	17	$SIM \to ME$		
18 ME → SIM				
19 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TEMPINAL R	40	NAT 01114		
TIMER MANAGEMENT 1.6.5 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8		$ME \rightarrow SIM$		[timor 5]
20 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TETCH PROACTI	13			[timer 5]
21 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.6 22 ME → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 24 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 25 SIM → ME MENDING: TIMER MANAGEMENT 1.6.7 26 ME → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 27 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 28 ME → SIM PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7 29 SIM → ME MANAGEMENT 1.6.7 29 SIM → ME MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 31 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [timer 8]	20	$ME \to SIM$		[command performed successfully]
PENDING: TIMER MANAGEMENT 1.6.6 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TIMER MANAGEMENT 1.6.8 TIMER MANAGEMENT 1.6.8 TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER [command performed successfully]				
22 ME → SIM MANAGEMENT 1.6.6 23 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 24 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 25 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 26 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 29 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 [timer 6] [timer 6] [command performed successfully]	21	$SIM \rightarrow ME$		
22 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER TIMER MANAGEMENT 1.6.8				
23	22	$MF \rightarrow SIM$		
TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND: MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER ME → SIM TERMINAL RESPONSE: TIMER TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER		.v / 0		[timer 6]
SIM → ME MANAGEMENT 1.6.6 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 SIM → ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8 TERMINAL RESPONSE: TIMER [timer 8]			TIMER MANAGEMENT 1.6.6	
25 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.7 26 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 31 ME → SIM TERMINAL RESPONSE: TIMER 32 ME → SIM TERMINAL RESPONSE: TIMER [timer 8]	24	$ME \rightarrow SIM$		[command performed successfully]
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	25	SIM ME		
26 ME → SIM FETCH 27 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 31 FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [timer 7] [timer 7] [timer 7] [timer 7] [timer 8]	20			
27 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6 28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 [timer 7] [timer 7]			_	
TIMER MANAGEMENT 1.6.6 TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 ME → SIM ME → SIM ME → SIM ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully] [timer 8] Timer MANAGEMENT 1.6.8 TIMER MANAGEMENT 1.6.8 TIMER MANAGEMENT 1.6.8 TIMER MANAGEMENT 1.6.8 [command performed successfully]		$ME \to SIM$		
28 ME → SIM TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7 29 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]	27			[timer 7]
29 SIM → ME MANAGEMENT 1.6.7 PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH 31 PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]	28	ME SIM		[command performed successfully]
29 SIM → ME PROACTIVE COMMAND PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]	20	IVIE -> SIIVI		[command performed successfully]
PENDING: TIMER MANAGEMENT 1.6.8 30 ME → SIM FETCH PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]	29	$SIM \to ME$		
30 ME → SIM FETCH 31 PROACTIVE COMMAND: [timer 8] 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]		•		
31 PROACTIVE COMMAND: [timer 8] TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]				
TIMER MANAGEMENT 1.6.8 32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]		$ME \rightarrow SIM$		[timer 9]
32 ME → SIM TERMINAL RESPONSE: TIMER [command performed successfully]	31			[uner o]
	32	$ME \rightarrow SIM$		[command performed successfully]

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Timer value:

Value of timer: 5 sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 01

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.2

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 2

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 02 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.2

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 2

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 02

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.3

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 3

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 03 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.3

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 3

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 03

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.4

435

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 4

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 04 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.4

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

4

Timer identifier:

Identifier of timer:

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 04

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.5

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 5

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 05 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.5

Logically:

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 5

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 05

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.6

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 6

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 06 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.6

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 6

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 06

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.7

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 7

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 07 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.7

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 7

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 07

PROACTIVE COMMAND: TIMER MANAGEMENT 1.6.8

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 8

Timer value:

Value of timer: 5sec

Coding:

BER-TLV: D0 11 81 03 01 27 00 82 02 81 82 A4

01 08 A5 03 00 00 50

TERMINAL RESPONSE: TIMER MANAGEMENT 1.6.8

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 8

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 08

27.22.4.21.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences

27.22.4.21.2 ENVELOPE TIMER EXPIRATION (normal)

27.22.4.21.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.21.2.2 Conformance requirement

The ME shall support the ENVELOPE (TIMER EXPIRATION) command as defined in the following technical specifications:

3GPP TS 11.14 clause 4.10, 10.1 and 10.2.

The ME shall support the TIMER MANAGEMENT as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.21 (Timer Management), clause 6.8 (Terminal Response), clause 12.6 (Commands details), clause 12.7 (Device Identities), clause 12.37 (Timer Identifier), clause 12.38 (Timer Value).

27.22.4.21.2.3 Test Purpose

To verify that the ME shall pass the identifier of the timer that has expired and its value using the ENVELOPE (TIMER EXPIRATION) command, when a timer previously started in a TIMER MANAGEMENT proactive command expires.

27.22.4.21.2.4 Method of test

27.22.4.21.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The timer 1 is not started.

When the SIM is busy when the envelope TIMER EXPIRATION is sent, either the ME retries periodically to send the envelope, either it waits for a TERMINAL RESPONSE processed by the SIM with status '90 00'.

If the ME waits for a TR with status '90 00', the ME manufacturer shall specify how many TERMINAL RESPONSES with status '90 00' are expected before sending the TIMER EXPIRATION envelope.

27.22.4.21.2.4.2 Procedure

Expected Sequence 2.1 (TIMER EXPIRATION, pending proactive SIM command)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: TIMER	
		MANAGEMENT 2.1.1	
2	$ME \to SIM$	FETCH	
3		PROACTIVE COMMAND: TIMER	[timer 1]
		MANAGEMENT 2.1.1	
4	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 2.1.1	
5	$ME \to SIM$	ENVELOPE: TIMER EXPIRATION	
		2.1.1	
6	$SIM \to ME$	PROACTIVE COMMAND	[response to envelope is "91 xx"]
		PENDING: MORE TIME X.1(or an	
		other SAT command tested before	
		to ensure it is properly supported	
		by the mobile).	
7	$ME \rightarrow SIM$	FETCH	

PROACTIVE COMMAND: TIMER MANAGEMENT 2.1.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer: 1

Timer value:

Value of timer: 0h 0min 10sec

Coding:

BER-TLV: 03 82 02 81 82 D0 11 81 01 27 00 A4 01 01 Α5 03 00 00 01

TERMINAL RESPONSE: TIMER MANAGEMENT 2.1.1

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 01

ENVELOPE: TIMER EXPIRATION 2.1.1

Logically:

Device identities

Source device: ME
Destination device: SIM
Timer identifier: Timer 1

Timer value

Hour: '00' Minute: '00'

Second: '10' +/- 1 sec

Coding:

BER-TLV: D7 0C 82 02 82 81 A4 01 01 A5 03 00

00 xx

Expected Sequence 2.2A (TIMER EXPIRATION, SIM application toolkit busy)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$		
		PENDING: TIMER	
		MANAGEMENT 2.2.1	
2	$ME \to SIM$	FETCH	
3		PROACTIVE COMMAND: TIMER	[timer 1]
		MANAGEMENT 2.2.1	
4	$ME \to SIM$	TERMINAL RESPONSE: TIMER	[command performed successfully]
		MANAGEMENT 2.2.1	
5	$ME \to SIM$	ENVELOPE: TIMER EXPIRATION	
		2.2.1A	
6	$SIM \to ME$	PROACTIVE SIM SESSION	[SIM is busy; response to the envelope = "93
		BUSY	00"]
			[SIM is busy during 10 seconds, the ME
			retries the sending of the envelope until it is
			accepted]
7	$\text{ME} \to \text{SIM}$	ENVELOPE: TIMER EXPIRATION	
		2.2.1B	
8	$SIM \to ME$	PROACTIVE SIM SESSION	[SIM is busy, response to the envelope = "93
		BUSY	00"]
9	$ME \rightarrow SIM$	ENVELOPE: TIMER EXPIRATION	
		2.2.1C	
10	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	[SIM is not busy]
		ENDED	

Or:

Expected Sequence 2.2B (TIMER EXPIRATION, SIM application toolkit busy)

Direction	MESSAGE / Action	Comments
$SIM \to ME$		
	MANAGEMENT 2.2.1	
$ME \rightarrow SIM$		
	MANAGEMENT 2.2.1	[timer 1]
	MANAGEMENT 2.2.1	[command performed successfully]
	2.2.1A	
$SIM \to ME$	RESPONSE TO THE ENVELOPE	[SIM is busy; response to the envelope = "93 00"] [SIM is busy during 10 sec, the ME may retry to send the envelope. After one (or several) answer(s) 93 00, the ME waits for a TERMINAL RESPONSE processed by the SIM with status "90 00"]
$MF \rightarrow SIM$	STATUS	[SIM is not busy]
		[SW1/SW2=91 xx]
$ME \to SIM$		
$SIM \to ME$	PROACTIVE COMMAND: e.g.	
$ME \to SIM$		[command performed successfully]
$SIM \to ME$		[SW1/SW2 = 90 00] Steps 7->12 shall be repeated (X-1) times if the ME manufacturers specifies that the ME waits for X TERMINAL RESPONSES with status 90 00 to send the TIMER EXPIRATION envelope.
$ME \to SIM$		
	PROACTIVE SIM SESSION ENDED	
	$\begin{array}{c} \text{ME} \rightarrow \text{SIM} \\ \\ \text{ME} \rightarrow \text{SIM} \\ \\ \text{ME} \rightarrow \text{SIM} \\ \\ \text{SIM} \rightarrow \text{ME} \\ \\ \\ \text{ME} \rightarrow \text{SIM} \\ \\ \\ \text{SIM} \rightarrow \text{ME} \\ \\ \\ \\ \text{ME} \rightarrow \text{SIM} \\ \\ \\ \\ \text{SIM} \rightarrow \text{ME} \\ \\ \\ \\ \\ \\ \text{ME} \rightarrow \text{SIM} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$	$\begin{array}{c} \text{PENDING: TIMER} \\ \text{MANAGEMENT 2.2.1} \\ \hline \text{ME} \rightarrow \text{SIM} & \text{FETCH} \\ \hline \text{PROACTIVE COMMAND: TIMER} \\ \text{MANAGEMENT 2.2.1} \\ \hline \text{ME} \rightarrow \text{SIM} & \text{TERMINAL RESPONSE: TIMER} \\ \text{MANAGEMENT 2.2.1} \\ \hline \text{ME} \rightarrow \text{SIM} & \text{ENVELOPE: TIMER EXPIRATION} \\ \text{2.2.1A} \\ \text{SIM} \rightarrow \text{ME} & \text{RESPONSE TO THE ENVELOPE} \\ \hline \\ \text{ME} \rightarrow \text{SIM} & \text{SRESPONSE TO THE ENVELOPE} \\ \hline \\ \text{ME} \rightarrow \text{SIM} & \text{PROACTIVE COMMAND} \\ \text{PENDING} & \text{FETCH} \\ \text{PROACTIVE COMMAND: e.g.} \\ \hline \text{MORE TIME 2.2.2} \\ \hline \text{TERMINAL RESPONSE: e.g.} \\ \hline \text{TIMER MANAGEMENT 2.2.2} \\ \hline \\ \text{SIM} \rightarrow \text{ME} \\ \hline \\ \text{ME} \rightarrow \text{SIM} & \text{ENVELOPE: TIMER EXPIRATION} \\ \hline \text{2.2.1B} \\ \hline \text{PROACTIVE SIM SESSION} \\ \hline \end{array}$

PROACTIVE COMMAND: TIMER MANAGEMENT 2.2.1

Command details

Command number: 1

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: SIM
Destination device: ME

Timer identifier:

Identifier of timer:

Timer value:

Value of timer: 0h 0min 30sec

Coding:

BER-TLV: 82 81 D0 11 81 03 01 27 00 02 82 A4 01 01 A5 03 00 00 03

TERMINAL RESPONSE: TIMER MANAGEMENT 2.2.1

Logically:

Command details

Command number:

Command type: TIMER MANAGEMENT

Command qualifier: start the Timer

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Timer identifier:

Identifier of timer: 1

Coding:

BER-TLV: 81 03 01 27 00 82 02 82 81 83 01 00

A4 01 01

ENVELOPE: TIMER EXPIRATION 2.2.1A

Logically:

Device identities

Source device: ME
Destination device: SIM
Timer identifier: Timer 1

Timer value

Hour: '00' Minute: '00'

Second: '30' +/- 1 sec

Coding:

BER-TLV: D7 0C 82 02 82 81 A4 01 01 A5 03 00

00 xx

ENVELOPE: TIMER EXPIRATION 2.2.1B

Logically:

Device identities

Source device: ME
Destination device: SIM
Timer identifier: Timer 1

Timer value

Hour: '00' Minute: '00'

Second: >= timer in 2.2.1A

Coding:

BER-TLV: D7 0C 82 02 82 81 A4 01 01 A5 03 00

00 xx

ENVELOPE: TIMER EXPIRATION 2.2.1C

Logically:

Device identities

Source device: ME
Destination device: SIM
Timer identifier: Timer 1

Timer value

Hour: '00' Minute: '00'

Second: >= timer in 2.2.1B

Coding:

BER-TLV: D7 0C 82 02 82 81 A4 01 01 A5 03 00

00 xx

PROACTIVE COMMAND: MORE TIME 2.2.2

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 02 00 82 02 81 82

TERMINAL RESPONSE: MORE TIME 2.2.2

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 02 00 82 02 82 81 83 01 00

27.22.4.21.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 and 2.

27.22.4.22 SET UP IDLE MODE TEXT

27.22.4.22.1 SET UP IDLE MODE TEXT (normal)

27.22.4.22.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.22.1.2 Conformance requirement

3GPP TS 11.14 [15] clause 4.7, 5.2 (Terminal Profile), 6.4.22, 6.6.22, 6.4.16, 6.6.16, 11.6, 6.8 (Terminal Response), 11, 11.1, 12.25, 6.4.7, 6.6.13

Additionally the ME shall support the REFRESH proactive SIM facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2, 6.1, 6.4.7, 6.6.13, 6.11, 12.6, 12.12, 13.4 and 14.

27.22.4.22.1.3 Test Purpose

To verify that the text passed to the ME is displayed as idle mode text.

27.22.4.22.1.4 Method of test

27.22.4.22.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The following events shall have been set up in the ME.

Event List

Logically:

Event 1: Idle screen available

•

27.22.4.22.1.4.2 Procedure

Expected Sequence 1.1 (SET UP IDLE MODE TEXT, display idle mode text)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST	With the event Idle Screen available
		1.1.1	
2	$ME \to SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.1.1	[Command performed successfully]
3	USER →		
	ME	mode. Select idle screen	
4	$ME \to SIM$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN	
5	SIM VME	AVAILABLE 1.1.1 PROACTIVE COMMAND	[Idle Mode Text]
	SIIVI → IVIE	PENDING: SET UP IDLE MODE	[late wode Text]
		TEXT 1.1.2	
6	$ME \rightarrow SIM$		
7	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET UP IDLE MODE TEXT 1.1.2	
8	$ME \to$	Display "Idle Mode Text"	
	USER		
9	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.1.2	[Command performed successfully]
10	$SIM \to ME$		
		ENDED	

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Idle screen available

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01 05

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 1.1.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 1.1.2

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

1

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: unpacked, 8 bit data Text: "Idle Mode Text"

BER-TLV: D0 81 03 01 28 00 81 8D 1A 82 02 82 0F 04 49 64 6C 65 20 4D 6F 64 65 20

56 65 78 74

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.1.2

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 1.2 (SET UP IDLE MODE TEXT, replace idle mode text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.1.1	With the event Idle Screen available
2	$ME \to SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.1.1	[Command performed successfully]
3	$\begin{array}{c} USER \to \\ ME \end{array}$	Wait for the mobile returns to idle mode. Select idle screen	
4	$ME \to SIM$	ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 1.1.1	
5	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP IDLE MODE TEXT 1.1.2	
6	$ME \to SIM$	FETCH	
7	$SIM \to ME$	PROACTIVE COMMAND : SET UP IDLE MODE TEXT 1.1.2	[Idle Mode Text]
8	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Idle Mode Text"	
9	$ME \to SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.1.2	
10	$SIM \to ME$	PENDING: SET UP IDLE MODE TEXT 1.2.1	[Idle Mode Text]
11	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Toolkit Test"	
12	$ME \to SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.2.1	
13	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: SETUP IDLE MODE TEXT 1.2.1

Command details

Command number: 1

Command type: SETUP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data
Text: "Toolkit Test"

Coding:

BER-TLV: D0 18 81 03 01 02 8D 28 00 82 81 82 0D 04 54 6F 6F 6C 74 20 54 65

73 74

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.2.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 1.3 (SET UP IDLE MODE TEXT, remove idle mode text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.1.1	With the event Idle Screen available
2	$ME \to SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.1.1	[Command performed successfully]
3	$\begin{array}{c} USER \to \\ ME \end{array}$	Wait for the user returns to idle mode. Select idle screen	
4	$ME \to SIM$	ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 1.1.1	
5	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP IDLE MODE TEXT 1.1.2	
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \to ME$	PROACTIVE COMMAND : SET UP IDLE MODE TEXT 1.1.2	["Idle Mode Text"]
8	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Idle Mode Text"	
9	$ME \to SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.1.2	
10	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP IDLE MODE TEXT 1.3.1	
11	$ME \rightarrow SIM$	FETCH	
12	$SIM \to ME$	PROACTIVE COMMAND : SET UP IDLE MODE TEXT 1.3.1	[Remove idle mode text]
13	$\begin{array}{c} ME \to \\ USER \end{array}$	Display idle screen / "Idle Mode Text" not to be displayed	
14	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.3.1	
15	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: SETUP IDLE MODE TEXT 1.3.1

Logically:

Command details

Command number: 1

Command type: SETUP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text String: zero length TLV

Coding:

BER-TLV: D0 0B 81 03 01 28 00 82 02 81 82 8D 00

TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.3.1Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

1

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 1.4 (SET UP IDLE MODE TEXT, competing information on ME display)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	With the event Idle Screen available
		PENDING: SET UP EVENT LIST	
		1.1.1	
2	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	[Command performed successfully]
		EVENT LIST 1.1.1	
3	USER →	Wait for the mobile returns to idle	
	ME	mode. Select idle screen	
4	ME → SIM	ENVELOPE: EVENT	
-	IVIL -> OIIVI	DOWNLOAD IDLE SCREEN	
		AVAILABLE 1.1.2	
5	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SET UP IDLE MODE	
		TEXT 1.1/2	
6	$ME \rightarrow SIM$		
7	$SIM \rightarrow ME$		["Idle Mode Text"]
		UP IDLE MODE TEXT 1.1.2	
8	ME o USER	Display "Idle Mode Text"	
9	USER ME → SIM	TERMINAL RESPONSE : SET UP	[Command performed successfully]
9		IDLE MODE TEXT 1.12	
		I DEE MODE TEXT 1.12	
10	$SS \rightarrow ME$	SMS PP 1.4.1	[Display immediate SMS]
11	ME o	Display "Short Message"	
	USER		
12	$USER \to$	Clear display and select idle	
	ME	screen	
13	ME o	Display "Idle Mode Text"	
	USER		

SMS-PP 1.4.1

SMS TPDU TP-MTI **SMS-SUBMIT** TP-RD Instruct the SC to accept an SMS-SUBMIT for a SM TP-VPF TP-VP field not present TP-Reply-Path is not set in this SMS-SUBMIT TP-RP The TP-UD field contains only the short message TP-UDHI TP-SRR A status report is not requested "00" TP-MR TP-DA TON International number NPI "ISDN / telephone numbering plan" Address value "012345678" TP-PID Short message type 0 TP-DCS Message coding 8-bit data class 0 Message class TP-UDL 12 "Test Message" TP-UD Coding: 01 00 91 10 54 76 F8 40 F4 0C

Expected Sequence 1.5 (SET UP IDLE MODE TEXT, ME power cycled)

65

73

74

20

4D

65

73

73

61

67

65

54

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$		With the event Idle Screen available
		PENDING: SET UP EVENT LIST 1.1.1	
2	$ME \rightarrow SIM$		[Command performed successfully]
_	IVIL -> OIIVI	EVENT LIST 1.1.1	[command performed edecestrally]
3	$USER \to$	Wait for the mobile returns into	
3	USER → ME	idle mode.	
		Select idle screen	
4	$\text{ME} \to \text{SIM}$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN AVAILABLE 1.1.1	
5	$SIM \rightarrow MF$	PROACTIVE COMMAND	
	0 / <u></u>	PENDING: SET UP IDLE MODE	
		TEXT 1.1.2	
6 7	$ME \rightarrow SIM$ $SIM \rightarrow ME$		["Idle Mode Text"]
'	SIIVI → IVIE	UP IDLE MODE TEXT 1.1.2	[Idle Mode Text]
8	ME o	Display "Idle Mode Text"	
	USER		
9	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.1.2	[command performed successfully]
		IDLE MODE TEXT 1.1.2	
10	$USER \to$	Power off ME	
	ME		
11	$ME \Leftrightarrow SIM$	GSM TERMINATION PROCEDURE	
		FROCEDURE	
12	$USER \to$	Power on ME	
	ME		
13		GSM ACTIVATION PROCEDURE	
14	$ME \Leftrightarrow SIM$	SIM INITIALISATION	
14	ME o	Display idle screen / "Idle Mode	
	USER	Text" not to be displayed	

Expected Sequence 1.6 (SET UP IDLE MODE TEXT, REFRESH with SIM Initialisation)

Step	Direction	MESSAGE / Action	Comments			
1	$SIM \rightarrow ME$		With the event Idle Screen available			
	· · · · · · · · · · · · · · · · · · ·	PENDING: SET UP EVENT LIST				
		1.1.1				
2	$ME \to SIM$		[Command performed successfully]			
		EVENT LIST 1.1.1				
3	$USER \to$	Wait for the mobile returns to idle				
	ME	mode.				
4	ME CIM	Select idle screen	ı			
4	ME → SIM	ENVELOPE: EVENT DOWNLOAD IDLE SCREEN				
		AVAILABLE 1.1.1				
5	$SIM \rightarrow ME$		[Idle Mode Text]			
	O 7	PENDING: SET UP IDLE MODE	[care mean care]			
		TEXT 1.1.1				
6	$ME \to SIM$	FETCH				
7	$SIM \to ME$					
		UP IDLE MODE TEXT 1.1.2				
8	$ME \rightarrow$	Display "Idle Mode Text"				
	USER	TERMINAL DESPONSE SETUR				
9	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP IDLE MODE TEXT 1.1.2				
10	$SIM \rightarrow ME$					
	SIIVI → IVIL	PENDING: REFRESH 1.6.1				
11	$ME \rightarrow SIM$					
12	$SIM \rightarrow ME$		[SIM Initialisation]			
		REFRESH 1.6.1				
13	$ME \Leftrightarrow SIM$	SIM INITIALISATION				
14	ME →	Display idle screen / "Idle Mode				
15	USER	Text" not to be displayed	[Command performed augeografishs]			
15	$ME \rightarrow SIM$	TERMINAL RESPONSE : REFRESH 1.6.1	[Command performed successfully]			
		or				
		TERMINAL RESPONSE :	[Command performed successfully with			
		REFRESH 1.6.1	additional files read]			
16	$SIM \rightarrow ME$					
		ENDED				

PROACTIVE COMMAND: REFRESH 1.6.1

Logically:

Command details

Command number:

Command type: REFRESH
Command qualifier: SIM Initialisation

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 01 03 82 02 81 82

TERMINAL RESPONSE: REFRESH 1.61A

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialisation

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 00

TERMINAL RESPONSE: REFRESH 1.61B

Logically:

Command details

Command number: 1

Command type: REFRESH
Command qualifier: SIM Initialisation

Device identities

Source device: ME
Destination device: SIM

Result

General Result: REFRESH performed with additional EFs read

Coding:

BER-TLV: 81 03 01 01 03 82 02 82 81 83 01 03

Expected Sequence 1.7 (SET UP IDLE MODE TEXT, large text string)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST 1.1.1	With the event Idle Screen available
2	$ME \to SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.1.1	[Command performed successfully]
3	$\begin{array}{c} USER \to \\ ME \end{array}$	Wait for the mobile returns to idle mode.	
4	$ME \to SIM$	Select idle screen ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 1.1.1	
5	$SIM \to ME$		[large text string]
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \to ME$	PROACTIVE COMMAND : SET UP IDLE MODE TEXT 1.7.1	
8	ME → USER	Display "The SIM shall supply a text string, which shall be displayed by the ME as an idle mode text if the ME is able to do it. The presentation style is left as an implementation decision to the ME manufacturer. The idle mode text shall be displayed in a manner that ensures that"	
9	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	[command performed successfully]
10	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 1.7.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 1.7.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: packed, SMS default alphabet

Text: "The SIM shall supply a text string, which shall be displayed by the ME as

an idle mode text if the ME is able to do it. The presentation style is left as an implementation decision to the ME manufacturer. The idle mode text

shall be displayed in a manner that ensures that"

BER-TLV:	D0	81	FB	81	03	01	28	00	82	02	81	82
	8D	81	EF	00	54	74	19	34	4D	36	41	73
	74	98	CD	06	CD	EB	70	38	3B	0F	0A	83
	E8	65	3C	1D	34	A7	CB	D3	EE	33	0B	74
	47	A7	C7	68	D0	1C	1D	66	B3	41	E2	32
	88	9C	9E	C3	D9	E1	7C	99	0C	12	E7	01
	74	74	19	D4	2C	82	C2	73	50	D8	0D	4A
	93	D9	65	50	FB	4D	2E	83	E8	65	3C	1D
	94	36	83	E8	E8	32	A8	59	04	A5	E7	A0
	B0	98	5D	06	D1	DF	20	F2	1B	94	A6	BB
	40	54	74	19	04	97	03	E5	79	D9	4D	0F
	D3	D3	6F	37	68	4E	CF	В3	CB	A0	F4	1C
	C4	2E	9B	E9	A0	F0	1C	14	76	83	D2	6D
	38	BB	DC	2E	BB	E9	61	7A	FΑ	ED	06	91
	СВ	E3	F4	3C	FD	76	83	E8	6F	10	1D	5D
	06	35	8B	ED	B0	BB	6E	0E	8F	E9	75	79
	59	EE	02	51	D1	65	50	9A	CC	2E	83	DA
	6F	72	19	44	2F	E3	01	74	D0	1C	1D	66
	B3	41	E2	32	88	9C	9E	C3	D9	E1	7C	99
	0C	4A	BB	41	61	50	3B	EC	76	97	E5	74
	74	98	0E	2A	BB	E7	75	79	79	0E	A2	А3
	C3	74										

TERMINAL RESPONSE: SET UP IDLE MODE TEXT 1.7.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 1.8 (SET UP IDLE MODE TEXT, display idle mode text followed by a display text)

Step	Direction	Message / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	With the event Idle Screen available
		PENDING: SET UP EVENT LIST	
		1.1.1	
2	$ME \rightarrow SIM$		[Command performed successfully]
		EVENT LIST 1.1.1	
3	USER →	Wait for the mobile returns to idle	
	ME	mode. Select idle screen	
4	ME SUM	ENVELOPE: EVENT	
4	IVIE -> SIIVI	DOWNLOAD IDLE SCREEN	
		AVAILABLE 1.1.1	
5	$SIM \rightarrow MF$	PROACTIVE COMMAND	[Idle Mode Text]
	0	PENDING: SET UP IDLE MODE	[rate mede rem]
		TEXT 1.1.2	
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 1.1.2	
8	ME o	Display "Idle Mode Text"	
	USER		
9	$ME \rightarrow SIM$		[Command performed successfully]
10	0114 145	IDLE MODE TEXT 1.1.2	
10	SIM → ME	PROACTIVE COMMAND PENDING: DISPLAY TEXT 1.8.1	
11	$ME \rightarrow SIM$		
12	$SIM \rightarrow ME$		[Normal priority, wait for user to clear
12	SIIVI → IVIE	DISPLAY TEXT 1.8.1	message, unpacked, 8 bit data
13	ME o	Display " Toolkit Test 1"	inioodago, anpaokoa, o bit dataj
	USER	2.50.60	
14	USER →	Clear Message	
	ME	S .	
15	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		DISPLAY TEXT 1.8.1	
16	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
17	$ME \rightarrow$	Display "Idle Mode Text"	
	USER		

PROACTIVE COMMAND: DISPLAY TEXT 1.8.1

Logically:

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: SIM
Destination device: Display

Text String

Data coding scheme: unpacked, 8 bit data Text: "Toolkit Test 1"

Coding:

BER-TLV: 03 D0 1A 01 21 80 82 02 81 02 8D 81 0F 04 54 6F 6F 6C 6B 69 74 20 54 65

TERMINAL RESPONSE: DISPLAY TEXT 1.8.1

Command details

Command number:

Command type: DISPLAY TEXT

Command qualifier: normal priority, wait for user to clear message

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 21 80 82 02 82 81 83 01 00

Expected Sequence 1.9 (SET UP IDLE MODE TEXT, display idle mode text followed by a play tone command)

Step	Direction	Message / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SET UP EVENT LIST	With the event Idle Screen available
		1.1.1	
2	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP EVENT LIST 1.1.1	[Command performed successfully]
3	$USER \ \to \\$	Wait for the mobile returns to idle	
	ME	mode.	
4	ME ZIM	Select idle screen ENVELOPE: EVENT	
	IVIE -> SIIVI	DOWNLOAD IDLE SCREEN	
		AVAILABLE 1.1.1	
5	$SIM \to ME$	PROACTIVE COMMAND	[Idle Mode Text]
		PENDING: SET UP IDLE MODE TEXT 1.1.2	
6	$ME \rightarrow SIM$		
7		PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 1.1.2	
8	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Idle Mode Text"	
9		TERMINAL RESPONSE : SET UP	[Command performed successfully]
	, o	IDLE MODE TEXT 1.1.2	[[
10	$SIM \to ME$		
11	ME SOM	PENDING: PLAY TONE 1.9.1	
12	$ME \rightarrow SIM$ $SIM \rightarrow ME$		
'-	OIIVI -> IVIL	TONE 1.9.1	
13	ME o	Display "Dial Tone"	
	USER	Disconsistent and accompanies and discons	
		Play a standard supervisory dial tone through the external ringer for	
		a duration of 5 seconds	
14	$ME \to SIM$		[Command performed successfully]
4.5	OIM ME	TONE 1.9.1	
15	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	
16	ME o	Display "Idle Mode Text"	
	USER		

PROACTIVE COMMAND: PLAY TONE 1.9.1

Command details

Command number: 1

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Earpiece
Alpha identifier: "Dial Tone"

Tone: Standard supervisory tones: dial tone

Duration

Time unit: Seconds
Time interval: 5

Coding:

BER-TLV: D0 1B 03 20 02 81 03 81 01 00 82 85 44 6C 54 6F 6E 65 8E 01 09 69 61 20

01 84 02 01 05

TERMINAL RESPONSE: PLAY TONE 1.9.1

Logically:

Command details

Command number:

Command type: PLAY TONE

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 20 00 82 02 82 81 83 01 00

27.22.4.22.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1, 2, 3, 4, 5, 6 and 7.

27.22.4.22.2 SET UP IDLE MODE TEXT (Icon support)

27.22.4.22.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.22.2.2 Conformance requirement

27.22.4.22.2.3 Test Purpose

To verify that the ME text and / or icon passed to the ME is displayed by the ME as an idle mode text.

To verify that the icon identifier provided with the text string can replace the text string or accompany it.

To verify that if both an alpha identifier or text string, and an icon are provided with a proactive command, and both are requested to be displayed, but the ME is not able to display both together on the screen, then the alpha identifier or text string takes precedence over the icon.

To verify that if the SIM provides an icon identifier with a proactive command, then the ME shall inform the SIM if the icon could not be displayed by sending the general result "Command performed successfully, but requested icon could not be displayed".

To verify that if the ME receives an icon qualifier with bit 1 set to 0, meaning "an alpha identifier or text string related to the icon may be displayed together with the icon by the ME", and no alpha identifier / text string is given by the SIM, than the ME shall reject the command with general result "Command data not understood by ME".

27.22.4.22.2.4 Method of test

27.22.4.22.2.4.1 Initial Conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

EF IMG

```
Logically:

Record 1

<small icon>

Record 2

<tall icon (line)>
```

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The following events shall have been set up in the ME.

Event List

Logically:

Event 1: Idle screen available

27.22.4.22.2.4.2 Procedure

Expected Sequence 2.1A (SET UP IDLE MODE TEXT, Icon is self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	USER →	Select idle screen	
	ME		
2	$ME \rightarrow SIM$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN	
		AVAILABLE 2.1.1	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND	[Icon is self-explanatory]
		PENDING: SET UP IDLE MODE	·
		TEXT 2.1.1	
4	$ME \rightarrow SIM$	FETCH	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 2.1.1	
6	ME o	Display the icon	
	USER		
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	[command performed successfully]
		IDLE MODE TEXT 2.1.1A	
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 2.1.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text string: "Idle text"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

19 03 28 BER-TLV: D0 81 01 00 82 02 81 82 8D 49 6C 65 78 74 0F 04 64 65 56 9E 20

02 00 01

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.1.1A

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 2.1B (SET UP IDLE MODE TEXT, Icon is self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select idle screen	
	ME		
2	$ME \rightarrow SIM$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN AVAILABLE 2.1.1	
3	$SIM \rightarrow MF$		[Icon is self-explanatory]
	O 7	PENDING: SET UP IDLE MODE	[[]
		TEXT 2.1.1	
4	$\text{ME} \to \text{SIM}$	FETCH	
5	$SIM \to ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 2.1.1	
6	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Idle text" without the icon	
7	$ME \to SIM$	TERMINAL RESPONSE : SET UP	[Command performed successfully, but
		IDLE MODE TEXT 2.1.1B	requested icon could not be displayed]
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.1.1B

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 04

Expected Sequence 2.2A (SET UP IDLE MODE TEXT, Icon is not self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select idle screen	
	ME		
2	$ME \rightarrow SIM$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN	
		AVAILABLE 2.2.1	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND	[Icon is not self-explanatory]
		PENDING: SET UP IDLE MODE	
		TEXT 2.2.1	
4	$ME \rightarrow SIM$		
5	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 2.2.1	
6	ME o	Display icon #1 and "Idle text"	
	USER		
7	$ME \rightarrow SIM$		[command performed successfully]
		IDLE MODE TEXT 2.2.1A	
8	$SIM \rightarrow ME$		
		ENDED	

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 2.2.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.2.1Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text string: "Idle text"

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV: D0 19 81 03 01 28 00 82 02 81 82 8D 0F 04 49 64 6C 65 20 56 65 78 74 9E

02 01 01

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.2.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

Expected Sequence 2.2B (SET UP IDLE MODE TEXT, Icon is not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select idle screen	
	ME		
2	$ME \rightarrow SIM$	_	
		DOWNLOAD IDLE SCREEN	
	0114 145	AVAILABLE 2.2.1	floor is not salt sombonstond
3	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SET UP IDLE MODE	[Icon is not self-explanatory]
		TEXT 2.2.1	
4	$ME \rightarrow SIM$		
5	$SIM \rightarrow ME$		
		UP IDLE MODE TEXT 2.2.1	
6	ME o	Display "Idle text" without the icon	
	USER		
7	$ME \rightarrow SIM$		[Command performed successfully, but
		IDLE MODE TEXT 2.2.1B	requested icon could not be displayed]
8	CINA . ME	PROACTIVE SIM SESSION	
٥	$SIM \rightarrow ME$	ENDED	
		LINDLD	

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.2.1B

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 04

Expected Sequence 2.3 (SET UP IDLE MODE TEXT, Icon is self-explanatory, colour icon)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select idle screen	
	ME		
2	$ME \rightarrow SIM$		
		DOWNLOAD IDLE SCREEN	
		AVAILABLE 2.3.1	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND	[Icon is self-explanatory]
		PENDING: SET UP IDLE MODE	
		TEXT 2.3.1	
4	$ME \rightarrow SIM$	_	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 2.3.1	
	ME USER	-12	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	[command performed successfully]
		IDLE MODE TEXT 2.3.1	
			[requested icon could not be displayed]
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 2.3.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.3.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME
Text string: "Idle text"

Icon identifier

Icon qualifier: icon is self-explanatory
Icon identifier: <record 2 in EF IMG>

Coding:

BER-TLV: D0 19 81 03 01 28 00 82 02 81 82 8D 65 0F 04 49 64 6C 65 20 56 78 74 9E

02 00 02

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.3.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.3.2

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 04

Expected Sequence 2.4 (SET UP IDLE MODE TEXT, Icon is not self-explanatory, no text string)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select idle screen	
	ME		
2	$ME \rightarrow SIM$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN	
		AVAILABLE 2.4.1	
3	$SIM \rightarrow ME$		[Icon is not self-explanatory, no text string]
		PENDING: SET UP IDLE MODE	
		TEXT 2.4.1	
4	$ME \rightarrow SIM$	FETCH	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 2.4.1	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	
		IDLE MODE TEXT 2.4.1	
7	$SIM \rightarrow ME$		
		ENDED	

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 2.4.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 2.4.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Icon identifier

Icon qualifier: icon is not self-explanatory
Icon identifier: <record 1 in EF IMG>

Coding:

BER-TLV: D0 19 81 03 01 28 00 82 02 81 82 9E

02 01 01

TERMINAL RESPONSE: SET UP IDLE MODE LIST 2.4.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command data not understood by ME

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 32

27.22.4.22.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1, 2, 3 and 4.

27.22.4.22.3 SET UP IDLE MODE TEXT (UCS2 support)

27.22.4.22.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.22.3.2 Conformance requirement

The ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646 [17], "Universal Multiple Octet Coded Character Set (UCS)".

27.22.4.22.3.3 Test Purpose

To verify that the UCS2 coded text string is displayed by the ME as an idle mode text.

27.22.4.22.3.4 Method of test

27.22.4.22.3.4.1 Initial Conditions

The ME is connected to both the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The following events shall have been set up in the ME.

Event List

Logically:

Event 1: Idle screen available

27.22.4.22.3.4.2 Procedure

Expected Sequence 3.1 (SET UP IDLE MODE TEXT, UCS2 alphabet text)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select idle screen	
	ME		
2	$ME \rightarrow SIM$	ENVELOPE: EVENT	
		DOWNLOAD IDLE SCREEN	
		AVAILABLE 3.1.1	
3	$SIM \rightarrow ME$		["Hello" in Russian]
		PENDING: SET UP IDLE MODE	
		TEXT 3.1.1	
4	$ME \rightarrow SIM$		
5	$SIM \rightarrow ME$	PROACTIVE COMMAND : SET	
		UP IDLE MODE TEXT 3.1.1	
6	ME o	Display " ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
	USER		
7	$ME \rightarrow SIM$	TERMINAL RESPONSE : SET UP	
		IDLE MODE TEXT 3.1.1	
8	$SIM \rightarrow ME$		
		ENDED	

ENVELOPE: EVENT DOWNLOAD IDLE SCREEN AVAILABLE 3.1.1

Logically:

Event list

Event 1: Idle screen available

Device identities

Source device: Display
Destination device: SIM

Coding:

BER-TLV: D6 07 99 01 05 82 02 02 81

PROACTIVE COMMAND: SET UP IDLE MODE TEXT 3.1.1

Logically:

Command details

Command number: 1

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Text string

Data coding scheme: UCS2 (16bit)

Техт: "ЗДРАВСТВУЙТЕ"

Coding:

03 BER-TLV: D0 24 81 01 28 82 02 81 82 8D 00 12 17 20 04 10 04 19 80 04 04 14 04 04 21 04 22 04 12 04 23 04 19 04 22 04 15

TERMINAL RESPONSE: SET UP IDLE MODE LIST 3.1.1

Logically:

Command details

Command number:

Command type: SET UP IDLE MODE TEXT

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 28 00 82 02 82 81 83 01 00

27.22.4.22.3.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.23 RUN AT COMMAND

27.22.4.23.1 RUN AT COMMAND (normal)

27.22.4.23.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.23.1.2 Conformance requirement

The ME shall support the Proactive SIM: RUN AT COMMAND facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.4.23 (Run AT Command), clause 6.6.23 (Run AT Command), clause 5.2 (Terminal Profile), clause 6.8 (Terminal Response), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpha Identifier), clause 12.40 (AT Command), clause 12.31 (Icon Identifier), clause 12.41 (AT Response)

TS 27.007 [18]

27.22.4.23.1.3 Test Purpose

To verify that the ME responds to an AT Command contained within a RUN AT COMMAND as though it were initiated by an attached TE, and returns an AT Response within a TERMINAL RESPONSE to the SIM.

27.22.4.23.1.4 Method of test

27.22.4.23.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the test the ME shall be connected to the TE.

The TA-TE interface is set to 8-bit operation.

27.22.4.23.1.4.2 Procedure

Expected Sequence 1.1(RUN AT COMMAND, no alpha identifier presented, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[no alpha identifier, request IMSI]
		AT COMMAND 1.1.1	
4	$ME \left(ightarrow ight.$	The ME may give information to	
	User)	the user concerning what is	
		happening	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 1.1.1	Response containing IMSI]

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.1.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Coding:

BER-TLV: D0 12 81 03 01 34 00 82 02 81 82 Α8 2B 43 49 07 41 54 4D 43

TERMINAL RESPONSE: RUN AT COMMAND 1.1.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

AT Response

AT Response string: IMSI

Coding:

00 BER-TLV: 81 03 01 34 82 02 82 81 83 01 00 Α9 80 80 09 10 10 32 54 76 98

Expected Sequence 1.2 (RUN AT COMMAND, null data alpha identifier presented, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[null data alpha identifier, request IMSI]
		AT COMMAND 1.2.1	
4	ME	The ME should not give any	
		information to user on the fact that	
		the ME is performing an AT	
		command	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 1.1.1	Response containing IMSI]

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.2.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier null data object

AT Command

AT Command string: "AT+CIMI"

Coding:

BER-TLV: D0 14 81 03 01 34 00 82 02 81 82 85 00 Α8 07 41 54 2B 43 49 4D 49

Expected Sequence 1.3 (RUN AT COMMAND, alpha identifier presented, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND: RUN	[alpha identifier, request IMSI]
		AT COMMAND 1.3.1	
4	ME o	Display "Run AT Command"	
	USER		
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 1.1.1	Response containing IMSI]

PROACTIVE SIM COMMAND: RUN AT COMMAND 1.3.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha identifier

Alpha identifier "Run AT Command"

AT Command

AT Command string: "AT+CIMI"

Coding:

BER-TLV: D0 22 81 03 01 00 82 02 81 82 85 34 0E 52 75 6E 20 41 54 20 43 6F 6D 6D 61 6E 64 **A8** 07 54 2B 43 49 4D 41 49

27.22.4.23.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 to 3.

27.22.4.23.2 RUN AT COMMAND (Icon support)

27.22.4.23.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.23.2.2 Conformance requirement

The ME shall support the Proactive SIM: RUN AT COMMAND facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.4.23 (Run AT Command), clause 6.6.23 (Run AT Command), clause 5.2 (Terminal Profile), clause 6.8 (Terminal Response), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpha Identifier), clause 12.40 (AT Command), clause 12.31 (Icon Identifier), clause 12.41 (AT Response)

TS 27.007 [18]

27.22.4.23.2.3 Test Purpose

To verify that the ME responds to an AT Command contained within a RUN AT COMMAND as though it were initiated by an attached TE, and returns an AT Response within a TERMINAL RESPONSE to the SIM.

In addition to verify that if an icon is provided by the SIM, the icon indicated in the command may be used by the ME to inform the user, in addition to, or instead of the alpha identifier, as indicated with the icon qualifier.

27.22.4.23.2.4 Method of test

27.22.4.23.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

Prior to the test the ME shall be connected to the TE.

The TA-TE interface is set to 8-bit operation.

Initial Conditions for Icon Management according to Annex C are valid.

27.22.4.23.2.4.2 Procedure

Expected Sequence 2.1 (RUN AT COMMAND, basic icon self explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[BASIC-ICON, self-explanatory, request IMSI]
		AT COMMAND 2.1.1	
4	ME o	Display BASIC ICON	
	USER	Or	
		May give information to user	
		concerning what is happening	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
			containing IMSI]

PROACTIVE COMMAND: RUN AT COMMAND 2.1.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 16 81 03 01 34 00 82 02 81 82 Α8 07 54 2B 43 49 4D 43 9E 02 00 01 41

TERMINAL RESPONSE: RUN AT COMMAND 2.1.1A

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

AT Response

AT Response string: IMSI

Coding:

BER-TLV: Α9

TERMINAL RESPONSE: RUN AT COMMAND 2.1.1B

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

AT Response

AT Response string: IMSI

Coding:

BER-TLV: Α9

Expected Sequence 2.2 (RUN AT COMMAND, colour icon self explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[COLOUR-ICON, self-explanatory, request
		AT COMMAND 2.2.1	IMSI]
4	ME o	Display COLOUR-ICON	
	USER	Or	
		May give information to user	
		concerning what is happening	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
			containing IMSI]

PROACTIVE COMMAND: RUN AT COMMAND 2.2.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 2 in } EF_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV: 03 Α8 D0 6 81 01 34 00 82 02 81 82 07 41 54 2B 43 49 4D 43 9E 02 02

Expected Sequence 2.3 (RUN AT COMAND, basic icon non self-explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[BASIC-ICON, non self-explanatory, request
		AT COMMAND 2.3.1	IMSI]
4	ME o	Display "Basic Icon" and BASIC-	
	USER	ICON	
		Or	
		Display "Basic Icon"	
7	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response
			containing IMSI]

PROACTIVE COMMAND: RUN AT COMMAND 2.3.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha identifier: "Basic Icon"

AT Command

AT Command string: "AT+CIMI"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

03 BER-TLV: D0 22 81 01 34 00 82 02 81 82 85 42 69 63 20 49 63 6F 6D Α8 0A 61 73 07 41 54 43 49 4D 43 9E 02 01 2B 01

Expected Sequence 2.4 (RUN AT COMMAND, colour icon non self-explanatory, request IMSI)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		2.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN	[COLOUR-ICON, non self-explanatory,
		AT COMMAND 2.4.1	request IMSI]
4	ME o	Display "Colour Icon" and	
	USER	COLOUR-ICON	
		Or	
		Display "Colour Icon"	
5	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT	[Command performed successfully, AT
		COMMAND 2.1.1A	response containing IMSI]
		Or	or
		TERMINAL RESPONSE: RUN AT	[Command performed but requested icon
		COMMAND 2.1.1B	could not be displayed, AT response containing IMSI]

PROACTIVE COMMAND: RUN AT COMMAND 2.4.1

Logically:

Command details

Command number: 1

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Alpha Identifier

Alpha identifier: "Colour Icon"

AT Command

AT Command string: "AT+CIMI"

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{icon is self-explanatory} \\ \text{Icon Identifier:} & \text{record 2 in } EF_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV: D0 23 81 03 01 34 00 82 02 81 82 85 0B 43 6F 6C 6F 75 72 20 49 63 6F 6D Α8 2B 02 07 41 54 43 49 4D 43 9E 01 02

Expected Sequence 2.5 (RUN AT COMMAND, basic icon non self-explanatory, no alpha identifier presented)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: RUN AT COMMAND	
		SS 2.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND: RUN AT COMMAND 2.5.1	[BASIC-ICON, non self-explanatory]
4	$ME \rightarrow SIM$	TERMINAL RESPONSE: RUN AT COMMAND 2.5.1	[Command data not understood by ME]
	1		

PROACTIVE COMMAND: RUN AT COMMAND 2.5.1

Logically: Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

AT Command

AT Command string: "AT+CIMI"

Icon Identifier

Icon qualifier: icon is non self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 16 81 03 01 34 00 82 02 81 82 **A8** 02 07 41 54 2B 43 49 4D 43 9E 01 01

TERMINAL RESPONSE: RUN AT COMMAND 2.5.1

Logically:

Command details

Command number:

Command type: RUN AT COMMAND

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Result

General Result: Command data not understood by ME

Coding:

BER-TLV: 81 03 01 34 00 82 02 82 81 83 01 32

27.22.4.23.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences 1 to 5.

27.22.4.24 SEND DTMF

27.22.4.24.1 SEND DTMF (Normal)

27.22.4.24.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.24.1.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.24 (Send DTMF), 6.6.24 (Send DTMF), clause 12.12.2 (Additional information for ME problem), clause 5.2 (Terminal Profile), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpa identifier), clause 12.44 (DTMF String).

27.22.4.24.1.3 Test Purpose

To verify that after a call has been successfully established the ME sends the DTMF string contained in the SEND DTMF proactive SIM command to the network, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME does not locally generate audible DTMF tones and play them to the user.

To verify that if the ME is in idle mode it informs the SIM using TERMINAL RESPONSE '20' with the additional information "Not in speech call" .

To verify that the ME displays the text contained in the SEND DTMF proactive SIM command.

To verify that if an alpha identifier is provided by the SIM and is a null data object the ME does not give any information to the user on the fact that the ME is performing a SEND DTMF command.

27.22.4.24.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

27.22.4.24.1.4. 2 Procedure

Expected Sequence 1.1 (SEND DTMF, A call has been successfully established before the beginning of the test)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DTMF 1.1.1	
4	ME o	May give information to the user	
	USER	concerning what is happening.	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \rightarrow SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DTMF 1.1.1	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SEND DTMF 1.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
DTMF String: "1" pause "2"

Coding:

03 BER-TLV: D0 0D 81 01 14 00 82 02 81 83 AC 02 C1 F2

Start DTMF 1.1

Logically:

DTMF String: "1"

Start DTMF 1.2

Logically:

DTMF String: "2"

TERMINAL RESPONSE: SEND DTMF 1.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 14 00 82 02 82 81 83 01 00

Expected Sequence 1.2 (SEND DTMF, containing alpha identifier, a call has been successfully established before the beginning of the test)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		DTMF 1.2.1	
4	$ME \to$	Display "Send DTMF"	Alpha identifier
	USER		
		Do not locally generate audible	
		DTMF tones and play them to the	
_		user.	FII.4 II.3
5	$ME \rightarrow SS$		["1"]
6	$ME \rightarrow SS$		["2"]
7	$ME \rightarrow SS$		["3"]
8	$ME \rightarrow SS$		["4"]
9	$ME \rightarrow SS$		["5"]
10	$ME \rightarrow SS$	Start DTMF 1.6	["6"]
11	$ME \rightarrow SS$	Start DTMF 1.7	["7"]
12	$ME \rightarrow SS$	Start DTMF 1.8	["8"]
13	$ME \rightarrow SS$	Start DTMF 1.9	["9"]
14	$ME \rightarrow SS$	Start DTMF 1.10	["0"]
15	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DTMF 1.1.1	
16	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SEND DTMF 1.2.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send DTMF"
DTMF String: "1234567890"

Coding:

BER-TLV: D0 1B 81 03 01 14 00 82 02 81 83 85 6E AC09 53 65 64 20 44 54 4D 46 05 21 43 65 87 09

Start DTMF 1.3

Logically:

DTMF String: "3"

Start DTMF 1.4

Logically:

DTMF String: "4"

Start DTMF 1.5

Logically:

DTMF String: "5"

Start DTMF 1.6

Logically:

DTMF String: "6"

Start DTMF 1.7

Logically:

DTMF String: "7"

Start DTMF 1.8

Logically:

DTMF String: "8"

Start DTMF 1.9

Logically:

DTMF String: "9"

Start DTMF 1.10

Logically:

DTMF String: "0"

Expected Sequence 1.3 (SEND DTMF, containing alpha identifier with null data object, a call has been successfully established before the beginning of the test)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND DTMF 1.3.1	Alpha identifier with null data object
4	ME → USER	DO not give any information to the user on the fact that the ME is performing a SEND DTMF command.	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 30 seconds +/-20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND DTMF 1.1.1	[Command performed successfully]
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: SEND DTMF 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "" (null data object)

DTMF String: "1" pause "2"

Coding:

BER-TLV: D0 13 03 02 81 83 85 81 01 14 00 AC CC CC CC CC 2C 00 06 C1

Expected Sequence 1.4 (SEND DTMF, mobile is not in a speech call)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: SEND DTMF 1.1.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND : SEND DTMF 1.1.1	
4	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE : SEND DTMF 1.4.1	[ME currently unable to process command, not in speech call]
5	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE SIM SESSION ENDED	

TERMINAL RESPONSE: SEND DTMF 1.4.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME

Destination device: SIM

Result

General Result: ME currently unable to process command

Additional information: Not in speech call

Coding:

BER-TLV: 81 03 01 14 00 82 02 82 81 83 02 20

07

27.22.4.24.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences.

27.22.4.24.2 SEND DTMF (Display of icons)

27.22.4.24.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.24.2.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.24 (Send DTMF), 6.6.24 (Send DTMF), clause 12.12.2 (Additional information for ME problem), clause 5.2 (Terminal Profile), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpa identifier), clause 12.44 (DTMF String), clause 12.31 (Icon identifier), clause 6.5.4 (Icon identifiers).

27.22.4.24.2.3 Test Purpose

To verify that after a call has been successfully established the ME send the DTMF string contained in the SEND DTMF proactive SIM command to the network, and returns a successful response in the TERMINAL RESPONSE command sent to the SIM.

To verify that the ME do not locally generate audible DTMF tones and play them to the user.

To verify that the ME displays the text contained in the SEND DTMF proactive SIM command.

To verify that the ME displays the icons which are referred to in the contents of the SEND DTMF proactive SIM command.

27.22.4.24.2.4 Method of test

27.22.4.24.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

Prior to this test the ME shall have been powered on, performed the PROFILE DOWNLOAD procedure and be in updated idle mode on the System Simulator.

See Annex C for coding of the elementary files on SIM.

27.22.4.24.2.4.2 Procedure

Expected Sequence 2.1 (SEND DTMF, BASIC ICON self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$		
		PENDING: SEND DTMF 2.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[BASIC-ICON, self-explanatory]
		DTMF 2.1.1	
4	ME o	Display the BASIC-ICON	
	USER		
		Do not locally generate audible	
		DTMF tones and play them to the	
		user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DTMF 2.1.1A	
9	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SEND DTMF 2.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Basic Icon"
DTMF String: "1" pause "2"

Icon identifier

Icon qualifier: icon is self-explanatory Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 1B 81 03 01 00 82 02 81 83 85 14 0Α 73 69 63 20 49 63 6F 6E AC 42 61 02 C1 F2 9E 02 00 01

DTMF Request 2.1.1

Logically:

DTMF String: \$DTMF_2.1\$ = "C1 F2" (given as example)

TERMINAL RESPONSE: SEND DTMF 2.1.1A

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 14 00 82 02 82 81 83 01 00

Expected Sequence 2.1B (SEND DTMF, BASIC ICON self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: SEND DTMF 2.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DTMF 2.1.1	[BASIC-ICON, self-explanatory]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Basic Icon" without the icon	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \rightarrow SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully, but
		DTMF 2.1.1B	requested icon could not be displayed]
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION ENDED	

TERMINAL RESPONSE: SEND DTMF 2.1.1B

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, but requested icon could not be

displayed

Coding:

BER-TLV: 81 03 01 14 00 82 02 82 81 83 01 04

Expected Sequence 2.2 (SEND DTMF, COLOUR-ICON self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[COLOUR-ICON]
		DTMF 2.2.1	
4	ME o	Display the COLOUR-ICON	
	USER		
		Do not locally generate audible	
		DTMF tones and play them to the	
		user.	
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DTMF 2.1.1A	
9	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SEND DTMF 2.2.1

Logically:

Command details

Command number: 1

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Colour Icon"
DTMF String: "1" pause "2"

Icon Identifier:

Icon qualifier: icon is self-explanatory Icon Identifier: record 2 in $EF_{(IMG)}$

Coding:

BER-TLV: D0 11 81 03 01 14 00 82 02 81 83 AC 02 C1 F2 9E 02 00 02 BER-TLV: 82 D0 02 81 83 85 1C 81 03 01 14 00 6C 6F 75 72 20 49 6E 0B 43 6F 63 6F AC 02 C1 F2 9E 02 00 02

Expected Sequence 2.2B (SEND DTMF, COLOUR-ICON self explanatory,requested icon could not be displayed)

Some details of the DTMF protocol have been left out for clarity.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DTMF 2.2.1	[COLOUR-ICON]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	Display "Colour Icon" without the icon	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \rightarrow SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND DTMF 2.1.1B	[Command performed successfully, but requested icon could not be displayed]
9	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

Expected Sequence 2.3A (SEND DTMF, Alpha identifier & BASIC-ICON, not self-explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND DTMF 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DTMF 2.3.1	[Alpha identifier & BASIC-ICON, not self- explanatory]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	Display the BASIC-ICON	
		Do not locally generate audible DTMF tones and play them to the user.	
5	$ME \rightarrow SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \rightarrow SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND DTMF 2.1.1A	[Command performed successfully]
9	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

PROACTIVE COMMAND: SEND DTMF 2.3.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network
Alpha identifier: "Send DTMF"
DTMF String: "1" pause "2"

Icon Identifier:

Icon qualifier: icon is not self-explanatory

Icon Identifier: record 1 in $EF_{(IMG)}$

Coding:

1C 03 BER-TLV: D0 81 01 14 02 85 00 82 81 83 AC 09 53 65 6E 64 20 44 54 4D 46 02 C1 9E 01

Expected Sequence 2.3B (SEND DTMF, Alpha identifier & BASIC-ICON, not self-explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 2.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	[Alpha identifier & BASIC-ICON, not self-
		DTMF 2.3.1	explanatory]
4	ME o	Display "Send DTMF" without the	
	USER	icon	
		Do not locally generate audible	
		DTMF tones and play them to the	
		user.	

5	$ME \to SS$	Start DTMF 1.1	["1"]	i
6	ME		No DTMF sending for 3 seconds +/-20%	1
7	$ME \to SS$	Start DTMF 1.2	["2"]	1
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully, but	i
9	$SIM \rightarrow ME$	DTMF 2.1.1B PROACTIVE SIM SESSION	requested icon could not be displayed]	Ì
		ENDED		

27.22.4.24.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences.

27.22.4.24.3 SEND DTMF (UCS2 support)

27.22.4.24.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.24.3.2 Conformance requirement

The ME shall support the Proactive SIM: Send DTMF facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 6.1, clause 6.4.24 (Send DTMF), 6.6.24 (Send DTMF), clause 12.12.2 (Additional information for ME problem), clause 5.2 (Terminal Profile), clause 12.6 (Command Details), clause 12.7 (Device Identities), clause 12.2 (Alpa identifier), clause 12.44 (DTMF String).

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646. [17].

27.22.4.24.3.3 Test Purpose

To verify that the ME displays the UCS2 text contained in the SEND DTMF proactive SIM command, and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.24.3.4 Method of test

27.22.4.24.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.24.3.4.2 Procedure

Expected Sequence 3.1 (SEND DTMF, successful, UCS2 text)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DTMF 3.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		DTMF 3.1.1	
4	ME o	Display "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
	USER		
5	$ME \to SS$	Start DTMF 1.1	["1"]
6	ME		No DTMF sending for 3 seconds +/-20%
7	$ME \to SS$	Start DTMF 1.2	["2"]
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DTMF 3.1.1	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: SEND DTMF 3.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: Network

Alpha Identifier

Data coding scheme: UCS2 (16bit)

Text: "ЗДРАВСТВУЙТЕ"

DTMF String: "1" pause "2"

Coding:

BER-TLV: D0 28 81 03 01 02 8D 14 00 82 81 83 19 80 04 17 04 14 04 20 04 10 04 12 04 04 04 23 04 04 21 22 04 12 19 22 04 AC 02 C1 15 F2

TERMINAL RESPONSE: SEND DTMF 3.1.1

Logically:

Command details

Command number:

Command type: SEND DTMF

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successful

Coding:

BER-TLV: 81 03 01 14 00 82 02 82 81 83 01 00

27.22.4.12.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.

27.22.4.25 LANGUAGE NOTIFICATION

27.22.4.25.1 Definition and applicability

See Section 3.2.2.

27.22.4.25.2 Conformance Requirement

The ME shall conclude the command by sending TERMINAL RESPONSE (OK) to the SIM, as soon as possible after receiving the LANGUAGE NOTIFICATION proactive SIM command.

3GPP TS 11.14 clause 6.4.25, 6.6.25.

27.22.4.25.3 Test Purpose

To verify that the ME shall send a TERMINAL RESPONSE (OK) to the SIM after the ME receives the LANGUAGE NOTIFICATION proactive SIM command.

27.22.4.25.4 Method of Test

27.22.4.25.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.25.4.2 Procedure

Expected Sequence 1.1 (LANGUAGE NOTIFICATION)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LANGUAGE	
		NOTIFICATION 1.1.1	
2	$ME \to SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	Language specified in the command is
		LANGUAGE NOTIFICATION 1.1.1	different from the one set on the mobile.
4	$ME \to SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LANGUAGE NOTIFICATION 1.1.1	
5	$SIM \to ME$	PROACTIVE SIM SESSION	Check that language of ME has been
		ENDED	replaced by the one specified in LANGUAGE
			NOTIFICATION 1.1.1

PROACTIVE COMMAND: LANGUAGE NOTIFICATION 1.1.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION
Command qualifier: "01" (specific language notification)

Device identities

Source device: SIM
Destination device: ME

Language

Language 'se'(spanish) -> 73 65

or 'de' \rightarrow 64 65 (german) for instance : choose a language different from the one initially set on the ME to check the proper execution

of the command

Coding:

BER-TLV: D0 0D 81 03 01 35 01 82 02 81 82 AD

02 73 65

TERMINAL RESPONSE: LANGUAGE NOTIFICATION 1.1.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "01"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 35 01 82 02 82 81 83 01 00

Expected Sequence 1.2 (LANGUAGE NOTIFICATION)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LANGUAGE	
		NOTIFICATION 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		LANGUAGE NOTIFICATION 1.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LANGUAGE NOTIFICATION 1.2.1	
5	$SIM \to ME$	PROACTIVE SIM SESSION	Check that initial language is set again.
		ENDED	
1			

PROACTIVE COMMAND: LANGUAGE NOTIFICATION 1.2.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "00" (non specific language notification)

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 35 01 82 02 81 82

TERMINAL RESPONSE: LANGUAGE NOTIFICATION 1.2.1

Logically:

Command details

Command number: 1

Command type: LANGUAGE NOTIFICATION

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 35 00 82 02 82 81 83 01 00

27.22.4.25.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1 and 2.

27.22.4.26 LAUNCH BROWSER

27.22.4.26.1 LAUNCH BROWSER (No session already launched)

27.22.4.26.1.1 Definition and applicability

See Section 3.2.2.

27.22.4.26.1.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clauses 6.4.26 and 6.6.26 (Launch browser), clause 12.6 (Commands details), clause 12.7 (device identities), clause 12.48 (URL),), clause 13.2 (command tag), clause 12.2 (Alpha

Identifier), clause 12.47 (Browser identity), clause 12.49 (Bearer), clause 1 12.50 (provisioning), clause 12.15 (Text String), clause 12.31 (icon identifier).

27.22.4.26.1.3 Test Purpose

To verify that when the ME is in idle state, it launches properly the Wap session required in LAUNCH BROWSER, and returns a successful result in the TERMINAL RESPONSE command.

27.22.4.26.1.4 Method of test

27.22.4.26.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

the default Wap parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway")

With that default gateway we shall be able to access to an URL different from the default one.

- another gateway with an IP address different from the one defined in default Wap parameters.

The mobile is in idle mode.

27.22.4.26.1.4.2 Procedure

Expected Sequence 1.1 (LAUNCH BROWSER, connect to the default URL)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.1.1	if not already launched", no null alpha id.]
4	ME o	ME displays the alpha identifier	
	USER		
5	$USER \to$	The user may have to confirm the	[option : user confirmation]
	ME	launch browser.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LAUNCH BROWSER 1.1.1	
7	ME->SS	The ME attempts to launch the	
		session with the default Wap	
		parameters and the default URL.	
8	$SIM \rightarrow ME$		
		ENDED	

9	$USER \to $	The user verifies that the default	
	ME	Wap session is properly	
		established.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha identifier "Default URL"

Coding:

BER-TLV: D0 18 03 01 15 00 02 82 31 00 05 0B 44 65 76 6C 74 20 55 66 61 52 4C

TERMINAL RESPONSE: LAUNCH BROWSER 1.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

Expected Sequence 1.2 (LAUNCH BROWSER, connect to the specified URL, alpha identifier length=0)

Step	Direction	MESSAGE / Action	Comments
------	-----------	------------------	----------

0	ME		[the ME is in idle mode]
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.2.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[connect to defined URL, "launch browser, if
		LAUNCH BROWSER 1.2.1	not already launched, alpha identifier
			length=0]
4	ME o	No information should be	
	USER	displayed.	
5	$USER \to$	The user may have to confirm the	[option : user confirmation]
	ME	launch browser.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LAUNCH BROWSER 1.2.1	
7	ME->SS	The ME attempts to connect the	
		URL specified in the LAUNCH	
		BROWSER command.	
8	$SIM \to ME$	PROACTIVE SIM SESSION	
		ENDED	
9	$USER \ \to \\$	The user verifies that the URL is	
	ME	properly connected.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: SIM
Destination device: ME

URL http://xxx.yyy.zzz (note: this URL shall be different from the default URL,

but it can be reached from the gateway defined by default in the Wap

parameters of the mobile)

Alpha identifier empty

Coding:

BER-TLV: D0 1F 81 03 01 15 00 82 02 81 82 31 74 70 2F 78 78 78 2E 12 68 74 ЗА 2F 79 79 79 2E 7A 7A 7A 05 00

TERMINAL RESPONSE: LAUNCH BROWSER 1.2.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

Expected Sequence 1.3 (LAUNCH BROWSER, Browser identity, no alpha identifier)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.3.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.3.1	if not already launched, browser identity]
4	ME o	ME may display a default	
	USER	message of its own.	
5	$USER \to$	The user may confirm the launch	[option : user confirmation]
	ME	browser.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LAUNCH BROWSER 1.3.1	
7	ME->SS	The ME attempts to connect the	
		default URL.	
8	$SIM \rightarrow ME$		
		ENDED	
9		The user verifies that the default	
	ME	Wap session is properly	
		established.	
		Then he/she ends the navigation.	
		The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: SIM
Destination device: ME
Browser Identity default
URL 0

Coding:

BER-TLV: D0 1F 81 03 01 15 00 82 02 81 82 30 00 31 00 01

TERMINAL RESPONSE: LAUNCH BROWSER 1.3.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

Expected Sequence 1.4 (LAUNCH BROWSER, one bearer specified and gateway/proxy identity)

Step	Direction	MESSAGE / Action	Comments
0	ME		[the ME is in idle mode]
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		1.4.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[connect to the default URL, "launch browser,
		LAUNCH BROWSER 1.4.1	if not already launched, 1 bearer specified,
			gateway/proxy id specified]
4	ME o	ME may display a default	
	USER	message	
5	$USER \to$	The user may confirm the launch	[option : user confirmation]
	ME	browser.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LAUNCH BROWSER 1.4.1 A	
		Or	
		TERMINAL RESPONSE :	[Launch browser generic error code – bearer
		LAUNCH BROWSER 1.4.1 B	not available]
		Or	[Company of montones of with monticl
		TERMINAL RESPONSE :	[Command performed with partial
1		LAUNCH BROWSER 1.4.1 C	comprehension]

-				
	7	ME->SS	The ME attempts to connect the	
			default URL using the requested	
			bearer and proxy identity	
	8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
			ENDED	
	9	USER →	If performed successfully:	
		ME	the user verifies that the Wap	
			session is properly established	
			with the required bearer. Then	
			he/she ends the navigation.	
			The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.4.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: SIM
Destination device: ME
URL 0
Bearer GPRS

Gateway/Proxy id

DCS unpacked, 8 bits data

Text string abc.def.ghi (different from the default IP address)

Coding:

BER-TLV: D0 1C 03 82 02 81 82 81 01 15 00 31 0D OC 62 63 2E 64 00 32 01 03 61 65 66 2E 67 68 69

TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1 A

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1 B

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Launch browser generic error code

Additional information Bearer not available

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 02 26

TERMINAL RESPONSE: LAUNCH BROWSER 1.4.1 C

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, with partial comprehension

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 01

Expected Sequence 1.5 (LAUNCH BROWSER, several bearers specified, gateway/proxy id specified)

L	Step	Direction	MESSAGE / Action	Comments
	0			[ME is in idle mode]
	1	$SIM \to ME$	PROACTIVE COMMAND	
			PENDING: LAUNCH BROWSER	
			1.5.1	
	2	$ME \to SIM$	FETCH	
	3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "launch browser,
			LAUNCH BROWSER 1.5.1	if not already launched, several bearers,
				gateway/proxy id specified]

4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME may display a default message	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user may confirm the launch browser.	[option : user confirmation]
6	$ME \to SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 1.5.1 A Or	[Command performed successfully]
		TERMINAL RESPONSE : LAUNCH BROWSER 1.5.1 B Or	[Launch browser generic error code – bearer not available]
		TERMINAL RESPONSE : LAUNCH BROWSER 1.5.1 C	[Command performed with partial comprehension]
7	ME->SS	The ME attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	If performed successfully: the user verifies that the Wap session is properly established with one of the required bearers. Then he/she ends the navigation. The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 1.5.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: SIM
Destination device: ME
URL 0

Bearer GPRS, USSD, SMS

Gateway/Proxy id

DCS 7 bits default alphabet

Text string abc.def.ghi (different from the default IP address)

Coding:

BER-TLV: D0 1D 81 03 01 15 00 82 02 81 82 31 00 32 03 03 02 00 0D 0C 00 61 F1 D8 45 2E 9B 5D 67 74 1A

TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 A

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 00

TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 B

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Launch browser generic error code

Additional information Bearer not available

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 02 26 01

TERMINAL RESPONSE: LAUNCH BROWSER 1.5.1 C

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully, with partial comprehension

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 01 01

27.22.4.26.2 LAUNCH BROWSER (Interaction with current session)

27.22.4.26.2.1 Definition and applicability

See Section 3.2.2.

27.22.4.26.2.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clauses 6.4.26 and 6.6.26 (Launch browser), clause 12.6 (Commands details), clause 12.7 (device identities), clause 12.48 (URL),), clause 13.2 (command tag), clause 12.2 (Alpha Identifier), clause 12.47 (Browser identity), optional 12.49 (Bearer), optional 12.50 (provisioning), clause 12.15 (Text String), clause 12.31 (icon identifier).

27.22.4.26.2.3 Test Purpose

To verify that when the ME is already busy in a Wap session, it launches properly the Wap session required in LAUNCH BROWSER, and returns a successful result in the TERMINAL RESPONSE.

27.22.4.26.2.4 Method of test

27.22.4.26.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to a Wap gateway is required. The default Wap parameters (IP address, gateway/proxy identity, called number ...) of the tested mobile shall be properly filled to access that gateway.

The mobile is busy in a Wap session, the user navigates in pages different from the URL defined by default in Wap parameters.

27.22.4.26.2.4.2 Procedure

Expected Sequence 2.1 (LAUNCH BROWSER, use the existing browser, connect to the default URL)

Step	Direction	MESSAGE / Action	Comments
0	ME	The user is navigating in a Wap	[Browser is in use, the current session is not
		session (not default URL).	secured]
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: LAUNCH BROWSER	
		2.1.1	

2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[connect to the default URL, "use the existing
		LAUNCH BROWSER 2.1.1	browser", no null alpha id.]
4	ME o	ME displays the alpha identifier	
	USER		
5	$USER \to$	The user confirms the launch	[user confirmation]
	ME	browser.	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE :	[Command performed successfully]
		LAUNCH BROWSER 2.1.1	
7	ME->SS	The ME does not close the	
		existing session and attempts to	
		connect the default URL.	
	0114 145		
8	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	
9	00-11	The user verifies that the default	
	ME	URL is connected; and the	
		previous URL can be retrieved.	
		Then he/she ends the navigation	
		with the default URL.	

PROACTIVE COMMAND: LAUNCH BROWSER 2.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha identifier "Default URL"

Coding:

BER-TLV: D0 18 03 01 15 02 82 02 81 82 31 0B 44 76 6C 74 20 00 05 65 66 61 55

52 4C

TERMINAL RESPONSE: LAUNCH BROWSER 2.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 00

Expected Sequence 2.2 (LAUNCH BROWSER, close the existing browser session and launch new browser session, connect to the default URL)

Step	Direction	MESSAGE / Action	Comments
0	ME	The user is navigating in a Wap session (not default URL)	[Browser is in use, the current session is not secured]
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: LAUNCH BROWSER 2.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND :	[connect to the default URL, "close the
		LAUNCH BROWSER 2.2.1	existing browser session and launch new browser session", no null alpha id.]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays the alpha identifier	
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the launch browser.	[user confirmation]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 2.2.1	[Command performed successfully]
7	ME->SS	The ME closes the existing session and attempts to launch the session with the default Wap parameters and the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	The user verifies that the default URL is connected; and the previous URL cannot be retrieved (to verify the previous session has been closed). Then he/she does not end the	
		navigation.	

PROACTIVE COMMAND: LAUNCH BROWSER 2.2.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: close the existing browser session and launch new browser session

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha identifier "Default URL"

Coding:

BER-TLV: D0 18 81 03 01 15 03 82 02 81 82 31 0B 6C 00 05 44 65 66 61 76 74 20 55

52 4C

TERMINAL RESPONSE: LAUNCH BROWSER 2.2.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: close the existing browser session and launch new browser session

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 03 82 02 82 81 83 01 00

Expected Sequence 2.3 (LAUNCH BROWSER, if not already launched)

Step	Direction	MESSAGE / Action	Comments
0	ME	The user is navigating in a Wap	[Browser is in use, the current session is not
1	$SIM \to ME$	PENDING: LAUNCH BROWSER	secured]
2	$ME \rightarrow SIM$	2.3.1 FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	[connect to the default URL, "launch browser,
	NAT 0184	LAUNCH BROWSER 2.3.1	if not already launched]
8	ME → SIM	TERMINAL RESPONSE : LAUNCH BROWSER 2.3.1	[ME unable to process command – browser unavailable]
9	$SIM \rightarrow ME$		•
40		ENDED	
10	USER →	The user verifies that the default	
	ME	URL has not been connected.	
		Then he/she ends the navigation. The ME returns in idle mode.	

PROACTIVE COMMAND: LAUNCH BROWSER 2.3.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: SIM
Destination device: ME
URL empty

Coding:

BER-TLV: D0 0C 81 03 01 15 00 82 02 81 82 31

00

TERMINAL RESPONSE: LAUNCH BROWSER 2.3.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER

Command qualifier: launch browser, if not already used

Device identities

Source device: ME
Destination device: SIM

Result

General Result: ME unable to process command

Additional data Browser unavailable

Coding:

BER-TLV: 81 03 01 15 00 82 02 82 81 83 02 26

27.22.4.26.3 LAUNCH BROWSER (UCS2 support)

27.22.4.26.3.1 Definition and applicability

See Section 3.2.2.

27.22.4.26.3.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clauses 6.4.26 and 6.6.26 (Launch browser), clause 12.6 (Commands details), clause 12.7 (device identities), clause 12.48 (URL),), clause 13.2 (command tag), clause 12.2 (Alpha Identifier), clause 12.47 (Browser identity), optional 12.49 (Bearer), optional 12.50 (provisioning), clause 12.15 (Text String), clause 12.31 (icon identifier)

Additionally the ME shall support the UCS2 facility for the coding of the Cyrillic alphabet, as defined in the following technical specifications: ISO/IEC 10646. [17].

27.22.4.26.2.3 Test Purpose

To verify that the ME performs a proper user confirmation with an USC2 alpha identifier, launches the Wap session required in LAUNCH BROWSER and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.26.3.4 Method of test

27.22.4.26.3.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

the default Wap parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway")

With that default gateway we shall be able to access to an URL different from the default one.

- another gateway with an IP address different from the one defined in default Wap parameters.

The mobile is busy in a Wap session, the user navigates in pages different from the URL defined by default in Wap parameters.

27.22.4.26.3.4.2 Procedure

Expected Sequence 3.1 (LAUNCH BROWSER, use the existing browser, connect to the default URL)

1		
ME	The user is navigating in a Wap session (not default URL)	[Browser is in use, the current session is not secured]]
$SIM \to ME$	PROACTIVE COMMAND PENDING: LAUNCH BROWSER 3.1.1	
$ME \rightarrow SIM$	FETCH	
$SIM \to ME$	PROACTIVE COMMAND : LAUNCH BROWSER 3.1.1	[connect to the default URL, "use the existing browser", alpha id. In UCS2]
$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays the alpha identifier "ЗДРАВСТВУЙТЕ"	["Hello" in Russian]
$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the launch browser.	[user confirmation]
$ME \to SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 3.1.1	[Command performed successfully]
ME->SS	The ME does not close the existing session and attempts to connect the default URL.	
$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
USER → ME	The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation	
	$\begin{array}{c} ME \to SIM \\ SIM \to ME \\ ME \to \\ USER \\ USER \to \\ ME \to SIM \\ ME \to SS \\ \\ SIM \to ME \\ USER \to \\ \\ U$	SIM → ME SIM → ME SIM → ME PROACTIVE COMMAND PENDING: LAUNCH BROWSER 3.1.1 FETCH PROACTIVE COMMAND: LAUNCH BROWSER 3.1.1 ME → USER USER → ME ME → SIM ME->SS PROACTIVE COMMAND: LAUNCH BROWSER 3.1.1 ME displays the alpha identifier "3ДРАВСТВУЙТЕ" The user confirms the launch browser. TERMINAL RESPONSE: LAUNCH BROWSER 3.1.1 The ME does not close the existing session and attempts to connect the default URL. SIM → ME PROACTIVE SIM SESSION ENDED The user verifies that the default URL is connected; and the previous URL can be retrieved.

PROACTIVE COMMAND: LAUNCH BROWSER 3.1.1

Logically:

Command details

Command number: 1

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier

Data coding scheme:UCS2 (16 bits)Text:"ЗДРАВСТВУЙТЕ"

Coding:

BER-TLV: 03 D0 26 81 01 15 02 82 02 81 82 31 80 04 04 10 00 05 19 04 17 04 14 20 04 12 04 21 04 22 04 12 04 23 04 19 04 04 22 15

TERMINAL RESPONSE: LAUNCH BROWSER 3.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 00

27.22.4.26.4 LAUNCH BROWSER (icons support)

27.22.4.26.4.1 Definition and applicability

See Section 3.2.2.

27.22.4.26.4.2 Conformance requirements

The ME shall support the LAUNCH BROWSER Proactive SIM Command as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clauses 6.4.26 and 6.6.26 (Launch browser), clause 12.6 (Commands details), clause 12.7 (device identities), clause 12.48 (URL), clause 13.2 (command tag), clause 12.2 (Alpha Identifier), clause 12.47 (Browser identity), optional 12.49 (Bearer), optional 12.50 (provisioning), clause 12.15 (Text String), clause 12.31 (icon identifier).

27.22.4.26.4.3 Test Purpose

To verify that the ME performs a proper user confirmation with an icon identifier, launches the Wap session required in LAUNCH BROWSER and returns a successful result in the TERMINAL RESPONSE command send to the SIM.

27.22.4.26.4.4 Method of test

27.22.4.26.4.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

A valid access to 2 different Wap gateways is required:

the default Wap parameters (IP address, gateway/proxy identity, called number, URL ...) of the tested mobile shall be properly filled to access one of the gateways ("default gateway")

With that default gateway we shall be able to access to an URL different from the default one.

- another gateway with an IP address different from the one defined in default Wap parameters.

The mobile is busy in a Wap session, the user navigates in pages different from the URL defined by default in Wap parameters.

27.22.4.26.4.4.2 Procedure

Expected Sequence 4.1A (LAUNCH BROWSER, use the existing browser, icon not self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not
		PENDING: LAUNCH BROWSER	secured]]
		4.1.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : LAUNCH BROWSER 4.1.1	[connect to the default URL, "use the existing browser", no null alpha id.]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays the alpha identifier and the icon	["Not self explan."]
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the launch browser.	[user confirmation]
6	$ME \to SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 4.1.1 A	[Command performed successfully]
7	ME->SS	The ME does not close the existing session and attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	

9	$USER \to $	The user verifies that the default	
	ME	URL is connected; and the	
		previous URL can be retrieved.	
		Then he/she ends the navigation	
		with the default URL.	

PROACTIVE COMMAND: LAUNCH BROWSER 4.1.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Not self explan."

Icon Identifier:

 $\begin{array}{ll} \text{Icon qualifier:} & \text{not self-explanatory} \\ \text{Icon Identifier:} & \text{record 1 in } EF_{\text{(IMG)}} \\ \end{array}$

Coding:

BER-TLV: D0 21 81 03 01 15 02 82 02 81 82 31 00 05 10 4E 6F 74 20 73 65 6C 66 20 65 78 70 6C 61 6E 2E 1E 02 01 01

TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 A

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 00

Expected Sequence 4.1B (LAUNCH BROWSER, use the existing browser, icon not self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not
		PENDING: LAUNCH BROWSER	secured]]
		4.1.1	
2	$ME \rightarrow SIM$	FETCH	

3	$SIM \to ME$	PROACTIVE COMMAND : LAUNCH BROWSER 4.1.1	[connect to the default URL, "use the existing browser", no null alpha id.]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays the alpha identifier Without the icon	["Not self explan."]
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the launch browser.	[user confirmation]
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 4.1.1 B	[Command performed successfully but requested icon could not be displayed]
7	ME->SS	The ME does not close the existing session and attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL.	

TERMINAL RESPONSE: LAUNCH BROWSER 4.1.1 B

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 06

Expected Sequence 4.2A (LAUNCH BROWSER, use the existing browser, icon self explanatory, successful)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[Browser is in use, the current session is not
		PENDING: LAUNCH BROWSER	secured]]
		4.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND :	[connect to the default URL, "use the existing
		LAUNCH BROWSER 4.2.1	browser", alpha id. In UCS2]
4	ME o	ME displays only the icon	["Self explan."]
	USER		
5	$USER \to$	The user confirms the launch	[user confirmation]
	ME	browser.	-

6	$ME \to SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 4.2.1 A	[Command performed successfully]
7	ME->SS	The ME does not close the existing session and attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL.	

PROACTIVE COMMAND: LAUNCH BROWSER 4.2.1

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: SIM
Destination device: ME
URL empty

Alpha Identifier "Self explan."

Icon Identifier:

 $\begin{tabular}{ll} Icon qualifier: & self-explanatory \\ Icon Identifier: & record 1 in EF_{(IMG)} \\ \end{tabular}$

Coding:

BER-TLV: D0 1D 03 01 02 82 02 82 81 15 81 31 6C 65 78 70 00 05 0C 73 65 66 20 6C 61

TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 A

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 00

Expected Sequence 4.2B (LAUNCH BROWSER, use the existing browser, icon self explanatory, requested icon could not be displayed)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING: LAUNCH BROWSER 4.2.1	[Browser is in use, the current session is not secured]]
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : LAUNCH BROWSER 4.2.1	[connect to the default URL, "use the existing browser", alpha id. In UCS2]
4	$\begin{array}{c} ME \to \\ USER \end{array}$	ME displays only the alpha identifier	["Self explan."]
5	$\begin{array}{c} USER \to \\ ME \end{array}$	The user confirms the launch browser.	[user confirmation]
6	$ME \to SIM$	TERMINAL RESPONSE : LAUNCH BROWSER 4.2.1 B	[Command performed successfully]
			[Command performed successfully but requested icon could not be displayed]
7	ME->SS	The ME does not close the existing session and attempts to connect the default URL.	
8	$SIM \to ME$	PROACTIVE SIM SESSION ENDED	
9	USER → ME	The user verifies that the default URL is connected; and the previous URL can be retrieved. Then he/she ends the navigation with the default URL.	

TERMINAL RESPONSE: LAUNCH BROWSER 4.2.1 B

Logically:

Command details

Command number:

Command type: LAUNCH BROWSER
Command qualifier: use the existing browser

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully but requested icon could not be displayed

Coding:

BER-TLV: 81 03 01 15 02 82 02 82 81 83 01 06

27.22.4.27 OPEN CHANNEL

27.22.4.27.1 Definition and applicability

See Section 3.2.2.

27.22.4.27.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

27.22.4.27.3 Test Purpose

To verify that the ME shall send a

- TERMINAL RESPONSE (OK) or
- TERMINAL RESPONSE (Command performed with modification) or
- TERMINAL RESPONSE (Network currently unable to process command)

to the SIM after the ME receives the OPEN CHANNEL proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.27.4 Method of test

27.22.4.27.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.27.4.2 Procedure

Expected Sequence 1.1 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.32)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : OPEN	
		CHANNEL (immediate) 1.1.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.1.1	
		, ,	

PROACTIVE COMMAND: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

81 BER-TLV: D0 1E 03 01 40 01 82 02 81 82 86 33 44 66 77 F8 **B**5 04 09 91 11 22 55

01 07 00 01 B9 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.1.1

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully
Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: 03 01 83 01 00 81 40 01 82 02 82 81 B8 02 81 01 B5 04 01 07 00 01 **B9** 02

00 2A

Expected Sequence 1.2 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.34)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: OPEN CHANNEL	
		1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : OPEN	
		CHANNEL (immediate) 1.2.1	
4	$ME \to SS$	SETUP CALL	
5	$SS \to ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : OPEN	[Command performed successfully]
		CHANNEL (immediate) 1.2.1	

PROACTIVE COMMAND: OPEN CHANNEL 1.2.1

Logically:

Command details

Command number:

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM
Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.34

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

D0 1E 81 03 01 82 BER-TLV: 40 01 02 81 82 86 09 91 22 33 44 66 77 F8 B5 04 11 55 В9 01 07 00 01 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.2.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: 81 03 01 40 01 82 82 81 83 01 00 B8 02 81 01 B5 04 01 07 00 01 B9 02 00 2A

Expected Sequence 1.3 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.120)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	SIM → ME	PROACTIVE COMMAND: OPEN CHANNEL (immediate) 1.3.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.3.1	[Command performed successfully]

PROACTIVE COMMAND: OPEN CHANNEL 1.3.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.34

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: D0 81 03 1E 01 40 01 82 02 81 82 86 09 91 11 22 33 55 66 77 F8 B5 04

01 07 00 01 B9 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.3.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

522

Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 01 00 **B**8 02 81 01 B5 04 01 07 00 01 B9 02 00 2A

Expected Sequence 1.4 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.110 or X.31 flag stuffing, bearer asynchronous UDI)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.4.1	
2	ME → SIM	FETCH	
3	SIM → ME	PROACTIVE COMMAND : OPEN CHANNEL (immediate) 1.4.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	ME → SIM	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.4.1	[Command performed successfully]
	$ME \rightarrow$	TERMINAL RESPONSE : OPEN	[Command performed successfully]

PROACTIVE COMMAND: OPEN CHANNEL 1.4.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.110 or X.31 flag stuffing Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: D0 81 03 02 1E 01 40 01 82 81 82 86 09 91 11 22 33 44 55 66 77 F8 **B**5 04 01 71 00 01 **B9** 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.4.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Bearer Description

Bearer Parameter

Data rate: 9600bps V.110 or X.31 flag stuffing

Bearer Service: data circuit asynchronous UDI

Connection Element: non-transparent

Coding:

40 BER-TLV: 81 03 01 01 82 02 82 81 83 01 00 01 71 00 01 B8 02 81 B5 01 **B9** 02 00 2A

Expected Sequence 1.5 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.32, bearer asynchronous RDI)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.5.1	
2	$ME \rightarrow SIM$	FETCH	
3	SIM → ME	PROACTIVE COMMAND: OPEN CHANNEL (immediate) 1.5.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	ME → SIM	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.5.1	[Command performed successfully]

PROACTIVE COMMAND: OPEN CHANNEL 1.5.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous RDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: D0 1E 81 03 01 40 01 82 02 81 82 86 09 91 22 77 F8 B5 04 11 33 44 55 66 01 07 04 01 B9 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.5.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Bearer Description

Bearer Parameter

Data rate: 9600bps V.32

Bearer Service: data circuit asynchronous RDI

Connection Element: non-transparent

Coding:

40 BER-TLV: 81 03 01 01 82 02 82 81 83 01 00 02 02 B8 81 01 B5 04 01 07 04 01 B9 00 2A

Expected Sequence 1.6 (OPEN CHANNEL, immediate link establishment, CSD, 9600bps V.32, bearer asynchronous)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.6.1	
2	$ME \rightarrow SIM$	FETCH	
3	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND: OPEN CHANNEL (immediate) 1.6.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$ME \rightarrow SIM$	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.6.1	[Command performed successfully]

PROACTIVE COMMAND: OPEN CHANNEL 1.6.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: both, transparent preferred

Buffer size 42

Coding:

BER-TLV: D0 1E 81 03 01 40 82 02 01 81 82 86 09 91 11 22 33 44 55 66 77 F8 **B5** 04 01 07 00 02 B9 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.6.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Bearer Description

Bearer Parameter

Data rate: 9600bps V.32

Bearer Service: data circuit asynchronous

Connection Element: both, transparent preferred

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 01 00 **B8** 02 81 01 B5 04 01 07 00 02 **B**9 02 00 2A

<u>Expected Sequence 1.7</u>(OPEN CHANNEL, immediate link establishment, CSD, 9600 bps, performed with modification)

The system simulator shall be configured such that open channel requests will be accepted with modification

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.7.1	
2	ME → SIM	FETCH	
3	SIM → ME	PROACTIVE COMMAND : OPEN CHANNEL (immediate) 1.7.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	ME → SIM	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.7.1	[Command performed with modification]

PROACTIVE COMMAND: OPEN CHANNEL 1.7.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 64000bps X.31

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

86 BER-TLV: D0 1E 81 03 01 40 01 82 02 81 82 09 91 22 77 F8 B5 04 11 33 44 55 66 01 01 B9 02 00 54 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.7.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed with modification

Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 9600bps V.32

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 01 07 **B8** 02 81 01 B5 01 07 00 01 **B9** 02 00 2A

<u>Expected Sequence 1.8</u> (OPEN CHANNEL, immediate link establishment, CSD, Network currently unable to process command)

The system simulator shall be configured such that open channel requests will be rejected with "No specific cause can be given".

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.8.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND : OPEN CHANNEL (immediate) 1.8.1	
4	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.8.1	[Network currently unable to process command]

PROACTIVE COMMAND: OPEN CHANNEL 1.8.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 64000bps X.31

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: D0 1E 81 03 01 40 01 82 02 81 82 86 09 91 22 33 77 F8 B5 04 11 44 55 66 01 54 00 01 B9 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.8.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Network currently unable to process command

Additional info: No

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 02 21 00

Expected Sequence 1.95 (OPEN CHANNEL, immediate link establishment, CSD, No channel available)

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.9.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	SIM → ME	PROACTIVE COMMAND : OPEN CHANNEL (immediate) 1.9.1	
4	$ME \rightarrow SS$	SETUP CALL	
5	$SS \rightarrow ME$	CONNECTED	
6	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.9.1	[Command performed successfully]
7	SIM → ME	PROACTIVE COMMAND: OPEN CHANNEL (immediate) 1.9.2	
8	ME → SIM	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.9.2	[Bearer independent protocol error]

PROACTIVE COMMAND: OPEN CHANNEL 1.9.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 56000bps V.120

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: D0 1E 81 03 01 40 01 82 02 81 82 86 09 91 22 77 11 33 44 55 66 F8 B5 04 01 78 00 01 B9 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.9.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Command performed successfully

Channel status Channel identifier 1 and link established

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 56000bps V.120

Bearer service: data circuit asynchronous

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 01 00 **B8** 02 81 01 B5 04 01 78 00 01 **B9** 02 00 2A

PROACTIVE COMMAND: OPEN CHANNEL 1.9.2

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: SIM

Destination device: ME

Address

TON: International number

NPI: ISDN / telephone numbering plan

Dialling number string "112233445566778"

Bearer description

Bearer type: CSD

Bearer parameter

Data rate: 56000bps V.120

Bearer service: data circuit asynchronous UDI

Connection element: non-transparent

Buffer size 42

Coding:

BER-TLV: D0 81 03 01 82 02 1E 40 01 81 82 86 09 91 11 22 33 44 55 66 77 F8 B5 04 01 78 00 01 **B9** 02 00 2A

TERMINAL RESPONSE: OPEN CHANNEL 1.9.2

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: Bearer Independent Protocol error

Additional info: No channel available

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 02 3A

01

Expected Sequence 1.10 (OPEN CHANNEL, ME is busy on another call related to CSD)

Step	Direction	MESSAGE / Action	Comments
1	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND PENDING: SET UP CALL 1.10.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND: SET UP CALL 1.10.1	
4	ME → USER	ME displays "Not busy" and prompts the user to set up a call to "+012340123456p1p2"	
5	$\begin{array}{c} \text{USER} \rightarrow \\ \text{ME} \end{array}$	The user confirms the call set up	[user confirmation]
6	ME->SS	The ME attempts to set up a call to "+012340123456p1p2"	
7	$SS \rightarrow ME$	The ME receives the CONNECT message from the system simulator.	

8	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE: SET UP CALL 1.10.1	[Command performed successfully]
9	SIM → ME	PROACTIVE COMMAND PENDING: OPEN CHANNEL 1.1.1	
10	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
11	SIM → ME	PROACTIVE COMMAND : OPEN CHANNEL (immediate) 1.1.1	
12	ME → SIM	TERMINAL RESPONSE : OPEN CHANNEL (immediate) 1.10.1	[ME currently unable to process command]

PROACTIVE COMMAND: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: SIM

Destination device: Network

Alpha identifier: "Not busy"

Address

TON: International

NPI: ISDN / telephone numbering plan

Dialling number string "012340123456p1p2"

Coding:

BER-TLV: D0 1E 81 03 01 00 02 10 82 81 83 85 08 4E 6F 74 20 62 75 73 79 86 09 91 10 32 04 21 43 65 1C 2C

TERMINAL RESPONSE: SET UP CALL 1.10.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: only if not currently busy on another call

Device identities

Source device: Network

Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 83 81 83 01 00

TERMINAL RESPONSE: OPEN CHANNEL 1.10.1

Logically:

Command details

Command number: 1

Command type: OPEN CHANNEL

Command qualifier: immediate link establishment

Device identities

Source device: ME

Destination device: SIM

Result

General Result: ME currently unable to process command

Additional info: ME currently busy on call

Coding:

BER-TLV: 81 03 01 40 01 82 02 82 81 83 02 20

02

27.22.4.28 CLOSE CHANNEL

27.22.4.28.1 Definition and applicability

See Section 3.2.2.

27.22.4.28.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

27.22.4.28.3 Test Purpose

To verify that the ME shall send a

- TERMINAL RESPONSE (Command Performed Successfully) or
- TERMINAL RESPONSE (Bearer Independent Protocol Error)

to the SIM after the ME receives the CLOSE CHANNEL proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.28.4 Method of Test

27.22.4.28.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.28.4.2 Procedure

Expected sequence 1.1 (CLOSE CHANNEL, successful)

For that test, it's mandatory to assume that an open channel proactive command has been successfully executed.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: CLOSE CHANNEL	
		1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND:	
		CLOSE CHANNEL 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE	[Command performed successfully]
		CHANNEL 1.1.1	

PROACTIVE COMMAND: CLOSE CHANNEL 1.1.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Coding:

BER-TLV: D0 09 81 03 01 41 00 82 02 81 21

TERMINAL RESPONSE: CLOSE CHANNEL 1.1.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 41 00 82 02 21 81 83 01 00

Expected sequence 1.2 (CLOSE CHANNEL, with an invalid channel identifier)

For that test, it is assumed that an open channel proactive command has been successfully executed (channel 1).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: CLOSE CHANNEL	
		1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND:	
		CLOSE CHANNEL 1.2.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE	[Invalide channel number]
		CHANNEL 1.2.1	_

PROACTIVE COMMAND: CLOSE CHANNEL 1.2.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 2

Coding:

BER-TLV: D0 09 81 03 01 41 00 82 02 81 22

TERMINAL RESPONSE: CLOSE CHANNEL 1.2.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Bearer Independent Protocol error Additional Result: Channel identifier not valid

Coding:

BER-TLV: 81 03 01 41 00 82 02 21 81 83 02 3A 03

Expected sequence 1.3 (CLOSE CHANNEL, on an already closed channel)

For that test, it is assumed that an open channel proactive command has been successfully executed (channel 1).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND PENDING:	
		CLOSE CHANNEL 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : CLOSE	
		CHANNEL 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE CHANNEL 1.1.1	[Command performed successfully]
_	0.14		
5	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: CLOSE CHANNEL 1.3.1	
6	$ME \rightarrow SIM$		
/	$SIM \rightarrow ME$	PROACTIVE COMMAND : CLOSE	
		CHANNEL 1.3.1	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE CLOSE	[Channel closed]
		CHANNEL 1.3.1	

PROACTIVE COMMAND: CLOSE CHANNEL 1.3.1

Logically:

Command details

Command number:

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Coding:

BER-TLV: D0 09 81 03 01 41 00 82 02 81 21

TERMINAL RESPONSE: CLOSE CHANNEL 1.3.1

Logically:

Command details

Command number: 1

Command type: CLOSE CHANNEL

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Bearer Independent Protocol error

Additional Result: Channel closed

Coding:

BER-TLV: 81 03 01 41 00 82 02 82 81 83 02 3A 02

· ·

27.22.4.29.1 Definition and applicability

RECEIVE DATA

See Section 3.2.2.

27.22.4.29

27.22.4.29.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

27.22.4.29.3 Test Purpose

To verify that the ME shall send a

- TERMINAL RESPONSE (Command Performed Successfully) or
- TERMINAL RESPONSE (ME currently unable to process command) or
- TERMINAL RESPONSE (Bearer Independent Protocol Error)

to the SIM after the ME receives the RECEIVE DATA proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.29.4 Method of test

27.22.4.29.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure. The SIM must have sent the SET UP EVENT LIST to the ME to supply a set of events (event Data available).

27.22.4.29.4.2 Procedure

Expected sequence 1.1 (RECEIVE DATA, already opened channel)

For that test, it is assumed that an open channel proactive command has been successfully executed (with a SIM buffer size of at least 1kB).

Step	Direction	MESSAGE / Action	Comments
1		ENVELOPPE (Data Available)	(1kB bytes of data in the ME buffer)
2	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: RECEIVE	
_		DATA 1.1.1	
3	$ME \rightarrow SIM$		_
4		PROACTIVE COMMAND: RECEIVE DATA 1.1.1	200 Bytes
5		TERMINAL RESPONSE: RECEIVE DATA 1.1.1	
6	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: RECEIVE	
7	ME OIM	DATA 1.1.2	
7	$ME \rightarrow SIM$		200 Putos
8 9		PROACTIVE COMMAND: RECEIVE DATA 1.1.2	200 Bytes
		TERMINAL RESPONSE: RECEIVE DATA 1.1.2	
10	SIIVI → IVIE	PROACTIVE COMMAND PENDING: RECEIVE DATA 1.1.3	
11	$ME \rightarrow SIM$		
12		PROACTIVE COMMAND: RECEIVE DATA 1.1.3	200 Bytes
13		TERMINAL RESPONSE: RECEIVE DATA 1.1.3	200 29,000
14		PROACTIVE COMMAND PENDING: RECEIVE	
	Olivi 7 IVIL	DATA 1.1.4	
15	$ME \rightarrow SIM$	FETCH	
16	$SIM \to ME$	PROACTIVE COMMAND: RECEIVE DATA 1.1.4	200 Bytes
17	$ME \rightarrow SIM$	TERMINAL RESPONSE: RECEIVE DATA 1.1.4	_
18	$SIM \to ME$	PROACTIVE COMMAND PENDING: RECEIVE	
		DATA 1.1.5	
19	$ME \rightarrow SIM$		
20		PROACTIVE COMMAND: RECEIVE DATA 1.1.5	200 Bytes
21	$ME \rightarrow SIM$	TERMINAL RESPONSE: RECEIVE DATA 1.1.5	

PROACTIVE COMMAND: RECEIVE DATA 1.1.1

Logically:

Command details

Command number:

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV: D0 0C 81 03 01 42 00 82 02 81 21 B7 01 C8

PROACTIVE COMMAND: RECEIVE DATA 1.1.2

Logically:

Command details

Command number: 2

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV: D0 0C 81 03 02 42 00 82 02 81 21 B7

01 C8

PROACTIVE COMMAND: RECEIVE DATA 1.1.3

Logically:

Command details

Command number:

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV: D0 0C 81 03 03 42 00 82 02 81 21 B7

01 C8

PROACTIVE COMMAND: RECEIVE DATA 1.1.4

Logically:

Command details

Command number:

Command type: RECEIVE DATA Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV: D0 0C 81 03 04 42 00 82 02 81 21 B7

01 C8

PROACTIVE COMMAND: RECEIVE DATA 1.1.5

Logically:

Command details

Command number: 5

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data Length

Channel Data Length: 200

Coding:

BER-TLV: D0 0C 81 03 05 42 00 82 02 81 21 B7

01 C8

TERMINAL RESPONSE: RECEIVE DATA 1.1.1

Logically:

Command details

Command number:

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: FF

Coding:

BER-TLV: 81 03 01 42 00 82 02 21 81 83 01 00

B6 C8 xx xx xx .

B7 01 FF

TERMINAL RESPONSE: RECEIVE DATA 1.1.2

Logically:

Command details

Command number: 2

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: FF

Coding:

BER-TLV: 81 03 02 42 00 82 02 21 81 83 01 00

B6 C8 xx xx xx ..

B7 01 FF

TERMINAL RESPONSE: RECEIVE DATA 1.1.3

Logically:

Command details

Command number: 3

Command type: RECEIVE DATA

Command qualifier: RFU

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: FF

Coding:

BER-TLV: 81 03 03 42 00 82 02 21 81 83 01 00

B6 C8 xx xx xx .

B7 01 FF

TERMINAL RESPONSE: RECEIVE DATA 1.1.4

Logically:

Command details

Command number: 4 Command type: RECEIVE DATA Command qualifier: RFU

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: C8

Coding:

BER-TLV: 81 03 04 42 00 82 02 21 81 83 01 00

B6 C8 xx xx xx ...

B7 01 C8

TERMINAL RESPONSE: RECEIVE DATA 1.1.5

Logically:

Command details

Command number: 5

Command type: RECEIVE DATA
Command qualifier: RFU Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: 00

Coding:

BER-TLV: 81 03 01 42 00 82 02 21 81 83 01 00

B6 C8 xx xx xx ...

B7 01 00

27.22.4.30 SEND DATA

27.22.4.30.1 Definition and applicability

See Section 3.2.2.

27.22.4.30.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

27.22.4.30.3 Test Purpose

To verify that the ME shall send a

- TERMINAL RESPONSE (Command Performed Successfully) or
- TERMINAL RESPONSE (ME currently unable to process command) or
- TERMINAL RESPONSE (Bearer Independent Protocol Error)

to the SIM after the ME receives the SEND DATA proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.30.4 Method of test

27.22.4.30.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.30.4.2 Procedure

Expected sequence 1.1 (SEND DATA, immediate mode)

For that test, it is assumed that an open channel proactive command has been successfully executed (with a SIM buffer size of 1kB).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: SEND DATA 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : SEND	
		DATA (immediate) 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DATA (immediate) 1.1.1	-

PROACTIVE COMMAND: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

Command type: SEND DATA Command qualifier: Send Immediatly

Device identities

Source device: SIM Channel 1 Destination device:

Channel Data

8 Bytes of data Channel Data:

Coding:

BER-TLV: D0 12 81 03 01 43 01 82 02 81 21 **B6** 80 XXXX XX XX

TERMINAL RESPONSE: SEND DATA 1.1.1

Logically:

Command details

Command number: 1

SEND DATA Command type: Command qualifier: Send Immediatly

Device identities

Channel 1 Source device: Destination device: SIM

Result

General Result:

Command performed successfully

Channel data length: 8 Bytes

Coding:

BER-TLV: 81 03 01 43 01 82 02 21 81 83 01 00 B7 01 80

Expected sequence 1.2 (SEND DATA, Store mode)

For that test, it is assumed that an open channel proactive command has been successfully executed (with a SIM buffer size of 1kB).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$		
		SEND DATA 1.2.1	
2	$ME \rightarrow SIM$		
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DATA (store mode) 1.2.1	Send 500 Bytes of data (200 + 200 + 100)
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND DATA (store mode) 1.2.1	[Command performed successfully]
5	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND DATA 1.2.2	
6	$ME \rightarrow SIM$		
7	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		DATA (store mode) 1.2.2	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DATA (store mode) 1.2.2	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING:	
40		SEND DATA 1.2.3	
10	$ME \rightarrow SIM$		
11	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND	
		DATA (Immediate mode) 1.2.3	
12	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND	[Command performed successfully]
		DATA (Immediate mode) 1.2.3	

PROACTIVE COMMAND: SEND DATA 1.2.1

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data : 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 00 82 02 81 21 B6

C8 xx xx xx xx ...

TERMINAL RESPONSE: SEND DATA 1.2.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 00 82 02 21 81 83 01 00

B7 01 FF

PROACTIVE COMMAND: SEND DATA 1.2.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 00 82 02 81 21 B6

C8 xx xx xx xx ..

TERMINAL RESPONSE: SEND DATA 1.2.2

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 00 82 02 21 81 83 01 00

B7 01 FF

PROACTIVE COMMAND: SEND DATA 1.2.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Immediate mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 100 Bytes of data

Coding:

BER-TLV: D0 6F 81 03 01 43 01 82 02 81 21 B6

64 xx xx xx xx ...

TERMINAL RESPONSE: SEND DATA 1.2.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Immediate mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 01 82 02 21 81 83 01 00

B7 01 FF

Expected sequence 1.3 (SEND DATA, Store mode, Tx buffer fully used)

For that test, it is assumed that an open channel proactive command has been successfully executed (with a SIM buffer size of 1kB).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
		DATA 1.3.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DATA (store	Send 1kByte of data by packet of 200 Bytes
		mode) 1.3.1	
4	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND DATA (store	[Command performed successfully]
		mode) 1.3.1	
5	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
		DATA 1.3.2	
6	$ME \rightarrow SIM$		
7	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DATA (store	[200 Bytes]
		mode) 1.3.2	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE : SEND DATA (store	[Command performed successfully]
		mode) 1.3.2	
9	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
4.0		DATA 1.3.3	
10	$ME \rightarrow SIM$		
11	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DATA (store	[200 Bytes]
40		mode) 1.3.3	
12	$ME \rightarrow SIM$		[Command performed successfully]
40	0.14	mode) 1.3.3	
13	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: SEND	
4.4	NAT CINA	DATA 1.3.4	
14	$ME \rightarrow SIM$		[000 D. 400]
15	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DATA (store	[200 Bytes]
16	ME CIM	mode) 1.3.4 TERMINAL RESPONSE : SEND DATA (store	[Command performed successfully]
10	$ME \rightarrow SIM$	mode) 1.3.4	[Command performed successfully]
17	SIM → ME	PROACTIVE COMMAND PENDING: SEND	
17	SIIVI → IVIE	DATA 1.3.5	
18	$ME \rightarrow SIM$		
19	$SIM \rightarrow ME$	PROACTIVE COMMAND : SEND DATA	[200 Bytes]
19	SIIVI → IVIE	(immediate) 1.3.5	[ZOO Dyles]
20	$ME \rightarrow SIM$		[Command performed successfully]
	IVIE -> SIIVI	(immediate) 1.3.5	[Command performed adocessiony]
		Millinodiate) 1.0.0	

PROACTIVE COMMAND: SEND DATA 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data : 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 00 82 02 81 21 B6 C8 XX XX XXXX

TERMINAL RESPONSE: SEND DATA 1.3.1

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 00 82 02 21 81 83 01 00

B7 01 FF

PROACTIVE COMMAND: SEND DATA 1.3.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 00 82 02 81 21 B6

C8 xx xx xx xx ...

TERMINAL RESPONSE: SEND DATA 1.3.2

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 00 82 02 21 81 83 01 00

B7 01 FF

PROACTIVE COMMAND: SEND DATA 1.3.3

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 00 82 02 81 21 B6

C8 xx xx xx xx ..

TERMINAL RESPONSE: SEND DATA 1.3.3

Logically:

Command details

Command number:

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: More than 255 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 00 82 02 21 81 83 01 00

B7 01 FF

PROACTIVE COMMAND: SEND DATA 1.3.4

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: SIM
Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 00 82 02 81 21 B6

C8 xx xx xx xx ..

TERMINAL RESPONSE: SEND DATA 1.3.4

Logically:

Command details

Command number: 1

Command type: SEND DATA
Command qualifier: Store mode

Device identities

Source device: Channel 1
Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: 200 bytes of space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 00 82 02 21 81 83 01 00

B7 01 C8

PROACTIVE COMMAND: SEND DATA 1.3.5

Logically:

Command details

Command number: 1

Command type: SEND DATA

Command qualifier: Send Immediatly

Device identities

Source device: SIM

Destination device: Channel 1

Channel Data

Channel Data: 200 Bytes of data

Coding:

BER-TLV: D0 D3 81 03 01 43 01 82 02 81 21 B6

 $C8 \hspace{0.4cm} xx \hspace{0.4cm} xx \hspace{0.4cm} xx \hspace{0.4cm} xx \hspace{0.4cm} x \hspace{$

TERMINAL RESPONSE: SEND DATA 1.3.5

Logically:

Command details

Command number: 1

Command type: SEND DATA

Command qualifier: Send Immediatly

Device identities

Source device: Channel 1

Destination device: SIM

Result

General Result: Command performed successfully

Channel data length: No space available in the Tx buffer

Coding:

BER-TLV: 81 03 01 43 01 82 02 21 81 83 01 00 B7 01 00

Expected sequence 1.4 SEND DATA, 2 consecutive SEND DATA Store mode)

For that test, it is assumed that an open channel proactive command has been successfully executed (with a SIM buffer size of 1kB).

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING: SEND DATA 1.3.1	
2	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
3	SIM → ME	PROACTIVE COMMAND : SEND DATA (store mode) 1.3.1	Send 1kByte of data by packet of 200 Bytes
4	ME → SIM	TERMINAL RESPONSE : SEND DATA (store mode) 1.3.1	[Command performed successfully]
•••	•••		
19	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND : SEND DATA (immediate) 1.3.5	
20	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE : SEND DATA (immediate) 1.3.5	[Command performed successfully]
21	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND PENDING: SEND DATA 1.3.1	
22	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	FETCH	
23	SIM → ME	PROACTIVE COMMAND : SEND DATA (store mode) 1.3.1	Send 1kByte of data by packet of 200 Bytes

24	$\begin{array}{c} \text{ME} \rightarrow \\ \text{SIM} \end{array}$	TERMINAL RESPONSE : SEND DATA (store mode) 1.3.1	[Command performed successfully]
•••	•••		····
39	$\begin{array}{c} \text{SIM} \rightarrow \\ \text{ME} \end{array}$	PROACTIVE COMMAND : SEND DATA (immediate) 1.3.5	
40	ME → SIM	TERMINAL RESPONSE : SEND DATA (immediate) 1.3.5	[Command performed successfully]

Expected sequence 1.5 (SEND DATA, immediate mode with a bad channel identifier)

For that test, it is assumed that an open channel proactive command has been successfully executed (channel 1).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow$	PROACTIVE COMMAND	
	ME	PENDING: SEND DATA 1.5.1	
2	$ME \rightarrow$	FETCH	
	SIM		
3	$SIM \rightarrow$	PROACTIVE COMMAND :	
	ME	SEND DATA (immediate) 1.5.1	
4	$ME \rightarrow$	TERMINAL RESPONSE : SEND	[Invalide channel number]
	SIM	DATA (immediate) 1.1.1	

PROACTIVE COMMAND: SEND DATA 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND DATA

Command qualifier: Send Immediatly

Device identities

Source device: SIM

Destination device: Channel 1

Channel Data

Channel Data: 8 Bytes of data

Coding:

BER-TLV: D0 03 01 82 02 81 22 81 01 43 B6 08 XXXXXXXX

TERMINAL RESPONSE: SEND DATA 1.5.1

Logically:

Command details

Command number: 1

Command type: SEND DATA

Command qualifier: Send Immediatly

Device identities

Source device: Channel 1

Destination device: SIM

Result

General Result: Bearer Independent Protocol error (3A)

Additional Result: Channel identifier not valid (03)

Coding:

BER-TLV: 81 03 01 43 01 82 02 21 81 83 02 3A

03

Expected sequence 1.6 (SEND DATA, immediate mode, Proactive SIM session terminated by the user)

For that test, it is assumed that an open channel proactive command has been successfully executed.

Step	Direction	MESSAGE / Action	Comments
1	SIM → ME	PROACTIVE COMMAND PENDING; SEND DATA 1.6.1	
2	ME → SIM	FETCH	
3	SIM → ME	PROACTIVE COMMAND : SEND DATA (immediate) 1.6.1	
4	ME → SIM	TERMINAL RESPONSE : SEND DATA (immediate) 1.1.1	[Proactive SIM session terminated by the user]

PROACTIVE COMMAND: SEND DATA 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND DATA

Command qualifier: Send Immediatly

Device identities

Source device: SIM

Destination device: Channel 1

Channel Data

Channel Data: 8 Bytes of data

Coding:

BER-TLV: D0 12 81 03 01 43 01 82 02 81 22 B6

08 xx xx xx xx ...

TERMINAL RESPONSE: SEND DATA 1.6.1

Logically:

Command details

Command number: 1

Command type: SEND DATA

Command qualifier: Send Immediatly

Device identities

Source device: Channel 1

Destination device: SIM

Result

General Result: Proactive SIM session terminated by the user

Coding:

BER-TLV: 81 03 01 43 01 82 02 21 81 83 01 10

27.22.4.31 GET CHANNEL STATUS

27.22.4.31.1 Definition and applicability

See Section 3.2.2.

27.22.4.31.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

27.22.4.31.3 Test Purpose

To verify that the ME shall send a TERMINAL RESPONSE (Command Performed Successfully) to the SIM after the ME receives the GET STATUS proactive command. The TERMINAL RESPONSE sent back to the SIM is function of the ME and the network capabilities against asked parameters by the SIM.

27.22.4.31.4 Method of test

27.22.4.31.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.4.31.4.2 Procedure

Expected sequence 1.1 (GET STATUS, without any BIP channel opened)

For that test, no channel has been opened.

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	
		PENDING: GET CHANNEL	
		STATUS 1.1.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	
		STATUS 1.1.1	
4	$ME \rightarrow SIM$	TERMINAL GET STATUS 1.1.1	[Command performed successfully]

PROACTIVE COMMAND: GET STATUS 1.1.1

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 44 00 82 02 81 82

TERMINAL RESPONSE: GET STATUS 1.1.1

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: No Channel, link not established

Coding:

BER-TLV: 81 03 01 44 00 82 02 82 81 83 01 00 88 02 00 00

Expected sequence 1.2 (GET STATUS, with a BIP channel currently opened)

For that test, it is assumed that an OPEN CHANNEL proactive command has been successfully executed (Channel 1).

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	
		PENDING: GET CHANNEL	
		STATUS 1.2.1	
2	$ME \rightarrow SIM$	FETCH	
3	$SIM \to ME$	PROACTIVE COMMAND : GET	
		STATUS 1.2.1	
4	$ME \rightarrow SIM$	TERMINAL GET STATUS 1.2.1	[Command performed successfully]

PROACTIVE COMMAND: GET STATUS 1.2.1

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 44 00 82 02 81 82

TERMINAL RESPONSE: GET STATUS 1.2.1

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: Channel 1 open, link established

Coding:

BER-TLV: 03 01 44 00 82 02 82 81 83 01 00 81 B8 02 81 00

Expected sequence 1.3 (GET STATUS, after a link dropped)

For that test, it is assumed that an OPEN CHANNEL proactive command has been successfully executed (Channel 1).

Step	Direction	MESSAGE / Action	Comments
1	$ME \rightarrow SIM$	ENVELOPE EVENT DOWNLOAD : CHANNEL	[Link dropped]
		STATUS 1.3.1	
2	$SIM \rightarrow ME$	PROACTIVE COMMAND PENDING: GET	
		STATUS 1.3.1	
3	$ME \rightarrow SIM$	FETCH	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND : GET STATUS 1.3.1	
5	$ME \rightarrow SIM$	TERMINAL GET STATUS 1.3.1	[Command performed successfully]

ENVELOPE EVENT DOWNLOAD: CHANNEL STATUS 1.3.1

Logically:

Event list

Event list: Channel Status

Device identities

Source device: ME
Destination device: SIM

Channel status

Channel status: Channel 1, link dropped

Coding:

BER-TLV: D6 0B 99 01 0A 82 02 82 81 B8 02 01

05

PROACTIVE COMMAND: GET STATUS 1.3.1

Logically:

Command details

Command number: 1

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 44 00 82 02 81 82

TERMINAL RESPONSE: GET STATUS 1.3.1

Logically:

Command details

Command number:

Command type: GET STATUS

Command qualifier: RFU

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Channel status

Channel status: Channel 1, link dropped

Coding:

BER-TLV: 03 01 44 00 82 02 82 81 83 01 00 81 B8 02 01 05

27.22.5 DATA DOWNLOAD TO SIM

27.22.5 Data Download to SIM

27.22.5.1 SMS-PP Data Download

27.22.5.1.1 Definition and applicability

See Section 3.2.2.

27.22.5.1.2 Conformance requirement

The ME shall support the Proactive SIM: SMS-PP Data Download facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.3 (Data download to SIM), 5 (Profile Download), 7.1 (SMS-PP data download), clause 12.1 (Address) clause 12.7 (Device Identities), clause 12.13 (SMS TPDU).

27.22.5.1.3 Test Purpose

To verify that the ME transparently passes the "data download via SMS Point-to-point" messages to the SIM.

To verify that the ME returns the RP-ACK message back to the system Simulator, if the SIM responds with '90 00' or '91 XX'.

To verify that the ME returns the response data from the SIM back to the system Simulator in the TP-User-Data element of the RP-ACK message, if the SIM responds with '9F XX'.

27.22.5.1.4 Method of Test

27.22.5.1.4.1 Initial Conditions

The ME is connected to the system Simulator and the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.5.1.4.2 Procedure

Expected Sequence 1.1 (SMS-PP Data Download, General Data Coding, Default Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	ME	The ME shall be in its normal idle mode	[Start a sequence to verify that the ME returns the RP-ACK message back to the system Simulator, if the SIM responds with '90 00']
2	$SS \to ME$	SMS-PP Data Download Message 1.1.1	-
3	ME → USER	The ME shall not display the message or alert the user of a short message waiting	
4	$ME \rightarrow SIM$	ENVELOPE: SMS-PP DOWNLOAD 1.1.2	
5	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
6	$ME \rightarrow SS$	RP-ACK.	

SMS-PP (Data Download) Message 1.1.1

Logically:

SMS TPDU **SMS-DELIVER** TP-MTI No more messages waiting for the MS in this SC TP-MMS TP-RP TP-Reply-Path is not set in this SMS-DELIVER TP-UDHI TP-UD field contains only the short message TP-SRI A status report will not be returned to the SME TP-OA TON International number "ISDN / telephone numbering plan" **NPI** "1234" Address value TP-PID SIM Data download TP-DCS Coding Group General Data Coding Compression Text is uncompressed Message Class Class 2 SIM Specific Message Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0 TP-UDL 13 TP-UD "Short Message"

Coding:

BER-TLV	04	03	91	21	43	7F	12	89	10	10	00	00
	00	00	0D	53	F4	5B	4E	07	35	CB	F3	79
	Гο	FC	O.C									

ENVELOPE: SMS-PP DOWNLOAD 1.1.2

Logically:

SMS-PP Download Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet Default Alphabet TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV: 2C 82 02 83 81 09 91 11 22 33 D1 06 44 55 66 77 F8 8B 1B 04 04 91 21 43 7F 0D F4 12 89 10 10 00 00 00 00 53 5B 4E 07 35 CB F3 79 F8 5C 06

Expected Sequence 1.2 (SMS-PP Data Download, General Data Coding, Default Alphabet, GET RESPONSE, Acknowledgement)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-PP Data Download Message	
		1.2.1	
2	ME o	The ME shall not display the	
	USER	message or alert the user of a	
		short message waiting.	
3	$ME \rightarrow SIM$	 ENVELOPE: SMS-PP	
3	IVIE -> SIIVI	DOWNLOAD 1.2.2	
4	CINA . NAT		[CW4 / CW2 of OF OP]
	$SIM \rightarrow ME$		[SW1 / SW2 of '9F 0B']
5	$ME \rightarrow SIM$	GET RESPONSE	
6	$SIM \rightarrow ME$	SMS-PP Data Download SIM	
		Acknowledgement 1.2.3	
7	$ME \to SS$	SMS-PP Data Download SIM	
		Acknowledgement 1.2.4 in the TP-	
		User-Data element of the RP-ACK	
		message. The values of protocol	
		identifier and data coding scheme	
		in RP-ACK shall be as in the	
		original message.	

Expected Sequence 1.3 (SMS-PP Data Download, General Data Coding, Default Alphabet, FETCH, MORE TIME)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	SMS-PP Data Download Message	
		1.3.1	
2	ME o	The ME shall not display the	
	USER	message or alert the user of a	
		short message waiting	
3	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
		DOWNLOAD 1.3.2	
4	$SIM \rightarrow ME$	PROACTIVE COMMAND	[SW1 / SW2 of '91 0B']
		PENDING: MORE TIME 1.3.3	
5	$ME \rightarrow SS$	RP-ACK	
6	$ME \rightarrow SIM$	FETCH	
7	$SIM \rightarrow ME$	PROACTIVE COMMAND: MORE	
		TIME 1.3.4	
8	$ME \rightarrow SIM$	TERMINAL RESPONSE: MORE	
		TIME 1.3.5	
9	$SIM \rightarrow ME$	PROACTIVE SIM SESSION	
		ENDED	

PROACTIVE COMMAND: MORE TIME 1.3.4

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 02 00 82 02 81 82

TERMINAL RESPONSE: MORE TIME 1.3.5

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 02 00 82 02 82 81 83 01 00

Expected Sequence 1.4 (SMS-PP Data Download, General Data Coding, 8 Bit Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	SMS-PP Data Download Message	
		1.4.1	
2	ME	The ME shall not display the	
		message or alert the user of a	
		short message waiting	
3	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
		DOWNLOAD 1.4.2	
4	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
5	$ME \to SS$	RP-ACK	

SMS-PP (Data Download) Message 1.2.1 / 1.3.1 / 1.4.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet 8 bit

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

7F BER-TLV: 04 03 91 21 43 16 89 10 10 00 00 53 00 00 0D 68 6F 72 74 20 4D 65 73

73 61 67 65

ENVELOPE: SMS-PP DOWNLOAD 1.2.2 / 1.3.2 / 1.4.2,

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group General Data Coding Compression Text is uncompressed

Message Class Class 2 SIM Specific Message

Alphabet 8 bit

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV:	D1	2D	82	02	83	81	06	09	91	11	22	33
	44	55	66	77	F8	8B	1C	04	04	91	21	43
	7F	16	89	10	10	00	00	00	00	0D	53	68
	6F	72	74	20	4D	65	73	73	61	67	65	

Expected Sequence 1.5 (SMS-PP Data Download, Data Coding / Message Class, Default Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	ME	The ME shall be in its normal idle	
2	$SS \to ME$	mode. SMS-PP Data Download Message 1.5.1.	
3	ME	The ME shall not display the	
		message or alert the user of a	
4	$ME \rightarrow SIM$	short message waiting ENVELOPE: SMS-PP DOWNLOAD 1.5.2.	
5	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
6	$ME \rightarrow SS$	RP-ACK	

SMS-PP (Data Download) Message 1.5.1

Logically:

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding Default Alphabet

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

03 43 7F 10 00 BER-TLV: 04 91 21 F2 89 10 00 00 00 0D 53 F4 5B 4E 35 CB F3 79 07

F8 5C 06

ENVELOPE: SMS-PP DOWNLOAD 1.5.2

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding Default Alphabet

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV: D1 2C 82 02 83 22 33 81 06 09 91 11 66 77 F8 8B 1B 04 04 91 21 43 44 55

89 07 7F 5B F2 4E 00 F8 00 5C 0D 06 10 10 00 00 53 F4 35 СВ 79 F3

Expected Sequence 1.6 (SMS-PP Data Download, with Data Coding / Message Class, 8 Bit Alphabet)

Step	Direction	MESSAGE / Action	Comments
1	$SS \rightarrow ME$	SMS-PP Data Download Message	
		1.6.1	
2	ME	The ME shall not display the	
		message or alert the user of a	
		short message waiting	
3	$ME \rightarrow SIM$	ENVELOPE: SMS-PP	
		DOWNLOAD 1.6.2	
4	$SIM \rightarrow ME$	SW1 / SW2 of '90 00'	
5	$ME \to SS$	RP-ACK	

SMS-PP (Data Download) Message 1.6.1

Logically: **SMS TPDU SMS-DELIVER** TP-MTI TP-MMS No more messages waiting for the MS in this SC TP-RP TP-Reply-Path is not set in this SMS-DELIVER TP-UDHI TP-UD field contains only the short message TP-SRI A status report will not be returned to the SME TP-OA TON International number "ISDN / telephone numbering plan" **NPI** "1234" Address value TP-PID SIM Data download **TP-DCS** Coding Group Data Coding / Message Class Message Coding Message Class Class 2 SIM Specific Message TP-SCTS: 01/01/98 00:00:00 +0 TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV: 03 43 7F 00 04 91 21 F6 89 10 10 00 00 00 0D 53 68 6F 74 20 4D 65 73 72 73 61 67 65

ENVELOPE: SMS-PP DOWNLOAD 1.6.2

Logically:

SMS-PP Download

Device identities

Source device: Network
Destination device: SIM

Address

TON International number

NPI "ISDN / telephone numbering plan"

Dialling number string "112233445566778"

SMS TPDU

TP-MTI SMS-DELIVER

TP-MMS No more messages waiting for the MS in this SC
TP-RP TP-Reply-Path is not set in this SMS-DELIVER
TP-UDHI TP-UD field contains only the short message
TP-SRI A status report will not be returned to the SME

TP-OA

TON International number

NPI "ISDN / telephone numbering plan"

Address value "1234"

TP-PID SIM Data download

TP-DCS

Coding Group Data Coding / Message Class

Message Coding 8 bit

Message Class Class 2 SIM Specific Message

TP-SCTS: 01/01/98 00:00:00 +0

TP-UDL 13

TP-UD "Short Message"

Coding:

BER-TLV:	D1	2D	82	02	83	81	06	09	91	11	22	33
	44	55	66	77	F8	8B	1C	04	04	91	21	43
	7F	F6	89	10	10	00	00	00	00	0D	53	68
	6F	72	74	20	4D	65	73	73	61	67	65	

SMS-PP Data Download SIM Acknowledgement 1.2.4

Coding: 50 68 69 6C 20 48 6F 6F 6B 65 72

27.22.5.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequences.

27.22.5.2 SMS-CB Data Download

27.22.5.2.1 Definition and applicability

See Section 3.2.2.

27.22.5.2.2 Conformance requirement

The ME shall support the Proactive SIM: SMS-CB Data Download facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.3 (Data download to SIM), 5 (Profile Download), clause 7.2 (Cell Broadcast data download), clause 12.5 (Cell Broadcast Page), clause 12.7 (Device Identities).

27.22.5.2.3 Test Purpose

To verify that the ME transparently passes the "data download via SMS Cell Broadcast" messages to the SIM, which contain a message identifier found in EF_{CBMID} .

27.22.5.2.4 Method of Test

27.22.5.2.4.1 Initial Conditions

The ME is connected to the system Simulator and the SIM Simulator.

The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.5.2.4.2 Procedure

Expected Sequence 1 (SMS-CB (Data Download), ENVELOPE(SMS-CB DOWNLOAD), ME does not display message)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-CB (DATA DOWNLOAD)	Message identifier '10 01'
2	$ME \rightarrow SIM$	1.1 ENVELOPE (SMS-CB DOWNLOAD) 1.1	
3	$SIM \rightarrow ME$	SW1, SW2 '90 00'	

SMS-CB (Data Download) Message 1.1

Logically:

Message Content

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "1001"

Data Coding Scheme

Message coding: 8 bit data

Message class: No message class

Page Parameter

Total number of pages: 1
Page number: 1

Content of message: "Cell Broadcast "...

Coding:

BER-TLV:	C0	11	10	01	F4	11	43	65	6C	6C	20	42
	72	6F	61	64	63	61	73	74	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20								

ENVELOPE: SMS-CB DOWNLOAD 1.1

Logically:

Cell Broadcast Download Device identities

Source device: Network
Destination device: SIM

Cell Broadcast page

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "1001"

Data Coding Scheme

Message coding: 8 bit data
Message class: No message class

Page Parameter

Number of pages: 1 Page number: 1

Content of message: "Cell Broadcast"...

Coding:

BER-TLV: 8C D2 5E C0 F4 6C 6C 6F

Expected Sequence 2 (SMS-CB(DATA DOWNLOAD), ENVELOPE(SMS-CB DATA DOWNLOAD), FETCH, MORE TIME, ME does not display message)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-CB (DATA DOWNLOAD)	Message identifier '10 01'
		1.1	
2	$\text{ME} \to \text{SIM}$	ENVELOPE (SMS-CB	
		DOWNLOAD) 1.1	
3	$SIM \to ME$		SW1/SW2 '91 0B'
4	$ME \to SIM$	FETCH 1.1	
5	$SIM \to ME$	PROACTIVE COMMAND:MORE	
		TIME 1.1	
6	$ME \to SIM$	TERMINAL RESPONSE	
7	$SIM \to ME$	SW1/SW2 '90 00'	SIM session ended

PROACTIVE COMMAND: MORE TIME 1.1

Logically:

Command details

Command number: 1

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: SIM
Destination device: ME

Coding:

BER-TLV: D0 09 81 03 01 02 00 82 02 81 82

TERMINAL RESPONSE: MORE TIME 1.1

Logically:

Command details

Command number:

Command type: MORE TIME

Command qualifier: "00"

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 02 00 82 02 82 81 83 01 00

Expected Sequence 3 (SMS-CB (DATA DOWNLOAD), ME displays message)

Step	Direction	MESSAGE / Action	Comments
1	$SS \to ME$	SMS-CB (DATA DOWNLOAD)	Message identifier '0C 0C'
		1.2	

SMS-CB (Data Download) Message 1.2

Logically:

Message Content

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "0C0C"

Data Coding Scheme

Message coding: 8 bit data

Message class: No message class

Page Parameter

Total number of pages: 1
Page number: 1

Content of message: "Cell Broadcast".

Coding:

BER-TLV: C0 0C 0C F4 6C 6C 6F

ENVELOPE: SMS-CB DOWNLOAD 1.1

Logically:

Cell Broadcast Download Device identities

Source device: Network
Destination device: SIM

Cell Broadcast page

Serial Number

Geographical scope: Cell wide, normal display mode

Message code: 1
Update number: 1
Message Identifier: "0C0C"

Data Coding Scheme

Message coding: 8 bit data

Message class: No message class

Page Parameter

Number of pages: 1 Page number: 1

Content of message: "Cell Broadcast"...

Coding:

BER-TLV:	D2	5E	82	02	83	81	8C	58	C0	11	0C	0C
	F4	11	43	65	6C	6C	20	42	72	6F	61	64
	63	61	73	74	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20
	20	20	20	20	20	20	20	20	20	20	20	20

27.22.5.2.5 Test Requirement

The ME shall operate in the manner defined in expected sequences.

27.22.6 CALL CONTROL BY SIM

27.22.6.1 Procedure for Mobile Originated calls

27.22.6.1.1 Definition and applicability

See Section 3.2.2.

27.22.6.1.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 9.1.1

27.22.6.1.3 Test Purpose

To verify that for all call set-up attempts , even those resulting from a SET UP CALL proactive SIM command, the ME shall first pass the call set-up details (dialled digits and associated parameters) to the SIM, using the ENVELOPE (CALL CONTROL)

To verify that if the SIM responds with '90 00', the ME shall set up the call with the dialled digits and other parameters as sent to the SIM.

To verify that if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to set up the call as proposed, not set up the call, set up a call using the data supplied by the SIM

To verify that, in the case where the initial call set-up request results from a proactive SET UP CALL, if the call control result is "not allowed" or "allowed with modifications", the ME shall inform the SIM using TERMINAL RESPONSE "interaction with call control by SIM or MO short message control by SIM, action not allowed".

To verify that it is possible for the SIM to request the ME to set up an emergency call by supplying the number "112" as the response data.

27.22.6.1.4 method of tests

27.22.6.1.4.1 Initial Conditions

The ME is connected to the System Simulator and has performed the location update procedure.

The GSM parameters of the system simulator are:

Mobile country Code (MCC) = 1,

Mobile network code (MNC) = 1,

Location Area code (LAC) = 1,

Cell Identity value = 1,

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

27.22.6.1.4.2 Procedure

Expected Sequence 1.1 (CALL CONTROL BY SIM, set up call attempt by user, the SIM responds with '90 00')

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.1.1	
3	SIM -> ME	90 00	
4	ME	The ME sets up the call without	[Set up call to
		modification	"+01234567890123456789"

ENVELOPE CALL CONTROL 1.1.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 82 02 1A 82 81 86 0B 91 10 32 54 32 54 F1 76 98 10 76 98 13 07 00 10 00 01 00 01

Expected Sequence 1.2 (CALL CONTROL BY SIM, set up call attempt by user, allowed without modification)

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.2.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.2.1	[Call control result : "Allowed, no
			modification"]
6	ME	The ME sets up the call without	[Set up call to
		modification	"+01234567890123456789"

ENVELOPE CALL CONTROL 1.2.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1) Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 1A 0B F1

CALL CONTROL RESULT 1.2.1

Logically:

Call control result : '00' = Allowed, no modification

Coding

BER-TLV: 00 00

Expected Sequence 1.3 (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, allowed without modification)

Step	Direction	Message / Action	Comments
1	SIM -> ME	PROACTIVE COMMAND PENDING	
2	ME->SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET UP CALL 1.3.1	[Set up call to "+012340123456"
4	ME -> SIM	ENVELOPE CALL CONTROL 1.3.1	
5	SIM -> ME	9F 02	
6	ME -> SIM	GET RESPONSE	
7	SIM -> ME	CALL CONTROL RESULT 1.3.1	[Call control result : "Allowed, no modification"]
8	ME -> SIM	TERMINAL RESPONSE: SET UP CALL 1.3.1	[command performed successfully]
9	ME	The ME sets up the call without modification	[Set up call to "+012340123456"

PROACTIVE COMMAND: SET UP CALL 1.3.1

Logically:

Command details

Command number:

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: the initial phone number ("+012340123456")

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding

BER-TLV: D0 0D 2B

ENVELOPE CALL CONTROL 1.3.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 16 02 02 82 81 06 07 91 10 32

04 21 43 65 13 07 00 F1 10 00 01

00 01

CALL CONTROL RESULT 1.3.1

Logically:

Call control result : '00' = Allowed, no modification

Coding

BER-TLV: 00 00

TERMINAL RESPONSE: SET UP CALL 1.3.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 1.4 (CALL CONTROL BY SIM, set up call attempt by user, not allowed)

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.4.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.4.1	[Call control result : "not Allowed"]
6	ME	The ME does not set up the call	

ENVELOPE CALL CONTROL 1.4.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 1A 82 02 82 81 86 0B 32 91 10 54 32 54 F1 10 76 98 10 76 98 13 07 00

00 01 00 01

CALL CONTROL RESULT 1.4.1

Logically:

Call control result: '01' = not Allowed

Coding

BER-TLV: 01 00

Expected Sequence 1.5 (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, not allowed)

Step	Direction	Message / Action	Comments
1	SIM -> ME	PROACTIVE COMMAND	
		PENDING	
2	ME->SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET	[Set up call to "+012340123456"
		UP CALL 1.5.1	
4	ME -> SIM	ENVELOPE CALL CONTROL	
		1.5.1	
5	SIM -> ME	9F 02	
6	ME -> SIM	GET RESPONSE	
7	SIM -> ME	CALL CONTROL RESULT 1.5.1	[Call control result : "Not Allowed"]
8	ME -> SIM	TERMINAL RESPONSE: SET UP	Permanent Problem – Interaction with
		CALL 1.5.1	Call Control by SIM]
9	ME	The ME does not set up the call	

PROACTIVE COMMAND: SET UP CALL 1.5.1

Command details

Command number:

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: the initial phone number ("+012340123456")

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding

BER-TLV: D0 21 81 03 01 10 00 82 02 81 83

05 0D 30 33 30 32 2B 31 32 34 31 33 34 36 86 07 10 32 04 21

43 65

ENVELOPE CALL CONTROL 1.5.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 16 02 02 82 81 06 07 91 10 32

04 21 43 65 13 07 00 F1 10 00 01

00 01

CALL CONTROL RESULT 1.5.1

Logically:

Call control result: 01' = not Allowed

Coding

BER-TLV: 01 00

TERMINAL RESPONSE: SET UP CALL 1.5.1

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Interaction with call control by SIM or MO short message control by SIM,

permanent problem

Additional information: Action not allowed

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 02 39

01

Expected Sequence 1.6 (CALL CONTROL BY SIM, set up call attempt by user, allowed with modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.6.1	
3	SIM -> ME	9F 07	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.6.1	[Call control result : "Allowed with
			modifications",]
6	ME	The ME sets up the call to	
		"+010203"	

ENVELOPE CALL CONTROL 1.6.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 82 02 1A 82 81 86 0B 91 10 32 54 32 54 00 F1 76 98 10 76 98 13 07 10

00 01 00 01

CALL CONTROL RESULT 1.6.1

Logically:

Call control result: '02' = Allowed with modifications

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "010203"

Coding

Coding: 02 06 86 04 91 10 20 30

Expected Sequence 1.7 (CALL CONTROL BY SIM , set up call attempt resulting from a set up call proactive command, allowed with modifications)

Step	Direction	Message / Action	Comments
1	SIM -> ME	PROACTIVE COMMAND	
		PENDING	
2	ME->SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET	[Set up call to "+012340123456"
		UP CALL 1.7.1	
4	ME -> SIM	ENVELOPE CALL CONTROL	
		1.7.1	
5	SIM -> ME	9F 0B	
6	ME -> SIM	GET RESPONSE	
7	SIM -> ME	CALL CONTROL RESULT 1.7.1	[Call control result : "Allowed with
			modifications",]
8	ME -> SIM	TERMINAL RESPONSE: SET UP	[command performed successfully]
		CALL 1.7.1	
9	ME	The ME sets up the call to	
		"+011111111111"	

PROACTIVE COMMAND: SET UP CALL 1.7.1

Device identities

Source device: ME
Destination device: SIM

Address

TON: National

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+012340123456"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1) Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 15 02 02 82 81 06 06 80 FB 21

43 10 32 13 07 00 F1 10 00 01 00

01

ENVELOPE CALL CONTROL 1.7.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "012340123456"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1) Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 16 02 02 82 81 06 07 91 10 32

00 01

CALL CONTROL RESULT 1.7.1

Logically:

Call control result: '02' = Allowed with modifications

Address

TON: National

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "+012340123450"

Coding

BER-TLV: 02 0A 86 06 07 91 10 11 11 11 11

11

TERMINAL RESPONSE: SET UP CALL 1.7.1

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

Expected Sequence 1.8 (CALL CONTROL BY SIM , set up call attempt by user, allowed with modifications : emergency call)

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.8.1	
3	SIM -> ME	9F 06	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.8.1	[Call control result : "Allowed with modifications",]
6	ME	The ME sets up the emergency call to "112"	

ENVELOPE CALL CONTROL 1.8.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 1A 82 02 82 81 0B 10 86 91 32 54 F1 76 98 10 32 54 76 98 13 07 00 10 01

CALL CONTROL RESULT 1.8.1

Call control result Allowed, with modification

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "112"

Coding: 02 05 86 03 81 11 F2

Expected Sequence 1.9 (CALL CONTROL BY SIM , set up call attempt by user, allowed with modifications : number in EF_{ECC})

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.9.1	
3	SIM -> ME	9F 06	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.9.1	[Call control result : "Allowed with
			modifications",]
6	ME	The ME sets up call with the	
		dialled digits "1020". The ME	
		does not set up an emergency	
		call	

ENVELOPE CALL CONTROL 1.9.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: International

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "01234567890123456789"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

02 BER-TLV: D4 1A 82 82 81 86 0B 91 10 32 54 54 10 76 98 10 32 76 98 13 07 00 F1 00 01

CALL CONTROL RESULT 1.9.1

Logically:

Call control result Allowed, with modification

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "1020"

Coding: 02 05 86 03 81 01 02

Expected Sequence 1.10 (CALL CONTROL BY SIM , set up call attempt by user to an emergency call)

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to "112"	
2	ME	The ME does not send any	
		ENVELOPE CALL CONTROL	
		1.9.1, set up the emergency call	

Expected Sequence 1.11 (CALL CONTROL BY SIM, set up call through call register, the SIM responds with '90 00')

Pre-condition: the ME has a mean to register the last dialed number(s), and the ME will store dialled numbers allowed by call control in its register.

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.1.1	
3	SIM -> ME	90 00	
4	ME	The ME sets up the call without	[Set up call to
		modification	"+01234567890123456789"
5	USER -> ME	End Call.	
6	USER -> ME	Recall the last dialled number	
7	ME . CIM	ENVELOPE CALL CONTROL	
7	ME -> SIM	ENVELOPE CALL CONTROL	
		1.1.1	
	OINA NAT	00.00	
8	SIM -> ME	90 00	
9	ME	The ME sets up the call without	[Set up call to
		modification	"+01234567890123456789"
10	USER -> ME	End Call.	

Expected Sequence 1.12 (CALL CONTROL BY SIM, set up call through call register, allowed without modification)

Pre-condition: the ME has a mean to register the last dialed number(s), and the ME will store dialled numbers allowed by call control in its register.

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to	
		"+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		1.2.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.2.1	[Call control result : "Allowed, no
			modification"]
6	ME	The ME sets up the call without	[Set up call to
		modification	"+01234567890123456789"
7	User -> ME	End the call then call the last	
		dialled number	
8	ME -> SIM	ENVELOPE CALL CONTROL	
		1.2.1	
9	SIM -> ME	9F 02	[Call control result : "Allowed, no
			modification"]
10	ME -> SIM	GET RESPONSE	[Set up call to
			"+01234567890123456789"
11	SIM -> ME	CALL CONTROL RESULT 1.2.1	

Expected Sequence 1.13 (CALL CONTROL BY SIM, set up call through call register, not allowed)

Pre-condition: the ME has a mean to register the last dialed number(s), and the ME will store dialled numbers not allowed by call control in its register.

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to "+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL 1.4.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.4.1	[Call control result : "not Allowed"]
6	ME	The ME does not set up the call	
7	User -> ME	The user calls the last dialled number	
8	ME -> SIM	ENVELOPE CALL CONTROL 1.4.1	
9	SIM -> ME	9F 02	
10	ME -> SIM	GET RESPONSE	
11	SIM -> ME	CALL CONTROL RESULT 1.4.1	[Call control result : "not Allowed"]
12	ME	The ME does not set up the call	

Expected Sequence 1.14 (CALL CONTROL BY SIM , set up call through call register, allowed with modifications)

Pre-condition: the ME has a mean to register the last dialed number(s), and the ME will store dialled numbers allowed with modification in its register.

Step	Direction	Message / Action	Comments
1	User -> ME	Set up a call to "+01234567890123456789"	
2	ME -> SIM	ENVELOPE CALL CONTROL 1.6.1	
3	SIM -> ME	9F 07	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 1.6.1	[Call control result : "Allowed with modifications",]
6	ME	The ME sets up the call to "+010203"	
7	User -> ME	Set up a call to "+01234567890123456789"	
8	ME -> SIM	ENVELOPE CALL CONTROL 1.6.1	
9	SIM -> ME	9F 07	
10	ME -> SIM	GET RESPONSE	
11	SIM -> ME	CALL CONTROL RESULT 1.6.1	[Call control result : "Allowed with modifications",]
12	ME	The ME sets up the call to "+010203"	

27.22.6.2 Procedure for Supplementary (SS) Services

27.22.6.2.1 Definition and applicability

See Section 3.2.2.

27.22.6.2.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 9.1.2

27.22.6.2.3 Test Purpose

To verify that the ME first pass the supplementary service control string corresponding to the supplementary service operation to the SIM, using the ENVELOPE (CALL CONTROL) command.

To verify that, if the SIM responds with '90 00', the ME shall send the supplementary service operation with the information as sent to the SIM.

To verify that, if the SIM responds with '9F XX', the ME shall use the GET RESPONSE command to get the response data. The response data from the SIM shall indicate to the ME whether to send the supplementary service operation as proposed, not send the SS operation, or instead send the SS operation using the data supplied by the SIM.

27.22.6.2.4 method of tests

27.22.6.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

27.22.6.2.4.2 Procedure

Expected Sequence 2.1 (CALL CONTROL BY SIM, send SS, the SIM responds with '90 00')

Step	Direction	Message / Action	Comments
1	User -> ME	The user selects the facility of the	
		ME which requires an	
		unconditional call forward	
		supplementary service operation	
		to be sent to the network (System	
		Simulator).	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		2.1.1	
3	SIM -> ME	90 00	
4	ME	The ME sends the supplementary	
		service operation with the	
		information as sent to the SIM	

ENVELOPE CALL CONTROL 2.1.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: Unknown

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "*21*#"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

02 FΒ BER-TLV: D4 13 82 82 81 89 04 81 2A Α1 13 07 00 F1 10 00 01 00 01

Expected Sequence 2.2 (CALL CONTROL BY SIM, send SS, allowed without modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user selects the facility of the	
		ME which requires an	
		unconditional call forward	
		supplementary service operation	
		to be sent to the network (System Simulator).	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		2.2.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 2.2.1	[Call control result : "Allowed without modifications"]
6	ME	The ME sends the supplementary	
		service operation with the	
		information as sent to the SIM	

ENVELOPE CALL CONTROL 2.2.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: Unknown

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "*21*#"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 02 82 81 04 81 2A Α1 FΒ 13 82 89 F1 10 00 00 01

CALL CONTROL RESPONSE 2.2.1

Logically:

Call control result Allowed, no modifications

Coding: 00 00

Expected Sequence 2.3 (CALL CONTROL BY SIM, send SS, not allowed)

Step	Direction	Message / Action	Comments
1	User -> ME	The user selects the facility of the	
		ME which requires an	
		unconditional call forward	
		supplementary service operation	
		to be sent to the network (System	
		Simulator).	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		2.3.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 2.3.1	[Call control result : "Not Allowed"]
6	ME	The ME does not send the	
		supplementary service operation	

ENVELOPE CALL CONTROL 2.3.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: Unknown

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "*21*#"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding

BER-TLV: D4 13 02 82 81 89 04 81 2A Α1 FΒ 10 07 00 F1 00 01 00 01 13

CALL CONTROL RESPONSE 2.3.1

Logically:

Call control result Not Allowed

Coding: 01 00

Expected Sequence 2.4 (CALL CONTROL BY SIM, send SS, allowed with modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user selects the facility of the	
		ME which requires an unconditional call forward	
		supplementary service operation	
		to be sent to the network (System	
		Simulator).	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		2.4.1	
3	SIM -> ME	9F 07	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 2.4.1	[Call control result : "Allowed with modifications"]
6	ME	The ME sends the supplementary	
		service operation with the	
		information as sent by the SIM	

ENVELOPE CALL CONTROL 2.4.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON: Unknown

NPI: "ISDN / telephone numbering plan" or "unknown"

Dialling number string "*21*#"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1) Cell ID Cell Identity Value (0001)

Coding

BER-TLV: 02 82 81 04 81 2A Α1 FΒ D4 13 82 89 F1 10 00 01

CALL CONTROL RESPONSE 2.4.1

Logically:

Call control result Allowed, with modifications

SS String

TON Unknown

NPI "ISDN / telephone numbering plan"

SS String "*#21#"

Coding: 02 06 89 04 81 BA 12 FB

27.22.6.3 Interaction with Fixed Dialling Number (FDN)

27.22.6.3.1 Definition and applicability

See Section 3.2.2.

27.22.6.3.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 9.1.4

27.22.6.2.3 Test Purpose

To verify that the ME checks that the number entered through the MMI is on the FDN list.

To verify that, if the MMI input does not pass the FDN check, the call shall not be set up.

To verify that, if the MMI input does pass the FDN check, the ME shall pass the dialled digits and other parameters to the SIM, using the ENVELOPE (CALL CONTROL) command.

To verify that, if the SIM responds with "allowed, no modification", the ME shall set up the call as proposed.

To verify that, if the SIM responds with "not allowed", the ME shall not set up the call.

To verify that, if the SIM responds with "allowed with modifications", the ME shall set up the call in accordance with the response from the SIM. If the modifications involve changing the dialled digits, the ME shall not recheck this modified number against the FDN list.

27.22.6.2.4 method of tests

27.22.6.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

Fixed Dialling Number service is enabled.

27.22.6.2.4.2 Procedure

Expected Sequence 3.1 (CALL CONTROL BY SIM, set up a call not in EF_{FDN})

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "4321"	
2	ME	The ME does not send the ENVELOPE (CALL CONTROL) command to the SIM and does not set up the call.	

Expected Sequence 3.2 (CALL CONTROL BY SIM, set up a call in EF_{FDN}, the SIM responds with '90 00')

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "123"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		3.2.1	
3	SIM -> ME	90 00	
4	ME	•	[Set up call to "123"]
		modification	

ENVELOPE CALL CONTROL 3.2.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "123"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding:

82 BER-TLV: D4 12 02 82 81 86 03 81 23 F1 13 07 00 F1 10 00 01 00 01

Expected Sequence 3.3 (CALL CONTROL BY SIM , set up a call in EF_{FDN} , Allowed without modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "9876"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		3.3.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 3.3.1	[Call control result : "Allowed without modifications"]
6	ME	The ME sets up the call without modification	[Set up call to "9876"]

ENVELOPE CALL CONTROL 3.3.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 82 02 82 81 86 03 81 89 67 13 07 00 F1 10 00 01 00 01

CALL CONTROL RESPONSE 3.3.1

Logically:

Call control result Allowed, no modifications

Coding: 00 00

Expected Sequence 3.4 (CALL CONTROL BY SIM , set up a call in EF_{FDN} , Not Allowed)

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "9876"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		3.4.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 3.4.1	[Call control result : "Not Allowed"]
6	ME	The ME does not set up the call	

ENVELOPE CALL CONTROL 3.4.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "987

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 02 82 81 03 81 89 67 82 86 13 07 00 F1 10 00 01 00 01

CALL CONTROL RESPONSE 3.4.1

Logically:

Call control result Not Allowed

Coding: 01 00

Expected Sequence 3.5 (CALL CONTROL BY SIM , set up a call in EF_{FDN} , Allowed with modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "9876"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		3.5.1	
3	SIM -> ME	9F 07	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 3.5.1	[Call control result : "Allowed with modifications"]
6	ME	The ME sets up the call with data sent by the SIM	[Set up call to "3333"]

ENVELOPE CALL CONTROL 3.5.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 82 02 82 81 86 03 81 89 67 13 01 00 01

CALL CONTROL RESPONSE 3.5.1

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "3333"

Coding: 02 05 86 03 81 33 33

27.22.6.4 Support of Barred Dialling Number (BDN) service

27.22.6.4.1 Definition and applicability

See Section 3.2.2.

27.22.6.4.2 Conformance requirement

The ME shall support the CALL CONTROL facility as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 9.1.5.

27.22.6.2.3 Test Purpose

To verify that, if Barred Dialling Number service is enabled, the ME checks the number entered through the MMI against EF_{BDN} .

To verify that, if the SIM responds with "not allowed", the ME does not set up the call.

To verify that, if the SIM responds with "allowed, no modification", the ME shall set up the call (or the supplementary service operation) as proposed.

To verify that, if the SIM responds with "allowed with modifications", the ME sets up the call in accordance with the response from the SIM. If the modifications involve changing the dialled number the ME does not re-check this modified number against the FDN list when FDN is enabled.

27.22.6.2.4 method of tests

27.22.6.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The call control service is allocated and activated in the SIM Service Table.

Barred Dialling Number service is enabled.

27.22.6.2.4.2 Procedure

Expected Sequence 4.1 (CALL CONTROL BY SIM , set up a call in EF_{BDN})

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "321"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		4.1.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 4.1.1	[Call control result : "Not Allowed"]
6	ME	The ME does not set up the call	

ENVELOPE CALL CONTROL 4.1.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "321"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 82 02 82 81 86 03 81 23 F1 13 07 00 F1 10 00 01 00 01

CALL CONTROL RESPONSE 4.1.1

Logically:

Call control result Not Allowed

Coding: 01 00

Expected Sequence 4.2 (CALL CONTROL BY SIM , set up a call not in EF_{BDN} , Allowed without modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "1234"	
2	ME -> SIM	ENVELOPE CALL CONTROL 4.2.1	
3	SIM -> ME	9F 02	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 4.2.1	[Call control result : "Allowed without modifications"]
6	ME	The ME sets up the call without modification	[Set up call to "1234"]

ENVELOPE CALL CONTROL 4.2.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "1234"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 82 02 82 81 86 03 81 21 43 13

07 00 F1 10 00 01 00 01

CALL CONTROL RESPONSE 4.2.1

Logically:

Call control result Allowed, no modifications

Coding: 00 00

Expected Sequence 4.3 (CALL CONTROL BY SIM , set up a call not in EF_{BDN} , Allowed with modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "1111"	
2	ME -> SIM	ENVELOPE CALL CONTROL	
		4.3.1	
3	SIM -> ME	9F 07	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 4.3.1	[Call control result : "Allowed with
			modifications"]
6	ME		[Set up call to "2222"]
		sent by the SIM	

ENVELOPE CALL CONTROL 4.3.1

Logically:

Device identities

Source device: ME
Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)
Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 82 02 82 81 86 03 81 11 11 13 07 00 F1 10 00 01 00 01

CALL CONTROL RESPONSE 4.3.1

Logically:

Call control result Allowed with modifications

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "2222"

Coding: 02 05 86 03 81 22 22

Expected Sequence 4.4 (CALL CONTROL BY SIM , FDN and BDN enabled, set up a call in EF_{FDN} , Allowed with modifications)

Step	Direction	Message / Action	Comments
1	User -> ME	The user sets up a call to "123"	
2	ME -> SIM	ENVELOPE CALL CONTROL 4.4.1	
3	SIM -> ME	9F 0A	
4	ME -> SIM	GET RESPONSE	
5	SIM -> ME	CALL CONTROL RESULT 4.4.1	[Call control result : "Allowed with modifications"]
6	ME	The ME sets up the call with data sent by the SIM	[Set up call to "987654321" the ME does not re-check this modified number against the FDN list]

ENVELOPE CALL CONTROL 4.4.1

Logically:

Device identities

Source device: ME

Destination device: SIM

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (1)

Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: D4 12 82 02 82 81 86 03 81 89 67 13

07 00 F1 10 00 01 00 01

CALL CONTROL RESPONSE 4.4.1

Logically:

Address

TON Unknown

NPI "ISDN / telephone numbering plan"

Address value "987654321"

Coding: 02 08 86 06 81 89 67 45 23 F1

27.22.7 EVENT DOWNLOAD

27.22.7.1 MT Call Event

27.22.7.1.1 MT Call Event (normal)

27.22.7.1.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.1.1.2 Conformance requirement

The ME shall support the EVENT: MT Call event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7, 5.2 (Terminal Profile), 6.4.16, 6.8 (Terminal Response), 11, 11.1, 12.25

27.22.7.1.1.3 Test Purpose

To verify that the ME informs the SIM the an Event: MT Call has occurred using the ENVELOPE (EVENT DOWNLOAD – MT Call) command.

27.22.7.1.1.4 Method of test

27.22.7.1.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.1.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -MT Call event)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND PENDING	
2	ME -> SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1	
4	ME -> SIM	TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1	
5	SS -> ME	CALL SET UP without CLI	[MT Call Set Up Without CLI]
6	ME -> SIM	ENVELOPE: EVENT	
		DOWNLOAD – MT Call 1.1.1	
7	SS -> ME	CALL DISCONNECT	
8	SS -> ME	CALL SET UP with CLI	[MT Call Set Up With CLI]
9	ME -> SIM	ENVELOPE: EVENT	
10	SS -> ME	DOWNLOAD – MT Call 1.1.2 CALL DISCONNECT	
11	SS -> ME	CALL SET UP with CLI and sub- address	[MT Call Set Up with CLI and sub-address]
12	ME -> SIM	ENVELOPE: EVENT	
13	SS -> ME	DOWNLOAD – MT Call 1.1.3 CALL DISCONNECT	

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: MT call

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01 00

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

1

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - MT CALL 1.1.1

Logically:

Event List: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 0 (bit 8)

Coding:

BER-TLV: D6 0A 19 01 00 82 02 83 81 1C 01 00

EVENT DOWNLOAD - MT CALL 1.1.2

Logically:

Event List: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 0 (bit 8)

Address:

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Coding:

BER-TLV: D6 0F 19 01 00 82 02 83 81 1C 01 00

86 03 90 89 67

EVENT DOWNLOAD - MT CALL 1.1.3

Event List: MT call event

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 0 (bit 8)

Address:

TON Unknown

NPI "ISDN / telephone numbering plan"

Dialling number string "9876"

Called party subaddress

Type of subaddress: NSAP (X.213 / ISO 8348 AD2) Odd / even indicator: even number of address signals

Subaddress information: AFI, 95, 95, 95, 95

:

Coding:

BER-TLV: 83 D6 19 19 00 82 1C 01 00 01 02 81 86 03 91 89 67 88 88 07 80 50 95 95

95 95 95

27.22.7.1.1.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.2 Call Connected Event

27.22.7.2.1 Call Connected Event (MT and MO call)

27.22.7.2.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.2.1.2 Conformance requirement

The ME shall support the EVENT: Call Connected event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7, 5.2 (Terminal Profile), 6.4.16, 6.8 (Terminal Response), 11, 11.2, 12.25

27.22.7.2.1.3 Test Purpose

To verify that the ME informs the SIM the an Event: Call Connected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Connected) command.

27.22.7.2.1.4 Method of test

27.22.7.2.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.2.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD –CALL CONNECTED)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND PENDING	
2	ME -> SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1	[EVENT: Call Connected active]
4	ME -> SIM	TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1	
5	SS -> ME	SETUP	[MT Call] Ti = 0
6	USER -> ME	Accept Call Set Up	
7	ME->SS	CONNECT	
8	ME -> SIM	ENVELOPE: EVENT DOWNLOAD - Call Connected 1.1.1	
9	SS -> ME	DISCONNECT	
10	USER -> ME	Initiate Call to "123"	
11	ME -> SS	SETUP	[MO Call] Ti = 0
12	SS -> ME	CONNECT	
13	ME -> SIM	ENVELOPE: EVENT DOWNLOAD – Call Connected 1.1.1	
14	USER -> ME	End Call	
15	ME -> SS	DISCONNECT	

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: Call Connected

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99

01 01

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - CALL CONNECTED 1.1.1

Logically:

Event List: Call connected

Device identities

Source device: ME
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 1 (bit 8)

Coding:

BER-TLV: D6 0A 19 01 01 82 02 82 81 1C 01 80

EVENT DOWNLOAD - CALL CONNECTED 1.1.2

Logically:

Event List: Call connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 1 (bit 8)

Coding:

BER-TLV: D6 0A 19 01 01 82 02 83 81 1C 01 80

27.22.7.2.1.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.2.2 Call Connected Event (ME supporting SET UP CALL)

27.22.7.2.2.1 Definition and applicability

See Section 3.2.2.

27.22.7.2.2.2 Conformance requirement

3GPP TS 11.14 [15] clause 11.2.2, 6.4.13, 6.6.12

Additionally the ME shall support the SET UP CALL Proactive SIM Command as defined in the following technical specifications

27.22.7.2.2.3 Test Purpose

To verify that the ME informs the SIM the an Event: Call Connected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Connected) command.

27.22.7.2.2.4 Method of test

27.22.7.2.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.2.2.4.2 Procedure

Expected Sequence 2.1 (EVENT DOWNLOAD -CALL CONNECTED, ME supporting SET UP CALL)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND PENDING	
2	ME -> SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET UP EVENT LIST 2.1.1	[EVENT: Call Connected active]
4	ME -> SIM	TERMINAL RESPONSE: SET UP EVENT LIST 2.1.1	
5	SIM -> ME	PROACTIVE COMMAND PENDING	
6	ME -> SIM	FETCH	
7	SIM -> ME	PROACTIVE COMMAND: SET UP CALL 2.1.1	[SAT Call]
8	ME		ME BEHAVIOUR: SET UP CALL
9	USER -> ME	Confirm call set up	
10	ME -> SS	SETUP	Ti=0
11		CONNECT	
12	ME -> SIM	TERMINAL RESPONSE: SET UP CALL 2.1.1	
13	ME -> SIM	ENVELOPE: CALL CONNECTED 2.1.1	

PROACTIVE COMMAND: SET UP EVENT LIST 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: Call Connected

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99

01 01

TERMINAL RESPONSE: SET UP EVENT LIST 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

PROACTIVE COMMAND: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: SIM
Destination device: Network

Alpha identifier: the initial phone number ("+012340123456")

Address

TON: International

NPI: "ISDN / telephone numbering plan"

Dialling number string "012340123456"

Coding

BER-TLV: D0 21 81 03 01 10 00 82 02 81 83

05 0D 2B 30 31 32 33 34 30 31 32 04 33 35 36 86 07 91 10 32 21 34

43 65

TERMINAL RESPONSE: SET UP CALL 2.1.1

Logically:

Command details

Command number: 1

Command type: SET UP CALL

Command qualifier: Only if not currently busy on another call

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 10 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - CALL CONNECTED 2.1.1

Logically:

Event List: Call connected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 1 (bit 8)

Coding:

BER-TLV: D6 0A 19 01 01 82 02 83 81 1C 01 80

27.22.7.2.2.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.3 Call Disconnected Event

27.22.7.3.1 Call Disconnected Event

27.22.7.3.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.3.1.2 Conformance requirement

The ME shall support the EVENT: Call Disconnected event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7, 5.2 (Terminal Profile), 6.4.16, 6.8 (Terminal Response), 11, 11.3, 12.25

27.22.7.3.1.3 Test Purpose

To verify that the ME informs the SIM the an Event: Call Disconnected has occurred using the ENVELOPE (EVENT DOWNLOAD -Call Disconnected) command.

27.22.7.3.1.4 Method of test

27.22.7.3.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.3.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -CALL DISCONNECTED)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND PENDING	
2	ME -> SIM SIM -> ME	FETCH PROACTIVE COMMAND: SET	[EVENT: Call Disconnected active]
4	ME -> SIM	UP EVENT LIST 1.1.1 TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1	
5 6	SS -> ME USER -> ME	SETUP Accept Call Set Up	[incoming call] Ti=0
7 8	SS -> ME ME-> SIM	DISCONNECT ENVELOPE: CALL DISCONNECTED 1.1.1	[MT DISCONNECT]
9 10	SS -> ME USER -> ME	SETUP Accept Call Set Up	[incoming call] Ti=0
11 12	SS -> ME ME-> SIM	RELEASE ENVELOPE: CALL DISCONNECTED 1.1.1	[MT RELEASE]
13 14	SS -> ME USER -> ME	SETUP Accept Call Set Up	[incoming call] Ti=0
15 16		RELEASE COMPLETE ENVELOPE: CALL DISCONNECTED 1.1.1	[MT RELEASE COMPLETE]
17 18	SS -> ME USER ->	SETUP Accept Call Set Up	[incoming call] Ti=0
19	ME USER -> ME	End Call	
20 21	ME -> SS ME -> SIM	DISCONNECT ENVELOPE: CALL DISCONNECTED 1.1.2	[MO DISCONNECT]
22	SS -> ME	DISCONNECT ACK ???	
23 24	SS -> ME USER -> ME	SETUP Accept Call Set Up	[incoming call] Ti=0
25	SS -> ME	DISCONNECT	[MT DISCONNECT + CAUSE : normal call clearing]
26	ME-> SIM	ENVELOPE: CALL DISCONNECTED 1.1.3	
27 28	SS -> ME USER -> ME	SETUP Accept Call Set Up	Ti=0
29 30	SS ME-> SIM	TX POWER to XX ENVELOPE: CALL DISCONNECTED 1.1.4A or 1.1.1B	[RADIO LINK FAILURE]

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: Call Disconnected

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99

01 02

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.1

Logically:

Event List: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 0 (bit 8)

Cause:

Coding:

BER-TLV: D6 0A 19 01 02 82 02 83 81 1C 01 00

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.2

Logically:

Event List: Call Disconnected

Device identities

Source device: ME
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 1 (bit 8)

Coding:

BER-TLV: D6 0A 19 01 01 82 02 83 81 1C 01 80

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.2

Logically:

Event List: Call Disconnected

Device identities

Source device: ME

Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 1 (bit 8)

Coding:

BER-TLV: D6 0A 19 01 01 82 02 82 81 1C 01 80

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.3

Logically:

Event List: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 0 (bit 8)

Cause: normal call clearing

Coding:

BER-TLV: D6 0E 19 01 01 82 02 82 81 1C 01 00

9A 02 60 90

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.4A

Logically:

Event List: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

 $\begin{array}{ll} \mbox{Ti value:} & 0 \mbox{ (bit 5-7)} \\ \mbox{Ti flag:} & 1 \mbox{ (bit 8)} \\ \mbox{Cause:} & \mbox{radio link failure} \end{array}$

Coding:

BER-TLV: D6 0E 19 01 01 82 02 82 81 1C 01 80

9A 00

EVENT DOWNLOAD - CALL DISCONNECTED 1.1.4B

Logically:

Event List: Call Disconnected

Device identities

Source device: Network
Destination device: SIM

Transaction identifier:

Ti value : 0 (bit 5-7)
Ti flag : 0 (bit 8)

Cause: radio link failure

Coding:

BER-TLV: D6 0E 19 01 01 82 02 82 81 1C 01 00

9A 00

27.22.7.3.1.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.4 Location Status Event

27.22.7.4.1 Location Status Event (normal)

27.22.7.4.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.4.1.2 Conformance requirement

The ME shall support the EVENT: Location Status event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 11.4, 6.4.16

27.22.7.4.1.3 Test Purpose

To verify that the ME informs the SIM that an Event: MM_IDLE state has occurred using the ENVELOPE (EVENT DOWNLOAD – Location Status) command.

27.22.7.4.1.4 Method of test

27.22.7.4.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

Two cells are defined. Cell 1 has location area code 1 and cell 2 has location area code 2.

MS is in service on Cell 1.

27.22.7.4.4.2 Procedure

Expected Sequence 1.1(EVENT DOWNLOAD –LOCATION STATUS)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND	
		PENDING	
2	ME -> SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET	
		UP EVENT LIST 1.1.1	
4	ME -> SIM	TERMINAL RESPONSE: SET UP	
		EVENT LIST 1.1.1	
5	SS		Cell 2 is switched on and cell 1 is switched off
6			ME performs cell reselection to cell 2
7	ME -> SS	Location Updating Request	
8		Location updating accept	
9	ME -> SIM	ENVELOPE: EVENT	[NOTE : The inclusion of the location
		DOWNLOAD – Location Status	information is optional: (If location status
		1.1.1	indicates normal status)

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: Location status

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01 03

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - LOCATION STATUS 1.1.1

Logically:

Event List: Location status

Device identities

Source device: ME
Destination device: SIM

Location status: normal service

Location Information

MCC & MNC the mobile country and network code (F110)

LAC the location Aera Code (2) Cell ID Cell Identity Value (0001)

Coding:

BER-TLV: 82 1B 01 00 D6 13 19 01 02 82 02 81 13 07 00 F1 10 00 02 00 01

27.22.7.4.1.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.5 User Activity Event

27.22.7.5.1 User Activity Event (normal)

27.22.7.5.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.5.1.2 Conformance Requirement

The ME shall support the EVENT DOWNLOAD -USER ACTIVITY as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 5.2 (Terminal Profile), clause 6.4.16 (Set Up Event List), clause 6.8 (Terminal Response), clause 6.6.16, clause 6.11, clause 11 (Event Download), clause 11.5 (User Activity event), clause 12.6 (Commands details), clause 12.25 (Event List).

27.22.7.5.1.3 Test Purpose

To verify that the ME performed correctly the procedure of USER ACTIVITY EVENT.

27.22.7.5.1.4 Method of Test

27.22.7.5.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The ME screen shall be in its normal stand-by display.

27.22.7.5.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD -USER ACTIVITY)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \to ME$	PROACTIVE COMMAND	[set up event list : event User Activity]
		PENDING: SET UP EVENT	
		LIST 1.1	
2	$ME \to SIM$	TERMINAL RESPONSE: SET	[command performed successfully]
		UP EVENT LIST 1.1	
3	USER	press any key	
4	$ME \to SIM$	ENVELOPE EVENT	
		DOWNLOAD -USER ACTIVITY	
		1.1	
9	USER	press any key	check if no envelope Event Download-User
			activity sending to the SIM (this event is
			reported once)

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier:

Device identities

Source device: SIM
Destination device: ME

Event List User Activity

Coding:

BER-TLV: D0 15 81 03 01 05 00 82 02 81 82 99 01 04

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier:

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 80 82 02 82 81 83 01 00

EVENT DOWNLOAD -USER ACTIVITY 1.1.1

Logically:

Event List User Activity

Device identities

Source device: ME
Destination device: SIM

Coding:

BER-TLV: D6 07 19 01 04 82 02 83 81

27.22.7.5.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.6 Idle screen available event

27.22.7.6.1 Idle Screen Available (normal)

27.22.7.6.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.6.1.2 Conformance requirement

The ME shall support the EVENT: IDLE SCREEN AVAILABLE event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7, 5.2 (Terminal Profile), 6.4.16, 6.8 (Terminal Response), 11, 11.1, 12.25

27.22.7.6.1.3 Test Purpose

To verify that the ME informs the SIM the an Event: Idle Screen Available has occurred using the ENVELOPE (EVENT DOWNLOAD – IDLE SCREEN AVAILABLE) command.

27.22.7.6.1.4 Method of test

27.22.7.6.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

27.22.7.6.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD - IDLE SCREEN AVAILABLE)

Step	Direction	MESSAGE / Action	Comments
1	$USER \to$	Select screen other than the ME	
	ME	idle screen	
2	$SIM \rightarrow ME$	PROACTIVE COMMAND	[set up event list : idle screen available]
		PENDING: SET UP EVENT LIST 1.1.1	
3	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1	[command performed successfully]
4	$\begin{array}{c} USER \to \\ ME \end{array}$	Select ME idle screen	
5	$ME \rightarrow SIM$	ENVELOPE: IDLE SCREEN AVAILABLE 1.1.1	
6	USER → ME	Select ME idle screen	check if no envelope Event Download- idle screen sending to the SIM (this event is reported once)

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: idle screen available

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99

01 05

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - IDLE SCREEN AVAILABLE 1.1.1

Logically:

Event List User Activity

Device identities

Source device: ME
Destination device: SIM

Coding:

BER-TLV: D6 07 19 01 05 82 02 83 81

27.22.7.6.1.5 Test Requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.7 Card reader status event

27.22.7.7.1 Card Reader Status (normal)

27.22.7.7.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.7.1.2 Conformance requirement

The ME shall support the EVENT: Call Card Reader Status event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7 (Event Download), clause 4.9 (Multiple Card), clause 5.2 (Terminal Profile), clause 6.4.16 (Set Up Event List), clause 6.8 (Terminal Response), clause 11 (Event download), clause 11.7 (Card reader status event), clause 12.25 (Event List), clause 12.33 (Card reader status), ANNEX G (Monitoring of events), Annex H (Support of MultipleCard Operation), clause 12.25 (Event list), clause 12.7 (Device identities).

27.22.7.7.1.3 Test Purpose

To verify that the ME informs the SIM the an Event: Card Reader Status has changed using the ENVELOPE (EVENT DOWNLOAD – Card Reader Status) command.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen.

27.22.7.7.1.4 Method of test

27.22.7.7.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.7.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD, Card reader status, Card reader 1, card reader attached, no card inserted)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND 1.1.1	
_		PENDING	
2	ME -> SIM	1	IEVENT. Oand Daadan Otaturi
3	SIIVI -> IVIE	PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1	[EVENT: Card Reader Status]
4	ME -> SIM	TERMINAL RESPONSE: SET UP	[Successfully]
5 6	User->ME ME-> SIM	Insert a card in Reader	
7 8	User->ME ME-> SIM	Remove the card from Reader ENVELOPE: CARD READER STATUS 1.1.2a Or ENVELOPE: CARD READER STATUS 1.1.2b Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2c Or ENVELOPE: CARD READER STATUS 1.1.2d	

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Card Reader Status

Coding:

BER-TLV: D0 0D 81 03 01 05 00 82 02 81 82

99 01 06

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 97

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader:

Card reader removable:

Yes

Card reader present:

Card reader ID-1 size:

No

Card present in reader:

Yes

Card powered:

No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 95

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1c

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 17

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1d

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: Yes
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 15

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 93

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 91

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2c

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 13

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.2d

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: No
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 91

27.22.7.7.1.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 1.1'.

27.22.7.7.2 Card Reader Status(detachable card reader)

27.22.7.7.2.1 Definition and applicability

See Section 3.2.2.

27.22.7.7.2.2 Conformance requirement

The ME shall support the EVENT: Call Card Reader Status event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7 (Event Download), clause 4.9 (Multiple Card), clause 5.2 (Terminal Profile), clause 6.4.16 (Set Up Event List), clause 6.8 (Terminal Response), clause 11 (Event download), clause 11.7 (Card reader status event), clause 12.25 (Event List), clause 12.33 (Card reader status), ANNEX G (Monitoring of events), Annex H (Support of MultipleCard Operation), clause 12.25 (Event list), clause 12.7 (Device identities).

27.22.7.7.2.3 Test Purpose

To verify that the ME informs the SIM the an Event: Card Reader Status has changed using the ENVELOPE (EVENT DOWNLOAD – Card Reader Status) command.

The ME-Manufacturer can assign the card reader identifier from 0 to 7.

This test applies for MEs with only one additional card reader.

In this particular case the card reader identifier 1 is chosen as an example

27.22.7.7.2.4 Method of test

27.22.7.7.2.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.7.2.4.2 Procedure

Expected Sequence 2.1 (EVENT DOWNLOAD, Detachable reader, Card reader 1, detachable card reader not attached, no card inserted)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND	
		1.1.1PENDING	
2	ME -> SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET	[SET UP EVENT: Card Reader Status]
		UP EVENT LIST 1.1.1	
4	ME -> SIM	TERMINAL RESPONSE: SET UP	[Successfully]
		EVENT LIST 1.1.1	
5	User->ME	Attach the Card Reader to ME	
6	ME-> SIM	ENVELOPE: CARD READER	
		STATUS 2.1.1a	
		Or	
		ENVELOPE: CARD READER	
		STATUS 2.1.1b	
7	User->ME		
8	ME-> SIM		
		STATUS 2.1.2a	
		Or	
		ENVELOPE: CARD READER	
		STATUS 2.1.2b	

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 1.1.1a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader:
Card reader removable:
Card reader present:
Card reader ID-1 size:
Card present in reader:
Card powered:
No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 93

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.1b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: Yes
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 91

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.2a

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: Yes
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 92

ENVELOPE: EVENT DOWNLOAD CARD READER STATUS 2.1.2b

Logically:

Event list

Event 1: Card Reader Status

Device identities

Source device: ME
Destination device: SIM

Card reader status

Identity of card reader: 01
Card reader removable: Yes
Card reader present: No
Card reader ID-1 size: No
Card present in reader: No
Card powered: No

Coding:

BER-TLV: D6 0A 99 01 06 82 02 82 81 A0 01 90

27.22.7.7.1.5 Test Requirement

The behaviour of the test is as defined in 'Expected Sequence 2.1'.

27.22.7.8 Language selection event

27.22.7.8.1 Language selection event (normal)

27.22.7.8.1.1 Definition and applicability

See Section 3.2.2.

27.22.7.8.1.2 Conformance requirement

The ME shall support the EVENT: LANGUAGE SELECTION event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7, 5.2 (Terminal Profile), 6.4.16, 6.8 (Terminal Response), 11, 11.8, 12.25

27.22.7.8.1.3 Test Purpose

To verify that the ME informs the SIM the an Event: Language selection has occurred using the ENVELOPE (EVENT DOWNLOAD – LANGUAGE SELECTION) command.

27.22.7.8.1.4 Method of test

27.22.7.8.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator and the System Simulator.

The elementary files are coded as SIM Application Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure.

The current language shall have been set to english. Another language has to be supported, german is an example.

27.22.7.8.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD - LANGUAGE SELECTION)

Step	Direction	MESSAGE / Action	Comments
1	$SIM \rightarrow ME$	PROACTIVE COMMAND	[set up event list : language selection]
		PENDING: SET UP EVENT LIST	
		1.1.1	
2	$ME \rightarrow SIM$	TERMINAL RESPONSE: SET UP	[command performed successfully]
		EVENT LIST 1.1.1	
3	$USER \to$	Change the language to german.	
	ME		
4	$ME \rightarrow SIM$	ENVELOPE: LANGUAGE	
		SELECTION 1.1.1	
5	$USER \to$	Change the language to english	
	ME		
6	$ME \rightarrow SIM$	ENVELOPE: LANGUAGE	check if an envelope Event Download-
		SELECTION 1.1.2	language selection is sending again to the
			SIM (this event is continuously reported)

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event List

Event 1: language selection

Coding:

BER-TLV: D0 0C 81 03 01 05 00 82 02 81 82 99 01 07

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

EVENT DOWNLOAD - LANGUAGE SELECTION 1.1.1

Logically:

Event List Language selection

Device identities

Source device: ME
Destination device: SIM

Language

Language 'de' → 64 65 (german)

Coding:

BER-TLV: D6 0B 19 01 07 82 02 83 81 2D 02 64

65

EVENT DOWNLOAD - LANGUAGE SELECTION 1.1.2

Logically:

Event List Language selection

Device identities

Source device: ME
Destination device: SIM

Language

Language 'en'→64 65 (german)

Coding:

27.22.7.8.1.5

BER-TLV: D6 0B 19 01 07 82 02 83 81 2D 02 65 6E

Test Requirement

The ME shall operate in the manner defined in expected sequence 1.1.

27.22.7.9 Browser termination event

27.22.7.9.1 Browser termination (normal)

27.22.7.9.1.1 Definition and applicability

This test is only applicable to ME's that support the EVENT: browser termination event driven information.

27.22.7.9.1.2 Conformance requirement

The ME shall support the EVENT: Browser termination event as defined in the following technical specifications:

3GPP TS 11.14 [15] clause 4.7 (Event Download), clause 5.2 (Terminal Profile), clause 6.4.16 (Set Up Event List), clause 6.8 (Terminal Response), clause 11 (Event download), clause 11.9 (Browser termination event), clause 12.25 (Event List), clause 12.51 (Browser termination cause), ANNEX G (Monitoring of events), clause 12.7 (Device identities).

27.22.7.9.1.3 Test Purpose

To verify that the ME informs the SIM of an Event: Browser termination using the ENVELOPE (EVENT DOWNLOAD – Card Reader Status) command.

This test applies for MEs which have a browser.

27.22.7.9.1.4 Method of test

27.22.7.9.1.4.1 Initial Conditions

The ME is connected to the SIM Simulator.

The ME shall be powered on and perform the PROFILE DOWNLOAD procedure.

27.22.7.9.1.4.2 Procedure

Expected Sequence 1.1 (EVENT DOWNLOAD - Browser termination)

Step	Direction	Message / Action	Behaviour
1	SIM -> ME	PROACTIVE COMMAND 1.1.1	
		PENDING	
2	ME -> SIM	FETCH	
3	SIM -> ME	PROACTIVE COMMAND: SET	[EVENT: Browser termination Status]
		UP EVENT LIST 1.1.1	
4	ME -> SIM	TERMINAL RESPONSE: SET UP	[Successfully]
		EVENT LIST 1.1.1	
5	User->ME	Launch the browser , go to an	
		URL, then stop the session and	
		the browser.	
6	ME-> SIM	ENVELOPE: BROWSER	
		TERMINATION 1.1.1	

PROACTIVE COMMAND: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number: 1

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: SIM
Destination device: ME

Event list

Event 1: Browser termination

Coding:

BER-TLV: D0 0D 81 03 01 05 00 82 02 81 82 99 01 08

TERMINAL RESPONSE: SET UP EVENT LIST 1.1.1

Logically:

Command details

Command number:

Command type: SET UP EVENT LIST

Command qualifier: '00'

Device identities

Source device: ME
Destination device: SIM

Result

General Result: Command performed successfully

Coding:

BER-TLV: 81 03 01 05 00 82 02 82 81 83 01 00

ENVELOPE: EVENT DOWNLOAD BROWSER TERMINATION 1.1.1

Logically:

Event list

Event 1: Browser termination

Device identities

Source device: ME
Destination device: SIM

Browser termination cause: User termination

Coding:

BER-TLV: D6 0A 99 01 08 82 02 82 81 B4 01 00

27.22.7.10 Data available event

27.22.7.10.1 Definition and applicability

See Section 3.2.2.

27.22.7.10.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

Additionnally the ME shall support ENVELOPE (EVENT DOWNLOAD – Data available)

27.22.7.10.3 Test Purpose

To verify that the ME shall send an ENVELOPE (EVENT DOWNLOAD – Data available) to the SIM after the ME receives a packet of data from the server by the BIP channel previously opened.

27.22.7.10.4 Method of test

27.22.7.10.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure. The SIM must have sent the SET UP EVENT LIST to the ME to supply a set of events (event Data available).

27.22.7.10.4.2 Procedure

Expected sequence 1.1 (EVENT DOWNLOAD – Data available)

For that test, it is assumed that an OPEN CHANNEL proactive command has been successfully executed (with a consistent SIM buffer size).

Step	Direction	MESSAGE / Action	Comments
1	SERVER	Data sent through the BIP channel	
	\rightarrow ME		
2	$ME \rightarrow SIM$	ENVELOPE 1.1.1 (Event-Data	
		Available)	

ENVELOPE: EVENT DOWNLOAD - Data available 1.1.1

Logically:

Event List

Event: Data available

Device identities

Source device: ME
Destination device: SIM

Channel status

Channel status: Channel 1 open, link established

Channel Data Length

Channel Data Length: 8 Bytes available in Rx buffer

Coding:

BER-TLV: D6 0E 99 01 09 82 02 82 81 В8 02 81 00 B7 08

27.22.7.11 Channel Status event

27.22.7.11.1 Definition and applicability

See Section 3.2.2.

27.22.7.11.2 Conformance requirements

The ME shall support the class "e" commands as defined in the following technical specifications: 3GPP TS 11.14 [15]

Additionnally the ME shall support ENVELOPE (EVENT DOWNLOAD – Channel Status)

27.22.7.11.3 Test Purpose

To verify that the ME shall send an ENVELOPE (EVENT DOWNLOAD – Channel Status) to the SIM after the link dropped between the NETWORK and the ME.

27.22.7.11.4 Method of test

27.22.7.11.4.1 Initial Conditions

The ME is connected to the SIM Simulator. The elementary files are coded as Toolkit default.

Prior to this test the ME shall have been powered on and performed the PROFILE DOWNLOAD procedure. The SIM must have sent the SET UP EVENT LIST to the ME to supply a set of events (event Channel Status).

27.22.7.11.4.2 Procedure

Expected sequence 1.1 (EVENT DOWNLOAD – Channel Status on a link dropped)

For that test, it is assumed that an OPEN CHANNEL proactive command has been successfully executed.

Step	Direction	MESSAGE / Action	Comments
1	NETWORK	Link dropped	
	\rightarrow ME		
2	$ME \to SIM$	ENVELOPE 1.1.1 (Event-Channel	
		Status)	

ENVELOPE: EVENT DOWNLOAD - Channel Status 1.1.1

Logically:

Event List

Event: Channel Status

Device identities

Source device: ME
Destination device: SIM

Channel status

Channel status: Channel 1, link dropped

Coding:

BER-TLV: D6 0E 99 01 09 82 02 82 81 B8 02 01 05

Annex A (normative): Void

Annex B (informative): void

Annex C (normative): Initial Conditions for Icon Management

The ME is connected to the SIM Simulator.

The elementary files are coded as Toolkit default with the following exceptions.

The ME screen shall be in its normal stand-by display.

For the display of icon:

- Under the DF Telecom: creation of DF Grafics (5F50),
- -Under the DF 5F50: creation of EF_{Img} (4F20, linear fixed file) and EF_{Instance} (4FXX, transparent file).

EF_{Img} (Image, 4F20)

Record 1:

Logically:

Number of Actual Images Instances: 01

Image Instance Width: 08
Image Instance Height: 08

Image Coding Scheme: 11 (basic image)

Image Instance File Identifier: 4F 04 (EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 0A

Coding:

BER-TLV: 01 08 08 11 4F 04 00 00 00 0A FF FF FF FF FF FF FF FF FF FF

Record 2:

Logically:

Number of Actual Images Instances: 01

Image Instance Width: 08
Image Instance Height: 08

Image Coding Scheme: 21 (colour image)

Image Instance File Identifier: 4F 02(EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 1F

Coding:

BER-TLV: 01 2E 28 21 4F 02 00 00 00 1F FF FF FF FF FF FF FF FF FF FF

Record 3:

Logically:

Number of Actual Images Instances: 01

Image Instance Width: 18

Image Instance Height: 10

Image Coding Scheme: 11 (basic image)

Image Instance File Identifier: 4F 03 (EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 32

Coding:

BER-TLV: 00 00 32 FF FF 01 10 03 00 FF FF FF FF FF FF FF FF

Record 4:

Logically:

Number of Actual Images Instances: 01

Image Instance Width: 2E
Image Instance Height: 28

Image Coding Scheme: 11 (basic image)

Image Instance File Identifier: 4F 01 (EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 E8

Coding:

BER-TLV: 00 E8 FF FF 01 2E 28 11 4F 01 00 00 FF FF FF

Record 5:

Logically:

Number of Actual Images Instances: 01

Image Instance Width: 05
Image Instance Height: 05

Image Coding Scheme: 11 (basic image)

Image Instance File Identifier: 4F 05 (EF_{Instance})

Offset into Image Instance File: 00 00 Length of Image Instance Data: 00 08

Coding:

BER-TLV: 4F FF FF FF FF FF FF FF FF

EF_{Instance} (4F01)

Logically:

Image Instance Data: see below

Coding:

BER-TLV: 2E FF 0F FF FΕ BF F8 FF E0 1A 6B F6 BC ΑF D8 BF FD 6B F6 1A A0 1F FF E4 1B FF 6D EE BF F9 6F FF E4 1B FΕ FF 6F BF F9 FF E6 1B FF FΕ BF F8 6F FF E0 F0 1B FF 7F FΕ 0C FF F8 1F 1C ΕE C4 1C 4D 4A C8 9E 4E E0

EF_{Instance} (4F02)

Logically:

Image Instance Data:

Image width: 08


Image length: 08

Bits per raster image point: 02

Number of CLUT entries: 03

Location of CLUT: 00 16

Image body: see below



EF_{Instance} (4F03)

Logically:

Image Instance Data: see below

Coding:

BER-TLV: 18 10 FF FF FF 80 00 01 80 00 01 80 3C 89 00 01 8F F1 89 20 81 89 20 81 20 3C F1 89 20 11 89 20 11 89 20 11 8F F1 FF 80 00 01 80 00 01 80 00 01 FF FF

EF_{Instance} (4F04)

Logically:

Image Instance Data: see below

Coding:

BER-TLV: 08 08 FF 03 A5 99 99 A5 C3 FF

EF_{Instance} (4F05)

Logically:

Image Instance Data: see below

Coding:

BER-TLV: 05 05 FE EB BF FF FF

Annex D (normative): Details of Test-SIM (TestSIM)

The TestSIM shall be able to present the following data:

1. ANSWER TO RESET

```
Logically:
    TS (Initial character):
                                     '3B'
    T0 (Format character):
                                          (Following interface characters: TD(1), number of historical
                                     '86'
                                         characters: 6)
                                     '00' (Following interface characters: none, Transfer protocol: T=0)
    TD1:
    T1:
    T2:
                                     99
                                     00
    T3:
    T4:
                                     12
    T5:
                                     C1
    T6:
                                     00
   Coding:
            BER-TLV:
                          3B
                                86
                                       00
                                              91
                                                    99
                                                           00
                                                                  12
                                                                        C1
                                                                               00
```

- 2. For a successful outcome of the command "Select MasterFile" the TestSIM shall send SW1/SW2 "9F 1B"
- 3. For a successful outcome of the command "Get Response with Length 1B" on the MasterFile the TestSIM shall respond:

RFU: '00 00'
Not allocated memory: '653 bytes'
File ID: Master File
Type of file: MF

RFU: 00 00 22 FF 01' Length of following data: 14 bytes'

Length of following data: File characteristics:

Clock Stop: Not allowed
Min. frequence for GSM algorithm: 13/8 MHz
Technology identification: 3V Technology SIM

CHV1: disabled

DFs in current directory: 2
EFs in current directory: 8
Number of CHV and admin. Codes: 3
RFU byte 18: 00

CHV1 status:

False represantations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialised

Unlock CHV1 status:

False representations remaining: 10 RFU-bits 7-5: 000 Secret code: Initialised

CHV2 status:

False representations remaining: 3
RFU-bits 7-5: 000
Secret code: Initialised

Unlock CHV2 status:

False represantations remaining: 10
RFU-bits 7-5: 000
Secret code: Initialised
RFU bytes 23: 00

Reserved for admin. management: 00 83 00 FF

Status Words

SW1 / SW2: Normal ending of command

Coding:

BER-TLV: 00 02 8D 3F 00 01 00 00 22 FF 01 00 0E 9B 03 00 83 A8 83 8A 00 00 02 80 83 00 FF 90 00

- 4. For a successful outcome of the command "Select GSM" the TestSIM shall send SW1/SW2 "9F 1B"
- 5. For a successful outcome of the command "Select PLMN" the TestSIM shall send SW1/SW2 "9F 0F"
- 6. EF_{PLMN} Information:

RFU-Bytes 1-2: 00 00

File size: 102 bytes

File ID: 6F30

Type of File: Elementary file

Byte 8

RFU: 00

Access Condition:

UPDATE: CHV1

READ/SEEK: CHV1

RFU-bits 4-1: 1111

INCREASE: NEVER

INVALIDATE: NEVER

REHABILITATE: NEVER

File Status:

Invalidation status: File not invalidated

Readable/updateable: Not readable/updaable when invalidated

RFU-bits 8-4, 2: 0000 0

Length of following data: 2 bytes

Structure: Transparent

Length of record: 00

The initial coding of the EF_{PLMN} shall be FF FF ... FF (logically: Empty).

Annex C (informative): Change History

SPEC	CR	RE	PHA	VERS	SUBJECT	CAT	NEW_VERS
11.10-4	-	96	2+	-	Approved as release 1996 at SMG#30	-	5.0.0
11.10-4	A001	96	2+	5.0.0	Corrections to SIM Application Toolkit Test Specification	F	5.1.0
11.10-4				5.1.0	Version update to 5.1.1 for Publication		5.1.1
11.10-4	A002	96	2+	5.1.0	Editorial and coding corrections	F	5.2.0
11.10-4	A003	96	2+	5.2.0	Correction of wrong coding for SIM Application Toolkit test 27.22.4.2	F	5.3.0
11.10-4	A004	96	2+	5.2.0	Corrections for Test Case 27.22.5.1 (SMS-PP Data Download)	F	5.3.0
11.10-4	A005	96	2+	5.3.0	Correction of wrong coding for SIM Application Toolkit 27.22	F	5.4.0
11.10-4	A006	96	2+	5.4.0	Corrections for Test Case 27.22.4.7 (REFRESH)	F	5.5.0
11.10-4	A007	96	2+	5.4.0	Corrections for Test Case 27.22.5.2 (SMS-CB Data Download)	F	5.5.0
11.10-4	A008	99	2+	5.5.0	Upgrade of the MS SAT test specification to Release 99	F	8.1.0

History

Document history		
V8.1.0	December 2002	Publication