# ETSI TS 103 115 V9.0.0 (2013-04)



# Smart Cards; Test specification for UICC Application Programming Interface for Java Card™ for Contactless Applications; Test Environment and Annexes; (Release 9)

# Reference DTS/SCP-00HCI\_API\_TESTv900

Keywords
API, NFC, Smart Card, testing

#### **ETSI**

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

#### Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

<a href="http://portal.etsi.org/tb/status/status.asp">http://portal.etsi.org/tb/status/status.asp</a></a>

#### Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2013. All rights reserved.

**DECT**<sup>TM</sup>, **PLUGTESTS**<sup>TM</sup>, **UMTS**<sup>TM</sup> and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members. **3GPP**<sup>TM</sup> and **LTE**<sup>TM</sup> are Trade Marks of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

**GSM**® and the GSM logo are Trade Marks registered and owned by the GSM Association.

# Contents

Intelle	ectual Property Rights	7
Forew	vord	7
1	Scope	8
2	References	8
2.1	Normative references	
2.2	Informative references	
3	Definitions, symbols and abbreviations	9
3.1	Definitions	
3.2	Symbols	
3.3	Abbreviations	
3.4	Formats	
3.4.1	Format of the table of optional features	
3.4.2	Format of the applicability table	
3.4.3	Status and Notations	
4	Applicability	12
4.1	Table of optional features	
4.2	Applicability table	
4.3	Information provided by the device supplier	
4.4	Execution requirements	
	•	
	Test environment	
5.1	Test environment description	
5.2	Tests format	
5.2.1	Test area reference	
5.2.1.1	1	
5.2.1.2		
5.2.1.3		
5.2.1.4	±	
5.3	Initial conditions	
5.4	Package name	
5.5	AID coding	
5.6	Test equipment	
5.6.1	Test tool	
5.6.2	Java Software Development Kit	19
	Test cases	
6.1	Package uicc.hci.framework	
6.1.1	Class HCIDevice	
6.1.1.1		
6.1.1.1	1	
6.1.1.1		
6.1.1.1		
6.1.1.1	±	
6.1.1.2		
6.1.1.2	*	
6.1.1.2		22
6.1.1.2		
6.1.1.2	±	
6.1.1.3	Method isHCIServiceAvailable	23
6.1.1.3	1	23
6.1.1.3		24
6.1.1.3		24
6.1.1.3	Test procedure	24
6.1.2	Interface HCIService	26
6.1.2.1	Method register	26

6.1.2.1.1	Conformance requirements	
6.1.2.1.2	Test suite files	27
6.1.2.1.3	Initial conditions	27
6.1.2.1.4	Test procedure	27
6.1.2.2	Method deregister	
6.1.2.2.1	Conformance requirements	
6.1.2.2.2	Test Suite Files	
6.1.2.2.3	Initial conditions	
6.1.2.2.4	Test procedure	
6.1.2.3	Method activateEvent	
6.1.2.3.1	Conformance requirements	
6.1.2.3.2	Test Suite Files	
6.1.2.3.3	Initial conditions	
6.1.2.3.4	Test procedure	
6.1.2.4	Method deactivateEvent	
6.1.2.4.1	Conformance requirements	
6.1.2.4.2	Test suite files	
6.1.2.4.3	Initial conditions	
6.1.2.4.4	Test procedure	
6.1.2.5	Method requestCallbackNotification	
6.1.2.5.1	Conformance requirements	
6.1.2.5.2	Test Suite Files	
6.1.2.5.3	Initial conditions	
6.1.2.5.4	Test procedure	
6.1.2.6	Method getEventNotificationStatus	
6.1.2.6.1	Conformance requirements	
6.1.2.6.2	Test Suite Files	
6.1.2.6.3	Initial conditions	
6.1.2.6.4	Test procedure	
6.1.3	Interface HCIMessage	
6.1.3.1	Method isHeading	
6.1.3.1.1	Conformance requirements	
6.1.3.1.2	Test Suite Files	
6.1.3.1.3	Initial conditions	
6.1.3.1.4	Test procedure	
6.1.3.2	Method isComplete	
6.1.3.2.1	Conformance requirements	
6.1.3.2.2	Test suite files	
6.1.3.2.3	Initial condition	
6.1.3.2.4	Test procedure	
6.1.3.3	Method getType	
6.1.3.3.1	Conformance requirements	
6.1.3.3.2	Test Suite Files	
6.1.3.3.3	Initial condition	
6.1.3.3.4	Test procedure	
6.1.3.4	Method getInstruction	
6.1.3.4.1	Conformance requirements	
6.1.3.4.2	Test Suite Files	
6.1.3.4.3	initial condition	
6.1.3.4.4	Test procedure	
6.1.3.5	Method getReceiveOffset	
6.1.3.5.1	Conformance requirements	
6.1.3.6	Method getReceiveLength	
6.1.3.6.1	Conformance requirements	
6.1.3.6.2	Test Suite Files	
6.1.3.6.3	Initial condition	
6.1.3.6.4		
6.1.3.7	Test procedure	
6.1.3.7.1	Conformance requirements	
6.1.3.7.1	Test suite files	
6.1.3.7.2		
6.1.3.7.4	Initial condition	
0.1.3./.4	1 CSt D10CCuutC	4

6.1.4	Class HCIException	
6.1.4.1	Method throwIt	49
6.1.4.1.1	Conformance requirements	49
6.1.4.1.2	Test suite files	
6.1.4.1.3	Initial conditions	
6.1.4.1.4	Test procedure	
6.1.5	Interface HCIListener	
6.1.5.1	Method onCallback	
6.1.5.1.1	Conformance requirements	
6.1.5.1.2	Test Suite Files	
6.1.5.1.3	Initial conditions	52
6.1.5.1.4	Test procedure	52
6.2	Package uicc.hci.services	53
6.2.1	Package CardEmulation Service	53
6.2.1.1	Interface CardEmulationMessage	
6.2.1.1.1	Method prepareAndSendGetParameterCommand	
6.2.1.1.2	Method prepareAndSendSendDataEvent	
6.2.1.1.3	Method selectingMessage	
6.2.1.2	Interface CardEmulationService	
6.2.1.2.1		
0.2.1.2.1	Method getCardRFType	
6.2.1.2.2	Test Suite Files	
6.2.1.2.3	Initial conditions	
6.2.1.3	Interface CardEmulationListener	
6.2.1.3.1	Method on Callback	
6.2.2	Package Connectivity Service	63
6.2.2.1	Interface ConnectivityService	63
6.2.2.1.1	Method prepareAndSendConnectivityEvent	63
6.2.2.1.2	Method prepareAndSendTransactionEvent(byte[] aid, short aidOffset, short aidLen,	
	byte[] parameters, short parametersOffset, short parametersLen)	66
6.2.2.1.3	Method prepareAndSendTransactionEvent (byte[] parameters, short parametersOffset, short	
	parametersLen)	69
6.2.3	Package Reader Service	
6.2.3.1	Interface ReaderMessage	
6.2.3.1.1	Method restartReaderModeProcedure	
6.2.3.1.2	Method prepareAndSendWriteXchgDataCommand	
6.2.3.1.3	Method prepareAndSendGetParameterCommand	
6.2.3.2	Interface ReaderListener	
6.2.3.2.1	Method onCallback	81
		0.4
Annex A	A (normative): Class, methods and tests acronyms	84
A.1 H	CI framework	84
A.1.1	Class HCIDevice	
A.1.1 A.1.2		
A.1.2 A.1.3	Interface HCIService	
	Interface HCIMessage	
A.1.4	Interface HCIListener	
A.1.5	Class HCIException	85
A.2 H	CI Services	85
A.2.1	Package cardemulation Package cardemulation	
A.2.1.1	Interface CardEmulationListener	
A.2.1.2	Interface CardEmulationMessage	
A.2.1.3	Interface CardEmulationService	
A.2.2	Package connectivity	
A.2.2.1	Interface ConnectivityListener	
A.2.2.2	Interface ConnectivityMessage	
A.2.2.3	Interface ConnectivityService	86
A.2.3	Readermode	86
A.2.3.1	Interface RaederListener	86
A.2.3.2	Interface ReaderMessage	
A.2.3.3	Interface ReaderService	
Annex I	3 (normative): AIDs - to be reserved	87

B.1 Package HCI framew	ork	87
B.1.1 Class HCIDevice		87
B.1.2 Interface HCIService	ce	87
B.1.3 Interface HCIMessa	nge	88
B.1.4 Interface HCILister	ner	88
B.1.5 Class HCIException	n	88
B.2 HCI Services		88
B.2.1 Package cardemular	tion	88
B.2.1.1 Interface CardEn	mulationListener	89
B.2.1.2 Interface CardEn	mulationMessage	89
B.2.1.3 Interface CardEn	mulationService	89
B.2.2 Package connectivity	ty	89
	ctivityListener	
B.2.2.2 Interface Conne	ctivityMessage	90
B.2.2.3 Interface Conne	ctivityService	90
B.2.3 Package readermod	e	90
B.2.3.1 Interface Reader	rMessage	90
B.2.3.2 Interface Reader	rListener	91
B.2.3.3 Interface Reader	rService	91
Annex C (normative):	Requirements	92
C.1 Non-occurrence and	out-of-scope requirements	92
	art	
C.2 FFS requirements		92
1		
$\mathcal{E}$	art	
Annex D (normative):	Test Specification for Java Card™ Platform HCI API for the U	ICC94
Annex E (normative):	uicc.contactless.test.util package and contactless interfaces	95
Annex F (normative):	Test Area files	
Annex G (informative):	Core specification version information	97
History	-	98

## Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://ipr.etsi.org).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

#### **Foreword**

This Technical Specification (TS) has been produced by ETSI Technical Committee Smart Card Platform (SCP).

The contents of the present document are subject to continuing work within TC SCP and may change following formal TC SCP approval. If TC SCP modifies the contents of the present document, it will then be republished by ETSI with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 0 early working draft;
  - 1 presented to TC SCP for information;
  - 2 presented to TC SCP for approval;
  - 3 or greater indicates TC SCP approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

## 1 Scope

The present document covers the minimum characteristics considered necessary in order to provide compliance to TS 102 705 [1].

It specifies conformance test cases for the UICC Application Programming Interface for Java Card<sup>TM</sup> for contactless Applications.

## 2 References

References are either specific (identified by date of publication and/or edition number or version number) or non-specific. For specific references, only the cited version applies. For non-specific references, the latest version of the reference document (including any amendments) applies.

• In the case of a reference to a TC SCP document, a non specific reference implicitly refers to the latest version of that document in the same Release as the present document.

Referenced documents which are not found to be publicly available in the expected location might be found at <a href="http://docbox.etsi.org/Reference">http://docbox.etsi.org/Reference</a>.

NOTE: While any hyperlinks included in this clause were valid at the time of publication ETSI cannot guarantee their long term validity.

#### 2.1 Normative references

The following referenced documents are necessary for the application of the present document.

[1]	ETSI TS 102 705: "Smart Cards; UICC Application Programming Interface for Java Card <sup>TM</sup> for Contactless Applications".
[2]	ISO/IEC 7816-3: "Identification cards - Integrated circuit cards - Part 3: Cards with contacts - Electrical interface and transmission protocols".
[3]	ETSI TS 102 622: "Smart Cards; UICC - Contactless Front-end (CLF) Interface; Host Controller Interface (HCI)".
[4]	ETSI TS 101 220: "Smart Cards; ETSI numbering system for telecommunication application providers".
[5]	ETSI TS 102 221: "Smart Cards; UICC-Terminal interface; Physical and logical characteristics".
[6]	ETSI TS 102 241: "Smart Cards; UICC Application Programming Interface (UICC API) for Java Card (TM)".
[7]	ETSI TS 102 223: "Smart Cards; Card Application Toolkit (CAT)".
[8]	ISO/IEC 9646-7: "Information technology - Open Systems Interconnection - Conformance testing methodology and framework - Part 7: Implementation Conformance Statements".
[9]	ETSI TS 102 226: "Smart Cards; Remote APDU structure for UICC based applications".
[10]	GlobalPlatform: "GlobalPlatform Card Specification Version 2.2, Amendment C: Contactless Services" Version 1.0.
NOTE: See h	ttp://www.globalplatform.org/

NOTE: See http://www.globalplatform.org/.

[11] Sun Microsystems "Application Programming Interface, Java Card<sup>TM</sup> Platform, 3.0.1 Classic Edition".

[12] Sun Microsystems "Runtime Environment Specification, Java Card<sup>TM</sup> Platform, 3.0.1 Classic

Edition".

[13] Sun Microsystems "Virtual Machine Specification Java Card<sup>TM</sup> Platform, 3.0.1 Classic Edition".

NOTE: SUN Java Card Specifications can be downloaded at

http://www.oracle.com/technetwork/java/javame/javacard/download/overview/index.html.

[14] ETSI TS 102 613: "Smart Cards; UICC - Contactless Front-end (CLF) Interface; Part 1: Physical

and data link layer characteristics".

#### 2.2 Informative references

The following referenced documents are not necessary for the application of the present document but they assist the user with regard to a particular subject area.

Not applicable.

## 3 Definitions, symbols and abbreviations

#### 3.1 Definitions

For the purposes of the present document, the following terms and definitions apply:

applet installation parameters: values for applet installation parameters in the Install(Install) command

**Conformance Requirement Reference (CRR):** description of the expected HCI API behaviour according to TS 102 705 [1]

contactless mode: is used as a generic term for "Card Emulation Mode" and "Reader Mode"

HCP message: message as specified in TS 102 622 [3]

NOTE: An HCP message can be of type "command", "event" or "response to a command".

test case: elementary test that checks for compliance with one or more Conformance Requirement References

test procedure: sequence of actions/commands to perform all the test cases defined in a test area

**test source file:** file containing methods that will load and install test applet in the card, execute and verify the test results, and restore the Default Initial Conditions on the UICC (when possible)

**RF Technology:** radio frequency technology supported by the HCI (TS 102 622 [3]) protocol specification

## 3.2 Symbols

For the purposes of the present document, the symbols given in TS 102 705 [1] apply.

#### 3.3 Abbreviations

For the purposes of the present document, the following abbreviations apply:

AID Application IDentifier

APDU Application Protocol Data Unit

NOTE: According to ISO/IEC 7816-3 [2].

API Application Programming Interface

CAT Card Application Toolkit

CB Chaining Bit

CLF Contactless Front-end

NOTE: According to TS 102 622 [3].

CRR Conformance Requirements Reference

CRRC Conformance Requirement Reference Context Error
CRRN Conformance Requirement Reference Normal

CRRP Conformance Requirement Reference Parameter Error

CRS Contactless Registry Services

DUT Device Under Test

EVT EVenT

FFS For Further Study

GND GrouND

HCI Host Controller Interface

NOTE: According to TS 102 622 [3].

HCP Host Controller Protocol

NOTE: According to TS 102 622 [3].

INS INStruction

ISO International Organisation for Standardisation

JCRE Java Card<sup>TM</sup> Run-time Environment

RF Radio Frequency

SAA Service Availability and Access possibility for the different services

SDK Software Development Kit

SW Status Word

SWP Single Wire Protocol

TAR Toolkit Application Reference

TBD To Be Defined

#### 3.4 Formats

#### 3.4.1 Format of the table of optional features

The columns in table 4.1 have the following meaning.

Column	Meaning			
Option	The optional feature supported or not by the DUT.	The optional feature supported or not by the DUT.		
Status	See clause 3.4.3.			
Support	The support columns are to be filled in by the supplier of the implementation. The following common notations, defined in ISO/IEC 9646-7 [8], are used for the support column in table 4.1.  Y or y supported by the implementation.  N or n not supported by the implementation.  N/A, n/a or - no answer required (allowed only if the status is N/A, directly or after evaluation of a conditional status).			
Mnemonic	The mnemonic column contains mnemonic identifiers for each item.			

## 3.4.2 Format of the applicability table

The applicability of every test in table 4.2 is formally expressed by the use of Boolean expression defined in the following clause.

The columns in table 4.2 have the following meaning.

Column	Meaning		
Clause	The "Clause" column identifies the clause containing the test case referenced in the "Test case number and description" column.		
Test case number and description	The "Test case number and description" column gives a reference to the test case number (along with the corresponding description) detailed in the present document and required to validate the DUT.		
Release	The "Release" column gives the Release applicable and onwards, for the corresponding test case.		
Execution requirements	The usage of the "Execution requirements" column is described in clause 4.4.		
Rel-x UICC	For a given Release, the corresponding "Rel-x UICC" column lists the tests required for a DUT to be declared compliant to this Release.		
Support	The "Support" column is blank in the proforma, and is to be completed by the manufacturer in respect of each particular requirement to indicate the choices, which have been made in the implementation.		

#### 3.4.3 Status and Notations

The "Rel-x" columns show the status of the entries as follows:

The following notations, defined in ISO/IEC 9646-7 [8], are used for the status column:

M	mandatory - the capability is required to be supported.
O	optional - the capability may be supported or not.
N/A	not applicable - in the given context, it is impossible to use the capability.
X	prohibited (excluded) - there is a requirement not to use this capability in the given context.
O.i	qualified optional - for mutually exclusive or selectable options from a set. "i" is an integer which identifies an unique group of related optional items and the logic of their selection which is defined immediately following the table.
Ci	conditional - the requirement on the capability ("M", "O", "X" or "N/A") depends on the support of other optional or conditional items. "i" is an integer identifying an unique conditional status expression which is defined immediately following the table. For nested conditional expressions, the syntax "IF THEN (IF THEN ELSE) ELSE" is to be used to avoid ambiguities.

#### References to items

For each possible item answer (answer in the support column) there exists a unique reference, used, for example, in the conditional expressions. It is defined as the table identifier, followed by a solidus character "/", followed by the item number in the table. If there is more than one support column in a table, the columns are to be discriminated by letters (a, b, etc.), respectively.

EXAMPLE: 4.1/4 is the reference to the answer of item 4 in table 4.1.

# 4 Applicability

## 4.1 Table of optional features

The device supplier shall state the support of possible options in table 4.1. See clause 3.4 for the format of table 4.1.

**Table 4.1: Options** 

Item	Option	Status	Support	Mnemonic
1	Card emulation, Type A	0		O_CE_TYPE_A
2	Card emulation, Type B	0		O_CE_TYPE_B
3	Card emulation, Type B'	0		O_CE_TYPE_B_PRIME
4	Card emulation, Type F	0		O_CE_TYPE_F
5	Reader Mode, Type A	0		O_RM_TYPE_A
6	Reader Mode, Type B	0		O_RM_TYPE_B
7	HCP message size greater than supported buffer size	0		O_MSG_GT_BUF

## 4.2 Applicability table

Table 4.2 specifies the applicability of each test case to the device under test. See clause 3.4 for the format of table 4.2.

Clause 4.4 should be referenced for usage of the execution requirements which are referenced in table 4.2 a) and described in table 4.2 c).

Table 4.2 a): Applicability of tests

Clause	Test case number and description	Release	Execution requirements	Rel-9 UICC	Support
6.1.1.1	Method getHCIService (ID2, ID4)	Rel-9	SAA1	М	
6.1.1.1	Method getHCIService (ID1-1)	Rel-9	SAA1	М	
6.1.1.1	Method getHCIService (ID1-2)	Rel-9	SAA2,	М	
			SAA1		
6.1.1.1	Method getHCIService (ID1-3)	Rel-9	SAA3	M	
6.1.1.1	Method getHCIService (ID3-1)	Rel-9	SAA6	M	
6.1.1.1	Method getHCIService (ID3-2)	Rel-9	SAA7	M	
6.1.1.1	Method getHCIService (ID3-3)	Rel-9	SAA8	M	
6.1.1.1	Method getHCIService (ID5-1)	Rel-9	SAA4	M	
6.1.1.1	Method getHCIService (ID5-2)	Rel-9	SAA5	M	
6.1.1.2	Method getPowerMode (ID1, ID2)	Rel-9	SAA1	M	
6.1.1.2	Method getPowerMode (ID3)	Rel-9		M	
6.1.1.3	Method isHCIServiceAvailable (ID1-1, ID3-1)	Rel-9	SAA1	М	
6.1.1.3	Method isHCIServiceAvailable (ID1-2)	Rel-9	SAA2,	M	
	, ,		SAA1		
6.1.1.3	Method isHCIServiceAvailable (ID1-3)	Rel-9	SAA3	M	
6.1.1.3	Method isHCIServiceAvailable (ID2)	Rel-9		M	
6.1.1.3	Method isHCIServiceAvailable (ID3-2)	Rel-9	SAA3	M	
6.1.1.3	Method isHCIServiceAvailable (ID4-1)	Rel-9	SAA4	М	
6.1.1.3	Method isHCIServiceAvailable (ID4-2)	Rel-9	SAA5	M	
6.1.1.3	Method isHCIServiceAvailable (ID5-1)	Rel-9	SAA10	М	
6.1.1.3	Method isHCIServiceAvailable (ID5-2)	Rel-9	SAA11	M	
6.1.2.1	Method register (ID1-1, ID2, ID3, ID4)	Rel-9	SAA1	M	
6.1.2.1	Method register (ID1, ID2, ID3-1, ID4)	Rel-9	SAA1	M	
6.1.2.1	Method register (ID1-2, ID3-2)	Rel-9	SAA1,	M	
			SAA2		
6.1.2.1	Method register (ID1-3, ID3-3)	Rel-9	SAA3	M	
6.1.2.2	Method deregister (ID1-1, ID1-3)	Rel-9	SAA1	M	
6.1.2.2	Method deregister (ID1-2, ID2)	Rel-9	SAA1,	M	
			SAA2		
6.1.2.3	Method activateEvent (ID1, ID4, ID6, ID7, ID8, ID9, ID10)	Rel-9	SAA1	М	
6.1.2.3	Method activateEvent (ID2)	Rel-9	SAA3	M	

Clause	Test case number and description	Release	Execution requirements	Rel-9 UICC	Support
6.1.2.3	Method activateEvent (ID3)	Rel-9	SAA1, SAA2	М	
6.1.2.3	Method activateEvent (ID5-1)	Rel-9	SAA10	М	
6.1.2.3	Method activateEvent (ID5-2)	Rel-9	SAA11	M	
6.1.2.4	Method detrvateEvent (ID1, ID4, ID5)	Rel-9	SAA1	M	
6.1.2.4	Method deactivateEvent (ID1, ID4, ID3)	Rel-9	SAA3	M	
6.1.2.4	Method deactivateEvent (ID3, ID6)	Rel-9	SAA1, SAA2	M	
6.1.2.5	Method requestCallbackNotification	Rel-9	SAA1	M	
6.1.2.6	Method getEventNotificationStatus(ID1, ID2, ID5-1)	Rel-9	SAA1	M	
6.1.2.6	Method getEventNotificationStatus(ID3,ID4, ID5-2)	Rel-9	SAA3	M	
6.1.2.6	Method getEventNotificationStatus(ID5-3, ID6, ID7)	Rel-9	SAA2,	М	
			SAA1		
6.1.3.1	Method isHeading	Rel-9	SAA1	M	
6.1.3.2	Method isComplete	Rel-9	SAA1	M	
6.1.3.3	Method getType (ID1)	Rel-9	SAA1	M	
6.1.3.3	Method getType (ID2)	Rel-9	SAA2,	M	
			SAA1		
6.1.3.4	Method getInstruction	Rel-9	SAA1	M	
6.1.3.6	Method getReceiveLength	Rel-9	SAA1	M	
6.1.3.7	Method getReceiveBuffer	Rel-9	SAA1	M	
6.1.4.1	Method throwlt	Rel-9	SAA1	M	
6.1.5.1	Method onCallback (ID1, ID2, ID3)	Rel-9	SAA1 SAA1	M	+
6.1.5.1	Method onCallback (ID4)	Rel-9	SAA1	C002	
6.1.5.1	Method onCallback (ID5)	Rel-9	SAA1	C001	
6.2.1.1.1	Method prepareAndSendGetParameterCommand (ID1)	Rel-9	SAA1	C001	
6.2.1.1.1	Method prepareAndSendGetParameterCommand (ID2)	Rel-9	SAA1	C002	
6.2.1.1.1	Method prepareAndSendGetParameterCommand (ID3-1)	Rel-9	SAA1	C001 C007	
6.2.1.1.1	Method prepareAndSendGetParameterCommand (ID3-2)	Rel-9	SAA1	C002 C007	
6.2.1.1.2	Method prepareAndSendSendDataEvent (ID1)	Rel-9	SAA1	C001	
6.2.1.1.2	Method prepareAndSendSendDataEvent (ID2)	Rel-9	SAA1	C002	
6.2.1.1.2	Method prepare/indeendSendDataEvent (ID2)  Method prepare/indeendSendDataEvent (ID4, ID5)	Rel-9	SAA1	M	
6.2.1.1.2	Method prepareAndSendSendDataEvent (ID4, ID5)  Method prepareAndSendSendDataEvent (ID3)	Rel-9	SAA1	C007	
		Rel-9	SAA1	M	
6.2.1.1.3	Method selectingMessage				
6.2.1.2.1	Method getCardRFType (ID1)	Rel-9	SAA1	C001	
6.2.1.2.1	Method getCardRFType (ID2)	Rel-9	SAA1	C002	
6.2.1.2.1	Method getCardRFType (ID4)	Rel-9	SAA1	C003	
6.2.1.2.1	Method getCardRFType (ID3)	Rel-9	SAA1	C004	
6.2.1.3.1	Method onCallback (ID1,ID2, ID3, ID5-2)	Rel-9	SAA1	C001	
6.2.1.3.1	Method onCallback (ID4, ID5, ID6, ID5-3)	Rel-9	SAA1	C002	
6.2.1.3.1	Method onCallback (ID5-1, ID5-4)	Rel-9	SAA1	M	
6.2.2.1.1	Method prepareAndSendConnectivityEvent (ID1, ID3, ID4, ID5)	Rel-9	SAA2, SAA1	М	
6.2.2.1.1	Method prepareAndSendConnectivityEvent (ID2-1)	Rel-9	SAA2, SAA1, SAA10	М	
6.2.2.1.1	Method prepareAndSendConnectivityEvent (ID2-1)	Rel-9	SAA10 SAA2, SAA1, SAA11	M	
6.2.2.1.1	Method prepareAndSendConnectivityEvent (ID6)	Rel-9	SAA2, SAA1, SAA9	М	
6.2.2.1.2	Method prepareAndSendTransactionEvent byte[] aid, short aidOffset, short aidLen, byte[] parameters, short parametersOffset, short parametersLen) (ID1, ID3, ID4, ID5)	Rel-9	SAA1, SAA2	M	
6.2.2.1.2	Method prepareAndSendTransactionEvent byte[] aid, short aidOffset, short aidLen, byte[] parameters, short parametersOffset, short parametersLen) (ID2-1)	Rel-9	SAA2, SAA10	M	

Clause	Test case number and description	Release	Execution requirements	Rel-9 UICC	Support
6.2.2.1.2	Method prepareAndSendTransactionEvent byte[] aid, short aidOffset, short aidLen, byte[] parameters, short parametersOffset, short parametersLen) (ID2-2)	Rel-9	SAA2, SAA11	M	
6.2.2.1.3	Method prepareAndSendTransactionEvent (byte[] parameters, short parametersOffset, short parametersLen ) (ID1, ID3, ID4)	Rel-9	SAA2	M	
6.2.2.1.3	Method prepareAndSendTransactionEvent (byte[] parameters, short parametersOffset, short parametersLen ) (ID2-1)	Rel-9	SAA2, SAA10	M	
6.2.2.1.3	Method prepareAndSendTransactionEvent (byte[] parameters, short parametersOffset, short parametersLen ) (ID2-2)	Rel-9	SAA2, SAA11	M	
6.2.3.1.1	Method restartReaderModeProcedure (ID1)	Rel-9	SAA3	C005	
6.2.3.1.1	Method restartReaderModeProcedure (ID2)	Rel-9	SAA3	C006	
6.2.3.1.1	Method restartReaderModeProcedure (ID3, ID4)	Rel-9	SAA3	M	
6.2.3.1.1	Method restartReaderModeProcedure (ID5-1)	Rel-9	SAA3, SAA10	М	
6.2.3.1.1	Method restartReaderModeProcedure (ID5-2)	Rel-9	SAA3, SAA11	М	
6.2.3.1.2	Method prepareAndSendWriteXchgDataCommand (ID1)	Rel-9	SAA3	C005	
6.2.3.1.2	Method prepareAndSendWriteXchgDataCommand (ID2)	Rel-9	SAA3	C006	
6.2.3.1.2	Method prepareAndSendWriteXchgDataCommand (ID4, ID5, ID6, ID7)	Rel-9	SAA3	М	
6.2.3.1.2	Method prepareAndSendWriteXchgDataCommand (ID3-1)	Rel-9	SAA3, SAA10	М	
6.2.3.1.2	Method prepareAndSendWriteXchgDataCommand (ID3-2)	Rel-9	SAA3, SAA11	М	
6.2.3.1.3	Method prepareAndSendGetParameterCommand (ID1)	Rel-9	SAA3	C005	
6.2.3.1.3	Method prepareAndSendGetParameterCommand (ID2)	Rel-9	SAA3	C006	
6.2.3.1.3	Method prepareAndSendGetParameterCommand (ID3-1)	Rel-9	SAA3, SAA10	М	
6.2.3.1.3	Method prepareAndSendGetParameterCommand (ID3-2)	Rel-9	SAA3, SAA11	М	
6.2.3.1.3	Method prepareAndSendGetParameterCommand (ID4)	Rel-9	SAA3	C007	
6.2.3.1.3	Method prepareAndSendGetParameterCommand (ID5)	Rel-9	SAA3	М	
6.2.3.2.1	Method onCallback	Rel-9	SAA3	М	
6.2.3.2.1	Method onCallback (ID1, ID2, ID3, ID4)	Rel-9	SAA3	C005	
6.2.3.2.1	Method onCallback (ID5, ID6, ID7, ID8)	Rel-9	SAA3	C006	

Table 4.2 b): Conditional items referenced by table 4.2 a)

Conditional item	Description
C001	IF O_CE_TYPE_A THEN M ELSE N/A
C002	IF O_CE_TYPE_B THEN M ELSE N/A
	IF O_CE_TYPE_B_PRIME THEN M ELSE N/A
C004	IF O_CE_TYPE_F THEN M ELSE N/A
C005	IF O_RM_TYPE_A THEN M ELSE N/A
C006	IF O_RM_TYPE_B THEN M ELSE N/A
C007	IF O_MSG_GT_BUF THEN M ELSE N/A

Table 4.2 c): Execution requirements referenced by table 4.2 a)

Execution requirement	Description			
SAA1	Card emulation service is available			
SAA2	Connectivity service is available			
SAA3	Reader Mode service is available			
SAA4	Access not allowed for Applet for Card Emulation service			
SAA5	Access not allowed for Applet for Reader service			
SAA6	Card emulation service is not available			
SAA7	Connectivity service is not available			
SAA8	Reader Mode service not available			
SAA9	Proactive functionalty in TS 102 241 [6] is supported			
SAA10	Toolkit application is available and registered to the ENVELOPE (EVENT DOWNLOAD - Contactless state request) and allowed to switch on/off HCI interface			
SAA11	No CRS on the card and test applet acting like CRS can be loaded			

## 4.3 Information provided by the device supplier

The device supplier shall provide the information indicated in table 4.3.

Table 4.3: Information provided by device suppliers

Item	Description	Value	Mnemonic
1	Presence of an application associated to an contactless applet that can be launched in the		AID,
	terminal host using EVT_TRANSACTION		Parameters
2	Supported received message buffer size		

## 4.4 Execution requirements

Table 4.2, Applicability of tests, specifies execution requirement (SAAn) for several test cases, to define the service availability and access possibility for the different services. For these test cases, the availability of the different services shall be guaranteed in order to execute the corresponding test procedure against the DUT. In case of absence of a particular (SAAn), the corresponding test case should not be carried out.

## 5 Test environment

This clause specifies requirements that shall be met and the testing rules that shall be followed during the test procedure.

## 5.1 Test environment description

The general architecture for the test environment is:




Figure 5.1

#### 5.2 Tests format

#### 5.2.1 Test area reference

Each test area is referenced as follows:

For HCI Framework and HCI services Testing: 'Api\_[package name]\_[class name]\_[method name]' where

- package name:
  - uicc.hci.framework: '1'.
  - uicc.hci.services: '2'.
- class name:
  - yyy: 3 letters for each class/interface.
    - See annex A for full classes/interfaces acronyms list.
- method name:
  - zzz[input parameters]:
    - See annex A for full methods name acronyms list.

#### 5.2.1.1 Conformance requirements

The conformance requirements are expressed in the following way:

- Method prototype as listed in TS 102 705 [1].
- Normal execution:
  - Contains normal execution and correct parameters limit values, each referenced as a Conformance Requirement Reference Normal (CRRN).
- Parameters error:
  - Contains parameter errors and incorrect parameter limit values, each referenced as a Conformance Requirement Reference Parameter Error (CRRP).
- Context error:
  - Contains errors due to the context the method is used in, each referenced as a Conformance Requirement Reference Context Error (CRRC).

#### 5.2.1.2 Test suite files

Each test suite files contains a table to indicate the correspondence between the applet names and the different test cases.

Applet Name	Test case ID
[Test Area Reference]_[Test applet number].java	Test case

The test applets and the related Cap Files use the following naming convention:

• Test Applet: [Test Area Reference]\_[Test applet number].java

• Cap File: [Test Area Reference].cap

The applet numbers start from '1'.

The Cap File format is described in Java Card<sup>TM</sup> Virtual Machine Specification [13].

All files from the same test area are located in the same subfolder.

#### 5.2.1.3 Initial conditions

In addition to the general precondtions defined in clause 5.3, this clause defines the initial conditions prior to the execution of each test case; i.e. for each ID.

#### 5.2.1.4 Test procedure

Each test procedure contains a table to indicate the expected responses form the API and APDU as follows.

	Test Case						
ld	HCI commands	API Description	API Expectation	HCI Response	CRR		
	Commands sent on	Test Case detailed	API expected	Expected behaviour at	Conformance		
	HCI interface	description	behaviour	APDU/HCI level	Requirements Reference		

#### 5.3 Initial conditions

The Initial Conditions are a set of general prerequisites for the UICC prior to the execution of testing. For each test procedure described in the present document, the following rules apply to the Initial Conditions:

• unless otherwise stated, before installing the applet(s) relevant to the current test procedure, all packages specific to other test procedures shall not be present.

Prior to any test the test environment shall have the UICC powered on and performed the session initialization and RF registries updates as described in TS 102 622 [3]. The test can be executed once the HCI interface is idle; i.e. no further communication is expected.

## 5.4 Package name

Java packages integrating this Test Suite shall follow this naming convention:

uicc.hci.test.framework.[Test Area Reference]: Java Card packages containing Test Area References for the TS 102 705 [1] uicc.hci.framework package.

**uicc.hci.test.services.cardemulation.[Test Area Reference]:** Java Card packages containing Test Area References for the TS 102 705 [1] uicc.hci.services.cardemulation package.

**uicc.hci.test.services.connectivity.[Test Area Reference]:** Java Card packages containing Test Area References for the TS 102 705 [1] uicc.hci.services.connectivity package.

**uicc.hci.test.services.readermode.[Test Area Reference]:** Java Card packages containing Test Area References for the TS 102 705 [1] uicc.hci.services.readermode package.

where the Test Area Reference is written in lower case.


**EXAMPLE:** 

The package ../uicc.hci.test.framework.[Test Area Reference] creates the following directory structure ../uicc/hci/test/framework/[Test Area Reference]/Api\_1\_...\_[1..n].\*, where 'Api\_1\_...\_[1..n].\*' are the different test applets Java source files used in [Test Area Reference].

## 5.5 AID coding

The AID coding for the Test Packages, Applet classes and Applets shall be as specified in TS 101 220 [4]. In addition, the following TAR and Application Provider specific data values are defined for use within the present document:

AID coding



TAR coding (3 bytes / 24 bits):

b1	b4 l	5	b8	b9	b16	b17	b24
							Applet class/instance number
							Package number
							Core package identifier
							Test Part Identifier

Applet instance number, Applet Class number, Package number:

- For package AID, package number shall start from 0 and class and instance numbers shall be 0.
- For class AID, package number is the number of the class package, class number shall start from 1 and instance shall be 0.
- For instance AID, package and class number are the number of class and package of which instance belongs, and instance number shall start from 1.

Test Part and Core Package Identifier

- 0000 0000 reserved (as TAR= '00.00.00' is reserved for Issuer Security Domain).
- 0010 0001 uicc.hci.test.framework.
- 0010 0100 uicc.hci.test.servces.
- 0010 0101 uicc.hci.test.services.cardemulation.
- 0010 0100 uicc.hci.test.servces.connectivity.
- 0010 0100 uicc.hci.test.servces.readermode.

Application Provider specific data (1 byte):

- '00' for Package.
- '01' for Applet class.
- '02' for Applet Instance.

EXAMPLE: Annex B.

## 5.6 Test equipment

These clauses recommend a minimum specification for each of the items of test equipment referenced in the tests.

#### 5.6.1 Test tool

This test tool shall meet the following requirements:

- be able to send and receive commands using the underlying HCI resources (e.g. gates and pipes) defined by the HCI protocol as specified in 102 622 [3];
- be able to send and receive the commands correctly on the lower layer; i.e TS 102 613 [14];
- the result of I/O commands shall be presented at the application layer;
- be able to provide results of the tests;
- shall send and/or compare all data specified in test file.

#### 5.6.2 Java Software Development Kit

Java Card<sup>TM</sup> software development kit (SDK) version supported by Java Card 3.0.1 specifications ([11], [12], [13]) is 1.5.

## 6 Test cases

## 6.1 Package uicc.hci.framework

#### 6.1.1 Class HCIDevice

#### 6.1.1.1 Method getHCIService

Test Area Reference: Api\_1\_Hdv\_Gsr.

#### 6.1.1.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

 $\label{eq:public_static} \begin{array}{c} \texttt{public static HCIService getHCIService(short serviceID)} \\ & \texttt{throws HCIException,} \\ & \texttt{javacard.framework.SystemException} \end{array}$ 

#### 6.1.1.1.1 Normal execution

- CRRN1: used to retrieve instances that implement one of HCIService subinterfaces defined in the present document.
- CRRN2: returns reference to the permanent JCRE entry point object of the HCIService.
- CRRN3: returns null if not yet registered.

#### 6.1.1.1.2 Parameter errors

• CRRP1: javacard.framework.SystemException is thrown with the reason code ILLEGAL\_VALUE if the serviceID does not match with the predefined values.

#### 6.1.1.1.3 Context errors

- CRRC1: HCIException thrown with reason HCI\_ACCESS\_NOT\_GRANTED if access to the indicated service is not permitted for the Applet.
- CRRC2: HCIException is thrown with reason HCI\_SERVICE\_NOT\_AVAILABLE if the requested service type is not available.

#### 6.1.1.1.2 Test suite files

Applet Name	Test case ID
Api_1_Hdv_Gsr_1.java	1
Api_1_Hdv_Gsr_2.java	2
Api_1_Hdv_Gsr_1.java	3
Api_1_Hdv_Gsr_1.java	4
Api_1_Hdv_Gsr_1.java	5

#### 6.1.1.1.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

## 6.1.1.1.4 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1			ed and registered service			
	1 - EVT_SEND_DATA (INS = '01')	<pre>getHCIService() serviceID = CARD_EMULATION_SERVICE_ID</pre>	No exception shall be thrown	EVT_SEND_DATA (SW - '90 00')	N1, N2	
	2 - EVT_SEND_DATA (INS = '02')	<pre>getHCIService() serviceID = CONNECTIVITY_SERVICE_ID</pre>	No exception shall be thrown	EVT_SEND_DATA (SW - '90 00')	N1, N2	
	3 - Send command on ISO interface; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet- INS= '03'	getHCIService() serviceID = READER_SERVICE_ID	No exception shall be thrown	SW - '90 00'	N1, N2	
2			t not registered			
	EVT_SEND_DATA (INS = '01')	Applet.register() has not yet been invoked.	Return: Null	EVT_SEND_DATA (SW - '90 00')	N3	
		<pre>getHCIService() serviceID = CARD_EMULATION_SERVICE_ID</pre>				
3			t availabile service			
	1 - Send command on ISO interface; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet- (INS = '01')	<pre>getHCIService() serviceID = CardEmulationService</pre>	Shall throw uicc.hci.framework.HCIExcept ion with error code HCI_SERVICE_NOT_AVAILA BLE	SW - '90 01'	C2	
	2 - EVT_SEND_DATA (INS='02')	<pre>getHCIService() serviceID = ConnectivityService</pre>	Shall throw uicc.hci.framework.HCIExcept ion with error code HCI_SERVICE_NOT_AVAILA BLE	EVT_SEND_DATA (SW - '90 01')	C2	
	3 - Send command on ISO interface; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet- (INS = '03')	getHCIService() serviceID = ReaderService	Shall throw uicc.hci.framework.HCIExcept ion with error code HCI_SERVICE_NOT_AVAILA BLE	SW - '90 01'	C2	
4			indefined service			
	EVT_SEND_DATA (INS = '04')	<pre>getHCIService() serviceID = -1</pre>	Shall throw javacard.framework.SystemE xception with error code ILLEGAL_VALUE	EVT_SEND_DATA (SW - '90 00')	P1	

	Test case							
ID	HCI Command	API Description	API Expectation	HCI Response	CRR			
5		Aco	ess not granted					
	1 - Send command on ISO interface; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet- INS = '01'	<pre>getHCIService() seviceID = CardEmulationService</pre>	Shall throw uicc.hci.framework.HCIExcept ion with error code HCI_ACCESS_NOT_GRANT ED	SW - '90 02'	C1			
	2 - Send command on ISO interface; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet- INS='03'	getHCIService() serviceID = ReaderSevice	Shall throw uicc.hci.framework.HCIExcept ion with error code HCI_ACCESS_NOT_GRANT ED	SW - '90 02'	C1			

#### 6.1.1.2 Method getPowerMode

Test Area Reference: Api\_1\_Hdv\_Gpm.

#### 6.1.1.2.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

public static byte getPowerMode()

#### 6.1.1.2.1.1 Normal execution

- CRRN1: returns the current power mode of the UICC as defined in TS 102 613 [14].
- CRRN2: returns the current power mode or -1 if the power mode cannot be retrieved.
- CRRN3: Applets communicating through the process() method shall also be able to use the API services defined in TS 102 705 [1] which do not require a CardEmulationListener registration (e.g. requesting the power mode or connectivity service).

#### 6.1.1.2.1.2 Parameter errors

• None.

#### 6.1.1.2.1.3 Context errors

• None.

#### 6.1.1.2.2 Test suite files

Applet Name	Test case ID
Api_1_Hdv_Gpm_1.java	1
Api_1_Hdv_Gpm_1.java	2
Api 1 Hdv Gpm 1.java	3

#### 6.1.1.2.3 Initial conditions

• The UICC is not powered up.

#### 6.1.1.2.4 Test procedure

	Test case						
ID	HCI Command	API Description	API Expectation	HCI Response	CRR		
1	Verify power mode						
	- Activate the UICC in full power mode EVT_FIELD_ON - EVT_CARD_ACTIVATED - EVT_SEND_DATA (select applet) - EVT_SEND_DATA(INS='05')	getPowerMode()	return = FULL_POWER_MODE	EVT_SEND_DATA (SW - '90 03')	N1, N3		
2		Verify	power mode		1		
	Activate the UICC in low power mode EVT_FIELD_ON - EVT_CARD_ACTIVATED - EVT_SEND_DATA (select applet) - EVT_SEND_DATA(INS='05')	getPowerMode()	return = LOW_POWER_MODE	EVT_SEND_DATA (SW - '90 04')	N1, N3		
3		SWP interfa	ce is not activated				
	sending command on ISO interface: - select applet- INS='05'	getPowerMode()	Return '-1'	SW - '90 05'	N2		

#### 6.1.1.3 Method isHCIServiceAvailable

Test Area Reference: Api\_1\_Hdv\_Isa.

#### 6.1.1.3.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

public static byte isHCIServiceAvailable(short serviceID)

#### 6.1.1.3.1.1 Normal execution

- CRRN1: this method is used to retrieve information about the availability of a HCIService more related to user interface.
- CRRN2: this method returns (byte)0x00 if the service is available and can be used, otherwise bit values set to:
  - bit 0 set: interface not supported by terminal;
  - bit 1 set: service not supported by terminal;
  - bit 2 set: access not allowed for Applet;
  - bit 3 set: HCI interface currently disabled in UICC.

#### 6.1.1.3.1.2 Parameter errors

• None.

#### 6.1.1.3.1.3 Context errors

None.

#### 6.1.1.3.2 Test suite files

Applet Name	Test case ID
Api_1_Hdv_Isa_1.java	1
Api_1_Hdv_Isa_1.java	2
Api_1_Hdv_Isa_1.java	3
Api_1_Hdv_Isa_1.java	4
Api_1_Hdv_Isa_2.java	5

#### 6.1.1.3.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

#### 6.1.1.3.4 Test procedure

		Test Case	)		
ID	HCI/APDU Command	API Description	API Expectation	HCI/APDU Response	CRR
1		Retrieve information of a	ın available service		
	1 - EVT_SEND_DATA (INS = '06')	isHCIServiceAvailable() serviceID = CARD_EMULATION_SERVICE_ID	0x00	EVT_SEND_DATA (SW - '90 00', data byte set to '00')	N1, N2
	2 - EVT_SEND_DATA (INS = '07')	<pre>isHCIServiceAvailable() serviceID = CONNECTIVITY_SERVICE_ID</pre>	0x00	EVT_SEND_DATA (SW - '90 00', data byte set to '00')	N1, N2
	3 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.3.1.3 not applicable here - send APDU INS='08'	isHCIServiceAvailable() serviceID = READER_SERVICE_ID	0x00	SW - '90 00', data byte set to '00'	N1, N2
2	Interface not supported by	terminal			
	Precondition: SWP interface not supported; the initial conditions in clause 6.1.1.3.1.3 not applicable here, and C6 should be connected to GND:	isHCIServiceAvailable()	bit 0 set	- SW - '90 00' - SW - '90 00', bit 0 set in the data byte	N2
	Sending command on ISO interface: - select applet - send APDU (INS = '06')				

	Test Case						
ID	HCI/APDU Command	API Description	API Expectation	HCI/APDU Response	CRR		
3	Service not supported by to	erminal					
	1 - Precondition: disable Connectivity service support in terminal; i.e. connectivity gate is not available in terminal pipe creation is not possible and the terminal shall indicate in TERMINAL PROFILE HCI Connectivity is not supported select applet - EVT_SEND_DATA (INS = '07')	<pre>isHCIServiceAvailable() serviceID = CONNECTIVITY_SERVICE_ID</pre>	bit 1 set	EVT_SEND_DATA (SW - '90 00', bit 1 set in the data byte)	N2		
	2 - Precondition: disable Reader service support in terminal; i.e. reader RF gates are not available in terminal Send command on ISO interface to select applet; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet - send APDU (INS='08')	isHCIServiceAvailable() serviceID = READER_SERVICE_ID	bit 1 set	SW - '90 00', bit 1 set in the data byte	N2		
4	Access not allowed for App	olet					
	1 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet - send APDU (INS = '06')	<pre>isHCIServiceAvailable() serviceID = CARD_EMULATION_SERVICE_ID</pre>	bit 2 set	SW - '90 00', bit 2 set in the data byte	N2		
	2 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.1.1.3 not applicable here - select applet - send APDU (INS = '08')	isHCIServiceAvailable() serviceID = READER_SERVICE_ID	bit 2 set	SW - '90 00', bit 2 set in the data byte	N2		
5	<b>HCI</b> interface currently disa						
	1 - Precondition: Contactless functionality state is disabled in the UICC as defined in TS 102 223 [7]. Send on ISO interface the following commands: - Send APDU to select the applet Send APDU (INS = '06')	isHCIServiceAvailable()	bit 3 set	SW - '90 00', bit 3 set in the data byte	N2		

		Test Case			
ID	HCI/APDU Command	API Description	API Expectation	HCI/APDU Response	CRR
	2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send APDU to select the applet Send APDU (INS = '06') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C	setCommunicationInterface() API method of Global Platform Amendment C [10] is used to disable HCI interface isHCIServiceAvailable()  setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface	bit 3 set	SW - '90 04', bit 3 set in the data byte	N2

#### 6.1.2 Interface HCIService

#### 6.1.2.1 Method register

Test Area Reference: Api\_1\_Hsr\_Reg.

#### 6.1.2.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

#### 6.1.2.1.1.1 Normal execution

- CRRN1: registers a Listener object to the Service instance.
- CRRN2: a certain listener type can only be registered to the same service type.
- CRRN3: The Registration of Listener Interfaces and activation of events shall be persistent.

#### 6.1.2.1.1.2 Parameter errors

- CRRP1: throws HCIException in case the listener Object registered to the service is not implementing the corresponding interface of the HCIService instance with error code:
  - HCIException.HCI\_WRONG\_LISTENER\_TYPE.

#### 6.1.2.1.1.3 Context errors

• CRRC1: throws HCIException with error code HCI\_LISTENER\_ALREADY\_REGISTERED in case a listener Object of the same type has already been registered.

#### 6.1.2.1.2 Test suite files

Applet Name	Test case ID
Api_1_Hsr_Reg_1.java	1-1
Api_1_Hsr_Reg_3.java	1-2
Api_1_Hsr_Reg_5.java	1-3
Api_1_Hsr_Reg_1.java	2
Api_1_Hsr_Reg_2.java	3-1
Api_1_Hsr_Reg_4.java	3-2
Api_1_Hsr_Reg_6.java	3-3
Api_1_Hsr_Reg_1.java	4

#### 6.1.2.1.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

#### 6.1.2.1.4 Test procedure

			Test case		
ID	HCI Command	Description	API Expectation	HCI Response	CRR
1		Register Li	stener to a service		
	1 - EVT_SEND_DATA (INS = '09')	<pre>register() Service = CardEmulationService Listener = CardEmulationListener</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1
	2 - EVT_SEND_DATA (INS = '09')	<pre>register() Service = ConnectivityService Listener = ConnectivityListener</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1
	3 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.1.3 not applicable here - send APDU (INS='09')	register() Service = ReaderService Listener = ReaderListener	No exception shall be thrown	SW- '90 00'	N1
2		Register w	rong listener type		
	EVT_SEND_DATA (INS = '0A')	register() Service = ConnectivityService Listener = CardEmulationListener	Shall throw uicc.hci.framework.HCIExceptio n with error code HCI_WRONG_LISTENER_TYP E	EVT_SEND_DATA (SW- '90 00')	N2, P1
3			Iready registered		
	1 - EVT_SEND_DATA (INS = '0B')	register() Service = CardEmulationService Listener = CardEmulationListener	Shall throw uicc.hci.framework.HCIExceptio n with error code HCI_LISTENER_ALREADY_RE GISTERED	EVT_SEND_DATA (SW- '90 00')	C1
	2 - EVT_SEND_DATA (INS = '0B')	register() Service = ConnectivityService Listener = ConnectivityListener	Shall throw uicc.hci.framework.HCIExceptio n with error code HCI_LISTENER_ALREADY_RE GISTERED	EVT_SEND_DATA (SW- '90 00')	C1

			Test case			
ID	HCI Command	Description	API Expectation	HCI Response	CRR	
	3 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.1.3 not applicable here - send APDU (INS='0B')	register() Service = ReaderService Listener = ReaderListener	Shall throw uicc.hci.framework.HCIExceptio n with error code HCI_LISTENER_ALREADY_RE GISTERED	SW- '90 00'	C1	
4		Persistent Li	Persistent Listener Registration			
	- Send EVT_SEND_DATA (INS = '09') - EVT_FIELD_OFF - EVT_FIELD_ON - EVT_CARD_ACTIV ATED - Select the applet - Send	<pre>register() Service = CardEmulationService Listener = CardEmulationListener</pre>	Shall throw uicc.hci.framework.HCIExceptio n with error code HCI_LISTENER_ALREADY_RE GISTERED	EVT_SEND_DATA (SW- '6F 01')	N3	
	EVT_SEND_DATA (INS = '09')					

#### 6.1.2.2 Method deregister

Test Area Reference: Api\_1\_Hsr\_Drg.

#### 6.1.2.2.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

void deregister(HCIListener listener)

#### 6.1.2.2.1.1 Normal execution

- CRRN1: deregisters a Listener object from the Service instance.
- CRRN2: Calling deregister with an argument that does not identify a currently registered HCIListener has no
  effect.
- CRRN3: Applets communicating through the process() method shall also be able to use the API services defined in TS 102 705 [1] which do not require a CardEmulationListener registration (e.g. requesting the power mode or connectivity service).

#### 6.1.2.2.1.2 Parameter errors

• None.

#### 6.1.2.2.1.3 Context errors

• None.

#### 6.1.2.2.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hsr_Drg_1.java	1
Api_1_Hsr_Drg_2.java	2

#### 6.1.2.2.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

#### 6.1.2.2.4 Test procedure

		Test o			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		Deregister Listener to a	Service - CardEmulation	n	
	1 - EVT_SEND_DATA (INS = '01')	<pre>register() Service = CardEmulationService Listener = CardEmulationListener</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1, N3
		<pre>deregister() Service = CardEmulationService Listener = CardEmulationListener</pre>			
	2 - EVT_SEND_DATA (INS = '02')	<pre>deregister() Service = ConnectivityService Listener = CardEmulationListener</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N2,
	3 - EVT_SEND_DATA (INS = '03')	<pre>deregister() Service = CardEmulationService Listener = CardEmulationListener</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N2, N3
2		Deregister Listener to	a Service - Connectivity	,	
	1 - EVT_SEND_DATA (INS = '01')	<pre>register() Service = ConnectivityService Listener = ConnectivityListener deregister()</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1
		Service = ConnectivityService Listener = ConnectivityListener			
	2 - EVT_SEND_DATA (INS = '02')	<pre>deregister() Service = CardEmulationService Listener = ConnectivityListener</pre>	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N2
	3 - EVT_SEND_DATA (INS = '03')	deregister() Service = ConnectivityService Listener = ConnectivityListener	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N2

#### 6.1.2.3 Method activateEvent

Test Area Reference: Api\_1\_Hsr\_Ace.

#### 6.1.2.3.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

 $\begin{tabular}{ll} \begin{tabular}{ll} \beg$ 

#### 6.1.2.3.1.1 Normal execution

- CRRN1: This method is used to activate an event.
- CRRN2: for all service interfaces HCIListener.EVENT\_HCI\_TRANSMISSION\_FAILED is sent to notify the applet when the UICC failed to transmit a message sent by CLF.
- CRRN3: for all service interfaces HCIListener.EVENT\_HCI\_RECEPTIONS\_FAILED is sent to notify the applet when the UICC failed to receive a message sent by CLF.
- CRRN4: Possible values for event for Card emulation service are:
  - EVENT\_GET\_PARAMETER\_RESPONSE.
  - EVENT\_ON\_SEND\_DATA.
  - EVENT\_FIELD\_OFF.
- CRRN5: Possible values for event for Reader service are:
  - EVENT\_GET\_PARAMETER\_RESPONSE.
  - EVENT\_WRITE\_EXCHANGE\_DATA\_RESPONSE.
  - EVENT\_TARGET\_DISCOVERED.
- CRRN6: Possible value for event for Connectivity service is EVENT\_STAND\_BY.
- CRRN7: The Registration of Listener Interfaces and activation of events shall be persistent.
- CRRN8: When the contactless interface is disabled (cf. "state of contactless functionality" in TS 102 223 [7] and setCommunicationInterface() API method of "GlobalPlatform Amendment C" [10]), the Contactless Framework shall throw an HCIException with reason code HCI\_CURRENTLY\_DISABLED.
- CRRN9: The Contactless Framework shall raise an EVENT\_FIELD\_OFF if this event is activated for this Applet instance, before the invocation of the deselect() method of the Applet instance.
- CRRN10: After the EVENT\_FIELD\_OFF event the Applet instance shall not be triggered by any other event until the Applet instance is selected again.
- CRRN11: If the current application protocol is APDU based the HCI framework shall handle an application session termination according to TS 102 221 [5] independent of the interface used for message exchange.
- CRRN12: Applet selection and deselection shall be performed by the Contactless Framework according to the rules defined in the "Java Card<sup>TM</sup> Runtime Environment Specification, 3.0 Classic Edition" [11] and in "GlobalPlatform Amendment C" [10].
- CRRN13: The select() method of the Applet instance shall always be invoked for an Applet selection according to the rules given in "Java Card<sup>TM</sup> Runtime Environment Specification, 3.0 Classic Edition" [11].
- CRRN14: If the HCI event EVT\_FIELD\_OFF or EVT\_CARD\_DEACTIVATED defined by the HCI protocol as specified in [4] is received by the Contactless Framework and the UICC is still powered, the Applet instance shall be deselected according to "GlobalPlatform Amendment C" [10].

#### 6.1.2.3.1.2 Parameter errors

- CRRP1: HCIException with reason code HCI\_WRONG\_EVENT\_TYPE if a wrong event was activated for this service instance.
- CRRP2: HCIException with reason code HCI\_CURRENTLY\_DISABLED if the interface to the contactless frontend (CLF) is currently disabled and the event is ReaderListener.EVENT\_TARGET\_DISCOVERED.

#### 6.1.2.3.1.3 Context errors

None.

#### 6.1.2.3.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hsr_Ace_1.java	1
Api_1_Hsr_Ace_3.java	2
Api_1_Hsr_Ace_2.java	3
Api_1_Hsr_Ace_1.java	4
Api_1_Hsr_Ace_7.java	5
Api_1_Hsr_Ace_4.java	6
Api_1_Hsr_Ace_5.java	7
Api_1_Hsr_Ace_6.java	8
Api_1_Hsr_Ace_8.java	9
Api_1_Hsr_Ace_6.java	10

#### 6.1.2.3.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

#### 6.1.2.3.4 Test procedure

		Test Case			
ID	HCI Command	Description	API Expectation	HCI Response	CRR
1		Event activation - CardE	mulationService		
	1 - EVT_SEND_DATA(INS = '10')	HCIListener = CardEmulationListener HCIService = CardEmulationService	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1, N2
		activateEvent() event = HCIListener.EVENT_HCI_TRANSMI SSION_FAILED			
	2 - EVT_SEND_DATA(INS = '11')	HCIListener = CardEmulationListener HCIService = CardEmulationService	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1, N3
		<pre>activateEvent() event = HCIListener.EVENT_HCI_RECEPTI ONS_FAILED</pre>			
	3 - EVT_SEND_DATA(INS = '12')	HCIListener = CardEmulationListener HCIService = CardEmulationService	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1, N4
		<pre>activateEvent() event = CardEmulationListener.EVENT_G ET_PARAMETER_RESPONSE</pre>			
	4 - - EVT_SEND_DATA(INS = '14')	HCIListener = CardEmulationListener HCIService = CardEmulationService activateEvent() event =	No exception shall be thrown	EVT_SEND_DATA (SW- '90 00')	N1, N4
		CardEmulationListener.EVENT_O N SEND DATA			

		Test Case			
ID	HCI Command	Description	API Expectation	HCI Response	CRR
2		Event activation - Re	eaderService		
	1 - EVT_SEND_DATA (INS = '11')	<pre>HCIService = ReaderService activateEvent() event = HCIListener.EVENT_HCI_RECEPTI</pre>	No exception shall be thrown.	SW - '90 00'	N1, N3
	2. Cand command an ICO	ONS_FAILED  HCIService = ReaderService	No avecation about	C/M 100 001	NIA
	2- Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.3.3 not applicable here - Send APDU INS='11'	activateEvent() event = EVENT_TARGET_DISCOVERED	No exception shall be thrown.	SW - '90 00'	N1, N5
	3 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.3.3 not applicable here - Send APDU INS='12'	<pre>HCIService = ReaderService activateEvent() event = EVENT_WRITE_EXCHANGE_DATA_RES PONSE</pre>	No exception shall be thrown.	SW - '90 00'	N1, N5
	4 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.3.3 not applicable here - Send APDU INS='13'	<pre>HCIService = ReaderService activateEvent() event = HCIListener.EVENT_HCI_TRANSMI SSION FAILED</pre>	No exception shall be thrown.	SW - '90 00'	N1, N2.
	5 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.3.3 not applicable here - Send APDU INS='14'	HCIService = ReaderService activateEvent() event = EVENT_GET_PARAMETER_RESPONSE	No exception shall be thrown.	SW - '90 00'	N1, N5
3		Event activation - Conr	nectivityListener		
	1 - EVT_SEND_DATA(INS = '10')	<pre>HCIListener = ConnectivityListener HCIService = ConnectivityService activateEvent()</pre>	No exception shall be thrown.	EVT_SEND_DATA (SW- '90 00')	N1, N2
	2 - EVT_SEND_DATA(INS =	event = HCIListener.EVENT_HCI_TRANSMI SSION_FAILED HCIListener =	No exception shall	EVT_SEND_DATA	N1,
	'11')	<pre>ConnectivityListener HCIService = ConnectivityService activateEvent() event = HCIListener.EVENT_HCI_RECEPTI ONS FAILED</pre>	be thrown.	(SW- '90 00')	N3
	3 - EVT_SEND_DATA(INS = '12')	HCIListener = ConnectivityListener HCIService = ConnectivityService activateEvent()	No exception shall be thrown.	EVT_SEND_DATA (SW- '90 00')	N1, N6
		event = EVENT_STAND_BY	t tumo		
4	EVT_SEND_DATA (INS = '16')	Wrong event  HCIListener = CardEmulationListener HCIService = CardEmulationService activateEvent() event value = 0x02	HCIException with reason code HCI_WRONG_EV ENT_TYPE shall be thrown	EVT_SEND_DATA (SW- '90 00')	P1

		Test Case			
<b>ID</b> 5	HCI Command	Description HCI is disal	API Expectation	HCI Response	CRR
5	1- Precondition: Contactless	HCIService = ReaderService	HCIException with	SW- '90 00'	P2, N8
	functionality state is disabled in the UICC as defined in TS 102 223 [7]. Send on ISO interface the following commands - Send APDU to select the	activateEvent() event = ReaderListener.EVENT_TARGET_D ISCOVERED	reason code HCI_CURRENTLY _DISABLED shall be thrown	3000	7 2, 140
	applet Send APDU (INS = '01') on ISO interface				
	2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C. Send on ISO interface send the following commands: - Send APDU to select the applet Send APDU (INS = '01') on ISO interface - Postcondition: Contactless functionality state is enabled again in the	setCommunicationInterface() API method of "GlobalPlatform Amendment C" [10] used to disable HCI interface HCIService = ReaderService activateEvent() event = ReaderListener.EVENT_TARGET_D ISCOVERED  setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface	HCIException with reason code HCI_CURRENTLY _DISABLED shall be thrown	SW- '90 00'	P2, N8
6	UICC as defined in Global Platform Amendment C	Persistent Event Activ	vation		
Ü	- Send	Service =		-	N7
	EVT_SEND_DATA (INS = '01') - EVT_FIELD_OFF - Power off - Power on - EVT_FIELD_ON - EVT_CARD_ACTIVATED - Select the applet - Send EVT_SEND_DATA (INS = '02')	<pre>CardEmulationService Listener = CardEmulationListener activateEvent(EVENT_FIELD_OFF )</pre>	No exception shall be thrown. getEventNotificatio nStatus() = true	EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00')	
7	,	Event Field Off before of	leselect		
	- EVT_FIELD_OFF - EVT_FIELD_ON - EVT_CARD_ACTIVATED - Select the applet - Send EVT_SEND_DATA (INS = '01')	<pre>Service = CardEmulationService Listener = CardEmulationListener activateEvent(EVENT_ON_SEND_D ATA) during the installation onCallback() activateEvent() event = EVENT_FIELD_OFF deselect()</pre>	EVENT_FIELD_OF F raised before deselect()	EVT_SEND_DATA (SW- '90 00')	N9, N11, N12, N14
8		No triggering after Event	Field Off	•	•
	EVT_FIELD_OFF - Send EVT_SEND_DATA (INS = '01')	<pre>Service = CardEmulationService Listener = CardEmulationListener activateEvent (EVENT_ON_SEND_D ATA) during the installation onCallback() activateEvent()</pre>	EVENT_ON_SEN D_DATA shall not be raised	No response, or EVT_SEND_DATA with any response except: (SW - '90 00')	N1, N4, N10, N11
		event = EVENT_FIELD_OFF			
9		Check for Selection			
	Send EVT_SEND_DATA (INS = '01')	Service = CardEmulationService Listener = CardEmulationListener	Check for invocation of select()	EVT_SEND_DATA (SW - '90 00')	N12, N13

	Test Case					
ID	HCI Command	Description	API Expectation	HCI Response	CRR	
10	No triggering after Event Card Deactivate					
	EVT_CARD_DEACTIVATE - Send EVT_SEND_DATA (INS = '01')	Service = CardEmulationService Listener = CardEmulationListener activateEvent(EVENT_ON_SEND_D ATA) during the installation onCallback() activateEvent()	EVT_SEND_DATA	No response or EVT_SEND_DATA withany response except: (SW - '90 00' or '6D 00')	N12, N14	

#### 6.1.2.4 Method deactivateEvent

Test Area Reference: Api\_1\_Hsr\_Dae.

#### 6.1.2.4.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

#### 6.1.2.4.1.1 Normal execution

- CRRN1: deactivates an event from the list of activated events.
- CRRN2: for all service interfaces HCIListenr.EVENT\_HCI\_TRANSMISSION\_FAILED is sent to notify the applet when the UICC failed to transmit a message sent by CLF.
- CRRN3: for all service interfaces HCIListenr HCIListener.EVENT\_HCI\_RECEPTIONS\_FAILED is sent to
  notify the applet when the UICC failed to receive a message sent by CLF.
- CRRN4: Possible values for parameter event for Card emulation service are:
  - EVENT\_GET\_PARAMETER\_RESPONSE.
  - EVENT\_ON\_SEND\_DATA.
  - EVENT\_FIELD\_OFF.
- CRRN5: Possible values for parameter event for Reader service are:
  - EVENT\_GET\_PARAMETER\_RESPONSE.
  - EVENT\_WRITE\_EXCHANGE\_DATA\_RESPONSE.
  - EVENT\_TARGET\_DISCOVERED.
- CRRN6: Possible values for Connectivity service is EVENT\_STANDBY.

#### 6.1.2.4.1.2 Parameter errors

- CRRP1: HCIException with reason code HCIException.HCI\_WRONG\_EVENT\_TYPE in case a wrong event was deactivated for this service instance.
- CRRP2: HCIException with reason code.HCI\_WRONG\_EVENT\_TYPE in case the event wasn't activated before.

#### 6.1.2.4.1.3 Context errors

None.

#### 6.1.2.4.2 Test suite files

Applet Name	Test case ID
Api_1_Hsr_Dae_1.java	1-1
Api_1_Hsr_Dae_1.java	1-2
Api_1_Hsr_Dae_2.java	1-3
Api_1_Hsr_Dae_2.java	1-4
Api_1_Hsr_Dae_5.java	2
Api_1_Hsr_Dae_4.java	3
Api_1_Hsr_Dae_1.java	4
Api_1_Hsr_Dae_3.java	5
Api_1_Hsr_Dae_6.java	6
Api_1_Hsr_Dae_7.java	7

#### 6.1.2.4.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

#### 6.1.2.4.4 Test procedure

		Test case				
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1	Event deactivation - CardEmulationService					
	1 - EVT_SEND_DATA(INS='10')	HCIService = CardEmulationService Event has been successfully activated	No exception shall be thrown	EVT_SEND_DAT A (SW- '90 00')	N1, N2	
		<pre>deactivateEvent() event = HCIListener.EVENT_HCI_TRA NSMISSION_FAILED</pre>				
	2 - EVT_SEND_DATA(INS='11')	<pre>HCIService = CardEmulationService Event has been successfully activated deactivateEvent() event =</pre>	No exception shall be thrown	EVT_SEND_DAT A (SW- '90 00')	N1, N3	
		HCIListener.EVENT_HCI_REC EPTIONS_FAILED				
	3 - EVT_SEND_DATA(INS='12')	HCIService = CardEmulationService Event has been successfully activated	No exception shall be thrown	EVT_SEND_DAT A (SW- '90 00')	N1, N4	
		<pre>deactivateEvent() event = CardEmulationListener.EVE NT_GET_PARAMETER_RESPONSE</pre>				
	4 - EVT_SEND_DATA(INS='14')	HCIService = CardEmulationService Event has been successfully activated	No exception shall be thrown	EVT_SEND_DAT A (SW- '90 00')	N1, N4	
		<pre>deactivateEvent() event = CardEmulationListener.EVE NT_ON_SEND_DATA</pre>				

		Test case				
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
2	Event deactivation - ReaderService  1- Send command on ISO HCIService = No exception shall SW - '90 00' N1 N2					
	1- Send command on ISO interface to select applet; the	ReaderService	No exception shall be thrown	SW - '90 00'	N1, N2	
	initial conditions in clause		De tillowii			
	6.1.2.3.3 not applicable here	deactivateEvent()				
	- Send APDU (INS='09')	<pre>event = HCIListener.EVENT HCI TRA</pre>				
	·	NSMISSION_FAILED				
	2 - Send command on ISO	HCIListener =	No exception shall	SW - '90 00'	N1, N3	
	interface to select applet; the	ReaderListener HCIService =	be thrown			
	initial conditions in clause	ReaderService				
	6.1.2.4.3 not applicable here	Event has been				
	- Send APDU (INS='10')	successfully activated				
		deactivateEvent()				
		event = HCIListener.				
		EVENT_HCI_TRANSMISSION_FA				
		ILED HCIListener =	N1 (* 1 11	0144 100 001	N/4 N/5	
	3 - Send command on ISO interface to select applet; the	ReaderListener =	No exception shall be thrown	SW - '90 00'	N1, N5	
	initial conditions in clause	HCIService =	be thrown			
	6.1.2.4.3 not applicable here	ReaderService				
	- Send APDU (INS='11')	Event has been successfully activated				
	(,	successfully activated				
		deactivateEvent()				
		event =				
		EVENT_GET_PARAMETER_RESPO				
	4 - Send command on ISO	HCIListener =	No exception shall	SW - '90 00'	N1, N5	
	interface to select applet; the	ReaderListener	be thrown	JOW 30 00	141,140	
	initial conditions in clause	HCIService =				
	6.1.2.4.3 not applicable here	ReaderService				
	- Send APDU (INS='12')	deactivateEvent()				
		event =				
		EVENT_WRITE_EXCHANGE_DATA				
	5- Send command on ISO	RESPONSE HCIListener =	No exception shall	SW - '90 00'	N1, N5	
	interface to select applet; the	ReaderListener	be thrown	3000	141, 143	
	initial conditions in clause	HCIService =				
	6.1.2.4.3 not applicable here	ReaderServiceEvent has been successfully				
	- Send APDU (INS='13')	activated				
		<pre>deactivateEvent()</pre>				
		event = EVENT TARGET DISCOVERED				
3		Event deactivation - Connec	ctivitvService	1	1	
	1 -	HCIListener =	No exception shall	EVT_SEND_DAT	N1, N2	
	EVT_SEND_DATA(INS='10')	ConnectivityListener	be thrown	A (SW- '90 00')	,	
		HCIService =		,		
		ConnectivityService Event has been				
		successfully activated				
		<pre>deactivateEvent() event =</pre>				
		HCIListener.EVENT_HCI_TRA				
		NSMISSION_FAILED				
	2 -	HCIListener =	No exception shall	EVT_SEND_DAT	N1, N3	
	EVT_SEND_DATA(INS='11')	ConnectivityListener HCIService =	be thrown	A (SW- '90 00')		
		ConnectivityService				
		Event has been				
		successfully activated				
		deactivateEvent()				
		event =				
		HCIListener.EVENT_HCI_REC				
		EPTIONS_FAILED			1	

	Test case						
ID	HCI Command	API Description	API Expectation	HCI Response	CRR		
	3 -	HCIListener =	No exception shall	EVT_SEND_DAT	N1,		
	EVT_SEND_DATA(INS='12')	ConnectivityListener HCIService =	be thrown	A (SW- '90 00')	N6		
		ConnectivityService					
		Event has been					
		successfully activated					
		deactivateEvent()					
		event = EVENT_STAND_BY					
4		Wrong event typ	oe				
	EVT_SEND_DATA (INS = '16')	HCIService =	HCIException with	EVT_SEND_DAT	P1		
		CardEmulationService Event has been	reason code	A (SW- '90 00')			
		successfully activated	HCI_WRONG_EV				
			ENT_TYPE shall be thrown				
		deactivateEvent()	be thrown				
5	Dear	event value = 02 ctivate an non-active event - Ca	ardEmulationService	<u> </u>			
5	1 - EVT_SEND_DATA (INS =	HCIService =	HCIException with	EVT_SEND_DAT	P2		
	11-EVI_SEND_DATA (INS = 110')	CardEmulationService	reason code	A (SW- '90 00')			
	1.07	Event was not activated	HCI_WRONG_EV	7. (5** 30 00)			
		before	ENT_TYPE shall				
		<pre>deactivateEvent() event =</pre>	be thrown				
		HCIListener.EVENT HCI TRA					
		NSMISSION_FAILED					
	2 - EVT_SEND_DATA (INS =	HCIService =	HCIException with	EVT_SEND_DAT	P2		
	'11')	CardEmulationService	reason code	A (SW- '90 00')			
		Event was not activated before	HCI_WRONG_EV				
		Deloie	ENT_TYPE shall				
		deactivateEvent()	be thrown				
		event =					
		HCIListener.EVENT_HCI_REC					
	3 - EVT_SEND_DATA (INS =	EPTIONS_FAILED  HCIService =	HCIException with	EVT_SEND_DAT	P2		
	12')	CardEmulationService	reason code	A (SW- '90 00')	_		
	. – ,	Event was not activated	HCI_WRONG_EV	7.(0 00 00)			
		before	ENT_TYPE shall				
		deactivateEvent()	be thrown				
		event =					
		CardEmulationListener.EVE					
	A EVE OFNID DATA (INC	NT_GET_PARAMETER_RESPONSE	LIOIE	EVE OFNE DAT	DO		
	4 -EVT_SEND_DATA (INS =	<pre>HCIService = CardEmulationService</pre>	HCIException with	EVT_SEND_DAT	P2		
	'13')	Event was not activated	reason code HCI_WRONG_EV	A (SW- '90 00')			
		before	ENT_TYPE shall				
		doogtivatoEvent()	be thrown				
		<pre>deactivateEvent() event =</pre>					
		CardEmulationListener.EVE					
		NT_FIELD_OFF					
	5- EVT_SEND_DATA (INS =	HCIService =	HCIException with	EVT_SEND_DAT	P2		
	'14')	CardEmulationService Event was not activated	reason code	A (SW- '90 00')			
		before	HCI_WRONG_EV				
			ENT_TYPE shall				
		deactivateEvent()	be thrown				
		<pre>event = CardEmulationListener.EVE</pre>					
		NT ON SEND DATA					
6	Dea	activate an non-active event - (	ConnectivityService	1	1		
_	EVT_SEND_DATA(INS='12')	HCIListener =	HCIException with	EVT_SEND_DAT	P2		
	_= '_='	ConnectivityListener	reason code	A (SW- '90 00')	1 -		
		HCIService =	HCI_WRONG_EV	, , , , , ,			
		ConnectivityService Event was not activated	ENT_TYPE shall				
		before	be thrown				
		deactivateEvent()					
		event = EVENT_STAND_BY					

	Test case						
ID	HCI Command	API Description	API Expectation	HCI Response	CRR		
7	D	eactivate an non-active event	- ReaderService				
	1 - EVT_SEND_DATA(INS='10')	HCIListener = ReaderListener HCIService = ReaderService Event was not activated before	HCIException with reason code HCI_WRONG_EV ENT_TYPE shall be thrown	EVT_SEND_DAT A (SW- '90 00')	P2		
		<pre>deactivateEvent() event = EVENT_GET_PARAMETER_RESPO NSE</pre>					
	2 - EVT_SEND_DATA(INS='11')	HCIListener = ReaderListener HCIService = ReaderService Event was not activated before  deactivateEvent() event = EVENT_WRITE_EXCHANGE_DATA	HCIException with reason code HCI_WRONG_EV ENT_TYPE shall be thrown	EVT_SEND_DAT A (SW- '90 00')	P2		
	3 - EVT_SEND_DATA(INS='12')	RESPONSE  HCIListener = ReaderListener HCIService = ReaderService Event was not activated before  deactivateEvent() event = EVENT TARGET DISCOVERED	HCIException with reason code HCI_WRONG_EV ENT_TYPE shall be thrown	EVT_SEND_DAT A (SW- '90 00')	P2		

# 6.1.2.5 Method requestCallbackNotification

Test Area Reference: Api\_1\_Hsr\_Rcn.

## 6.1.2.5.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

 $\begin{tabular}{ll} {\tt void requestCallbackNotification(byte event)} \\ & {\tt throws HCIException} \end{tabular}$ 

## 6.1.2.5.1.1 Normal execution

• CRRN1: the call of this method trows HCIException with reason code HCI\_ACCESS\_NOT\_GRANTED.

## 6.1.2.5.1.2 Parameter errors

None.

## 6.1.2.5.1.3 Context errors

• None.

## 6.1.2.5.2 Test Suite Files

Applet Name	Test case ID
Api 1 Hsr Rcn 7.java	1

## 6.1.2.5.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

## 6.1.2.5.4 Test procedure

	Test case							
ID	HCI Command	API Description	API Expectation	HCI Response	CRR			
1		Request Callback	Notification					
	EVT_SEND_DAT A (INS = '10')	Precondition: HCIService = CardEmulationService Corresponding listener registered No event is activated	throws HClexception with reason code HCI_ACCESS_NOT_ GRANTED	EVT_SEND_DAT A (SW- '90 00')	N1			
		<pre>requestCallbackNotification () event = HCIListener.EVENT_HCI_TRANSMISS ION_FAILED</pre>						

## 6.1.2.6 Method getEventNotificationStatus

Test Area Reference: Api\_1\_Hsr\_Gen.

## 6.1.2.6.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

boolean getEventNotificationStatus(byte event) throws HCIException

#### 6.1.2.6.1.1 Normal execution

- CRRN1: return the activation state of an event; if true the event is activated for this listener, else false.
- CRRN2: For CardEmulationService:EVENT\_GET\_PARAMETER\_RESPONSE, EVENT\_SEND\_DATA, and EVENT\_FIELD\_OFF.
- CRRN3: For ReaderService: EVENT\_GET\_PARAMETER\_RESPONSE, EVENT\_WRITE\_EXCHANGE\_DATA\_RESPONSE, and EVENT\_TARGET\_DISCOVERED.
- CRRN4: For ConnectivityService: ConnectivityListener.EVENT\_STANDBY.
- CRRN5: For all service interfaces: HCIListener.EVENT\_HCI\_TRANSMISSION\_FAILED HCIListener.EVENT HCI RECEPTIONS FAILED.

## 6.1.2.6.1.2 Parameter errors

 CRRP1: HCIException with reason code HCIException.HCI\_WRONG\_EVENT\_TYPE in case the event was not one of the possible values.

## 6.1.2.6.1.3 Context errors

None.

## 6.1.2.6.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hsr_Gen_1.java	1
Api_1_Hsr_Gen_1.java	2
Api_1_Hsr_Gen_3.java	3
Api_1_Hsr_Gen_3.java	4
Api_1_Hsr_Gen_1.java	5-1
Api_1_Hsr_Gen_3.java	5-2
Api_1_Hsr_Gen_2.java	5-3
Api_1_Hsr_Gen_2.java	6
Api_1_Hsr_Gen_2.java	7

## 6.1.2.6.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

# 6.1.2.6.4 Test procedure

	Test case						
ID	HCI Command	API Description	API Expectation	HCI Response	CRR		
1		Event notification status	false - CardEmulationService				
	1 - EVT_SEND_DATA	HCIService = CardEmulationService	No exception shall be thrown.	EVT_SEND_DAT A (SW- '90 00')	N1, N5		
	(INS = '10')	<pre>getEventNotificationStatus() event = HCIListener.EVENT HCI TRANSM</pre>	getEventNotificationStatus() = false				
		ISSION_FAILED					
	2 - EVT_SEND_DATA	HCIService = CardEmulationService	No exception shall be thrown.	EVT_SEND_DAT A (SW- '90 00')	N1, N5		
	(INS = '11')	<pre>getEventNotificationStatus() event =</pre>	getEventNotificationStatus() = false				
		HCIListener.EVENT_HCI_RECEPT IONS_FAILED					
	3 - EVT_SEND_DATA	HCIService = CardEmulationService	No exception shall be thrown.	EVT_SEND_DAT A (SW- '90 00')	N1, N2		
	(INS = '12')	<pre>getEventNotificationStatus() event = CardEmulationListener.EVENT_ GET PARAMETER RESPONSE</pre>	getEventNotificationStatus() = false				
	4 - EVT_SEND_DATA	4 HCIService = CardEmulationService	No exception shall be thrown.	EVT_SEND_DAT A (SW- '90 00')	N1, N2		
	(INS = '13')	<pre>getEventNotificationStatus() event = CardEmulationListener. EVENT_FIELD_OFF</pre>	getEventNotificationStatus() = false	,			
	5 - EVT_SEND_DATA	HCIService = CardEmulationService	No exception shall be thrown.	EVT_SEND_DAT A (SW- '90 00')	N1, N2		
	(INS = '14')	<pre>getEventNotificationStatus() event = CardEmulationListener. EVENT_ON_SEND_DATA</pre>	getEventNotificationStatus() = false	,			

		Test c			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
2			true - CardEmulationService		
	EVT_SEND_DATA (INS = '15')	<pre>HCIService = CardEmulationService activateEvent() event = CardEmulationListener.EVENT_ ON_SEND_DATA</pre>	No exception shall be thrown.  getEventNotificationStatus() = true	EVT_SEND_DAT A (SW- '90 00')	N1, N2
		<pre>getEventNotificationStatus () event = CardEmulationListener.EVENT_ ON_SEND_DATA</pre>			
3			tus true - ReaderService	Tarre	1
	1 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here	<pre>HCIService = ReaderService activateEvent() event = ReaderListener. EVENT_WRITE_EXCHANGE_DATA_RE SPONSE</pre>	No exception shall be thrown.  getEventNotificationStatus() = true	SW - '90 00'	N1, N3
	- Send APDU (INS = '21')	<pre>getEventNotificationStatus() event = ReaderListener. EVENT_WRITE_EXCHANGE_DATA_RE SPONSE</pre>			
	2 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here	<pre>HCIService = ReaderService activateEvent() event = ReaderListener.EVENT_TARGET_ DISCOVERED</pre>	No exception shall be thrown.  getEventNotificationStatus() = true	SW - '90 00'	N1, N3
	Send APDU (INS = '22')  3 - Send APDU	<pre>getEventNotificationStatus() event = ReaderListener.EVENT_TARGET_ DISCOVERED  HCIService = ReaderService</pre>	No exception shall be thrown.	SW - '90 00'	N1, N3
	(INS = '23')	activateEvent() event = ReaderListener. EVENT_GET_PARAMETER_RESPONSE	getEventNotificationStatus() = true	SW - 90 00	INT, INS
	4 - Send command	<pre>getEventNotificationStatus() event = ReaderListener. EVENT_GET_PARAMETER_RESPONSE HCIService = ReaderService</pre>	No exception shall be thrown.	SW - '90 00'	N1, N5
	on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here	<pre>activateEvent() event = ReaderListener. EVENT_HCI_RECEPTIONS_FAILED getEventNotificationStatus()</pre>	getEventNotificationStatus() = true	- 30 00	IVI, IVO
	- Send APDU (INS = '24')	<pre>getEventNotIffcatIonStatus() event = ReaderListener. EVENT_HCI_RECEPTIONS_FAILED HCIService = ReaderService</pre>	No exception shall be thrown.	SW - '90 00'	N1, N5
	on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here - Send APDU (INS = '25')	<pre>activateEvent() event = ReaderListener. EVENT_HCI_TRANSMISSION_FAILE D  getEventNotificationStatus() event = ReaderListener.</pre>	getEventNotificationStatus() = true	55 55	,110
		EVENT_HCI_TRANSMISSION_FAILE D			

		Test c	ase		
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
4			tus false - ReaderService	Total (100 00)	T
	1 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here - Send APDU (INS='10')	<pre>HCIListener = ReaderListener HCIService = ReaderServiceEvent has been successfully activated  deactivateEvent() event = HCIListener. EVENT_HCI_TRANSMISSION_FAILE D</pre>	No exception shall be thrown.  getEventNotificationStatus() = false	SW - '90 00'	N1, N5
	2 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here - Send APDU (INS = '11')	HCIListener = ReaderListener HCIService = ReaderServiceEvent has been successfully activated  deactivateEvent() event = EVENT_GET_PARAMETER_RESPONSE	No exception shall be thrown.  getEventNotificationStatus() = false	SW - '90 00'	N1, N3
	3 - Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here - Send APDU (INS='12')	HCIListener = ReaderListener HCIService = ReaderServiceEvent has been successfully activated  deactivateEvent() event = EVENT_WRITE_EXCHANGE_DATA_RE SPONSE	No exception shall be thrown. getEventNotificationStatus() = false	SW - '90 00'	N1, N3
	4- Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here - Send APDU (INS = '13')	HCIListener = ReaderListener HCIService = ReaderServiceEvent has been successfully activated  deactivateEvent() event = EVENT_TARGET_DISCOVERED	No exception shall be thrown. getEventNotificationStatus() = false	SW - '90 00'	N1, N3
	5- Send command on ISO interface to select applet; the initial conditions in clause 6.1.2.6.5 not applicable here - Send APDU (INS='14')	HCIListener = ReaderListener HCIService = ReaderServiceEvent has been successfully activated  deactivateEvent() event = EVENT_HCI_RECEPTION_FAILED	No exception shall be thrown.  getEventNotificationStatus() = false	SW - '90 00'	N1, N3
5		Wrong	event type	<u> </u>	
	1- EVT_SEND_DATA (INS = '16')	<pre>HCIService = CardEmulationService getEventNotificationStatus() event = 0x02</pre>	HCIException with reason code HCI_WRONG_EVENT_TYPE shall be thrown	EVT_SEND_DAT A (SW- '90 00')	P1
	2- Send on ISO interface - Send APDU (INS = '16')	HCIService = ReaderService getEventNotificationStatus() event = 0x84	HCIException with reason code HCI_WRONG_EVENT_TYPE shall be thrown	SW - '90 00'	P1
	3 - EVT_SEND_DATA (INS = '16')	HCIService = ConnectivityService getEventNotificationStatus() event = 0x02	HCIException with reason code HCI_WRONG_EVENT_TYPE shall be thrown	EVT_SEND_DAT A (SW - '90 00')	P1

		Test ca	ase		
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
6		Event notification status	false - ConnectivityService		
	1 - EVT_SEND_DATA (INS = '10')	HCIListener = ConnectivityListener HCIService = ConnectivityService	No exception shall be thrown.  getEventNotificationStatus() = false	EVT_SEND_DAT A (SW - '90 00')	N1, N5
		<pre>getEventNotificationStatus() event = HCIListener.EVENT_HCI_TRANSM ISSION_FAILED</pre>			
	2 - EVT_SEND_DATA (INS = '11')	<pre>HCIListener = ConnectivityListener HCIService =</pre>	No exception shall be thrown. getEventNotificationStatus() =	EVT_SEND_DAT A (SW - '90 00')	N1, N5
	(1145 = 11)	ConnectivityService	false		
		<pre>getEventNotificationStatus() event = HCIListener.EVENT_HCI_RECEPT IONS_FAILED</pre>			
	3 - EVT_SEND_DATA (INS = '12')	HCIListener = ConnectivityListener HCIService =	No exception shall be thrown.  getEventNotificationStatus() =	EVT_SEND_DAT A (SW - '90 00')	N1, N4
		ConnectivityService  getEventNotificationStatus() event =	false		
		ConnectivityListener.EVENT_S TAND BY			
7			true - ConnectivityService	1	<u> </u>
	EVT_SEND_DATA (INS = '15')	HCIListener = ConnectivityListener HCIService = ConnectivityService	No exception shall be thrown.  getEventNotificationStatus() =	EVT_SEND_DAT A (SW - '90 00')	N1, N4
		activateEvent() event = ConnectivityListener.EVENT_S TAND_BY	true		
		<pre>getEventNotificationStatus() event = ConnectivityListener.EVENT_S TAND_BY</pre>			

# 6.1.3 Interface HCIMessage

## 6.1.3.1 Method is Heading

Test Area Reference: Api\_1\_Hme\_Mhd.

## 6.1.3.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

boolean isHeading()

## 6.1.3.1.1.1 Normal execution

- CRRN1: Checks if the current content is the heading part of an HCP message The heading information
  indicates the first part of an HCP message; with the isComplete() method it is possible to check whether the
  complete message has already been received.
- CRRN2: returns true if the current message is the heading part of the message.
- CRRN3: An HCIMessage object shall encapsulate one HCP message according to the HCI protocol as specified in [3].

- CRRN4: HCI message for the different contactless modes shall be identified by different types of interfaces.
- CRRN5: In case the Applet instance has registered the CardEmulationListener and has activated the EVENT\_ON\_SEND\_DATA the process() method of this Applet instance shall not be invoked during the selection.

## 6.1.3.1.1.2 Parameter errors

None.

## 6.1.3.1.1.3 Context errors

None.

#### 6.1.3.1.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hme_Mhd_1.java	1

#### 6.1.3.1.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT CARD ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

## 6.1.3.1.4 Test procedure

	Test case							
ID	HCI Command	API Description	API Expectation	HCI Response	CRR			
1		me	ssage is complete					
	EVT_SEND_DATA (INS ='01')	event =	No exception shall be thrown.	EVT_SEND_DATA (SW - '90 00')	N1, N2,			
		EVENT_ON_SEND_DATA HCIMessage.isHeading()		Result returned in the first response byte of the R-APDU data: b1 is set	N3, N4, N5			

## 6.1.3.2 Method isComplete

Test Area Reference: Api\_1\_Hme\_Mco.

## 6.1.3.2.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

boolean isComplete()

## 6.1.3.2.1.1 Normal execution

- CRRN1: this method checks for the completeness of the HCP message, i.e. the last received HCP packet had the chaining bit CB set to 1. It returns true if the message is complete.
- CRRN2: the framework shall copy data into the receive buffer up to the end of the buffer. When the HCI message is longer than the available buffer length the HCIMessage shall be set as not complete.

## 6.1.3.2.1.2 Parameter errors

None.

#### 6.1.3.2.1.3 Context errors

• None.

## 6.1.3.2.2 Test suite files

Applet Name	Test case ID
Api_1_Hme_Mco_1.java	1

## 6.1.3.2.3 Initial condition

- EVT FIELD ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

## 6.1.3.2.4 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1		message	is complete			
	EVT_SEND_DATA (INS = '01')	<pre>onCallback() event = EVENT_ON_SEND_DATA HCIMessage.isComplete()</pre>	No exception shall be thrown. isComplete() = true	EVT_SEND_DATA (SW - '90 00')  Result returned in the second response byte of the R-APDU data: b1 is set	N1	

## 6.1.3.3 Method getType

Test Area Reference: Api\_1\_Hme\_Mty.

## 6.1.3.3.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

byte getType()

#### 6.1.3.3.1.1 Normal execution

- CRRN1: Returns the type of the incoming HCI message, it shall be one of constant values TYPE\_defined in this interface. The returned type possibilities are: TYPE\_COMMAND Indicates the HCI message type "command", TYPE\_EVENT Indicates the HCI message type "event" and TYPE\_RESPONSE indicates the HCI message type "response".
- CRRN2: In the case of a fragmented incoming message this method shall return the HCI message type coded in the first part of the HCI message.

## 6.1.3.3.1.2 Parameter errors

• None.

#### 6.1.3.3.1.3 Context errors

• None.

## 6.1.3.3.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hme_Mty_1.java	1
Api_1_Hme_Mty_2.java	2

## 6.1.3.3.3 Initial condition

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

## 6.1.3.3.4 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1		message of type even	- Card emulation			
	EVT_SEND_DATA (INS = '01')	onCallback() event = EVENT_ON_SEND_DATA HCIMessage.getType()	No exception shall be thrown.	EVT_SEND_DATA (SW - '90 00')	N1	
			getType () = TYPE_EVENT	third response byte of the R-APDU data is '40'		
2		message of type eve	nt - Connectivity			
	- Send command on ISO interface to select applet; the initial	<pre>extends ConnectivityListener activateEvent() event = EVENT_STAND_BY</pre>	No exception shall be thrown.	SW = '90 00' third response byte	N1	
	conditions in clause 6.1.3.3.3 not applicable here	onCallback() event = EVENT_STAND_BY HCIMessage.getType()	getType () = TYPE_EVENT	of the R-APDU data is '40'		
	- EVT_STANDBY - Send on ISO interface (INS = '01')					

## 6.1.3.4 Method getInstruction

Test Area Reference: Api\_1\_Hme\_Min.

## 6.1.3.4.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

byte getInstruction()

#### 6.1.3.4.1.1 Normal execution

• CRRN1: returns the instruction part of the HCP message header of the current incoming HCP message, see TS 102 622 [3] for further information. It returns the message instruction, b8,b7 of the return value are set to zero.

## 6.1.3.4.1.2 Parameter errors

• None.

#### 6.1.3.4.1.3 Context errors

None.

## 6.1.3.4.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hme_Min_1.java	1
Api_1_Hme_Min_2.java	2

## 6.1.3.4.3 initial condition

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

## 6.1.3.4.4 Test procedure

	Test case				
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		message of type event: 0	Card emulation		
	EVT_SEND_DATA (INS = '01')	onCallback() event = EVENT_ON_SEND_DATA HCIMessage.getInstruction()	No exception shall be thrown.  getInstruction() = '10'	EVT_SEND_DATA (SW - '90 00') the 4th response byte of the R-APDU data is '10'	N1
2		message of type response	: Card emulation	1	1
	- EVT_SEND_DATA (INS = '01') - ANY_OK(ATQA) - EVT_SEND_DATA (arbitrary data)	<pre>onCallback() prepareAndSendGetParameterComman d() parameter = PARAM_ID_TYPE_A_CARD_ATQA onCallback() event = EVENT_GET_PARAMETER_RESPONSE HCIMessage.getInstruction()</pre>	No exception shall be thrown. getInstruction() = '00'	- EVT_SEND_DATA (SW - '90 00') - ANY_GET_PARAM TER(ATQA) - EVT_SEND_DATA (SW - '90 00')  the 4th response byte of the R-APDU data is '00'	N1

## 6.1.3.5 Method getReceiveOffset

Test Area Reference: Api\_1\_Hme\_Mro.

## 6.1.3.5.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

short getReceiveOffset()

#### 6.1.3.5.1.1 Normal execution

• CRRN1: this method returns the offset of the received HCI message data in the receive buffer, retrieved via getReceiveBuffer().

## 6.1.3.5.1.2 Parameter errors

• None.

## 6.1.3.5.1.3 Context error

• None.

NOTE: This method is implicitly tested in clause 6.1.3.7.

## 6.1.3.6 Method getReceiveLength

Test Area Reference: Api\_1\_Hme\_Mrl.

## 6.1.3.6.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

short getReceiveLength()

## 6.1.3.6.1.1 Normal execution

• CRRN1: this method returns the length of the received HCI message data. It is the size of the message data available in the receive buffer.

## 6.1.3.6.1.2 Parameter errors

None.

## 6.1.3.6.1.3 Context error

• None.

## 6.1.3.6.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hme_Mrl_1.java	1

#### 6.1.3.6.3 Initial condition

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

## 6.1.3.6.4 Test procedure

	Test case						
ID	HCI Command	API Description	API Expectation	HCI Response	CRR		
1		Get received message leng	gth: CardEmulationSe	ervice			
	EVT_SEND_DATA: Send message with	onCallback() event = EVENT_ON_SEND_DATA HCIMessage.getReceiveLength()	No exception shall be thrown.	EVT_SEND_DATA (SW - '90 00')	N1		
	the length '0A' message is complete		getReceiveLength() = '0A'	Result returned in the 7th and 8th response byte of the R-APDU data ('00 0A')			

## 6.1.3.7 Method getReceiveBuffer

Test Area Reference: Api\_1\_Hme\_Mrb.

## 6.1.3.7.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

byte[] getReceiveBuffer()

#### 6.1.3.7.1.1 Normal execution

- CRRN1: returns a reference to the underlying HCI message receive buffer. The length of this buffer is system dependent; it is guaranteed to be at least 270 bytes.
- CRRN2: it returns the buffer holding the current HCI message.
- CRRN3: the content of the array starts at the location indicated by getReceiveOffset() and has the length indicated by getReceiveLength().

## 6.1.3.7.1.2 Parameter errors

None.

#### 6.1.3.7.1.3 Context errors

• None.

## 6.1.3.7.2 Test suite files

Applet Name	Test case ID
Api_1_Hme_Mrb_1.java	1

#### 6.1.3.7.3 Initial condition

- EVT FIELD ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

## 6.1.3.7.4 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1		Message	length < 270 bytes			
	EVT_SEND_DATA (message with the length = 09: '00 01 02 03 04 05 06 07 08')	Idat Dacai Makiit tar ()	No exception shall be thrown. First 9 bytes of getReceiveBuffer() shall be '01 02 03 04 05 06 07 08 09'	EVT_SEND_DATA () First 9 bytes of the response data shall be '00 01 02 03 04 05 06 07 08'	N1, N2, N3	

# 6.1.4 Class HCIException

## 6.1.4.1 Method throwlt

Test Area Reference: Api\_1\_Hxp\_Trw.

## 6.1.4.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

 $\begin{array}{c} {\tt public \ static \ void \ throwIt(short \ reason)} \\ {\tt throws \ HCIException} \end{array}$ 

## 6.1.4.1.1.1 Normal execution

• CRRN1: Throws the JCRE owned instance of the HCIException with the specified reason code.

## 6.1.4.1.1.2 Parameter errors

• None.

## 6.1.4.1.1.3 Context errors

• None.

## 6.1.4.1.2 Test suite files

Applet Name	Test case ID
Api_1_Hxp_Trw_1.java	1

## 6.1.4.1.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI Interface.

# 6.1.4.1.4 Test procedure

	Test Case				
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		Throw Exception			
	1 - EVT_SEND_DATA (INS = '01')	<pre>throwIt() reason = HCI_ACCESS_NOT_GRANTED</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	2 - EVT_SEND_DATA (INS = '02')	<pre>throwIt() reason = HCI_CONDITIONS_NOT_SATISFIED</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	3 - EVT_SEND_DATA (INS = '03')	throwIt() reason = HCI_CURRENTLY_DISABLED	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	4 - EVT_SEND_DATA (INS = '04')	<pre>throwIt() reason = HCI_FRAGMENTED_MESSAGE_ONGOING</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	5 - EVT_SEND_DATA (INS = '05')	throwIt() reason = HCI_INVALID_LENGTH	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	6 - EVT_SEND_DATA (INS = '06')	throwIt() reason = HCI_LISTENER_ALREADY_REGISTERED	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	7 - EVT_SEND_DATA (INS = '07')	throwIt() reason = HCI_NOT_AVAILABLE	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	8 - EVT_SEND_DATA (INS = '08')	<pre>throwIt() reason = HCI_RESOURCES_NOT_AVAILABLE</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1
	9 - EVT_SEND_DATA (INS = '09')	<pre>throwIt() reason = HCI_SERVICE_NOT_AVAILABLE</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1

	Test Case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
	10 - EVT_SEND_DATA (INS = '0A')	<pre>throwIt() reason = HCI_WRONG_EVENT_TYPE</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1	
	11 - EVT_SEND_DATA (INS = '0B')	<pre>throwIt() reason = HCI_WRONG_LISTENER_TYPE</pre>	Throw exception with corresponding reason code	EVT_SEND_DA TA (SW - '90 00')	N1	

## 6.1.5 Interface HCIListener

## 6.1.5.1 Method on Callback

Test Area Reference: Api\_1\_Hln\_Ocb.

## 6.1.5.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

void onCallback(byte event, HCIMessage message)

#### 6.1.5.1.1.1 Normal execution

- CRRN1: The Contactless Framework shall invoke the method \*typeListener.onCallback only with events which are defined in this particular listener or HCIListener and only with message objects of this listener type.
- CRRN2: The Applet instance shall activate the events with CardEmulationService.activateEvent before it will receive any event notification.
- CRRN3: The context as defined in the Java Card<sup>TM</sup> specification [11], [12] and [13] shall be set to the context of the Applet which implements the onCallback() method. The previous context (context of the caller) shall be the context of the Contactless Framework.
- CRRN4: Upon return from the onCallback() method a pending transaction shall be aborted.
- CRRN5: As stated in TS 102 622 [3], a reset of the underlying data link layer shall be transparent to the application layer if the data link layer recovers without any loss of data.
- CRRN6: The Contactless Framework shall be able to receive one or more HCI messages while waiting for a response related to a command originated by the Applet (e.g. processing a request for parameters) especially for the EVT\_FIELD\_OFF case.

#### 6.1.5.1.1.2 Parameter errors

• None.

#### 6.1.5.1.1.3 Context errors

None.

## 6.1.5.1.2 Test Suite Files

Applet Name	Test case ID
Api_1_Hln_Ocb_4.java	1
Api_1_Hln_Ocb_5.java	2
Api_1_Hln_Ocb_6.java	3
Api_1_Hln_Ocb_2.java	4
Api_1_Hln_Ocb_3.java	5

# 6.1.5.1.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.

# 6.1.5.1.4 Test procedure

		Test c	ase		
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		Get o	context		
	1 - Send EVT_SEND_DAT A (Select applet) Send EVT_SEND_DAT A (INS = '01')	<pre>Service = CardEmulationService Listener = CardEmulationListener process(): JCSystem.getAID();</pre>	No exception shall be thrown expected AID = current AID	EVT_SEND_DATA (SW '90 00')	N3
	2 - Send EVT_SEND_DAT A (Select applet) Send EVT_SEND_DAT A (INS = '02')	<pre>Service = CardEmulationService Listener = CardEmulationListener process(): JCSystem.getPreviousContextAID( );</pre>	No exception shall be thrown previous AID = null	EVT_SEND_DATA (SW '90 00')	N3
2		Abort tr	ansaction		
	Send EVT_SEND_DAT A (Select applet) - Send EVT_SEND_DAT A (INS = '01') - Send ENVELOPE_UN RECOGNIZED	<pre>Service = CardEmulationService Listener = CardEmulationListener  onCallback():     JCsystem.beginTransaction(); Set up test array     //no     JCSystem.commitTransaction!!  processToolkit():</pre>	No exception shall be thrown  Test array shall not be modifed	EVT_SEND_DATA (SW '90 00')	N4
		check array modification			
3			yer recovery		
	- Send EVT_SEND_DAT A (Select applet) - Send EVT_SEND_DAT A (INS = '01') - reset the underlying data link layer while receiving the reponse	Service = CardEmulationService Listener = CardEmulationListener activateEvent(EVENT_ON_SEND_DAT A) during the installation onCallback() prepareAndSendSendDataEvent() data = {0x00, 0x00, 0x00, 0x00, 0x00, 0x0, 0x00, 0x00, 0x00,, 0x90, 0x00} length = 256B	No exception shall be thrown	- EVT_SEND_DATA (SW - '90 00') in the response to selecting applet - EVT_SEND_DATA (0x00, 0x00, 0x00, 0x00, 0x00, 0x0, 0x00, 0x00, 0x00,, 0x90, 0x00) No loss of data expected	N5

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
4		Receive messages while	waiting for get parame	eter		
	- EVT_SEND_DAT A (Select applet) - EVT_FIELD_OFF before ANY_OK	Listener = CardEmulationListener activateEvent() event = EVENT_GET_PARAMETER_RESPONSE  prepareAndSendGetParameterComma nd() paramID = PARAM ID TYPE B CARD ATQB	No exception shall be thrown on Callback() shall receive ANY_OK as EVENT_GET_PARAM ETER_RESPONSE	EVT_SEND_DATA ()  ANY_GET_PARAMETE R(ATQB)  No error after EVT_FIELD_OFF	N1, N2, N6	
5		Receive messages while	waiting for get parame	eter	·	
	- EVT_SEND_DAT A (Select applet) - EVT_FIELD_OFF before ANY_OK	Listener = CardEmulationListener activateEvent() event = EVENT_GET_PARAMETER_RESPONSE  prepareAndSendGetParameterComma nd() paramID = PARAM ID TYPE A CARD ATOA	No exception shall be thrown onCallback() shall receive ANY_OK as EVENT_GET_PARAM ETER_RESPONSE	EVT_SEND_DATA ()  ANY_GET_PARAMETE R(ATQA)  No error after EVT_FIELD_OFF	N1, N2, N6	

# 6.2 Package uicc.hci.services

# 6.2.1 Package CardEmulation Service

## 6.2.1.1 Interface CardEmulationMessage

## 6.2.1.1.1 Method prepareAndSendGetParameterCommand

Test Area Reference: Api\_2\_CEm\_ Sgp.

## 6.2.1.1.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

 $\begin{tabular}{ll} void prepareAndSendGetParameterCommand(byte paramID) \\ throws HCIException \\ \end{tabular}$ 

#### 6.2.1.1.1.1 Normal execution

- CRRN1: this non-blocking method builds the HCI command ANY\_GET\_PARAMETER for the indicated information and sends it to the appropriate Card RF Gate of the CLF.
- CRRN2: the paramID indicates a constant parameter of the requested value.
- CRRN3: The CardEmulationListener.onCallback method shall be called by the Contactless Framework. The HCI message that resulted in the selection of this Applet according to the rules defined in "GlobalPlatform Amendment C" [10] shall be provided by the CardEmulationMessage.

## 6.2.1.1.1.2 Parameter errors

• CRRP1: throws HCIException with the reason code HCI\_CURRENTLY\_DISABLED if the HCI interface was disabled.

## 6.2.1.1.1.3 Context errors

• CRRC1: throws HCIException with the reason code HCI\_FRAGMENTED\_MESSAGE\_ONGOING if the Contactless Framework is still receiving a fragmented HCI Message.

• CRRC2: throws HCIException with the reason code HCI\_RESOURCES\_NOT\_AVAILABLE if the contactless framework does not have enough resources to process the command.

## 6.2.1.1.1.2 Test suite files

Applet Name	Test case ID
Api_2_CEm_Sgp_1.java	1-1
Api_2_CEm_Sgp_2.java	1-2
Api_2_CEm_Sgp_3.java	1-3
Api_2_CEm_Sgp_4.java	1-4
Api_2_CEm_Sgp_5.java	1-5
Api_2_CEm_Sgp_6.java	1-6
Api_2_CEm_Sgp_7.java	1-7
Api_2_CEm_Sgp_8.java	1-8
Api_2_CEm_Sgp_9.java	2-1
Api_2_CEm_Sgp_10.java	2-2
Api_2_CEm_Sgp_11.java	2-3
Api_2_CEm_Sgp_12.java	2-4
Api_2_CEm_Sgp_13.java	2-5
Api_2_CEm_Sgp_2.java	3-1
Api_2_CEm_Sgp_10.java	3-2

## 6.2.1.1.3 Initial condition

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.

## 6.2.1.1.1.4 Test procedure

	Test cas	se				
<b>HCI Command</b>	API Description	API Expectation	HCI Response	CRR		
Get parameter: Type A						
1 - EVT_SEND_DAT A (Sele	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_APPLICATION_D ATA□</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
2 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_ATQA□</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
3 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_CID_SUPPORT</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
4 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM ID TYPE A CARD CLT SUPPORT</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
5 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_DATARATE_MAX</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
6 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_FWI_SFGI</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
7 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand() ) paramID = PARAM_ID_TYPE_A_CARD_MODE</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		
8 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_SAK</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3		

		Test cas	se		
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
2		Get paramet			_
	1- EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM ID TYPE B CARD AFI </pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3
	2 - EVT_SEND_DAT A (Select applet)	prepareAndSendGetParameterCommand() ) paramID = PARAM_ID_TYPE_B_CARD_ATQB	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3
	3 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_B_CARD_DATARATE_MAX</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3
	4 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_B_CARD_HIGHER_LAYER_ RESPONSE</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3
	5 - EVT_SEND_DAT A (Select applet)	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_B_CARD_MODE</pre>	No exception shall be thrown	GET_PARAMETER with the predefined parameter value	N1, N2, N3
3		The Contactless Framework is rec			
	1 - Select applet on ISO interface  Send as fragmented HCI Message: - EVT_SEND_DAT A (data length = supported buffer size + 5 bytes, message not complete) With CB = 1 for the last sent frame EVT_SEND_DAT A sent without waiting for response	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_A_CARD_ATQA</pre>	Shall throw uicc.hci.framework.HCIE xception with error code HCI_FRAGMENTED_M ESSAGE_ONGOING	- SW - '90 00' on ISO interface - EVT_SEND_DATA (No data) - EVT_SEND_DATA (one byte with second least significant bit set)	C1
	2 - Select applet on ISO interface  Send as fragmented HCI Message: EVT_SEND_DAT A (data length = supported buffer size + 5 bytes, message not complete)  EVT_SEND_DAT A sent without waiting for response	<pre>prepareAndSendGetParameterCommand( ) paramID = PARAM_ID_TYPE_B_CARD_ATQB</pre>	Shall throw uicc.hci.framework.HCIE xception with error code HCI_FRAGMENTED_M ESSAGE_ONGOING	- SW - '90 00' on ISO interface - EVT_SEND_DATA (No data) - EVT_SEND_DATA (one byte with second least significant bit set)	C1

## 6.2.1.1.2 Method prepareAndSendSendDataEvent

Test Area Reference: Api\_2\_CEm\_ Ssd.

## 6.2.1.1.2.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

#### 6.2.1.1.2.1.1 Normal execution

- CRRN1: This non-blocking method builds the HCI event EVT\_SEND\_DATA sends it to the Contactless Card Emulation Gate of the CLF.
- CRRN2: the data to be sent should be formatted according to the HCI specification, the offset define the offset of data into the data buffer and the len define the length of data in the data buffer.
- CRRN3: Applet instances shall receive CardEmulationMessages after the registration of a CardEmulationListener interface to a CardEmulationService only if the EVENT\_ON\_SEND\_DATA is activated for the Applet instance.
- CRRN4: The CardEmulationListener.onCallback method shall be called by the Contactless Framework. The HCI message that resulted in the selection of this Applet according to the rules defined in "GlobalPlatform Amendment C" [10] shall be provided by the CardEmulationMessage.

#### 6.2.1.1.2.1.2 Parameter errors

- CRRP1: throws java.lang.NullPointerException if data is null.
- CRRP2: throws java.lang.ArrayIndexOutOfBoundsException if operation would cause access of data outside array bounds.

## 6.2.1.1.2.1.3 Context errors

- CRRC1: throws HCIException with the reason code HCI\_CURRENTLY\_DISABLED if the HCI interface
  was disabled.
- CRRC2: throws HCIException with the reason code HCI\_FRAGMENTED\_MESSAGE\_ONGOING if the Contactless Framework is still receiving a fragmented HCI Message.
- CRRC3: throws HCIException with the reason code HCI\_RESOURCES\_NOT\_AVAILABLE if the
  contactless framework does not have enough resources to process the command.

#### 6.2.1.1.2.2 Test suite files

Applet Name	Test case ID
Api_2_CEm_Ssd_1.java	1
Api_2_CEm_Ssd_1.java	2
Api_2_CEm_Ssd_1.java	3
Api_2_CEm_Ssd_4.java	4
Api_2_CEm_Ssd_2.java	5-1
Api_2_CEm_Ssd_3.java	5-2

## 6.2.1.1.2.3 Initial condition

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.

## 6.2.1.1.2.4 Test procedure

	Test case						
ID	HCI Commnad	API Description	API Expectation	HCI Response	CRR		
1		Send data			_		
	EVT_SEND_DATA (Select applet)	<pre>prepareAndSendSendDataEvent()   data = {0x01, 0x02, 0x03,   0x04, 0x05, 0x06, 0x07,   0x08, 0x09}   offset = 2 length = 5</pre>	No exception shall be thrown	EVT_SEND_DATA ({0x03, 0x04, 0x05, 0x06, 0x07})	N1, N2, N3, N4		
2		Send data	- Type B	<u> </u>			
	EVT_SEND_DATA (Select applet)	<pre>prepareAndSendSendDataEvent( )   data = {0x01, 0x02, 0x03,   0x04, 0x05, 0x06, 0x07,   0x08, 0x09}   offset = 2 length = 5</pre>	No exception shall be thrown	EVT_SEND_DATA ({0x03, 0x04, 0x05, 0x06, 0x07})	N1, N2, N3, N4		
3		Recption of fragme	nted HCI Message				
	- EVT_SEND_DATA to select applet Send as fragmented HCI Message: - EVT_SEND_DATA (data length = supported buffer size + 5 bytes, message not complete) - EVT_SEND_DATA (INS = '01') without waiting for response - Send EVT_SEND_DATA (INS = '01')	<pre>prepareAndSendSendDataEvent() data = {0x01, 0x02, 0x03, 0x04, 0x05, 0x06, 0x07, 0x08, 0x09} offset = 2 length = 5</pre>	Shall throw uicc.hci.framework.H CIException with error code HCI_FRAGMENTED _MESSAGE_ONGOI NG	- EVT_SEND_DATA (SW - '90 00') - EVT_SEND_DATA (No data) - EVT_SEND_DATA (SW- '90 02')	C2		
4	(1145 = 01)	Send no	h data				
	EVT_SEND_DATA (Select applet)	<pre>prepareAndSendSendDataEvent( ) data = null offset = 2 length = 5</pre>	Shall throw java.lang exception with error code NullPointerException	EVT_SEND_DATA ({0xFF, 0xFF, 0xFF, 0xFF, 0xFF })	P1		
5		Array Index Ou		1	<b>-</b>		
	1 - EVT_SEND_DATA (Select applet)	<pre>prepareAndSendSendDataEvent()  1 - data = {0x01, 0x02, 0x03, 0x04, 0x05, 0x06, 0x07, 0x08, 0x09} offset = 2 length = 15</pre>	Shall throw java.lang exception with error code ArrayIndexOutOfBou ndsException	EVT_SEND_DATA ({0xFF, 0xFF, 0xFF, 0xFF, 0xFF })	P2		
	2 - EVT_SEND_DATA (Select applet)	<pre>prepareAndSendSendDataEvent() data = {0x01, 0x02, 0x03, 0x04, 0x05, 0x06, 0x07, 0x08, 0x09} offset = 15 length = 5</pre>	Shall throw java.lang exception with error code ArrayIndexOutOfBou ndsException	EVT_SEND_DATA ({0xFF, 0xFF, 0xFF, 0xFF, 0xFF })	P2		

## 6.2.1.1.3 Method selectingMessage

Test Area Reference: Api\_2\_CEm\_ Scm

## 6.2.1.1.3.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

boolean selectingMessage()

## 6.2.1.1.3.1.1 Normal execution

- CRRN1: This method is used by the applet to distinguish the HCI Message command which selected this applet from all other HCI messages.
- CRRN2: returns true if the current HCI message caused the selection of the Applet according to the rules in GlobalPlatform Amendment C [10].

## 6.2.1.1.3.1.2 Parameter errors

• None.

#### 6.2.1.1.3.1.3 Context errors

• None.

## 6.2.1.1.3.2 Test suite files

Applet Name	Test case ID
Api_2_CEm_Scm_1.java	1
Api_2_CEm_Scm_1.java	2

## 6.2.1.1.3.3 Initial condition

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.

## 6.2.1.1.3.4 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1		Se	lect Applet	<u>-</u>		
	EVT_SEND_DATA (Select applet)	selectingMessage()	No exception shall be thrown.	EVT_SEND_DATA (SW - '90 00')	N1, N2	
			selectingMessage()= true			
2		Arbitr	ary Command	·		
	- EVT_SEND_DATA (Select applet) - EVT_SEND_DATA (INS = '01')	selectingMessage()	No exception shall be thrown.  selectingMessage() = false	- EVT_SEND_DATA(SW - '90 00') - EVT_SEND_DATA ('01 02 03 90 00')	N1, N2	

## 6.2.1.2 Interface CardEmulationService

## 6.2.1.2.1 Method getCardRFType

Test Area Reference: Api\_2\_CEs\_RFt.

## 6.2.1.2.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

byte getCardRFType()

#### 6.2.1.2.2.1.1 Normal execution

- CRRN1: returns the reader RF type on which the service is connected, shall be one of the TYPE\_\* constant values defined in this interface, or -1 if the RF type can not be evaluated.
- CRRN2: Applets communicating through the process() method shall also be able to use the API services defined in the present document which do not require a CardEmulationListener registration (e.g. requesting the power mode or connectivity service).

#### 6.2.1.2.2.1.2 Parameter errors

• None.

#### 6.2.1.2.2.1.3 Context errors

• None.

## 6.2.1.2.2 Test Suite Files

Applet Name	Test case ID
Api_2_CEs_RFt_1.java	1
Api_2_CEs_RFt_1.java	2
Api_2_CEs_RFt_1.java	3
Api_2_CEs_RFt_1.java	4

## 6.2.1.2.3 Initial conditions

- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

## 6.2.1.2.3.1 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1			RF type A			
	EVT_SEND_DATA	<pre>getCardRFType()</pre>	No exception shall be thrown	EVT_SEND_DATA	N1	
	(INS = '01')		getCardRFType() = TYPE_A_CARD_RF	$(SW = '90 \ 01')$	N2	
2			RF type B			
	EVT_SEND_DATA	<pre>getCardRFType()</pre>	No exception shall be thrown	EVT_SEND_DATA	N1	
	(INS = '01')		getCardRFType() = TYPE_B_CARD_RF	$(SW = '90 \ 02')$	N2	
3			RF type F			
	EVT_SEND_DATA	<pre>getCardRFType()</pre>	No exception shall be thrown	EVT_SEND_DATA	N1	
	(INS = '01')		getCardRFType() = TYPE_F_CARD_RF	$(SW = '90 \ 04')$	N2	
4	RF type B'					
	EVT_SEND_DATA	<pre>getCardRFType()</pre>	No exception shall be thrown	EVT_SEND_DATA	N1	
	(INS = '01')		getCardRFType() = TYPE_B_PRIM_CARD_RF	$(SW = '90 \ 03')$	N2	

## 6.2.1.3 Interface CardEmulationListener

#### 6.2.1.3.1 Method on Callback

Test Area Reference: Api\_2\_CEl\_Ocb.

## 6.2.1.3.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

void onCallback(byte event, HCIMessage message)

#### 6.2.1.3.1.1.1 Normal execution

- CRRN1: The Contactless Framework shall invoke the method CardEmulationListener.onCallback only with events which are defined in this particular listener or CardEmulationListener and only with CardEmulationMessage objects.
- CRRN2: The Applet instance shall activate the events with CardEmulationService.activateEvent before it will
  receive any event notification.
- CRRN3: If the EVENT\_ON\_SEND\_DATA is deactivated for the Applet instance the
  javacard.framework.APDU class and the process() method shall be used if the current application protocol is
  APDU based. Otherwise, if the EVENT\_ON\_SEND\_DATA is deactivated and the current application
  protocol is not APDU based the process() method will not be invoked, i.e. the Applet will not receive any
  messages from the external reader.
- CRRN4: It shall not be possible to switch between the usage of the CardEmulationListener interface and the invocation through the process() method within a contactless application session, i.e. not before the Applet has been deselected and selected again.

#### 6.2.1.3.1.1.2 Parameter errors

• None.

#### 6.2.1.3.1.1.3 Context errors

• None.

#### 6.2.1.3.1.2 Test Suite Files

Applet Name	Test case ID
Api_2_CEI_Ocb_1.java	1
Api_2_CEI_Ocb_2.java	2
Api_2_CEI_Ocb_3.java	3
Api_2_CEI_Ocb_1.java	4
Api_2_CEI_Ocb_2.java	5
Api_2_CEI_Ocb_4.java	6
Api_2_CEI_Ocb_5.java	7-1
Api_2_CEI_Ocb_6.java	7-2
Api_2_CEI_Ocb_7.java	7-3
Api_2_CEI_Ocb_8.java	7-4

## 6.2.1.3.1.3 Initial conditions

- EVT FIELD ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

6.2.1.3.1.4 Test procedure

	Test case				
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		EVT_SEND_I	DATA - Type A		
	- EVT_SEND_DAT A(INS = '14') -	HCIListener = CardEmulationListener HCIService = CardEmulationService	<ul><li>No exception shall be thrown</li><li>No exception shall be</li></ul>	- EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA	N1, N2, N3, N4,
	EVT_SEND_DAT A(INS = '24')-	<pre>activateEvent() event = CardEmulationListener.EVENT_ON_ SEND DATA</pre>	thrown onCallback() method	(SW- '90 00')	,
	- deselect the applet - select the applet	22.2_2	shall notice the event EVENT_ON_SEND_D ATA	data in the response to the select applet command	
	T CONSCIENCE SEPTION	EVENT_HCI_RECEPTIO			I .
2	EVT_SEND_DAT A(INS = '11') - EVT_SEND_DAT A(INS = '14') - deselect/select the applet	<pre>HCIListener = CardEmulationListener HCIService = CardEmulationService activateEvent() event = HCIListener.EVENT_HCI_RECEPTION S_FAILED</pre>	No exception shall be thrown onCallback() method shall notice the event	-EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00') - Response to RF error message not verified	N1, N2, N3, N4
	EVT_SEND_DAT A(INS = '11', RF error indicator is set to '01')  - deselect/select the applet			- EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00')	
	EVT_SEND_DAT A(INS = '21')				
3		EVENT_GET_PARAMET	TER_RESPONSE - Type	Α	•
	- EVT_SEND_DAT A (INS = '01') - ANY_OK as response to GET_PARAMET ER - deselect/select the applet	Listener = CardEmulationListener activateEvent() event = EVENT_GET_PARAMETER_RESPONSE  prepareAndSendGetParameterComma nd() paramID = PARAM_ID_TYPE_A_CARD_ATQA	No exception shall be thrown onCallback() shall receive ANY_OK as EVENT_GET_PARAM ETER_RESPONSE	GET_PARAMETER with the PARAM_ID_TYPE_A_C ARD_ATQA - No exception after ANY_OK reception - EVT_SEND_DATA (SW- '90 00')	N1, N2, N3, N4,
	- EVT_SEND_DAT A(INS='22')			- EVT_SEND_DATA (SW- '90 00')	

		Test c			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
4			DATA - Type B	LEVE OF DATA	Ta
	EVT_SEND_DAT A(INS = '14')	<pre>HCIListener = CardEmulationListener HCIService = CardEmulationService</pre>	- No exception shall be thrown	- EVT_SEND_DATA (SW- '90 00')	N1, N2, N3,
	EVT_SEND_DAT A(INS = '24')-	<pre>activateEvent() event = CardEmulationListener.EVENT_ON_</pre>	- No exception shall be thrown	- EVT_SEND_DATA (SW- '90 00')	N4,
	- deselect the applet	SEND_DATA	onCallback() method shall notice the event EVENT_ON_SEND_D	- No response or no data in the response to the select applet	
5	- select the applet	EVENT HOLDECEDT	ATA TONS_FAILED - Type B	command	
5	_	HCIListener =	No exception shall be	-EVT_SEND_DATA	N1,
	EVT_SEND_DAT A(INS = '11') - EVT_SEND_DAT	CardEmulationListener HCIService = CardEmulationService	thrown onCallback() method shall notice the event	(SW- '90 00') - EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA	N2, N3, N4
	A(INS = '14') - deselect/select	<pre>activateEvent() event = HCIListener.EVENT_HCI_RECEPTION S FAILED</pre>	Shair House the event	(SW- '90 00') - Response to RF error	
	the applet	_		message not verified - EVT_SEND_DATA	
	EVT_SEND_DAT A(INS = '11', RF error indicator is set to '01')			(SW- '90 00') - EVT_SEND_DATA	
	- deselect/select the applet			(SW- '90 00')	
	- EVT_SEND_DAT A(INS = '21')				
6		EVENT_GET_PARAMET			Th. La
	EVT_SEND_DAT A (INS = '01') - ANY_OK as response to GET_PARAMET ER - deselect/select the applet	Listener = CardEmulationListener activateEvent() event = EVENT_GET_PARAMETER_RESPONSE prepareAndSendGetParameterComma nd() paramID = PARAM_ID_TYPE_B_CARD_ATQB	No exception shall be thrown.  onCallback() shall receive ANY_OK as EVENT_GET_PARAM ETER_RESPONSE	- GET_PARAMETER with the PARAM_ID_TYPE_B_C ARD_ATQB - No exception after ANY_OK reception - EVT_SEND_DATA (SW- '90 00')	N1, N2, N3, N4
	- EVT_SEND_DAT A(INS = '22')			- EVT_SEND_DATA (SW- '90 00')	
7		•	ate events		
	1 - EVT_SEND_DAT A(INS='11')	HCIService = CardEmulationService Event has been successfully activated	No exception shall be thrown. onCallback() method	EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA	N2
	- deselect/select the applet	<pre>deactivateEvent() event = HCIListener.EVENT HCI RECEPTION</pre>	shall not notice the event	(SW- '90 00')	
	EVT_SEND_DAT A(INS='20', RF error indicator is set to '01')	S_FAILED		message not verified - EVT_SEND_DATA (SW- '90 00')	
	- deselect/select the applet			- EVT_SEND_DATA (SW- '90 00')	
	EVT_SEND_DAT A(INS='20')				

Test case					
)	HCI Command	API Description	API Expectation	HCI Response	CRR
	2 - EVT_SEND_DAT A(INS='12') - ANY_OK as response to GET_PARAMET ER	HCIService = CardEmulationService Event has been successfully activated  deactivateEvent() event = CardEmulationListener.EVENT_GET _PARAMETER_RESPONSE	No exception shall be thrown onCallback() method shall not notice the event	- ignore the first response - EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00')	N2
	- deselect/select the applet - EVT_SEND_DAT A(INS='20')	<pre>prepareAndSendGetParameterComma nd() paramID = PARAM_ID_TYPE_A_CARD_ATQA□</pre>			
	3 - EVT_SEND_DAT A(INS='12') - ANY_OK as response to GET_PARAMET ER - deselect/select the applet - EVT_SEND_DAT A(INS='20')	HCIService = CardEmulationService Event has been successfully activated  deactivateEvent() event = CardEmulationListener.EVENT_GET _PARAMETER_RESPONSE  prepareAndSendGetParameterComma nd() paramID = PARAM_ID_TYPE_B_CARD_ATQB	No exception shall be thrown on Callback() method shall not notice the event	- ignore the first response - EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00')	N2
	- EVT_SEND_DAT A(INS='14') - deselect /select the applet - EVT_SEND_DAT A(INS='20')	HCIService = CardEmulationService Event has been successfully activated  deactivateEvent() event = CardEmulationListener.EVENT_ON_ SEND_DATA	No exception shall be thrown onCallback() method shall not notice the event	- EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 00') - EVT_SEND_DATA (SW- '90 01')	N2

# 6.2.2 Package Connectivity Service

# 6.2.2.1 Interface ConnectivityService

# 6.2.2.1.1 Method prepareAndSendConnectivityEvent

Test Area Reference: Api\_2\_CNs\_Sce.

## 6.2.2.1.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

void prepareAndSendConnectivityEvent()

throws HCIException

#### 6.2.2.1.1.1.1 Normal execution

- CRRN1: This non-blocking method builds the HCI event EVT\_CONNECTIVITY which notifies the terminal host that it shall send a "HCI connectivity event" as defined in TS 102 223 [7].
- CRRN2: If the Applet wants to use proactive functionality it shall use the Connectivity Service defined above to send an HCI event EVT\_CONNECTIVITY to the terminal, register for EVENT\_EVENT\_DOWNLOAD\_HCI\_CONNECTIVITY and return. All the proactive functionality of the UICC API defined in TS 102 241 [6] is then available to the Applet when that Applet instance is triggered with the processToolkit() method defined in TS 102 241 [6].
- CRRN3: the contactless runtime environment shall bind the services defined in uicc.hci.services.connectivity to the corresponding resources (e.g. gates and pipes) specified by the HCI protocol [3] for the connectivity service.
- CRRN4: The Contactless Framework shall only send the HCI event EVT\_CONNECTIVITY or EVT\_TRANSACTION specified by the HCI protocol [3] to an Applet instance, when it is the selected Applet, which is in card emulation mode or when it is in the state ACTIVATED (according to "GlobalPlatform Amendment C" [10]) for the reader mode.
- CRRN5: The ProactiveHandler defined in TS 102 241 [6] shall not be available when the contactless Applet is invoked with the callback methods defined in the present document, or when the Applet is invoked with the process() method of the Applet class defined in Application Programming Interface, Java Card<sup>TM</sup> Platform [6] (in card emulation mode).

#### 6.2.2.1.1.1.2 Parameter errors

None.

#### 6.2.2.1.1.1.3 Context errors

- CRRC1: throw HCIException with error code reason HCI\_CURRENTLY\_DISABLED if the HCI interface was disabled.
- CRRC2: throw HCIException with error code reason HCI\_RESOURCES\_NOT\_AVAILABLE if the contactless framework does not have enough resources to process the command.
- CRRC3: throw HCIException with error code reason HCI\_CONDITIONS\_NOT\_SATISFIED if the conditions to call this method are not satisfied.

#### 6.2.2.1.1.2 Test suite files

Applet Name	Test case ID
Api_2_CNs_Sce_1.java	1
Api_2_CNs_Sce_1.java	2
Api_2_CNs_Sce_2.java	3
Api_2_CNs_Sce_3.java	4
Api_2_CNs_Sce_4.java	5
Api_2_CNs_Sce_5.java	6

## 6.2.2.1.1.3 Initial condition

- Prior to this test the Terminal shall have been powered on and performed the PROFILE DOWNLOAD procedure.
- In terminal profile set the 25th byte, 'b6' indicates that class m is supported.
- In terminal profile 5th byte, b1 indicates proactive UICC: SET UP EVENT LIST.
- Pipe has been created and opened to connectivity gate in the terminal host.
- EVT\_FIELD\_ON has been sent on HCI interface.

- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

# 6.2.2.1.1.4 Test procedure

		Test case			
ID	HCI commands	API Description	API Expectation	HCI Response	CRR
1		Send HCI Connectivity	*		_
	- Send EVT_SEND_DATA (Select applet) - Send EVT_SEND_DATA (INS = '01')	<pre>Listener = CardEmulationListener process(): prepareAndSendConnectivityEvent()</pre>	No exception shall be thrown	SW - '90 00' HCI event EVT_CONNECT IVITY sent	N1 N3
2		HCI interface disab	oled		·
	1 - Precondition: Contactless functionality state is disabled in the UICC as defined in TS 102 223 [7]. Send on ISO interface: - Select applet - Send APDU (INS =	Listener = CardEmulationListener process(): prepareAndSendConnectivityEvent()	throw HCIException with error code reason HCI_CURRENTLY_D ISABLED	SW - '90 00' No EVT_ CONNECTIVITY shall be sent	C1 N3
	'02')  2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send APDU to select the applet Send APDU (INS = '02') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C	setCommunicationInterface() API method of Global Platform Amendment C [10] is used to disable HCI interface in the CRS  Listener = CardEmulationListener process(): prepareAndSendConnectivityEvent()  setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface	throw HCIException with error code reason HCI_CURRENTLY_D ISABLED	SW - '90 00' No EVT_ CONNECTIVITY shall be sent	C1 N3
3	7 inchament o	Wrong Precondition Conne	ctivity Event		1
	Send on ISO: - Select applet - Send APDU with (INS = '01')	Service = ConnectivityService Listener = ConnectivityListener  process() ConnectivityService. prepareAndSendConnectivityEvent()	Shall throw exception with error code reason HCI_CONDITIONS_NOT_SATISFIED	No EVT_ CONNECTIVITY shall be sent	N4, C3
4	0 1	No Proactive Hand		014/ 100 001	INIC
	- Send EVT_SEND_DATA (Select applet) - Send EVT_SEND_DATA (INS = '01')	<pre>Service = CardEmulationService Listener = CardEmulationListener process() ProactiveHandlerSystem.getTheHandle r()</pre>	ProactiveHandler shall not be available	SW - '90 00'	N5

		Test case			
ID	HCI commands	API Description	API Expectation	HCI Response	CRR
5		No Proactive Handler or	nCallback		
	- Send EVT_SEND_DATA (Select applet) - Send EVT_SEND_DATA (INS = '01')	<pre>Service = CardEmulationService Listener = CardEmulationListener activateEvent(EVENT_ON_SEND_DATA) during the installation onCallback() ProactiveHandlerSystem.getTheHandle r()</pre>	ProactiveHandler shall not be available	SW - '90 00'	N5
6		Use proactive function	nality	<u> </u>	1
	- Send EVT_SEND_DATA (Select applet) - Send EVT_SEND_DATA with INS = '01' - Send ENVELOPE (HCI Connectivity) on ISO interface after receiving HCI Connectivity Event	Listener = CardEmulationListener process(): prepareAndSendConnectivityEvent() register for EVENT_EVENT_DOWNLOAD_HCI_CONNECTIVI TY  processToolkit(): use arbitrary method of the UICC API (TS 102 241 [6])	No exception shall be thrown	- SW - '90 00' - HCI event EVT_CONNECT IVITY sent - response to ENVELOPE	N1 N2 N3

# 6.2.2.1.2 Method prepareAndSendTransactionEvent(byte[] aid, short aidOffset, short aidLen, byte[] parameters, short parametersOffset, short parametersLen)

Test Area Reference: Api\_2\_CNs\_Ste.

#### 6.2.2.1.2.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

#### 6.2.2.1.2.1.1 Normal execution

- CRRN1: this non-blocking method builds the HCI event EVT\_TRANSACTION which notifies the terminal host that it shall launch an application on the terminal which is associated to an Applet in the UICC host identified.
- CRRN2: the contactless runtime environment shall bind the services defined in uicc.hci.services.connectivity
  to the corresponding resources (e.g. gates and pipes) specified by the HCI protocol [3] for the connectivity
  service.
- CRRN3: The Contactless Framework shall only send the HCI event EVT\_CONNECTIVITY or EVT\_TRANSACTION specified by the HCI protocol [3] to an Applet instance, when it is the selected Applet, which is in card emulation mode or when it is in the state ACTIVATED (according to "GlobalPlatform Amendment C" [10]) for the reader mode.

#### 6.2.2.1.2.1.2 Parameter errors

- CRRP1: throw HCIException with error code reason HCI\_INVALID\_LENGTH if the parameter length or the AID is not compliant to TS 102 622 [3].
- CRRP2: throw java.lang.ArrayIndexOutOfBoundsException if operation would cause access of data outside array bounds.

• CRRP3: throw java.lang.NullPointerException - if parameters is null.

## 6.2.2.1.2.1.3 Context errors

- CRRC1: throw HCIException with error code reason HCI\_CURRENTLY\_DISABLED if the HCI interface was disabled.
- CRRC2: throw HCIException with error code reason HCI\_RESOURCES\_NOT\_AVAILABLE if the contactless framework does not have enough resources to process the command.
- CRRC3: throw HCIException with error code reason HCI\_CONDITIONS\_NOT\_SATISFIED if the conditions to call this method are not satisfied.

#### 6.2.2.1.2.2 Test suite files

Applet Name	Test case ID
Api_2_CNs_Ste_1.java	1
Api_2_CNs_Ste_1.java	2
Api_2_CNs_Ste_4.java	3
Api_2_CNs_Ste_2.java	4
Api_2_CNs_Ste_3.java	5

#### 6.2.2.1.2.3 Initial condition

- Prior to this test the Terminal shall have been powered on and performed the PROFILE DOWNLOAD procedure.
- In terminal profile set the 25th byte, 'b6' indicates that class m is supported.
- In terminal profile 5th byte, b1 indicates proactive UICC: SET UP EVENT LIST.
- Pipe has been created and opened to connectivity gate in the terminal host.
- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

## 6.2.2.1.2.4 Test procedure

	Test case					
ID	HCI commands	API Description	API Expectation	HCI Response	CRR	
1		Send HCI Transacti	on Event			
	Send	extends CardEmulationListener	No exception shall be	EVT_SEND_DA	N1,	
	A with INS = '01'	<pre>process(): prepareAndSendTransactionEvent() aid = 'A0000000090101' aidOffset = 0 aidLen = 16 parameters = '0101' parametersOffset = 0 parametersLen = 10</pre>	thrown	TA (SW - '90 00')  HCI event  EVT_TRANSAC  TION sent	N2,	

<u> </u>	1101	Test case	ADI Farma at attack	LICI D	000
<u>ID</u>	HCI commands	API Description	API Expectation	HCI Response	CRR
2	4 Dunnandition	HCI interface di		014 100 001	104
	1 - Precondition:	extends CardEmulationListener process():	throw HCIException with	SW - '90 00'	C1
	Contactless	prepareAndSendTransactionEvent()	error code reason	No EVT_	
	functionality state	proparomiasonariamsaccionis vene ()	HCI_CURRENTLY_DISA	CONNECTIVITY	
	is disabled in the		BLED	shall be sent	
	UICC as defined				
	in TS 102 223 [7].				
	Send on ISO				
	interface:				
	<ul> <li>Send APDU to</li> </ul>				
	select the applet				
	- Send APDU				
	(INS = '02')				
	2 - Precondition:	setCommunicationInterface() API	throw HCIException with	SW - '90 00'	C1
	Contactless	method of Global Platform Amendment	error code reason	No EVT	
	functionality state	C [10] is used to disable HCI	HCI_CURRENTLY_DISA	CONNECTIVITY	
	is disabled in the	interface	BLED	shall be sent	
	UICC as defined			oriali bo con	
	in Global	extends CardEmulationListener			
	Platform	<pre>process(): prepareAndSendTransactionEvent()</pre>			
	Amendment C	proparemiabenariansaceronevene()			
	Send on ISO				
	interface send	setCommunicationInterface() API			
	the following	method of Global Platform Amendment			
	_	C [10] is used to enable again HCI			
	commands:	interface			
	- Send APDU to				
	select the applet.				
	- Send APDU				
	(INS = '02')				
	- Postcondition:				
	Contactless				
	functionality state				
	is enabled again				
	in the UICC as				
	defined in Global				
	Platform				
	Amendment C				
3		Wrong condit	ions		
	Send on ISO:	Service = ConnectivityService	throw HCIException with	SW - '90 00'	C3
	- Select applet	Listener = ConnectivityListener	error code reason	No EVT	
	- Send	process():	HCI_CONDITIONS_NOT	TRANSACTION	
	APDU with (INS	prepareAndSendTransactionEvent()	SATISFIED	shall be sent	
	= '03')				
4	,	Wrong parame	eters		•
	1 - Send	extends CardEmulationListener	throw	EVT_SEND_DA	P2,
	EVT_SEND_DAT	process():	java.lang.ArrayIndexOut		
	Awith INS = '01'		OfBoundsException	No EVT_	0
	AWILLING = 01	<pre>prepareAndSendTransactionEvent()</pre>	OlbouriusException	TRANSACTION	
		aid = 'A0000000090101'		shall be sent	
		aidOffset = 20		shall be sent	
		aidLen = 16			
		parameters = '0101'			
		parametersOffset = 0			
		parametersLen = 10			
	2 - Send	extends CardEmulationListener	throw	EVT_SEND_DA	P2,
	EVT_SEND_DAT	process():	java.lang.ArrayIndexOut	TA (SW - '90 00')	P3
	Awith INS = '02'	3 10 15	OfBoundsException	No EVT_	
		prepareAndSendTransactionEvent()		TRANSACTION	
		aid = 'A0000000090101'		shall be sent	
		aidOffset = 0		Silan Do Solit	
		aidLen = 20			
		parameters = '0101'			
		parametersOffset = 0			
	I	parametersLen = 10	1	1	I

		Test case			
ID	HCI commands	API Description	API Expectation	HCI Response	CRR
	3 - Send EVT_SEND_DAT Awith INS = '03'	<pre>extends CardEmulationListener process():  prepareAndSendTransactionEvent() aid = 'A0000000090101' aidOffset = 0 aidLen = 16 parameters = '0101' parametersOffset = 20</pre>	throw java.lang.ArrayIndexOut OfBoundsException	EVT_SEND_DA TA (SW - '90 00') No EVT_ TRANSACTION shall be sent	P2, P3
	4 - Send EVT_SEND_DAT Awith INS = '04'	<pre>parametersLen = 10 extends CardEmulationListener process():  prepareAndSendTransactionEvent() aid = 'A0000000090101' aidOffset = 0 aidLen = 16 parameters = '0101' parametersOffset = 0 parametersLen = 20</pre>	throw java.lang.ArrayIndexOut OfBoundsException	EVT_SEND_DA TA (SW - '90 00') No EVT_ TRANSACTION shall be sent	P2, P3
	5 - Send EVT_SEND_DAT Awith INS = '05'	extends CardEmulationListener process():  prepareAndSendTransactionEvent() aid = null aidOffset = 0 aidLen = 16 parameters = '0101' parametersOffset = 0 parametersUffset = 0 parametersLen = 10	throw java.lang.NullPointerExc eption	EVT_SEND_DA TA (SW - '90 00') No EVT_ TRANSACTION shall be sent	P2, P3
	6 - Send EVT_SEND_DAT AINS = '06'	extends CardEmulationListener process():  prepareAndSendTransactionEvent() aid = 'A0000000090101' aidOffset = 0 aidLen = 16 parameters = null parametersOffset = 0 parametersLen = 10	throw java.lang.NullPointerExc eption	EVT_SEND_DA TA (SW - '90 00') No EVT_ TRANSACTION shall be sent	P2, P3
5		Wrong Precondition T	ransaction Event	1	1
	- Send EVT_SEND_DAT A (INS = '01')	Service = ConnectivityService Listener = ConnectivityListener process() ConnectivityService. prepareAndSendTransactionEvent()	Shall throw exception	EVT_SEND_DA TA (SW - '90 00') No EVT_ TRANSACTION shall be sent	N3

# 6.2.2.1.3 Method prepareAndSendTransactionEvent (byte[] parameters, short parametersOffset, short parametersLen)

Test Area Reference: Api\_2\_CNs\_Stt.

## 6.2.2.1.3.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

## 6.2.2.1.3.1.1 Normal execution

- CRRN1: this non-blocking method builds the HCI event EVT\_TRANSACTION which notifies the terminal
  host that it shall launch an application on the terminal which is associated to an Applet in the UICC host
  identified.
- CRRN2: the contactless runtime environment shall bind the services defined in uicc.hci.services.connectivity to the corresponding resources (e.g. gates and pipes) specified by the HCI protocol [3] for the connectivity service.

#### 6.2.2.1.3.1.2 Parameter errors

- CRRP1: throw HCIException with error code reason HCI\_INVALID\_LENGTH if the parameter length or the AID is not compliant to TS 102 622 [3].
- CRRP2: throw java.lang.ArrayIndexOutOfBoundsException if operation would cause access of data outside array bounds.
- CRRP3: throw java.lang.NullPointerException if parameters is null.

#### 6.2.2.1.3.1.3 Context errors

- CRRC1: throw HCIException with error code reason HCI\_CURRENTLY\_DISABLED if the HCI interface
  was disabled.
- CRRC2: throw HCIException with error code reason HCI\_RESOURCES\_NOT\_AVAILABLE if the
  contactless framework does not have enough resources to process the command.
- CRRC3: throw HCIException with error code reason HCI\_CONDITIONS\_NOT\_SATISFIED if the conditions to call this method are not satisfied.

#### 6.2.2.1.3.2 Test suite files

Applet Name	Test case ID
Api_2_CNs_Stt_1.java	1
Api_2_CNs_Stt_1.java	2
Api_2_CNs_Stt_3.java	3
Api_2_CNs_Stt_2.java	4

#### 6.2.2.1.3.3 Initial condition

- Prior to this test the Terminal shall have been powered on and performed the PROFILE DOWNLOAD procedure.
- In terminal profile set the 25th byte, 'b6' indicates that class m is supported.
- In terminal profile 5th byte, b1 indicates proactive UICC: SET UP EVENT LIST.
- Pipe has been created and opened to connectivity gate in the terminal host.
- EVT\_FIELD\_ON has been sent on HCI interface.
- EVT\_CARD\_ACTIVATED has been sent on HCI interface.
- According applet has been successfully installed and selected using HCI interface.

6.2.2.1.3.4 Test procedure

HCI commands	API Description	ADI Europetation	LIOLD				
		API Expectation	HCI Response	CRR			
	Send HCI Transaction Event						
Send EVT_SEND_DAT A with INS = '01'	<pre>extends CardEmulationListener process(): prepareAndSendTransactionEvent() parameters = '0101' parametersOffset = 0 parametersLen = 10</pre>	No exception shall be thrown	SW - '90 00'  HCI event  EVT_TRANSAC  TION sent	N1, N2			
		sabled		ı			
1 - Precondition: Contactless functionality state is disabled in the UICC as defined in TS 102 223 [7]. Send on ISO interface: - Send APDU to select applet - Send APDU (INS = '02') 2 - Precondition: Contactless	extends CardEmulationListener process(): prepareAndSendTransactionEvent()  setCommunicationInterface() API method of Global Platform Amendment C [10] is used to disable HCI	throw HCIException with error code reason HCI_CURRENTLY_DISA BLED  throw HCIException with error code reason	SW - '90 00' No EVT_ CONNECTIVITY shall be sent  SW - '90 00' No EVT_	C1			
functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send APDU to select the applet Send APDU (INS = '02') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C	<pre>interface extends CardEmulationListener process(): prepareAndSendTransactionEvent() setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface</pre>	HCI_CURRENTLY_DISA BLED	CONNECTIVITY shall be sent				
Send on ISO interface: - Select applet - APDU data with INS = '03'	<pre>Service = ConnectivityService Listener = ConnectivityListener process(): prepareAndSendTransactionEvent()</pre>	throw HCIException with error code reason HCI_CONDITIONS_NOT _SATISFIED	SW - '90 00' No EVT_ TRANSACTION shall be sent	C3			
Wrong parameters							
1 - Send EVT_SEND_DAT A with INS = '01'	<pre>extends CardEmulationListener process(): prepareAndSendTransactionEvent() parameters = '0101' parametersOffset = 20 parametersLen = 10</pre>	throw java.lang.ArrayIndexOut OfBoundsException	SW - '90 00' No EVT_ TRANSACTION shall be sent	P2, P3			
	EVT_SEND_DAT A with INS = '01'  1 - Precondition: Contactless functionality state is disabled in the UICC as defined in TS 102 223 [7]. Send on ISO interface: - Send APDU to select applet - Send APDU (INS = '02') 2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send APDU to select the applet Send APDU (INS = '02') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C  Send on ISO interface: - Select applet - APDU data with INS = '03'  1 - Send EVT_SEND_DAT	EVT_SEND_DAT A with INS = '01' Parameters = '0101'	EVT_SEND_DAT A with INS = '01'  A with INS = '01'  Drocess():     parameters = '0101'     parameters = '0101'     parameters = '0101'     parameters = '0101'     parameters = '001'     parameters = '0101'     parameters	EVT_SEND_DAT A with INS = '01' PrepareAndSendTransactionEvent() parameters = '0101' para			

Test case								
ID	HCI commands	API Description	API Expectation	HCI Response	CRR			
	2 - Send EVT_SEND_DAT A with INS = '02'	<pre>extends CardEmulationListener process():  prepareAndSendTransactionEvent() parameters = '0101' parametersOffset = 0 parametersLen = 20</pre>	throw java.lang.ArrayIndexOut OfBoundsException	SW - '90 00' No EVT_ TRANSACTION shall be sent	P2, P3			
	3 - Send EVT_SEND_DAT A with INS = '03'	<pre>extends CardEmulationListener process():  prepareAndSendTransactionEvent() parameters = null parametersOffset = 0 parametersLen = 10</pre>	throw java.lang.NullPointerExc eption	SW - '90 00' No EVT_ TRANSACTION shall be sent	P2, P3			

# 6.2.3 Package Reader Service

## 6.2.3.1 Interface ReaderMessage

#### 6.2.3.1.1 Method restartReaderModeProcedure

Test Area Reference: Api\_2\_RMm\_Rrp.

## 6.2.3.1.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

## 6.2.3.1.1.1.1 Normal execution

- CRRN1: this method sends first the HCI event EVT\_END\_OPERATION and then the HCI event EVT\_READER\_REQUESTED.
- CRRN2: this method is intended to recover from the following error states:
  - reception of EVT\_TARGET\_DISCOVERED with a MULTIPLE\_TARGET\_STATUS.
  - reception of RESP\_WR\_RF\_ERROR.
  - reception of RESP\_ANY\_E\_TIMEOUT.
- CRRN3: an Applet shall only be able to activate ReaderListener.EVENT\_TARGET\_DISCOVERED or to use the restartReadermodeProcedure method if it is in lifecycle state ACTIVATED.

#### 6.2.3.1.1.2 Parameter errors

None.

#### 6.2.3.1.1.3 Context errors

- CRRC1: throw HCIException with error code reason HCI\_CURRENTLY\_DISABLED if the HCI interface is disabled.
- CRRC2: throw HCIException with error code reason HCI\_CONDITIONS\_NOT\_SATISFIED if the Applet is not ACTIVATED.

## 6.2.3.1.1.2 Test suite files

Applet Name	Test case ID
Api_2_RMm_Rrp_1.java	1
Api_2_RMm_Rrp_1.java	2
Api_2_RMm_Rrp_1.java	3
Api_2_RMm_Rrp_2.java	4
Api_2_RMm_Rrp_2.java	5

### 6.2.3.1.1.3 Initial condition

- According applet has been successfully installed and selected using ISO Interface and the applet is set into ACTIVATED state.
- The event ReaderListener.EVENT\_TARGET\_DISCOVERED has been activated in the applet.

## 6.2.3.1.1.4 Test procedure

		Test case			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		MULTIPLE_TARGET_STATUS is re	eceived - Type A		
	Send	restartReaderModeProcedure()	No exception shall	-	N1,
	EVT_TARGET_DI	orrort EVE END ODERATION	be thrown	EVT_END_OPER	N2,
	SCOVERED(Statu	event = EVT_END_OPERATION event = EVT READER REQUESTED		ATION	N3
	s = '03')	evene = hvi_khabbk_khagobbibb		-	
				EVT_READER_R	
			<u> </u>	EQUESTED	
2		MULTIPLE_TARGET_STATUS is re			1
	Send	restartReaderModeProcedure()	No exception shall	-	N1,
	EVT_TARGET_DI	event = EVT_END_OPERATION	be thrown	EVT_END_OPER	N2,
	SCOVERED(Statu	event = EVT READER REQUESTED		ATION	N3
	s = '03')			-	
				EVT_READER_R	
_		DEOD WE DE EDDOD	<u> </u>	EQUESTED	
3		RESP_WR_RF_ERROR is I			In a
	- Send	- prepareAndSendWriteXchgDataCommand() timeout = -1	No exception shall	-	N1,
	EVT_TARGET_DI SCOVERED	data = '0101'	be thrown	WR_XCHG_DATA	N2,
		offset = 0		- EVT END ODED	N3
	(status = '00') -WR_RF_ERROR	len = 10		EVT_END_OPER ATION	
	-WK_KF_EKKOK			ATION	
		- restartReaderModeProcedure()		- EVT_READER_R	
		event = EVT_END_OPERATION event = EVT READER REQUESTED		EQUESTED	
4		RESP_ANY_E_TIMEOUT is	received	LQULUILD	
7	- Send	- prepareAndSendWriteXchgDataCommand()	No exception shall	_	N1,
	EVT_TARGET_DI	timeout = -1	be thrown	WR_XCHG_DATA	N2,
	SCOVERED	data = '0101'	DO UNOWN	WIN_XONO_D/N/	N3
	(status = '00')	offset = 0		_	'
	-	len = 10		EVT_END_OPER	
	ANY_E_TIMEOUT			ATION	
		- restartReaderModeProcedure()		-	
		event = EVT END OPERATION		EVT_READER_R	
		event = EVT_READER_REQUESTED		EQUESTED	

	Test case			
ID HCI Command	API Description	API Expectation	HCI Response	CRR
5	HCI interface is disab	led		
1 - Precondition: Contactless functionality state is disabled in the UICC as defined in TS 102 223 [7] - Send APDU to select the applet Send EVT_TARGET_DI SCOVERED (status = '03') - Send APDU on ISO interface ('01')	<pre>restartReaderModeProcedure() event = EVT_END_OPERATION event = EVT_READER_REQUESTED</pre>	Shall throw uicc.hci.framework. HCIException with error code HCI_CURRENTLY_ DISABLED	- SW - '90 03' No EVT_READER_R EQUESTED shall be sent	C1
2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send EVT_TARGET_DI SCOVERED (status = '03') - Send APDU on ISO interface ('01') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C	<pre>setCommunicationInterface() API method of Global Platform Amendment C [10] is used to disable HCI interface - restartReaderModeProcedure()  event = EVT_END_OPERATION event = EVT_READER_REQUESTED  setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface</pre>	Shall throw uicc.hci.framework. HCIException with error code HCI_CURRENTLY_ DISABLED	- SW - '90 03' No EVT_READER_R EQUESTED shall be sent	C1

## 6.2.3.1.2 Method prepareAndSendWriteXchgDataCommand

Test Area Reference: Api\_2\_RMm\_Srx

## 6.2.3.1.2.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

#### 6.2.3.1.2.1.1 Normal execution

- CRRN1: this non-blocking method builds the HCI command WR\_XCHG\_DATA with the data passed in the parameter data and sends it to the Contactless Reader Gate of the CLF.
- CRRN2: The response data from the CLF will be transferred to the UICC with the event ReaderListener.EVENT WRITE EXCHANGE DATA RESPONSE.
- CRRN3: to be able to receive and send messages over the contactless interface in reader mode the applet shall activate the ReaderListener.EVENT\_TARGET\_DISCOVERED.
- CRRN4: an Applet has to be in the selectable state (according to the Java Card™ specification [11], [12] and [13]) to act as a contactless Applet in reader mode.

#### 6.2.3.1.2.1.2 Parameter errors

- CRRP1: throw java.lang.NullPointerException if data is null.
- CRRP2: throw java.lang.ArrayIndexOutOfBoundsException if operation would cause access of data outside array bounds.
- CRRP3: throw javacard.framework.SystemException with the error code ILLEGAL\_VALUE if the timeout value does not match with the predefined values.

#### 6.2.3.1.2.1.3 Context errors

- CRRC1: throw HCIException with error code reason HCI\_CURRENTLY\_DISABLED if the HCI interface
  was disabled.
- CRRC2: throw HCIException with error code reason HCI\_RESOURCES\_NOT\_AVAILABLE if the contactless framework does not have enough resources to process the command.
- CRRC3: throw HCIException with error code reason HCI\_FRAGMENTED\_MESSAGE\_ONGOING if the Contactless Framework is still receiving a fragmented HCI Message.

#### 6.2.3.1.2.2 Test suite files

Applet Name	Test case ID
Api_2_RMm_Srx_1.java	1
Api_2_RMm_Srx_1.java	2
Api_2_RMm_Srx_2.java	3
Api_2_RMm_Srx_2.java	4
Api_2_RMm_Srx_2.java	5
Api_2_RMm_Srx_2.java	6
Api_2_RMm_Srx_2.java	7

#### 6.2.3.1.2.3 Initial condition

- According applet has been successfully installed and selected using ISO Interface and the applet is set into ACTIVATED state.
- The event ReaderListener.EVENT\_TARGET\_DISCOVERED has been activated in the applet.

6.2.3.1.2.4 Test procedure

		Test case			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
1		Send Data - Ty		1	
	- Send EVT_TARGET_DI SCOVERED (status = '00') - Send ANY_OK	<pre>prepareAndSendWriteXchgDataCommand() timeout = -1 data = '0101' offset = 0 len = 10</pre>	No exception shall be thrown	- command WR_XCHG_DAT A Is received	N1, N2, N3, N4
2	0011471111_011	Send Data - Ty	pe B		
	- Send EVT_TARGET_DI SCOVERED (status = '00') - Send ANY_OK	<pre>prepareAndSendWriteXchgDataCommand() timeout = -1 data = '0101' offset = 0 len = 10</pre>	No exception shall be thrown	- command WR_XCHG_DAT A Is received	N1, N2, N3, N4
3	_	HCI interface is d	isabled	1	•
	1 - Precondition: Contactless functionality stateis disabled in the UICC as defined in TS 102 223 [7] - Send APDU on ISO interface to select the applet - Send EVT_TARGET_DI SCOVERED (status = '00') - Send APDU on ISO interface (INS = '11')	<pre>prepareAndSendWriteXchgDataCommand() timeout = 14 data = '0101' offset = 0 len = 10</pre>	Shall throw uicc.hci.framework.HCIEx ception with error code HCI_CURRENTLY_DISA BLED	- SW - '90 01'	C1
	2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send APDU on ISO interface to select the applet - Send EVT_TARGET_DI SCOVERED (status = '00') - Send APDU on ISO interface (INS = '01') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C	<pre>setCommunicationInterface() API method of Global Platform Amendment C [10] is used to disable HCI interface prepareAndSendWriteXchgDataCommand() timeout = 14 data = '0101' offset = 0 len = 10 setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface</pre>	Shall throw uicc.hci.framework.HCIEx ception with error code HCI_CURRENTLY_DISA BLED	- SW - '90 01'	C1

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
4		Data is nul				
	- Send APDU on ISO interface (INS = '02') - Send EVT_TARGET_DI SCOVERED (status = '00') - Send APDU on ISO interface ('12')	<pre>prepareAndSendWriteXchgDataCommand() timeout = 14 data = null offset = 0 len = 10</pre>	Shall throw java.lang.NullPointerExce ption	- SW - '90 02'	P1	
5		ArrayIndexOutOfBound	ds Exception	•	•	
	- Send APDU on ISO interface (INS = '03') - Send EVT_TARGET_DI SCOVERED (status = 00) - Send APDU on ISO interface ('13')	<pre>prepareAndSendWriteXchgDataCommand() timeout = 14 data = '0101' offset = -1 len = 10</pre>	Shall throw java.lang. ArrayIndexOutOfBoundsE xception	- SW - '90 03'	P2	
6		ArrayIndexOutOfBound				
	- Send APDU on ISO interface (INS = '03') - Send EVT_TARGET_DI SCOVERED (status = '00') - Send APDU on ISO interface (INS = '13')	<pre>prepareAndSendWriteXchgDataCommand() timeout = 14 data = '0101' offset = 0 len = 11</pre>	Shall throw java.lang. ArrayIndexOutOfBoundsE xception	- SW - '90 04'	P2	
7		Timeout has illega			_	
	- Send EVT_TARGET_DI SCOVERED (status = 00) - Send APDU on ISO interface (INS = '01')	<pre>prepareAndSendWriteXchgDataCommand() timeout = -2 data = '0101' offset = 0 len = 10</pre>	Shall throw uicc.hci.framework.HCIEx ception with error code ILLEGAL_VALUE	- SW - '90 05'	P3	

## 6.2.3.1.3 Method prepareAndSendGetParameterCommand

Test Area Reference: Api\_2\_RMm\_Sgp.

## 6.2.3.1.3.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

 $\label{lem:parameterCommand} \mbox{void prepareAndSendGetParameterCommand(byte paramid)} \\ \mbox{throws HCIException,} \\ \mbox{javacardframework.SystemException}$ 

### 6.2.3.1.3.1.1 Normal execution

- CRRN1: This non-blocking method builds the HCI command ANY\_GET\_PARAMETER for the indicated information and sends it to the Contactless Reader Gate of the CLF.
- CRRN2: this method should only be called when the CLF has successfully discovered a card in the field, i.e. after reception of the HCI event EVT\_TARGET\_DISCOVERED.
- CRRN3: paramid shall be one of the PARAM\_\* values defined in this interface.

#### 6.2.3.1.3.1.2 Parameter errors

• CRRP1: throw javacard.framework.SystemException - with the following reason code ILLEGAL\_VALUE if the paramID does not match with the predefined values.

#### 6.2.3.1.3.1.3 Context errors

- CRRC1: throw HCIException with error code reason HCI\_CURRENTLY\_DISABLED if the HCI interface
  was disabled.
- CRRC2: throw HCIException with error code reason HCI\_RESOURCES\_NOT\_AVAILABLE if the contactless framework does not have enough resources to process the command.
- CRRC3: throw HCIException with error code reason HCI\_FRAGMENTED\_MESSAGE\_ONGOING if the Contactless Framework is still receiving a fragmented HCI Message.

#### 6.2.3.1.3.2 Test suite files

Applet Name	Test case ID
Api_2_RMm_Sgp_1.java	1
Api_2_RMm_Sgp_1.java	2
Api_2_RMm_Sgp_2.java	3
Api_2_RMm_Sgp_2.java	4
Api_2_RMm_Sgp_2.java	5

#### 6.2.3.1.3.3 Initial condition

- According applet has been successfully installed and selected using ISO Interface and the applet is set into ACTIVATED state.
- The event ReaderListener.EVENT\_TARGET\_DISCOVERED has been activated in the applet.

### 6.2.3.1.3.4 Test procedure

	Test case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
1		Get Parameter: Type	Α			
	1 - Send APDU on ISO interface (INS = '01') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_UID  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0100'	N1, N2, N3	
	2 - Send APDU on ISO interface (INS = '02') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_ATQA  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0200'	N1, N2, N3	
	3 - Send APDU on ISO interface (INS = '03') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_APPLICATION_DA TA  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	GET_PARAMETE R with the predefined parameter value - APDU-Response '0300'	N1, N2, N3	

		Test case			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
	4 - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_SAK  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown.	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0400'	N1, N2, N3
	5 - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	- prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_FWI  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE	No exception shall be thrown	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0500'	N1, N2, N3
	6 - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_DATARATE_MAX Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0600'	N1, N2, N3
2		Get Parameter: Type			1
	1 - Send APDU on ISO interface (INS = '07') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_B_READER_PUPI Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	GET_PARAMETE R with the predefined parameter value - APDU-Response '0700'	N1, N2, N3
	2 - Send APDU on ISO interface (INS = '08') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_B_READER_APPLICATION_DA TA  Response received: onCallback() event = EVENT GET PARAMETER RESPONSE</pre>	No exception shall be thrown	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0800'	N1, N2, N3
	3 - Send APDU on ISO interface (INS = '09') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_B_READER_AFI  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE	No exception shall be thrown	GET_PARAMETE R with the predefined parameter value - APDU-Response '0900'	N1, N2, N3
	4 - Send APDU on ISO interface (INS = '0A') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_B_READER_HIGHER_LAYER_R ESPONSE  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	GET_PARAMETE R with the predefined parameter value - APDU-Response '0A00'	N1, N2, N3
	5 - Send APDU on ISO interface (INS = '0B') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '20')	<pre>prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_B_READER_HIGHER_LAYER_D ATA  Response received: onCallback() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown	- GET_PARAMETE R with the predefined parameter value - APDU-Response '0B00'	N1, N2, N3

		Test case			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
3	4.5	HCI interface is disab		0.44 100 001	104
	1 - Precondition: Contactless functionality state is disabled in the UICC as defined in TS 102 223 [7] - Send APDU on ISO interface (INS = '01') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO	<pre>- prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_UID</pre>	Shall throw uicc.hci.framework. HCIException with error code HCI_CURRENTLY_ DISABLED	- SW - '90 03'	C1
	interface (INS = '11')	10 11 7 1 5 () 777	01 11 11	0144 100 001	0.4
	2 - Precondition: Contactless functionality state is disabled in the UICC as defined in Global Platform Amendment C Send on ISO interface send the following commands: - Send APDU on ISO interface to select the applet - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '11') - Postcondition: Contactless functionality state is enabled again in the UICC as defined in Global Platform Amendment C	setCommunicationInterface() API method of Global Platform Amendment C [10] is used to disable HCI interface  prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_UID  setCommunicationInterface() API method of Global Platform Amendment C [10] is used to enable again HCI interface	Shall throw uicc.hci.framework. HCIException with error code HCI_CURRENTLY_ DISABLED	- SW - '90 03'	C1
4		The Contactless Framework is receiving fr	agmented HCI Messa	ge	I.
	- Send APDU on ISO interface (INS = '02') - Send EVT_TARGET_DISCO VERED (status = '00') - Send ANY_OK as fragmented HCI Message (data length = supported buffer size + 5 bytes, message not complete) - Send APDU on ISO interface (INS = '12')	- prepareAndSendGetParameterCommand() paramid = PARAM_ID_TYPE_A_READER_UID	Shall throw uicc.hci.framework. HCIException with error code HCI_FRAGMENTE D_MESSAGE_ONG OING	- SW - '90 04'	C3
5		The parameter has an illeg	al value	1	
	- Send APDU on ISO interface (INS = '05') - Send EVT_TARGET_DISCO VERED (status = '00') - Send APDU on ISO interface (INS = '15')	- prepareAndSendGetParameterCommand() paramid = -1	Shall throw uicc.hci.framework. HCIException with error code ILLEGAL_VALUE	- SW - '90 05'	P1

### 6.2.3.2 Interface ReaderListener

### 6.2.3.2.1 Method on Callback

Test Area Reference: Api\_2\_Rml\_Ocb.

#### 6.2.3.2.1.1 Conformance requirements

The method with the following header shall be compliant to its definition in the API.

void onCallback(byte event, HCIMessage message)

#### 6.2.3.2.1.1.1 Normal execution

- CRRN1: The Contactless Framework shall invoke the method ReaderListener.onCallback only with events which are defined in ReaderListener or HCIListener and only with ReaderMessage objects.
- CRRN2: The Applet instance shall activate the events with ReaderService.activateEvent before it will receive any event notification.

#### 6.2.3.2.1.1.2 Parameter errors

None.

#### 6.2.3.2.1.1.3 Context errors

• None.

## 6.2.3.2.1.2 Test Suite Files

Applet Name	Test case ID
Api_2_Rml_Ocb_1.java	1
Api_2_Rml_Ocb_1.java	2
Api_2_Rml_Ocb_1.java	3
Api_2_Rml_Ocb_1.java	4
Api_2_Rml_Ocb_1.java	5
Api_2_Rml_Ocb_1.java	6
Api_2_Rml_Ocb_1.java	7
Api_2_Rml_Ocb_1.java	8

### 6.2.3.2.1.3 Initial conditions

- According applet has been successfully installed and selected using ISO Interface and the applet is set into ACTIVATED state.
- The event ReaderListener.EVENT\_TARGET\_DISCOVERED has been activated in the applet.

#### 6.2.3.2.1.4 Test procedure

	Test Case						
ID	HCI Command	API Description	API Expectation	HCI Response	CRR		
1		EVENT_TARGET_DISCOVER	RED - Type A				
	Send command on ISO interface	HCIService = ReaderService	No exception shall	WR_XCHG_DAT	N1,		
	to select applet.	activateEvent()	be thrown.	A ('00 01 00 00')	N2		
	- select applet APDU (INS = '10')	event =		is received			
	- Select applet Al DO (INS = 10)	EVENT_TARGET_DISCOVERED	onCallback()				
	- Send		method shall notice				
	EVENT_TARGET_DISCOVERE		the event				
i	D (status = '00')						

		Test Case			
ID	HCI Command	API Description	API Expectation	HCI Response	CRR
	EVENT	_WRITE_EXCHANGE_DATA_RESF	PONSE - Type A		
2	Send command on ISO interface to select applet select applet APDU(INS = '11') - Send EVT_TARGET_DISCOVERED (status = '00')	HCIService = ReaderService activateEvent() event = EVENT_WRITE_EXCHANGE_DATA_RES PONSE	No exception shall be thrown. onCallback() method shall notice the event	Start bulk data transfer on HCI interface.	N1, N2
	- Send ANY_OK ()				
			FAILED - Type A		
3	Send command on ISO interface to select applet select applet APDU (INS = '12') - Send EVT_TARGET_DISCOVERED (status = '00') - Send ANY_OK ('11 22 33 44 00'), RF error indicator is set to '01' - Send APDU (INS = '2') on ISO	<pre>HCIService = ReaderService activateEvent() event = HCIListener.EVENT_HCI_TRANSMI SSION_FAILED</pre>	No exception shall be thrown. onCallback() method shall notice the event	- No WR_XCHG_DAT A () is received. - SW - '90 00'	N1, N2.
	interface				
		ENT_GET_PARAMETER_RESPON			
4	Send command on ISO interface to select applet select applet APDU(INS = '13') - Send EVT_TARGET_DISCOVERED (status = '00') - Send ANY_OK ()	<pre>HCIService = ReaderService activateEvent() event = EVENT_GET_PARAMETER_RESPONSE</pre>	No exception shall be thrown. onCallback() method shall notice the event	ANY_GET_PAR AMETER is received	N1, N2
5	<u> </u>	EVENT_TARGET_DISCOVERE	D - Type B		•
	Send command on ISO interface to select applet select applet APDU (INS = '10') - Send EVENT_TARGET_DISCOVERE D (status = '00')	HCIService = ReaderService activateEvent() event = EVENT_TARGET_DISCOVERED	No exception shall be thrown. onCallback() method shall notice the event	WR_XCHG_DAT A ('00 01 00 00') is received	N1, N2
	EVENT	_WRITE_EXCHANGE_DATA_RESE	PONSE - Type B		I
6	Send command on ISO interface to select applet select applet APDU(INS = '11') - Send EVT_TARGET_DISCOVERED (status = '00') - Send ANY_OK ()	HCIService = ReaderService activateEvent() event = EVENT_WRITE_EXCHANGE_DATA_RES PONSE	No exception shall be thrown. onCallback() method shall notice the event	Start bulk data transfer on HCI interface.	N1, N2
		l ener.EVENT_HCI_TRANSMISSION_	FAILED - Type B	1	<u> </u>
7	Send command on ISO interface to select applet select applet APDU (INS = '12') - Send EVT_TARGET_DISCOVERED (status = '00') - Send ANY_OK ('11 22 33 44 00'), RF error indicator is set to '01' - Send APDU (INS = '2') on ISO interface	HCIService = ReaderService  activateEvent() event = HCIListener.EVENT_HCI_TRANSMI SSION_FAILED	No exception shall be thrown. onCallback() method shall notice the event	- No WR_XCHG_DAT A () is received. - SW - '90 00'	N1, N2.

	Test Case					
ID	HCI Command	API Description	API Expectation	HCI Response	CRR	
	EVENT_GET_PARAMETER_RESPONSE - Type B					
8	to select applet.	HCIService = ReaderService activateEvent() event = EVENT_GET_PARAMETER_RESPONSE		ANY_GET_PAR AMETER is received	N1, N2	

# Annex A (normative): Class, methods and tests acronyms

## A.1 HCI framework

Class name	Acronyms
HCIDevice	Hdv
HCISevice	HSr
HCIMessage	Hme
HCIListener	Hln
HCIException	Нхр

## A.1.1 Class HCIDevice

Method name	Acronyms
<pre>public static HCIService getHCIService()</pre>	Gsr
<pre>public static byte getPowerMode()</pre>	Gpm
public static byte isHCIServiceAvailable()	Isa

## A.1.2 Interface HCIService

Method name	Acronyms
void register()	Reg
void deregister()	Drg
<pre>void activateEvent()</pre>	Ace
<pre>void deactivateEvent()</pre>	Dae
<pre>void requestCallbackNotification()</pre>	Rcn
boolean getEventNotificationStatus()	Gen

# A.1.3 Interface HCIMessage

Method Name	Acronyms
boolean isHeading()	Mhd
boolean isComplete()	Mco
byte getType()	Mty
byte getInstruction()	Min
short getReceiveOffset()	Mro
short getReceiveLength()	Mrl
<pre>byte[] getReceiveBuffer()</pre>	Mrb

## A.1.4 Interface HCIListener

Method Name	Acronyms
void onCallback()	Ocb

## A.1.5 Class HCIException

Method Name	Acronyms
<pre>public static void throwIt()</pre>	Trw

# A.2 HCI Services

# A.2.1 Package cardemulation

Interface Name	Acronyms
CardEmulationMessage	CEm
CardEmulationService	CEs

## A.2.1.1 Interface CardEmulationListener

Method Name	Acronyms
void onCallback()	Ocb

## A.2.1.2 Interface CardEmulationMessage

Method Name	Acronyms
<pre>void prepareAndSendGetParameterCommand()</pre>	Sgp
<pre>void prepareAndSendSendDataEvent()</pre>	Ssd
boolean selectingMessage()	Scm

## A.2.1.3 Interface CardEmulationService

Method Name	Acronyms
<pre>byte getCardRFType()</pre>	Rft

# A.2.2 Package connectivity

Interface Name	Acronyms
ConnectivityMessage	CNm
ConnectivityService	CNs

# A.2.2.1 Interface ConnectivityListener

FFS

## A.2.2.2 Interface ConnectivityMessage

**FFS** 

# A.2.2.3 Interface ConnectivityService

Method Name	Acronyms
prepareAndSendConnectivityEvent()	Sce
<pre>prepareAndSendTransactionEvent(byte[] aid,</pre>	Ste
short aidOffset, short aidLen, byte[] parameters,	
short parametersOffset, short parametersLen)	
<pre>prepareAndSendTransactionEvent(byte[] parameters, short</pre>	Stt
parametersOffset, short parametersLen)	

## A.2.3 Readermode

## A.2.3.1 Interface RaederListener

Method Name	Acronyms
<pre>void onCallback()</pre>	Ocb

## A.2.3.2 Interface ReaderMessage

Method Name	Acronyms
<pre>void prepareAndSendGetParameterCommand()</pre>	Sgp
<pre>void prepareAndSendWriteXchgDataCommand()</pre>	Srx
void restartReaderModeProcedure()	Rrp

## A.2.3.3 Interface ReaderService

FFS

# Annex B (normative): AIDs - to be reserved

# B.1 Package HCI framework

Package name	AID
uicc.test.hci.framework	A0 00 00 00 09 00 05 FF FF FF FF 89 21 00 00 00

# B.1.1 Class HCIDevice

Package name	AID
uicc.test.hci.framework. Api_1_Hdv_Gsr	A0 00 00 00 09 00 05 FF FF FF FF 89 21 01 00 00
uicc.test.hci.framework. Api_1_Hdv_Gpm	A0 00 00 00 09 00 05 FF FF FF FF 89 21 02 00 00
uicc.test.hci.framework. Api_1_Hdv_lsa	A0 00 00 00 09 00 05 FF FF FF FF 89 21 03 00 00

Applet name	AID
Api_1_Hdv_Gsr_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 01 01 02
Api_1_Hdv_Gsr_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 01 02 02
Api_1_Hdv_Gpm_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 02 01 02
Api_1_Hdv_lsa_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 03 01 02
Api_1_Hdv_Isa_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 03 02 02

# B.1.2 Interface HCIService

Package name	AID
uicc.test.hci.framework. Api_1_Hsr_Reg	A0 00 00 00 09 00 05 FF FF FF FF 89 21 04 00 00
uicc.test.hci.framework. Api_1_Hsr_Drg	A0 00 00 00 09 00 05 FF FF FF FF 89 21 05 00 00
uicc.test.hci.framework. Api_1_Hsr_Ace	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 00 00
uicc.test.hci.framework. Api_1_Hsr_Dae	A0 00 00 00 09 00 05 FF FF FF FF 89 21 07 00 00
uicc.test.hci.framework. Api_1_Hsr_Rcn	A0 00 00 00 09 00 05 FF FF FF FF 89 21 08 00 00
uicc.test.hci.framework. Api_1_Hsr_Gen	A0 00 00 00 09 00 05 FF FF FF FF 89 21 09 00 00

Applet name	AID
Api_1_Hsr_Reg_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 04 01 02
Api_1_Hsr_Reg_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 04 02 02
Api_1_Hsr_Reg_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 04 03 02
Api_1_Hsr_Reg_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 04 04 02
Api_1_Hsr_Drg_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 05 01 02
Api_1_Hsr_Drg_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 05 02 02
Api_1_Hsr_Ace_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 01 02
Api_1_Hsr_Ace_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 02 02
Api_1_Hsr_Ace_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 04 02
Api_1_Hsr_Ace_5.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 05 02
Api_1_Hsr_Ace_6.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 06 02
Api_1_Hsr_Ace_8.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 06 08 02
Api_1_Hsr_Dae_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 07 01 02
Api_1_Hsr_Dae_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 07 02 02
Api_1_Hsr_Dae_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 07 03 02
Api_1_Hsr_Dae_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 07 04 02
Api_1_Hsr_Dae_6.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 07 06 02
Api_1_Hsr_Rcn_7.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 08 07 02
Api_1_Hsr_Gen_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 09 01 02
Api_1_Hsr_Gen_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 09 02 02

# B.1.3 Interface HCIMessage

Package name	AID
uicc.test.hci.framework. Api_1_Hme_Mhd	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0A 00 00
uicc.test.hci.framework. Api_1_Hme_Mco	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0B 00 00
uicc.test.hci.framework. Api_1_Hme_Mty	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0C 00 00
uicc.test.hci.framework. Api_1_Hme_Min	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0D 00 00
uicc.test.hci.framework. Api_1_Hme_Mro	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0E 00 00
uicc.test.hci.framework. Api_1_Hme_Mrl	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0F 00 00
uicc.test.hci.framework. Api_1_Hme_Mrb	A0 00 00 00 09 00 05 FF FF FF FF 89 21 10 00 00

Applet name	AID
Api_1_Hme_Mhd_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0A 01 02
Api_1_Hme_Mco_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0B 01 02
Api_1_Hme_Mty_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0C 01 02
Api_1_Hme_Mty_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0C 02 02
Api_1_Hme_Min_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0D 01 02
Api_1_Hme_Min_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0D 02 02
Api_1_Hme_Mrl_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 0F 01 02
Api_1_Hme_Mrb_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 10 01 02

# B.1.4 Interface HCIListener

Package name	AID
uicc.test.hci.framework. Api_1_Hln_Ocb	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 00 00

Applet name	AID
Api_1_Hln_Ocb_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 01 02
Api_1_Hln_Ocb_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 02 02
Api_1_Hln_Ocb_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 03 02
Api_1_Hln_Ocb_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 04 02
Api_1_Hln_Ocb_5.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 05 02
Api_1_Hln_Ocb_6.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 11 06 02

# B.1.5 Class HCIException

Package name	AID
uicc.test.hci.framework. Api_1_Hxp_Trw	A0 00 00 00 09 00 05 FF FF FF FF 89 21 12 00 00

Applet name	AID
Api_1_Hxp_Trw_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 21 12 01 02

# B.2 HCI Services

# B.2.1 Package cardemulation

Package name	AID
uicc.test.hci.services.cardemulation	A0 00 00 00 09 00 05 FF FF FF FF 89 25 00 00 00

## B.2.1.1 Interface CardEmulationListener

Package name	AID
uicc.test.hci.services.cardemulation.Api_2_CEI_Ocb	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 00 00

Applet name	AID
Api_2_CEI_Ocb_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 01 02
Api_2_CEI_Ocb_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 02 02
Api_2_CEI_Ocb_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 03 02
Api_2_CEI_Ocb_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 04 02
Api_2_CEI_Ocb_5.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 05 02
Api_2_CEI_Ocb_6.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 06 02
Api_2_CEI_Ocb_7.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 07 02
Api_2_CEI_Ocb_8.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 05 08 02

# B.2.1.2 Interface CardEmulationMessage

Package name	AID
uicc.test.hci.services.cardemulation.Api_2_CEm_Sgp	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 00 00
uicc.test.hci.services.cardemulation.Api_2_CEm_Ssd	A0 00 00 00 09 00 05 FF FF FF FF 89 25 02 00 00
uicc.test.hci.services.cardemulation.Api_2_CEm_Scm	A0 00 00 00 09 00 05 FF FF FF FF 89 25 03 00 00

Applet name	AID
Api_2_CEm_Sgp _1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 01 02
Api_2_CEm_Sgp _2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 02 02
Api_2_CEm_Sgp _3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 03 02
Api_2_CEm_Sgp _4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 04 02
Api_2_CEm_Sgp _5.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 05 02
Api_2_CEm_Sgp _6.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 06 02
Api_2_CEm_Sgp _7.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 07 02
Api_2_CEm_Sgp _8.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 08 02
Api_2_CEm_Sgp _9.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 09 02
Api_2_CEm_Sgp _10.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 0A 02
Api_2_CEm_Sgp _11.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 0B 02
Api_2_CEm_Sgp _12.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 0C 02
Api_2_CEm_Sgp _13.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 01 0D 02
Api_2_CEm_Ssd _1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 02 01 02
Api_2_CEm_Ssd _2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 02 02 02
Api_2_CEm_Ssd _3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 02 03 02
Api_2_CEm_Ssd _4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 02 04 02
Api_2_CEm_Scm _1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 03 01 02

## B.2.1.3 Interface CardEmulationService

Package name	AID
uicc.test.hci.services.cardemulation.Api_2_CEs_RFt	A0 00 00 00 09 00 05 FF FF FF FF 89 25 04 00 00

Applet name	AID
Api_2_CEs_RFt_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 25 04 01 02

# B.2.2 Package connectivity

Package name	AID
uicc.test.hci.services.connectivity	A0 00 00 00 09 00 05 FF FF FF FF 89 26 00 00 00

# B.2.2.1 Interface ConnectivityListener

FFS

## B.2.2.2 Interface ConnectivityMessage

FFS

## B.2.2.3 Interface ConnectivityService

Package name	AID
uicc.test.hci.services.connectivity.Api_2_CNs_Sce	A0 00 00 00 09 00 05 FF FF FF FF 89 26 01 00 00
uicc.test.hci.services.connectivity.Api_2_CNs_Ste	A0 00 00 00 09 00 05 FF FF FF FF 89 26 02 00 00
uicc.test.hci.services.connectivity.Api_2_CNs_Stt	A0 00 00 00 09 00 05 FF FF FF FF 89 26 03 00 00

Applet name	AID
Api_2_CNs_Sce_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 01 01 02
Api_2_CNs_Sce_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 01 02 02
Api_2_CNs_Sce_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 01 03 02
Api_2_CNs_Sce_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 01 04 02
Api_2_CNs_Sce_5.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 01 05 02
Api_2_CNs_Ste_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 02 01 02
Api_2_CNs_Ste_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 02 02 02
Api_2_CNs_Ste_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 02 03 02
Api_2_CNs_Ste_4.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 02 04 02
Api_2_CNs_Stt_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 03 01 02
Api_2_CNs_Stt_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 03 02 02
Api_2_CNs_Stt_3.java	A0 00 00 00 09 00 05 FF FF FF FF 89 26 03 03 02

# B.2.3 Package readermode

Package name	AID
uicc.test.hci.services.reader	A0 00 00 00 09 00 05 FF FF FF FF 89 27 00 00 00

## B.2.3.1 Interface ReaderMessage

Package name	AID
uicc.test.hci.services.reader.Api_2_RMm_Rrp	A0 00 00 00 09 00 05 FF FF FF FF 89 27 01 00 00
uicc.test.hci.services.reader.Api_2_ RMm _Srx	A0 00 00 00 09 00 05 FF FF FF FF 89 27 02 00 00
uicc.test.hci.services.reader.Api_2_RMm_Sgp	A0 00 00 00 09 00 05 FF FF FF FF 89 27 03 00 00

Applet name	AID
Api_2_RMm_Rrp_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 01 01 02
Api_2_RMm_Rrp_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 01 02 02
Api_2_RMm_Srx_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 02 01 02
Api_2_RMm_Srx_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 02 02 02
Api_2_RMm_Sgp_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 03 01 02
Api_2_RMm_Sgp_2.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 03 02 02

# B.2.3.2 Interface ReaderListener

Package name	AID	
uicc.test.hci.services.reader.Api_2_RMI_Ocb	A0 00 00 00 09 00 05 FF FF FF FF 89 27 04 00 00	

Applet name	AID
Api_2_Rml_Ocb_1.java	A0 00 00 00 09 00 05 FF FF FF FF 89 27 04 01 02

## B.2.3.3 Interface ReaderService

FFS

# Annex C (normative): Requirements

# C.1 Non-occurrence and out-of-scope requirements

# C.1.1 Package uicc.hci

Requirement	Reference
A mechanism to launch an application on the terminal host that is related to the Applet running in the	Api_2_CNs_Ste
UICC	Api_2_CNs_Stt
The Contactless Framework shall add the AID of the calling Applet instance to the HCI event passed	Api_2_CNs_Stt
to the CLF	
A mechanism that allows a UICC to start a proactive session as defined in TS 102 223 [7]	Api_2_CNs_Sce
Content of the buffer outside of the area which is used for the HCI message part is undefined	Api_1_Hme_Mrb
This method throw HCIException with error code reason HCI_RESOURCES_NOT_AVAILABLE if	Api_2_RMm_Srx
the contactless framework does not have enough resources to process the command	Api_2_RMm_Sgp
	Api_2_CNs_Sce
	Api_2_CEm_ Ssd
	Api_2_CNs_Ste
	Api 2 CNs Stt

# C.1.2 TS 102 705 prose part

Requirement	Reference
To release the CLF control at the end of a transaction an Applet shall deactivate the	4.3
ReaderListener.EVENT_TARGET_DISCOVERED	
The Contactless Framework shall bind the services defined in the uicc.hci.services.cardemulation package	
to the underlying HCl resources (e.g. gates and pipes) defined by the HCl protocol as specified in [3]	

# C.2 FFS requirements

# C.2.1 Package uicc.hci

Requirement	Reference
The application may use the whole receive buffer for its internal purposes. If the buffer is used for	Api_1_Hme_Mrb
manipulation of sensitive data it shall be cleared by the Applet before returning to the contactless	
framework	
Throw HCIException with error code reason HCI_FRAGMENTED_MESSAGE_ONGOING if the	Api_2_RMm_Srx
Contactless Framework is still receiving a fragmented HCI Message	
Throw java.lang.ArrayIndexOutOfBoundsException if operation would cause access of data outside	Api_2_RMm_Srx
array bounds	
Throws HCIException with the reason code HCI_CURRENTLY_DISABLED if the HCI interface was	Api_2_CEm_ Sgp
disabled	Api_2_CEm_ Ssd
Throw HCIException with error code reason HCI_INVALID_LENGTH if the parameter length or the	Api_2_CNs_Ste
AID is not compliant to TS 102 622 [3]	Api_2_CNs_Stt
In the case of a fragmented incoming message this method shall return the HCI message instruction	Api_1_Hme_Min
coded in the first part of the HCI message	
If the message is not complete then the returned value is the actual HCI message fragment length	Api_1_Hme_Mrl
HCIException with reason code HCI_CONDITIONS_NOT_SATISFIED if one or more conditions to	Api_1_Hsr_Ace
activate the event are not satisfied	
All other HCl messages shall be delivered to the Applet instance in the same order as they were	Api_1_Hln_Ocb
received by the Contactless Framework	

# C.2.2 TS 102 705 prose part

Requirement	Reference
When the contactless interface is disabled (cf. "state of contactless functionality" in TS 102 223 [7] and	4.1
setCommunicationInterface() API method of "GlobalPlatform Amendment C" [10]), the Contactless	
Framework shall throw an HCIException with reason code HCI_CURRENTLY_DISABLED	
The Contactless Framework shall request the reader mode control on the CLF by sending the HCl events	4.3
EVT_READER_REQUESTED and EVT_END_OPERATION according to the state of the reader mode	
Applet	
The Contactless Framework shall resend the EVT_READER_REQUESTED to the CLF if another Applet	4.3
instance exists with the ReaderListener.EVENT_TARGET_DISCOVERED event activated	
The EVT_READER_REQUESTED shall be sent by the Contactless Framework if an Applet instance	4.3
activates the event ReaderListener.EVENT_TARGET_DISCOVERED and no other Applet instance has the	
event activated, i.e. it shall not be sent if the Contactless Framework has earlier sent an	
EVT_READER_REQUESTED due to the request from another Applet instance, which was not yet ended	
by an EVT_END_OPERATION	
The Contactless Framework shall ensure that the ReaderListener.EVENT_TARGET_DISCOVERED is	4.3
deactivated for all Applets when access to the interface is disabled on the UICC level	
To be able to receive and send messages over the contactless interface in reader mode the applet shall	4.3
activate the ReaderListener.EVENT_TARGET_DISCOVERED	
When an Applet lifecycle state changes from ACTIVATED to DEACTIVATED the Contactless Framework	4.3
shall enforce that the ReaderListener.EVENT_TARGET_DISCOVERED is deactivated	
The HCI event EVT_END_OPERATION shall be sent to the CLF when an Applet instance or the	4.3
Contactless Framework deactivates the event ReaderListener.EVENT_TARGET_DISCOVERED	
The Contactless Framework shall inform the Applet instance which has activated the	4.3
ReaderListener.EVENT_TARGET_DISCOVERED when a target is discovered on one of the RF	
technologies the Applet instance is registered to with its installation parameters as specified in TS 102 226	
[9]	
Reader mode Applets shall follow the extended lifecycle model that is defined in "GlobalPlatform	4.3
Amendment C" [10] for contactless Applets in card emulation mode (i.e. following Application Availability	
States and the related transition rules)	
Per RF technology there shall be only one reader mode Applet in the state ACTIVATED (according to	4.3
"GlobalPlatform Amendment C" [10]) at any time	
When the state of a reader mode Applet changes to lifecycle ACTIVATED (according to "GlobalPlatform	4.3
Amendment C" [10]) the Contactless Framework shall ensure that the HCl gates and pipes are setup for	
the RF technologies that are supported by the reader mode Applet	

# Annex D (normative): Test Specification for Java Card™ Platform HCl API for the UICC

The source files for the HCI API for the UICC Application Programming Interface for Java Card<sup>TM</sup> for contactless Applets are contained in Annex\_D\_TestAppletsSourceCode.zip, which accompanies the present document.

# Annex E (normative): uicc.contactless.test.util package and contactless interfaces

The use of Java as a test scripting language is optional. However, if Java is used as the test scripting language, then the test descriptions shall be implemented according to annex E.

The content of this annex is TBD.

# Annex F (normative): Test Area files

The use of Java as a test scripting language is optional. However, if Java is used as the test scripting language, then the test descriptions shall be implemented according to annex F.

The content of this annex is TBD.

# Annex G (informative): Core specification version information

Unless otherwise specified, the versions of TS 102 705 [1] from which conformance requirements have been extracted are as follows.

Release	Latest version from which conformance requirements have been extracted
9	V9.3.0

# History

Document history		
V9.0.0	April 2013	Publication