
Matrix-Core Pin List



Power

USB5V: connect to USB(5V); input or output.

VIN : connect to MIC5219-3.3; input 3.4V-5V.

PH2.0 : connect to battery(and charger);

Battery charged 300ma by USB5V.

Wireless

WiFi: 802.11 b/g/n/e/i

WEP, WPA/WPA2 PSK/Enterprise

Bluetooth: Bluetooth 4.2/BLE

: The left is Matrix-Core IO function name and right is ESP32 GPIO name. 34*,35*,36*,39* only used as input.

Matrix-Core I/O function

3 x UARTs, including hardware flow control

2 x SPI 2 x I2S

16 x ADC input channels

2 x DAC 2 x I2C

SD-card interface support

and so on...

Notice

Attention to the correspondence of pins sorting