



Research & Vehicle Technology "Infotainment Systems Product Development"

Feature – Rejuvenate

Infotainment Subsystem Part Specific Specification (SPSS)

Version 1.4
UNCONTROLLED COPY IF PRINTED

Version Date: October 7, 2022

FORD CONFIDENTIAL



Revision History

Date	Version Notes		
September 17, 2021	1.0	1.0 Initial Release	
December 2, 2021	1.1		
	STR-88736	67/B-Architectural Design	nmajjiga: added new class descriptions and signal
		69/B-Physical Mapping of Classes	nmajjiga: added new class descriptions
		70/B-Logical Signal Mapping	nmajjiga: added new signal
		EQ-413906/B-RJV Server Tx	nmajjiga: added new signal
		466740/A-RSeatSetSave_Rq	nmajjiga: new signal for save seat position change
		88/B-General Requirements	nmajjiga: Added Requirement
		438019/B-Preconditions for	
		e Experience	nmajjiga: updated with vehicle stationary mode
	RJV-REQ-	466683/A-Vehicle Stationary Mode	nmajjiga: new requirement
	RJV-REQ-	442203/B-Configuration Settings	nmajjiga: updated feature configuration details
	RJV-REQ-	438021/B-Save/Recall Parameters	nmajjiga: updated audio requirements
	RJV-REQ-	438022/B-Orchestration Schedule	nmajjiga: update audio requirements
	STR-88737	71/B-Functional Definition	nmajjiga: added new functional definition for data analytics
	RJV-REQ-	438030/B-Audio Selection	nmajjiga: updated requirement
	RJV-REQ- Experience	438032/B-Start Rejuvenate	nmajjiga: updated requirement
	RJV-STR-9	956311/B-Activity Diagrams	nmajjiga: added new activity diagram
	RJV-ACT-I	REQ-441934/B-Start Rejuvenate	nmajjiga: updated to separate audio sequence
	RJV-ACT-I	REQ-466685/A-Start	nmajjiga: updated audio sequence as per alignment with
	Rejuvenate	e_Audio Sequence	audio team
	RJV-STR-9	956312/B-Sequence Diagrams	nmajjiga: added new sequence diagram
	RJV-SD-R	EQ-441935/B-Start Rejuvenate	nmajjiga: updated to separate audio sequence
	RJV-SD-R	EQ-466688/A-Start	nmajjiga: updated audio sequence as per alignment with
	Rejuvenate	e_Audio Sequence	audio team
	RJV-REQ- Experience	438033/B-End Rejuvenate	nmajjiga: updated requirement
	RJV-STR-9	956331/B-Activity Diagrams	nmajjiga: added new activity diagram
	RJV-ACT-I	REQ-441936/B-End Rejuvenate	nmajjiga: updated to separate accepted phone call/high priority audio request sequence
	RJV-ACT-I	REQ-466686/A-End	nmajjiga: updated accepted phone call/high priority audio
	-	e_Phone Call Accepted or Other	request sequence as per alignment with audio team
		y Audio Request	
	RJV-STR-9	956332/B-Sequence Diagrams	nmajjiga: added new sequence diagram
	RJV-SD-R	EQ-441937/B-End Rejuvenate	nmajjiga: updated to separate accepted phone call/high priority audio request sequence
		EQ-466689/A-End	nmajjiga: updated accepted phone call/high priority audio
	_	e_Phone Call Accepted or Other	request sequence as per alignment with audio team
		y Audio Request	
		95/B-Requirements	nmajjiga: added new requirement
	Position	466742/A-Save Altered Seat	nmajjiga: new requirement for save seat position change
	STR-94999	96/B-Use Cases	nmajjiga: added new use case

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 2 of 60
, ,	The information contained in this document is Proprietary to Ford Motor Company.	7 age 2 6/ 60



RJV-UC-REQ-466744/A-Save Altered Seat Position	nmajjiga: new use case for save seat position change
RJV-FUN-REQ-438070/B-Abort Experience	nmajjiga: added requirement
STR-949997/B-Requirements	nmajjiga: added requirement
RJV-REQ-438035/B-Abort Definition	nmajjiga: updated requirement
RJV-REQ-438036/B-Abort - Soft Button	nmajjiga: updated requirement
RJV-REQ-438037/B-Abort - Exit Precondition	nmajjiga: updated with vehicle stationary mode
RJV-REQ-442270/B-Abort - Accept Phone	
Call/Other high priority Audio requested	nmajjiga: updated requirement
RJV-REQ-470267/A-Abort - Climate System	
Unavailable For Rejuvenate	nmajjiga: new requirement
RJV-UC-REQ-442271/B-Abort - Accept	
Phone Call/Other high priority audio	nmajjiga: updated use case
requested	
RJV-ACT-REQ-441999/B-Abort Rejuvenate	nmajjiga: reference version B of End Rejuvenate
RJV-SD-REQ-442000/B-Abort Rejuvenate	nmajjiga: reference version B of End Rejuvenate
RJV-FUN-REQ-466751/A-Rejuvenate Data	nmailiga: now functional definition for data analytics
Analytics	nmajjiga: new functional definition for data analytics
STR-1007574/A-Requirements	nmajjiga: added new requirements
RJV-REQ-466745/A-Record and Store Data	
While Rejuvenate Active	nmajjiga: new requirement
RJV-REQ-466746/A-Record and Store	nmailiga: now requirement
Engine ON time and Data Logging Timer	nmajjiga: new requirement
RJV-REQ-466747/A-Record Feature	nmajjiga: new requirement
Completed Instances	innajjiga. new requirement
RJV-REQ-466748/A-Record Feature Preview	nmajjiga: new requirement
Instances	minajjiga. new requirement
RJV-REQ-466749/A-Record Feature Aborted	nmajjiga: new requirement
Instances	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
RJV-REQ-466750/A-Record Alterations	nmajjiga: new requirement
during Rejuvenate Experience	
STR-887374/B-Appendix: Reference Documents	nmajjiga: updated reference documents
Documents	
1.2	
STR-887370/C-Logical Signal Mapping	nmajiiga: added now signal for cost mayoment
	nmajjiga: added new signal for seat movement
RJV-IIR-REQ-413906/C-RJV Server_Tx	nmajjiga: added new signal for seat movement
MD-REQ-488637/A-RSeatMovement_Rq RJV-REQ-438022/C-Orchestration Schedule	nmajjiga: new signal for seat movement
	nmajjiga: modified requirement to remove version
STR-949989/B-Requirements	nmajjiga: added requirement for seat movement
RJV-REQ-488657/A-Seat Movement Selection	nmajjiga: new requirement for seat movement
STR-949990/B-Use Cases RJV-UC-REQ-488658/A-Seat Movement Selection	nmajjiga: new usecase for seat movement
	nmajjiga: new usecase for seat movement
RJV-STR-956355/B-Activity Diagrams	nmajjiga: added new activity diagram for seat movement
RJV-ACT-REQ-488659/A-Seat Movement Selection	nmajjiga: new activity diagram for seat movement
RJV-STR-956356/B-Sequence Diagrams	nmajjiga: added new sequence diagram for seat movement
RJV-SD-REQ-441930/B-Seat Massage Selection	nmajjiga: modified requirement to remove version
RJV-SD-REQ-488660/A-Seat Movement Selection	nmajjiga: new sequence diagram for seat movement
RJV-REQ-438032/C-Start Rejuvenate Experience RJV-ACT-REQ-466685/B-Start Rejuvenate_Audio	nmajjiga: updated requirement to add seat movement
_	nmajjiga: added clarification about MSS feature
Sequence	
RJV-SD-REQ-441935/C-Start Rejuvenate	nmajjiga: modified requirement to remove version

May 4, 2022



Subsystem Part Specific Specification Engineering Specification

	·	
	RJV-SD-REQ-466688/B-Start Rejuvenate_Audio Sequence	nmajjiga: added clarification about MSS feature
	RJV-REQ-438033/C-End Rejuvenate Experience	nmajjiga: modified requirement to remove version
	RJV-ACT-REQ-441936/C-End Rejuvenate	nmajjiga: removed MSSApplicationServer from diagram
	RJV-ACT-REQ-466686/B-End Rejuvenate_Accepted Phone Call/Other High Priority Audio Request	nmajjiga: removed MSSApplicationServer from diagram
	RJV-SD-REQ-441937/C-End Rejuvenate	nmajjiga: removed MSSApplicationServer from diagram
	RJV-SD-REQ-466689/B-End Rejuvenate_Accepted Phone Call/Other High Priority Audio Request	nmajjiga: removed MSSApplicationServer from diagram
	RJV-REQ-438034/B-Alter Rejuvenate Experience	nmajjiga: updated requirement to add seat movement
	RJV-UC-REQ-438016/B-Alter Rejuvenate Experience	nmajjiga: updated usecase to add seat movement
	RJV-REQ-438035/C-Abort Definition	nmajjiga: modified requirement to remove version
	RJV-REQ-438037/C-Abort - Exit Precondition	nmajjiga: modified requirement to remove version
	RJV-ACT-REQ-441999/C-Abort Rejuvenate	nmajjiga: updated to align with End Rejuvenate diagram
	RJV-SD-REQ-442000/C-Abort Rejuvenate	nmajjiga: updated to align with End Rejuvenate diagram
A		
August 4, 2022	1.3	
	STR-887367/C-Architectural Design	nmajjiga: revised to remove Audio Setting Client
	RJV-CLD-REQ-437967/B-RJV Client2	nmajjiga: updated to include door ajar
	RJV-CLD-REQ-437969/B-RJV Client4	nmajjiga: updated to remove personalization and SOA door ajar
	STR-887370/D-Logical Signal Mapping	nmajjiga: added door ajar signals
	MD-REQ-437974/B-RPhs_St	nmajjiga: fixed table format
	RJV-IIR-REQ-413908/B-RJV Server_Rx	nmajjiga: added door ajar signals
	MD-REQ-437983/B-RClimtOvrrd_St	nmajjiga: fixed table format
	STR-949988/C-General Requirements	nmajjiga: added new requirement for Personalization Settings Default
	RJV-REQ-438019/C-Preconditions for Rejuvenate Experience	nmajjiga: updated to add door ajar signals requirement
	RJV-REQ-442203/C-Configuration Settings	nmajjiga: fixed typo
	RJV-REQ-438020/B-HMI requirements for feature	nmajjiga: updated to align with HMI spec
	RJV-REQ-438021/C-Save/Recall Parameters	nmajjiga: updated audio content
	RJV-REQ-438022/D-Orchestration Schedule	nmajjiga: updated typo in door lock requirement
	RJV-REQ-516560/A-Personalization Settings Default	nmajjiga: new requirement for Personalization Settings Default
	STR-887371/C-Functional Definition	nmajjiga: added new functional definition for Audio Interruption While Rejuvenate Active
	RJV-REQ-438026/B-Heated Seat Selection	nmajjiga: added clarification
	RJV-REQ-438027/B-Cooled Seat Selection	nmajjiga: added clarification
	RJV-REQ-438028/B-Digital Scent Selection	nmajiga: modified to add scent options
	RJV-REQ-438030/C-Audio Selection	nmajjiga: modified to add source audio as option
	RJV-REQ-438031/B-Do Not Disturb Selection	nmajjiga: updated requirement to align with implementation
	RJV-STR-956355/C-Activity Diagrams	nmajjiga: added new activity diagram for Audio Toggle
	RJV-ACT-REQ-516797/A-Audio Toggle While Rejuvenate Active	nmajjiga: new activity diagram for Audio Toggle
	RJV-ACT-REQ-441931/B-Do Not Disturb Selection	nmajjiga: updated activity diagram to include AudioResourceServer
	RJV-STR-956356/C-Sequence Diagrams	nmajjiga: added new sequence diagram for Audio Toggle
	RJV-SD-REQ-516798/A-Audio Toggle While Rejuvenate Active	nmajjiga: new sequence diagram for Audio Toggle
	RJV-SD-REQ-441933/B-Do Not Disturb Selection	nmajjiga: updated sequence diagram to include AudioResourceServer
	RJV-REQ-438032/D-Start Rejuvenate Experience	nmajjiga: updated as per new feature implementation requirements
	RJV-ACT-REQ-466685/C-Start Rejuvenate_Audio Sequence	nmajjiga: updated as per revised feature implementation requirements for audio content
	RJV-SD-REQ-466688/C-Start Rejuvenate_Audio Sequence	nmajjiga: updated as per revised feature implementation requirements for audio content
	RJV-REQ-438033/D-End Rejuvenate Experience	nmajjiga: updated as per revised feature implementation requirements for audio
	RJV-UC-REQ-438015/B-End Rejuvenate Experience	nmajjiga: updated as per revised feature implementation requirements for audio






Ford Motor Company

RJV-STR-956331/C-Activity Diagrams	nmajjiga: revised to remove "End Rejuvenate_Accepted Phone Call/Other High Priority Audio Request" activity diagram
RJV-ACT-REQ-441936/D-End Rejuvenate	nmajjiga: updated as per new feature implementation requirements
RJV-STR-956332/C-Sequence Diagrams	nmajjiga: revised to remove "End Rejuvenate_Accepted Phone Call/Other High Priority Audio Request" sequence diagram
RJV-SD-REQ-441937/D-End Rejuvenate	nmajjiga: updated as per new feature implementation requirements
RJV-REQ-438034/C-Alter Rejuvenate Experience	nmajjiga: updated as per revised feature implementation requirements for audio content
RJV-UC-REQ-438016/C-Alter Rejuvenate Experience	nmajjiga: updated as per revised feature implementation requirements for audio content
STR-949997/C-Requirements	nmajjiga: updated as per new feature implementation requirements
RJV-REQ-438035/D-Abort Definition	nmajjiga: updated as per new feature implementation requirements
RJV-REQ-438037/D-Abort - Exit Precondition	nmajjiga: updated to add door ajar signals requirement
RJV-REQ-516970/A-Abort - Vehicle Controls other than Climate selected on HMI	nmajjiga: new requirement to abort rejuvenate experience
STR-949998/B-Use Cases	nmajjiga: updated as per new feature implementation requirements
RJV-UC-REQ-438018/B-Abort - Exit Precondition	nmajjiga: updated as per new feature implementation requirements
RJV-UC-REQ-516971/A-Abort - Vehicle Controls other than Climate selected on HMI	nmajjiga: new requirement to abort rejuvenate experience
RJV-ACT-REQ-441999/D-Abort Rejuvenate	nmajjiga: updated to align with End Rejuvenate diagram
RJV-SD-REQ-442000/D-Abort Rejuvenate	nmajjiga: updated to align with End Rejuvenate diagram
RJV-FUN-REQ-517009/A-Audio Interruption While Rejuvenate Active	nmajjiga: new function definition as per revised feature implementation requirements for audio content
STR-1109416/A-Requirements	nmajjiga: added new requirement as per revised feature implementation requirements for audio content
RJV-REQ-516984/A-Audio Interruption While Rejuvenate Active	nmajjiga: new requirement as per revised feature implementation requirements for audio content
STR-1109417/A-Use Cases	nmajjiga: added new use case as per revised feature implementation requirements for audio content
RJV-UC-REQ-516986/A-Audio Interruption While Rejuvenate Active	nmajjiga: new use case as per revised feature implementation requirements for audio content
RJV-STR-1109418/A-White Box Views	added new activity and sequence diagram as per revised feature implementation requirements for audio content
RJV-STR-1109419/A-Activity Diagrams	nmajjiga: added new activity diagram as per revised feature implementation requirements for audio content
RJV-ACT-REQ-516987/A-Audio Interruption While Rejuvenate Active	nmajjiga: new activity diagram as per revised feature implementation requirements for audio content
RJV-STR-1109420/A-Sequence Diagrams	nmajjiga: added new sequence diagram as per revised feature implementation requirements for audio content
RJV-SD-REQ-516988/A-Audio Interruption While Rejuvenate Active	nmajjiga: new sequence diagram as per revised feature implementation requirements for audio content
RJV-REQ-466745/B-Record and Store Data While Rejuvenate Active	nmajjiga: updated as per new data analytics requirements
RJV-REQ-466750/B-Record Alterations during Rejuvenate Experience	nmajjiga: updated as per new data analytics requirements
STR-887374/C-Appendix: Reference Documents	nmajjiga: updated reference documents
1.4	
STR-887367/D-Architectural Design	nmajjiga: revised to remove RJVClient4
STR-887369/C-Physical Mapping of Classes	nmajjiga: removed RJVClient4
STR-887370/E-Logical Signal Mapping	nmajjiga: added new CAN signals for Engine Active
RJV-IIR-REQ-413908/C-RJV Server_Rx	nmajjiga: added signals for Engine Active
MD-REQ-524077/A-PwPckTqRdy_B_Dsply	nmajjiga: signal for power pack torque ready lamp
STR-949988/D-General Requirements	nmajjiga: removed Vehicle Stationary Mode
RJV-REQ-438019/D-Preconditions for Rejuvenate Experience	nmajjiga: updated signals for engine active and removed stationary mode
RJV-REQ-438022/E-Orchestration Schedule	nmajjiga: removed doors lock requirement
RJV-REQ-516560/B-Personalization Settings Default	nmajjiga: added clarification
RJV-REQ-438032/E-Start Rejuvenate Experience	nmajjiga: removed doors lock requirement
RJV-UC-REQ-438014/B-Start Rejuvenate Experience	nmajjiga: removed doors locked post-condition
RJV-REQ-438037/E-Abort - Exit Precondition	nmajjiga: revised to remove Stationary Mode

FILE: REJUVENATE	SPSS v1.4	OCT 7, 2022

October 7, 2022



Subsystem Part Specific Specification



Table of Contents

REVISIO	ON HISTORY	2
AR	CHITECTURAL DESIGN	9
1.1	Overview	9
1.2	RJV-CLD-REQ-413904/A-RJV Server	9
1.3	RJV-CLD-REQ-413905/A-RJV Client1	9
1.4	RJV-CLD-REQ-437967/B-RJV Client2	
1.5	RJV-CLD-REQ-437968/A-RJV Client3	
1.6	RJV-CLD-REQ-437970/A-RJV Client5	
1.7	RJV-CLD-REQ-437971/A-RJV Client6	
1.8	DST-CLD-REQ-376671/A-Digital Scent Client	
1.9	VS-CLD-REQ-025445/B-Ambient Lighting / Vehicle Settings Client (TcSE ROIN-159910-1)	9
1.10	AUMGNTv2-CLD-REQ-410571/A-Audio Resource Server	10
1.11	MSS-CLD-REQ-410679/A-MSSApplicationServer	10
1.12	Physical Mapping of Classes	
1.13		
1.14	RJV-IIR-REQ-413906/C-RJV Server_TX	
	14.1 MD-REQ-437972/A-RACIV_St	
	14.3 MD-REQ-437974/B-RPhs_St	
	14.4 MD-REQ-437975/A-RSeatHeat_Rq	
	14.5 MD-REQ-437977/A-RSeatCool_Rq	
	14.6 MD-REQ-437978/A-RSeatMassage_Rq	
	14.7 MD-REQ-192189/B-LightAmbColor_No_Rq - Variant 2	
1.1	14.8 MD-REQ-192190/B-LightAmbIntsty_No_Rq - Variant 2	13
1.1	4.9 MD-REQ-426848/A-LghtAmbRqSrc_B_Stat	
1.1	4.10 MD-REQ-377212/A-CabinScentMode_St	14
1.1	4.11 MD-REQ-377213/A-CabinScentChannel_St	
	14.12 MD-REQ-377214/A-CabinScentIntensity_St	
	l4.13 MD-REQ-466740/A-RSeatSetSave_Rq	
1.1	14.14 MD-REQ-488637/A-RSeatMovement_Rq	15
1.15	RJV-IIR-REQ-413908/C-RJV Server_Rx	
	5.1 MD-REQ-437980/A-RClimt_St	
	5.2 MD-REQ-437981/A-RClimtOvrrd_St	
	l5.3 MD-REQ-437982/A-RSeatOvrrd_St	
	15.4 MD-REQ-437983/B-RClimtOvrrd_St	
	15.5 MD-REQ-403324/A-GearPosition_St	
	5.6 MD-REQ-273750/A-Ignition_Status	
	5.7 MD-REQ-273497/A-DriverDoorStatus	
	15.8 MD-REQ-273720/A-PassengerDoorStatus	
	15.9 MD-REQ-372987/A-RearLeftDoorStatus	
	15.10 MD-REQ-372988/A-RearRightDoorStatus	
	5.11 MD-REQ-273748/A-Eng_D_Stat	
	5.12 MD-REQ-273747/A-PwPckTq_D_Stat 5.13 MD-REQ-524077/A-PwPckTqRdy_B_Dsply	18 18
GE!	NERAL REQUIREMENTS	19



	2.1	RJV-REQ-438019/D-Preconditions for Rejuvenate Experience	19
	2.2	RJV-REQ-442203/C-Configuration Settings	19
	2.3	RJV-REQ-438020/B-HMI requirements for feature	19
	2.4	VS-SR-REQ-426847/A-LghtAmbRqSrc_B_Stat signal usage	19
	2.5	RJV-REQ-438021/C-Save/Recall Parameters	20
	2.6	RJV-REQ-438022/E-Orchestration Schedule	20
	2.7	RJV-REQ-516560/B-Personalization Settings Default	21
3	Func	CTIONAL DEFINITION	22
	3.1	RJV-FUN-REQ-413910/A-Update Theme	22
	3.1.1	· ·	
	3.1.2		
	3.2 3.2.1	RJV-FUN-REQ-438064/A-Settings Selection	
	3.2.2		
	3.2.3		
	3.3	RJV-FUN-REQ-438067/A-Start Rejuvenate Experience	42
	3.3.1	·	
	3.3.2 3.3.3		
		RJV-FUN-REQ-438068/A-End Rejuvenate Experience	
	3.4.1		
	3.4.2	2 Use Cases	48
	3.4.3		
	3.5	RJV-FUN-REQ-438069/A-Alter Rejuvenate Experience	
	3.5.1 3.5.2	·	
	3.6 3.6.1	RJV-FUN-REQ-438070/B-Abort Experience	
	3.6.2	·	
	3.6.3		
	3.7	RJV-FUN-REQ-517009/A-Audio Interruption While Rejuvenate Active	55
	3.7.1	· ·	
	3.7.2 3.7.3		
	3.8 3.8.1	RJV-FUN-REQ-466751/A-Rejuvenate Data Analytics	
	5.0.1	roquironionio	00
4	APPE	ENDIX: REFERENCE DOCUMENTS	60



1 Architectural Design

1.1 Overview

The Rejuvenate feature provides environment for customer to relax and recharge whenever they need by providing immersive sights, sounds, and scents. The feature will also encompass massage seating and orchestrated climate to further the immersion and relaxation. When the customer exits their vehicle, they should do so feeling refreshed and energized – ready to greet the next part of their day with a renewed purpose.

1.2 RJV-CLD-REQ-413904/A-RJV Server

Rejuvenate Server (RJVServer) shall pass commands to Rejuvenate clients to activate required features as per set parameters .

1.3 RJV-CLD-REQ-413905/A-RJV Client1

Rejuvenate Client1 (RJVClient1) shall take commands from RJVServer to set parameters for climate, EM register, heated seats, cooled seats experience as required to provide rejuvenate experience as selected by customer. RJVClient1 also provides RJVServer the status of rejuvenate climate logic and if it is overridden.

1.4 RJV-CLD-REQ-437967/B-RJV Client2

Rejuvenate Client2 (RJVClient2) shall take commands from RJVServer to set parameters for lighting experience as required to provide rejuvenate experience as selected by customer.

Rejuvenate Client2 (RJVClient2) shall also provide doors close/open status.

1.5 RJV-CLD-REQ-437968/A-RJV Client3

Rejuvenate Client3 (RJVClient3) shall take commands from RJVServer to set parameters for seat position as required to provide rejuvenate experience as selected by customer.

1.6 RJV-CLD-REQ-437970/A-RJV Client5

Rejuvenate Client5 (RJVClient5) shall take commands from RJVServer to set parameters for steering column movement as required to provide rejuvenate experience as selected by customer.

1.7 RJV-CLD-REQ-437971/A-RJV Client6

Rejuvenate Client6 (RJVClient6) shall take commands from RJVServer to set parameters for seat message operation as required to provide rejuvenate experience as selected by customer.

1.8 DST-CLD-REQ-376671/A-Digital Scent Client

The Digital Scent Client is responsible to provide the user HMI, to store and apply user settings using the Enhanced Memory feature, to receive OTA updates and to store scent data tables, to conditionally transmit selected subsets of scent data tables to the Digital Scent Server, to prioritize scenting requests from scent related features, to transmit scenting commands to the Digital Scent Server, to receive status information from the Digital Scent Server.

1.9 VS-CLD-REQ-025445/B-Ambient Lighting / Vehicle Settings Client (TcSE ROIN-159910-1)

Responsibility: The Ambient Lighting Settings Client makes requests to the external vehicle settings function to change Ambient lighting color or intensity as requested by the user.

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 9 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	1 3.92 3 0.00



1.10 AUMGNTv2-CLD-REQ-410571/A-Audio Resource Server

The Audio Resource Server object acts as the overall audio manager which is responsible for the interfaces between the requesters for the audio system (ie source clients/resource clients).

The Audio Resource Server is the audio prioritizer for audio requests.

The Audio Resource Server is responsible for providing the status of the audio sources to the source clients and status of the infotainment system.

The Audio Resource Server can stream audio to the Audio I/O controller for applicable sources

The Audio Resource Server mutes/unmutes it audio output signal as necessary for source changes.

1.11 MSS-CLD-REQ-410679/A-MSSApplicationServer

The 'MSSApplicationServer' object is responsible to co-ordinate and interface between the Audio Source Client(s), Input Client(s) and 'AudioResourceServer'. The 'MSSApplicationServer' is also responsible for controlling and updating the MSS Zone Manager objects when incoming service requests are received. The 'MSSApplicationServer' also transmits related status information to the Input client(s) (i.e. 'MSSOnboardClient', 'URC Client'). The 'MSSApplicationServer' shall interface with 'Passenger BT Phone Client' to handle the passenger BT phone calling and BT Media streaming. It also requests the 'Audio Resource Server' if the audio resources are needed.

1.12 Physical Mapping of Classes

The table below shows how the logical classes that make up the Rejuvenate feature may be mapped into physical modules.

Logical Class	Physical Module (ECU)
RJVServer	APIM PDC
RJVClient1	RCCM
RJVClient2	BCM
RJVClient3	DSM
RJVClient5	PSM
RJVClient6	SCMG
RJVClientX	All applicable RJVClients
DigitalScentClient	APIM PDC
AmbientLightingClient	APIM PDC
AudioResourceServer	APIM PDC
MSSApplicationServer	APIM PDC

1.13 Logical Signal Mapping

The CAN signals mentioned throughout this document shall refer to the CAN signal's logical name. The logical names shall be mapped to their actual CAN signal names. Please use the table below to perform the mapping.

Logical Name	CAN Signal Name
RActv_St	RjvntActv_D_Stat
RThemSel_St	RjvntThemSel_D_Stat
RPhs_St	RjvntPhs_D_Stat
RSeatHeat_Rq	RjvntSeatHeat_B_Rq
RSeatCool_Rq	RjvntSeatCool_B_Rq
RClimt_St	RjvntClimt_B_Stat
RSeatMassage_Rq	SeatFnDrv_D_Rq
LightAmbColor_No_Rq	LightAmbColor_No_Rq

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 10 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	1



LightAmbIntsty_No_Rq	LightAmbIntsty_No_Rq
LghtAmbRqSrc_B_Stat	LghtAmbRqSrc_B_Stat
CabinScentMode_St	CabnScentMde_D_Stat
CabinScentIntensity_St	CabnScentIntns_D_Stat
CabinScentChannel_St	CabnScentChnl_D_Stat
RClimtOvrrd_St	RjvntClimtOvrrd_D_Stat
RSeatOvrrd_St	RjvntSeatOvrrd_D_Stat
RClimtOvrdTyp_St	RjvntClimtOvrdTyp_D_St
GearPosition_St	TrnRng_D_Rq
Ignition_Status	Ignition_Status
RSeatSetSave_Rq	RjvntSeatSetSavDrv_B_Rq
RSeatMovement_Rq	RjvntSeatMov_B_Rq
DriverDoorStatus	DrStatDrv_B_ActI
PassengerDoorStatus	DrStatPsngr_B_Actl
RearLeftDoorStatus	DrStatRI_B_Actl
RearRightDoorStatus	DrStatRr_B_Actl
Eng_D_Stat	Eng_D_Stat
PwPckTq_D_Stat	PwPckTq_D_Stat
PwPckTqRdy_B_Dsply	PwPckTqRdy_B_Dsply

1.14 RJV-IIR-REQ-413906/C-RJV Server_Tx

1.14.1 MD-REQ-437972/A-RActv_St

Message Type: Status

This signal shall be sent by the RJVServer to provide feature status

Name	Literals	Value	Description
RActv_St	-	-	Feature status
	Inactive	0x0	
	Active	0x1	
	Not Used	0x2	
	Faulty	0x3	

1.14.2 MD-REQ-437973/A-RThemSel_St

Message Type: Status
This signal shall be sent by the RJVServer to provide theme selected status

Name	Literals	Value	Description
RThemSel_St	-	-	Theme selected status
	Null	0x0	
	Theme1	0x1	
	Theme2	0x2	
	Theme3	0x3	
	Theme4	0x4	
	Theme5	0x5	

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 11 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	r ago 11 or oo



Ford Motor Company

Theme6	0x6	
Theme7	0x7	
Theme8	0x8	
Theme9	0x9	
Theme10	0xA	
Theme11	0xB	
Theme12	0xC	
Theme13	0xD	
Theme14	0xE	
Theme15	0xF	

1.14.3 MD-REQ-437974/B-RPhs_St

Message Type: Status

This signal shall be sent by the RJVServer to provide feature phase status

Name	Literals	Value	Description
RPhs_St	-	-	Feature status
	Inactive	0x0	
	Relax	0x1	
	Invigorate	0x2	
	Exit	0x3	
	Abort	0x4	
	Not used	0x5 – 0x7	

1.14.4 MD-REQ-437975/A-RSeatHeat_Rq

Message Type: Request

This signal shall be sent by the RJVServer to request heated seat On/Off

Name	Literals	Value	Description
RSeatHeat_Rq	-	-	Feature status
_ '			
	Off	0x0	
	On	0x1	

1.14.5 MD-REQ-437977/A-RSeatCool_Rq

Message Type: Request

This signal shall be sent by the RJVServer to request cooled seat On/Off

Name	Literals	Value	Description
RSeatCool_Rq	-	-	Feature status
	Off	0x0	
	On	0x1	

1.14.6 MD-REQ-437978/A-RSeatMassage_Rq

Message Type: Request

This signal shall be sent by the RJVServer to request seat massage On/Off

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 12 of 60
,	The information contained in this document is Proprietary to Ford Motor Company.	, ago 12 0, 00

Logical Signal Name	Literals	Value	Description
RSeatMassage_Rq	Inactive	0x0	
	LowerLumbar	0x1	
	MiddleLumbar	0x2	
	UpperLumbar	0x3	
	LowerBolster	0x4	
	UpperBolster	0x5	
	LumbarMassage	0x6	
	CushionMassage	0x7	

1.14.7 MD-REQ-192189/B-LightAmbColor_No_Rq - Variant 2

Message Type: Request

The Ambient Lighting Client uses this signal to request the color selection for ambient lighting from the Ambient Lighting Server.

Logical Signal Name	Literals	Value	Description
LightAmbColor_No_Rq -	Inactive	0x00	
Variant 2	Color ID1	0x01	
	Color ID2	0x02	
	Color ID3	0x03	
	Color ID4	0x04	
	Color ID5	0x05	
	Color ID6	0x06	
	Color ID7	0x07	
	Color ID8	0x08	
	Color ID9	0x09	
	Color ID10	0x0A	
	Color ID11	0x0B	
	Color ID12	0x0C	
	Color ID13	0x0D	
	Color ID14	0x0E	
	Color ID15	0x0F	
	Color ID16	0x10	
	Reserved	0x11 to 0xFF	

1.14.8 MD-REQ-192190/B-LightAmbIntsty_No_Rq - Variant 2

Message Type: Request

This signal requests the selection of intensity for ambient lighting.

Logical Signal Name	Literals	Value	Description
LightAmbIntsty_No_Rq -	Inactive / No Data Exits	0x00	
Variant 2	0% Intensity / Ambient	0x01	
	Lighting OFF		
	1% Intensity	0x02	
	2% Intensity	0x03	
	3% Intensity	0x04	
	cont.		
	100% Intensity	0x65	

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 13 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	. a.g



Ford Motor Company

Ambient Lighting Turn ON	0x66	

1.14.9 MD-REQ-426848/A-LghtAmbRqSrc_B_Stat

Message Type: Status

Signal from the Phoenix PDC Ambient Lighting Client module indicating if in manual or automatic mode

Logical Signal Name	Literals	Value	Description
LghtAmbRqSrc_B_Stat	Manual	0x0	
	Auto	0x1	

1.14.10 MD-REQ-377212/A-CabinScentMode_St

Message Type: Status

Signal provides the scenting operation status of scent module.

Name	Literals	Value	Description
	-	-	
	AwakeNotScenting	0x0	
	AwakeScenting	0x1	

1.14.11 MD-REQ-377213/A-CabinScentChannel_St

Message Type: Status

Signal provides the currently selected scent channel (scent cartridge) status in the scent module.

Name	Literals	Value	Description
	-	-	
	Off	0x0	
	Channel_1	0x1	
	Channel_2	0x2	
	Channel_3	0x3	
	Channel_4	0x4	
	Channel_5	0x5	
	Channel_6	0x6	
	Channel_7	0x7	

1.14.12 MD-REQ-377214/A-CabinScentIntensity_St

Message Type: Status

Signal provides the current status of scent level intensity in the scent module.

Name	Literals	Value	Description
	-	-	
	NotDetermined	0x0	

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 14 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	1 3.9 1 1 31 33



Ford Motor Company

Off	0x1	
NotUsed_1	0x2	
Low	0x3	
NotUsed_2	0x4	
Medium	0x5	
NotUsed_3	0x6	
High	0x7	

1.14.13 MD-REQ-466740/A-RSeatSetSave_Rq

Message Type: Request

Signal requests the selection to save seat settings if changed.

Name	Literals	Value	Description
	-	-	
	No	0x0	
	Yes	0x1	

1.14.14 MD-REQ-488637/A-RSeatMovement_Rq

Message Type: Request

This signal shall be sent by the RJVServer to have seat movement On/Off

Name	Literals	Value	Description
RSeatMovement_Rq	-	-	Feature status
	Off	0x0	
	On	0x1	

1.15 RJV-IIR-REQ-413908/C-RJV Server_Rx

1.15.1 MD-REQ-437980/A-RClimt_St

Message Type: Status

This is feature climate status signal received by RJVServer

Name	Literals	Value	Description
RClimt St	-	-	Feature climate status
	Off	0x0	
	On	0x1	

1.15.2 MD-REQ-437981/A-RClimtOvrrd_St

Message Type: Status

This is feature climate overridden status signal received by RJVServer

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 15 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	1 age 13 01 00



Name	Literals	Value	Description
RClimtOvrrd_St	-	-	Feature climate overridden status
	Active	0x0	
	Overridden	0x1	
	Not used	0x2	
	Faulty	0x3	

1.15.3 MD-REQ-437982/A-RSeatOvrrd_St

Message Type: Status
This is feature seat climate overridden status signal received by RJVServer

Name	Literals	Value	Description
RSeatOvrrd_St	-	-	Feature seat climate overridden status
	Active	0x0	
	Overridden	0x1	
	Not used	0x2	
	Faulty	0x3	

1.15.4 MD-REQ-437983/B-RClimtOvrrd_St

Message Type: Status

This is feature climate overridden type signal received by RJVServer

Name	Literals	Value	Description
RClimtOvrdTyp_St	-	-	Feature climate
			overridden type
	NoOverrides	0x0	
	Climate Power Off	0x1	
	Blower Changes	0x2	
	Auto Selected	0x3	
	Temperature	0x4	
	Mode Changes	0x5	
	Recirc Changes	0x6	
	Seat Climate	0x7	
	EM Register	0x8	
	Not used	0x9 – 0xE	
	Faulty	0xF	

1.15.5 MD-REQ-403324/A-GearPosition_St

Message Type: Status

This signal is used to indicate the gear position status

Name	Literals	Value	Description
GearPosition_St	-	-	Status of the vehicle Gear Position
	Park	0x0	
	Reverse	0x1	
	Neutral	0x2	

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 16 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	



Drive	0x3	
Sport_DriveSport_ Mposition	0x4	
Low	0x5	
Range1_M1_L1	0x6	
Range2_M2_L2	0x7	
Range3_M3_L3	0x8	
Range4	0x9	
Range5	0xA	
Range6	0xB	
NotUsed_1	0xC	
NotUsed_2	0xD	
Unknown_Position	0xE	
Fault	0xF	

1.15.6 MD-REQ-273750/A-Ignition_Status

Message Type: Status

Signal sent to the infotainment system indicating the ignition status of the vehicle

Logical Signal Name	Literals	Value	Description
Ignition_Status	Unknown	0x0	
	OFF	0x1	
	Accessory	0x2	
	Run	0x4	
	Start	0x8	
	Invalid	0xF	

1.15.7 MD-REQ-273497/A-DriverDoorStatus

Message Type: Status

Signal to indicate if the front driver door is closed or ajar.

Logical Signal Name	Literals	Value	Description
DriverDoorStatus	Closed	0x0	
	Ajar	0x1	

1.15.8 MD-REQ-273720/A-PassengerDoorStatus

Message Type: Status

Signal to indicate if the front passenger door is closed or ajar.

Logical Signal Name	Literals	Value	Description
PassengerDoorStatus	Closed	0x0	
	Ajar	0x1	

1.15.9 MD-REQ-372987/A-RearLeftDoorStatus

Message Type: Status

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 17 of 60
,	The information contained in this document is Proprietary to Ford Motor Company.	. ago ., o, oo



Signal to indicate if the Rear Left Door is closed or ajar.

Logical Signal Name	Literals	Value	Description
RearLeftDoorStatus /	Closed	0x0	
DrStatRI_B_ActI	Ajar	0x1	

1.15.10 MD-REQ-372988/A-RearRightDoorStatus

Message Type: Status

Signal to indicate if the Rear Right Door is closed or ajar.

Logical Signal Name	Literals	Value	Description
RearRightDoorStatus /	Closed	0x0	
DrStatRr_B_Actl	Ajar	0x1	

1.15.11 MD-REQ-273748/A-Eng_D_Stat

Message Type: Status

Signal indicating the engine status

Logical Signal Name	Literals	Value	Description
Eng_D_Stat	EngOff	0x0	
	EngON	0x1	
	EngAutoStopped	0x2	
	NotUsed	0x3	

1.15.12 MD-REQ-273747/A-PwPckTq_D_Stat

Message Type: Status

Signal sent to the Infotainment System indicating the engine torque status

Logical Signal Name	Literals	Value	Description
PwPckTq_D_Stat	Off Tq Not Available	0x0	
	On Tq Not Available	0x1	
	Strt In Prg No Tq	0x2	
	On Tq Available	0x3	

1.15.13 MD-REQ-524077/A-PwPckTqRdy_B_Dsply

Message Type: Status

Signal indicating to illuminate the Ready Lamp (green car telltale)

Logical Signal Name	Literals	Value	Description
PwPckTqRdy_B_Dsply	Off	0x0	
	On	0x1	

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 18 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	



2 General Requirements

2.1 RJV-REQ-438019/D-Preconditions for Rejuvenate Experience

For RJVServer to process this feature signals and for HMI to provide Rejuvenate screens following preconditions should be met:

1. Vehicle engine is Active, which is determined as follows:

a. For ICE:

Ignition_Status = 0x4 (Run) or 0x8 (Start)

and $Eng_D_Stat = 0x1$ (EngOn)

b. For BEV:

Ignition Status = 0x4 (Run) or 0x8 (Start) or 0x2 (Acc)

c. For PHEV/FHEV:

Ignition_Status = 0x4 (Run) or 0x8 (Start) or 0x2 (Acc)

and PwPckTq_D_Stat = 0x3 (On Tq Available) or PwPckTqRdy_B_Dsply = 0x1 (On)

- 2. Vehicle is in park position, GearPosition_St = 0x0 (Park)
- 3. All doors closed, RJVClient2 shall indicate to RJVServer doors are closed as per following signals:

DriverDoorStatus = 0x0 (Closed)

PassengerDoorStatus = 0x0 (Closed)

RearLeftDoorStatus = 0x0 (Closed)

RearRightDoorStatus = 0x0 (Closed)

Refer HMI specification document (X93_Rejuvenate) for the different states of Rejuvenate that these pre-conditions must be met.

2.2 RJV-REQ-442203/C-Configuration Settings

The RJVServer shall have a configurable parameter to determine whether Rejuvenate feature is supported or not:

- If the parameter indicates the vehicle supports Rejuvenate, then all the functionality and signals defined in this SPSS shall be supported as defined.
- If the parameter indicates the vehicle does not support Rejuvenate, then none of the functionality defined in this SPSS shall be supported.

Fuel type configuration needs to be checked to determine engine running conditions. When Fuel Type parameter in DID DE04 is set to 0x2 (BEV), Engine status shall be set to Active for Ignition Status = 0x2 (Acc) as well.

Refer to Infotainment Diagnostics Specification for config parameter details.

2.3 RJV-REQ-438020/B-HMI requirements for feature

HMI display for this feature is available only when all the preconditions are met.

Further details of how to navigate to the screen, look/naming/placement/accessing of buttons and timing requirements for button presses is covered in HMI specification document (X93_Rejuvenate).

Note: In case of discrepancy in the HMI requirements defined in this spec and HMI specification document the HMI specification document shall take precedence.

2.4 VS-SR-REQ-426847/A-LghtAmbRqSrc B Stat signal usage

The Ambient Lighting Client shall not be set "LghtAmbRqSrc_B_Stat = Auto" unless explicitly called out in a feature SPSS spec (ex Rejuvenate SPSS). All other times the Ambient Lighting Client shall have LghtAmbRqSrc_B_Stat set to Manual. Reference the feature SPSS spec for when "Auto" would be set and when "Manual" would be set.

This requirement is only for the Phoenix PDC Module. At the time this spec was written this was not for other modules that might be the Ambient Lighting Client (ex RACM).



2.5 RJV-REQ-438021/C-Save/Recall Parameters

Driver Seat Positions

Upon entering the "Entry Phase" the RJVClient3 shall read and store the current value for each of the below driver seat positions and recall them Upon entering the "Abort Sequence" or "Exit Phase":

- position (forward/back) on track
- position (up/down) on track
- cushion track fore/aft
- cushion track up/down
- cushion track tilt
- cushion extension left
- cushion extension right
- back recline
- back upper pivot
- back lumbar (mechanical or bladders)
- head rest fore/aft
- head rest up/down
- cushion bolster bladders
- back bolster bladders
- calf raise (up-down)

Audio Parameters

Upon entering the "Entry Phase", the RJVServer shall read and store the current audio source (if no audio or theme audio selected as preferred audio) and recall upon entering the "Abort Sequence" or "Exit Phase".

Climate Parameters

Upon entering the "Entry Phase", the RJVClient1 shall read and store the current settings for climate, including but not limited to set temperature, blower mode, blower speed, etc; and recall them upon entering the "Abort Sequence" or "Exit Phase".

EM Register Parameters

Upon entering the "Entry Phase", the RJVClient1 shall read and store the current settings for the EM Registers including but not limited to set position, etc; and recall them upon entering the "Abort Sequence" or "Exit Phase".

Ambient Light Parameters

Upon entering the "Entry Phase", the RJVClient2 shall read and store the current settings for the Ambient lighting system including but not limited to set color, intensity; and recall them upon entering the "Abort Sequence" or "Exit Phase".

2.6 RJV-REQ-438022/E-Orchestration Schedule

RJVServer shall run a schedule of orchestration which triggers all actions to happen at the appropriate time.

The actions include, but are not limited to:

storing/recalling settings, commanding values for settings, dictating when to display/output imagery/audio.

This schedule is represented in "phases" such as: Entry, Relax, Transition, Invigorate, Exit

Entry Phase

After the user has selected to begin the rejuvenate experience, the rejuvenate feature shall be in the "Entry Phase".

The aim is to prepare the cabin of the vehicle for the rejuvenate experience as defined in "Orchestration with Theme Matrix" document.

During this phase following activities happen:

Current values of different parameters are stored. Refer to Save/Recall parameters section (RJV-REQ-438021-Save/Recall Parameters) for details.

The RJVClient5 shall command that the Steering Wheel/Column are stowed or pushed away from the user.

The desired audio shall be played.

The RJVServer shall display the desired imagery on the main and secondary screen.

The RJVClient2 shall provide the desired Ambient Light experience.

Transition from Entry Phase to Relax Phase

Rejuvenate feature shall transition from "Entry Phase" to "Relax Phase" once the following actions have been completed:

- the "entry display" image/video has been displayed and allowed to play for its duration
- the "entry lighting" light color and intensity have been output via ambient lighting
- the "entry audio" has been output via the vehicle's audio system and allowed to play for its duration

Relax Phase

Upon entering the "Relax Phase" RJVServer shall transmit signal RPhs_St = 0x1 (Relax).

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 20 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	9



The aim of the "Relax Phase" is to make the user feel relaxed.

During this phase rejuvenate feature shall perform following schedule program of activities as defined in "Orchestration with Theme Matrix" document for "Relax Phase":

The RJVClient3 shall adjust the Driver Seat Position. The user can adjust Seat Position via manual controls as well.

The RJVClient1 shall provide the desired Seat Climate, Climate and EM Registers experience.

The RJVClient6 shall provide the desired Seat Massage experience.

The desired audio shall be played.

The RJVServer shall display the desired imagery on the main and secondary screen.

The RJVServer shall provide the desired Ambient Light experience.

Transition from Relax Phase to Transition Phase

Rejuvenate feature shall switch from "Relax Phase" to "Transition Phase" once the "Relax Phase" has been allowed to run through its scheduled program which has been defined in "Orchestration with Theme Matrix" document.

Transition Phase

The aim of the "Transition Phase" is to alert the user to the upcoming changes which will be part of the "Invigorate Phase". During this phase rejuvenate feature shall perform following schedule program of activities as defined in "Orchestration with Theme Matrix" document for "Transition Phase":

The RJVClient3 shall adjust the Driver Seat Position.

The RJVClient6 shall make adjustments to the Seat Massage settings.

The desired audio shall be played.

The RJVServer shall display the desired imagery on the main and secondary screen.

The RJVServer shall provide the desired Ambient Light experience.

Transition from Transition Phase to Invigorate Phase

Rejuvenate feature shall switch from "Transition Phase" to "Invigorate Phase" once the "Transition Phase" has been allowed to run through its scheduled program which has been defined in "Orchestration with Theme Matrix" document.

Invigorate Phase

Upon entering the "Invigorate Phase" RJVServer shall transmit signal RPhs_St = 0x2 (Invigorate).

The aim of this phase is to make the user feel Invigorated.

During this phase rejuvenate feature shall perform following schedule program of activities as defined in "Orchestration with Theme Matrix" document for "Invigorate Phase":

The RJVClient3 shall adjust the Driver Seat Position. The user can adjust Seat Position via manual controls as well.

The RJVClient1 shall provide the desired Seat Climate, Climate and EM Registers experience.

The RJVClient6 shall provide the desired Seat Massage experience.

The desired audio shall be played.

The RJVServer shall display the desired imagery on the main and secondary screen.

The RJVServer shall provide the desired Ambient Light experience.

Transition from Invigorate Phase to Exit Phase

Rejuvenate feature shall switch from "Invigorate Phase" to "Exit Phase" once the "Invigorate Phase" has been allowed to run through its scheduled program which has been defined in "Orchestration with Theme Matrix" document.

Exit Phase

Upon entering the "Exit Phase" RJVServer shall transmit signals RPhs_St = 0x3 (Exit) and RActv_St = 0x0 (Inactive).

The aim of this phase is to return the cabin of the vehicle to the conditions that it was in before the rejuvenate experience as defined in "Orchestration with Theme Matrix" document.

During this phase following activities happen:

The stored values of different parameters are recalled. Refer to Save/Recall parameters section (RJV-REQ-438021-

Save/Recall Parameters) for details

The RJVClient5 shall recall the steering wheel position.

The preview audio shall be played when "Exit Phase" completes until user exits to home screen.

The RJVServer shall display the desired imagery on the main and secondary screen.

The RJVClient2 shall provide the desired Ambient Light experience.

2.7 RJV-REQ-516560/B-Personalization Settings Default

Orchestration shall define the defaults for all the personalization settings in the "Orchestration with Theme Matrix" document. For all the Rejuvenate Personalization settings the default shall be overwritten if changed by the user. The last selection shall be remembered by RJVServer and shall be persisted in the next session of Rejuvenate for the current profile user. Refer to "Enhanced Memory InterfaceClient SPSS" for the details of saved settings.



3 Functional Definition

3.1 RJV-FUN-REQ-413910/A-Update Theme

3.1.1 Requirements

3.1.1.1 RJV-REQ-438023/A-Update Theme

Rejuvenate theme content can be modified via OTA. When available and command is sent to vehicle and if vehicle has active cellular data connection the rejuvenate feature shall be able to receive an OTA package that can replace the existing content of a theme with different and/or updated content.

3.1.2 Use Cases

3.1.2.1 RJV-UC-REQ-438005/A-Update Theme

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON.
	RJVServer is active.
	The vehicle has a cellular or wifi connection and is ready for OTA.
Scenario	OEM will push theme content out to the vehicle.
Description	
Post-conditions	The pushed content package will replace the stored content in the appropriate locations. The next time that the user enters the rejuvenate HMI, the theme changes will be reflected.
List of Exception Use Cases	
Interfaces	HMI, CAN

3.2 RJV-FUN-REQ-438064/A-Settings Selection

3.2.1 Requirements

3.2.1.1 RJV-REQ-438024/A-Theme Selection

RJVServer shall allow user to select the theme for rejuvenate experience from available options by pressing "Theme" button on HMI before starting rejuvenate experience.

Once the theme is selected RJVServer shall transmit signal RThemSel_St = 0x1 through 0xF associated to the selected theme.

For any given theme RJVServer shall set associated Audio, Video, Scent, Ambient lighting/brightness.

3.2.1.2 RJV-REQ-438025/A-Time Selection

RJVServer shall allow user to select the time for rejuvenate experience from available options by pressing "Time" button on HMI before starting rejuvenate experience.

Once rejuvenate experience starts it will run through all the phases for selected time.

FILE: REJUVENATE SPSS V	1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 22 of 60
TIEET REDUCENATE OF GO			r age 22 01 00
	The	information contained in this document is Proprietary to Ford Motor Company.	



3.2.1.3 RJV-REQ-438026/B-Heated Seat Selection

RJVServer shall allow user to select if heated seat is turned On or Off by pressing "Heated Seat" button on HMI before starting rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall transmit signal:

RSeatHeat_Rq = 0x1 (On) if user toggles "Heated Seat" button to ON

RSeatHeat_Rq = 0x0 (Off) if user toggles "Heated Seat" button to OFF

Upon receiving this signal RJVClient1 shall set the climate parameters accordingly.

If selection is made while rejuvenate session is in progress, RJVClient1 shall make changes as needed and applicable for rest of the experience.

3.2.1.4 RJV-REQ-438027/B-Cooled Seat Selection

RJVServer shall allow user to select if cooled seat is turned On or Off by pressing "Cooled Seat" button on HMI before starting rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall transmit signal:

RSeatCool_Rq = 0x1 (On) if user toggles "Cooled Seat" button to ON

RSeatCool Rg = 0x0 (Off) if user toggles "Cooled Seat" button to OFF

Upon receiving this signal RJVClient1 shall set the climate parameters accordingly.

If selection is made while rejuvenate session is in progress, RJVClient1 shall make changes as needed and applicable for rest of the experience.

3.2.1.5 RJV-REQ-438028/B-Digital Scent Selection

RJVServer shall allow user to select any digital scent option or no scent from "Digital Scent" menu in personalization screen before starting rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall send internal signal to DigitalScentClient:

Rejuvenate Status = 0x1 (Feature Active) if user selects any of the scent options and rejuvenate is active

Rejuvenate Status = 0x0 (Feature Not Active) if user selects No Scent

3.2.1.6 RJV-REQ-438029/A-Seat Massage Selection

RJVServer shall allow user to select if seat massage is turned On or Off by pressing "Seat Massage" button on HMI before starting rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall transmit signal:

RSeatMassage Rq = 0x7 (CushionMassage) if user toggles "Seat Massage" button to ON

RSeatMassage_Rq = 0x2 (MiddleLumbar) if user toggles "Seat Massage" button to OFF

Upon receiving this signal RJVClient6 shall set the seat massage parameters accordingly.

If selection is made while rejuvenate session is in progress, RJVClient6 shall make changes as needed for rest of the experience.

3.2.1.7 RJV-REQ-438030/C-Audio Selection

RJVServer shall allow user to select Theme Audio or Source Audio or No Audio from the "Audio" menu in personalization screen before stating rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall set:

AudioStreaming: If user selected Theme Audio or Source Audio

NoAudioStreaming; If user selected No Audio

If selection is made while rejuvenate session is in progress, the changes shall be made for rest of the experience.

Audio Options are "Grayed Out" when Phone call or other High Priority audio (ex. VR session) is active, and user cannot change audio selection at this time.

3.2.1.8 RJV-REQ-438031/B-Do Not Disturb Selection

RJVServer shall allow user to select if Do Not Disturb is turned On or Off by pressing "Do Not Disturb" button on HMI before starting rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall send internal signal to AudioResourceServer:

Rejuvenate DND = On If user toggles "Do Not Disturb" button ON

Rejuvenate DND = Off If user toggles "Do Not Disturb" button OFF

Upon receiving this signal AudioResourceServer shall set Do Not Disturb On or Not accordingly.

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 23 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	g



If selection is made while rejuvenate session is in progress, AudioResourceServer shall make changes as needed for rest of the experience.

3.2.1.9 RJV-REQ-488657/A-Seat Movement Selection

RJVServer shall allow user to select if seat movement is turned On or Off by pressing "Seat Movement" button on HMI before starting rejuvenate experience or alter selection while rejuvenate session is in progress.

RJVServer shall transmit signal:

RSeatMovement_Rq = 0x1 (On) if user toggles "Seat Movement" button to ON

RSeatMovement_Rq = 0x0 (Off) if user toggles "Seat Movement" button to OFF

Upon receiving this signal RJVClient3 shall set the seat movement parameters accordingly.

If selection is made while rejuvenate session is in progress, RJVClient3 shall make changes as needed for rest of the experience.

3.2.2 Use Cases

3.2.2.1 RJV-UC-REQ-438006/A-Theme selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is Active. Vehicle is in park position.
Scenario	User selects required theme on HMI.
Description	
Post-conditions	When rejuvenate experience starts the selected theme is displayed.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.2.2.2 RJV-UC-REQ-438007/A-Time selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active. Vehicle is in park position.
Scenario Description	User selects required time on HMI.
Post-conditions	When rejuvenate experience starts it will be available for selected time.
List of Exception Use Cases	

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 24 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	1



Ford Motor Company

Interfaces	HMI, CAN

3.2.2.3 RJV-UC-REQ-438008/A-Heated Seat Selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active. Vehicle is in park position.
Scenario Description	User makes required selection for heated seat on HMI.
Post-conditions	User experiences rejuvenate as per the heated seat selection.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.2.2.4 RJV-UC-REQ-438009/A-Cooled Seat Selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active.
Scenario Description	Vehicle is in park position. User makes required selection for cooled seat on HMI.
Post-conditions	User experiences rejuvenate as per the cooled seat selection.
List of Exception Use Cases	
Interfaces	HMI, CAN

3.2.2.5 RJV-UC-REQ-438010/A-Digital Scent Selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active.

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 25 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	190 = 0 00



	RJVServer_screen is ON. All doors are closed. Vehicle engine is active. Vehicle is in park position.
Scenario	User makes required selection for scent on HMI.
Description	
Post-conditions	User experiences rejuvenate with or without scent as per selection.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.2.2.6 RJV-UC-REQ-438011/A-Seat Massage Selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active. Vehicle is in park position.
Scenario Description	User makes required selection for seat massage on HMI.
Post-conditions	User experiences rejuvenate as per the seat massage selection.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.2.2.7 RJV-UC-REQ-438012/A-Audio Selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON.
	RJVServer is active.
	RJVServer_screen is ON.
	All doors are closed.
	Vehicle engine is active.
	Vehicle is in park position.
Scenario	User makes required selection for Audio on HMI.
Description	
Post-conditions	User experiences rejuvenate with or without Audio as per selection.
List of Exception	
Use Cases	

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 26 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	1 3.9 = 2 2. 22





Ford Motor Company

Interfaces	HMI, CAN

3.2.2.8 RJV-UC-REQ-438013/A-Do Not Disturb Selection

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active. Vehicle is in park position.
Scenario Description	User makes required selection for Do Not Disturb on HMI.
Post-conditions	User experiences rejuvenate as per the Do Not Disturb selection.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.2.2.9 RJV-UC-REQ-488658/A-Seat Movement Selection


Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active.
	Vehicle is in park position.
Scenario	User makes required selection for seat movement on HMI.
Description	
Post-conditions	User experiences rejuvenate as per the seat movement selection.
List of Exception	
Use Cases	
Interfaces	HMI, CAN



3.2.3 White Box Views


3.2.3.1 Activity Diagrams

3.2.3.1.1 RJV-ACT-REQ-441918/A-Theme Selection






3.2.3.1.2 RJV-ACT-REQ-441921/A-Time Selection




3.2.3.1.3 RJV-ACT-REQ-441923/A-Heated Seat Selection






3.2.3.1.4 RJV-ACT-REQ-441925/A-Cooled Seat Selection




3.2.3.1.5 RJV-ACT-REQ-441927/A-Digital Scent Selection






3.2.3.1.6 RJV-ACT-REQ-441929/A-Seat Massage Selection




3.2.3.1.7 RJV-ACT-REQ-441837/A-Audio Selection






3.2.3.1.8 RJV-ACT-REQ-516797/A-Audio Toggle While Rejuvenate Active




3.2.3.1.9 RJV-ACT-REQ-441931/B-Do Not Disturb Selection






3.2.3.1.10 RJV-ACT-REQ-488659/A-Seat Movement Selection




3.2.3.2 Sequence Diagrams

3.2.3.2.1 RJV-SD-REQ-441920/A-Theme Selection






3.2.3.2.2 RJV-SD-REQ-441922/A-Time Selection






3.2.3.2.3 RJV-SD-REQ-441924/A-Heated Seat Selection




Ford

3.2.3.2.4 RJV-SD-REQ-441926/A-Cooled Seat Selection






3.2.3.2.5 RJV-SD-REQ-441928/A-Digital Scent Selection




3.2.3.2.6 RJV-SD-REQ-441930/B-Seat Massage Selection





3.2.3.2.7 RJV-SD-REQ-441838/A-Audio Selection






3.2.3.2.8 RJV-SD-REQ-516798/A-Audio Toggle While Rejuvenate Active






3.2.3.2.9 RJV-SD-REQ-441933/B-Do Not Disturb Selection



Ford Motor Compa

3.2.3.2.10 RJV-SD-REQ-488660/A-Seat Movement Selection



3.3 RJV-FUN-REQ-438067/A-Start Rejuvenate Experience

3.3.1 Requirements

3.3.1.1 RJV-REQ-438032/E-Start Rejuvenate Experience

If preconditions are met RJVServer shall allow user to start rejuvenate experience by pressing "Start experience" button on HMI.

User can make selections or keep default value for the following settings before pressing "Start Experience" button:

Theme

Time

Heated seat

Cooled seat

Digital scent

Seat massage

Audio



Do Not Disturb Seat movement

Once user enters Rejuvenate Home screen RJVServer shall:

If Theme Audio or No Audio is the preferred Audio Selection: Request current Audio Source from AudioResourceServer to store as pre-rejuvenate parameter and send internal signal to AudioResourceServer and MSSApplicationServer (if MSS feature supported) to set Audio Source type to Rejuvenate Audio and to set the vehicleAudioMode to Cabin.

If System Audio is the preferred Audio Selection: Request to set the vehicleAudioMode to Cabin.

If Phone call or other High Priority audio (ex. VR session) is active then audio options are "Grayed Out" and the last selected audio is applicable. At this point if Theme Audio or System Audio is the preference then audio shall not play until the active phone call or other High Priority audio (ex. VR session) becomes inactive.

If user prefers not to start Rejuvenate experience and exits Rejuvenate Home screen it shall follow the sequence of Exit Rejuvenate for Audio alone (refer RJV-FUN-REQ-438068-End Rejuvenate Experience).

After user presses "start experience" on HMI, RJVServer shall transmit signal RActv_St = 0x1 (Active).

Upon receiving RActv_St = 0x1 (Active), RJVClient1 shall transmit signal RClimt_St = 0x1 (On) to indicate that climate strategy can initiate.

Upon receiving RClimt_St = 0x1 (On), RJVServer shall transmit signals:

LghtAmbRqSrc B Stat = 0x1 (Auto)

Rejuvenate Status = 0x1 (Feature Active) internal signal to DigitalScentClient if digital scent was requested to be turned On Rejuvenate Status = 0x0 (Feature Not Active) internal signal to DigitalScentClient if digital scent was requested to be turned Off

"AudioStreaming" if Theme Audio or System Audio selected

"NoAudioStreaming" if No Audio Selected

After 10 seconds of receiving RClimt_St = 0x1 (On), RJVServer shall transmit signal:

RSeatMassage_Rq = 0x7 (CushionMassage) if user selected "Seat Massage" ON

RSeatMassage Rg = 0x2 (MiddleLumbar) if user selected "Seat Massage" OFF

Incase if RJVClient1 transmits RClimat_St = 0x0 (Off) when RActv_St = 0x1 (Active) after "start experience" button pressed, the rejuvenate experience shall not begin and "Unable to launce Rejuvenate at this time, please try again" message is displayed on HMI.

Incase if RJVClient1 transmits RClimat_St = 0x0 (Off) while rejuvenate experience is on it shall abort the experience.

At the beginning of rejuvenate experience (Entry Phase) vehicle parameters are saved as defined in Save/Recall Parameters section (RJV-REQ-43802-Save/Recall Parameters).

Once Rejuvenate is active and Digital Scent settings is ON with any scent selection following signals will be used to control the Digital Scent feature:

CabinScentMode St

CabinScentIntensity St

CabinScentChannel_St

See "Orchestration with Theme Matrix" document for details.

Once Rejuvenate is active following signals will be used for Ambient Lighting:

LightAmbIntsty_No_Rq

LightAmbColor_No_Rq

See "Orchestration with Theme Matrix" document for details.

For Rejuvenate Audio following signals shall be used:



AudioStatus_St(SourceType = Aux_Media, Status = Granted, VehicleAudioMode = Cabin) AudioStreaming/NoAudioStreaming depending on Audio Selected/Not Selected.

3.3.2 Use Cases


3.3.2.1 RJV-UC-REQ-438014/B-Start Rejuvenate Experience

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. All doors are closed. Vehicle engine is active. Vehicle is in park position.
Scenario Description	User presses "Start Experience" soft button on the HMI.
Post-conditions	Rejuvenate experience begins.
List of Exception Use Cases	
Interfaces	HMI, CAN

3.3.3 White Box Views


3.3.3.1 Activity Diagrams

3.3.3.1.1 RJV-ACT-REQ-441934/B-Start Rejuvenate



3.3.3.1.2 RJV-ACT-REQ-466685/C-Start Rejuvenate_Audio Sequence









3.3.3.2 Sequence Diagrams

3.3.3.2.1 RJV-SD-REQ-441935/C-Start Rejuvenate





3.3.3.2.2 RJV-SD-REQ-466688/C-Start Rejuvenate_Audio Sequence



3.4 RJV-FUN-REQ-438068/A-End Rejuvenate Experience

3.4.1 Requirements

3.4.1.1 RJV-REQ-438033/D-End Rejuvenate Experience

After rejuvenate time expires the rejuvenate experience shall be ended. RJVServer shall send signals: RActv_St = 0x0 (In-Active)

LghtAmbRqSrc_B_Stat = 0x0 (Manual)

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 47 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	



Rejuvenate Status = 0x0 (Feature Not Active) internal signal to DigitalScentClient

When Rejuvenate ends HMI shall go back to Rejuvenate Home screen and preview audio/video shall play.

When user exits Rejuvenate Home screen:

RJVServer shall send internal signal to AudioResourceServer to restore Audio Source type to pre-rejuvenate value (In case of Theme Audio or No Audio Option).

Once the rejuvenate experience ends, the cabin of the vehicle except audio/video shall go to the conditions that it was in before the rejuvenate experience, audio/video shall go back to pre-rejuvenate condition only when user exits Rejuvenate Home screen. Refer section Save/Recall Parameters for details (RJV-REQ-438021-Save/Recall Parameters).

3.4.2 Use Cases

3.4.2.1 RJV-UC-REQ-438015/B-End Rejuvenate Experience


Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario	The time selected for rejuvenate experience elapsed and all the phases of
Description	orchestration is complete as selected.
Post-conditions	The cabin of the vehicle except audio/video shall go to the conditions that it was in before the rejuvenate experience. The audio/video shall go back to pre-rejuvenate condition after user exits Rejuvenate Home screen.
List of Exception	
Use Cases	
Interfaces	HMI, CAN



3.4.3 White Box Views

3.4.3.1 Activity Diagrams


3.4.3.1.1 RJV-ACT-REQ-441936/D-End Rejuvenate





3.4.3.2 Sequence Diagrams

3.4.3.2.1 RJV-SD-REQ-441937/D-End Rejuvenate





3.5 RJV-FUN-REQ-438069/A-Alter Rejuvenate Experience

3.5.1 Requirements

3.5.1.1 RJV-REQ-438034/C-Alter Rejuvenate Experience

While rejuvenate experience is underway RJVServer shall allow user to alter any of the following settings:

Heated seats

Cooled seats

Digital scent

Seat massage

Audio

Do Not Disturb

Seat movement

Upon changing the setting the experience will alter and remain at new selection for reminder of the time.

Note: Audio options are "Grayed Out" and cannot be altered while Phone call or other High Priority audio (ex. VR session) is active.

3.5.1.2 RJV-REQ-466742/A-Save Altered Seat Position

While Rejuvenate experience is underway user can change the seat position manually.

At end of the relax phase and at end of the invigorate phase there will be message pop-up for user to save the seat settings so that it will be remembered as desired position for next time during that phase.

If user selects to save the changes, RJVServer shall transmit signal RSeatSetSave_Rq = 0x1 (Yes) to RJVClient3. RJVClient3 shall then save the seat settings.

If user selects to not to save the changes, RJVServer shall transmit signal RSeatSetSave_Rq = 0x0 (No) to RJVClient3. RJVClient3 shall not save the seat settings.

3.5.2 Use Cases

3.5.2.1 RJV-UC-REQ-438016/C-Alter Rejuvenate Experience

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario	The user selects to alter one of the rejuvenate settings (heated seats on/off,
Description	cooled seats on/off, seat massage on/off, digital scent, audio, do not disturb
	On/Off, seat movement On/Off) on the HMI screen.
Post-conditions	The changed settings/features will be reflected throughout the rest of the experience.
	The changed setting/feature preferences will be remembered upon next entry into the Rejuvenate HMI.

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 51 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	l agoon or oo



List of Exception Use Cases	
Interfaces	HMI, CAN

3.5.2.2 RJV-UC-REQ-466744/A-Save Altered Seat Position

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario Description	The user changes the seat settings. At end of the relax phase and at end of the invigorate phase RJVServer shall display options to save the seat settings. User can select to save the changes or discard the changes.
Post-conditions	If user selects to save the changes that will be reflected next time experience is On.
List of Exception Use Cases	
Interfaces	HMI, CAN

RJV-FUN-REQ-438070/B-Abort Experience

3.6.1 Requirements

3.6.1.1 RJV-REQ-438035/D-Abort Definition

When rejuvenate experience is aborted either by pressing soft button or exiting pre-condition or any system UI feature outside climate selected on HMI (ex. App menu or Hone screen) or if climate system becomes unavailable for rejuvenate, the expectation is to return the cabin of the vehicle to the conditions that it was in before the Rejuvenate Experience as guickly as possible. Refer section Save/Recall Parameters (RJV-REQ-438021-Save/Recall Parameters) for details.

The main activities of the "Abort Sequence" are:

- 1. To turn off associated audio/video/lighting associated with the Rejuvenate experience.
- 2. To recall the settings/parameters for all items which were stored at the beginning of the experience.

Upon detecting that rejuvenate shall be aborted RJVServer shall transmit signals:

 $RPhs_St = 0x4$ (Abort), if aborted by pressing soft button

 $RActv_St = 0x0 (In-Active)$

LghtAmbRqSrc B Stat = 0x0 (Manual)

Rejuvenate Status = 0x0 (Feature Not Active), internal signal to DigitalScentClient

When Rejuvenate aborts HMI shall go back to Rejuvenate preview screen.

After Rejuvenate is aborted, preview audio/video shall play until user has not exited out of Rejuvenate Home screen.

FILE: REJUVENATE SPSS v1.4 OCT 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 52 of 60
·	The information contained in this document is Proprietary to Ford Motor Company.	. ug = = = = = =



3.6.1.2 RJV-REQ-438036/B-Abort - Soft Button

When user presses "Abort" button on HMI during any time of rejuvenate experience. RJVServer shall send RPhs_St = 0x4 (Abort) and abort the sequence.

3.6.1.3 RJV-REQ-438037/E-Abort - Exit Precondition

When any of the following events occur:

- 1. GearPosition_St ≠ 0x0 (Park); vehicle gear out of park.
- 2. Vehicle engine ≠ Active; engine turned off (Refer RJV-REQ-438019-Preconditions for Rejuvenate Experience for vehicle engine = Active condition).
- 3. Doors open; RJVClient2 shall indicate to RJVServer one or more doors are open as per following signals:

DriverDoorStatus = 0x1 (Ajar)

PassengerDoorStatus = 0x1 (Ajar)

RearLeftDoorStatus = 0x1 (Ajar)

RearRightDoorStatus = 0x1 (Ajar)

The rejuvenate experience shall abort immediately.

3.6.1.4 RJV-REQ-516970/A-Abort - Vehicle Controls other than Climate selected on HMI

If user selects any vehicle controls setting other than climate, it shall exit the rejuvenate screen and shall abort the rejuvenate experience. RJVServer shall send RPhs_St = 0x4 (Abort) and abort the sequence.

3.6.1.5 RJV-REQ-470267/B-Abort - Climate System Unavailable For Rejuvenate

If for any reason Climate system cannot support rejuvenate and RJVClient1 transmits signal RClimt_St = 0x0 (Off), it shall abort the rejuvenate experience. RJVServer shall send RPhs_St = 0x4 (Abort) and abort the sequence.

There will be message pop-up for user on HMI indicating that Rejuvenate aborted due to climate system being unavailable.

3.6.2 Use Cases

3.6.2.1 RJV-UC-REQ-438017/A-Abort - Soft Button

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario Description	User presses "End Experience" soft button on the HMI.
Post-conditions	Rejuvenate experience has been ended prematurely. The user is returned to the same conditions (seat settings, light settings, etc) as they were in, before the experience.
List of Exception Use Cases	
Interfaces	HMI, CAN

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 53 of 60
	The information contained in this document is Proprietary to Ford Motor Company.	. aga aa a a



3.6.2.2 RJV-UC-REQ-438018/C-Abort - Exit Precondition

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario	User does one or more of the following due to which vehicle doesn't meet
Description	preconditions for rejuvenate experience:
	Opens doors
	Puts vehicle gear out of park
	Engine not active
Post-conditions	Rejuvenate experience has been ended prematurely.
	The user is returned to the same conditions (seat settings, light settings, etc) as
	they were in, before the experience.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.6.2.3 RJV-UC-REQ-516971/A-Abort - Vehicle Controls other than Climate selected on HMI

Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario	User selects any vehicle controls setting other than climate.
Description	
Post-conditions	Rejuvenate experience has been ended prematurely. The user is returned to the same conditions (seat settings, light settings, etc) as they were in, before the experience.
	they were in, before the experience.
List of Exception	
Use Cases	
Interfaces	HMI, CAN

3.6.3 White Box Views

3.6.3.1 Activity Diagrams

3.6.3.1.1 RJV-ACT-REQ-441999/D-Abort Rejuvenate

FILE: REJUVENATE SPSS v1.4 Oct 7, 2022	FORD MOTOR COMPANY CONFIDENTIAL	Page 54 of 60
11EE: RESOVERATE OF GO V1:4 GCT 7, 2022		Page 34 01 00
	The information contained in this document is Proprietary to Ford Motor Company.	3
	The information contained in the december to Frequency to Ford wictor company.	



Refer End Rejuvenate Activity Diagram (RJV-ACT-REQ-441936-End Rejuvenate)

3.6.3.2 Sequence Diagrams

3.6.3.2.1 RJV-SD-REQ-442000/D-Abort Rejuvenate

Refer End Rejuvenate Sequence Diagram (RJV-SD-REQ-441937-End Rejuvenate)

3.7 RJV-FUN-REQ-517009/A-Audio Interruption While Rejuvenate Active

3.7.1 Requirements

3.7.1.1 RJV-REQ-516984/A-Audio Interruption While Rejuvenate Active

While Rejuvenate experience is active if user accepts Phone Call or if any other high priority (ex. VR session) audio is requested, it shall overwrite the Rejuvenate Audio. The Rejuvenate experience except Audio shall continue as is.

When this audio interruption ends the following paths are possible:

- 1. Rejuvenate is still Active: In this case the Rejuvenate Audio shall resume to play as per Orchestration.
- 2. Active Rejuvenate session is Ended/Aborted but Rejuvenate Home screen not exited: In this case the Rejuvenate Audio shall play for the Preview Mode.
- 3. Active Rejuvenate session is Ended/Aborted and Rejuvenate Home screen is exited: In this case the Pre-Rejuvenate source shall be recalled after the active Phone Call / High Priority Audio session ends.

3.7.2 Use Cases

3.7.2.1 RJV-UC-REQ-516986/A-Audio Interruption While Rejuvenate Active


Actors	User, RJVServer
Pre-conditions	Infotainment system is powered ON. RJVServer is active. RJVServer_screen is ON. Rejuvenate experience is ON.
Scenario	User presses "Accept Phone Call" button on the HMI when phone call received,
Description	or other high priority audio requested.
Post-conditions	Rejuvenate Audio shall be overwritten. Rejuvenate experience except audio shall continue as it was.
List of Exception	
Use Cases	
Interfaces	HMI, CAN



3.7.3 White Box Views

3.7.3.1 Activity Diagrams


3.7.3.1.1 RJV-ACT-REQ-516987/A-Audio Interruption While Rejuvenate Active





3.7.3.2 Sequence Diagrams

3.7.3.2.1 RJV-SD-REQ-516988/A-Audio Interruption While Rejuvenate Active





3.8 RJV-FUN-REQ-466751/A-Rejuvenate Data Analytics

3.8.1 Requirements

3.8.1.1 RJV-REQ-466745/B-Record and Store Data While Rejuvenate Active

RJVServer shall provide data analytic services in support of the Rejuvenate feature. Services shall include monitoring and data recording of the subsequent signals or internal values to RJVServer software as defined here for further processing and analysis by the Rejuvenate Dashboard/API.

Upon activation of Rejuvenate feature which shall be detected when RActv_St signal transitions from Inactive to Active, RJVServer shall record and store the following data elements independently and in association with their accompanying UTC timestamp:

1. Rejuvenate settings:

- Rejuvenate Theme as per RThemSel_St value
- Heated Seat Status ON or OFF as per RSeatHeat_Rq = 0x1 (On) or 0x0 (OFF)
- Cooled Seat Status ON or OFF as per RSeatCool Rg = 0x1 (On) or 0x0 (OFF)
- Massage Setting Status ON or OFF as per RSeatMassage_Rq = 0x7 (CushionMassage) for ON or 0x2 (MiddleLumbar) for OFF
- Cabin Scent Status ON or OFF as per Rejuvenate Status = 0x1 (Feature Active) or 0x0 (Feature Not Active)
- Meditation Audio Setting ON or OFF
- Selected Length of Rejuvenation Experience
- Changed Audio Track "System Audio" is selected at beginning of experience or while experience is ON

2. Other Data:

- UTC time from LocationServices_1 message
- Date from LocationServices_1 message
- Vehicle Location from LocationServices 1 message
- Vehicle Cabin Temperature as in CabnAmb Te ActlAft
- Outdoor Temperature transmitted as in Outside Air Temp Stat
- Cabin Mode Status as in CabinScentMode_St
- Cabin Scent Intensity as in CabinScentIntensity_St
- Cabin Scent Selection as in CabinScentChannel St
- Ambient Light Level Litval
- Phone Call Accepted When user accepts incoming phone call BTServer shall send PhoneCall (Active) signal to RJVServer

3.8.1.2 RJV-REQ-466746/A-Record and Store Engine ON time and Data Logging Timer

RJVServer shall record and store the event instance when CAN signal Eng_D_Stat changes state from OFF to ON. RJVServer shall accompany this instance by recording a UTC timestamp of the event.

RJVServer shall maintain a log of total duration between the vehicle's engine ON status and when a user activates the feature Rejuvenate. A change in CAN signal Eng_D_Stat from the state OFF to ON shall indicate the start of a data logging timer; CAN signal RjvntActv_D transitioning from the state INACTIVE to ACTIVE shall indicate the end of such timer. The total duration shall be stored by RJVServer. In the event the user does not use activate Rejuvenate before turning the vehicle off where Eng_D_Stat transitions from ON to OFF, RJVServer shall end the timer and not log any duration.



3.8.1.3 RJV-REQ-466747/A-Record Feature Completed Instances

RJVServer shall maintain a running tally of total completed instances of the feature Rejuvenate. A single instance of Rejuvenate shall be defined as an activation of the feature where the CAN signal RActv_St transitions from the INACTIVE to ACTIVE state and is not aborted.

3.8.1.4 RJV-REQ-466748/A-Record Feature Preview Instances

RJVServer shall maintain and store a running tally of total uses of the feature's preview function. Every instance of a user selecting a Rejuvenate theme's preview and playing it shall increase the tally by one. RJVServer shall identified theme selection as per CAN signal RThemSel_St. RJVServer shall record and store separately a tally for each available theme.

3.8.1.5 RJV-REQ-466749/A-Record Feature Aborted Instances

RJVServer shall maintain a running tally of total aborted instances of the feature Rejuvenate. An aborted instance of Rejuvenate shall be defined as an activation of the feature where the CAN signal RActv_St transitions from the INACTIVE to ACTIVE state but Rejuvenate does not complete all phases or is ended prematurely.

RJVServer shall maintain a log of duration for when users activate Rejuvenate and the feature undergoes an abortion or premature exit of the experience. Whenever a premature exit of Rejuvenate occurs, RJVServer shall record the activity or trigger that causes the premature exit and store this instance along with total duration before abortion.

Please refer section RJV-FUN-REQ-438070-Abort Experience for abort or premature exit triggers.

3.8.1.6 RJV-REQ-466750/B-Record Alterations during Rejuvenate Experience

RJVServer shall monitor the vehicle for customer-initiated setting changes during Rejuvenate's user experience. The following data elements shall be monitored and changes in state or value shall be recorded with an accompanying timestamp:

- Any Climate Setting Changes YES or NO RClimtOvrdTyp St
- Climate Related Setting Changed (Which Climate Setting Changed related to Rejuvenate) RClimtOvrrd_St, RSeatOvrrd_St
- Driver Climate Temperature Setting (User Selected Temperature) Drv_Set_Temp
- Driver Seat Temperature Setting (COOL SETTING 1,2,3 or HEATED SETTING 1,2,3) LHS_Cond_Seat_Status
- Driver AC Blower Setting (INCREASE BLOWER SPEED or DECREASE BLOWER SPEED) Frt_Btn_Status_1st,
 Frt_Btn_Status_2nd
- Seat Motion User manually changes the seat position



4 Appendix: Reference Documents

Reference #	Document Title
1	Orchestration with Theme Matrix document
2	Audio Management Variant 2 SPSS
3	MSS Zone Audio Management APIM_AOS SPSS
4	Bluetooth Connectivity APIM_AOS SPSS
5	Infotainment Diagnostics Specification
6	X93_Rejuvenate
7	Enhanced Memory InterfaceClient SPSS
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	