# Lincoln Embrace / Ford Welcome-Farewell Feature Specification

## Ford Motor Company

This engineering specification stakeholders and reviewers:

Names	CDSID	Role	
Ahmet Cinar	ACINAR1	Technical Specialist - Body Security Restraints	
Anacah Mathai	AMATHAI	Cockpit Control Electrical Application - aHUD	
Aneesh Mathai	AWATHAI	welcome/farewell	
Bob Miller	BMILLE86	Exterior Lighting Electronics Supervisor	
Brad White	BWHIT161	BCM Software – Door Closures	
Dante Williams	DWILL360	Driver Info Upper Body Applications Supervisor	
Dinh Tran	DTRAN39	Infotainment Connectivity Electrical Applications -	
Dinn Tran	DIRANS9	Sync display dimming & day-night pallet	
Dennis Trombly	DTROMB15	Body Module Software Feature Engineer	
Elizabeth Wickey	EWICKEY	Core Ambient Lighting Engineer	
Elton Jamoua	EJAMOUA	D&R Engineer - Approach detection & Illuminated	
Eiton Jamoua	EJAMOUA	Door pockets	
Farhan Ehsan	FEHSAN2	Lincoln Embrace and Ford Welcome/Farewell	
raman Ensan	FERSAN2	Feature Owner	
Fred Butler	FBUTLER9	Upper body Applications UN Supervisor	
James Baker	JBAKE268	Lighting Electrical Engineer	
Jennifer Prescott	JPRESCO2	Feature Champion: I&E Harmony Supervisor	
lim Cramaina	JGREGOIR	Cockpit Control Electrical Application - IPC	
Jim Gregoire	JGREGOIR	welcome/farewell	
John Barrs	JBARRS	BCM Software - Interior and Exterior lighting owner	
John Ricks	JRICKS7	Body and Security Electronics - DCU Software	
Joseph Celani	JCELANI	Lincoln EESE APPS D&R Supervisor	
Laura Burek	LBUREK	Sync 3 Supervisor	
Matt Majkowski	MMAJKOWS	Core Interior Lighting Engineer	
Nicholas Frazier	NFRAZIE4	Infotainment Connectivity Electrical Applications -	
Nicholas Fraziei	NFRAZIE4	Sync Welcome/Farewell displays	
Nimish Patel	NPATEL4	Underbody Application Supervisor	
Paul Linden	PLINDEN6	Body Closures Supervisor	
Roy Sutherland	RSUTHERL	EESE ADAS Climate Switch Engineer	
Scott Watkins	SWATKINS	DI Technical Expert - IPC	
Sean Degennaro	SDEGENN1	Feature Champion: Vehicle Harmony Engineer	
Shormin Talukder	STALUKDE	Global Driver IVI Systems and DV Supervisor	
Stanban England	SENGLAN6	Lighting Electronics Engineer - Exterior	
Stephen England	SENGLANO	Mechantronics	
Stephen Helwig	SHELWIG	Lighting System BOF Supervisor	
Steven Antilla	SANTILLA	Core Interior Lighting Supervisor	
Terrence Wilson	TWILSO32	Unibody Exterior Lighting Supervisor	
Thomas Luckett	TLUCKETT	IP BOF Engineering Supervisor	
William Crafts	WCRAFTS	Core Switches Supervisor	
Wissam Joumaa	WJOUMAA	BCM Core Engineer - Hardware	

## TABLE OF CONTENTS

1	INTRODUCTION	8
	1.1 Purpose	8
	1.2 History	
	1.3 SCOPE	
	1.4 REFERENCE SPECIFICATIONS	
	1.5 SPECIFICATION FORMAT	
	1.5.1 Requirement Numbering	
2		
_		
	2.1 THEORY OF OPERATION	_
	2.2 FEATURE INTERFACE	
	2.3 USE CASE TREE (USE CASES IN APPENDIX 2)	
3	FEATURE REQUIREMENTS	
	3.1 FEATURE LEVEL REQUIREMENTS	
	3.1.1 Feature Classification	
	3.1.2 Feature Requirements	
	3.1.2.1 Feature Enablers	
	3.1.2.2 Welcome/Farewell State Definitions	
	3.1.2.3 Additional Concurrent Features interacting with Welcome/FarewellStates	
	3.1.2.5 Feature Overrides/Inhibits	10
	3.2 QUALITY REQUIREMENTS	
	3.2.1 Reliability Requirements	
	3.2.2 Performance Requirements	
	3.2.2.1 Performance Latency Requirements	
	3.2.3 Safety Requirements	
	3.2.3.1 NAFTA Requirements to abide by (or not violate)	
	3.2.3.2 ECE Requirements to abide by (or not violate)	
	3.2.3.3 China Requirements to abide by (or not violate)	
	3.2.4 Security Requirements	
4	FUNCTIONAL DECOMPOSITION	
	4.1 FUNCTIONAL ARCHITECTURE	
	4.2 LIST OF FUNCTIONS	24
5	FUNCTION REQUIREMENT	26
	5.1 Power Modes of each Function	26
	5.2 WELCOME/FAREWELL STATE DETERMINATION	
	5.2.1 Inputs used for Welcome/Farewell State determination	27
	5.2.2 Welcome/Farewell State determination without Battery Saver tie-in	27
	5.2.3 Welcome/Farewell State determination with Battery Saver tie-in	30
	5.3 EXTERIOR ILLUMINATION RESPONSE BASED ON WELCOME/FAREWELL STATE	
	5.3.1 Exterior Front Illumination Algorithm	
	5.3.1.1 Applicable Welcome Farewell State Transitions	
	5.3.1.2 Control Signal Definitions & Configurability	
	5.3.1.3 Control Signal Value Targets	
	specified behavior for "Front Illumination".	
	5.3.1.5 Additional requirements	
	5.3.1.6 Exterior Front Illumination Algorithm inhibits and overrides	
	5.3.2 Exterior Front Illumination Lighting Response	
	5.3.3 Exterior Rear Illumination Algorithm	
	5.3.3.1 Applicable Welcome Farewell State Transitions	37
	5.3.3.2 Control Signal Definitions & Configurability	37
	5.3.3.3 Control Signal Value Targets	
	5.3.3.4 Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team	
	specified behavior for "Rear Illumination"	38 30

5.3.3.2 Exterior Rear Illumination Algorithm inhibits and overrides	40
5.3.4 Exterior Rear Illumination Lighting Response	
5.3.5 Exterior Supplementary Illumination Algorithm:	41
5.3.5.1 Applicable Welcome Farewell State Transitions	
5.3.5.2 Control Signal Definitions & Configurability	
5.3.5.3 Control Signal Value Targets	41
5.3.5.4 Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team	
specified behavior for "Supplementary Illumination".  5.3.5.5 Additional requirements	
5.3.5.6 Exterior Supplementary Illumination Algorithm inhibits and overrides	
5.3.6 Exterior Supplementary Illumination Lighting Response	
5.4 INTERIOR ILLUMINATION RESPONSE BASED ON WELCOME/FAREWELL STATE	
5.4.1 Courtesy Lamps Illumination Algorithm:	
5.4.1.1 Applicable Welcome Farewell State Transitions	
5.4.1.2 Control Signal Definitions & Configurability	44
5.4.1.3 Control Signal Value Targets	45
5.4.1.4 Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team	
specified behavior for "Courtesy Lamps".	
5.4.1.5 Additional requirements	
5.4.2 Courtesy Lamps Illumination Lighting Response	
5.4.3 Ambient Lighting Illumination Algorithm (without static sequential):	
5.4.3.1 Applicable Welcome Farewell State Transitions	
5.4.3.2 Control Signal Definitions & Configurability	
5.4.3.3 Control Signal Value Targets	
5.4.3.4 Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team	
specified behavior for "Ambient Lighting Illumination"	
5.4.3.5 Additional requirements	
5.4.3.6 Ambient Lighting Illumination Algorithm (without static sequential) inhibits and overrides	
5.4.4 Ambient Lighting Illumination (without Static Sequential) Lighting Response	
5.4.5 Ambient Lighting Illumination Algorithm (with static sequential):	51
5.4.5.1 Applicable Welcome Farewell State Transitions	51
5.4.5.3 Control Signal Value Targets	
5.4.5.4 Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team	<u>0</u> _
specified behavior for "Ambient Lighting Illumination"	
5.4.5.5 Additional requirements	54
5.4.5.5.1 Static Sequential Triggers	54
5.4.5.5.2 Static Sequential "Groups"	
5.4.5.5.3 Static Sequential Definitions & Configurability	
5.4.6 Ambient Lighting Illumination (with Static Sequential) Lighting Response	
5.4.7 Dimmable Backlighting Illumination Algorithm:	
5.4.7.1 "Day-time Dimmable" Backlighting Illumination algorithm:	ined.
5.4.7.1.1 Applicable Welcome Farewell State Transitions	
5.4.7.1.2 Control Signal Definitions & Configurability	
5.4.7.1.3 Control Signal Value Targets	
5.4.7.1.4 Illumination level response based on Welcome/Farewell state transitions and "Vehicle Harmony	
team specified behavior for "Day-time Dimmable Backlighting Illumination" 5.4.7.1.5 Responding to changes in "Exterior Light Level" during Welcome/Farewell State transitions	
"Day-time" to "Night-time"	
"Night-time" to "Day-time"	
5.4.7.1.6 Additional requirements	
5.4.7.1.7 Day-Time Dimmable Backlighting Illumination Algorithm inhibits and overrides	
5.4.7.2 Day-Time Dimmable Backlighting Illumination Response	60
5.4.7.3 "Night-time Dimmable" Backlighting Illumination algorithm:	ined.
5.4.7.3.1 Applicable Welcome Farewell State Transitions	
5.4.7.3.3 Control Signal Value Targets	
5.4.7.3.4 Illumination level response based on Welcome/Farewell state transitions and "Vehicle Harmony	
team specified behavior for "Day-time Dimmable Backlighting Illumination"Error! Bookmark not def	fined.
5.4.7.3.5 Responding to changes in "Exterior Light Level" during Welcome/Farewell State transitions	Error!
Bookmark not defined.	
"Day-time" to "Night-time"	
"Night-time" to "Day-time"	
·	eu.
Page 4 of 175	

	5.4.7.3.7 Night-Time Dimmable Backlighting Illumination Algorithm inhibits and overrides Erro	or! Bookmark
	not defined.	
	5.4.7.4 Night-Time Dimmable Backlighting Illumination Response Error! Bookmark	not defined.
	5.4.7.5 "2-Step Dimmable" Backlighting Illumination algorithm: Error! Bookmark	
	5.4.7.5.1 Applicable Welcome Farewell State Transitions	
	5.4.7.5.2 Control Signal Definitions & Configurability	
	5.4.7.5.3 Control Signal Value Targets	
	5.4.7.5.4 Illumination level response based on Welcome/Farewell state transitions and "Vehicle I	
	team specified behavior for "Day-time Dimmable Backlighting Illumination"Error! Bookmark	
	5.4.7.5.5 Responding to changes in "Exterior Light Level" during Welcome/Farewell State transit	ions Error!
	Bookmark not defined.	
	"Day-time" to "Night-time"Error! Bookmark	
	"Night-time" to "Day-time"Error! Bookmark	
	5.4.7.5.6 Additional requirementsError! Bookmark	
	5.4.7.5.7 2-Step Dimmable Backlighting Illumination Algorithm inhibits and overrides Error! B	ookmark not
	defined.	
	5.4.7.6 2-Step Dimmable Backlighting Illumination Response Error! Bookmark	not defined.
	5.5 VEHICLE COCKPIT DISPLAY(S) RESPONSE BASED ON WELCOME/FAREWELL STATE	61
	5.5.1 Center-stack Welcome/Farewell Displays (Sync Screen):	
	5.5.2 Cluster Welcome/Farewell Displays (TFT/Digital portion):	
	5.5.2.1 Cluster Display Area (TFT/Digital portion):	not defined
	5.5.2.2 Odometer Display:	not defined.
	5.5.3 HUD Welcome/Farewell Displays (aHUD):	
		FAREWELL
	STATE 66	
6	5 FEATURE VARIANT DESIGN ARCHITECTURE	66
Ū		
	6.1 ELECTRICAL ARCHITECTURE – LINCOLN VEHICLES	66
	6.1.1 Electrical Topology	66
	6.1.1.1 Combined Network/Block Diagram	66
	6.1.2 Common Requirements	
	6.1.2.1 Participating ECUs	
	6.1.2.2 Performance and Functional Voltage Ranges	68
	6.1.2.3 Signal Requirements	
	6.1.2.3.1 CAN Signal Requirements	
	6.1.2.3.1 CAN Error Handling for Signal Gateway Messages	76
	6.1.2.3.2 CAN Error Handling for Frame Gateway Messages	
	6.1.2.3.3 LIN Signal Requirements	
	6.1.2.3.4 Linking Logical Data Flows to CAN/LIN Signals	
	6.1.3 Lincoln Vehicle ECU specific requirements	
	6.1.3.1 Body Control Module (BCM)	
	6.1.3.1.1 Over-arching requirements	
	6.1.3.1.2 Support Welcome Farewell State Determination functions	
	6.1.3.1.3 Support Exterior Front Illumination	
	6.1.3.1.4 Support Exterior Rear Illumination	
	6.1.3.1.5 Support Exterior Supplementary Illumination	
	6.1.3.1.6 Support Interior Courtesy Lamps Illumination	84
	6.1.3.1.7 Support Interior Ambient Lighting (with Static Sequential) Illumination	85
	6.1.3.1.8 Support Interior Day-time Dimmable Backlighting Illumination	
	6.1.3.1.9 Support Interior Night-time Dimmable Backlighting Illumination	
	6.1.3.1.10 Support Interior 2-Step Dimmable Backlighting Illumination	
	6.1.3.1.11 Support Vehicle Display Center-stack Day-time Dimmable Illumination for Display Brig	
	6.1.3.1.12 Support Vehicle Display Cluster Day-time Dimmable Illumination for Display Brightnes	
	6.1.3.1.13 Support Vehicle Display aHUD Welcome/Farewell behavior	92
	6.1.3.2 LED Driver Module (LDM) requirements	93
	6.1.3.2.1 Over-arching requirements	93
	6.1.3.2.1 Provide Control Signal to support Front Exterior Illumination	
	6.1.3.3 Rear Fade Control Module (R-FCM) requirements	
	6.1.3.3.1 Over-arching requirements	
	6.1.3.3.2 Provide Control Signal to support Rear Exterior Illumination	
	6.1.3.4 Overhead Console (OHC) requirements	
	6.1.3.4.1 Over-arching requirements	
	6.1.3.4.2 Provide Control Signal to support Courtesy Lamps Illumination	
	6.1.3.5 Ambient Light Module (ALM) requirements	
	6.1.3.5.1 Over-arching requirements	
	6.1.3.5.2 Provide Control Signal to support Ambient Lighting Illumination	
	O. 1. O.O.Z. I TOVIGO CONTROL CIGNAL TO SUPPORT AMDIGNE LIGHTING INTUMINATION	

0.4.0.0 D.: D. M. I.I. (DDM)	
6.1.3.6 Driver Door Module (DDM) requirements	
6.1.3.6.1 Over-arching requirements	
6.1.3.6.2 Provide Control Signal to support Exterior Supplementary Illumination	
6.1.3.6.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	
6.1.3.7 Passenger Door Module (PDM) requirements	
6.1.3.7.1 Over-arching requirements	
6.1.3.7.2 Provide Control Signal to support Exterior Supplementary Illumination	
6.1.3.7.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination	
6.1.3.7.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	
6.1.3.8 Steering Column Control Module (SCCM) requirements	102
6.1.3.8.1 Over-arching requirements	103
6.1.3.8.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination	
6.1.3.9 Terrain Management Switch (TMS) requirements	
6.1.3.9.1 Over-arching requirements	104
6.1.3.10 Front Control Interface Module (FCIMB) requirements	
6.1.3.10.1 Provide Control Signal to support Interior Day-Time Dimmable Backlighting Illumination	
6.1.3.10.2 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination	
6.1.3.10.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	
6.1.3.11 Accessory Protocol Interface Module (APIM/SYNC) requirements	
6.1.3.11.1 Over-arching requirements	107
6.1.3.11.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness	
6.1.3.11.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence	
6.1.3.12 Rear Audio Control Module (RACM) requirements	
6.1.3.12.1 Over-arching requirements	109
6.1.3.12.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness	Error!
Bookmark not defined. 6.1.3.12.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence.	. 111
6.1.3.13 Instrument Panel Cluster (IPC) requirements	
6.1.3.13.1 Over-arching requirements	
6.1.3.13.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination .	
6.1.3.13.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination	
6.1.3.13.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	113
6.1.3.13.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farew	ell e
sequence 113	
6.1.3.14 Austere Heads-Up Display (aHUD) requirements	114
6.1.3.14.1 Over-arching requirements	
6.1.3.14.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence	
6.1.4 Lincoln Vehicle Lighting Element/Assembly Response Performance requirements 6.1.4.1 "Other" Performance requirements	110
6.2 ELECTRICAL ARCHITECTURE – FORD VEHICLES	
6.2.1 Electrical Topology	
6.2.1.1 Combined Network/Block Diagram	
6.2.2 Common Requirements	
6.2.2.1 Participating ECUs	
6.2.2.2 Performance and Functional Voltage Ranges	118
6.2.2.3 Signal Requirements	
6.2.2.3.1 CAN Signal Requirements	
6.2.2.3.1 CAN Error Handling for Signal Gateway Messages	126
6.2.2.3.2 CAN Error Handling for Frame Gateway Messages	
6.2.2.3.3 LIN Signal Requirements	
6.2.2.3.4 Linking Logical Data Flows to CAN/LIN Signals	
6.2.3 Ford Vehicle ECU specific requirements	
6.2.3.1 Body Control Module (BCM)	
6.2.3.1.1 Over-arching requirements	130
6.2.3.1.2 Support Welcome Farewell State Determination functions	
6.2.3.1.4 Support Exterior Rear Illumination	
6.2.3.1.5 Support Exterior Supplementary Illumination	
6.2.3.1.6 Support Interior Courtesy Lamps Illumination	
6.2.3.1.7 Support Interior Ambient Lighting (without Static Sequential) Illumination	
6.2.3.1.8 Support Interior Day-time Dimmable Backlighting Illumination	
6.2.3.1.9 Support Interior Night-time Dimmable Backlighting Illumination	137
6.2.3.1.10 Support Interior 2-Step Dimmable Backlighting Illumination	
6.2.3.1.1. Support Vahicle Display Center-stack Day-time Dimmable Illumination for Display Bright	tnoon 140

	6.2.3.1.12 Support Venicle Display Cluster Day-time Dimmable Illumination for Display Brightness	
	6.2.3.1.13 Support Vehicle Display aHUD Welcome/Farewell behavior	
	6.2.3.1.14 Support "Other" Welcome/Farewell Behavior	
	6.2.3.2 LED Driver Module (LDM) requirements	143
	6.2.3.2.1 Over-arching requirements	143
	6.2.3.2.2 Provide Control Signal to support Front Exterior Illumination	
	6.2.3.3 Overhead Console (OHC) requirements	
	6.2.3.3.1 Over-arching requirements	
	6.2.3.3.2 Provide Control Signal to support Courtesy Lamps Illumination	
	6.2.3.4 Ambient Light Module (ALM) requirements	
	6.2.3.4.1 Over-arching requirements	
	6.2.3.4.2 Provide Control Signal to support Ambient Lighting Illumination	
	6.2.3.5 Driver Door Module (DDM) requirements	
	6.2.3.5.1 Over-arching requirements	
	6.2.3.5.2 Provide Control Signal to support Exterior Supplementary Illumination	
	6.2.3.5.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination	148
	6.2.3.5.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	148
	6.2.3.6 Passenger Door Module (PDM) requirements	149
	6.2.3.6.1 Over-arching requirements	
	6.2.3.6.2 Provide Control Signal to support Exterior Supplementary Illumination	149
	6.2.3.6.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination	
	6.2.3.6.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	
	6.2.3.7 Steering Column Control Module (SCCM) requirements	151
	6.2.3.7.1 Over-arching requirements	
	6.2.3.7.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination	
	6.2.3.8 Front Control Interface Module (FCIM) requirements	
	6.2.3.8.1 Provide Control Signal to support Interior Day-Time Dimmable Backlighting Illumination	
	6.2.3.8.2 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination	
	6.2.3.8.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	
	6.2.3.9 Accessory Protocol Interface Module (APIM/SYNC) requirements	
	6.2.3.9.1 Over-arching requirements	
	6.2.3.9.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness	
	6 2 3 9 3 Support Welcome/Farewell Animations and Displays during Welcome Farewell seguence	155
	6.2.3.9.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence	
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error!
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error!
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error! 158 158
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 <b>Error!</b> 158 158
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error! 158 158 158
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error! 158 158 159 159
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error! 158 158 159 159
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 156 Error! 158 158 159 159
	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination	156 156 Error! 158 158 159 159 160
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 158 158 158 158 159 160
	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence  Error! Bookmark not defined. 6.2.3.12 Austere Heads-Up Display (aHUD) requirements	156 Error! 158 158 159 160 160
	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence	156 Error! 158 158 159 160 160 161
é	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence  Error! Bookmark not defined. 6.2.3.12 Austere Heads-Up Display (aHUD) requirements	156 Error! 158 158 159 160 160 161
6	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence	156 158 158 158 159 160 161 161
	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements	156 158 Error! 158 158 159 160 160 161 161 162
	6.2.3.10 Rear Audio Control Module (RACM) requirements	156 158 Error! 158 158 159 160 160 161 161 162
7 [	6.2.3.10.1 Over-arching requirements	156 158 158 158 159 160 161 161 162 163
	6.2.3.10.1 Over-arching requirements	156 158 158 158 159 160 161 161 162 163
<b>7</b> [	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY	156 158 158 158 159 160 161 161 162 163
7 [ 7.1 8 F	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY  DICTIONARY  REVISION HISTORY	156 158 158 158 158 159 160 160 161 161 162 163 169
7 [ 7.1 8 F	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY	156 158 158 158 158 159 160 160 161 161 162 163 169
7 [ 7.1 8 F 9 A	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell Sequence 6.2.3.12 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY  REVISION HISTORY  APPENDIX.	156 158 158 158 158 159 160 160 161 161 162 163 163 169
7 [ 7.1 8 F 9 4 9.1	6.2.3.10 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements	156 158 158 158 159 160 160 161 161 163 163 169 170
7.1 8 F 9 A 9.1 9.2	6.2.3.10.1 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY  DICTIONARY  APPENDIX 1: EXTERIOR LIGHTING PWM SIGNAL SPECIFICATION APPENDIX 2: INTERIOR LIGHTING PWM SIGNAL SPECIFICATION	156 158 158 158 159 160 160 161 161 163 163 169 170 170
7 [ 7.1 8 F 9 4 9.1	6.2.3.10.1 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY  DICTIONARY  APPENDIX 1: EXTERIOR LIGHTING PWM SIGNAL SPECIFICATION APPENDIX 2: INTERIOR LIGHTING PWM SIGNAL SPECIFICATION	156 158 158 158 159 160 160 161 161 163 163 169 170 170
7.1 8 F 9 A 9.1 9.2	6.2.3.10.1 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY  DICTIONARY  APPENDIX 1: EXTERIOR LIGHTING PWM SIGNAL SPECIFICATION APPENDIX 2: INTERIOR LIGHTING PWM SIGNAL SPECIFICATION	156 158 158 158 159 160 160 161 161 163 163 169 170 170
7 <b>C</b> 7.1 <b>8 F</b> 9 <b>A</b> 9.1 9.2 9.3	6.2.3.10.1 Rear Audio Control Module (RACM) requirements 6.2.3.10.1 Over-arching requirements 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.11 Instrument Panel Cluster (IPC) requirements 6.2.3.11.1 Over-arching requirements 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination 6.2.3.11.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell 6.2.3.12 Austere Heads-Up Display (aHUD) requirements 6.2.3.12.1 Over-arching requirements 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements 6.2.4.1 "Other" Performance requirements  DATA DICTIONARY  DICTIONARY  APPENDIX 1: EXTERIOR LIGHTING PWM SIGNAL SPECIFICATION APPENDIX 2: INTERIOR LIGHTING PWM SIGNAL SPECIFICATION	156 158 158 158 159 160 160 161 161 163 163 169 170 170
7	6.2.3.10 Rear Audio Control Module (RACM) requirements. 6.2.3.10.1 Over-arching requirements. 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness	156 158 158 158 159 160 160 161 162 163 163 170 170 171
7	6.2.3.10.1 Rear Audio Control Module (RACM) requirements. 6.2.3.10.1 Over-arching requirements. 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness	156158158158159160161161163163170171
7	6.2.3.10. Rear Audio Control Module (RACM) requirements. 6.2.3.10.1 Over-arching requirements. 6.2.3.10.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness.  Bookmark not defined. 6.2.3.10.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence. 6.2.3.11 Instrument Panel Cluster (IPC) requirements. 6.2.3.11.1 Over-arching requirements. 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination. 6.2.3.11.3 Provide Control Signal to support Interior Pight-Time Dimmable Backlighting Illumination. 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination. 6.2.3.11.5 Support Odometer, Welcome/Farewell Animations and Displays during Welcome Farewell sequence 6.2.3.12 Austere Heads-Up Display (aHUD) requirements. 6.2.3.12.1 Over-arching requirements. 6.2.3.12.2 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence. 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements. 6.2.4.1 "Other" Performance requirements.  DATA DICTIONARY.  DICTIONARY.  REVISION HISTORY  APPENDIX  APPENDIX  APPENDIX  1: EXTERIOR LIGHTING PWM SIGNAL SPECIFICATION. APPENDIX 3: FEATURE LEVEL USE CASES  OF FIGURES e 1: Welcome Farewell Feature Context Diagram e 2: Welcome Farewell Feature Context Diagram e 2: Welcome Farewell Functional Architecture.	156158158158159160161161163163170171171

Figure 2	: Welcome Farewell State Determination (with Battery Saver)	31
Figure 3	: Front Illumination Control Signal transitions based on ARL requests	35
Figure 4	: Rear Illumination Control Signal transitions based on ARL requests	
Figure 5	: Supplementary Illumination Control Signal transitions based on ARL requests	
Figure 6	: "Courtesy Lamps" Illumination Control Signal transitions based on ARL requests	
Figure 7	: "Ambient Lighting" Illumination Control Signal transitions based on ARL requests	49
Figure 8	: NOTE: Static Sequential Ambient lighting response to Welcome/Farewell state	51
Figure 9	: "Ambient Lighting" Illumination Control Signal transitions based on ARL requests	53
Figure 10	: "Day-time Dimmable Backlighting" Illumination Control Signal transitions based on A	ARL requests.
	58	
Figure 11	: "Day-time Dimmable Backlighting" Illumination Control Signal transitions based on A	ARL requests.
	Error! Bookmark not defined.	
Figure 12	: "Day-time Dimmable Backlighting" Illumination Control Signal transitions based on A	ARL requests.
	Error! Bookmark not defined.	
Figure 13	: Lincoln: Lincoln Embrace Combined Network/Block Diagram	67
Figure 14	: Ford: Welcome Farewell Combined Network/Block Diagram	117
LIST OF T	TABI ES	
Table 1	: Features described in this FD	9
Table 2	: Reference Specification	
Table 3	: Feature Interface	12
Table 4	: Functional Classification Fror! Bookmark	

## 1 INTRODUCTION

#### 1.1 Purpose

This document specifies the electrical system function requirements for the determination of welcome/farewell states and the desired response(s) from different vehicle lighting elements during those states.

## 1.2 History

The "Welcome-Farewell" system is in place to anticipate the customer's interaction with the vehicle (approaching, entering, leaving etc.) and then respond accordingly by enabling or disabling visual lighting elements on the exterior and interior of the vehicle.

#### **Welcome and Farewell Vision Statements:**

The initial idea for Welcome and Farewell was formulated for Ford vehicles and the following vision statements were approved and circulated:

Welcome: "As you approach your Ford vehicle, you are welcomed by the lights. Opening the door reinforces the invitation. As the vehicle wakes up, the displays and switches illuminate with crisp, clear Ice Blue™ backlighting hinting at the exciting driving experience."

Farewell: "As you exit your Ford vehicle, interior lighting is turned on to aid in exiting. Exterior lighting remains on for a period of time to enable you to see obstacles and your pathway when leaving your vehicle."

#### Welcome Farewell evolution for "Lincoln Embrace":

Welcome Farewell implementation was evolved for Lincoln Vehicle specific applications, which included impacting additional lighting elements, a different signature color ("Lincoln White" vs. "Ice Blue") and responding to Customers over additional vehicle states not initially defined for Ford Welcome Farewell.

#### Vision statement:

 "Anticipating needs and preferences - As you approach the vehicle it anticipates you, welcomes you, and guides you with subtle and focused lighting where it is most needed.

- Fluid, seamless motions and sounds Unlocking and entering the vehicle is a fluid and effortless experience with refined motions and sounds, ambient lighting, and crafted human interfaces.
- Warm and Inviting Comfort The cabin is a warm and inviting space with seating that embraces and forms around you and appropriate ambient lighting to meet your needs and personal preferences."

## 1.3 Scope

The following set of features from the Global Feature & Function List is described in this FD.

Feature ID	Feature Name	Owner
F000416/A	Approach Detection	Elton Jamoua (EESE)
F000308/A	Welcome Mat	Ahmet Cinar (EESE)
F000309/A	Illuminated Door Handle Pockets	Elton Jamoua (EESE)
F000148/C	Auto Fold Mirrors	Ahmet Cinar (EESE)
Fn001857/J	Center Stack Animation/Graphic	Nicholar Frazier (SYNC)
Fn00335/C	Instrument Cluster Animation/Graphic - Needle	Scott Watkins (EESE)
F000317/A	Tail Lamp Static Fade	Terrence Wilson (Ext Lighting)
F000317/A	Rear Corner Lamp/Rear Side Marker Fade	Terrence Wilson (Ext Lighting)
F000315/A	Dynamic (Sequential) Signature DRL's	Terrence Wilson (Ext Lighting)
F000315/A	Fog/Fascia Lamp Static Fade	Terrence Wilson (Ext Lighting)
F000061/D	Pulsing Push to Start Switch	TBD
F000063/C	Static Sequential Ambient Lighting	Steven Antilla (Int Lighting)
F000061/D	Door Switch Backlighting	John Ricks (EESE)
F000059/C	Courtesy Lamps	Steven Antilla (Int Lighting)
F000061/D	I/P and Overhead Console Button Backlighting	Steven Antilla (Int Lighting)
F000061/D	Sync & Radio Control Button Backlighting	Dinh Tran (SYNC)
F000061/D	Headlamp Switch Backlighting	Steven Antilla (Int Lighting)
F000061/D	Instrument Cluster Backlighting	Scott Watkins (EESE)
F000059/C	Illuminated Scuff Plates	Steven Antilla (Int Lighting)
Fn003250/B	aHUD Animation	Aneesh Mathai (EESE)
F000315/A	Lit Lincoln Star	Farhan Ehsan (EESE)
F000317/A	Illuminated Deployable Runningboards	Farhan Ehsan (EESE)
F000316/A	Illuminated Seatbelt Buckles	Matt Majkowski (Int Lighting)
Fn000335/C	Instrument Cluster Animation/Graphic - Starfield	Scott Watkins (EESE)
F001002/A	Ford Welcome/Farewell	Farhan Ehsan (EESE)
F001003/A	Lincoln Welcome/Farewell	Farhan Ehsan (EESE)
F001004/A	Ford Signature Light	Frank Aust
F001005/A	Lincoln Signature Light	John Barrs (EESE)
F000052/C	Courtesy Lighting	John Barrs (EESE)
F000053/B	Courtesy Lighting Delay	John Barrs (EESE)
F000054/B	Illuminated Entry/Exit	John Barrs (EESE)

Table 1: Features described in this FD

### 1.4 Reference Specifications

Sub-system	Specification
Body Control Module (BCM)	FS-HU5T-14B476-AAG
Ford Welcome Farewell ARL	RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1
Lincoln Embrace ARL	RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1
Lit Belt Buckle Feature Spec	Illuminated Belt Buckle Spec
Combiner Heads up Display (cHUD)	cHUD Welcome – Goodbye Strategy – CGEA1.3
Approach Detection Functional Spec	Approach Detection ReqSTD-2013-04-11-16-09

**Table 2: Reference Specification** 

### 1.5 Specification Format

This specification consists of 7 major sections.

- Section 1 Introduction: Giving an explanation how to use this document including responsibilities and the scope of the document. Additionally, it contains the revision history and a list of unsettled but known issues that have to be consolidated in future versions. It explains the terminology and gives a clarification of the definitions, concepts and abbreviations used in the document.
- Section 2 Feature Description: States briefly the background and the purpose of the feature. Defines the context and boundaries of the feature
- Section 3 Feature Requirements: Lists functional and non-functional requirements of the feature.
- Section 4 Functional Decomposition: Giving an overview of which functions are necessary to implement this feature. The feature requirements shall be cascaded to the functions
- Section 5 Feature Variant design architecture
- Section 6 Testing Design verification method
- Section 7 Data Dictionary
- Section 8 Revision History: Change log of the document / template
- Section 9 Appendix Use Case details

## 1.5.1 Requirement Numbering

When a requirement is introduced it is given a tag including a requirement number. This tag follows the requirement throughout the development process. In this document requirements are identified using a tag consisting of two parts. The first part consists of the document ID in which the requirement was introduced or updated. The second part consists of the requirement number and the requirement version. A dash separates each part. A requirement tag shall be unique, i.e. there must not exist two different requirements with the same requirement tag. The same requirement may however be used more than once (i.e. the same requirement may exist several times, even within the same document).

Requirements are text denoted as "Caption, the font is Arial 10pt, BOLD" to identify a requirement. All Requirements are Level 4 Captions. Requirements are sequenced based upon the "Heading 4" numbering sequence

#### Example:

R: 1.4.4.1 This example demonstrates requirement 1 in Section 1.4.4 of this document

## **2 FEATURE DESCRIPTION**

## 2.1 Theory of Operation

#### Ford Welcome Farewell

The vehicle's Exterior, Interior lights, and Displays shall respond by either fading ON/OFF or turning ON/OFF based on user interaction with the vehicle – Approaching it with a valid PK, locking or unlocking a vehicle, opening or closing vehicle doors, and cycling the ignition between OFF and RUN/Start.

#### **Lincoln Embrace**

A variant of Ford Welcome Farewell which was adapted for Lincoln vehicles, with aesthetic level differences and the total number of lighting/display elements being impacted.

#### Feature Context Diagram




Figure 1: Welcome Farewell Feature Context Diagram

## 2.2 Feature Interface


Interaction	Direction	Influence	Description	Value Range
Host Vehicle	Input	Ignition State Remote Start state Vehicle Lock status Vehicle Door ajar status		Off, Accessory, Crank, On, Locked/unlocked, Ajar/Closed
Welcome Farewell state detection	Input	Welcome/Farewell state	Using existing welcome farewell state determination	Welcome state, Farewell state, Run/Start State, Approach, Illuminated Entry, Illuminated Exit, Courtesy Lighting,

				Courtesy Lighting Delay
Driver	Input	Approach Vehicle, Remote start vehicle, Unlock/Lock Vehicle, Open/Close Door		Approach detected, Locked/Unlocked , Ajar/Closed
Passengers	Input	Open/Close Door		Ajar/Closed
Welcome Farewell Feature	Output	Illumination/De- illumination of exterior vehicle lights, interior vehicle lights, and infotainment screens	Using existing welcome farewell state determination to driver vehicle behavior	Fade ON/OFF Snap ON/OFF Display welcome screen Display farewell screen

**Table 3: Feature Interface** 

## 2.3 <u>Use Case Tree (Use Cases in Appendix 2)</u>

For full list of "Ideal" Use-Cases refer to "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles. For full list of (event based) use cases, refer to "Ford WF and LE FMA XXXX16" document.



## **3 FEATURE REQUIREMENTS**

## 3.1 Feature Level Requirements

#### 3.1.1 Feature Classification

As per FMC1278 "Electromagnetic Compatibility Specification for Electrical/Electronic Components and Subsystems" the functional classification of the aforementioned feature is "Class B"

## 3.1.2 Feature Requirements

The feature is intended to be able to either "Welcome" or bid "Farewell" to the Driver based off of how he/she interacts with the vehicle. The manner in which the vehicle shall interact with the Driver is by controlling the Exterior Lights, Interior Lights, or Vehicle Displays (turn then ON or OFF)

Rqmt #	Requirement
R: 3.1.2-1	The feature shall smoothly fade ON or snap ON Exterior Lights and Interior Lights as the
	Driver approaches the vehicles with a functioning keyfob.
R: 3.1.2-2	The feature shall smoothly fade ON, snap ON, or keep ON (if previously illuminated) Exterior
	Lighting and Interior Lighting as the Driver is unlocking the vehicle from outside.
R: 3.1.2-3	The feature shall smoothly fade ON, snap ON, or keep ON (if previously illuminated) Exterior
	Lights and Interior Lights as the Driver or Passenger is entering the vehicle (via vehicle
	doors).
R: 3.1.2-4	The feature shall turn ON vehicle displays and "Welcome" the Driver or Passenger as they
	are entering the vehicle (via vehicle doors).
R: 3.1.2-5	The feature shall smoothly fade ON, snap ON, or keep ON (if previously illuminated) Exterior
	Lights and Interior Lighting as the Driver is settling into their seat (shutting open doors).
R: 3.1.2-6	The feature shall turn ON or keep ON (if previously ON) vehicle displays and "Welcome" (or
	continue to "Welcome") the Driver as he/she is settling into their seat.

R: 3.1.2-7	Exterior lighting, Interior Lighting, and Vehicle Displays shall behave as required by law/market-specific-regulations when the Driver cycles the ignition to Run/Start					
R: 3.1.2-8	The feature shall smoothly fade ON or snap ON (if previously OFF) Exterior Lights and Interior Lights after the Driver cycles the Ignition to OFF.					
R: 3.1.2-9	The feature shall smoothly fade ON, snap ON, or keep ON (if previously illuminated) Exterior Lights and Interior Lights as the Driver or Passenger is exiting the vehicle.					
R: 3.1.2-10	The feature shall turn ON or keep ON (if previously ON) vehicle displays and bid "Farewell" to the Driver as they are exiting the vehicle.					
R: 3.1.2-11	The feature shall smoothly fade ON, snap ON, or keep ON (if previously illuminated) Exterior Lights and Interior Lighting after the Driver has exited the vehicle.					
R: 3.1.2-12	The feature shall stop bidding the Driver "Farewell" and turn OFF vehicle displays after they have exited the vehicle.					
R: 3.1.2-13	The feature shall fade OFF or snap OFF Exterior Lighting and Interior Lighting after the Driver has left the vehicle and locked it from outside.					
R: 3.1.2-14	The feature shall keep OFF or turn OFF (if re-enabled) vehicle displays after the Driver has left the vehicle and locked it from outside.					
R: 3.1.2-15	For Ford vehicles: Feature shall meet all requirements published under ARL "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1"					
R: 3.1.2-16	For Lincoln vehicles: Feature shall meet all requirements published under ARL "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1"					

#### 3.1.2.1 Feature Enablers

The following features are required to be enabled and functioning in order for the Welcome/Farewell (and Lincoln Embrace by extension) to behave as intended.

R: 3.1.2.1-1	"Approach Detection" is required to be enabled and behave as specified under the "Approach Detection ReqSTD-2013-04-11-16-09" document, as well as within section 2.2.19 "Approach Lighting" of BCM FS-HU5T-14B476-AAG
R: 3.1.2.1-2	"Illuminated Entry" is required to be enabled and behave as specified under BCM FS-HU5T-14B476-AAG section 2.2.4 "Illuminated Entry"
R: 3.1.2.1-3	"Courtesy Lighting" is required to be enabled and behave as specified under BCM FS-HU5T-14B476-AAG section 2.2.5 "Courtesy Lighting"
R: 3.1.2.1-4	"Courtesy Lighting Delay" is required to be enabled and behave as specified under BCM FS-HU5T-14B476-AAG section 2.2.6 "Courtesy Lighting Delay"
R: 3.1.2.1-5	"Illuminated Exit" is required to be enabled and behave as specified under BCM FS-HU5T-14B476-AAG section 2.2.7 "Illuminated Exit"
R: 3.1.2.1-6	"Courtesy and Demand Lamps Battery Saver" is required to be enabled and behave as specified under BCM FS-HU5T-14B476-AAG section 2.1.1 "Battery Saver"
R: 3.1.2.1-7	"Locking" is required to be enabled and behave as specified under BCM FS-HU5T- 14B476-AAG section 2.4 "Locking"

## 3.1.2.2 <u>Welcome/Farewell State Definitions</u>

The Feature requires that the Driver's interactions with the vehicle be interpreted and categorized across 3 broad categories: "Welcome", "Ignition Run/Start", and "Farewell.

Each of the aforementioned categories are then divided into subcategories (sub-states) which match up to existing features on the vehicle.

#### **Welcome States:**

• Approach Detection: A valid key-fob/PK is detected approaching the vehicle while the feature is enabled, the ignition is off, and the vehicle is locked.

- Illuminated Entry: While the ignition is OFF, the vehicle is unlocked or the key-fob is used to open a closed power sliding door / power lift-gate / lift-gate glass.
- Courtesy Lighting: While the ignition is OFF, a vehicle door, lift-gate, or lift-gate glass transitions to ajar.
- Courtesy Lighting Delay: While the ignition is OFF, all ajar vehicle doors/lift-gate/lift-gate glass transition to closed.

Rqmt #	Requirement					
R: 3.1.2.2-1	"Approach Detection" shall be a valid state within the "Welcome" portion of Welcome/Farewell feature: State relies on location of a functioning PK/Keyfob either being within or outside the detected range of "Approach Detection" feature as defined in "Approach Detection ReqSTD-2013-04-11-16-09" document					
R: 3.1.2.2-2	"Illuminated Entry" shall be a valid state within the "Welcome" portion of Welcome/Farewell feature: Enabled only while the Ignition is in "OFF" state and vehicle unlocked from the outside: using Keyfob/PK, using Keypad, using lock-cylinder. ( <b>Note</b> : Shall not transition to this state is vehicle is unlocked using inner door switch)					
R: 3.1.2.2-3	"Courtesy Lighting" shall be a valid state within the "Welcome" portion of Welcome/Farewell feature: Enabled only while Ignition is in "OFF" state and a vehicle door (Driver, Passenger, Rear Right, Rear Left, Lift-gate, or Lift-gate glass) transitions to Ajar.					
R: 3.1.2.2-4	"Courtesy Lighting Delay" shall be a valid state within the "Welcome" portion of Welcome/Farewell feature: Enabled only while ignition is in "OFF" after all ajar vehicle doors (Driver, Passenger, Rear Right, Rear Left, Lift-gate, and Lift-gate glass if present) are closed.					

#### "Ignition RUN/START" States:

Vehicle ignition has transitioned out of "OFF" to "RUN"/"START" with the engine running.

	Requirement					
R: 3.1.2.2-5	Welcome/Farewell shall monitor the ignition state of the vehicle.					

#### **Farewell States:**

- Illuminated Exit: The ignition transitions from "RUN"/"START" to OFF"
- Courtesy Lighting: Identical to Welcome Courtesy Lighting, except it occurs after ignition has transitioned to OFF.
- Courtesy Lighting Delay: Identical to Welcome Courtesy Lighting Delay, except it occurs after ignition has transitioned to OFF.
- Security Locking: Occurs after the ignition has transitioned from "ON"/"RUN" to "OFF" and the vehicle
  is locked using Key-fob, Key-pad, or exterior lock cylinder (interior door lock/unlock switch is not
  included)

	Requirement
R: 3.1.2.2-6	"Illuminated Exit" shall be a valid state within the "Farewell" portion of Welcome/Farewell
	feature: Enabled when the ignition transitions from Run/Start to OFF
R: 3.1.2.2-7	"Courtesy Lighting" shall be a valid state within the "Farewell" portion of Welcome/Farewell feature: Enabled only while Ignition is in "OFF" state (in this case after ignition transitions to "OFF") and a vehicle door (Driver, Passenger, Rear Right, Rear Left, Lift-gate, or Lift-
	gate glass) transitions to Ajar.
R: 3.1.2.2-8	"Courtesy Lighting Delay" shall be a valid state within the "Farewell" portion of
	Welcome/Farewell feature: Enabled only while Ignition is in "OFF" state (in this case after
	ignition transitions to "OFF") after all ajar vehicle doors (Driver, Passenger, Rear Right,
	Rear Left, Lift-gate, and Lift-gate glass if present) are closed.
R: 3.1.2.2-9	

"Vehicle Locking" shall be a valid state within the "Farewell" portion of Welcome/Farewell
feature: Enabled only while ignition is in "OFF" state, all doors are closed, and vehicle is
locked from the outside: using Keyfob/PK, using Keypad, using lock-cylinder. (Note: Shall
not transition to this state is vehicle is locked using inner door switch)

\*NOTE – Courtesy Lighting and Courtesy Lighting Delay states occur and drive the same behavior during both "Welcome" and "Farewell" sequences.

#### 3.1.2.3 Additional Concurrent Features interacting with Welcome/FarewellStates

There are additional vehicle functions that either use the same triggers to activate as a currently defined Welcome Farewell States while driving different behavior, or those that can be activated either during or prior to Welcome Farwell state transitions which impact how the lighting elements that are tied to the feature behave.

- Remote start: Feature shall behave as described in BCM FS HU5T-14B476-AAG, and while it is active shall impact Exterior Lighting
- Delayed Accessory: Feature shall behave as described in BCM FS HU5T-14B476-AAG, and while it
  is active shall impact Interior Lighting. Drives vehicle behavior after ignition transitions to OFF.
  Behavior is identical to Illuminate Exit state, except it can remain enabled for a longer duration, and
  cannot be re-enabled until ignition has been cycled from RUN to OFF.
- Extended Play: Feature impacts vehicle infotainment displays and associated control backlighting (currently tied to Sync screen). State occurs Same as Illuminated Exit, except the state lasts for 10 minutes after ignition OFF vs. 25 seconds tied to Illuminated Exit. Can be re-enabled by pressing media power button.

	Requirement				
R: 3.1.2.3-1	Key-fob holder can activate Remote Start by meeting conditions listed under section 2.13.2 of BCM FS-HU5T-14B476-AAG. Feature shall stay active until it is aborted or until vehicle ignition is started. While feature is active, exterior lighting elements tied to feature shall remain active for duration that the feature is active – override Welcome/Farewell state transition based requirements.				
R: 3.1.2.3-2	Key-fob holder can activate Delayed Accessory by meeting conditions listed under section 2.1.2 of BCM FS-HU5T-14B476-AAG. Feature shall keep specific lighting and features on the interior active after Ignition transitions to OFF for either 10 minutes or a front vehicle door transitioning to Ajar (whichever occurs first) – override Welcome/Farewell state transition based requirements.				
R: 3.1.2.3-3	"Extended Play" shall be a valid state within the "Farewell" portion of Welcome/Farewell feature that is exclusive to the Center-stack Display and Controls: takes the place of "Illuminated Exit" during welcome farewell state transitions; however, timeout is extended to 10 minutes (vs. 25 seconds for Illuminated Exit). Feature can be re-enabled manually by Driver (hard button press), which shall then override Welcome/Farewell state transition based requirements.				

#### 3.1.2.4 <u>Power Modes and Vehicle states required for Feature operation</u>

The feature is expected to have functionality across all Power Modes and Vehicle Modes that would qualify under "normal" operation of vehicle – Vehicle isn't in an error, error recovery, diagnostic, or any related state which would inhibit normal function of the vehicle.

	Power Mode	Vehicle Mode	
R: 3.1.2.4-1 OFF		Vehicle Asleep or Vehicle Awake	
R: 3.1.2.4-2	ACCESSORY Vehicle Asleep or Vehicle Awake		
R: 3.1.2.4-3	RUN/START	Vehicle Awake.	

### 3.1.2.5 **Feature Overrides/Inhibits**

Ford Welcome Farewell and Lincoln Embrace are intended to be low-priority features, where if a "conflicting" feature is activated it shall be given higher priority.

	Requirement				
R: 3.1.2.5-1	Activating "Perimeter Alarm Mode" or "Panic Alarm" as per sections 2.5-4 or 2.5-7 of BCM FS-HU5T-14B476-AAG shall override Welcome/Farewell state transition based requirements for duration feature is active				
R: 3.1.2.5-2	Activating "Silent Mode" as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall over Welcome/Farewell state transition based requirements for duration feature is active				
R: 3.1.2.5-3	Activating "Key-Off-Load Mode" as per section 2.14.6-7 of BCM FS-HU5T-14B476-AAG shall override Welcome/Farewell state transition based requirements for duration feature is active.				
R: 3.1.2.5-4	Activating "Post-Crash Alert" as per section 2.5-78 of BCM FS-HU5T-14B476-AAG shall override Welcome/Farewell state transition based requirements for duration feature is active.				

## 3.2 **Quality Requirements**

## 3.2.1 Reliability Requirements

No additional reliability requirements for the intended implementation.

## 3.2.2 Performance Requirements

Rqmt #	Requirement					
R: 3.2.2-1	The lighting elements controlled by this feature while it is active shall be steady burning (no flickering) when illuminated					
R: 3.2.2-2	By default, if a lighting element is required to "Fade ON", it shall take 3 seconds to ramp up its illumination level from "OFF" level to the desired "ON" level – "ON" illumination level shall be specified by Vehicle Harmony group.					
R: 3.2.2-3	By default, if a lighting element is required to "Fade OFF", it shall take 5 seconds to complete when starting at "ON" illumination level					
R: 3.2.2-4	If a lighting element is required to "Fade ON" or "Fade OFF", it shall continuously ramp ON or OFF to its "ON" level - shall not "flicker" as defined by the Interior Harmony Group, identified during vehicle walk-around					
R: 3.2.2-5	Exterior Lighting elements required to "Fade ON" or "Fade OFF" shall follow ramp in either direction following Stevens' Power Law curve until the illumination reaches the desired "ON" or "OFF" level respectively					
R: 3.2.2-6	Interior Lighting elements required to "Fade ON" or "Fade OFF" shall transition in either direction following "Smooth Dimming" until the illumination reaches the desired "ON" or "OFF" level					
R: 3.2.2-7	Exterior Lighting elements required to "Snap ON" or "Snap OFF" shall step up or down their illumination level to the desired "ON" or "OFF" level following a step function					
R: 3.2.2-8	Interior Lighting elements required to "Snap ON" or "Snap OFF" shall step up or down their illumination level to the desired "ON" or "OFF" level following a step function					
R: 3.2.2-9	Interior Lighting elements required to "Pulse" shall ramp up to their "ON" illumination level and then immediately transition between their "ON" and configurable illumination level (10% of "ON" illumination level by default) at a configurable frequency (set to 1Hz by default) – point back BCM FS					

#### 3.2.2.1 Performance Latency Requirements

 Rqm't Num
 Latency

 R: 3.2.2.1-1
 0.250 seconds

**Note:** End-to-End Latency is defined as once the Publisher changes the internal value of their publishing signal, the Subscriber must begin to respond within this defined latency (some functionality shall take time to fully enable the required functionality).

## 3.2.3 Safety Requirements

The following requirements refer to the safety requirements as defined and managed by the ASO office. Each requirement points to a specific "Regulation Records" (RRs) as they're listed in FSMS, which in turn refer to sections from the applicable Regulation.

Links to RRs are used instead of pointing to the specific language that applies within the larger Regulatory document to protect against continual updates/re-interpretations – link to RR won't change, but content within RR shall/might eventually change. It is also strongly advised that the listed "RR" Author" be contacted to assure that the content within the RR is being interpreted correctly.

#### 3.2.3.1 NAFTA Requirements to abide by (or not violate)

Rqmt #	RR ID/ Revision	Country/ Vehicle area	Regulation Number and Title	RR Author
R: 3.2.3.1-1	<u>CAN-</u> 004804/1	Canada/ Exterior Lighting	SCHEDULE IV Part II(CMVSS 108 and 108.1)/LIGHTING SYSTEM, RETRO-REFLECTIVE DEVICES and HEADLAMP CONCEALMENT DEVICES	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-2	<u>CAN-</u> 004804/3	Canada/ Exterior Lighting	CMVSS 108/LIGHTING SYSTEM, RETRO-REFLECTIVE DEVICES and HEADLAMP CONCEALMENT DEVICES	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-3	<u>CAN-</u> 004911/3	Canada/ Interior Lighting	CMVSS 101/SCHEDULE IV PART II 101 (CMVSS 101) Controls and Displays	Laesch,Renu- RLAESCH1 (rlaesch1)
R: 3.2.3.1-4	XCT- 011075/1	Cross Country Topics/ Instrument Cluster	CROSS COUNTRY SPEEDOMETER MATRIX/CROSS COUNTRY MATRIX FOR SPEEDOMETER AND ODOMETER	Laesch,Renu- RLAESCH1 (rlaesch1)
R: 3.2.3.1-5	MEX- 006101/1	Mexico/ Interior Lighting	MEX SECOFI-18/HAZARD WARNING SYSTEM	Arellano-Belloc,Hector- HARELLAN (harellan)
R: 3.2.3.1-6	MEX- 006103/1	Mexico/ Exterior Lighting	MEX SECOFI-20/CLEARANCE LAMPS	Arellano-Belloc,Hector- HARELLAN (harellan)
R: 3.2.3.1-7	MEX- 006134/1	Mexico/ Vehicle Display	MEX SECOFI-25/INSTRUMENT CLUSTER.	Arellano-Belloc,Hector- HARELLAN (harellan)
R: 3.2.3.1-8	<u>USA-</u> 004809/20	US / Exterior Lighting	FMVSS 108/LAMPS, REFLECTIVE DEVICES AND ASSOCIATED EQUIPMENT	Adams-Campos,Kelley- KADAMSCA (kadamsca)

R: 3.2.3.1-9	<u>USA-</u> 004890/4	US / Vehicle Display	Voluntary Agreements/Mandatory/Voluntary Agreement /Mandatory Commitment - Driver Focus-Telematics Guidelines	Overbeck,Thomas- TOVERBEC (toverbec)
R: 3.2.3.1-10	<u>USA-</u> 004921/3	US / Exterior Lighting	FMVSS 111/FMVSS 111 - Rear Visibility	Vemulakonda,Gurunath- GVEMULAK (gvemulak)
R: 3.2.3.1-11	<u>USA-</u> 006675/1	US / Vehicle Display	USA - STATE - SEVERAL/ODOMETER	Laesch,Renu- RLAESCH1 (rlaesch1)
R: 3.2.3.1-12	<u>USA-</u> 006677/1	US / Exterior Lighting	USA - STATE - SEVERAL/FRONT FOG LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-13	<u>USA-</u> 006734/1	US / Exterior Lighting	USA - STATE - SEVERAL/REAR FOG LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-14	<u>USA-</u> 006735/1	US / Exterior Lighting	USA - STATE - SEVERAL/SIDE TURN SIGNAL LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-15	<u>USA-</u> 006736/1	US / Exterior Lighting	USA - STATE - SEVERAL/AUXILIARY PASSING/LOW BEAM	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-16	<u>USA-</u> 006737/1	US / Exterior Lighting	USA - STATE - SEVERAL/FRONT CORNERING LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-17	<u>USA-</u> 006738/1	US / Exterior Lighting	USA - STATE - SEVERAL/REAR CORNERING LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-18	<u>USA-</u> 006739/1	US / Interior Lighting	USA - STATE - SEVERAL/CARGO LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-19	<u>USA-</u> 006740/1	US / Exterior Lighting	USA - STATE - SEVERAL/SPOT LAMPS	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-20	<u>USA-</u> 006741/1	US / Exterior Lighting	USA - STATE - ALL/EXTERIOR LIGHTING - GENERAL	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-21	<u>USA-</u> 008712/1	US / Exterior Lighting	USA - STATE - SEVERAL/AUXILIARY DRIVING/HIGH BEAM	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-22	<u>USA-</u> 008716/3	US / Interior Lighting & Vehicle Displays	FMVSS 101/FMVSS 101 Controls and Displays	Laesch,Renu- RLAESCH1 (rlaesch1)
R: 3.2.3.1-23	<u>USA-</u> 008732/1	US / Interior Lighting &	/NHTSA Visual-Manual Guidelines for In-Vehicle Electronic Devices	Leigh,Michael-MLEIGH (mleigh)

		Vehicle Displays		
R: 3.2.3.1-24	<u>USA-</u> 009169/2	US / Exterior Lighting	USA - STATE - SEVERAL/HEADLAMPS (LOW- BEAMS)	Adams-Campos,Kelley- KADAMSCA (kadamsca)
R: 3.2.3.1-25	<u>USA-</u> 011127/2	US / Exterior Lighting, Interior Lighting & Vehicle Display	/2019MY U.S. NHTSA New Car Assessment Program (NCAP)	Buckman,Jennifer- JBARNARD (jbarnard)

## 3.2.3.2 **ECE Requirements to abide by (or not violate)**

	RR ID/ Revision	Country/ Vehicle area	Regulation Number and Title	RR Author
R: 3.2.3.2-1	ECE- 009219/2	ECE / Exterior Lighting	ECE-20 amended to ECE- 20.03/HALOGEN HEADLAMPS (LOW- BEAMS) (H4).	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-2	ECE- 007310/1	ECE / Exterior Lighting	ECE-01 amended to ECE- 01.02/TUNGSTEN (R2, HS1) HEADLAMPS (LOW-BEAMS).	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-3	ECE- 008757/1	ECE / Vehicle Displays & Interior Lighting	RE3 ANNEX 16./ON-BOARD COMMUNICATION AND INFORMATION SYSTEMS.	Abraham,James- JABRAH11 (jabrah11)
R: 3.2.3.2-4	ECE- 006905/1	ECE / Exterior Lighting	ECE-02 amended to ECE-02.03./TUNGSTEN HEADLAMP BULBS.	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-5	ECE- 009223/2	ECE / Exterior Lighting	ECE-31/HALOGEN SEALED BEAM HEADLAMPS (LOW-BEAMS) (HSB).	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-6	ECE- 005007/3	ECE / Exterior Lighting	ECE-65 amended to ECE-65.00 Supp.9/FLASHING WARNING BEACONS.	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-7	ECE- 004623/1	ECE / Exterior Lighting	ECE-123/ADAPTIVE FRONT-LIGHTING SYSTEMS (AFS)	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-8	ECE- 007313/1	ECE / Exterior Lighting	ECE-08 amended to ECE- 08.05/HALOGEN HEADLAMPS (LOW- BEAMS) (EXCEPT H4 & HSB).	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-9	ECE- 007345/1	ECE / Exterior Lighting	ECE-5/TUNGSTEN SEALED BEAM HEADLAMPS (LOW-BEAMS).	Sanchez, Greg- GSANCHE1 (gsanche1)
R: 3.2.3.2-10	ECE- 005026/6	ECE / Exterior Lighting	ECE-99/GAS DISCHARGE LIGHT SOURCES.	Sanchez, Greg- GSANCHE1 (gsanche1)

R: 3.2.3.2-11	ECE-	ECE /	ECE-37/FILAMENT LAMPS.	Sanchez, Greg-
	005000/1	Exterior		GSANCHE1 (gsanche1)
	<u>5</u>	Lighting		
R: 3.2.3.2-12	ECE-	ECE /	ECE-128.00 Supp 2/LIGHT EMITTING	Sanchez, Greg-
	008647/3	Exterior	DIODE (LED) LIGHT SOURCES	GSANCHE1 (gsanche1)
		Lighting &		
		Interior		
		Lighting		
R: 3.2.3.2-13	ECE-	ECE /	ECE-39/SPEEDOMETER	Sanchez, Greg-
	004951/1	Vehicle		GSANCHE1 (gsanche1)
	<u>0</u>	Display		
R: 3.2.3.2-14	ECE-	ECE /	ECE-4.00.Supp.17/REAR	Sanchez, Greg-
	004965/1	Exterior	REGISTRATION PLATE LAMPS.	GSANCHE1 (gsanche1)
	<u>0</u>	Lighting		
R: 3.2.3.2-15	ECE-	ECE /	ECE-121.01/Identification of Hand	Mueller, Joachim-
	005073/1	Interior	Controls, Tell-Tales and Indicators	JMUELLE6 (jmuelle6)
	<u>6</u>	Lighting &		
		Vehicle		
		Displays		
R: 3.2.3.2-16	ECE-	ECE /	ECE-26.02/Exterior Projections	Mueller, Joachim-
	005009/1	Exterior		JMUELLE6 (jmuelle6)
	<u>2</u>	Lighting		

## 3.2.3.3 China Requirements to abide by (or not violate)

	RR ID/Revision	Country	Regulation Number and Title	RR Author
R: 3.2.3.3-1	<u>CHN-</u> 005552/2	China / Exterior Lighting	GB 11554-2008/CHINA: REAR FOG LAMPS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-2	<u>CHN-</u> 005656/2	China / Exterior Lighting	GB 21259-2007/CHINA: GAS- DISCHARGE HEADLAMPS (LOW- BEAMS)	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-3	CHN- 008890/3	China / Exterior Lighting	GB 18099/CHINA: SIDE-MARKER LAMPS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-4	<u>CHN-</u> 004328/8	China / Exterior Lighting	GB 4785/CHINA: INSTALLATION OF EXTERNAL LIGHTING AND LIGHT SIGNALING DEVICES	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-5	<u>CHN-</u> 005445/2	China / Exterior Lighting	GB 5920-2008/CHINA: FRONT AND REAR POSITION, END-OUTLINE MARKER, AND STOP LAMPS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-6	<u>CHN-</u> 008533/2	China / Exterior Lighting	GB 18408-2001, GB 18408- 2015/CHINA: ILLUMINATION OF REAR REGISTRATION PLATES	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-7	<u>CHN-</u> 008566/2	China / Exterior Lighting	GB/T 30036-2013/CHINA: ADAPTIVE FRONT LIGHTING STSTEM (AFS)	Zhang,Yue-YZHAN256 (yzhan256)

R: 3.2.3.3-8	<u>CHN-</u> 004539/19	China / Exterior Lighting, Interior Lighting & Vehicle Display	CNCA CCC rules-component/CHINA: CCC COMPONENT CERTIFICATION	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-9	XCT- 011075/1	Cross Country Topics / Vehicle Display	CROSS COUNTRY SPEEDOMETER MATRIX/CROSS COUNTRY MATRIX FOR SPEEDOMETER AND ODOMETER	Laesch,Renu-RLAESCH1 (rlaesch1)
R: 3.2.3.3-10	CHN- 005684/2	China / Exterior Lighting	GB 23255/CHINA: DAYTIME RUNNING LAMP	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-11	CHN- 005443/1	China / Exterior Lighting	GB 4599-2007/CHINA: HEADLAMPS (LOW-BEAMS)	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-12	CHN- 004515/2	China / Exterior Lighting	GB 25991-2010/CHINA: LED HEADLAMPS (LOW-BEAMS)	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-13	<u>CHN-</u> 005444/1	China / Exterior Lighting & Interior Lighting	GB 17509-2008/CHINA: DIRECTION INDOCATORS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-14	<u>CHN-</u> 010709/2	China / Vehicle Display	GB/T 19836/CHINA: INSTRUMENTATION FOR ELECTRIC VEHICLES	Peng,Quanping- QPENG4 (qpeng4)
R: 3.2.3.3-15	CHN- 008524/1	China / Exterior Lighting	GB 11566-2009/CHINA: EXTERIOR PROJECTIONS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-16	CHN- 005446/1	China / Exterior Lighting	GB 15235-2007/CHINA: REVERSING LAMPS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-17	<u>CHN-</u> 008936/2	China / Exterior Lighting	GB/T 30511/CHINA: CORNERING LAMPS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-18	<u>CHN-</u> 004436/16	China / Exterior Lighting, Interior Lighting & Vehicle Display	GB 7258/CHINA: CCC VEHICLE APPROVAL	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-19	CHN- 004481/6	China / Interior Lighting	GB 20182/CHINA: EXTERNAL RPOJECTIONS - COMMERCIAL VEHICLE CABIN	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-20	CHN- 005596/1	China / Exterior Lighting	GB 15766.1-2000/CHINA: LAMPS FOR ROAD VEHICLES (FILAMENT LAMPS & GAS-DISCHAGE LAMPS)	Zhang,Yue-YZHAN256 (yzhan256)

R: 3.2.3.3-21	<u>CHN-</u> 005597/1	China / Exterior Lighting	GB 18409-2001/CHINA: PARKING LAMPS	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-22	<u>CHN-</u> 004329/5	China / Interior Lighting & Vehicle Displays	GB 4094/CHINA: SYMBOLS FOR CONTROLS, INDICATORS, AND TELL- TALES	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-23	<u>CHN-</u> 004330/5	China / Interior Lighting & Vehicle Display	GB 15082/CHINA: SPEEDOMETERS FOR MOTOR VEHICLE	Zhang,Yue-YZHAN256 (yzhan256)
R: 3.2.3.3-24	CHN- 005551/2	China / Exterior Lighting	GB 4660-2007/CHINA: FRONT FOG LAMPS	Zhang,Yue-YZHAN256 (yzhan256)

<sup>\*</sup>NOTE – China market regulatory requirements are close to ECE market requirements with very few exceptions.

## 3.2.4 Security Requirements

N/A – No unique security requirements are required by this feature.

## 4 FUNCTIONAL DECOMPOSITION

## 4.1 Functional Architecture




Figure 2: Welcome Farewell Functional Architecture

<sup>\*</sup>NOTE - Consult ASO team for any markets not specified.

## 4.2 <u>List of Functions</u>

Section #	Function Name	Function Description
5.2.2	Welcome/Farewell	Algorithm within the controlling module which shall accept input
0.2.2	State determination	signals to then determine the specific state of welcome farewell –
	without Battery Saver	not taking BCM specific "Battery Saver" function into account
	tie-in	The same grant and same and sa
5.2.3	Welcome/Farewell	Algorithm within the controlling module which shall accept input
	State determination	signals to then determine the specific state of welcome farewell -
	with Battery Saver	taking BCM specific "Battery Saver" function into account
5.3.1	Exterior "Front	Function used to transmit the appropriate control signals to
	Illumination" Algorithm	lighting elements located at the front of the vehicle, based on
		Welcome/Farewell State
5.3.2	Exterior "Front	Defines how the lighting elements identified as "Front
	Illumination" Lighting	Illumination" as per "RQT-002004-021878 DNA WELCOME-
	Response	FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-
		002004-022094 LINCOLN EMBRACE WELCOME AND
		FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall
		respond to the control signals they're receiving from the Exterior
		"Front Illumination" Algorithm
5.3.3	Exterior "Rear	Function used to transmit the appropriate control signals to
	Illumination"	lighting elements located at the rear of the vehicle, based on
	Algorithm	Welcome/Farewell State
5.3.4	Exterior "Rear	Defines how the lighting elements identified as "Rear Illumination"
	Illumination" Lighting	as per "RQT-002004-021878 DNA WELCOME-FAREWELL
	Response	STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094
		LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR
		REV. 1" for Lincoln vehicles shall respond to the control signals
5.3.5	Exterior	they're receiving from the Exterior "Rear Illumination" Algorithm
5.3.5	"Supplementary	Function used to transmit the appropriate control signals to supplemental lighting elements on the exterior of the vehicle,
	Illumination" Algorithm	based on Welcome/Farewell State
5.3.6	Exterior	Defines how the lighting elements identified as "Supplementary
0.0.0	"Supplementary	Illumination" as per "RQT-002004-021878 DNA WELCOME-
	Illumination" Lighting	FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-
	Response	002004-022094 LINCOLN EMBRACE WELCOME AND
		FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall
		respond to the control signals they're receiving from the Exterior
		"Supplementary Illumination" Algorithm
5.4.1	Interior "Courtesy	Function used to transmit the appropriate control signals to
	Lights" Algorithm	Interior Courtesy lighting elements, based on Welcome/Farewell
		State
5.4.2	Interior "Courtesy	Defines how the lighting elements identified as "Courtesy Lights"
	Lights" Lighting	as per "RQT-002004-021878 DNA WELCOME-FAREWELL
	Response	STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094
		LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR
		REV. 1" for Lincoln vehicles shall respond to the control signals
		they're receiving from the Interior "Courtesy Lights" Algorithm.
5.4.3	Interior "Ambient	Function used to transmit the appropriate control signals to
	Lighting without static	Interior Ambient lighting elements without enabling static
<b>5</b> 4 4	sequential" Algorithm	sequential, based on Welcome/Farewell State
5.4.4	Interior "Ambient	Defines how the lighting elements identified as "Ambient Lighting
	Lighting without static	without Static Sequential" as per "RQT-002004-021878 DNA
	sequential" Lighting	WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
	Response	or "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
		FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall
		respond to the control signals they're receiving from the Interior
		"Ambient Lighting without Static Sequential" Algorithm.

	T	T=
5.4.5	Interior "Ambient Lighting with static	Function used to transmit the appropriate control signals to Interior Ambient lighting elements while supporting static
	sequential" Algorithm	sequential, based on Welcome/Farewell State
5.4.6	Interior "Ambient Lighting with static sequential" Lighting Response	Defines how the lighting elements identified as "Ambient Lighting with Static Sequential" as per "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall respond to the control signals they're receiving from the Interior "Ambient Lighting with Static Sequential" Algorithm.
5.4.7.1	Interior "Day-time Dimmable Backlighting" Algorithm	Function used to transmit the appropriate control signals to Interior Dimmable Backlighting elements, based on Welcome/Farewell State. Broken down into 3 sub functions: "Daytime Dimmable", "Night-time Dimmable", and "2-step Dimmable" backlighting algorithm.
5.4.7.2	Interior "Day-time Dimmable Backlighting" Lighting Response	Defines how the lighting elements identified as "Dimmable Backlighting" as per "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall respond to the control signals they're receiving from Interior "Dimmable Backlighting" Algorithm (more specifically either: "Daytime Dimmable", "Night-time Dimmable", and "2-step Dimmable" backlighting algorithm.)
5.4.7.3	Interior "Night-time Dimmable Backlighting" Algorithm	Function used to transmit the appropriate control signals to Interior Dimmable Backlighting elements, based on Welcome/Farewell State. Broken down into 3 sub functions: "Daytime Dimmable", "Night-time Dimmable", and "2-step Dimmable" backlighting algorithm.
5.4.7.4	Interior "Night-time Dimmable Backlighting" Lighting Response	Defines how the lighting elements identified as "Dimmable Backlighting" as per "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall respond to the control signals they're receiving from Interior "Dimmable Backlighting" Algorithm (more specifically either: "Daytime Dimmable", "Night-time Dimmable", and "2-step Dimmable" backlighting algorithm.)
5.4.7.5	Interior "2-Step Dimmable Backlighting" Algorithm	Function used to transmit the appropriate control signals to Interior Dimmable Backlighting elements, based on Welcome/Farewell State. Broken down into 3 sub functions: "Daytime Dimmable", "Night-time Dimmable", and "2-step Dimmable" backlighting algorithm.
5.4.7.6	Interior "2-Step Dimmable Backlighting" Lighting Response	Defines how the lighting elements identified as "Dimmable Backlighting" as per "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles or "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles shall respond to the control signals they're receiving from Interior "Dimmable Backlighting" Algorithm (more specifically either: "Daytime Dimmable", "Night-time Dimmable", and "2-step Dimmable" backlighting algorithm.)
5.5.1	Center-stack welcome/farewell Display	Function used to transmit the appropriate control signals to the Cluster display, based on Welcome/Farewell State
5.5.2	Cluster Welcome/Farewell Displays	Function used to transmit the appropriate control signals to the Cluster display, based on Welcome/Farewell State

5.5.3	HUD	Function used to transmit the appropriate control signals to the
	Welcome/Farewell	unspecified displays, based on Welcome/Farewell State
	Displays (aHUD)	

## **5 Function Requirement**

## 5.1 Power Modes of each Function

Rqmt #	Function Name	Power Mode
R: 5.1-1	Welcome/Farewell State	OFF, ACCESSORY, RUN, and
	determination without Battery Saver	START
	tie-in	
R: 5.1-2	Welcome/Farewell State	OFF, ACCESSORY, RUN, and
	determination with Battery Saver	START
R: 5.1-3	Exterior "Front Illumination"	OFF, ACCESSORY, RUN, and
	Algorithm	START
R: 5.1-4	Exterior "Front Illumination" Lighting	OFF, ACCESSORY, RUN, and
	Response	START
R: 5.1-5	Exterior "Rear Illumination"	OFF, ACCESSORY, RUN, and
	Algorithm	START
R: 5.1-6	Exterior "Rear Illumination" Lighting	OFF, ACCESSORY, RUN, and
	Response	START
R: 5.1-7	Exterior "Supplementary	OFF, ACCESSORY, RUN, and
	Illumination" Algorithm	START
R: 5.1-8	Exterior "Supplementary	OFF, ACCESSORY, RUN, and
	Illumination" Lighting Response	START
R: 5.1-9	Interior "Courtesy Lights" Algorithm	OFF, ACCESSORY, RUN, and
	, ,	START
R: 5.1-10	Interior "Courtesy Lights" Lighting	OFF, ACCESSORY, RUN, and
	Response	START
R: 5.1-11	Interior "Ambient Lighting without	OFF, ACCESSORY, RUN, and
	static sequential" Algorithm	START
R: 5.1-12	Interior "Ambient Lighting without	OFF, ACCESSORY, RUN, and
	static sequential" Lighting Response	START
R: 5.1-13	Interior "Ambient Lighting with static	OFF, ACCESSORY, RUN, and
	sequential" Algorithm	START
R: 5.1-14	Interior "Ambient Lighting with static	OFF, ACCESSORY, RUN, and
	sequential" Lighting Response	START
R: 5.1-15	Interior "Day-time Dimmable	OFF, ACCESSORY, RUN, and
	Backlighting" Algorithm	START
R: 5.1-16	Interior "Day-time Dimmable	OFF, ACCESSORY, RUN, and
	Backlighting" Lighting Response	START
R: 5.1-17	Interior "Night-time Dimmable	OFF, ACCESSORY, RUN, and
	Backlighting" Algorithm	START
R: 5.1-18	Interior "Night-time Dimmable	OFF, ACCESSORY, RUN, and
	Backlighting" Lighting Response	START
R: 5.1-19	Interior "2-Step Dimmable	OFF, ACCESSORY, RUN, and
	Backlighting" Algorithm	START
R: 5.1-20	Interior "2-Step Dimmable	OFF, ACCESSORY, RUN, and
	Backlighting" Lighting Response	START
R: 5.1-21	Center-stack welcome/farewell	OFF, ACCESSORY, RUN, and
	Display	START
R: 5.1-22	Cluster Welcome/Farewell Displays	OFF, ACCESSORY, RUN, and
		START
R: 5.1-23	HUD Welcome/Farewell Displays	OFF, ACCESSORY, RUN, and
		START

## 5.2 Welcome/Farewell State determination

## 5.2.1 Inputs used for Welcome/Farewell State determination

In order to transition between the Welcome/Farewell states listed within section 3.1.2, the vehicle shall need to monitor the following:

Rqmt #	Requirement	Values
R: 5.2.1-1	The Welcome/Farewell feature shall use the output associated with "Approach Detection Proximity Sensing", as defined in FS-HU5T-14B476-AAG, being active or in-active as an input for Welcome/Farewell State determination.	Approach Detected Approach not Detected
R: 5.2.1-2	The Welcome/Farewell feature shall accept Vehicle Driver Door Status (Driver, Passenger, Rear Left, and Rear Right: Ajar or Open) on change, as an input for Welcome/Farewell State determination	Driver Door Ajar Driver Door Closed
R: 5.2.1-3	The Welcome/Farewell feature shall accept Vehicle Passenger Door Status (Driver, Passenger, Rear Left, and Rear Right: Ajar or Open) on change, as an input for Welcome/Farewell State determination	Passenger Door Ajar Passenger Door Closed
R: 5.2.1-4	The Welcome/Farewell feature shall accept Vehicle Rear Left Door Status on change, as an input for Welcome/Farewell State determination	Rear Left Door Ajar Rear Left Door Closed
R: 5.2.1-5	The Welcome/Farewell feature shall accept Vehicle Rear Right Door Status on change, as an input for Welcome/Farewell State determination	Rear Right Door Ajar Rear Right Door Closed
R: 5.2.1-6	The Welcome/Farewell feature shall accept Vehicle Door Lock Status actuated via Keyfob / PK on change, as an input for Welcome/Farewell State determination.	Keyfob/PK lock  Keyfob/PK unlock
R: 5.2.1-7	The Welcome/Farewell feature shall accept Vehicle Door Lock Status actuated via Keypad on change, as an input for Welcome/Farewell State determination.	Keypad lock Keypad unlock
R: 5.2.1-8	The Welcome/Farewell feature shall accept Vehicle Door Lock Status actuated via external lock cylinder on change, as an input for Welcome/Farewell State determination.	Cylinder lock  Cylinder unlock
R: 5.2.1-9	The Welcome/Farewell feature shall accept Ignition Status (Off, Run and Start) on change, as an input for Welcome/Farewell State determination. NOTE: "Vehicle Ignition is OFF" refers to "Accessory" ignition state as well.	Vehicle Ignition is OFF Vehicle ignition is in Run/Start

## 5.2.2 Welcome/Farewell State determination without Battery Saver tie-in

The Control module containing the Welcome/Farewell State determination shall transition between its identified states slightly differently if the "Battery Saver" function, as defined in section 2.1.1 of FS-HU5T-14B476-AAG, is taken into consideration or not. The following section, diagram and list of requirements don't take it into account.




Figure 3: Welcome Farewell State Determination (without Battery Saver)

- \*NOTE Even though the diagram above has two separate "Null" states called out, they are referring to the same "Null" state.
- \*\*NOTE Additional details expressed in terms of transitions and inputs defined in section 5.2.1 listed in requirements/table below.

A -> I.1: PK/Key Fob entered then went outside of Approach Detection range, currently set at 2.5 meters
"Approach Detected" -> "Approach not Detected"
A -> I.2: Approach Detection timer set at 25 seconds. State shall expire if no action is taken after initially detected and PK/Key fob remains within 2.5 meters' range.
"Approach Detected" -> "Approach not Detected"
I -> A.3: 25 seconds Approach Detection starts after PK/Key Fob enters Approach Detection range.
"Null" -> "Approach Detected"
A -> B.5: Unlock must occur using Key-fob, Keypad, or exterior door lock cylinder. 25 seconds "Courtesy Light Timer" starts at Unlock.
"Approach Detected" -> "Approach not Detected"
"Keyfob/Pk unlock" OR "Keypad unlock" OR "Cylinder unlock"
<b>B</b> -> <b>C.7</b> : 25 second "Courtesy Light Timer" starts at first door open. Does not reset with each additional door open.

"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed" -> "Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar"
B -> I.10: 25 second "Courtesy Light Timer" started at Unlock (via Key-fob, Keypad, or exterior door lock cylinder). Timer resets with each additional unlock request made.
"Keyfob/Pk unlock" OR "Keypad unlock" OR "Cylinder unlock" AND Courtesy Light Timer expired -> "Null" state
I -> B.11: Unlock must occur using Key-fob, Keypad, or exterior door lock cylinder. 25 seconds "Courtesy Light Timer" starts at Unlock
"Null" -> "Keyfob/Pk unlock" OR "Keypad unlock" OR "Cylinder unlock"
B ->G.12: Lock must occur using Key-fob, Keypad, or exterior door lock cylinder.
 "Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
C ->I.13: 25 seconds passed from first door ajar event.
("Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar") AND "Courtesy Light Timer" expired -> "Null"
I -> C.14: 25 second "Courtesy Light Timer" starts at first door open. Does not reset with each additional door open.
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"-> "Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar"
C -> D.15: All vehicle doors have to be closed within 25 seconds of first door ajar in order for transition to occur. Otherwise state shall transition to "Null". 25 second "Courtesy Light Timer" shall reset at all doors closed.
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar" OR "Lift-Gate Ajar" OR "Lift-Gate Glass Ajar -> "Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"
<b>D -&gt; C.16</b> : 25 second "Courtesy Light Timer" resets at first door open. Does not reset with each additional door open.
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed" AND "Lift-Gate Closed" AND "Lift-Gate Glass Closed" -> "Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar"
D -> I.17: 25 seconds passed from all ajar doors closed event.
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar" OR "Lift-Gate Ajar" OR "Lift-Gate Glass Ajar -> ("Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed) AND "Courtesy Light Timer" expired.
I -> D.18: 25 second "Courtesy Light Timer" shall start at all doors closed.
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar" OR "Lift-Gate Ajar" OR "Lift-Gate Glass Ajar" -> "Driver Door Closed" AND "Page Closed
"Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"  F -> I.19: 25 seconds passed from ignition transitioning from RUN/Start to OFF.
"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF" AND "Courtesy Light Timer" expired
F -> C.20: 25 second "Courtesy Light Timer" starts at first door open. Does not reset with each additional door open.
"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF"  "Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed" AND "Lift-Gate Closed" AND "Lift-Gate Glass Closed" ->

"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar"
C -> E.21: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar" "Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start"
E -> F.22: 25 second "Courtesy Light Timer" shall start at Ignition transitioning from RUN/Start to OFF.
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed" "Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF"
D -> E.23: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"
"Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start"
E -> C.24: 25 second "Courtesy Light Timer" shall start at Ignition transitioning from RUN/Start to OFF.
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar"
"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF" <b>D -&gt; G.25</b> : Lock must occur using Key-fob, Keypad, or exterior door lock cylinder.
D -> G.25: Lock must occur using Key-lob, Keypad, or exterior door lock cylinder.
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"  "Keyfob / Dk Josk" OP "Keyrood Josk" OP "Cydinder Josk"
"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"  G -> E.26: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
G -> E.20. Legislative/in drive vehicle behavior is enabled during ignition Run/Start state
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed" AND
("Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock") AND ("Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start")
C -> G.27: "Courtesy Lighting Timer" shall continue counting down if door(s) left ajar after vehicle lock request is made (via keyfob/keypad/door cylinder). Transition to state shall occur at all doors closed.
"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar" -> "Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"
I -> G.28: Lock must occur using Key-fob, Keypad, or exterior door lock cylinder. Same
transition to state can occur if vehicle locked prior to all vehicle doors closed.
"Vehicle Ignition is OFF"
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"
"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
<b>G -&gt; I.29:</b> Transition to "Null" occurs after vehicle locking operation/state is complete/confirmed.
I -> E.30: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
"Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start"

## 5.2.3 Welcome/Farewell State determination with Battery Saver tie-in

The Control module containing the Welcome/Farewell State determination shall transition between its identified states slightly differently if the "Battery Saver" function, as defined in section 2.1.1 of FS-HU5T-14B476-AAG, is taken into consideration or not. The following section, diagram and list of requirements take it into account.




Figure 4: Welcome Farewell State Determination (with Battery Saver)

\*NOTE – Even though the diagram above has two separate "Null" states called out, they are referring to the same "Null" state.

A -> I.1: PK/Key Fob entered then went outside of Approach Detection range, currently set at 2.5 meters
Set at 2.5 meters
"Approach Detected" -> "Approach not Detected"
A -> I.2: Approach Detection timer set at 25 seconds. State shall expire if no action is
taken after initially detected and PK/Key fob remains within 2.5 meter range.
"Approach Detected" -> "Approach not Detected"
I -> A.3: 25 seconds Approach Detection starts after PK/Key Fob enters Approach
Detection range.
"Null" -> "Approach Detected"
A -> B.5: Unlock must occur using Key-fob, Keypad, or exterior door lock cylinder. 25
seconds "Courtesy Light Timer" starts at Unlock
"Approach Detected" -> "Approach not Detected"
"Keyfob/Pk unlock" OR "Keypad unlock" OR "Cylinder unlock"

B -> C.7: Battery saver timer (10 minutes by default) starts at first door open and resets
with each new door ajar.
·
("Driver Door Closed" -> "Driver Door Ajar") OR ("Passenger Door Closed" -> "Passenger
Door Ajar") OR ("Rear Left Door Closed" -> "Rear Left Door Ajar") OR ("Rear Right Door
Closed" -> "Rear Right Door Ajar") <b>B -&gt; I.10</b> : 25 second "Courtesy Light Timer" started at Unlock (via Key-fob, Keypad, or
exterior door lock cylinder). Timer resets with each additional unlock request made.
exterior door look cylinder). Filmer resets with each additional diffock request made.
"Keyfob/Pk unlock" OR "Keypad unlock" OR "Cylinder unlock"
AND Courtesy Light Timer expired -> "Null" state
I -> B.11: Unlock must occur using Key-fob, Keypad, or exterior door lock cylinder. 25
seconds "Courtesy Light Timer" starts at Unlock
"Null" -> "Keyfob/Pk unlock" OR "Keypad unlock" OR "Cylinder unlock"
B ->G.12: Lock must occur using Key-fob, Keypad, or exterior door lock cylinder.
2 POINE. Look made dodar doing redy look, redypad, or oxioner door look dylindor.
"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
C ->I.13: Timer expired 10 minutes (by default) after last door open.
("Daily and Doors Alice") OD "Doors alice" OD "Doors Alic
("Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right
Door Ajar") AND "Battery Saver Timer" expired -> "Null"  I -> C.14: Battery saver timer (10 minutes by default) starts at first door open and resets
with each new door ajar.
This can non accordant
("Driver Door Closed" -> "Driver Door Ajar") OR ("Passenger Door Closed" -> "Passenger
Door Ajar") OR ("Rear Left Door Closed" -> "Rear Left Door Ajar") OR ("Rear Right Door
Closed" -> "Rear Right Door Ajar")
C -> D.15: All vehicle doors have to be closed within 25 seconds of first door ajar in order for transition to occur. Otherwise state shall transition to "Null". 25 second "Courtesy
Light Timer" shall reset at all doors closed.
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right
Door Ajar" -> "Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door
Closed" AND "Rear Right Door Closed"
D -> C.16: Battery saver timer (10 minutes by default) starts at first door open and resets
with each new door ajar.
"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
"Rear Right Door Closed" -> "Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left
Door Ajar" OR "Rear Right Door Ajar"
<b>D</b> -> I.17: 25 seconds passed from all ajar doors closed event.
"Driver Deer Ajer" OD "December Deer Ajer" OD "Deer Left Deer Ajer" OD "Deer Left Deer Ajer" OD "Deer Deer Deer Ajer" OD "Deer Left Deer Ajer Deer Deer Ajer Deer Ajer Deer Deer Deer Ajer Deer Deer Deer Deer Deer Deer Deer D
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right Door Ajar" -> ("Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door
Closed" AND "Rear Right Door Closed") AND "Courtesy Light Timer" expired.
I -> D.18: 25 second "Courtesy Light Timer" shall start at all doors closed.
"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right
Door Ajar" OR "Lift-Gate Ajar" OR "Lift-Gate Glass Ajar" -> "Driver Door Closed" AND
"Passenger Door Closed" AND "Rear Left Door Closed" AND "Rear Right Door Closed"
<b>F -&gt; I.19</b> : 25 seconds passed from ignition transitioning from RUN/Start to OFF.
"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF" AND "Courtesy Light Timer"
expired
F -> C.20: Battery saver timer (10 minutes by default) starts at first door open and resets
with each new door ajar
, and the second
"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF"

	"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
	"Rear Right Door Closed" -> "Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left
	Door Ajar" OR "Rear Right Door Ajar"
	C -> E.21: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
	"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right
	Door Ajar"
	"Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start"
	E -> F.22: 25 second "Courtesy Light Timer" shall start at Ignition transitioning from
	RUN/Start to OFF.
	Trong dark to of the
	"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
	"Rear Right Door Closed"
	"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF"  D -> E.23: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
	D-> E.23. Legislative/in drive vehicle behavior is enabled during ignition Run/Start state
	"D D
	"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
	"Rear Right Door Closed"
	"Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start"
	E -> C.24:10 minute battery saver timer shall start at Ignition transitioning from RUN/Start
	to OFF.
	"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right
	Door Ajar" OR "Lift-Gate Ajar" OR "Lift-Gate Glass Ajar"
	"Vehicle Ignition is in Run/Start" -> "Vehicle Ignition is OFF"
	D -> G.25: Lock must occur using Key-fob, Keypad, or exterior door lock cylinder.
	"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
	"Rear Right Door Closed"
	"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
	G -> E.26: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
	g.g.mon. tanyotan otan
	"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
	"Rear Right Door Closed"
	"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
	"Vehicle Ignition is OFF" -> "Vehicle Ignition is in Run/Start"
	C -> G.27: "Courtesy Lighting Timer" shall continue counting down if door(s) left ajar after
	vehicle lock request is made (via keyfob/keypad/door cylinder). Transition to state shall
	occur at all doors closed.
	"Koyfoh/Dk look" OP "Koynod look" OP "Cylindar look"
	"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
	"Driver Door Ajar" OR "Passenger Door Ajar" OR "Rear Left Door Ajar" OR "Rear Right
	Door Ajar" -> "Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door
	Closed" AND "Rear Right Door Closed"
	I -> G.28: Lock must occur using Key-fob, Keypad, or exterior door lock cylinder. Same
	transition to state can occur if vehicle locked prior to all vehicle doors closed.
	"Vehicle Ignition is OFF"
	"Driver Door Closed" AND "Passenger Door Closed" AND "Rear Left Door Closed" AND
	"Rear Right Door Closed"
	"Keyfob/Pk lock" OR "Keypad lock" OR "Cylinder lock"
	G -> I.29: Transition to "Null" occurs after vehicle locking operation/state is
	complete/confirmed.
	C -> C.30: Battery saver timer (10 minutes by default) starts at first door open and resets
	with each new door ajar.
	("Driver Door Closed" -> "Driver Door Ajar") OR ("Passenger Door Closed" -> "Passenger
	Door Ajar") OR ("Rear Left Door Closed" -> "Rear Left Door Ajar") OR ("Rear Right Door
	Closed" -> "Rear Right Door Ajar")
	I -> E.31: Legislative/In drive vehicle behavior is enabled during Ignition Run/Start state
I	1 -> L.J. Legislative/in unive vehicle behavior is enabled duffing ignition Kuff/Staft State

"Vehicle	Ignition	is OFF"	->	"Vehicle	Ignition	is in	Run/Start"
VEHICLE	IGHILIOH	15 OFF		VEHICLE	IGHILIOH	15 111	Null/Stait

## 5.3 Exterior Illumination response based on Welcome/Farewell state

## 5.3.1 Exterior Front Illumination Algorithm

Exterior lights that are at the front of the vehicle and have functional use beyond "Welcome" and "Farewell". These include but aren't limited to:

- Low Beams
- Signature/Decorative LED Lamps
- Fog Lamps
- Front Side Markers
- Front Park Lamps

#### 5.3.1.1 Applicable Welcome Farewell State Transitions

	Illumination Algorithm Name	Headlamp switch position	State Determination Algorithm: as per section 5.2.2 or 5.2.3	Respond to Remote Start state	Respond to Delayed Accessory	Respond to Extended Play
R: 5.3.1.1-1	Exterior Front Illumination Algorithm	"Auto" or "OFF"	Both: 5.2.2 by default if not specifically mentioned	Yes (as per section 2.13.2 of FS HU5T- 14B476)	No	No

#### 5.3.1.2 Control Signal Definitions & Configurability

Exterior Front Illumination shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.3.1.2-1	"Fade ON"/Ramp up	"Steven's Power Law"	3 seconds	120ms	10 seconds	40ms
R: 5.3.1.2-2	"Fade OFF"/Ramp down	"Steven's Power Law"	5 seconds	120ms	10 seconds	40ms
R: 5.3.1.2-3	"Snap ON"/Step up	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.3.1.2-4	"Snap OFF"/Step down	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.3.1.2-5	Delay before "Fade ON"	N/A	0ms	0ms	2 seconds	120ms
R: 5.3.1.2-6	Delay before "Fade OFF"	N/A	0ms	0ms	2 seconds	120ms

**NOTE**: 1. "Steven's Power Law" curve owned and managed by Exterior Lighting group, who can specify a different curve if it better serves the final goal of "perceived linear ramping"

2. "Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Front Illumination" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

3. Definition of Control Signal (PWM) found within Appendix 1 "Exterior Lighting PWM Signal Specification"

#### 5.3.1.3 **Control Signal Value Targets**

The Control Signals tied to Exterior "Front Illumination" shall ramp or snap along the aforementioned curves until they reach a target value that's defined as either "ON/Embrace" or "OFF" under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Target Control Signal value	Minimum value	Maximum value	Config. Steps
R: 5.3.1.3-1	"ON/Embrace"	80% PWM	20% PWM	100% PWM	1%
R: 5.3.1.3-2	"OFF"	<= 15% PWM	0% PWM	15% PWM	1%

## 5.3.1.4 <u>Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for "Front Illumination".</u>




Figure 5: Front Illumination Control Signal transitions based on ARL requests.

A -> A.1: No action, remain OFF
A -> D.2: Illuminate to "ON/Embrace Level", step function
A ->C.3: Start "Fade ON" sequence (3 seconds by default)
C ->A.4: De-illuminate to "OFF" level, step function
D ->B.5: Start "Fade OFF" sequence (5 seconds by default)
D -> D.6: Remain at "ON/Embrace" level, reset state time-out timer
C ->A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function

C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"
from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %
Fade ON complete * Fade OFF total time.
C ->C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence
with each new request.
C ->D.10: "Fade ON" complete. Start state time-out timer.
C -> D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function
<b>B -&gt;B.12</b> : Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"
sequence with each new request.
B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.
<b>B -&gt;A.14</b> : Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function
B -> D.15: Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function
B ->C.16: Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"
from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %
Fade OFF complete * Fade ON total time.

NOTE: 1. Additional requirements called out under section 5.3.1.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response" 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1

- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

#### 5.3.1.5 **Additional requirements**

R: 5.3.1.5-1	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on new Fade request.
R: 5.3.1.5-2	Ignition transitions from OFF to RUN/Start: Front Illumination shall follow legislative requirements on Illumination behavior (can forego "Fade ON" or "Fade OFF" behavior/delays if in conflict legislative requirements)

#### 5.3.1.6 **Exterior Front Illumination Algorithm inhibits and overrides**

R: 5.3.1.6-1	
	algorithms that control Exterior Front Illumination
R: 5.3.1.6-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of
	BCM FS-HU5T-14B476-AAG shall inhibit Exterior Front Illumination Algorithm while feature
	is active
R: 5.3.1.6-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall
	inhibit Exterior Front Illumination Algorithm while feature is active
R: 5.3.1.6-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-
	AAG shall inhibit Exterior Front Illumination Algorithm while feature is active
R: 5.3.1.6-5	Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14B476-AAG
	shall inhibit Exterior Front Illumination Algorithm while feature is active.

## 5.3.2 Exterior Front Illumination Lighting Response

R: 5.3.2-1	Exterior Front Illumination shall illuminate in response to control signal ramping up
R: 5.3.2-2	Exterior Front Illumination shall de-illuminate in response to control signal ramping down
R: 5.3.2-3	When the control signal reaches the duty cycle matched to the desired Front Exterior
	Illumination lighting element's intensity level, the lighting element shall consistently illuminate
	to the same level each time
R: 5.3.2-4	Specific "ON", "ON/Embrace", "Snap ON" illumination level for each individual lighting element shall be specified by Vehicle Harmony Group in conjunction with Exterior Lighting group.

R: 5.3.2-5	Exterior Front Illumination Lighting elements shall meet the requirements specified in section 3.2.2 "Performance Requirements" unless otherwise specified by SME or Vehicle Harmony Group
R: 5.3.2-6	Exterior Front Illumination Lighting elements shall meet (or not violate) requirements labelled "Exterior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China applications.
R: 5.3.2-7	When the control signal reaches 0% duty cycle the desired Front Exterior Illumination lighting element's intensity level shall equal 0 (go to "OFF")
R: 5.3.2-8	During control signal "Fade ON" sequence, the Exterior Front Illumination lighting element shall Fade ON smoothly – no observable flickering.
R: 5.3.2-9	During control signal "Fade OFF" sequence, the Exterior Front Illumination lighting element shall Fade OFF smoothly – no observable flickering.
R: 5.3.2-10	During control signal "Snap ON" sequence, the Exterior Front Illumination lighting element shall Snap ON without flickering.
R: 5.3.2-11	During control signal "Snap OFF" sequence, the Exterior Front Illumination lighting element shall Snap OFF without flickering.
R: 5.3.2-12	Exterior Front Illumination Lighting response to ramping control signals shall not be inhibited if any of the individual exterior front lighting elements are malfunctioning/burnout.
R: 5.3.2-13	If the Control Signal, Power, or Ground to a specific Exterior Front Illumination lighting element is corrupted/disconnects, that specific lighting element shall default to "OFF" (deilluminated)

### 5.3.3 Exterior Rear Illumination Algorithm

Exterior Lights that are at the rear of the vehicle and have functional use beyond "Welcome" and "Farewell". These include but aren't limited to:

- Rear Corner Lamps
- Rear Corner Lamps
- Rear Applique Light
- Rear Corner Lamps
- Rear Parklamps

#### 5.3.3.1 **Applicable Welcome Farewell State Transitions**

	Illumination Algorithm Name	Headlamp switch position	State Determination Algorithm: as per section 5.2.2 or 5.2.3	Respond to Remote Start state	Respond to Delayed Accessory	Respond to Extended Play
R: 5.3.3.1-1	Exterior Rear Illumination Algorithm	"Auto" or "OFF"	Both: 5.2.2 by default if not specifically mentioned	Yes (as per section 2.13.2 of FS HU5T- 14B476)	No	No

#### 5.3.3.2 Control Signal Definitions & Configurability

Exterior Rear Illumination shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

R: 5.3.3.2-1	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.3.3.2-2	"Fade ON"/Ramp up	"Steven's Power Law"	3 seconds	120ms	10 seconds	40ms

R: 5.3.3.2-3	"Fade OFF"/Ramp down	"Steven's Power Law"	5 seconds	120ms	10 seconds	40ms
R: 5.3.3.2-4	"Snap ON"/Step up	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.3.3.2-5	"Snap OFF"/Step down	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.3.3.2-6	Delay before "Fade ON"	N/A	0ms	0ms	2 seconds	120ms
R: 5.3.3.2-7	Delay before "Fade OFF"	N/A	0ms	0ms	2 seconds	120ms

**NOTE**: 1. "Steven's Power Law" curve owned and managed by Exterior Lighting group, who can specify a different curve if it better serves the final goal of "perceived linear ramping"

#### 5.3.3.3 **Control Signal Value Targets**

The Control Signals tied to Exterior "Rear Illumination" shall ramp or snap along the aforementioned curves until they reach a target value that's defined as either "ON/Embrace" or "OFF" under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Target Control Signal value	Minimum value	Maximum value	Config. Steps
R: 5.3.3.3-1	"ON/Embrace"	80% PWM	20% PWM	100% PWM	1%
R: 5.3.3.3-2	"OFF"	<= 15% PWM	0% PWM	15% PWM	1%

**Note**: Target Control Signal Value for "ON/Embrace" and "OFF" shall vary depending on specific lighting element and controlling module. Above specified values are intended as a reference for remaining requirements

# 5.3.3.4 <u>Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for "Rear Illumination".</u>

<sup>2. &</sup>quot;Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Rear Illumination" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.




Figure 6: Rear Illumination Control Signal transitions based on ARL requests.

-	
	A -> A.1: No action, remain OFF
	A -> D.2: Illuminate to "ON/Embrace Level", step function
	A ->C.3: Start "Fade ON" sequence (3 seconds by default)
	C ->A.4: De-illuminate to "OFF" level, step function
	<b>D -&gt;B.5</b> : Start "Fade OFF" sequence (5 seconds by default)
	<b>D -&gt;D.6</b> : Remain at "ON/Embrace" level, reset state time-out timer
	C ->A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function
	C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"
	from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %
	Fade ON complete * Fade OFF total time.
	C ->C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence
	with each new request.
	C ->D.10: "Fade ON" complete. Start state time-out timer.
	C ->D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function
	<b>B -&gt;B.12</b> : Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"
	sequence with each new request.
	B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.
	<b>B -&gt;A.14</b> : Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function
	<b>B -&gt;D.15</b> : Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function
	<b>B -&gt;C.16</b> : Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"
	from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %
	Fade OFF complete * Fade ON total time.

**NOTE**: 1. Additional requirements called out under section 5.3.3.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response"

- 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1
- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

#### 5.3.3.1 Additional requirements

R: 5.3.3.1-1	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on
R: 5.3.3.1-2	new Fade request.  Ignition transitions from OFF to RUN/Start: Rear Illumination shall follow legislative requirements on Illumination behavior (can forego "Fade ON" or "Fade OFF" behavior/delays if in conflict legislative requirements)

# 5.3.3.2 <u>Exterior Rear Illumination Algorithm inhibits and overrides</u>

R: 5.3.3.2-1	Exterior Rear Illumination Algorithm shall be given the least priority over competing algorithms that control Exterior Rear Illumination
R: 5.3.3.2-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Rear Illumination Algorithm while feature is active
R: 5.3.3.2-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Rear Illumination Algorithm while feature is active
R: 5.3.3.2-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Rear Illumination Algorithm while feature is active
R: 5.3.3.2-5	Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Rear Illumination Algorithm while feature is active.

# 5.3.4 Exterior Rear Illumination Lighting Response

R: 5.3.4-1	Exterior Rear Illumination shall illuminate in response to control signal ramping up
R: 5.3.4-2	Exterior Rear Illumination shall de-illuminate in response to control signal ramping down
R: 5.3.4-3	When the control signal reaches the duty cycle matched to the desired Rear Exterior Illumination lighting element's intensity level, the lighting element shall consistently illuminate to the same level each time.
R: 5.3.4-4	Specific "ON", "ON/Embrace", "Snap ON" illumination level for each individual lighting element shall be specified by Vehicle Harmony Group in conjunction with Exterior Lighting group.
R: 5.3.4-5	Exterior Rear Illumination Lighting elements shall meet the requirements specified in section 3.2.2 "Performance Requirements", unless specified otherwise by SME or Vehicle Harmony Group
R: 5.3.4-6	Exterior Rear Illumination Lighting elements shall meet (or not violate) requirements labelled "Exterior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China applications.
R: 5.3.4-7	When the control signal reaches 0% duty cycle the desired Exterior Rear Illumination lighting element's intensity level shall equal 0 (go to "OFF")
R: 5.3.4-8	During control signal "Fade ON" sequence, the Exterior Rear Illumination lighting element shall Fade ON smoothly – no observable flickering.
R: 5.3.4-9	During control signal "Fade OFF" sequence, the Exterior Rear Illumination lighting element shall Fade OFF smoothly – no observable flickering.
R: 5.3.4-10	During control signal "Snap ON" sequence, the Exterior Rear Illumination lighting element shall Snap ON without flickering.
R: 5.3.4-11	During control signal "Snap OFF" sequence, the Exterior Rear Illumination lighting element shall Snap OFF without flickering.
R: 5.3.4-12	Exterior Rear Illumination Lighting response to ramping control signals shall not be inhibited if any of the individual exterior front lighting elements are malfunctioning/burnout.
R: 5.3.4-13	If the Control Signal, Power, or Ground to a specific Exterior Rear Illumination lighting element is corrupted/disconnects, that specific lighting element shall default to "OFF" (deilluminated)

### 5.3.5 Exterior Supplementary Illumination Algorithm:

Exterior lights that do not have any functional operation beyond "Welcome" and "Farewell", or require additional customer input to operate while vehicle is in Drive. These include but aren't limited to:

- Illuminated Door Handles
- Driver/Passenger Welcome Mats
- Puddle Lamps
- Running Board Illumination

#### 5.3.5.1 Applicable Welcome Farewell State Transitions

	Illumination Algorithm Name	Headlamp switch position	State Determination Algorithm: as per section 5.2.2 or 5.2.3	Respond to Remote Start state	Respond to Delayed Accessory	Respond to Extended Play
R: 5.3.5.1-1	Exterior Supplementary Illumination Algorithm	"Auto" or "OFF"	Both: 5.2.2 by default if not specifically mentioned	No	No	No

#### 5.3.5.2 Control Signal Definitions & Configurability

Exterior Supplementary Illumination shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.3.5.2-1	"Fade ON"/Ramp up	"Steven's Power Law"	3 seconds	120ms	10 seconds	40ms
R: 5.3.5.2-2	"Fade OFF"/Ramp down	"Steven's Power Law"	5 seconds	120ms	10 seconds	40ms
R: 5.3.5.2-3	"Snap ON"/Step up	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.3.5.2-4	"Snap OFF"/Step down	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.3.5.2-5	Delay before "Fade ON"	N/A	0ms	0ms	2 seconds	120ms
R: 5.3.5.2-6	Delay before "Fade OFF"	N/A	0ms	0ms	2 seconds	120ms

**NOTE**: 1. "Steven's Power Law" curve owned and managed by Exterior Lighting group, who can specify a different curve if it better serves the final goal of "perceived linear ramping"

#### 5.3.5.3 Control Signal Value Targets

The Control Signals tied to Exterior "Supplementary Illumination" shall ramp or snap along the aforementioned curves until they reach a target value that's defined as either "ON/Embrace" or "OFF" under "RQT-002004-

<sup>2. &</sup>quot;Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Supplementary Illumination" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Target Control Signal value	Minimum value	Maximum value	Config. Steps
R: 5.3.5.3-1	"ON/Embrace"	80% PWM	20% PWM	100% PWM	1%
R: 5.3.5.3-2	"OFF"	<= 15% PWM	0% PWM	15% PWM	1%

**Note**: Target Control Signal Value for "ON/Embrace" and "OFF" shall vary depending on specific lighting element and controlling module. Above specified values are intended as a reference for remaining requirements

# 5.3.5.4 Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for "Supplementary Illumination".




Figure 7: Supplementary Illumination Control Signal transitions based on ARL requests.

A -> A.1: No action, remain OFF
A -> D.2: Illuminate to "ON/Embrace Level", step function
A ->C.3: Start "Fade ON" sequence (3 seconds by default)
C -> A.4: De-illuminate to "OFF" level, step function
D ->B.5: Start "Fade OFF" sequence (5 seconds by default)
D -> D.6: Remain at "ON/Embrace" level, reset state time-out timer
C -> A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function
C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"
from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %
Fade ON complete * Fade OFF total time.
C -> C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence
with each new request.
C -> D.10: "Fade ON" complete. Start state time-out timer.
C -> D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function

<b>B -&gt;B.12</b> : Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"
sequence with each new request.
B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.
B ->A.14: Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function
<b>B -&gt;D.15</b> : Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function
B ->C.16: Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"
from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %
Fade OFF complete * Fade ON total time.

**NOTE**: 1. Additional requirements called out under section 5.3.5.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response"

- 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1
- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

#### 5.3.5.5 **Additional requirements**

R: 5.3.5.5-1	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on new Fade request.
R: 5.3.5.5-2	Ignition transitions from OFF to RUN/Start: Supplementary Illumination shall follow legislative requirements on Illumination behavior (can forego "Fade ON" or "Fade OFF" behavior/delays if in conflict legislative requirements)

#### 5.3.5.6 <u>Exterior Supplementary Illumination Algorithm inhibits and overrides</u>

R: 5.3.5.6-1	algorithms that control Exterior Supplementary Illumination
R: 5.3.5.6-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Supplementary Illumination Algorithm while feature is active
R: 5.3.5.6-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Supplementary Illumination Algorithm while feature is active
R: 5.3.5.6-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Supplementary Illumination Algorithm while feature is active
R: 5.3.5.6-5	Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14B476-AAG shall inhibit Exterior Supplementary Illumination Algorithm while feature is active.

# 5.3.6 Exterior Supplementary Illumination Lighting Response

R: 5.3.6-1	Exterior Supplementary Illumination shall illuminate in response to control signal ramping up
R: 5.3.6-2	Exterior Supplementary Illumination shall de-illuminate in response to control signal ramping
	down
R: 5.3.6-3	When the control signal reaches the duty cycle matched to the desired Front Exterior
	Illumination lighting element's intensity level, the lighting element shall consistently illuminate
	to the same level each time.
R: 5.3.6-4	Specific "ON", "ON/Embrace", "Snap ON" illumination level for each individual lighting element shall be specified by Vehicle Harmony Group in conjunction with Exterior Lighting group (if lighting element located on exterior of vehicle) or Interior Lighting group (if lighting element located in interior of vehicle.
R: 5.3.6-5	Exterior Supplementary Illumination Lighting elements shall meet the requirements specified in section 3.2.2 "Performance Requirements", unless specified otherwise by SME or Vehicle Harmony Group
R: 5.3.6-6	Exterior Supplementary Illumination Lighting elements shall meet (or not violate) requirements labelled "Exterior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1
	requirements labelled Exterior Lighting in section 3.2.3. Safety Requirements = 3.2.3.1

	"NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE
	applications, and 3.2.3.3 "China Requirements" for China applications.
R: 5.3.6-7	When the control signal reaches 0% duty cycle the desired Exterior Supplementary
	Illumination lighting element's intensity level shall equal 0 (go to "OFF")
R: 5.3.6-8	During control signal "Fade ON" sequence, the Exterior Supplementary Illumination lighting
	element shall Fade ON smoothly – no observable flickering.
R: 5.3.6-9	During control signal "Fade OFF" sequence, the Exterior Supplementary Illumination lighting
	element shall Fade OFF smoothly – no observable flickering.
R: 5.3.6-10	During control signal "Snap ON" sequence, the Exterior Supplementary Illumination lighting
	element shall Snap ON without flickering.
R: 5.3.6-11	During control signal "Snap OFF" sequence, the Exterior Supplementary Illumination lighting
	element shall Snap OFF without flickering.
R: 5.3.6-12	Exterior Supplementary Illumination Lighting response to ramping control signals shall not be
	inhibited if any of the individual Exterior Supplementary lighting elements are
	malfunctioning/burnout.
R: 5.3.6-13	If the Control Signal, Power, or Ground to a specific Exterior Supplementary Illumination
	lighting element is corrupted/disconnects, that specific lighting element shall default to "OFF"
	(de-illuminated)
R: 5.3.6-14	Shall meet Generic, Exterior lighting specific, and all applicable Market specific Reliability,
	Performance, Safety and Security requirements specified under section 3.2 "Quality".

# 5.4 Interior Illumination response based on Welcome/Farewell state

### 5.4.1 Courtesy Lamps Illumination Algorithm:

Lights that are the primary source of illumination within the vehicle's interior (can function as Demand lamps if vehicle specific implementation allows). These include but aren't limited to:

- o Dome Lamp(s)
- o Map Lamp(s)
- o Foot-well Lighting (if not tied to Ambient Lighting)

#### 5.4.1.1 <u>Applicable Welcome Farewell State Transitions</u>

	Illumination Algorithm Name	Headlamp switch position	State Determination Algorithm: as per section 5.2.2 or 5.2.3	Respond to Remote Start state	Respond to Delayed Accessory	Respond to Extended Play
R: 5.4.1.1-1	Courtesy Lamps Algorithm	"Auto" or "OFF"	5.2.3	No	No	No

#### 5.4.1.2 Control Signal Definitions & Configurability

Courtesy Lamps shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.4.1.2-1	"Fade ON"/Ramp up	"Theater Dimming"	3 seconds	100ms	10 seconds	100ms
R: 5.4.1.2-2	"Fade OFF"/Ramp down	"Theater Dimming"	5 seconds	100ms	10 seconds	100ms

R: 5.4.1.2-3	•	"Step	Less than 1	N/A	N/A	N/A
	ON"/Step up	Function"	microsecond			
R: 5.4.1.2-4	"Snap	"Step	Less than 1	N/A	N/A	N/A
	OFF"/Step	Function"	microsecond			
	down					
R: 5.4.1.2-5	Delay	N/A	0ms	0ms	2 seconds	100ms
	before					
	"Fade ON"					
R: 5.4.1.2-6	Delay	N/A	0ms	0ms	2 seconds	100ms
	before					
	"Fade OFF"					

**NOTE**: 1. "Theater Dimming" curve owned and managed by Interior Lighting group, who can specify a different curve if it better serves the final goal of "perceived linear ramping"

#### 5.4.1.3 **Control Signal Value Targets**

The Control Signals tied to Interior "Courtesy Lamps" shall ramp or snap along the aforementioned curves until they reach a target value that's defined as either "ON/Embrace" or "OFF" under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Target Control Signal value	Minimum value	Maximum value	Config. Steps
R: 5.4.	1.3-1 "ON/Embrace"	80% PWM	20% PWM	100% PWM	1%
R: 5.4.	1.3-2 "OFF"	<= 15% PWM	0% PWM	15% PWM	1%

**Note**: Target Control Signal Value for "ON/Embrace" and "OFF" shall vary depending on specific lighting element and controlling module. Above specified values are intended as a reference for remaining requirements

# 5.4.1.4 <u>Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for "Courtesy Lamps".</u>

<sup>2. &</sup>quot;Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Courtesy Lamps" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.




Figure 8: "Courtesy Lamps" Illumination Control Signal transitions based on ARL requests.

A -> A.1: No action, remain OFF
A -> D.2: Illuminate to "ON/Embrace Level", step function
A ->C.3: Start "Fade ON" sequence (3 seconds by default)
C ->A.4: De-illuminate to "OFF" level, step function
D ->B.5: Start "Fade OFF" sequence (5 seconds by default)
D -> D.6: Remain at "ON/Embrace" level, reset state time-out timer
C -> A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function
C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"
from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %
Fade ON complete * Fade OFF total time.
C -> C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence
with each new request.
C ->D.10: "Fade ON" complete. Start state time-out timer.
C -> D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function
<b>B -&gt;B.12</b> : Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"
sequence with each new request.
B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.
B ->A.14: Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function
<b>B -&gt;D.15</b> : Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function
<b>B -&gt;C.16</b> : Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"
from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %
Fade OFF complete * Fade ON total time.

**NOTE**: 1. Additional requirements called out under section 5.4.1.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response"

- 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1
- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

#### 5.4.1.5 Additional requirements

R: 5.4.1.1-1	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on new Fade request.
R: 5.4.1.1-2	Ignition transitions from OFF to RUN/Start: Courtesy Lamps Illumination shall follow legislative requirements on Illumination behavior (can forego "Fade ON" or "Fade OFF" behavior/delays if in conflict legislative requirements)

# 5.4.1.6 Courtesy Lamps Illumination Algorithm inhibits and overrides

R: 5.4.1.2-1	Courtesy Lamps Illumination Algorithm shall be given the least priority over competing			
	algorithms that control Courtesy Lamps Illumination			
R: 5.4.1.2-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of			
	BCM FS-HU5T-14B476-AAG shall inhibit Courtesy Lamps Illumination Algorithm while			
	feature is active			
R: 5.4.1.2-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall			
	inhibit Courtesy Lamps Illumination Algorithm while feature is active			
R: 5.4.1.2-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-			
	AAG shall inhibit Courtesy Lamps Illumination Algorithm while feature is active			
R: 5.4.1.2-5	Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14B476-AAG			
	shall inhibit Courtesy Lamps Illumination Algorithm while feature is active.			

# **5.4.2 Courtesy Lamps Illumination Lighting Response**

R: 5.4.2-1	Courtesy Lamps Illumination shall illuminate in response to control signal ramping up		
R: 5.4.2-2	Courtesy Lamps Illumination shall de-illuminate in response to control signal ramping down		
R: 5.4.2-3	When the control signal reaches the duty cycle matched to the desired Courtesy Lamps Illumination lighting element's intensity level, the lighting element shall consistently illuminate to the same level each time		
R: 5.4.2-4	Specific "ON", "ON/Embrace", "Snap ON" illumination level for each individual lighting element shall be specified by Vehicle Harmony Group in conjunction with Interior Lighting group.		
R: 5.4.2-5	Courtesy Lamps Illumination shall meet the dimming and illumination requirements specified in RQT-001601-012984 "Illumination and Dimming". Any deviations shall be reviewed and bought off by Interior Harmony Group.		
R: 5.4.2-6	Courtesy Lamps Illumination shall meet the general illumination color requirements specified in RQT-001601-012986 "General Illumination Color". Any deviations shall be reviewed and bought off by Interior Harmony Group.		
R: 5.4.2-7	Courtesy Lamps Illumination Lighting elements shall meet (or not violate) requirements labelled "Interior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China applications.		
R: 5.4.2-8	When the control signal reaches 0% duty cycle the desired Courtesy Lamps Illumination lighting element's intensity level shall equal 0 (go to "OFF")		
R: 5.4.2-9	During control signal "Fade ON" sequence, the Courtesy Lamps Illumination lighting element shall Fade ON smoothly – no observable flickering.		
R: 5.4.2-10	During control signal "Fade OFF" sequence, the Courtesy Lamps Illumination lighting element shall Fade OFF smoothly – no observable flickering.		
R: 5.4.2-11	Courtesy Lamps Illumination Lighting response to ramping control signals shall not be inhibited if any of the individual Courtesy Lamps lighting elements are malfunctioning/burnout.		
R: 5.4.2-12	If the Control Signal, Power, or Ground to a specific Courtesy Lamps Illumination lighting element is corrupted/disconnects, that specific lighting element shall default to "OFF" (deilluminated)		

### 5.4.3 Ambient Lighting Illumination Algorithm (without static sequential):

As the name implies, these lights vary their intensity depending on the ambient light level. Depending on the vehicle line, the customer can also configure the color of these lights. These include but aren't limited to:

- Cup Holders 0
- Lower Pass through 0
- Upper Pass through 0
- Door Release Handle 0
- Door map pocket 0

#### 5.4.3.1 **Applicable Welcome Farewell State Transitions**

	Illumination Algorithm Name	Headlamp switch position	State Determination Algorithm: as per section 5.2.2 or 5.2.3	Respond to Remote Start state	Respond to Delayed Accessory	Respond to Extended Play
R: 5.4.3.1-1	Ambient Lighting Illumination Algorithm (without Static Sequential)	"Auto" or "OFF"	5.2.3	No	No	No

#### 5.4.3.2 **Control Signal Definitions & Configurability**

Ambient Lighting Illumination (without static sequential) shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

R: 5.4.3.2-1	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.4.3.2-2	"Fade ON"/Ramp up	"Theater Dimming"	700ms	100ms	10 seconds	100ms
R: 5.4.3.2-3	"Fade OFF"/Ramp down	"Theater Dimming"	1700ms	100ms	10 seconds	100ms
R: 5.4.3.2-4	"Snap ON"/Step up	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.4.3.2-5	"Snap OFF"/Step down	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.4.3.2-6	Delay before "Fade ON"	N/A	0ms	0ms	2 seconds	100ms
R: 5.4.3.2-7	Delay before "Fade OFF"	N/A	0ms	0ms	2 seconds	100ms

NOTE: 1. "Theater Dimming" curve owned and managed by Interior Lighting group, who can specify a

different curve if it better serves the final goal of "perceived linear ramping"

2. "Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Ambient Lighting Illumination" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

#### 5.4.3.3 Control Signal Value Targets

The Control Signals tied to Exterior "Ambient Lighting Illumination" shall ramp or snap along the aforementioned curves until they reach a target value that's defined as either "ON/Embrace" or "OFF" under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Target Control Signal value	Minimum value	Maximum value	Config. Steps
R: 5.4.3.3-1	"ON/Embrace"	80% PWM	20% PWM	100% PWM	1%
R: 5.4.3.3-2	"OFF"	<= 15% PWM	0% PWM	15% PWM	1%

**Note**: Target Control Signal Value for "ON/Embrace" and "OFF" shall vary depending on specific lighting element and controlling module. Above specified values are intended as a reference for remaining requirements

# 5.4.3.4 <u>Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for "Ambient Lighting Illumination".</u>




Figure 9: "Ambient Lighting" Illumination Control Signal transitions based on ARL requests.

A -> A.1: No action, remain OFF
A -> D.2: Illuminate to "ON/Embrace Level", step function
A ->C.3: Start "Fade ON" sequence (3 seconds by default)
C ->A.4: De-illuminate to "OFF" level, step function
D ->B.5: Start "Fade OFF" sequence (5 seconds by default)
D -> D.6: Remain at "ON/Embrace" level, reset state time-out timer
C -> A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function
C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"
from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %
Fade ON complete * Fade OFF total time.

C ->C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence
with each new request.
C ->D.10: "Fade ON" complete. Start state time-out timer.
C -> D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function
B ->B.12: Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"
sequence with each new request.
B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.
<b>B -&gt;A.14</b> : Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function
B -> D.15: Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function
B ->C.16: Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"
from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %
Fade OFF complete * Fade ON total time.

**NOTE**: 1. Additional requirements called out under section 5.4.3.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response"

- 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1
- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

#### 5.4.3.5 **Additional requirements**

R: 5.4.3.5-1	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on new Fade request.
R: 5.4.3.5-2	For vehicles equipped with multi-colored LEDs, Ambient Lighting Illumination shall illuminate to customer selected color. Set to "signature color" by default (i.e. "Ice Blue" for Ford vehicles, "Lincoln White" for Lincoln vehicles) at each "Fade ON", "ON", or "Snap ON" event. Refer to RQT-Lincoln Chart (for Lincoln vehicles) or RQT-Ford Chart (for Ford vehicles) for Color and Intensity requirements.
R: 5.4.3.5-3	Ignition transitions from OFF to RUN/Start: Ambient Lighting Illumination shall follow legislative requirements on Illumination behavior (can forego "Fade ON" or "Fade OFF" behavior/delays if in conflict legislative requirements)

#### 5.4.3.6 Ambient Lighting Illumination Algorithm (without static sequential) inhibits and overrides

R: 5.4.3.6-1	Ambient Lighting Illumination Algorithm shall be given the least priority over competing algorithms that control Ambient Lighting Illumination
R: 5.4.3.6-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of BCM FS-HU5T-14B476-AAG shall inhibit Ambient Lighting Illumination Algorithm while feature is active
R: 5.4.3.6-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall inhibit Ambient Lighting Illumination Algorithm while feature is active
R: 5.4.3.6-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-AAG shall inhibit Ambient Lighting Illumination Algorithm while feature is active
R: 5.4.3.6-5	Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14B476-AAG shall inhibit Ambient Lighting Illumination Algorithm while feature is active.

# 5.4.4 Ambient Lighting Illumination (without Static Sequential) Lighting Response

R: 5.4.4-1	Ambient Lighting Illumination shall illuminate in response to control signal ramping up			
R: 5.4.4-2	Ambient Lighting Illumination shall de-illuminate in response to control signal ramping down			
R: 5.4.4-3	When the control signal reaches the duty cycle matched to the desired Ambient Lighting			
	Illumination lighting element's intensity level, the lighting element shall consistently illuminate			
	to the same level each time.			

R: 5.4.4-4	Specific "ON", "ON/Embrace", "Snap ON" illumination level for each individual lighting
	element shall be specified by Vehicle Harmony Group in conjunction with Interior Lighting
	group.
R: 5.4.4-5	Ambient Lighting Illumination shall meet the dimming and illumination requirements specified in RQT-001601-012984 "Illumination and Dimming". Any deviations shall be reviewed and
	bought off by Interior Harmony Group.
R: 5.4.4-6	Ambient Lighting Illumination shall meet the general illumination color requirements specified
	in RQT-001601-012986 "General Illumination Color". Any deviations shall be reviewed and bought off by Interior Harmony Group.
R: 5.4.4-7	Ambient Lighting Illumination elements shall meet (or not violate) requirements labelled
	"Interior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements"
	for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3
	"China Requirements" for China applications.
R: 5.4.4-8	When the control signal reaches 0% duty cycle the desired Ambient Lighting Illumination
	element's intensity level shall equal 0 (go to "OFF")
R: 5.4.4-9	During control signal "Fade ON" sequence, the Ambient Lighting Illumination element shall
	Fade ON smoothly – no observable flickering.
R: 5.4.4-10	During control signal "Fade OFF" sequence, the Ambient Lighting Illumination element shall
	Fade OFF smoothly – no observable flickering.
R: 5.4.4-11	Ambient Lighting Illumination Lighting response to ramping control signals shall not be
	inhibited if any of the individual Ambient Lighting elements are malfunctioning/burnout.
R: 5.4.4-12	If the Control Signal, Power, or Ground to a specific Ambient Lighting Illumination element is
	corrupted/disconnects, that specific lighting element shall default to "OFF" (de-illuminated)

### 5.4.5 Ambient Lighting Illumination Algorithm (with static sequential):

A "delight the customer" feature which utilized individual ambient lights within the interior of the vehicle and illuminates them in sequence to "wrap" around the vehicle occupants. This feature is only active during Welcome/Farewell while the Ignition is OFF.




Figure 10: NOTE: Static Sequential Ambient lighting response to Welcome/Farewell state

#### 5.4.5.1 **Applicable Welcome Farewell State Transitions**

Illumination Algorithm switch Name position	Determination Re	espond to emote Delayed Accessor	Extended
---	------------------	----------------------------------	----------

R: 5.4.5.1-1	Ambient	"Auto" or	5.2.3	No	No	No
	Lighting	"OFF"				
	Illumination					
	Algorithm					
	(with Static					
	Sequential)					

#### 5.4.5.2 Control Signal Definitions & Configurability

Ambient Lighting Illumination shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.4.5.2-1	"Fade ON"/Ramp up	"Theater Dimming"	700ms	100ms	10 seconds	100ms
R: 5.4.5.2-2	"Fade OFF"/Ramp down	"Theater Dimming"	1700ms	100ms	10 seconds	100ms
R: 5.4.5.2-3	"Snap ON"/Step up	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.4.5.2-4	"Snap OFF"/Step down	"Step Function"	Less than 1 microsecond	N/A	N/A	N/A
R: 5.4.5.2-5	Delay before "Fade ON"	N/A	0ms	0ms	2 seconds	100ms
R: 5.4.5.2-6	Delay before "Fade OFF"	N/A	0ms	0ms	2 seconds	100ms

**NOTE**: 1. "Theater Dimming" curve owned and managed by Interior Lighting group, who can specify a different curve if it better serves the final goal of "perceived linear ramping"

#### 5.4.5.3 **Control Signal Value Targets**

The Control Signals tied to Interior "Ambient Lighting Illumination" shall ramp or snap along the aforementioned curves until they reach a target value that's defined as either "ON/Embrace" or "OFF" under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Target Control Signal value	Minimum value	Maximum value	Config. Steps
R: 5.4.5.1-1	"ON/Embrace"	80% PWM	20% PWM	100% PWM	1%
R: 5.4.5.1-2	"OFF"	<= 15% PWM	0% PWM	15% PWM	1%

**NOTE**: Target Control Signal Value for "ON/Embrace" and "OFF" shall vary depending on specific lighting element and controlling module. Above specified values are intended as a reference for remaining requirements

# 5.4.5.4 <u>Control Signal response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for "Ambient Lighting Illumination".</u>

<sup>2. &</sup>quot;Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Ambient Lighting Illumination" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.




Figure 11: "Ambient Lighting" Illumination Control Signal transitions based on ARL requests.

A -> A.1: No action, remain OFF		
A -> D.2: Illuminate to "ON/Embrace Level", step function		
A ->C.3: Start "Fade ON" sequence (3 seconds by default)		
C ->A.4: De-illuminate to "OFF" level, step function		
<b>D -&gt;B.5</b> : Start "Fade OFF" sequence (5 seconds by default)		
D -> D.6: Remain at "ON/Embrace" level, reset state time-out timer		
C ->A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function		
C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"		
from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %		
Fade ON complete * Fade OFF total time.		
C ->C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence		
with each new request.		
C ->D.10: "Fade ON" complete. Start state time-out timer.		
C ->D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function		
<b>B -&gt;B.12</b> : Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"		
sequence with each new request.		
B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.		
B ->A.14: Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function		
B -> D.15: Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function		
<b>B -&gt;C.16</b> : Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"		
from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %		
Fade OFF complete * Fade ON total time.		
A ->E.17: Begin Welcome Static Sequential		

E -> D.18: Static Sequential complete. Transition ambient light color from signature color		
to last user selected color after complete.		
E -> D.19: Interrupt Static Sequential. Immediately transition ambient lighting to last user-		
selected color.		
D ->F.20: Begin Farewell Static Sequential		
F -> A.21: Static Sequential complete. All ambient lighting should be off.		
F -> A.22: Interrupt "Static Sequential" sequence. Immediately transition ambient lighting		
to "OFF".		

**NOTE**: 1. Additional requirements called out under section 5.4.5.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response"

- 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1
- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

#### 5.4.5.5 Additional requirements

R: 5.4.5.3-1	Sync Screen), then the Algorithm shall only respond to Welcome/Farewell states if it is enabled (shall not respond/illuminate if disabled, and be forced OFF)
R: 5.4.5.3-2	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on new Fade request.
R: 5.4.5.3-3	For vehicles equipped with multi-colored LEDs, Ambient Lighting Illumination shall illuminate to "signature color" during "Welcome" phase (i.e. "Ice Blue" for Ford vehicles, "Lincoln White" for Lincoln vehicles) at each "Fade ON", "ON", or "Snap ON" event. Refer to RQT-Lincoln Chart (for Lincoln vehicles) or RQT-Ford Chart (for Ford vehicles) for Color and Intensity requirements.
R: 5.4.5.3-4	For vehicles equipped with multi-colored LEDs, Ambient Lighting Illumination shall illuminate to (or remain in) customer selected color during Farewell phase. Set to "signature color" by default (i.e. "Ice Blue" for Ford vehicles, "Lincoln White" for Lincoln vehicles) at each "Fade ON", "ON", or "Snap ON" event. Refer to RQT-Lincoln Chart (for Lincoln vehicles) or RQT-Ford Chart (for Ford vehicles) for Color and Intensity requirements.

#### 5.4.5.5.1 Static Sequential Triggers

"Static Sequential" is an additional feature which impacts vehicles equipped with multicolor LEDs (currently limited to Lincoln vehicle applications).

# R: 5.4.5.3.1-1 Static Sequential shall be broken down into two broad phases: "Static Sequential Fade ON" and "Static Sequential Fade OFF".

Trigger name	Trigger input
"Static Sequential Fade ON"	IGN transition to RUN/Start
"Static Sequential Fade OFF"	IGN transition to OFF/Accy

#### 5.4.5.5.2 Static Sequential "Groups"

"Static Sequential" shall illuminate or de-illuminate specific locations/groups of ambient lights within the vehicle cockpit after "Static Sequential Fade ON" and "Static Sequential Fade OFF" triggers have occurred (respectively).

Light group name	Light group location
G1	Cup holders
G2	Lower Pass Through
G3	Upper Pass Through
G4	Front Doors
G5	Rear Doors

	G6	Front and Rear Foot wells		
R: 5.4.5.3.2-	"Static Sequential Fade ON" trigger shall be			
	at a time (sequentially) in order from G1 to 0			
	group locations subject to change and shall	require buyoff from Vehicle Harmony group		
	as well as Interior Lighting group.			
R: 5.4.5.3.2-	Multicolor Ambient lighting LEDs shall illumi	nate to vehicle signature color during "Static		
	Sequential Fade ON" event. ("Ice Blue" for I	Ford vehicles, "Lincoln White" for Lincoln		
	vehicles, exact color targets shall be provided by Vehicle Harmony team)			
R: 5.4.5.3.2-	For vehicles equipped with Multicolor Ambient Lighting LEDs, they shall transition from			
	signature color to last user selected color/intensity after "Static Sequential Fade ON"			
	sequence is complete (last lighting group has illuminated).			
R: 5.4.5.3.2-	"Static Sequential Fade OFF" trigger shall be used to begin de-illuminating Light groups			
	one at a time (sequentially) in order from G6 to G1 (G6, G5, G4, G3, G2, then G1). Light			
	group locations subject to change and shall	require buyoff from Vehicle Harmony group		
	as well as Interior Lighting group.			

#### 5.4.5.5.3 <u>Static Sequential Definitions & Configurability</u>

Besides being able to configure specific lighting groups and their order, the feature shall also allow for additional configurability of time delays between illuminating each group, duration a specific lighting group shall take to Fade ON/OFF, time to maintain "signature color" after last lighting group has illuminated before transitioning to customer selected color and intensity, and time to transition from "signature color" to customer selected color and intensity

	Time based config. parameter	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.4.5.3.3-1	"Time delay between consecutive group illumination"	300ms	100ms	2 seconds	100ms
R: 5.4.5.3.3-2	"Single Group Fade ON duration"	1200ms	100ms	2 seconds	100ms
R: 5.4.5.3.3-3	"Single Group Fade OFF duration"	1200ms	100ms	2 seconds	100ms
R: 5.4.5.3.3-4	"Time delay before transitioning from 'signature color' to 'last selected customer color and intensity"	1800ms	100ms	2 seconds	100ms
R: 5.4.5.3.3-5	"'Signature color' to 'last selected customer color and intensity' fading transition time"	1500ms	100ms	2 seconds	100ms

#### 5.4.5.6 Ambient Lighting Illumination Algorithm (with static sequential) inhibits and overrides

R: 5.4.5.4-1				
	algorithms that control Ambient Lighting Illumination			
R: 5.4.5.4-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of			
	BCM FS-HU5T-14B476-AAG shall inhibit Ambient Lighting Illumination Algorithm while			
	feature is active			
R: 5.4.5.4-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall			
	inhibit Ambient Lighting Illumination Algorithm while feature is active			
R: 5.4.5.4-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-			
	AAG shall inhibit Ambient Lighting Illumination Algorithm while feature is active			
R: 5.4.5.4-5 Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14				
	shall inhibit Ambient Lighting Illumination Algorithm while feature is active.			

# 5.4.6 Ambient Lighting Illumination (with Static Sequential) Lighting Response

R: 5.4.6-1	Ambient Lighting shall illuminate to the vehicle's signature color ("Ice Blue" for Ford vehicles, "Lincoln White" for Lincoln vehicles) when the illumination algorithm requests the "ON/Embrace" illumination level – as identified in RQT-001601-012986 "General Illumination Color".)
R: 5.4.6-2	Ambient Lighting shall illuminate to the driver selected color and intensity when the illumination algorithm requests the "ON/Drive" illumination level.
R: 5.4.6-3	When the control signal reaches the duty cycle matched to the desired Ambient Lighting Illumination lighting element's intensity level, the lighting element shall consistently illuminate to the same level each time
R: 5.4.6-4	Specific "ON/Embrace" illumination level for each individual lighting element shall be specified by Vehicle Harmony Group in conjunction with Interior Lighting group.
R: 5.4.6-5	Ambient Lighting Illumination shall meet the dimming and illumination requirements specified in RQT-001601-012984 "Illumination and Dimming". Any deviations shall be reviewed and bought off by Interior Harmony Group.
R: 5.4.6-6	Ambient Lighting Illumination shall meet the general illumination color requirements specified in RQT-001601-012986 "General Illumination Color". Any deviations shall be reviewed and bought off by Interior Harmony Group.
R: 5.4.6-7	Ambient Lighting Illumination elements shall meet (or not violate) requirements labelled "Interior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China applications.
R: 5.4.6-8	When the control signal reaches 0% duty cycle the desired Ambient Lighting Illumination element's intensity level shall equal 0 (go to "OFF")
R: 5.4.6-9	During control signal "Fade ON" sequence, the Ambient Lighting Illumination element shall Fade ON smoothly – no observable flickering.
R: 5.4.6-10	During control signal "Fade OFF" sequence, the Ambient Lighting Illumination element shall Fade OFF smoothly – no observable flickering.
R: 5.4.6-11	Ambient Lighting Illumination Lighting response to ramping control signals shall not be inhibited if any of the individual Ambient Lighting elements are malfunctioning/burnout.
R: 5.4.6-12	If the Control Signal, Power, or Ground to a specific Ambient Lighting Illumination element is corrupted/disconnects, that specific lighting element shall default to "OFF" (de-illuminated)

## 5.4.7 Dimmable Backlighting Illumination Algorithm:

Interior lighting that is not specifically used to illuminate the cabin but instead assist in either the find-ability or display of components OR switches within the interior of the vehicle. These lighting elements respond to inputs and changes in exterior ambient light level to transition between user-selectable "Day-time" and "Night-time" levels. The driver cannot configure the color of these lighting elements.

Dimmable Backlighting can exist in the following zones / vehicle-areas

- Door trim switch illumination
- Cluster switch illumination
- o Engine Start/Stop button backlighting
- Instrument Cluster Backlighting/Indicators

#### 5.4.7.1 <u>Applicable Welcome Farewell State Transitions</u>

	Illumination Algorithm Name	Headlamp switch position	State Determination Algorithm: as per section 5.2.2 or 5.2.3	Respond to Remote Start state	Respond to Delayed Accessory	Respond to Extended Play
R: 5.4.7.1.1-1	Dimmable Backlighting Illumination Algorithm	"Auto"	Both: 5.2.2	No	No	No

#### 5.4.7.2 Control Signal Definitions & Configurability

Dimmable Backlighting Illumination shall respond to changes in its driving Control Signal which is driven by transitions of Welcome/Farewell states

	Control Signal Response	Control Signal Curve	Default Duration	Minimum Duration	Max Duration	Config. Steps
R: 5.4.7.1.2-1	"Fade ON"/Ramp up	"Smooth Dimming"	40ms	40ms	20.480 seconds	(40ms*2^x), where x is the number of shifts
R: 5.4.7.1.2-2	"Fade OFF"/Ramp down	"Smooth Dimming"	40ms	40ms	20.480 seconds	(40ms*2^x), where x is the number of shifts
R: 5.4.7.1.2-3	"Snap ON"/Step up	"Smooth Dimming"	40ms	40ms	20.480 seconds	(40ms*2^x), where x is the number of shifts
R: 5.4.7.1.2-4	"Snap OFF"/Step down	"Smooth Dimming"	40ms	40ms	20.480 seconds	(40ms*2^x), where x is the number of shifts
R: 5.4.7.1.2-5	Delay before "Fade ON"	N/A	0ms	0ms	2 seconds	100ms
R: 5.4.7.1.2-6	Delay before "Fade OFF"	N/A	0ms	0ms	2 seconds	100ms

**Note**: 1. "Smooth Dimming" curve owned and managed by Interior Lighting group, who can specify a different curve if it better serves the final goal of "perceived linear ramping". Refer to ES-H1BT-1A278-AA-VX for additional details

2. "Fade ON" vs "Fade OFF" vs. "Snap ON" vs. "Snap OFF" behavior shall be called out under "Day-time Dimmable Backlighting Illumination" sections under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

#### 5.4.7.3 **Control Signal Value Targets**

Dimmable Backlighting shall rely on an Ambient Light Sensor (ALS) in order to satisfy the requirements called out under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

The Dimmable Backlighting shall illuminate to either a "Day-time" user selectable level or to a "Night-time" user selectable level for instances of "Fade ON", "ON, or "Snap ON" called out under "RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1" for Ford vehicles and "RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1" for Lincoln vehicles.

	ARL call-out	Exterior Ambient Light Level	Illumination Level target	Default Level (if no user selection/battery reset)	Selectable Steps
R: 5.4.7.1.3-1	"ON/Embrace"	"Day-time"	User selected "Day-time" illumination level	Maximum "Day- time" illumination level	6 (1 lowest, 6 being highest)

R: 5.4.7.1.3-2	"ON/Embrace"	"Night-time"	User selected "Night-time" illumination level	Maximum "Night- time" illumination level	12 (1 lowest, 12 being highest)
R: 5.4.7.1.3-3	"OFF"	N/A	OFF	Off	N/A

#### Note:

- 1. Refer to RQT-002004-021873 General Illumination Dimming Rev. XX for illumination intensity values for "Day-time" and "Night-time" selectable steps.
- 2. "Day-time" and "Night-time" determination function based off of Ambient Light Sensor is owned by BCM and called out under sections 2.3.10 "Autolamps", 2.3.19 "Headlamps Arbitrator" and 2.2.16 "Day-time Dimmable Backlighting" within BCM FS HU5T-14B476-AAG
- 3. Refer to latest version of ES-H1BT-1A278-AA-VX for information on how to drive PWM values based on target intensity values.

# 5.4.7.4 <u>Illumination level response based on Welcome/Farewell state transitions and "Vehicle Harmony" team specified behavior for Dimmable Backlighting Illumination.</u>




Figure 12: Dimmable Backlighting Illumination Control Signal transitions based on ARL requests.

	A -> A.1: No action, remain OFF
	A -> D.2: Illuminate to "ON/Embrace Level", step function. Go to "Day-time" or "Night-
	time" level based on exterior ambient light level
_	A ->C.3: Start "Fade ON" sequence (3 seconds by default)

C ->A.4: De-illuminate to "OFF" level, step function
D ->B.5: Start "Fade OFF" sequence (5 seconds by default)
D ->D.6: Remain at "ON/Embrace" level, reset state time-out timer
C -> A.7: Interrupt "Fade ON" sequence, de-illuminate to "OFF" level, step function
C ->B.8: Interrupt "Fade ON" sequence, begin "Fade OFF" sequence. Start "Fade OFF"
from same point/level "Fade ON" reached at time of interruption. "Fade OFF" time = %
Fade ON complete * Fade OFF total time.
C ->C.9: Start "Fade ON" sequence after first request. Do not reset "Fade ON" sequence
with each new request.
C ->D.10: "Fade ON" complete. Start state time-out timer.
C -> D.11: Interrupt "Fade ON" sequence, illuminate to "ON/ Embrace" level, step function
<b>B -&gt;B.12</b> : Start "Fade OFF" sequence after first request. Do not reset "Fade OFF"
sequence with each new request.
B ->A.13: "Fade OFF" complete. Remain OFF for duration of state.
<b>B -&gt;A.14</b> : Interrupt "Fade OFF" sequence, de-illuminate to "OFF" level, step function
<b>B -&gt;D.15</b> : Interrupt "Fade OFF" sequence, illuminate to "ON/ Embrace" level, step function
<b>B -&gt;C.16</b> : Interrupt "Fade OFF" sequence, begin "Fade ON" sequence. Start "Fade ON"
from same point/level "Fade OFF" reached at time of interruption. "Fade ON" time = %
Fade OFF complete * Fade ON total time.
E ->F.17: Follow Smooth Dimming Day to Night transition (transtime_amb_down) as
defined in ES-H1BT-1A278-AA-VX
F ->E.18: Smooth Dimming Night to Day transition (transtime_amb_up) as defined in ES-
H1BT-1A278-AA-VX

**NOTE**: 1. Additional requirements called out under section 5.4.7.2 Control Signal Definitions and Configurability in satisfying behavior listed under "Control signal response"

- 2. Ford ARL: RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. 1
- 3. Lincoln ARL: RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. 1

# 5.4.7.5 Responding to changes in "Exterior Light Level" during Welcome/Farewell State transitions

The Dimmable Backlighting Algorithm function is expected to react to changes in Exterior Ambient Lighting as they occur.

	Exterior Ambient Light level transition	Current Illumination Level Target	Next Illumination Level Target	Control Signal Response
R: 5.4.7.1.5-1	"Day-time" to "Night-time"	User selected "Day-time" illumination level	User selected "Night-time" illumination level	"Smooth Dimming Day to Night transition (transtime_amb_down)" as defined in ES-H1BT- 1A278-AA-VX
R: 5.4.7.1.5-2	"Night-time" to "Day-time"	User selected "Night-time" illumination level	User selected "Day-time" illumination level	"Smooth Dimming Night to Day transition (transtime_amb_up)" as defined in ES-H1BT- 1A278-AA-VX

**Note**: 1. "Day-time" to "Night-time" and vice versa transitions require that the Headlamp Switch be kept in the "AUTO" position and that the vehicle be equipped with an Ambient Light Sensor; otherwise illumination shall follow headlamp switch position ("ON"/"POS" = "Night-time" and "OFF" = "Day-time")

#### 5.4.7.6 Additional requirements

R: 5.4.7.1.6-1	Ignition transitions from OFF to RUN/Start: Dimmable Backlighting shall follow legislative
	requirements on Illumination behavior (can forego "Fade ON" or "Fade OFF" behavior/delays
	if in conflict legislative requirements)

	If Driver is allowed to directly control Backlighting within the vehicle during Welcome/Farewell states (via headlamp switch, dimmer switch etc.), the requests shall be honored immediately: transitioning between "Day-time", "Night-time" and "OFF" levels; or between user selectable levels for "Day-time" and "Night-time".
R: 5.4.7.1.6-3	Conflicting requests sent mid illumination ramping (Fade ON -> Fade OFF before Fade ON complete, or Fade OFF -> Fade ON before Fade OFF complete): New Fade request shall be honored starting at illumination level that was reached by previous request while maintaining specified ramp rate (shall complete in lesser time). No time delay required before acting on new Fade request.
R: 5.4.7.1.6-4	Day-Time Dimmable Backlighting Illumination Algorithm will also support Smooth Dimming capability as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VX"

### 5.4.7.7 <u>Dimmable Backlighting Illumination Algorithm inhibits and overrides</u>

R: 5.4.7.1.7-1	Day-Time Dimmable Backlighting Illumination Algorithm shall be given the least priority over competing algorithms that control Day-Time Dimmable Backlighting
R: 5.4.7.1.7-2	Activating "Perimeter Alarm Mode" or "Panic Alarm" feature as per sections 2.5-4 or 2.5-7 of BCM FS-HU5T-14B476-AAG shall inhibit Day-Time Dimmable Backlighting Illumination Algorithm while feature is active
R: 5.4.7.1.7-3	Activating "Silent Mode" feature as per section 3.2-1 of BCM FS-HU5T-14B476-AAG shall inhibit Day-Time Dimmable Backlighting Illumination Algorithm while feature is active
R: 5.4.7.1.7-4	Activating "Key-Off-Load Mode" feature as per section 2.14.6-7 of BCM FS-HU5T-14B476-AAG shall inhibit Day-Time Dimmable Backlighting Illumination Algorithm while feature is active
R: 5.4.7.1.7-5	Activating "Post-Crash Alert" feature as per section 2.5-78 of BCM FS-HU5T-14B476-AAG shall inhibit Day-Time Dimmable Backlighting Illumination Algorithm while feature is active.

# 5.4.8 Dimmable Backlighting Illumination Response

R: 5.4.7.2-1	Dimmable Backlighting Illumination shall illuminate in response to control signal ramping up
R: 5.4.7.2-2	Dimmable Backlighting Illumination shall de-illuminate in response to control signal ramping
	down
R: 5.4.7.2-3	When the control signal reaches the duty cycle matched to the desired Dimmable
	Backlighting Illumination lighting element's intensity level, the lighting element shall
	consistently illuminate to the same level each time.
R: 5.4.7.2-4	Specific "ON/Day-Embrace", "ON/Night-Embrace", "ON/Day-pulse", and "ON/Night-pulse"
	illumination level for each individual lighting element shall be specified by Vehicle Harmony
	Group in conjunction with Interior Lighting group.
R: 5.4.7.2-5	Dimmable Backlighting Illumination shall meet the dimming and illumination requirements
	specified in RQT-001601-012984 "Illumination and Dimming". Any deviations shall be
	reviewed and bought off by Interior Harmony Group.
R: 5.4.7.2-6	Dimmable Backlighting Illumination shall meet the general illumination color requirements
	specified in RQT-001601-012986 "General Illumination Color". Any deviations shall be
	reviewed and bought off by Interior Harmony Group.
R: 5.4.7.2-7	Dimmable Backlighting Illumination elements shall meet (or not violate) requirements labelled
	"Interior Lighting" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements"
	for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3
	"China Requirements" for China applications.
R: 5.4.7.2-8	When the control signal reaches 0% duty cycle the desired Dimmable Backlighting
	Illumination lighting element's intensity level shall equal 0 (go to "OFF")
R: 5.4.7.2-9	During control signal "Fade ON" sequence, the Dimmable Backlighting Illumination lighting
	element shall Fade ON smoothly – no observable flickering.
R: 5.4.7.2-10	During control signal "Fade OFF" sequence, the Dimmable Backlighting Illumination lighting
	element shall Fade OFF smoothly – no observable flickering.
R: 5.4.7.2-11	During control signal "Pulsing", the Dimmable Backlighting element shall transition between
	its "ON/Day-Embrace" and "ON/Day-Pulse" (10% of ON/Day-Embrace by default) or

	"ON/Night-Embrace" and "ON/Night-Pulse" (10% of ON/Night-Embrace by default) at 1 HZ (by default) smoothly – no visible flickering
R: 5.4.7.2-12	Dimmable Backlighting Illumination Lighting response to ramping control signals shall not be inhibited if any of the individual Dimmable Backlighting lighting elements are malfunctioning/burnout.
R: 5.4.7.2-13	If the Control Signal, Power, or Ground to a specific Dimmable Backlighting Illumination lighting element is corrupted/disconnects, that specific lighting element shall default to "OFF" (de-illuminated)

# 5.5 <u>Vehicle cockpit display(s) response based on Welcome/Farewell state</u>

Vehicles equipped with customer facing displays or display devices i.e. heads-up-displays, shall be required to respond based off of welcome/farewell state. These displays or display devices include but aren't limited to:

- Center-stack Welcome/Farewell Display (Sync Screen)
- Cluster Welcome/Farewell Display (TFT/Digital portion)
- Heads-up displays (aHUD)

### 5.5.1 Center-stack Welcome/Farewell Displays (Sync Screen):

R: 5.5.1-1	Center-stack Display shall follow the Welcome Farewell state transitions as they're listed in section 5.2.2 "Welcome/Farewell State determination without Battery saver tie-in" with the addition of "Extended Play" as described in section 3.1.2 under "Additional States"		
R: 5.5.1-2	Ignition transitions from OFF to RUN/Start: Center-stack display shall transition from its previous display (can be OFF) to the last screen that was selected/enabled by the Driver while in RUN/Start. Transition animation (if any) shall be determined by HMI group		
R: 5.5.1-3	Center-stack Display shall be capable of displaying a "Welcome" animation when given the correct inputs. Length and content of "Welcome" animation shall be determined by HMI group (3.3 seconds by default)		
R: 5.5.1-4	Center-stack Display shall be capable of displaying a "Farewell" animation when given the correct inputs. Length and content of "Farewell" animation shall be determined by HMI group (3.3 seconds by default)		
R: 5.5.1-5	IGN OFF, Center-stack Display OFF: Center-stack Display shall remain OFF when Welcome/Farewell state transitions to "Null", "Remote Start", "Approach Detection", "Illuminated Entry", or "Vehicle Locking" following state transitions as per section 5.2.2 "Welcome/Farewell state determination without Battery Saver tie-in"		
R: 5.5.1-6	IGN OFF, Center-stack Display ON: Center-stack Display shall turn OFF when Welcome/Farewell state transitions to "Null", "Remote Start", "Approach Detection", "Illuminated Entry", or "Vehicle Locking" following state transitions as per section 5.2.2 "Welcome/Farewell state determination without Battery Saver tie-in"		
R: 5.5.1-7	IGN OFF, Center-stack Display OFF: Center-stack Display shall turn ON, display "Welcome" animation and transition to "Welcome" display when Welcome/Farewell state transitions to "Courtesy Lighting". If no "Welcome" display present/loaded, then transition to last in-drive screen after "Welcome" animation complete. If no "Welcome" animation present/loaded, then transition directly to "Welcome" display and continue displaying for duration of w/f state. If neither present, then transition to last in-drive screen when Welcome/Farewell state transitions to "Courtesy Lighting"		
R: 5.5.1-8	IGN OFF, Center-stack Display OFF: Center-stack Display shall turn ON display "Welcome" animation and transition to "Welcome" display when Welcome/Farewell state transitions to "Courtesy Lighting Delay". If no "Welcome" display present/loaded, then transition to last indrive screen after "Welcome" animation complete. If no "Welcome" animation present/loaded, then transition directly to "Welcome" display and continue displaying for duration of w/f state. If neither present, then transition to last in-drive screen when Welcome/Farewell state transitions to "Courtesy Lighting Delay"		
R: 5.5.1-9	IGN OFF, Center-stack Display OFF: Center-stack Display shall turn ON and display "Welcome" animation (if present/loaded) when Welcome/Farewell state transitions to "IGN RUN/Start" and then transition to In-drive display.		

R: 5.5.1-10	IGN OFF, Center-stack Display ON: Center-stack Display shall remain ON (display "Welcome" display if present or last in-drive screen if "Welcome" display not present, and not re-display "Welcome" animation) when Welcome/Farewell state transitions to "Courtesy Lighting"
R: 5.5.1-11	IGN OFF, Center-stack Display ON: Center-stack Display shall remain ON (display "Welcome" display if present or last in-drive screen if "Welcome" display not present, and not re-display "Welcome" animation) when Welcome/Farewell state transitions to "Courtesy Lighting Delay"
R: 5.5.1-12	IGN OFF, Center-stack Display ON: Center-stack Display shall remain ON and display "Welcome" animation (if present/loaded) when Welcome/Farewell state transitions to "IGN RUN/Start" and then transition to In-drive display.
R: 5.5.1-13	Center-stack Display OFF and IGN transitions to OFF: Welcome/Farewell state shall transition to "Extended Play" state and remain OFF while in that state.
R: 5.5.1-14	Center-stack Display ON and IGN transitions to OFF: Welcome/Farewell state shall transition to "Extended Play" state and Center-stack Display shall continue displaying screen/info it was while in Drive.
R: 5.5.1-15	IGN OFF, Center-stack Display OFF and Driver manually toggles "Extended Play" mode via hard button: Welcome/Farewell state shall transition to "Extended Play" state, Center-stack Display shall turn ON and display last screen that was active while in-drive (not required to display "Welcome" animation)
R: 5.5.1-16	IGN OFF, Center-stack Display ON and Driver manually toggles "Extended Play" mode via hard button: Welcome/Farewell state shall transition to "Extended Play" state, Center-stack Display shall remain ON and display last screen that was active while in-drive (not required to display "Welcome" animation)
R: 5.5.1-17	All vehicle doors closed, IGN transitioned to OFF, Center-stack Display ON or OFF: Center-stack Display shall display "Farewell" graphic then transition to OFF Welcome/Farewell state transitions to "Courtesy Lighting"
R: 5.5.1-18	Vehicle door(s) Ajar, IGN transitioned to OFF, Center-stack Display ON or OFF: Center-stack Display shall display "Farewell" graphic then transition to OFF Welcome/Farewell state transitions to "Courtesy Lighting Delay"
R: 5.5.1-19	IGN transitioned to OFF, "Farewell" graphic already displayed, Center-stack Display OFF: Center-stack Display shall turn ON and display "Welcome" animation and remain ON when Welcome/Farewell state transitions to "Courtesy Lighting"
R: 5.5.1-20	"Welcome Animation", "Welcome Display", "Farewell Animation", and "Farewell Display" shall be specified by Vehicle Harmony Group, HMI group, and Studio graphics group
R: 5.5.1-21	Center-stack Display shall meet the illumination requirements specified in RQT-001601-012984 "Illumination and Dimming". Any deviations shall be reviewed and bought off by Interior Harmony Group.
R: 5.5.1-22	Center-stack Display shall meet the general illumination color requirements specified in RQT-001601-012986 "General Illumination Color". Any deviations shall be reviewed and bought off by Interior Harmony Group.
R: 5.5.1-23	Center-stack display shall meet (or not violate) requirements labelled "Vehicle Displays" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China applications.

# 5.5.2 Cluster during Welcome/Farewell:

The Cluster is required to respond to Welcome-Farewell state transitions:

### 5.5.2.1 <u>Welcome/Farewell screen definitions:</u>

R: 5.5.2.1-1	Cluster Display Area shall be capable of displaying a "Welcome Animation". HMI team in
	conjunction with Vehicle Harmony team to determine content and length of "Welcome
	animation".

R: 5.5.2.1-2	Cluster Display Area shall be capable of displaying a "Farewell Animation". HMI team in conjunction with Vehicle Harmony team to determine content and length of "Farewell animation".		
R: 5.5.2.1-3	Cluster Display Area shall be capable of displaying a "Welcome Display" (looping graphic or static image). HMI team in conjunction with Vehicle Harmony team to determine content and length of "Welcome Display".		
R: 5.5.2.1-4	Cluster Display Area shall be capable of displaying a "Farewell Display" (looping graphic or static image). HMI team in conjunction with Vehicle Harmony team to determine content and length of "Farewell Display"		
R: 5.5.2.1-5	If both "Welcome Animation" and "Welcome Display" are configured ON. "Welcome Display" shall enable after "Welcome Animation" is complete. HMI team in conjunction with Vehicle Harmony team to determine transitions between animation and display.		
R: 5.5.2.1-6	If both "Farewell Animation" and "Farewell Display" are configured ON. "Farewell Display" shall enable after "Farewell Animation" is complete. HMI team in conjunction with Vehicle Harmony team to determine transitions between animation and display.		
R: 5.5.2.1-7	"Welcome Animation", "Welcome Display", "Farewell Animation", and "Farewell Display" shall be specified by Vehicle Harmony Group, HMI group, and Studio graphics group		
R: 5.5.2.1-8	Cluster Display shall meet the illumination requirements specified in RQT-001601-012984 "Illumination and Dimming". Any deviations shall be reviewed and bought off by Interior Harmony Group.		
R: 5.5.2.1-9	Cluster Display shall meet the general illumination color requirements specified in RQT-001601-012986 "General Illumination Color". Any deviations shall be reviewed and bought off by Interior Harmony Group.		
R: 5.5.2.1-10	Cluster display shall meet (or not violate) requirements labelled "Vehicle Displays" in section 3.2.3. "Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2 "ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China applications.		

#### 5.5.2.2 <u>Welcome/Farewell States vs. Screens transitions</u>




Figure 13: Welcome Farewell state transitions for Cluster Welcome/Farewell display.

Note: "=" requires that the signal value must be true for at least 200ms. Transitions denoted by "->" requires that the signal value changed to the specified value within 200ms

• -> A.1: Initialize/Bus Wake up. Cluster is not required to remember last time it was in at
time of local sleep upon wake up.
A -> B.2: Transition should enable "Welcome Animation" and transition to "Welcome
Display" after complete while in "Welcome State". If "Welcome Animation" or "Welcome
Display" not configured or not present then screen can remain "Blank" while in "Welcome"
state.
B -> A.3
A ->B.4:
<b>B</b> ->D.5: Occurs if "Welcome Animation" interrupted by change in ignition.
D ->B.6: Occurs if "Farewell Animation" interrupted by change in ignition
<b>B</b> ->C.7: "Welcome Animation" required to complete before transition if configured ON. If
"Welcome Animation" not configured ON or not present, then "& Animation Complete (2.2
sec)" does not apply.
C -> D.8: Transition should only occur if no other conflicting (higher priority) feature is
requiring to use same display area as Farewell Graphic (do not suppress warnings etc.
that would be displayed in same area as farewell graphic)
D -> A.9: "Farewell Animation" required to complete before transition if configured ON. If
"Farewell Animation" not configured ON or not present, then "& Animation Complete (2.2
sec)" does not apply.
D ->E.10: "Farewell Animation" required to complete before transition if configured ON. If
"Farewell Animation" not configured ON or not present, then "& Animation Complete (2.2
sec)" does not apply.
E ->A.11
A ->E.12
A ->E.13: Transition occurs at Local Sleep.

#### NOTE:

- 1. "=" requires that the signal value must be true for at least 200ms. Transitions denoted by "->" requires that the signal value changed to the specified value within 200ms
- 2. "Welcome" state mapped to "Courtesy lighting" and "Courtesy Lighting Delay", "In-Drive" mapped to "Ignition ON Powertrain systems active" and "Ignition ON Powertrain systems not active", and "Farewell" mapped to "Illuminated Exit" as defined in RQT-002004-021878 DNA Welcome-Farewell Strategy Rev. X for Ford vehicles and RQT-002004-022094 Lincoln Embrace Welcome and Farewell Behavior Rev. X for Lincoln vehicles. Any state called out in RQT documents not mapped in above transition diagram shall be treated as "Blank".

### 5.5.3 HUD Welcome/Farewell Displays (aHUD):

	HUD Welcome/Farewell Displays shall follow the Welcome Farewell state transitions as
R: 5.5.3-1	they're listed in section 5.2.2 "Welcome/Farewell State determination without Battery saver
	tie-in"
R: 5.5.3-2	Ignition OFF HUD not initialized: HUD shall initialize when Welcome/Farewell state
	transitions to "Approach Detection", "Illuminated Entry", "Courtesy Lighting", or "Courtesy
	Lighting Delay", as per section 5.2.2 "Welcome/Farewell state determination without Battery
	Saver tie-in".
R: 5.5.3-3	Ignition OFF HUD not initialized: HUD shall not initialize (de-initialize) when
	Welcome/Farewell state transitions to "Remote Start", "Null", "Vehicle Locking" as per
	section 5.2.2 "Welcome/Farewell state determination without Battery Saver tie-in".
R: 5.5.3-4	Ignition OFF HUD not initialized, HUD equipped with "Welcome" graphic/display: HUD shall
	initialize, display "Welcome" graphic/display (as determined by HMI group) then transition to
	in-drive display when Welcome/Farewell state transitions to "Ignition RUN/START".
R: 5.5.3-5	Ignition OFF HUD not initialized, HUD not equipped with "Welcome" graphic/display: HUD
	shall initialize, then transition to in-drive display when Welcome/Farewell state transitions to
	"Ignition RUN/START".
R: 5.5.3-6	Ignition OFF HUD initialized: HUD shall remain initialized when Welcome/Farewell state
	transitions to "Approach Detection", "Illuminated Entry", "Courtesy Lighting", or "Courtesy
	Lighting Delay", as per section 5.2.2 "Welcome/Farewell state determination without Battery
D 5507	Saver tie-in".
R: 5.5.3-7	Ignition OFF HUD initialized: HUD shall de-initialize/turn off when Welcome/Farewell state
	transitions to "Remote Start", "Null", or "Vehicle Locking" as per section 5.2.2
R: 5.5.3-8	"Welcome/Farewell state determination without Battery Saver tie-in".  Ignition RUN/Start, HUD turned OFF: HUD shall remain "OFF" for remainder of "Farewell"
K. 5.5.5-6	States ("Illuminated Exit", "Courtesy Lighting", "Courtesy Lighting Delay", and "Vehicle
	Locking"). Shall return to "Welcome" States after "Vehicle Locking" state has occurred.
R: 5.5.3-9	Ignition RUN/Start, HUD active with in-drive display, HUD not configured with "Farewell"
14. 3.3.3-3	graphic/display: HUD shall turn OFF when Welcome/Farewell state transitions to "Illuminated
	Exit". Shall remain "OFF" for remainder of "Farewell" States ("Courtesy Lighting", "Courtesy
	Lighting Delay", and "Vehicle Locking"). Shall return to "Welcome" States after "Vehicle
	Locking" state has occurred.
R: 5.5.3-10	Ignition RUN/Start, HUD active with in-drive display, HUD configured with "Farewell"
	graphic/display: HUD shall display "Farewell" graphic/display and turn OFF when
	Welcome/Farewell state transitions to "Illuminated Exit". Shall remain "OFF" for remainder of
	"Farewell" States ("Courtesy Lighting", "Courtesy Lighting Delay", and "Vehicle Locking").
	Shall return to "Welcome" States after "Vehicle Locking" state has occurred.
R: 5.5.3-11	HUD shall meet the illumination requirements specified in RQT-001601-012984 "Illumination
	and Dimming". Any deviations shall be reviewed and bought off by Interior Harmony Group.
R: 5.5.3-12	HUD shall meet the general illumination color requirements specified in RQT-001601-012986
	"General Illumination Color". Any deviations shall be reviewed and bought off by Interior
	Harmony Group.
R: 5.5.3-13	HUD shall meet (or not violate) requirements labelled "Vehicle Displays" in section 3.2.3.
	"Safety Requirements" – 3.2.3.1 "NAFTA Requirements" for NAFTA applications, 3.2.3.2
	"ECE Requirements" for ECE applications, and 3.2.3.3 "China Requirements" for China
	applications.

# 5.6 <u>"Other" vehicle lighting elements or part assemblies' response</u> based on Welcome/Farewell state

This category is used to call out specific lighting elements or part assemblies' which don't necessarily fit within the aforementioned categories (or provide a "lighting" based output) but still respond to welcome/farewell state transitions. The exact behavior of these lighting elements or part assemblies' is owned by other feature owners/groups, with their own separate specifications. Examples include:

- Illuminated Seat Belt Buckle
- Engine Start Stop LED
- Night Lock Indication
- Illuminated Running Board Deployment
- Auto-fold mirrors

R: 5.6-1	Turn signal behavior dictated by Ford Body Security-Locking Group, and is dependent on local market requirements/features.		
R: 5.6-2	Engine Start Stop LED behavior dictated by Ford Body Security-Locking Group, and is dependent on local market requirements/features (By default turns ON when brake pedal is depressed, turns OFF when brake pedal is released)		
R: 5.6-3	Night Lock indication dictated by Ford Body Security-Locking Group, and is dependent on local market requirements/features.		
R: 5.6-4	Autofold Mirrors dictated by Ford Body Security-Locking Group, and is dependent on local market requirements/features.		
R: 5.6-5	Illuminated Running Board Deployment dictated by Ford Body Electronics Group		
R: 5.6-6	Illuminated Seat belt behavior is dictated by Interior Lighting group		
R: 5.6-7	cHUD behavior dictated by Ford Upperbody Electronics group		

# **6 FEATURE VARIANT DESIGN ARCHITECTURE**

# 6.1 Electrical Architecture - Lincoln Vehicles

Please note that the feature does not require specific modules (except the BCM) to be present on a vehicle, and is instead tailored to the content of the vehicle. The following section is a generic starting point to show how functions are allocated based off vehicle content and desired functionality.

# 6.1.1 Electrical Topology

Lincoln Embrace topology diagrams for the following architectures:

• CGEA 1.3

#### 6.1.1.1 Combined Network/Block Diagram

The following combined network/block diagram is a generic starting point, and the actual topology should be consulted for each specific implementation




Figure 14: Lincoln: Lincoln Embrace Combined Network/Block Diagram

### 6.1.2 Common Requirements

#### 6.1.2.1 Participating ECUs

Generic list of participating ECUs provided in table below. Functionality along with Publisher and Subscriber requirements will change based on vehicle content.

Rqm't Num	ECU	Requirement	
R: 6.1.2-1	BCM	CAN Publisher, LIN Publisher	
R: 6.1.2-2	LDM	LIN Subscriber	
R: 6.1.2-3	R-FCM	LIN Subscriber	
R: 6.1.2-4	ALM	LIN Subscriber	
R: 6.1.2-5	OHC	LIN Subscriber	

R: 6.1.2-6	HLS	LIN Subscriber
R: 6.1.2-7	DDM	CAN Subscriber
R: 6.1.2-8	PDM	CAN Subscriber
R: 6.1.2-9	IPC	CAN Subscriber
R: 6.1.2-10	APIM	CAN Publisher, CAN Subscriber
R: 6.1.2-11	FCIMB	CAN Subscriber
R: 6.1.2-12	RACM	CAN Subscriber
R: 6.1.2-13	aHUD	CAN Subscriber
R: 6.1.2-14	SCCM	CAN Subscriber
R: 6.1.2-15	TMS	CAN Subscriber
R: 6.1.2-16	SDLC	CAN Publisher, CAN Subscriber

#### 6.1.2.2 **Performance and Functional Voltage Ranges**

For this feature, Performance Voltage Range is the same as the Functional Range. It shall be noted that below 9v.

Rqm't Num	Туре	Voltage Range
R: 6.1.2-17	Performance	9-16v
R: 6.1.2-18	Functional	6-16v

#### 6.1.2.3 **Signal Requirements**

The following section lists all of the signals required to complete the desired behaviors required by the Feature. It links the logical data-flows used within this document to the actual CAN OR LIN signals which shall actually be used by the modules.

#### 6.1.2.3.1 CAN Signal Requirements

Requirement	Signal Database Detail	Value
	Signal Name	Dimming_Lvl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange

Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	BCM
Subscribing ECU	APIM, IPC, DDM, PDM, FCIMB, SCCM, RACM
Subscribing Function	APIM: Interior Day-time Dimmable Backlighting Illumination Algorithm FCIMB: Interior Dimmable Backlighting Illumination Algorithm IPC: Interior Dimmable Backlighting Illumination Algorithm DDM: Interior Dimmable Backlighting Illumination Algorithm PDM: Interior Dimmable Backlighting Illumination Algorithm SCCM: Interior Dimmable Backlighting Illumination Algorithm RACM: Interior Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Litval
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	APIM, IPC, DDM, PDM, FCIMB, SCCM, RACM, TMS
	Subscribing Function	APIM: Interior Dimmable Backlighting Illumination Algorithm FCIMB: Interior Dimmable Backlighting Illumination Algorithm IPC: Interior Dimmable Backlighting Illumination Algorithm DDM: Interior Dimmable Backlighting Illumination Algorithm

PDM: Interior Dimmable Backlighting Illumination Algorithm SCCM: Interior Dimmable Backlighting Illumination Algorithm RACM: Interior Dimmable Backlighting Illumination Algorithm TMS: Interior Dimmable Backlighting Illumination
Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Delay_Accy
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	IPC
	Subscribing Function	IPC: Vehicle Display Cluster Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	HMI_HMIMode_St
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS3 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
Publisher Latency Requirements	Publisher Latency	If microprocessor is awake: <= 51ms
	If microprocessor is asleep: <=121ms	
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep

Updates Signal while asleep	Updates on change
Network Wake Up	Wake up network on signal change to non-OFF value
Max latency before signal is valid on Network wakeup	<= 50ms
Max latency before signal is valid on reset	<= 120ms
CAN Node Type	HS3
Signal Domain	Refer to data dictionary
Signal Transmit Strategy	Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	APIM
Subscribing ECU	FCIMB, RACM
Subscribing Function	FCIMB: Interior Dimmable Backlighting Illumination Algorithm RACM: Interior Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Ignition_Status
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	1000ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	APIM, IPC, AHUD, RACM
	Subscribing Function	APIM: Vehicle Display Center-stack Welcome/Farewell IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell RACM: Vehicle Display Center-stack Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatDrv_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	1000ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to Closed, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	DDM, APIM, IPC, aHUD, RACM
	Subscribing Function	DDM: Exterior Supplementary Illumination Algorithm APIM: Vehicle Display Center-stack Welcome/Farewell IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell RACM: Vehicle Display Center-stack Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatPsngr_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	1000ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to Closed, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms

CA	N Node Type	HS1
Sig	nal Domain	Refer to data dictionary
Sig	nal Transmit Strategy	Event Periodic
Sig	nal Send Type	OnChange
Sig	nal Transmit Cycle Time	500 ms
	d-to-End Latency quirements	<=250 ms
Puk	blishing ECU	BCM
Sub	oscribing ECU	PDM, APIM, IPC, AHUD, RACM
Sub	oscribing Function	PDM: Exterior Supplementary Illumination Algorithm APIM: Vehicle Display Center-stack Welcome/Farewell IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell RACM: Vehicle Display Center-stack Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatRI_B_ActI
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep	If signal is not equal to Closed, then allow for network
	Inhibitor	sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	IPC, AHUD
	Subscribing Function	IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatRr_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN

Signal refresh rate	500 ms
Publishing Interval (ms)	<= 40ms
Publisher Latency	If microprocessor is awake: <= 51ms
Requirements	If microprocessor is asleep: <=121ms
Publishing Network Sleep Inhibitor	If signal is not equal to Closed, then allow for network sleep but not for local sleep
Updates Signal while asleep	Updates on change
Network Wake Up	Wake up network on signal change
Max latency before signal is valid on Network wakeup	<= 50ms
Max latency before signal is valid on reset	<= 120ms
CAN Node Type	HS1
Signal Domain	Refer to data dictionary
Signal Transmit Strategy	Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	BCM
Subscribing ECU	IPC, AHUD
Subscribing Function	IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	PudLamp_D_Rq
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	DDM, PDM, AHUD

Subscribing Function	DDM: Exterior Supplementary Illumination Algorithm PDM: Exterior Supplementary Illumination Algorithm aHUD: Vehicle Display aHUD Welcome/Farewell
----------------------	---

Requirement	Signal Database Detail	Value
	Signal Name	PudLampDrv_D_Rq
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250ms
	Publishing ECU	BCM
	Subscribing ECU	DDM
	Subscribing Function	DDM: Exterior Supplementary Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	PudLampPsngr_D_Rq
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value

Max latency before signal is valid on Network wakeup	<= 50ms
Max latency before signal is valid on reset	<= 120ms
CAN Node Type	HS1
Signal Domain	Refer to data dictionary
Signal Transmit Strategy	Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<= 250 ms
Publishing ECU	BCM
Subscribing ECU	PDM
Subscribing Function	PDM: Exterior Supplementary Illumination Algorithm

#### 6.1.2.3.2 CAN Error Handling for Signal Gateway Messages

Requirements for signals that go missing either due to SNA or NC for a period of time, as per document name: "Diagnostic Fault Coverage and DTC Numbers Design Consideration", section 3.5 "Detection of faults caused by signal content and data values received from other ECUs"

R: 6.1.2-19	If a Signal gateway message containing the transmitted signal has an update bit which shows "not updated" for less than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall continue using last known value of the signal
R: 6.1.2-20	If a Signal gateway message containing the transmitted signal has an update bit which shows "not updated" for greater than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall use the signal's default value as listed in the data dictionary

#### 6.1.2.3.3 CAN Error Handling for Frame Gateway Messages

Requirements for Frame Message that go missing due to SNA or NC for a period of time as per document name: "Diagnostic Fault Coverage and DTC Numbers Design Consideration", section 3.5 "Detection of faults caused by signal content and data values received from other ECUs"

R: 6.1.2-21	If a Frame gateway message goes missing for less than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall continue using last known value of the signal received in the last Frame message.
R: 6.1.2-22	If a Frame gateway message goes missing for greater than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall use the signal's default value as listed in the data dictionary

#### 6.1.2.3.4 LIN Signal Requirements

It should be noted that the following section does not cover the level of details included under the previous "CAN Signal Requirements", since that level of details is owned and controlled by the LIN module owner, and contained within the LDFs.

The intention of this section is to list the required LIN signals to ensure that they are not discarded due to any future LDF updates.

Requirement   Signal Database Detail	Value
--------------------------------------	-------

Signal Name	Dimming_lvl	
Source Network	LIN	
Signal refresh rate	<=40ms	
Signal Domain	Refer to Data Dictionary	
Signal Transmit Strategy	<=40ms Event Periodic	
Signal Send Type	OnChange	
Signal Transmit Cycle Time	<=40ms Event Periodic	
Publishing ECU	BCM	
Subscribing ECU	HLS	
Subscribing Function	HLS: Interior Day-time Dimmable Backlighting Illumination Algorithm	

Requirement   Signal Database Detail		Value	
	Signal Name	Litval	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
	Signal Domain	Refer to Data Dictionary	
Signal Transmit Strategy		<=40ms Event Periodic	
Signal Send Type		OnChange	
	Signal Transmit Cycle Time	<=40ms Event Periodic	
	Publishing ECU	BCM	
	Subscribing ECU	HLS	
	Subscribing Function	HLS: Interior Day-time Dimmable Backlighting Illumination Algorithm	

Requirement	Signal Database Detail	Value	
	Signal Name	Ignition_Status	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
	Signal Domain	Refer to Data Dictionary	
	Signal Transmit Strategy	<=40ms Event Periodic	
	Signal Send Type	OnChange	
	Signal Transmit Cycle Time	<=40ms Event Periodic	
	Publishing ECU	BCM	
	Subscribing ECU	LDM, R-FCM, ALM, OHC	
	LDM: Exterior Front Illumination Algorithm; R-FCM: Exterior Rear Illumination Algorithm; ALM: Interior Ambient Light Illumination (with St Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Sequential) Algorithm OHC: Interior Courtesy Lamps Illumination Algo		

Requirement	Signal Database Detail	Value	
Signal Name		Wfsuperstate	
Source Network		LIN	
	Signal refresh rate	<=40ms	

Signal Domain	Refer to Data Dictionary	
Signal Transmit Strategy	<=40ms Event Periodic	
Signal Send Type	OnChange	
Signal Transmit Cycle Time	<=40ms Event Periodic	
Publishing ECU	BCM	
Subscribing ECU	LDM, R-FCM	
Subscribing Function	LDM: Exterior Front Illumination Algorithm; R-FCM: Exterior Rear Illumination Algorithm;	

Requirement	Signal Database Detail	Value	
	Signal Name	Wfsubstate	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
	Signal Domain	Refer to Data Dictionary	
	Signal Transmit Strategy	<=40ms Event Periodic	
	Signal Send Type	OnChange	
	Signal Transmit Cycle Time	<=40ms Event Periodic	
	Publishing ECU BCM		
	Subscribing ECU	LDM, R-FCM	
	Subscribing Function	LDM: Exterior Front Illumination Algorithm; R-FCM: Exterior Rear Illumination Algorithm;	

Requirement	Signal Database Detail	Value	
	Signal Name	WelcomeFarewell_State	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
	Signal Domain	Refer to Data Dictionary	
	Signal Transmit Strategy	<=40ms Event Periodic	
	Signal Send Type	OnChange	
	Signal Transmit Cycle Time	<=40ms Event Periodic	
	Publishing ECU	BCM	
	Subscribing ECU	ALM, OHC	
Subscribing Function  Subscribing Function  Sequential) Algorithm  ALM: Interior Ambient Light Illumin Sequential) Algorithm		ALM: Interior Ambient Light Illumination (without Static	

Requirement	Signal Database Detail	Value	
	Signal Name	WelcomeFarewell_Substate	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
Signal Domain		Refer to Data Dictionary	
Signal Transmit Strategy		<=40ms Event Periodic	
	Signal Send Type	OnChange	
Signal Transmit Cycle Time <=40ms Event Periodic		<=40ms Event Periodic	
Publishing ECU BCM		BCM	

Subscribing ECU	ALM, OHC
Subscribing Function	ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm OHC: Interior Courtesy Lamps Illumination Algorithm

Requirement	Signal Database Detail	Value	
	Signal Name	Customer_Color	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
	Signal Domain	Refer to Data Dictionary	
	Signal Transmit Strategy	<=40ms Event Periodic	
	Signal Send Type	OnChange	
	Signal Transmit Cycle Time	<=40ms Event Periodic	
	Publishing ECU	BCM	
	Subscribing ECU	ALM	
Subscribing Function Seq ALM		ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm	

Requirement	Signal Database Detail	Value	
	Signal Name	Customer_Intensity	
	Source Network	LIN	
	Signal refresh rate	<=40ms	
	Signal Domain	Refer to Data Dictionary	
	Signal Transmit Strategy	<=40ms Event Periodic	
	Signal Send Type	OnChange	
	Signal Transmit Cycle Time	<=40ms Event Periodic	
	Publishing ECU	BCM	
	Subscribing ECU	ALM	
Subscribing Function Sequential) Algorit ALM: Interior Ambi		ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm	

# 6.1.2.3.5 <u>Linking Logical Data Flows to CAN/LIN Signals</u>

Rqmt #	Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
R: 6.1.2.3.4-	Ignition Status	Vehicle Ignition is OFF	Ignition_Status	OFF
		Vehicle Ignition is Accessory		Accessory
		Vehicle Ignition is Run		RUN
		Vehicle Ignition is Start		Start
		Not supported		Unknown

		Not supported		Invalid
R: 6.1.2.3.4-	Driver Door	Driver Door Ajar	DrStatDrv_B_Actl	Ajar
	Status	Driver Door Closed		Closed
R: 6.1.2.3.4-	Passenger Door Status	Passenger Door Ajar	DrStatPsngr_B_ActI	Ajar
		Passenger Door Closed		Closed
R: 6.1.2.3.4-	Rear Left Door	Rear Left Door Ajar	DrStatRI_B_ActI	Ajar
	Status	Rear Left Door Closed		Closed
R: 6.1.2.3.4-	Rear Right Door Status	Rear Right Door Ajar	DrStatRr_B_Actl	Ajar
		Rear Right Door Closed		Closed
	Battery Saver Timer	Battery Saver Timer Active	Courtesy_Bsave_Stat	No_Effect
R: 6.1.2.3.4-		Battery Saver Timer Expired		Off
		Not supported		Unknown
		Not supported		Invalid
	Delayed Accessory	Delayed Accessory True	Delay_Accy	ON
R: 6.1.2.3.4-	•	Delayed Accessory False		OFF
	Extended Play	Extended Play True	HMI_HMIMode_St	On
R: 6.1.2.3.4-		Extended Play False		OffMode
		Not supported		Phone
		Not supported		Climate
		Not supported		Load_Shed_Active
		Not supported		Invalid

# 6.1.3 Lincoln Vehicle ECU specific requirements

## 6.1.3.1 Body Control Module (BCM)

The Body Control Module (BCM) shall be responsible for doing the Welcome Farewell State determination (both with and without battery saver) and then either transmitting the state information (via CAN or LIN) or transmitting a control signal to a specific lighting element that is directly connected to it.

#### 6.1.3.1.1 Over-arching requirements

R: 6.1.3.1.1-1	The BCM shall contain its Performance Latency within the End-to-End latency specified in
	section 3.2.2.1 "Performance Latency Requirements"
	The BCM shall take into account the requirements contained within section 3.2.3 "Safety
R: 6.1.3.1.1-2	Requirements" to ensure that no lighting element that it directly controls (via control
K. 0.1.3.1.1-2	signal) ends up violating any requirement (specific to the market the target vehicle shall be
	sold in) within the aforementioned section.
R: 6.1.3.1.1-3	The BCM shall take into account the requirements contained within section 3.2.4 "Security
	Requirements" to ensure that no lighting element that it directly controls (via control
	signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.1.1-1	The BCM shall meet the publisher requirements for all the signals it has been identified as
	a publisher to within section 6.1.2.3 "Signal Requirements"
R: 6.1.3.1.1-1	The BCM shall meet the subscriber requirements for all the signals it has been identified
	as a subscriber to within section 6.1.2.3 "Signal Requirements"

R: 6.1.3.1.2-1

The BCM shall meet the "Welcome/Farewell State Determination" requirements under section 5.2 – shall be capable of supporting both "Welcome/Farewell State Determination without Battery Saver tie-in" and "Welcome/Farewell State Determination with Battery Saver tie-in" functions / state transitions

# 6.1.3.1.3 <u>Support Exterior Front Illumination</u>

#### 6.1.3.1.3.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-1	The BCM shall transmit a control signal to Exterior Front Illumination elements directly
	connected to it that meet the requirements under section 5.3.1 "Exterior Front
	Illumination Algorithm" (including the associated "State Determination Algorithm)
R: 6.1.3.1.3-1	The BCM shall transmit a control signal to Exterior Front Illumination elements directly
	connected to it that will support the desired Welcome/Farewell state specific behavior
	called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-1	The BCM shall transmit a control signal to Exterior Front Illumination elements directly
	connected to it that will satisfy the control signal specific requirements listed under
	Appendix 1 "Exterior Lighting PWM Signal Specification"

#### 6.1.3.1.3.2 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-1	The BCM shall use the outputs/state determination from section 5.2.2					
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then					
	transmit WFsuperstate and WFsubstate as listed in the table below in order to support					
	Exterior Front Illumination					

	Logical Logical Data F			
Rqmt #	Data Flow	Domain Name	Wfsuperstate	Wfsubstate
	Approach	Approach Detected	Welcome	Approach
	Detection	Approach Not		
R: 6.1.2.3.5-	Detection	Detected	Don't care	NULL**
		Illuminated Entry		
	Illuminated	True	Welcome	IllumEntry
	Entry	Illuminated Entry		
R: 6.1.2.3.5-	-	False	Don't care	NULL**
		Courtesy Lighting		
	Courtesy	True	Don't care	DoorAjarCourtesyLight
	Lighting	Courtesy Lighting		
R: 6.1.2.3.5-		False	Don't care	NULL**
	Courtoov	Courtesy Lighting		
	Courtesy	Delay True	Don't care	CourtesyLightDelay
	Lighting Delay	Courtesy Lighting		
R: 6.1.2.3.5-	Delay	Delay False	Don't care	NULL**
		Illuminated Exit		
	Illuminated	True	Farewell	IIIExit
	Exit	Illuminated Exit		
R: 6.1.2.3.5-		False	Don't care	NULL**
		Vehicle Ignition is		
		OFF	NOT (RunStart)	Don't Care
	Ignition	Vehicle Ignition is		
	State	in Accessory	NOT (RunStart)	Don't Care
		Vehicle Ignition is		
R: 6.1.2.3.5-		in Run/Start	RunStart	NULL**
	Vehicle	Vehicle Locking		
R: 6.1.2.3.5-	Locking	True	OFF	NULL

	Vehicle Locking		
	False	Don't care	NULL**

## 6.1.3.1.4 <u>Support Exterior Rear Illumination</u>

# 6.1.3.1.4.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-2	The BCM shall transmit a control signal to Exterior Rear Illumination elements directly connected to it that meet the requirements under section 5.3.3 "Exterior Rear Illumination Algorithm" (including the associated "State Determination Algorithm)
R: 6.1.3.1.3-2	The BCM shall transmit a control signal to Exterior Rear Illumination elements directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-2	The BCM shall transmit a control signal to Exterior Rear Illumination elements directly connected to it that will satisfy the control signal specific requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"

## 6.1.3.1.4.2 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-2	The BCM shall use the outputs/state determination from section 5.2.2					
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then					
	transmit WFsuperstate and WFsubstate as listed in the table below in order to support					
	Exterior Rear Illumination					

Logical Rqmt # Data Flow		Logical Data Flow Domain Name	Wfsuperstate	Wfsubstate
1	A	Approach Detected	Welcome	Approach
R: 6.1.2.3.5-	Approach Detection	Approach Not Detected	Don't care	NULL**
	Illuminated	Illuminated Entry True	Welcome	IllumEntry
R: 6.1.2.3.5-	Entry	Illuminated Entry False	Don't care	NULL**
	Courtesy	Courtesy Lighting True	Don't care	DoorAjarCourtesyLight
R: 6.1.2.3.5-1	Lighting	Courtesy Lighting False	Don't care	NULL**
	Courtesy Lighting	Courtesy Lighting Delay True	Don't care	CourtesyLightDelay
R: 6.1.2.3.5-1	Delay	Courtesy Lighting Delay False	Don't care	NULL**
	Illuminated	Illuminated Exit True	Farewell	IIIExit
R: 6.1.2.3.5-1	Exit	Illuminated Exit False	Don't care	NULL**
		Vehicle Ignition is OFF	NOT (RunStart)	Don't Care
	Ignition State	Vehicle Ignition is in Accessory	NOT (RunStart)	Don't Care
R: 6.1.2.3.5-1		Vehicle Ignition is in Run/Start	RunStart	NULL**
	Vehicle	Vehicle Locking True	OFF	NULL
R: 6.1.2.3.5-1	Locking	Vehicle Locking False	Don't care	NULL**

# 6.1.3.1.5 <u>Support Exterior Supplementary Illumination</u>

# 6.1.3.1.5.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-3	The BCM shall transmit a control signal to Exterior Supplementary Illumination			
	elements directly connected to it that meet the requirements under section 5.3.5			
	"Exterior Supplementary Illumination Algorithm" (including the associated "State			
	Determination Algorithm)			
R: 6.1.3.1.3-3	The BCM shall transmit a control signal to Exterior Supplementary Illumination			
	elements directly connected to it that will support the desired Welcome/Farewell state			
	specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE			
	WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles			
R: 6.1.3.1.3-3	The BCM shall transmit a control signal to Exterior Supplementary Illumination			
	elements directly connected to it that will satisfy the control signal specific			
	requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"			

# 6.1.3.1.5.1 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-1	The BCM shall use the outputs/state determination from section 5.2.3 "Welcome/Farewell
	State Determination with Battery Saver tie-in" function to then transmit PudLamp_D_Rq,
	PudLampDrv_D_Rq and PudLampPsngr_D_Rq as listed in the table below in order to
	support Exterior Supplementary Illumination

	Approach	Illuminated	Courtesy	Courtesy Lighting		PudLamp	PudLamp
Rqmt #	Detected	Entry	Lighting	Delay	PudLamp_D_Rq	Drv_D_Rq	Psngr_D_Rq
5.2.2.3.6-1	Approach	(Don't		(Don't			
	Detected	Care)	(Don't Care)	Care)	Ramp_Up	Ramp_Up	Ramp_Up
5.2.2.3.6-2		Illuminated					
	Approach	Entry True					
	Not	(Keyfob/PK		(Don't			
	Detected	unlock)	(Don't Care)	Care)	Ramp_Up	Ramp_Up	Ramp_Up
5.2.2.3.6-3		Illuminated					
	Approach	Entry True		(n)			
	Not	(Keypad	(5 ) (6 )	(Don't		0==	0==
	Detected	unlock)	(Don't Care)	Care)	Ramp_Up	OFF	OFF
5.2.2.3.6-4		Illuminated					
	Approach	Entry True		(D)(			
	Not	(Cylinder	(David Oasa)	(Don't	Danielli.	055	055
20000	Detected	unlock)	(Don't Care)	Care)	Ramp_Up	OFF	OFF
5.2.2.3.6-1			Courtesy				
			Lighting True AND (Both				
	Approach		Driver AND				
	Not	Illuminated	Passenger	(Don't			
	Detected	Entry False	Door Closed)	Care)	Ramp_Up	Ramp Up	Ramp_Up
5.2.2.3.6-2	Botootoa	Zitti y i dioo	Courtesy	Curo)	Tramp_op	rtamp_op	rtamp_op
5.2.2.0.0 2	Approach		Lighting True				
	Not	Illuminated	AND Driver	(Don't			
	Detected	Entry False	Door Closed	Care)	Ramp_Up	Ramp_Up	OFF
5.2.2.3.6-3		ĺ	Courtesy	,	· · · · · ·	, _ ,	
			Lighting True				
	Approach		AND				
	Not	Illuminated	Passenger	(Don't			
	Detected	Entry False	Door Closed	Care)	Ramp_Up	OFF	Ramp_Up
5.2.2.3.6-4	Approach		Courtesy	Courtesy			
	Not	Illuminated	Lighting	Lighting			
	Detected	Entry False	False	Delay True	Ramp_Up	OFF	OFF

6.2.2.3.6-5				Courtesy				
	Approach		Courtesy	Lighting				
	Not	Illuminated	Lighting	Delay				
	Detected	Entry False	False	False	Ramp Down	OFF	OFF	

Note: "Ramp\_Up" outputs for "PudLampDrv\_D\_Rq" and "PudLampDrv\_D\_Rq" during "Courtesy Lighting True AND Driver Door Closed", and "Courtesy Lighting True AND Passenger Door Closed" conditions only apply when Courtesy Lighting State first occurs during "Welcome". Doors transitioning from Closed to Ajar to Closed should not re-enable "Ramp\_Up" output, and stay at OFF while Courtesy Lighting remains active.

#### 6.1.3.1.6 Support Interior Courtesy Lamps Illumination

#### 6.1.3.1.6.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-4	The BCM shall transmit a control signal to Interior Courtesy Lamps Illumination elements directly connected to it that meet the requirements under section 5.4.1 "Courtesy Lamps Illumination Algorithm" (including the associated "State
	Determination Algorithm)
R: 6.1.3.1.3-4	The BCM shall transmit a control signal to Courtesy Lamps Illumination elements
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-4	The BCM shall transmit a control signal to Courtesy Lamps Illumination elements
	directly connected to it that will satisfy the control signal specific requirements listed
	under Appendix 2 "Interior Lighting PWM Signal Specification"

#### 6.1.3.1.6.2 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-3	The BCM shall use the outputs/state determination from section 5.2.3
	"Welcome/Farewell State Determination with Battery Saver tie-in" function to then
	transmit WelcomeFarewell_State and WelcomeFarewell_Substate as listed in the
	table below in order to support Courtesy Lamps Illumination

Logical   Rqmt # Data Flow		Logical Data Flow Domain Name	WelcomeFarewell _State	WelcomeFarewell _Substate
•	Approach	Approach Detected	WELCOME	APPROACH
R: 6.1.2.3.5-1	Approach Detection	Approach Not Detected	Don't care	NULL**
	Illuminated	Illuminated Entry True	WELCOME	ENTRY
R: 6.1.2.3.5-1	Entry	Illuminated Entry False	Don't care	NULL**
	Courtesy	Courtesy Lighting True	Don't care	DOOR
R: 6.1.2.3.5-1	Lighting	Courtesy Lighting False	Don't care	NULL**
	Courtesy Lighting	Courtesy Lighting Delay True	Don't care	DELAY
R: 6.1.2.3.5-1	Delay	Courtesy Lighting Delay False	Don't care	NULL**
	Illuminated	Illuminated Exit True	FAREWELL	EXIT
R: 6.1.2.3.5-1		Illuminated Exit False	Don't care	NULL**
	Ignition	Vehicle Ignition is OFF	NOT (RUN_START)	Don't Care
R: 6.1.2.3.5-2	State	Vehicle Ignition is in Accessory	NOT (RUN_START)	Don't Care

		Vehicle Ignition is		
		in Run/Start	RUN_START	NULL**
		Vehicle Locking		
	Vehicle	True	NULL	NULL
	Locking	Vehicle Locking		
R: 6.1.2.3.5-2	_	False	Don't care	NULL**

# 6.1.3.1.7 <u>Support Interior Ambient Lighting (with Static Sequential) Illumination</u>

# 6.1.3.1.7.1 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-4	The BCM shall use the outputs/state determination from section 5.2.3
	"Welcome/Farewell State Determination with Battery Saver tie-in" function to then
	transmit WelcomeFarewell_State and WelcomeFarewell_Substate as listed in the
	table below in order to support Interior Ambient Lighting (with Static Sequential)
	Illumination

Logical Rqmt # Data Flow		Logical Data Flow Domain Name	WelcomeFarewell State	WelcomeFarewell Substate
•		Approach Detected	WELCOME	APPROACH
R: 6.1.2.3.5-2	Approach Detection	Approach Not Detected	Don't care	NULL**
	Illuminated	Illuminated Entry True	WELCOME	ENTRY
R: 6.1.2.3.5-2	Entry	Illuminated Entry False	Don't care	NULL**
	Courtesy	Courtesy Lighting True	Don't care	DOOR
R: 6.1.2.3.5-2	Lighting	Courtesy Lighting False	Don't care	NULL**
	Courtesy Lighting	Courtesy Lighting Delay True	Don't care	DELAY
R: 6.1.2.3.5-2	Delay	Courtesy Lighting Delay False	Don't care	NULL**
	Illuminated	Illuminated Exit True	FAREWELL	EXIT
R: 6.1.2.3.5-2	Exit	Illuminated Exit False	Don't care	NULL**
		Vehicle Ignition is OFF	NOT (RUN_START)	Don't Care
	Ignition State	Vehicle Ignition is in Accessory	NOT (RUN_START)	Don't Care
R: 6.1.2.3.5-2		Vehicle Ignition is in Run/Start	RUN_START	NULL**
	Vehicle	Vehicle Locking True	NULL	NULL
R: 6.1.2.3.5-2	Locking	Vehicle Locking False	Don't care	NULL**

R: 6.1.3.1.3-1	The BCM shall use the outputs/state determination from section 5.2.3
	"Welcome/Farewell State Determination with Battery Saver tie-in" function to then
	transmit Customer_Color and Customer_Intensity to support the desired
	Welcome/Farewell state specific behavior called out in "RQT-002004-022094
	LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln
	vehicles

# 6.1.3.1.8 <u>Support Interior Day-time Dimmable Backlighting Illumination</u>

# 6.1.3.1.8.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-5	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	Illumination elements directly connected to it that meet the requirements under section
	5.4.7.1 "Interior Day-time Dimmable Backlighting Illumination Algorithm" (including the
	associated "State Determination Algorithm)
R: 6.1.3.1.3-5	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE
	WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-5	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will satisfy the control signal specific
	requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-5	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will support the desired Smooth Dimming
	behavior as detailed in the latest version of the following specification: "ES-H1BT-
	1A278-AA-VXX"

# 6.1.3.1.8.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-2	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then
	transmit Dimming_IvI and Litval as listed in the table below in order to support Interior
	Day-time Dimmable Backlighting

	Exterior Ambient	Ignition	Courtesy	Courtesy Lighting	Illuminated	
Rqmt #	Level	Status	Lighting	Delay	Exit	Dimming_lvl
5.2.2.3.6-5						User selected
			(Don't	(Don't	( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( )	Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
5.2.2.3.6-1						User selected
	//s		(Don't	(Don't	( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( ) ( )	Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
5.2.2.3.6-2			Courtesy			User selected
			Lighting	(Don't		Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
5.2.2.3.6-3			Courtesy			User selected
			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
5.2.2.3.6-6			Courtesy	Courtesy		User selected
			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-1			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
5.2.2.3.6-1				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Day_1 to
	"Day"	OFF/Accy	False	False	True	Day_6 level
5.2.2.3.6-2				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Night_1 to
	"Night"	OFF/Accy	False	False	True	Night_12 level
5.2.2.3.6-3			Courtesy			
			Lighting	Courtesy	Illuminated Exit	
	Don't Care	OFF/Accy	False	Lighting	False	OFF

		Delay		
		False		

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1 :4	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
2070.	"Night"		Night
	not supported		Unknown
	not supported		Invalid

#### 6.1.3.1.9 Support Interior Night-time Dimmable Backlighting Illumination

#### 6.1.3.1.9.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-6	The BCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	Illumination elements directly connected to it that meet the requirements under section
	5.4.7.3 "Interior Night-time Dimmable Backlighting Illumination Algorithm" (including
	the associated "State Determination Algorithm)
R: 6.1.3.1.3-6	The BCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE
	WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-6	The BCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will satisfy the control signal specific
	requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-6	
	elements directly connected to it that will support the desired Smooth Dimming
	behavior as detailed in the latest version of the following specification: "ES-H1BT-
	1A278-AA-VXX"

#### 6.1.3.1.9.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-3	The BCM shall use the outputs/state determination from section 5.2.2			
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then			
	transmit Dimming_IvI and Litval as listed in the table below in order to support Interior			
	Night-time Dimmable Backlighting			

Rqmt #	Exterior Ambient Level	Ignition Status	Courtesy Lighting	Courtesy Lighting Delay	Illuminated Exit	Dimming_lvl
5.2.2.3.6-6						User selected
			(Don't	(Don't		Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
5.2.2.3.6-4						User selected
			(Don't	(Don't		Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level

3.2.2.3.6-5			Courtesy	(Don't		User selected
	"Day"	OFF/Accy	Lighting True	(Don't Care)	(Don't Care)	Day_1 to Day_6 level
5.2.2.3.6-6		,	Courtesy Lighting	(Don't		User selected Night_1 to
5.2.2.3.6-7	"Night" "Day"	OFF/Accy OFF/Accy	True Courtesy Lighting False	Care) Courtesy Lighting Delay True	(Don't Care) (Don't Care)	Night_12 level User selected Day_1 to Day_6 level
5.2.2.3.6-2	"Night"	OFF/Accy	Courtesy Lighting False	Courtesy Lighting Delay True	(Don't Care)	User selected Night_1 to Night_12 level
5.2.2.3.6-4	"Day"	OFF/Accy	Courtesy Lighting False	Courtesy Lighting Delay False	Illuminated Exit	User selected Day_1 to Day_6 level
3.2.2.3.6-5	"Night"	OFF/Accy	Courtesy Lighting False	Courtesy Lighting Delay False	Illuminated Exit	User selected Night_1 to Night_12 level
5.2.2.3.6-6	Don't Care	OFF/Accy	Courtesy Lighting False	Courtesy Lighting Delay False	Illuminated Exit False	OFF

Note: "User selected Day\_1 to Day\_6 level" are all set to the same intensity level for Night-time Dimmable Backlighting which is decided by Vehicle Harmony team.

Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1.90 -1	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
20701	"Night"		Night
	not supported		Unknown
	not supported		Invalid

#### 6.1.3.1.9.1 Support LIN Headlamp Switch Backlighting Illumination

R: 6.1.3.1.3-1	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to
	transmit Dimming_IvI as listed in previous section, to support LIN Headlamp Switch
	Backlighting Illumination.

#### 6.1.3.1.10 Support Interior 2-Step Dimmable Backlighting Illumination

#### 6.1.3.1.10.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-7	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting
	Illumination elements directly connected to it that meet the requirements under section
	5.4.7.5 "Interior Day-time Dimmable Backlighting Illumination Algorithm" (including the
	associated "State Determination Algorithm)

R: 6.1.3.1.3-7	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting elements directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-7	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting elements directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-7	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

6.1.3.1.10.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-2	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then
	transmit Dimming_IvI and Litval as listed in the table below in order to support Interior
	2-Step Dimmable Backlighting

Damet #	Exterior Ambient	Ignition	Courtesy	Courtesy Lighting	Illuminated	Discoming a lad
Rqmt # 5.2.2.3.6-7	Level	Status	Lighting	Delay	Exit	Dimming_IvI User selected
0.2.2.3.6-7			(Don't	(Don't		Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
5.2.2.3.6-7	Бау	Ttur/Start	Care)	Carej	(Don't Cale)	User selected
5.2.2.0.0 7			(Don't	(Don't		Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
5.2.2.3.6-8	- rug		Courtesy		(= 0 0 0 0)	User selected
			Lighting	(Don't		Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
5.2.2.3.6-9		•	Courtesy		,	User selected
			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
5.2.2.3.6-8			Courtesy	Courtesy		User selected
			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-3			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
5.2.2.3.6-7				Courtesy		
			Courtesy	Lighting		User selected
	"Day"	055/4	Lighting	Delay	Illuminated Exit	Day_1 to
20000	"Day"	OFF/Accy	False	False	True	Day_6 level
5.2.2.3.6-8			Courtoov	Courtesy		User selected
			Courtesy Lighting	Lighting Delay	Illuminated Exit	
	"Night"	OFF/Accy	False	False	True	Night_1 to Night_12 level
5.2.2.3.6-9	INIGHT	OI I /ACCY	1 0136	Courtesy	TIUC	TVIGITE IZ IEVEL
0.2.2.3.0-3			Courtesy	Lighting		
			Lighting	Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

	Logical Data		
Logical	Flow Domain	Signal	Signal Domain
Data Flow	Name	Name	Value

Exterior Ambient Level	"Day"		Day
	"Night"	Litval	Twilight_1
	"Night"		Twilight_2
	"Night"		Twilight_3
	"Night"		Twilight_4
	"Night"		Night
	not supported		Unknown
	not supported		Invalid

# 6.1.3.1.10.3 Support LIN Headlamp Switch Indicator Illumination

R: 6.1.3.1.3-3	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to
	transmit Dimming_IvI and Litval as listed in previous section, to support LIN Headlamp
	Switch Indicator Illumination.

# 6.1.3.1.11 Support Vehicle Display Center-stack Day-time Dimmable Illumination for Display Brightness

R: 6.1.3.1.3-4	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then
	transmit Dimming_IvI and Litval as listed in the table below in order to support Center-
	stack Day-time Dimmable Illumination for Display Brightness

	Exterior Ambient	Ignition	Courtesy	Courtesy Lighting	Illuminated	
Rqmt #	Level	Status	Lighting	Delay	Exit	Dimming_lvl
5.2.2.3.6-8						User selected
			(Don't	(Don't		Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
2.2.3.6-10						User selected
			(Don't	(Don't		Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-11			Courtesy			User selected
			Lighting	(Don't		Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
2.2.3.6-12			Courtesy			User selected
			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
5.2.2.3.6-9			Courtesy	Courtesy		User selected
			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-4			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-10			_	Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Day_1 to
	"Day"	OFF/Accy	False	False	True	Day_6 level
2.2.3.6-11				Courtesy		
			Courtesy	Lighting		User selected
	"N 1" 1 4"	055/4	Lighting	Delay	Illuminated Exit	Night_1 to
0.000.46	"Night"	OFF/Accy	False	False	True	Night_12 level
2.2.3.6-12			0	Courtesy		
			Courtesy	Lighting	III	
	Danit Os	055/4	Lighting	Delay	Illuminated Exit	OFF
	Don't Care	OFF/Accy	False	False	False	OFF

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1.56	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
20001	"Night"		Night
	not supported		Unknown
	not supported		Invalid

# 6.1.3.1.12 <u>Support Vehicle Display Cluster Day-time Dimmable Illumination for Display Brightness</u>

R: 6.1.3.1.3-5	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then
	transmit Dimming_IvI and litval as listed in the table below in order to support Cluster
	Day-time Dimmable Illumination for Display Brightness

	Exterior			Courtesy		
Damt #	Ambient	Ignition Status	Courtesy Lighting	Lighting	Illuminated Exit	Dimmina Iul
Rqmt # 5.2.2.3.6-9	Level	Status	Lighting	Delay	EXIL	Dimming_lvl User selected
0.2.2.3.0-9			(Don't	(Don't		Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_1 to Day_6 level
2.2.3.6-13	Day	ixui/Start	Care)	Care)	(Don't Cale)	User selected
2.2.3.0-13			(Don't	(Don't		Night 1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-14	TVIGIT	Runotan	Courtesy	Cale)	(Don't Care)	User selected
2.2.3.0-14			Lighting	(Don't		Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_1 to Day_6 level
2.2.3.6-15	Бау	OTT/ACCY	Courtesy	Cale)	(Don't Care)	User selected
2.2.3.0-13			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
2.2.3.6-10	rugiit	OI I // tody	Courtesy	Courtesy	(Boirt Gare)	User selected
2.2.0.0 10			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-5	July	G. i miooy	Courtesy	Courtesy	(Don't Gare)	User selected
7.2.2.0.0			Lighting	Lighting		Night 1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-13		<u> </u>	1 4.00	Courtesy	(20:::00::0)	g.n
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Day_1 to
	"Day"	OFF/Accv	False	False	True	Day_6 level
2.2.3.6-14		,		Courtesy		7-
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Night_1 to
	"Night"	OFF/Accy	False	False	True	Night_12 level
2.2.3.6-15	_			Courtesy		
			Courtesy	Lighting		
			Lighting	Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Logical Flow Domain Data Flow Name		Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1.56	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
2575.	"Night"		Night
	not supported		Unknown
	not supported		Invalid

#### 6.1.3.1.13 Support Vehicle Display aHUD Welcome/Farewell behavior

R: 6.1.3.1.3-6	The BCM shall use the outputs/state determination from section 5.2.2 "Welcome/Farewell
	State Determination without Battery Saver tie-in" function to then transmit
	PudLamp_D_Rq, as listed in the table below in order to support aHUD Welcome/Farewell
	behavior

	Approach	Illuminated	Courtesy	Courtesy Lighting	
Rqmt #	Detected	Entry	Lighting	Delay	PudLamp_D_Rq
2.2.3.6-10	Approach	(Don't		(Don't	
	Detected	Care)	(Don't Care)	Care)	Ramp_Up
2.2.3.6-11	Approach Not	Illuminated Entry True (Keyfob/PK	(Dank Cara)	(Don't Care)	Down Un
2.2.3.6-12	Approach Not Detected	unlock) Illuminated Entry True (Keypad unlock)	(Don't Care)  (Don't Care)	(Don't	Ramp_Up Ramp_Up
2.2.3.6-13	Approach Not Detected	Illuminated Entry True (Cylinder unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-11	Approach Not Detected	Illuminated Entry False	Courtesy Lighting True AND (Both Driver AND Passenger Door Closed)	(Don't Care)	Ramp_Up
2.2.3.6-12	Approach Not Detected	Illuminated Entry False	Courtesy Lighting True AND Driver Door Closed	(Don't Care)	Ramp_Up
2.2.3.6-13	Approach Not Detected	Illuminated Entry False	Courtesy Lighting True AND Passenger Door Closed	(Don't Care)	Ramp_Up

2.2.3.6-14	Approach Not Detected	Illuminated Entry False	Courtesy Lighting False	Courtesy Lighting Delay True	Ramp_Up
2.2.3.6-15	Approach Not Detected	Illuminated Entry False	Courtesy Lighting False	Courtesy Lighting Delay False	Ramp_Down

#### 6.1.3.2 <u>LED Driver Module (LDM) requirements</u>

The LDM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: Headlamps (low-beams), Front Side Markers, Signature/Decorative LED Lamps, Illuminated Lincoln Star, Front Fog Lamps.

**NOTE**: Lincoln Lit Star feature spec: LINCOLN LIT STAR SPEC. Contains additional feature specific information.

#### 6.1.3.2.1 Over-arching requirements

R: 6.1.3.2-1	The LDM shall contain its Performance Latency within the End-to-End latency specified in
	section 3.2.2.1 "Performance Latency Requirements"
	The LDM shall take into account the requirements contained within section 3.2.3 "Safety
R: 6.1.3.2-2	Requirements" to ensure that no lighting element that it directly controls (via control
K. 0.1.3.2-2	signal) ends up violating any requirement (specific to the market the target vehicle shall be
	sold in) within the aforementioned section.
R: 6.1.3.2-3	The LDM shall take into account the requirements contained within section 3.2.4 "Security
	Requirements" to ensure that no lighting element that it directly controls (via control
	signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.2-4	The LDM shall be a publisher to signals it has been identified as a publisher for within
	section 6.1.2.3 "Signal requirements"

#### 6.1.3.2.1 Provide Control Signal to support Front Exterior Illumination

D- C 4 0 0 E	The LDM shall enth and be the (LIN) since all a social about the enth and big for stine III sets arise
R: 6.1.3.2-5	The LDM shall subscribe to the (LIN) signals required by the subscribing function "Exterior
	Front Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements":
	Wfsuperstate and WFsubstate.
R: 6.1.3.2-6	The LDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3
	"Signal Requirements" to transmit a control signal to Exterior Front Lighting elements
	directly connected to it that meet the requirements under section 5.3.1 "Exterior Front
	Illumination Algorithm"
R: 6.1.3.2-7	The LDM shall transmit a control signal to Exterior Front Illumination elements directly
	connected to it that will support the desired Welcome/Farewell state specific behavior
	called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL
	BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-8	The LDM shall transmit a control signal to Front Exterior Illumination elements directly
	connected to it that will satisfy the control signal specific requirements listed under
	Appendix 1 "Exterior Lighting PWM Signal Specification"

Note: Table below provided as reference for LDM subscribed signals to ARL callouts mapping:

ARL call-out		Subscriber	Signal Mapping
Logical Data Flow	Logical Data Flow Domain Name	Wfsuperstate	Wfsubstate
Approach	Approach Detected	Welcome	Approach
Approach Detection	Approach Not		
Detection	Detected	Don't care	NULL**
	Illuminated Entry		
Illuminated	True	Welcome	IllumEntry
Entry	Illuminated Entry		
	False	Don't care	NULL**

Courtesy Lighting	Courtesy Lighting True	Don't care	DoorAjarCourtesyLight
	Courtesy Lighting		
	False	Don't care	NULL**
Courtoov	Courtesy Lighting		
Courtesy	Delay True	Don't care	CourtesyLightDelay
Lighting	Courtesy Lighting		
Delay	Delay False	Don't care	NULL**
	Illuminated Exit		
Illuminated	True	Farewell	IIIExit
Exit	Illuminated Exit		
	False	Don't care	NULL**
	Vehicle Ignition is		
	OFF	NOT (RunStart)	Don't Care
Ignition	Vehicle Ignition is		
State	in Accessory	NOT (RunStart)	Don't Care
	Vehicle Ignition is		
	in Run/Start	RunStart	NULL**
	Vehicle Locking		
Vehicle	True	OFF	NULL
Locking	Vehicle Locking		
	False	Don't care	NULL**

# 6.1.3.3 Rear Fade Control Module (R-FCM) requirements

The R-FCM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: Rear Parklamps and Rear Applique Park Lamp (RAPL).

## 6.1.3.3.1 Over-arching requirements

R: 6.1.3.2-9	The R-FCM shall contain its Performance Latency within the End-to-End latency specified in section 3.2.2.1 "Performance Latency Requirements"
R: 6.1.3.2-10	The R-FCM shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no lighting element that it directly controls (via control signal) ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.
R: 6.1.3.2-11	The R-FCM shall take into account the requirements contained within section 3.2.4 "Security Requirements" to ensure that no lighting element that it directly controls (via control signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.2-12	The R-FCM shall be a publisher to signals it has been identified as a publisher for within section 6.1.2.3 "Signal requirements"

## 6.1.3.3.2 Provide Control Signal to support Rear Exterior Illumination

R: 6.1.3.2-13	The R-FCM shall subscribe to the (LIN) signals required by the subscribing function
	"Exterior Rear Illumination Algorithm" as identified in section 6.1.2.3 "Signal
	Requirements": Wfsuperstate and WFsubstate.
R: 6.1.3.2-14	The R-FCM shall use the signals it has been identified as a subscriber to in section
	6.1.2.3 "Signal Requirements" to transmit a control signal to Exterior Rear Lighting
	elements directly connected to it that meet the requirements under section 5.3.3 "Exterior
	Rear Illumination Algorithm"
R: 6.1.3.2-15	The R-FCM shall transmit a control signal to Exterior Rear Illumination elements directly
	connected to it that will support the desired Welcome/Farewell state specific behavior
	called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL
	BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-16	The R-FCM shall transmit a control signal to Exterior Rear Illumination elements directly
	connected to it that will satisfy the control signal specific requirements listed under
	Appendix 1 "Exterior Lighting PWM Signal Specification"

Note: Table below provided as reference for RCM subscribed signals to ARL callouts mapping:

ARL call-out		Subscriber	Signal Mapping
Logical	Logical Data Flow		
Data Flow	Domain Name	Wfsuperstate	Wfsubstate
Approach	Approach Detected	Welcome	Approach
Detection	Approach Not		
Detection	Detected	Don't care	NULL**
	Illuminated Entry		
Illuminated	True	Welcome	IllumEntry
Entry	Illuminated Entry		
	False	Don't care	NULL**
_	Courtesy Lighting		
Courtesy	True	Don't care	DoorAjarCourtesyLight
Lighting	Courtesy Lighting	_ ,,	
	False	Don't care	NULL**
Courtesy	Courtesy Lighting	Don't core	Countaged inhtDalay
Lighting	Delay True	Don't care	CourtesyLightDelay
Delay	Courtesy Lighting Delay False	Don't care	NULL**
	Illuminated Exit	Dont care	NOLL
Illuminated	True	Farewell	IIIExit
Exit	Illuminated Exit	1 diewen	IIIEAR
2,11	False	Don't care	NULL**
	Vehicle Ignition is		
	OFF	NOT (RunStart)	Don't Care
Ignition	Vehicle Ignition is		
State	in Accessory	NOT (RunStart)	Don't Care
	Vehicle Ignition is		
	in Run/Start	RunStart	NULL**
Vehicle	Vehicle Locking		
	True	OFF	NULL
Locking	Vehicle Locking		
	False	Don't care	NULL**

#### 6.1.3.4 Overhead Console (OHC) requirements

The OHC shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: "Courtesy Lamps"

#### 6.1.3.4.1 Over-arching requirements

R: 6.1.3.2-17	The OHC shall contain its Performance Latency within the End-to-End latency specified in		
	section 3.2.2.1 "Performance Latency Requirements"		
	The OHC shall take into account the requirements contained within section 3.2.3 "Safety		
R: 6.1.3.2-18	Requirements" to ensure that no lighting element that it directly controls (via control		
K. 0.1.3.2-10	signal) ends up violating any requirement (specific to the market the target vehicle shall be		
	sold in) within the aforementioned section.		
R: 6.1.3.2-19	The OHC shall take into account the requirements contained within section 3.2.4 "Security		
	Requirements" to ensure that no lighting element that it directly controls (via control		
	signal) ends up violating any requirement within the aforementioned section.		
R: 6.1.3.2-20	The OHC shall be a publisher to signals it has been identified as a publisher for within		
	section 6.1.2.3 "Signal requirements"		

#### 6.1.3.4.2 <u>Provide Control Signal to support Courtesy Lamps Illumination</u>

R: 6.1.3.2-21	The OHC shall subscribe to the (LIN) signals required by the subscribing function " Interior
	Courtesy Lamps Illumination Algorithm " as identified in section 6.1.2.3 "Signal
	Requirements": WelcomeFarewell_State and WelcomeFarewell_SubState

R: 6.1.3.2-22	The OHC shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Interior Courtesy Lamps directly connected to it that meet the requirements under section 5.4.1 "Courtesy Lamps Illumination Algorithm"
R: 6.1.3.2-23	The OHC shall transmit a control signal to Interior Courtesy Lamps directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-24	The OHC shall transmit a control signal to Interior Courtesy Lamps directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"

Note: Table below provided as reference for OHC subscribed signals to ARL callouts mapping:

ARL call-out		Subscriber S	Signal Mapping
Logical	Logical Data Flow	WelcomeFarewell	WelcomeFarewell
Data Flow	Domain Name	_State	_Substate
Approach	Approach Detected	WELCOME	APPROACH
Detection	Approach Not		
Dotootion	Detected	Don't care	NULL**
	Illuminated Entry		
Illuminated	True	WELCOME	ENTRY
Entry	Illuminated Entry		
	False	Don't care	NULL**
	Courtesy Lighting		
Courtesy	True	Don't care	DOOR
Lighting	Courtesy Lighting		
	False	Don't care	NULL**
Courtesy	Courtesy Lighting		
Lighting	Delay True	Don't care	DELAY
Delay	Courtesy Lighting		
Delay	Delay False	Don't care	NULL**
	Illuminated Exit		
Illuminated	True	FAREWELL	EXIT
Exit	Illuminated Exit		
	False	Don't care	NULL**
	Vehicle Ignition is		
Ignition State	OFF	NOT (RUN_START)	Don't Care
	Vehicle Ignition is		
	in Accessory	NOT (RUN_START)	Don't Care
	Vehicle Ignition is		
	in Run/Start	RUN_START	NULL**
	Vehicle Locking		
Vehicle	True	NULL	NULL
Locking	Vehicle Locking		
	False	Don't care	NULL**

6.1.3.5 <u>Ambient Light Module (ALM) requirements</u>
The ALM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: "Ambient Lighting" and "Illuminated Seat Belt Buckle"

#### 6.1.3.5.1 Over-arching requirements

R: 6.1.3.2-25	The ALM shall contain its Performance Latency within the End-to-End latency specified in		
	section 3.2.2.1 "Performance Latency Requirements"		
R: 6.1.3.2-26 The ALM shall take into account the requirements contained within section 3.2.3			
N. U.1.3.2-20	Requirements" to ensure that no lighting element that it directly controls (via control		

	signal) ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.
R: 6.1.3.2-27	The ALM shall take into account the requirements contained within section 3.2.4 "Security Requirements" to ensure that no lighting element that it directly controls (via control signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.2-28	The ALM shall be a publisher to signals it has been identified as a publisher for within section 6.1.2.3 "Signal requirements"

# 6.1.3.5.2 <u>Provide Control Signal to support Ambient Lighting Illumination</u>

R: 6.1.3.2-29	The ALM shall subscribe to the (LIN) signals required by the subscribing function "Interior Ambient Light Illumination (without Static Sequential) Algorithm "as identified in section 6.1.2.3 "Signal Requirements": WelcomeFarewell_State, WelcomeFarewell_SubState, Customer_Color, and Customer_Intensity
R: 6.1.3.2-30	The ALM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Interior Ambient Lighting Illumination directly connected to it that meet the requirements under section 5.4.3 "Interior Ambient Lighting (without Static Sequential) Illumination Algorithm"
R: 6.1.3.2-31	The ALM shall transmit a control signal to Interior Ambient Lights directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-32	The ALM shall transmit a control signal to Interior Ambient Lights directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"

Note: Table below provided as reference for ALM subscribed signals to ARL callouts mapping:

ARL call-out		Subscriber Signal Mapping	
Logical	Logical Data Flow	WelcomeFarewell	WelcomeFarewell
Data Flow	Domain Name	_State	_Substate
Approach	Approach Detected	WELCOME	APPROACH
Approach Detection	Approach Not		
Detection	Detected	Don't care	NULL**
	Illuminated Entry		
Illuminated	True	WELCOME	ENTRY
Entry	Illuminated Entry		
	False	Don't care	NULL**
	Courtesy Lighting		
Courtesy	True	Don't care	DOOR
Lighting	Courtesy Lighting		
	False	Don't care	NULL**
Courtesy	Courtesy Lighting		
Lighting	Delay True	Don't care	DELAY
Delay	Courtesy Lighting		
Dolay	Delay False	Don't care	NULL**
	Illuminated Exit		
Illuminated	True	FAREWELL	EXIT
Exit	Illuminated Exit		
	False	Don't care	NULL**
	Vehicle Ignition is		
	OFF	NOT (RUN_START)	Don't Care
Ignition State	Vehicle Ignition is		
	in Accessory	NOT (RUN_START)	Don't Care
	Vehicle Ignition is		
	in Run/Start	RUN_START	NULL**
Vehicle	Vehicle Locking		
Locking	True	NULL	NULL

Vehicle Locking		
False	Don't care	NULL**

## 6.1.3.6 **Driver Door Module (DDM) requirements**

The DDM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to: Welcome Mat (Driver's), "Door trim switch/button backlighting Illumination", "Autofold mirrors".

#### 6.1.3.6.1 Over-arching requirements

R: 6.1.3.2-33	The DDM shall contain its Performance Latency within the End-to-End latency specified in	
	section 3.2.2.1 "Performance Latency Requirements"	
	The DDM shall take into account the requirements contained within section 3.2.3 "Safety	
R: 6.1.3.2-34	Requirements" to ensure that no lighting element that it directly controls (via control	
K. 0.1.3.2-34	signal) ends up violating any requirement (specific to the market the target vehicle shall be	
	sold in) within the aforementioned section.	
R: 6.1.3.2-35	The DDM shall take into account the requirements contained within section 3.2.4 "Security	
	Requirements" to ensure that no lighting element that it directly controls (via control	
	signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.2-36	The DDM shall be a publisher to signals it has been identified as a publisher for within	
	section 6.1.2.3 "Signal requirements"	

#### 6.1.3.6.2 Provide Control Signal to support Exterior Supplementary Illumination

R: 6.1.3.2-37	The DDM shall subscribe to the (CAN) signals required by the subscribing function " Exterior Supplementary Illumination Algorithm " as identified in section 6.1.2.3 "Signal Requirements": Pudlamp_D_Rq, PudlampDrv_D_Rq (specific only for driver side "Welcome Mats")
R: 6.1.3.2-38	The DDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Exterior Supplementary Lighting directly connected to it that meet the requirements under section 5.3.5 "Exterior Supplementary Illumination Algorithm"
R: 6.1.3.2-39	The DDM shall transmit a control signal to Exterior Supplementary Lights directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-40	The DDM shall transmit a control signal to Exterior Supplementary Lights directly connected to it that will satisfy the control signal specific requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

·		Expected initial response as per section 5.3.5
Subscriber Signal Mapping		"Exterior Supplementary Illumination Algorithm"
	PudLampDrv_D_Rq (only	
Pudlamp_D_Rq	for Driver Welcome Mat)	Control Signal Response
RAMP_UP	RAMP_UP	"Fade ON"/Ramp up
RAMP_DOWN	N/A	"Fade OFF"/Ramp down
ON	N/A	"Snap ON"/Step up
OFF	OFF	"Snap OFF"/"Step down

#### 6.1.3.6.3 Provide Control Signal to support Interior Day-time Dimmable Backlighting/Display Illumination

R: 6.1.3.2-41	The DDM shall subscribe to the (CAN) signals required by the subscribing function
111 0111012 11	"Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.1.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local
	sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination
	will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI
	= OFF

R: 6.1.3.2-42	The DDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3
	"Signal Requirements" to transmit a control signal to Day-time Dimmable
	Backlighting/Display Illumination directly connected to it that meet the requirements under
	section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-43	The DDM shall transmit a control signal to Day-time Dimmable Backlighting/Display
	Illumination directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME
	AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-44	The DDM shall transmit a control signal to Day-time Dimmable Backlighting/Display
	Illumination directly connected to it that will satisfy the control signal specific requirements
	listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-8	The DDM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	/Display elements directly connected to it that will support the desired Smooth Dimming
	behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-
	AA-VXX"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.6.4 <u>Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination</u>

R: 6.1.3.2-45	The DDM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-46	The DDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.3 "Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-47	The DDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-48	The DDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-9	The DDM shall transmit a control signal to Interior Night-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"
Mapping	Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.6.5 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-49	The DDM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section

	6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-50	The DDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-51	The DDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-52	The DDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-10	The DDM shall transmit a control signal to 2-Step Dimmable Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 - Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.7 Passenger Door Module (PDM) requirements

The PDM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to: Welcome Mat (Passenger's), "Door trim switch/button backlighting Illumination", "Autofold mirrors"

#### 6.1.3.7.1 Over-arching requirements

R: 6.1.3.2-53	The PDM shall contain its Performance Latency within the End-to-End latency specified in section 3.2.2.1 "Performance Latency Requirements"
R: 6.1.3.2-54	The PDM shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no lighting element that it directly controls (via control signal) ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.
R: 6.1.3.2-55	The PDM shall take into account the requirements contained within section 3.2.4 "Security Requirements" to ensure that no lighting element that it directly controls (via control signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.2-56	The PDM shall be a publisher to signals it has been identified as a publisher for within section 6.1.2.3 "Signal requirements"

#### 6.1.3.7.2 <u>Provide Control Signal to support Exterior Supplementary Illumination</u>

R: 6.1.3.2-57	The PDM shall subscribe to the (CAN) signals required by the subscribing function " Exterior Supplementary Illumination Algorithm " as identified in section 6.1.2.3 "Signal Requirements": Pudlamp_D_Rq, PudlampPsngr_D_Rq (specific only for driver side "Welcome Mats")
R: 6.1.3.2-58	The PDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Exterior Supplementary Lighting directly connected to it that meet the requirements under section 5.3.5 "Exterior Supplementary Illumination Algorithm"

R: 6.1.3.2-59	The PDM shall transmit a control signal to Exterior Supplementary Lights directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-60	The PDM shall transmit a control signal to Exterior Supplementary Lights directly connected to it that will satisfy the control signal specific requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Expected initial response as per section 5.3.5 "Exterior Supplementary Illumination Algorithm"
	PudlampPsngr_D_Rq (only for Passenger	
Pudlamp_D_Rq	Welcome Mat)	Control Signal Response
RAMP_UP	RAMP_UP	"Fade ON"/Ramp up
RAMP_DOWN	N/A	"Fade OFF"/Ramp down
ON	N/A	"Snap ON"/Step up
OFF	OFF	"Snap OFF"/"Step down

## 6.1.3.7.3 Provide Control Signal to support Interior Day-time Dimmable Backlighting/Display Illumination

R: 6.1.3.2-61	The PDM shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-62	The PDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable
	Backlighting/Display Illumination directly connected to it that meet the requirements under
	section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-63	The PDM shall transmit a control signal to Day-time Dimmable Backlighting/Display
	Illumination directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-64	The PDM shall transmit a control signal to Day-time Dimmable Backlighting/Display
	Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
D. E 4 7 4 C 44	
R: 5.4.7.1.6-11	The PDM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	/Display elements directly connected to it that will support the desired Smooth Dimming
	behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"
Mapping	Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.7.4 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-65	The PDM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local
	sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination
	will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl
	= OFF

D 0 1 0 0 00	TI DDM 1 II I
R: 6.1.3.2-66	The PDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3
	"Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.3
	"Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-67	The PDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-68	The PDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-12	The PDM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.7.5 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-69	The PDM shall subscribe to the (CAN) signals required by the subscribing function "Interior 2-Step Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-70	The PDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-71	The PDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-72	The PDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-13	The PDM shall transmit a control signal to 2-Step Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"
Mapping	Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.8 <u>Steering Column Control Module (SCCM) requirements</u>

The SCCM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to.

#### 6.1.3.8.1 Over-arching requirements

R: 6.1.3.2-73	The SCCM shall contain its Performance Latency within the End-to-End latency specified	
	in section 3.2.2.1 "Performance Latency Requirements"	
	The SCCM shall take into account the requirements contained within section 3.2.3 "Safety	
R: 6.1.3.2-74	Requirements" to ensure that no lighting element that it directly controls (via control	
N. 0.1.3.2-14	signal) ends up violating any requirement (specific to the market the target vehicle shall be	
	sold in) within the aforementioned section.	
R: 6.1.3.2-75	The SCCM shall take into account the requirements contained within section 3.2.4	
	"Security Requirements" to ensure that no lighting element that it directly controls (via	
	control signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.2-76	The SCCM shall be a publisher to signals it has been identified as a publisher for within	
	section 6.1.2.3 "Signal requirements"	

# 6.1.3.8.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination

R: 6.1.3.2-77	The SCCM shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI
	= OFF
R: 6.1.3.2-78	The SCCM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-79	The SCCM shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-80	The SCCM shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-14	The SCCM shall transmit a control signal to Interior Day-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for SCCM subscribed signals to Expected Initial Control Signal Response:

Table below provided as t	rable below provided as reference for Goow subscribed signals to Expedice initial Control Gignal Response:	
Subscriber Signal	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"	
Mapping	Backlighting Illumination Algorithm	
Dimming_lvl	Control Signal Response	
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"	
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"	
OFF	"Fade OFF"/Ramp down	

#### 6.1.3.8.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-81	The SCCM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-82	The SCCM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.3
	"Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-83	The SCCM shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific

	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-84	The SCCM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-15	The SCCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.9 <u>Terrain Management Switch (TMS) requirements</u>

The TMS shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to.

#### 6.1.3.9.1 Over-arching requirements

R: 6.1.3.2-85	The TMS shall contain its Performance Latency within the End-to-End latency specified in	
	section 3.2.2.1 "Performance Latency Requirements"	
	The TMS shall take into account the requirements contained within section 3.2.3 "Safety	
R: 6.1.3.2-86	Requirements" to ensure that no lighting element that it directly controls (via control	
K: 0.1.3.2-00	signal) ends up violating any requirement (specific to the market the target vehicle shall be	
	sold in) within the aforementioned section.	
R: 6.1.3.2-87	The TMS shall take into account the requirements contained within section 3.2.4 "Security	
	Requirements" to ensure that no lighting element that it directly controls (via control	
	signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.2-88	The TMS shall be a publisher to signals it has been identified as a publisher for within	
	section 6.1.2.3 "Signal requirements"	

#### 6.1.3.9.2 <u>Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination</u>

R: 6.1.3.2-89	The TMS shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-90	The TMS shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-91	The TMS shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-92	The TMS shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-16	The TMS shall transmit a control signal to Interior Day-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for SCCM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.9.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-93	The TMS shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-94	The TMS shall use the signals it has been identified as a subscriber to in section 6.1.2.3  "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting  Illumination directly connected to it that meet the requirements under section 5.4.7.3  "Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-95	The TMS shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-96	The TMS shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-17	The TMS shall transmit a control signal to Interior Night-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for TMS subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.10 Front Control Interface Module (FCIM, FCIMB, HVAC) requirements

The FCIM shall be a subscriber to the BCM (Welcome Farewell State determination function) and APIM (Radio Power Button toggle) then use it to transmit a control signal to specific lighting elements it is directly connected to: "Sync/Radio Control button backlighting illumination"

#### 6.1.3.10.1 Provide Control Signal to support Interior Day-Time Dimmable Backlighting Illumination

R: 6.1.3.2-97	The FCIM shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI, Litval and HMI_HMIMode_St. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
R: 6.1.3.2-98	sleep is allowed then Dimming_IvI = OFF  The FCIM shall use the signals it has been identified as a subscriber to in section 6.1.2.3  "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting  Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm

R: 6.1.3.2-99	The FCIM shall transmit a control signal to Day-time Dimmable Backlighting Illumination	
	directly connected to it that will support the desired Welcome/Farewell state specific	
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND	
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles	
R: 6.1.3.2-100	The FCIM shall transmit a control signal to Day-time Dimmable Backlighting Illumination	
	directly connected to it that will satisfy the control signal specific requirements listed under	
	Appendix 2 "Interior Lighting PWM Signal Specification"	
R: 5.4.7.1.6-18	The FCIM shall transmit a control signal to Interior Day-time Dimmable Backlighting	
	elements directly connected to it that will support the desired Smooth Dimming behavior	
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"	

Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Expected initial response as per section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
Dimming_IvI	HMI_HMIMode_St	Control Signal Response
Day_1 to Day_6 or	Don't Care	
Night_1 – Night_12		"Fade ON"/Ramp up
OFF	≠ OFFmode	"Fade ON"/Ramp up**
OFF	OFFmode	"Fade OFF"/Ramp down

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

Table below provided as reference for FCIM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6 or	Don't Care	
Night_1 – Night_12		Day_1 to Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12**
OFF	OFFmode	OFF

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): OFF

#### 6.1.3.10.2 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-101	The FCIM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.1.2.3 "Signal Requirements": Dimming_lvl, Litval and HMI_HMIMode_St. Note:
	Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
	sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-102	The FCIM shall use the signals it has been identified as a subscriber to in section 6.1.2.3
	"Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.3
	"Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-103	The FCIM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-104	The FCIM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-19	
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Exp	ected initial response as per section
			5.4.7.3 "Night-time Dimmable"
		В	acklighting Illumination Algorithm
Dimming_lvl	HMI_HMIMode_St	Con	trol Signal Response

Day_1 to Day_6 or	Don't Care	
Night_1 – Night_12		"Fade ON"/Ramp up
OFF	≠ OFFmode	"Fade ON"/Ramp up**
OFF	OFFmode	"Fade OFF"/Ramp down

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

Table below provided as reference for FCIM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6 or	Don't Care	
Night_1 – Night_12		Day_1 to Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12**
OFF	OFFmode	OFF

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): OFF

#### 6.1.3.10.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-105	The FCIM shall subscribe to the (CAN) signals required by the subscribing function "Interior 2-Step Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-106	The FCIM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-107	The FCIM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-108	The FCIM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-20	The FCIM shall transmit a control signal to Interior Day-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

#### Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"
Mapping	Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

## 6.1.3.11 Accessory Protocol Interface Module (APIM/SYNC) requirements

The APIM/SYNC shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

## 6.1.3.11.1 Over-arching requirements

R: 6.1.3.10-1	The APIM/SYNC shall contain its Performance Latency within the End-to-End latency	
	specified in section 3.2.2.1 "Performance Latency Requirements"	
R: 6.1.3.10-2	The APIM/SYNC shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no screen/display that it directly controls ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.	

R: 6.1.3.10-3	The APIM/SYNC shall take into account the requirements contained within section 3.2.4 "Security Requirements" to ensure that no screen/display that it directly controls (via control signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.10-4	The APIM shall be a publisher to signals it has been identified as a publisher for within section 6.1.2.3 "Signal requirements"

#### 6.1.3.11.2 Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness

R: 6.1.3.2-109	The APIM shall subscribe to the (CAN) signals required by the subscribing function		
	"Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section		
	6.1.2.3 "Signal Requirements": Dimming_lvl, Litval and HMI_HMIMode_St. Note:		
	Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the		
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local		
	sleep is allowed then Dimming_lvl = OFF		
R: 6.1.3.2-110	The APIM shall use the signals it has been identified as a subscriber to in section 6.1.2.3		
	"Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting		
	Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-		
	time Dimmable" Backlighting Illumination Algorithm		
R: 6.1.3.2-111	The APIM shall transmit a control signal to Day-time Dimmable Backlighting Illumination		
	directly connected to it that will support the desired Welcome/Farewell state specific		
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND		
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles		

Table below provided as reference for APIM subscribed signals to Expected Initial Control Signal Response:

Subsci	iber Signal Mapping	Expected initial response as per section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
Dimming_lvl	HMI_HMIMode_St	Display Illumination Response
Day_1 to Day_6 or		
Night_1 – Night_12	Don't Care	"Snap ON"/ Turn On
OFF	≠ OFFmode	"Snap ON"/ Turn On
OFF	OFFmode	"Snap OFF"/ Turn Off

Table below provided as reference for APIM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6 or		
Night_1 – Night_12	Don't Care	Day_1 to Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12
OFF	OFFmode	OFF

#### 6.1.3.11.3 Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence

R: 6.1.3.1.3-8	The APIM shall meet the requirements listed under section 5.5.1 "Center-stack	
	Welcome/Farewell Displays (Sync Screen)" (including the associated "State	
	Determination Algorithm)	
R: 6.1.3.1.3-8	The APIM will support the desired Welcome/Farewell state specific behavior specific to	
	"Welcome" and "Farewell" graphics called out in "RQT-002004-022094 LINCOLN	
	EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles	
R: 6.1.3.1.3-1	The APIM shall use the signals it has been identified as a subscriber to in section	
	6.1.2.3 "Signal Requirements" to follow the state transitions as they're listed section	
	5.2.2 "Welcome/Farewell State determination without Battery saver tie-in" with the	
	addition of "Extended Play" as described in section 3.1.2 under "Additional States":	
	Ignition_Status, DrStatDrv_B_Actl, DrStatPsngr_B_Actl, Dimming_lvl,	
	HMI_hmimode_st.	

Welcome Farewell state	Required Signals	Behavior
Welcome Courtesy Lighting		(Ignition_Status = OFF/ACCY) &
True	Ignition_Status	Dimming_lvl ≠ OFF &

	DrStatDrv_B_Actl, DrStatPsngr_B_Actl	(DrStatDrv_B_Actl OR DrStatPsngr_B_Actl = Ajar)
	Dimming_lvl	Diotati siigi_b_Acti = Ajai)
		(Ignition_Status = OFF/ACCY) &
	Ignition_Status	Dimming_lvl ≠ OFF &
	DrStatDrv_B_Actl,	(
Welcome Courtesy Lighting	DrStatPsngr_B_Actl	( DrStatDrv_B_Actl &
Delay True	Dimming_lvl	DrStatPsngr_B_Actl = Closed)
Ignition RUN/Start	Ignition_Status	Ignition_Status = RUN/Start
		Ignition_Status = RUN/Start
		transition to OFF &
Illuminated Exit True	Ignition_Status	Dimming_lvl ≠ OFF
		Ignition_Status = RUN/Start
	Ignition_Status	transition to OFF &
Extended Play	HMI_hmimode_st	(HMI_hmimode_st ≠ OFFmode)
	Ignition_Status	(Ignition_Status transition to OFF)
	DrStatDrv_B_Actl,	& Dimming_IvI ≠ OFF
Farewell Courtesy Lighting	DrStatPsngr_B_Actl	&( DrStatDrv_B_Actl OR
True	Dimming_lvl	DrStatPsngr_B_Actl = Ajar)
	Ignition_Status	(Ignition_Status transition to OFF)
	DrStatDrv_B_Actl,	& Dimming_lvl ≠ OFF &
Farewell Courtesy Lighting	DrStatPsngr_B_Actl	( DrStatDrv_B_Actl &
Delay True	Dimming_lvl	DrStatPsngr_B_Actl = Closed)

Note: Please refer to section 5.2.2 "Welcome/Farewell State Determination without Battery saver tie-in" for additional transition criteria, timeouts etc. "Approach Detection", "Illuminated Entry", and "Vehicle Locking" state should be treated the same as "Null". Dimming\_IvI = nonOFF value

#### 6.1.3.12 Rear Audio Control Module (RACM) requirements

The RACM shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

## 6.1.3.12.1 Over-arching requirements

R: 6.1.3.10-5	The RACM shall contain its Performance Latency within the End-to-End latency specified
	in section 3.2.2.1 "Performance Latency Requirements"
	The RACM shall take into account the requirements contained within section 3.2.3 "Safety
R: 6.1.3.10-6	Requirements" to ensure that no screen/display that it directly controls ends up violating
K. 0.1.3.10-0	any requirement (specific to the market the target vehicle shall be sold in) within the
	aforementioned section.
R: 6.1.3.10-7	The RACM shall take into account the requirements contained within section 3.2.4
	"Security Requirements" to ensure that no screen/display that it directly controls (via
	control signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.10-8	The RACM shall be a publisher to signals it has been identified as a publisher for within
	section 6.1.2.3 "Signal requirements"

## 6.1.3.12.2 <u>Provide Control Signal to support Interior Day-Time Dimmable Illumination (Display Brightness and Switch Backlighting)</u>

R: 6.1.3.2-112	The RACM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.1.2.3 "Signal Requirements": Dimming_lvl, Litval and HMI_HMIMode_St. Note:
	Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
	sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-113	The RACM shall use the signals it has been identified as a subscriber to in section 6.1.2.3
	"Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-
	time Dimmable" Backlighting Illumination Algorithm

R: 6.1.3.2-114	The RACM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-115	The RACM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-21	The RACM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for RACM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Expected initial response as per section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm	
Dimming_lvl	HMI_HMIMode_St Display Illumination Backlighting Control S		Backlighting Control Signal
Day_1 to Day_6 or Night_1 –	Don't Care		
Night_12		"Snap ON"/ Turn On	"Fade ON"/Ramp up
OFF	≠ OFFmode	"Snap ON"/ Turn On	"Fade ON"/Ramp up**
OFF	OFFmode	"Snap OFF"/ Turn Off	"Fade OFF"/Ramp down

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

Table below provided as reference for RACM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6	Don't Care	
or Night_1 –		
Night_12		Day_1 - Day_6 or Night_1 - Night_12
Transition to OFF	≠ OFFmode	Night_12**
OFF	OFFmode	OFF

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): OFF

## 6.1.3.12.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-116	The RACM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_IvI, Litval and HMI_HMIMode_St. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
D: C 4 2 2 447	sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-117	The RACM shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.3
	"Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-118	The RACM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND
	FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-119	The RACM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-22	
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for RACM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		"Night-time Dimmab	Expected initial response as per section 5.4.7.5 "Night-time Dimmable" Backlighting Illumination Algorithm	
HMI_HMIMode_St		Display Illumination	Backlighting Control Signal	
Dimming_IvI		Response	Response	
Day_1 to Day_6	Don't Care			
or Night_1 –				
Night_12		"Snap ON"/ Turn On	"Fade ON"/Ramp up	
OFF	≠ OFFmode	"Snap ON"/ Turn On	"Fade ON"/Ramp up**	
OFF	OFFmode	"Snap OFF"/ Turn Off	"Fade OFF"/Ramp down	

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

Table below provided as reference for RACM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6	Don't Care	
or Night_1 –		
Night_12		Day_1 - Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12**
OFF	OFFmode	OFF

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): OFF

## 6.1.3.12.4 <u>Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence</u>

R: 6.1.3.1.3-9	The RACM shall meet the requirements listed under section 5.5.1 "Center-stack Welcome/Farewell Displays (Sync Screen)" (including the associated "State Determination Algorithm)
R: 6.1.3.1.3-9	The RACM will support the desired Welcome/Farewell state specific behavior specific
	to "Welcome" and "Farewell" graphics called out in "RQT-002004-022094 LINCOLN
	EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-2	The RACM shall use the signals it has been identified as a subscriber to in section
	6.1.2.3 "Signal Requirements" to follow the state transitions as they're listed section
	5.2.2 "Welcome/Farewell State determination without Battery saver tie-in" with the
	addition of "Extended Play" as described in section 3.1.2 under "Additional States":
	Ignition_Status, DrStatDrv_B_Actl, DrStatPsngr_B_Actl, HMI_hmimode_st.

Welcome Farewell state Required Signals		Behavior
Ignition RUN/Start	Ignition_Status	Ignition_Status = RUN/Start
Illuminated Exit True	Ignition_Status	Ignition_Status = RUN/Start transition to OFF
	Ignition_Status	Ignition_Status = RUN/Start transition to OFF &
Extended Play	HMI_hmimode_st	(HMI_hmimode_st ≠ OFFmode)
Farewell Courtesy Lighting True	Ignition_Status (Ignition_Status transition	
Farewell Courtesy Lighting Delay True	Ignition_Status (Ignition_Status transition to C DrStatDrv_B_Actl, &( DrStatDrv_B_Actl & DrStatPsngr_B_Actl	

Note: Please refer to section 5.2.2 "Welcome/Farewell State Determination without Battery saver tie-in" for additional transition criteria, timeouts etc. "Approach Detection", "Illuminated Entry", "Welcome Courtesy

Lighting", "Welcome Courtesy Lighting Delay" and "Vehicle Locking" state should be treated the same as "Null".

#### 6.1.3.13 <u>Instrument Panel Cluster (IPC) requirements</u>

The IPC shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

#### 6.1.3.13.1 Over-arching requirements

R: 6.1.3.11-1	The IPC shall contain its Performance Latency within the End-to-End latency specified in
	section 3.2.2.1 "Performance Latency Requirements"
R: 6.1.3.11-2	The IPC shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no screen/display that it directly controls ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.
R: 6.1.3.11-3	The IPC shall take into account the requirements contained within section 3.2.4 "Security
	Requirements" to ensure that no screen/display that it directly controls (via control signal)
	ends up violating any requirement within the aforementioned section.

#### 6.1.3.13.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting/Display Illumination

R: 6.1.3.2-120	The IPC shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-121	The IPC shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-122	The IPC shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-123	The IPC shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-23	The IPC shall transmit a control signal to Interior Day-time Dimmable Backlighting /Display elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for IPC subscribed signals to Expected Illumination Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.1.3.13.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-124	The IPC shall subscribe to the (CAN) signals required by the subscribing function "Interior
	Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3
	"Signal Requirements": Backlit_LED_Status and Litval. Note: Backlit_LED_Status ≠ OFF
	is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but

	illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Backlit LED Status = OFF
R: 6.1.3.2-125	The IPC shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.3 "Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-126	The IPC shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-127	The IPC shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"

Table below provided as reference for IPC subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"  Backlighting Illumination Algorithm
Backlit_LED_status	Control Signal Response
Night_1 – Night_12	"Fade ON"/Ramp up
OFF	"Fade OFF"/Ramp down

#### 6.1.3.13.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-128	The IPC shall subscribe to the (CAN) signals required by the subscribing function "Interior 2-Step Dimmable Backlighting Illumination Algorithm" as identified in section 6.1.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-129	The IPC shall use the signals it has been identified as a subscriber to in section 6.1.2.3 "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-130	The IPC shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-131	The IPC shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-24	The IPC shall transmit a control signal to 2-Step Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for IPC subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

# 6.1.3.13.5 <u>Support Welcome/Farewell Animations and Displays, Gauges/Acrylic Rings, Cluster Pointers and Odometer illumination during Welcome Farewell sequence</u>

The requirements under this section are only applicable to vehicles with push button ignitions. For any bladed key or alternative implementations please refer to "Welcome-Goodbye Strategy - CGEA1.3\_v6.0" document.

R: 6.1.3.1.3-1	The IPC shall meet the welcome farewell state transition requirements listed under section 5.5.2 "Cluster Display, Pointers, and Odometer during Welcome/Farewell" – already takes inputs associated with each applicable state and their timeouts into account.
R: 6.1.3.1.3-10	The IPC will support the desired Welcome/Farewell state specific behavior
	(Illumination Levels) for "Welcome/Farewell Displays", "Instrument Cluster Backlighting
	/ Gauges and/or Acrylic Rings", "Instrument Cluster Pointers" and "Odometer" called
	out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL
	BEHAVIOR REV. X" for Lincoln vehicles.
R: 6.1.3.1.3-3	The IPC shall subscribe to the (CAN) signals required by the subscribing function "
	Vehicle Display Cluster Welcome/Farewell" as identified in section 6.1.2.3 "Signal
	Requirements" (included within state transition diagrams within section 5.2.2)

## 6.1.3.14 Austere Heads-Up Display (aHUD) requirements

The aHUD shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

## 6.1.3.14.1 Over-arching requirements

R: 6.1.3.12-1	The AHUD shall contain its Performance Latency within the End-to-End latency specified		
	in section 3.2.2.1 "Performance Latency Requirements"		
	The AHUD shall take into account the requirements contained within section 3.2.3 "Safety		
R: 6.1.3.12-2	Requirements" to ensure that no screen/display that it directly controls ends up violating		
K. 0.1.3.12-2	any requirement (specific to the market the target vehicle shall be sold in) within the		
	aforementioned section.		
R: 6.1.3.12-3	The AHUD shall take into account the requirements contained within section 3.2.4		
	"Security Requirements" to ensure that no screen/display that it directly controls (via		
	control signal) ends up violating any requirement within the aforementioned section.		
R: 6.1.3.12-4	The aHUD shall be a publisher to signals it has been identified as a publisher for within		
	section 6.1.2.3 "Signal requirements"		

## 6.1.3.14.2 <u>Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence</u>

R: 6.1.3.1.3-10	The aHUD shall meet the requirements listed under section 5.5.3 HUD
	Welcome/Farewell Displays (aHUD)" (including the associated "State Determination
	Algorithm)
R: 6.1.3.1.3-11	
	to "Welcome" and "Farewell" graphics called out in "RQT-002004-022094 LINCOLN
	EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.1.3-1	The aHUD shall use the signals it has been identified as a subscriber to in section
	6.1.2.3 "Signal Requirements" to follow the state transitions as they're listed section
	5.2.2 "Welcome/Farewell State determination without Battery saver tie-in":
	Ignition_Status, DrStatDrv_B_Actl, DrStatPsngr_B_Actl,, DrStatRI_B_ Actl,
	DrStatRr_B_ Actl, and PudLamp_D_Rq

Welcome Farewell state	Required Signals	Behavior
	Ignition_Status	(Ignition_Status = OFF/ACCY)
Welcome Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl OR
True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Ajar)
	Ignition_Status	(Ignition_Status = OFF/ACCY)
Welcome Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl &
Delay True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Closed)
Ignition RUN/Start	Ignition_Status	Ignition_Status = RUN/Start
		Ignition_Status = RUN/Start
Illuminated Exit True	Ignition_Status	transition to OFF
	Ignition_Status	(Ignition_Status transition to OFF)
Farewell Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl OR
True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Ajar)

	Ignition_Status	(Ignition_Status transition to OFF)
Farewell Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl &
Delay True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Closed)

Note: Please refer to section 5.2.2 "Welcome/Farewell State Determination without Battery saver tie-in" for additional transition criteria, timeouts etc. "Approach Detection", "Illuminated Entry", and "Vehicle Locking" state should be treated the same as "Null".

Due to aHUD initialization delays, aHUD will initialize at whichever occurs first: Pudlamp\_D\_Rq = Fade/ON or ON, Vehicle Door transitioning to ajar, or ignition transitioning to RUN/Start..

# 6.1.4 Lincoln Vehicle Lighting Element/Assembly Response Performance requirements

Requirement	Performance requirements (section reference)	Control Signal Source (for Illumination)	Component
R: 6.1.4-1	Section 5.3.2 "Exterior Front Illumination Lighting Response"	LDM	Headlamps (Low-beams) Front Side Markers Signature/Decorative LED Lamps Illuminated Lincoln Star Front Fog Lamps
R: 6.1.4-2	Section 5.3.4 "Exterior Rear Illumination Lighting Response"	R-FCM	Rear Parklamps Rear Applique Park Lamp (RAPL)
R: 6.1.4-3		BCM	Rear Corner Lamps
R: 6.1.4-4	Section 5.3.6 "Exterior	DDM	Driver's Welcome Mat
R: 6.1.4-5	Supplementary Illumination	PDM	Passenger's Welcome Mat
R: 6.1.4-6	Lighting Response"	RBM	Illuminated Power Running Boards
R: 6.1.4-7		BCM	Illuminated Door Handle Pockets
R: 6.1.4-8	Section 5.4.2 "Courtesy Lamps Lighting Response"	BCM	Courtesy Lamps Scuff Plates
R: 6.1.4-9	Section 5.4.4 "Ambient Lighting Illumination (without Static Sequential) Lighting Response"	ALM	Ambient Lighting
R: 6.1.4-10	Cooking 5 4 7 2 "Day Time	BCM	Pulsing PTS
R: 6.1.4-11	Section 5.4.7.2 "Day-Time Dimmable Backlighting	IPC	Cluster Backlighting/Indicators
R: 6.1.4-12	Illumination Response"	APIM	Center-stack display dimming
R: 6.1.4-13	Section 5.4.7.4 "Night-Time	DDM/PDM/BCM	Door trim switch/button backlighting
R: 6.1.4-14	Dimmable Backlighting Illumination Response"	ВСМ	Headlamp switch IP & Overhead-Control Switch/Button
R: 6.1.4-15		IPC	Cluster Backlighting/Indicators
R: 6.1.4-16		FCIM	Sync/Radio Control button Backlighting
R: 6.1.4-17	Section 5.4.7.6 "2-step	DDM/PDM/BCM	Door trim switch/button backlighting
R: 6.1.4-18	Dimmable Backlighting Illumination Response"	BCM	Headlamp switch IP & Overhead-Control Switch/Button
R: 6.1.4-19		FCIM	Sync/Radio Control button Backlighting
R: 6.1.4-20		IPC	Cluster Backlighting/Indicators
R: 6.1.4-21	Section 5.5.1 "Center-stack Welcome/Farewell Displays (Sync Screen)"	APIM	Center-stack Welcome/Farewell Displays
R: 6.1.4-22	Section 5.5.2 "Cluster Welcome/Farewell Displays (Sync Screen)"	IPC	Cluster Welcome/Farewell Displays Odometer
R: 6.1.4-23	Section 5.5.3 "HUD Welcome/Farewell Displays"	aHUD	aHUD Welcome/Farewell Displays

#### 6.1.4.1 "Other" Performance requirements

This section is for lighting elements or vehicle part assemblies that have been identified on "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" that respond to inputs that are outside the scope of "Welcome/Farewell" but have been included due to their impact on the feature as a whole (additionally these "features" have their own separate owners)

Requirement	Component	Control Signal Source (for Illumination)	Performance requirements owner
R: 6.1.4.1-1	Turn Signal Indicator	BCM	Body Security Group
R: 6.1.4.1-2	Illuminated Seat Belt Buckles	ALM	Interior Lighting Group Additional requirements contained within "Illuminated Belt Buckle Spec" owned by MMAJKOWS
R: 6.1.4.1-3	Night Lock Indication	BCM	Body Security Group
R: 6.1.4.1-4	Illuminated Deployable Running Board Performance	RBM	Body Electronics Group
R: 6.1.4.1-5	Autofold Mirrors	DDM/PDM	Body Electronics Group
R: 6.1.4.1-6	SECURICODE Keypad	BCM	Body Security Group
R: 6.1.4.1-7	Engine/Start stop LED	BCM	Body Electronics Group

## 6.2 Electrical Architecture - Ford Vehicles

Please note that the feature does not require specific modules (except the BCM) to be present on a vehicle, and is instead tailored to the content of the vehicle. The following section is a generic starting point to show how functions are allocated based off vehicle content and desired functionality.

## 6.2.1 Electrical Topology

Ford Welcome-Farewell topology diagrams for the following architectures:

• CGEA 1.3

#### 6.2.1.1 Combined Network/Block Diagram

The following combined network/block diagram is a generic starting point, and the actual topology should be consulted for each specific implementation.




Figure 15: Ford: Welcome Farewell Combined Network/Block Diagram

## 6.2.2 Common Requirements

#### 6.2.2.1 **Participating ECUs**

Rqm't Num	ECU	Requirement
R: 6.2.2-1	BCM	CAN Publisher, LIN Publisher
R: 6.2.2-2	LDM	LIN Subscriber
R: 6.2.2-3	ALM	LIN Subscriber
R: 6.2.2-4	OHC	LIN Subscriber
R: 6.2.2-5	HLS	LIN Subscriber
R: 6.2.2-6	DDM	CAN Subscriber
R: 6.2.2-7	PDM	CAN Subscriber
R: 6.2.2-8	IPC	CAN Subscriber
R: 6.2.2-9	APIM	CAN Publisher, CAN Subscriber
R: 6.2.2-10	RACM	CAN Subscriber
R: 6.2.2-11	FCIM	CAN Subscriber
R: 6.2.2-12	SCCM	CAN Subscriber
R: 6.2.2-13	SDLC	CAN Publisher, CAN Subscriber

## 6.2.2.2 Performance and Functional Voltage Ranges

For this feature, Performance Voltage Range is the same as the Functional Range. It shall be noted that below 9v.

Rqm't Num	Туре	Voltage Range
R: 6.2.2.2-1	Performance	9-16v
R: 6.2.2.2-2	Functional	6-16v

## 6.2.2.3 Signal Requirements

The following section lists all of the signals required to complete the desired behaviors required by the Feature. It links the logical data-flows used within this document to the actual CAN OR LIN signals that are used by the modules.

#### 6.2.2.3.1 CAN Signal Requirements

Requirement	Signal Database Detail	Value
	Signal Name	Dimming_Lvl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	APIM, FCIM, IPC, DDM, PDM, SCCM, RACM
	Subscribing Function	APIM: Interior Dimmable Backlighting Illumination Algorithm FCIM: Interior Dimmable Backlighting Illumination Algorithm IPC: Interior Dimmable Backlighting Illumination Algorithm DDM: Interior Dimmable Backlighting Illumination Algorithm PDM: Interior Dimmable Backlighting Illumination Algorithm SCCM: Interior Dimmable Backlighting Illumination Algorithm RACM: Interior Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Litval
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	APIM, IPC, DDM, PDM, FCIM, SCCM, RACM
	Subscribing Function	APIM: Interior Dimmable Backlighting Illumination Algorithm FCIM: Interior Dimmable Backlighting Illumination Algorithm IPC: Interior Dimmable Backlighting Illumination Algorithm DDM: Interior Dimmable Backlighting Illumination Algorithm PDM: Interior Dimmable Backlighting Illumination Algorithm SCCM: Interior Dimmable Backlighting Illumination Algorithm RACM: Interior Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Delay_Accy
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms

Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
Updates Signal while asleep	Updates on change
Network Wake Up	Wake up network on signal change to non-OFF value
Max latency before signal is valid on Network wakeup	<= 50ms
Max latency before signal is valid on reset	<= 120ms
CAN Node Type	HS1
Signal Domain	Refer to data dictionary
Signal Transmit Strategy	Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	BCM
Subscribing ECU	IPC
Subscribing Function	IPC: Vehicle Display Cluster Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	Backlit_LED_Status
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	DDM, PDM, SCCM, IPC, FCIM, RACM
	Subscribing Function	DDM: Interior Night-time Dimmable Backlighting Illumination Algorithm PDM: Interior Night-time Dimmable Backlighting Illumination Algorithm SCCM: Interior Night-time Dimmable Backlighting Illumination Algorithm IPC: Interior Night-time Dimmable Backlighting Illumination Algorithm FCIM: Interior Night-time Dimmable Backlighting Illumination Algorithm

RACM: Interior Night-time Dimmable Backlighting
Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	HMI_HMIMode_St
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS3 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS3
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	APIM
	Subscribing ECU	FCIM, RACM
	Subscribing Function	FCIM: Interior Day-time Dimmable Backlighting Illumination Algorithm FCIM: Interior Night-time Dimmable Backlighting Illumination Algorithm FCIM: Interior 2 step Dimmable Backlighting Illumination Algorithm RACM: Interior Day-time Dimmable Backlighting Illumination Algorithm RACM: Interior Night-time Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Ignition_Status
	Functional Voltage Range (Min,Max)	6-16v

Performance Voltage Range (Min,Max)	9-16v
Source Network	HS1 CAN
Signal refresh rate	1000ms
Publishing Interval (ms)	<= 40ms
Publisher Latency	If microprocessor is awake: <= 51ms
Requirements	If microprocessor is asleep: <=121ms
Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
Updates Signal while asleep	Updates on change
Network Wake Up	Wake up network on signal change to non-OFF value
Max latency before signal is valid on Network wakeup	<= 50ms
Max latency before signal is valid on reset	<= 120ms
CAN Node Type	HS1
Signal Domain	Refer to data dictionary
Signal Transmit Strategy	Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	BCM
Subscribing ECU	APIM, IPC, AHUD, RACM
Subscribing Function	APIM: Vehicle Display Center-stack Welcome/Farewell IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell RACM: Vehicle Display Center-stack Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatDrv_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to Closed, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change

Network Wake Up	Wake up network on signal change
Max latency before signal valid on Network wake	
Max latency before signal valid on reset	gnal is <= 120ms
CAN Node Type	HS1
Signal Domain	Refer to data dictionary
Signal Transmit Strate	egy Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle	Time 500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	BCM
Subscribing ECU	DDM, APIM, IPC, aHUD, RACM
Subscribing Function	DDM: Exterior Supplementary Illumination Algorithm APIM: Vehicle Display Center-stack Welcome/Farewell IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell RACM: Vehicle Display Center-stack Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatPsngr_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to Closed, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM

Subscribing ECU	PDM, APIM, IPC, AHUD, RACM
Subscribing Function	PDM: Exterior Supplementary Illumination Algorithm APIM: Vehicle Display Center-stack Welcome/Farewell IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell RACM: Vehicle Display Center-stack Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatRl_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency	If microprocessor is awake: <= 51ms
	Requirements	If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to Closed, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	500 ms
	End-to-End Latency Requirements	<=250 ms
	Publishing ECU	BCM
	Subscribing ECU	IPC, aHUD
	Subscribing Function	IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	DrStatRr_B_Actl
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms

Publish	er Latency	If microprocessor is awake: <= 51ms
Require	•	If microprocessor is asleep: <=121ms
Publish Inhibitor	ing Network Sleep r	If signal is not equal to Closed, then allow for network sleep but not for local sleep
Updates	s Signal while asleep	Updates on change
Network	k Wake Up	Wake up network on signal change
	ency before signal is Network wakeup	<= 50ms
Max late valid on	ency before signal is reset	<= 120ms
CAN No	ode Type	HS1
Signal [	Domain	Refer to data dictionary
Signal 7	Transmit Strategy	Event Periodic
Signal S	Send Type	OnChange
Signal	Transmit Cycle Time	500 ms
End-to- Require	End Latency ements	<=250 ms
Publish	ing ECU	BCM
Subscri	bing ECU	IPC, HUD (adv)
Subscri	bing Function	IPC: Vehicle Display Cluster Welcome/Farewell aHUD: Vehicle Display aHUD Welcome/Farewell

Requirement	Signal Database Detail	Value
	Signal Name	PudLamp_D_Rq
	Functional Voltage Range (Min,Max)	6-16v
	Performance Voltage Range (Min,Max)	9-16v
	Source Network	HS1 CAN
	Signal refresh rate	500 ms
	Publishing Interval (ms)	<= 40ms
	Publisher Latency Requirements	If microprocessor is awake: <= 51ms If microprocessor is asleep: <=121ms
	Publishing Network Sleep Inhibitor	If signal is not equal to OFF, then allow for network sleep but not for local sleep
	Updates Signal while asleep	Updates on change
	Network Wake Up	Wake up network on signal change to non-OFF value
	Max latency before signal is valid on Network wakeup	<= 50ms
	Max latency before signal is valid on reset	<= 120ms
	CAN Node Type	HS1
	Signal Domain	Refer to data dictionary

Signal Transmit Strategy	Event Periodic
Signal Send Type	OnChange
Signal Transmit Cycle Time	500 ms
End-to-End Latency Requirements	<=250 ms
Publishing ECU	BCM
Subscribing ECU	DDM, PDM, AHUD
Subscribing Function	DDM: Exterior Supplementary Illumination Algorithm PDM: Exterior Supplementary Illumination Algorithm aHUD: Vehicle Display aHUD Welcome/Farewell

#### 6.2.2.3.2 CAN Error Handling for Signal Gateway Messages

Requirements for signals that go missing either due to SNA or NC for a period of time, as per document name: "Diagnostic Fault Coverage and DTC Numbers Design Consideration", section 3.5 "Detection of faults caused by signal content and data values received from other ECUs"

R: 6.2.2.3.1-1	If a Signal gateway message containing the transmitted signal has an update bit which shows "not updated" for less than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall continue using last known value of the signal
R: 6.2.2.3.1-2	If a Signal gateway message containing the transmitted signal has an update bit which shows "not updated" for greater than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall use the signal's default value as listed in the data dictionary

#### 6.2.2.3.3 CAN Error Handling for Frame Gateway Messages

Requirements for Frame Message that go missing due to SNA or NC for a period of time as per document name: "Diagnostic Fault Coverage and DTC Numbers Design Consideration", section 3.5 "Detection of faults caused by signal content and data values received from other ECUs"

R: 6.2.2.3.2-1	If a Frame gateway message goes missing for less than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall continue using last known value of the signal received in the last Frame message.
R: 6.2.2.3.2-2	If a Frame gateway message goes missing for greater than a period of time as per "Diagnostic Fault Coverage and DTC Numbers Design Consideration" (typically 5 seconds). Then the subscriber shall use the signal's default value as listed in the data dictionary

#### 6.2.2.3.4 LIN Signal Requirements

It should be noted that the following section does not cover the level of details included under the previous "CAN Signal Requirements", since that level of details is owned and controlled by the LIN module owner, and contained within the LDFs.

The intention of this section is to list the required LIN signals to ensure that they are not discarded due to any future LDF updates.

Requirement	Signal Database Detail	Value
	Signal Name	Dimming_lvl
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to Data Dictionary

Signal <sup>-</sup>	Transmit Strategy	<=40ms Event Periodic
Signal	Send Type	OnChange
Signal <sup>-</sup>	Transmit Cycle Time	<=40ms Event Periodic
Publish	ing ECU	BCM
Subscri	bing ECU	HLS
Subscri	bing Function	HLS: Interior Day-time Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Litval
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to Data Dictionary
	Signal Transmit Strategy	<=40ms Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	<=40ms Event Periodic
	Publishing ECU	BCM
	Subscribing ECU	HLS
	Subscribing Function	HLS: Interior Day-time Dimmable Backlighting Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Ignition_Status
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	<=40ms
	Publishing ECU	BCM
	Subscribing ECU	LDM, ALM, OHC
	Subscribing Function	LDM: Exterior Front Illumination Algorithm; ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm OHC: Interior Courtesy Lamps Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Wfsuperstate
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to Data Dictionary
	Signal Transmit Strategy	<=40ms Event Periodic
	Signal Send Type	OnChange

Signal Transmit Cycle Time	<=40ms Event Periodic
Publishing ECU	BCM
Subscribing ECU	LDM, R-FCM
Subscribing Function	LDM: Exterior Front Illumination Algorithm; R-FCM: Exterior Rear Illumination Algorithm;

Requirement	Signal Database Detail	Value
	Signal Name	Wfsubstate
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to Data Dictionary
	Signal Transmit Strategy	<=40ms Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	<=40ms Event Periodic
	Publishing ECU	BCM
	Subscribing ECU	LDM, R-FCM
	Subscribing Function	LDM: Exterior Front Illumination Algorithm; R-FCM: Exterior Rear Illumination Algorithm;

Requirement	Signal Database Detail	Value
	Signal Name	WelcomeFarewell_State
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to Data Dictionary
	Signal Transmit Strategy	<=40ms Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	<=40ms Event Periodic
	Publishing ECU	BCM
	Subscribing ECU	ALM, OHC
	Subscribing Function	ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm OHC: Interior Courtesy Lamps Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	WelcomeFarewell_Substate
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to Data Dictionary
	Signal Transmit Strategy	<=40ms Event Periodic
	Signal Send Type	OnChange

Signal Transmit Cycle Time	<=40ms Event Periodic
Publishing ECU	BCM
Subscribing ECU	ALM, OHC
Subscribing Function	ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm OHC: Interior Courtesy Lamps Illumination Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Customer_Color
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	<=40ms
	Publishing ECU	ВСМ
	Subscribing ECU	ALM
	Subscribing Function	ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm

Requirement	Signal Database Detail	Value
	Signal Name	Customer_Intensity
	Source Network	LIN
	Signal refresh rate	<=40ms
	Signal Domain	Refer to data dictionary
	Signal Transmit Strategy	Event Periodic
	Signal Send Type	OnChange
	Signal Transmit Cycle Time	<=40ms
	Publishing ECU	BCM
	Subscribing ECU	ALM
	Subscribing Function	ALM: Interior Ambient Light Illumination (with Static Sequential) Algorithm ALM: Interior Ambient Light Illumination (without Static Sequential) Algorithm

## 6.2.2.3.5 <u>Linking Logical Data Flows to CAN/LIN Signals</u>

Rqmt #	Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
R: 6.1.2.3.4-	Ignition Status	Vehicle Ignition is OFF	Ignition_Status	OFF
		Vehicle Ignition is Accessory		Accessory

		Vehicle Ignition is Run		RUN
		Vehicle Ignition is Start		Start
		Not supported		Unknown
		Not supported		Invalid
R: 6.1.2.3.4-	Driver Door	Driver Door Ajar	DrStatDrv_B_ActI	Ajar
	Status	Driver Door Closed		Closed
R: 6.1.2.3.4-	Passenger Door Status	Passenger Door Ajar	DrStatPsngr_B_ActI	Ajar
		Passenger Door Closed		Closed
R: 6.1.2.3.4-	Rear Left Door	Rear Left Door Ajar	DrStatRI_B_ActI	Ajar
	Status	Rear Left Door Closed		Closed
R: 6.1.2.3.4-	Rear Right Door Status	Rear Right Door Ajar	DrStatRr_B_ActI	Ajar
		Rear Right Door Closed		Closed
	Battery Saver Timer	Battery Saver Timer Active	Courtesy_Bsave_Stat	No_Effect
R: 6.1.2.3.4-		Battery Saver Timer Expired		Off
		Not supported		Unknown
		Not supported		Invalid
	Delayed Accessory	Delayed Accessory True	Delay_Accy	ON
R: 6.1.2.3.4-	·	Delayed Accessory False		OFF
	Extended Play	Extended Play True	HMI_HMIMode_St	On
R: 6.1.2.3.4-		Extended Play False		OffMode
		Not supported		Phone
		Not supported		Climate
		Not supported		Load_Shed_Active
		Not supported		Invalid

## 6.2.3 Ford Vehicle ECU specific requirements

## 6.2.3.1 Body Control Module (BCM)

The Body Control Module (BCM) shall be responsible for doing the Welcome Farewell State determination (both with and without battery saver) and then either transmitting the state information (via CAN or LIN) or transmitting a control signal to a specific lighting element that is directly connected to it.

#### 6.2.3.1.1 Over-arching requirements

R: 6.2.3.1.1-1	The BCM shall contain its Performance Latency within the End-to-End latency specified in		
	section 3.2.2.1 "Performance Latency Requirements"		
R: 6.2.3.1.1-2	The BCM shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no lighting element that it directly controls (via control signal) ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.		
R: 6.2.3.1.1-3	The BCM shall take into account the requirements contained within section 3.2.4 "Security Requirements" to ensure that no lighting element that it directly controls (via control		
	signal) ends up violating any requirement within the aforementioned section.		

R: 6.1.3.1.1-2	The BCM shall meet the publisher requirements for all the signals it has been identified as
	a publisher to within section 6.2.2.3 "Signal Requirements"
R: 6.1.3.1.1-2	The BCM shall meet the subscriber requirements for all the signals it has been identified
	as a subscriber to within section 6.2.2.3 "Signal Requirements"

## 6.2.3.1.2 <u>Support Welcome Farewell State Determination functions</u>

section 5.2 – shall be capable of support	rewell State Determination" requirements under orting both "Welcome/Farewell State Determination ome/Farewell State Determination with Battery s
---	--

## 6.2.3.1.3 Support Exterior Front Illumination

## 6.2.3.1.3.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-11	The BCM shall transmit a control signal to Exterior Front Illumination elements directly connected to it that meet the requirements under section 5.3.1 "Exterior Front
	Illumination Algorithm" (including the associated "State Determination Algorithm)
R: 6.1.3.1.3-12	The BCM shall transmit a control signal to Exterior Front Illumination elements directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-8	The BCM shall transmit a control signal to Exterior Front Illumination elements directly connected to it that will satisfy the control signal specific requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"

## 6.2.3.1.3.2 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-5	The BCM shall use the outputs/state determination from section 5.2.2		
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then		
	transmit WFsuperstate and WFsubstate as listed in the table below in order to support		
	Exterior Front Illumination		

	Logical	Logical Data Flow		
Rqmt #	Data Flow	Domain Name	Wfsuperstate	Wfsubstate
	Approach	Approach Detected	Welcome	Approach
	Approach Detection	Approach Not		
R: 6.1.2.3.5-2	Detection	Detected	Don't care	NULL**
		Illuminated Entry		
	Illuminated	True	Welcome	IllumEntry
	Entry	Illuminated Entry		
R: 6.1.2.3.5-3		False	Don't care	NULL**
		Courtesy Lighting		
	Courtesy	True	Don't care	DoorAjarCourtesyLight
	Lighting	Courtesy Lighting		
R: 6.1.2.3.5-3		False	Don't care	NULL**
	Courtesy	Courtesy Lighting		
	Lighting	Delay True	Don't care	CourtesyLightDelay
	Delay	Courtesy Lighting		
R: 6.1.2.3.5-3	Dolay	Delay False	Don't care	NULL**
		Illuminated Exit		
	Illuminated	True	Farewell	IIIExit
	Exit	Illuminated Exit		
R: 6.1.2.3.5-3		False	Don't care	NULL**
	Ignition	Vehicle Ignition is		
R: 6.1.2.3.5-3	State	OFF	NOT (RunStart)	Don't Care

		Vehicle Ignition is		
		in Accessory	NOT (RunStart)	Don't Care
		Vehicle Ignition is		
		in Run/Start	RunStart	NULL**
		Vehicle Locking		
	Vehicle	True	OFF	NULL
	Locking	Vehicle Locking		
R: 6.1.2.3.5-3		False	Don't care	NULL**

## 6.2.3.1.4 Support Exterior Rear Illumination

## 6.2.3.1.4.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-12	The BCM shall transmit a control signal to Exterior Rear Illumination elements directly connected to it that meet the requirements under section 5.3.3 "Exterior Rear
	Illumination Algorithm" (including the associated "State Determination Algorithm)
R: 6.1.3.1.3-13	The BCM shall transmit a control signal to Exterior Rear Illumination elements directly
	connected to it that will support the desired Welcome/Farewell state specific behavior
	called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV.
	1" for Ford vehicles
R: 6.1.3.1.3-9	The BCM shall transmit a control signal to Exterior Rear Illumination elements directly
	connected to it that will satisfy the control signal specific requirements listed under
	Appendix 1 "Exterior Lighting PWM Signal Specification"

## 6.2.3.1.4.2 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-6	The BCM shall use the outputs/state determination from section 5.2.2		
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then		
	transmit WFsuperstate and WFsubstate as listed in the table below in order to support		
	Exterior Rear Illumination		

Damt #	Logical Data Flow	Logical Data Flow Domain Name	Wfoundratete	Wfsubstate
Rqmt #	Data Flow		Wfsuperstate Welcome	11100.001.01
	Approach	Approach Detected	vveicome	Approach
D 040050	Detection	Approach Not	Davilla and	NII II I **
R: 6.1.2.3.5-3		Detected	Don't care	NULL**
		Illuminated Entry	1A/ 1	
	Illuminated	True	Welcome	IllumEntry
	Entry	Illuminated Entry		
R: 6.1.2.3.5-3		False	Don't care	NULL**
		Courtesy Lighting		
	Courtesy	True	Don't care	DoorAjarCourtesyLight
	Lighting	Courtesy Lighting		
R: 6.1.2.3.5-3		False	Don't care	NULL**
	Courtoov	Courtesy Lighting		
	Courtesy	Delay True	Don't care	CourtesyLightDelay
	Lighting	Courtesy Lighting		
R: 6.1.2.3.5-3	Delay	Delay False	Don't care	NULL**
		Illuminated Exit		
	Illuminated	True	Farewell	IIIExit
	Exit	Illuminated Exit		
R: 6.1.2.3.5-4		False	Don't care	NULL**
		Vehicle Ignition is		
		OFF	NOT (RunStart)	Don't Care
	Ignition	Vehicle Ignition is	, ,	
	State	in Accessory	NOT (RunStart)	Don't Care
		Vehicle Ignition is	,	
R: 6.1.2.3.5-4		in Run/Start	RunStart	NULL**

	Vehicle	Vehicle Locking True	OFF	NULL
	Locking	Vehicle Locking		
R: 6.1.2.3.5-4		False	Don't care	NULL**

## 6.2.3.1.5 Support Exterior Supplementary Illumination

## 6.2.3.1.5.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-13	The BCM shall transmit a control signal to Exterior Supplementary Illumination
	elements directly connected to it that meet the requirements under section 5.3.5
	"Exterior Supplementary Illumination Algorithm" (including the associated "State
	Determination Algorithm)
R: 6.1.3.1.3-14	The BCM shall transmit a control signal to Exterior Supplementary Illumination
	elements directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL
	STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-10	The BCM shall transmit a control signal to Exterior Supplementary Illumination
	elements directly connected to it that will satisfy the control signal specific
	requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"

## 6.2.3.1.5.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-4	.3-4 The BCM shall use the outputs/state determination from section 5.2.3	
	"Welcome/Farewell State Determination with Battery Saver tie-in" function to then	
	transmit PudLamp_D_Rq, as listed in the table below in order to support Exterior	
	Supplementary Illumination	

Rqmt #	Approach Detected	Illuminated Entry	Courtesy Lighting	Courtesy Lighting Delay	PudLamp_D_Rq
2.2.3.6-14	Approach				,
	Detected	(Don't Care)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-15	Approach	Illuminated Entry			
	Not	True (Keyfob/PK			
	Detected	unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-16	Approach	Illuminated Entry			
	Not	True (Keypad			
	Detected	unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-17	Approach	Illuminated Entry			
	Not	True (Cylinder			
	Detected	unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-16	Approach				
	Not	Illuminated Entry	Courtesy		
	Detected	False	Lighting True	(Don't Care)	Ramp_Up
2.2.3.6-17	Approach			Courtesy	
	Not	Illuminated Entry	Courtesy	Lighting Delay	
	Detected	False	Lighting False	True	Ramp_Up
2.2.3.6-18	Approach			Courtesy	
	Not	Illuminated Entry	Courtesy	Lighting Delay	
	Detected	False	Lighting False	False	Ramp_Down

## 6.2.3.1.6 Support Interior Courtesy Lamps Illumination

## 6.2.3.1.6.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-14	The BCM shall transmit a control signal to Interior Courtesy Lamps Illumination
	elements directly connected to it that meet the requirements under section 5.4.1
	"Courtesy Lamps Illumination Algorithm" (including the associated "State
	Determination Algorithm)

R: 6.1.3.1.3-1	The BCM shall transmit a control signal to Courtesy Lamps Illumination elements		
directly connected to it that will support the desired Welcome/Farewell state s			
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL		
	STRATEGY REV. 1" for Ford vehicles		
R: 6.1.3.1.3-1	The BCM shall transmit a control signal to Courtesy Lamps Illumination elements		
	directly connected to it that will satisfy the control signal specific requirements listed		
	under Appendix 2 "Interior Lighting PWM Signal Specification"		

## 6.2.3.1.6.2 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-7	The BCM shall use the outputs/state determination from section 5.2.3	
	"Welcome/Farewell State Determination with Battery Saver tie-in" function to then	
	transmit WelcomeFarewell_State and WelcomeFarewell_Substate as listed in the	
	table below in order to support Courtesy Lamps Illumination	

Rqmt #	Logical Data Flow	Logical Data Flow Domain Name	WelcomeFarewell State	WelcomeFarewell Substate
Kqiii #	Data Flow	Approach Detected	WELCOME	APPROACH
	Approach		WELCOME	AFFROACH
R: 6.1.2.3.5-4	Detection	Approach Not Detected	Don't care	NULL**
	Illuminated	Illuminated Entry True	WELCOME	ENTRY
R: 6.1.2.3.5-4	Entry	Illuminated Entry False	Don't care	NULL**
	Courtesy	Courtesy Lighting True	Don't care	DOOR
R: 6.1.2.3.5-4	Lighting	Courtesy Lighting False	Don't care	NULL**
	Courtesy Lighting	Courtesy Lighting Delay True	Don't care	DELAY
R: 6.1.2.3.5-4	Delay	Courtesy Lighting Delay False	Don't care	NULL**
	Illuminated	Illuminated Exit True	FAREWELL	EXIT
R: 6.1.2.3.5-4	Exit	Illuminated Exit False	Don't care	NULL**
		Vehicle Ignition is OFF	NOT (RUN_START)	Don't Care
	Ignition State	Vehicle Ignition is in Accessory	NOT (RUN_START)	Don't Care
R: 6.1.2.3.5-4		Vehicle Ignition is in Run/Start	RUN_START	NULL**
	Vehicle	Vehicle Locking True	NULL	NULL
R: 6.1.2.3.5-4	Locking	Vehicle Locking False	Don't care	NULL**

## 6.2.3.1.7 <u>Support Interior Ambient Lighting (without Static Sequential) Illumination</u>

## 6.2.3.1.7.1 Modules that subscribe to BCM via LIN

R: 6.1.3.1.3-8	The BCM shall use the outputs/state determination from section 5.2.3	
	"Welcome/Farewell State Determination with Battery Saver tie-in" function to then	
	transmit WelcomeFarewell_State and WelcomeFarewell_Substate as listed in the	

table below in order to support Interior Ambient Lighting (without Static Sequential) Illumination

	Logical	Logical Data Flow	WelcomeFarewell	WelcomeFarewell
Rqmt #	Data Flow	Domain Name	_State	_Substate
	Approach	Approach Detected	WELCOME	APPROACH
R: 6.1.2.3.5-5	Dotoction	Approach Not Detected	Don't care	NULL**
	Illuminated	Illuminated Entry True	WELCOME	ENTRY
R: 6.1.2.3.5-5	Entry	Illuminated Entry False	Don't care	NULL**
	Courtesy	Courtesy Lighting True	Don't care	DOOR
R: 6.1.2.3.5-5	Lighting	Courtesy Lighting False	Don't care	NULL**
	Courtesy Lighting Delay	Courtesy Lighting Delay True	Don't care	DELAY
R: 6.1.2.3.5-5		Courtesy Lighting Delay False	Don't care	NULL**
	Illuminated	Illuminated Exit True	FAREWELL	EXIT
R: 6.1.2.3.5-5	Exit	Illuminated Exit False	Don't care	NULL**
		Vehicle Ignition is OFF	NOT (RUN_START)	Don't Care
	Ignition State	Vehicle Ignition is in Accessory	NOT (RUN_START)	Don't Care
R: 6.1.2.3.5-5		Vehicle Ignition is in Run/Start	RUN_START	NULL**
	Vehicle	Vehicle Locking True	NULL	NULL
R: 6.1.2.3.5-5	Locking	Vehicle Locking False	Don't care	NULL**

1		
	R: 6.1.3.1.3-2	The BCM shall use the outputs/state determination from section 5.2.3
		"Welcome/Farewell State Determination with Battery Saver tie-in" function to then
		transmit Customer_Color and Customer_Intensity to support the desired
		Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA
		WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles

## 6.2.3.1.8 <u>Support Interior Day-time Dimmable Backlighting Illumination</u>

## 6.2.3.1.8.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-15	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	Illumination elements directly connected to it that meet the requirements under section
	5.4.7.1 "Interior Day-time Dimmable Backlighting Illumination Algorithm" (including the
	associated "State Determination Algorithm)
R: 6.1.3.1.3-16	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL
	STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-12	The BCM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will satisfy the control signal specific
	requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"

R: 5.4.7.1.6-25	The BCM shall transmit a control signal to Day-time Dimmable Backlighting elements
	directly connected to it that will support the desired Smooth Dimming behavior as
	detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

6.2.3.1.8.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-5	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then
	transmit Dimming_IvI and Litval as listed in the table below in order to support Interior
	Day-time Dimmable Backlighting

	Exterior	Laure it is an	0	Courtesy	III	
Rqmt #	Ambient Level	Ignition Status	Courtesy Lighting	Lighting Delay	Illuminated Exit	Dimming_lvl
2.2.3.6-18						User selected
			(Don't	(Don't		Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
2.2.3.6-16						User selected
			(Don't	(Don't		Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-17			Courtesy			User selected
			Lighting	(Don't		Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
2.2.3.6-18			Courtesy			User selected
			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
2.2.3.6-19			Courtesy	Courtesy		User selected
			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-6			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-16				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Day_1 to
	"Day"	OFF/Accy	False	False	True	Day_6 level
2.2.3.6-17				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Night_1 to
	"Night"	OFF/Accy	False	False	True	Night_12 level
2.2.3.6-18				Courtesy		
			Courtesy	Lighting		
			Lighting	Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"	Litval	Twilight_1
Exterior	"Night"		Twilight_2
Ambient Level	"Night"		Twilight_3
20101	"Night"		Twilight_4
	"Night"		Night

not supported	Unknown
not supported	Invalid

## 6.2.3.1.9 <u>Support Interior Night-time Dimmable Backlighting Illumination</u>

## 6.2.3.1.9.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-16	The BCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	Illumination elements directly connected to it that meet the requirements under section
	5.4.7.3 "Interior Night-time Dimmable Backlighting Illumination Algorithm" (including
	the associated "State Determination Algorithm)
R: 6.1.3.1.3-17	The BCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL
	STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-13	The BCM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will satisfy the control signal specific
	requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-26	The BCM shall transmit a control signal to Night-time Dimmable Backlighting elements
	directly connected to it that will support the desired Smooth Dimming behavior as
	detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

## 6.2.3.1.9.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

R: 6.1.3.1.3-6	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then
	transmit Backlit_Led_status and Litval as listed in the table below in order to support
	Interior Night-time Dimmable Backlighting

Rqmt #	Exterior Ambient Level	Ignition Status	Courtesy Lighting	Courtesy Lighting Delay	Illuminated Exit	Backlit_ Led_ Status
2.2.3.6-19				_		Non-selectable
			(Don't	(Don't		Night_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Night_12 value
2.2.3.6-19						User selected
			(Don't	(Don't		Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-20			Courtesy			Non-selectable
			Lighting	(Don't		Night_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Night_12 value
2.2.3.6-21			Courtesy			User selected
			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
2.2.3.6-20			Courtesy	Courtesy		Non-selectable
			Lighting	Lighting		Night_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 value
5.2.2.3.6-7			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-19				Courtesy		
			Courtesy	Lighting		Non-selectable
			Lighting	Delay	Illuminated Exit	Night_1 to
	"Day"	OFF/Accy	False	False	True	Night_12 value
2.2.3.6-20			Courtesy			User selected
			Lighting	Courtesy	Illuminated Exit	Night_1 to
	"Night"	OFF/Accy	False	Lighting	True	Night_12 level

				Delay		
				False		
2.2.3.6-21				Courtesy		
			Courtesy	Lighting		
			Lighting	Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF

Note: "Non-selectable Night\_1 to Night\_12 value" is configurable within the BCM, and must be approved by Vehicle Harmony team.

Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1 :6	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
2010.	"Night"		Night
	not supported		Unknown
	not supported		Invalid

#### 6.2.3.1.9.3 Support LIN Headlamp Switch Backlighting Illumination

	R: 6.1.3.1.3-7	The BCM shall use the outputs/state determination from section 5.2.2
		"Welcome/Farewell State Determination without Battery Saver tie-in" function to
		transmit Backlit_Led_status as listed in previous section, to support LIN Headlamp
l		Switch Backlighting Illumination.

#### 6.2.3.1.10 Support Interior 2-Step Dimmable Backlighting Illumination

#### 6.2.3.1.10.1 Rely on BCM for Control Signal

R: 6.1.3.1.3-17	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting
	Illumination elements directly connected to it that meet the requirements under section
	5.4.7.5 "Interior Day-time Dimmable Backlighting Illumination Algorithm" (including the
	associated "State Determination Algorithm)
R: 6.1.3.1.3-18	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting
	elements directly connected to it that will support the desired Welcome/Farewell state
	specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL
	STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-14	The BCM shall transmit a control signal to Interior 2-Step Dimmable Backlighting
	elements directly connected to it that will satisfy the control signal specific
	requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-27	The BCM shall transmit a control signal to 2-Step Dimmable Backlighting elements
	directly connected to it that will support the desired Smooth Dimming behavior as
	detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

#### 6.2.3.1.10.2 Modules that subscribe to CAN signals originating from BCM (can be via Gateway)

Ī	R: 6.1.3.1.3-8	The BCM shall use the outputs/state determination from section 5.2.2				
		"Welcome/Farewell State Determination without Battery Saver tie-in" function to then				
		transmit Dimming_IvI and Litval as listed in the table below in order to support Interior				
		2-Step Dimmable Backlighting				

	Exterior			Courtesy		
D #	Ambient	Ignition	Courtesy	Lighting	Illuminated	Dimension of the
Rqmt # 2.2.3.6-20	Level	Status	Lighting	Delay	Exit	Dimming_IvI User selected
2.2.3.6-20			(Don't	(Don't		
	"Dov"	Divis/Otout	(Don't	(Don't	(Danit Cara)	Day_1 to
0.0.0.00	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
2.2.3.6-22			/Don't	(Don't		User selected
	"N I: I- 4"	D. v.s. /Ot s. s.t	(Don't	(Don't	(Dault Cana)	Night_1 to
0.0.0.00	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-23			Courtesy	(D1)		User selected
	"D"	055/4	Lighting	(Don't	(D (O )	Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
2.2.3.6-24			Courtesy	(5.1)		User selected
	(A) 11 1 4 W	0==/4	Lighting	(Don't	(5 1: 0 )	Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
2.2.3.6-21			Courtesy	Courtesy		User selected
			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-8			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-22				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Day_1 to
	"Day"	OFF/Accy	False	False	True	Day_6 level
2.2.3.6-23				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Night_1 to
	"Night"	OFF/Accy	False	False	True	Night_12 level
2.2.3.6-24				Courtesy		
			Courtesy	Lighting		
			Lighting	Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1.56	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
2070.	"Night"		Night
	not supported		Unknown
	not supported		Invalid

## 6.2.3.1.10.3 Support LIN Headlamp Switch Indicator Illumination

R: 6.1.3.1.3-9	The BCM shall use the outputs/state determination from section 5.2.2
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to
	transmit Dimming_IvI, and Litval as listed in previous section, to support LIN
	Headlamp Switch Indicator Illumination.

R: 6.1.3.1.3-10	R: 6.1.3.1.3-10 The BCM shall use the outputs/state determination from section 5.2.2					
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then					
	transmit Dimming_IvI and Litval as listed in the table below in order to support Center-					
	stack Day-time Dimmable Illumination for Display Brightness					

	Exterior Ambient	Ignition	Courtesy	Courtesy Lighting	Illuminated	
Rqmt #	Level	Status	Lighting	Delay	Exit	Dimming_lvl
2.2.3.6-21						User selected
			(Don't	(Don't		Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
2.2.3.6-25						User selected
			(Don't	(Don't		Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-26			Courtesy			User selected
			Lighting	(Don't		Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
2.2.3.6-27			Courtesy			User selected
			Lighting	(Don't		Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
2.2.3.6-22			Courtesy	Courtesy		User selected
			Lighting	Lighting		Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
5.2.2.3.6-9			Courtesy	Courtesy		User selected
			Lighting	Lighting		Night_1 to
	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-25				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Day_1 to
	"Day"	OFF/Accy	False	False	True	Day_6 level
2.2.3.6-26				Courtesy		
			Courtesy	Lighting		User selected
			Lighting	Delay	Illuminated Exit	Night_1 to
	"Night"	OFF/Accy	False	False	True	Night_12 level
2.2.3.6-27				Courtesy		
			Courtesy	Lighting	l <u> </u>	
			Lighting	Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	l itual	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
	"Night"		Night
	not supported		Unknown
	not supported		Invalid

R: 6.1.3.1.3-11	11 The BCM shall use the outputs/state determination from section 5.2.2					
	"Welcome/Farewell State Determination without Battery Saver tie-in" function to then					
	transmit Dimming_IvI and Litval as listed in the table below in order to support Cluster					
	Day-time Dimmable Illumination for Display Brightness					

	Exterior Ambient	Ignition	Courtesy	Courtesy Lighting	Illuminated	
Rqmt #	Level	Status	Lighting	Delay	Exit	Dimming_lvl
2.2.3.6-22						User selected
		_ /2	(Don't	(Don't	(	Day_1 to
	"Day"	Run/Start	Care)	Care)	(Don't Care)	Day_6 level
2.2.3.6-28			(B)	<b>(5</b> );		User selected
	<b>"</b>	D (0)	(Don't	(Don't	(5 1: 0 )	Night_1 to
	"Night"	Run/Start	Care)	Care)	(Don't Care)	Night_12 level
2.2.3.6-29			Courtesy	(D. 1)		User selected
	"D"	055/4	Lighting	(Don't	(5 1: 0 )	Day_1 to
	"Day"	OFF/Accy	True	Care)	(Don't Care)	Day_6 level
2.2.3.6-30			Courtesy	(D. )		User selected
	"NI" I 1"	055/4	Lighting	(Don't	(5 1: 0 )	Night_1 to
	"Night"	OFF/Accy	True	Care)	(Don't Care)	Night_12 level
2.2.3.6-23			Courtesy	Courtesy		User selected
	"D"	0==/4	Lighting	Lighting	(5 1: 0 )	Day_1 to
	"Day"	OFF/Accy	False	Delay True	(Don't Care)	Day_6 level
2.2.3.6-10			Courtesy	Courtesy		User selected
	"N 1" - 1- 1"	055/4	Lighting	Lighting	(D1) (O)	Night_1 to
0.0.0.00	"Night"	OFF/Accy	False	Delay True	(Don't Care)	Night_12 level
2.2.3.6-28			0	Courtesy		11
			Courtesy	Lighting		User selected
	"D "	055/4	Lighting	Delay	Illuminated Exit	Day_1 to
2.2.3.6-29	"Day"	OFF/Accy	False	False	True	Day_6 level
2.2.3.6-29			Countage	Courtesy		Lloor colootod
			Courtesy	Lighting	Illiumsimasta d. Essit	User selected
	"Night"	OFF/Accir	Lighting	Delay	Illuminated Exit	Night_1 to
2 2 2 6 20	"Night"	OFF/Accy	False	False	True	Night_12 level
2.2.3.6-30			Courtesy	Courtesy		
			Lighting	Lighting Delay	Illuminated Exit	
	Don't Care	OFF/Accy	False	False	False	OFF
	Don't Cale	OI I /ACC)	ו מוטכ	i aise	1 8136	Oi I

Note: Current Ambient Light Sensing strategy that relies on the ALS sensor listed under the following table and should be used as reference only. Ambient light sensing strategy subject to change depending on vehicle architecture and strategy owned by BCM team.

Logical Data Flow	Logical Data Flow Domain Name	Signal Name	Signal Domain Value
	"Day"		Day
	"Night"		Twilight_1
	"Night"		Twilight_2
Exterior	"Night"	1 :4	Twilight_3
Ambient Level	"Night"	Litval	Twilight_4
	"Night"		Night
	not supported		Unknown
	not supported		Invalid

R: 6.1.3.1.3-12 The BCM shall use the outputs/state determination from section 5.2.2 "Welcome/Farewell State Determination without Battery Saver tie-in" function to then transmit PudLamp\_D\_Rq, as listed in the table below in order to support aHUD Welcome/Farewell behavior

Rqmt #	Approach Detected	Illuminated Entry	Courtesy Lighting	Courtesy Lighting Delay	PudLamp_D_Rq
2.2.3.6-23	Approach	(Don't		(Don't	
	Detected	Care)	(Don't Care)	Care)	Ramp_Up
2.2.3.6-24	Approach Not Detected	Illuminated Entry True (Keyfob/PK unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-25	Approach Not Detected	Illuminated Entry True (Keypad unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-26	Approach Not Detected	Illuminated Entry True (Cylinder unlock)	(Don't Care)	(Don't Care)	Ramp_Up
2.2.3.6-24	Approach Not Detected	Illuminated Entry False	Courtesy Lighting True AND (Both Driver AND Passenger Door Closed)	(Don't Care)	Ramp_Up
2.2.3.6-25	Approach Not Detected	Illuminated Entry False	Courtesy Lighting True AND Driver Door Closed	(Don't Care)	Ramp_Up
2.2.3.6-26	Approach Not Detected	Illuminated Entry False	Courtesy Lighting True AND Passenger Door Closed	(Don't Care)	Ramp_Up
2.2.3.6-27	Approach Not Detected	Illuminated Entry False	Courtesy Lighting False	Courtesy Lighting Delay True	Ramp_Up
2.2.3.6-28	Approach Not Detected	Illuminated Entry False	Courtesy Lighting False	Courtesy Lighting Delay False	Ramp_Down

## 6.2.3.1.14 Support "Other" Welcome/Farewell Behavior

R: 6.2.3.1.14-1	To support the "Turn Signal Indicators" illumination as per "RQT-002004-021878 DNA						
	WELCOME-FAREWELL STRATEGY REV. 1" the BCM shall use the outputs/state						
	determination from section 5.2.2 "Welcome/Farewell State Determination without Battery						
	Saver tie-in". Turn signal response to welcome farewell states is owned by Body Security						
	Group.						
R: 6.2.3.1.14-2	To support the "Illuminated Scuff Plates" behavior as per "RQT-002004-021878 DNA						
	WELCOME-FAREWELL STRATEGY REV. 1" the BCM shall use the outputs/state						
	determination from section 5.2.3 "Welcome/Farewell State Determination with Battery						

	Saver tie-in" to meet the requirements listed within section 5.4.1 "Interior Courtesy Lamps Illumination Algorithm"
R: 6.2.3.1.14-3	<u> </u>
R: 6.2.3.1.14-4	U /

## 6.2.3.2 **LED Driver Module (LDM) requirements**

The LDM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: Headlamps (low-beams), Signature/Decorative LED Lamps

#### 6.2.3.2.1 Over-arching requirements

R: 6.1.3.2-132	The LDM shall contain its Performance Latency within the End-to-End latency specified in		
	section 3.2.2.1 "Performance Latency Requirements"		
The LDM shall take into account the requirements contained within section 3.2			
R: 6.1.3.2-133	Requirements" to ensure that no lighting element that it directly controls (via control		
K. 0.1.3.2-133	signal) ends up violating any requirement (specific to the market the target vehicle shall be		
	sold in) within the aforementioned section.		
R: 6.1.3.2-134	The LDM shall take into account the requirements contained within section 3.2.4 "Security		
	Requirements" to ensure that no lighting element that it directly controls (via control		
	signal) ends up violating any requirement within the aforementioned section.		
R: 6.1.3.2-135	The LDM shall be a publisher to signals it has been identified as a publisher for within		
	section 6.2.2.3 "Signal requirements"		

#### 6.2.3.2.2 Provide Control Signal to support Front Exterior Illumination

R: 6.1.3.2-136	The LDM shall subscribe to the (LIN) signals required by the subscribing function "Exterior		
14. 0.1.3.2-130	Front Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements":		
	Wfsuperstate and WFsubstate.		
R: 6.1.3.2-137	The LDM shall use the signals it has been identified as a subscriber to in section 6.1.2.3		
	"Signal Requirements" to transmit a control signal to Exterior Front Lighting elements		
	directly connected to it that meet the requirements under section 5.3.1 "Exterior Front		
	Illumination Algorithm"		
R: 6.1.3.2-138	The LDM shall transmit a control signal to Exterior Front Illumination elements directly		
	connected to it that will support the desired Welcome/Farewell state specific behavior		
	called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for		
	Ford vehicles		
R: 6.1.3.2-139	The LDM shall transmit a control signal to Front Exterior Illumination elements directly		
	connected to it that will satisfy the control signal specific requirements listed under		
	Appendix 1 "Exterior Lighting PWM Signal Specification"		

Note: Table below provided as reference for LDM subscribed signals to ARL callouts mapping:

l	ARL call-out		Subscriber	Signal Mapping
	Logical	Logical Data Flow		
	Data Flow	Domain Name	Wfsuperstate	Wfsubstate

A  -	Approach Detected	Welcome	Approach
Approach	Approach Not		
Detection	Detected	Don't care	NULL**
	Illuminated Entry		
Illuminated	True	Welcome	IllumEntry
Entry	Illuminated Entry		
	False	Don't care	NULL**
	Courtesy Lighting		
Courtesy	True	Don't care	DoorAjarCourtesyLight
Lighting	Courtesy Lighting		
	False	Don't care	NULL**
Courtesy	Courtesy Lighting		
Lighting	Delay True	Don't care	CourtesyLightDelay
Delay	Courtesy Lighting		
	Delay False	Don't care	NULL**
	Illuminated Exit	_ "	
Illuminated	True	Farewell	IIIExit
Exit	Illuminated Exit	Dan't	NII II I **
	False	Don't care	NULL**
	Vehicle Ignition is OFF	NOT (Due Chart)	Dan't Care
Ignition		NOT (RunStart)	Don't Care
Ignition State	Vehicle Ignition is in Accessory	NOT (RunStart)	Don't Care
State	Vehicle Ignition is	NOT (Runstant)	Don't Care
	in Run/Start	RunStart	NULL**
	Vehicle Locking	Runolan	NOLL
Vehicle	True	OFF	NULL
Locking	Vehicle Locking	011	INOLL
Looking	False	Don't care	NULL**
	. 4.50	20.11.00.10	

## 6.2.3.3 Overhead Console (OHC) requirements

The OHC shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: "Courtesy Lamps"

#### 6.2.3.3.1 Over-arching requirements

R: 6.1.3.2-140	The OHC shall contain its Performance Latency within the End-to-End latency specified in		
	section 3.2.2.1 "Performance Latency Requirements"		
	The OHC shall take into account the requirements contained within section 3.2.3 "Safety		
R: 6.1.3.2-141	Requirements" to ensure that no lighting element that it directly controls (via control		
1. 0.1.3.2-141	signal) ends up violating any requirement (specific to the market the target vehicle shall be		
	sold in) within the aforementioned section.		
R: 6.1.3.2-142	The OHC shall take into account the requirements contained within section 3.2.4 "Securi		
	Requirements" to ensure that no lighting element that it directly controls (via control		
	signal) ends up violating any requirement within the aforementioned section.		
R: 6.1.3.2-143	143 The OHC shall be a publisher to signals it has been identified as a publisher for within		
	section 6.2.2.3 "Signal requirements"		

## 6.2.3.3.2 <u>Provide Control Signal to support Courtesy Lamps Illumination</u>

R: 6.1.3.2-144	The OHC shall subscribe to the (LIN) signals required by the subscribing function " Interior	
	Courtesy Lamps Illumination Algorithm " as identified in section 6.2.2.3 "Signal	
	Requirements": WelcomeFarewell_State and WelcomeFarewell_SubState	
R: 6.1.3.2-145	The OHC shall use the signals it has been identified as a subscriber to in section 6.2.2.3	
	"Signal Requirements" to transmit a control signal to Interior Courtesy Lamps directly connected to it that meet the requirements under section 5.4.1 "Courtesy Lamps Illumination Algorithm"	

R: 6.1.3.2-146	The OHC shall transmit a control signal to Interior Courtesy Lamps directly connected to it
	that will support the desired Welcome/Farewell state specific behavior called out in "RQT-
	002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-147	The OHC shall transmit a control signal to Interior Courtesy Lamps directly connected to it
	that will satisfy the control signal specific requirements listed under Appendix 2 "Interior
	Lighting PWM Signal Specification"

Note: Table below provided as reference for OHC subscribed signals to ARL callouts mapping:

ARL call-out		Subscriber Signal Mapping	
Logical Data Flow	Logical Data Flow Domain Name	WelcomeFarewell _State	WelcomeFarewell _Substate
Approach	Approach Detected	WELCOME	APPROACH
Detection	Approach Not Detected	Don't care	NULL**
Illuminated	Illuminated Entry True	WELCOME	ENTRY
Entry	Illuminated Entry False	Don't care	NULL**
Courtesy	Courtesy Lighting True	Don't care	DOOR
Lighting	Courtesy Lighting False	Don't care	NULL**
Courtesy	Courtesy Lighting Delay True	Don't care	DELAY
Lighting Delay	Courtesy Lighting Delay False	Don't care	NULL**
Illuminated	Illuminated Exit True	FAREWELL	EXIT
Exit	Illuminated Exit False	Don't care	NULL**
	Vehicle Ignition is OFF	NOT (RUN_START)	Don't Care
Ignition State	Vehicle Ignition is in Accessory	NOT (RUN_START)	Don't Care
	Vehicle Ignition is in Run/Start	RUN_START	NULL**
Vehicle	Vehicle Locking True	NULL	NULL
Locking	Vehicle Locking False	Don't care	NULL**

#### 6.2.3.4 <u>Ambient Light Module (ALM) requirements</u>

The ALM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to a specific lighting element it is directly connected to: "Ambient Lighting

#### 6.2.3.4.1 Over-arching requirements

R: 6.1.3.2-148	The ALM shall contain its Performance Latency within the End-to-End latency specified in	
	section 3.2.2.1 "Performance Latency Requirements"	
	The ALM shall take into account the requirements contained within section 3.2.3 "Safety	
R: 6.1.3.2-149	Requirements" to ensure that no lighting element that it directly controls (via control	
K. 0.1.3.2-149	signal) ends up violating any requirement (specific to the market the target vehicle shall be	
	sold in) within the aforementioned section.	
R: 6.1.3.2-150	The ALM shall take into account the requirements contained within section 3.2.4 "Security	
	Requirements" to ensure that no lighting element that it directly controls (via control	
	signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.2-151	The ALM shall be a publisher to signals it has been identified as a publisher for within	
	section 6.2.2.3 "Signal requirements"	

#### 6.2.3.4.2 Provide Control Signal to support Ambient Lighting Illumination

R: 6.1.3.2-152	The ALM shall subscribe to the (LIN) signals required by the subscribing function "Interior Ambient Light Illumination (without Static Sequential) Algorithm " as identified in section 6.2.2.3 "Signal Requirements": WelcomeFarewell_State, WelcomeFarewell_SubState, Customer_Color, and Customer_Intensity
R: 6.1.3.2-153	The ALM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Interior Ambient Lighting Illumination directly connected to it that meet the requirements under section 5.4.5 "Interior Ambient Lighting (without Static Sequential) Illumination Algorithm"
R: 6.1.3.2-154	The ALM shall transmit a control signal to Interior Ambient Lights directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-155	The ALM shall transmit a control signal to Interior Ambient Lights directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"

Note: Table below provided as reference for ALM subscribed signals to ARL callouts mapping:

ARL call-out		Subscriber S	Signal Mapping
Logical Logical Data Flow		WelcomeFarewell	WelcomeFarewell
Data Flow	<b>Domain Name</b>	_State	_Substate
Approach	Approach Detected	WELCOME	APPROACH
Approach Detection	Approach Not		
Detection	Detected	Don't care	NULL**
	Illuminated Entry		
Illuminated	True	WELCOME	ENTRY
Entry	Illuminated Entry		
	False	Don't care	NULL**
	Courtesy Lighting		
Courtesy	True	Don't care	DOOR
Lighting	Courtesy Lighting		
	False	Don't care	NULL**
Courtesy	Courtesy Lighting		
Lighting	Delay True	Don't care	DELAY
Delay	Courtesy Lighting		
	Delay False	Don't care	NULL**
	Illuminated Exit		EVIT
Illuminated	True	FAREWELL	EXIT
Exit	Illuminated Exit	Davitana	NII II I ++
	False	Don't care	NULL**
	Vehicle Ignition is	NOT (DUN CTART)	Dan't Care
Laure iti a va	OFF	NOT (RUN_START)	Don't Care
Ignition State	Vehicle Ignition is	NOT (BUN START)	Don't Care
State	in Accessory	NOT (RUN_START)	Don't Care
	Vehicle Ignition is in Run/Start	RUN START	NULL**
	Vehicle Locking	LON_STAKT	INULL
Vehicle	True	NULL	NULL
Locking	Vehicle Locking	NULL	INOLL
Locking	False	Don't care	NULL**
	เ ผเงษ	Dont Gale	NOLL

#### 6.2.3.5 <u>Driver Door Module (DDM) requirements</u>

The DDM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to: "Door trim switch/button backlighting Illumination", "Autofold mirrors"

#### 6.2.3.5.1 Over-arching requirements

R: 6.1.3.2-156	The DDM shall contain its Performance Latency within the End-to-End latency specified in	
	section 3.2.2.1 "Performance Latency Requirements"	
	The DDM shall take into account the requirements contained within section 3.2.3 "Safety	
R: 6.1.3.2-157	Requirements" to ensure that no lighting element that it directly controls (via control	
K. 0.1.3.2-131	signal) ends up violating any requirement (specific to the market the target vehicle shall be	
	sold in) within the aforementioned section.	
R: 6.1.3.2-158	The DDM shall take into account the requirements contained within section 3.2.4 "Security	
	Requirements" to ensure that no lighting element that it directly controls (via control	
	signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.2-159	The DDM shall be a publisher to signals it has been identified as a publisher for within	
	section 6.2.2.3 "Signal requirements"	

#### 6.2.3.5.2 Provide Control Signal to support Exterior Supplementary Illumination

R: 6.1.3.2-160	The DDM shall subscribe to the (CAN) signals required by the subscribing function " Exterior Supplementary Illumination Algorithm " as identified in section 6.2.2.3 "Signal Requirements": Pudlamp_D_Rq,
R: 6.1.3.2-161	The DDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Exterior Supplementary Lighting directly connected to it that meet the requirements under section 5.3.5 "Exterior Supplementary Illumination Algorithm"
R: 6.1.3.2-162	The DDM shall transmit a control signal to Exterior Supplementary Lights directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-163	The DDM shall transmit a control signal to Exterior Supplementary Lights directly connected to it that will satisfy the control signal specific requirements listed under Appendix 1 "Exterior Lighting PWM Signal Specification"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.3.5 "Exterior Supplementary
Mapping	Illumination Algorithm"
Pudlamp_D_Rq	Control Signal Response
RAMP_UP	"Fade ON"/Ramp up
RAMP_DOWN	"Fade OFF"/Ramp down
ON	"Snap ON"/Step up
OFF	"Snap OFF"/"Step down

#### 6.2.3.5.3 Provide Control Signal to support Interior Day-time Dimmable Backlighting/Display Illumination

R: 6.1.3.2-164	The DDM shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-165	The DDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-166	The DDM shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-167	The DDM shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"

R: 5.4.7.1.6-28	The DDM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	/Display elements directly connected to it that will support the desired Smooth Dimming
	behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-
	AA-VXX"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"
Mapping	Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.2.3.5.4 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-168	The DDM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Backlit_LED_Status and Litval. Note: Backlit_LED_Status ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Backlit_LED_Status = OFF
R: 6.1.3.2-169	The DDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.3 "Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-170	The DDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-171	The DDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-29	The DDM shall transmit a control signal to Night-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"  Backlighting Illumination Algorithm
Backlit_LED_status	Control Signal Response
Night_1 – Night_12	"Fade ON"/Ramp up
OFF	"Fade OFF"/Ramp down

#### 6.2.3.5.5 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-172	\
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local
	sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination
	will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl
	= OFF
R: 6.1.3.2-173	The DDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-
	Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-174	The DDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific

	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles
R: 6.1.3.2-175	The DDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-30	The DDM shall transmit a control signal to 2-Step Dimmable Backlighting elements
	directly connected to it that will support the desired Smooth Dimming behavior as detailed
	in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for DDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

#### 6.2.3.6 Passenger Door Module (PDM) requirements

The PDM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to: "Door trim switch/button backlighting Illumination", "Autofold mirrors"

#### 6.2.3.6.1 Over-arching requirements

R: 6.1.3.2-176	The PDM shall contain its Performance Latency within the End-to-End latency specified in
1. 0.1.3.2-170	
	section 3.2.2.1 "Performance Latency Requirements"
	The PDM shall take into account the requirements contained within section 3.2.3 "Safety
R: 6.1.3.2-177	Requirements" to ensure that no lighting element that it directly controls (via control
14. 0.1.3.2-177	signal) ends up violating any requirement (specific to the market the target vehicle shall be
	sold in) within the aforementioned section.
R: 6.1.3.2-178	The PDM shall take into account the requirements contained within section 3.2.4 "Security
	Requirements" to ensure that no lighting element that it directly controls (via control
	signal) ends up violating any requirement within the aforementioned section.
R: 6.1.3.2-179	The PDM shall be a publisher to signals it has been identified as a publisher for within
	section 6.2.2.3 "Signal requirements"

#### 6.2.3.6.2 Provide Control Signal to support Exterior Supplementary Illumination

R: 6.1.3.2-180	
	Exterior Supplementary Illumination Algorithm " as identified in section 6.2.2.3 "Signal
	Requirements": Pudlamp_D_Rq.
R: 6.1.3.2-181	The PDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Exterior Supplementary Lighting
	directly connected to it that meet the requirements under section 5.3.5 "Exterior
	Supplementary Illumination Algorithm"
R: 6.1.3.2-182	
	connected to it that will support the desired Welcome/Farewell state specific behavior
	called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL
	BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-183	
	connected to it that will satisfy the control signal specific requirements listed under
	Appendix 1 "Exterior Lighting PWM Signal Specification"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.3.5 "Exterior Supplementary
Mapping	Illumination Algorithm"
Pudlamp_D_Rq	Control Signal Response
RAMP_UP	"Fade ON"/Ramp up

RAMP_DOWN	"Fade OFF"/Ramp down
ON	"Snap ON"/Step up
OFF	"Snap OFF"/"Step down

#### 6.2.3.6.3 Provide Control Signal to support Interior Day-time Dimmable Backlighting/Display Illumination

R: 6.1.3.2-184	The PDM shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-185	The PDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-186	The PDM shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-187	The PDM shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-31	The PDM shall transmit a control signal to Interior Day-time Dimmable Backlighting /Display elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.2.3.6.4 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-188	The PDM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.2.2.3 "Signal Requirements": Backlit_LED_Status and Litval. Note: Backlit_LED_Status
	≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep
	but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed
	then Backlit_LED_Status = OFF
R: 6.1.3.2-189	The PDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.3
	"Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-190	The PDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles
R: 6.1.3.2-191	The PDM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-32	The PDM shall transmit a control signal to Night-time Dimmable Backlighting elements
	directly connected to it that will support the desired Smooth Dimming behavior as detailed
	in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"
Mapping	Backlighting Illumination Algorithm
Backlit_LED_status	Control Signal Response
Night_1 – Night_12	"Fade ON"/Ramp up
OFF	"Fade OFF"/Ramp down

#### 6.2.3.6.5 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-192	The PDM shall subscribe to the (CAN) signals required by the subscribing function "Interior 2-Step Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-193	The PDM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-
	Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-194	The PDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-022094 LINCOLN EMBRACE WELCOME AND FAREWELL BEHAVIOR REV. 1" for Lincoln vehicles
R: 6.1.3.2-195	The PDM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-33	
	directly connected to it that will support the2-Step desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for PDM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

#### 6.2.3.7 <u>Steering Column Control Module (SCCM) requirements</u>

The SCCM shall be a subscriber to the BCM (Welcome Farewell State determination function) and then use it to transmit a control signal to specific lighting elements or part assemblies it is directly connected to.

#### 6.2.3.7.1 Over-arching requirements

R: 6.1.3.2-196	The SCCM shall contain its Performance Latency within the End-to-End latency specified	
	in section 3.2.2.1 "Performance Latency Requirements"	
	The SCCM shall take into account the requirements contained within section 3.2.3 "Safety	
R: 6.1.3.2-197	Requirements" to ensure that no lighting element that it directly controls (via control	
K. 0.1.3.2-191	signal) ends up violating any requirement (specific to the market the target vehicle shall be	
	sold in) within the aforementioned section.	
R: 6.1.3.2-198	The SCCM shall take into account the requirements contained within section 3.2.4	
	"Security Requirements" to ensure that no lighting element that it directly controls (via	
	control signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.2-199	The SCCM shall be a publisher to signals it has been identified as a publisher for within	
	section 6.1.2.3 "Signal requirements"	

#### 6.2.3.7.2 <u>Provide Control Signal to support Interior Day-time Dimmable Backlighting Illumination</u>

R: 6.1.3.2-200	The SCCM shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-201	The SCCM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-202	The SCCM shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-203	The SCCM shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-34	The SCCM shall transmit a control signal to Day-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for SCCM subscribed signals to Expected Initial Control Signal Response:

Table below provided as i	able below provided as reference for booth subscribed signals to Expedice littlial both or signal response.		
Subscriber Signal	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"		
Mapping	Backlighting Illumination Algorithm		
Dimming_lvl	Control Signal Response		
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"		
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"		
OFF	"Fade OFF"/Ramp down		

#### 6.2.3.7.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-204	The SCCM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Backlit_LED_Status and Litval. Note: Backlit_LED_Status
	≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep
	but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Backlit_LED_Status = OFF
R: 6.1.3.2-205	The SCCM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.3 "Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-206	The SCCM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles
R: 6.1.3.2-207	The SCCM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
D. E 4 7 4 C 05	
R: 5.4.7.1.6-35	
	directly connected to it that will support the desired Smooth Dimming behavior as detailed
	in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for SCCM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"
Mapping	Backlighting Illumination Algorithm
Backlit_LED_status	Control Signal Response
Night_1 – Night_12	"Fade ON"/Ramp up
OFF	"Fade OFF"/Ramp down

#### 6.2.3.8 Front Control Interface Module (FCIM, FCIMB, HVAC) requirements

The FCIM shall be a subscriber to the BCM (Welcome Farewell State determination function) and APIM (Radio Power Button toggle) then use it to transmit a control signal to specific lighting elements it is directly connected to: "Sync/Radio Control button backlighting illumination"

#### 6.2.3.8.1 Provide Control Signal to support Interior Day-Time Dimmable Backlighting Illumination

R: 6.1.3.2-208	The FCIM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.2.2.3 "Signal Requirements": Dimming_lvl, Litval and HMI_HMIMode_St. Note:
	Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
	sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-209	The FCIM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-
	time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-210	The FCIM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles
R: 6.1.3.2-211	The FCIM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-36	
	directly connected to it that will support the desired Smooth Dimming behavior as detailed
	in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Expected initial response as per section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
Dimming_lvl	HMI_HMIMode_St	Control Signal Response
Day_1 to Day_6 or	Don't Care	
Night_1 – Night_12		"Fade ON"/Ramp up
OFF	≠ OFFmode	"Fade ON"/Ramp up**
OFF	OFFmode	"Fade OFF"/Ramp down

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

Table below provided as reference for FCIM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6 or	Don't Care	
Night_1 – Night_12		Day_1 to Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12**
OFF	OFFmode	OFF

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

#### 6.2.3.8.2 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-212	The FCIM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.2.2.3 "Signal Requirements": Backlit_LED_Status, Litval, and HMI_HMIMode_St. Note:
	Backlit LED Status ≠ OFF is a local sleep inhibitor. Modules on the network will allow the
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
	sleep is allowed then Backlit_LED_Status = OFF
R: 6.1.3.2-213	The FCIM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting

	Illumination directly connected to it that meet the requirements under section 5.4.7.3	
	"Night-time Dimmable" Backlighting Illumination Algorithm	
R: 6.1.3.2-214	The FCIM shall transmit a control signal to Night-time Dimmable Backlighting Illumination	
	directly connected to it that will support the desired Welcome/Farewell state specific	
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY	
	REV. 1" for Ford vehicles	
R: 6.1.3.2-215	The FCIM shall transmit a control signal to Night-time Dimmable Backlighting Illumination	
	directly connected to it that will satisfy the control signal specific requirements listed under	
	Appendix 2 "Interior Lighting PWM Signal Specification"	
R: 5.4.7.1.6-37		
	directly connected to it that will support the desired Smooth Dimming behavior as detailed	
	in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"	

Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Expected initial response as per section 5.4.7.3 "Night-time Dimmable" Backlighting Illumination Algorithm
Backlit_LED_status	HMI_HMIMode_St	Control Signal Response
Night_1 – Night_12	Don't Care	"Fade ON"/Ramp up
OFF	≠ OFFmode	"Fade ON"/Ramp up
OFF	OFFmode	"Fade OFF"/Ramp down

Table below provided as reference for FCIM subscribed signals to Expected Illumination Level

Backlit_LED_status	HMI_HMIMode_St	Desired Illumination Level
Night_1 – Night_12	Don't Care	Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12
OFF	OFFmode	OFF

#### 6.2.3.8.3 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-216	The FCIM shall subscribe to the (CAN) signals required by the subscribing function "Interior 2-Step Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_IvI and Litval. Note: Dimming_IvI ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_IvI = OFF
R: 6.1.3.2-217	The FCIM shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-Step Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-218	The FCIM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-219	The FCIM shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-38	The FCIM shall transmit a control signal to 2-Step Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"  Backlighting Illumination Algorithm	
Dimming_lvl	Control Signal Response	
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"	
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"	
OFF	"Fade OFF"/Ramp down	

#### 6.2.3.9 Accessory Protocol Interface Module (APIM/SYNC) requirements

The APIM/SYNC shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

#### 6.2.3.9.1 Over-arching requirements

R: 6.1.3.10-9	The APIM/SYNC shall contain its Performance Latency within the End-to-End latency	
	specified in section 3.2.2.1 "Performance Latency Requirements"	
	The APIM/SYNC shall take into account the requirements contained within section 3.2.3	
R: 6.1.3.10-10	"Safety Requirements" to ensure that no screen/display that it directly controls ends up	
K. 0.1.3.10-10	violating any requirement (specific to the market the target vehicle shall be sold in) within	
	the aforementioned section.	
R: 6.1.3.10-11	The APIM/SYNC shall take into account the requirements contained within section 3.2.4	
	"Security Requirements" to ensure that no screen/display that it directly controls (via	
	control signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.10-12	The APIM shall be a publisher to signals it has been identified as a publisher for within	
	section 6.2.2.3 "Signal requirements"	

#### 6.2.3.9.2 <u>Support Interior Day-Time Dimmable Backlighting Illumination for Display Brightness</u>

R: 6.1.3.2-220	The APIM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.2.2.3 "Signal Requirements": Dimming_lvl, Litval and HMI_HMIMode_St. Note:
	Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
	sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-221	The APIM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-
	time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-222	The APIM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles
R: 5.4.7.1.6-39	The APIM shall transmit a control signal to Day-time Dimmable Backlighting elements
	directly connected to it that will support the desired Smooth Dimming behavior as detailed
	in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for FCIM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		Expected initial response as per section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
Dimming_IvI	HMI_HMIMode_St	Display Illumination Response
Day_1 to Day_6 or		
Night_1 – Night_12	Don't Care	"Snap ON"/ Turn On
OFF	≠ OFFmode	"Snap ON"/ Turn On
OFF	OFFmode	"Snap OFF"/ Turn Off

Table below provided as reference for FCIM subscribed signals to Expected Illumination Level

Dimming_IvI	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6 or		
Night_1 – Night_12	Don't Care	Day_1 to Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12
OFF	OFFmode	OFF

6.2.3.9.3 <u>Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence</u>

R: 6.1.3.1.3-18	The APIM shall meet the requirements listed under section 5.5.1 "Center-stack
	Welcome/Farewell Displays (Sync Screen)" (including the associated "State
	Determination Algorithm)
R: 6.1.3.1.3-19	The APIM will support the desired Welcome/Farewell state specific behavior specific to
	"Welcome" and "Farewell" graphics called out in "RQT-002004-021878 DNA
	WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-4	The APIM shall use the signals it has been identified as a subscriber to in section
	6.2.2.3 "Signal Requirements" to follow the state transitions as they're listed section
	5.2.2 "Welcome/Farewell State determination without Battery saver tie-in" with the
	addition of "Extended Play" as described in section 3.1.2 under "Additional States":
	Ignition_Status, DrStatDrv_B_Actl, DrStatPsngr_B_Actl, HMI_hmimode_st.

Welcome Farewell state	Required Signals	Behavior
	Ignition_Status	(Ignition_Status = OFF/ACCY)
Welcome Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl OR
True	DrStatPsngr_B_Actl	DrStatPsngr_B_Actl = Ajar)
	Ignition_Status	(Ignition_Status = OFF/ACCY)
Welcome Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl &
Delay True	DrStatPsngr_B_Actl	DrStatPsngr_B_Actl = Closed)
Ignition RUN/Start	Ignition_Status	Ignition_Status = RUN/Start
		Ignition_Status = RUN/Start
Illuminated Exit True	Ignition_Status	transition to OFF
		Ignition_Status = RUN/Start
	Ignition_Status	transition to OFF &
Extended Play	HMI_hmimode_st	(HMI_hmimode_st ≠ OFFmode)
	Ignition_Status	(Ignition_Status transition to OFF)
Farewell Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl OR
True	DrStatPsngr_B_Actl	DrStatPsngr_B_Actl = Ajar)
	Ignition_Status	(Ignition_Status transition to OFF)
Farewell Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl &
Delay True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Closed)

#### Note:

#### 6.2.3.10 Rear Audio Control Module (RACM) requirements

The RACM shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

#### 6.2.3.10.1 Over-arching requirements

R: 6.1.3.10-13	The RACM shall contain its Performance Latency within the End-to-End latency specified	
	in section 3.2.2.1 "Performance Latency Requirements"	
R: 6.1.3.10-14	The RACM shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no screen/display that it directly controls ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.	
R: 6.1.3.10-15	The RACM shall take into account the requirements contained within section 3.2.4	
	"Security Requirements" to ensure that no screen/display that it directly controls (via	
	control signal) ends up violating any requirement within the aforementioned section.	
R: 6.1.3.10-16		
	section 6.2.2.3 "Signal requirements"	

# 6.2.3.10.2 <u>Provide Control Signal to support Interior Day-Time Dimmable Illumination (Display Brightness and Switch Backlighting)</u>

<sup>1.</sup> Please refer to section 5.2.2 "Welcome/Farewell State Determination without Battery saver tie-in" for additional transition criteria, timeouts etc. "Approach Detection", "Illuminated Entry", and "Vehicle Locking" state should be treated the same as "Null". Dimming\_lvl = OFF should be used for "Courtesy Light Timer = Expired"

R: 6.1.3.2-223	The RACM shall subscribe to the (CAN) signals required by the subscribing function
	"Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section
	6.2.2.3 "Signal Requirements": Dimming_lvl, Litval and HMI_HMIMode_St. Note:
	Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the
	network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local
	sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-224	The RACM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-
	time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-225	The RACM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles
R: 6.1.3.2-226	The RACM shall transmit a control signal to Day-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-40	The RACM shall transmit a control signal to Interior Day-time Dimmable Backlighting
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for RACM subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping		"Day-time Dimmabl	Expected initial response as per section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm	
	HMI_HMIMode_St	Display Illumination	Backlighting Control Signal	
Dimming_IvI		Response	Response	
Day_1 to Day_6 or Night_1 –	Don't Care			
Night_12		"Snap ON"/ Turn On	"Fade ON"/Ramp up	
OFF	≠ OFFmode	"Snap ON"/ Turn On	"Fade ON"/Ramp up**	
OFF	OFFmode	"Snap OFF"/ Turn Off	"Fade OFF"/Ramp down	

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): "Fade OFF"/Ramp down

Table below provided as reference for RACM subscribed signals to Expected Illumination Level

Dimming_lvl	HMI_HMIMode_St	Desired Illumination Level
Day_1 to Day_6	Don't Care	
or Night_1 –		
Night_12		Day_1 - Day_6 or Night_1 – Night_12
Transition to OFF	≠ OFFmode	Night_12**
OFF	OFFmode	OFF

<sup>\*\*</sup>Note: Only for Radio Controls, remaining controls (i.e. HVAC): OFF

#### 6.2.3.10.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-227	The RACM shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Backlit_LED_Status, Litval and HMI_HMIMode_St. Note: Backlit_LED_Status ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Backlit_LED_Status = OFF
R: 6.1.3.2-228	The RACM shall use the signals it has been identified as a subscriber to in section 6.2.2.3
	"Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting
	Illumination directly connected to it that meet the requirements under section 5.4.7.3
	"Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-229	The RACM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will support the desired Welcome/Farewell state specific
	behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY
	REV. 1" for Ford vehicles

R: 6.1.3.2-230	The RACM shall transmit a control signal to Night-time Dimmable Backlighting Illumination
	directly connected to it that will satisfy the control signal specific requirements listed under
	Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-41	The RACM shall transmit a control signal to Interior Night-time Dimmable Backlighting
	elements directly connected to it that will support the desired Smooth Dimming behavior
	as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

#### 6.2.3.10.4 <u>Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence</u>

R: 6.1.3.1.3-5	The RACM shall meet the requirements listed under section 5.5.1 "Center-stack
	Welcome/Farewell Displays (Sync Screen)" (including the associated "State
	Determination Algorithm)
R: 6.1.3.1.3-20	The RACM will support the desired Welcome/Farewell state specific behavior specific
	to "Welcome" and "Farewell" graphics called out in "RQT-002004-021878 DNA
	WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-6	The RACM shall use the signals it has been identified as a subscriber to in section
	6.2.2.3 "Signal Requirements" to follow the state transitions as they're listed section
	5.2.2 "Welcome/Farewell State determination without Battery saver tie-in" with the
	addition of "Extended Play" as described in section 3.1.2 under "Additional States":
	Ignition_Status, DrStatDrv_B_Actl, DrStatPsngr_B_Actl, HMI_hmimode_st and
	Dimming_lvl

Welcome Farewell state	Required Signals	Behavior
Ignition RUN/Start	Ignition_Status	Ignition_Status = RUN/Start
Illuminated Exit True	Ignition_Status Dimming_lvl	Ignition_Status = RUN/Start transition to OFF & Dimming_lvl ≠ OFF
marimated Exit Frag		Ignition_Status = RUN/Start
Extended Play	Ignition_Status HMI_hmimode_st	transition to OFF & (HMI_hmimode_st ≠ OFFmode)
	Ignition_Status DrStatDrv_B_ActI,	(Ignition_Status transition to OFF) & Dimming_lvl ≠ OFF
Farewell Courtesy Lighting	DrStatPsngr_B_Actl	&( DrStatDrv_B_Actl OR
True	Dimming_lvl	DrStatPsngr_B_Actl = Ajar)
	Ignition_Status DrStatDrv_B_Actl,	(Ignition_Status transition to OFF) & Dimming_lvl ≠ OFF
Farewell Courtesy Lighting	DrStatPsngr_B_Actl	&( DrStatDrv_B_Actl &
Delay True	Dimming_lvl	DrStatPsngr_B_Actl = Closed)

Note: Please refer to section 5.2.2 "Welcome/Farewell State Determination without Battery saver tie-in" for additional transition criteria, timeouts etc. "Approach Detection", "Illuminated Entry", "Welcome Courtesy Lighting", "Welcome Courtesy Lighting Delay" and "Vehicle Locking" state should be treated the same as "Null". Dimming\_IvI = OFF should be used for "Courtesy Light Timer = Expired"

#### 6.2.3.11 <u>Instrument Panel Cluster (IPC) requirements</u>

The IPC shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

#### 6.2.3.11.1 Over-arching requirements

R: 6.1.3.11-4	The IPC shall contain its Performance Latency within the End-to-End latency specified in section 3.2.2.1 "Performance Latency Requirements"
R: 6.1.3.11-5	The IPC shall take into account the requirements contained within section 3.2.3 "Safety Requirements" to ensure that no screen/display that it directly controls ends up violating any requirement (specific to the market the target vehicle shall be sold in) within the aforementioned section.
R: 6.1.3.11-6	The IPC shall take into account the requirements contained within section 3.2.4 "Security Requirements" to ensure that no screen/display that it directly controls (via control signal) ends up violating any requirement within the aforementioned section.

#### 6.2.3.11.2 Provide Control Signal to support Interior Day-time Dimmable Backlighting/Display Illumination

R: 6.1.3.2-231	The IPC shall subscribe to the (CAN) signals required by the subscribing function "Interior Day-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF
R: 6.1.3.2-232	The IPC shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that meet the requirements under section 5.4.7.1 "Day-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-233	The IPC shall transmit a control signal to Day-time Dimmable Backlighting/Display Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-234	The IPC shall transmit a control signal to Day-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-42	The IPC shall transmit a control signal to Day-time Dimmable Backlighting/Display elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for IPC subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.1 "Day-time Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Day_1 – Day_6"
Night_1 – Night_12	"Fade ON"/Ramp up to "Night_1 – Night_12"
OFF	"Fade OFF"/Ramp down

#### 6.2.3.11.3 Provide Control Signal to support Interior Night-Time Dimmable Backlighting Illumination

R: 6.1.3.2-235	The IPC shall subscribe to the (CAN) signals required by the subscribing function "Interior Night-time Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Backlit_LED_Status and Litval. Note: Backlit_LED_Status ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Backlit LED Status = OFF
R: 6.1.3.2-236	The IPC shall use the signals it has been identified as a subscriber to in section 6.2.2.3 "Signal Requirements" to transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that meet the requirements under section 5.4.7.3 "Night-time Dimmable" Backlighting Illumination Algorithm
R: 6.1.3.2-237	The IPC shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.2-238	The IPC shall transmit a control signal to Night-time Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"
R: 5.4.7.1.6-43	The IPC shall transmit a control signal to Night-time Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"

Table below provided as reference for IPC subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal	Expected initial response as per section 5.4.7.3 "Night-time Dimmable"
Mapping	Backlighting Illumination Algorithm

Backlit_LED_status	Control Signal Response
Night_1 – Night_12	"Fade ON"/Ramp up
OFF	"Fade OFF"/Ramp down

#### 6.2.3.11.4 Provide Control Signal to support Interior 2-Step Dimmable Backlighting Illumination

R: 6.1.3.2-239	The IPC shall subscribe to the (CAN) signals required by the subscribing function "Interior 2-Step Dimmable Backlighting Illumination Algorithm" as identified in section 6.2.2.3 "Signal Requirements": Dimming_lvl and Litval. Note: Dimming_lvl ≠ OFF is a local sleep inhibitor. Modules on the network will allow the network(s) to sleep but illumination will remain ON indefinitely, no timeouts allowed. Local sleep is allowed then Dimming_lvl = OFF			
R: 6.1.3.2-240	The IPC shall use the signals it has been identified as a subscriber to in section 6.2.2.3  "Signal Requirements" to transmit a control signal to 2-Step Dimmable Backlighting  Illumination directly connected to it that meet the requirements under section 5.4.7.5 "2-Step Dimmable" Backlighting Illumination Algorithm			
R: 6.1.3.2-241	The IPC shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will support the desired Welcome/Farewell state specific behavior called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles			
R: 6.1.3.2-242	The IPC shall transmit a control signal to 2-Step Dimmable Backlighting Illumination directly connected to it that will satisfy the control signal specific requirements listed under Appendix 2 "Interior Lighting PWM Signal Specification"			
R: 5.4.7.1.6-44	The IPC shall transmit a control signal to 2-Step Dimmable Backlighting elements directly connected to it that will support the desired Smooth Dimming behavior as detailed in the latest version of the following specification: "ES-H1BT-1A278-AA-VXX"			

Table below provided as reference for IPC subscribed signals to Expected Initial Control Signal Response:

Subscriber Signal Mapping	Expected initial response as per section 5.4.7.5 "2-Step Dimmable"  Backlighting Illumination Algorithm
Dimming_lvl	Control Signal Response
Day_1 - Day_6	"Fade ON"/Ramp up to "Non-selectable Daytime level"
Night_1 – Night_12	"Fade ON"/Ramp up to "Non-selectable Nighttime level"
OFF	"Fade OFF"/Ramp down

# 6.2.3.11.5 <u>Support Odometer, Welcome/Farewell Animations and Displays, and Pointer illumination during</u> Welcome Farewell sequence

The requirements under this section are only applicable to vehicles with push button ignitions. For any bladed key or alternative implementations please refer to "Welcome-Goodbye Strategy - CGEA1.3\_v6.0" document.

	The IPC shall meet the welcome farewell state transition requirements listed under section 5.5.2 "Cluster Display, Pointers, and Odometer during Welcome/Farewell" – already taken inputs associated with each applicable state and their timeouts into account.			
R: 6.1.3.1.3-21	The IPC will support the desired Welcome/Farewell state specific behavior (Illumination Level) for "Welcome/Farewell Displays", "Pointers", and "Odometer"			
	called out in "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV.			
	X" for Ford vehicles			
R: 6.1.3.1.3-7	The IPC shall subscribe to the (CAN) signals required by the subscribing function "			
	Vehicle Display Cluster Welcome/Farewell" as identified in section 6.2.2.3 "Signal			
	Requirements" (included within state transition diagrams within section 5.2.2)			

#### 6.2.3.12 Austere Heads-Up Display (aHUD) requirements

The aHUD shall be a subscriber to the BCM (Welcome Farewell State determination function) then use it to determine which screen/graphics to display.

#### 6.2.3.12.1 Over-arching requirements

R: 6.1.3.12-5	The AHUD shall contain its Performance Latency within the End-to-End latency specified			
	in section 3.2.2.1 "Performance Latency Requirements"			
	The AHUD shall take into account the requirements contained within section 3.2.3 "Safety			
D. 6 1 2 12 6	Requirements" to ensure that no screen/display that it directly controls ends up violating			
R: 6.1.3.12-6 any requirement (specific to the market the target vehicle shall be sold in) with				
	aforementioned section.			
R: 6.1.3.12-7	The AHUD shall take into account the requirements contained within section 3.2.4			
	"Security Requirements" to ensure that no screen/display that it directly controls (via			
	control signal) ends up violating any requirement within the aforementioned section.			
R: 6.1.3.12-8	The aHUD shall be a publisher to signals it has been identified as a publisher for within			
	section 6.1.2.3 "Signal requirements"			

#### 6.2.3.12.2 <u>Support Welcome/Farewell Animations and Displays during Welcome Farewell sequence</u>

R: 6.1.3.1.3-8	The aHUD shall meet the requirements listed under section 5.5.3 HUD
	Welcome/Farewell Displays (aHUD)" (including the associated "State Determination
	Algorithm)
R: 6.1.3.1.3-22	The aHUD will support the desired Welcome/Farewell state specific behavior specific
	to "Welcome" and "Farewell" graphics called out in "RQT-002004-021878 DNA
	WELCOME-FAREWELL STRATEGY REV. 1" for Ford vehicles
R: 6.1.3.1.3-2	The aHUD shall use the signals it has been identified as a subscriber to in section
	6.2.2.3 "Signal Requirements" to follow the state transitions as they're listed section
	5.2.2 "Welcome/Farewell State determination without Battery saver tie-in":
	Ignition_Status, DrStatDrv_B_Actl, DrStatPsngr_B_Actl,, DrStatRI_B_ Actl,
	DrStatRr_B_ Actl, and PudLamp_D_Rq

Welcome Farewell state	Required Signals	Behavior		
	Ignition Status	(Ignition_Status = OFF/ACCY)		
Welcome Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl OR		
True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Ajar)		
	Ignition_Status	(Ignition_Status = OFF/ACCY)		
Welcome Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl &		
Delay True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Closed)		
Ignition RUN/Start	Ignition_Status	Ignition_Status = RUN/Start		
		Ignition_Status = RUN/Start		
Illuminated Exit True	Ignition_Status	transition to OFF		
	Ignition_Status	(Ignition_Status transition to OFF)		
Farewell Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl OR		
True	DrStatPsngr_B_Actl	DrStatPsngr_B_Actl = Ajar)		
	Ignition_Status	(Ignition_Status transition to OFF)		
Farewell Courtesy Lighting	DrStatDrv_B_Actl,	&( DrStatDrv_B_Actl &		
Delay True	DrStatPsngr_B_ActI	DrStatPsngr_B_Actl = Closed)		

Note: Please refer to section 5.2.2 "Welcome/Farewell State Determination without Battery saver tie-in" for additional transition criteria, timeouts etc. "Approach Detection", "Illuminated Entry", and "Vehicle Locking" state should be treated the same as "Null".

Due to aHUD initialization delays, aHUD will initialize at whichever occurs first: Pudlamp\_D\_Rq = Fade/ON or ON, Vehicle Door transitioning to ajar, or ignition transitioning to RUN/Start..

# 6.2.4 Ford Vehicle Lighting Element/Assembly Response Performance requirements

Requirement	Performance requirements (section reference)	Control Signal Source (for	Component
		Illumination)	

R: 6.2.4-1	Section 5.3.2 "Exterior Front	LDM	Headlamps (Low-beams)
	Illumination Lighting Response"	5014	Signature/Decorative LED Lamps
R: 6.2.4-2		BCM	Front Parklamps
R: 6.2.4-3	Section 5.3.4 "Exterior Rear	BCM	Rear Park Lamp
	Illumination Lighting Response"		License Plate Lamps
R: 6.2.4-4	Section 5.3.6 "Exterior	BCM	Illuminated Door Handle Pockets
	Supplementary Illumination		Puddle Area Side
	Lighting Response"		Pickup truck cargo light
R: 6.2.4-5	Section 5.4.2 "Courtesy Lamps	BCM	Courtesy Lamps
	Lighting Response"		Scuff Plates
R: 6.2.4-6	Section 5.4.4 "Ambient Lighting	ALM	Ambient Lighting
	Illumination (without Static		
	Sequential) Lighting Response"		
R: 6.2.4-7	Section 5.4.7.2 "Day-Time	IPC	Cluster Backlighting/Indicators
R: 6.2.4-8	Dimmable Backlighting	APIM	Center-stack display dimming
	Illumination Response"		
R: 6.2.4-9	Section 5.4.7.4 "Night-Time	DDM/PDM/BCM	Door trim switch/button backlighting
R: 6.2.4-10	Dimmable Backlighting	BCM	Headlamp switch
	Illumination Response"		IP & Overhead-Control Switch/Button
			Engine Start/Stop button graphic/halo
R: 6.2.4-11		IPC	Cluster Backlighting/Indicators
R: 6.2.4-12		FCIM	Sync/Radio Control button Backlighting
R: 6.2.4-13	Section 5.4.7.6 "2-step	DDM/PDM/BCM	Door trim switch/button backlighting
R: 6.2.4-14	Dimmable Backlighting	BCM	Headlamp switch
	Illumination Response"		IP & Overhead-Control Switch/Button
R: 6.2.4-15		FCIM	Sync/Radio Control button Backlighting
R: 6.2.4-16		IPC	Cluster Backlighting/Indicators
R: 6.2.4-17	Section 5.5.1 "Center-stack	APIM	Center-stack Welcome/Farewell Displays
	Welcome/Farewell Displays		
	(Sync Screen)"		
R: 6.2.4-18	Section 5.5.2 "Cluster	IPC	Cluster Welcome/Farewell Displays
	Welcome/Farewell Displays		Odometer
	(Sync Screen)"		
R: 6.2.4-19	Section 5.5.3 "HUD	aHUD	aHUD Welcome/Farewell Displays
	Welcome/Farewell Displays		
	(Sync Screen)"		

6.2.4.1 <u>"Other" Performance requirements</u>
This section is for lighting elements or vehicle part assemblies that have been identified on "RQT-002004-021878 DNA WELCOME-FAREWELL STRATEGY REV. 1" that respond to inputs that are outside the scope of "Welcome/Farewell" but have been included due to their impact on the feature as a whole (additionally these "features" have their own separate owners)

Requirement	Component	Control Signal Source (for Illumination)	Performance requirements owner
R: 6.2.4.1-1	Turn Signal Indicator	BCM	Body Security Group
R: 6.2.4.1-2	Pick-up truck bedlamp	BCM	Body Electronics Group Additional requirements contained within "Illuminated Belt Buckle Spec" owned by MMAJKOWS
R: 6.2.4.1-3	Night Lock Indication	BCM	Body Security Group
R: 6.2.4.1-4	Autofold Mirrors	DDM/PDM	Body Electronics Group
R: 6.2.4.1-5	SECURICODE Keypad	BCM	Body Security Group
R: 6.2.4.1-6	cHUD	cHUD	Driver Information HUD Group

	Additional requirements contained within "cHUD Welcome – Goodbye Strategy – CGEA1.3" spec owned by AMATHAI
--	--

## 7 DATA DICTIONARY

#### 7.1 Dictionary

Name: Backlit\_LED\_Status

Description: Status of Backlighting LED output. Used in-place of dimming\_lvl for night-time dimmable

backlighting elements

Type: Discrete
Category: CAN and LIN
Initial Value: NIGHT\_12
Storage Class: Volatile
Structure of Data: Scalar

Domain Element Description

NIGHT\_1 nighttime step 1, minimum nighttime mode

brightness

NIGHT\_10 nighttime step 10
NIGHT\_11 nighttime step 11

NIGHT\_12 nighttime step 12, maximum nighttime mode

brightness

NIGHT 2 nighttime step 2 NIGHT 3 nighttime step 3 nighttime step 4 NIGHT 4 nighttime step 5 NIGHT 5 NIGHT 6 nighttime step 6 nighttime step 7 NIGHT\_7 nighttime step 8 NIGHT\_8 NIGHT\_9 nighttime step 9

OFF standard backlighting is off

\_\_\_\_\_\_

Name: Customer\_Color

Description: Color X, where X is a value in the range of  $0 \rightarrow 15$  and corresponds to the customer's

selected color

Type: Discrete
Category: LIN
Initial Value: 0

Storage Class: Non-Volatile – Customer Set

Structure of Data: Scalar Units: N/A Resolution: 1 Min Value: 0 Max Value: 15

------

Name: Customer\_Intensity

Description: A value in the range of  $0 \rightarrow 0xF$  and corresponds to the customer's selected intensity.

Type: Discrete Category: LIN Initial Value: 1

Storage Class: Non-Volatile – Customer Set

Structure of Data: Scalar Units: N/A Resolution: 1 Min Value: 0 Max Value: 15

Page 163 of 175

Name: **Delay\_Accy** 

Description: Indicated if Delayed Accessory power is active

Type: Discrete Category: CAN

Initial Value:
Storage Class:
Structure of Data: NO\_EFFECT Volatile Scalar

**Domain Element Description** Domain

**OFF** ON

Name: **Dimming Lvl** 

Description: Intensity level of dimmable backlighting.

Type: Category: Initial Value: Storage Class: Structure of Data: Discrete CAN and LIN NIGHT\_12 Volatile Scalar

Domain **Domain Element Description** 

DAY\_1 daytime step 1, minimum daytime mode brightness

DAY\_2 daytime step 2 DAY\_3 daytime step 3 DAY 4 daytime step 4 daytime step 5 DAY 5

DAY 6 daytime step 6, maximum daytime mode brightness **INVALID** 

means that the BCM is not configured for Day-time

Dimmable Backlighting

NIGHT\_1 nighttime step 1, minimum nighttime mode

brightness

NIGHT 10 nighttime step 10 NIGHT 11 nighttime step 11

NIGHT 12 nighttime step 12, maximum nighttime mode

brightness

NIGHT 2 nighttime step 2 nighttime step 3 NIGHT 3 NIGHT 4 nighttime step 4 NIGHT\_5 nighttime step 5 nighttime step 6 NIGHT 6 nighttime step 7 NIGHT 7 nighttime step 8 NIGHT 8 NIGHT 9 nighttime step 9 **OFF** backlighting is off

UNKNOWN is not used. BCM never sets this to UNKNOWN.

Name: Litval

Description: An indication of ambient light level for use by modules implementing non-standard dimmable

backlighting.

Type: Discrete CAN & LIN Category: Initial Value: NIGHT Volatile Storage Class: Structure of Data: Scalar

Domain **Domain Element Description** DAY ambient light is at day level **NIGHT** ambient light is at night level TWILIGHT\_1 ambient light is at twilight 1 level TWILIGHT\_2 ambient light is at twilight 2 level TWILIGHT\_3 TWILIGHT\_4 ambient light is at twilight 3 level ambient light is at twilight 4 level

.....

Name: DrStatDrv\_B\_ActI

Description: Indicates if the driver's front door is ajar.

Type: Discrete
Category: CAN
Initial Value: CLOSED
Storage Class: Volatile
Structure of Data: Scalar

DomainDomain Element DescriptionAJARThe driver's front door is ajar.CLOSEDThe driver's front door is not ajar.

Name: DrStatPsngr\_B\_ActI

Description: Indicates if the passenger's front door is ajar.

Type: Discrete
Category: CAN
Initial Value: CLOSED
Storage Class: Volatile
Structure of Data: Scalar

DomainDomain Element DescriptionAJARthe passenger's front door is ajarCLOSEDthe passenger's front door is not ajar

------

Name: **DrStatRI\_B\_ActI** 

Description: Rear left door ajar status. Applies to the rear left door regardless of vehicle configuration.

Type: Discrete
Category: CAN
Initial Value: CLOSED
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

AJAR door is ajar CLOSED door is closed

\_\_\_\_\_\_

Name: DrStatRr B Actl

Description: Rear right door ajar status. Applies to the rear right door regardless of vehicle configuration.

Type: Discrete
Category: CAN
Initial Value: CLOSED
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

AJAR door is ajar CLOSED door is closed

.....

Name: HMI\_HMIMode\_St

Description: Multimedia system state

Type: Discrete
Category: CAN
Initial Value: OFF
Storage Class: Volatile
Structure of Data: Scalar

Domain Element Description

InvalidInvalid state (error)OffModeSync screen is OFFOnSync screen is ON

Phone Sync screen is held at Phone screen/display Climate Sync screen is held at Climate screen/display

Load\_Shed\_Active Sync is in low power/function mode

Name: Ignition\_Status

Description: The processed value for current Ignition state.

Type: Discrete
Category: CAN
Initial Value: OFF
Storage Class: Volatile
Structure of Data: Scalar

DomainDomain Element DescriptionACC- ignition is in the ACC positionOFF- ignition is in the OFF positionRUN- ignition is in the RUN positionSTART- ignition is in the START position

g.....

Name: PudLamp\_D\_Rq

Description: CAN signal to mimic the puddle lamp circuit.

Type: Discrete
Category: CAN
Initial Value: OFF
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

OFF Puddle lamp is on ON Puddle lamp is off

RAMP\_DOWN Puddle lamp is ramping down RAMP\_UP Puddle lamp is ramping up

Name: PudLampDrv\_D\_Rq

Description: CAN signal to mimic the puddle lamp circuit.

Type: Discrete
Category: CAN
Initial Value: OFF
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

OFF Puddle lamp is on ON Puddle lamp is off

RAMP\_DOWN Puddle lamp is ramping down RAMP\_UP Puddle lamp is ramping up

------

Name: PudLampPsngr\_D\_Rq

Description: CAN signal to mimic the puddle lamp circuit.

Type: Discrete
Category: CAN
Initial Value: OFF
Storage Class: Volatile
Structure of Data: Scalar

Domain Domain Element Description

OFF Puddle lamp is on ON Puddle lamp is off

RAMP\_DOWN Puddle lamp is ramping down RAMP\_UP Puddle lamp is ramping up

Name: Remote\_Start\_Status

Description: Request from FCSD remote start receiver to activate remote start.

Type: Discrete Category: LIN

Initial Value: NULL Storage Class: Volatile Structure of Data: Scalar

<u>Domain Element Description</u>

CANCEL Request to cancel remote start event

NULL No request for action made

START Request for remote start event to occur

Name: Wfsuperstate

Description: Indicates the different phases of Courtesy illumination. i.e Welcome/Farewell/Iginition Run.

Used by Exterior Lighting specific modules connected to BCM via LIN

Type: Discrete
Category: LIN
Initial Value: NULL
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

OFF Vehicle is not in any part of Welcome/Farewell

WELCOME Vehicle is in Welcome State

RUNSTART Vehicle is in Ignition Run/Start State

FAREWELL Vehicle is in Farewell State

------

Name: Wfsubstate

Description: Tell the status of BCM current welcome farewell Substate(i.e. Entry, Door, Delay, Exit,

Approach) on LIN. Used by Exterior Lighting specific modules connected to BCM via LIN

Type: Discrete
Category: LIN
Initial Value: NULL
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

NULL Vehicle is either locked or timed out of states
IllumEntry Vehicle was unlocked from outside of vehicle
IIIEXIT Vehicle ignition has transitioned to OFF

DoorAjarCourtesyLight Vehicle door(s) transitioned to Ajar

CourtesyLightDelay Vehicle door(s) transitioned from Ajar to all Closed

APPROACH Vehicle Approach was detected

Name: WelcomeFarewell\_State

Description: Indicates the different phases of Courtesy illumination. i.e Welcome/Farewell/Iginition Run.

Used by Interior Lighting specific modules connected to BCM via LIN

Type: Discrete
Category: LIN
Initial Value: NULL
Storage Class: Volatile
Structure of Data: Scalar

<u>Domain Element Description</u>

NULL Vehicle is not in any part of Welcome/Farewell

WELCOME Vehicle is in Welcome State

RUN\_START Vehicle is in Ignition Run/Start State

FAREWELL Vehicle is in Farewell State

Name: WelcomeFarewell\_Substate

Description: Tell the status of BCM current welcome farewell Substate(i.e. Entry, Door, Delay, Exit,

Approach) on LIN. Used by Interior Lighting specific modules connected to BCM via LIN

Type: Discrete
Category: LIN
Initial Value: NULL

Page 167 of 175

Storage Class: Volatile Structure of Data: Scalar

Domain **Domain Element Description** 

Vehicle is either locked or timed out of states NULL

APPROACH Vehicle Approach was detected

Vehicle door(s) transitioned from Ajar to all Closed Vehicle door(s) transitioned to Ajar **DELAY** 


DOOR Vehicle was unlocked from outside of vehicle **ENTRY** Vehicle ignition has transitioned to OFF **EXIT** 

## **8 REVISION HISTORY**

Revision Level	Name	Change Description	Date
V1.0	FEHSAN2	Initial Release	4/21/2016
V1.1	FEHSAN2	Section 3.2.2: Functional Voltage Range updated from 9 – 16V to 6 – 16V Section 6.1.2.3.1: Updated Functional Voltage Range for all CAN messages from 9 – 16v to 6 – 16V Section 6.2.2.3.1: Updated Functional Voltage Range for all CAN messages from 9 – 16v to 6 – 16V Section 5.2.1: Included "Accessory" as part of "Ignition OFF" state. Section 5.2.2: Changed "AND/OR" to "OR" Section 5.2.3: Changed "AND/OR" to "OR" Section 5.4.7.1.2: Changed Theater Dimming curve to Smooth Dimming curves and updated Default durations Section 5.4.7.3.2: Changed Theater Dimming curve to Smooth Dimming curves and updated Default durations Section 5.4.7.5.2: Changed Theater Dimming curve to Smooth Dimming curves and updated Default durations	6/8/2016
V1.2	FEHSAN2	Section 5.5.2: Updated to include state flow diagram Section 6.1.3.13.5: Updated based on section 5.5.2 update Section 6.2.3.11.5: Updated based on section 5.5.2 update	

## 9 APPENDIX


## 9.1 APPENDIX 1: Exterior Lighting PWM Signal Specification



Opera	iting Conditions: 1,2	System Voltage: 9.5 < Vsys < 16.0 volts	3			
		Ambient Temperature: -40oC < Tamb < 85oC	;			
No	Characteristic	Comment	Min	Тур	Max	Unit
1	PWM output frequency 1/P for Incandescent Bulbs	Configurable in the ECU	100	110	300	Hz
2	PWM output frequency 1/P for LED Bulbs	Configurable in the ECU	100	220	300	Hz
3	Frequency jitter	Measured via 1 second sliding window			0.1	Δ%
4	PWM rise t(r) / fall time t(f)		8		50	μs
5	PWM output duty cycle Pw/P <sup>7</sup>		0		100	%
6	PWM output duty cycle jitter	Measured via 1 second sliding window			0.1	Δ%
7	PWM output duty cycle				0.2	Δ%
	tolerance total					
8	PWM resolution	8 bit or better			1/255	
9	PWM response time message 4				21	ms
10	PWM response time voltage 5				18	ms
11	Shortage to GND detection	Duty cycle while error detection active	10		100	%
12	Shortage to Ubat or open line detection	Duty cycle while error detection active	0		90	%
13	PWM output voltage (Vpk)	Short circuit & reverse battery protected	Vsys-1.5			V
14	Ground Offset See ELCOMP requirement RQT-191001-009976 & 009989			V		

- Note 1: Specified values are valid for complete range of system voltage and ambient temperature.
- Note 2: Output values are measured at the ECU with the PWM output and related to ECU GND.
- Note 4: Time when message is complete at bus to PWM response is measured at ECU PWM output.
- Note 5: Time when voltage jump is applied to PWM response is measured at ECU PWM output.
- Note 6: Any received PWM duty cycle shall be mapped to the closed available (taking into account resolution) duty cycle in the receiving ECU.

## 9.2 APPENDIX 2: Interior Lighting PWM Signal Specification



Opera	ting Conditions: 1,2	System Voltage: 9.5 < Vsys < 16.0 volts Ambient Temperature: -40oC < Tamb < 85oC				
No	Characteristic	Comment	Min	Тур	Max	Unit
1	PWM output frequency 1/P for Incandescent Bulbs	Configurable in the ECU	100	110	300	Hz
2	PWM output frequency 1/P for LED Bulbs	Configurable in the ECU	100	220	300	Hz
3	Frequency jitter	Measured via 1 second sliding window			0.1	Δ %
4	PWM rise t(r) / fall time t(f)		8		50	μs
5	PWM output duty cycle Pw/P <sup>7</sup>		0		100	%
6	PWM output duty cycle jitter	Measured via 1 second sliding window			0.1	Δ%
7	PWM output duty cycle tolerance total				0.2	Δ %
8	PWM resolution	8 bit or better			1/255	
9	PWM response time message 4				21	ms
10	PWM response time voltage 5				18	ms
11	Shortage to GND detection	Duty cycle while error detection active	10		100	%
12	Shortage to Ubat or open line detection	Duty cycle while error detection active	0		90	%
13	PWM output voltage (Vpk)	Short circuit & reverse battery protected	Vsys-1.5			V
14	Ground Offset	See ELCOMP requirement F	RQT-191001-0	09976 & 00	9989	V

- Note 1: Specified values are valid for complete range of system voltage and ambient temperature.
- Note 2: Output values are measured at the ECU with the PWM output and related to ECU GND.
- Note 4: Time when message is complete at bus to PWM response is measured at ECU PWM output.
- Note 5: Time when voltage jump is applied to PWM response is measured at ECU PWM output.
- Note 6: Any received PWM duty cycle shall be mapped to the closed available (taking into account resolution) duty cycle in the receiving ECU.

## 9.3 APPENDIX 3: FEATURE LEVEL USE CASES

# Use Case ID Use Case Title Actors Vehicle is Locked, Approach detection is enabled, Ignition is OFF, Headlamp switch "AUTO" or "OFF" Keyfob holder approaches vehicle with functioning PK Valid PK detected within approach detection range

Post-conditions	Exterior Illumination: Fades ON over 3 seconds Interior Illumination: Stays OFF Vehicle Displays: Stay OFF
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 02.0 UNLOCK

Use Case ID	
Use Case Title	Keyfob holder unlocks vehicle
Actors	Keyfob holder
Pre-conditions	Approach was detected. Ignition is OFF, Headlamp switch "AUTO" or "OFF"
Scenario Description	Keyfob holder walks towards the vehicle Approach detected Keyfob holder unlocks vehicle using keyfob or keypad
Post-conditions	Exterior Illumination: Remains ON Interior Illumination: Stays OFF Vehicle Displays: Stay OFF
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 03.0 OPEN DOOR

Use Case ID	
Use Case Title	Keyfob holder opens vehicle door
Actors	Keyfob holder
Pre-conditions	Vehicle Unlocked, Ignition is OFF, Headlamp switch "AUTO" or "OFF"
Scenario Description	Keyfob holder opens any exterior door
Post-conditions	Exterior Illumination: Remains ON Interior Illumination: Fade ON over 3 seconds Vehicle Displays: Begin/Display Welcome Animation
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 04.0 CLOSE ALL DOORS

Use Case ID	
Use Case Title	Keyfob holder closed all vehicle door
Actors	Keyfob holder
Pre-conditions	Ignition is OFF, vehicle door(s) ajar, Headlamp switch "AUTO" or "OFF"

Scenario Description	Keyfob holder closes all vehicle doors
Post-conditions	Exterior Illumination: Remains ON Interior Illumination: Remains ON Vehicle Displays: Continue displaying Welcome Animation until complete, then enable welcome display (static)
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

# 05.0 IGN TO RUN/START

11011/01/111	
Use Case ID	
Use Case Title	Keyfob holder cycles ignition to RUN/START
Actors	Keyfob holder
Pre-conditions	Ignition is OFF, vehicle door closed, Headlamp switch "AUTO" or "OFF"
Scenario Description	Keyfob holder cycles ignition to RUN/START
Post-conditions	Exterior Illumination: Revert to legislatively required in-drive setting Interior Illumination: Revert to legislatively required in-drive setting Vehicle Displays: Revert to legislatively required in-drive setting
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 06.0 IGN TO OFF

Use Case ID	
Use Case Title	Ignition transitions from RUN to OFF
Actors	Keyfob holder
Pre-conditions	Ignition is RUN, Headlamp switch "AUTO" or "OFF", Illumination and Displays are ON
Scenario Description	Ignition transitions to OFF
Post-conditions	Exterior Illumination: Remains ON Interior Illumination: Remains ON Vehicle Displays: Remain ON (remain at previous selected screen)
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 07.0 MEDIA ACCESSORY DELAY

Use Case ID	

Use Case Title	Ignition transitions from RUN to OFF
Actors	Keyfob holder
Pre-conditions	Ignition is RUN, Headlamp switch "AUTO" or "OFF"
Scenario Description	Ignition transitions to OFF
Post-conditions	Exterior Illumination: Not impacted Interior Illumination: Not impacted Vehicle Displays: Remain ON (remain at previous selected screen)
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 08.0 OPEN DOOR

Use Case ID	
Use Case Title	Keyfob holder opens vehicle door after Ignition transitions to OFF
Actors	Keyfob holder
Pre-conditions	Ignition transitioned to OFF, vehicle doors closed, Headlamp switch "AUTO" or "OFF"
Scenario Description	Keyfob holder opens any vehicle door
Post-conditions	Exterior Illumination: Remains ON Interior Illumination: Remains ON Vehicle Displays: Begin/Display Farewell Animation. Turn OFF after Animation complete
List of Exception Use Cases	
Interfaces	
Links to Referenced Use Cases	

## 09.0 CLOSE ALL DOORS

Use Case ID	
Use Case Title	Keyfob holder closes all open vehicle doors after Ignition transitions to OFF
Actors	Keyfob holder
Pre-conditions	Ignition transitioned to OFF, vehicle door(s) open, Headlamp switch "AUTO" or "OFF"
Scenario Description	Keyfob holder closes all open vehicle doors
Post-conditions	Exterior Illumination: Remains ON Interior Illumination: Remains ON Vehicle Displays: Remains OFF
List of Exception Use Cases	
Interfaces	

s to Referenced	
Use Cases	

## 10.0 LOCK VEHICLE

Use Case ID		
Use Case Title	Keyfob holder locks vehicle after Ignition transitions to OFF	
Actors	Keyfob holder	
Pre-conditions	Ignition is OFF, vehicle doors closed, Headlamp switch "AUTO" or "OFF"	
Scenario Description	Keyfob holder locks vehicle using keyfob/keypad	
Post-conditions	Exterior Illumination: Fades OFF over 5 seconds Interior Illumination: Fades OFF over 5 seconds Vehicle Displays: Remains OFF	
List of Exception Use Cases		
Interfaces		
Links to Referenced Use Cases		