State / Substate		CAN Signals		Status	
Welcome / Farewell State VehWlcmFrwl_D_Stat	Welcome / Farewell SubState VehWlcmFrwlMde_D_Stat	PudLamp_D_Rq	DrStatDrv_B_Actl DrStatInnrTgate_B_Actl DrStatPsngr_B_Actl DrStatRI_B_Actl DrStatRr_B_Actl	Initialization	Welcome / Farewell aHUD light
WELCOME	APPROACH	OFF/Ramp_down	Ajar	YES	OFF
WELCOME	APPROACH	OFF/Ramp_down	Closed	NO	OFF
WELCOME	ILLUMINATEDENTRY	OFF/Ramp_down	Ajar	YES	OFF
WELCOME	ILLUMINATEDENTRY	OFF/Ramp_down	Closed	NO	OFF
WELCOME	COURTESYLIGHTNGALL	OFF/Ramp_down	Ajar	YES	OFF
WELCOME	COURTESYLIGHTNGALL	OFF/Ramp_down	Closed	NO	OFF
WELCOME	COURTESYLIGHTNGDELAYALL	OFF/Ramp_down	Ajar	YES	OFF
WELCOME	COURTESYLIGHTNGDELAYALL	OFF/Ramp_down	Closed	NO	OFF
WELCOME	COURTESYLIGHTNGEXTENDED	OFF/Ramp_down	Ajar	YES	OFF
WELCOME	COURTESYLIGHTNGEXTENDED	OFF/Ramp_down	Closed	NO	OFF
WELCOME	COURTESYLIGHTINGDELAYEXT	OFF/Ramp_down	Ajar	YES	OFF
WELCOME	COURTESYLIGHTINGDELAYEXT	OFF/Ramp_down	Closed	NO	OFF
WELCOME	NULL	OFF/Ramp_down	Closed	NO	OFF
RUNSTART	Don't care	ON / Ramp_up	Don't care	YES	ON
FAREWELL	ILLUMINATEDEXIT	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	ILLUMINATEDEXIT	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTINGALL	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTINGALL	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTINGEXTENDED	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTINGEXTENDED	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTNGDELAYALL	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTNGDELAYALL	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTINGDELAYEXT	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	COURTESYLIGHTINGDELAYEXT	OFF/Ramp_down	Don't care	NO	OFF
FAREWELL	NULL	OFF/Ramp_down	Don't care	NO	OFF
NULL	NULL	OFF/Ramp_down	Don't care	NO	OFF