"Powered by Neve" Custom 75 Workflow

- 1. To Tape/ from Tape Signal flow
- 2. Headphones and communication
- 3. Inserts in Mix Mode
- 4. Group Inserts and parallel processing
- 5. Send and return routing for FX
- 6. Re- recording Main Mix

1. To Tape/ from Tape Signal flow

- Mic in Channel 25 crosspatched to Channel 9:
 - ✓ Mic/Line 25 → Mic Input 9 (Set Gain/48V on Channel 9 in Mic Mode)
- Set Channel Path Fader to unity, → Main Mix: Set Fader all the way up (retro/ modern circuitry can be schwitched:)
 - ✓ Turn up speakers to to check for Signal
- Protools: Create new Track with corresponding I/O (9/9)
 - **✓** Set <u>Input Monitoring/ Rec ready</u>, visually check for Levels in Protools
- Select Channel 9 and take it OFF Main Mix in Center Section for monitoring post Tape
 - ✔ Check Main Mix for "no" signal
- Switch to Monitor Mix in Mon Source Section
- Turn up Monitor Path in Channel (FADER SWAP????)
 - **✓** Test if post Tape by moving Fader in Protools
- Set Monitor → Mains switch to send Monitors to Main Mix for eg. Overdub Situation:
 - ✓ Monitor currently recording Signals via Monitor Path after taking the Channel off the Main Mix and sending Mon → Main and switching to Monitor Mix
 - **✓** Monitor Signals from Tape via Channel Path
- Set DAW Channels up to monitor Tape signal via Channel Path

2. Headphones and communication

- HP Mix: Go to HP 1 (Aux) in Mon Source Section then select AUX A as Source for HP1:
- Turn Aux A Master to Unity
- Turn on Aux A on Recording Channel, select Source: Pre Fader Monitor
- Send Tape Signal Pre Fader Channel and pan
- Turn up HP Output and set Level/Balance
- Talkback: Cue → both HPs

3. Inserts in Mix Mode

- Mon → Mains OFF
- Swap Channel Inputs to DAW globally from Channel Mode Section
 - **✓** Monitor Retro or Modern Path
 - ✓ Turn Panning on
- EQ In
- Insert external FX via Insert Send/ Returns

4. Group Inserts and parallel processing

- Send Tracks to Groups:
 - **✓** Select Tracks and take them OFF Main Mix
 - ✓ Send to Group eg.1/2
 - ✓ Turn Group Trims all the way up and pan, Faders up
- Insert FX on Group:
 - **✓** Bus Insert/ Send to and from FX eg Comp.
 - ✓ Engage Insert for Group: Labelled "DAW"
- Parallel Processing
 - **✓** Reassign Channels back to Main Mix
 - ✓ Fade in Group (Mute via ,"DAW" Button)

5. Send and return routing for FX

- Solo Track to be sent:
 - ✓ Turn up corresponding Aux Master
 - ✓ Turn on Aux (Mono for Dly/Vrb) in Channel
 - ✓ Send Aux Post Fader Channel
 - **∨** Patch Aux Send 1 → eg Fx Unit Input L
 - **✓** Return Stereo either:
 - ➤ Reverb Returns: If all Channels are used or for <u>Tracking</u> FX
 - Reverb Return 1: Turn up and Assign to Main Mix
 - (can be sent to HP for HP Mix Reverb without it in the Main Mix)
 - ➤ Or New Channel: Patch to Line Input of new Channel(s)

6. Re- recording Main Mix

- Create new Audio Track in Protools, engage Input Monitoring (rerecording Mix Bus)
- Choose Modern/ Retro/ Both?? Output → Interface Input (Protools)
 - ✓ Turn Master Fader down to check connection to Protools
- Post Tape Monitoring:
 - **✔** Patch corresponding Interface Output → External Input: 2 Track Monitoring
 - **✓** Monitor Source Section: 2T1
 - Check Protools if connection is working