Capacitive scale (passive)

File: scale.kicad_sch

PrettyCool Caliper capacitive scale -- generated by caliper/hardware/design/build.py from caliper/hardware/design/sheets/scale.py. Do not hand-edit.

PrettyCool Boards


Sheet: /
File: prettycool-caliper-scale.kicad_sch

Title: PrettyCool Caliper capacitive scale

Size: A3	Date: 2026-11-07	**Rev: A**
KiCad E.D.A. 10.0.8		Id: 1/2


Mounting (plated M2, back-copper ground)

One hole at each end, clear of the 150 mm measuring range. The pads tie the back ground plane to the beam through the screws, so the scale's reference is the beam potential, as the slider's guard ground is.



Fiducials

One per end (front side), for the reflector-pattern inspection and any later assembly



Power flag

GND has no driver on a passive board



PrettyCool Boards

Sheet: /Capacitive scale (passive)/
File: scale.kicad_sch

Title: Capacitive scale (passive)

Size: A3	Date: 2026-11-07	**Rev: A**
KiCad E.D.A. 10.0.8		Id: 2/2