

Method Statement

Project: Riverside Residential Complex (Phase 1)

Scope: Excavation, Foundation, and Drainage.

Objective

To safely execute the groundworks and foundation phase of the residential blocks according to structural specifications.

Health & Safety

- **PPE:** Hard hats, high-visibility vests, steel-toe boots, and gloves are mandatory.
- **Exclusion Zones:** Physical barriers and signage will be placed around open excavations.
- **Permits:** A "Permit to Dig" must be signed off daily after checking utility maps.

Procedure

1. **Site Setup:** Install hoarding, welfare facilities, and temporary power/water.
2. **Excavation:** Use a 20-tonne tracked excavator to remove topsoil and dig to the specified depth (1.5m typical for strip foundations).
3. **Support:** Install trench sheets where ground stability is compromised.
4. **Concrete Pour:** Pour C35 grade concrete for the footings. Reinforcement steel (rebar) to be inspected by the structural engineer prior to pouring.
5. **Blockwork:** Construct the substructure blockwork up to the DPC (Damp Proof Course) level.
6. **Backfilling:** Infill with Type 1 MOT sub-base and compact in 150mm layers using a vibrating plate.