

Drinking Water Purification System with Field Serviceable Pump, Float & Prefilter

INSTRUCTIONS

Keep with your First Need xL Purification System

EASY TO USE


- No chemicals required.
- No boiling.
- · No brushing.


FEATURES

- With pumping, provides 2.0 quarts of purified water per minute. Avg. capacity of 150 gallons (varies with source water).
- With gravity flow, "Matrix Pumping™" provides purified water with no pumping.
- Prevents exposure to Giardia and Cryptosporidia.

Flow Rate = 2 qts. per min.

Micron Retention = 0.1 nominal





BREAK Palm Shaped Connector Handle **Tubing** (1) Pull retaining pin out. Pump Body (2) Lift connector tube from canister, Slide pump body Bracket ifirst ne Retaining (3) Slide bracket down. Ring (4) Unscrew pump barrel. Pump Barrel Canister -Direct Connect™ Outlet Sanitary Cover Easy access to Seals, lube annually with petroleum jelly Adjustable Float П Long, non-kink hose Prefilter

Weight = 16 oz.

Capacity = 150 gallons

(varies with source water)

800-441-8166 EST M-F (for retail orders) 24 hr. Fax (610)-363-0412 e-mail: info@generalecology.com www.generalecology.com

GENERAL ECOLOGY® PURIFIERS

CALL 800-441-8166 EST M-F





SEAGULL®IV X-1F

First Need® Base Camp™

Add purity to your life...for more information about SEAGULL®IV X-1F point-of-use drinking water purifiers and other General Ecology® products please contact:

General Ecology, Inc.

the pure science of safe water




151 Sheree Blvd., Exton, Pennsylvania 19341 USA

Technical Questions (610)-363-7900

EPA. EST. REG. NO. 37403-PA-01 ©2007 - TM trademarks of General Ecology, Inc.

BACKWASH INSTRUCTIONS



Backwash - During trip to clean or unclog:


1. Pump purified water <u>slowly</u> backward through canister as shown. Excessive force may break the canister internally.

Backwash - Pre-storage clean:

- 1. Add 5 drops of household bleach to one quart of purified water.
- 2. Pump this water <u>slowly</u> backward through canister as shown.
- Air dry—store in a clean, dry area away from fumes.

HANDS FREE PUMPING MATRIX PUMPING To replace plastic liner make small hole in a corner of any suitable plastic bag. Maximize Distance Pump to start flow. Purified water will continue to flow on its own after all air is expelled from line. "Matrix Pumping" works even with a clogged canister.

INTEGRITY TEST PROCEDURE



"Blue Dye" test:

Pump colored water through canister as shown. If the purified water is still colored, even faintly, the internal canister matrix has most likely been damaged and **The Canister Can Not Be Relied Upon Under This Condition And Must Be Replaced.***

*NOTE: Because the initial flow from a new purification canister may contain black "fines" from the manufacturing process it is best to pump at least a quart of water before doing an integrity test to avoid possible confusion.

STORAGE



- Pump unit as dry as possible to expel loose water before storage.
- 2. Replace sanitary cover.
- 3. Entire unit can be stored in nylon bag.
- Do not store inside "Matrix Pumping" clear plastic bag.
- For long term storage, see backwash instructions for cleaning before storage.

HELPFUL TIPS FOR OPTIMUM USE

.....................

- 1. Remember to perform "blue dye" test before each trip and check that pump is in working order.
- 2. Use the cleanest water source available.
- 3. If pumping becomes difficult, backwash or replace canister.
- 4. Remember "Matrix Pumping" works even with a clogged canister.
- 5. Avoid freezing or high shock loads perform integrity test procedure if canister freezes or receives a shock.
- 6. Store in a clean, dry area away from fumes.
- Questions or replacements contact us at 800-441-8166 or www.generalecology.com